

BODY AND TRIM

SECTION **BT**

GI
EM
LC
EC

FE

CONTENTS

PRECAUTIONS	COWL TOP COVER	RS
Precautions	Removal • Installation	23
WINDSHIELD GLASS • WINDSHIELD MOLDING	FENDER PROTECTOR	AC
Removal • Installation	Removal • Installation	24
REAR WINDOW GLASS • REAR WINDOW MOLDING	WINDSHIELD MOLDING	AV
Removal • Installation	Removal • Installation	25
FRONT DOOR GLASS AND REGULATOR	DOOR OUTSIDE MOLDING	
Removal • Installation	Removal • Installation	26
REAR DOOR GLASS AND REGULATOR	SIDE GUARD MOLDING	CL
Removal • Installation	Removal • Installation	27
DOOR MIRROR	FRONT BUMPER COVER	MT
Removal • Installation	Removal • Installation	28
Disassembly • Assembly		
INSIDE MIRROR	HEADLAMP/TURN SIGNAL LAMP	AT
Removal • Installation	Removal • Installation	29
FRONT BUMPER	REAR COMBINATION/REAR FOG LAMP	FA
Removal • Installation	Removal • Installation	30
REAR BUMPER	REAR MUD GUARD	RA
Removal • Installation	Removal • Installation	31
FRONT GRILLE	DOOR TRIM	BR
Removal • Installation	Removal • Installation	32
	BODY SIDE TRIM	
	Removal • Installation	34

ST

BT

CONTENTS

REAR PARTIAL SELF FINISHER	
Removal • Installation	35
FLOOR TRIM	
Removal • Installation	36
HEAD LINING	
Removal • Installation	37
TRUNK TRIM AND TRUNK LID TRIM	
Removal • Installation	39
INSTRUMENT ASSEMBLY	
Components Diagram.....	40
Removal • Installation	41
Disassembly • Assembly.....	46
FRONT SEAT	
Components Diagram.....	47
Removal • Installation of Front Seat Assembly...	48
Disassembly • Assembly of Seatback	49
REAR SEAT	
Removal • Installation	52
HOOD	
Assembly Dimension Adjustment.....	53
Removal • Installation of Hood Assembly	54
Removal • Installation of Hood Lock Control	55
Hood Lock Control Inspection	56
DOOR	
Door Assembly Dimension Adjustment.....	57
Removal • Installation	58
FRONT DOOR LOCK	
Components Diagram.....	59
Removal • Installation	59
Disassembly • Assembly.....	61
REAR DOOR LOCK	
Components Diagram.....	62
Removal • Installation	62
TRUNK LID	
Assembly Dimension Adjustment.....	64
Removal • Installation of Trunk Lid Assembly	65
Removal • Installation of Torsion Bar	66
Removal • Installation of Trunk Lid Welt Strip	67
TRUNK LID & FUEL FILLER LID OPENER	
Components Location	68
BODY ALIGNMENT	
Description	69
Engine Compartment.....	70
Underbody	72
Passenger Compartment	74
Rear Body	76

PRECAUTIONS

Precautions

Precautions for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"

The Supplemental Restraint System such as "AIR BAG" and "SEAT BELT PRE-TENSIONER", used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. Information necessary to service the system safely is included in the RS section of this Service Manual.

WARNING:

- To install/remove the SRS airbag, pretensioner seatbelt system related components and harness, turn the ignition switch "OFF", disconnect the battery terminals and wait over 3 minutes. (This is to discharge all the remaining electricity in the airbag sensor unit's auxiliary power circuit.) LC
- Do not use air impact or electrical tools when installing/removing the components. EC
- Do not use any hand-held tools for harness used in SRS airbag and pretensioner seatbelt systems. Be careful with the harness not to tangle with or interfere with other components.
- Do not use any electrical test equipments such as circuit tester when inspecting the SRS airbag and pretensioner seatbelt circuit while installed unless the Service Manual instructs to do so. (The weak current in the tester can cause the SRS airbag to operate.) FE
- Do not insert any foreign materials such as a screwdriver in the airbag module and pretensioner seatbelt connector in order to prevent unintended operation due to static electricity. RS
- The harnesses used in SRS airbag and pretensioner are covered with yellow insulation for easy identification. AC
- Refer to "RS Restraint System" in this Service Manual for safe airbag system service information. AV

Sealant and Primer Handling

- Use the sealant less than 6 months from the manufacturing date.
- Store the primer and sealant in cool and shaded area. EL
- Open the primer and sealant container right before using it. Do not reuse the remaining. WH
- Always shake the primer container before using it. Do not use it if foreign particles are floating on.
- If primer or sealant touches the skin, quickly wipe out with white gasoline and clean with soap.
- In addition to above cautions, always follow the instructions on the container. CL

Caution in Service

- Be careful not to damage or deform the components during removal and disassembly. Protect the components that interfere with the other components in service with cloth. MT
- Protect the components by covering with a cloth or vinyl tape when removing the components using a screwdriver (When removing the components that are engaged each other). AT
- Store the removed components safely with a cloth. FA
- Replace the clip if deformed or damaged. RA
- For the components that are not allowed reuse, always replace them with new if removed.
- Tighten the bolts and nuts to the specified torque.
- After assembling, check if every component operates properly.
- Remove the dirt as follows:
 - If watersoluble: Clean the polluted area with cloth dampened in warm water and wipe out with a soft dry cloth.
 - If oilsoluble: Clean the polluted area with cloth dampened in warm water with mild soap (2 - 3 % of concentration). Remove the soap with cloth dampened in clean water and then wipe out with a soft dry cloth.BR
- Do not use any organic detergent such as thinner, benzene, alcohol and gasoline. ST


PRECAUTIONS

MEMO:

WINDSHIELD GLASS • WINDSHIELD MOLDING

Windshield Glass • Windshield Molding


Removal • Installation




GI
EM
LC
EC
FE
RS
AC

REMOVAL

1. Remove the front pillar garnish and head lining front end. AV
2. Remove the front pillar weatherstrip. EL
3. Remove the windshield side molding. WH
4. Remove the cowl top cover. CL
5. Put the protector tape around the windshield glass to prevent from scratching the body surface. MT
6. Cut the molding surface using a cutter knife following the glass line. AT



FA





RA
BR
ST
BT

7. Pull out and completely remove the molding remaining at the body flange using pliers.
 - When reusing the windshield glass, put an alignment mark on the body and the glass.RA
8. Cut the sealant.
 - Perform as below according to using tools.BR

CAUTION:

- When reusing the windshield glass, do not use the windshield knife. (Glass may be damaged.)
- ST

WINDSHIELD GLASS • WINDSHIELD MOLDING




- a. When using the windshield knife (When replacing the glass)
- Apply some soap solution on the body side sealant for easy windshield knife operation.
 - Insert the windshield knife into the sealant and adjust the knife parallel to the glass and cut the sealant by pulling the knife.


- b. When using the piano cord (When reusing the glass)
- Perforate a hole using a gimlet or cutter to the glass sealant from the inside of the vehicle.
 - Insert the piano cord into the hole from the inside of the vehicle and connect the both cord ends with screwdrivers.
 - By pulling the both ends of the piano cord (one inside and one outside of the vehicle), cut the sealant following the glass line.

CAUTION:

- **Strongly contact the piano cord onto the glass edge.**
- **Insert copper plates to prevent the piano cord from touching the instrument panel.**



9. Using the glass holder (commercial tool), remove the glass from the vehicle.




INSTALLATION

1. Cut the remaining sealant evenly leaving the 2 mm thickness using a knife.

CAUTION:

- **When the body side is damaged, always repair with 2-fluid type urethane paint. Do not use the lacquer paint.**

WINDSHIELD GLASS • WINDSHIELD MOLDING



2. Put the clip to the clip holes on the vehicle.
3. For new glass installation, place the glass onto the vehicle, mark the alignment marks on the body and the glass and remove the glass again.
4. For the reused glass, cut the remainder evenly with a knife.
5. Wipe out the glass's sealant surfaces and upper molding installation surface with white gasoline.

GI


EM

LC

EC

FE

RS



6. Stick the dam rubber on the glass as shown in the illustration by centering center below point.
7. Apply the primer.

REFERENCE:

- The primer is very important since it strengthens the sealing effect between the glass and the body surface.

RS

CAUTION:

- There are 2 types of primers. Be careful not to confuse AC between the two.

AC

Primer M: For body surface.


Primer G: For glass.

- Apply the primer G around the glass following the instructions.

EL

WH

CL



8. Apply the primer M on the vehicle surface.

CAUTION:


- When primer M stains on the body surface besides the sealant surface, quickly wipe it out with white gasoline.
- Insert copper plates to prevent the primer M from touching the instrument panel.

MT

AT

FA

RA




9. Apply the primer and apply the sealant around the glass within the instructed time on the user's guide.
 - Cut the sealant nozzle end and open it. Then apply with a sealant gun.
10. Install the glass holder (commercial tool) to the glass and install the glass to the vehicle by mating the alignment marks on the body and the glass.
11. Press the glass lightly and completely seat the glass.
12. Make the glass even by removing the slipped out sealant or adding sealant where lacks.

BR

ST

BT

WINDSHIELD GLASS • WINDSHIELD MOLDING



13. Determine the upper molding position and insert and fix the bottom of the molding to the glass.

CAUTION:


- Perform the windshield molding installation before the sealant hardens.
- Leave the door glass open until the sealant hardens after installing the glass. Do not drive.

14. Inspect for any water leakage.
15. Remove the protector tape.
16. Install the removed components.

REAR WINDOW GLASS • REAR WINDOW MOLDING

Rear Window Glass • Rear Window Molding

Removal • Installation




GI
EM
LC
EC
FE
RS
AC

REMOVAL

1. Remove the rear part of the head lining.
2. Remove the rear pillar garnish and rear partial self finisher.
3. Remove the rear defogger and glass antenna connector.
4. Put the protector tape around the rear window glass (molding) not to scratch the body surface.

AV
EL
WH



CL
MT
AT
FA
RA

5. Cut the rear window molding using a cutter knife following the glass line.
6. Pull out and completely remove the molding remaining at the body flange.
 - When reusing the rear window glass, put an alignment marks on the body and the glass.


BR

7. Cut the sealant.
 - Cut the 2 upper clips with sealant.
 - Perform as below according to using tools.


ST
BT

CAUTION:


- When reusing the rear window glass, do not use the windshield knife. (Glass may be damaged.)



REAR WINDOW GLASS AND REAR WINDOW MOLDING




- a. When using the windshield knife (When replacing the glass)
 - i. Apply some soap solution on the body side sealant for easy windshield knife operation.
 - ii. Insert the windshield knife into the sealant and adjust the knife parallel to the glass and cut the sealant by pulling the knife.




- b. When using the piano cord (When reusing the glass)
 - i. Perforate a hole using a gimlet or cutter to the glass sealant from the inside of the vehicle.
 - ii. Insert the piano cord into the hole from the inside of the vehicle and connect the both cord ends with screwdrivers.
 - iii. By pulling the both ends of the piano cord (one inside and one outside of the vehicle), cut the sealant following the glass line.

CAUTION:

- **Strongly contact the piano cord onto the glass edge.**
- **Insert copper plates to prevent the piano cord from touching the instrument panel.**



- 8. Using the glass holder (commercial tool), remove the glass from the vehicle.




INSTALLATION

1. Cut the remaining sealant evenly leaving the 2 mm thickness using a knife.

CAUTION:


- **When the body side is damaged, always repair with 2-fluid type urethane paint. Do not use the lacquer paint.**
- 2. For the reused glass, cut the remainder evenly with a knife.
- 3. Wipe out the glass's sealant surfaces and surroundings with white gasoline.

REAR WINDOW GLASS AND REAR WINDOW MOLDING



- Stick the dam rubber on the glass sides as shown in the illustration by centering center upper point.
- Install the rear window molding to the rear window glass and fix the glass by pressing the glass with a bamboo piece.

GI



- Apply the primer.

EM

REFERENCE:

- The primer is very important since it strengthens the sealing effect between the glass and the body surface.

FE

CAUTION:

- There are 2 types of primers. Be careful not to confuse between the two.

RS

Primer M: For body surface.

Primer G: For glass.

AC

- Apply the primer G around the glass following the instructions.


- Apply the primer M on the vehicle surface.

AV


CAUTION:

- When primer M stains on the body surface besides the sealant surface, quickly wipe it out with white gasoline.

EL



WH



- Apply the primer and apply the sealant around the glass within the instructed time on the user's guide.

MT

- Cut the sealant nozzle end and open it. Then apply with a sealant gun.

- Install the glass holder (commercial tool) to the glass and install the glass to the vehicle by mating the upper clip (2 EA) to the body holes. When reusing the glass, install the glass to the vehicle by mating the alignment marks on the body and the glass.

AT

- Press the glass lightly and completely seat the glass.
- Make the glass even by removing the slipped out sealant or adding sealant where lacks.

FA

- CAUTION:**
- Leave the door glass open until the sealant hardens after installing the glass. Do not drive.

ST

- Inspect for any water leakage.

BT


- Remove the protector tape.

- Install the removed components.


FRONT DOOR GLASS AND REGULATOR

Front Door Glass and Regulator

Removal • Installation




PIIA0029J_D1




1. Remove the front door finisher.
2. Remove the sealing screen.

REFERENCE:

- When reusing the sealing screen, cut the butyl tape with a cutter so that the butyl tape remains on the sealing screen.
3. Operate the power window main switch and adjust the door glass until can see the carrier plate mounting bolt.
 4. Remove the carrier plate mounting bolt.
 5. Remove the door glass by lifting from the rear end and pulling out towards outside from the chassis.



FRONT DOOR GLASS AND REGULATOR



6. Disconnect the regulator assembly connector.
7. Remove the regulator assembly and guide rail mounting bolts and pull out through the operation hole.
Installation is in the reverse order of removal.

GI

EM


LC

EC

FE

RS

AC



INSPECTION AFTER REMOVAL

Inspect the regulator assembly for the below items and replace or lubricate if defective.

- Wire wear.
- Regulator deformation.
- Lubrication condition on major moving parts.
The arrow in the illustration shows the lubrication points.

ASSEMBLING DIMENSION INSPECTION

- Check if the glass is securely installed into the glass run groove.
- Check for proper operation by moving the glass up and down.

EL

WH

CL

MT

AT

FA

RA

BR


ST

BT


REAR DOOR GLASS AND REGULATOR

Rear Door Glass and Regulator

Removal • Installation



PIIA0030J_D1




1. Remove the door outside molding.
2. Remove the rear door finisher.
3. Remove the sealing screen.

REFERENCE:


- When reusing the sealing screen, cut the butyl tape with a cutter so that the butyl tape remains on the sealing screen.
4. Remove the mounting bolts and remove the lower chassis rear towards the bottom.
 5. Operate the power window main switch and adjust the door glass until can see the main channel mounting bolts.
 6. Remove the main channel mounting bolts.

REAR DOOR GLASS AND REGULATOR




7. Lower the door glass to its bottom and remove the glass from the partition chassis's glass run.
8. Insert the glass in the gap between the partition chassis and door outer panel and remove the glass towards the outside of the door.


9. Disconnect the regulator assembly connector. **EM**



10. Remove the regulator assembly mounting bolts and remove it through the operation hole. **EC**



11. Remove the glass run partition chassis.
12. Remove the partition chassis mounting bolts (lower section) and screws (upper section). **AV**



13. Remove the partition glass.
Installation is in the reverse order of removal. **MT**

AT

FA


RA

BR

ST

BT

REAR DOOR GLASS AND REGULATOR



INSPECTION AFTER REMOVAL

- Inspect the regulator assembly for the below items and replace or lubricate if defective.
 - Gear wear
 - Regulator deformation
 - Spring damage
 - Lubrication condition on major moving parts
- The arrow in the illustration shows the lubrication points.


ASSEMBLING DIMENSION INSPECTION

- Check if the glass is securely installed into the glass run groove.
- Check for proper operation by moving the glass up and down.

DOOR MIRROR

Door Mirror

Removal • Installation




CAUTION:


- Be careful not to damage the mirror assembly.

1. Remove the corner cover (Remove it from the upper clip section).
 2. Disconnect the door mirror harness connector.
 3. Remove the door mirror mounting nuts and remove the door mirror assembly.
- Installation is in the reverse order of removal.

Disassembly • Assembly



DOOR MIRROR




DISASSEMBLY

1. Fold up mirror.
2. Put a protective tape around the mirror body.
3. Insert a small minus (-) screwdriver into the gap between the mirror (mirror holder) and mirror holder bracket as in the illustration. Remove the bottom of the mirror holder by pressing and lifting up the mirror holder mounts (2 points).

CAUTION:

- When pressing and lifting the mount, do not lift just one location too much. Always lift up 2 locations.



ASSEMBLY

1. Position the mirror holder bracket and mirror body assembly (actuator) horizontal.
2. Install the mirror to the mirror holder bracket by facing the upper part of the mirror mounts forwards and press in the lower part of the mirror until clicks to install.


CAUTION:

- Check the lower part of the mirror after assembly and make sure that the lower mount (2 locations) is securely installed.

INSIDE MIRROR

Inside Mirror

Removal • Installation



REMOVAL

Push "D" area to removal direction.


INSTALLATION

Install the inside mirror to the windshield bracket placing it vertically to the base surface "B" and assemble the inside mirror by rotating it 90° to the assembling direction with the force "F" (less than 147 N).

FRONT BUMPER

Front Bumper

Removal • Installation



Tightening torque

Unit: N·m (kgf·m)

NOMINAL	PITCH	AREA	4T		7T	
			STANDARD	MAXIMUM	STANDARD	MAXIMUM
M5	0.8	14.2	2.94 (0.30)	3.82 (0.39)	5.001 (0.51)	6.37 (0.65)
M6	1.0	20.1	5.10 (0.52)	6.37 (0.66)	8.43 (0.86)	10.8 (1.1)
M8	1.25	36.6	12.7 (1.3)	15.7 (1.6)	20.6 (2.1)	26.5 (2.7)
	1.0	39.2	12.7 (1.3)	16.7 (1.7)	21.6 (2.2)	28.4 (2.9)
M10	1.5	58.0	24.5 (2.5)	31.1 (3.2)	41.2 (4.2)	52.0 (5.3)
	1.25	61.2	25.5 (2.6)	32.4 (3.3)	43.1 (4.4)	54.9 (5.6)


PIIB8642E

- ① Front fender (LH)
- ② Front fender (RH)
- ③ Bolts (8 EA)
- ④ Front bumper stay (LH)
- ⑤ Front bumper stay (RH)
- ⑥ Front bumper beam
- ⑦ Nuts (4 EA)
- ⑧ Front bumper energy absorber
- ⑨ Nuts (4 EA)
- ⑩ Front bumper bracket (LH)
- ⑪ Front bumper bracket (RH)
- ⑫ Clips (2 EA)
- ⑬ Radiator grille
- ⑭ Rivets (4 EA)
- ⑮ Front bumper side bracket (LH)
- ⑯ Front bumper side bracket (RH)
- ⑰ Screw grommets (2 EA)
- ⑱ Screws (4 EA)
- ⑲ Front fascia low grille
- ⑳ Nuts (6 EA)
- ㉑ Front bumper fascia
- ㉒ Fog lamp (LH)
- ㉓ Fog lamp (RH)
- ㉔ License plate
- ㉕ Screws (2 EA)

REAR BUMPER

Rear Bumper

Removal • Installation



\bullet : N·m {kgf·m}

SNRZ003_D1

GI
EM
LC
EC
FE
RS
AC
AV
EL
WH
CL
MT

- | | | |
|------------------------------------|------------------------------------|----------------------|
| ① Long bolt | ⑩ Rear bumper energy absorber (RH) | ⑯ Trim clips (6 EA) |
| ② Nuts (2 EA) | ⑪ Clip pushes (2 EA) | ⑰ License plate |
| ③ Bolts (2 EA) | ⑫ Rear bumper closing (LH) | ⑯ Clips (4 EA) |
| ④ Rear bumper stay (LH) | ⑬ Rear bumper closing (RH) | ⑯ Screws (2 EA) |
| ⑤ Rear bumper stay (RH) | ⑭ Screw grommets (2 EA) | ⑯ Screws (2 EA) |
| ⑥ Bolts (8 EA) | ⑮ Screws (2 EA) | ⑯ Screws (2 EA) |
| ⑦ Rear bumper beam | ⑯ Rear bumper side bracket (LH) | ⑯ Rear bumper fascia |
| ⑧ Nuts (4 EA) | ⑰ Rear bumper side bracket (RH) | ⑯ Spring nut (1 EA) |
| ⑨ Rear bumper energy absorber (LH) | | |


AT
FA
RA
BR

ST
BT

FRONT GRILLE

Front Grille

Removal • Installation



PIIB8643E

① Clips (2 EA)

② Tap screws (4 EA)

③ Radiator grille assembly

④ Screw grommets (4 EA)


⑤ Radiator core support

⑥ Front bumper fascia

COWL TOP COVER

Cowl Top Cover

Removal • Installation



PIIA0004J_E1

- ① Cowl top seal rubber
- ② Cowl top cover
- ③ Clips (8 EA)

- ④ Clips (2 EA)
- ⑤ Screw (1 EA)


ACCOMPANYING WORKS

- Wiper arm removal/installation.
- Windshield side molding removal/installation.

FENDER PROTECTOR

Fender Protector

Removal • Installation



: N·m {kgf·m}


SNRZ005_D1

- | | | |
|---------------------|----------------------|------------------------------|
| ① Front fender | ⑥ Screws (R/L: 2 EA) | ⑩ Front mud guard |
| ② Bumper fascia | ⑦ Clips (R/L: 6 EA) | ⑪ Protector chipping |
| ③ Clips (R/L: 2 EA) | ⑧ Clips (R/L: 2 EA) | ⑫ Screw grommets (R/L: 3 EA) |
| ④ Underside cover | ⑨ Screws (R/L: 3 EA) | ⑬ Dash side |
| ⑤ Fender protector | | |

WINDSHIELD MOLDING

Windshield Molding

Removal • Installation



(Accompanying work)

- Weather strip removal/installation (at windshield molding)

AV

CAUTION:

- The windshield upper molding removal and installation is included in windshield glass assembly.

EL

WH

CL

MT

AT

FA

RA

BR


ST

BT

DOOR OUTSIDE MOLDING

Door Outside Molding


Removal • Installation



SIDE GUARD MOLDING

Side Guard Molding

Removal • Installation




GI
EM
LC
EC
FE
RS
AC
AV
EL

WH
CL
MT
AT
FA
RA
BR
ST
BT

FRONT BUMPER COVER

Front Bumper Cover

Removal • Installation



: N·m {kgf·m}

SNRZ006_D1


- ① Front bumper fascia
- ② Clips (5 EA)
- ③ Screws (4 EA)

- ④ Front bumper cover
- ⑤ Radiator core support

HEADLAMP/TURN SIGNAL LAMP

Headlamp/Turn Signal Lamp

Removal • Installation



① Nuts (3 EA)

② Front fender tape

③ Turn signal lamp assembly

④ Grommet (1 EA)

⑤ Headlamp assembly


⑥ Screws (3 EA)

GI
EM
LC
EC
FE
RS
AC
AV
EL
WH
CL
MT
AT
FA
RA
BR
ST
BT

REAR COMBINATION/REAR FOG LAMP

Rear Combination/Rear Fog Lamp

Removal • Installation



SNRZ008_D1

- ① Nuts (4 EA)
- ② Nuts (2 EA)
- ③ Rear fog lamp bracket


- ④ Grommet (1 EA)
- ⑤ Rear combination lamp assembly
- ⑥ Rear fog lamp assembly (for export)

- ⑦ Trim clip
- ⑧ Screws (2 EA)
- ⑨ License plate assembly

REAR MUD GUARD

Rear Mud Guard

Removal • Installation



SNRZ009_D1

- ① Rear bumper closing
- ② Trim clips (2 EA)
- ③ Spring nuts (3 EA)

- ④ Tap screws (3 EA)
- ⑤ Rear mud guard
- ⑥ Rear bumper fascia


- ⑦ Air draft assembly
- ⑧ Rear fender

GI
EM
LC
EC
FE
RS
AC
AV
EL
WH
CL
MT
AT
FA
RA
BR
ST
BT

DOOR TRIM

Door Trim


Removal • Installation



SIIA0051J_D1


FRONT AND REAR

1. Remove the armrest.




SIIA0009J_D1

DOOR TRIM




2. Remove the power window switch finisher by holding and lifting up the rear end. Disconnect the power window switch connector.

GI



3. Insert a cloth protected minus (-) screwdriver into the gap at the center bottom of the inside handle escutcheon and remove it by disconnecting the 6 connection mounts.

EC



4. Remove the door finisher mounting screws (front door), clip and the bolt.

AV

5. Insert the hand into the door finisher lower opening, pull out and remove the clip.


EL

6. Remove the door finisher by pulling upwards.

WH

Installation is in the reverse order of removal.

CL



REFERENCE:

- Insert the clip driver or clip clamping tool into the arrow location (between the body panel and clip) and remove the finisher.

MT

CAUTION:

- During finisher installation, check if the clip is securely inserted into the body panel holes. Then push it in.

AT

FA

RA

BR


ST

BT

BODY SIDE TRIM

Body Side Trim

Removal • Installation



SIIA0016J_D1

CENTER PILLAR LOWER GARNISH


- Front and rear kicking plate inner removal/installation.

CENTER PILLAR UPPER GARNISH

- Seatbelt shoulder anchor removal/installation.
- Front and rear kicking plate inner and center pillar lower garnish removal/installation.

REAR PILLAR FINISHER

- Rear seat removal/installation.



REAR SEATBACK FINISHER

- Rear seat and rear pillar finisher removal/installation.


CAUTION:

- Insert a cloth protected screwdriver or clip driver into the arrow location (between the body panel and clip) and remove the clip.
- During installation, check if the clip is securely inserted into the chassis panel holes. Then push it in.

REAR PARTIAL SELF FINISHER

Rear Partial Self Finisher

Removal • Installation



(Accompanying works)

- Rear seat removal/installation.
- Rear pillar finisher removal/installation.
- Rear seatbelt floor anchor bolt removal/installation.

GI
EM
LC
EC
FE
RS

AC

AV

EL

WH

CL

MT

AT

FA

RA

BR


ST

BT

FLOOR TRIM

Floor Trim

Removal • Installation



SIIA0018J_D1


(Accompanying works)

- Front seat and rear seat cushion removal/installation.
- Center console removal/installation.
- Instrument lower cover and instrument lower center panel removal/installation.
- Instrument stay removal/installation.
- Front seatbelt floor anchor bolt removal/installation.
- Front and rear kicking plate inner and body side welt removal/installation.
- Dash side finisher and center pillar lower garnish removal/installation.

HEAD LINING

Head Lining

Removal • Installation




- ① Map lamp assembly
② Tap screws (2 EA)
③ Sun visor (R/L:1EA)
④ Tap screws (R/L:1EA)

- ⑤ Sun visor holder (R/L:1EA)
⑥ Assist clip (RH)
⑦ Headlining

Screw tightening torque: N·m (kgf·m)
M5 : 2.26 ± 0.34 {0.23 ± 0.03}
M6 : 3.82 ± 0.57 {0.39 ± 0.06}


SNRZ011_D1

- ⑧ Assist clip (R/L:1EA)
⑨ Room lamp
⑩ Trim clips (3 EA)




(Accompanying works)

- Center pillar garnish removal/installation.
- Body side welt removal/installation.
- Front pillar and rear pillar finisher removal/installation.
- (Point) Assist grip
- Using the clip clamping tool, remove the assist grip cover's top and bottom mounts. Place it sideways and remove the screws (each 1 EA left and right).



1. Tilt the head lining and pass the right side through in between the shift knob and lower cluster lid C.

HEAD LINING




2. Remove the head lining from the passenger's door opening.

CAUTION:

- **Two people must work together during removal.**
- **Place a cloth cover around the instrument assembly to prevent from scratching.**
- **Do not excessively bend the head lining.**

Installation is in the reverse order of removal.




REFERENCE:

- **Insert into the center pillar upper hole during installation.**

TRUNK TRIM AND TRUNK LID TRIM

Trunk Trim and Trunk Lid Trim


Removal • Installation



- ① Rear seatback welt
- ② Trunk front finisher assembly
- ③ Trim clips (2 EA)
- ④ Trunk net hook (2 EA)
- ⑤ Trunk side finisher (LH)

- ⑥ Trunk carpet support (2 EA)
- ⑦ Trunk rear plate
- ⑧ Trunk trim clip
- ⑨ Trunk carpet hook (1 EA)


- ⑩ Trim clips (6 EA)
- ⑪ Trunk side finisher (RH)
- ⑫ Trunk lid finisher
- ⑬ Trim clips (15 EA)



INSTRUMENT ASSEMBLY

Instrument Assembly

Components Diagram



SIIA0035J_D1

INSTRUMENT ASSEMBLY

Removal • Installation

WORK LIST

Item	Instrument panel	Combination meter	Display	Audio	Console	GI
Key cylinder escutcheon	[1]	[1]				EM
Steering column cover	[2]	[2]				LC
Light • turn signal switch	[3]	[3]				EC
Cluster lid A	[4]	[4]				FE
Combination meter	[5]	[5]				RS
Instrument lower driver panel	[6]					AC
Switch finisher	[7]					AV
A/T (M/T) finisher	[8]			[1]	[1]	EL
Cluster lid C lower	[9]			[2]		WH
Cluster lid C	[10]		[1]	[3]		CL
Console	[11]			[4]	[2]	MT
Audio, A/C controller	[12]					AT
Glove box	[13]					FA
Instrument lower assist panel	[14]					RA
Glove box cover	[15]					BR
Instrument lower cover	[16]					ST
Instrument center panel	[17]					BT
Passenger airbag module	[18]					
Instrument mask	[19]					
Front pillar garnish	[20]					
Instrument panel	[21]					

KEY CYLINDER ESCUTCHEON

- Remove the key cylinder escutcheon to the outside of the vehicle.


STEERING COLUMN COVER

- Remove the steering column cover (screw: 5 EA).

LIGHT • TURN SIGNAL SWITCH


- Remove the light • turn signal switch (screw: 2 EA).

INSTRUMENT ASSEMBLY




CLUSTER LID A

1. Remove the two crews and remove the metal clip by pulling the cluster lid A forwards.
2. Remove from the right side cautioning with other surrounding components.




COMBINATION METER

- Remove the 3 screws, disconnect the connector and then remove the combination meter.



INSTRUMENT LOWER DRIVER PANEL

1. Remove the fuse box lid.
2. Remove the metal clip by pulling the instrument lower driver panel forwards after removing the screw.
3. Remove the two screws from the diagnosis connector mount bracket in the back of the panel.




SWITCH FINISHER

- Pull out and remove the top mounts (2 locations) and disconnect all switch connectors.

A/T (M/T) FINISHER

- Remove the ashtray and then pull out the finisher.

INSTRUMENT ASSEMBLY



CLUSTER LID C LOWER

1. Remove the two screws.
2. Insert the hand into the top and bottom of the cluster lid C lower and remove it by pulling it forwards.

GI


EM

LC

EC

FE

RS



AUDIO • A/C CONTROLLER

- Remove the 4 screws and connectors and remove the audio and A/C controller.

FE

CLUSTER LID C

1. Insert the hand into the lid and pull it forwards.

RS

CAUTION:

- Be careful with the hazard switch, door lock switch and AC snow switch harness.


AV

2. Disconnect the hazard switch, door lock switch and snow switch connectors.

EL

WH

CL



CONSOLE


1. Remove the two screws from the rear of the console.
2. Remove the console center cap and remove the screw (1 EA).
3. Remove the console finisher.
4. Remove the two screws and then remove the console.

MT

AT

FA

RA



GLOVE BOX


- Open the glove box and remove the glove box pin from the inside.

BR

ST



BT

INSTRUMENT ASSEMBLY




INSTRUMENT LOWER ASSIST PANEL

- Remove the 2 screws. Pull it forwards and remove it from the blower unit lower mount.



INSTRUMENT LOWER COVER


1. Remove the metal clip and resin mount from the driver's side and remove by pulling towards the driver's seat.
2. Remove the wooden mount from the passenger side and remove by pulling towards the rear of the vehicle.



INSTRUMENT LOWER CENTER PANEL

1. Remove the 2 screws.
2. Disconnect the power outlet harness connector.
3. Pull the instrument lower center panel forwards and remove it after removing the metal clip.

INSTRUMENT ASSEMBLY



PASSENGER SEAT AIRBAG MODULE

- Remove the special bolt and then remove the passenger side airbag module.
Refer to "Restraint System".

GI

EM

LC

EC

FE

INSTRUMENT MASK


- Insert a cloth protected minus (-) screwdriver into the cut portion of the instrument mask end and remove it by releasing the mount.

RS

FRONT PILLAR GARNISH

- Pull the front pillar garnish forwards and remove it after removing the metal clip.

AC



INSTRUMENT PANEL

1. Press the A/T device's key interlock cable slider mount and push into the casing cap direction, then remove the key interlock rod and adjuster holder.
2. Remove the casing cap from the bracket.
3. Remove the nut and lower down the steering column.
4. Remove the 3 bolts, 2 nuts and 1 screw that holds the instrument panel and remove the instrument panel.

AV

EL

WH

CL


AT

FA


RA

BR

ST




INSTRUMENT ASSEMBLY



Disassembly • Assembly


INSTRUMENT PAD

- Remove the 6 screws from the rear of the instrument panel.



GLOVE BOX

- Remove the 2 screws from the inside of the glove box.




FRONT SEAT

Front Seat

Components Diagram

CAUTION:


- Protect the locations that interfere during seat removal with a cloth.



SIIA0044J_D1


FRONT SEAT

Removal • Installation of Front Seat Assembly




REMOVAL


1. Remove the front seat assembly in the order as shown in the figure.



2. Remove two front bolts fixing the front seat.



3. Remove the inner side seat slide cover and mounting bolts.




4. Remove the outer side seat slide cover and mounting bolts.

INSTALLATION

Assemble in the reverse order of disassembly.

FRONT SEAT

Removal • Installation of Front Seat




Disassembly • Assembly of Seatback

SEATBACK TRIM (WITH SIDE AIRBAG)


1. Remove the seatback finisher.

GI




2. Remove the retainer.

EM



3. Remove the 2 nuts and remove the inner cross mount stay.

AV



4. Press the headrest holder mounts on the headrest stay pipe's hole from the rear of the seatback. Remove the stopper and lift up the headrest to remove.

MT

CAUTION:

- Be careful of the headrest holder directions (left & right and forwards & rearwards) during installation.

AT



5. Remove the hug ring and separate the pad and trim after removing the seatback.

RA

BR

SEATBACK ASSEMBLY

- To remove the seatback assembly, remove the 4 bolts after step 1 and 2.


ST

CAUTION:

- During assembling the seatback frame, check the reclining device's lock in both sides and insert the bolt and then tighten.


BT

FRONT SEAT




SEATBACK TRIM (VEHICLE WITHOUT SIDE AIRBAG)

1. Remove the retainer from the lower side of the seatback rear.



2. Pry up the trim and remove the retainer from the back and hug rings from the front.



3. Remove the headrest holder mount by holding and pushing it up.

CAUTION:

- Be careful of the headrest holder directions (left & right and forwards & rearwards) during installation.

4. Remove the hug ring and separate the pad and trim after removing the seatback.


SEATBACK ASSEMBLY

- To remove the seatback assembly, remove the 4 bolts after step 1.

CAUTION:

- During assembling the seatback frame, check the reclining device's lock in both sides and insert the bolt and then tighten.


FRONT SEAT



DISASSEMBLY • ASSEMBLY OF SEAT CUSHION TRIM


1. Remove the reclining lever by standing the mount inside and pushing the knob towards the front.

GI



2. Remove the snap ring by hanging a wire and lifting it up and then remove the lifter dial.

EM




3. Remove the seat harness and bolts from the rear of the seat cushion.

AV

CAUTION:


- For bolt installation, check the slide's lock in both sides and insert the bolt and then tighten.

EL
WH



4. Remove the retainer on the rear of the cushion.

MT



5. Pry up the trim and remove the hug ring.

AT

FA

RA

BR


ST

BT

REAR SEAT

Rear Seat


Removal • Installation



① Rear seatback assembly
(with armrest)
② Tap screws (2 EA)
③ Armrest

④ Rear seatback assembly
(without armrest)
⑤ Screw (R/L:1EA)

⑦ Bolts (4 EA)
⑧ Hook
⑨ Tether anchor plate assembly



- Secure the pad side wire and trim side wire using the hug ring.

REFERENCE:








- The hug ring installation is easier if use the hug ring pliers (A: commercial tool).
- When installing a new trim, it is easier if put the hug ring locations by referring the old trim.

HOOD

Hood

Assembly Dimension Adjustment

GI
EM
LC
EC
FE
RS
AC
AV
EL
WH
CL
MT
AT
FA
RA
BR
ST



Unit : mm
: Body grease
: N·m {kgf·m}

PIIB8645E


FRONT END HEIGHT ADJUSTMENT, LEFT-RIGHT AND FRONT-REAR GAP ADJUSTMENT

1. Remove the hood lock. Adjust the hood by rotating the bumper rubber so that it becomes 1-1.5 mm lower than the fender.
2. Temporarily install the hood lock and determine the position so that the hood lock engages with the striker. Check if the lock and the striker has any looseness and tighten the lock mounting bolts to the specified torque.

SURFACE DIFFERENCE (FLUSH) ADJUSTMENT


1. Remove the hood lock. Adjust the bumper rubber left and right so that the surface difference between the hood and the fender becomes the plant assembling standard.
2. Install the hood lock. Adjust the hood lock left and right so that the striker and the lock center are perpendicular when viewed from the front.

BT



- Check if the secondary latch engages securely with the secondary striker when drop the hood from 200 mm of height or press the hood with 3 kg of force.
- Close the hood. Adjust the hood by moving the hood lock up and down so that the striker and the lock are securely engaged.
- After the adjustment, tighten the lock mounting bolt to the specified torque.

Removal • Installation of Hood Assembly





■ : Body grease
▣ : N·m (kgf·m)

PIIA0019J D1


- Disconnect the washer hose from the connecting section.
- Remove the hinge mounting nut from the hood and remove the hood assembly.

Installation is in the reverse order of removal.

Removal • Installation of Hood Lock Control




Section A-A



Section B-B, C-C

Nm (kgf-m)

PIIA0020J_D1

GI
EM
LC
EC
FE
RS
AC
AV
EL
WH
CL

REMOVAL


1. Disconnect the hood lock cable from the hood lock and remove the hood lock cable from the radiator core support upper and hood latch clip. **MT**
2. Remove the dash side finisher. Refer to "Removal • Installation" (BT-34) in "Body Side Trim". **AT**
3. Remove the mounting screws and remove the hood opener. **FA**
4. Remove the grommet from the dash and pull out towards the inside of the hood lock cable. **RA**

CAUTION:

- When removing by pulling, be careful not to damage the hood lock cable (surface peeling) by the body hole. **BR**




ST

BT



INSTALLATION

1. Push in the hood lock cable with maximum R (over R 100 mm).
2. Check if not escaped from the position determining grommet. Insert the grommet securely into the panel hole.
3. Apply the sealant on the grommet where * marked section.
4. Install the cable securely to the lock.
5. Adjust hood lock after installation and check opener for proper operation.



Hood Lock Control Inspection



CAUTION:

- Replace the hood lock cable if bent or deformed.
1. Check if the hood lock secondary latch engages securely with the secondary striker only when drop the hood from 200 mm of height.
 2. Check if the hood end pops up about 20 mm when pull the hood opener smoothly. Also check if the hood opener returns to the original position.
 3. Inspect the lubrication at the hood lock and apply "body grease" to the illustrated positions if necessary.

DOOR

Door


Door Assembly Dimension Adjustment



Section A-A

Section B-B

Section C-C



Unit : mm

▣ : N·m {kgf·m}

Body side hinge mounting bolt (1 EA)

▣ 17.5~23.7{1.79~2.42}

Body side hinge mounting nut (2 EA)

▣ 17.5~23.7{1.79~2.42}

Body side hinge mounting bolt (1 EA)

▣ 17.5~23.7{1.79~2.42}

PIIA0031J_D1

GI
EM
LC
EC
FE
RS
AC
AV
EL
WH
CL

Front Door

FORE AND AFT GAP AND FRONT END FLUSH ADJUSTMENT

1. Remove the fender protector.
2. Loosen the body side hinge mounting bolt from inside of the fender. Lift up the rear of the front door and perform adjustment.

MT

AT

Rear Door

FORE AND AFT GAP AND FRONT END FLUSH ADJUSTMENT

1. Remove the center pillar upper and lower garnish.
2. Loosen the mounting bolt from outside and mounting nuts from inside. Open the rear door and lift up the rear of the rear door and then perform adjustment.


FA

RA

BR

ST

BT



STRIKER ADJUSTMENT

Adjust the striker so that it becomes parallel with the lock engaging direction.


Removal • Installation

CAUTION:

- While removing/installing the door assembly, secure the door with a cloth-covered jack to prevent from scratching the door and the body panels.
- Perform the door assembly dimension adjustment when removing/installing the door assembly.
- Inspect the lubrication condition at the hinge pivots and main moving section of the check link. Apply body grease if necessary.

1. Remove the door finisher.
2. Remove the door harness.
3. Remove the mounting bolts and nuts and remove the door assembly. Install in the reverse order of removal and tighten the mounting bolts and nuts to the specified torque.


Door Welt Strip



FRONT DOOR LOCK

Front Door Lock

Components Diagram




Inspection • Adjustment

1. Remove the front door finisher.
2. Remove the sealing screen.

REFERENCE:

- When reusing the sealing screen, cut the butyl tape with **WH** a cutter so that the butyl tape remains on the sealing screen.



Outside Handle Rod Adjustment

Adjust by rotating the bush so that the gap between the bush **MT** and rod becomes as shown in the illustration.

REFERENCE:

- Do not let the gap become 0 mm or rod always be pressed.

Removal • Installation

REMOVAL


1. Remove the front door finisher.
2. Remove the sealing screen.

REFERENCE:


- When reusing the sealing screen, cut the butyl tape with **BT** a cutter so that the butyl tape remains on the sealing screen.

3. Remove the front door glass.

FRONT DOOR LOCK




4. Remove the fixing clip and remove the inner pad.



5. Remove the mounting bolts and remove the lower chassis and rear glass as an assembly from the door panel up to the upper part of the door panel.

6. Remove the inside handle escutcheon A.



7. Remove the inside handle mounting screws.

8. Disconnect the lock knob rod connections (2 locations) on the bell crank.

9. Disconnect the inside handle rod (door lock assembly side).

10. Push the inside handle rearwards and remove it from the door panel hole.


11. Remove the rod from the inside handle.

12. Insert the hand into the work hole and disconnect the key lock rod and outside handle rod connections (handle side).

13. Remove the connector on the door lock actuator.

14. Remove the mounting screw and remove the door lock assembly from the work hole.

15. Remove the outside handle and key cylinder stay mounting bolt and remove the outside handle assembly.




INSTALLATION

Install in the reverse order of removal.

CAUTION:

- During door lock assembly installation, apply the anti-corrosion wax on body side.
- To install the rod, rotate the rod holder until each rod clicks.

FRONT DOOR LOCK



Disassembly • Assembly

DISASSEMBLY

CAUTION:

- Perform the actuator removal/installation after removing the door lock assembly from the vehicle.

GI

1. Remove the mounting screws and remove the actuator from the door lock assembly.
2. Pull the actuator downward and remove it from the door lock assembly.

EM

LC

EC

FE

RS

AC

ASSEMBLY

1. Insert the actuator pivot into the door lock assembly's knob lever.
2. Locate the lock lever and actuator pivot to lock position and check if it is securely engaged.

AV

EL

WH

CL

MT

AT

FA

RA

BR


ST

BT

REAR DOOR LOCK

Rear Door Lock

Components Diagram




Inspection • Adjustment

1. Remove the rear door finisher. Refer to "Removal • Installation" (BT-32) in "Door Trim".
2. Remove the sealing screen.

REFERENCE:

- When reusing the sealing screen, cut the butyl tape with a cutter so that the butyl tape remains on the sealing screen.



Outside Handle Rod Adjustment

Adjust by rotating the bush so that the gap between the bush and rod becomes as shown in the illustration.

REFERENCE:

- Do not let the gap become 0 mm or rod always be pressed.

Removal • Installation


REMOVAL

1. Remove the rear door finisher.
2. Remove the sealing screen.


REFERENCE:

- When reusing the sealing screen, cut the butyl tape with a cutter so that the butyl tape remains on the sealing screen.
3. Open all rear door glasses.
 4. Pull out the inside handle escutcheon A.
 5. Remove the inside handle mounting screw.

REAR DOOR LOCK



6. Disconnect the inside handle rod (door lock assembly side).
7. Disconnect the lock knob rod (door lock assembly side).
8. Open the rod holder using a minus (-) screwdriver and remove the rod. **GI**
9. Push the inside handle rearwards and remove it from the door panel hole. **EM**
10. Remove the rod from the inside handle. **LC**



11. Remove the mounting bolts and remove the lower chassis rear by pulling downward. **EC**
12. Remove the connector on the door lock actuator.
13. Remove the mounting screws and remove the door lock assembly from the work hole. **FE**
14. Remove the mounting bolts and remove the outside handle. **RS**

AC


INSTALLATION

Installation is in the reverse order of removal. **AV**

CAUTION:

- During door lock assembly installation, apply the “anti-corrosion wax” on body side. **EL**
- To install the rod, rotate the rod holder until each rod **WH** clicks.

CL



Disassembly • Assembly

DISASSEMBLY

MT

CAUTION:

- Perform the actuator removal/installation after removing the door lock assembly from the vehicle. **AT**
1. Remove the mounting screws and remove the actuator from the door lock assembly. **FA**
 2. Pull the actuator downward and remove it from the door lock assembly. **RA**

BR

ASSEMBLY


1. Insert the actuator pivot into the door lock assembly’s knob lever.
2. Locate the lock lever and actuator pivot to lock position and check if it is securely engaged. **ST**

BT

TRUNK LID

Trunk Lid

Assembly Dimension Adjustment



FORE & AFT AND LEFT & RIGHT GAP ADJUSTMENT


1. Remove the striker. Remove the trunk lid hinge mounting bolts and close the trunk lid.
2. After adjusting the gap between the left and right and with the rear window glass, open the trunk lid and tighten the mounting bolts to the specified torque.

SURFACE DIFFERENCE (FLUSH) ADJUSTMENT

1. Remove the striker mounting bolts. Lift the striker and temporarily insert the upper mounting bolts while striker is at the highest point.
2. Lightly close the trunk lid. Open the trunk lid and tighten the striker mounting bolts to the specified torque after adjusting the surface difference (flush).

TRUNK LID

Removal • Installation of Trunk Lid Assembly




1. Remove all connectors in the trunk lid. Remove all harness clamps and then remove the harness from the trunk lid by pulling it out.
2. Remove the mounting bolts and remove the trunk lid assembly.

CAUTION

- Apply the anti-corrosion wax on the connection between the trunk lid and hinge.
- After tightening the hinge mounting bolts, apply touch-up paint on the bolt heads with the same color.

Installation is in the reverse order of removal.



Removal • Installation of Trunk Lid Lock & Striker


LOCK REMOVAL

1. Remove the trunk lid finisher.
2. Remove the trunk lid lock cover.
3. Remove the mounting bolts and remove the trunk lid lock.

STRIKER REMOVAL

1. Remove the trunk rear plate and trunk rear finisher.


TRUNK LID



2. Remove the mounting bolts and remove the trunk lid opener bracket.
3. Remove the mounting bolts and trunk room lamp connector and remove the trunk lid striker.
4. Remove the trunk lid opener cable from the trunk lid striker.

LOCK AND STRIKER INSTALLATION

1. After installation, lightly close the trunk lid and adjust the lock and the surface difference.
2. Check the operation after installation.
3. Install the trunk lid lock cover, trunk lid finisher and trunk finisher.



Removal • Installation of Torsion Bar


CAUTION:

- The folding force of the torsion bar is very strong. Be careful when removing/installing the torsion bar.
- Cover the tool with a cloth to prevent from slipping.

1. Hang the torsion bar wrench onto the torsion bar and remove it by lifting up.

TRUNK LID

Removal • Installation of Trunk Lid Welt Strip



1. Align the welt strip marking to the vehicle center position marking from the front and then install.
2. For the rear, insert the welt strip connections into the center of the striker.
3. After installation, check if the welt strip is not loose by pulling it lightly.


CAUTION:

- Securely install the each corner and trunk lid rear plate area.

TRUNK LID & FUEL FILLER LID OPENER

Trunk Lid & Fuel Filler Lid Opener

Components Location




PIIB8647E

BODY ALIGNMENT

Body Alignment

Description

- All dimensions indicated in the figures are actual.
- When using a tracking gauge, adjust both pointers to equal length. Then check the pointers and **GI** gauge itself to make sure there is no free play.
- When a measuring tape is used, check to be sure there is no elongation, twisting or bending. **EM**
- Measurements should be taken at the center of the mounting holes. **EM**
- An asterisk (*) following the value at the measuring point indicates that the measuring point on the other side is symmetrically the same value. **LC**
- The coordinates of the measurement points are the distances measured from the standard line of "X", "Y" and "Z". **EC**



PIIA0104E

EM
LC
EC

FE
RS
AC
AV
EL
WH
CL
MT
AT
FA
RA
BR
ST
BT


BODY ALIGNMENT

Engine Compartment

MEASUREMENT

Figures marked with a (*) indicate symmetrically identical dimensions on both right and left hand sides of the vehicle.


Unit : mm



BODY ALIGNMENT

MEASUREMENT POINTS

(A) : Cowl top base hole center of center positioning mark (5dia.)




Front

(B), (b) : Front hoodledge reinforcement measuring hole center (7x10)


(C), (c) : Front strut mounting hole center (9dia.)

(D), (d) : Front fender mounting hole center (5dia.)



Front


(E), (e) : Front fender mounting hole center (5dia.)
(K), (k) : Radiator core support side base hole center (12dia.)



Front


(F) : Upper radiator core support measuring hole center of center positioning mark (5dia.)

(J), (j) : Hood lock mounting hole center (11dia.)




Front

(G) : ABS mounting hole center (8dia.)
(H) : Battery bracket mounting hole center (11dia.)




Front

(I) : Front side member measuring hole center (8dia.)
(J) : Engine bracket mounting hole center (14dia.)



Front

(L), (l) : Radiator core support lower base hole center (12dia.)
(M) : Hood lock stay measuring hole center of center positioning mark (18dia.)



Front

SIIA2618E

GI
EM
LC
EC
FE
RS
AC
AV
EL
WH
CL
MT
AT
FA
RA
BR
ST
BT


BODY ALIGNMENT

Underbody

MEASUREMENT

Figures marked with a (*) indicate symmetrically identical dimensions on both right and left hand sides of the vehicle.

Unit : mm




BODY ALIGNMENT


MEASUREMENT POINTS

GI
EM
LC
EC
FE
RS
AC
AV
EL
WH
CL
MT
AT
FA
RA
BR
ST
BT


(A),(a) : Lower radiator core support base hole center (8dia.)
(B),(b) : Front side member base hole center (16dia.)
(C),(c) : Front suspension member mounting bolt end




(D),(d) : Front suspension member mounting bolt end
(E),(e) : Front side member base hole center (10dia.)
(F),(f) : Front side member extension base hole center (12dia.)
(G),(g) : Front floor measuring hole center (8dia.)



(J) : Lateral link mounting hole center (13dia.)




(K),(L) : Rear side member reinforcement base hole center (8dia.)
(M) : Rear side member extension base hole center (12dia.)




(N),(n) : Front strut mounting hole center (30dia.)


Front ←



(I),(i) : Rear suspension mounting bolt end
(O),(o) : Rear strut mounting hole center (68dia.)



(H),(h) : Rear side member base hole center (16dia.)
(K),(l) : Rear side member reinforcement base hole center (8dia.)
(m) : Rear side member extension base hole center (12dia.)



SIIA2620E


BODY ALIGNMENT

Passenger Compartment

MEASUREMENT

Unit : mm

Figures marked with a (*) indicate symmetrically identical dimensions on both right and left hand sides of the vehicle.










Point	Dimension	Point	Dimension	Point	Dimension
Ⓐ~Ⓑ	1,172	Ⓛ~Ⓜ	1,375*	Ⓓ~Ⓔ	896*
Ⓔ~Ⓖ	1,495*	Ⓛ~Ⓛ	1,386	Ⓓ~Ⓡ	785*
Ⓔ~Ⓗ	1,324*	Ⓜ~Ⓜ	1,396	Ⓡ~Ⓛ	1,006*
Ⓕ~Ⓕ	1,374	Ⓜ~Ⓟ	1,462*	Ⓡ~Ⓜ	835*
Ⓖ~Ⓖ	1,392	Ⓝ~Ⓝ	1,204	Ⓡ~Ⓝ	767*
Ⓖ~Ⓗ	1,769*	Ⓝ~Ⓟ	1,544*	Ⓡ~Ⓝ	1,069*
Ⓖ~Ⓡ	1,626*	Ⓞ~Ⓞ	1,378	Ⓡ~Ⓞ	880*
Ⓗ~Ⓗ	1,164	Ⓟ~Ⓟ	1,399	Ⓡ~Ⓟ	709*
Ⓗ~Ⓡ	1,466*	Ⓟ~Ⓡ	1,545*	Ⓢ~Ⓤ	1,082*
Ⓘ~Ⓘ	1,386	Ⓠ~Ⓔ	987*	Ⓢ~Ⓠ	1,102*
Ⓡ~Ⓡ	1,396	Ⓠ~Ⓕ	930*	Ⓣ~Ⓤ	1,125*
Ⓛ~Ⓛ	1,163	Ⓠ~Ⓖ	864*	Ⓣ~Ⓠ	1,061*
Ⓛ~Ⓜ	1,456*	Ⓠ~Ⓗ	1,122*		

SIIA2621E

BODY ALIGNMENT

MEASUREMENT POINTS



GI
EM
LC
EC
FE
RS
AC
AV
EL
WH
CL
MT
AT
FA
RA
BR
ST
BT


BODY ALIGNMENT

Rear Body

MEASUREMENT

Unit : mm






Figures marked with a (*) indicate symmetrically identical dimensions on both right and left hand sides of the vehicle.



SIIA2623E

BODY ALIGNMENT

MEASUREMENT POINTS



GI
EM
LC
EC
FE
RS
AC
AV
EL
WH
CL
MT
AT
FA
RA
BR
ST
BT

