

SECTION **AV**

AUDIO, VISUAL & NAVIGATION SYSTEM

CONTENTS

BASE AUDIO	SYMPTOM DIAGNOSIS	25
BASIC INSPECTION	AUDIO SYSTEM	25
DIAGNOSIS AND REPAIR WORKFLOW	Symptom Table	25
Work Flow	NORMAL OPERATING CONDITION	27
SYSTEM DESCRIPTION	Description	27
AUDIO SYSTEM	PRECAUTION	28
System Diagram	PRECAUTIONS	28
System Description	Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"	28
Component Parts Location	Precaution for Procedure without Cowl Top Cover	28
Component Description	Precaution for Work	28
DTC/CIRCUIT DIAGNOSIS	PREPARATION	30
POWER SUPPLY AND GROUND CIRCUIT	PREPARATION	30
AUDIO UNIT	Special Service Tool	30
AUDIO UNIT : Diagnosis Procedure	Commercial Service Tools	30
FRONT DOOR SPEAKER	REMOVAL AND INSTALLATION	31
Description	AUDIO UNIT	31
Diagnosis Procedure	Removal and Installation	31
FRONT TWEETER	FRONT TWEETER	33
Description	Removal and Installation	33
Diagnosis Procedure	FRONT DOOR SPEAKER	34
REAR DOOR SPEAKER	Removal and Installation	34
Description	REAR DOOR SPEAKER	35
Diagnosis Procedure	Removal and Installation	35
ECU DIAGNOSIS INFORMATION	AUDIO ANTENNA	36
AUDIO UNIT	Location of Audio Antenna System Component	36
Reference Value	Removal and Installation	36
WIRING DIAGRAM	DISPLAY AUDIO WITHOUT AMPLIFIER	
BASE AUDIO SYSTEM	SYSTEM DESCRIPTION	37
Wiring Diagram		

COMPONENT PARTS	37	AUDIO SYSTEM	80
Component Parts Location	37	Symptom Table	80
Component Description	37	NORMAL OPERATING CONDITION	83
SYSTEM	39	Description	83
System Diagram	39	PRECAUTION	85
System Description	39	PRECAUTIONS	85
DIAGNOSIS SYSTEM (AUDIO UNIT)	41	Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TEN- SIONER"	85
Description	41	Precaution for Trouble Diagnosis	85
On Board Diagnosis Function	41	Precaution for Harness Repair	85
ECU DIAGNOSIS INFORMATION	46	Precaution for Work	86
AUDIO UNIT	46	PREPARATION	87
Reference Value	46	PREPARATION	87
BLUETOOTH® CONTROL UNIT	49	Special Service Tools	87
Reference Value	49	Commercial Service Tools	87
WIRING DIAGRAM	51	REMOVAL AND INSTALLATION	88
DISPLAY AUDIO WITHOUT AMPLIFIER	51	AUDIO UNIT	88
Wiring Diagram	51	Removal and Installation	88
BASIC INSPECTION	64	FRONT TWEETER	89
DIAGNOSIS AND REPAIR WORKFLOW	64	Removal and Installation	89
Work Flow	64	FRONT DOOR SPEAKER	90
DTC/CIRCUIT DIAGNOSIS	66	Removal and Installation	90
POWER SUPPLY AND GROUND CIRCUIT	66	REAR DOOR SPEAKER	91
AUDIO UNIT	66	Removal and Installation	91
AUDIO UNIT : Diagnosis Procedure	66	STEERING SWITCH	92
BLUETOOTH® CONTROL UNIT	66	Removal and Installation	92
BLUETOOTH® CONTROL UNIT : Diagnosis Pro- cedure	66	BLUETOOTH CONTROL UNIT	93
MICROPHONE	67	Removal and Installation	93
MICROPHONE : Diagnosis Procedure	67	MICROPHONE	95
FRONT DOOR SPEAKER	69	Removal and Installation	95
Diagnosis Procedure	69	AUDIO ANTENNA	96
FRONT TWEETER	71	Location of Antenna	96
Diagnosis Procedure	71	Removal and Installation	96
REAR DOOR SPEAKER	73	SATELLITE RADIO ANTENNA	98
Diagnosis Procedure	73	Removal and Installation	98
STEERING SWITCH	75	USB CONNECTOR	99
Diagnosis Procedure	75	Removal and Installation	99
MICROPHONE SIGNAL CIRCUIT	77	DISPLAY AUDIO WITH AMPLIFIER	
Diagnosis Procedure	77	SYSTEM DESCRIPTION	100
USB CONNECTOR	79	COMPONENT PARTS	100
Diagnosis Procedure	79	Component Parts Location	100
SYMPTOM DIAGNOSIS	80	Component Description	100
		SYSTEM	102

System Diagram	102	Diagnosis Procedure	154	
System Description	102	MICROPHONE SIGNAL CIRCUIT	156	A
DIAGNOSIS SYSTEM (AUDIO UNIT)	104	Diagnosis Procedure	156	
Description	104	USB CONNECTOR	158	B
On Board Diagnosis Function	104	Diagnosis Procedure	158	
ECU DIAGNOSIS INFORMATION	109	SYMPTOM DIAGNOSIS	159	C
AUDIO UNIT	109	AUDIO SYSTEM	159	
Reference Value	109	Symptom Table	159	D
AUDIO AMP.	112	NORMAL OPERATING CONDITION	163	
Reference Value	112	Description	163	E
BLUETOOTH CONTROL UNIT	115	PRECAUTION	165	
Reference Value	115	PRECAUTIONS	165	F
WIRING DIAGRAM	117	Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TEN- SIONER"	165	
DISPLAY AUDIO WITH AMPLIFIER	117	Precaution for Trouble Diagnosis	165	G
Wiring Diagram	117	Precaution for Harness Repair	165	
BASIC INSPECTION	132	Precaution for Work	166	H
DIAGNOSIS AND REPAIR WORKFLOW	132	PREPARATION	167	
Work Flow	132	PREPARATION	167	I
DTC/CIRCUIT DIAGNOSIS	134	Special Service Tools	167	
POWER SUPPLY AND GROUND CIRCUIT ...	134	Commercial Service Tools	167	J
AUDIO UNIT	134	REMOVAL AND INSTALLATION	168	
AUDIO UNIT : Diagnosis Procedure	134	AUDIO UNIT	168	K
AUDIO AMP.	134	Removal and Installation	168	
AUDIO AMP. : Diagnosis Procedure	134	AUDIO AMP.	169	L
BLUETOOTH CONTROL UNIT	135	Removal and Installation	169	
BLUETOOTH CONTROL UNIT : Diagnosis Pro- cedure	135	FRONT TWEETER	170	M
MICROPHONE	136	Removal and Installation	170	
MICROPHONE : Diagnosis Procedure	136	FRONT DOOR SPEAKER	171	AV
FRONT DOOR SPEAKER	138	Removal and Installation	171	
Diagnosis Procedure	138	REAR DOOR SPEAKER	172	O
FRONT TWEETER	141	Removal and Installation	172	
Diagnosis Procedure	141	REAR TWEETER	173	P
REAR DOOR SPEAKER	144	Removal and Installation	173	
Diagnosis Procedure	144	SUBWOOFER	174	
REAR TWEETER	147	Removal and Installation	174	
Diagnosis Procedure	147	STEERING SWITCH	175	
SUBWOOFER	150	Removal and Installation	175	
Diagnosis Procedure	150	BLUETOOTH CONTROL UNIT	176	
AMP. ON SIGNAL CIRCUIT	153	Removal and Installation	176	
Diagnosis Procedure	153	MICROPHONE	178	
STEERING SWITCH	154	Removal and Installation	178	

AUDIO ANTENNA	179	DTC/CIRCUIT DIAGNOSIS	220
Location of Antenna	179	U1000 CAN COMM CIRCUIT	220
Removal and Installation	179	DTC Logic	220
SATELLITE RADIO ANTENNA	181	Diagnosis Procedure	220
Removal and Installation	181	U1010 CONTROL UNIT (CAN)	221
USB CONNECTOR	182	DTC Logic	221
Removal and Installation	182	U1217 AV CONTROL UNIT	222
NAVIGATION		DTC Logic	222
SYSTEM DESCRIPTION	183	U1229 AV CONTROL UNIT	223
COMPONENT PARTS	183	DTC Logic	223
Component Parts Location	183	U122F AV CONTROL UNIT	224
Component Description	184	DTC Logic	224
SYSTEM	185	U1244 GPS ANTENNA	225
System Diagram	185	DTC Logic	225
System Description	185	Diagnosis Procedure	225
DIAGNOSIS SYSTEM (AV CONTROL UNIT) ..	189	U1258 SATELLITE RADIO ANTENNA	226
Description	189	DTC Logic	226
On Board Diagnosis Function	189	Diagnosis Procedure	226
CONSULT Function	190	U1263 USB	227
ECU DIAGNOSIS INFORMATION	191	DTC Logic	227
AV CONTROL UNIT	191	Diagnosis Procedure	227
Reference Value	191	U1265 AUDIO AMP.	228
DTC Index	193	DTC Logic	228
AUDIO AMP.	195	Diagnosis Procedure	228
Reference Value	195	U12AA CONFIGURATION ERROR	229
WIRING DIAGRAM	198	DTC Logic	229
NAVIGATION SYSTEM	198	Diagnosis Procedure	229
Wiring Diagram	198	U12AB ANTENNA	230
BASIC INSPECTION	215	DTC Logic	230
DIAGNOSIS AND REPAIR WORKFLOW	215	Diagnosis Procedure	230
Work Flow	215	U12AC AV CONTROL UNIT	231
INSPECTION AND ADJUSTMENT	217	DTC Logic	231
ADDITIONAL SERVICE WHEN REPLACING AV		U12AD AV CONTROL UNIT	232
CONTROL UNIT	217	DTC Logic	232
ADDITIONAL SERVICE WHEN REPLACING AV		U12AE AV CONTROL UNIT	233
CONTROL UNIT : Description	217	DTC Logic	233
ADDITIONAL SERVICE WHEN REPLACING AV		U12AF AV CONTROL UNIT	234
CONTROL UNIT : Work Procedure	217	DTC Logic	234
CONFIGURATION (AV CONTROL UNIT)	217	U12B0 POWER SUPPLY VOLTAGE	235
CONFIGURATION (AV CONTROL UNIT) : De-		DTC Logic	235
scription	218	Diagnosis Procedure	235
CONFIGURATION (AV CONTROL UNIT) : Work		U12B1 POWER SUPPLY VOLTAGE	236
Procedure	218	DTC Logic	236
CONFIGURATION (AV CONTROL UNIT) : Con-		Diagnosis Procedure	236
figuration List	219	U1310 AV CONTROL UNIT	237

DTC Logic	237	Precaution for Trouble Diagnosis	278	
POWER SUPPLY AND GROUND CIRCUIT ...	238	Precaution for Harness Repair	278	A
AV CONTROL UNIT	238	Precaution for Work	279	
AV CONTROL UNIT : Diagnosis Procedure	238	PREPARATION	280	B
AUDIO AMP.	238	PREPARATION	280	
AUDIO AMP. : Diagnosis Procedure	238	Special Service Tools	280	C
FRONT DOOR SPEAKER	240	Commercial Service Tools	280	
Diagnosis Procedure	240	REMOVAL AND INSTALLATION	281	
FRONT TWEETER	243	AV CONTROL UNIT	281	D
Diagnosis Procedure	243	Removal and Installation	281	
REAR DOOR SPEAKER	246	AUDIO AMP.	282	E
Diagnosis Procedure	246	Removal and Installation	282	
REAR TWEETER	249	FRONT TWEETER	283	F
Diagnosis Procedure	249	Removal and Installation	283	
SUBWOOFER	252	FRONT DOOR SPEAKER	284	G
Diagnosis Procedure	252	Removal and Installation	284	
AMP. ON SIGNAL CIRCUIT	255	REAR DOOR SPEAKER	285	H
Diagnosis Procedure	255	Removal and Installation	285	
REAR VIEW CAMERA IMAGE SIGNAL CIRCUIT	256	REAR TWEETER	286	I
Diagnosis Procedure	256	Removal and Installation	286	
STEERING SWITCH	258	SUBWOOFER	287	J
Diagnosis Procedure	258	Removal and Installation	287	
MICROPHONE SIGNAL CIRCUIT	260	STEERING SWITCH	288	K
Diagnosis Procedure	260	Removal and Installation	288	
USB CONNECTOR	262	MICROPHONE	289	L
Diagnosis Procedure	262	Removal and Installation	289	
AUXILIARY INPUT JACK	263	AUDIO ANTENNA	290	M
Diagnosis Procedure	263	Location of Antenna	290	
SYMPTOM DIAGNOSIS	264	Removal and Installation	290	
MULTI AV SYSTEM	264	AUXILIARY INPUT JACK	292	
Symptom Table	264	Removal and Installation	292	
NORMAL OPERATING CONDITION	269	SATELLITE RADIO ANTENNA	293	AV
Description	269	Removal and Installation	293	
PRECAUTION	278	GPS ANTENNA	294	O
PRECAUTIONS	278	Removal and Installation	294	
Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"	278	USB CONNECTOR	295	P
		Removal and Installation	295	
		REAR VIEW CAMERA	296	
		Removal and Installation	296	


BASIC INSPECTION

DIAGNOSIS AND REPAIR WORKFLOW

Work Flow

INFOID:000000008799435

OVERALL SEQUENCE



DETAILED FLOW

1.GET INFORMATION FOR SYMPTOM

Get detailed information from the customer about the symptom (the condition and the environment when the incident/malfunction occurred).

>> GO TO 2

2.CONFIRM THE SYMPTOM

Try to confirm the symptom described by the customer. Verify relation between the symptom and the condition when the symptom is detected.

>> GO TO 3

3.DETECT MALFUNCTIONING PART BY DIAGNOSTIC PROCEDURE

Inspect according to Diagnostic Procedure of the system.

DIAGNOSIS AND REPAIR WORKFLOW

< BASIC INSPECTION >

[BASE AUDIO]

Is malfunctioning part detected?

YES >> GO TO 4

NO >> GO TO 2

4.REPAIR OR REPLACE THE MALFUNCTIONING PART

1. Repair or replace the malfunctioning part.
2. Reconnect parts or connectors disconnected during Diagnostic Procedure.

>> GO TO 5

5.FINAL CHECK

Refer to confirmed symptom in step 2, and make sure that the symptom is not detected.

Has the symptom been repaired?

YES >> Inspection End.

NO >> GO TO 2

A

B

C

D

E

F

G

H

I

J

K

L

M

AV


O

P

SYSTEM DESCRIPTION

AUDIO SYSTEM

System Diagram



System Description

INFOID:000000008799437

AUDIO SYSTEM

The audio system consists of the following components

- Audio unit
- Rod antenna
- Front door speakers
- Front tweeters
- Rear door speakers

When the audio system is on, radio signals are received by the rod antenna. The audio unit then sends audio signals to the front door speakers, front tweeters and rear door speakers.

Refer to Owner's Manual for audio system operating instructions.


AUDIO SYSTEM

< SYSTEM DESCRIPTION >

[BASE AUDIO]

Component Parts Location

INFOID:000000008799438



- | | | |
|--|--|--------------------------|
| 1. Front tweeter LH M109 | 2. Audio unit M43 | 3. Front tweeter RH M111 |
| 4. Front door speaker
LH D12
RH D112 | 5. Rear door speaker
LH D207
RH D307 | |

Component Description

INFOID:000000008799439

Part name	Description
Audio unit	Controls audio system functions
Front door speakers	• Outputs audio signal from audio unit • Outputs high, mid and low range sounds
Front tweeters	• Outputs audio signal from audio unit • Outputs high range sounds
Rear door speakers	• Outputs audio signal from audio unit • Outputs high, mid and low range sounds

DTC/CIRCUIT DIAGNOSIS**POWER SUPPLY AND GROUND CIRCUIT
AUDIO UNIT****AUDIO UNIT : Diagnosis Procedure**

INFOID:000000008799440

Regarding Wiring Diagram information, refer to [AV-19, "Wiring Diagram"](#).

1.CHECK FUSES

Check that the following fuses of the audio unit are not blown.

Unit	Terminals	Signal name	Fuse No.
Audio unit	19	Battery power	29
	7	Ignition switch ACC or ON	4

Are the fuses OK?

YES >> GO TO 2

NO >> If fuse is blown, be sure to eliminate cause of malfunction before installing new fuse.

2.POWER SUPPLY CIRCUIT CHECK

1. Disconnect audio unit connector M43.
2. Check voltage between the audio unit connector M43 ground.

(+)		(-)	OFF	ACC	ON
Connector	Terminal				
M43	7	Ground	0V	Battery voltage	Battery voltage
	19	Ground	Battery voltage	Battery voltage	Battery voltage

Are the voltage results as specified?

YES >> GO TO 3

NO >> • Check connector housings for disconnected or loose terminals.
• Repair harness or connector.


3.GROUND CIRCUIT CHECK

Inspect audio unit case ground.

Does case ground pass inspection?

YES >> Inspection end.

NO >> Repair audio unit case ground.



FRONT DOOR SPEAKER

< DTC/CIRCUIT DIAGNOSIS >

[BASE AUDIO]

FRONT DOOR SPEAKER

Description

INFOID:000000008799441

The audio unit sends audio signals to the front door speakers using the front door speaker circuits.

Diagnosis Procedure

INFOID:000000008799442

Regarding Wiring Diagram information, refer to [AV-19, "Wiring Diagram"](#).

1.CONNECTOR CHECK

Check the audio unit and speaker connectors for the following:

- Proper connection
- Damage
- Disconnected or loose terminals

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair the terminal and connector.

2.HARNESS CHECK

1. Disconnect audio unit connector M43 and suspect speaker connector.
2. Check continuity between audio unit harness connector M43 (A) terminal and suspect speaker harness connector (B) terminal.

A		B		Continuity
Connector	Terminal	Connector	Terminal	
M43	2	D12	1	Yes
	3		2	
	11	D112	1	
	12		2	

3. Check continuity between audio unit harness connector M43 (A) terminal and ground.


A		—	Continuity
Connector	Terminal		
M43	2	Ground	No
	3		
	11		
	12		

Are continuity results as specified?

YES >> GO TO 3

NO >> Repair harness or connector.

3.FRONT SPEAKER SIGNAL CHECK




FRONT DOOR SPEAKER

< DTC/CIRCUIT DIAGNOSIS >


[BASE AUDIO]

1. Connect audio unit connector M43 and front speaker connector.
2. Turn ignition switch to ACC.
3. Push audio unit "POWER" switch.
4. Check the signal between audio unit harness connector M43 terminals with CONSULT or oscilloscope.

Con- nector	(+)		Condition	Reference signal
	Terminal	Terminal		
M43	2	3	Receive audio signal	 SKIA0177E
	11	12		

Is the audio signal voltage as specified?

- YES >> Replace speaker. Refer to [AV-34, "Removal and Installation"](#).
- NO >> Replace audio unit. Refer to [AV-31, "Removal and Installation"](#).



FRONT TWEETER

Description

INFOID:000000008799443

The audio unit sends audio signals to the front tweeters using the front tweeter circuits.

Diagnosis Procedure

INFOID:000000008799444

Regarding Wiring Diagram information, refer to [AV-19, "Wiring Diagram"](#).

1.CONNECTOR CHECK

Check the audio unit and speaker connectors for the following:

- Proper connection
- Damage
- Disconnected or loose terminals

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair the terminal and connector.

2.HARNESS CHECK

1. Disconnect audio unit connector M43 and suspect front tweeter connector.
2. Check continuity between audio unit harness connector M43 (A) and suspect front tweeter harness connector (B).

A		B		Continuity
Connector	Terminal	Connector	Terminal	
M43	2	M109	1	Yes
	3		2	
	11	M111	1	
	12		2	

3. Check continuity between audio unit harness connector M43 (A) and ground.


A		—	Continuity
Connector	Terminal		
M43	2	Ground	No
	3		
	11		
	12		

Are the continuity results as specified?

YES >> GO TO 3

NO >> Repair harness or connector.

3.FRONT TWEETER SIGNAL CHECK




FRONT TWEETER

< DTC/CIRCUIT DIAGNOSIS >


[BASE AUDIO]

1. Connect audio unit connector M43 and front tweeter connector.
2. Turn ignition switch to ACC.
3. Push audio unit "POWER" switch.
4. Check the signal between audio unit harness connector M43 terminals with CONSULT or oscilloscope.

Con- nector	(+)		Condition	Reference signal
	Terminal	Terminal		
M43	2	3	Receive audio signal	
	11	12		

Is the audio signal voltage as specified?

- YES >> Replace the suspect front tweeter. Refer to [AV-33, "Removal and Installation"](#).
- NO >> Replace audio unit. Refer to [AV-31, "Removal and Installation"](#).



REAR DOOR SPEAKER

< DTC/CIRCUIT DIAGNOSIS >

[BASE AUDIO]

REAR DOOR SPEAKER

Description

INFOID:000000008799445

The audio unit sends audio signals to the rear door speakers using the rear door speaker circuits.

Diagnosis Procedure

INFOID:000000008799446

Regarding Wiring Diagram information, refer to [AV-19, "Wiring Diagram"](#).

1.CONNECTOR CHECK

Check the audio unit and speaker connectors for the following:

- Proper connection
- Damage
- Disconnected or loose terminals

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair the terminal and connector.

2.HARNESS CHECK

1. Disconnect audio unit connector M43 and suspect rear door speaker connector.
2. Check continuity between audio unit harness connector M43 (A) and suspect rear door speaker harness connector (B).

A		B		Continuity
Connector	Terminal	Connector	Terminal	
M43	4	D207	1	Yes
	5		2	
	13	D307	1	
	14		2	

3. Check continuity between audio unit harness connector M43 (A) and ground.


A		—	Continuity
Connector	Terminal		
M43	4	Ground	No
	5		
	13		
	14		

Are the continuity results as specified?

YES >> GO TO 3

NO >> Repair harness or connector.

3.REAR DOOR SPEAKER SIGNAL CHECK




REAR DOOR SPEAKER

[BASE AUDIO]

< DTC/CIRCUIT DIAGNOSIS >

1. Connect audio unit connector and rear door speaker connector.
2. Turn ignition switch to ACC.
3. Push audio unit "POWER" switch.
4. Check the signal between audio unit harness connector M43 terminals with CONSULT or oscilloscope.


Connector	(+)	(-)	Condition	Reference signal
	Terminal	Terminal		
M43	4	5	Receive audio signal	
	13	14		

SKIA0177E

Is the audio signal voltage as specified?

YES >> Replace the suspect rear door speaker. Refer to [AV-35. "Removal and Installation"](#).

NO >> Replace audio unit. Refer to [AV-31. "Removal and Installation"](#).



AWNIA00342Z


ECU DIAGNOSIS INFORMATION

AUDIO UNIT

Reference Value

INFOID:000000008799447

TERMINAL LAYOUT





PHYSICAL VALUES

Terminal (Wire color)		Description		Condition		Reference value (Approx.)
+	–	Signal name	Input/ Output			
2 (BR)	3 (L)	Sound signal front door speaker and front tweeter LH	Output	Ignition switch ON	Audio output	
4 (G)	5 (B)	Sound signal rear door speaker LH	Output	Ignition switch ON	Audio output	
7 (G/B)	Ground	ACC power supply	Input	Ignition switch ACC or ON	—	Battery voltage
8 (GR)	Ground	ILL control	Input	Ignition switch ACC or ON	—	0V
9 (R)	Ground	Light switch	Input	Ignition switch ACC or ON	—	Battery voltage

AUDIO UNIT


< ECU DIAGNOSIS INFORMATION >

[BASE AUDIO]

Terminal (Wire color)		Description		Condition		Reference value (Approx.)
+	—	Signal name	Input/ Output			
11 (LG)	12 (R)	Sound signal front door speaker and front tweeter RH	Output	Ignition switch ON	Audio output	 SKIB3609E
13 (GR)	14 (O)	Sound signal rear door speaker RH	Output	Ignition switch ON	Audio output	 SKIB3609E
19 (Y)	Ground	Battery power supply	Input	Ignition switch OFF	—	Battery voltage


Wiring Diagram

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P



BASE AUDIO SYSTEM CONNECTORS

Connector No.	M4
Connector Name	FUSE BLOCK (J/B)
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
4P	G/B	—

Connector No.	M8
Connector Name	WIRE TO WIRE
Connector Color	BROWN




Terminal No.	Color of Wire	Signal Name
2	L	—
3	BR	—

Connector No.	M17
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
11	GR	—
12	O	—

Connector No.	M31
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
77G	Y	—

Connector No.	M32
Connector Name	AUDIO UNIT (BASE AUDIO SYSTEM)
Connector Color	GRAY



Terminal No.	Color of Wire	Signal Name
21	—	—
22	B	ANT MAIN
23	—	—

Connector No.	M40
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
3J	G	—
8J	B	—

BASE AUDIO SYSTEM

< WIRING DIAGRAM >

[BASE AUDIO]

Connector No.	M75
Connector Name	WIRE TO WIRE
Connector Color	WHITE



5	4	3	2	1
12	11	10	9	8
7	6			

Terminal No.	Color of Wire	Signal Name
4	R	–
11	LG	–

Terminal No.	Color of Wire	Signal Name
9	R	LIGHT SW
10	–	–
11	LG	FR SP RH (+)
12	R	FR SP RH (-)
13	GR	RR SP RH (+)
14	O	RR SP RH (-)
15	–	–
16	–	–
17	–	–
18	–	–
19	Y	BAT
20	–	–

Connector No.	M43
Connector Name	AUDIO UNIT (WITH BASE AUDIO SYSTEM)
Connector Color	WHITE



1	2	3	4	5	6	7	8	9
19	10	11	12	13	14	15	16	17
18	20							

Terminal No.	Color of Wire	Signal Name
1	–	–
2	BR	FR SP LH (+)
3	L	FR SP LH (-)
4	G	RR SP LH (+)
5	B	RR SP LH (-)
6	–	–
7	G/B	ACC
8	GR	ILL CONT

Connector No.	M111
Connector Name	FRONT TWEETER RH
Connector Color	BROWN



2	1
---	---

Terminal No.	Color of Wire	Signal Name
1	W	–
2	L	– (WITH BASE AUDIO SYSTEM)

Connector No.	M109
Connector Name	FRONT TWEETER LH
Connector Color	BROWN



2	1
---	---

Terminal No.	Color of Wire	Signal Name
1	G	– (WITH BASE AUDIO SYSTEM)
2	L	– (WITH BASE AUDIO SYSTEM)

ABNIA2715GB



A
B
C
D
E
F
G
H
I
J
K
L
M
O
P

AV

BASE AUDIO SYSTEM

< WIRING DIAGRAM >

[BASE AUDIO]



ABNIA0557GB

BASE AUDIO SYSTEM

< WIRING DIAGRAM >


[BASE AUDIO]

Connector No.	D112
Connector Name	FRONT DOOR SPEAKER RH
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	W/B	-
2	L/B	-

Connector No.	D101
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
4	L/B	-
11	W/B	-

Connector No.	D12
Connector Name	FRONT DOOR SPEAKER LH
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
1	L/W	-
2	L/R	-

Connector No.	D201
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
5	L	-
12	O	-

Connector No.	D153
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
4	R	-
11	LG	-

Connector No.	D152
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
4	R	-
11	LG	-

ABNIA4250GB

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P


AV

Connector No.	D307
Connector Name	REAR DOOR SPEAKER RH
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	L	-
2	O	-

Connector No.	D301
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
5	L	-
12	O	-

Connector No.	D207
Connector Name	REAR DOOR SPEAKER LH
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	L	-
2	O	-

ABNIA4251GB

SYMPTOM DIAGNOSIS

AUDIO SYSTEM

Symptom Table

INFOID:000000009292199

AUDIO SYSTEM

Symptoms	Check items	Probable malfunction location
The disk cannot be removed.	Audio unit	Malfunction in audio unit. Refer to AV-31, "Removal and Installation" .
No sound comes out or the level of the sound is low.	No sound from all speakers.	- Speaker circuit shorted to ground. Refer to AV-19, "Wiring Diagram". - Audio unit power supply and ground circuits malfunction. Refer to AV-10, "AUDIO UNIT : Diagnosis Procedure".
	Only a certain speaker (front tweeter LH, front tweeter RH, front door speaker LH, front door speaker RH, rear door speaker LH, rear door speaker RH) does not output sound.	- Poor connector connection of speaker. - Sound signal circuit malfunction between audio unit and speaker. Refer to: AV-13, "Diagnosis Procedure" (front tweeter). AV-11, "Diagnosis Procedure" (front door speaker). AV-15, "Diagnosis Procedure" (rear door speaker). - Malfunction in speaker. Refer to: AV-33, "Removal and Installation" (front tweeter). AV-34, "Removal and Installation" (front door speaker). AV-35, "Removal and Installation" (rear door speaker). - Malfunction in audio unit. Refer to AV-31, "Removal and Installation".

A
B
C
D
E
F
G
H
I
J
K
L
M
O
P

AV

AUDIO SYSTEM

< SYMPTOM DIAGNOSIS >

[BASE AUDIO]

Symptoms	Check items	Probable malfunction location
Noise is mixed with audio.	Noise comes out from all speakers.	Malfunction in audio unit. Refer to AV-31, "Removal and Installation" .
	Noise comes out only from a certain speaker (front tweeter LH, front tweeter RH, front door speaker LH, front door speaker RH, rear door speaker LH, rear door speaker RH).	- Poor connector connection of speaker. - Sound signal circuit malfunction between audio unit and speaker. Refer to: AV-13, "Diagnosis Procedure" (front tweeter). AV-11, "Diagnosis Procedure" (front door speaker). AV-15, "Diagnosis Procedure" (rear door speaker). - Malfunction in speaker. - Poor Installation of speaker (e.g. backlash and looseness). Refer to: AV-33, "Removal and Installation" (front tweeter). AV-34, "Removal and Installation" (front door speaker). AV-35, "Removal and Installation" (rear door speaker). - Malfunction in audio unit. Refer to AV-31, "Removal and Installation".
	Noise is mixed with radio only (when the vehicle hits a bump or while driving over bad roads)	Poor connector connection of antenna or antenna feeder. Refer to AV-36, "Location of Audio Antenna System Component" .
No radio reception or poor reception.	- Other audio sounds are normal. - Any radio station cannot be received or poor reception is caused even after moving to a service area with good reception (e.g. a place with clear view and no obstacles generating external noises).	- Rod antenna is not fully connected to antenna base. - Antenna base/rod connection (thread zone) has foreign material or corrosion inside. - Poor connector connection of antenna or antenna feeder. Refer to AV-36, "Location of Audio Antenna System Component" .
Buzz/rattle sound from speaker	The majority of buzz/rattle sounds are not indicative of an issue with the speaker, usually something nearby the speaker is causing the buzz/rattle.	Refer to "SQUEAK AND RATTLE TROUBLE DIAGNOSIS" in the appropriate interior trim section.

NORMAL OPERATING CONDITION

< SYMPTOM DIAGNOSIS >

[BASE AUDIO]

NORMAL OPERATING CONDITION

Description

INFOID:000000009292200

The majority of the audio concerns are the result of outside causes (bad CD, electromagnetic interference, etc.).

NOISE

The following noise results from variations in field strength, such as fading noise and multi-path noise, or external noise from trains and other sources. It is not a malfunction.

- Fading noise: This noise occurs because of variations in the field strength in a narrow range due to mountains or buildings blocking the signal.
- Multi-path noise: This noise results from the waves sent directly from the broadcast station arriving at the antenna at a different time from the waves which reflect off mountains or buildings.

The vehicle itself can be a source of noise if noise prevention parts or electrical equipment is malfunctioning. Check if noise is caused and/or changed by engine speed, ignition switch turned to each position, and operation of each piece of electrical equipment to determine the cause.

NOTE:

The source of the noise can be found easily by listening to the noise while removing the fuses of electrical components, one by one.

Type of Noise and Possible Cause

Occurrence condition		Possible cause
Occurs only when engine is ON.	A continuous growling noise occurs. The speed of the noise varies with changes in the engine speed.	• Ignition components
The occurrence of the noise is linked with the operation of the fuel pump.		• Fuel pump condenser
Noise only occurs when various electrical components are operating.	A cracking or snapping sound occurs with the operation of various switches.	• Relay malfunction, audio unit malfunction
	The noise occurs when various motors are operating.	• Motor case ground • Motor
The noise occurs constantly, not just under certain conditions.		Poor ground of antenna feeder line
A cracking or snapping sound occurs while the vehicle is being driven, especially when it is vibrating excessively.		• Ground wire of body parts • Ground due to improper part installation • Wiring connections or a short circuit

PRECAUTION

PRECAUTIONS

Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"

INFOID:000000008799451

The Supplemental Restraint System such as "AIR BAG" and "SEAT BELT PRE-TENSIONER", used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. This system includes seat belt switch inputs and dual stage front air bag modules. The SRS system uses the seat belt switches to determine the front air bag deployment, and may only deploy one front air bag, depending on the severity of a collision and whether the front occupants are belted or unbelted. Information necessary to service the system safely is included in the SR and SB section of this Service Manual.

WARNING:

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision which would result in air bag inflation, all maintenance must be performed by an authorized NISSAN/INFINITI dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see the SR section.
- Do not use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harnesses or harness connectors.

PRECAUTIONS WHEN USING POWER TOOLS (AIR OR ELECTRIC) AND HAMMERS


WARNING:

- When working near the Airbag Diagnosis Sensor Unit or other Airbag System sensors with the Ignition ON or engine running, DO NOT use air or electric power tools or strike near the sensor(s) with a hammer. Heavy vibration could activate the sensor(s) and deploy the air bag(s), possibly causing serious injury.
- When using air or electric power tools or hammers, always switch the Ignition OFF, disconnect the battery, and wait at least 3 minutes before performing any service.

Precaution for Procedure without Cowl Top Cover

INFOID:000000008799452

When performing the procedure after removing cowl top cover, cover the lower end of windshield with urethane, etc.



Precaution for Work

INFOID:000000008799453

- When removing or disassembling each component, be careful not to damage or deform it. If a component may be subject to interference, be sure to protect it with a shop cloth.
- When removing (disengaging) components with a screwdriver or similar tool, be sure to wrap the component with a shop cloth or vinyl tape to protect it.
- Protect the removed parts with a shop cloth and prevent them from being dropped.
- Replace a deformed or damaged clip.
- If a part is specified as a non-reusable part, always replace it with a new one.
- Be sure to tighten bolts and nuts securely to the specified torque.
- After installation is complete, be sure to check that each part works properly.
- Follow the steps below to clean components:
 - Water soluble dirt:

PRECAUTIONS

< PRECAUTION >

[BASE AUDIO]

- Dip a soft cloth into lukewarm water, wring the water out of the cloth and wipe the dirty area.
- Then rub with a soft, dry cloth.
- Oily dirt:
- Dip a soft cloth into lukewarm water with mild detergent (concentration: within 2 to 3%) and wipe the dirty area.
- Then dip a cloth into fresh water, wring the water out of the cloth and wipe the detergent off.
- Then rub with a soft, dry cloth.
- Do not use organic solvent such as thinner, benzene, alcohol or gasoline.
- For genuine leather seats, use a genuine leather seat cleaner.

A

B

C

D

E

F

G

H

I

J

K

L

M

AV

O

P

PREPARATION

< PREPARATION >

[BASE AUDIO]


PREPARATION

PREPARATION

Special Service Tool

INFOID:000000008799454

The actual shapes of Kent-Moore tools may differ from those of special service tools illustrated here.

Tool number (Kent-Moore No.) Tool name	Description
— (J-46534) Trim Tool Set	Removing trim components
 AWJIA04832Z	

Commercial Service Tools

INFOID:000000008799455

Tool name	Description
Power tool	Loosening nuts, screws and bolts
 PIIB1407E	

REMOVAL AND INSTALLATION


AUDIO UNIT

Removal and Installation


INFOID:000000008799456

REMOVAL


1. Remove cluster lid C. Refer to [IP-15. "Removal and Installation"](#).
2. Remove the ventilator grilles (LH/RH). Refer to [VTL-22. "Removal and Installation"](#).
3. Remove the audio unit assembly screws (A).



4. Remove the audio unit bracket screws (A).



5. Remove the audio unit bracket screws (A) using power tool and the audio unit brackets (LH/RH).




AUDIO UNIT


< REMOVAL AND INSTALLATION >

[BASE AUDIO]

6. Remove the audio unit screws (A) using power tool.



7. Release the audio unit tab (A) and remove the audio unit (1).



INSTALLATION

Installation is in the reverse order of removal.

FRONT TWEETER


Removal and Installation

INFOID:000000008799458

REMOVAL

CAUTION:**Use a suitable tool to prevent damage to the front tweeter grille and the instrument panel.**

1. Remove the front tweeter grille.
2. Remove the front tweeter screws (A).
3. Pull out the front tweeter (1), then disconnect the harness connector from the front tweeter and remove.



INSTALLATION

Installation is in the reverse order of removal.

A
B
C
D
E
F
G
H
I
J
K
L
M
O
P

AV


FRONT DOOR SPEAKER

Removal and Installation

INFOID:000000008799459

REMOVAL

1. Remove the front door finisher. Refer to [INT-14, "Removal and Installation"](#).
2. Remove the front door speaker screws (A).
3. Pull out the front door speaker (1).
4. Disconnect the harness connector from the front door speaker (1) and remove.



INSTALLATION

Installation is in the reverse order of removal.

REAR DOOR SPEAKER

< REMOVAL AND INSTALLATION >

[BASE AUDIO]


REAR DOOR SPEAKER

Removal and Installation

INFOID:000000008799460

REMOVAL

1. Remove the rear door finisher. Refer to [INT-14. "Removal and Installation"](#).
2. Remove the rear door speaker screws (A).
3. Disconnect the harness connector (B) from the rear door speaker (1) and remove.



INSTALLATION

Installation is in the reverse order of removal.


A
B
C
D
E
F
G
H
I
J
K
L
M
O
P

AV

AUDIO ANTENNA

Location of Audio Antenna System Component

INFOID:000000008799461



1. Audio antenna

2. Antenna feeder


3. Audio unit

Removal and Installation

INFOID:000000008799462

REMOVAL

1. Remove lower glove box. Refer to [IP-20, "Removal and Installation"](#).
2. Remove audio unit. Refer to [AV-31, "Removal and Installation"](#).
3. Disconnect audio antenna cable from antenna feeder.
4. Remove antenna rod.
5. Remove rubber seal.
6. Remove cowl top. Refer to [EXT-20, "Removal and Installation"](#).
7. Remove front fender protector. Refer to [EXT-22, "Removal and Installation"](#).
8. Remove antenna base bolts.
9. Remove antenna base and cable.



INSTALLATION

Installation is in the reverse order of removal.

CAUTION:

Always properly tighten the antenna rod during installation or the antenna rod may bend or break during vehicle operation.

COMPONENT PARTS

< SYSTEM DESCRIPTION >


[DISPLAY AUDIO WITHOUT AMPLIFIER]

SYSTEM DESCRIPTION

COMPONENT PARTS

Component Parts Location

INFOID:000000009291949



AWNIA29352Z

- | | | |
|---|--|--|
| 1. Front tweeter LH M109 | 2. Steering wheel audio control switches | 3. Audio unit M41, M44, M45, M64 |
| 4. Front tweeter RH M111 | 5. Microphone R8 | 6. Front door speaker LH D12
Front door speaker RH D112 |
| 7. Rear door speaker LH D207
Rear door speaker RH D307 | 8. Bluetooth® control unit B141, B142,
B143 (Underneath passenger seat) | 9. Bluetooth® antenna |
| 10. USB interface M214 | 11. Satellite antenna | 12. Rod antenna |

Component Description

INFOID:000000009291950

Part name	Description
Audio unit	- Controls audio, USB connection, AUX IN connection and satellite radio. - Display unit is built in to audio unit.
Front door speakers	Outputs high, mid and low range audio signals from audio unit.
Rear door speakers	
Front tweeters	
Steering wheel audio control switches	- Operations for audio, hands-free phone and voice recognition are possible. - Steering switch signal is output to Bluetooth® control unit. - Bluetooth® control unit outputs steering switch signal to audio unit.

COMPONENT PARTS

< SYSTEM DESCRIPTION >

[DISPLAY AUDIO WITHOUT AMPLIFIER]

Part name	Description
Microphone	• Used for hands-free phone operations. • Microphone signal is transmitted to Bluetooth® control unit. • Power is supplied from Bluetooth® control unit.
Bluetooth® control unit	• Inputs TEL voice signal from Bluetooth® antenna and outputs it to audio unit. • Controlled via AV communication by audio unit.
Bluetooth® antenna	Receives TEL voice signal and outputs it to Bluetooth® control unit.
USB interface	USB sound and data input signals are transmitted to audio unit.
Satellite antenna	Satellite radio signal is received and transmitted to audio unit.
Rod antenna	AM/FM signal is received and transmitted to the audio unit.


SYSTEM

< SYSTEM DESCRIPTION >

[DISPLAY AUDIO WITHOUT AMPLIFIER]

SYSTEM

System Diagram



INFOID:000000009291951

System Description

INFOID:000000009291952

AUDIO SYSTEM

The audio system consists of the following components

- Audio unit
- Front door speakers
- Front tweeters
- Rear door speakers
- Steering wheel audio control switches
- USB interface
- Rod antenna

When the audio system is on, AM/FM signals received by the rod antenna are sent to the audio unit. The audio unit then sends audio signals to the front door speakers, front tweeters and rear door speakers.

Refer to Owner's Manual for audio system operating instructions.

SATELLITE RADIO SYSTEM

The satellite radio system consists of the following components

- Satellite antenna
- Satellite radio tuner integral to the audio unit

When the satellite radio system is on, satellite radio signals are supplied to the audio unit from the satellite antenna. The audio unit then sends audio signals to the speakers.

Refer to Owner's Manual for satellite radio system operating instructions.

HANDS-FREE PHONE SYSTEM

System Operation

NOTE:

Cellular telephones must have their wireless connection set up (paired) before using the Bluetooth® telephone system.

The Bluetooth® telephone system allows users who have a Bluetooth® cellular telephone to make a wireless connection between their cellular telephone and the Bluetooth® control unit. Hands-free cellular telephone calls can be sent and received. Some Bluetooth® cellular telephones may not be recognized by the Bluetooth® control unit. When a cellular telephone or the Bluetooth® control unit is replaced, the telephone must be paired with the Bluetooth® control unit. Different cellular telephones may have different pairing procedures, refer to the cellular telephone operating manual.

Refer to the Owner's Manual for Bluetooth® telephone system operating instructions.

Bluetooth® Control Unit

When the ignition switch is turned to ACC or ON, the Bluetooth® control unit will power up. During power up, the Bluetooth® control unit is initialized and performs various self-checks. Initialization may take up to 20 seconds. If a phone is present in the vehicle and paired with the Bluetooth® control unit, Nissan Voice Recognition will then become active. Bluetooth® telephone functions can be turned off using the Nissan Voice Recognition system.

Steering Wheel Audio Control Switches

When buttons on the steering wheel audio control switch are pushed, the resistance in steering wheel audio control switch circuit changes, depending on which button is pushed. The Bluetooth® control unit uses this signal to perform various functions while navigating through the voice recognition system.

The following functions can be performed using the steering wheel audio control switch:

- Initiate self-diagnosis of the Bluetooth® telephone system
- Start a voice recognition session
- Answer and end telephone calls
- Adjust the volume of calls

Microphone

The microphone is located in the roof console assembly. The microphone sends a signal to the Bluetooth® control unit. The microphone can be actively tested during self-diagnosis.

Audio Unit

The audio unit receives signals from the Bluetooth® control unit and sends audio signals to the speakers.

DIAGNOSIS SYSTEM (AUDIO UNIT)

< SYSTEM DESCRIPTION >

[DISPLAY AUDIO WITHOUT AMPLIFIER]

DIAGNOSIS SYSTEM (AUDIO UNIT)

Description

INFOID:000000009291953

The audio unit on board diagnosis performs the functions listed in the table below:

Mode		Description
Self Diagnosis		• Audio unit diagnosis. • Diagnoses the connections across system components.
Confirmation/ Adjustment	Display Diagnosis	The following check functions are available: color tone check by color bar display and white display, light and shade check by gray scale display.
	Vehicle Signals	Diagnosis of signals can be performed for vehicle speed, lights, reverse, EQ pin, destination.
	Speaker Test	The connection of a speaker can be confirmed by test tone.
	Error History	The system malfunction and the frequency when occurring in the past are displayed. When the malfunctioning item is selected, the time and place that the selected malfunction last occurred are displayed.
	AV COMM Diagnosis	The communication condition of each unit of display audio system can be monitored.
	Delete Unit Connection Log	Erase the connection history of unit and error history.
	Initialize Setting	Initializes the audio unit memory.


On Board Diagnosis Function

INFOID:000000009291954

SELF DIAGNOSIS MODE

Audio Unit Self Diagnosis

1. Select Self Diagnosis.
2. Self diagnosis screen is displayed. The bar graph visible in center of screen indicates progress of self diagnosis.
3. Diagnosis results are displayed after the self diagnosis is completed. The unit names and the connection lines are color coded according to the diagnostic results.



Diagnosis results	Unit	Connection line
Normal	Green	Green
Connection malfunction	Gray	Yellow
Unit malfunction ¹	Red	Green

1: Control unit (audio unit) is displayed in red.


- Replace audio unit if Self Diagnosis did not run because control unit malfunction is indicated. The symptom is audio unit internal error. Refer to [AV-88. "Removal and Installation"](#).
- If multiple errors occur at the same time for a single unit, the screen switch colors are determined according to the following order of priority: red > gray.

DIAGNOSIS SYSTEM (AUDIO UNIT)

[DISPLAY AUDIO WITHOUT AMPLIFIER]

< SYSTEM DESCRIPTION >

- Comments of self diagnosis results can be viewed in the diagnosis result screen.




Audio Unit Self Diagnosis Results

Only Unit Part Is Displayed In Red		
Screen switch	Description	Possible cause
Control unit	Malfunction is detected in audio unit power supply and ground circuits.	- Audio unit power supply or ground circuits. Refer to AV-66, "AUDIO UNIT : Diagnosis Procedure". - If no malfunction is detected in audio unit power supply and ground circuits, replace audio unit. Refer to AV-88, "Removal and Installation".
A Connecting Cable Between Units Is Displayed In Yellow		
Area with yellow connection lines	Description	Possible cause
Control unit ↔ BTHF	When one of the following is detected: - malfunction is detected in Bluetooth® control unit power supply and ground circuits. - malfunction is detected in AV communication circuits between audio unit and Bluetooth® control unit.	- Bluetooth® control unit power supply or ground circuits. Refer to AV-66, "BLUETOOTH® CONTROL UNIT : Diagnosis Procedure". - AV communication circuits between audio unit and Bluetooth® control unit.

Audio Unit Confirmation/Adjustment

- Select Confirmation/Adjustment.
- Select each switch on the Confirmation/Adjustment screen to display the relevant trouble diagnosis screen. Press the BACK switch to return to the initial Confirmation/Adjustment screen.




DIAGNOSIS SYSTEM (AUDIO UNIT)

< SYSTEM DESCRIPTION >


[DISPLAY AUDIO WITHOUT AMPLIFIER]

Display Diagnosis




Vehicle Signals

A comparison check can be made of each actual vehicle signal and the signals recognized by the system.



Speaker Test

Select Speaker Test to display the Speaker Diagnosis screen. Press Start to generate a test tone in a speaker. Press Start again to generate a test tone in the next speaker. Press End to stop the test tones.



Error History

The self diagnosis results are judged depending on whether any error occurs from when Self Diagnosis is selected until the self diagnosis results are displayed.

However, the diagnosis results are judged normal if an error has occurred before the ignition switch is turned ON and then no error has occurred until the self diagnosis start. Check the Error Record to detect any error that may have occurred before the self diagnosis start because of this situation.

The frequency of occurrence is displayed in a count up manner. The actual count up method differs depending on the error item.

Count up method A

- The counter is set to 40 if an error occurs. 1 is subtracted from the counter if the condition is normal at a next ignition ON cycle.
- The counter lower limit is 1. The counter can be reset (no error record display) with the Delete log switch.

Count up method B


DIAGNOSIS SYSTEM (AUDIO UNIT)

[DISPLAY AUDIO WITHOUT AMPLIFIER]

< SYSTEM DESCRIPTION >

- The counter increases by 1 if an error occurs when ignition switch is ON. The counter will not decrease even if the condition is normal at the next ignition ON cycle.
- The counter upper limit is 50. Any counts exceeding 50 are ignored. The counter can be reset (no error record display) with the Delete log switch.

Display type of occurrence frequency	Error history display item
Count up method A	AV communication line, control unit (AV)
Count up method B	Other than the above



Error item

Some error items may be displayed simultaneously according to the cause. If some error items are displayed simultaneously, the detection of the cause can be performed by the combination of display items

Error item	Description	Possible cause
CONTROL UNIT (AV)	AV communication circuit initial diagnosis malfunction is detected.	Replace the audio unit if the malfunction occurs constantly. Refer to AV-88, "Removal and Installation" .
• AV COMM CIRCUIT • H/F Unit Connection Error	When one of the following is detected: • malfunction is detected in Bluetooth® control unit power supply and ground circuits. • malfunction is detected in AV communication circuits between audio unit and Bluetooth® control unit.	• Bluetooth® control unit power supply or ground circuits. Refer to AV-66, "BLUETOOTH® CONTROL UNIT : Diagnosis Procedure". • AV communication circuits between audio unit and Bluetooth® control unit.


AV COMM Diagnosis

- Displays the communication status between audio unit (master unit) and each unit.
- The error counter displays OK if any malfunction was not detected in the past and displays 0 if a malfunction is detected. It increases by 1 if the condition is normal at the next ignition switch ON cycle. The upper limit of the counter is 39.
- The error counter is erased if Reset is pressed.

Items	Status (Current)	Counter (Past)
C Rx(BTHF-ITM)	OK / ???	OK / 0 – 39

NOTE:

"???" indicates UNKNWN.




DIAGNOSIS SYSTEM (AUDIO UNIT)

< SYSTEM DESCRIPTION >

[DISPLAY AUDIO WITHOUT AMPLIFIER]


Delete Unit Connection Log

Deletes any unit connection records and error records from the audio unit memory (clears the records of the unit that has been removed).



Initialize Settings

Deletes data stored from the audio unit.



A

B

C

D

E

F

G

H

I

J

K

L

M

AV

O

P

AUDIO UNIT

< ECU DIAGNOSIS INFORMATION >

[DISPLAY AUDIO WITHOUT AMPLIFIER]


ECU DIAGNOSIS INFORMATION

AUDIO UNIT



Reference Value

INFOID:000000009291955

TERMINAL LAYOUT






PHYSICAL VALUES

Terminal (Wire color)		Description		Condition		Reference value (Approx.)
+	–	Signal name	Input/ Output	Ignition switch	Operation	
2 (BR)	3 (L)	Sound signal front speaker LH	Output	ON	Sound output	 SKIB3609E
4 (G)	5 (B)	Sound signal rear speaker LH	Output	ON	Sound output	 SKIB3609E
6 (V)	Ground	STRG SW A	Input	ON	Press and hold MODE switch.	0 V
					Press and hold △ switch.	1.34 V
					Press and hold ▽ switch.	2.45 V
					Press and hold  switch.	3.43 V
					Except for above.	5.0 V
7 (G/B)	Ground	ACC power supply	Input	ACC	—	Battery voltage
9 (R)	8 (GR)	Illumination control signal	Input	ON	Headlamps ON	Battery voltage

AUDIO UNIT

< ECU DIAGNOSIS INFORMATION >

[DISPLAY AUDIO WITHOUT AMPLIFIER]

Terminal (Wire color)		Description		Condition		Reference value (Approx.)
+	—	Signal name	Input/ Output	Ignition switch	Operation	
11 (LG)	12 (R)	Sound signal front speaker RH	Output	ON	Sound output	 SKIB3609E
13 (GR)	14 (O)	Sound signal rear speaker RH	Output	ON	Sound output	 SKIB3609E
15 (O)	—	STRG SW ground	Output	—	—	—
16 (LG)	Ground	STRG SW B	Input	ON	Press VOL DOWN switch	0 V
					Press VOL UP switch.	1.34 V
					Press  switch.	2.45 V
					Except for above.	5.0 V
18 (SB)	Ground	Vehicle speed signal	Input	ON	When vehicle speed is ap- prox. 40 km/h (25 MPH)	 JSNIA0012GB
19 (Y)	Ground	Battery power supply	Input	OFF	—	Battery voltage
20 (B)	—	GND	—	—	—	—
25 (W)	24 (B)	Telephone audio in	—	—	—	0 V
28 (R)	—	MCAN2 H	—	—	—	—
29 (G)	—	MCAN2 L	—	—	—	—
30	—	MCAN shield	—	—	—	—
31 (L)	—	MCAN1 H	—	—	—	—
32 (W)	—	MCAN1 L	—	—	—	—
46 (B)	—	EQ2	—	—	—	—
48 (B)	—	EQ3	—	—	—	—
53 (R)	—	V BUS signal	—	—	—	—

A

B

C

D

E

F

G

H

I

J

K

L

M

AV

O

P

AUDIO UNIT

< ECU DIAGNOSIS INFORMATION >

[DISPLAY AUDIO WITHOUT AMPLIFIER]

Terminal (Wire color)		Description		Condition		Reference value (Approx.)
+	—	Signal name	Input/ Output	Ignition switch	Operation	
54 (B)	—	USB ground	—	—	—	—
55 (G)	—	USB D+	—	—	—	—
56 (W)	—	USB D-	—	—	—	—
57	—	Shield	—	—	—	—
58 (B)	Ground	Satellite antenna signal	Input	ON	—	5.0 V
59 (B)	—	SAT Shield	—	—	—	—
61 (B)	Ground	AM-FM main antenna	—	—	—	—

BLUETOOTH® CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >


[DISPLAY AUDIO WITHOUT AMPLIFIER]

BLUETOOTH® CONTROL UNIT


Reference Value

INFOID:000000009291956

TERMINAL LAYOUT




PHYSICAL VALUES

Terminal (wire color)		Description		Condition		Reference value (Approx.)
+	–	Signal name	Input/ output	Ignition switch	Condition	
1 (R/B)	Ground	Battery power	Input	–	–	Battery voltage
2 (G/Y)	Ground	ACC power	Input	ACC or ON	–	Battery voltage
3 (W/G)	Ground	IGN power	Input	ON or START	–	Battery voltage
4 (B)	Ground	Ground	–	ON	–	0V
6	–	MIC Shield	–	–	–	–
7 (G)	8 (L)	MIC in signal	Input	–	–	–
9 (W)	10 (B)	Audio out	Output	ACC or ON	Bluetooth control unit sends audio signal	
12 (BR)	Ground	Ladder in 1	Input	ACC or ON	Press and hold MODE switch.	0 V
					Press and hold △ switch.	1.34 V
					Press and hold ▽ switch.	2.45 V
					Press and hold ⚡ switch.	3.43 V
					Except for above.	5.0 V
13 (L)	Ground	Ladder in 2	Input	ACC or ON	Press VOL DOWN switch	0 V
					Press VOL UP switch.	1.34 V
					Press ⚡ switch.	2.45 V
					Except for above.	5.0 V

BLUETOOTH® CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >

[DISPLAY AUDIO WITHOUT AMPLIFIER]

Terminal (wire color)		Description		Condition		Reference value (Approx.)
+	–	Signal name	Input/ output	Ignition switch	Condition	
14 (G)	-	Ladder in ground	Input	-	-	-
17 (V)	Ground	Ladder out 1	Input	ACC or ON	Press and hold MODE switch.	0 V
					Press and hold Δ switch.	1.34 V
					Press and hold ∇ switch.	2.45 V
					Press and hold  switch.	3.43 V
					Except for above.	5.0 V
18 (LG)	Ground	Ladder out 2	Input	ACC or ON	Press VOL DOWN switch	0 V
					Press VOL UP switch.	1.34 V
					Press  switch.	2.45 V
					Except for above.	5.0 V
19 (O)	Ground	Ladder out ground	Output	–	–	–
21 (B)	Ground	Cont 2	–	–	–	0V
22 (B)	Ground	Cont 3	–	–	–	0V
23 (B)	Ground	Cont 4	–	–	–	0V
28 (SB)	Ground	Vehicle speed signal (8-pulse)	Input	ON	When vehicle speed is approx. 40 km/h (25 MPH)	
29 (Y)	Ground	Microphone power	Output	ON	–	5V
33 (B)	–	Bluetooth antenna	–	–	–	–
34	–	Bluetooth antenna shield	–	–	–	–
35 (R)	–	MCAN H	–	–	–	–
36 (G)	–	MCAN L	–	–	–	–
37	–	MCAN shield	–	–	–	–

DISPLAY AUDIO WITHOUT AMPLIFIER


< WIRING DIAGRAM >

[DISPLAY AUDIO WITHOUT AMPLIFIER]

WIRING DIAGRAM

DISPLAY AUDIO WITHOUT AMPLIFIER


Wiring Diagram



DISPLAY AUDIO WITHOUT AMPLIFIER

< WIRING DIAGRAM >

[DISPLAY AUDIO WITHOUT AMPLIFIER]




DISPLAY AUDIO WITHOUT AMPLIFIER

< WIRING DIAGRAM >

[DISPLAY AUDIO WITHOUT AMPLIFIER]

DISPLAY AUDIO WITHOUT AMPLIFIER CONNECTORS

Connector No.	M1
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	Y	– (WITHOUT NAVI)
13	SHIELD	–
14	G	– (WITHOUT NAVI)
15	L	– (WITHOUT NAVI)

Connector No.	M4
Connector Name	FUSE BLOCK (J/B)
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
2P	W/G	–
4P	G/B	–

Connector No.	M8
Connector Name	WIRE TO WIRE
Connector Color	BROWN




Terminal No.	Color of Wire	Signal Name
2	L	–
3	BR	–

Connector No.	M17
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
11	GR	–
12	O	–

Connector No.	M24
Connector Name	COMBINATION METER
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
6	SB	SPEED OUT 8

Connector No.	M30
Connector Name	COMBINATION SWITCH (SPIRAL CABLE)
Connector Color	GRAY




Terminal No.	Color of Wire	Signal Name
24	BR	–
25	L	– (WITHOUT NAVI)
31	G	–

DISPLAY AUDIO WITHOUT AMPLIFIER

< WIRING DIAGRAM >


[DISPLAY AUDIO WITHOUT AMPLIFIER]

Connector No.	M33
Connector Name	AUDIO UNIT (WITH DISPLAY AUDIO WITHOUT AMPLIFIER)
Connector Color	GRAY



Terminal No.	Color of Wire	Signal Name
60	—	—
61	B	ANT MAIN
62	—	—

Connector No.	M31
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
77G	Y	—

Terminal No.	Color of Wire	Signal Name
44M	LG	—
45M	L	—
46M	G	—
47M	SB	—
49M	R	—
50M	G	—

Terminal No.	Color of Wire	Signal Name
5M	R/B	—
10M	G/Y	—
31M	B	—
34M	V	—
35M	BR	—
36M	SHIELD	—
37M	W/G	—
38M	G	—
39M	SHIELD	—
40M	L	—
41M	Y	—
42M	W	—
43M	O	—

Connector No.	M36
Connector Name	WIRE TO WIRE
Connector Color	WHITE




ABNIA4265GB

DISPLAY AUDIO WITHOUT AMPLIFIER

< WIRING DIAGRAM >

[DISPLAY AUDIO WITHOUT AMPLIFIER]


Connector No.	M41
Connector Name	AUDIO UNIT (WITH DISPLAY AUDIO WITHOUT AMPLIFIER)
Connector Color	PINK



Terminal No.	Color of Wire	Signal Name
58	B	SAT ANT
59	SHIELD	SAT SHIELD


Terminal No.	Color of Wire	Signal Name
3J	G	-
8J	B	-

Connector No.	M40
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
7	G/B	ACC
8	GR	ILL (-)
9	R	ILL (+)
10	-	-
11	LG	FR SP RH (+)
12	R	FR SP RH (-)
13	GR	RR SP RH (+)
14	O	RR SP RH (-)
15	O	STRG SW GND
16	LG	STRG SW B
17	-	-
18	SB	SPD
19	Y	+B
20	B	GND

Connector No.	M44
Connector Name	AUDIO UNIT (WITH DISPLAY AUDIO WITHOUT AMPLIFIER)
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	-	-
2	BR	FR SP LH (+)
3	L	FR SP LH (-)
4	G	RR SP LH (+)
5	B	RR SP LH (-)
6	V	STRG SW A

ABNIA4266GB

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P

AV

DISPLAY AUDIO WITHOUT AMPLIFIER

< WIRING DIAGRAM >

[DISPLAY AUDIO WITHOUT AMPLIFIER]

Terminal No.	Color of Wire	Signal Name
40	-	-
41	-	-
42	-	-
43	-	-
44	-	-
45	-	-
46	B	EQ2
47	-	-
48	B	EQ3
49	-	-
50	-	-
51	-	-
52	-	-

Terminal No.	Color of Wire	Signal Name
26	-	-
27	-	-
28	R	MCAN2 H
29	G	MCAN2 L
30	SHIELD	MCAN GND
31	L	MCAN1 H
32	W	MCAN1 L
33	-	-
34	-	-
35	-	-
36	-	-
37	-	-
38	-	-
39	-	-

Connector No.	M45
Connector Name	AUDIO UNIT (WITH DISPLAY AUDIO WITHOUT AMPLIFIER)
Connector Color	WHITE

36	35	34	33	32	31	30	29	28	27	26	25	24	23	22	21
52	51	50	49	48	47	46	45	44	43	42	41	40	39	38	37




Terminal No.	Color of Wire	Signal Name
21	-	-
22	-	-
23	-	-
24	B	TEL VOICE (-)
25	W	TEL VOICE (+)

Connector No.	M75
Connector Name	WIRE TO WIRE
Connector Color	WHITE

5	4		3	2	1	
12	11	10	9	8	7	6



Connector No.	M67
Connector Name	WIRE TO WIRE
Connector Color	PINK



Connector No.	M64
Connector Name	AUDIO UNIT (WITH DISPLAY AUDIO WITHOUT AMPLIFIER)
Connector Color	GREEN

54	53	52	51	50	49	48	47	46	45	44	43	42	41	40	39	38	37
----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----



Terminal No.	Color of Wire	Signal Name
4	R	-
11	LG	-

Terminal No.	Color of Wire	Signal Name
1	B	-
2	SHIELD	-

Terminal No.	Color of Wire	Signal Name
53	R	VBUS
54	B	USB GND
55	G	USB D+
56	W	USB D-
57	SHIELD	SHIELD

ABNIA4267GB

DISPLAY AUDIO WITHOUT AMPLIFIER

< WIRING DIAGRAM >

[DISPLAY AUDIO WITHOUT AMPLIFIER]

Connector No.	M111
Connector Name	FRONT TWEETER RH
Connector Color	BROWN



Terminal No.	Color of Wire	Signal Name
1	W	—
2	P	— (EXCEPT BASE AUDIO SYSTEM)

Connector No.	M109
Connector Name	FRONT TWEETER LH
Connector Color	BROWN



Terminal No.	Color of Wire	Signal Name
1	Y	— (EXCEPT BASE AUDIO SYSTEM)
2	GR	— (EXCEPT BASE AUDIO SYSTEM)

Connector No.	M102
Connector Name	COMBINATION SWITCH (SPIRAL CABLE)
Connector Color	GRAY




Terminal No.	Color of Wire	Signal Name
15	GR	—
16	G	—
18	B	—

Connector No.	M214
Connector Name	USB INTERFACE
Connector Color	BLUE




Terminal No.	Color of Wire	Signal Name
1	B	—
2	G	—
3	W	—
4	R	—
5	SHIELD	—

Connector No.	M205
Connector Name	WIRE TO WIRE
Connector Color	BLUE



Terminal No.	Color of Wire	Signal Name
1	SHIELD	—
2	B	—
3	R	—
4	W	—
5	G	—

Connector No.	M169
Connector Name	WIRE TO WIRE
Connector Color	BLUE



Terminal No.	Color of Wire	Signal Name
1	SHIELD	—
2	B	—
3	R	—
4	W	—
5	G	—


ABNIA4268GB

DISPLAY AUDIO WITHOUT AMPLIFIER

< WIRING DIAGRAM >


[DISPLAY AUDIO WITHOUT AMPLIFIER]

Connector No.	M501
Connector Name	SATELLITE ANTENNA
Connector Color	BROWN



Terminal No.	Color of Wire	Signal Name
1	B	-
2	SHIELD	-

Connector No.	M500
Connector Name	WIRE TO WIRE
Connector Color	PINK



Terminal No.	Color of Wire	Signal Name
1	B	-
2	SHIELD	-


Connector No.	B6
Connector Name	WIRE TO WIRE
Connector Color	WHITE



1	2	3	4	5
6	7	8	9	10
11	12			

Terminal No.	Color of Wire	Signal Name
77G	Y	-

Connector No.	E152
Connector Name	WIRE TO WIRE
Connector Color	WHITE



ABNIA4269GB

DISPLAY AUDIO WITHOUT AMPLIFIER

< WIRING DIAGRAM >

[DISPLAY AUDIO WITHOUT AMPLIFIER]

Connector No.	B106
Connector Name	WIRE TO WIRE
Connector Color	WHITE

1	2	3	4	5
6	7	8	9	10
11	12			




Terminal No.	Color of Wire	Signal Name
5	GR	—
12	O	—

Terminal No.	Color of Wire	Signal Name
3J	G	—
8J	B	—

Connector No.	B69
Connector Name	WIRE TO WIRE
Connector Color	WHITE

1J	2J	3J	4J	5J
6J	7J	8J	9J	10J



Terminal No.	Color of Wire	Signal Name
21	B	CONT 2
22	B	CONT 3
23	B	CONT 4
24	—	—
25	—	—
26	—	—
27	—	—
28	SB	SPEED SIGNAL
29	Y	MIC POWER
30	—	—
31	—	—
32	—	—

Terminal No.	Color of Wire	Signal Name
6	SHIELD	MIC SHIELD
7	G	MIC IN+
8	L	MIC IN-
9	W	AUDIO OUT+
10	B	AUDIO OUT-
11	—	—
12	BR	LADDER IN 1
13	L	LADDER IN 2
14	G	LADDER IN GND
15	—	—
16	—	—
17	V	LADDER OUT 1
18	LG	LADDER OUT 2
19	O	LADDER OUT GND
20	—	—

Connector No.	B141
Connector Name	BLUETOOTH® CONTROL UNIT
Connector Color	WHITE



2	4	6	8	10	12	14	16	18	20	22	24	26	28	30	32
1	3	5	7	9	11	13	15	17	19	21	23	25	27	29	31

Terminal No.	Color of Wire	Signal Name
1	R/B	BATT
2	G/Y	ACC
3	W/G	IGN
4	B	GND
5	—	—

ABNIA4270GB

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P

AV


DISPLAY AUDIO WITHOUT AMPLIFIER

< WIRING DIAGRAM >

[DISPLAY AUDIO WITHOUT AMPLIFIER]

Terminal No.	Color of Wire	Signal Name
35	R	CAN-H1
36	G	CAN-L1
37	SHIELD	CAN SHIELD 1
38	-	-
39	-	-
40	-	-
41	-	-
42	-	-

Connector No.	B143
Connector Name	BLUETOOTH® CONTROL UNIT
Connector Color	WHITE



Connector No.	B142
Connector Name	BLUETOOTH® CONTROL UNIT
Connector Color	BLACK




Terminal No.	Color of Wire	Signal Name
33	B	BT ANTENNA
34	SHIELD	BT ANTENNA SHIELD

Terminal No.	Color of Wire	Signal Name
41M	Y	-
42M	W	-
43M	O	-
44M	LG	-
45M	L	-
46M	G	-
47M	SB	-
49M	R	-
50M	G	-

Terminal No.	Color of Wire	Signal Name
5M	R/B	-
10M	G/Y	-
31M	B	-
34M	V	-
35M	BR	-
36M	SHIELD	-
37M	W/G	-
38M	G	-
39M	SHIELD	-
40M	L	-

Connector No.	B149
Connector Name	WIRE TO WIRE
Connector Color	WHITE




ABNIA4271GB

DISPLAY AUDIO WITHOUT AMPLIFIER

< WIRING DIAGRAM >


[DISPLAY AUDIO WITHOUT AMPLIFIER]

Connector No.	R8
Connector Name	MICROPHONE
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
1	G	– (WITHOUT NAVI)
2	L	– (WITHOUT NAVI)
3	–	–
4	Y	– (WITHOUT NAVI)

Connector No.	R1
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
1	Y	– (WITHOUT NAVI)
13	SHIELD	–
14	G	– (WITHOUT NAVI)
15	L	– (WITHOUT NAVI)

Connector No.	B163
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
11	GR	–
12	O	–

Connector No.	D101
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
4	L/B	–
11	W/B	–

Connector No.	D12
Connector Name	FRONT DOOR SPEAKER LH
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	L/W	–
2	L/R	–

Connector No.	D2
Connector Name	WIRE TO WIRE
Connector Color	BROWN



Terminal No.	Color of Wire	Signal Name
2	L/R	–
3	L/W	–

ABNIA4272GB

A
B
C
D
E
F
G
H
I
J
K
L
M
O
P

AV

DISPLAY AUDIO WITHOUT AMPLIFIER

< WIRING DIAGRAM >

[DISPLAY AUDIO WITHOUT AMPLIFIER]

Connector No.	D153
Connector Name	WIRE TO WIRE
Connector Color	WHITE



1	2	3	4	5
6	7	8	9	10
11	12			

Terminal No.	Color of Wire	Signal Name
4	R	–
11	LG	–

Connector No.	D152
Connector Name	WIRE TO WIRE
Connector Color	WHITE



5	4	3	2	1
12	11	10	9	8
7	6			

Terminal No.	Color of Wire	Signal Name
4	R	–
11	LG	–

Connector No.	D112
Connector Name	FRONT DOOR SPEAKER RH
Connector Color	WHITE



2	1
---	---

Terminal No.	Color of Wire	Signal Name
1	W/B	–
2	L/B	–

Connector No.	D301
Connector Name	WIRE TO WIRE
Connector Color	WHITE



5	4	3	2	1
12	11	10	9	8
7	6			

Terminal No.	Color of Wire	Signal Name
5	L	–
12	O	–

Connector No.	D207
Connector Name	REAR DOOR SPEAKER LH
Connector Color	WHITE



2	1
---	---

Terminal No.	Color of Wire	Signal Name
1	L	–
2	O	–

Connector No.	D201
Connector Name	WIRE TO WIRE
Connector Color	WHITE



5	4	3	2	1
12	11	10	9	8
7	6			

Terminal No.	Color of Wire	Signal Name
5	L	–
12	O	–

ABNIA4273GB

DISPLAY AUDIO WITHOUT AMPLIFIER

< WIRING DIAGRAM >

[DISPLAY AUDIO WITHOUT AMPLIFIER]

A
B
C
D
E
F
G
H
I
J
K
L
M
O
P

Connector No.	D307
Connector Name	REAR DOOR SPEAKER RH
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	L	-
2	O	-

AV

ABNIA4334GB


BASIC INSPECTION

DIAGNOSIS AND REPAIR WORKFLOW

Work Flow

INFOID:000000009291958

OVERALL SEQUENCE



DETAILED FLOW

1.GET INFORMATION FOR SYMPTOM

Get detailed information from the customer about the symptom (the condition and the environment when the incident/malfunction occurred).

>> GO TO 2.

2.CONFIRM THE SYMPTOM

Try to confirm the symptom described by the customer. Verify relation between the symptom and the condition when the symptom is detected.

>> GO TO 3.

3.DETECT MALFUNCTIONING PART BY DIAGNOSTIC PROCEDURE

Inspect according to Diagnostic Procedure of the system.

DIAGNOSIS AND REPAIR WORKFLOW

< BASIC INSPECTION >

[DISPLAY AUDIO WITHOUT AMPLIFIER]

Is malfunctioning part detected?

YES >> GO TO 4.

NO >> GO TO 2.

4.REPAIR OR REPLACE THE MALFUNCTIONING PART

1. Repair or replace the malfunctioning part.
2. Reconnect parts or connectors disconnected during Diagnostic Procedure.

>> GO TO 5.

5.FINAL CHECK

Refer to confirmed symptom in step 2, and make sure that the symptom is not detected.

Was the repair confirmed?

YES >> Inspection End.

NO >> GO TO 2.

A

B

C

D

E

F

G

H

I

J

K

L

M

AV

O

P

POWER SUPPLY AND GROUND CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[DISPLAY AUDIO WITHOUT AMPLIFIER]

DTC/CIRCUIT DIAGNOSIS

POWER SUPPLY AND GROUND CIRCUIT AUDIO UNIT

AUDIO UNIT : Diagnosis Procedure

INFOID:0000000009291959

1.CHECK FUSE

Check that the following fuses are not blown.

Terminal No.	Signal name	Fuse No.
7	ACC power supply	4 (10A)
19	Battery power supply	29 (20A)

Are the fuses blown?

YES >> Replace the blown fuse after repairing the affected circuit.

NO >> GO TO 2.

2.CHECK POWER SUPPLY CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect audio unit connector M44.
3. Check voltage between audio unit connector M44 and ground.

Audio unit		Ground	Condition	Voltage (Approx.)
Connector	Terminal			
M44	7	—	Ignition switch: ON	Battery voltage
	19		Ignition switch: OFF	

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace harness or connectors.

3.CHECK GROUND CIRCUIT

Check continuity between audio unit connectors M44, M45 and ground.

Audio unit		Ground	Continuity
Connector	Terminal		
M44	20	—	Yes
M45	46		
	48		

Is the inspection result normal?

YES >> Inspection End.

NO >> Repair or replace harness or connectors.

BLUETOOTH® CONTROL UNIT

BLUETOOTH® CONTROL UNIT : Diagnosis Procedure

INFOID:0000000009291960

Regarding Wiring Diagram information, refer to [AV-51. "Wiring Diagram"](#).

1.CHECK FUSE

Check that the following fuses are not blown.

POWER SUPPLY AND GROUND CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[DISPLAY AUDIO WITHOUT AMPLIFIER]

Terminal No.	Signal name	Fuse No.
1	Battery power supply	29 (20A)
2	ACC power supply	4 (10A)
3	Ignition power supply	12 (10A)

Are the fuses blown?

YES >> Replace the blown fuse after repairing the affected circuit.

NO >> GO TO 2.

2.CHECK POWER SUPPLY CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect Bluetooth® control unit connector B141.
3. Check voltage between Bluetooth® control unit connector B141 and ground.

Bluetooth® control unit		Ground	Condition	Voltage (Approx.)
Connector	Terminal			
B141	1	—	Ignition switch: OFF	Battery voltage
	2		Ignition switch: ON	
	3			

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace harness or connectors.

3.CHECK GROUND CIRCUIT

1. Turn ignition switch OFF.
2. Check continuity between Bluetooth® control unit connector B141 and ground.

Bluetooth® control unit		Ground	Continuity
Connector	Terminal		
B141	4	—	Yes
	21		
	22		
	23		

Is the inspection result normal?

YES >> Inspection End.

NO >> Repair or replace harness or connectors.

MICROPHONE

MICROPHONE : Diagnosis Procedure

INFOID:000000009291961

AV

Regarding Wiring Diagram information, refer to [AV-51, "Wiring Diagram"](#).

1.CHECK POWER SUPPLY CIRCUIT

1. Turn ignition switch ON.
2. Check voltage between microphone connector R8 and ground.

(+)		(-)	Value (Approx.)
Connector	Terminal		
R8	4	Ground	5V

POWER SUPPLY AND GROUND CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[DISPLAY AUDIO WITHOUT AMPLIFIER]

Is the inspection result normal?

YES >> GO TO 3.

NO >> GO TO 2.

2.CHECK POWER SUPPLY CIRCUIT CONTINUITY

1. Turn ignition switch OFF.
2. Disconnect microphone connector and Bluetooth® control unit connector B141.
3. Check continuity between microphone connector R8 and Bluetooth® control unit connector B141.

Microphone		Bluetooth® control unit		Continuity
Connector	Terminal	Connector	Terminal	
R8	4	B141	29	Yes

4. Check continuity between microphone connector R8 and ground.

Microphone		—	Continuity
Connector	Terminal		
R8	4	Ground	No

Is the inspection result normal?

YES >> Replace the Bluetooth® control unit. Refer to [AV-93, "Removal and Installation"](#).

NO >> Repair or replace harness or connectors.

3.CHECK GROUND CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect microphone connector and Bluetooth® control unit connector B141.
3. Check continuity between microphone connector R8 and Bluetooth® control unit connector B141.

Microphone		Bluetooth® control unit		Continuity
Connector	Terminal	Connector	Terminal	
R8	2	B141	8	Yes

Is the inspection result normal?

YES >> Inspection End.

NO >> Repair or replace harness or connectors.

FRONT DOOR SPEAKER

< DTC/CIRCUIT DIAGNOSIS >

[DISPLAY AUDIO WITHOUT AMPLIFIER]

FRONT DOOR SPEAKER

Diagnosis Procedure

INFOID:000000009291962

Regarding Wiring Diagram information, refer to [AV-51. "Wiring Diagram"](#).

1.CONNECTOR CHECK

Check the audio unit and speaker connectors for the following:

- Proper connection
- Damage
- Disconnected or loose terminals

Is the inspection result normal?

YES >> GO TO 2

NO >> Repair the terminals or connectors.

2.CHECK FRONT DOOR SPEAKER SIGNAL CIRCUIT CONTINUITY

1. Disconnect audio unit connector M44 and suspect front door speaker connector.
2. Check continuity between audio unit connector M44 and suspect front door speaker connector.

Audio unit		Front door speaker		Continuity
Connector	Terminal	Connector	Terminal	
M44	2	D12 (LH)	1	Yes
	3		2	
	11	D112 (RH)	1	
	12		2	

3. Check continuity between audio unit connector M44 and ground.

Audio unit		Ground	Continuity
Connector	Terminal		
M44	2	—	No
	3		
	11		
	12		

Is the inspection result normal?

YES >> GO TO 3

NO >> Repair or replace harness or connectors.

3.CHECK FRONT DOOR SPEAKER SIGNAL


1. Connect audio unit connector M44 and suspect front door speaker connector.
2. Turn ignition switch to ACC.
3. Push audio unit POWER switch.
4. Check signal between the terminals of audio unit connector M44.

Audio unit connector M44		Condition	Reference value
(+)	(-)		
Terminal	Terminal		

FRONT DOOR SPEAKER

< DTC/CIRCUIT DIAGNOSIS >

[DISPLAY AUDIO WITHOUT AMPLIFIER]

2	3	Audio signal output	
11	12		

Is the inspection result normal?

- YES >> Replace front door speaker. Refer to [AV-90. "Removal and Installation"](#).
 NO >> Replace audio unit. Refer to [AV-88. "Removal and Installation"](#).

FRONT TWEETER

< DTC/CIRCUIT DIAGNOSIS >

[DISPLAY AUDIO WITHOUT AMPLIFIER]

FRONT TWEETER

Diagnosis Procedure

INFOID:000000009291963

Regarding Wiring Diagram information, refer to [AV-51. "Wiring Diagram"](#).

1.CONNECTOR CHECK

Check the audio unit and speaker connectors for the following:

- Proper connection
- Damage
- Disconnected or loose terminals

Is the inspection result normal?

YES >> GO TO 2

NO >> Repair the terminals or connectors.

2.CHECK FRONT DOOR SPEAKER SIGNAL CIRCUIT CONTINUITY

1. Disconnect audio unit connector M44 and suspect front tweeter connector.
2. Check continuity between audio unit connector M44 and suspect front tweeter connector.

Audio unit		Front tweeter		Continuity
Connector	Terminal	Connector	Terminal	
M44	2	M109 (LH)	1	Yes
	3		2	
	11	M111 (RH)	1	
	12		2	

3. Check continuity between audio unit connector M44 and ground.

Audio unit		Ground	Continuity
Connector	Terminal		
M44	2	—	No
	3		
	11		
	12		

Is the inspection result normal?

YES >> GO TO 3

NO >> Repair or replace harness or connectors.

3.CHECK FRONT DOOR SPEAKER SIGNAL


1. Connect audio unit connector M44 and suspect front tweeter connector.
2. Turn ignition switch to ACC.
3. Push audio unit POWER switch.
4. Check signal between the terminals of audio unit connector M44.

Audio unit connector M44		Condition	Reference value
(+)	(-)		
Terminal	Terminal		

FRONT TWEETER

< DTC/CIRCUIT DIAGNOSIS >

[DISPLAY AUDIO WITHOUT AMPLIFIER]

2	3	Audio signal output	
11	12		

SKIB3609E

Is the inspection result normal?

- YES >> Replace front tweeter. Refer to [AV-89. "Removal and Installation"](#).
- NO >> Replace audio unit. Refer to [AV-88. "Removal and Installation"](#).

REAR DOOR SPEAKER

< DTC/CIRCUIT DIAGNOSIS >

[DISPLAY AUDIO WITHOUT AMPLIFIER]

REAR DOOR SPEAKER

Diagnosis Procedure

INFOID:000000009291964

Regarding Wiring Diagram information, refer to [AV-51. "Wiring Diagram"](#).

1.CONNECTOR CHECK

Check the audio unit and speaker connectors for the following:

- Proper connection
- Damage
- Disconnected or loose terminals

Is the inspection result normal?

YES >> GO TO 2

NO >> Repair the terminals or connectors.

2.CHECK FRONT DOOR SPEAKER SIGNAL CIRCUIT CONTINUITY

1. Disconnect audio unit connector M44 and suspect rear door speaker connector.
2. Check continuity between audio unit connector M44 and suspect rear door speaker connector.

Audio unit		Rear door speaker		Continuity
Connector	Terminal	Connector	Terminal	
M44	4	D207 (LH)	1	Yes
	5		2	
	13	D307 (RH)	1	
	14		2	

3. Check continuity between audio unit connector M44 and ground.

Audio unit		Ground	Continuity
Connector	Terminal		
M44	4	—	No
	5		
	13		
	14		

Is the inspection result normal?

YES >> GO TO 3

NO >> Repair or replace harness or connectors.

3.CHECK FRONT DOOR SPEAKER SIGNAL


1. Connect audio unit connector M44 and suspect rear door speaker connector.
2. Turn ignition switch to ACC.
3. Push audio unit POWER switch.
4. Check signal between the terminals of audio unit connector M44.

Audio unit connector M44		Condition	Reference value
(+)	(-)		
Terminal	Terminal		

REAR DOOR SPEAKER

< DTC/CIRCUIT DIAGNOSIS >

[DISPLAY AUDIO WITHOUT AMPLIFIER]

4	5	Audio signal output	
13	14		

Is the inspection result normal?

- YES >> Replace rear door speaker. Refer to [AV-91. "Removal and Installation"](#).
- NO >> Replace audio unit. Refer to [AV-88. "Removal and Installation"](#).

STEERING SWITCH

< DTC/CIRCUIT DIAGNOSIS >

[DISPLAY AUDIO WITHOUT AMPLIFIER]

STEERING SWITCH

Diagnosis Procedure

INFOID:000000009291966

Regarding Wiring Diagram information, refer to [AV-51, "Wiring Diagram"](#).

1. CHECK STEERING WHEEL AUDIO CONTROL SWITCH RESISTANCE

1. Disconnect combination switch connector M102.
2. Check resistance between combination switch connector terminals.

Combination switch connector M102		Condition	Resistance (Ω) (Approx.)
Terminal	Terminal		
16	18	Depress VOL DOWN switch.	1
		Depress VOL UP switch.	121
		Depress  switch.	321
15		Depress MODE switch.	1
		Depress  switch.	121
		Depress  switch.	321
		Depress  switch.	723

Is the inspection result normal?

YES >> GO TO 2.

NO >> Replace steering wheel audio control switches. Refer to [AV-92, "Removal and Installation"](#).

2. CHECK HARNESS BETWEEN BLUETOOTH® CONTROL UNIT AND COMBINATION SWITCH

1. Turn ignition switch OFF.
2. Disconnect Bluetooth® control unit connector B141 and combination switch connector M30.
3. Check continuity between Bluetooth® control unit connector B141 and combination switch connector M30.

Bluetooth® control unit		Combination switch		Continuity
Connector	Terminal	Connector	Terminal	
B141	12	M30	24	Yes
	13		25	
	14		31	

4. Check continuity between Bluetooth® control unit connector B141 and ground.

Bluetooth® control unit		—	Continuity
Connector	Terminal		
B141	12	Ground	No
	13		
	14		

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace harness or connectors.

3. SPIRAL CABLE CHECK

Check continuity between combination switch connectors M30 and M102.

STEERING SWITCH

< DTC/CIRCUIT DIAGNOSIS >

[DISPLAY AUDIO WITHOUT AMPLIFIER]

Combination switch				Continuity
Connector	Terminal	Connector	Terminal	
M30	24	M102	15	Yes
	25		16	
	31		18	

Is the inspection result normal?

YES >> GO TO 4.

NO >> Replace spiral cable. Refer to [SR-13, "Removal and Installation"](#).

4. CHECK HARNESS BETWEEN BLUETOOTH® CONTROL UNIT AND AUDIO UNIT

1. Disconnect audio unit connector M44.
2. Check continuity between Bluetooth® control unit connector B141 and audio unit connector M44.

Bluetooth® control unit		Audio unit		Continuity
Connector	Terminal	Connector	Terminal	
B141	17	M44	6	Yes
	18		16	
	19		15	

3. Check continuity between Bluetooth® control unit connector B141 and ground.

Bluetooth® control unit		—	Continuity
Connector	Terminal		
B141	17	Ground	No
	18		
	19		

Is the inspection result normal?

YES >> Replace audio unit. Refer to [AV-88, "Removal and Installation"](#).

NO >> Repair or replace harness or connectors.

MICROPHONE SIGNAL CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[DISPLAY AUDIO WITHOUT AMPLIFIER]

MICROPHONE SIGNAL CIRCUIT

Diagnosis Procedure

INFOID:000000009291967

Regarding Wiring Diagram information, refer to [AV-51. "Wiring Diagram"](#).

1.CHECK HARNESS BETWEEN BLUETOOTH® CONTROL UNIT AND MICROPHONE

1. Turn ignition switch OFF.
2. Disconnect Bluetooth® control unit connector B141 and microphone connector.
3. Check continuity between Bluetooth® control unit connector B141 and microphone connector R8.

Bluetooth® control unit		Microphone		Continuity
Connector	Terminal	Connector	Terminal	
B141	7	R8	1	Yes
	8		2	
	29		4	

4. Check continuity between Bluetooth® control unit connector B141 and ground.

Bluetooth® control unit		—	Continuity
Connector	Terminal		
B141	7	Ground	No
	8		
	29		

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair harness or connector.

2.CHECK MICROPHONE POWER SUPPLY

1. Connect Bluetooth® control unit connector B141 and microphone connector.
2. Turn ignition switch ON.
3. Check voltage between microphone connector R8 terminal 4 and ground.

Microphone		Ground	Value (Approx.)
Connector	Terminal		
R8	4	—	5V

Is the inspection result normal?

YES >> GO TO 3.

NO >> Replace Bluetooth® control unit. Refer to [AV-93. "Removal and Installation"](#).


3.CHECK MICROPHONE SIGNAL

Check signal between Bluetooth® control unit connector B141 with CONSULT or and oscilloscope.

MICROPHONE SIGNAL CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[DISPLAY AUDIO WITHOUT AMPLIFIER]

Bluetooth® control unit connector B141		Condition	Reference signal
(+)	(-)		
Terminal	Terminal		
7	8	Speak into microphone.	 PKIB5037J

Is the inspection result normal?

YES >> Replace Bluetooth® control unit. Refer to [AV-93. "Removal and Installation"](#).

NO >> Replace microphone. Refer to [AV-95. "Removal and Installation"](#).

USB CONNECTOR

< DTC/CIRCUIT DIAGNOSIS >

[DISPLAY AUDIO WITHOUT AMPLIFIER]

USB CONNECTOR

Diagnosis Procedure

INFOID:000000009291968

Regarding Wiring Diagram information, refer to [AV-51, "Wiring Diagram"](#).

1. CHECK USB INTERFACE HARNESS CONTINUITY

1. Turn ignition switch OFF.
2. Disconnect audio unit connector M64 and USB interface connector M214.
3. Check continuity between audio unit connector M64 and USB interface connector M214.

Audio unit		USB interface		Continuity
Connector	Terminal	Connector	Terminal	
M64	53	M214	4	Yes
	54		1	
	55		2	
	56		3	
	57		5	

4. Check continuity between audio unit connector M64 and ground.

Audio unit		—	Continuity
Connector	Terminal		
M64	54	Ground	No
	57		

Is the inspection result normal?

- YES >> Replace the USB interface. Refer to [AV-99, "Removal and Installation"](#).
NO >> Repair or replace harness or connectors.

SYMPTOM DIAGNOSIS

AUDIO SYSTEM

Symptom Table

INFOID:000000009291969

RELATED TO AUDIO

Symptoms	Check items	Probable malfunction location
The disk cannot be removed.	Audio unit	Malfunction in audio unit. Refer to AV-41, "On Board Diagnosis Function" .
No sound comes out or the level of the sound is low.	No sound from all speakers.	- Speaker circuit shorted to ground. Refer to AV-51, "Wiring Diagram". - Audio unit power supply and ground circuits malfunction. Refer to AV-66, "AUDIO UNIT : Diagnosis Procedure".
	Only a certain speaker (front door speaker LH, front door speaker RH, front tweeter LH, front tweeter RH, rear door speaker LH, rear door speaker RH) does not output sound.	- Poor connector connection of speaker. - Sound signal circuit malfunction between audio unit and speaker. Refer to: AV-69, "Diagnosis Procedure" (front door speaker). AV-71, "Diagnosis Procedure" (front tweeter). AV-73, "Diagnosis Procedure" (rear door speaker). - Malfunction in speaker. Refer to: AV-90, "Removal and Installation" (front door speaker). AV-89, "Removal and Installation" (front tweeter). AV-91, "Removal and Installation" (rear door speaker). - Malfunction in audio unit. Refer to AV-41, "On Board Diagnosis Function".

AUDIO SYSTEM

< SYMPTOM DIAGNOSIS >

[DISPLAY AUDIO WITHOUT AMPLIFIER]

Symptoms	Check items	Probable malfunction location
Noise is mixed with audio.	Noise comes out from all speakers.	Malfunction in audio unit. Refer to AV-41, "On Board Diagnosis Function" .
	Noise comes out only from a certain speaker (front door speaker LH, front door speaker RH, front tweeter LH, front tweeter RH, rear door speaker LH, rear door speaker RH).	- Poor connector connection of speaker. - Sound signal circuit malfunction between audio unit and speaker. Refer to: AV-69, "Diagnosis Procedure" (front door speaker). AV-71, "Diagnosis Procedure" (front tweeter). AV-73, "Diagnosis Procedure" (rear door speaker). - Malfunction in speaker. - Poor Installation of speaker (e.g. backlash and looseness). Refer to: AV-90, "Removal and Installation" (front door speaker). AV-89, "Removal and Installation" (front tweeter). AV-91, "Removal and Installation" (rear door speaker). - Malfunction in audio unit. Refer to AV-41, "On Board Diagnosis Function".
	Noise is mixed with radio only (when the vehicle hits a bump or while driving over bad roads)	Poor connector connection of antenna or antenna feeder. Refer to AV-96, "Location of Antenna" .
No radio reception or poor reception.	- Other audio sounds are normal. - Any radio station cannot be received or poor reception is caused even after moving to a service area with good reception (e.g. a place with clear view and no obstacles generating external noises).	- Rod antenna is not fully connected to antenna base. - Antenna base/rod connection (thread zone) has foreign material or corrosion inside. - Poor connector connection of antenna or antenna feeder. Refer to AV-96, "Location of Antenna".
No satellite radio reception.	Satellite radio antenna malfunction.	- Poor continuity in antenna feeder. - Poor connector connection of antenna or antenna feeder. - Loose satellite radio antenna mounting nut. Refer to AV-96, "Location of Antenna".
Buzz/rattle sound from speaker	The majority of buzz/rattle sounds are not indicative of an issue with the speaker, usually something nearby the speaker is causing the buzz/rattle.	Refer to "SQUEAK AND RATTLE TROUBLE DIAGNOSIS" in the appropriate interior trim section.

RELATED TO HANDS-FREE PHONE

- Before performing diagnosis, confirm that the cellular phone being used by the customer is compatible with the vehicle.
- It is possible that a malfunction is occurring due to a version change of the phone even though the phone is a compatible type. This can be confirmed by changing the cellular phone to another compatible type, and check that it operates normally. It is important to determine whether the cause of the malfunction is the vehicle or the cellular phone.

Check Compatibility

- Make sure the customer's Bluetooth® related concern is understood.
- Verify the customer's concern.

NOTE:

The customer's phone may be required, depending upon their concern.

AUDIO SYSTEM

< SYMPTOM DIAGNOSIS >

[DISPLAY AUDIO WITHOUT AMPLIFIER]

3. Write down the customer's phone brand, model and service provider.

NOTE:

It is necessary to know the service provider. On occasion, a given phone may be on the approved list with one provider, but may not be on the approved list with other providers.

4. Go to "www.nissanusa.com/bluetooth/".

- a. Using the website's search engine, find out if the customer's phone is on the approved list.
- b. If the customer's phone is NOT on the approved list:
Stop diagnosis here. The customer needs to obtain a Bluetooth® phone that is on the approved list before any further action.
- c. If the feature related to the customer's concern shows as "N" (not compatible):
Stop diagnosis here. If the customer still wants the feature to function, they will need to get an approved phone showing the feature as "Y" (compatible) in the "Basic Features".
- d. If the feature related to the customer's concern shows as "Y" (compatible):
Perform diagnosis as per the following table.

Symptoms	Check items	Probable malfunction location
Does not recognize cellular phone connection (no connection is displayed on the display at the guide).	Repeat the registration of cellular phone.	Malfunction in audio unit. Replace audio unit. Refer to AV-88, "Removal and Installation" .
Hands-free phone cannot be established.	- Hands-free phone operation can be made, but the communication cannot be established. - Hands-free phone operation can be performed, however, voice between each other cannot be heard during the conversation.	
The other party's voice cannot be heard by hands-free phone.	Check the "microphone speaker" in Inspection & Adjustment Mode if sound is heard.	
Originating sound is not heard by the other party with hands-free phone communication.	Sound operation function is normal.	Microphone signal circuit malfunction. Refer to AV-77, "Diagnosis Procedure" .
	Sound operation function does not work.	
The system cannot be operated.	- The voice recognition can be controlled. - Steering switch's VOL UP and VOL DOWN switch works, but  does not work.	Steering switch malfunction. Replace steering switch. Refer to AV-92, "Removal and Installation" .
	Steering switch's  , VOL UP and VOL DOWN switches do not work.	Steering switch signal circuit malfunction. Refer to AV-75, "Diagnosis Procedure" .
	All steering switches do not work.	Steering switch ground circuit malfunction. Refer to AV-75, "Diagnosis Procedure" .

NORMAL OPERATING CONDITION

< SYMPTOM DIAGNOSIS >

[DISPLAY AUDIO WITHOUT AMPLIFIER]

NORMAL OPERATING CONDITION

Description

INFOID:000000009291970

RELATED TO NOISE

The majority of the audio concerns are the result of outside causes (bad CD, electromagnetic interference, etc.).

The following noise results from variations in field strength, such as fading noise and multi-path noise, or external noise from trains and other sources. It is not a malfunction.

- Fading noise: This noise occurs because of variations in the field strength in a narrow range due to mountains or buildings blocking the signal.
- Multi-path noise: This noise results from the waves sent directly from the broadcast station arriving at the antenna at a different time from the waves which reflect off mountains or buildings.

The vehicle itself can be a source of noise if noise prevention parts or electrical equipment is malfunctioning. Check if noise is caused and/or changed by engine speed, ignition switch turned to each position, and operation of each piece of electrical equipment, and determine the cause.

NOTE:

The source of the noise can be found easily by listening to the noise while removing the fuses of electrical components, one by one.

Type of Noise and Possible Cause

Occurrence condition		Possible cause
Occurs only when engine is ON.	A continuous growling noise occurs. The speed of the noise varies with changes in the engine speed.	• Ignition components
The occurrence of the noise is linked with the operation of the fuel pump.		• Fuel pump condenser
Noise only occurs when various electrical components are operating.	A cracking or snapping sound occurs with the operation of various switches.	• Relay malfunction, audio unit malfunction
	The noise occurs when various motors are operating.	• Motor case ground • Motor
The noise occurs constantly, not just under certain conditions.		• Rear defogger coil malfunction • Open circuit in printed heater • Poor ground of antenna feeder line
A cracking or snapping sound occurs while the vehicle is being driven, especially when it is vibrating excessively.		• Ground wire of body parts • Ground due to improper part installation • Wiring connections or a short circuit

RELATED TO HANDS-FREE PHONE

Symptom	Cause and Counter measure
Does not recognize cellular phone connection (No connection is displayed on the display at the guide).	Some Bluetooth® enabled cellular phones may not be recognized by the in-vehicle phone module. Refer to "RELATED TO HANDS-FREE PHONE (Check Compatibility)" in AV-80, "Symptom Table" .
Cannot use hands-free phone.	Customer will not be able to use a hands-free phone under the following conditions: • The vehicle is outside of the telephone service area. • The vehicle is in an area where it is difficult to receive radio waves; such as in a tunnel, in an underground parking garage, near a tall building or in a mountainous area. • The cellular phone is locked to prevent it from being dialed. NOTE: While a cellular phone is connected through the Bluetooth® wireless connection, the battery power of the cellular phone may discharge quicker than usual. The Bluetooth® Hands-Free Phone System cannot charge cellular phones.

NORMAL OPERATING CONDITION

< SYMPTOM DIAGNOSIS >

[DISPLAY AUDIO WITHOUT AMPLIFIER]

Symptom	Cause and Counter measure
The other party's voice cannot be heard by hands-free phone.	When the radio wave condition is not ideal or ambient sound is too loud, it may be difficult to hear the other person's voice during a call.
Poor sound quality.	Do not place the cellular phone in an area surrounded by metal or far away from the in-vehicle phone module to prevent tone quality degradation and wireless connection disruption.

PRECAUTIONS

< PRECAUTION >

[DISPLAY AUDIO WITHOUT AMPLIFIER]

PRECAUTION

PRECAUTIONS

Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"

INFOID:000000009291971

The Supplemental Restraint System such as "AIR BAG" and "SEAT BELT PRE-TENSIONER", used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. This system includes seat belt switch inputs and dual stage front air bag modules. The SRS system uses the seat belt switches to determine the front air bag deployment, and may only deploy one front air bag, depending on the severity of a collision and whether the front occupants are belted or unbelted. Information necessary to service the system safely is included in the SR and SB section of this Service Manual.

WARNING:

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision which would result in air bag inflation, all maintenance must be performed by an authorized NISSAN/INFINITI dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see the SR section.
- Do not use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harnesses or harness connectors.

PRECAUTIONS WHEN USING POWER TOOLS (AIR OR ELECTRIC) AND HAMMERS

WARNING:

- When working near the Airbag Diagnosis Sensor Unit or other Airbag System sensors with the Ignition ON or engine running, DO NOT use air or electric power tools or strike near the sensor(s) with a hammer. Heavy vibration could activate the sensor(s) and deploy the air bag(s), possibly causing serious injury.
- When using air or electric power tools or hammers, always switch the Ignition OFF, disconnect the battery and wait at least 3 minutes before performing any service.

Precaution for Trouble Diagnosis

INFOID:000000009291972

AV COMMUNICATION SYSTEM


- Do not apply voltage of 7.0 V or higher to the measurement terminals.
- Use the tester with its open terminal voltage being 7.0 V or less.
- Be sure to turn ignition switch OFF and disconnect the battery cable from the negative terminal before checking the circuit.

Precaution for Harness Repair

INFOID:000000009291973

AV COMMUNICATION SYSTEM

- Solder the repaired parts, and wrap with tape. [Frays of twisted line must be within 110 mm (4.33 in).]




PRECAUTIONS

< PRECAUTION >

[DISPLAY AUDIO WITHOUT AMPLIFIER]

- Do not perform bypass wire connections for the repair parts. (The spliced wire will become separated and the characteristics of twisted line will be lost.)



Precaution for Work

INFOID:000000009291974

- When removing or disassembling each component, be careful not to damage or deform it. If a component may be subject to interference, be sure to protect it with a shop cloth.
- When removing (disengaging) components with a screwdriver or similar tool, be sure to wrap the component with a shop cloth or vinyl tape to protect it.
- Protect the removed parts with a shop cloth and prevent them from being dropped.
- Replace a deformed or damaged clip.
- If a part is specified as a non-reusable part, always replace it with a new one.
- Be sure to tighten bolts and nuts securely to the specified torque.
- After installation is complete, be sure to check that each part works properly.
- Follow the steps below to clean components:
 - Water soluble dirt:
 - Dip a soft cloth into lukewarm water, wring the water out of the cloth and wipe the dirty area.
 - Then rub with a soft, dry cloth.
 - Oily dirt:
 - Dip a soft cloth into lukewarm water with mild detergent (concentration: within 2 to 3%) and wipe the dirty area.
 - Then dip a cloth into fresh water, wring the water out of the cloth and wipe the detergent off.
 - Then rub with a soft, dry cloth.
 - Do not use organic solvent such as thinner, benzene, alcohol or gasoline.
 - For genuine leather seats, use a genuine leather seat cleaner.

PREPARATION

< PREPARATION >

[DISPLAY AUDIO WITHOUT AMPLIFIER]

PREPARATION


PREPARATION

Special Service Tools

INFOID:0000000009291975

The actual shapes of Kent-Moore tools may differ from those of special service tools illustrated here.

Tool number (Kent-Moore No.) Tool name	Description
— (J-46534) Trim Tool Set	Removing trim components



AMJIA04832Z

Commercial Service Tools

INFOID:0000000009291976

Tool name	Description
Power tool	Loosening nuts, screws and bolts



PIIB1407E

A
B
C
D
E
F
G
H
I
J
K
L
M
O
P

AV

REMOVAL AND INSTALLATION


AUDIO UNIT

Removal and Installation

INFOID:000000009291977

REMOVAL

1. Disconnect the negative battery terminal. Refer to [PG-72, "Removal and Installation"](#).
2. Remove cluster lid C. Refer to [IP-15, "Removal and Installation"](#).
3. Remove the screws (A) from the bracket.
4. Remove the audio unit (1) from cluster lid C.



INSTALLATION

Installation is in the reverse order of removal.

FRONT TWEETER

< REMOVAL AND INSTALLATION >

[DISPLAY AUDIO WITHOUT AMPLIFIER]

FRONT TWEETER

Removal and Installation


INFOID:000000009291978

REMOVAL

CAUTION:

Use a suitable tool to prevent damage to the front tweeter grille and the instrument panel.

1. Remove the front tweeter grille.
2. Remove the front tweeter screws (A).
3. Pull out the front tweeter (1), then disconnect the harness connector from the front tweeter and remove.



INSTALLATION

Installation is in the reverse order of removal.

A
B
C
D
E
F
G
H
I
J
K
L
M
O
P

AV

FRONT DOOR SPEAKER

< REMOVAL AND INSTALLATION >

[DISPLAY AUDIO WITHOUT AMPLIFIER]


FRONT DOOR SPEAKER

Removal and Installation

INFOID:000000009291979

REMOVAL

1. Remove the front door finisher. Refer to [INT-14, "Removal and Installation"](#).
2. Remove the front door speaker screws (A).
3. Pull out the front door speaker (1).
4. Disconnect the harness connector from the front door speaker (1) and remove.



INSTALLATION

Installation is in the reverse order of removal.

REAR DOOR SPEAKER

< REMOVAL AND INSTALLATION >

[DISPLAY AUDIO WITHOUT AMPLIFIER]


REAR DOOR SPEAKER

Removal and Installation

INFOID:000000009291980

REMOVAL

1. Remove the rear door finisher. Refer to [INT-14. "Removal and Installation"](#).
2. Remove the rear door speaker screws (A).
3. Disconnect the harness connector (B) from the rear door speaker (1) and remove.



INSTALLATION

Installation is in the reverse order of removal.

A
B
C
D
E
F
G
H
I
J
K
L
M
O
P

AV

STEERING SWITCH


< REMOVAL AND INSTALLATION >

[DISPLAY AUDIO WITHOUT AMPLIFIER]

STEERING SWITCH

Removal and Installation

INFOID:000000009291981



1. Steering wheel

2. Steering wheel audio control switches


REMOVAL

1. Remove the driver air bag module. Refer to [SR-11. "Removal and Installation"](#).
2. Remove the steering wheel audio control switch assembly screws.
3. Disconnect the harness connectors from the steering wheel audio control switches.
4. Remove the steering wheel audio control switches by pulling on steering wheel audio control switches to release the pawls.

○: Pawl

CAUTION:

Do not tilt steering wheel audio control switches during removal or damage may occur to the pawls.



INSTALLATION

Installation is in the reverse order of removal.

BLUETOOTH CONTROL UNIT


< REMOVAL AND INSTALLATION >

[DISPLAY AUDIO WITHOUT AMPLIFIER]

BLUETOOTH CONTROL UNIT

Removal and Installation

INFOID:000000009291982



1. Bluetooth control unit front bracket 2. Bluetooth control unit/antenna 3. Bluetooth control unit rear bracket

⇨ Front

REMOVAL

NOTE:

Do not remove the RH front seat from the vehicle.

1. Remove the RH front seat bolts, disconnect the harness connectors from the RH front seat. Refer to [SE-14, "Exploded View"](#).
2. Tilt the RH front seat back to access the bluetooth control unit.


A
B
C
D
E
F
G
H
I
J
K
L
M
AV
O
P

BLUETOOTH CONTROL UNIT

< REMOVAL AND INSTALLATION >

[DISPLAY AUDIO WITHOUT AMPLIFIER]

3. Disconnect the harness connector (B) from the Bluetooth control unit.
4. Remove the Bluetooth control unit screws (A), then remove the Bluetooth control unit assembly (1).
5. Remove the Bluetooth control unit bracket screws and the Bluetooth control unit front and rear brackets.



INSTALLATION

Installation is in the reverse order of removal.

MICROPHONE

< REMOVAL AND INSTALLATION >

[DISPLAY AUDIO WITHOUT AMPLIFIER]


MICROPHONE

Removal and Installation

INFOID:000000009291983

REMOVAL

1. Remove the roof console. Refer to [INT-21, "Removal and Installation"](#).
2. Release the pawls that retain the Bluetooth microphone (1) to the roof console.
3. Disconnect the harness connector (A) from the Bluetooth microphone (1) and remove.



INSTALLATION

Installation is in the reverse order of removal.

A
B
C
D
E
F
G
H
I
J
K
L
M
O
P

AV

AUDIO ANTENNA


< REMOVAL AND INSTALLATION >

[DISPLAY AUDIO WITHOUT AMPLIFIER]

AUDIO ANTENNA

Location of Antenna

INFOID:000000009291984



- | | | |
|-----------------------------|--------|---------|
| 1. Coaxial antenna feeder | 2. M41 | 3. M33 |
| 4. Satellite antenna feeder | 5. M67 | 6. M500 |
| 7. M501 | | |

Removal and Installation

INFOID:000000009291985

REMOVAL


1. Remove instrument lower panel RH and glove box. Refer to [IP-20. "Removal and Installation"](#).
2. Disconnect audio antenna cable from antenna feeder.

AUDIO ANTENNA

< REMOVAL AND INSTALLATION >

[DISPLAY AUDIO WITHOUT AMPLIFIER]

3. Remove antenna rod.
4. Remove rubber seal.
5. Remove cowl top. Refer to [EXT-20. "Removal and Installation"](#).
6. Remove fender protector. Refer to [EXT-22. "Removal and Installation"](#).
7. Remove antenna base bolts.
8. Remove antenna base and cable.



INSTALLATION

Installation is in the reverse order of removal.

CAUTION:

Always properly tighten the antenna rod during installation or the antenna rod may bend or break during vehicle operation.

SATELLITE RADIO ANTENNA

< REMOVAL AND INSTALLATION >

[DISPLAY AUDIO WITHOUT AMPLIFIER]


SATELLITE RADIO ANTENNA

Removal and Installation

INFOID:000000009291986

REMOVAL

1. Remove the roof console. Refer to [INT-21, "Removal and Installation"](#).
2. Disconnect the harness connector from the satellite radio antenna.
3. Remove the satellite radio antenna nut.
4. Remove the satellite radio antenna.



INSTALLATION

Installation is in the reverse order of removal.

USB CONNECTOR

Removal and Installation

INFOID:000000009291987

REMOVAL

1. Remove the center console assembly. Refer to [IP-22. "Removal and Installation"](#).
2. Push the pawl from the back of the center console to remove the USB interface.

INSTALLATION

Installation is in the reverse order of removal.

A
B
C
D
E
F
G
H
I
J
K
L
M
O
P

AV

COMPONENT PARTS

< SYSTEM DESCRIPTION >


[DISPLAY AUDIO WITH AMPLIFIER]

SYSTEM DESCRIPTION

COMPONENT PARTS

Component Parts Location

INFOID:000000009291989



AMNIA29332Z

- | | | |
|---|---|--|
| 1. Front tweeter LH M109 | 2. Steering wheel audio control switches | 3. Audio unit M46, M48, M65, M66 |
| 4. Front tweeter RH M111 | 5. Microphone R8 | 6. Front door speaker LH D12
Front door speaker RH D112 |
| 7. Rear tweeter LH D208
Rear tweeter RH D308 | 8. Rear door speaker LH D207
Rear door speaker RH D307 | 9. Audio amp. B158, B159 (Underneath
passenger seat) |
| 10. Bluetooth® control unit B141, B142,
B143 (Underneath passenger seat) | 11. Bluetooth® antenna | 12. Subwoofer B72 (Underneath rear LH
seat) |
| 13. USB interface M214 | 14. Satellite antenna | 15. Rod antenna |

Component Description

INFOID:000000009291990

COMPONENT PARTS

< SYSTEM DESCRIPTION >

[DISPLAY AUDIO WITH AMPLIFIER]

Part name	Description
Audio unit	- Controls audio, USB connection, AUX IN connection and satellite radio functions. - Display unit is built in to audio unit.
Audio amplifier	Receives audio signals from audio unit and outputs audio signals to each speaker.
Front tweeters	Outputs high, mid and low range audio signals from audio amp.
Front door speakers	
Rear tweeters	
Rear door speakers	
Subwoofer	
Steering wheel audio control switches	- Operations for audio, hands-free phone and voice recognition are possible. - Steering switch signal is output to Bluetooth® control unit. - Bluetooth® control unit outputs steering switch signal to audio unit.
Microphone	- Used for hands-free phone operations. - Microphone signal is transmitted to Bluetooth® control unit. - Power is supplied from Bluetooth® control unit.
Bluetooth® control unit	- Inputs TEL voice signal from Bluetooth® antenna and outputs it to audio unit. - Controlled via AV communication by audio unit.
Bluetooth® antenna	Receives TEL voice signal and outputs it to Bluetooth® control unit.
USB interface	USB sound and data input signals are transmitted to audio unit.
Satellite antenna	Satellite radio signal is received and transmitted to audio unit.
Rod antenna	AM/FM signal is received and transmitted to audio unit.

A

B

C

D

E

F

G

H

I

J

K

L

M

AV


O

P

SYSTEM

System Diagram

INFOID:000000009291991



AWNIA2934GB

System Description

INFOID:000000009291992

AUDIO SYSTEM

The audio system consists of the following components

- Audio unit
- Audio amplifier
- Front tweeters
- Front door speakers
- Rear tweeters
- Rear door speakers
- Subwoofer
- Steering wheel audio control switches
- USB interface
- Rod antenna

When the audio system is on, AM/FM signals received by the rod antenna are sent to the audio unit. The audio unit then sends audio signals to the audio amplifier. The audio amplifier then sends audio signals to the front tweeters, front door speakers, rear tweeters, rear door speakers and subwoofer.

Refer to Owner's Manual for audio system operating instructions.

SATELLITE RADIO SYSTEM

The satellite radio system consists of the following components

- Satellite antenna
- Satellite radio tuner integral to audio unit

When the satellite radio system is on, satellite radio signals are supplied to the audio unit from the satellite antenna. The audio unit then sends audio signals to the audio amplifier. The audio amplifier amplifies the audio signals before sending them to the speakers, tweeters and subwoofer.

Refer to Owner's Manual for satellite radio system operating instructions.

HANDS-FREE PHONE SYSTEM

System Operation

NOTE:

Cellular telephones must have their wireless connection set up (paired) before using the Bluetooth® telephone system.

The Bluetooth® telephone system allows users who have a Bluetooth® cellular telephone to make a wireless connection between their cellular telephone and the Bluetooth® control unit. Hands-free cellular telephone calls can be sent and received. Some Bluetooth® cellular telephones may not be recognized by the Bluetooth® control unit. When a cellular telephone or the Bluetooth® control unit is replaced, the telephone must be paired

with the Bluetooth® control unit. Different cellular telephones may have different pairing procedures, refer to the cellular telephone operating manual.

Refer to the Owner's Manual for Bluetooth® telephone system operating instructions.

Bluetooth® Control Unit

When the ignition switch is turned to ACC or ON, the Bluetooth® control unit will power up. During power up, the Bluetooth® control unit is initialized and performs various self-checks. Initialization may take up to 20 seconds. If a phone is present in the vehicle and paired with the Bluetooth® control unit, Nissan Voice Recognition will then become active. Bluetooth® telephone functions can be turned off using the Nissan Voice Recognition system.

Steering Wheel Audio Control Switches

When buttons on the steering wheel audio control switch are pushed, the resistance in steering wheel audio control switch circuit changes, depending on which button is pushed. The Bluetooth® control unit uses this signal to perform various functions while navigating through the voice recognition system.

The following functions can be performed using the steering wheel audio control switch:

- Initiate self-diagnosis of the Bluetooth® telephone system
- Start a voice recognition session
- Answer and end telephone calls
- Adjust the volume of calls

Microphone

The microphone is located in the roof console assembly. The microphone sends a signal to the Bluetooth® control unit. The microphone can be actively tested during self-diagnosis.

Audio Unit

The audio unit receives signals from the Bluetooth® control unit and sends audio signals to the audio amplifier. The audio amplifier amplifies the audio signals before sending them to the speakers.

A
B
C
D
E
F
G
H
I
J
K
L
M
O
P

DIAGNOSIS SYSTEM (AUDIO UNIT)

< SYSTEM DESCRIPTION >

[DISPLAY AUDIO WITH AMPLIFIER]

DIAGNOSIS SYSTEM (AUDIO UNIT)

Description

INFOID:000000009291993

The audio unit on board diagnosis performs the functions listed in the table below:


Mode		Description
Self Diagnosis		• Audio unit diagnosis. • Diagnoses the connections across system components.
Confirmation/ Adjustment	Display Diagnosis	The following check functions are available: color tone check by color bar display and white display, light and shade check by gray scale display.
	Vehicle Signals	Diagnosis of signals can be performed for vehicle speed, lights, reverse, EQ pin and destination.
	Speaker Test	The connection of a speaker can be confirmed by test tone.
	Error History	The system malfunction and the frequency when occurring in the past are displayed. When the malfunctioning item is selected, the time and place that the selected malfunction last occurred are displayed.
	AV COMM Diagnosis	The communication condition of each unit of display audio system can be monitored.
	Delete Unit Connection Log	Erase the connection history of unit and error history.
	Initialize Setting	Initializes the audio unit memory.

On Board Diagnosis Function


INFOID:000000009291994

METHOD OF STARTING

1. Turn the ignition ON.
2. Turn the audio system OFF.
3. While pressing the preset 1 button, turn the volume control dial clockwise or counterclockwise for 40 clicks or more. When self-diagnosis mode begins, a short beep will be heard. Shifting from current screen to previous screen is performed by pressing BACK button.



4. The trouble diagnosis initial screen is displayed, and Self Diagnosis or Confirmation/Adjustment can be selected.



SELF DIAGNOSIS MODE

Audio Unit Self Diagnosis


1. Select Self Diagnosis.
2. Self diagnosis screen is displayed. The bar graph visible in center of screen indicates progress of self diagnosis.

DIAGNOSIS SYSTEM (AUDIO UNIT)

< SYSTEM DESCRIPTION >

[DISPLAY AUDIO WITH AMPLIFIER]

3. Diagnosis results are displayed after the self diagnosis is completed. The unit names and the connection lines are color coded according to the diagnostic results.




Diagnosis results	Unit	Connection line
Normal	Green	Green
Connection malfunction	Gray	Yellow
Unit malfunction ¹	Red	Green

1: Control unit (audio unit) is displayed in red.

- Replace audio unit if Self Diagnosis did not run because control unit malfunction is indicated. The symptom is audio unit internal error. Refer to [AV-168, "Removal and Installation"](#).
- If multiple errors occur at the same time for a single unit, the screen switch colors are determined according to the following order of priority: red > gray.

4. Comments of self diagnosis results can be viewed in the diagnosis result screen.



Audio Unit Self Diagnosis Results

Only Unit Part Is Displayed In Red		
Screen switch	Description	Possible cause
Control unit	Malfunction is detected in audio unit power supply and ground circuits.	• Audio unit power supply or ground circuits. Refer to AV-134, "AUDIO UNIT : Diagnosis Procedure". • If no malfunction is detected in audio unit power supply and ground circuits, replace audio unit. Refer to AV-168, "Removal and Installation".

A Connecting Cable Between Units Is Displayed In Yellow		
Area with yellow connection lines	Description	Possible cause
Control unit ↔ BTHF	When one of the following is detected: • malfunction is detected in Bluetooth® control unit power supply and ground circuits. • malfunction is detected in AV communication circuits between audio unit and Bluetooth® control unit.	• Bluetooth® control unit power supply or ground circuits. Refer to AV-135, "BLUETOOTH CONTROL UNIT : Diagnosis Procedure". • AV communication circuits between audio unit and Bluetooth® control unit.


Audio Unit Confirmation/Adjustment

DIAGNOSIS SYSTEM (AUDIO UNIT)


< SYSTEM DESCRIPTION >

[DISPLAY AUDIO WITH AMPLIFIER]

1. Select Confirmation/Adjustment.
2. Select each switch on the Confirmation/Adjustment screen to display the relevant trouble diagnosis screen. Press the BACK switch to return to the initial Confirmation/Adjustment screen.




Display Diagnosis



Vehicle Signals

A comparison check can be made of each actual vehicle signal and the signals recognized by the system.




Speaker Test

DIAGNOSIS SYSTEM (AUDIO UNIT)

< SYSTEM DESCRIPTION >

[DISPLAY AUDIO WITH AMPLIFIER]

Select Speaker Test to display the Speaker Diagnosis screen. Press Start to generate a test tone in a speaker. Press Start again to generate a test tone in the next speaker. Press End to stop the test tones.



Error History

The self diagnosis results are judged depending on whether any error occurs from when Self Diagnosis is selected until the self diagnosis results are displayed.

However, the diagnosis results are judged normal if an error has occurred before the ignition switch is turned ON and then no error has occurred until the self diagnosis start. Check the Error Record to detect any error that may have occurred before the self diagnosis start because of this situation.

The frequency of occurrence is displayed in a count up manner. The actual count up method differs depending on the error item.


Count up method A

- The counter is set to 40 if an error occurs. 1 is subtracted from the counter if the condition is normal at a next ignition ON cycle.
- The counter lower limit is 1. The counter can be reset (no error record display) with the Delete log switch.

Count up method B

- The counter increases by 1 if an error occurs when ignition switch is ON. The counter will not decrease even if the condition is normal at the next ignition ON cycle.
- The counter upper limit is 50. Any counts exceeding 50 are ignored. The counter can be reset (no error record display) with the Delete log switch.

Display type of occurrence frequency	Error history display item
Count up method A	AV communication line, control unit (AV)
Count up method B	Other than the above



Error item

Some error items may be displayed simultaneously according to the cause. If some error items are displayed simultaneously, the detection of the cause can be performed by the combination of display items

DIAGNOSIS SYSTEM (AUDIO UNIT)

< SYSTEM DESCRIPTION >

[DISPLAY AUDIO WITH AMPLIFIER]

Error item	Description	Possible cause
CONTROL UNIT (AV)	AV communication circuit initial diagnosis malfunction is detected.	Replace the audio unit if the malfunction occurs constantly. Refer to AV-168, "Removal and Installation" .
- AV COMM CIRCUIT - H/F Unit Connection Error	When one of the following is detected: - malfunction is detected in Bluetooth® control unit power supply and ground circuits. - malfunction is detected in AV communication circuits between audio unit and Bluetooth® control unit.	- Bluetooth® control unit power supply or ground circuits. Refer to AV-135, "BLUETOOTH CONTROL UNIT : Diagnosis Procedure". - AV communication circuits between audio unit and Bluetooth® control unit.

AV COMM Diagnosis

- Displays the communication status between audio unit (master unit) and each unit.
- The error counter displays OK if any malfunction was not detected in the past and displays 0 if a malfunction is detected. It increases by 1 if the condition is normal at the next ignition switch ON cycle. The upper limit of the counter is 39.
- The error counter is erased if Reset is pressed.



Items	Status (Current)	Counter (Past)
C Rx(BTHF-ITM)	OK / ???	OK / 0 – 39

NOTE:

“???” indicates UNKWN.


Delete Unit Connection Log

Deletes any unit connection records and error records from the audio unit memory (clears the records of the unit that has been removed).



Initialize Settings

Deletes data stored from the audio unit.



AUDIO UNIT

< ECU DIAGNOSIS INFORMATION >

[DISPLAY AUDIO WITH AMPLIFIER]


ECU DIAGNOSIS INFORMATION

AUDIO UNIT



Reference Value

INFOID:000000009291995

TERMINAL LAYOUT








PHYSICAL VALUES

Terminal (Wire color)		Description		Condition		Reference value (Approx.)
+	—	Signal name	Input/ Output	Ignition switch	Operation	
1 (G/W)	Ground	Amp. ON signal	Output	ACC	—	Battery voltage
2 (W)	3 (B)	Sound signal front speaker LH	Output	ON	Sound output	 SKIB3609E
4 (P)	5 (B/R)	Sound signal rear speaker LH	Output	ON	Sound output	 SKIB3609E
6 (V)	15 (O)	Steering switch signal A	Input	ON	Press and hold MODE switch.	0 V
					Press and hold Δ switch.	1.34 V
					Press and hold ∇ switch.	2.45 V
					Press and hold  switch.	3.43 V
					Except for above.	5.0 V
7 (G/B)	Ground	ACC power supply	Input	ACC	—	Battery voltage
9 (R)	8 (GR)	Illumination control signal	Input	ON	Headlamps ON	Battery voltage

AUDIO UNIT

< ECU DIAGNOSIS INFORMATION >

[DISPLAY AUDIO WITH AMPLIFIER]

Terminal (Wire color)		Description		Condition		Reference value (Approx.)
+	–	Signal name	Input/ Output	Ignition switch	Operation	
11 (Y)	12 (R)	Sound signal front speaker RH	Output	ON	Sound output	 SKIB3609E
13 (L)	14 (B/W)	Sound signal rear speaker RH	Output	ON	Sound output	 SKIB3609E
16 (LG)	15 (O)	Steering switch signal B	Input	ON	Press and hold VOL DOWN switch	0 V
					Press and hold VOL UP switch	1.34 V
					Press and hold  switch	2.45 V
					Except for above.	5.0 V
18 (SB)	Ground	Vehicle speed signal	Input	ON	When vehicle speed is ap- prox. 40 km/h (25 MPH)	 JSNIA0012GB
19 (Y)	Ground	Battery power supply	Input	OFF	—	Battery voltage
20 (B)	Ground	Ground	—	ON	—	0 V
24 (B)	—	TEL I/F –	Input	ON	—	 SKIB3609E
25 (W)	—	TEL I/F +	Input	ON	—	 SKIB3609E
28 (R)	—	MCAN2 H	Input/ Output	—	—	—

AUDIO UNIT

< ECU DIAGNOSIS INFORMATION >

[DISPLAY AUDIO WITH AMPLIFIER]

Terminal (Wire color)		Description		Condition		Reference value (Approx.)
+	—	Signal name	Input/ Output	Ignition switch	Operation	
29 (G)	—	MCAN2 L	Input/ Output	—	—	—
30	Shield	MCAN shield	—	—	—	—
31 (L)	—	MCAN1 H	Input/ Output	—	—	—
32 (W)	—	MCAN1 L	Input/ Output	—	—	—
46 (B)	Ground	EQ2	—	ON	—	0 V
48 (B)	Ground	EQ3	—	ON	—	0 V
53 (R)	—	V BUS signal	—	—	—	—
54 (B)	—	USB ground	—	—	—	—
55 (G)	—	USB D+ signal	—	—	—	—
56 (W)	—	USB D- signal	—	—	—	—
57	—	Shield	—	—	—	—
58 (B)	Ground	Satellite antenna signal	Input	ON	—	5.0 V
59 (B)	—	SAT Shield	—	—	—	—
61 (B)	Ground	AM-FM main antenna	—	—	—	—

A
B
C
D
E
F
G
H
I
J
K
L
M
O
P

AV

AUDIO AMP.

< ECU DIAGNOSIS INFORMATION >


[DISPLAY AUDIO WITH AMPLIFIER]

AUDIO AMP.




Reference Value

INFOID:000000009291996

TERMINAL LAYOUT









PHYSICAL VALUES

Terminal (wire color)		Description		Condition		Reference value (Approx.)
+	–	Signal name	Input/ Output	Ignition switch	Operation	
1 (Y)	Ground	Battery	Input	–	–	Battery voltage
2 (W)	18 (G)	Subwoofer	Output	ON	Receive audio signal	 SKIA0177E
3 (O)	19 (BR)	Subwoofer	Output	ON	Receive audio signal	 SKIA0177E
4 (B)	Ground	Ground	–	ON	–	–
9 (G/W)	Ground	Amp. ON signal	Input	ON	–	Greater than 6.5 V
11 (G)	27 (B)	Rear door speaker LH	Output	ON	Receive audio signal	 SKIA0177E

AUDIO AMP.

< ECU DIAGNOSIS INFORMATION >




[DISPLAY AUDIO WITH AMPLIFIER]

Terminal (wire color)		Description		Condition		Reference value (Approx.)
+	–	Signal name	Input/ Output	Ignition switch	Operation	
12 (GR)	28 (O)	Rear door speaker RH	Output	ON	Receive audio signal	 SKIA0177E
13 (W)	29 (P)	Front tweeter RH	Output	ON	Receive audio signal	 SKIA0177E
14 (Y)	30 (GR)	Front tweeter LH	Output	ON	Receive audio signal	 SKIA0177E
15 (BR)	31 (L)	Front door speaker LH	Output	ON	Receive audio signal	 SKIA0177E
16 (LG)	32 (R)	Front door speaker RH	Output	ON	Receive audio signal	 SKIA0177E
17 (R/B)	Ground	Battery	Input	–	–	Battery voltage
20 (B)	Ground	Ground	–	ON	–	–
21 (Y)	5 (R)	Audio sound signal front RH	Input	ON	Receive audio signal	 SKIA0177E

AUDIO AMP.

< ECU DIAGNOSIS INFORMATION >

[DISPLAY AUDIO WITH AMPLIFIER]

Terminal (wire color)		Description		Condition		Reference value (Approx.)
+	-	Signal name	Input/ Output	Ignition switch	Operation	
22 (W)	6 (B)	Audio sound signal front LH	Input	ON	Receive audio signal	 SKIA0177E
23 (L)	7 (B/W)	Audio sound signal rear RH	Input	ON	Receive audio signal	 SKIA0177E
24 (P)	8 (B/R)	Audio sound signal rear LH	Input	ON	Receive audio signal	 SKIA0177E

BLUETOOTH CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >


[DISPLAY AUDIO WITH AMPLIFIER]

BLUETOOTH CONTROL UNIT


Reference Value

INFOID:000000009291997

TERMINAL LAYOUT




PHYSICAL VALUES

Terminal (wire color)		Description		Condition		Reference value (Approx.)
+	–	Signal name	Input/ output	Ignition switch	Condition	
1 (R/B)	Ground	Battery power	Input	–	–	Battery voltage
2 (G/Y)	Ground	ACC power	Input	ACC or ON	–	Battery voltage
3 (W/G)	Ground	IGN power	Input	ON or START	–	Battery voltage
4 (B)	Ground	Ground	–	ON	–	0V
6	–	MIC Shield	–	–	–	–
7 (G)	8 (L)	MIC in signal	Input	–	–	–
9 (W)	10 (B)	Audio out	Output	ACC or ON	Bluetooth control unit sends audio signal	 SKIB3609E
12 (BR)	Ground	Ladder in 1	Input	ACC or ON	Press and hold MODE switch.	0 V
					Press and hold △ switch.	1.34 V
					Press and hold ▽ switch.	2.45 V
					Press and hold ⚡ switch.	3.43 V
					Except for above.	5.0 V
13 (L)	Ground	Ladder in 2	Input	ACC or ON	Press VOL DOWN switch	0 V
					Press VOL UP switch.	1.34 V
					Press ⏮ switch.	2.45 V
					Except for above.	5.0 V

BLUETOOTH CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >

[DISPLAY AUDIO WITH AMPLIFIER]


Terminal (wire color)		Description		Condition		Reference value (Approx.)
+	–	Signal name	Input/ output	Ignition switch	Condition	
14 (G)	-	Ladder in ground	Input	-	-	-
17 (V)	Ground	Ladder out 1	Input	ACC or ON	Press and hold MODE switch.	0 V
					Press and hold Δ switch.	1.34 V
					Press and hold ∇ switch.	2.45 V
					Press and hold  switch.	3.43 V
					Except for above.	5.0 V
18 (LG)	Ground	Ladder out 2	Input	ACC or ON	Press VOL DOWN switch	0 V
					Press VOL UP switch.	1.34 V
					Press  switch.	2.45 V
					Except for above.	5.0 V
19 (O)	Ground	Ladder out ground	Output	–	–	–
21 (B)	Ground	Cont 2	–	–	–	0V
22 (B)	Ground	Cont 3	–	–	–	0V
23 (B)	Ground	Cont 4	–	–	–	0V
28 (SB)	Ground	Vehicle speed signal (8-pulse)	Input	ON	When vehicle speed is approx. 40 km/h (25 MPH)	
29 (Y)	Ground	Microphone power	Output	ON	–	5V
33 (B)	–	Bluetooth antenna	–	–	–	–
34	–	Bluetooth antenna shield	–	–	–	–
35 (R)	–	MCAN H	–	–	–	–
36 (G)	–	MCAN L	–	–	–	–
37	–	MCAN shield	–	–	–	–

[DISPLAY AUDIO WITH AMPLIFIER]

WIRING DIAGRAM

Wiring Diagram

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P




* : THIS CONNECTOR IS NOT SHOWN IN "HARNES LAYOUT" OF PG SECTION.

ABNWA1672GB

DISPLAY AUDIO WITH AMPLIFIER

< WIRING DIAGRAM >


[DISPLAY AUDIO WITH AMPLIFIER]



ABNWA1673GB

[DISPLAY AUDIO WITH AMPLIFIER]

A
B
C
D
E
F
G
H
I
J
K
L
M
AV
O
P




DISPLAY AUDIO WITH AMPLIFIER

< WIRING DIAGRAM >

[DISPLAY AUDIO WITH AMPLIFIER]


DISPLAY AUDIO WITH AMPLIFIER CONNECTORS

Connector No.	M1
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
1	Y	– (WITHOUT NAVI)
13	SHIELD	–
14	G	– (WITHOUT NAVI)
15	L	– (WITHOUT NAVI)

Connector No.	M4
Connector Name	FUSE BLOCK (J/B)
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
2P	W/G	–
4P	G/B	–
16P	R/B	–

Connector No.	M8
Connector Name	WIRE TO WIRE
Connector Color	BROWN




Terminal No.	Color of Wire	Signal Name
2	L	–
3	BR	–

Connector No.	M24
Connector Name	COMBINATION METER
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
6	SB	SPEED OUT 8

Connector No.	M30
Connector Name	COMBINATION SWITCH (SPIRAL CABLE)
Connector Color	GRAY



Terminal No.	Color of Wire	Signal Name
24	BR	–
25	L	– (WITHOUT NAVI)
31	G	–

[DISPLAY AUDIO WITH AMPLIFIER]

A
B
C
D
E
F
G
H
I
J
K
L
M
AV
O
P


2013 Xterra

DISPLAY AUDIO WITH AMPLIFIER

< WIRING DIAGRAM >


[DISPLAY AUDIO WITH AMPLIFIER]

Connector No.	M46
Connector Name	AUDIO UNIT (WITH DISPLAY AUDIO WITH AMPLIFIER)
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
1	G/W	AMP ON
2	W	FR SP LH (+)
3	B	FR SP LH (-)
4	P	RR SP LH (+)
5	B/R	RR SP LH (-)
6	V	STRG SW A
7	G/B	ACC
8	GR	ILL (-)
9	R	ILL (+)
10	-	-
11	Y	FR SP RH (+)
12	R	FR SP RH (-)
13	L	RR SP RH (+)
14	B/W	RR SP RH (-)
15	O	STRG SW GND
16	LG	STRG SW B
17	-	-
18	SB	SPD
19	Y	+B
20	B	GND

Connector No.	M40
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1J	O	-
2J	BR	-
3J	G	-
6J	G	-
7J	W	-
8J	B	-

Connector No.	M37
Connector Name	AUDIO UNIT (WITH DISPLAY AUDIO WITH AMPLIFIER)
Connector Color	GRAY



Terminal No.	Color of Wire	Signal Name
60	-	-
61	B	ANT MAIN
62	-	-

ABNIA4254GB


DISPLAY AUDIO WITH AMPLIFIER

< WIRING DIAGRAM >

[DISPLAY AUDIO WITH AMPLIFIER]


Terminal No.	Color of Wire	Signal Name
41	—	—
42	—	—
43	—	—
44	—	—
45	—	—
46	B	EQ2
47	—	—
48	B	EQ3
49	—	—
50	—	—
51	—	—
52	—	—

Connector No.	M65 AUDIO UNIT (WITH DISPLAY AUDIO WITH AMPLIFIER)
Connector Name	
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
21	—	—
22	—	—
23	—	—
24	B	TEL VIOCE (-)
25	W	TEL VIOCE (+)
26	—	—
27	—	—
28	R	MCAN2 H
29	G	MCAN2 L
30	SHIELD	MCAN GND
31	L	MCAN1 H
32	W	MCAN1 L
33	—	—
34	—	—
35	—	—
36	—	—
37	—	—
38	—	—
39	—	—
40	—	—

Connector No.	M48 AUDIO UNIT (WITH DISPLAY AUDIO WITH AMPLIFIER)
Connector Name	
Connector Color	PINK



Terminal No.	Color of Wire	Signal Name
58	B	SAT ANT
59	SHIELD	SAT SHIELD

ABNIA4255GB

A
B
C
D
E
F
G
H
I
J
K
L
M
O
P

AV

DISPLAY AUDIO WITH AMPLIFIER

< WIRING DIAGRAM >


[DISPLAY AUDIO WITH AMPLIFIER]

Connector No.	M75
Connector Name	WIRE TO WIRE
Connector Color	WHITE

5	4		3	2	1	
12	11	10	9	8	7	6



Connector No.	M67
Connector Name	WIRE TO WIRE
Connector Color	PINK



Terminal No.	Color of Wire	Signal Name
4	R	—
11	LG	—

Terminal No.	Color of Wire	Signal Name
1	B	—
2	SHIELD	—

Connector No.	M66
Connector Name	AUDIO UNIT (WITH DISPLAY AUDIO WITH AMPLIFIER)
Connector Color	GREEN

54	53	55
56	55	57



Terminal No.	Color of Wire	Signal Name
53	R	VBUS
54	B	USB GND
55	G	USB D +
56	W	USB D -
57	SHIELD	SHIELD

Connector No.	M111
Connector Name	FRONT TWEETER RH
Connector Color	BROWN

2	1
---	---



Connector No.	M109
Connector Name	FRONT TWEETER LH
Connector Color	BROWN

2	1
---	---



Connector No.	M102
Connector Name	COMBINATION SWITCH (SPIRAL CABLE)
Connector Color	GRAY

14	15	16	17	18	19	20	21
----	----	----	----	----	----	----	----



Terminal No.	Color of Wire	Signal Name
1	W	—
2	P	— (EXCEPT BASE AUDIO SYSTEM)

Terminal No.	Color of Wire	Signal Name
1	Y	— (EXCEPT BASE AUDIO SYSTEM)
2	GR	— (EXCEPT BASE AUDIO SYSTEM)

Terminal No.	Color of Wire	Signal Name
15	GR	—
16	G	—
18	B	—


ABNIA4256GB

DISPLAY AUDIO WITH AMPLIFIER

< WIRING DIAGRAM >


[DISPLAY AUDIO WITH AMPLIFIER]

Connector No.	M214
Connector Name	USB INTERFACE
Connector Color	BLUE




Terminal No.	Color of Wire	Signal Name
1	B	—
2	G	—
3	W	—
4	R	—
5	SHIELD	—

Connector No.	M205
Connector Name	WIRE TO WIRE
Connector Color	BLUE




Terminal No.	Color of Wire	Signal Name
1	SHIELD	—
2	B	—
3	R	—
4	W	—
5	G	—

Connector No.	M169
Connector Name	WIRE TO WIRE
Connector Color	BLUE




Terminal No.	Color of Wire	Signal Name
1	SHIELD	—
2	B	—
3	R	—
4	W	—
5	G	—

Connector No.	E152
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
77G	Y	—

Connector No.	M501
Connector Name	SATELLITE ANTENNA
Connector Color	BROWN



Terminal No.	Color of Wire	Signal Name
1	B	—
2	SHIELD	—

Connector No.	M500
Connector Name	WIRE TO WIRE
Connector Color	PINK



Terminal No.	Color of Wire	Signal Name
1	B	—
2	SHIELD	—

ABNIA4257GB


A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P

AV

DISPLAY AUDIO WITH AMPLIFIER

< WIRING DIAGRAM >

[DISPLAY AUDIO WITH AMPLIFIER]



Connector No.	B106
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	5	12
Color of Wire	GR	O
Signal Name	-	-

Connector No.	B72
Connector Name	SUBWOOFER
Connector Color	WHITE



Terminal No.	1	2	3	4
Color of Wire	W	G	O	BR
Signal Name	-	-	-	-

ABNIA4258GB

DISPLAY AUDIO WITH AMPLIFIER

< WIRING DIAGRAM >

[DISPLAY AUDIO WITH AMPLIFIER]

Terminal No.	Color of Wire	Signal Name
21	B	CONT 2
22	B	CONT 3
23	B	CONT 4
24	-	-
25	-	-
26	-	-
27	-	-
28	SB	SPEED SIGNAL
29	Y	MIC POWER
30	-	-
31	-	-
32	-	-

Terminal No.	Color of Wire	Signal Name
6	SHIELD	MIC SHIELD
7	G	MIC IN+
8	L	MIC IN-
9	W	AUDIO OUT+
10	B	AUDIO OUT-
11	R	MUTE CONTROL
12	BR	LADDER IN 1
13	L	LADDER IN 2
14	G	LADDER IN GND
15	-	-
16	-	-
17	V	LADDER OUT 1
18	LG	LADDER OUT 2
19	O	LADDER OUT GND
20	-	-

Connector No.	B141
Connector Name	BLUETOOTH® CONTROL UNIT
Connector Color	WHITE



2	4	6	8	10	12	14	16	18	20	22	24	26	28	30	32
1	3	5	7	9	11	13	15	17	19	21	23	25	27	29	31

Terminal No.	Color of Wire	Signal Name
1	R/B	BATT
2	G/Y	ACC
3	W/G	IGN
4	B	GND
5	-	-

Terminal No.	Color of Wire	Signal Name
35	R	CAN-H1
36	G	CAN-L1
37	SHIELD	CAN SHIELD 1
38	-	-
39	-	-
40	-	-
41	-	-
42	-	-

Connector No.	B143
Connector Name	BLUETOOTH® CONTROL UNIT
Connector Color	WHITE



35	37	39	41
36	38	40	42

Connector No.	B142
Connector Name	BLUETOOTH® CONTROL UNIT
Connector Color	BLACK



33	34
----	----

Terminal No.	Color of Wire	Signal Name
33	B	BT ANTENNA
34	SHIELD	BT ANTENNA SHIELD

ABNIA4259GB

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P

AV


DISPLAY AUDIO WITH AMPLIFIER

< WIRING DIAGRAM >

[DISPLAY AUDIO WITH AMPLIFIER]

Terminal No.	Color of Wire	Signal Name
52M	L	-
54M	B/R	-
55M	P	-
57M	R	-
58M	Y	-
60M	B	-
61M	W	-
63M	G/W	-
72M	R	-
73M	BR	-
74M	W	-
76M	R/B	-
77M	LG	-
78M	O	-
79M	G	-

Terminal No.	Color of Wire	Signal Name
8M	B	-
9M	G	-
10M	G/Y	-
31M	B	-
34M	V	-
35M	BR	-
36M	SHIELD	-
37M	W/G	-
38M	G	-
39M	SHIELD	-
40M	L	-
41M	Y	-
42M	W	-
43M	O	-
44M	LG	-
45M	L	-
46M	G	-
47M	SB	-
49M	R	-
50M	G	-
51M	B/W	-



Terminal No.	Color of Wire	Signal Name
1M	GR	-
2M	Y	-
3M	P	-
4M	W	-
5M	R/B	-
6M	L	-
7M	BR	-

ABNIA4260GB

DISPLAY AUDIO WITH AMPLIFIER

< WIRING DIAGRAM >

[DISPLAY AUDIO WITH AMPLIFIER]

Terminal No.	Color of Wire	Signal Name
13	W	FR RH TW (+)
14	Y	FR LH TW (+)
15	BR	FRSP LH OUT (+)
16	LG	FRSP RH OUT (+)
21	Y	FRSP RH (+) IN
22	W	FRSP LH (+) IN
23	L	RRSP RH (+) IN
24	P	RRSP LH (+) IN
25	-	-
26	-	-
27	B	RRSP LH OUT (-)
28	O	RRSP RH OUT (-)
29	P	FR RH TW (-)
30	GR	FR LH TW (-)
31	L	FRSP LH OUT (-)
32	R	FRSP RH OUT (-)

Connector No.	B159
Connector Name	AUDIO AMPLIFIER
Connector Color	WHITE

16	15	14	13	12	11	10	9	8	7	6	5
32	31	30	29	28	27	26	25	24	23	22	21



Terminal No.	Color of Wire	Signal Name
5	R	FRSP RH (-) IN
6	B	FRSP LH (-) IN
7	B/W	RRSP RH (-) IN
8	B/R	RRSP LH (-) IN
9	G/W	AMP ON/OFF SIGNAL
10	-	-
11	G	RRSP LH OUT (+)
12	GR	RRSP RH OUT (+)

Terminal No.	Color of Wire	Signal Name
1	Y	BAT
2	W	WOOFER (+) 1
3	O	WOOFER (+) 2
4	B	GND
17	R/B	BAT
18	G	WOOFER (-) 1
19	BR	WOOFER (-) 2
20	B	GND

4	3	2	1
20	19	18	17



Connector No.	D2
Connector Name	WIRE TO WIRE
Connector Color	BROWN

1	2	3	4	5
6	7	8	9	10
11	12			



Connector No.	R8
Connector Name	MICROPHONE
Connector Color	WHITE

1	2	3	4
---	---	---	---



Connector No.	R1
Connector Name	WIRE TO WIRE
Connector Color	WHITE

12	11	10	9	8	7	6	5	4	3	2	1
24	23	22	21	20	19	18	17	16	15	14	13



Terminal No.	Color of Wire	Signal Name
2	L/R	-
3	L/W	-

Terminal No.	Color of Wire	Signal Name
1	G	- (WITHOUT NAVI)
2	L	- (WITHOUT NAVI)
3	-	-
4	Y	- (WITHOUT NAVI)

Terminal No.	Color of Wire	Signal Name
1	Y	- (WITHOUT NAVI)
13	SHIELD	-
14	G	- (WITHOUT NAVI)
15	L	- (WITHOUT NAVI)

ABNIA4261GB

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P

AV

DISPLAY AUDIO WITH AMPLIFIER

< WIRING DIAGRAM >

[DISPLAY AUDIO WITH AMPLIFIER]

Connector No.	D112
Connector Name	FRONT DOOR SPEAKER RH
Connector Color	WHITE



1	2
---	---

Terminal No.	Color of Wire	Signal Name
1	W/B	—
2	L/B	—

Connector No.	D101
Connector Name	WIRE TO WIRE
Connector Color	WHITE



1	2	3	4	5		
6	7	8	9	10	11	12

Terminal No.	Color of Wire	Signal Name
4	L/B	—
11	W/B	—

Connector No.	D12
Connector Name	FRONT DOOR SPEAKER LH
Connector Color	WHITE



2	1
---	---

Terminal No.	Color of Wire	Signal Name
1	L/W	—
2	L/R	—

Connector No.	D201
Connector Name	WIRE TO WIRE
Connector Color	WHITE



5	4		3	2	1	
12	11	10	9	8	7	6

Connector No.	D153
Connector Name	WIRE TO WIRE
Connector Color	WHITE



1	2	3	4	5		
6	7	8	9	10	11	12

Connector No.	D152
Connector Name	WIRE TO WIRE
Connector Color	WHITE



5	4	3	2	1		
12	11	10	9	8	7	6

Terminal No.	Color of Wire	Signal Name
5	L	—
12	O	—

Terminal No.	Color of Wire	Signal Name
4	R	—
11	LG	—

Terminal No.	Color of Wire	Signal Name
4	R	—
11	LG	—

ABNIA4262GB

DISPLAY AUDIO WITH AMPLIFIER

< WIRING DIAGRAM >

[DISPLAY AUDIO WITH AMPLIFIER]

Connector No.	D301
Connector Name	WIRE TO WIRE
Connector Color	WHITE



5	4	3		2	1
12	11	10	9	8	7
				6	

Terminal No.	Color of Wire	Signal Name
5	L	–
12	O	–

Connector No.	D208
Connector Name	REAR TWEETER LH
Connector Color	BROWN



2	1
---	---

Terminal No.	Color of Wire	Signal Name
1	L	–
2	O	–

Connector No.	D207
Connector Name	REAR DOOR SPEAKER LH
Connector Color	WHITE



2	1
---	---

Terminal No.	Color of Wire	Signal Name
1	L	–
2	O	–

Connector No.	D308
Connector Name	REAR TWEETER RH
Connector Color	BROWN



2	1
---	---

Terminal No.	Color of Wire	Signal Name
1	L	–
2	O	–

Connector No.	D307
Connector Name	REAR DOOR SPEAKER RH
Connector Color	WHITE



2	1
---	---

Terminal No.	Color of Wire	Signal Name
1	L	–
2	O	–

ABNIA4333GB

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P

AV


BASIC INSPECTION

DIAGNOSIS AND REPAIR WORKFLOW

Work Flow

INFOID:000000009291999

OVERALL SEQUENCE



DETAILED FLOW

1.GET INFORMATION FOR SYMPTOM

Get detailed information from the customer about the symptom (the condition and the environment when the incident/malfunction occurred).

>> GO TO 2

2.CONFIRM THE SYMPTOM

Try to confirm the symptom described by the customer. Verify relation between the symptom and the condition when the symptom is detected.

>> GO TO 3

3.DETECT MALFUNCTIONING PART BY DIAGNOSTIC PROCEDURE

Inspect according to Diagnostic Procedure of the system.

DIAGNOSIS AND REPAIR WORKFLOW

< BASIC INSPECTION >

[DISPLAY AUDIO WITH AMPLIFIER]

Is malfunctioning part detected?

YES >> GO TO 4

NO >> GO TO 2

4.REPAIR OR REPLACE THE MALFUNCTIONING PART

1. Repair or replace the malfunctioning part.
2. Reconnect parts or connectors disconnected during Diagnostic Procedure.

>> GO TO 5

5.FINAL CHECK

Refer to confirmed symptom in step 2, and make sure that the symptom is not detected.

Was the repair confirmed?

YES >> Inspection End.

NO >> GO TO 2

A

B

C

D

E

F

G

H

I

J

K

L

M

AV

O

P

POWER SUPPLY AND GROUND CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[DISPLAY AUDIO WITH AMPLIFIER]

DTC/CIRCUIT DIAGNOSIS

POWER SUPPLY AND GROUND CIRCUIT

AUDIO UNIT

AUDIO UNIT : Diagnosis Procedure

INFOID:000000009292000

Regarding Wiring Diagram information, refer to [AV-117, "Wiring Diagram"](#).

1.CHECK FUSE

Check that the following fuses are not blown.

Terminal No.	Signal name	Fuse No.
7	ACC power supply	4 (10A)
19	Battery power supply	29 (20A)

Are the fuses blown?

YES >> Replace the blown fuse after repairing the affected circuit.

NO >> GO TO 2.

2.CHECK POWER SUPPLY CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect audio unit connector M46.
3. Check voltage between audio unit connector M46 and ground.

Audio unit		Ground	Condition	Voltage (Approx.)
Connector	Terminal			
M46	7	—	Ignition switch: ON	Battery voltage
	19		Ignition switch: OFF	

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace harness or connectors.

3.CHECK GROUND CIRCUIT

1. Disconnect audio unit connector M65.
2. Check continuity between audio unit connectors and ground.

Audio unit		Ground	Continuity
Connector	Terminal		
M46	20	—	Yes
M65	46		
	48		

Is the inspection result normal?

YES >> Inspection End.

NO >> Repair or replace harness or connectors.

AUDIO AMP.

AUDIO AMP. : Diagnosis Procedure

INFOID:000000009292001

Regarding Wiring Diagram information, refer to [AV-117, "Wiring Diagram"](#).

POWER SUPPLY AND GROUND CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[DISPLAY AUDIO WITH AMPLIFIER]

1.CHECK FUSE

Check that the following fuse is not blown.

Terminal No.	Signal name	Fuse No.
1	Battery power supply	17 (15A)
17		

Is the fuse blown?

YES >> Replace the blown fuse after repairing the affected circuit.

NO >> GO TO 2.

2.CHECK POWER SUPPLY CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect audio amplifier connector B158.
3. Check voltage between audio amplifier connector B158 and ground.

Audio amplifier		Ground	Condition	Voltage (Approx.)
Connector	Terminal			
B158	1	—	Ignition switch: OFF	Battery voltage
	17			

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace harness or connectors.

3.CHECK GROUND CIRCUIT

Check continuity between audio amplifier connector B158 and ground.

Audio amplifier		Ground	Continuity
Connector	Terminal		
B158	4	—	Yes
	20		

Is the inspection result normal?

YES >> Inspection End.

NO >> Repair or replace harness or connectors.

BLUETOOTH CONTROL UNIT

BLUETOOTH CONTROL UNIT : Diagnosis Procedure

INFOID:000000009292002

Regarding Wiring Diagram information, refer to [AV-117, "Wiring Diagram"](#).

1.CHECK FUSE

Check that the following fuses are not blown.

Terminal No.	Signal name	Fuse No.
1	Battery power supply	29 (20A)
2	ACC power supply	4 (10A)
3	Ignition power supply	12 (10A)

Are the fuses blown?

YES >> Replace the blown fuse after repairing the affected circuit.

NO >> GO TO 2.

POWER SUPPLY AND GROUND CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[DISPLAY AUDIO WITH AMPLIFIER]

2.CHECK POWER SUPPLY CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect Bluetooth® control unit connector B141.
3. Check voltage between Bluetooth® control unit connector B141 and ground.

Bluetooth® control unit		Ground	Condition	Voltage (Approx.)
Connector	Terminal			
B141	1	—	Ignition switch: OFF	Battery voltage
	2		Ignition switch: ON	
	3			

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace harness or connectors.

3.CHECK GROUND CIRCUIT

1. Turn ignition switch OFF.
2. Check continuity between Bluetooth® control unit connector B141 and ground.

Bluetooth® control unit		Ground	Continuity
Connector	Terminal		
B141	4	—	Yes
	21		
	22		
	23		

Is the inspection result normal?

YES >> Inspection End.

NO >> Repair or replace harness or connectors.

MICROPHONE

MICROPHONE : Diagnosis Procedure

INFOID:000000009292003

Regarding Wiring Diagram information, refer to [AV-117, "Wiring Diagram"](#).

1.CHECK POWER SUPPLY CIRCUIT

1. Turn ignition switch ON.
2. Check voltage between microphone connector R8 and ground.

(+)		(-)	Value (Approx.)
Connector	Terminal		
R8	4	Ground	5V

Is the inspection result normal?

YES >> GO TO 3.

NO >> GO TO 2.

2.CHECK POWER SUPPLY CIRCUIT CONTINUITY

1. Turn ignition switch OFF.
2. Disconnect microphone connector and Bluetooth® control unit connector B141.
3. Check continuity between microphone connector R8 and Bluetooth® control unit connector B141.

POWER SUPPLY AND GROUND CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[DISPLAY AUDIO WITH AMPLIFIER]

Microphone		Bluetooth® control unit		Continuity
Connector	Terminal	Connector	Terminal	
R8	4	B141	29	Yes

4. Check continuity between microphone connector R8 and ground.

Microphone		—	Continuity
Connector	Terminal		
R8	4	Ground	No

Is the inspection result normal?

YES >> Replace the Bluetooth® control unit. Refer to [AV-176, "Removal and Installation"](#).

NO >> Repair or replace harness or connectors.

3.CHECK GROUND CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect microphone connector and Bluetooth® control unit connector B141.
3. Check continuity between microphone connector R8 and Bluetooth® control unit connector B141.

Microphone		Bluetooth® control unit		Continuity
Connector	Terminal	Connector	Terminal	
R8	2	B141	8	Yes

Is the inspection result normal?

YES >> Inspection End.

NO >> Repair or replace harness or connectors.

AV

FRONT DOOR SPEAKER

< DTC/CIRCUIT DIAGNOSIS >

[DISPLAY AUDIO WITH AMPLIFIER]

FRONT DOOR SPEAKER

Diagnosis Procedure

INFOID:000000009292004

Regarding Wiring Diagram information, refer to [AV-117. "Wiring Diagram"](#).

1.CONNECTOR CHECK

Check the audio unit, audio amplifier and speaker connectors for the following:

- Proper connection
- Damage
- Disconnected or loose terminals

Is the inspection result normal?

YES >> GO TO 2

NO >> Repair the terminals or connectors.

2.CHECK FRONT DOOR SPEAKER SIGNAL CIRCUIT CONTINUITY

1. Disconnect audio amplifier connector B159 and suspect front door speaker connector.
2. Check continuity between audio amplifier connector B159 and suspect front door speaker connector.

Audio amplifier		Front door speaker		Continuity
Connector	Terminal	Connector	Terminal	
B159	15	D12 (LH)	1	Yes
	31		2	
	16	D112 (RH)	1	
	32		2	

3. Check continuity between audio amplifier connector B159 and ground.

Audio amplifier		Ground	Continuity
Connector	Terminal		
B159	15	—	No
	31		
	16		
	32		

Is the inspection result normal?

YES >> GO TO 3

NO >> Repair or replace harness or connectors.

3.CHECK FRONT DOOR SPEAKER SIGNAL


1. Connect audio amplifier connector B159 and suspect front door speaker connector.
2. Turn ignition switch to ACC.
3. Push audio unit POWER switch.
4. Check signal between the terminals of audio amplifier connector B159.

Audio amplifier connector B159		Condition	Reference value
(+)	(-)		
Terminal	Terminal		

FRONT DOOR SPEAKER

< DTC/CIRCUIT DIAGNOSIS >

[DISPLAY AUDIO WITH AMPLIFIER]

15	31	Audio signal output	
16	32		

Is the inspection result normal?

YES >> Replace front door speaker. Refer to [AV-171, "Removal and Installation"](#).

NO >> GO TO 4.

4.CHECK PRE-AMP SIGNAL CIRCUIT CONTINUITY

1. Disconnect audio unit connector M46 and audio amplifier connector B159.
2. Check continuity between audio unit connector M46 and audio amplifier connector B159.

Audio unit		Audio amplifier		Continuity
Connector	Terminal	Connector	Terminal	
M46	2	B159	22	Yes
	3		6	
	11		21	
	12		5	

3. Check continuity between audio unit connector M46 and ground.

Audio unit		Ground	Continuity
Connector	Terminal		
M46	2	—	No
	3		
	11		
	12		


Is the inspection result normal?

YES >> GO TO 5.

NO >> Repair or replace harness or connectors.

5.CHECK PRE-AMP SIGNAL

1. Connect audio unit connector M46 and audio amplifier connector B159.
2. Turn ignition switch to ACC.
3. Push audio unit POWER switch.
4. Check signal between the terminals of audio unit connector M46.

Audio unit connector M46		Condition	Reference value
(+)	(-)		
Terminal	Terminal	Audio signal output	
2	3		
11	12		

Is the inspection result normal?

FRONT DOOR SPEAKER

< DTC/CIRCUIT DIAGNOSIS >

[DISPLAY AUDIO WITH AMPLIFIER]

-
- YES >> Replace audio amplifier. Refer to [AV-169, "Removal and Installation"](#).
NO >> Replace audio unit. Refer to [AV-168, "Removal and Installation"](#).

FRONT TWEETER

< DTC/CIRCUIT DIAGNOSIS >

[DISPLAY AUDIO WITH AMPLIFIER]

FRONT TWEETER

Diagnosis Procedure

INFOID:000000009292005

Regarding Wiring Diagram information, refer to [AV-117, "Wiring Diagram"](#).

1.CONNECTOR CHECK

Check the audio unit, audio amplifier and tweeter connectors for the following:

- Proper connection
- Damage
- Disconnected or loose terminals

Is the inspection result normal?

YES >> GO TO 2

NO >> Repair the terminals or connectors.

2.CHECK FRONT TWEETER SIGNAL CIRCUIT CONTINUITY

1. Disconnect audio amplifier connector B159 and suspect front tweeter connector.
2. Check continuity between audio amplifier connector B159 and suspect front tweeter connector.

Audio amplifier		Front tweeter		Continuity
Connector	Terminal	Connector	Terminal	
B159	14	M109 (LH)	1	Yes
	30		2	
	13	M111 (RH)	1	
	29		2	

3. Check continuity between audio amplifier connector B159 and ground.

Audio amplifier		Ground	Continuity
Connector	Terminal		
B159	14	—	No
	30		
	13		
	29		

Is the inspection result normal?

YES >> GO TO 3

NO >> Repair or replace harness or connectors.

3.CHECK FRONT TWEETER SIGNAL


1. Connect audio amplifier connector B159 and suspect front tweeter connector.
2. Turn ignition switch to ACC.
3. Push audio unit POWER switch.
4. Check signal between the terminals of audio amplifier connector B159.

Audio amplifier connector B159		Condition	Reference value
(+)	(-)		
Terminal	Terminal		

FRONT TWEETER

< DTC/CIRCUIT DIAGNOSIS >

[DISPLAY AUDIO WITH AMPLIFIER]

14	30	Audio signal output	
13	29		

Is the inspection result normal?

YES >> Replace front tweeter. Refer to [AV-170, "Removal and Installation"](#).

NO >> GO TO 4.

4.CHECK PRE-AMP SIGNAL CIRCUIT CONTINUITY

1. Disconnect audio unit connector M46 and audio amplifier connector B159.
2. Check continuity between audio unit connector M46 and audio amplifier connector B159.

Audio unit		Audio amplifier		Continuity
Connector	Terminal	Connector	Terminal	
M46	2	B159	22	Yes
	3		6	
	11		21	
	12		5	

3. Check continuity between audio unit connector M46 and ground.

Audio unit		Ground	Continuity
Connector	Terminal		
M46	2	—	No
	3		
	11		
	12		


Is the inspection result normal?

YES >> GO TO 5.

NO >> Repair or replace harness or connectors.

5.CHECK PRE-AMP SIGNAL

1. Connect audio unit connector M46 and audio amplifier connector B159.
2. Turn ignition switch to ACC.
3. Push audio unit POWER switch.
4. Check signal between the terminals of audio unit connector M46.

Audio unit connector M46		Condition	Reference value
(+)	(-)		
Terminal	Terminal	Audio signal output	
2	3		
11	12		

Is the inspection result normal?

FRONT TWEETER

< DTC/CIRCUIT DIAGNOSIS >

[DISPLAY AUDIO WITH AMPLIFIER]

YES >> Replace audio amplifier. Refer to [AV-169, "Removal and Installation"](#).
NO >> Replace audio unit. Refer to [AV-168, "Removal and Installation"](#).

A

B

C

D

E

F

G

H

I

J

K

L

M

AV

O

P

REAR DOOR SPEAKER

< DTC/CIRCUIT DIAGNOSIS >

[DISPLAY AUDIO WITH AMPLIFIER]

REAR DOOR SPEAKER

Diagnosis Procedure

INFOID:000000009292006

Regarding Wiring Diagram information, refer to [AV-117. "Wiring Diagram"](#).

1.CONNECTOR CHECK

Check the audio unit, audio amplifier and speaker connectors for the following:

- Proper connection
- Damage
- Disconnected or loose terminals

Is the inspection result normal?

YES >> GO TO 2

NO >> Repair the terminals or connectors.

2.CHECK REAR DOOR SPEAKER SIGNAL CIRCUIT CONTINUITY

1. Disconnect audio amplifier connector B159 and suspect rear door speaker connector.
2. Check continuity between audio amplifier connector B159 and suspect rear door speaker connector.

Audio amplifier		Rear door speaker		Continuity
Connector	Terminal	Connector	Terminal	
B159	11	D207 (LH)	1	Yes
	27		2	
	12	D307 (RH)	1	
	28		2	

3. Check continuity between audio amplifier connector B159 and ground.

Audio amplifier		Ground	Continuity
Connector	Terminal		
B159	11	—	No
	27		
	12		
	28		

Is the inspection result normal?

YES >> GO TO 3

NO >> Repair or replace harness or connectors.

3.CHECK REAR DOOR SPEAKER SIGNAL


1. Connect audio amplifier connector B159 and suspect rear door speaker connector.
2. Turn ignition switch to ACC.
3. Push audio unit POWER switch.
4. Check signal between the terminals of audio amplifier connector B159.

Audio amplifier connector B159		Condition	Reference value
(+)	(-)		
Terminal	Terminal		

REAR DOOR SPEAKER

< DTC/CIRCUIT DIAGNOSIS >

[DISPLAY AUDIO WITH AMPLIFIER]

11	27	Audio signal output	
12	28		

Is the inspection result normal?

YES >> Replace rear door speaker. Refer to [AV-172, "Removal and Installation"](#).

NO >> GO TO 4.

4.CHECK PRE-AMP SIGNAL CIRCUIT CONTINUITY

1. Disconnect audio unit connector M46 and audio amplifier connector B159.
2. Check continuity between audio unit connector M46 and audio amplifier connector B159.

Audio unit		Audio amplifier		Continuity
Connector	Terminal	Connector	Terminal	
M46	4	B159	24	Yes
	5		8	
	13		23	
	14		7	

3. Check continuity between audio unit connector M46 and ground.

Audio unit		Ground	Continuity
Connector	Terminal		
M46	4	—	No
	5		
	13		
	14		


Is the inspection result normal?

YES >> GO TO 5.

NO >> Repair or replace harness or connectors.

5.CHECK PRE-AMP SIGNAL

1. Connect audio unit connector M46 and audio amplifier connector B159.
2. Turn ignition switch to ACC.
3. Push audio unit POWER switch.
4. Check signal between the terminals of audio unit connector M46.

Audio unit connector M46		Condition	Reference value
(+)	(-)		
Terminal	Terminal	Audio signal output	
4	5		
13	14		

Is the inspection result normal?

REAR DOOR SPEAKER

< DTC/CIRCUIT DIAGNOSIS >

[DISPLAY AUDIO WITH AMPLIFIER]

-
- YES >> Replace audio amplifier. Refer to [AV-169, "Removal and Installation"](#).
NO >> Replace audio unit. Refer to [AV-168, "Removal and Installation"](#).

REAR TWEETER

Diagnosis Procedure

INFOID:000000009292007

Regarding Wiring Diagram information, refer to [AV-117, "Wiring Diagram"](#).

1.CONNECTOR CHECK

Check the audio unit, audio amplifier and tweeter connectors for the following:

- Proper connection
- Damage
- Disconnected or loose terminals

Is the inspection result normal?

YES >> GO TO 2

NO >> Repair the terminals or connectors.

2.CHECK REAR TWEETER SIGNAL CIRCUIT CONTINUITY

1. Disconnect audio amplifier connector B159 and suspect rear tweeter connector.
2. Check continuity between audio amplifier connector B159 and suspect rear tweeter connector.

Audio amplifier		Rear tweeter		Continuity
Connector	Terminal	Connector	Terminal	
B159	11	D208 (LH)	1	Yes
	27		2	
	12	D308 (RH)	1	
	28		2	

3. Check continuity between audio amplifier connector B159 and ground.

Audio amplifier		Ground	Continuity
Connector	Terminal		
B159	11	—	No
	27		
	12		
	28		

Is the inspection result normal?

YES >> GO TO 3

NO >> Repair or replace harness or connectors.

3.CHECK REAR TWEETER SIGNAL


1. Connect audio amplifier connector B159 and suspect rear tweeter connector.
2. Turn ignition switch to ACC.
3. Push audio unit POWER switch.
4. Check signal between the terminals of audio amplifier connector B159.

Audio amplifier connector B159		Condition	Reference value
(+)	(-)		
Terminal	Terminal		

REAR TWEETER

< DTC/CIRCUIT DIAGNOSIS >

[DISPLAY AUDIO WITH AMPLIFIER]

11	27	Audio signal output	
12	28		

Is the inspection result normal?

YES >> Replace rear tweeter. Refer to [AV-173. "Removal and Installation"](#).

NO >> GO TO 4.

4. CHECK PRE-AMP SIGNAL CIRCUIT CONTINUITY

1. Disconnect audio unit connector M46 and audio amplifier connector B159.
2. Check continuity between audio unit connector M46 and audio amplifier connector B159.

Audio unit		Audio amplifier		Continuity
Connector	Terminal	Connector	Terminal	
M46	4	B159	24	Yes
	5		8	
	13		23	
	14		7	

3. Check continuity between audio unit connector M46 and ground.

Audio unit		Ground	Continuity
Connector	Terminal		
M46	4	—	No
	5		
	13		
	14		


Is the inspection result normal?

YES >> GO TO 5.

NO >> Repair or replace harness or connectors.

5. CHECK PRE-AMP SIGNAL

1. Connect audio unit connector M46 and audio amplifier connector B159.
2. Turn ignition switch to ACC.
3. Push audio unit POWER switch.
4. Check signal between the terminals of audio unit connector M46.

Audio unit connector M46		Condition	Reference value
(+)	(-)		
Terminal	Terminal		
4	5	Audio signal output	
13	14		

Is the inspection result normal?

REAR TWEETER

< DTC/CIRCUIT DIAGNOSIS >

[DISPLAY AUDIO WITH AMPLIFIER]

YES >> Replace audio amplifier. Refer to [AV-169, "Removal and Installation"](#).
NO >> Replace audio unit. Refer to [AV-168, "Removal and Installation"](#).

A

B

C

D

E

F

G

H

I

J

K

L

M

AV

O

P

SUBWOOFER

< DTC/CIRCUIT DIAGNOSIS >

[DISPLAY AUDIO WITH AMPLIFIER]

SUBWOOFER

Diagnosis Procedure

INFOID:000000009292008

Regarding Wiring Diagram information, refer to [AV-117. "Wiring Diagram"](#).

1.CONNECTOR CHECK

Check the audio unit, audio amplifier and subwoofer connectors for the following:

- Proper connection
- Damage
- Disconnected or loose terminals

Is the inspection result normal?

YES >> GO TO 2

NO >> Repair the terminals or connectors.

2.CHECK SUBWOOFER SIGNAL CIRCUIT CONTINUITY

1. Disconnect audio amplifier connector B158 and subwoofer connector.
2. Check continuity between audio amplifier connector B158 and subwoofer connector.

Audio amplifier		Subwoofer		Continuity
Connector	Terminal	Connector	Terminal	
B158	2	B72	1	Yes
	18		2	
	3		3	
	19		4	

3. Check continuity between audio amplifier connector B158 and ground.

Audio amplifier		Ground	Continuity
Connector	Terminal		
B158	2	—	No
	18		
	3		
	19		

Is the inspection result normal?

YES >> GO TO 3

NO >> Repair or replace harness or connectors.

3.CHECK SUBWOOFER SIGNAL


1. Connect audio amplifier connector B158 and subwoofer connector.
2. Turn ignition switch to ACC.
3. Push audio unit POWER switch.
4. Check signal between the terminals of audio amplifier connector B158.

Audio amplifier connector B158		Condition	Reference value
(+)	(-)		
Terminal	Terminal		

SUBWOOFER

< DTC/CIRCUIT DIAGNOSIS >

[DISPLAY AUDIO WITH AMPLIFIER]

2	18	Audio signal output	
3	19		

Is the inspection result normal?

YES >> Replace subwoofer. Refer to [AV-174, "Removal and Installation"](#).

NO >> GO TO 4.

4.CHECK PRE-AMP SIGNAL CIRCUIT CONTINUITY

1. Disconnect audio unit connector M46 and audio amplifier connector B159.
2. Check continuity between audio unit connector M46 and audio amplifier connector B159.

Audio unit		Audio amplifier		Continuity
Connector	Terminal	Connector	Terminal	
M46	4	B159	24	Yes
	5		8	
	13		23	
	14		7	

3. Check continuity between audio unit connector M46 and ground.

Audio unit		Ground	Continuity
Connector	Terminal		
M46	4	—	No
	5		
	13		
	14		


Is the inspection result normal?

YES >> GO TO 5.

NO >> Repair or replace harness or connectors.

5.CHECK PRE-AMP SIGNAL

1. Connect audio unit connector M46 and audio amplifier connector B159.
2. Turn ignition switch to ACC.
3. Push audio unit POWER switch.
4. Check signal between the terminals of audio unit connector M46.

Audio unit connector M46		Condition	Reference value
(+)	(-)		
Terminal	Terminal		
4	5	Audio signal output	
13	14		

Is the inspection result normal?

SUBWOOFER

< DTC/CIRCUIT DIAGNOSIS >

[DISPLAY AUDIO WITH AMPLIFIER]

-
- YES >> Replace audio amplifier. Refer to [AV-169, "Removal and Installation"](#).
NO >> Replace audio unit. Refer to [AV-168, "Removal and Installation"](#).

AMP. ON SIGNAL CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[DISPLAY AUDIO WITH AMPLIFIER]

AMP. ON SIGNAL CIRCUIT

Diagnosis Procedure

INFOID:000000009292009

Regarding Wiring Diagram information, refer to [AV-117. "Wiring Diagram"](#).

1. CHECK AUDIO AMPLIFIER AMP. ON SIGNAL

1. Turn audio system ON.
2. Check voltage between audio amplifier connector B159 and ground.

Audio amplifier		Ground	Voltage (Approx.)
Connector	Terminal		
B159	9	—	Greater than 6.5 V

Is inspection result normal?

- YES >> Inspection End.
NO >> GO TO 2.

2. CHECK AUDIO UNIT AMP. ON SIGNAL

Check voltage between audio unit connector M46 and ground.

Audio unit		Ground	Voltage (Approx.)
Connector	Terminal		
M46	1	—	Greater than 6.5 V

Is inspection result normal?

- YES >> Repair or replace harness or connectors.
NO >> Replace audio unit. Refer to [AV-168. "Removal and Installation"](#).

STEERING SWITCH

< DTC/CIRCUIT DIAGNOSIS >

[DISPLAY AUDIO WITH AMPLIFIER]

STEERING SWITCH

Diagnosis Procedure

INFOID:000000009292011

Regarding Wiring Diagram information, refer to [AV-117, "Wiring Diagram"](#).

1. CHECK STEERING WHEEL AUDIO CONTROL SWITCH RESISTANCE

1. Disconnect combination switch connector M102.
2. Check resistance between combination switch connector terminals.

Combination switch connector M102		Condition	Resistance (Ω) (Approx.)
Terminal	Terminal		
16	18	Depress VOL DOWN switch.	1
		Depress VOL UP switch.	121
		Depress  switch.	321
15		Depress MODE switch.	1
		Depress  switch.	121
		Depress  switch.	321
		Depress  switch.	723

Is the inspection result normal?

YES >> GO TO 2.

NO >> Replace steering wheel audio control switches. Refer to [AV-175, "Removal and Installation"](#).

2. CHECK HARNESS BETWEEN BLUETOOTH® CONTROL UNIT AND COMBINATION SWITCH

1. Turn ignition switch OFF.
2. Disconnect Bluetooth® control unit connector B141 and combination switch connector M30.
3. Check continuity between Bluetooth® control unit connector B141 and combination switch connector M30.

Bluetooth® control unit		Combination switch		Continuity
Connector	Terminal	Connector	Terminal	
B141	12	M30	24	Yes
	13		25	
	14		31	

4. Check continuity between Bluetooth® control unit connector B141 and ground.

Bluetooth® control unit		—	Continuity
Connector	Terminal		
B141	12	Ground	No
	13		
	14		

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace harness or connectors.

3. SPIRAL CABLE CHECK

Check continuity between combination switch connectors M30 and M102.

STEERING SWITCH

< DTC/CIRCUIT DIAGNOSIS >

[DISPLAY AUDIO WITH AMPLIFIER]

Combination switch				Continuity
Connector	Terminal	Connector	Terminal	
M30	24	M102	15	Yes
	25		16	
	31		18	

Is the inspection result normal?

YES >> GO TO 4.

NO >> Replace spiral cable. Refer to [SR-13, "Removal and Installation"](#).

4. CHECK HARNESS BETWEEN BLUETOOTH® CONTROL UNIT AND AUDIO UNIT

1. Disconnect audio unit connector M46.
2. Check continuity between Bluetooth® control unit connector B141 and audio unit connector M46.

Bluetooth® control unit		Audio unit		Continuity
Connector	Terminal	Connector	Terminal	
B141	17	M46	6	Yes
	18		16	
	19		15	

3. Check continuity between Bluetooth® control unit connector B141 and ground.

Bluetooth® control unit		—	Continuity
Connector	Terminal		
B141	17	Ground	No
	18		
	19		

Is the inspection result normal?

YES >> Replace audio unit. Refer to [AV-168, "Removal and Installation"](#).

NO >> Repair or replace harness or connectors.

AV

MICROPHONE SIGNAL CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[DISPLAY AUDIO WITH AMPLIFIER]

MICROPHONE SIGNAL CIRCUIT

Diagnosis Procedure

INFOID:000000009292012

Regarding Wiring Diagram information, refer to [AV-117. "Wiring Diagram"](#).

1.CHECK HARNESS BETWEEN BLUETOOTH® CONTROL UNIT AND MICROPHONE

1. Turn ignition switch OFF.
2. Disconnect Bluetooth® control unit connector B141 and microphone connector.
3. Check continuity between Bluetooth® control unit connector B141 and microphone connector R8.

Bluetooth® control unit		Microphone		Continuity
Connector	Terminal	Connector	Terminal	
B141	7	R8	1	Yes
	8		2	
	29		4	

4. Check continuity between Bluetooth® control unit connector B141 and ground.

Bluetooth® control unit		—	Continuity
Connector	Terminal		
B141	7	Ground	No
	8		
	29		

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair harness or connector.

2.CHECK MICROPHONE POWER SUPPLY

1. Connect Bluetooth® control unit connector B141 and microphone connector.
2. Turn ignition switch ON.
3. Check voltage between microphone connector R8 terminal 4 and ground.

Microphone		Ground	Value (Approx.)
Connector	Terminal		
R8	4	—	5V

Is the inspection result normal?

YES >> GO TO 3.

NO >> Replace Bluetooth® control unit. Refer to [AV-176. "Removal and Installation"](#).


3.CHECK MICROPHONE SIGNAL

Check signal between Bluetooth® control unit connector B141 with CONSULT or and oscilloscope.

MICROPHONE SIGNAL CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[DISPLAY AUDIO WITH AMPLIFIER]

Bluetooth® control unit connector B141		Condition	Reference signal
(+)	(-)		
Terminal	Terminal		
7	8	Speak into microphone.	 PKIB5037J

Is the inspection result normal?

- YES >> Replace Bluetooth® control unit. Refer to [AV-176, "Removal and Installation"](#).
- NO >> Replace microphone. Refer to [AV-178, "Removal and Installation"](#).

AV

USB CONNECTOR

< DTC/CIRCUIT DIAGNOSIS >

[DISPLAY AUDIO WITH AMPLIFIER]

USB CONNECTOR

Diagnosis Procedure

INFOID:000000009292013

Regarding Wiring Diagram information, refer to [AV-117, "Wiring Diagram"](#).

1. CHECK USB INTERFACE HARNESS CONTINUITY

1. Turn ignition switch OFF.
2. Disconnect audio unit connector M65 and USB interface connector M214.
3. Check continuity between audio unit connector M65 and USB interface connector M214.

Audio unit		USB interface		Continuity
Connector	Terminal	Connector	Terminal	
M65	53	M214	4	Yes
	54		1	
	55		2	
	56		3	
	57		5	

4. Check continuity between audio unit connector M65 and ground.

Audio unit		—	Continuity
Connector	Terminal		
M65	54	Ground	No
	57		

Is the inspection result normal?

- YES >> Replace the USB interface. Refer to [AV-182, "Removal and Installation"](#).
NO >> Repair or replace harness or connectors.

SYMPTOM DIAGNOSIS

AUDIO SYSTEM

Symptom Table

INFOID:000000009292014

RELATED TO AUDIO

Symptoms	Check items	Probable malfunction location
The disk cannot be removed.	Audio unit	Malfunction in audio unit. Refer to AV-104, "On Board Diagnosis Function" .
No sound comes out or the level of the sound is low.	No sound from all speakers.	• Speaker circuit shorted to ground. Refer to AV-117, "Wiring Diagram". • Audio amp. ON signal circuit malfunction. Refer to AV-153, "Diagnosis Procedure". • Audio amp. power supply and ground circuits malfunction. Refer to AV-134, "AUDIO AMP.: Diagnosis Procedure".
	Only a certain speaker (front door speaker LH, front door speaker RH, front tweeter LH, front tweeter RH, rear door speaker LH, rear door speaker RH, rear tweeter LH, rear tweeter RH, subwoofer) does not output sound.	• Poor connector connection of speaker. • Sound signal circuit malfunction between audio unit and audio amp. Refer to: - AV-138, "Diagnosis Procedure" (front door speaker). - AV-141, "Diagnosis Procedure" (front tweeter). - AV-144, "Diagnosis Procedure" (rear door speaker). - AV-147, "Diagnosis Procedure" (rear tweeter). • Sound signal circuit malfunction between audio amp. and speaker. Refer to: - AV-138, "Diagnosis Procedure" (front door speaker). - AV-141, "Diagnosis Procedure" (front tweeter). - AV-144, "Diagnosis Procedure" (rear door speaker). - AV-147, "Diagnosis Procedure" (rear tweeter). - AV-150, "Diagnosis Procedure" (subwoofer). • Malfunction in speaker. Refer to: - AV-171, "Removal and Installation" (front door speaker). - AV-170, "Removal and Installation" (front tweeter). - AV-172, "Removal and Installation" (rear door speaker). - AV-173, "Removal and Installation" (rear tweeter). - AV-174, "Removal and Installation" (subwoofer). • Malfunction in audio unit. Refer to AV-104, "On Board Diagnosis Function". • Malfunction in audio amp. Replace audio amp. Refer to AV-169, "Removal and Installation".

AUDIO SYSTEM

< SYMPTOM DIAGNOSIS >

[DISPLAY AUDIO WITH AMPLIFIER]

Symptoms	Check items	Probable malfunction location
Noise is mixed with audio.	Noise comes out from all speakers.	• Malfunction in audio unit. Refer to AV-104, "On Board Diagnosis Function". • Malfunction in audio amp. Replace audio amp. Refer to AV-169, "Removal and Installation".
	Noise comes out only from a certain speaker (front door speaker LH, front door speaker RH, front tweeter LH, front tweeter RH, rear door speaker LH, rear door speaker RH, rear tweeter LH, rear tweeter RH, sub-woofer).	• Poor connector connection of speaker. • Sound signal circuit malfunction between audio unit and audio amp. Refer to: - AV-138, "Diagnosis Procedure" (front door speaker). - AV-141, "Diagnosis Procedure" (front tweeter). - AV-144, "Diagnosis Procedure" (rear door speaker). - AV-147, "Diagnosis Procedure" (rear tweeter). • Sound signal circuit malfunction between audio amp. and speaker. Refer to: - AV-138, "Diagnosis Procedure" (front door speaker). - AV-141, "Diagnosis Procedure" (front tweeter). - AV-144, "Diagnosis Procedure" (rear door speaker). - AV-147, "Diagnosis Procedure" (rear tweeter). - AV-150, "Diagnosis Procedure" (sub-woofer). • Malfunction in speaker. • Poor Installation of speaker (e.g. back-lash and looseness). Refer to: - AV-171, "Removal and Installation" (front door speaker). - AV-170, "Removal and Installation" (front tweeter). - AV-172, "Removal and Installation" (rear door speaker). - AV-173, "Removal and Installation" (rear tweeter). - AV-174, "Removal and Installation" (sub-woofer). • Malfunction in audio unit. Refer to AV-104, "On Board Diagnosis Function". • Malfunction in audio amp. Replace audio amp. Refer to AV-169, "Removal and Installation".
	Noise is mixed with radio only (when the vehicle hits a bump or while driving over bad roads)	• Poor connector connection of antenna or antenna feeder. Refer to AV-179, "Location of Antenna".

AUDIO SYSTEM

< SYMPTOM DIAGNOSIS >

[DISPLAY AUDIO WITH AMPLIFIER]

Symptoms	Check items	Probable malfunction location
No radio reception or poor reception.	- Other audio sounds are normal. - Any radio station cannot be received or poor reception is caused even after moving to a service area with good reception (e.g. a place with clear view and no obstacles generating external noises).	- Antenna amp. ON signal circuit malfunction. Refer to AV-153. "Diagnosis Procedure" . - Rod antenna is not fully connected to antenna base. - Antenna base/rod connection (thread zone) has foreign material or corrosion inside. - Poor connector connection of antenna or antenna feeder. Refer to AV-179. "Location of Antenna" .
No satellite radio reception.	Satellite radio antenna malfunction.	- Poor continuity in antenna feeder. - Poor connector connection of antenna or antenna feeder. - Loose satellite radio antenna mounting nut. Refer to AV-179. "Location of Antenna" .
Buzz/rattle sound from speaker	The majority of buzz/rattle sounds are not indicative of an issue with the speaker, usually something nearby the speaker is causing the buzz/rattle.	Refer to "SQUEAK AND RATTLE TROUBLE DIAGNOSIS" in the appropriate interior trim section.

RELATED TO HANDS-FREE PHONE

- Before performing diagnosis, confirm that the cellular phone being used by the customer is compatible with the vehicle.
- It is possible that a malfunction is occurring due to a version change of the phone even though the phone is a compatible type. This can be confirmed by changing the cellular phone to another compatible type, and check that it operates normally. It is important to determine whether the cause of the malfunction is the vehicle or the cellular phone.

Check Compatibility

- Make sure the customer's Bluetooth® related concern is understood.
- Verify the customer's concern.
NOTE:
The customer's phone may be required, depending upon their concern.
- Write down the customer's phone brand, model and service provider.
NOTE:
It is necessary to know the service provider. On occasion, a given phone may be on the approved list with one provider, but may not be on the approved list with other providers.
- Go to "www.nissanusa.com/bluetooth/".
 - Using the website's search engine, find out if the customer's phone is on the approved list.
 - If the customer's phone is NOT on the approved list:
Stop diagnosis here. The customer needs to obtain a Bluetooth® phone that is on the approved list before any further action.
 - If the feature related to the customer's concern shows as "N" (not compatible):
Stop diagnosis here. If the customer still wants the feature to function, they will need to get an approved phone showing the feature as "Y" (compatible) in the "Basic Features".
 - If the feature related to the customer's concern shows as "Y" (compatible):
Perform diagnosis as per the following table.

AUDIO SYSTEM

< SYMPTOM DIAGNOSIS >

[DISPLAY AUDIO WITH AMPLIFIER]

Symptoms	Check items	Probable malfunction location
Does not recognize cellular phone connection (no connection is displayed on the display at the guide).	Repeat the registration of cellular phone.	Malfunction in audio unit. Replace audio unit. Refer to AV-168, "Removal and Installation" .
Hands-free phone cannot be established.	- Hands-free phone operation can be made, but the communication cannot be established. - Hands-free phone operation can be performed, however, voice between each other cannot be heard during the conversation.	
The other party's voice cannot be heard by hands-free phone.	Check the "microphone speaker" in Inspection & Adjustment Mode if sound is heard.	
Originating sound is not heard by the other party with hands-free phone communication.	Sound operation function is normal. Sound operation function does not work.	
The system cannot be operated.	- The voice recognition can be controlled. - Steering switch's VOL UP and VOL DOWN switch works, but  does not work.	Steering switch malfunction. Replace steering switch. Refer to AV-175, "Removal and Installation" .
	Steering switch's  , VOL UP and VOL DOWN switches do not work.	Steering switch signal circuit malfunction. Refer to AV-154, "Diagnosis Procedure" .
	All steering switches do not work.	Steering switch ground circuit malfunction. Refer to AV-154, "Diagnosis Procedure" .

NORMAL OPERATING CONDITION

< SYMPTOM DIAGNOSIS >

[DISPLAY AUDIO WITH AMPLIFIER]

NORMAL OPERATING CONDITION

Description

INFOID:000000009292015

RELATED TO NOISE

The majority of the audio concerns are the result of outside causes (bad CD, electromagnetic interference, etc.).

The following noise results from variations in field strength, such as fading noise and multi-path noise, or external noise from trains and other sources. It is not a malfunction.

- Fading noise: This noise occurs because of variations in the field strength in a narrow range due to mountains or buildings blocking the signal.
- Multi-path noise: This noise results from the waves sent directly from the broadcast station arriving at the antenna at a different time from the waves which reflect off mountains or buildings.

The vehicle itself can be a source of noise if noise prevention parts or electrical equipment is malfunctioning. Check if noise is caused and/or changed by engine speed, ignition switch turned to each position, and operation of each piece of electrical equipment, and determine the cause.

NOTE:

The source of the noise can be found easily by listening to the noise while removing the fuses of electrical components, one by one.

Type of Noise and Possible Cause

Occurrence condition		Possible cause
Occurs only when engine is ON.	A continuous growling noise occurs. The speed of the noise varies with changes in the engine speed.	• Ignition components
The occurrence of the noise is linked with the operation of the fuel pump.		• Fuel pump condenser
Noise only occurs when various electrical components are operating.	A cracking or snapping sound occurs with the operation of various switches.	• Relay malfunction, audio unit malfunction
	The noise occurs when various motors are operating.	• Motor case ground • Motor
The noise occurs constantly, not just under certain conditions.		• Rear defogger coil malfunction • Open circuit in printed heater • Poor ground of antenna feeder line
A cracking or snapping sound occurs while the vehicle is being driven, especially when it is vibrating excessively.		• Ground wire of body parts • Ground due to improper part installation • Wiring connections or a short circuit

RELATED TO HANDS-FREE PHONE

Symptom	Cause and Counter measure
Does not recognize cellular phone connection (No connection is displayed on the display at the guide).	Some Bluetooth® enabled cellular phones may not be recognized by the in-vehicle phone module. Refer to "RELATED TO HANDS-FREE PHONE (Check Compatibility)" in AV-159, "Symptom Table" .
Cannot use hands-free phone.	Customer will not be able to use a hands-free phone under the following conditions: • The vehicle is outside of the telephone service area. • The vehicle is in an area where it is difficult to receive radio waves; such as in a tunnel, in an underground parking garage, near a tall building or in a mountainous area. • The cellular phone is locked to prevent it from being dialed. NOTE: While a cellular phone is connected through the Bluetooth® wireless connection, the battery power of the cellular phone may discharge quicker than usual. The Bluetooth® Hands-Free Phone System cannot charge cellular phones.

NORMAL OPERATING CONDITION

< SYMPTOM DIAGNOSIS >

[DISPLAY AUDIO WITH AMPLIFIER]

Symptom	Cause and Counter measure
The other party's voice cannot be heard by hands-free phone.	When the radio wave condition is not ideal or ambient sound is too loud, it may be difficult to hear the other person's voice during a call.
Poor sound quality.	Do not place the cellular phone in an area surrounded by metal or far away from the in-vehicle phone module to prevent tone quality degradation and wireless connection disruption.

PRECAUTION

PRECAUTIONS

Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"

INFOID:000000009292016

The Supplemental Restraint System such as "AIR BAG" and "SEAT BELT PRE-TENSIONER", used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. This system includes seat belt switch inputs and dual stage front air bag modules. The SRS system uses the seat belt switches to determine the front air bag deployment, and may only deploy one front air bag, depending on the severity of a collision and whether the front occupants are belted or unbelted. Information necessary to service the system safely is included in the SR and SB section of this Service Manual.

WARNING:

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision which would result in air bag inflation, all maintenance must be performed by an authorized NISSAN/INFINITI dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see the SR section.
- Do not use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harnesses or harness connectors.

PRECAUTIONS WHEN USING POWER TOOLS (AIR OR ELECTRIC) AND HAMMERS

WARNING:

- When working near the Airbag Diagnosis Sensor Unit or other Airbag System sensors with the Ignition ON or engine running, DO NOT use air or electric power tools or strike near the sensor(s) with a hammer. Heavy vibration could activate the sensor(s) and deploy the air bag(s), possibly causing serious injury.
- When using air or electric power tools or hammers, always switch the Ignition OFF, disconnect the battery and wait at least 3 minutes before performing any service.

Precaution for Trouble Diagnosis

INFOID:000000009292017

AV COMMUNICATION SYSTEM


- Do not apply voltage of 7.0 V or higher to the measurement terminals.
- Use the tester with its open terminal voltage being 7.0 V or less.
- Be sure to turn ignition switch OFF and disconnect the battery cable from the negative terminal before checking the circuit.

Precaution for Harness Repair

INFOID:000000009292018

AV COMMUNICATION SYSTEM

- Solder the repaired parts, and wrap with tape. [Frays of twisted line must be within 110 mm (4.33 in).]




PKIA0306E

PRECAUTIONS

< PRECAUTION >

[DISPLAY AUDIO WITH AMPLIFIER]

- Do not perform bypass wire connections for the repair parts. (The spliced wire will become separated and the characteristics of twisted line will be lost.)



Precaution for Work

INFOID:000000009292019

- When removing or disassembling each component, be careful not to damage or deform it. If a component may be subject to interference, be sure to protect it with a shop cloth.
- When removing (disengaging) components with a screwdriver or similar tool, be sure to wrap the component with a shop cloth or vinyl tape to protect it.
- Protect the removed parts with a shop cloth and prevent them from being dropped.
- Replace a deformed or damaged clip.
- If a part is specified as a non-reusable part, always replace it with a new one.
- Be sure to tighten bolts and nuts securely to the specified torque.
- After installation is complete, be sure to check that each part works properly.
- Follow the steps below to clean components:
 - Water soluble dirt:
 - Dip a soft cloth into lukewarm water, wring the water out of the cloth and wipe the dirty area.
 - Then rub with a soft, dry cloth.
 - Oily dirt:
 - Dip a soft cloth into lukewarm water with mild detergent (concentration: within 2 to 3%) and wipe the dirty area.
 - Then dip a cloth into fresh water, wring the water out of the cloth and wipe the detergent off.
 - Then rub with a soft, dry cloth.
 - Do not use organic solvent such as thinner, benzene, alcohol or gasoline.
 - For genuine leather seats, use a genuine leather seat cleaner.

PREPARATION

< PREPARATION >

[DISPLAY AUDIO WITH AMPLIFIER]


PREPARATION

PREPARATION

Special Service Tools

INFOID:0000000009292020

The actual shapes of Kent-Moore tools may differ from those of special service tools illustrated here.

Tool number (Kent-Moore No.) Tool name	Description
— (J-46534) Trim Tool Set	Removing trim components
 AWJIA04832Z	

Commercial Service Tools

INFOID:0000000009292021

Tool name	Description
Power tool	Loosening nuts, screws and bolts
 PIIB1407E	

A
B
C
D
E
F
G
H
I
J
K
L
M
AV
O
P

REMOVAL AND INSTALLATION


AUDIO UNIT

Removal and Installation

INFOID:000000009292022

REMOVAL

1. Disconnect the negative battery terminal. Refer to [PG-72, "Removal and Installation"](#).
2. Remove cluster lid C. Refer to [IP-15, "Removal and Installation"](#).
3. Remove the screws (A) from the bracket.
4. Remove the audio unit (1) from cluster lid C.



INSTALLATION

Installation is in the reverse order of removal.

AUDIO AMP.

< REMOVAL AND INSTALLATION >

[DISPLAY AUDIO WITH AMPLIFIER]

AUDIO AMP.

Removal and Installation


INFOID:000000009292023

REMOVAL

NOTE:

Do not remove the RH front seat from the vehicle.

1. Remove the RH front seat bolts, disconnect the harness connectors from the RH front seat. Refer to [SE-14. "Exploded View"](#).
2. Tilt the RH front seat back to access the audio amp. (1) and remove the audio amp. kick shield screws (C).
⇐: Front
3. Disconnect the harness connectors (A) from the audio amp. and remove the audio amp. (1) from the bracket (2).
4. Remove the audio amp. bracket screws (B) and bracket (2).



INSTALLATION

Installation is in the reverse order of removal.

A
B
C
D
E
F
G
H
I
J
K
L
M
O
P

AV

FRONT TWEETER

< REMOVAL AND INSTALLATION >

[DISPLAY AUDIO WITH AMPLIFIER]

FRONT TWEETER

Removal and Installation


INFOID:000000009292024

REMOVAL

CAUTION:

Use a suitable tool to prevent damage to the front tweeter grille and the instrument panel.

1. Remove the front tweeter grille.
2. Remove the front tweeter screws (A).
3. Pull out the front tweeter (1), then disconnect the harness connector from the front tweeter and remove.



INSTALLATION

Installation is in the reverse order of removal.

FRONT DOOR SPEAKER

< REMOVAL AND INSTALLATION >

[DISPLAY AUDIO WITH AMPLIFIER]


FRONT DOOR SPEAKER

Removal and Installation

INFOID:000000009292025

REMOVAL

1. Remove the front door finisher. Refer to [INT-14, "Removal and Installation"](#).
2. Remove the front door speaker screws (A).
3. Pull out the front door speaker (1).
4. Disconnect the harness connector from the front door speaker (1) and remove.



INSTALLATION

Installation is in the reverse order of removal.

A
B
C
D
E
F
G
H
I
J
K
L
M
O
P

AV

REAR DOOR SPEAKER

< REMOVAL AND INSTALLATION >

[DISPLAY AUDIO WITH AMPLIFIER]


REAR DOOR SPEAKER

Removal and Installation

INFOID:000000009292026

REMOVAL

1. Remove the rear door finisher. Refer to [INT-14, "Removal and Installation"](#).
2. Remove the rear door speaker screws (A).
3. Disconnect the harness connector (B) from the rear door speaker (1) and remove.



INSTALLATION

Installation is in the reverse order of removal.

REAR TWEETER

< REMOVAL AND INSTALLATION >

[DISPLAY AUDIO WITH AMPLIFIER]


REAR TWEETER

Removal and Installation

INFOID:000000009292027

REMOVAL

1. Remove the rear door finisher. Refer to [INT-14. "Removal and Installation"](#).
2. Remove the rear door tweeter screws (A) and the rear door tweeter (1).



INSTALLATION

Installation is in the reverse order of removal.

A
B
C
D
E
F
G
H
I
J
K
L
M
O
P

AV

SUBWOOFER


< REMOVAL AND INSTALLATION >

[DISPLAY AUDIO WITH AMPLIFIER]

SUBWOOFER

Removal and Installation

INFOID:000000009292028



- | | | |
|-----------------|--------------|-----------------------|
| 1. Subwoofer | 2. Bracket | 3. Locating pin plate |
| 4. Locating pin | 5. Connector | |

REMOVAL

1. Position the LH rear seat cushion in the folded up position.
2. Remove storage box (RH). Refer to [INT-23, "Component"](#).
3. Remove the subwoofer screws.
4. Disconnect the harness connector from the subwoofer and remove.

INSTALLATION

Installation is in the reverse order of removal.

STEERING SWITCH


< REMOVAL AND INSTALLATION >

[DISPLAY AUDIO WITH AMPLIFIER]

STEERING SWITCH

Removal and Installation

INFOID:000000009292029



1. Steering wheel

2. Steering wheel audio control switches


REMOVAL

1. Remove the driver air bag module. Refer to [SR-11, "Removal and Installation"](#).
2. Remove the steering wheel audio control switch assembly screws.
3. Disconnect the harness connectors from the steering wheel audio control switches.
4. Remove the steering wheel audio control switches by pulling on steering wheel audio control switches to release the pawls.

○: Pawl

CAUTION:

Do not tilt steering wheel audio control switches during removal or damage may occur to the pawls.



INSTALLATION

Installation is in the reverse order of removal.

BLUETOOTH CONTROL UNIT


< REMOVAL AND INSTALLATION >

[DISPLAY AUDIO WITH AMPLIFIER]

BLUETOOTH CONTROL UNIT

Removal and Installation

INFOID:000000009292030



1. Bluetooth control unit front bracket 2. Bluetooth control unit/antenna 3. Bluetooth control unit rear bracket

⇨ Front

REMOVAL

NOTE:

Do not remove the RH front seat from the vehicle.


1. Remove the RH front seat bolts, disconnect the harness connectors from the RH front seat. Refer to [SE-14, "Exploded View"](#).
2. Tilt the RH front seat back to access the bluetooth control unit.

BLUETOOTH CONTROL UNIT

< REMOVAL AND INSTALLATION >

[DISPLAY AUDIO WITH AMPLIFIER]

3. Disconnect the harness connector (B) from the Bluetooth control unit.
4. Remove the Bluetooth control unit screws (A), then remove the Bluetooth control unit assembly (1).
5. Remove the Bluetooth control unit bracket screws and Bluetooth control unit front and rear brackets.



INSTALLATION

Installation is in the reverse order of removal.

A
B
C
D
E
F
G
H
I
J
K
L
M
O
P

AV


MICROPHONE

Removal and Installation

INFOID:000000009292031

REMOVAL

1. Remove the roof console. Refer to [INT-21, "Removal and Installation"](#).
2. Release the pawls that retain the Bluetooth microphone (1) to the roof console.
3. Disconnect the harness connector (A) from the Bluetooth microphone (1) and remove.



INSTALLATION

Installation is in the reverse order of removal.

AUDIO ANTENNA


< REMOVAL AND INSTALLATION >

[DISPLAY AUDIO WITH AMPLIFIER]

AUDIO ANTENNA

Location of Antenna

INFOID:000000009292032



- | | | |
|-----------------------------|--------|---------|
| 1. Coaxial antenna feeder | 2. M48 | 3. M37 |
| 4. Satellite antenna feeder | 5. M67 | 6. M500 |
| 7. M501 | | |

Removal and Installation

INFOID:000000009292034

REMOVAL

1. Remove instrument lower panel RH and glove box. Refer to [IP-20. "Removal and Installation"](#).
2. Disconnect audio antenna cable from antenna feeder.


AV

AUDIO ANTENNA

< REMOVAL AND INSTALLATION >

[DISPLAY AUDIO WITH AMPLIFIER]

3. Remove antenna rod.
4. Remove rubber seal.
5. Remove cowl top. Refer to [EXT-20. "Removal and Installation"](#).
6. Remove fender protector. Refer to [EXT-22. "Removal and Installation"](#).
7. Remove antenna base bolts.
8. Remove antenna base and cable.



INSTALLATION

Installation is in the reverse order of removal.

CAUTION:

Always properly tighten the antenna rod during installation or the antenna rod may bend or break during vehicle operation.

SATELLITE RADIO ANTENNA

< REMOVAL AND INSTALLATION >

[DISPLAY AUDIO WITH AMPLIFIER]


SATELLITE RADIO ANTENNA

Removal and Installation

INFOID:000000009292035

REMOVAL

1. Remove the roof console. Refer to [INT-21, "Removal and Installation"](#).
2. Disconnect the harness connector from the satellite radio antenna.
3. Remove the satellite radio antenna nut.
4. Remove the satellite radio antenna.



INSTALLATION

Installation is in the reverse order of removal.

A
B
C
D
E
F
G
H
I
J
K
L
M
O
P

AV

USB CONNECTOR

Removal and Installation

INFOID:000000009292036

REMOVAL

1. Remove the center console assembly. Refer to [IP-22. "Removal and Installation"](#).
2. Push the pawl from the back of the center console to remove the USB interface.

INSTALLATION


Installation is in the reverse order of removal.

SYSTEM DESCRIPTION

COMPONENT PARTS

Component Parts Location

INFOID:000000009296807



AWNIA29392Z

COMPONENT PARTS

< SYSTEM DESCRIPTION >

[NAVIGATION]

- | | | |
|--|---|--|
| 1. Front tweeter LH M109 | 2. Steering wheel audio control switches | 3. AV control unit M96, M97, M98, M99, M100 |
| 4. Front tweeter RH M111 | 5. Microphone R8 | 6. GPS antenna (Underneath instrument panel, forward of combination meter) |
| 7. Front door speaker LH D12
Front door speaker RH D112 | 8. Rear door tweeter LH D208
Rear door tweeter RH D308 | 9. Rear door speaker LH D207
Rear door speaker RH D307 |
| 10. Audio amp. B158, B159 (Underneath passenger seat) | 11. Subwoofer B72 (Underneath rear LH seat) | 12. USB interface M214 |
| 13. AUX in jack M215 | 14. Rear view camera D506 | 15. Satellite antenna |
| 16. Rod antenna | | |


Component Description

INFOID:000000009296808

Part name	Description
AV control unit	• Operation of navigation and audio systems are integrated. • Includes the audio, hands-free phone, navigation, satellite radio, rear view monitor, USB connection and AUX IN connection functions. • Map data can be loaded from SD-card inserted in SD-card slot. • Audio signals are output to audio amplifier. • Inputs illumination signals required for display dimming control. • Inputs signals for driving status recognition (vehicle speed and reverse). • Touch panel functions can be operated by touching display directly.
Map SD-card	A collection of Map data.
Audio amplifier	Receives audio signals from AV control unit and outputs audio signals to each speaker.
Front tweeters	Outputs high, mid and low range audio signals from audio amp.
Front door speakers	
Rear tweeters	
Rear door speakers	
Subwoofer	
Steering wheel audio control switches	• Operations for audio, hands-free phone and voice recognition are possible. • Steering switch signal is output to combination meter. • Combination meter outputs steering switch signal to AV control unit.
Microphone	• Used for hands-free phone operations. • Microphone signal is transmitted to AV control unit. • Power is supplied from AV control unit.
USB interface	USB sound and data signals are transmitted to AV control unit.
AUX input	Auxillary sound signals are transmitted to AV control unit.
Rear view camera	• Outputs image of vehicle rear to AV control unit. • Power is supplied from AV control unit.
Satellite antenna	Satellite radio signal is received and transmitted to AV control unit.
GPS antenna	GPS signal is received and transmitted to AV control unit.
Rod antenna	AM/FM signal is received and transmitted to AV control unit.

SYSTEM

System Diagram



System Description

INFOID:000000009296810

Refer to Owner's Manual for navigation and audio system operating instructions.

Audio function and display are built into AV control unit.

This navigation has the following functions.

- Map data on SD-card
- Full support for playback of music from iPod® and USB device
- High resolution color 5 inch display with touch panel function
- FM/AM twin digital tuner
- USB mass storage connection
- Satellite radio
- Hands-free phone system

iPod® is a trademark of Apple inc., registered in the U.S. and other countries.

NAVIGATION SYSTEM FUNCTION

Description

- The navigation system can be operated by control panel of the AV control unit and display (touch panel) of the AV control unit.
- Guide sound during the operation of the navigation system is output from AV control unit to front speakers.
- AV control unit calculates the vehicle location based on the signals from GYRO (angle speed sensor), vehicle sensor, and GPS satellite, as well as the map data from map SD-card. The vehicle location is displayed on the AV control unit.

POSITION DETECTION PRINCIPLE

The navigation system periodically calculates the vehicle's current position according to the following three signals:

- Travel distance of the vehicle as determined by the vehicle speed sensor
- Turning angle of the vehicle as determined by the gyroscope (angular velocity sensor)
- Direction of vehicle travel as determined by the GPS antenna (GPS information)

The current position of the vehicle is then identified by comparing the calculated vehicle position with map data read from the map SD-card (map-matching), and indicated on the screen as a vehicle mark. More accurate data is judged and used by comparing vehicle position detection results found by the GPS with the result by map-matching.

SYSTEM

< SYSTEM DESCRIPTION >

[NAVIGATION]


The current vehicle position will be calculated by detecting the distance the vehicle moved from the previous calculation point and its direction.

- Travel distance

Travel distance calculations are based on the vehicle speed sensor input signal. Therefore, the calculation may become incorrect as the tires wear down. To prevent this, an automatic distance correction function has been adopted.

- Travel direction

Change in the travel direction of the vehicle is calculated by a gyroscope (angular velocity sensor) and a GPS antenna (GPS information). They have both advantages and disadvantages.



Type	Advantage	Disadvantage
Gyroscope (angular velocity sensor)	Can detect the vehicle's turning angle quite accurately.	Direction errors may accumulate when vehicle is driven for long distances without stopping.
GPS antenna (GPS information)	Can detect the vehicle's travel direction (North/South/East/West).	Correct direction cannot be detected when vehicle speed is low.


More accurate traveling direction is detected because priorities are set for the signals from these two devices according to the situation.

MAP-MATCHING

Map-matching compares a current location detected by the method in the "Location Detection Principle" with a road map data from map SD-card.

NOTE:

The road map data is based on data stored in the map SD-card.




The vehicle position may not be corrected under the following circumstances and after driving for a certain time when GPS information is difficult to receive. In this case, the vehicle mark on the display must be corrected manually.


- In map-matching, alternative routes to reach the destination will be shown and prioritized, after the road on which the vehicle is currently driven has been judged and the vehicle mark has been repositioned.

Alternative routes will be shown in different order of priority, and the incorrect road can be avoided if there is an error in distance and/or direction.

Routes are of the same priority if two roads are running in parallel. Therefore, the vehicle mark may appear on either of them alternately, depending on maneuvering of the steering wheel and configuration of the road.




- Map-matching does not function correctly when a road on which the vehicle is driving is new and not recorded in the map SD-card, or when road pattern stored in the map data and the actual road pattern are different due to repair. The map-matching function may find another road and position the vehicle mark on it when driving on a road not present in the map. Then, the vehicle mark may change to it when the correct road is detected.
- Effective range for comparing the vehicle position and travel direction calculated by the distance and direction with the road data read from the map SD-card is limited. Therefore, correction by map-matching is not possible when there is an excessive gap between current vehicle position and the position on the map.



GPS (Global Positioning System)

GPS (Global Positioning System) is developed for and is controlled by the US Department of Defense. The system utilizes GPS satellites (NAVSTAR), transmitting out radio waves while flying on an orbit around the earth at an altitude of approximately 21,000 km (13,049 mile).

The receiver calculates the travel position in three dimensions (latitude/longitude/altitude) according to the time lag of the radio waves that four or more GPS satellites transmit (three-dimensional positioning). The GPS receiver calculates the travel position in two dimensions (latitude/longitude) with the previous altitude data if the GPS receiver receives only three radio waves (two-dimensional positioning). GPS position correction is not performed while stopping the vehicle.



Accuracy of the GPS will deteriorate under the following conditions:

- In two-dimensional positioning, GPS accuracy will deteriorate when altitude of the vehicle position changes.
- The position of GPS satellite affects GPS detection precision. The position detection may not be precisely performed.
- The position detection is not performed if GPS receiver does not receive radio waves from GPS satellites. (Inside a tunnel, parking in a building, under an elevated highway etc.) GPS receiver may not receive radio waves from GPS satellites if any object is placed on the GPS antenna.

NOTE:

- The detection result has an error of approximately 10 m (32.81 ft) even with a high-precision three dimensional positioning.
- There may be cases when the accuracy is lowered and radio waves are stopped intentionally because the GPS satellite signal is controlled by the US trace control center.

SATELLITE RADIO FUNCTION

- Satellite radio function is built into AV control unit.
- Sound signal (satellite radio) is received by satellite antenna and transmitted to AV control unit. AV control unit outputs sound signal to each speaker.

AUXILIARY INPUT FUNCTION

- Sound can be output from an external device by connecting a device with USB connector and AUX jack.
- AUX sound signals are transmitted to each speaker via AV control unit.

REAR VIEW MONITOR FUNCTION

Camera Image Operation Principle

- The ITS control unit supplies power to the rear view camera when receiving a reverse signal.
- The rear view camera transmits camera images to the ITS control unit when power is supplied from the ITS control unit.
- The ITS control unit transmits camera images to the AV control unit.
- The AV control unit combines a warning message and fixed guide lines with an image received from the ITS control unit to display a rear view camera image on the screen.

USB CONNECTION FUNCTION

- iPod® or music files in USB memory can be played.

< SYSTEM DESCRIPTION >

- Sound signals are transmitted from USB connector and AUX jack to the AV control unit and output to each speaker and tweeter.
- iPod® is recharged when connected to USB connector and AUX jack.

NOTE:

Use the enclosed USB harness when connecting iPod® to USB connector and AUX jack.

iPod® is a trademark of Apple inc., registered in the U.S. and other countries.

SPEED SENSITIVE VOLUME SYSTEM

- Volume level of this system goes up and down automatically in proportion to the vehicle speed.
- The control level can be selected by the customer.

HANDS-FREE PHONE SYSTEM

- Bluetooth® control is built into AV control unit.
- The connection between cellular phone and AV control unit is performed with Bluetooth® communication.
- The voice guidance signal is input from the AV control unit and output to the front speakers when operating the cellular phone.

When A Call Is Originated

- Spoken voice sound output from the microphone (microphone signal) is input to AV control unit.
- AV control unit outputs to cellular phone with Bluetooth® communication as a TEL voice signal.
- Voice sound is then heard at the other party.

When Receiving A Call

- Voice sound is input to own cellular phone from the other party.
- TEL voice signal is input to AV control unit by establishing Bluetooth® communication from cellular phone, and the signal is output to front speakers.

DIAGNOSIS SYSTEM (AV CONTROL UNIT)

< SYSTEM DESCRIPTION >

[NAVIGATION]

DIAGNOSIS SYSTEM (AV CONTROL UNIT)

Description

INFOID:000000009296811

The AV control unit on board diagnosis performs the functions listed in the table below:

Mode		Item	Content
Version		—	Version data of the AV control unit is displayed.
User Configuration	Touch Display Calibration	—	Allows correction of the position detection accuracy of the touch panel.
Radio	FM monitor	—	Monitors the dynamic values of the current tuner
	AM monitor	—	
	XM monitor	—	Version data is displayed.
	XM functions	• Clear XM Chipset NVM • Reset All XM Settings • Clear IGS • XM CBM Debug Mode • External Diag Mode	Current status is displayed.
System State	Running System Status	• SD card slot Access • Power Supply • Speed Signal • Direction Signal • Illumination Signal • GPS Antenna • GPS Tracking • Satellites Visible • Satellites Tracked • Microphone Current • Steering wheel key • Radio Antenna • USB Device • iPod® firmware version • BT Status	The current system status is displayed.
	Speaker Test 4kHz	—	This activates a sequence of test tone outputs to the audio circuits one after the other for 1 second.
	Speaker Test 100Hz		
	Display-Test	—	This provides a test sequence where test displays (plain colored display: e.g. white, black, red, blue, green) are shown one after the other. The respective color is shown for an indicated period of time (parameter). After the display test, the design of the display previously available is stored. While the screen shows a plain colored display, a pixel malfunction may be detected.
Self Test		• SD Card Access • BT Module Access • Radio Antenna • GPS Antenna • XM Antenna	A system self test is executed and the results are stored into the error memory.

Perform CONSULT diagnosis if the AV control unit on board diagnosis does not start or the screen does not display anything.

On Board Diagnosis Function

INFOID:000000009296812

METHOD OF STARTING


1. Turn the ignition ON.
2. Turn the audio system OFF.

DIAGNOSIS SYSTEM (AV CONTROL UNIT)


< SYSTEM DESCRIPTION >

[NAVIGATION]

3. While pressing the MENU button, turn the TUNE-SCROLL dial counterclockwise 3 or more clicks, then clockwise 3 or more clicks, then counterclockwise 3 or more clicks. When self diagnosis mode begins, a short beep will be heard. Shifting from current screen to previous screen is performed by pressing BACK button.



4. The trouble diagnosis initial screen is displayed, and Version, User Config, Radio, System State or Self Test can be selected.



CONSULT Function

INFOID:000000009296813

CONSULT FUNCTIONS

CONSULT performs the following functions via communication with the AV control unit.

Direct Diagnostic Mode	Description
ECU Identification	The AV control unit part number is displayed.
Self Diagnostic Result	The AV control unit self diagnostic results are displayed.
Data Monitor	The AV control unit input/output data is displayed in real time.
Configuration	• The vehicle specification can be read and saved. • The vehicle specification can be written when replacing AV control unit.
CAN Diag Support Mntr	• The result of transmit/receive diagnosis of AV communication is displayed. • The result of transmit/receive diagnosis of CAN communication is displayed.

ECU IDENTIFICATION

The part number of AV control unit is displayed.

SELF DIAGNOSTIC RESULT

Refer to [AV-193, "DTC Index"](#).

DATA MONITOR

Monitor Item [Unit]	Description
VHCL SPD SIG [On/Off]	Indicates vehicle speed signal received from combination meter on CAN communication line.
ILLUM SIG [On/Off]	Indicates condition of illumination signal for the AV control unit.
IGN SIG [On/Off]	Indicates condition of ignition signal.
REV SIG [On/Off]	Indicates condition of reverse signal received from BCM.

CONFIGURATION

Refer to [AV-218, "CONFIGURATION \(AV CONTROL UNIT\) : Description"](#).

CAN DIAG SUPPORT MNTR

Refer to [LAN-50, "CAN Diagnostic Support Monitor"](#).


ECU DIAGNOSIS INFORMATION

AV CONTROL UNIT

Reference Value

INFOID:000000009296814

TERMINAL LAYOUT






PHYSICAL VALUES

Terminal (Wire color)		Description		Condition		Reference value (Approx.)
+	—	Signal name	Input/ Output	Ignition switch	Operation	
1 (G/W)	Ground	Amp. ON signal	Output	ACC	—	Battery voltage
2 (W)	3 (B)	Sound signal front speaker LH	Output	ON	Sound output	 SKIB3609E
4 (P)	5 (B/R)	Sound signal rear speaker LH	Output	ON	Sound output	 SKIB3609E
6 (BR)	15 (G)	Steering switch signal A	Input	ON	Press and hold MODE switch.	0 V
					Press and hold △ switch.	1.34 V
					Press and hold ▽ switch.	2.45 V
					Press and hold ⚡ switch.	3.43 V
					Except for above.	5.0 V
7 (G/B)	Ground	ACC power supply	Input	ACC	—	Battery voltage
8 (L)	—	CAN (H)	Input/ Output	—	—	—
9 (R)	44 (GR)	Illumination control signal	Input	ON	Headlamps ON	Battery voltage

AV CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >



[NAVIGATION]

Terminal (Wire color)		Description		Condition		Reference value (Approx.)
+	—	Signal name	Input/ Output	Ignition switch	Operation	
11 (Y)	12 (R)	Sound signal front speaker RH	Output	ON	Sound output	 SKIB3609E
13 (L)	14 (B/W)	Sound signal rear speaker RH	Output	ON	Sound output	 SKIB3609E
16 (W)	15 (G)	Steering switch signal B	Input	ON	Press and hold VOL DOWN switch	0 V
					Press and hold VOL UP switch	1.34 V
					Press and hold  switch	2.45 V
					Except for above	5.0 V
17 (P)	—	CAN (L)	Input/ Output	—	—	—
18 (SB)	Ground	Vehicle speed signal	Input	ON	When vehicle speed is ap- prox. 40 km/h (25 MPH)	 JSNIA0012GB
19 (Y)	Ground	Battery power supply	Input	OFF	—	Battery voltage
20 (B)	Ground	Ground	—	ON	—	0 V
23 (P)	—	MR output	—	—	—	—
28 (SB)	Ground	Reverse signal	Input	ON	Selector lever in R (re- verse)	Battery voltage
					Selector lever in any posi- tion other than R (reverse)	0 V
30 (B)	—	AUX L	Input	—	—	—
31 (R)	—	AUX ground	—	—	—	—
32 (W)	—	AUX R	Input	—	—	—
33	Shield	Camera ground	—	—	—	—
34 (G/Y)	—	Camera ON	—	ON	Selector lever in R (re- verse)	6.0 V

AV CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >

[NAVIGATION]

Terminal (Wire color)		Description		Condition		Reference value (Approx.)
+	—	Signal name	Input/ Output	Ignition switch	Operation	
36 (B)	35 (W)	Camera image signal	Input	ON	When camera image is displayed	
37 (W/G)	Ground	Ignition power supply	Input	ON or START	—	Battery voltage
42 (L)	Ground	Microphone power supply	Output	ON	—	5.0 V
43 (P)	41 (Shield)	Microphone signal	Input	ON	While speaking into microphone.	
45 (R)	—	V BUS signal	—	—	—	—
46 (B)	—	USB ground	—	—	—	—
47 (G)	—	USB D+ signal	—	—	—	—
48 (W)	—	USB D- signal	—	—	—	—
49	—	Shield	—	—	—	—
50 (B)	Ground	GPS antenna signal	Input	ON	—	5.0 V
51 (B)	—	GPS Shield	—	—	—	—
58 (B)	Ground	Satellite antenna signal	Input	ON	—	5.0 V
59 (B)	—	SAT Shield	—	—	—	—
61 (B)	Ground	AM-FM main antenna	—	—	—	—

DTC Index

INFOID:000000009296815

CONSULT Display	Reference Page
U1000: CAN COMM CIRCUIT	AV-220, "DTC Logic"
U1010: CONTROL UNIT (CAN)	AV-221, "DTC Logic"
U1217: BLUETOOTH MODULE	AV-222, "DTC Logic"
U1229: iPod CERTIFICATION	AV-223, "DTC Logic"
U122F: Digital broadcasting connection error	AV-224, "DTC Logic"
U1244: GPS ANTENNA CONN	AV-225, "DTC Logic"
U1258: XM ANTENNA CONN	AV-226, "DTC Logic"

AV CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >

[NAVIGATION]

CONSULT Display	Reference Page
U1263: USB OVERCURRENT	AV-227, "DTC Logic"
U1265: AMP ON TERMINAL	AV-228, "DTC Logic"
U12AA: Configuration Error	AV-229, "DTC Logic"
U12AB: FM Antenna error	AV-230, "DTC Logic"
U12AC: Display Temperature too High	AV-231, "DTC Logic"
U12AD: ECU Temperature too High	AV-232, "DTC Logic"
U12AE: Internal Amplifier temperature Warning	AV-233, "DTC Logic"
U12AF: CD Mechanism Temperature Warning	AV-234, "DTC Logic"
U12B0: Supply Voltage Goes below 9V > 20s	AV-235, "DTC Logic"
U12B1: Supply Voltage Goes High > 16V for 20s	AV-236, "DTC Logic"
U1310: CONTROL UNIT (AV)	AV-237, "DTC Logic"

AUDIO AMP.

< ECU DIAGNOSIS INFORMATION >


[NAVIGATION]

AUDIO AMP.




Reference Value

INFOID:000000009296816

TERMINAL LAYOUT



PHYSICAL VALUES







Terminal (wire color)		Description		Condition		Reference value (Approx.)
+	-	Signal name	Input/ Output	Ignition switch	Operation	
1 (Y)	Ground	Battery	Input	-	-	Battery voltage
2 (W)	18 (G)	Subwoofer	Output	ON	Receive audio signal	
3 (O)	19 (BR)	Subwoofer	Output	ON	Receive audio signal	
4 (B)	Ground	Ground	-	ON	-	-
9 (G/W)	Ground	Amp. ON signal	Input	ON	-	Greater than 6.5 V
11 (G)	27 (B)	Rear door speaker LH	Output	ON	Receive audio signal	

A
B
C
D
E
F
G
H
I
J
K
L
M
AV
O
P

AUDIO AMP.

< ECU DIAGNOSIS INFORMATION >




[NAVIGATION]

Terminal (wire color)		Description	Condition			Reference value (Approx.)
+	–		Input/ Output	Ignition switch	Operation	
12 (GR)	28 (O)	Rear door speaker RH	Output	ON	Receive audio signal	 SKIA0177E
13 (W)	29 (P)	Front tweeter RH	Output	ON	Receive audio signal	 SKIA0177E
14 (Y)	30 (GR)	Front tweeter LH	Output	ON	Receive audio signal	 SKIA0177E
15 (BR)	31 (L)	Front door speaker LH	Output	ON	Receive audio signal	 SKIA0177E
16 (LG)	32 (R)	Front door speaker RH	Output	ON	Receive audio signal	 SKIA0177E
17 (R/B)	Ground	Battery	Input	–	–	Battery voltage
20 (B)	Ground	Ground	–	ON	–	–
21 (Y)	5 (R)	Audio sound signal front RH	Input	ON	Receive audio signal	 SKIA0177E

AUDIO AMP.

< ECU DIAGNOSIS INFORMATION >

[NAVIGATION]


Terminal (wire color)		Description		Condition		Reference value (Approx.)
+	−	Signal name	Input/ Output	Ignition switch	Operation	
22 (W)	6 (B)	Audio sound signal front LH	Input	ON	Receive audio signal	
23 (L)	7 (B/W)	Audio sound signal rear RH	Input	ON	Receive audio signal	
24 (P)	8 (B/R)	Audio sound signal rear LH	Input	ON	Receive audio signal	

A
B
C
D
E
F
G
H
I
J
K
L
M
O
P

AV

* : THIS CONNECTOR IS NOT SHOWN IN "HARNES LAYOUT" OF PG SECTION.

ABNWA1677GB




ABNWA1678GB

A
B
C
D
E
F
G
H
I
J
K
L
M
AV
O
P

AV


[NAVIGATION]



2013 Xterra

NAVIGATION SYSTEM CONNECTORS

Connector No.	M1
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
1	L	– (WITH NAVI)
14	P	– (WITH NAVI)
15	SHIELD	– (WITH NAVI)

Connector No.	M4
Connector Name	FUSE BLOCK (J/B)
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
2P	W/G	–
4P	G/B	–
16P	R/B	–

Connector No.	M8
Connector Name	WIRE TO WIRE
Connector Color	BROWN




Terminal No.	Color of Wire	Signal Name
2	L	–
3	BR	–

Connector No.	M24
Connector Name	COMBINATION METER
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
6	SB	SPEED OUT 8


Connector No.	M30
Connector Name	COMBINATION SWITCH (SPIRAL CABLE)
Connector Color	GRAY



Terminal No.	Color of Wire	Signal Name
24	BR	–
25	W	– (WITH NAVI)
31	G	–


Terminal No.	Color of Wire	Signal Name
51M	B/W	—
52M	L	—
54M	B/R	—
55M	P	—
57M	R	—
58M	Y	—
60M	B	—
61M	W	—
63M	G/W	—
72M	R	—
73M	BR	—
74M	W	—
76M	R/B	—
77M	LG	—
78M	O	—
79M	G	—

Connector No.	M36
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1M	GR	—
2M	Y	—
3M	P	—
4M	W	—
6M	L	—
7M	BR	—
8M	B	—
9M	G	—


Connector No.	M31
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
38G	SB	—
77G	Y	—

Terminal No.	Color of Wire	Signal Name
1J	O	—
2J	BR	—
3J	G	—
6J	G	—
7J	W	—
8J	B	—
56J	B	—
65J	G/Y	—
66J	SHIELD	—
67J	W	—

Connector No.	M40
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Connector No.	M38
Connector Name	AV CONTROL UNIT (WITH NAVI)
Connector Color	GRAY




Terminal No.	Color of Wire	Signal Name
60	—	—
61	B	ANT MAIN
62	—	—

Connector No.	M75
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Connector No.	M67
Connector Name	WIRE TO WIRE
Connector Color	PINK



Connector No.	M63
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
4	R	—
11	LG	—

Terminal No.	Color of Wire	Signal Name
1	B	—
2	SHIELD	—

Terminal No.	Color of Wire	Signal Name
1	R	—
2	W	—
3	B	—
6	SHIELD	—

ABNIA4277GB

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P


AV

NAVIGATION SYSTEM

< WIRING DIAGRAM >


[NAVIGATION]

Connector No.	M98
Connector Name	AV CONTROL UNIT (WITH NAVI)
Connector Color	GREEN




Terminal No.	Color of Wire	Signal Name
45	R	VBUS
46	B	USB GND
47	G	USB D+
48	W	USB D-
49	SHIELD	SHIELD

Connector No.	M97
Connector Name	AV CONTROL UNIT (WITH NAVI)
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
21	-	-
22	-	-
23	P	MR OUTPUT
24	-	-
25	-	-
26	-	-
27	-	-
28	SB	REVERSE
29	-	-
30	B	AUX L (+)
31	R	AUX GND
32	W	AUX R (+)
33	SHIELD	CAM GND
34	G/Y	CAMERA ON
35	W	VIDEO GND
36	B	CAM VIDEO
37	W/G	IGN
38	-	-
39	-	-
40	-	-
41	SHIELD	MIC GND
42	L	MIC VCC
43	P	MIC SIG
44	GR	ILL CONT

Connector No.	M96
Connector Name	AV CONTROL UNIT (WITH NAVI)
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	G/W	AMP ON
2	W	FR SP LH (+)
3	B	FR SP LH (-)
4	P	RR SP LH (+)
5	B/R	RR SP LH (-)
6	BR	STRG SW A
7	G/B	ACC
8	L	CAN-H
9	R	LIGHT SW
10	-	-
11	Y	FR SP RH (+)
12	R	FR SP RH (-)
13	L	RR SP RH (+)
14	B/W	RR SP RH (-)
15	G	STRG SW GND
16	W	STRG SW B
17	P	CAN-L
18	SB	SPD
19	Y	+B
20	B	GND


ABNIA4278GB

Connector No.	M102
Connector Name	COMBINATION SWITCH (SPIRAL CABLE)
Connector Color	GRAY




Terminal No.	Color of Wire	Signal Name
15	GR	-
16	G	-
18	B	-

Connector No.	M100
Connector Name	AV CONTROL UNIT (WITH NAVI)
Connector Color	PINK




Terminal No.	Color of Wire	Signal Name
58	B	SAT ANT
59	SHIELD	SAT SHIELD

Connector No.	M99
Connector Name	AV CONTROL UNIT (WITH NAVI)
Connector Color	BLUE



Terminal No.	Color of Wire	Signal Name
50	B	GPS ANT
51	SHIELD	GPS SHIELD

Connector No.	M169
Connector Name	WIRE TO WIRE
Connector Color	BLUE



Terminal No.	Color of Wire	Signal Name
1	SHIELD	-
2	B	-
3	R	-
4	W	-
5	G	-

Connector No.	M111
Connector Name	FRONT TWEETER RH
Connector Color	BROWN



Terminal No.	Color of Wire	Signal Name
1	W	-
2	P	-(EXCEPT BASE AUDIO SYSTEM)

Connector No.	M109
Connector Name	FRONT TWEETER LH
Connector Color	BROWN



Terminal No.	Color of Wire	Signal Name
1	Y	-(EXCEPT BASE AUDIO SYSTEM)
2	GR	-(EXCEPT BASE AUDIO SYSTEM)

ABNIA4279GB

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P


AV

NAVIGATION SYSTEM

< WIRING DIAGRAM >


[NAVIGATION]

Connector No.	M214
Connector Name	USB INTERFACE
Connector Color	BLUE



Terminal No.	Color of Wire	Signal Name
1	B	-
2	G	-
3	W	-
4	R	-
5	SHIELD	-

Connector No.	M205
Connector Name	WIRE TO WIRE
Connector Color	BLUE




Terminal No.	Color of Wire	Signal Name
1	SHIELD	-
2	B	-
3	R	-
4	W	-
5	G	-

Connector No.	M204
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
1	R	-
2	W	-
3	B	-
6	SHIELD	-

Connector No.	M501
Connector Name	SATELLITE ANTENNA
Connector Color	BROWN




Terminal No.	Color of Wire	Signal Name
1	B	-
2	SHIELD	-

Connector No.	M500
Connector Name	WIRE TO WIRE
Connector Color	PINK



Terminal No.	Color of Wire	Signal Name
1	B	-
2	SHIELD	-


Connector No.	M215
Connector Name	AUX IN JACK
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	W	-
2	R	-
3	-	-
4	B	-

ABNIA4280GB

Connector No.	E119
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
16	W/G	REVERSE LAMP

Connector No.	E45
Connector Name	BACK-UP LAMP RELAY (WITH A/T)
Connector Color	BROWN




Terminal No.	Color of Wire	Signal Name
1	LG	-
2	W/G	-
3	SB	-
5	W/G	-
6	Y	-
7	W/G	-

Connector No.	E5
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
9	LG	-
10	W/G	-
11	SB	-


Connector No.	F9
Connector Name	A/T ASSEMBLY
Connector Color	GREEN



Terminal No.	Color of Wire	Signal Name
7	LG	-

Terminal No.	Color of Wire	Signal Name
38G	SB	-
77G	Y	-

Connector No.	E152
Connector Name	WIRE TO WIRE
Connector Color	WHITE



ABNIA4281GB

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P

AV

Connector No.	F502
Connector Name	TCM (TRANSMISSION CONTROL MODULE)
Connector Color	GRAY



10	9	8	7	6	5	4	3	2	1
----	---	---	---	---	---	---	---	---	---

Terminal No.	Color of Wire	Signal Name
7	O	REV LAMP RLY

Connector No.	F69
Connector Name	BACK-UP LAMP SWITCH
Connector Color	WHITE



1	2
---	---

Terminal No.	Color of Wire	Signal Name
1	W/G	-
2	SB	-

Connector No.	F14
Connector Name	WIRE TO WIRE
Connector Color	WHITE



12	11	10	9	8	7	6	5	4	3	2	1
24	23	22	21	20	19	18	17	16	15	14	13

Terminal No.	Color of Wire	Signal Name
9	LG	-
10	W/G	-
11	SB	-

Connector No.	B48
Connector Name	WIRE TO WIRE
Connector Color	WHITE



1	2	3	4	5	6	7		
8	9	10	11	12	13	14	15	16

Terminal No.	Color of Wire	Signal Name
5	W	-
6	SHIELD	-
14	B	-
15	G/Y	-

Connector No.	B6
Connector Name	WIRE TO WIRE
Connector Color	WHITE



1	2	3	4	5		
6	7	8	9	10	11	12

Terminal No.	Color of Wire	Signal Name
5	G	-
12	B	-

ABNIA4282GB


Connector No.	B72
Connector Name	SUBWOOFER
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
1	W	-
2	G	-
3	O	-
4	BR	-

Terminal No.	Color of Wire	Signal Name
1J	O	-
2J	BR	-
3J	G	-
6J	G	-
7J	W	-
8J	B	-
56J	B	-
65J	G/Y	-
66J	SHIELD	-
67J	W	-

Connector No.	B69
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Connector No.	B106
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
5	GR	-
12	O	-

ABNIA4283GB

Terminal No.	Color of Wire	Signal Name
52M	L	-
54M	B/R	-
55M	P	-
57M	R	-
58M	Y	-
60M	B	-
61M	W	-
63M	G/W	-
72M	R	-
73M	BR	-
74M	W	-
76M	R/B	-
77M	LG	-
78M	O	-
79M	G	-


Terminal No.	Color of Wire	Signal Name
1M	GR	-
2M	Y	-
3M	P	-
4M	W	-
6M	L	-
7M	BR	-
8M	B	-
9M	G	-
51M	B/W	-

Connector No.	B149
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
13	W	FR RH TW (+)
14	Y	FR LH TW (+)
15	BR	FRSP LH OUT (+)
16	LG	FRSP RH OUT (+)
21	Y	FRSP RH (+) IN
22	W	FRSP LH (+) IN
23	L	RRSP RH (+) IN
24	P	RRSP LH (+) IN
25	-	-
26	-	-
27	B	RRSP LH OUT (-)
28	O	RRSP RH OUT (-)
29	P	FR RH TW (-)
30	GR	FR LH TW (-)
31	L	FRSP LH OUT (-)
32	R	FRSP RH OUT (-)

Connector No.	B159
Connector Name	AUDIO AMPLIFIER
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
5	R	FRSP RH (-) IN
6	B	FRSP LH (-) IN
7	B/W	RRSP RH (-) IN
8	B/R	RRSP LH (-) IN
9	G/W	AMP ON/OFF SIGNAL
10	-	-
11	G	RRSP LH OUT (+)
12	GR	RRSP RH OUT (+)

Connector No.	B158
Connector Name	AUDIO AMPLIFIER
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	Y	BAT
2	W	WOOFER (+) 1
3	O	WOOFER (+) 2
4	B	GND
17	R/B	BAT
18	G	WOOFER (-) 1
19	BR	WOOFER (-) 2
20	B	GND

ABNIA4284GB

Connector No.	D2
Connector Name	WIRE TO WIRE
Connector Color	BROWN



1	2	3	4	5
6	7	8	9	10
11	12			

Terminal No.	Color of Wire	Signal Name
2	L/R	-
3	L/W	-

Connector No.	R8
Connector Name	MICROPHONE
Connector Color	WHITE



1	2	3	4
---	---	---	---

Terminal No.	Color of Wire	Signal Name
1	P	- (WITH NAVI)
2	SHIELD	- (WITH NAVI)
3	-	-
4	L	- (WITH NAVI)

Connector No.	R1
Connector Name	WIRE TO WIRE
Connector Color	WHITE



12	11	10	9	8	7	6	5	4	3	2	1
24	23	22	21	20	19	18	17	16	15	14	13

Terminal No.	Color of Wire	Signal Name
1	L	- (WITH NAVI)
14	P	- (WITH NAVI)
15	SHIELD	- (WITH NAVI)

Connector No.	D112
Connector Name	FRONT DOOR SPEAKER RH
Connector Color	WHITE



2	1
---	---

Terminal No.	Color of Wire	Signal Name
1	W/B	-
2	L/B	-

Connector No.	D101
Connector Name	WIRE TO WIRE
Connector Color	WHITE



1	2	3	4	5
6	7	8	9	10
11	12			

Terminal No.	Color of Wire	Signal Name
4	L/B	-
11	W/B	-

Connector No.	D12
Connector Name	FRONT DOOR SPEAKER LH
Connector Color	WHITE



2	1
---	---

Terminal No.	Color of Wire	Signal Name
1	L/W	-
2	L/R	-

ABNIA4285GB

A
B
C
D
E
F
G
H
I
J
K
L
M
O
P

AV

NAVIGATION SYSTEM

< WIRING DIAGRAM >

[NAVIGATION]

Connector No.	D201
Connector Name	WIRE TO WIRE
Connector Color	WHITE



5	4			3	2	1
12	11	10	9	8	7	6

Terminal No.	Color of Wire	Signal Name
5	L	–
12	O	–

Connector No.	D153
Connector Name	WIRE TO WIRE
Connector Color	WHITE



1	2	3	4	5		
6	7	8	9	10	11	12

Terminal No.	Color of Wire	Signal Name
4	R	–
11	LG	–

Connector No.	D152
Connector Name	WIRE TO WIRE
Connector Color	WHITE



5	4			3	2	1
12	11	10	9	8	7	6

Terminal No.	Color of Wire	Signal Name
4	R	–
11	LG	–

Connector No.	D301
Connector Name	WIRE TO WIRE
Connector Color	WHITE



5	4		3	2	1	
12	11	10	9	8	7	6

Terminal No.	Color of Wire	Signal Name
5	L	–
12	O	–

Connector No.	D208
Connector Name	REAR TWEETER LH
Connector Color	BROWN



2	1
---	---

Terminal No.	Color of Wire	Signal Name
1	L	–
2	O	–

Connector No.	D207
Connector Name	REAR DOOR SPEAKER LH
Connector Color	WHITE



2	1
---	---

Terminal No.	Color of Wire	Signal Name
1	L	–
2	O	–

ABNIA428 6GB

Connector No.	D402
Connector Name	WIRE TO WIRE
Connector Color	WHITE



7	6	5	4	3	2	1
16	15	14	13	12	11	10
9	8					

Terminal No.	Color of Wire	Signal Name
5	W	-
6	SHIELD	-
14	B	-
15	G/Y	-

Connector No.	D308
Connector Name	REAR TWEETER RH
Connector Color	BROWN



2	1
---	---

Terminal No.	Color of Wire	Signal Name
1	L	-
2	O	-

Connector No.	D307
Connector Name	REAR DOOR SPEAKER RH
Connector Color	WHITE



2	1
---	---

Terminal No.	Color of Wire	Signal Name
1	L	-
2	O	-

Connector No.	D503
Connector Name	WIRE TO WIRE
Connector Color	WHITE



1	2	3	4
5	6	7	8

Terminal No.	Color of Wire	Signal Name
1	G/Y	-
4	GR	-
5	B	-
6	W	-
8	SHIELD	-

Connector No.	D409
Connector Name	WIRE TO WIRE
Connector Color	WHITE



1	2
---	---

Terminal No.	Color of Wire	Signal Name
2	B	-

Connector No.	D404
Connector Name	WIRE TO WIRE
Connector Color	WHITE



4	3	2	1
8	7	6	5

Terminal No.	Color of Wire	Signal Name
1	G/Y	-
4	GR	-
5	B	-
6	W	-
8	SHIELD	-

ABNIA4287GB

A
B
C
D
E
F
G
H
I
J
K
L
M
O
P


AV

Connector No.	D650
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
2	B	—

Connector No.	D506
Connector Name	REAR VIEW CAMERA
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	G/Y	—
2	GR	—
3	B	—
4	W	—

ABNIA4332GB


BASIC INSPECTION

DIAGNOSIS AND REPAIR WORKFLOW

Work Flow

INFOID:000000009296818

OVERALL SEQUENCE



DETAILED FLOW

1.GET INFORMATION FOR SYMPTOM

Get detailed information from the customer about the symptom (the condition and the environment when the incident/malfunction occurred).

>> GO TO 2

2.CONFIRM THE SYMPTOM

Try to confirm the symptom described by the customer. Verify relation between the symptom and the condition when the symptom is detected. Refer to [AV-264, "Symptom Table"](#).

>> GO TO 3

3.DETECT MALFUNCTIONING PART BY DIAGNOSTIC PROCEDURE

Inspect according to Diagnostic Procedure of the system.

DIAGNOSIS AND REPAIR WORKFLOW

< BASIC INSPECTION >

[NAVIGATION]

Is malfunctioning part detected?

YES >> GO TO 4

NO >> GO TO 2

4. REPAIR OR REPLACE THE MALFUNCTIONING PART

1. Repair or replace the malfunctioning part.
2. Reconnect parts or connectors disconnected during Diagnostic Procedure.

>> GO TO 5

5. FINAL CHECK

Refer to confirmed symptom in step 2, and make sure that the symptom is not detected.

Was the repair confirmed?

YES >> Inspection End.

NO >> GO TO 2

INSPECTION AND ADJUSTMENT

ADDITIONAL SERVICE WHEN REPLACING AV CONTROL UNIT

ADDITIONAL SERVICE WHEN REPLACING AV CONTROL UNIT : Description

INFOID:000000009296819

BEFORE REPLACEMENT

When replacing AV control unit, save or print current vehicle specification with CONSULT configuration before replacement.

NOTE:

If "Before Replace ECU" cannot be used, use the "After Replace ECU" or "Manual Configuration" after replacing AV control unit.

AFTER REPLACEMENT

CAUTION:

When replacing AV control unit, you must perform "After Replace ECU" with CONSULT.

- Complete the procedure of "After Replace ECU" in order.
- If you set incorrect "After Replace ECU", incidents might occur.
- Configuration is different for each vehicle model. Confirm configuration of each vehicle model.

ADDITIONAL SERVICE WHEN REPLACING AV CONTROL UNIT : Work Procedure

INFOID:000000009296820

1. SAVING VEHICLE SPECIFICATION

 CONSULT

Enter "Re/Programming, Configuration" and perform "Before Replace ECU" to save or print current vehicle specification.

NOTE:

If "Before Replace ECU" cannot be used, use the "After Replace ECU" or "Manual Configuration" after replacing AV control unit.

>> GO TO 2.

2. REPLACE AV CONTROL UNIT

Replace AV control unit. Refer to [AV-281, "Removal and Installation"](#).

>> GO TO 3.

3. WRITING VEHICLE SPECIFICATION

 CONSULT

1. Enter "Re/Programming, Configuration".
2. If "Before Replace ECU" operation was performed, automatically an "Operation Log Selection" screen will be displayed. Select the applicable file from the "Saved Data List" and press "Confirm" to write vehicle specification. Refer to [AV-218, "CONFIGURATION \(AV CONTROL UNIT\) : Work Procedure"](#).
3. If "Before Replace ECU" operation was not performed, select "After Replace ECU" or "Manual Configuration" to write vehicle specification. Refer to [AV-218, "CONFIGURATION \(AV CONTROL UNIT\) : Work Procedure"](#).

>> GO TO 4.

4. OPERATION CHECK

Check that the operation of the AV control unit and camera images (fixed guide lines) are normal.

>> Work End.

CONFIGURATION (AV CONTROL UNIT)

CONFIGURATION (AV CONTROL UNIT) : Description

INFOID:000000009296821

Vehicle specification needs to be written with CONSULT because it is not written after replacing AV control unit.

Configuration has three functions as follows:

Function	Description
"Before Replace ECU"	• Reads the vehicle configuration of current AV control unit. • Saves the read vehicle configuration.
"After Replace ECU"	Writes the vehicle configuration with manual selection.
"Select Saved Data List"	Writes the vehicle configuration with saved data.

CAUTION:

- When replacing AV control unit, you must perform "Select Saved Data List" or "After Replace ECU" with CONSULT.
- Complete the procedure of "Select Saved Data List" or "After Replace ECU" in order.
- If you set incorrect "Select Saved Data List" or "After Replace ECU", incidents might occur.
- Configuration is different for each vehicle model. Confirm configuration of each vehicle model.
- Never perform "Select Saved Data List" or "After Replace ECU" except for new AV control unit.

CONFIGURATION (AV CONTROL UNIT) : Work Procedure

INFOID:000000009296822

1. WRITING MODE SELECTION

CONSULT

Select "Reprogramming, Configuration" of AV control unit.

When writing saved data>>GO TO 2.

When writing manually>>GO TO 3.

2. PERFORM "SAVED DATA LIST"

CONSULT

Automatically "Operation Log Selection" window will display if "Before Replace ECU" was performed. Select applicable file from the "Save Data List" and press "Confirm".

>> Work End.

3. PERFORM "AFTER REPLACE ECU" OR "MANUAL CONFIGURATION"

CONSULT

1. Select "After Replace ECU" or "Manual Configuration".
2. Identify the correct model and configuration list. Refer to [AV-219. "CONFIGURATION \(AV CONTROL UNIT\) : Configuration List"](#).
3. Confirm and/or change setting value for each item.

CAUTION:

Thoroughly read and understand the vehicle specification. ECU control may not operate normally if the setting is not correct.

4. Select "Next".

CAUTION:

Make sure to select "Next", confirm each setting value and press "OK" even if the indicated configuration of brand new AV control unit is same as the desirable configuration. If not, configuration which is set automatically by selecting vehicle model can not be memorized.

5. When "Completed", select "End".

>> GO TO 4.

4. OPERATION CHECK

Confirm that each function controlled by AV control unit operates normally.

INSPECTION AND ADJUSTMENT

< BASIC INSPECTION >

[NAVIGATION]

>> Work End.

CONFIGURATION (AV CONTROL UNIT) : Configuration List

INFOID:0000000009296823

CAUTION:

Thoroughly read and understand the vehicle specification. Incorrect settings may result in abnormal control of ECU.

MANUAL SETTING ITEM	
Items	Setting value
SOUND SYSTEM	BASE ⇔ BOSE
CAMERA SYSTEM	NONE/AVM ⇔ REAR CAMERA

⇔: Items which confirm vehicle specifications

A
B
C
D
E
F
G
H
I
J
K
L
M
O
P

AV

DTC/CIRCUIT DIAGNOSIS

U1000 CAN COMM CIRCUIT

DTC Logic

INFOID:000000009296824

DTC DETECTION LOGIC

CONSULT Display	DTC Detection Condition	Possible Cause
CAN COMM CIRCUIT [U1000]	AV control unit is not transmitting or receiving CAN communication signal for 2 seconds or more.	CAN communication system.

Diagnosis Procedure

INFOID:000000009296825

1.PERFORM SELF DIAGNOSTIC RESULT

1. Turn ignition switch ON and wait for 2 seconds or more.
2. Perform Self Diagnostic Result for MULTI AV.

Is CAN COMM CIRCUIT displayed?

- YES >> Refer to [LAN-14, "Trouble Diagnosis Flow Chart"](#).
NO >> Refer to [GI-40, "Intermittent Incident"](#).

U1010 CONTROL UNIT (CAN)

< DTC/CIRCUIT DIAGNOSIS >

[NAVIGATION]

U1010 CONTROL UNIT (CAN)

DTC Logic

INFOID:000000009296826

DTC DETECTION LOGIC

CONSULT Display	DTC Detection Condition	Possible Cause
CONTROL UNIT (CAN) [U1010]	Error during CAN controller hardware initialization (VCAN).	Replace the AV control unit if the malfunction occurs constantly. Refer to AV-281, "Removal and Installation" .

A

B

C

D

E

F

G

H

I

J

K

L

M

AV

O

P

U1217 AV CONTROL UNIT

< DTC/CIRCUIT DIAGNOSIS >

[NAVIGATION]

U1217 AV CONTROL UNIT

DTC Logic

INFOID:000000009296827

DTC DETECTION LOGIC

CONSULT Display	DTC Detection Condition	Possible Cause
BLUETOOTH MODULE [U1217]	Connection failure to the internal Bluetooth [®] sub unit is detected.	Replace AV control unit if malfunction occurs constantly. Refer to AV-281, "Removal and Installation" .

U1229 AV CONTROL UNIT

DTC Logic

INFOID:000000009296828

DTC DETECTION LOGIC

CONSULT Display	DTC Detection Condition	Possible Cause
iPod CERTIFICATION [U1229]	iPod authentication chip error.	Replace AV control unit if malfunction occurs constantly. Refer to AV-281, "Removal and Installation" .

A
B
C
D
E
F
G
H
I
J
K
L
M
O
P

U122F AV CONTROL UNIT

< DTC/CIRCUIT DIAGNOSIS >

[NAVIGATION]

U122F AV CONTROL UNIT

DTC Logic

INFOID:000000009296829

DTC DETECTION LOGIC

CONSULT Display	DTC Detection Condition	Possible Cause
Digital broadcasting connection error [U122F]	Communication error with digital audio broadcast module internal to AV control unit.	Replace AV control unit if malfunction occurs constantly. Refer to AV-281, "Removal and Installation" .

U1244 GPS ANTENNA

< DTC/CIRCUIT DIAGNOSIS >

[NAVIGATION]

U1244 GPS ANTENNA

DTC Logic

INFOID:000000009296830

DTC DETECTION LOGIC

CONSULT Display	DTC Detection Condition	Possible Cause
GPS ANTENNA CONN [U1244]	Open or short to ground is detected in GPS antenna connection.	- GPS antenna disconnection. - Open or short to ground in GPS antenna signal circuit.

Diagnosis Procedure

INFOID:000000009296831

Regarding Wiring Diagram information, refer to [AV-198, "Wiring Diagram"](#).

1. GPS ANTENNA INSPECTION

Visually inspect the GPS antenna and antenna feeder. Refer to [AV-290, "Location of Antenna"](#).

Is inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace malfunctioning components.

2. CHECK AV CONTROL UNIT VOLTAGE

1. Disconnect AV control unit connector M99.
2. Turn ignition switch ON.
3. Check voltage between AV control unit connector M99 and ground.

AV control unit		Ground	Voltage
Connector	Terminal		
M99	50	—	5.0 V

Is inspection result normal?

YES >> Replace GPS antenna.

NO >> Replace AV control unit. Refer to [AV-281, "Removal and Installation"](#).

AV

U1258 SATELLITE RADIO ANTENNA

< DTC/CIRCUIT DIAGNOSIS >

[NAVIGATION]

U1258 SATELLITE RADIO ANTENNA

DTC Logic

INFOID:000000009296832

DTC DETECTION LOGIC

CONSULT Display	DTC Detection Condition	Possible Cause
XM ANTENNA CONN [U1258]	Open or short to ground is detected in satellite antenna connection.	- Satellite antenna disconnection. - Open or short to ground in satellite antenna signal circuit.

Diagnosis Procedure

INFOID:000000009296833

Regarding Wiring Diagram information, refer to [AV-198, "Wiring Diagram"](#).

1. SATELLITE ANTENNA INSPECTION

Visually inspect the satellite antenna and antenna feeder. Refer to [AV-290, "Location of Antenna"](#).

Is inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace malfunctioning components.

2. CHECK AV CONTROL UNIT VOLTAGE

1. Disconnect AV control unit connector M100.
2. Turn ignition switch ON.
3. Check voltage between AV control unit connector M100 and ground.

AV control unit		Ground	Voltage
Connector	Terminal		
M100	58	—	5.0 V

Is inspection result normal?

YES >> Replace satellite radio antenna. Refer to [AV-293, "Removal and Installation"](#).

NO >> Replace AV control unit. Refer to [AV-281, "Removal and Installation"](#).

U1263 USB

DTC Logic

INFOID:000000009296834

DTC DETECTION LOGIC

CONSULT Display	DTC Detection Condition	Possible Cause
USB OVERCURRENT [U1263]	Overcurrent in USB harness is detected.	- Device connected to USB interface. - Harness between the AV control unit and USB interface.

DTC CONFIRMATION PROCEDURE

1.PERFORM SELF DIAGNOSTIC RESULT

1. If there is a device connected to the USB interface, disconnect it.
2. Turn ignition switch ON and wait for 2 seconds or more.
3. Perform Self Diagnostic Result for MULTI AV.

Is DTC U1263 displayed?

- YES >> Refer to [AV-227, "Diagnosis Procedure"](#).
 NO >> Inspection End.

Diagnosis Procedure

INFOID:000000009296835

1.CHECK USB INTERFACE HARNESS

Visually inspect USB interface harness. Refer to [AV-295, "Removal and Installation"](#).

Is the inspection result normal?

- YES >> GO TO 2.
 NO >> Replace USB interface harness. Refer to [AV-295, "Removal and Installation"](#).

2.CHECK USB INTERFACE HARNESS

Check USB interface harness. Refer to [AV-262, "Diagnosis Procedure"](#).

Is the inspection result normal?

- YES >> Replace AV control unit. Refer to [AV-281, "Removal and Installation"](#).
 NO >> Replace USB interface harness. Refer to [AV-295, "Removal and Installation"](#).

U1265 AUDIO AMP.

< DTC/CIRCUIT DIAGNOSIS >

[NAVIGATION]

U1265 AUDIO AMP.

DTC Logic

INFOID:000000009296836

CONSULT Display	DTC Detection Condition	Possible Cause
AMP ON TERMINAL [U1265]	Open or short to ground is detected in audio amp. ON signal circuit.	Open or short to ground in audio amp. ON signal circuit.

Diagnosis Procedure

INFOID:000000009296837

Regarding Wiring Diagram information, refer to [AV-198. "Wiring Diagram"](#).

1.CHECK CONTINUITY BETWEEN AV CONTROL UNIT AND AUDIO AMP.

1. Turn ignition switch OFF.
2. Disconnect AV control unit connector M96 and audio amplifier connector B158.
3. Check continuity between AV control unit connector M96 and audio amp. connector B158.

AV control unit		Audio amplifier		Continuity
Connector	Terminal	Connector	Terminal	
M96	1	B158	9	Yes

4. Check continuity between AV control unit connector M96 and ground.

AV control unit		Ground	Continuity
Connector	Terminal		
M96	1	—	No

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace harness or connectors.

2.CHECK AV CONTROL UNIT VOLTAGE

1. Connect AV control unit connector M96.
2. Turn ignition switch ON.
3. Check voltage between AV control unit connector M96 and ground.

AV control unit		Ground	Voltage (Approx.)
Connector	Terminal		
M96	1	—	Battery voltage

Is the inspection result normal?

YES >> Replace audio amplifier. Refer to [AV-282. "Removal and Installation"](#).

NO >> Replace AV control unit. Refer to [AV-281. "Removal and Installation"](#).

U12AA CONFIGURATION ERROR

< DTC/CIRCUIT DIAGNOSIS >

[NAVIGATION]

U12AA CONFIGURATION ERROR

DTC Logic

INFOID:000000009296838

DTC DETECTION LOGIC

CONSULT Display	DTC Detection Condition	Possible Cause
Configuration Error [U12AA]	AV control unit is not properly configured or configuration is corrupt.	Configuration data needs to be written. Refer to AV-218, "CONFIGURATION (AV CONTROL UNIT) : Work Procedure" .

Diagnosis Procedure

INFOID:000000009296839

1.PERFORM CONFIGURATION

When U12AA is detected, configuration data must be written.

>> Write configuration data with CONSULT. Refer to [AV-218, "CONFIGURATION \(AV CONTROL UNIT\) : Work Procedure"](#).

A
B
C
D
E
F
G
H
I
J
K
L
M
O
P

AV

U12AB ANTENNA

< DTC/CIRCUIT DIAGNOSIS >

[NAVIGATION]

U12AB ANTENNA

DTC Logic

INFOID:000000009296840

DTC DETECTION LOGIC

CONSULT Display	DTC Detection Condition	Possible Cause
FM Antenna error [U12AB]	Open or short to ground is detected in rod antenna connection.	• Rod antenna disconnection. • Open or short to ground in antenna feeder.

Diagnosis Procedure

INFOID:000000009296841

Regarding Wiring Diagram information, refer to [AV-198, "Wiring Diagram"](#).

1. ROD ANTENNA INSPECTION

Visually inspect the rod antenna and antenna feeder. Refer to [AV-290, "Location of Antenna"](#).

Is inspection result normal?

- YES >> Replace AV control unit. Refer to [AV-281, "Removal and Installation"](#).
NO >> Repair or replace malfunctioning components.

U12AC AV CONTROL UNIT

< DTC/CIRCUIT DIAGNOSIS >

[NAVIGATION]

U12AC AV CONTROL UNIT

DTC Logic

INFOID:000000009296842

DTC DETECTION LOGIC

CONSULT Display	DTC Detection Condition	Possible Cause
Display Temperature too High [U12AC]	Display temperature has exceeded maximum temperature. Display is switched OFF to avoid irreversible damage.	Replace AV control unit if malfunction occurs constantly. Refer to AV-281, "Removal and Installation" .

A

B

C

D

E

F

G

H

I

J

K

L

M

AV

O

P

U12AD AV CONTROL UNIT

< DTC/CIRCUIT DIAGNOSIS >

[NAVIGATION]

U12AD AV CONTROL UNIT

DTC Logic

INFOID:000000009296843

DTC DETECTION LOGIC

CONSULT Display	DTC Detection Condition	Possible Cause
ECU Temperature too High [U12AD]	AV control unit temperature has exceeded maximum temperature.	Replace AV control unit if malfunction occurs constantly. Refer to AV-281, "Removal and Installation" .

U12AE AV CONTROL UNIT

< DTC/CIRCUIT DIAGNOSIS >

[NAVIGATION]

U12AE AV CONTROL UNIT

DTC Logic

INFOID:000000009296844

DTC DETECTION LOGIC

CONSULT Display	DTC Detection Condition	Possible Cause
Internal Amplifier temperature Warning [U12AE]	Internal amplifier temperature has exceeded maximum temperature.	Replace AV control unit if malfunction occurs constantly. Refer to AV-281, "Removal and Installation" .

A

B

C

D

E

F

G

H

I

J

K

L

M

AV

O

P

U12AF AV CONTROL UNIT

< DTC/CIRCUIT DIAGNOSIS >

[NAVIGATION]

U12AF AV CONTROL UNIT

DTC Logic

INFOID:000000009296845

DTC DETECTION LOGIC

CONSULT Display	DTC Detection Condition	Possible Cause
CD Mechanism Temperature Warning [U12AF]	CD drive temperature has exceeded maximum temperature. CD drive is switched OFF to avoid irreversible damage.	Replace AV control unit if malfunction occurs constantly. Refer to AV-281, "Removal and Installation" .

U12B0 POWER SUPPLY VOLTAGE

< DTC/CIRCUIT DIAGNOSIS >

[NAVIGATION]

U12B0 POWER SUPPLY VOLTAGE

DTC Logic

INFOID:000000009296846

DTC DETECTION LOGIC

CONSULT Display	DTC Detection Condition	Possible Cause
Supply Voltage Goes below 9V > 20s [U12B0]	AV control unit supply voltage exceeds lower limits.	- Charging system malfunction. - AV control unit power supply or ground circuits.

Diagnosis Procedure

INFOID:000000009296847

1.CHECK CHARGING SYSTEM

Check the vehicle charging system. Refer to [CHG-2, "Work Flow \(With EXP-800 NI or GR8-1200 NI\)"](#) or [CHG-5, "Work Flow \(Without EXP-800 NI or GR8-1200 NI\)"](#).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace the malfunctioning components.

2.CHECK AV CONTROL UNIT POWER SUPPLY AND GROUND CIRCUITS

Perform the AV control unit power supply and ground circuit diagnosis procedure. Refer to [AV-238, "AV CONTROL UNIT : Diagnosis Procedure"](#).

Is the inspection result normal?

YES >> Replace the AV control unit. Refer to [AV-281, "Removal and Installation"](#).

NO >> Repair or replace harness or connectors.

A
B
C
D
E
F
G
H
I
J
K
L
M
O
P

AV

U12B1 POWER SUPPLY VOLTAGE

< DTC/CIRCUIT DIAGNOSIS >

[NAVIGATION]

U12B1 POWER SUPPLY VOLTAGE

DTC Logic

INFOID:000000009296848

DTC DETECTION LOGIC

CONSULT Display	DTC Detection Condition	Possible Cause
Supply Voltage Goes High > 16V for 20s [U12B1]	AV control unit supply voltage exceeds upper limits.	Charging system malfunction.

Diagnosis Procedure

INFOID:000000009296849

1. CHECK CHARGING SYSTEM

Check the vehicle charging system. Refer to [CHG-2, "Work Flow \(With EXP-800 NI or GR8-1200 NI\)"](#) or [CHG-5, "Work Flow \(Without EXP-800 NI or GR8-1200 NI\)"](#).

Is the inspection result normal?

- YES >> Replace the AV control unit. Refer to [AV-281, "Removal and Installation"](#).
NO >> Repair or replace the malfunctioning components.

U1310 AV CONTROL UNIT

DTC Logic

INFOID:000000009296850

DTC DETECTION LOGIC

CONSULT Display	DTC Detection Condition	Possible Cause
CONTROL UNIT (AV) [U1310]	Error during CAN controller hardware initialization (MCAN).	Replace AV control unit if malfunction occurs constantly. Refer to AV-281, "Removal and Installation" .

A
B
C
D
E
F
G
H
I
J
K
L
M
AV
O
P

AV

POWER SUPPLY AND GROUND CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[NAVIGATION]

POWER SUPPLY AND GROUND CIRCUIT

AV CONTROL UNIT

AV CONTROL UNIT : Diagnosis Procedure

INFOID:000000009296851

Regarding Wiring Diagram information, refer to [AV-198. "Wiring Diagram"](#).

1.CHECK FUSE

Check that the following fuses are not blown.

Terminal No.	Signal name	Fuse No.
7	ACC power supply	4 (10A)
19	Battery power supply	29 (20A)
37	IGN power supply	12 (10A)

Are the fuses blown?

YES >> Replace the blown fuse after repairing the affected circuit.

NO >> GO TO 2.

2.CHECK POWER SUPPLY CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect AV control unit connector M96 and M97.
3. Check voltage between AV control unit connectors and ground.

AV control unit		Ground	Condition	Voltage (Approx.)
Connector	Terminal			
M96	19	—	Ignition switch: OFF	Battery voltage
	7		Ignition switch: ON	
M97	37			

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace harness or connectors.

3.CHECK GROUND CIRCUIT

Check continuity between AV control unit connector M96 and ground.

AV control unit		Ground	Continuity
Connector	Terminal		
M96	20	—	Yes

Is the inspection result normal?

YES >> Inspection End.

NO >> Repair or replace harness or connectors.

AUDIO AMP.

AUDIO AMP. : Diagnosis Procedure

INFOID:000000009296852

Regarding Wiring Diagram information, refer to [AV-198. "Wiring Diagram"](#).

1.CHECK FUSE

Check that the following fuse is not blown.

POWER SUPPLY AND GROUND CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[NAVIGATION]

Terminal No.	Signal name	Fuse No.
1	Battery power supply	17 (15A)
17		

Is the fuse blown?

YES >> Replace the blown fuse after repairing the affected circuit.

NO >> GO TO 2.

2.CHECK POWER SUPPLY CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect audio amplifier connector B158.
3. Check voltage between audio amplifier connector B158 and ground.

Audio amplifier		Ground	Condition	Voltage (Approx.)
Connector	Terminal			
B158	1	—	Ignition switch: OFF	Battery voltage
	17			

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace harness or connectors.

3.CHECK GROUND CIRCUIT

Check continuity between audio amplifier connector B158 and ground.

Audio amplifier		Ground	Continuity
Connector	Terminal		
B158	4	—	Yes
	20		

Is the inspection result normal?

YES >> Inspection End.

NO >> Repair or replace harness or connectors.

AV

FRONT DOOR SPEAKER

Diagnosis Procedure

INFOID:000000009296853

Regarding Wiring Diagram information, refer to [AV-198. "Wiring Diagram"](#).

1.CONNECTOR CHECK

Check the AV control unit, audio amplifier and speaker connectors for the following:

- Proper connection
- Damage
- Disconnected or loose terminals

Is the inspection result normal?

YES >> GO TO 2

NO >> Repair the terminals or connectors.

2.CHECK FRONT DOOR SPEAKER SIGNAL CIRCUIT CONTINUITY

1. Disconnect audio amplifier connector B159 and suspect front door speaker connector.
2. Check continuity between audio amplifier connector B159 and suspect front door speaker connector.

Audio amplifier		Front door speaker		Continuity
Connector	Terminal	Connector	Terminal	
B159	15	D12 (LH)	1	Yes
	31		2	
	16	D112 (RH)	1	
	32		2	

3. Check continuity between audio amplifier connector B159 and ground.

Audio amplifier		Ground	Continuity
Connector	Terminal		
B159	15	—	No
	31		
	16		
	32		

Is the inspection result normal?

YES >> GO TO 3

NO >> Repair or replace harness or connectors.

3.CHECK FRONT DOOR SPEAKER SIGNAL


1. Connect audio amplifier connector B159 and suspect front door speaker connector.
2. Turn ignition switch to ACC.
3. Push AV control unit POWER switch.
4. Check signal between the terminals of audio amplifier connector B159.

Audio amplifier connector B159		Condition	Reference value
(+)	(-)		
Terminal	Terminal		

FRONT DOOR SPEAKER

< DTC/CIRCUIT DIAGNOSIS >

[NAVIGATION]

15	31	Audio signal output	
16	32		

Is the inspection result normal?

YES >> Replace front door speaker. Refer to [AV-284, "Removal and Installation"](#).

NO >> GO TO 4.

4.CHECK PRE-AMP SIGNAL CIRCUIT CONTINUITY

1. Disconnect AV control unit connector M96 and audio amplifier connector B159.
2. Check continuity between AV control unit connector M96 and audio amplifier connector B159.

AV control unit		Audio amplifier		Continuity
Connector	Terminal	Connector	Terminal	
M96	2	B159	22	Yes
	3		6	
	11		21	
	12		5	

3. Check continuity between AV control unit connector M96 and ground.

AV control unit		Ground	Continuity
Connector	Terminal		
M96	2	—	No
	3		
	11		
	12		


Is the inspection result normal?

YES >> GO TO 5.

NO >> Repair or replace harness or connectors.

5.CHECK PRE-AMP SIGNAL

1. Connect AV control unit connector M96 and audio amplifier connector B159.
2. Turn ignition switch to ACC.
3. Push AV control unit POWER switch.
4. Check signal between the terminals of AV control unit connector M96.

AV control unit connector M96		Condition	Reference value
(+)	(-)		
Terminal	Terminal	Audio signal output	
2	3		
11	12		

Is the inspection result normal?

FRONT DOOR SPEAKER

< DTC/CIRCUIT DIAGNOSIS >

[NAVIGATION]

-
- YES >> Replace audio amplifier. Refer to [AV-282, "Removal and Installation"](#).
NO >> Replace AV control unit. Refer to [AV-281, "Removal and Installation"](#).

FRONT TWEETER

Diagnosis Procedure

INFOID:000000009296854

Regarding Wiring Diagram information, refer to [AV-198, "Wiring Diagram"](#).

1.CONNECTOR CHECK

Check the AV control unit, audio amplifier and tweeter connectors for the following:

- Proper connection
- Damage
- Disconnected or loose terminals

Is the inspection result normal?

YES >> GO TO 2

NO >> Repair the terminals or connectors.

2.CHECK FRONT TWEETER SIGNAL CIRCUIT CONTINUITY

1. Disconnect audio amplifier connector B159 and suspect front tweeter connector.
2. Check continuity between audio amplifier connector B159 and suspect front tweeter connector.

Audio amplifier		Front tweeter		Continuity
Connector	Terminal	Connector	Terminal	
B159	14	M109 (LH)	1	Yes
	30		2	
	13	M111 (RH)	1	
	29		2	

3. Check continuity between audio amplifier connector B159 and ground.

Audio amplifier		Ground	Continuity
Connector	Terminal		
B159	14	—	No
	30		
	13		
	29		

Is the inspection result normal?

YES >> GO TO 3

NO >> Repair or replace harness or connectors.

3.CHECK FRONT TWEETER SIGNAL


1. Connect audio amplifier connector B159 and suspect front tweeter connector.
2. Turn ignition switch to ACC.
3. Push AV control unit POWER switch.
4. Check signal between the terminals of audio amplifier connector B159.

Audio amplifier connector B159		Condition	Reference value
(+)	(-)		
Terminal	Terminal		

FRONT TWEETER

< DTC/CIRCUIT DIAGNOSIS >

[NAVIGATION]

14	30	Audio signal output	
13	29		

Is the inspection result normal?

YES >> Replace front tweeter. Refer to [AV-283, "Removal and Installation"](#).

NO >> GO TO 4.

4.CHECK PRE-AMP SIGNAL CIRCUIT CONTINUITY

1. Disconnect AV control unit connector M96 and audio amplifier connector B159.
2. Check continuity between AV control unit connector M96 and audio amplifier connector B159.

AV control unit		Audio amplifier		Continuity
Connector	Terminal	Connector	Terminal	
M96	2	B159	22	Yes
	3		6	
	11		21	
	12		5	

3. Check continuity between AV control unit connector M96 and ground.

AV control unit		Ground	Continuity
Connector	Terminal		
M96	2	—	No
	3		
	11		
	12		


Is the inspection result normal?

YES >> GO TO 5.

NO >> Repair or replace harness or connectors.

5.CHECK PRE-AMP SIGNAL

1. Connect AV control unit connector M96 and audio amplifier connector B159.
2. Turn ignition switch to ACC.
3. Push AV control unit POWER switch.
4. Check signal between the terminals of AV control unit connector M96.

AV control unit connector M96		Condition	Reference value
(+)	(-)		
Terminal	Terminal	Audio signal output	
2	3		
11	12		

Is the inspection result normal?

FRONT TWEETER

< DTC/CIRCUIT DIAGNOSIS >

[NAVIGATION]

- YES >> Replace audio amplifier. Refer to [AV-282, "Removal and Installation"](#).
- NO >> Replace AV control unit. Refer to [AV-281, "Removal and Installation"](#).

A
B
C
D
E
F
G
H
I
J
K
L
M
O
P

AV

REAR DOOR SPEAKER

Diagnosis Procedure

INFOID:000000009296855

Regarding Wiring Diagram information, refer to [AV-198. "Wiring Diagram"](#).

1.CONNECTOR CHECK

Check the AV control unit, audio amplifier and speaker connectors for the following:

- Proper connection
- Damage
- Disconnected or loose terminals

Is the inspection result normal?

YES >> GO TO 2

NO >> Repair the terminals or connectors.

2.CHECK REAR DOOR SPEAKER SIGNAL CIRCUIT CONTINUITY

1. Disconnect audio amplifier connector B159 and suspect rear door speaker connector.
2. Check continuity between audio amplifier connector B159 and suspect rear door speaker connector.

Audio amplifier		Rear door speaker		Continuity
Connector	Terminal	Connector	Terminal	
B159	11	D207 (LH)	1	Yes
	27		2	
	12	D307 (RH)	1	
	28		2	

3. Check continuity between audio amplifier connector B159 and ground.

Audio amplifier		Ground	Continuity
Connector	Terminal		
B159	11	—	No
	27		
	12		
	28		

Is the inspection result normal?

YES >> GO TO 3

NO >> Repair or replace harness or connectors.

3.CHECK REAR DOOR SPEAKER SIGNAL


1. Connect audio amplifier connector B159 and suspect rear door speaker connector.
2. Turn ignition switch to ACC.
3. Push AV control unit POWER switch.
4. Check signal between the terminals of audio amplifier connector B159.

Audio amplifier connector B159		Condition	Reference value
(+)	(-)		
Terminal	Terminal		

REAR DOOR SPEAKER

< DTC/CIRCUIT DIAGNOSIS >

[NAVIGATION]

11	27	Audio signal output	
12	28		

Is the inspection result normal?

YES >> Replace rear door speaker. Refer to [AV-285, "Removal and Installation"](#).

NO >> GO TO 4.

4.CHECK PRE-AMP SIGNAL CIRCUIT CONTINUITY

1. Disconnect AV control unit connector M96 and audio amplifier connector B159.
2. Check continuity between AV control unit connector M96 and audio amplifier connector B159.

AV control unit		Audio amplifier		Continuity
Connector	Terminal	Connector	Terminal	
M96	4	B159	24	Yes
	5		8	
	13		23	
	14		7	

3. Check continuity between AV control unit connector M96 and ground.

AV control unit		Ground	Continuity
Connector	Terminal		
M96	4	—	No
	5		
	13		
	14		


Is the inspection result normal?

YES >> GO TO 5.

NO >> Repair or replace harness or connectors.

5.CHECK PRE-AMP SIGNAL

1. Connect AV control unit connector M96 and audio amplifier connector B159.
2. Turn ignition switch to ACC.
3. Push AV control unit POWER switch.
4. Check signal between the terminals of AV control unit connector M96.

AV control unit connector M96		Condition	Reference value
(+)	(-)		
Terminal	Terminal	Audio signal output	
4	5		
13	14		

Is the inspection result normal?

A
B
C
D
E
F
G
H
I
J
K
L
M
AV

REAR DOOR SPEAKER

< DTC/CIRCUIT DIAGNOSIS >

[NAVIGATION]

-
- YES >> Replace audio amplifier. Refer to [AV-282, "Removal and Installation"](#).
NO >> Replace AV control unit. Refer to [AV-281, "Removal and Installation"](#).

REAR TWEETER

Diagnosis Procedure

INFOID:000000009296856

Regarding Wiring Diagram information, refer to [AV-198. "Wiring Diagram"](#).

1.CONNECTOR CHECK

Check the AV control unit, audio amplifier and tweeter connectors for the following:

- Proper connection
- Damage
- Disconnected or loose terminals

Is the inspection result normal?

YES >> GO TO 2

NO >> Repair the terminals or connectors.

2.CHECK REAR TWEETER SIGNAL CIRCUIT CONTINUITY

1. Disconnect audio amplifier connector B159 and suspect rear tweeter connector.
2. Check continuity between audio amplifier connector B159 and suspect rear tweeter connector.

Audio amplifier		Rear tweeter		Continuity
Connector	Terminal	Connector	Terminal	
B159	11	D208 (LH)	1	Yes
	27		2	
	12	D308 (RH)	1	
	28		2	

3. Check continuity between audio amplifier connector B159 and ground.

Audio amplifier		Ground	Continuity
Connector	Terminal		
B159	11	—	No
	27		
	12		
	28		

Is the inspection result normal?

YES >> GO TO 3

NO >> Repair or replace harness or connectors.

3.CHECK REAR TWEETER SIGNAL


1. Connect audio amplifier connector B159 and suspect rear tweeter connector.
2. Turn ignition switch to ACC.
3. Push AV control unit POWER switch.
4. Check signal between the terminals of audio amplifier connector B159.

Audio amplifier connector B159		Condition	Reference value
(+)	(-)		
Terminal	Terminal		

REAR TWEETER

< DTC/CIRCUIT DIAGNOSIS >

[NAVIGATION]

11	27	Audio signal output	
12	28		

Is the inspection result normal?

YES >> Replace rear tweeter. Refer to [AV-286. "Removal and Installation"](#).

NO >> GO TO 4.

4.CHECK PRE-AMP SIGNAL CIRCUIT CONTINUITY

1. Disconnect AV control unit connector M96 and audio amplifier connector B159.
2. Check continuity between AV control unit connector M96 and audio amplifier connector B159.

AV control unit		Audio amplifier		Continuity
Connector	Terminal	Connector	Terminal	
M96	4	B159	24	Yes
	5		8	
	13		23	
	14		7	

3. Check continuity between AV control unit connector M96 and ground.

AV control unit		Ground	Continuity
Connector	Terminal		
M96	4	—	No
	5		
	13		
	14		


Is the inspection result normal?

YES >> GO TO 5.

NO >> Repair or replace harness or connectors.

5.CHECK PRE-AMP SIGNAL

1. Connect AV control unit connector M96 and audio amplifier connector B159.
2. Turn ignition switch to ACC.
3. Push AV control unit POWER switch.
4. Check signal between the terminals of AV control unit connector M96.

AV control unit connector M96		Condition	Reference value
(+)	(-)		
Terminal	Terminal	Audio signal output	
4	5		
13	14		

Is the inspection result normal?

REAR TWEETER

< DTC/CIRCUIT DIAGNOSIS >

[NAVIGATION]

- YES >> Replace audio amplifier. Refer to [AV-282, "Removal and Installation"](#).
- NO >> Replace AV control unit. Refer to [AV-281, "Removal and Installation"](#).

A
B
C
D
E
F
G
H
I
J
K
L
M
O
P

AV

SUBWOOFER

Diagnosis Procedure

INFOID:000000009296857

Regarding Wiring Diagram information, refer to [AV-198. "Wiring Diagram"](#).

1.CONNECTOR CHECK

Check the AV control unit, audio amplifier and subwoofer connectors for the following:

- Proper connection
- Damage
- Disconnected or loose terminals

Is the inspection result normal?

YES >> GO TO 2

NO >> Repair the terminals or connectors.

2.CHECK SUBWOOFER SIGNAL CIRCUIT CONTINUITY

1. Disconnect audio amplifier connector B158 and subwoofer connector.
2. Check continuity between audio amplifier connector B158 and subwoofer connector.

Audio amplifier		Subwoofer		Continuity
Connector	Terminal	Connector	Terminal	
B158	2	B72	1	Yes
	18		2	
	3		3	
	19		4	

3. Check continuity between audio amplifier connector B158 and ground.

Audio amplifier		Ground	Continuity
Connector	Terminal		
B158	2	—	No
	18		
	3		
	19		

Is the inspection result normal?

YES >> GO TO 3

NO >> Repair or replace harness or connectors.

3.CHECK SUBWOOFER SIGNAL


1. Connect audio amplifier connector B158 and subwoofer connector.
2. Turn ignition switch to ACC.
3. Push AV control unit POWER switch.
4. Check signal between the terminals of audio amplifier connector B158.

Audio amplifier connector B158		Condition	Reference value
(+)	(-)		
Terminal	Terminal		

SUBWOOFER

< DTC/CIRCUIT DIAGNOSIS >

[NAVIGATION]

2	18	Audio signal output	
3	19		

Is the inspection result normal?

YES >> Replace subwoofer. Refer to [AV-287, "Removal and Installation"](#).

NO >> GO TO 4.

4.CHECK PRE-AMP SIGNAL CIRCUIT CONTINUITY

1. Disconnect AV control unit connector M96 and audio amplifier connector B159.
2. Check continuity between AV control unit connector M96 and audio amplifier connector B159.

AV control unit		Audio amplifier		Continuity
Connector	Terminal	Connector	Terminal	
M96	4	B159	24	Yes
	5		8	
	13		23	
	14		7	

3. Check continuity between AV control unit connector M96 and ground.

AV control unit		Ground	Continuity
Connector	Terminal		
M96	4	—	No
	5		
	13		
	14		


Is the inspection result normal?

YES >> GO TO 5.

NO >> Repair or replace harness or connectors.

5.CHECK PRE-AMP SIGNAL

1. Connect AV control unit connector M96 and audio amplifier connector B159.
2. Turn ignition switch to ACC.
3. Push AV control unit POWER switch.
4. Check signal between the terminals of AV control unit connector M96.

AV control unit connector M96		Condition	Reference value
(+)	(-)		
Terminal	Terminal	Audio signal output	
4	5		
13	14		

Is the inspection result normal?

SUBWOOFER

< DTC/CIRCUIT DIAGNOSIS >

[NAVIGATION]

YES >> Replace audio amplifier. Refer to [AV-282, "Removal and Installation"](#).
NO >> Replace AV control unit. Refer to [AV-281, "Removal and Installation"](#).

AMP. ON SIGNAL CIRCUIT

Diagnosis Procedure

INFOID:000000009296858

Regarding Wiring Diagram information, refer to [AV-198, "Wiring Diagram"](#).

1.CHECK AUDIO AMPLIFIER AMP. ON SIGNAL

1. Turn audio system ON.
2. Check voltage between audio amplifier connector B159 and ground.

Audio amplifier		Ground	Voltage (Approx.)
Connector	Terminal		
B159	9	—	Greater than 6.5 V

Is inspection result normal?

- YES >> Inspection End.
NO >> GO TO 2.

2.CHECK AV CONTROL UNIT AMP. ON SIGNAL

Check voltage between AV control unit connector M96 and ground.

AV control unit		Ground	Voltage (Approx.)
Connector	Terminal		
M96	1	—	Greater than 6.5 V

Is inspection result normal?

- YES >> Repair or replace harness or connectors.
NO >> Replace AV control unit. Refer to [AV-281, "Removal and Installation"](#).

REAR VIEW CAMERA IMAGE SIGNAL CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[NAVIGATION]

REAR VIEW CAMERA IMAGE SIGNAL CIRCUIT

Diagnosis Procedure

INFOID:000000009296859

Regarding Wiring Diagram information, refer to [AV-198, "Wiring Diagram"](#).

1. CHECK REVERSE INPUT SIGNAL

1. Turn ignition switch ON.
2. Shift the selector lever to R (reverse).
3. Check voltage between AV control unit connector M97 and ground.

AV control unit		Ground	Condition	Voltage (Approx.)
Connector	Terminal			
M97	28	—	Selector lever in R (reverse)	Battery Voltage

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace harness or connectors.

2. CHECK CAMERA POWER SUPPLY CIRCUIT CONTINUITY

1. Turn ignition switch OFF.
2. Disconnect AV control unit connector M97 and rear view camera connector.
3. Check continuity between AV control unit connector M97 and rear view camera connector D506.

AV control unit		Rear view camera		Continuity
Connector	Terminal	Connector	Terminal	
M97	34	D506	1	Yes

4. Check continuity between AV control unit connector M97 and ground.

AV control unit		Ground	Continuity
Connector	Terminal		
M97	34		No

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace harness or connectors.

3. CHECK CAMERA POWER SUPPLY VOLTAGE

1. Connect AV control unit connector M97 and rear view camera connector.
2. Turn ignition switch ON.
3. Shift the selector lever to R (reverse).
4. Check voltage between AV control unit connector M97 and ground.

AV control unit		Ground	Condition	Voltage (Approx.)
Connector	Terminal			
M97	34	—	Selector lever is in "R".	6.0 V

Is the inspection result normal?

YES >> GO TO 4.

NO >> Replace AV control unit. Refer to [AV-281, "Removal and Installation"](#).

4. CHECK CAMERA IMAGE SIGNAL CIRCUIT CONTINUITY

1. Turn ignition switch OFF.

REAR VIEW CAMERA IMAGE SIGNAL CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[NAVIGATION]

2. Disconnect AV control unit connector M97 and rear view camera connector.
3. Check continuity between AV control unit connector M97 and rear view camera connector D506.

AV control unit		Rear view camera		Continuity
Connector	Terminal	Connector	Terminal	
M97	36	D506	3	Yes

4. Check continuity between AV control unit connector M97 and ground.

AV control unit		Ground	Continuity
Connector	Terminal		
M97	36		No

Is the inspection result normal?

YES >> GO TO 5.

NO >> Repair or replace harness or connectors.

5.CHECK CAMERA GROUND CIRCUIT CONTINUITY

Check continuity between AV control unit connector M97 and rear view camera connector D506.

AV control unit		Rear view camera		Continuity
Connector	Terminal	Connector	Terminal	
M97	35	D506	4	Yes


Is the inspection result normal?

YES >> GO TO 6.

NO >> Repair or replace harness or connectors.

6.CHECK CAMERA IMAGE SIGNAL

1. Connect AV control unit connector M97 and rear view camera connector.
2. Turn ignition switch ON.
3. Shift the selector lever to R (reverse).
4. Check signal between AV control unit connector M97 and ground.

AV control unit Connector M97		Condition	Reference value
(+)	(-)		
Terminal	Terminal		
36	35	Camera image displayed.	 SKIB2251J

Is the inspection result normal?

YES >> Replace AV control unit. Refer to [AV-281. "Removal and Installation"](#).

NO >> Replace rear view camera. Refer to [AV-296. "Removal and Installation"](#).

STEERING SWITCH

Diagnosis Procedure

INFOID:000000009296860

Regarding Wiring Diagram information, refer to [AV-198, "Wiring Diagram"](#).

1. CHECK STEERING WHEEL AUDIO CONTROL SWITCH RESISTANCE

1. Disconnect combination switch connector M102.
2. Check resistance between combination switch connector terminals.

Combination switch connector M102		Condition	Resistance (Ω) (Approx.)
Terminal	Terminal		
16	18	Depress VOL DOWN switch.	1
		Depress VOL UP switch.	121
		Depress  switch.	321
15		Depress MODE switch.	1
		Depress  switch.	121
		Depress  switch.	321
		Depress  switch.	723

Is the inspection result normal?

YES >> GO TO 2.

NO >> Replace steering wheel audio control switches. Refer to [AV-288, "Removal and Installation"](#).

2. CHECK HARNESS BETWEEN AV CONTROL UNIT AND COMBINATION SWITCH

1. Turn ignition switch OFF.
2. Disconnect AV control unit connector M96 and combination switch connector M30.
3. Check continuity between AV control unit connector M96 and combination switch connector M30.

AV control unit		Combination switch		Continuity
Connector	Terminal	Connector	Terminal	
M96	6	M30	24	Yes
	16		25	
	15		31	

4. Check continuity between AV control unit connector M96 and ground.

AV control unit		—	Continuity
Connector	Terminal		
M96	6	Ground	No
	16		
	15		

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace harness or connectors.

3. SPIRAL CABLE CHECK

Check continuity between combination switch connectors M30 and M102.

STEERING SWITCH

< DTC/CIRCUIT DIAGNOSIS >

[NAVIGATION]

Combination switch				Continuity
Connector	Terminal	Connector	Terminal	
M30	24	M102	15	Yes
	25		16	
	31		18	

Is the inspection result normal?

YES >> Replace AV control unit. Refer to [AV-281, "Removal and Installation"](#).

NO >> Replace spiral cable. Refer to [SR-13, "Removal and Installation"](#).

A
B
C
D
E
F
G
H
I
J
K
L
M
O
P

AV

MICROPHONE SIGNAL CIRCUIT

Diagnosis Procedure

INFOID:000000009296861

Regarding Wiring Diagram information, refer to [AV-198. "Wiring Diagram"](#).

1.CHECK MICROPHONE SIGNAL CIRCUIT CONTINUITY

1. Turn ignition switch OFF.
2. Disconnect AV control unit connector M97 and microphone connector R8.
3. Check continuity between AV control unit connector M97 and microphone connector R8.

AV control unit		Microphone		Continuity
Connector	Terminal	Connector	Terminal	
M97	41	R8	2	Yes
	42		4	
	43		1	

4. Check continuity between AV control unit connector M97 and ground.

AV control unit		Ground	Continuity
Connector	Terminal		
M97	41	—	No
	42		
	43		

Is inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace harness or connectors.

2.CHECK MICROPHONE VCC VOLTAGE

1. Connect AV control unit connector M97.
2. Turn ignition switch ON.
3. Check voltage between terminals of AV control unit connector M97.

AV control unit connector M97		Voltage (Approx.)
(+)	(-)	
Terminal	Terminal	
42	41	5.0 V

Is the inspection result normal?

YES >> GO TO 3.

NO >> Replace AV control unit. Refer to [AV-281. "Removal and Installation"](#).


3.CHECK MICROPHONE SIGNAL

1. Connect microphone connector.
2. Check signal between terminals of AV control unit connector M97.

MICROPHONE SIGNAL CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[NAVIGATION]

AV control unit connector M97		Condition	Reference value
(+)	(-)		
Terminal	Terminal		
43	41	Speak into microphone.	 SKIB3609E

Is the inspection result normal?

- YES >> Replace AV control unit. Refer to [AV-281. "Removal and Installation"](#).
- NO >> Replace microphone. Refer to [AV-289. "Removal and Installation"](#).

AV

USB CONNECTOR

Diagnosis Procedure

INFOID:000000009296862

Regarding Wiring Diagram information, refer to [AV-198, "Wiring Diagram"](#).

1. CHECK USB INTERFACE HARNESS CONTINUITY

1. Turn ignition switch OFF.
2. Disconnect AV control unit connector M98 and USB interface connector M214.
3. Check continuity between AV control unit connector M98 and USB interface connector M214.

AV control unit		USB interface		Continuity
Connector	Terminal	Connector	Terminal	
M98	45	M214	4	Yes
	46		1	
	47		2	
	48		3	
	49		5	

4. Check continuity between AV control unit connector M98 and ground.

AV control unit		—	Continuity
Connector	Terminal		
M98	45	Ground	No
	47		

Is the inspection result normal?

- YES >> Replace the USB interface. Refer to [AV-295, "Removal and Installation"](#).
 NO >> Repair or replace harness or connectors.

AUXILIARY INPUT JACK

< DTC/CIRCUIT DIAGNOSIS >

[NAVIGATION]

AUXILIARY INPUT JACK

Diagnosis Procedure

INFOID:000000009296863

Regarding Wiring Diagram information, refer to [AV-198. "Wiring Diagram"](#).

1. CHECK AUX JACK HARNESS CONTINUITY

1. Turn ignition switch OFF.
2. Disconnect AV control unit connector M97 and AUX jack connector M215.
3. Check continuity between AV control unit connector M97 and AUX jack connector M215.

AV control unit		AUX jack		Continuity
Connector	Terminal	Connector	Terminal	
M97	30	M215	4	Yes
	31		2	
	32		1	

4. Check continuity between AV control unit connector M97 and ground.

AV control unit		—	Continuity
Connector	Terminal		
M97	30	Ground	No
	32		

Is the inspection result normal?

- YES >> Replace the AUX jack. Refer to [AV-292. "Removal and Installation"](#).
NO >> Repair or replace harness or connectors.

AV

SYMPTOM DIAGNOSIS

MULTI AV SYSTEM

Symptom Table

INFOID:000000009296864

RELATED TO AUDIO

Symptoms	Check items	Probable malfunction location
The disk cannot be removed.	AV control unit	Malfunction in AV control unit. Refer to AV-189. "On Board Diagnosis Function" .

MULTI AV SYSTEM

< SYMPTOM DIAGNOSIS >

[NAVIGATION]

Symptoms	Check items	Probable malfunction location	
No sound comes out or the level of the sound is low.	No sound from all speakers.	• Speaker circuit shorted to ground. Refer to AV-198, "Wiring Diagram". • Amp. ON signal circuit malfunction. Refer to AV-255, "Diagnosis Procedure". • Audio amplifier power supply and ground circuits malfunction. Refer to AV-238, "AUDIO AMP. : Diagnosis Procedure".	A B C
	Only a certain speaker (front door speaker LH, front door speaker RH, front tweeter LH, front tweeter RH, rear door speaker LH, rear door speaker RH, rear tweeter LH, rear tweeter RH, subwoofer) does not output sound.	• Poor connector connection of speaker. • Sound signal circuit malfunction between AV control unit and audio amplifier. Refer to: - AV-240, "Diagnosis Procedure" (front door speaker). - AV-243, "Diagnosis Procedure" (front tweeter). - AV-246, "Diagnosis Procedure" (rear door speaker). - AV-249, "Diagnosis Procedure" (rear tweeter). - AV-252, "Diagnosis Procedure" (subwoofer). • Sound signal circuit malfunction between audio amplifier and speaker. Refer to: - AV-240, "Diagnosis Procedure" (front door speaker). - AV-243, "Diagnosis Procedure" (front tweeter). - AV-246, "Diagnosis Procedure" (rear door speaker). - AV-249, "Diagnosis Procedure" (rear tweeter). - AV-252, "Diagnosis Procedure" (subwoofer). • Malfunction in speaker. Refer to: - AV-284, "Removal and Installation" (front door speaker). - AV-283, "Removal and Installation" (front tweeter). - AV-285, "Removal and Installation" (rear door speaker). - AV-286, "Removal and Installation" (rear tweeter). - AV-287, "Removal and Installation" (subwoofer). • Malfunction in AV control unit. Refer to AV-189, "On Board Diagnosis Function". • Malfunction in audio amplifier. Replace Audio amplifier. Refer to AV-282, "Removal and Installation".	D E F G H I J K L M AV O P

MULTI AV SYSTEM

< SYMPTOM DIAGNOSIS >

[NAVIGATION]

Symptoms	Check items	Probable malfunction location
Noise is mixed with audio.	Noise comes out from all speakers.	• Malfunction in AV control unit. Refer to AV-189. "On Board Diagnosis Function". • Malfunction in audio amplifier. Replace audio amp. Refer to AV-282. "Removal and Installation".
	Noise comes out only from a certain speaker (front door speaker LH, front door speaker RH, front tweeter LH, front tweeter RH, rear door speaker LH, rear door speaker RH, rear tweeter LH, rear tweeter RH, sub-woofer).	• Poor connector connection of speaker. • Sound signal circuit malfunction between AV control unit and audio amplifier. Refer to: - AV-240. "Diagnosis Procedure" (front door speaker). - AV-243. "Diagnosis Procedure" (front tweeter). - AV-246. "Diagnosis Procedure" (rear door speaker). - AV-249. "Diagnosis Procedure" (rear tweeter). - AV-252. "Diagnosis Procedure" (sub-woofer). • Sound signal circuit malfunction between audio amplifier and speaker. Refer to: - AV-240. "Diagnosis Procedure" (front door speaker). - AV-243. "Diagnosis Procedure" (front tweeter). - AV-246. "Diagnosis Procedure" (rear door speaker). - AV-249. "Diagnosis Procedure" (rear tweeter). - AV-252. "Diagnosis Procedure" (sub-woofer). • Malfunction in speaker. • Poor Installation of speaker (e.g. backlash and looseness). Refer to: - AV-284. "Removal and Installation" (front door speaker). - AV-283. "Removal and Installation" (front tweeter). - AV-285. "Removal and Installation" (rear door speaker). - AV-286. "Removal and Installation" (rear tweeter). - AV-287. "Removal and Installation" (sub-woofer). • Malfunction in AV control unit. Refer to AV-189. "On Board Diagnosis Function". • Malfunction in audio amplifier. Replace audio amplifier. Refer to AV-282. "Removal and Installation".
	Noise is mixed with radio only (when the vehicle hits a bump or while driving over bad roads)	• Poor connector connection of antenna or antenna feeder. Refer to AV-290. "Location of Antenna".

MULTI AV SYSTEM

< SYMPTOM DIAGNOSIS >

[NAVIGATION]

Symptoms	Check items	Probable malfunction location
No radio reception or poor reception.	- Other audio sounds are normal. - Any radio station cannot be received or poor reception is caused even after moving to a service area with good reception (e.g. a place with clear view and no obstacles generating external noises).	- Antenna amp. ON signal circuit malfunction. Refer to AV-255, "Diagnosis Procedure" . - Rod antenna is not fully connected to antenna base. - Antenna base/rod connection (thread zone) has foreign material or corrosion inside. - Poor connector connection of antenna or antenna feeder. Refer to AV-290, "Location of Antenna" .
No satellite radio reception.	There is malfunction in the CONSULT self diagnosis result. Refer to AV-190, "CONSULT Function" .	- Malfunction in antenna, antenna feeder or AV control unit. Perform DTC diagnosis. Refer to AV-190, "CONSULT Function" . - Poor continuity in antenna feeder. - Poor connector connection of antenna or antenna feeder. Refer to AV-290, "Location of Antenna" .
	There is no malfunction in the CONSULT self diagnosis result. Refer to AV-190, "CONSULT Function" .	- Poor continuity in antenna feeder. - Poor connector connection of antenna or antenna feeder. - Loose satellite radio antenna mounting nut. Refer to AV-290, "Location of Antenna" .
Buzz/rattle sound from speaker	The majority of buzz/rattle sounds are not indicative of an issue with the speaker, usually something nearby the speaker is causing the buzz/rattle.	Refer to "SQUEAK AND RATTLE TROUBLE DIAGNOSIS" in the appropriate interior trim section.

RELATED TO HANDS-FREE PHONE

- Before performing diagnosis, confirm that the cellular phone being used by the customer is compatible with the vehicle.
- It is possible that a malfunction is occurring due to a version change of the phone even though the phone is a compatible type. This can be confirmed by changing the cellular phone to another compatible type, and check that it operates normally. It is important to determine whether the cause of the malfunction is the vehicle or the cellular phone.

Check Compatibility

- Make sure the customer's Bluetooth® related concern is understood.
- Verify the customer's concern.

NOTE:
The customer's phone may be required, depending upon their concern.
- Write down the customer's phone brand, model and service provider.

NOTE:
It is necessary to know the service provider. On occasion, a given phone may be on the approved list with one provider, but may not be on the approved list with other providers.
- Go to "www.nissanus.com/bluetooth/".
 - Using the website's search engine, find out if the customer's phone is on the approved list.
 - If the customer's phone is NOT on the approved list:

Stop diagnosis here. The customer needs to obtain a Bluetooth® phone that is on the approved list before any further action.
 - If the feature related to the customer's concern shows as "N" (not compatible):

Stop diagnosis here. If the customer still wants the feature to function, they will need to get an approved phone showing the feature as "Y" (compatible) in the "Basic Features".
 - If the feature related to the customer's concern shows as "Y" (compatible):

Perform diagnosis as per the following table.

MULTI AV SYSTEM

< SYMPTOM DIAGNOSIS >

[NAVIGATION]

Symptoms	Check items	Probable malfunction location
Does not recognize cellular phone connection (no connection is displayed on the display at the guide).	Repeat the registration of cellular phone.	Malfunction in AV control unit. Replace AV control unit. Refer to AV-281, "Removal and Installation" .
Hands-free phone cannot be established.	- Hands-free phone operation can be made, but the communication cannot be established. - Hands-free phone operation can be performed, however, voice between each other cannot be heard during the conversation.	
The other party's voice cannot be heard by hands-free phone.	Check the "microphone speaker" in Inspection & Adjustment Mode if sound is heard.	
Originating sound is not heard by the other party with hands-free phone communication.	Sound operation function is normal.	Microphone signal circuit malfunction. Refer to AV-260, "Diagnosis Procedure" .
	Sound operation function does not work.	
The system cannot be operated.	- The voice recognition can be controlled. - Steering switch's VOL UP and VOL DOWN switch works, but  does not work.	Steering switch malfunction. Replace steering switch. Refer to AV-288, "Removal and Installation" .
	Steering switch's  , VOL UP and VOL DOWN switches do not work.	Steering switch signal circuit malfunction. Refer to AV-258, "Diagnosis Procedure" .
	All steering switches do not work.	Steering switch ground circuit malfunction. Refer to AV-258, "Diagnosis Procedure" .

RELATED TO NAVIGATION

Symptoms	Check items	Probable malfunction location
Navigation system is inoperative.	Navigation malfunction.	- Malfunction in SD card. - Malfunction in AV control unit. Refer to AV-189, "On Board Diagnosis Function".
	Steering switches malfunction.	Steering switch signal circuit malfunction. Refer to AV-258, "Diagnosis Procedure" .
	Voice activated control malfunction.	Microphone signal circuit malfunction. Refer to AV-260, "Diagnosis Procedure" . Steering switch signal circuit malfunction. Refer to AV-258, "Diagnosis Procedure" .

RELATED TO REAR VIEW CAMERA

Symptoms	Check items	Probable malfunction location
Rear view camera is inoperative.	Reverse signal circuit malfunction.	Reverse signal circuit malfunction between BCM and AV control unit. Refer to AV-256, "Diagnosis Procedure" .
	Camera image signal circuit malfunction.	Camera image signal circuit malfunction between rear view camera and AV control unit. Refer to AV-256, "Diagnosis Procedure" .
	Rear view camera malfunction.	Replace rear view camera. Refer to AV-296, "Removal and Installation" .

NORMAL OPERATING CONDITION

Description

INFOID:000000009296865

RELATED TO NOISE

The majority of the audio concerns are the result of outside causes (bad CD, electromagnetic interference, etc.).

The following noise results from variations in field strength, such as fading noise and multi-path noise, or external noise from trains and other sources. It is not a malfunction.

- Fading noise: This noise occurs because of variations in the field strength in a narrow range due to mountains or buildings blocking the signal.
- Multi-path noise: This noise results from the waves sent directly from the broadcast station arriving at the antenna at a different time from the waves which reflect off mountains or buildings.

The vehicle itself can be a source of noise if noise prevention parts or electrical equipment is malfunctioning. Check if noise is caused and/or changed by engine speed, ignition switch turned to each position, and operation of each piece of electrical equipment, and determine the cause.

NOTE:

The source of the noise can be found easily by listening to the noise while removing the fuses of electrical components, one by one.

Type of Noise and Possible Cause

Occurrence condition		Possible cause
Occurs only when engine is ON.	A continuous growling noise occurs. The speed of the noise varies with changes in the engine speed.	• Ignition components
The occurrence of the noise is linked with the operation of the fuel pump.		• Fuel pump condenser
Noise only occurs when various electrical components are operating.	A cracking or snapping sound occurs with the operation of various switches.	• Relay malfunction, AV control unit malfunction
	The noise occurs when various motors are operating.	• Motor case ground • Motor
The noise occurs constantly, not just under certain conditions.		• Rear defogger coil malfunction • Open circuit in printed heater • Poor ground of antenna feeder line
A cracking or snapping sound occurs while the vehicle is being driven, especially when it is vibrating excessively.		• Ground wire of body parts • Ground due to improper part installation • Wiring connections or a short circuit

RELATED TO HANDS-FREE PHONE

Symptom	Cause and Counter measure
Does not recognize cellular phone connection (No connection is displayed on the display at the guide).	Some Bluetooth® enabled cellular phones may not be recognized by the in-vehicle phone module. Refer to "RELATED TO HANDS-FREE PHONE (Check Compatibility)" in AV-264, "Symptom Table" .
Cannot use hands-free phone.	Customer will not be able to use a hands-free phone under the following conditions: • The vehicle is outside of the telephone service area. • The vehicle is in an area where it is difficult to receive radio waves; such as in a tunnel, in an underground parking garage, near a tall building or in a mountainous area. • The cellular phone is locked to prevent it from being dialed. NOTE: While a cellular phone is connected through the Bluetooth® wireless connection, the battery power of the cellular phone may discharge quicker than usual. The Bluetooth® Hands-Free Phone System cannot charge cellular phones.

NORMAL OPERATING CONDITION

< SYMPTOM DIAGNOSIS >

[NAVIGATION]

Symptom	Cause and Counter measure
The other party's voice cannot be heard by hands-free phone.	When the radio wave condition is not ideal or ambient sound is too loud, it may be difficult to hear the other person's voice during a call.
Poor sound quality.	Do not place the cellular phone in an area surrounded by metal or far away from the in-vehicle phone module to prevent tone quality degradation and wireless connection disruption.

RELATED TO NAVIGATION

Basic Operation

Symptom	Cause	Remedy
No image is shown.	Display brightness adjustment is set fully to DARK side.	Adjust the display brightness.
No guide sound is heard. Audio guide volume is too low or too high.	Volume control is set to OFF, MIN or MAX. Audio guidance is not available while the vehicle is driving on a dark pink route.	Adjust the audio guide volume. System is not malfunctioning.
Screen is too dark. Motion of the image is too slow.	Temperature inside the vehicle is low.	Wait until the temperature inside the vehicle reaches the proper temperature.
Small black or bright spots appear on the screen.	Symptom peculiar to a liquid crystal display (display unit).	System is not malfunction.

Vehicle Mark

Symptom	Cause	Remedy
Map screen and BIRDVIEW™ Name of the place vary with the screen.	Some thinning of the character data is done to prevent the display becoming to complex. In some cases and in some locations, the display contents may differ. The same place name, street name, etc. may not be displayed every time on account of the data processing.	System is not malfunctioning.
Vehicle mark is not positioned correctly.	Vehicle is transferred by ferry or by towing after its ignition switch is turned to OFF.	Drive the vehicle for a while in the GPS satellite signal receiving condition.
Screen will not switch to nighttime mode after the lighting switch is turned ON.	The daytime screen is selected by the "SWITCH SCREENS" when the last time the screen dimming setting is done. Switching between daytime/nighttime screen may be inhibited by the automatic illumination adjustment function.	Perform screen dimming and select the nighttime screen by "SWITCH SCREENS".
Map screen will not scroll in accordance with the vehicle travel.	Current location is not displayed.	Press "MAP" button to display the current location.
Vehicle mark will not be shown.	Current location is not displayed.	Press "MAP" button to display the current location.
Accuracy indicator (GPS satellite mark) on the map screen stays gray.	GPS satellite signal is intercepted because the vehicle is in or behind a building.	Move the vehicle out to an open space.
	GPS satellite signal cannot be received because an obstacle is placed on top of the instrument panel.	Do not place anything on top of the meter display (instrument panel).
	GPS satellites are not visible from current location.	Wait until GPS satellites are visible by moving the vehicle.

NORMAL OPERATING CONDITION

< SYMPTOM DIAGNOSIS >

[NAVIGATION]

Symptom	Cause	Remedy
Vehicle location accuracy is low.	Accuracy indicator (GPS satellite mark) on the map screen stays gray.	Current location is not determined.
	Vehicle speed setting by the vehicle speed pulse has been deviated (advanced or retarded) from the actual vehicle speed because tire chain is fitted or the system has been used on another vehicle.	Drive the vehicle for a while [for approx. 30 minutes at approx. 30 km/h (19 MPH)] and the deviation will be automatically adjusted. If advancement or retard still occur, perform the distance adjustment by CONFIRMATION/ADJUSTMENT mode of diagnosis function.
	Map data has error or omission. (Vehicle mark is always deviated to the same position.)	As a rule, an updated map DVD-ROM will be released once a year.

Destination, Passing Points and Menu Items Cannot be Selected/Set

Symptom	Cause	Remedy
Destination cannot be set.	Destination to be set is on an expressway.	Set the destination on an ordinary road.
Passing point is not searched when re-searching the route.	The vehicle has already passed the passing point, or the system judged so.	To include the passing points that have been passed into the route again, set the route again.
Route information will not be displayed.	Route searching has not been done.	Set the destination and perform route searching.
	Vehicle mark is not on the recommended route.	Drive on the recommended route.
	Route guide is turned OFF.	Turn route guide ON.
	Route information is not available on the dark pink route.	System is not malfunctioning.
After the route searching, no guide sign will appear as the vehicle goes near the entrance/exit to the toll road.	Vehicle mark is not on the recommended route. (On the display, only guide signs related to the recommended route will be shown.)	Drive on the recommended route.
Automatic route searching is not possible.	Vehicle is driving on a highway (gray route), or no recommended route is available.	Drive on a road to be searched. Or re-search the route manually. In this case, however, the whole route will be searched.
Performed automatic detour search (or detour search). However, the result is the same as that of the previous search.	Performed search with every conditions considered. However, the result is the same as that of the previous search.	System is not malfunctioning.
Passing points cannot be set.	More than five passing points were set.	Passing points can be set up to five. To stop at more than five points, perform sharing in several steps.
When setting the route, the starting point cannot be selected.	The current vehicle location is always set as the starting point of a route.	System is not malfunctioning.
Some menu items cannot be selected.	The vehicle is being driven.	Stop the vehicle at a safe place and then operate the system.

Voice Guide

NORMAL OPERATING CONDITION

< SYMPTOM DIAGNOSIS >

[NAVIGATION]

Symptom	Cause	Remedy
Voice guide will not operate.	Note: Voice guide is only available at intersections that satisfy certain conditions (indicated by ● on the map). Therefore, guidance may not be given even when the route on the map changes direction.	System is not malfunctioning.
	The vehicle is not on the recommended route.	Return to the recommended route or re-search the route.
	Voice guide is turned OFF.	Turn voice guide ON.
	Route guide is turned OFF.	Turn route guide ON.
Voice guide does not match the actual road pattern.	Voice guide may vary with the direction to which the vehicle is turn and the connection of the road to other roads.	Drive in conformity to the actual traffic rules.

Route Search

Symptom	Cause	Remedy
No route is shown.	No road to be searched is found around the destination.	Find wider road (orange road or wider) nearby and reset the destination and passing points onto it. Take care of the traveling direction when there are separate up and down roads.
	Starting point and the destination are too close.	Set the destination at more distant point.
	Conditional traffic regulation (day of the week/ time of the day) is set at the area around the current location or the destination.	Turn the time-regulating search conditions OFF. Turn "Avoid regulation time" in the search conditions OFF.
Indicated route is intermittent.	In some areas, highways (gray routes) are not used for the search ^(Note) Therefore, the route to the current location or the passing points may be intermittent.	System is not malfunctioning.
When the vehicle has passed the recommended route, it is deleted from the screen.	A recommended route is controlled by each section. When the vehicle has passed the passing point 1, then the map data from the starting point up to the passing point 1 will be deleted. (The data may remain undeleted in some area.)	System is not malfunctioning.
Detouring route is recommended.	In some areas, highways (gray routes) are not used for the search. (Note). Therefore, detour route may be recommended.	Set the route closer to the basic route (gray route).
	A detour route may be shown when some traffic regulation (one-way traffic, etc.) is set at the area around the starting point or the destination.	Slightly move the starting point or the destination, or set the passing point on the route of your choice.
	In the area where highways (gray routes) are used for the search, left turn has priority around the current location and the destination (passing points). For this reason, the recommended route may be detouring.	System is not malfunctioning.
Landmarks on the map do not match the actual ones.	This can be happen due to omission or error in the map data.	As a rule, an updated map DVD-ROM will be released once a year. Wait until the latest map has become available.
Recommended route is far from the starting point, passing points, and destination.	Starting point, passing points, and destination of the route guide were set far from the desired points because route searching data around these area were not stored.	Reset the destination onto the road nearby. If this road is one of the highways (gray routes), an ordinary road nearby may be displayed as the recommended route.

NOTE:

Except for the ordinance-designated cities. (Malfunctioning areas may be changed in the updated map disc.)


Examples of Current-Location Mark Displacement

NORMAL OPERATING CONDITION

< SYMPTOM DIAGNOSIS >

[NAVIGATION]

Vehicle's travel amount is calculated by reading its travel distance and turning angle. Therefore, if the vehicle is driven in the following manner, an error will occur in the vehicle's current location display. If correct location has not been restored after driving the vehicle for a while, perform location correction.









A
B
C
D
E
F
G
H
I
J
K
L
M
AV
O
P

NORMAL OPERATING CONDITION

< SYMPTOM DIAGNOSIS >





[NAVIGATION]

Cause (condition) -: While driving ooo: Display		Driving condition	Remarks (correction, etc.)
Road configuration	Y-intersections  ELK0192D	At a Y intersection or similar gradual division of roads, an error in the direction of travel deduced by the sensor may result in the current-location mark appearing on the wrong road.	If after travelling about 10 km (6 miles) the correct location has not been restored, perform location correction and, if necessary, direction correction.
	Spiral roads  ELK0193D	When driving on a large, continuous spiral road (such as loop bridge), turning angle error is accumulated and the vehicle mark may deviate from the correct location.	
	Straight roads  ELK0194D	When driving on a long, straight road and slow curve without stopping, map-matching does not work effectively enough and distance errors may accumulate. As a result, the vehicle mark may deviate from the correct location when the vehicle is turned at a corner.	
	Zigzag roads  ELK0195D	When driving on a zigzag road, the map may be matched to other roads in the similar direction nearby at every turn, and the vehicle mark may deviate from the correct location.	
	Roads laid out in a grid pattern  ELK0196D	When driving where roads are laid out in a grid pattern, or where many roads are running in the similar direction nearby, the map may be matched to them by mistake and the vehicle mark may deviate from the correct location.	
	Parallel roads  ELK0197D	When two roads are running in parallel (such as highway and sideways), the map may be matched to the other road by mistake and the vehicle mark may deviate from the correct location.	

NORMAL OPERATING CONDITION

< SYMPTOM DIAGNOSIS >



[NAVIGATION]

Cause (condition) -: While driving ooo: Display		Driving condition	Remarks (correction, etc.)
Place	In a parking lot  SEL709V	When driving in a parking lot, or other location where there are no roads on the map, matching may place the vehicle mark on a nearby road. When the vehicle returns to the road, the vehicle mark may have deviated from the correct location. When driving in circle or turning the steering wheel repeatedly, direction errors accumulate, and the vehicle mark may deviate from the correct location.	If after travelling about 10 km (6 miles) the correct location has not been restored, perform location correction and, if necessary, direction correction.
	Turntable  SEL710V	When the ignition switch is OFF, the navigation system cannot get the signal from the gyroscope (angular speed sensor). Therefore, the displayed direction may be wrong and the correct road may not be easily returned to after rotating the vehicle on a turntable with the ignition OFF.	
	Slippery roads	On snow, wet roads, gravel, or other roads where tires may slip easily, accumulated mileage errors may cause the vehicle mark to deviate from the correct road.	
	Slopes	When parking in sloped garages, when travelling on banked roads, or in other cases where the vehicle turns when tilted, an error in the turning angle will occur, and the vehicle mark may deviate from the road.	
Map data	Road not displayed on the map screen  SEL699V	When driving on new roads or other roads not displayed on the map screen, map matching does not function correctly and matches the location to a nearby road. When the vehicle returns to a road which is on the map, the vehicle mark may deviate from the correct road.	
	Different road pattern (Changed due to repair)  ELK0201D	If the road pattern stored in the map data and the actual road pattern are different, map matching does not function correctly and matches the location to a nearby road. The vehicle mark may deviate from the correct road.	
Vehicle	Use of tire chains	When tire chains are used, the mileage is not correctly detected, and the vehicle mark may deviate from the correct road.	Drive the vehicle for a while. If the distance still deviates, adjust it by using the distance adjustment function. (If the tire chain is removed, recover the original value.)

NORMAL OPERATING CONDITION

< SYMPTOM DIAGNOSIS >

[NAVIGATION]

Cause (condition) -: While driving ooo: Display		Driving condition	Remarks (correction, etc.)
Precautions for driving	Just after the engine is started	If the vehicle is driven just after the engine is started when the gyroscope (angular speed sensor) correction is not completed, the vehicle can lose its direction and may have deviated from the correct location.	Wait for a short while before driving after starting the engine.
	Continuous driving without stopping	When driving long distances without stopping, direction errors may accumulate, and the current-location mark may deviate from the correct road.	Stop and adjust the orientation.
	Abusive driving	Spinning the wheels or engaging in other kinds of abusive driving may result in the system being unable perform correct detection, and may cause the vehicle mark to deviate from the correct road.	If after travelling about 10 km (6 miles) the correct location has not been restored, perform location correction and, if necessary, direction correction.
How to correct location	Position correction accuracy  SEL701V	If the accuracy of location settings is poor, accuracy may be reduced when the correct road cannot be found, particularly in places where there are many roads.	Enter in the road displayed on the screen with an accuracy of approx. 1mm. Caution: Whenever possible, use detailed map for the correction.
	Direction when location is corrected  SEL702V	If the accuracy of location settings during correction is poor, accuracy may be reduced afterwards.	Perform direction correction.

Location Correction by Map-Matching is Slow

- The map-matching function needs to refer to the data of the surrounding area. It is necessary to drive some distance for the function to work.
- Because map-matching operates on this principle, when there are many roads running in similar directions in the surrounding area, no matching determination may be made. The location may not be corrected until some special feature is found.

Name of Road is Not Displayed

The current road name may not be displayed if there are no road names displayed on the map screen.

Contents of Display Differ for Birdview™ and the (Flat) Map Screen

Difference of the BIRDVIEW™ screen from the flat map screen are as follows.

- The current place name displays names which are primarily in the direction of vehicle travel.
- The amount of time before the vehicle travel or turn angle is updated on the screen is longer than for the (flat) map display.
- The conditions for display of place names, roads, and other data are different for nearby areas and for more distant areas.
- Some thinning of the character data is done to prevent the display becoming too complex. In some cases and in some locations, the display contents may differ.
- The same place name, street name, etc. may be displayed multiple times.

Vehicle Mark Shows a Position Which is Completely Wrong

In the following cases, the vehicle mark may appear on completely different position in the map depending on the GPS satellite signal receiving conditions. In this case, perform location correction and direction correction.

- When location correction has not been done
- If the receiving conditions of the GPS satellite signal is poor, if the vehicle mark becomes out of place, it may move to a completely different location and not come back if location correction is not done. The position will be corrected if the GPS signal can be received.
- When the vehicle has traveled by ferry, or when the vehicle has been being towed

NORMAL OPERATING CONDITION

< SYMPTOM DIAGNOSIS >

[NAVIGATION]

- Because calculation of the current location cannot be done when traveling with the ignition off, for example when traveling by ferry or when being towed, the location before travel is displayed. If the precise location can be detected with GPS, the location will be corrected.

A

Vehicle Mark Jumps

In the following cases, the vehicle mark may appear to jump as a result of automatic correction of the current location.

B

- When map matching has been done
- If the current location and the vehicle mark are different when map matching is done, the vehicle mark may seem to jump. At this time, the location may be “corrected” to the wrong road or to a location which is not on a road.
- When GPS location correction has been done
- If the current location and the vehicle mark are different when the location is corrected using GPS measurements, the vehicle mark may seem to jump. At this time, the location may be “corrected” to a location which is not on a road.

C

D

Vehicle Mark is in a River or Sea

The navigation system moves the vehicle mark with no distinction between land and rivers or sea. If the vehicle mark is somehow out of place, it may appear that the vehicle is driving in a river or the sea.

E

Vehicle Mark Automatically Rotates

The system wrongly memorizes the rotating status as stopping when the ignition switch is turned ON with the turntable rotating. That causes the vehicle mark to rotate when the vehicle is stopped.

F

When Driving on Same Road, Sometimes Vehicle Mark is in Right Place and Sometimes it is in Wrong Place

The conditions of the GPS antenna (GPS data) and gyroscope (angular speed sensor) change gradually. Depending on the road traveled and the operation of the steering wheel, the location detection results will be different. Therefore, even on a road on which the location has never been wrong, conditions may cause the vehicle mark to deviate.

G

H

I

J

K

L

M

AV

O

P

PRECAUTION

PRECAUTIONS

Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"

INFOID:000000009296866

The Supplemental Restraint System such as "AIR BAG" and "SEAT BELT PRE-TENSIONER", used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. This system includes seat belt switch inputs and dual stage front air bag modules. The SRS system uses the seat belt switches to determine the front air bag deployment, and may only deploy one front air bag, depending on the severity of a collision and whether the front occupants are belted or unbelted. Information necessary to service the system safely is included in the SR and SB section of this Service Manual.

WARNING:

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision which would result in air bag inflation, all maintenance must be performed by an authorized NISSAN/INFINITI dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see the SR section.
- Do not use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harnesses or harness connectors.

PRECAUTIONS WHEN USING POWER TOOLS (AIR OR ELECTRIC) AND HAMMERS

WARNING:

- When working near the Airbag Diagnosis Sensor Unit or other Airbag System sensors with the Ignition ON or engine running, DO NOT use air or electric power tools or strike near the sensor(s) with a hammer. Heavy vibration could activate the sensor(s) and deploy the air bag(s), possibly causing serious injury.
- When using air or electric power tools or hammers, always switch the Ignition OFF, disconnect the battery and wait at least 3 minutes before performing any service.

Precaution for Trouble Diagnosis

INFOID:000000009296867

AV COMMUNICATION SYSTEM


- Do not apply voltage of 7.0 V or higher to the measurement terminals.
- Use the tester with its open terminal voltage being 7.0 V or less.
- Be sure to turn ignition switch OFF and disconnect the battery cable from the negative terminal before checking the circuit.

Precaution for Harness Repair

INFOID:000000009296868

AV COMMUNICATION SYSTEM

- Solder the repaired parts, and wrap with tape. [Frays of twisted line must be within 110 mm (4.33 in).]




PKIA0306E

PRECAUTIONS

< PRECAUTION >

[NAVIGATION]

- Do not perform bypass wire connections for the repair parts. (The spliced wire will become separated and the characteristics of twisted line will be lost.)



Precaution for Work

INFOID:000000009296869

- When removing or disassembling each component, be careful not to damage or deform it. If a component may be subject to interference, be sure to protect it with a shop cloth.
- When removing (disengaging) components with a screwdriver or similar tool, be sure to wrap the component with a shop cloth or vinyl tape to protect it.
- Protect the removed parts with a shop cloth and prevent them from being dropped.
- Replace a deformed or damaged clip.
- If a part is specified as a non-reusable part, always replace it with a new one.
- Be sure to tighten bolts and nuts securely to the specified torque.
- After installation is complete, be sure to check that each part works properly.
- Follow the steps below to clean components:
 - Water soluble dirt:
 - Dip a soft cloth into lukewarm water, wring the water out of the cloth and wipe the dirty area.
 - Then rub with a soft, dry cloth.
 - Oily dirt:
 - Dip a soft cloth into lukewarm water with mild detergent (concentration: within 2 to 3%) and wipe the dirty area.
 - Then dip a cloth into fresh water, wring the water out of the cloth and wipe the detergent off.
 - Then rub with a soft, dry cloth.
 - Do not use organic solvent such as thinner, benzene, alcohol or gasoline.
 - For genuine leather seats, use a genuine leather seat cleaner.

A
B
C
D
E
F
G
H
I
J
K
L
M
O
P

AV

PREPARATION

< PREPARATION >

[NAVIGATION]


PREPARATION

PREPARATION

Special Service Tools

INFOID:000000009296870

The actual shapes of Kent-Moore tools may differ from those of special service tools illustrated here.

Tool number (Kent-Moore No.) Tool name	Description
— (J-46534) Trim Tool Set  AWJIA04832Z	Removing trim components

Commercial Service Tools

INFOID:000000009296871

Tool name	Description
Power tool  PIIB1407E	Loosening nuts, screws and bolts

REMOVAL AND INSTALLATION

AV CONTROL UNIT

Removal and Installation


INFOID:000000009296872

REMOVAL

CAUTION:

Before replacing AV control unit, perform "READ CONFIGURATION" to save current vehicle specification. Refer to [AV-217, "ADDITIONAL SERVICE WHEN REPLACING AV CONTROL UNIT : Work Procedure"](#).

1. Disconnect the negative battery terminal. Refer to [PG-72, "Removal and Installation"](#).
2. Remove cluster lid C. Refer to [IP-15, "Removal and Installation"](#).
3. Remove the screws (A) from the bracket.
4. Remove the audio unit (1) from cluster lid C.



INSTALLATION

CAUTION:

When replacing AV control unit, perform "WRITE CONFIGURATION". Refer to [AV-217, "ADDITIONAL SERVICE WHEN REPLACING AV CONTROL UNIT : Work Procedure"](#).

Installation is in the reverse order of removal.

A
B
C
D
E
F
G
H
I
J
K
L
M
O
P

AV

AUDIO AMP.

Removal and Installation


INFOID:000000009296873

REMOVAL

NOTE:

Do not remove the RH front seat from the vehicle.

1. Remove the RH front seat bolts, disconnect the harness connectors from the RH front seat. Refer to [SE-14, "Exploded View"](#).
2. Tilt the RH front seat back to access the audio amp. (1) and remove the audio amp. kick shield screws (C).
⇐: Front
3. Disconnect the harness connectors (A) from the audio amp. and remove the audio amp. (1) from the bracket (2).
4. Remove the audio amp. bracket screws (B) and bracket (2).



INSTALLATION

Installation is in the reverse order of removal.

FRONT TWEETER


Removal and Installation

INFOID:000000009296874

REMOVAL

CAUTION:**Use a suitable tool to prevent damage to the front tweeter grille and the instrument panel.**

1. Remove the front tweeter grille.
2. Remove the front tweeter screws (A).
3. Pull out the front tweeter (1), then disconnect the harness connector from the front tweeter and remove.



INSTALLATION

Installation is in the reverse order of removal.

A
B
C
D
E
F
G
H
I
J
K
L
M
O
P

AV


FRONT DOOR SPEAKER

Removal and Installation

INFOID:000000009296875

REMOVAL

1. Remove the front door finisher. Refer to [INT-14, "Removal and Installation"](#).
2. Remove the front door speaker screws (A).
3. Pull out the front door speaker (1) and disconnect the harness connector from the front door speaker.
4. Remove the front door speaker (1).



INSTALLATION

Installation is in the reverse order of removal.


REAR DOOR SPEAKER

Removal and Installation

INFOID:000000009296876

REMOVAL

1. Remove the rear door finisher. Refer to [INT-14. "Removal and Installation"](#).
2. Remove the rear door speaker screws (A).
3. Disconnect the harness connector (B) from the rear door speaker (1) and remove.



INSTALLATION

Installation is in the reverse order of removal.

A
B
C
D
E
F
G
H
I
J
K
L
M

AV

O
P


REAR TWEETER

Removal and Installation

INFOID:000000009296877

REMOVAL

1. Remove the rear door finisher. Refer to [INT-14, "Removal and Installation"](#).
2. Remove the rear door tweeter screws (A) and rear door tweeter (1).




INSTALLATION

Installation is in the reverse order of removal.

SUBWOOFER

Removal and Installation

INFOID:000000009296878



1. Subwoofer
4. Locating pin

2. Bracket
5. Connector

3. Locating pin plate

REMOVAL

1. Position the LH rear seat cushion in the folded up position.
2. Remove storage box (RH). Refer to [INT-23, "Component"](#).
3. Remove the subwoofer screws.
4. Disconnect the harness connector from the subwoofer and remove.

INSTALLATION

Installation is in the reverse order of removal.

STEERING SWITCH


< REMOVAL AND INSTALLATION >

[NAVIGATION]

STEERING SWITCH

Removal and Installation

INFOID:000000009296879



1. Steering wheel

2. Steering wheel audio control switches


REMOVAL

1. Remove the driver air bag module. Refer to [SR-11. "Removal and Installation"](#).
2. Remove the steering wheel audio control switch assembly screws.
3. Disconnect the harness connectors from the steering wheel audio control switches.
4. Remove the steering wheel audio control switches by pulling on steering wheel audio control switches to release the pawls.

○: Pawl

CAUTION:

Do not tilt steering wheel audio control switches during removal or damage may occur to the pawls.



INSTALLATION

Installation is in the reverse order of removal.


MICROPHONE

Removal and Installation

INFOID:000000009296880

REMOVAL

1. Remove the roof console. Refer to [INT-21, "Removal and Installation"](#).
2. Release the pawls that retain the Bluetooth microphone (1) to the roof console.
3. Disconnect the harness connector (A) from the Bluetooth microphone (1) and remove.



INSTALLATION

Installation is in the reverse order of removal.


A
B
C
D
E
F
G
H
I
J
K
L
M
O
P

AV

AUDIO ANTENNA

Location of Antenna

INFOID:000000009296881



AWNIA2971ZZ

- | | | |
|-----------------------------|-----------------------|----------------|
| 1. Coaxial antenna feeder | 2. GPS antenna feeder | 3. M100 |
| 4. M99 | 5. M38 | 6. GPS antenna |
| 7. Satellite antenna feeder | 8. M67 | 9. M500 |
| 10. M501 | | |

Removal and Installation

INFOID:000000009296882

REMOVAL


1. Remove instrument lower panel RH and glove box. Refer to [IP-20, "Removal and Installation"](#).
2. Disconnect audio antenna cable from antenna feeder.

AUDIO ANTENNA

< REMOVAL AND INSTALLATION >

[NAVIGATION]

3. Remove antenna rod.
4. Remove rubber seal.
5. Remove cowl top. Refer to [EXT-20. "Removal and Installation"](#).
6. Remove fender protector. Refer to [EXT-22. "Removal and Installation"](#).
7. Remove antenna base bolts.
8. Remove antenna base and cable.



INSTALLATION

Installation is in the reverse order of removal.

CAUTION:

Always properly tighten the antenna rod during installation or the antenna rod may bend or break during vehicle operation.

A
B
C
D
E
F
G
H
I
J
K
L
M
O
P

AV

AUXILIARY INPUT JACK

Removal and Installation

INFOID:000000009296883

Removal

1. Remove the center console. Refer to [IP-22. "Removal and Installation"](#).
2. Push the pawl from the back of the center console to remove the auxiliary input jack.

Installation

Installation is in the reverse order of removal.


SATELLITE RADIO ANTENNA

Removal and Installation

INFOID:000000009298800

REMOVAL

1. Remove the roof console. Refer to [INT-21, "Removal and Installation"](#).
2. Disconnect the harness connector from the satellite radio antenna.
3. Remove the satellite radio antenna nut.
4. Remove the satellite radio antenna.



INSTALLATION

Installation is in the reverse order of removal.

A
B
C
D
E
F
G
H
I
J
K
L
M
O
P

AV

GPS ANTENNA

Removal and Installation

INFOID:000000009298822

REMOVAL

1. Remove the combination meter. Refer to [MWI-84, "Removal and Installation"](#).
2. Remove the GPS antenna screw and the GPS antenna.

INSTALLATION

Installation is in the reverse order of removal.

USB CONNECTOR

Removal and Installation

INFOID:000000009296885

REMOVAL

1. Remove the center console assembly. Refer to [IP-22. "Removal and Installation"](#).
2. Push the pawl from the back of the center console to remove the USB interface.

INSTALLATION

Installation is in the reverse order of removal.

A
B
C
D
E
F
G
H
I
J
K
L
M
O
P

AV


REAR VIEW CAMERA

Removal and Installation

INFOID:000000009296886

REMOVAL

1. Remove the back door lower finisher. Refer to [INT-26. "Removal and Installation"](#).
2. Remove the rear view camera nuts (A).



3. Disconnect the harness connector from the rear view camera and remove.

INSTALLATION

Installation is in the reverse order of removal.