

SECTION BT

CONTENTS

PRECAUTIONS	2	INSTRUMENT PANEL ASSEMBLY	21
Service Notice.....	2	Removal and Installation	21
Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"	2	SIDE AND FLOOR TRIM	28
PREPARATION	3	Removal and Installation	28
Special Service Tools	3	DOOR TRIM	30
Commercial Service Tools	3	Removal and Installation	30
SQUEAK AND RATTLE TROUBLE DIAGNOSES	4	ROOF TRIM	32
Work Flow.....	4	Removal and Installation	32
CUSTOMER INTERVIEW	4	BACK DOOR TRIM	34
DUPLICATE THE NOISE AND TEST DRIVE	5	Removal and Installation	34
CHECK RELATED SERVICE BULLETINS	5	EXTERIOR	35
LOCATE THE NOISE AND IDENTIFY THE ROOT CAUSE	5	Removal and Installation	35
REPAIR THE CAUSE	5	FRONT SEAT	41
CONFIRM THE REPAIR	6	Removal and Installation	41
Generic Squeak and Rattle Troubleshooting	6	HEATED SEAT	43
INSTRUMENT PANEL.....	6	REAR SEAT	44
CENTER CONSOLE	6	Removal and Installation	44
DOORS.....	6	SUNROOF	45
TRUNK	7	Adjustment	45
SUNROOF/HEADLINER	7	Removal and Installation	45
SEATS.....	7	Trouble Diagnoses.....	49
UNDERHOOD	7	DIAGNOSTIC TABLE.....	49
Diagnostic Worksheet.....	8	WIND DEFLECTOR	49
CLIP AND FASTENER	10	ADJUSTMENT	50
Description	10	DRAIN HOSES	51
BODY FRONT END	12	WEATHERSTRIP	51
Removal and Installation	12	LINK AND WIRE ASSEMBLY	52
FRONT BUMPER ASSEMBLY	12	WINDSHIELD AND WINDOWS	53
BODY REAR END AND OPENER	15	Removal and Installation	53
Removal and Installation	15	REMOVAL.....	53
REAR BUMPER ASSEMBLY	15	INSTALLATION.....	53
FRONT DOOR	18	WINDSHIELD	54
Overhaul	18	REAR SIDE WINDOW.....	55
Front Door Limit Switch Reset	19	DOOR MIRROR	56
RESET CONDITIONS	19	Removal and Installation	56
RESET PROCEDURES	19	BODY (ALIGNMENT)	57
REAR DOOR	20	Alignment	57
Overhaul	20	ENGINE COMPARTMENT	58
		UNDERBODY	60

PRECAUTIONS

Service Notice

Service Notice

NBBT0001

- When removing or installing various parts, place a cloth or padding onto the vehicle body to prevent scratches.
- Handle trim, molding, instruments, grille, etc. carefully during removing or installing. Be careful not to soil or damage them.
- Apply sealing compound where necessary when installing parts.
- When applying sealing compound, be careful that the sealing compound does not protrude from parts.
- When replacing any metal parts (for example body outer panel, members, etc.), be sure to take rust prevention measures.

Supplemental Restraint System (SRS) “AIR BAG” and “SEAT BELT PRE-TENSIONER”

NBBT0002

The Supplemental Restraint System such as “AIR BAG” and “SEAT BELT PRE-TENSIONER” used along with a seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. The SRS system composition which is available to INFINITI QX4 is as follows:

- For a frontal collision
The Supplemental Restraint System consists of driver air bag module (located in the center of the steering wheel), front passenger air bag module (located on the instrument panel on passenger side), seat belt pre-tensioners, a diagnosis sensor unit, warning lamp, wiring harness and spiral cable.
- For a side collision
The Supplemental Restraint System consists of side air bag module (located in the outer side of front seat), satellite sensor, diagnosis sensor unit (one of components of air bags for a frontal collision), wiring harness, warning lamp (one of components of air bags for a frontal collision).

Information necessary to service the system safely is included in the **RS section** of this Service Manual.

WARNING:

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision which would result in air bag inflation, all maintenance must be performed by an authorized INFINITI dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see the RS section.
- Do not use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. Spiral cable and wiring harnesses covered with yellow insulation tape either just before the harness connectors or for the complete harness are related to the SRS.



PREPARATION

Special Service Tools

Special Service Tools


NBBT0022

The actual shapes of Kent-Moore tools may differ from those of special service tools illustrated here.

Tool number (Kent-Moore No.) Tool name	Description	
— (J-39570) Chassis ear	 Locating the noise SBT839	GI MA EM LC EC FE
— (J-43980) Nissan Squeak and Rattle kit	 Repairing the cause of noise SBT840	AT TF PD AX SU

Commercial Service Tools

NBBT0023


Tool name	Description	
Engine ear	 Locating the noise SBT841	BR ST RS BT HA SC EL IDX

SQUEAK AND RATTLE TROUBLE DIAGNOSES

Work Flow

Work Flow

NBBT0024



CUSTOMER INTERVIEW

NBBT0024S01

Interview the customer, if possible, to determine the conditions that exist when the noise occurs. Use the Diagnostic Worksheet during the interview to document the facts and conditions when the noise occurs and any customer's comments; refer to BT-8. This information is necessary to duplicate the conditions that exist when the noise occurs.

- The customer may not be able to provide a detailed description or the location of the noise. Attempt to obtain all the facts and conditions that exist when the noise occurs (or does not occur).
- If there is more than one noise in the vehicle, be sure to diagnose and repair the noise that the customer is concerned about. This can be accomplished by test driving the vehicle with the customer.
- After identifying the type of noise, isolate the noise in terms of its characteristics. The noise characteristics are provided so the customer, service adviser and technician are all speaking the same language when defining the noise.
- Squeak — (Like tennis shoes on a clean floor)
Squeak characteristics include the light contact/fast movement/brought on by road conditions/hard surfaces = higher pitch noise/softer surfaces = lower pitch noises/edge to surface = chirping
- Creak — (Like walking on an old wooden floor)
Creak characteristics include firm contact/slow movement/twisting with a rotational movement/pitch dependent on materials/often brought on by activity.
- Rattle — (Like shaking a baby rattle)
Rattle characteristics include the fast repeated contact/vibration or similar movement/loose parts/missing clip or fastener/incorrect clearance.
- Knock — (Like a knock on a door)
Knock characteristics include hollow sounding/sometimes repeating/often brought on by driver action.
- Tick — (Like a clock second hand)
Tick characteristics include gentle contacting of light materials/loose components/can be caused by driver action or road conditions.
- Thump — (Heavy, muffled knock noise)
Thump characteristics include softer knock/dead sound often brought on by activity.
- Buzz — (Like a bumble bee)
Buzz characteristics include high frequency rattle/firm contact.
- Often the degree of acceptable noise level will vary depending upon the person. A noise that you may judge as acceptable may be very irritating to the customer.
- Weather conditions, especially humidity and temperature, may have a great effect on noise level.

DUPLICATE THE NOISE AND TEST DRIVE

NBBT0024S02

If possible, drive the vehicle with the customer until the noise is duplicated. Note any additional information on the Diagnostic Worksheet regarding the conditions or location of the noise. This information can be used to duplicate the same conditions when you confirm the repair.

If the noise can be duplicated easily during the test drive, to help identify the source of the noise, try to duplicate the noise with the vehicle stopped by doing one or all of the following:

- 1) Close a door.
- 2) Tap or push/pull around the area where the noise appears to be coming from.
- 3) Rev the engine.
- 4) Use a floor jack to recreate vehicle "twist".
- 5) At idle, apply engine load (electrical load, half-clutch on M/T model, drive position on A/T model).
- 6) Raise the vehicle on a hoist and hit a tire with a rubber hammer.
- Drive the vehicle and attempt to duplicate the conditions the customer states exist when the noise occurs.
- If it is difficult to duplicate the noise, drive the vehicle slowly on an undulating or rough road to stress the vehicle body.

CHECK RELATED SERVICE BULLETINS

NBBT0024S03

After verifying the customer concern or symptom, check ASIST for Technical Service Bulletins (TSBs) related to that concern or symptom.

If a TSB relates to the symptom, follow the procedure to repair the noise.

LOCATE THE NOISE AND IDENTIFY THE ROOT CAUSE

NBBT0024S04

1. Narrow down the noise to a general area. To help pinpoint the source of the noise, use a listening tool (Chassis Ear: J-39570, Engine Ear: J-39565 and mechanics stethoscope).
2. Narrow down the noise to a more specific area and identify the cause of the noise by:
 - removing the components in the area that you suspect the noise is coming from.
Do not use too much force when removing clips and fasteners, otherwise clips and fastener can be broken or lost during the repair, resulting in the creation of new noise.
 - tapping or pushing/pulling the component that you suspect is causing the noise.
Do not tap or push/pull the component with excessive force, otherwise the noise will be eliminated only temporarily.
 - feeling for a vibration with your hand by touching the component(s) that you suspect is (are) causing the noise.
 - placing a piece of paper between components that you suspect are causing the noise.
 - looking for loose components and contact marks.

Refer to "Generic Squeak and Rattle Troubleshooting", BT-6.

REPAIR THE CAUSE

NBBT0024S05

- If the cause is a loose component, tighten the component securely.
- If the cause is insufficient clearance between components:
 - separate components by repositioning or loosening and retightening the component, if possible.
 - insulate components with a suitable insulator such as urethane pads, foam blocks, felt cloth tape or urethane tape. A Nissan Squeak and Rattle Kit (J-43980) is available through your authorized Nissan Parts Department.

CAUTION:

Do not use excessive force as many components are constructed of plastic and may be damaged. Always check with the Parts Department for the latest parts information.

The following materials are contained in the Nissan Squeak and Rattle Kit (J-43980). Each item can be ordered separately as needed.

URETHANE PADS [1.5 mm (0.059 in) thick]

Insulates connectors, harness, etc.

76268-9E005: 100 x 135 mm (3.94 x 5.31 in)/76884-71L01: 60 x 85 mm (2.36 x 3.35 in)/76884-71L02: 15 x 25 mm (0.59 x 0.98 in)

INSULATOR (Foam blocks)

Insulates components from contact. Can be used to fill space behind a panel.

73982-9E000: 45 mm (1.77 in) thick, 50 x 50 mm (1.97 x 1.97 in)/73982-50Y00: 10 mm (0.39 in) thick, 50 x 50 mm (1.97 x 1.97 in)

INSULATOR (Light foam block)

SQUEAK AND RATTLE TROUBLE DIAGNOSES

Work Flow (Cont'd)

80845-71L00: 30 mm (1.18 in) thick, 30 x 50 mm (1.18 x 1.97 in)

FELT CLOTH TAPE

Used to insulate where movement does not occur. Ideal for instrument panel applications.

68370-4B000: 15 x 25 mm (0.59 x 0.98 in) pad/68239-13E00: 5 mm (0.20 in) wide tape roll

The following materials, not found in the kit, can also be used to repair squeaks and rattles.

UHMW (TEFLON) TAPE

Insulates where slight movement is present. Ideal for instrument panel applications.

SILICONE GREASE

Used in place of UHMW tape that will be visible or not fit.

Note: Will only last a few months.

SILICONE SPRAY

Use when grease cannot be applied.

DUCT TAPE

Use to eliminate movement.

CONFIRM THE REPAIR

Confirm that the cause of a noise is repaired by test driving the vehicle. Operate the vehicle under the same conditions as when the noise originally occurred. Refer to the notes on the Diagnostic Worksheet.

NBBT0024S06

Generic Squeak and Rattle Troubleshooting

NBBT0025

Refer to Table of Contents for specific component removal and installation information.

INSTRUMENT PANEL

Most incidents are caused by contact and movement between:

1. The cluster lid A and instrument panel
2. Acrylic lens and combination meter housing
3. Instrument panel to front pillar garnish
4. Instrument panel to windshield
5. Instrument panel mounting pins
6. Wiring harnesses behind the combination meter
7. A/C defroster duct and duct joint

These incidents can usually be located by tapping or moving the components to duplicate the noise or by pressing on the components while driving to stop the noise. Most of these incidents can be repaired by applying felt cloth tape or silicon spray (in hard to reach areas). Urethane pads can be used to insulate wiring harness.

CAUTION:

Do not use silicone spray to isolate a squeak or rattle. If you saturate the area with silicone, you will not be able to recheck the repair.

CENTER CONSOLE

Components to pay attention to include:

1. Shifter assembly cover to finisher
2. A/C control unit and cluster lid C
3. Wiring harnesses behind audio and A/C control unit

The instrument panel repair and isolation procedures also apply to the center console.

DOORS

Pay attention to the:

1. Finisher and inner panel making a slapping noise
2. Inside handle escutcheon to door finisher
3. Wiring harnesses tapping
4. Door striker out of alignment causing a popping noise on starts and stops

Tapping or moving the components or pressing on them while driving to duplicate the conditions can isolate many of these incidents. You can usually insulate the areas with felt cloth tape or insulator foam blocks from the Nissan Squeak and Rattle Kit (J-43980) to repair the noise.

NBBT0025S02

NBBT0025S03

SQUEAK AND RATTLE TROUBLE DIAGNOSES

Generic Squeak and Rattle Troubleshooting (Cont'd)

TRUNK

=NBBT0025S04

Trunk noises are often caused by a loose jack or loose items put into the trunk by the owner.

In addition look for:

1. Trunk lid bumpers out of adjustment
2. Trunk lid striker out of adjustment
3. The trunk lid torsion bars knocking together
4. A loose license plate or bracket

Most of these incidents can be repaired by adjusting, securing or insulating the item(s) or component(s) causing the noise.

SUNROOF/HEADLINER

NBBT0025S05

Noises in the sunroof/headliner area can often be traced to one of the following:

1. Sunroof lid, rail, linkage or seals making a rattle or light knocking noise
2. Sunvisor shaft shaking in the holder
3. Front or rear windshield touching headliner and squeaking

Again, pressing on the components to stop the noise while duplicating the conditions can isolate most of these incidents. Repairs usually consist of insulating with felt cloth tape.

SEATS

NBBT0025S06

When isolating seat noises it's important to note the position the seat is in and the load placed on the seat when the noise is present. These conditions should be duplicated when verifying and isolating the cause of the noise.

Cause of seat noise include:

1. Headrest rods and holders
2. A squeak between the seat pad cushion and frame
3. The rear seat back lock and bracket

These noises can be isolated by moving or pressing on the suspected components while duplicating the conditions under which the noise occurs. Most of these incidents can be repaired by repositioning the component or applying urethane tape to the contact area.

UNDERHOOD

NBBT0025S07

Some interior noises may be caused by components under the hood or on the engine wall. The noise is then transmitted into the passenger compartment.

Causes of transmitted underhood noises include:

1. Any component mounted to the engine wall
2. Components that pass through the engine wall
3. Engine wall mounts and connectors
4. Loose radiator mounting pins
5. Hood bumpers out of adjustment
6. Hood striker out of adjustment

These noises can be difficult to isolate since they cannot be reached from the interior of the vehicle. The best method is to secure, move or insulate one component at a time and test drive the vehicle. Also, engine RPM or load can be changed to isolate the noise. Repairs can usually be made by moving, adjusting, securing, or insulating the component causing the noise.

GI

MA

EM

LC

EC

FE

AT

TF

PD

AX

SU

BR

ST

RS

BT

HA

SC

EL

IDX

SQUEAK AND RATTLE TROUBLE DIAGNOSES

Diagnostic Worksheet

Diagnostic Worksheet

NBBT0026




SQUEAK & RATTLE DIAGNOSTIC WORKSHEET

Dear Infiniti Customer:

We are concerned about your satisfaction with your Infiniti vehicle. Repairing a squeak or rattle sometimes can be very difficult. To help us fix your Infiniti right the first time, please take a moment to note the area of the vehicle where the squeak or rattle occurs and under what conditions. You may be asked to take a test drive with a service advisor or technician to ensure we confirm the noise you are hearing.

I. WHERE DOES THE NOISE COME FROM? (circle the area of the vehicle)

The illustrations are for reference only, and may not reflect the actual configuration of your vehicle.



Continue to the back of the worksheet and briefly describe the location of the noise or rattle.

In addition, please indicate the conditions which are present when the noise occurs.

SBT860

SQUEAK AND RATTLE TROUBLE DIAGNOSES

Diagnostic Worksheet (Cont'd)

SQUEAK & RATTLE DIAGNOSTIC WORKSHEET- page 2

Briefly describe the location where the noise occurs:

II. WHEN DOES IT OCCUR? (check the boxes that apply)

- | | |
|--|---|
| ☐ anytime | ☐ after sitting out in the sun |
| ☐ 1 st time in the morning | ☐ when it is raining or wet |
| ☐ only when it is cold outside | ☐ dry or dusty conditions |
| ☐ only when it is hot outside | ☐ other: _____ |

III. WHEN DRIVING:

- ☐ through driveways
- ☐ over rough roads
- ☐ over speed bumps
- ☐ only at about ____ mph
- ☐ on acceleration
- ☐ coming to a stop
- ☐ on turns : left, right or either (circle)
- ☐ with passengers or cargo
- ☐ other: _____
- ☐ after driving ____ miles or ____ minutes

IV. WHAT TYPE OF NOISE?

- ☐ squeak (like tennis shoes on a clean floor)
- ☐ creak (like walking on an old wooden floor)
- ☐ rattle (like shaking a baby rattle)
- ☐ knock (like a knock on a door)
- ☐ tick (like a clock second hand)
- ☐ thump (heavy, muffled knock noise)
- ☐ buzz (like a bumble bee)

TO BE COMPLETED BY DEALERSHIP PERSONNEL

Test Drive Notes:

	YES	NO	Initials of person performing
Vehicle test driven with customer	☐	☐	_____
- Noise verified on test drive	☐	☐	_____
- Noise source located and repaired	☐	☐	_____
- Follow up test drive performed to confirm repair	☐	☐	_____

VIN: _____ Customer Name: _____

W.O. #: _____ Date: _____

This form must be attached to Work Order

SBT844

GI
MA
EM
LC
EC
FE
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX










CLIP AND FASTENER

Description

Description











NBBT0003

- Clips and fasteners in BT section correspond to the following numbers and symbols.
- Replace any clips and/or fasteners which are damaged during removal or installation.

Symbol No.	Shapes	Removal & Installation
C101 	 SBF302H	Removal: Remove by bending up with flat-bladed screwdrivers or clip remover.  SBF367BA
C103 	 SBT095	 Removal: Remove with a clip remover. SBF423H
C203 	 SBF258G	 Installation: Push center pin to catching position. (Do not remove center pin by hitting it.) SBF708E
C205 	 MBT080A	Removal: Flat-bladed screwdriver Clip Finisher  SBF638CA
CE103 	 SBF104B	Removal:  SBF147B

CLIP AND FASTENER

Description (Cont'd)

Symbol No.	Shapes	Removal & Installation	
CE117 	 SBF174D	Removal: Remove with a flat-bladed screwdriver or pliers.  SBF175D	GI MA EM LC
CF109 	 SBF651B	Removal:  SBF652B	EC FE AT TF
CG101 	 SBF145B	Removal: Rotate 45° to remove.  Installation:  SBF085B	PD AX SU BR
CR103 	 SBF768B	Removal: Holder portion of clip must be spread out to remove rod.  SBF770B	ST RS BT
CS101 	 SBF078B	Removal: 1. Screw out with a Phillips screwdriver. 2. Remove female portion with flat-bladed screwdriver.  SBF992G	HA SC EL IDX

BODY FRONT END

Removal and Installation

Removal and Installation




NBBT0004

- When removing or installing hood, place a cloth or other padding on front fender panel and cowl top. This prevents vehicle body from being scratched.
- Bumper fascia is made of plastic. Do not use excessive force and be sure to keep oil away from it.
- Hood adjustment: Adjust at hinge portion.
- Hood lock adjustment: After adjusting, check hood lock control operation. Apply a coat of grease to hood locks engaging mechanism.
- Hood opener: Do not attempt to bend cable forcibly. Doing so increases effort required to unlock hood.

FRONT BUMPER ASSEMBLY

NBBT0004S01

1. Remove screws and clips securing left and right sides of front fender protector. **B**
2. Remove clips securing bumper fascia to radiator core support lower. **C**
3. Remove clips securing radiator grille and remove the radiator grille.
4. Remove finisher and bolts securing left and right fog lamps and remove the lamps. **D**
5. Remove bolts securing left and right radiator grille and remove the radiator grilles. **E**
6. Remove bolts securing license plate bracket and remove the license plate bracket. **F**
7. Remove clips securing bumper fascia to bumper reinforcement. **G**
8. Remove bolts securing front fender to bumper fascia. **H**
9. Extract bumper fascia assembly. **I**
10. Remove bolts and nuts securing bumper reinforcement. **J**
11. Extract bumper reinforcement.



: N·m (kg-m, in-lb)

★ : Bumper assembly mounting clips

SBT022A


SEC. 260•261•262•263•620•623•630•650

Hood lock adjustment

- Adjust hood so that hood primary lock meshes at a position 1 to 1.5 mm (0.039 to 0.059 in) lower than fender.
- After hood lock adjustment, adjust bumper rubber.
- When securing hood lock, ensure it does not tilt. Striker must be positioned at the center of hood primary lock.
- After adjustment, ensure that hood primary and secondary lock operate properly.

Hood lock secondary latch hooking length


More than 5.0 mm (0.197 in)



Bumper rubber adjustment

- Adjust so that hood is aligned with fender. At that time deflection is approx. 2 mm (0.08 in).








[Bumper rubber free height is approx. 13 mm (0.51 in)]



GI
MA
EM
LC
EC
FE
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

BODY FRONT END

Removal and Installation (Cont'd)



★ : Bumper assembly mounting clips, bolts and nuts.

SBT024A

Removal and Installation

NBBT0005

- Bumper fascia is made of plastic. Do not use excessive force and be sure to keep oil away from it.
- Back door lock system adjustment: Adjust lock & striker so that they are in the center. After adjustment, check back door lock operation.
- Back door hatch lock system adjustment: Adjust lock & striker so that they are in the center. After adjustment, check back door hatch lock operation.






WARNING:

- Be careful not to scratch back door stay and/or back door hatch stay when installing back door and/or back door hatch. A scratched stay may cause gas leakage.
- The contents of the back door stay and back door hatch stay are under pressure. Do not take apart, puncture, apply heat or allow fire near them.

REAR BUMPER ASSEMBLY

NBBT0005S01

1. Remove bolts and screws securing left and right mudguards and remove the mudguards. **J**
2. Remove clips and screws securing left and right sides of wheel protector. **K**
3. Remove clips and bolts securing left and right rear fenders to bumper fascia. **L**
4. Remove bolts securing bumper reinforcement to bumper fascia. **M**
5. Remove clips securing bumper fascia. **N**
6. Extract bumper fascia assembly. **O**
7. Remove bolts and nuts securing bumper reinforcement. **P**
8. Extract bumper reinforcement.



: N•m (kg-m, in-lb)


: N•m (kg-m, ft-lb)

SBT715

BODY REAR END AND OPENER

Removal and Installation (Cont'd)












SEC. 570•767•850•900•905



SBT716

BODY REAR END AND OPENER

Removal and Installation (Cont'd)



★ : Bumper assembly mounting bolts, nuts and clips

: N•m (kg-m, in-lb)

: N•m (kg-m, ft-lb)

GI

MA

EM

LC

EC

FE

AT

TF

PD

AX

SU

BR

ST

RS

BT

HA

SC

EL

IDX

SBT717

FRONT DOOR


Overhaul

Overhaul


NBBT0006

- For removal of door trim, refer to "DOOR TRIM" (BT-30).
- After adjusting door or door lock, check door lock operation.

SEC. 800•803•805•998




A Bell crank adjustment




Lock door after setting door lock assembly and inside handle in position. Move bell crank in direction of arrow (shown in figure at left) to take up knob free play, and secure with bolts.

B Door-hinge adjustment



Striker adjustment



⊗ : N•m (kg-m, in-lb)
⊙ : N•m (kg-m, ft-lb)

SBT512-B

Front Door Limit Switch Reset


NBBT0027

RESET CONDITIONS

NBBT0027S01

After each of the following operations are performed, reset the limit switch (with built-in motor).

- Regulator removal and installation
- Removal of motor from regulator
- Operation of regulator as a single unit
- Door glass removal and installation
- Glass run removal and installation



RESET PROCEDURES

NBBT0027S02

After installing parts, proceed as follows:

1. Close the door window completely.
2. Press the reset switch and open the door window completely.
3. Release the reset switch. After making sure the reset switch has returned to the original position, close the door window completely.
4. The limit switch is now reset.

CAUTION:

Be sure to manually open or close the door window. (Do not use the automatic open-close procedures.)

GI

MA

EM

LC

EC

FE

AT

TF

PD

AX

SU

BR

ST

RS

BT

HA

SC

EL

IDX


REAR DOOR

Overhaul

Overhaul



NBBT0007

SEC. 820•823•825




A Outside handle adjustment


Turn holder until the clearance between holder & rod is the specified value.



B Door-hinge adjustment



Striker adjustment



: N•m (kg-m, in-lb)

: N•m (kg-m, ft-lb)


SBT736

Removal and Installation

NBBT0008

CAUTION:

- Disconnect both battery cables in advance.
- Disconnect air bag system line in advance.
- Never tamper with or force air bag lid open, as this may adversely affect air bag performance.
- Be careful not to scratch pad and other parts.



*1 RS-17

*2 BT-28

SBT042A

INSTRUMENT PANEL ASSEMBLY

Removal and Installation (Cont'd)



11 Glove box

- Remove clips.

12 Instrument finisher

- Remove screws.

13 Instrument lower panel on passenger side

- Remove screws then disconnect harness connector.
- Then remove passenger air bag module bracket. Refer to "Front Passenger Air Bag Module" for details. (*3)

14 Defroster grille

- Disconnect harness connectors.

15 Instrument mask

- Disconnect harness connectors.

16 Front pillar garnish

- Refer to "SIDE AND FLOOR TRIM" for details. (*2)

17 Instrument panel and pads

- Remove bolts and nuts.
- Then disconnect GPS antenna connector.

18 Passenger air bag module

Refer to "Front Passenger Air Bag Module" for details. (*3)


SBT043A

*2 BT-28

*3 RS-19

Removal and Installation (Cont'd)


GI
MA
EM
LC
EC
FE
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX



BT-23

INSTRUMENT PANEL ASSEMBLY

Removal and Installation (Cont'd)




* : Not installed on some models

SBT039A

INSTRUMENT PANEL ASSEMBLY

Removal and Installation (Cont'd)



Steering column cover


After removing the screws, release the pawls by pressing on the upper cover where it meets (the bottom cover) from both sides.

GI

MA

EM

LC



Instrument lower panel on the driver side


Open the pocket after removing the screws. Hold the opening and the bottom and pull out horizontally.

EC

FE

AT

TF



Cluster lid A

After removing the screws, hold the bottom and pull out.

CAUTION:


Cover the surroundings with a cloth to prevent damage.

PD

AX

SU

BR



Center ventilator

Hook a cloth-covered flat-bladed screwdriver into the right-side groove section, and pull out.

CAUTION:


To prevent the screwdriver from slipping and causing damage to the surface, pull out while applying pressure on the screwdriver towards the right.

ST

RS

BT

HA



Cluster lid C

After removing the screws, place hands on the metal clip section, and pull forward to remove the metal clips.


SC

EL

IDX


INSTRUMENT PANEL ASSEMBLY

Removal and Installation (Cont'd)




Console finisher

- 1) Open the lid of the cup holders, insert a cloth-covered flat-bladed screwdriver into the gap between the console and the finisher, and remove the clip at the back.
- 2) Lift up the metal clip section, and pull forward to remove.




Console box

- 1) Pull up the parking brake lever.
 - 2) Remove the screws, pull the console towards the back of the car until it is free of the instrument panel, lift up the front and remove.
- It will be easier to remove if the parking brake lever is pulled up for more than 10 notches.




Instrument finisher

Remove the screws and pull up.



Instrument lower panel on the passenger side

After removing the screws, hold both sides and pull out horizontally.




Instrument mask

Insert a cloth-covered flat-bladed screwdriver, and remove by lifting up.

INSTRUMENT PANEL ASSEMBLY

Removal and Installation (Cont'd)



Defroster grille

REMOVAL


Insert a cloth-covered flat-bladed screwdriver into the grilles of the outside, center and central grilles, respectively, lift up the front of the grilles and remove.

INSTALLATION

After inserting the front section, insert the rear section (pawls) to attach.


CAUTION:

Confirm that the pawls at the rear are securely attached.



Side ventilator-left

Insert a cloth-covered flat-bladed screwdriver into the lower section, and pull out forward.



Side ventilator-right

Insert a cloth-covered flat-bladed screwdriver into the corner of the lower section, and pull out forward. (Securely press the screwdriver against the ventilator.) Or, after removing the instrument lower panel, push the ventilator out from the back.

Side defroster grille

After removing the side ventilator, reach in with hands from the opening, push on the pawls from behind the grille, and remove by pushing out.

GI
MA
EM
LC
EC
FE
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

SIDE AND FLOOR TRIM

Removal and Installation

Removal and Installation


NBBT0009

CAUTION:






Wrap the tip of flat-bladed screwdriver with a cloth when removing metal clips from garnishes.

1. Remove front and rear seats. Refer to "FRONT SEAT" and "REAR SEAT" for details, BT-41, BT-44.
2. Remove front and rear seat belts. Refer to RS-4 and RS-5, "Front Seat Belt" and "Rear Seat Belt" for details.
3. Remove front and rear kicking plates.
4. Remove dash side lower finishers.
5. Remove front and rear body side welts.
6. Remove front pillar garnishes. **B**
7. Remove center assist grips.
8. Remove center pillar lower garnishes. **C**
9. Remove center pillar upper garnishes. **C**
10. Remove rear gate kicking plate.
11. Remove rear net hooks.
12. Remove tonneau cover assembly and rear parcel holder.
13. Remove rear side lower garnishes. **E**
14. Remove rear side upper garnishes. **D**

SEC. 678•738•769•799•849



SBT694



GI

MA

EM

LC

EC

FE

AT

TF

PD

AX

SU

BR

ST

RS

BT

HA

SC

EL

IDX

DOOR TRIM

Removal and Installation

Removal and Installation

NBBT0010


Front Door Trim

1. Remove inside handle escutcheon. **A**
2. Remove power window switch, then disconnect the connectors. **B**
3. Remove door armrest. **C**
4. Remove bolts securing door finisher.
5. Pull on door finisher to remove clips from door panel and remove door finisher, then disconnect glass hatch and fuel lid opener switch connector.

Rear Door Trim

6. Remove inside handle escutcheon. **A**
7. Remove power window switch, then disconnect the connector. **D**
8. Remove door armrest cap. **E**
9. Remove bolts securing door finisher.
10. Pull on door finisher to remove clips from door panel and remove door finisher.






SEC. 251•809•828



SBT696

DOOR TRIM

Removal and Installation (Cont'd)



GI

MA

EM

LC

EC

FE

AT

TF

PD

AX

SU

BR

ST

RS

BT

HA

SC

EL

IDX

SBT697

ROOF TRIM

Removal and Installation

Removal and Installation




NBBT0011

1. Remove front and rear seats. Refer to "FRONT SEAT" and "REAR SEAT" for details, BT-41, BT-44.
2. Remove front and rear seat belts. Refer to RS-4 and RS-5, "Front Seat Belt" and "Rear Seat Belt" for details.
3. Remove body side trim. Refer to "SIDE AND FLOOR TRIM" for details, BT-28.
4. Remove roof console assembly. **A**
5. Remove inside mirror assembly.
6. Remove sun visors.
7. Remove interior lamp assembly and luggage room lamp assembly.
8. Remove assist grips.
9. Remove clips securing headlining.
10. Remove rear roof garnish. **B**
11. Remove headlining from vehicle through either back door.

ROOF TRIM

Removal and Installation (Cont'd)

SEC. 264•738•963•964•970



SBT487

GI
MA
EM
LC
EC
FE
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

BACK DOOR TRIM


Removal and Installation

Removal and Installation

NBBT0012

1. Remove back door grip.
2. Remove back door finisher assembly.
3. Remove high-mounted stop lamp.
4. Remove back door upper finisher assembly.


SEC. 268•909



SBT223


Removal and Installation

NBBT0013




① ② Hood front seal

SEC. 650



③ ④ Cowl top seal and cowl top grille

SEC. 660



⑤ Windshield side molding

Mounted with screws.

SBT494



EXTERIOR

Removal and Installation (Cont'd)

⑥ Windshield upper molding

SEC. 720


1. Cut off adhesive at glass end.
2. Remove old adhesive from panel surface.
3. Set molding fastener and apply primer to body panel, and apply adhesive to body.



4. Install molding by aligning the molding mark located on center with vehicle center. Be sure to install tightly so that there is no gap around the corner.


⑧ Drip weatherstrip

SEC. 767




⑨ Body side welt

SEC. 769




⑦ Sunroof lid weatherstrip

SEC. 736



⑩ Door weatherstrip


SEC. 800-820




SBT722

⑪ Door outside molding

Front door
SEC. 800




Rear door
SEC. 820





⑫ Back door weatherstrip

SEC. 900




⑬ Side guard molding

SEC. 766




■ : Double-faced adhesive tape
○ : Clip C101



• With a vehicle coated with Hard Clear Coat, use double-faced 3M adhesive tape Product No. 4210 or equivalent, after priming with 3M primer Product No. N-200 or C-100 or equivalent.

⑭ Back door window weatherstrip

SEC. 900




SBT495


EXTERIOR

Removal and Installation (Cont'd)

⑮ Air outlet grille




⑯ High-mounted stop lamp



⑰ Back door deflector


- When installing, make sure that there are not gaps or waves at ends of deflector.
- Before installing deflector, clean and remove oil from surface where deflector will be mounted.




SBT491

Removal and Installation (Cont'd)

SEC. 730



SEC. 767



BT-39

EXTERIOR

Removal and Installation (Cont'd)

⑳ Rear side window molding



Refer to the applicable sections on the preceding pages.

㉑ Rear combination lamp

Rear combination lamps are installed with nuts.


㉒ Over fender

SEC. 630-780



㉓ License plate finisher

SEC. 900



SBT028A

Removal and Installation



NBBT0014

- When removing or installing the seat trim, carefully handle it to keep dirt out and avoid damage.

★ For Wiring Diagram, refer to EL-181, "POWER SEAT" for details.

CAUTION:

- Before removing the front seat, turn the ignition switch off, disconnect both battery cables and wait at least 3 minutes.
- When checking the power seat circuit for continuity using a circuit tester, do not confuse its connector with the side air bag module connector. Such an error may cause the air bag to deploy.
- Do not drop, tilt, or bump the side air bag module installed in the seat. Always handle it with care.



GI

MA

EM

LC

EC

FE

AT

TF

PD

AX

SU

BR

ST

RS

BT

HA

SC


EL

IDX

FRONT SEAT

Removal and Installation (Cont'd)

SEC. 870



SBT019A

HEATED SEAT

=NBBT0014S03

- When handling seat, be extremely careful not to scratch heating unit.
 - To replace heating unit, seat trim and pad should be separated.
 - Do not use any organic solvent, such as thinner, benzene, alcohol, gasoline, etc. to clean trims.
- ★ For Wiring Diagram, refer to EL-183, “HEATED SEAT” for details.

GI

MA

EM

LC

EC

FE

AT

TF

PD

AX

SU

BR

ST

RS

BT

HA

SC

EL

IDX




REAR SEAT

Removal and Installation

Removal and Installation

NBBT0015

SEC. 870



: N•m (kg-m, in-lb)
 : N•m (kg-m, ft-lb)


SBT190-A

Adjustment

NBBT0016

Install motor & limit SW assembly and sunroof rail assembly in the following sequence:

1. Arrange equal lengths of link and wire assemblies on both sides of sunroof opening.
2. Connect sunroof connector to sunroof switch and positive (+) power supply.
3. Set lid assembly to fully closed position **A** by operating OPEN switch and TILT switch.
4. Fit outer side of lid assembly to the surface of roof on body outer panel.
5. Remove motor, and keep OPEN switch pressed until motor pinion gear reaches the end of its rotating range.
6. Install motor.
7. Check that motor drive gear fits properly in wires.
8. Press TILT-UP switch to check lid assembly for normal tilting.
9. Check sunroof lid assembly for normal operations (tilt-up, tilt-down, open, and close).



SBF920F

Removal and Installation

NBBT0017

- After any adjustment, check sunroof operation and lid alignment.
- Handle finisher plate and glass lid with care so not to cause damage.
- It is desirable for easy installation to mark each point before removal.

CAUTION:

- Always work with a helper.
- Before removal, fully close the glass lid assembly, then after removal, do not move motor assembly.

SUNROOF

Removal and Installation (Cont'd)

Link and wire assembly	Sunroof frame assembly	Shade assembly	Lid assembly	Motor assembly
Tilt glass lid up.				
1 Side trim • Remove side trim clips.				
2 Sunroof lid mount nuts				
3 Lid assembly				
4 Rear drain mount screws				
5 Rear drain assembly				
Operate sunroof switch to tilt glass lid down.				
6 Shade assembly				
Sunroof switch/interior accessories/headlining • Refer to "ROOF TRIM" for details, *1.				
7 Sunroof switch bracket				
8 Motor assembly				
9 Wind deflector holder				
10 Wind deflector mount screw				
11 Wind deflector assembly				
12 Drain hoses				
13 Sunroof unit bracket				
14 Sunroof frame assembly				
15 Guide stopper				
16 Rear guide				
17 Link and wire assembly				

A

B1-B3


★ For Wiring Diagram, refer to (*2) "POWER SUNROOF" for details.

SBT515-C

*1 BT-32

*2 EL-174


SEC. 736




MBF462BG

SUNROOF


Removal and Installation (Cont'd)




A Using flat-bladed screwdriver, pry shade assembly holder off rail. Then pull shade assembly forward to remove it from rail.



B1 Disengage pawls from rail, then remove wind deflector holder.



B2 Using flat-bladed screwdriver, pry stopper spring off rail groove. Then slide rear guide backward to remove it from rail.



B3 Remove wire and link assembly from rail while pushing link back with flat-bladed screwdriver.

Trouble Diagnoses

DIAGNOSTIC TABLE

=NBBT0018


NBBT0018S01

NOTE:

For diagnosing electric problem, refer to EL-174 "POWER SUN-ROOF" for details.

		Check items (Components)				
		Wind deflector	Adjustment	Drain hoses	Weatherstrip	Link and wire assembly
	Reference page	BT-49	BT-50	BT-51	BT-51	BT-52
Symptom	Excessive wind noise	1	2		3	
	Water leaks		1	2	3	
	Sunroof rattles		1	4	2	3
	Excessive operation noise		1		2	3


The numbers in this table mean checking order.



WIND DEFLECTOR

NBBT0018S02

1. Open lid.
2. Check visually for proper installation.
3. Check to ensure a proper amount of petroleum jelly has been applied to wind deflector connection points; apply if necessary.
4. Check that wind deflector is properly retracted by hand. If it is not, remove and visually check condition. (Refer to removal procedures, BT-45.) If wind deflector is damaged, replace with new one. If wind deflector is not damaged, re-install properly.




SUNROOF

Trouble Diagnoses (Cont'd)

ADJUSTMENT

NBBT0018S03

SEC. 736



If any gap or height difference between glass lid and roof is found, check glass lid fit and adjust as follows:

Gap Adjustment

NBBT0018S0301

1. Open shade assembly.
2. Tilt glass lid up then remove side trim.
3. Loosen glass lid securing nuts (3 each on left and right sides), then tilt glass lid down.
4. Adjust glass lid from outside of vehicle so it resembles "A-A" as shown in the figure above.
5. Tilt glass lid up and down until it is adjusted to "B-B" as shown in the figure above.
6. After adjusting glass lid, tilt glass lid up and tighten nuts.
7. Tilt glass lid up and down several times to check that it moves smoothly.


Height Difference Adjustment

NBBT0018S0302


1. Tilt glass lid up and down.
2. Check height difference between roof panel and glass lid to see if it is as "A-A" as shown in the figure above.
3. If necessary, adjust it by using one of following procedures.
 - Adjust by adding or removing adjustment shim(s) between glass lid and link assembly.
 - If glass lid protrudes above roof panel, add shim(s) or plain washer(s) at sunroof mounting bracket or stud bolt locations to adjust sunroof installation as required.

DRAIN HOSES


NBBT0018S04



SBT376



SBT333



SBT377

1. Remove headlining to access drain hose connections. (Refer to "Removal and Installation" in "ROOF TRIM", BT-32, for detail.)
2. Check visually for proper connections, damage or deterioration. **A** (The figure shows only the front side.)
3. If leakage occurs around luggage room, remove luggage room side trim and check connecting area. Check for proper connection, damage or tear. **B**
4. Remove drain hoses and check visually for any damage, cracks, or deterioration.
5. Pour water into drain hoses and find damaged portion.
 - If any damaged portion is found at each step, replace the damaged part.

WEATHERSTRIP

NBBT0018S05

- In the case of leakage around glass lid, close glass lid and pour water over glass lid to find damaged or gap portion.
1. Remove glass lid assembly. (Refer to removal procedures, BT-45, for details.)
 2. Visually check weatherstrip for proper installation. If a gap exists between glass lid and weatherstrip, check for sufficient amount of butyl seal. If required, remove weatherstrip and apply butyl seal. Refer to "EXTERIOR" (BT-35), for details.

3. Check weatherstrip visually for any damage, deterioration, or flattening.
 - If any damage is found, replace weatherstrip.

CAUTION:

Do not remove weatherstrip except when replacing, or filling up butyl seal.




LINK AND WIRE ASSEMBLY

NBBT0018S06

NOTE:

Before replacing a suspect part, carefully ensure it is the source of noise being experienced.

1. Check link to determine if coating film has peeled off to such an extent that substrate is visible. Check also to determine if link is the source of noise. If it is, replace it.
2. Visually check to determine if a sufficient amount of petroleum jelly has been applied to wire or rail groove. If not, add petroleum jelly as required.
3. Check wire for any damage or deterioration. If any damage is found, remove rear guide (refer to removal procedures, BT-45 for details), then replace wire.



Removal and Installation

NBBT0019

REMOVAL

NBBT0019S01

After removing moldings, remove glass using piano wire or power cutting tool and an inflatable pump bag.

WARNING:

When cutting the glass from the vehicle, always wear safety glasses and heavy gloves to help prevent glass splinters from entering your eyes or cutting your hands.

CAUTION:

- Be careful not to scratch the glass when removing.
- Do not set or stand the glass on its edge. Small chips may develop into cracks.

INSTALLATION

NBBT0019S02

- Use a genuine Nissan Urethane Adhesive Kit or equivalent and follow the instructions furnished with it.
- While the urethane adhesive is curing, open a door window. This will prevent the glass from being forced out by passenger compartment air pressure when a door is closed.
- The molding must be installed securely so that it is in position and leaves no gap.
- Inform the customer that the vehicle should remain stationary until the urethane adhesive has completely cured (preferably 24 hours). Curing time varies with temperature and humidity.

WARNING:

- Keep heat and open flames away as primers and adhesive are flammable.
- The materials contained in the kit are harmful if swallowed, and may irritate skin and eyes. Avoid contact with the skin and eyes.
- Use in an open, well ventilated location. Avoid breathing the vapors. They can be harmful if inhaled. If affected by vapor inhalation, immediately move to an area with fresh air.
- Driving the vehicle before the urethane adhesive has completely cured may affect the performance of the windshield in case of an accident.

CAUTION:





- Do not use an adhesive which is past its usable term. Shelf life of this product is limited to six months after the date of manufacture. Carefully adhere to the expiration or manufacture date printed on the box.
- Keep primers and adhesive in a cool, dry place. Ideally, they should be stored in a refrigerator.
- Do not leave primers or adhesive cartridge unattended with their caps open or off.
- The vehicle should not be driven for at least 24 hours or until the urethane adhesive has completely cured. Curing time varies depending on temperature and humidities. The curing time will increase under higher temperatures and lower humidities.

WINDSHIELD AND WINDOWS

Removal and Installation (Cont'd)

WINDSHIELD

NBBT0019S03

Body side Install spacer to panel. 	Glass side Install open cell foam dam. 
Install molding fastener. When installing it, heat body panel and fastener to approx. 30 to 40°C (86 to 104°F). 	Apply urethane adhesive evenly. Windshield  Unit: mm (in)

SBT191-A

Repairing Water Leaks for Windshield

NBBT0019S0301





Leaks can be repaired without removing and reinstalling glass.
If water is leaking between the urethane adhesive material and body or glass, determine the extent of leakage. This can be done by applying water to the windshield area while pushing glass outward.

To stop the leak, apply primer (if necessary) and then urethane adhesive to the leak point.

REAR SIDE WINDOW

NBBT0019S04

SEC. 830



GI

MA

EM

LC

EC

FE

AT

TF

PD

AX

SU

BR

ST

RS

BT

HA

SC

EL

IDX

DOOR MIRROR

Removal and Installation

Removal and Installation

NBBT0020


CAUTION:

Be careful not to scratch door rearview mirror body.

★ For Wiring Diagram, refer to EL-177, "DOOR MIRROR" for details.

1. Remove door trim. Refer to "DOOR TRIM" for details, BT-30.
2. Remove clip securing inner cover from front corner of door.
3. Disconnect door mirror harness connector.
4. Remove bolts securing door mirror, then remove door mirror assembly.


SEC. 963



Alignment

NBBT0021

- All dimensions indicated in figures are actual ones.
- When using a tracking gauge, adjust both pointers to equal length. Then check the pointers and gauge itself to make sure there is no free play.
- When a measuring tape is used, check to be sure there is no elongation, twisting or bending.
- Measurements should be taken at the center of the mounting holes.
- An asterisk (★) following the value at the measuring point indicates that the measuring point on the other side is symmetrically the same value.
- The coordinates of the measurement points are the distances measured from the standard line of "X", "Y" and "Z".



SBF874GD

GI
MA
EM
LC
EC
FE
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX


BODY (ALIGNMENT)

Alignment (Cont'd)

ENGINE COMPARTMENT Measurement

NBBT0021S01

NBBT0021S0101











Unit: mm

SBT194

Measurement Points

NBBT0021S0102

Unit: mm



GI

MA

EM

LC

EC

FE

AT

TF

PD

AX

SU

BR

ST

RS

BT

HA

SC


EL

IDX

UNDERBODY Measurement

NBBT0021S02

NBBT0021S0201




BODY (ALIGNMENT)

Alignment (Cont'd)

NBBT0021S0202

Measurement Points



Front
coordinates:

(A, a)
X: 266
Y: -580.4
Z: 191.4

(B, b)
X: 403
Y: -500
Z: 297.7

(C, c)
X: 396
Y: -201
Z: 279.7

(D, d)
X: 396
Y: 228
Z: 156.7

(E, e)
X: 524
Y: 568
Z: 112.7

(F, f)
X: 489
Y: 637
Z: 114.1

Rear
coordinates:

(G, g)
X: 565
Y: 1,630
Z: 115

(H, h)
X: 476.9
Y: 2,392.6
Z: 321.9

(K, k)
X: 513.3
Y: 2,434.5
Z: 301.4

(M)
X: 446.1
Y: 2,960.2
Z: 190

(m)
X: 350
Y: 2,878
Z: 424.8

(N, n)
X: 430
Y: 3,100
Z: 426.2

(P)
X: 290
Y: 3,230
Z: 394.1

(P)
X: 142
Y: 3,230
Z: 383.6


(Q, q)
X: 430
Y: 3,419.3
Z: 353.6

(R, r)
X: 277
Y: 3,570
Z: 435.6

Unit: mm

Front strut tower center coordinates:

(S, s)
X: 499.9
Y: 41.2
Z: 748.9



GI
MA
EM
LC
EC
FE
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

SBT361

NOTES