

SERVICE MANUAL

DATSUN 280Z
MODEL S30 SERIES



NISSAN MOTOR CO., LTD.
TOKYO, JAPAN

SECTION BE

BODY ELECTRICAL SYSTEM

BODY ELECTRICAL WIRING.....	BE- 2
LIGHTING AND SIGNAL.....	BE- 7
LAMP SYSTEM	
METERS AND GAUGES	BE-29
ELECTRICAL ACCESSORY.....	BE-45
EMISSION WARNING SYSTEM	BE-94

BE

BODY ELECTRICAL WIRING

CONTENTS

DESCRIPTION	BE-2	MAINTENANCE	
WIRING HARNESS	BE 2	FUSE BLOCK AND FUSIBLE LINK	
COLORS OF CABLES	BE-2	DESCRIPTION	
WIRING	BE-3	MAINTENANCE INSTRUCTIONS	
INSPECTION	BE-5	RELAY BRACKET	

DESCRIPTION

Cables used for body electrical wiring are low tension cables. They are covered with color-coded vinyl for easy identification. Each system (e.g. ignition, lighting, or signal system) has its own distinctive color. This facilitates trouble-shooting. In the wiring diagram, the colors are indicated by one or two alphabetical letters. Basic colors include standard and supplementary ones.

The entire wiring system consists of several harnesses connected one to another by means of connectors.

These include the engine room harness, engine room sub-harness, instrument harness, dash harness, console harness, electronic fuel injection harness, electronic fuel injection sub-harness, and battery cable.

It is recommended that the battery be disconnected before performing any electrical service other than bulb, or fuse replacement. To protect the electrical devices, fuses are installed in the middle of circuit.

In addition to fuses, some fusible links are installed to protect wiring. Fusible links function almost the same as fuses, though they are slightly different in their characteristics.

Refer to Section EE for engine harness and Section EF for electronic fuel injection harness.

WIRING HARNESS

COLORS OF CABLES

The system of colors used in the covering of cable conductors are as




Fig. BE-1 Wiring harness

Circuit system	Standard color	Supplementary color	Supplementary color Standard
Starting and ignition system	B (Black)	W, Y, R	
Charging system	W (White)	B, R, L	Y
Lighting system	R (Red)	W, B, G, Y, L	
Signal system	G (Green)	W, B, R, Y, L	W, Br (B)
Instrument system	Y (Yellow)	W, B, G, R, L	
Others	L (Blue) Lg (Light green)	W, R, Y	Y Br lg (Light green)
	B		

The main cable of each system is generally coded with a standard or supplementary color. These colors are represented by such letters as G, W, and B. Minor items of each circuit's terminal are coded with a two-tone color composed of both standard and supplementary colors. These colors are represented by a combination of two letters like RW or GY. The first letter of each combination stands for standard color, and the second for supplementary color.




Fig. BE-3 Engine room harness




Fig. BE-5 Instrument harness

WIRING

Engine room harness

Engine room harness is connected to instrument harness with one connector and dash harness with four connectors at junction block under right side of instrument panel.

It has three branches. One branch runs along right side of engine room, servicing starting motor, fuel pump relay, fuel pump control relay, inhibitor relay, fusible link, alternator, headlamp, combination lamp, horn, etc., and transverses engine room under radiator, servicing headlamp, horn, combination lamp, etc. and is connected to distributor, ignition coil, B.C.D.D. solenoid, thermal transmitter, etc. on left side of engine room.

Another branch runs along rear end of engine room to inspection lamp, servicing wiper motor, washer motor, brake fluid level switch, etc.




Fig. BE-2 Engine room harness

The other branch runs along transmission housing to back-up lamp switch (Manual transmission models) and inhibitor switch (Automatic transmission models).

On automatic transmission models, this also services downshift solenoid via engine sub-harness.




Fig. BE-4 Engine sub-harness (A/T models)

Instrument harness

Instrument harness is connected to engine room harness and dash harness with three connectors at junction block under right side of instrument panel.

Two connectors for dash harness are white and black. Connector for engine room harness is blue.

This harness traverses to left side of passenger compartment behind instrument panel and services glove box lamp, map lamp, fuel level warning lamp, clock, volt and fuel gauge, water temperature and oil pressure gauge, floor temperature warning lamp (California models), cigarette lighter, tachometer, speedometer, warning buzzer, and illumination control rheostat.

Dash harness

Dash harness is connected to engine room harness and instrument harness with six connectors at junction block under right side of instrument panel. Two connectors (white and black) for instrument harness and four (white, green and black) for engine room harness.

This harness has four main branches. One goes to relay bracket and seat belt warning timer unit, horn relay, intermittent wiper amplifier, defogger relay and ignition relay, and goes to right-hand side door switch.

One goes to left side of car along dash panel and services console harness, air conditioner harness, turn signal flasher unit, kickdown switch, stop lamp switch, steering lock switch, combination switch, ignition switch, electronic fuel injection harness, hazard flasher unit, and left-hand side door switch.

The other goes along right side of car backward and has four branches. One services driver's seat belt switch, floor sensor relay, brake warning lamp check relay, parking brake switch.


One services radio speaker, rear window defogger, room lamp and tailgate switch.

One services fuel pump.

The other services fuel tank gauge unit.

Main line goes around rear right side corner and goes along rear panel servicing side marker lamp, combination lamp, floor temperature sensor (California models) and license lamp, and goes around the other rear corner of car and services auto antenna.


Body Electrical System



- | | |
|-----------------------|----------------------------|
| 1 E.F.I. control unit | 5 Transistor ignition unit |
| 2 Engine room harness | 6 Fuse block |
| 3 Junction block | |
| 4 Relay bracket | |


BE420C

Fig. BE-6 Dash harness



BE421C

Fig. BE-7 Dash harness (2 seater)



BE422C

Fig. BE-8 Dash harness (2 + 2 seater)

Console harness

Console harness is connected to dash harness with a pair of connectors. It is connected to engine room harness, transmission indicator

switch, radio, rear defogger switch and lamp, seat belt warning lamp and hazard switch.




Fig. BE-9 Console harness


Electronic fuel injection harness and electronic injection sub-harness

The electronic fuel injection harness is connected to electronic injection system components. It is connected to the positive terminal through a fusible link on the right side of the engine compartment.

It is connected to the relay in the relay bracket on the right side of the engine compartment.

It is connected to the cold start valve under the left side of the engine compartment instrument panel.

It is connected to the altitude switch in the passenger compartment, and to the throttle valve switch, air filter, cold start valve, air regulator, earth point and injectors on the left side of the engine compartment. The electronic injection sub-harness is connected to the electronic fuel injection harness on the left front side of the engine compartment. See Section 4 for details.



BE423C

- | |
|--------------------------------|
| 1 Engine room harness |
| 2 Electronic injection harness |

INSPECTION

Inspect all electrical circuits, referring to wiring or circuit diagrams. Circuits should be tested for continuous or short circuit with a conventional test lamp or low reading voltmeter. Before inspection of circuit, insure the following items.

1. Each electrical component part or cable is securely fastened to its connector or terminal.
2. Each connection is tight in place and free from rust and dirt.
3. Each cable covering shows no evidence of cracks, deterioration or other damage.
4. Each terminal is kept away from any adjacent metal parts.
5. Each cable is fastened to its proper connector or terminal.
6. Each grounding bolt is planted tight.
7. Wiring is kept away from any adjacent sharp edges of parts or parts having high temperature (such as exhaust pipe).
8. Wiring is kept away from any rotating or working parts such as fan pulley, fan belt, etc.
9. Cables between fixed portions and moving equipment are long enough to withstand shocks and vibratory forces.

MAINTENANCE

Wire harness must be replaced if insulation becomes burned, cracked, or deteriorated. Whenever it is necessary to splice or repair a wire, be sure to use resin flux solder or electrical connections. And use insulating tape to cover all splices or bare wire. In replacing wire, correct size wire must be used. Never replace a wire with smaller one. Each harness and wire must be held securely in place with clips or other holding devices to avoid chafing or wearing away insulation due to vibration.

Note:

- a. Before starting to inspect and repair any part of electrical system or other parts which may lead to a short circuit, disconnect cables at battery terminals as follows:

Disconnect cable at negative (-) terminal, and then disconnect cable at positive (+) terminal. Before connecting cables to battery terminals, be sure to clean terminals with a rag. Fasten cable at positive (+) terminal, and then ground cable at negative (-) terminal. Apply grease to the top of these terminals to prevent rust from developing on them.

- b. Never use a screwdriver or service tool to conduct a continuity test. Use test leads to conduct this check.
- c. Never ground an open circuit or circuits under no load. Use a test lamp (12V-3W) or circuit tester as a load.

FUSE BLOCK AND FUSIBLE LINK

DESCRIPTION

The fuse and fusible link are protective devices used in an electric

circuit. When current increases beyond rated amperage, fusible metal melts and the circuit is broken, thus protecting cable and electrical equipment from burning. Whenever a fuse is melted for one reason or another, use a systematic procedure to check and eliminate cause of problem before installing new fuse.

MAINTENANCE INSTRUCTIONS

Fuse

In nearly all cases, visual inspection can reveal a faulty fuse. If condition of fuse is questionable, conduct a continuity test with a circuit tester or test lamp.

Note:

- a. If fuse is blown, be sure to eliminate the cause before installing new fuse in position.
- b. Use fuse of specified rating. Do not use fuse of more than specified rating. See the following figure.

LIGHT (R) LUZ DER	10 A	HEAD LAMP		15 A	PARK, TAIL, ESTAC TRASE
LIGHT (L) LUZ IZO	10 A			10 A	DOVE LAMP LUZ INSTRU
FLASHER LUZ INTERM	10 A			10 A	GILIGHTER ENCEN DEDOR
FUEL GAUGE CALIBRADOR	10 A	IGN.	BATT.	15 A	HORN STOP BOCINA LUZ PARADA
AIR CON AIRE ACON	20 A	ACC.		10 A	HAZARD
WIPER LIMPIADOR	15 A			20 A	DEFOGGER
RADIO	10 A			1 A	FLOORTEMP LAMP


USE SPECIFIED FUSES ONLY.

USE UNICAMENTE LOS FUSIBLES ESPECIFICADOS.

USE SPECIFIED FUSES ONLY.
USE ÚNICAMENTE LOS FUSIBLES ESPECIFICADOS.

BE424C

- 1 Dash harness
- 2 Engine room harness
- 3 Resistor for tachometer
- 4 Dash harness
- 5 Transistor ignition unit



BE438B

- 6 Fuse block
- 7 Timer unit
- 8 Relay bracket
- 9 Instrument harness

Fig. BE-11 Fuse block

- c. Check fuse holders for condition. If rust or dirt is found thereon, clean metal parts with fine-grained sandpaper until proper metal-to-metal contact is made.

Poor contact of any fuse holder will often lead to voltage drop or heating in the circuit and could result in improper operation of circuit.

Body Electrical System

Fusible link


Color	Size mm ² (sq in)
Black	1.25 (0.0019)
Green	0.5 (0.0008)
Brown	0.3 (0.0005)

The fusible link holder is mounted on the relay bracket in the engine compartment, a fusible link for electronic fuel injection system is connected between battery cable (+) and fuel injection harness.

A melted fusible link can be detected by either visual or finger-tip inspection. If its condition is questionable, use circuit tester or test lamp, as required, to conduct continuity test. This continuity test can be performed in the same manner as for any conventional fuse.

CAUTION:

- If fusible link should melt, it is possible that critical circuit (power supply or large current carrying circuit) is shorted. In such a case, carefully check and eliminate cause of problem.
- Never wrap periphery of fusible link with vinyl tape. Extreme care should be taken with this link to ensure that it does not come into contact with any other wiring harness or vinyl or rubber parts.



- Relay bracket
- Fusible link
- Fusible link holder
- Fusible link for electronic fuel injection system
- Relay bracket


RELAY BRACKET

The relay bracket is so installed that a number of relays can be located in the same place for easy maintenance.

There are two relay brackets. One is installed on the hoodedge on the right side of the engine compartment, and the other on the dash side panel.

The following parts are attached to the relay brackets:

- Engine compartment
 - Fuel pump control relay
 - Fuel pump relay
 - Electronic Fuel Injection main relay
 - Air conditioner relay
 - Inhibitor relay




- Fuel pump control relay
- Fuel pump relay
- Electronic fuel injection main relay
- Air conditioner relay
- Inhibitor relay

Fig. BE-13 Relay bracket

- Inside passenger compartment


- Intermittent wiper amplifier
- Rear defogger relay
- Ignition relay
- Horn relay
- Seat belt warning timer unit



- Dash harness
- Engine room harness
- Resistor for tachometer
- Dash harness
- Transistor ignition
- Fuse block
- Timer unit
- Relay bracket
- Instrument harness

BE438B

Fig. BE-14 R



BE439B

Fig. BE-15 R

LIGHTING AND SIGNAL LAMP SYSTEM

CONTENTS

DESCRIPTION	BE- 7	INSPECTION LAMP	BE-23
BULB SPECIFICATIONS	BE 8	REMOVAL AND INSTALLATION	BE-23
CIRCUIT DIAGRAM OF LIGHTING SYSTEM	BE 9	BULB REPLACEMENT	BE-24
HEADLAMP	BE-19	INSPECTION	BE-24
AIMING ADJUSTMENT	BE-19	COMBINATION SWITCH	BE-24
HEADLAMP BEAM REPLACEMENT	BE-19	REMOVAL AND INSTALLATION	BE-24
FRONT COMBINATION LAMP	BE-20	INSPECTION	BE-24
BULB REPLACEMENT	BE-20	DOOR SWITCH	BE-25
LAMP BODY REPLACEMENT	BE-20	REMOVAL AND INSTALLATION	BE-25
SIDE MARKER LAMP	BE-20	INSPECTION	BE-25
BULB REPLACEMENT	BE-20	STOP LAMP SWITCH	BE-25
LAMP BODY REPLACEMENT	BE-20	REMOVAL AND INSTALLATION	BE-25
INTERIOR LAMP	BE-21	INSPECTION	BE-25
BULB REPLACEMENT	BE-21	BACK UP LAMP SWITCH	BE-25
LAMP BODY REPLACEMENT	BE-21	REPLACEMENT	BE-25
REAR COMBINATION LAMP	BE-21	INSPECTION	BE-25
BULB REPLACEMENT	BE-21	HAZARD SWITCH	BE-26
LAMP BODY REPLACEMENT	BE-21	REMOVAL AND INSTALLATION	BE-26
LICENSE LAMP	BE-21	BULB REPLACEMENT	BE-26
BULB REPLACEMENT	BE-21	INSPECTION	BE-26
LAMP BODY REPLACEMENT	BE-22	IGNITION AND STARTING SWITCH	BE-26
MAP LAMP	BE-22	REPLACEMENT	BE-26
BULB REPLACEMENT	BE-22	INSPECTION	BE-26
LAMP BODY REPLACEMENT	BE-22	RHEOSTAT (FOR ILLUMINATION CONTROL)	BE-27
GLOVE BOX LAMP	BE-23	REMOVAL AND INSTALLATION	BE-27
BULB REPLACEMENT	BE-23	INSPECTION	BE-27
LAMP BODY REPLACEMENT	BE-23	FLASHER UNIT REPLACEMENT	BE-27
INSPECTION	BE-23	TROUBLE DIAGNOSES AND CORRECTIONS	BE-28
AUTOMATIC TRANSMISSION INDICATOR ILLUMINATION LAMP	BE-23	HEADLAMP	BE-28
BULB REPLACEMENT	BE-23	TURN SIGNAL LAMP	BE-28
ASHTRAY ILLUMINATION LAMP	BE-23	TAIL LAMP, STOP LAMP AND BACK UP LAMP	BE-29
REMOVAL AND INSTALLATION	BE-23		
INDICATOR LAMPS	BE-23		

DESCRIPTION

Lighting and signal lamp system includes headlamps, front combination lamps, side marker lamps, rear combination lamps, license lamps, interior lamp, map lamp and some illumination

lamps.

They are controlled by combination switch, flasher unit, hazard unit, hazard switch and resistor

Each lighting system is not com-

pletely independent; Consequently, there are some wires used in common. Refer to Circuit Diagram for detailed description of each system


Body Electrical System

BULB SPECIFICATIONS

	Wattage (W)	SAE trade number
Headlamp unit	50/40	6012
Side clearance and turn signal lamp	8/23	1034
Side marker lamp	8	67
License plate lamp	7.5	89
Rear combination lamp		
Tail light	8	67
Tail/Stop (Brake) lamp	8/23	1034
Turn signal lamp	23	1073
Back-up lamp	23	1073
Meter illumination lamp	3.4	57X
Brake warning lamp	3.4	57X
Turn signal indicator lamp	3.4	57X
Headlamp beam indicator lamp	3.4	57X
Engine compartment inspection lamp	8	67
Interior lamp	10	—
Glove box lamp	3.4	57X
Clock illumination lamp	3.4	57X
Cigarette lighter illumination lamp	1.7	—
Hazard illumination lamp	1.4	—
Heater control illumination lamp	3.4	57X
Seat belt warning lamp	1.4	—
Rear defogger indicator lamp	1.4	—
Floor temperature warning lamp	1.4	—
Fuel level warning lamp	3.4	57X
Charge warning lamp	3.4	57X
Ash tray illumination lamp	3.4	57X



CIRCUIT DIAGRAM OF LIGHTING SYSTEM


Headlamp system




Body Electrical System

Turn signal lamp system





Stop lamp system



[illegible]

Meter Illumination system






Fig. BE-22 Circuit diagram for meter illumination lamp

Body Electrical System

Interior lamp system



Glove box, cigarette lighter and ashtray lamp illumination




BE512C

Fig. BE-24 Circuit diagram for glove box and cigarette lighter illumination

Body Electrical System

Map lamp system



CONNECTOR

C-1 : Blue
C-6 : Black
C-9 : White

COLOR CODE

B : Black
W : White
WR : White with red stripe
RW : Red with white stripe
LW : Blue with white stripe

HEADLAMP

AIMING ADJUSTMENT

Both vertical and horizontal aiming adjustments can be carried out through the cutting hole of headlight case.

Adjust the adjusting screw on upper side of each headlamp to adjust vertical aiming and adjust the adjusting screw on side of each headlamp to adjust horizontal aiming as sketched below.


Note:

Before making headlamp aiming adjustment, observe the following:

- Keep all tires inflated to correct pressure.
- Place car and tester on the same flat surface
- See that there is no load in car.
 - Gasoline, radiator and engine oil pan filled to correct levels.
 - No passenger.

When performing headlamp aiming adjustment, use an aiming device, aiming wall screen or headlamp tester. For operating instructions of any aimer, refer to the operation manuals supplied with the unit.

Adjust each headlamp beam as shown in Figure BE-26.



Dimensions/Angle	Values for adjustment
H mm (in)	620.6 (24.43) *624 (24.57)
θ	36'
θ'	1°26'
L m (ft)	59.3 (194.6) *59.6 (195.5)
L' m (ft)	24.8 (81.4) *24.9 (81.7)
H' mm (in)	104.7 (4.12)

* means GS30 (2 + 2 scale)




Fig. BE-26 Headlamp aiming adjustment

HEADLAMP BEAM REPLACEMENT


- Remove four screws retaining headlamp housing to fender panel. These screws can be removed through wheel opening of front fender panel.
- Remove headlamp assembly from body.

Note: To facilitate removing headlamp assembly from body, turn steering wheel all the way to right or left from which headlamp is removed.

- Then, remove headlamp retaining ring by loosening three screws.

Note: Be careful not to disturb aiming adjusting screws.

- Remove headlamp beam from housing, and disconnect connector, Headlamp beam can then be taken out.



- Retaining ring
- Sealed beam
- Headlamp housing assembly
- Retaining screw

BE427C

Fig. BE-27 Headlamp

- New unit should be installed in the reverse sequence of removal. In installing new unit, be sure that "TOP" raised on lens is on upper side.

Note:

- Whenever beam is replaced, adjust headlamp aiming.
- Lamp housing for L.H. and R.H. are different from each other. They can be distinguished by the letter "L" and "R" on lamp housing.

Bulb wattage

Headlamp beam

Main/Dimmer 50W/40W

Body Electrical System

FRONT COMBINATION LAMP

BULB REPLACEMENT

1. Remove two screws and remove lens.
2. Push in on bulb, twist it counter-clockwise, and remove it from socket.
3. Insert new bulb into socket, press it inward and rotate it clockwise. Make sure that the bulb is locked in socket.

Bulb wattage

Front combination lamp

Turn/Clearance . . . 23W/8W





Fig. BE-28 Front combination

LAMP BODY REPLACEMENT

1. Disconnect connector for front combination lamp behind lamp body.
2. Remove front combination lamp cover by removing two screws.
3. Remove screws retaining lamp body to front grille from front of the panel and remove front combination lamp.
4. Installation is in the reverse sequence of removal.

SIDE MARKER LAMP

BULB REPLACEMENT

1. Remove two lens retaining screws.
2. Remove lens from lamp body.
3. Push in on bulb, twist it counter-clockwise and remove from socket.
4. Insert new bulb into socket, press it inward and rotate it clockwise. Make sure that bulb is locked in socket.
5. Install lens in the reverse sequence of removal.


Bulb wattage

Side marker lamp

LAMP BODY REPLACEMENT


1. Disconnect lead wire at a connector (front) or at two connectors (rear).
2. Remove two lens retaining screws and take out lamp body assembly.
3. Install new lamp body assembly in the reverse sequence of removal.

Front



- 1 Lamp body
- 2 Adapter
- 3 Bulb
- 4 Lens
- 5 Limb

Rear



INTERIOR LAMP

BULB REPLACEMENT


1. Remove interior lamp assembly from roof. Interior lamp is retained by its spring back.
2. Pulling lamp body out a little, disconnect three connectors on its back.
3. Remove bulb from lamp body through the hole in its back.
4. Install new bulb in the reverse sequence of removal.

Bulb wattage

Interior lamp 10W

LAMP BODY REPLACEMENT

1. Remove lamp body from roof.
Lamp body is attached by its spring back.
2. Pulling body out from roof, disconnect three connectors. Lamp body can then be taken out easily.
3. Install new lamp body in the reverse sequence of removal.



BE987

Fig. BE-30 Interior lamp

REAR COMBINATION LAMP

BULB REPLACEMENT

1. Lift up rear carpet and luggage floor center trim.
2. Remove screws retaining rear trim cover lid.
3. Through hole in rear trim, twist socket counterclockwise and remove socket with bulb.
4. Press in on bulb, twist it counterclockwise, and remove it from socket.
5. Install new bulb in the reverse sequence of removal.


Bulb wattage

Stop/Tail 23W/8W

Tail 8W

Turn 23W

Reverse 23W



BE428C

Fig. BE-31 Replacing bulbs

LAMP BODY REPLACEMENT

1. Remove rear carpet, luggage floor center trim, luggage floor trim (R.H. and L.H.) and rear trim.
2. Disconnect lead wires for rear combination lamp at a connector.
3. Remove six flange nuts retaining rear combination lamp body to rear body panel. Lamp body can then be taken out.
4. Rear panel finisher can be separated by removing four screws.
5. Installation is in the reverse sequence of removal.


LICENSE LAMP

BULB REPLACEMENT

1. Remove two screws retaining lamp body to rear panel and take out lamp body. Refer to Figure BE-32.
2. Twist the socket counterclockwise and remove socket, with bulb, from lamp body.
3. Push in on bulb and twist it counterclockwise. Bulb can then be easily taken out from socket.
4. Install new bulb in the reverse sequence of removal.

Bulb wattage

License lamp . . . 7.5W x 2



1. Seat packing
2. Bulb (Back-up)
3. Bulb (Tail)
4. Bulb (Turn signal)
5. Bulb (Stop/Tail)
6. Combination body and lens
7. Rear finisher

BE451B

Fig. BE-32 Rear combination lamp

Body Electrical System

LAMP BODY REPLACEMENT

1. Remove two screws retaining lamp body to rear finisher and take out lamp body.
2. Disconnect pair of lead wires at connectors.
3. Install new lamp body in the reverse sequence of removal.

MAP LAMP

BULB REPLACEMENT

1. Remove four screws retaining instrument finisher to instrument panel.
2. Pulling instrument finisher out a little, disconnect lead wires at three connectors. Instrument finisher can then be removed from instrument panel.

Note: Three connectors are for map lamp, floor temperature warning lamp (California models) and fuel warning lamp.

3. Twist socket behind map lamp and remove socket with bulb.
4. Extract bulb from socket.
5. Installation is in the reverse sequence of removal.

Bulb wattage

Map lamp 5W

LAMP BODY REPLACEMENT

1. Remove four screws retaining instrument finisher to instrument panel.
2. Pulling instrument finisher out a little, disconnect three connectors. Instrument finisher can then be removed from instrument panel.

Note: Three connectors are for map




Fig. BE-33 License

3. Remove two screws retaining map lamp body to instrument finisher. Lamp body can then be taken out
4. Installation is in the reverse sequence of removal





Fig. BE-34 Removing ins



GLOVE BOX LAMP

BULB REPLACEMENT

Bulb is installed at the bottom of lamp body. Pushing the bulb into switch body, twist it counterclockwise. Bulb can then be taken out. Install new bulb in reverse sequence of removal.

Bulb wattage:


Glove box lamp 3.4W

LAMP BODY REPLACEMENT

1. Disconnect battery ground cable.
2. Disconnect pair of lead wires at connectors in glove box.
3. Pull the lamp body with bulb out from bracket.
4. Installation is in the reverse sequence of removal.

INSPECTION

Test continuity between two lead wires. When plunger is pressed into lamp body, continuity must not exist. Conversely, continuity must exist when the plunger is projecting.



BE992

Fig. BE-36 Glove box lamp

AUTOMATIC TRANSMISSION INDICATOR ILLUMINATION LAMP


The illumination lamp is located in the indicator finisher and illuminates the indicator of select lever. Removal and installation is described in Section BF.

BULB REPLACEMENT

1. Remove console box.
2. Remove automatic transmission indicator finisher.
3. Remove socket with bulb from beneath indicator finisher.
4. Remove bulb from socket.
5. Install new bulb in the reverse sequence of removal.

Bulb wattage:

Automatic transmission indicator illumination lamp 3.4W



BE913

Fig. BE-37 Automatic transmission indicator lamp


ASHTRAY ILLUMINATION LAMP

Ashtray illumination lamp is installed in the ashtray on the console.

This lamp is useful at night when using ashtray.

REMOVAL AND INSTALLATION

1. Pull up the ashtray pan and remove it.
2. Push in bulb with socket backward and take it out.
3. Remove bulb from socket (Push and turn counterclockwise).
4. Installation is in the reverse sequence of removal.



BE452B

Fig. BE-38 Ashtray illumination lamp

INDICATOR LAMPS

Turn signal indicator lamps and high beam indicator lamp are installed on tachometer and speedometer.


They can be replaced easily by pulling socket, with bulb, from back of meter. Refer to Meters and Gauges.

INSPECTION LAMP

Inspection lamp is located on left side of engine room. Should some mechanical difficulty occur at night, this lamp is extremely useful for detection of the source of the problem and/or illumination of the repair job.

REMOVAL AND INSTALLATION

1. Disconnect lead wire at a connector.
2. Remove two screws retaining lamp to engine room. Lamp assembly can then be taken out easily.
3. Installation is in the reverse sequence of removal.



BE993

Fig. BE-39 Inspection lamp

Body Electrical System

BULB REPLACEMENT

1. Twist socket and lens and take them out from lamp housing.
2. Push on lens and twist counterclockwise. Lens can then be taken out from socket.
3. Push in on bulb and twist bulb counterclockwise. Bulb can then be taken out from socket.

INSPECTION

Test continuity between terminal for power source harness and body at each step of switch. Test can be carried out by using ohmmeter or test lamp.

COMBINATION SWITCH

The combination switch consists of a light switch, a wiper switch, a washer switch, a turn signal and lane changer switch, and a dimmer switch. The two levers on the switch are for turn signal and lane changer switch and for light and wiper switch. They can be separated into two pieces. Position the turn signal switch lever at the first stop position, for left or right direction, when changing lanes. Turn signal lamps operate until the lever is released.

Move the lever up and down to change headlamp between high and low beams.

Lighting switch is operated by a dial with a small knob. Wiper switch is operated by outer dial; washer switch is at the top of the switch lever.

REMOVAL AND INSTALLATION

1. Disconnect battery ground cable.
2. Remove all screws retaining shell covers to each other and remove shell covers from steering column jacket.
3. Disconnect lead wires from combination switch at five connectors. They consist of two large connectors. One with nine terminals and the other with six terminals.
4. Remove two screws retaining combination switch to steering column jacket.

The switch will then separate into two pieces and can be easily removed.

Note: There is a lead wire between L.H. and R.H. piece. It is unnecessary to disconnect the connector for it.





Fig. BE-40 Removing combination switch

5. Installation is in the reverse sequence of removal.

Note: Make sure that location of combination switch lines up with hole in steering column jacket. Location tab is inside of steering column jacket.



INSPECTION

Test continuity through terminals at each step of switch and position test lamp or ohmmeter. Continuity diagram described in Fig. BE-41.



	LIGHT		WIPER		WASHER	
	OFF	1 2	OFF	L H	OFF	ON
4						
5						
6						
7						
L						
H						
E						
2						
3						
W						
B						
1						

	TURN SIGNAL			DIMMER		HORN	
	L	N	R	M	D	OFF	PUSH
10							
11							
14							
15							
16							
E							
18							
20							



DOOR SWITCH

The switch for L.H. door is different than that for R.H. door.

The switch for L.H. door has four lead wires. Two of them are for the theft protection system and the other two for the interior lamp.

The switch for R.H. door has two lead wires for the interior lamp.

REMOVAL AND INSTALLATION

Door switch is located at L.H. and R.H. front door pillar.

1. Withdraw switch and wire assembly from front pillar.


Note: If it proves difficult to remove by hand, it can be removed easily with aid of screwdriver.

In using screwdriver, however, take care not to damage painted surface.

2. Disconnect lead wires at connectors. Switch can then be taken out.
3. Installation is in the reverse sequence of removal.

INSPECTION

Test continuity through door switch with a test lamp or ohmmeter.



When plunger is pressed into switch assembly, door switch contacts are open. Conversely, contacts are closed when plunger is projected.

STOP LAMP SWITCH

REMOVAL AND INSTALLATION

Stop lamp switch is integral part of brake pedal height.


Whenever stop lamp switch is removed, some adjustment is required.

1. Disconnect lead wires at connectors.
2. Loosen lock nut. Switch assembly can then be taken out by rotating switch.
3. Install in reverse sequence of removal.

INSPECTION

When plunger is pressed into switch assembly, stop lamp switch contacts are open, contacts are closed when plunger is projected.

Test continuity as previously described with a test lamp or ohmmeter.



- 1 Stop lamp switch
- 2 Steering column
- 3 Brake pedal

BE997

Fig. BE-43 Stop lamp switch


BACK-UP LAMP SWITCH

REPLACEMENT


Back-up lamp switch is installed on transmission. In manual transmission, this switch is installed on its case. In automatic transmission, the switch is an integral part of inhibitor switch. Removal and installation are described in Sections MT and AT.

INSPECTION

When the transmission lever is in R position, continuity between these harnesses for back-up lamp switch must exist.



BE813



- 1 Back-up lamp switch

BE454B

Fig. BE-42 Door switch

Fig. BE-44 Back-up lamp switch

Body Electrical System





Fig. BE-45 Inhibitor switch

HAZARD SWITCH

REMOVAL AND INSTALLATION


1. Disconnect battery ground cable.
2. Remove console box, referring to Section BF.
3. From behind console box, grasp nail of switch body and push it out of console box.
4. Disconnect lead wires at a connector.
5. Installation is in the reverse sequence of removal.

Note: Switch body can be installed on console box only by pressing it in.

BULB REPLACEMENT

1. Take out switch assembly as described previously.
2. Push the socket and twist counterclockwise; socket with bulb can then be taken out.
3. Extract the bulb from socket.
4. Installation is in the reverse sequence of removal.

Bulb wattage:



	OFF
1	
2	
3	
4	
5	
6	
7	




Fig. BE-46

INSPECTION

Test continuity through the switch at each step with an ohmmeter or test lamp.

The continuity diagram is indicated in the following figure.

IGNITION AND STARTING SWITCH

The ignition switch is installed at bottom of steering lock. For information on engine electrical system, refer to Section EE.

REPLACEMENT

1. Remove screws retaining shell

covers to each other.

2. Remove shell covers and connect lead wires at a connector.

Note: Connector is at bottom of steering lock.


3. Remove screw retaining steering lock.

Switch assembly can be removed easily.

4. Installation is in the reverse sequence of removal.

INSPECTION

Test continuity through the switch at each step with an ohmmeter or test lamp. Refer to following continuity diagram.



	OFF	ACC	ON	START
B				
S				
IG				
A				

	Key IN	OUT
1		
2		
3		
4		
5		
6		
7		

RHEOSTAT (For illumination control)

This rheostat controls the brightness of illumination for each meter, clock, radio and heater control; it is a rheostat (variable resistor) and its value can be controlled by a knob.

REMOVAL AND INSTALLATION

1. Pull off illumination control knob and tripmeter reset knob.

They should come off easily.

2. Remove tachometer.

Refer to METER AND GAUGE REPLACEMENT section.


3. Loosen small screw retaining trip-meter cable to speedometer and detach cable from the hole of tachometer.

4. Disconnect leading wire to rheostat at the connector from behind instrument panel.

5. Disconnect left-hand air duct from behind instrument panel.

6. Remove screws securing tripmeter reset cable to a bracket and detach trip reset cable.

7. Loosen nut securing rheostat to the bracket and then rheostat can be taken out from behind instrument panel.



BE100A

1 Left-hand air duct

2 Floor duct

(Air conditioned model)

Fig. BE-48 Disconnect connector for rheostat

8. Installation is in the reverse sequence of removal.

INSPECTION

Test continuity and resistance between two lead wires with ohmmeter.

When switch is in OFF position, continuity must not exist. In ON position the resistance varies from about 10 Ω to 0 Ω depending on the setting of the knob.

FLASHER UNIT REPLACEMENT

Two flasher units are installed at L.H. side trim under instrument panel.


One is for turn signal and the other is for hazard. They are different from each other.

1. Disconnect battery ground cable.

2. Disconnect lead wires at connector.

3. Remove screw retaining flasher unit.


4. Install new flasher unit in the reverse sequence of removal



1 For hazard

2 For turn signal BE570A

Fig. BE-50 Flasher units



BE456B

Fig. BE-49 Illumination control rheostat

Body Electrical System

TROUBLE DIAGNOSES AND CORRECTIONS HEADLAMP

Condition	Probable cause	Corrective action
Headlamps do not light for either high or low beams.	Burnt fusible link. Loose connection or open circuit. Faulty combination switch. No ground.	Correct cause and replace fuse. Check wiring and/or repair connection. Conduct continuity test and replace if necessary. Clean and tighten ground terminal.
High beam cannot be switched to low beam or vice versa.	Faulty combination switch.	Conduct continuity test and replace if necessary.
Headlamps dim.	Partly discharged or faulty battery. Faulty charging system. Poor ground or loose connection. Burnt fusible link.	Measure specific gravity of electrolyte and recharge or replace battery if necessary. Measure voltage at headlamp terminals. If it is less than 12.8V, check charging system for proper operation. Clean and/or tighten. Replace.
Headlamp lights on only one side.	Loose headlamp connection. Faulty headlamp beam.	Repair. Replace.

TURN SIGNAL LAMP

Condition	Probable cause	Corrective action
Turn signals do not operate.	Burnt fuse. Faulty ignition relay Loose connection or open circuit. Faulty flasher unit. Faulty turn signal switch.	Correct cause and replace. Check for operation of circuits (i.e., lights and gauges) electrically connected to turn signal relay. If they do not function, replace if necessary. Check wiring and/or repair connection. Replace. Conduct continuity test and replace if necessary.
Flashing cycle is too slow, (Pilot lamp does not go out.) or too fast.	Bulbs of other than specified wattage are being used. Burnt bulbs. Loose connection. Faulty flasher unit.	Replace with one specified. Replace. Repair. Replace.
Flashing cycle is irregular.	Burnt bulb. Loose connection.	Replace. Repair.

TAIL LAMP, STOP LAMP AND BACK-UP LAMP

Condition	Probable cause	Corrective action
Both right and left lamps do not light	Burnt fuse	Correct cause and replace.
	Faulty ignition relay (Back-up lamp only)	Check for operation of circuits (i.e., meters, gauges and turn signal lamp) electrically connected to ignition relay If they do not function, replace ignition relay.
	Faulty back-up lamp switch.	Conduct continuity test and replace if necessary.
	Faulty inhibitor switch.	Check wiring and/or repair connection.
Lamp on only one side lights	Loose connection or open circuit.	
	Burnt bulb	Replace.
	Loose bulb.	Repair lamp socket.

METERS AND GAUGES

CONTENTS

DESCRIPTION	BE-29	INSPECTION	BE-41
BULB SPECIFICATIONS	BE-30	CHARGE WARNING SYSTEM	BE-41
CIRCUIT DIAGRAM	BE-31	DESCRIPTION	BE-41
METER AND GAUGE REPLACEMENT	BE-37	REPLACEMENT	BE-41
TACHOMETER	BE-37	BRAKE WARNING SYSTEM	BE-41
SPEEDOMETER	BE-38	DESCRIPTION	BE-41
TEMP-OIL AND VOLT FUEL GAUGES	BE-39	REPLACEMENT	BE 41
OIL PRESSURE AND WATER		INSPECTION	BE 42
TEMPERATURE INDICATING SYSTEM	BE 40	TROUBLE DIAGNOSES AND	
DESCRIPTION	BE-40	CORRECTIONS	BE 42
REPLACEMENT	BE-40	SPEEDOMETER	BE 42
INSPECTION	BE-40	WATER TEMPERATURE AND	
VOLTMETER AND FUEL LEVEL		OIL PRESSURE GAUGES	BE-43
INDICATING SYSTEM	BE-40	FUEL GAUGE	BE-44
DESCRIPTION	BE-40		
REPLACEMENT	BE-40		

DESCRIPTION

This section includes information on all meters and gauges. Bulbs for indicator or for illumination can be

easily replaced by twisting bulb socket.

All meters and gauges can be easily

replaced without removing instrument panel.

Body Electrical System






Fig. BE-51 Meters and Instruments

BULB SPECIFICATIONS

Item	Wattage	Q'ty	SAE trade number	Remarks
Speedometer Illumination lamp	3.4W	2	57X	
Tachometer Illumination lamp	3.4W	2	57X	
Brake warning lamp	3.4W	1	57X	
OIL-TEMP gauge illumination	3.4W	1	57X	
VOLT-FUEL gauge illumination	3.4W	1	57X	
CLOCK illumination lamp	3.4W	1	57X	
Charge warning lamp	3.4W	1	57X	

Body Electrical System

Water temperature and oil pressure indicating system



Voltmeter and fuel level indicating and fuel level warning system






Fig. BE-54 Circuit diagram for voltmeter and fuel level indicating and fuel level warning system

Body Electrical System

Brake warning system






BE-35

BE432C



Body Electrical System

Charge warning lamp system



METER AND GAUGE REPLACEMENT

TACHOMETER



BE4648

Fig. BE-58 Tachometer

The tachometer is retained by two screws, and can be taken out easily. A pair of turn signal indicator lamps and a pair of illumination lamps are also installed. Their bulbs can be removed easily by twisting socket at back of tachometer.


This tachometer is a voltage trigger type.

Removal and installation

1. Remove screw ① retaining tachometer at upper side of instrument panel. See following figure.


2. Working from beneath instrument panel, remove the other screw ② retaining tachometer to bracket of instrument panel.

3. Pulling tachometer assembly out from instrument panel, disconnect connector to instrument harness. Tachometer assembly can then be taken out easily.




BE110A

Fig. BE-61 Removing screw—②




BE4658

Fig. BE-59 Removing screws



BE663A

Fig. BE-60 Removing screw—①



BE669B

Fig. BE-62 Disconnecting connector

Body Electrical System

Bulb replacement

Pull out socket, with bulb, from back of tachometer and extract bulb from socket.

Install new bulb in reverse sequence of removal.

Bulb wattage:

Turn signal indicator lamp	3.4W
Illumination lamp	3.4W

SPEEDOMETER

Speedometer is attached by two screws.

High beam indicator lamp, brake warning lamp, an odometer and a tripmeter are integral parts of speedometer. On manual transmission models, a speed switch with amplifier is added.


Consequently, speedometer on manual transmission models is different from that on automatic transmission models. All bulbs on speedometer can be replaced easily.

Removal and installation

1. Remove tachometer as described previously.
2. Disconnect speedometer cable at junction screw on back of meter.
3. Through hole in which tachome-

ter is installed, disconnect trip meter reset cable.


Note: Reset cable can be removed from speedometer by loosening a small screw.



- 1 Tripmeter reset cable
- 2 Retaining small screw BE113A


Fig. BE-64 Removing reset cable

4. Remove screw (1) retaining speedometer. See following figure.



BE671B

Fig. BE-65 Removing screws



- 1 High beam warning lamp
- 2 Illumination lamp
- 3 Trip counter reset cable




Fig. BE-66 Removing

5. Working from beneath panel, remove other screw retaining speedometer to bracket on instrument panel.






Fig. BE-67 Removing




For U.S.A.



For Can.

6. Pulling speedometer out from instrument harness, disconnect a connector for instrument harness.

Speedometer can then be taken out.



BE672B

Fig. BE-68 Disconnecting connector

TEMP-OIL AND VOLT-FUEL GAUGES

These gauges are attached to instrument panel with spring bracket. The spring bracket is retained by a screw. Consequently, each gauge can be easily taken out by removing retaining screw.

Removal and Installation

1. Remove four screws retaining instrument finisher to instrument panel. Pulling instrument finisher out a little, disconnect two connectors.

Instrument finisher can then be taken out.



- 1 Floor temperature warning lamp (California models)
- 2 Map lamp
- 3 Fuel warning lamp

BE989A

Fig. BE-70 Removing instrument finisher

2. Remove two screws retaining three-way venti-duct to instrument panel and four screw for bracket.





Fig. BE-71 Removing three-way duct retaining screws

3. Disconnect duct hoses from three-way duct and take out three-way duct.

4. Remove screw retaining each gauge to instrument panel.



BE117A

Fig. BE-72 Removing gauge retaining screws

Bulb replacement





Pull out socket, with bulb, from back of speedometer and extract bulb from socket.

Install new bulb in reverse sequence of removal.

Bulb wattage:


High beam indicator 3.4W

Brake warning lamp 3.4W



- 1 Charge warning lamp
- 2 Illumination lamp

Illumination lamp



BE673B

Fig. BE-69 TEMP-OIL and VOLT-FUEL gauges

Body Electrical System

5 Pulling gauge out backward, disconnect each connector. Gauge can then be taken out.

Note: TEMP-OIL gauge has a connector with six terminals. VOLT-FUEL gauge has two connectors: a larger one and a smaller one.

Bulb replacement

Illumination bulb can be taken out easily by pulling socket with bulb at back of each gauge.

Extract bulb from socket and install new bulb in reverse sequence of removal.

Bulb wattage

Illumination bulb . . . 34W

OIL PRESSURE AND WATER TEMPERATURE INDICATING SYSTEM

DESCRIPTION

The oil pressure sending unit consists of an oil pressure switch and an oil pressure gauge. The oil pressure switch is used as a control unit of the fuel pump.

The oil pressure gauge consists of a bimetal meter unit, a variable resistance sensing unit (incorporating a diaphragm) and a voltage regulator.

As oil pressure varies, the diaphragm moves accordingly, causing the sliding contact to move along the resistance. This changes the amount of current that can flow in the circuit and actuates the bimetal.

The water temperature gauge consists of a meter and thermal transmitter located in the engine block. The thermal transmitter is equipped with a thermistor element which converts cooling water temperature variation to a resistance, thereby controlling current flowing to the gauge.

The oil pressure gauge and water temperature gauge are equipped with a bimetal arm and heater coil.

When the ignition switch is set to "ON", current flows to the heater coil, and the heater coil is heated. With this heat, the bimetal arm is bent, thus causing the pointer connected to the

If both the oil pressure and water temperature gauges become faulty at the same time, the fault may lie in the voltage regulator.


REPLACEMENT

OIL-TEMP gauge

Refer to previous section "Meter and Gauge Replacement".

Oil pressure sending unit

The oil pressure sending unit is located on cylinder block beside oil filter element. The unit can be removed by unscrewing it. Be sure to apply conductive sealer to threads prior to installing new unit.




ER431

Fig. BE-73 Oil pressure sending unit

Thermal transmitter

To replace thermal transmitter, disconnect lead wire from its terminal and unscrew thermal transmitter from oil filter bracket.

Be sure to apply conductive sealer to threads prior to installing new thermal transmitter.



BE065B

- 1 Thermal transmitter
- 2 Water temperature sensor (For Electronic Fuel Injection System)
- 3 Thermotime switch (For Electronic Fuel)

INSPECTION

Check each unit for proper operation.

Test continuity of oil pressure gauge and water temperature gauge using test lamp and ohmmeter. See Figure BE-53.

Test continuity of oil pressure switch, referring to Fuel Pump and Gauge System (Section EF).

VOLTMETER AND FUEL LEVEL INDICATING SYSTEM

DESCRIPTION

The fuel level indicating system consists of a tank unit and a fuel level gauge. The tank unit consists of a float arm which moves up and down in the fuel tank with changes in fuel level. A sliding contact that slides back and forth on a resistance when the float arm moves. This changes the amount of electric resistance offered by the tank unit and controls the current flowing to the fuel level gauge. The gauge moves with the changes in fuel level.

The fuel gauge is equipped with a bimetal arm and heater coil. When the ignition switch is turned "ON", current flows to the heater coil and the heater coil is heated. With this heat, the bimetal arm is bent, thus causing the pointer connected to the arm to move.

The voltmeter monitors the operation of the electrical system and indicates if it is in good order. It registers more than 11 volts before and during starting, and 6 to 8 volts during cranking. If it registers more than 11 volts during engine running, the voltage regulator is out of order.

REPLACEMENT

VOLT-FUEL gauge

Fuel tank gauge unit

Refer to Section FF (Fuel and Exhaust system) for Replacement




Fig. BE-75 Fuel tank gauge unit

Fuel warning lamp bulb


1. Remove four screws retaining instrument finisher to instrument panel.
2. Pull instrument finisher forward slightly, and disconnect lead wires at three connectors. Instrument finisher can then be removed from instrument panel.

Note: Three connectors are for map lamp, floor temperature warning lamp (California models) and fuel warning lamp.

3. Pull out socket and bulb from back of lamp body and extract bulb from socket.
4. Install new bulb. Installation is in the reverse sequence of removal.

Bulb wattage

Fuel warning lamp 3.4W



- 1 Floor temperature warning lamp (California models)
- 2 Map lamp
- 3 Fuel warning lamp




Fig. BE-76 Fuel warning lamp

Lamp body

1. Remove four screws retaining instrument finisher to instrument panel.
2. Pull instrument finisher forward slightly, and disconnect lead wires at connectors. Instrument finisher can then be removed from instrument panel.

Note: Three connectors are for map lamp, floor temperature warning lamp (California models) and fuel warning lamp.

3. Remove two screws retaining warning lamp body to instrument finisher. Lamp body can then be taken out.
4. Installation is in the reverse sequence of removal.

INSPECTION

Test continuity of voltmeter and fuel level indicating system with test lamp or ohmmeter. See Figure BE-54.

CHARGE WARNING SYSTEM

DESCRIPTION

Refer to Charging Circuit (Section EE).

REPLACEMENT

Charge warning lamp bulb

The charge warning lamp is built into the voltmeter.

1. Remove four screws retaining instrument finisher to instrument panel.
2. Pull instrument finisher forward slightly and disconnect lead wires at three connectors. Instrument finisher can then be removed from instrument panel.

Note: Three connectors are for map lamp, floor temperature warning lamp (California models) and fuel warning lamp.

3. Pull out socket and bulb from back of voltmeter and extract bulb from socket.
4. Install new bulb. Installation is in the reverse sequence of removal.

Bulb wattage.

Charge warning lamp 3.4W

BRAKE WARNING SYSTEM

DESCRIPTION

The brake warning system consists of a warning lamp, a parking brake switch and a brake fluid level switch.

The brake warning lamp checking system consists of a warning lamp, a check relay and an IC regulator (alternator).

This warning light functions for both the parking brake and foot brake systems. The warning light glows when the ignition switch is turned to the "ON" position and the engine is not running. If the light does not glow, check the electrical system for a burned-out bulb or an open circuit.

The warning light will continue to glow when the parking brake is applied with the engine running.

The warning light glows when the fluid level is lower than the prescribed level, the ignition switch is "ON", the engine is running, and the parking brake is free.

REPLACEMENT

Parking brake switch

The parking brake switch is mounted on lever support bracket.

To replace parking brake switch, disconnect lead wire at connector plug and pull switch assembly out of bracket.

When plunger is pressed into switch assembly, parking brake switch contacts are open. Contacts are closed when plunger is projected.

Body Electrical System




Fig. BE-77 Parking brake switch

Brake fluid level switch

Brake fluid level switch is built into brake master cylinder cap. The cap can be easily removed by twisting it after disconnecting lead wire terminals. Then replace cap.

Brake warning lamp check relay

The relay is attached to the floor under the front passenger seat.

1. Disconnect battery ground cable.
2. Remove four bolts securing front

passenger seat in place, and remove seat.

3. Disconnect connector from relay.
4. Remove two screws retaining re-

lay. Relay can then be taken out.

5. Installation is in the reverse sequence of removal.




Fig. BE-78 Brake warning lamp check relay

INSPECTION

Check each switch for proper operation and test continuity of wiring

system with ohmmeter or test lamp. Take care that each connection is correctly secured.

TROUBLE DIAGNOSES AND CORRECTIONS

SPEEDOMETER

Condition	Probable cause	Corrective action
Speedometer pointer and odometer do not operate	Loose speedometer cable union nut Broken speedometer cable. Damaged speedometer drive pinion gear (Transmission side) Faulty speedometer.	Retighten Replace. Replace. Replace.
Unstable speedometer pointer.	Improperly tightened or loose speedometer cable union nut Faulty speedometer cable. Faulty speedometer.	Retighten Replace. Replace.
Unusual sound occurs in when driving speed is increased	Excessively bent or twisted speedometer cable inner wire or lack of lubrication. Faulty speedometer.	Replace or lubricate. Replace

Body Electrical System

Condition	Probable cause	Corrective action
Inaccurate speedometer indication	Faulty speedometer.	Replace.
Inaccurate odometer operation	Improperly meshed second and third gear or worn gears Faulty feeding due to deformed odometer and pinion carrier.	Replace speedometer Replace speedometer

WATER TEMPERATURE AND OIL PRESSURE GAUGES

Condition	Probable cause	Corrective action
Both water temperature and oil pressure gauges do not operate.	Burnt fuse. Faulty ignition relay. Faulty gauge voltage regulator	Correct cause and replace fuse Check for operation of circuits (i.e., fuel gauge and turn signal lamp) electrically connected to ignition relay If they do not function, replace ignition relay. Replace water temperature gauge
Both water temperature and oil pressure gauges indicate inaccurately	Faulty gauge voltage regulator (Gauge pointer fluctuates excessively). Loose or poor connection (Gauge pointer fluctuates slightly)	Replace water temperature gauge. Correct connector contact.
Water temperature gauge Water temperature gauge does not operate	Faulty thermal transmitter or loose terminal connection. (When thermal transmitter yellow/white wire is grounded, gauge pointer fluctuates) Faulty water temperature gauge. Open circuit	Replace thermal transmitter or correct terminal connection Replace water temperature gauge.
Gauge indicates only maximum temperature	Faulty thermal transmitter. (Gauge pointer returns to original position when ignition switch is turned off) Faulty water temperature gauge (Gauge pointer indicates maximum temperature even after ignition switch is turned off.)	Replace thermal transmitter. Replace water temperature gauge
Water temperature gauge does not operate accurately.	Faulty water temperature gauge Loose or poor connection	[Connect a 116Ω resistance between thermal transmitter yellow/white wire and ground. When gauge indicates approximately 50°C (122°F), gauge is serviceable] Correct connector terminal contact.
Oil pressure gauge Oil pressure gauge does not operate	Faulty oil pressure sending unit or loose terminal connection. Open circuit.	Replace oil pressure sending unit or correct terminal connection Repair or replace.

Body Electrical System

Condition	Probable cause	Corrective action
Gauge indicates only maximum pressure.	Faulty oil pressure gauge unit. (Gauge pointer returns to original position when ignition switch is turned off.)	Replace.
	Faulty oil pressure gauge (Gauge pointer indicates maximum pressure even after ignition switch is turned off.)	Replace.

FUEL GAUGE

Condition	Probable cause	Corrective action
Fuel gauge does not operate.	Burnt fuse. Faulty ignition relay. Faulty tank unit or loose unit terminal connection. (Pointer deflects when tank unit yellow wire is grounded.) Faulty fuel gauge. Open circuit.	Correct cause and replace fuse. Check for operation of circuits (i.e. temperature, oil pressure gauge and signal lamp) electrically connected to ignition relay. If they do not function, replace relay. Replace tank unit or correct terminal connection. Replace fuel gauge.
Pointer indicates only "F" position.	Faulty tank unit. (Pointer drops below "E" mark when ignition switch is turned off.) Faulty fuel gauge. (Pointer still indicates "F" position when ignition switch is turned off.)	Replace tank unit. Replace fuel gauge.
Fuel gauge does not operate accurately	Faulty tank unit. (Pointer indicates a half level when a 32Ω resistor is connected between tank unit yellow wire and ground.) Faulty fuel gauge. Poor or loose connection.	Replace tank unit. Replace fuel gauge. Correct connector terminal contact.

ELECTRICAL ACCESSORY

CONTENTS

HEATER	BE-45	ELECTRIC REAR WINDOW DEFOGGER	BE-70
DESCRIPTION	BE-45	DESCRIPTION	BE-70
AIR FLOW	BE-46	REMOVAL AND INSTALLATION	BE-70
REMOVAL AND INSTALLATION	BE-48	WARNING LAMP BULB REPLACEMENT	BE-71
DISASSEMBLY AND ASSEMBLY	BE-50	INSPECTION	BE-71
HEATER ILLUMINATION BULB		FILAMENT MAINTENANCE	BE-72
REPLACEMENT	BE-51	RADIO	BE-74
ADJUSTMENT	BE-51	DESCRIPTION	BE-74
INSPECTION	BE-52	REMOVAL AND INSTALLATION	BE-74
TROUBLE DIAGNOSES AND		ANTENNA TRIMMER ADJUSTMENT	BE-75
CORRECTIONS	BE-55	INSPECTION	BE-75
HORN	BE-56	TROUBLE DIAGNOSES AND	
DESCRIPTION	BE-56	CORRECTIONS	BE-76
REMOVAL AND INSTALLATION	BE-56	THEFT PROTECTION SYSTEM	BE-78
INSPECTION	BE-56	DESCRIPTION	BE-78
TROUBLE DIAGNOSES AND		REMOVAL AND INSTALLATION	BE-78
CORRECTIONS	BE-57	INSPECTION	BE-79
WINDSHIELD WIPER AND WASHER	BE-59	SEAT BELT WARNING SYSTEM	BE-81
DESCRIPTION	BE-59	DESCRIPTION	BE-81
ADJUSTMENT	BE-60	REMOVAL AND INSTALLATION	BE-81
REMOVAL AND INSTALLATION	BE-60	WARNING LAMP BULB REPLACEMENT	BE-82
INSPECTION	BE-61	INSPECTION	BE-82
TROUBLE DIAGNOSES AND		KICKDOWN SYSTEM (For automatic	
CORRECTIONS	BE-62	transmission models only)	BE-84
CIGARETTE LIGHTER	BE-68	DESCRIPTION	BE-84
DESCRIPTION	BE-68	REPLACEMENT	BE-84
ILLUMINATION BULB REPLACEMENT	BE-68	INSPECTION	BE-84
REMOVAL AND INSTALLATION	BE-68	STARTING SYSTEM (For automatic	
INSPECTION	BE-68	transmission models only)	BE-86
CLOCK	BE-69	DESCRIPTION	BE-86
DESCRIPTION	BE-69	REPLACEMENT	BE-86
REPLACEMENT	BE-69	INSPECTION	BE-86
INSPECTION	BE-69		

HEATER

DESCRIPTION

The heater unit combines heating and ventilating functions. It is located in the lower part of the instrument panel, to the front of the center console.

Outside air enters the cowl top grille by the blower through the air intake case. As air is passed through the heater core, heat is picked up from

the core. When the air is not passed through the core, the heater unit serves as a ventilating unit.

The heater electrical system consists of fan motor, ignition relay, control illumination lamp, resistor and fan switch.


The fan switch controls the three

speed fan motor through a resistor located in the fan unit.

A heater control illumination lamp is located behind the control finisher, its brightness is controlled by an illumination control resistor. Ventilation air duct hoses are installed behind the instrument panel.

Body Electrical System

AIR FLOW



BE0098

Fig. BE-79 Sectional view of heater

Air intake door

The air intake door controls the flow of outside air into the heater unit. Outside air is drawn from the cowl top grille. This door is controlled by AIR lever on heater control.

Mode door

The mode door controls air flowing through heater core and directs fresh cool air flowing from center ventilator and instrument side ventilator. This door is controlled by AIR lever.

Floor door

The floor door controls air flow discharged from heater unit. When the door is open, air is discharged to floor area with a small amount going to the defroster nozzle. When the door is closed, all air is discharged through the defroster nozzle.

AIR lever

The AIR lever controls with the aid of air intake door and floor door. These three can be controlled with a lever. When the AIR lever is set in the position, all air from the heater is discharged through the center vents. When the AIR lever is in HI AT position, all air passes the heater core and flows to the defroster nozzle and floor area.

TEMP lever


The TEMP lever controls the water cock. The water cock controls the water flowing into heater core. The temperature of discharged air is controlled by the position of the TEMP lever.

This heater cock, a flow type, adequately controls the temperature of the discharged air by moving to the position of the TEMP lever.

FAN lever


The FAN lever controls the fan motor with aid of a resistor located in the heater unit. The fan motor controls the speed of discharged air.

Ventilating




AIR lever is in VENT position. TEMP lever is in any position. Amount of discharged air is controlled by FAN lever. During high speed driving, FAN lever may be useless.


To defroster nozzle




BI-LEVEL



AIR lever is in BI-LEVEL position. TEMP lever controls the temperature of heat air discharged to floor or defroster nozzle. FAN lever controls amount of air discharged.




Heating




AIR lever is in HEAT position. TEMP lever controls temperature of discharged air.

FAN lever controls amount of air discharged.




Defrosting




AIR lever is in DEF position. TEMP lever controls the temperature of discharged air.


FAN lever controls amount of air discharged.



Not in use



AIR lever is in OFF position. TEMP lever is in COLD position. FAN lever is in OFF position.



Body Electrical System

REMOVAL AND INSTALLATION






Fig. BE-81 Exploded view

Heater control

1. Disconnect battery ground cable and drain engine coolant.
2. Remove console box, referring to Section BF.
3. Remove four screws retaining finisher and take out by moving forward. Disconnect lead wires at two (three for California models) connectors and finisher can then be taken out easily.

4. Remove control cables at air intake duct, water cock, and floor door and disconnect mode door control rod.




BE011B

Fig. BE-84 Disconnecting in con



BE989A

- 1 Floor temperature warning lamp (California models)
- 2 Map lamp






Fig. BE-86 Disconnecting mode door control rod




Fig. BE-87 Disconnecting floor door control cable

5. Disconnect lead wires from heater control to heater sub-harness at two connectors.
6. Remove two screws retaining control assembly to instrument panel reinforcement.




Fig. BE-88 Removing retaining screws

7. Remove screw retaining reinforcement to instrument panel and remove reinforcement.
8. Remove two screws retaining heater control to heater unit. Heater control and bracket can then be removed.




Fig. BE-89 Removing retaining screws

9. Installation is in the reverse sequence of removal. Refer to Adjustment.

Note: When installing control assembly, be careful not to twist or bend control cables.

Heater unit

1. Disconnect battery ground cable and drain engine coolant.
2. Remove console box, referring to Section BF.
3. Remove four screws retaining finisher and take out by moving forward. Disconnect lead wires at three (California models) or two (Non California models) connectors. Finisher can then be taken out easily. See Figure BE-82.
4. Remove two screws retaining three-way venti-duct to instrument finisher bracket and four screws retaining brackets. Then remove instrument finisher brackets. Disconnect ventilator duct hose from three-way venti-duct and take out three-way venti-duct. See Figure BE-71.
5. Remove heater control as previously described.
6. Disconnect defroster ducts from heater unit and disconnect two heater hoses from inlet and outlet tubes of heater unit by removing clamps.
7. Remove two screws retaining venti-duct adapter to heater unit.
8. Remove two nuts and two screws retaining heater unit to body panel.

Two nuts and two screws can be removed from engine compartment side. Other two screws are located under the heater control location.




Fig. BE-90 Removing heater unit

9. Pull heater unit out slightly and turn to left 90°. Heater unit can then be removed from center of instrument panel.
10. Installation is in the reverse sequence of removal. Refer to Adjustment.

Fan unit

1. Disconnect battery ground cable.
2. Disconnect control cable for air intake box by removing clamp at an intake duct. See Figure BE-84.
3. Disconnect lead wires for fan and resistor at connectors. Fan unit can then be taken out easily by removing retaining screws.




Fig. BE-91 Removing fan unit

Body Electrical System

4. Installation is in the reverse sequence of removal.

DISASSEMBLY AND ASSEMBLY

Fan switch


1. Remove heater control. For re-

moval procedure, refer to the previous section.

2. Remove nut securing gear to fan switch and take out gear

3. Remove two screws retaining fan switch to heater control. Fan switch can then be taken out easily.

4. Assembly is in the reverse sequence of disassembly.




- 1 Fan switch
- 2 Illumination lamp

BE018B

Fig. BE-92 Disassembling fan switch

Heater cock and core



BE019B

Fig. BE-93 Removing heater cock and core

1. Remove heater unit. For removal procedure, refer to the previous section.

2. Loosen hose clamps on heater cock side and disconnect hose from heater cock.

3. Remove two screws retaining heater cock to heater cock bracket.

4. Remove four screws retaining heater bracket to heater control. Remove heater bracket.

5. Remove two screws retaining capillary tube bracket to heater control. Then take out capillary tube. Heater cock can then be taken out.

Note:

- a. Make sure that capillary tube is neither twisted nor excessively bent.
- b. When bending capillary tube, be sure that heater cock is fully open so as to prevent change in heater cock operation.

6. Remove screws retaining heater cock bracket to heater unit and disconnect to heater unit.

7. Loosen hose clamps on heater core side and disconnect hose from heater core. Heater cock bracket and hose connector can then be taken out.

8. Disconnect floor door rod from floor door.





Fig. BE-94 Disconnecting floor door rod

9. Remove screws retaining heater unit cover to heater unit and detach cover.

10. Pull heater core out.

Note: Be sure to detach heater unit with floor door opened. Failure to do so may scratch heater core.

Fan unit



BE064B

Fig. BE-95 Disassembling fan unit

1. Remove fan unit, referring to previous section.
2. Remove screw retaining air intake duct hose to blower housing and take out duct hose
3. Remove three screws retaining fan motor to blower housing. Fan motor can then be taken out
4. Remove two screws retaining resistor to blower housing. Resistor with harness can then be taken out through the hole in which fan motor is installed
5. Remove four screws retaining intake duct to blower housing. Intake duct can then be taken out
6. Assembly is in the reverse sequence of disassembly

HEATER ILLUMINATION BULB REPLACEMENT

1. Remove heater control. For removal procedure, refer to the previous section
2. Take out socket with bulb from behind heater control and remove bulb from socket
3. Install new bulb and then assemble in the reverse sequence of removal. See Figure BE-92.

Bulb wattage:

Heater control


illumination bulb 3 4W

ADJUSTMENT

When a new or reconditioned heater unit is installed, observe the following.

Note:

- a. Make sure that cables are neither twisted nor excessively bent
- b. Be careful not to bend wires when inserting into pin
- c. Be sure to secure cable outer after it is pushed toward heater control.
- d. Tighten clamps and clips securely and make sure that control lever functions properly.



BE021B


Fig. BE-96 Inserting wire into pin

Air intake door

1. Set AIR lever in OFF position.
2. Close air intake door and fasten cable outer with clamp.

BE-51

Note: Make sure that the tip end of cable outer is not exposed beyond 10 mm (0.39 in) at clamp location.



BE022B


- 1 Air intake door lever
- 2 Clamp
- 3 Cable

Fig. BE-97 Adjusting air intake door

Mode door

1. Place AIR lever in HEAT position
2. With mode door lever moved toward the dash panel side fasten control rod with screw.

Note: Make sure that AIR lever and mode door lever are in HEAT position.



- 1 Mode door lever
- 2 Mode door rod

BE023B

Fig. BE-98 Adjusting mode door


Body Electrical System

Floor door

1. Place AIR lever in DEF position.
2. Move floor door lever to DEF position, and set lead wire at door lever.
3. Fasten cable outer with clamp with the tip end of the cable outer exposed 2 mm (0.8 in) beyond clamp.

Note:

- a. Make sure that AIR lever and floor door lever are moved to DEF position.
- b. Make sure that doors are closed when connecting cables.



- 1 Floor door lever
- 2 Clamp
- 3 Cable

BE024B


Fig. BE-99 Adjusting floor door

Heater cock

1. Place TEMP lever in HOT position.
2. Pull heater cock lever toward you (HOT), and set cable wire at cock lever.
3. Fasten cable outer with clip.

Note:

- a. Make sure that TEMP lever and heater cock lever are in HOT position.
- b. If heater cock is not set properly, warm air may flow into the compartment when not desired.



BE025B

Fig. BE-100 Adjusting heater cock

INSPECTION

Inspect all parts of heater box for damage. Refer to Trouble Diagnoses and Corrections. For electrical system, check wiring, fan switch resistor and fan motor for continuity.

If fan motor fails to rotate check following items.

1. Fuse and fusible link.
2. To check for burned out fuse, follow same procedure as for ordinary fuses using a circuit tester or test lamp.
3. Loose wire connection

Fan motor power supply

1. Disconnect lead wires from connector.
2. Move ignition switch to DEF position.
3. Connect test lamp lead to "LY" color wire terminal in connector plug on dash harness side and to ground.
4. Make sure test lamp comes on.

Fan motor

1. Disconnect lead wires from connector.
2. Move ignition switch to DEF position.
3. Connect test lead to position of fuse block power supply and to terminal in connector plug on motor side. Another terminal on motor, must be connected to (body earth).
4. Make sure fan motor operates in each fan lever position.


Fan switch

Test continuity through the switch at each step with test lamp or meter.

Refer to following continuity diagram for fan switch.



Wiring system

Test system continuity with meter or test lamp. Refer to fan wiring diagram for heater and fan motor lamp.



	OFF	LOW	Me
1			
2			
3			
4			

Heater



COLOR CODE

B	Black
W	White
WR	White with red stripe
L	Blue
LB	Blue with black stripe
LW	Blue with white stripe
LR	Blue with red stripe
LY	Blue with yellow stripe

BE677B

Fig. BE-102 Circuit diagram for heater

CONNECTOR	COLOR	CODE
C- 1 : Blue	B	Black
C- 6 : Black	W	White
C- 9 : White	WR	White with red stripe
C-10 : White	RL	Red with blue stripe
	GW	Green with white stripe

TROUBLE DIAGNOSES AND CORRECTIONS

Condition	Probable cause	Corrective action
Insufficient heating performance No heated air discharged.	Cooling water temperature too low Heater core plugged. Insufficient cooling water level. Water cock not operating properly. Mode door not operating properly.	Check thermostat. Replace as necessary. Clean. Refill Adjust control cable Adjust control cable.
Insufficient air flow to floor.	Fan motor speed too low. Floor door and mode door not operating properly.	Check motor terminal voltage. Repair poor connection and discontinuity. Replace motor if necessary. Adjust control cable.
Insufficient defrosting performance. Cold air discharged.	Refer to "No heated air discharged".	
Insufficient air flow to defroster.	Floor door and mode door not operating properly (or seal damaged) Defroster nozzle plugged. Leak at defroster duct-to-nozzle connection	Adjust control cable. Clean. Correct
Heated air discharged with lever in VENT.	Water cock not operating properly Mode door not operating properly (or seal damaged).	Adjust control cable. Adjust control cable.
Failure of fan to run.	Fuse melted. Motor wire connector disconnected. Switch damaged Motor damaged	Replace. Correct. Replace. Check and correct.
Control lever drags.	Inner wire rubbing against outer case end Control cable bent excessively. Doors, door levers, etc. not operating properly.	Adjust control cable. Correct. Check and correct.
Outside air comes in with fan in OFF.	Air intake door not operating properly. Control cable out of adjustment.	Repair or replace. Adjust control cable.
Noise from fan motor	Unusual noise from fan motor.	Check and tighten loose bolts.

Body Electrical System

HORN

DESCRIPTION

The horn electrical system consists of a horn switch, a horn relay, two horns and lead wires connecting these parts to each other. Horn is dual type; one is for low tone and the other for high tone. They can be distinguished by the letter L or R printed on their body. Horn relay is installed on relay bracket.

REMOVAL AND INSTALLATION

Horn

A pair of horns are installed in front of radiator.

1. Disconnect horn lead wire at connector.
2. Loosen a screw retaining horn to bracket.
3. Installation is in the reverse sequence of removal.




Fig. BE-104 Removing horn

Horn switch

The horn switch is an integral part of steering column.

The combination switch has a lead wire for horn, so refer to Figure BE-41 for combination switch.

Horn relay

The horn relay is installed on relay bracket.

1. Disconnect battery ground cable.
2. Disconnect three lead wires for horn relay at connectors.
3. Remove screw retaining horn relay to relay bracket. Horn relay can

then be taken out.

4. Installation is in the reverse sequence of removal.

INSPECTION

Test system continuity with test lamp or ohmmeter. Refer to Figure BE-105 for horn system. When testing horn relay, there must be continuity between ①-②. When 12V current is given to ①-②, there must be continuity between ①-③.







Fig. BE-105

TROUBLE DIAGNOSES AND CORRECTIONS

Condition	Probable cause	Corrective action
Horn does not operate.	Discharged battery. (Measure specific gravity of electrolyte.) Burnt fuse. Faulty horn button contact. [Horn sounds when horn relay terminal ① is grounded.] Faulty horn relay. [Horn sounds when ② and ③ horn relay terminals are connected with a test lead.] Faulty horn or loose horn terminal connection.	Recharge or replace battery. Correct cause and replace fuse. Repair horn button Replace horn relay. Correct horn terminal connection or replace horn.
Horn sounds continuously.	Short-circuited horn button and/or horn button lead wire. [When black lead wire is disconnected from horn relay terminal ①, horn stops sounding.] Faulty horn relay.	Repair horn button or its wiring. Replace horn relay.
Reduced volume and/or tone quality.	Loose or poor connector contact. (Fuse, relay, horn and/or horn button.) Faulty horn.	Repair. Replace.

Body Electrical System

Horn



WINDSHIELD WIPER AND WASHER

DESCRIPTION

The windshield wiper and washer system consists of a wiper motor, wiper links and arms, washer nozzles, a washer tank, a washer motor, an intermittent amplifier and a wiper switch. The wiper switch is an integral part of combination switch. Washer motor operates when the knob at the top end of combination switch lever is pressed into the lever. The wiper system also has an intermittent amplifier.

This wiper system is equipped with a rise-up mechanism. Wiper motor revolves reversely for one turn at the end of use with the aid of relay. Then, wiper linkage varies in length and stops wiper blades at lower position than normal wiping area.

Both the wiper motor and the intermittent amplifier have contacts. Refer to Figures BE-118 through BE-120. The motor contacts are con-

trolled by the wiper switch, while amplifier contacts are controlled by an integrated circuit in the amplifier, that is, electric current flowing through the coil (RL) is not powerful enough to switch the contacts in the amplifier.


When the condenser (C_2) is charged with electric current flowing through the coil (RL), however, the transistors (Tr_1 and Tr_2) switch on and electric current increases. The contacts are then changed.

Amplifier contacts are for bypassing the auto-stop mechanism in the wiper motor. Consequently, when the amplifier contacts change, the motor begins to rotate. The condenser (C_2) discharges electric current as the wiper link rotates one turn and the contacts revert to their original position. Wiper motor then stops with the


aid of the auto-stop mechanism

When the condenser is re-charged, the motor starts again. Wiper motor contacts are for changing rotating direction, normal rotation or reverse rotation. When the wiper switch is turned off, the motor contacts change. Consequently as soon as the switch is turned off, the motor begins to rotate reversely and stops. If a washer is in use, condensers (C_1 and C_2) are charged with electric current through washer motor circuit and change contacts in amplifier; wiper motor thus rotates without auto-stop mechanism.

If washer motor is stopped, condensers (C_1 and C_2) begin to discharge electric current. The amplifier contacts revert back to their original positions and the wiper motor stops with the aid of auto-stop mechanism.




- 1 Windshield wiper motor assembly
- 2 Auto-stop mechanism
- 3 Windshield wiper blade
- 4 Windshield wiper arm



ADJUSTMENT

Wiping area



Unit: mm (in)

BE637B

Fig. BE-108 Wiping area

To adjust wiping area, loosen arm set nut and adjust blade to correct installation angle to obtain correct sweeping zone as sketched in figure above.

Then, secure nut at specified tightening torque.

Tightening torque

Wiper blade arm lock nut:


0.8 to 1.0 kg-m

(5.8 to 7.2 ft-lb)

Nozzle direction

Adjust nozzle direction so that fluid is sprayed in proper range by bending nozzle with screwdriver. This adjustment can be carried out through cowl top grille

* Adjusting range 100 (3.9) dia.



REMOVAL AND INSTALLATION

Wiper arm and wiper blade

Remove arm and blade assembly from pivot in this sequence.

1. Raise wiper blade from windshield glass
2. Unscrew arm set nut. Arm can then be pulled off pivot.
3. Install in reverse sequence of removal.

Note: Be sure to install arm and blade assembly in correct peak position. Position of blade can be adjusted when pushing it onto pivot.


Tightening torque:

Arm set nut:

0.8 to 1.0 kg-m

(5.8 to 7.2 ft-lb)

To remove blade, raise tab to unlatch blade lock and pull blade off top end of arm.



Wiper motor and linkage

1. Remove wiper arm, refer previous section.
2. Open hood, and disconnect motor connector.




Fig. BE-111 Connector

3. Remove cowl top grille, removing cowl top retaining screws.





Fig. BE-112 Wiper

4. Remove four screws and wiper motor bracket.

The bracket with wiper motor then be taken out. Refer to BE-112.


5. Remove three screws and pivot.

6. The linkage can then be taken out easily. Refer to Figure BE-113.



Washer nozzle

1. Remove washer nozzle fixing screws from cowl top panel
2. Take out washer nozzle with tube.
3. Install in reverse sequence of removal.



- 1 Nozzle
- 2 Windshield washer motor
- 3 Windshield washer tank

Fig. BE-114 Washer nozzle

Washer pump and tank

The washer pump is installed at bottom of washer tank.

1. Remove washer tank with washer motor from tank bracket in engine room.
2. Disconnect two washer pump lead wires at connectors.
3. Remove hoses from washer pump and drain washer fluid.
4. Separate washer pump from washer tank
5. Install washer tank and motor assembly in reverse sequence of removal.

Note: In assembling washer motor and washer tank, it is recommended that soapy water be used to facilitate the operation.

CAUTION:

- a. Be sure to use only windshield washing solution. Never mix soap powder or detergent with solution.
- b. To avoid improper windshield washer operation, do not operate windshield washer continuously for more than 30 seconds or without washer fluid. Normally, windshield washer should be operated for 10 seconds or less at one time.






Fig. BE 115 Washer pump and tank



- 1 Intermittent wiper amplifier
- 2 Rear defogger relay
- 3 Ignition relay
- 4 Horn relay
- 5 Timer unit



Wiper switch

Wiper switch and washer switch are integral parts of combination switch, so, refer to page BE-24 for Removal of Combination Switch

Intermittent wiper amplifier

The intermittent wiper amplifier is installed on relay bracket.

1. Disconnect connectors for intermittent wiper amplifier.
2. Remove intermittent wiper amplifier retaining screws.

Then, intermittent wiper amplifier can be taken out of bracket.

3. Installation is in the reverse sequence of removal.

INSPECTION

Check operation of each part of wiper system and test continuity of system with ohmmeter or test lamp

For electrical wiring, refer to Figures BE-117 through BE-120 for windshield wiper circuit diagram.




Fig. BE-116 Intermittent wiper amplifier

Body Electrical System

TROUBLE DIAGNOSES AND CORRECTIONS


Condition		Probable cause		Corrective action
Windshield wiper does not operate.	Motor	No current flows to motor due to: Broken armature. Worn motor brush. Motor is overheated due to seized motor shaft. Windshield wiper fuse (20A) is easily fused due to short-circuit, rate short-circuit, or inside motor component burnt.		Replace motor. Replace motor. Replace motor. Replace motor or repair short-circuit part.
	Power supply and cable	Blown fuse due to problem in other part of windshield wiper circuit. Loose, open or broken wiring Erroneous wiring. Improper grounding.		Check other part for operation rect problem. Check wiring near motor and correct for proper connection. Correct if necessary. Check each wire for color code correct if necessary. Correct.
	Switch	Improper switch contact.		Correct
	Link	Foreign materials interrupt movement of windshield wiper circuit. Disconnected link rod. Seized or rusted arm shaft.		Correct. Correct. Lubricate or replace arm shaft.
	Windshield wiper blade	Windshield wiper blade sticks on windshield glass.		Raise arm and operate windshield wiper without applying load. Clean windshield glass and/or wiper blade.
Windshield wiper speed cannot be adjusted correctly.	Motor	Low or high speed motor brush is worn.		Replace motor.
Windshield wiper does not stop correctly.	Stops anywhere.	Motor	Contaminated auto-stop relay contacts or improper contact due to foreign matter.	Remove auto-stop device cover, and clean contacts carefully so as not to damage relay plate.
		Cable and switch	Improper connection between 1st and 2nd switch steps.	Remove switch, and make sure 1st and 2nd steps are not connected. "OFF" position. If connected, replace switch

Body Electrical System

Condition	Probable cause		Corrective action
Windshield wiper operating speed is too slow.	Motor	With arm raised, excessive current still flows due to layer short-circuit of motor armature Windshield wiper stops when lightly held with hand due to worn motor brush. With arm raised, excessive current still flows (3 to 5A) due to seized motor shaft.	Replace motor Replace motor. Replace motor or lubricate bearing with engine oil.
	Power supply and cable	Low source voltage.	Measure voltage, check other electrical parts for operation, and take corrective action for power supply if necessary.
	Link	Humming occurs on motor in arm operating cycle due to seized arm shaft.	Lubricate or replace.
	Switch	Improper switch contact.	Conduct continuity test, and replace if necessary.


Body Electrical System

Windshield washer




Body Electrical System


"High" position



"Low" position



Wiper




BE644B

Fig. BE-120 Circuit diagram for windshield wiper

CLOCK

DESCRIPTION

The clock is installed on instrument panel; removal procedure is the same as for the other two gauges. It has a connector with four terminals. The illumination bulb can be easily taken out by pulling socket from back of clock.




BE534C

Fig. BE-123 Clock

REPLACEMENT

Clock

1. Remove four screws retaining instrument finisher to instrument panel. Take out instrument finisher a little and disconnect two connectors. Instrument finisher can then be taken out. See Figure BE-82.
2. Remove six screws retaining three-way venti-duct to instrument panel.
3. Disconnect duct hoses from three-way duct and take out three-way duct.
4. Remove screw retaining clock to instrument panel.



BE117A

Fig. BE-124 Removing clock retaining screw

5. Take out clock backward and disconnect lead wires at connector. Clock can then be taken out.

Bulb replacement

The illumination bulb can be easily taken out by pulling socket with bulb at back of clock.

Remove bulb from socket and install new bulb.


Assemble in reverse sequence of removal.

Bulb wattage:

Clock illumination bulb . . 3.4W

INSPECTION

Test continuity and operation of each unit with ohmmeter or test lamp. Refer to Figure BE-125 for circuit diagram of clock.



BE648B

Fig. BE-126 Defogger switch and warning lamp

WARNING LAMP BULB REPLACEMENT

1. Remove console box, referring to Section BF.

2. Push socket with bulb behind warning lamp body and twist it counterclockwise.



Socket with bulb can then be taken out.

3. Remove bulb from socket.

4. Install new bulb. Assembly is in the reverse sequence of removal.

Bulb wattage.

Rear window defogger warning lamp 1.4W



BE439B

- 1 Intermittent wiper amplifier
- 2 Rear defogger relay
- 3 Ignition relay
- 4 Horn relay
- 5 Timer unit


BE649B

Fig. BE-127 Defogger relay

INSPECTION

Defogger switch

Test continuity of switch by using test lamp or ohmmeter. Test must be carried out with switch at both ON and OFF. Refer to Figure BE-126 for continuity diagram of defogger switch.



BE537

Fig. BE-128 Broken filament

Body Electrical System

Defogger relay

Test continuity of relay with ohmmeter or test lamp. Refer to Figure BE-127 for defogger relay. In testing relay, there must be continuity between ③-④. When 12V direct current is applied to ③ ④, there must be continuity between ①-②.

Rear window filaments

Rear window defogger filament can be inspected for circuit breaks by one of three methods.

Method 1:

Start engine and turn on window defroster system. If area around a specific filament is not defogged, that line is broken.

Method 2:

Start engine and turn on window defroster system. With a direct-current voltmeter setup shown in Figure BE-129, check each heat wire for discontinuity. If meter indicates 12 volts or 0 on a specific wire, that line is broken. (Normal indication: 6 volts)

Break in that line can then be detected by moving positive lead of meter along line until an abrupt variation in meter indication is encountered




Fig. BE-129 Checking for broken filament with d-c voltmeter

Method 3:

With an ohmmeter setup shown in Figure BE-130, place one lead at one end of a heat wire and other in middle section of that wire. If meter registers, on a specific grind line, a value twice as much as on any other line, that line is broken.

Break in that line can then be




Fig. BE-130 Checking for broken filament with ohmmeter

FILAMENT MAINTENANCE

Repair equipment

1. Conductive silver composition (Dupont No. 4817)
2. Ruler, 30 cm (12 in) long
3. Drawing pen
4. Heat gun
5. Alcohol
6. Cloth




Fig. BE-131 Locating ruler in position

Repair procedure

1. Wipe broken heat wire and its surrounding area clean with a cloth




Fig. BE-133 Incorrect and correct deposition of silver composition

6. Apply a constant stream of hot air directly to the repaired area for approximately 20 minutes with a heat gun. A minimum distance of 3 cm (1.18 in) should be kept between

dampened in alcohol.

2. Apply a small amount of silver composition to the break with a drawing pen.

Note: Shake silver composition container before use.

3. Place ruler on glass along line to be repaired as shown in Figure BE-131. Deposit conductive silver composition on break with drawing pen. Slightly overlap existing composition on both sides [5 mm (0.20 in) or more] of the break.

4. Wipe clean silver composition from tip of drawing pen.

5. After repair has been completed, check repaired wire for continuity. This check should be conducted 10 minutes after silver composition is deposited.

Note: Do not touch repaired area while test is being conducted.





Fig. BE-132 Deposition of silver composition

Instruction after repair

Wiper repaired area clean with soft, clean cloth.

Rear window defogger



BE650B

Fig. BE-134 Circuit diagram for rear window defogger

Body Electrical System

RADIO

DESCRIPTION

The radio system consists of an antenna, speakers, a radio receiver and an antenna switch.

Antenna is connected to radio receiver with feeder cable. Speaker is connected to radio receiver with pair of speaker harnesses. Radio receiver is installed on console box.

Speaker is installed on body side.

Antenna trimmer adjustment is required for best radio performance.

Antenna trimmer adjustment is required for best radio performance.

A fuse is added on harness midway from ignition switch.

Antenna switch is installed on radio receiver.

- 1 Knob
- 2 Escutcheon
- 3 Radio receiver
- 4 Antenna feeder cable
- 5 Auto antenna switch




Fig. BE-135 Removing radio

REMOVAL AND INSTALLATION

Radio receiver

1. Remove console box, referring to Section BF.
2. Disconnect lead wires for radio and antenna switch at two connectors. Feeder cable is also removed.
3. Pull out dials on radio receiver and remove two nuts retaining escutcheon to radio receiver.
4. Remove two screws retaining radio receiver to console box. Radio receiver can then be taken out.
5. Installation is in the reverse sequence of removal.





Fig. BE-136 Antenna

Antenna switch

1. Remove console box and escutcheon as previously described.
2. Remove antenna switch retaining screw and switch can then be taken out from radio receiver.
3. Installation is in the reverse sequence of removal.

Antenna


1. Remove body side rear trim and disconnect lead wires at connectors.



3. Remove bolt retaining antenna bracket to body panel. Antenna can then be taken out.
4. Installation is in the reverse order of removal.

Speaker

1. Remove body side trim and disconnect lead wires at connectors.
2. Remove four mounting screws retaining speaker.
3. Take out speaker.
4. Installation is in the reverse sequence of removal.



- 1 Speaker cable (R.H.)
- 2 Speaker (R.H.)
- 3 Body side trim
- 4 Quarter panel garnish
- 5 Speaker cable (L.H.)
- 6 Speaker (L.H.)
- 7 Antenna feeder cable

BE437C

Fig. BE-138 Removing speaker

ANTENNA TRIMMER ADJUSTMENT

When a new radio receiver, antenna or antenna feeder cable is installed, antenna trimmer should be adjusted.

1. Extend antenna completely.
2. Tune in weakest station between 12 and 16 (1,200 to 1,600 Hz) on dial.

Note: Noise may be generated but disregard it.

3. Turn antenna trimmer to right and left slowly with screwdriver and set it where receiving sensitivity is best.




Fig. BE-139 Trimmer adjust screw

INSPECTION

If radio does not work, test continuity through the system with ohmmeter or test lamp. When testing, refer to Figure BE-136 for continuity diagram of antenna switch and Figure BE-140 for wiring diagram of radio system.

If noise is generated, refer to Noise Prevention Chart.

Note:

When installing wireless telegraph, pay attention to the following items.

- a. Be sure to separate antenna cable more than 2 inches (50.8 mm) from electronic fuel injection control unit and transistor ignition unit.
- b. Make sure that radio interference does not cause engine malfunction.

Body Electrical System

TROUBLE DIAGNOSES AND CORRECTIONS

Noise prevention chart

Position car in an open area away from steel buildings, run engine, extend antenna to its maximum length, set control to maximum and set dial at a medium point without catching broadcasting wave.

Condition	Probable cause	Corrective action
Ignition system Noise occurs when engine is operated.	High tension cable Ignition coil.	Install new high tension cable. Replace a 0.5 μ F radio condenser of primary terminal of ignition coil. Note: Be careful not to install capacitor on secondary or primary breaker side, otherwise engine operation becomes improper.
Charging system. Sound of alternating current present. When accelerator pedal is depressed or released, noise occurs.	Alternator.	Replace a 0.5 μ F capacitor to charging terminal or charge warning terminal L. Note: Do not use a larger capacitor.
Fuel system When ignition switch is set to "ON", noise occurs.	Electric fuel pump.	Install a 0.5 μ F capacitor to power lead connector plug of electric fuel pump.

Note:

a. Be sure to locate capacitor as close to noise source as possible and connect in parallel.

b. Cut lead wire as short as possible.


c. Ground wire should be attached securely to body.

d. Make installation and connections

securely.

e. Carefully identify "+", "-", or "OUT" marks.

Radio system



8E438C

Fig. BE-140 Circuit diagram for radio and antenna

THEFT PROTECTION SYSTEM

DESCRIPTION

This system consists of an ignition switch, a door switch and a buzzer and is designed to prevent driver from leaving car without taking key. When L.H. door is opened with ignition key still in ignition switch, buzzer sounds.

REMOVAL AND INSTALLATION

Door switch

Door switch is located on L.H. front door pillar.

1. Withdraw switch and wire assembly from front pillar.
2. Disconnect lead wire at connectors, switch can then be taken out.
3. Installation is in the reverse sequence of removal.

Ignition switch

To make switch tamper-proof, self-shear type screws are used. Their heads are sheared off when installed so that the steering lock system cannot be easily removed.

When required, replace the steering lock in accordance with the following instructions.

Break self-shear type screws with a drill or other proper tool, then remove the steering lock from the steering lock clamp.

When installing a new steering lock, be sure to tighten new self-shear type screws until their heads shear off.

Warning buzzer

The warning buzzer is installed behind speedometer on bracket from instrument panel.

1. Disconnect battery ground cable.
2. Remove speedometer as described in page BE-37 for Meter and Gauge Replacement.




Fig. BE-141 Door






Fig. BE-142 Ignition

4. Remove screw retaining buzzer assembly to bracket through the hole in which speedometer is installed.
5. Buzzer assembly can then be taken out.
6. Installation is in the reverse sequence of removal.








INSPECTION

Body Electrical System

Theft protection system



CONNECTOR

C-1 : Blue
C-5 : White
C-9 : White

COLOR CODE

B : Black
BY : Black with yellow stripe
W : White
WR : White with red stripe
RW : Red with white stripe

SEAT BELT WARNING SYSTEM

DESCRIPTION

This system consists of an ignition switch, a timer unit, a warning light, a driver's seat belt switch and a warning buzzer, and is designed to remind the driver to buckle his seat belt.

When the ignition switch is turned to the "ON" position, the warning light comes on and remains on for 4 to 8 seconds. At the same time, the warning buzzer sounds for 4 to 8 seconds intermittently if the driver's seat belt is not fastened properly. The buzzer is also used as a theft warning buzzer.

REMOVAL AND INSTALLATION

Ignition switch and warning buzzer

Refer to pages BE-26 and BE-78 for Removal and Installation.

Timer unit


1. Disconnect all connectors from junction block and remove junction block from bracket.

Disconnect lead wires for timer unit at a connector.

2. Remove two screws retaining timer unit.

Timer unit can then be taken out easily.

3. Installation is in the reverse sequence of removal.



- 1 Intermittent wiper amplifier
- 2 Rear defogger relay
- 3 Ignition relay
- 4 Horn relay
- 5 Timer unit


BE439B

Fig. BE-146 Timer unit

Driver's seat belt switch

The belt switch is an integral part of the inner lap belt so the switch and seat belt must be replaced as an assembly.

1. Slide seat all the way forward.
2. Remove seat belt securing bolt.
3. Disconnect lead wires at connector.
4. Seat belt can then be taken out.
5. Installation is in the reverse sequence of removal.




BE657B

Fig. BE-147 Seat belt switch


Warning lamp body

1. Remove console box. Refer to Section BF.
2. From behind console box, grasp nail of lamp body and push it out of console box.
3. Disconnect lead wires at connector.
4. Installation is in the reverse sequence of removal.



BE439C

- 1 Rear defogger warning lamp
- 2 Seat belt warning lamp



- 1 Lamp body
- 2 Bulb
- 3 Socket

Fig. BE-148 Seat belt warning lamp

Body Electrical System

WARNING LAMP BULB REPLACEMENT

1. Remove console box. Refer to Section BF.
2. Push socket and bulb behind warning lamp body and twist it counterclockwise. Socket and bulb can then be taken out as an assembly.
3. Remove bulb from socket.
4. Install new bulb in the reverse sequence of removal.

Bulb wattage:

Seat belt warning lamp 1.4W

INSPECTION

Warning buzzer

Refer to page BE-79 for Warning Buzzer Inspection.

Timer unit

Test timer unit with a power source of 12V D.C. and test lamp, following the procedures below.

1. Connect terminal ③ to negative terminal of power source, terminal ② to test lamp terminal and the other test lamp terminal to negative terminal of the power source.
2. Contact terminal ① to positive terminal of power source, and test lamp will glow.
3. Test lamp should remain on for 4 to 8 seconds and then go out.





Fig. BE-149 Inspecting t

Belt switch

Test continuity between wires from seat belt switch w meter or test lamp.

Seat belt warning system




8E66QB

Fig. BE-150 Circuit diagram for seat belt warning system

KICKDOWN SYSTEM (For automatic transmission models only)

DESCRIPTION

The kickdown system consists of a kickdown switch and a kickdown solenoid. Kickdown switch is located on the accelerator pedal. Kickdown solenoid is located on left side of automatic transmission. They are connected to each other. For details on automatic transmission, refer to section Automatic Transmission.



BE776





Fig. BE-152 Kickdown



- 1 Steering column
- 2 Accelerator pedal rod

BE116A

Fig. BE-151 Kickdown switch

REPLACEMENT

Kickdown switch

1. Disconnect pair of lead wires.
2. Loosen lock nut on switch body.
3. Remove kickdown switch by rotating switch body.
4. Install in reverse sequence of removal.

Kickdown solenoid

Refer to Section AT for Removal of Kickdown Solenoid.

INSPECTION

Kickdown switch

The switch plunger is controlled by the accelerator pedal. When the plunger is pressed into the switch assembly, the switch contacts are closed.

Therefore there must be contact between the plunger and the switch body only when the plunger is pressed into the switch body.

Kickdown solenoid

Refer to Section AT for Inspection of Kickdown Solenoid

Wiring

Referring to the following wiring diagram, test continuity with an ohmmeter or test lamp.

STARTING SYSTEM (For automatic transmission models only)

DESCRIPTION

The starting system consists of an ignition relay, an inhibitor switch and an inhibitor relay.

The inhibitor switch is located on right side of automatic transmission case. The inhibitor relay is located on the engine compartment relay bracket.




REPLACEMENT

Inhibitor switch

Refer to Section AT.

Inhibitor relay

1. Disconnect battery ground cable.
2. Remove relay bracket and relay bracket cover.
3. Remove harness connector.
4. Remove relay attaching screws.
5. Install relay in the reverse order of removal.



- 1 Fuel pump control relay
- 2 Fuel pump relay
- 3 Electronic fuel injection relay
- 4 Air conditioner relay
- 5 Inhibitor relay

Fig. BE-154 Inhibitor relay

INSPECTION

Inhibitor switch

Refer to Section AT.


Inhibitor relay

Test continuity through relay with an ohmmeter in accordance with the following chart.


Check terminal	Normal Condition	12V direct current is applied between terminals ① and ②
	Test results : Continuity	
① - ④	Yes	—
② - ③	No	Yes

Body Electrical System


Engine room harness



- 1 To horn
- 2 To terminal block
- 3 To condenser
- 4 To check connector
- 5 To thermal transmission
- 6 To engine earth
- 7 To body earth
- 8 To magnet clutch (For air conditioner)
- 9 To ignition coil and resistor
- 10 To B.C.D.D. cut solenoid
- 11 To side marker lamp (L.H.)
- 12 To head lamp (L.H.)
- 13 To clearance and turn signal lamp (L.H.)



DETAIL "B"



DETAIL "C"


- 1 To clearance and turn signal lamp (R.H.)
- 2 To horn
- 3 To headlamp (R.H.)
- 4 To side marker lamp (R.H.)
- 5 To magnet valve F.I.C.D. and magnet valve vacuum source (For air conditioner)
- 6 To pressure switch (For air conditioner)
- 7 To fusible link box
- 8 To inhibitor relay (A/T only)
- 9 To compressor relay (For air conditioner)
- 10 To fuel pump relay
- 11 To fuel pump control relay
- 12 To starter motor
- 13 To engine earth
- 14 To oil pressure sending unit
- 15 To alternator
- 16 To condenser


BE442C

Fig. BE-156 Wiring harness-Engine room

Body Electrical System

Instrument harness






BE445C


Fig. BE-157 Wiring harness-Instrument

Body Electrical System

Dash harness and console harness



DETAIL "E"



BE443C

Fig. BE-158 Wiring harness—Dash

EMISSION WARNING SYSTEM (For California)

CONTENTS

FLOOR TEMPERATURE WARNING
SYSTEM (For California) BE-94

WARNING LAMP
TROUBLE SHOOTING GUIDE

FLOOR TEMPERATURE WARNING SYSTEM (For California)

The floor temperature warning system consists of a floor temperature sensing switch installed on the car's floor, a floor temperature relay, a floor temperature warning lamp and harnesses.

When the floor temperature rises to an abnormal level, the warning lamp will come on to call the attention of the driver.

The warning lamp also comes on during operation of the starter motor, permitting inspection of the lamp's condition. The lamp goes out after the engine starts.

Refer to Section EC for details.

WARNING LAMP

Bulb replacement

1. Pull heater control knobs off.
2. Remove four screws retaining instrument finisher to instrument panel.
3. Pull instrument finisher forward slightly, and disconnect lead wires at three connectors. Instrument finisher can then be removed from instrument panel.

Note: Three connectors are for map lamp, fuel warning lamp and floor temperature warning lamp (California models).

4. Twist socket behind warning lamp and take out socket with bulb.
5. Installation is in the reverse sequence of removal.


Bulb wattage:

Lamp body replacement


1. Pull heater control knobs off.
2. Remove four screws retaining instrument finisher to instrument panel.
3. Pull instrument finisher forward slightly, and disconnect lead wires at three connectors. Instrument finisher can then be removed from instrument panel.

Note: Three connectors are for map lamp, fuel warning lamp and floor temperature warning lamp (California models).

4. Remove two screws retaining warning lamp body to instrument finisher. Lamp body can then be removed.
5. Installation is in the reverse sequence of removal.



BE656A




- 1 Floor temperature warning lamp
- 2 Map lamp
- 3 Fuel warning lamp

TROUBLE DIAGNOSES AND CORRECTIONS

Condition	Probable cause	Corrective action
Warning lamp does not light in "START" position of ignition switch.	Burnt or loose bulb. Faulty floor temperature relay. Loose connection or open circuit.	Replace bulb or correct bulb socket. Conduct continuity test and repair or replace. Refer to "EC" section. Check wiring and/or repair if necessary.

Floor temperature warning system



BE444C

Fig. BE-160 Circuit diagram for floor temperature warning system