

INL

SECTION

INTERIOR LIGHTING SYSTEM

CONTENTS

BASIC INSPECTION	4	BATTERY SAVER : CONSULT Function (BCM - BATTERY SAVER)	25
DIAGNOSIS AND REPAIR WORK FLOW	4	DTC/CIRCUIT DIAGNOSIS	27
Work Flow	4	POWER SUPPLY AND GROUND CIRCUIT	27
SYSTEM DESCRIPTION	7	TOTAL ILLUMINATION CONTROL UNIT	27
INTERIOR ROOM LAMP CONTROL SYSTEM	7	TOTAL ILLUMINATION CONTROL UNIT : Diagnosis Procedure	27
System Diagram	7	BCM	27
System Description	7	BCM : Diagnosis Procedure	27
Component Parts Location	11	INTERIOR ROOM LAMP POWER SUPPLY CIRCUIT	29
Component Description	12	Description	29
INTERIOR ROOM LAMP BATTERY SAVER SYSTEM	13	Diagnosis Procedure	29
System Diagram	13	BATTERY SAVER SIGNAL CIRCUIT	31
System Description	13	Description	31
Component Parts Location	14	Diagnosis Procedure	31
Component Description	15	HOSPITALITY LIGHTING POWER SUPPLY CIRCUIT 1	32
ILLUMINATION CONTROL SYSTEM	16	Description	32
System Diagram	16	Diagnosis Procedure	32
System Description	16	HOSPITALITY LIGHTING POWER SUPPLY CIRCUIT 2	35
Component Parts Location	17	Description	35
Component Description	18	Diagnosis Procedure	35
DIAGNOSIS SYSTEM (TOTAL ILLUMINATION CONTROL UNIT)	19	HOSPITALITY LIGHTING POWER SUPPLY CIRCUIT 3	37
CONSULT Function (TOTAL ILLUM C/U)	19	Description	37
DIAGNOSIS SYSTEM (BCM)	22	Diagnosis Procedure	37
COMMON ITEM	22	MAP LAMP CIRCUIT	39
COMMON ITEM : CONSULT Function (BCM - COMMON ITEM)	22	Description	39
INT LAMP	23	Component Function Check	39
INT LAMP : CONSULT Function (BCM - INT LAMP)	23	Diagnosis Procedure	39
BATTERY SAVER	25		

PERSONAL LAMP CIRCUIT	41	Diagnosis Procedure	65
Description	41		
Component Function Check	41		
Diagnosis Procedure	41		
CENTER CONSOLE INDIRECT ILLUMINATION CIRCUIT	43	DOOR SWITCH CIRCUIT	67
Description	43	Component Function Check	67
Component Function Check	43	Diagnosis Procedure	67
Diagnosis Procedure	43	ROOM LAMP REQUEST SIGNAL CIRCUIT ...	71
FOOT LAMP CIRCUIT	45	Component Function Check	71
Description	45	Diagnosis Procedure	71
Component Function Check	45	Diagnosis Procedure	72
Diagnosis Procedure	45	INTERIOR ROOM LAMP CONTROL SYSTEM	
PUDDLE LAMP CIRCUIT	48		73
Description	48	Wiring Diagram - INTERIOR ROOM LAMP -	73
Component Function Check	48	ILLUMINATION	90
Diagnosis Procedure	48	Wiring Diagram - ILLUMINATION -	90
MOOD LAMP (FRONT DOOR ARMREST) CIRCUIT	50	ECU DIAGNOSIS INFORMATION	105
Description	50	TOTAL ILLUMINATION CONTROL UNIT	105
Component Function Check	50	Reference Value	105
Diagnosis Procedure	50	Wiring Diagram - INTERIOR ROOM LAMP -	113
PUSH-BUTTON IGNITION SWITCH ILLUMINATION CIRCUIT	52	Wiring Diagram - ILLUMINATION -	130
Description	52	BCM (BODY CONTROL MODULE)	145
Component Function Check	52	Reference Value	145
Diagnosis Procedure	52	Wiring Diagram - BCM -	167
MOOD LAMP (REAR DOOR ARMREST) CIRCUIT	54	Fail-safe	182
Description	54	DTC Inspection Priority Chart	183
Component Function Check	54	DTC Index	184
Diagnosis Procedure	54	SYMPTOM DIAGNOSIS	186
HOSPITALITY ILLUMINATION CIRCUIT	56	INTERIOR LIGHTING SYSTEM SYMPTOMS..	186
Description	56	Symptom Table	186
Component Function Check	56	PRECAUTION	188
Diagnosis Procedure	56	PRECAUTIONS	188
STEP LAMP CIRCUIT	59	Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"	188
Description	59	Precautions For Xenon Headlamp Service	188
Component Function Check	59	Precautions for Removing Battery Terminal	189
Diagnosis Procedure	59	REMOVAL AND INSTALLATION	190
TAIL LAMP SIGNAL CIRCUIT	61	MAP LAMP	190
Description	61	Exploded View	190
Component Function Check	61	Removal and Installation	190
Diagnosis Procedure	61	Replacement	190
ILLUMINATION CONTROL SIGNAL CIRCUIT		VANITY MIRROR LAMP	191
.....	63	Exploded View	191
Component Function Check	63	Replacement	191
Diagnosis Procedure	63	ASHTRAY ILLUMINATION	192
MAP LAMP SWITCH CIRCUIT	65	Exploded View	192
Component Function Check	65	Replacement	192
		GLOVE BOX LAMP	193

Exploded View	193	Removal and Installation	199	
Replacement	193	Replacement	199	A
TOTAL ILLUMINATION CONTROL UNIT	194	PERSONAL LAMP	200	
Exploded View	194	Exploded View	200	B
Removal and Installation	194	Removal and Installation	200	
FOOT LAMP	195	Replacement	201	
DRIVER SIDE	195	PUDDLE LAMP	202	C
DRIVER SIDE : Exploded View	195	Exploded View	202	
DRIVER SIDE : Removal and Installation	195	LUGGAGE ROOM LAMP	203	D
DRIVER SIDE : Replacement	195	LUGGAGE SIDE	203	
PASSENGER SIDE	195	LUGGAGE SIDE : Exploded View	203	E
PASSENGER SIDE : Exploded View	196	LUGGAGE SIDE : Removal and Installation	203	
PASSENGER SIDE : Removal and Installation ...	196	LUGGAGE SIDE : Replacement	203	
PASSENGER SIDE : Replacement	196	BACK DOOR SIDE	203	F
MOOD LAMP	197	BACK DOOR SIDE : Exploded View	204	
FRONT DOOR ARMREST	197	BACK DOOR SIDE : Removal and Installation	204	G
FRONT DOOR ARMREST : Exploded View	197	BACK DOOR SIDE : Replacement	204	
FRONT DOOR ARMREST : Replacement	197	SERVICE DATA AND SPECIFICATIONS		H
REAR DOOR ARMREST	197	(SDS)	205	
REAR DOOR ARMREST : Exploded View	197	SERVICE DATA AND SPECIFICATIONS		I
REAR DOOR ARMREST : Replacement	198	(SDS)	205	
STEP LAMP	199	Bulb Specifications	205	J
Exploded View	199			K

INL

DIAGNOSIS AND REPAIR WORK FLOW

< BASIC INSPECTION >


BASIC INSPECTION

DIAGNOSIS AND REPAIR WORK FLOW

Work Flow

INFOID:0000000010584897

OVERALL SEQUENCE



JMKIA8652GB

DETAILED FLOW

Revision: 2015 February

INL-4

2015 QX70

DIAGNOSIS AND REPAIR WORK FLOW

< BASIC INSPECTION >

1.GET INFORMATION FOR SYMPTOM

1. Get detailed information from the customer about the symptom (the condition and the environment when the incident/malfunction occurs).
2. Check operation condition of the function that is malfunctioning.

>> GO TO 2.

2.CHECK DTC

1. Check DTC.
2. Perform the following procedure if DTC is detected.
 - Record DTC and freeze frame data (Print them out using CONSULT.)
 - Erase DTC.
 - Study the relationship between the cause detected by DTC and the symptom described by the customer.
3. Check related service bulletins for information.

Are any symptoms described and any DTC detected?

Symptom is described, DTC is detected>>GO TO 3.

Symptom is described, DTC is not detected>>GO TO 4.

Symptom is not described, DTC is detected>>GO TO 5.

3.CONFIRM THE SYMPTOM

Try to confirm the symptom described by the customer.

Also study the normal operation and fail-safe related to the symptom.

Verify relation between the symptom and the condition when the symptom is detected.

>> GO TO 5.

4.CONFIRM THE SYMPTOM

Try to confirm the symptom described by the customer.

Verify relation between the symptom and the condition when the symptom is detected.

>> GO TO 6.

5.PERFORM DTC CONFIRMATION PROCEDURE

Perform DTC CONFIRMATION PROCEDURE for the detected DTC, and then check that DTC is detected again. At this time, always connect CONSULT to the vehicle, and check self diagnostic results in real time. If two or more DTCs are detected, refer to DTC INSPECTION PRIORITY CHART, and determine trouble diagnosis order.

NOTE:

- Freeze frame data is useful if the DTC is not detected.
- Perform Component Function Check if DTC CONFIRMATION PROCEDURE is not included on Service Manual. This simplified check procedure is an effective alternative though DTC cannot be detected during this check.
If the result of Component Function Check is NG, it is the same as the detection of DTC by DTC CONFIRMATION PROCEDURE.

Is DTC detected?

YES >> GO TO 7.

NO >> Check according to [GI-47. "Intermittent Incident"](#).

6.DETECT MALFUNCTIONING SYSTEM BY SYMPTOM DIAGNOSIS

Detect malfunctioning system according to SYMPTOM DIAGNOSIS based on the confirmed symptom in step 4, and determine the trouble diagnosis order based on possible causes and symptom.

Is the symptom described?

YES >> GO TO 7.

NO >> Monitor input data from related sensors or check voltage of related module terminals using CONSULT.

7.DETECT MALFUNCTIONING PART BY DIAGNOSTIC PROCEDURE

DIAGNOSIS AND REPAIR WORK FLOW

< BASIC INSPECTION >

Inspect according to Diagnostic Procedure of the system.

Is malfunctioning part detected?

YES >> GO TO 8.

NO >> Check according to [GI-47, "Intermittent Incident"](#).

8. REPAIR OR REPLACE THE MALFUNCTIONING PART

1. Repair or replace the malfunctioning part.
2. Reconnect parts or connectors disconnected during Diagnostic Procedure again after repair and replacement.
3. Check DTC. If DTC is detected, erase it.

>> GO TO 9.

9. FINAL CHECK

When DTC is detected in step 2, perform DTC CONFIRMATION PROCEDURE again, and then check that the malfunction is repaired securely.

When symptom is described by the customer, refer to confirmed symptom in step 3 or 4, and check that the symptom is not detected.

Is DTC detected and does symptom remain?

YES-1 >> DTC is detected: GO TO 7.

YES-2 >> Symptom remains: GO TO 4.

NO >> Before returning the vehicle to the customer, always erase DTC.


INTERIOR ROOM LAMP CONTROL SYSTEM

< SYSTEM DESCRIPTION >

SYSTEM DESCRIPTION

INTERIOR ROOM LAMP CONTROL SYSTEM

System Diagram



System Description

INFOID:000000010584899

OUTLINE

INTERIOR ROOM LAMP CONTROL SYSTEM

< SYSTEM DESCRIPTION >

Interior room lamps and illuminations are controlled by each function of the total illumination control unit and BCM.

Total Illumination Control Unit

Function

- Interior room lamp control function

Lamp control

- Push-button ignition switch illumination
- Map lamp and personal lamps (when map lamp main switch is in DOOR position.)
- Puddle lamps
- Mood lamps (Door armrest)
- Foot lamps
- Center console indirect illumination
- Each illumination (Clock, switches, etc.)

BCM

Function

- Interior room lamp timer function
- Welcome light function (Welcome light function is controlled by Intelligent Key system. Refer to [DLK-37, "WELCOME LIGHT FUNCTION : System Description"](#).)
- Step lamp control function

Lamp control

- Step lamp

HOSPITALITY LIGHTING SYSTEM

- Hospitality lighting system is controlled by the total illumination control unit, BCM and combination meter.
- Hospitality lighting system controls each interior room lamp by each unit to show the driver hospitality.

INTERIOR ROOM LAMP CONTROL SYSTEM

< SYSTEM DESCRIPTION >

Hospitality lighting functioning table

Light source	Push-button ignition switch illumination	Map lamp and Personal lamp		Puddle lamp	Mood lamps (Door armrest)	Foot lamp	Step lamp	Center console indirect illumination	Each illumination (Clock, switches, etc.)	Meter illumination							
		A close door side lamp	An open door side lamp														
Scene 1 • Door is unlocked (Interior room lamp timer function) • Driver approach to the vehicle (Welcome light function)	Heart beat (Pulse)	Dim (30%)		ON (100%)	OFF	OFF	OFF	OFF	OFF	OFF	D						
Scene 2 Any door is opened		Dim (30%)	1 sec. delay ON (90%)		ON (80%)	ON	2.5 sec. delay ON (100%)		Meter panel illuminates	G							
Scene 3 All doors are closed		Dim (30%)				OFF				ON (100%)	Dim (10%)	OFF	ON (10%)	OFF	Combination meter activates	H	
Scene 4 Ignition switch ACC or ON	Steady	OFF		ON (100%)	Dim (10%)		OFF	ON (10%)	OFF							Engine start excitement function	I
Scene 5 Engine start																	OFF
Scene 6 Engine running						Steady				ON (100%)	—	—	—	—	—		
Scene 7 Tail lamps ON (Linked to illumination control switch)	ON (100%)		—	—	—		—	ON (100%)	—							—	N
Scene 8 Map lamp main switch ALL ON	—	ON (100%)		—	—	—	—	ON (100%)	—	—	O						
Scene 6 Ignition switch OFF	Steady	Dim (30%)		ON (100%)	ON (100%)	ON (80%)	OFF	OFF	OFF	OFF (Gradual dimming)	P						
Scene 7 Any door is opened		Dim (30%)	1 sec. delay ON (90%)				ON		OFF	OFF	O						
Scene 8 All doors are closed		Dim (30%)					OFF		OFF	OFF	2.5 sec. delay ON (100%)	Meter panel illuminates	OFF	OFF	P		
Scene 9 • Door is locked • Battery saver activates	OFF	OFF	OFF	OFF	OFF	OFF		OFF								OFF	OFF

NOTE:

INTERIOR ROOM LAMP CONTROL SYSTEM

< SYSTEM DESCRIPTION >

- Heart beat function of push-button ignition switch illumination can be set to OFF by CONSULT.
 - Total illumination control unit controlled lamps fade-in/fade-out time can be set by CONSULT.
- Refer to [INL-19, "CONSULT Function \(TOTAL ILLUM C/U\)"](#).

TOTAL ILLUMINATION CONTROL UNIT

Total illumination control unit controls each lamp (ground side) by PWM signal (duty) depending on vehicle conditions.

INTERIOR ROOM LAMP TIMER CONTROL

BCM operates the timer for a period of time when satisfying the timer operating condition. And it outputs the room lamp timer signal to total illumination control unit while the timer counts the time.

Timer ON

- Door is unlocked.
- Welcome light function operating condition is satisfied.

Timer OFF

- Ignition switch is OFF ⇒ ON or ACC.
- Door is locked.

NOTE:

Interior room lamp timer can be set by CONSULT. Refer to [INL-23, "INT LAMP : CONSULT Function \(BCM - INT LAMP\)"](#).

STEP LAMP CONTROL


BCM controls the step lamp (ground-side) to turn the step lamp ON when any door switch is ON.

INTERIOR ROOM LAMP CONTROL SYSTEM

< SYSTEM DESCRIPTION >

Component Parts Location

INFOID:000000010584900



- | | | |
|--|--|-------------------------------------|
| 1. Puddle lamp | 2. • Request switch
• Key cylinder switch | 3. Door switch |
| 4. Luggage room lamp (Back door side) | 5. Automatic back door close switch | 6. Luggage room lamp (Luggage side) |
| 7. Map lamp | 8. Push-button ignition switch illumination | 9. Combination meter |
| 10. Mood lamp | 11. Personal lamp | 12. Step lamp |
| 13. Door lock/unlock switch | 14. Illuminations | 15. Foot lamp |
| 16. Center console indirect illumination | 17. Map lamp main switch | 18. IPDM E/R |
| 19. Back door switch | 20. BCM | 21. Remote keyless entry receiver |
| 22. Total illumination control unit | 23. Unified meter and A/C amp. | |
| A. Engine room dash panel (RH) | B. Back door lock assembly | C. Dash side lower (passenger side) |
| D. Over the glove box | E. Instrument lower cover LH | F. Behind the cluster lid C |

INTERIOR ROOM LAMP CONTROL SYSTEM

< SYSTEM DESCRIPTION >

Component Description

INFOID:0000000010584901

Part	Description
Total illumination control unit	Controls each interior room lamp and each illumination depending on the vehicle conditions and each signal.
BCM	• Outputs room lamp timer signal and battery saver signal to the total illumination control unit depending on the vehicle conditions. • Turns the step lamp ON/OFF according to any door switch status. • Controls welcome light function of Intelligent Key system.
Combination meter	• Illuminates the meter illumination according to request signals from BCM via CAN communication (through the unified meter and A/C amp.). • Outputs the illumination control signal to the total illumination control unit.
• Remote keyless entry receiver • Outside key antenna	• Receives the lock/unlock signal from keyfob. • Transmits the lock/unlock signal to BCM.
• Request switch • Key cylinder switch • Door lock/unlock switch	Inputs the lock/unlock signal to BCM.
Door switch	Inputs the door switch signal to BCM and the total illumination control unit.
Tail lamp relay	Inputs the tail lamp signal to the total illumination control unit.
Map lamp main switch	Inputs the map lamp switch signal to the total illumination control unit.


INTERIOR ROOM LAMP BATTERY SAVER SYSTEM

< SYSTEM DESCRIPTION >

INTERIOR ROOM LAMP BATTERY SAVER SYSTEM

System Diagram

INFOID:0000000010584902



System Description

INFOID:0000000010584903

OUTLINE

- Interior room lamp battery saver is controlled by battery saver function of BCM.
- BCM cuts the interior room lamp power supply depending on the vehicle condition. Total illumination control unit cuts the hospitality lighting power supply according to interior room lamp power supply (battery saver signal). This function prevents the battery from over-discharging if the driver neglects turning OFF the lamps.

Applicable lamps

Control by the total illumination control unit

- Push-button ignition switch illumination
- Map lamp and personal lamps
- Center console indirect illumination
- Vanity mirror lamps
- Puddle lamps
- Foot lamps
- Mood lamps (Door armrest)
- Each illumination (Clock, switches, etc.)

Control by BCM

- Step lamps
- Luggage room lamps
- Automatic back door close switch (Illumination)

INTERIOR ROOM LAMP BATTERY SAVER FUNCTION

- When the ignition switch is turned OFF, BCM operates the timer for a period of time to cut the interior room lamp power supply.
- When interior room lamp power supply (battery saver signal) is OFF, the total illumination control unit cuts hospitality lighting power supply. And then it switches to sleep mode.
- BCM restarts the timer when any of the following signals changes while operating the timer.
- Ignition switch status

INTERIOR ROOM LAMP BATTERY SAVER SYSTEM

< SYSTEM DESCRIPTION >


- Door switch signal (ALL)
- Door lock/unlock signal (Remote keyless entry receiver, each request switch, key cylinder switch, door lock/unlock switch)
- Back door switch signal
- Key switch signal (Key slot)
- BCM provides the interior room lamp power supply continuously when the ignition switch is in an other than OFF.

NOTE:

Each function of interior room lamp battery saver can be set by CONSULT. Refer to [INL-25, "BATTERY SAVER : CONSULT Function \(BCM - BATTERY SAVER\)"](#).

Component Parts Location

INFOID:0000000010584904



- | | | |
|--|--|-------------------------------------|
| 1. Puddle lamp | 2. • Request switch
• Key cylinder switch | 3. Door switch |
| 4. Luggage room lamp
(Back door side) | 5. Automatic back door close
switch | 6. Luggage room lamp (Luggage side) |
| 7. Map lamp | 8. Vanity mirror lamp | 9. Mood lamp |

INTERIOR ROOM LAMP BATTERY SAVER SYSTEM

< SYSTEM DESCRIPTION >

- | | | |
|--|-------------------------------------|--|
| 10. Personal lamp | 11. Step lamp | 12. Door lock/unlock switch |
| 13. Key slot | 14. Illuminations | 15. Foot lamp |
| 16. Center console indirect illumination | 17. Map lamp main switch | 18. Push-button ignition switch illumination |
| 19. Back door switch | 20. BCM | 21. Remote keyless entry receiver |
| 22. Total illumination control unit | | |
| A. Back door lock assembly | B. Dash side lower (passenger side) | C. Over the glove box |
| D. Instrument lower cover LH | | |

Component Description

INFOID:0000000010584905

Part	Description
Total illumination control unit	Cuts the hospitality lighting power supply according to interior room lamp power supply (battery saver signal).
BCM	Operates the interior room lamp battery saver depending on the vehicle condition to cut the interior room lamp power supply (battery saver signal).
Remote keyless entry receiver	- Receives the lock/unlock signal from keyfob. - Transmits the lock/unlock signal to BCM.
- Request switch - Key cylinder switch - Door lock/unlock switch	Inputs the lock/unlock signal to BCM.
- Door switch - Back door switch	Inputs a switch signal to BCM.
Key slot	Inputs the key switch status to BCM.


INL

ILLUMINATION CONTROL SYSTEM

< SYSTEM DESCRIPTION >

ILLUMINATION CONTROL SYSTEM

System Diagram



System Description

INFOID:0000000010584907

OUTLINE

Each illumination lamp is controlled by each function of BCM, IPDM E/R, total illumination control unit and combination meter.

Control by BCM

- Combination switch reading function
- Headlamp control function

Control by IPDM E/R

- Relay control function

Control by combination meter

- Meter illumination control function (Refer to [MWI-27, "METER ILLUMINATION CONTROL : System Description"](#).)

Control by the total illumination control unit

- Interior room lamp control function (Refer to [INL-7, "System Description"](#).)

ILLUMINATION CONTROL

- BCM detects the combination switch condition by the combination switch reading function.
- BCM transmits position light request signal to IPDM E/R and combination meter (through the unified meter and A/C amp.) according to tail lamp ON condition.

Tail lamp ON condition


- Lighting switch 1ST
- Lighting switch 2ND
- Lighting switch AUTO, and the auto light function ON judgment (With auto light system)
- IPDM E/R turns the integrated tail lamp relay ON according to position light request signal. It provides the power supply to each illumination lamp.
- Total illumination control unit turns each illumination (linked with hospitality lighting system) ON according to tail lamp signal from IPDM E/R.
- Combination meter enters in the nighttime mode according to position light request signal (through the unified meter and A/C amp.). Under the nighttime mode the combination meter controls each illumination brightness.
- Total illumination control unit controls each illumination (linked with hospitality lighting system) brightness according to the illumination control signal from combination meter.

ILLUMINATION CONTROL SYSTEM

< SYSTEM DESCRIPTION >

Component Parts Location

INFOID:0000000010584908



- | | | |
|--------------------------------|-------------------------------------|------------------------------------|
| 1. Combination meter | 2. Illumination control switch | 3. Combination switch |
| 4. IPDM E/R | 5. BCM | 6. Total illumination control unit |
| 7. Unified meter and A/C amp. | | |
| A. Engine room dash panel (RH) | B. Dash side lower (passenger side) | C. Instrument lower cover LH |
| D. Behind the cluster lid C | | |

JPLIA1250ZZ

ILLUMINATION CONTROL SYSTEM

< SYSTEM DESCRIPTION >

Component Description

INFOID:0000000010584909

Part	Description
BCM	• Detects each switch condition by the combination switch reading function. • Judges the illumination lamp ON/OFF status depending on the vehicle condition. And then it transmits position light request signal to IPDM E/R and combination meter via CAN communication (through the unified meter and A/C amp.).
IPDM E/R	Controls the integrated relay according to the request from BCM via CAN communication.
Combination meter	• Enters in the nighttime mode according to the request from BCM via CAN communication. • Controls each illumination brightness in the nighttime mode. Refer to MWI-27, "METER ILLUMINATION CONTROL : System Description".
Total illumination control unit	• Turns each illumination (linked with hospitality lighting system) ON according to tail lamp signal from IPDM E/R • Controls each illumination (linked with hospitality lighting system) brightness according to the illumination control signal from combination meter.
Combination switch (Lighting & turn signal switch)	Refer to BCS-11, "System Description" .

DIAGNOSIS SYSTEM (TOTAL ILLUMINATION CONTROL UNIT)

< SYSTEM DESCRIPTION >

DIAGNOSIS SYSTEM (TOTAL ILLUMINATION CONTROL UNIT)

CONSULT Function (TOTAL ILLUM C/U)


INFOID:0000000010584910

APPLICATION ITEM

CONSULT performs the following functions via DDL2 communication line with the total illumination control unit.

Diagnosis mode	Function Description
Work Support	Changes the setting for each function.
Data Monitor	Total illumination control unit input/output signals are displayed.
Active Test	The signals used to activate each device are forcibly supplied from total illumination control unit.
Ecu Identification	Total illumination control unit part number is displayed.

WORK SUPPORT



Service item	Setting item		Setting
FOOT LAMP FADE-IN/OUT	FADE-IN	0 – 3.0 sec. (1.0 sec.*)	Sets fade-in/fade-out time of the foot lamps.
	FADE-OUT	0 – 3.0 sec. (1.0 sec.*)	
MAP&PERSNL LAMP FADE-IN/OUT	FADE-IN	0 – 3.0 sec. (1.0 sec.*)	Sets fade-in/fade-out time of the map lamps and personal lamps.
	FADE-OUT	0 – 3.0 sec. (1.0 sec.*)	
PUDDLE LAMP FADE-IN/OUT	FADE-IN	0 – 3.0 sec. (0 sec.*)	Sets fade-in/fade-out time of the puddle lamps.
	FADE-OUT	0 – 3.0 sec. (3.0 sec.*)	
MOOD LAMP FADE-IN/OUT	FADE-IN	0 – 3.0 sec. (1.0 sec.*)	Sets fade-in/fade-out time of the mood lamps.
	FADE-OUT	0 – 3.0 sec. (1.0 sec.*)	
AMBIENCE LAMP FADE-IN/OUT	FADE-IN	0 – 3.0 sec. (1.0 sec.*)	Sets fade-in/fade-out time of the ambience lamp (center console indirect illumination).
	FADE-OUT	0 – 3.0 sec. (1.0 sec.*)	
HSPL ILLUMINATION FADE-IN/OUT	FADE-IN	0 – 3.0 sec. (1.0 sec.*)	Sets fade-in/fade-out time of each illumination (linked with hospitality lighting).
	FADE-OUT	0 – 3.0 sec. (1.0 sec.*)	
E/G SW ILLUMI FADE-IN/OUT	FADE-IN	0 – 3.0 sec. (1.5 sec.*)	Sets fade-in/fade-out time of the engine switch illumination.
	FADE-OUT	0 – 3.0 sec. (1.5 sec.*)	
E/G SW ILL HEART BEAT FUNCTION	On*		With the engine switch illumination heart beat function
	Off		Without the engine switch illumination heart beat function

*: Factory setting

DATA MONITOR

NOTE:

The following table includes information (items) inapplicable to this vehicle. For information (items) applicable to this vehicle, refer to CONSULT display items.

DIAGNOSIS SYSTEM (TOTAL ILLUMINATION CONTROL UNIT)

< SYSTEM DESCRIPTION >

Monitor item [Unit]	Description
BAT SAVER SIGNAL [On/Off]	Battery saver status input from BCM
IGN SIGNAL [On/Off]	Ignition switch ON signal status
ACC SIGNAL [On/Off]	Ignition switch ACC signal status
ROOM LAMP REQ [On/Off]	Room lamp timer signal status input from BCM
TAIL LAMP SIGNAL [On/Off]	Tail lamp status input from IPDM E/R
DOOR SW-DR [On/Off]	The switch status input from front door switch (driver side)
DOOR SW-AS [On/Off]	The switch status input from front door switch (passenger side)
DOOR SW-RR [On/Off]	The switch status input from rear door switch (RH)
DOOR SW- RL [On/Off]	The switch status input from rear door switch (LH)
MAP LAMP SW [Door/All On/Off]	The switch status input from map lamp main switch
ENGINE SW ILLUMI [STEADY/PULSE/Off]	Control status of the engine switch illumination
FOOT LAMP [%]	Brightening rate of the foot lamps
MAP LAMP-DR [%]	Brightening rate of the map lamp (driver side)
MAP LAMP-AS [%]	Brightening rate of the map lamp (passenger side)
PERSONAL LMP-RR [%]	Brightening rate of the personal lamp (RH)
PERSONAL LMP-RL [%]	Brightening rate of the personal lamp (LH)
PUDDLE LAMP [%]	Brightening rate of the puddle lamps
MOOD LAMP [%]	Brightening rate of the mood lamps
AMBIENCE LAMP [%]	Brightening rate of the ambience lamp (center console indirect illumination)
HSPL ILLUMI [%]	Brightening rate of each illumination (linked with hospitality lighting)
ILLUM CONT SIGNAL [%]	Illumination control signal status input from combination meter

ACTIVE TEST

Test item	Operation	Description
ENGINE SWITCH ILLUMINATION	On	Total illumination control unit turns ON/OFF the engine switch illumination.
	Off	
FOOT LAMP	On	Total illumination control unit turns ON/OFF the foot lamps.
	Off	

DIAGNOSIS SYSTEM (TOTAL ILLUMINATION CONTROL UNIT)

< SYSTEM DESCRIPTION >

Test item	Operation	Description
MAP LAMP-DR	On	Total illumination control unit turns ON/OFF the map lamp (driver side).
	Off	
MAP LAMP-AS	On	Total illumination control unit turns ON/OFF the map lamp (passenger side).
	Off	
PERSONAL LAMP-RR	On	Total illumination control unit turns ON/OFF the personal lamp (RH).
	Off	
PERSONAL LAMP-RL	On	Total illumination control unit turns ON/OFF the personal lamp (LH).
	Off	
PUDDLE LAMP	On	Total illumination control unit turns ON/OFF the puddle lamps.
	Off	
MOOD LAMP	On	Total illumination control unit turns ON/OFF the mood lamp.
	Off	
AMBIENCE LAMP	On	Total illumination control unit turns ON/OFF the ambience lamp (center console indirect illumination).
	Off	
HSPL ILLUMINATION	On	Total illumination control unit turns ON/OFF each illumination (linked with hospitality lighting).
	Off	

A

B

C

D

E

F

G

H

I

J

K

INL

M

N

O

P

DIAGNOSIS SYSTEM (BCM)

< SYSTEM DESCRIPTION >

DIAGNOSIS SYSTEM (BCM)

COMMON ITEM

COMMON ITEM : CONSULT Function (BCM - COMMON ITEM)

INFOID:0000000011015591

APPLICATION ITEM

CONSULT performs the following functions via CAN communication with BCM.

Diagnosis mode	Function Description
Work Support	Changes the setting for each system function.
Self Diagnostic Result	Displays the diagnosis results judged by BCM.
CAN Diag Support Monitor	Monitors the reception status of CAN communication viewed from BCM.
Data Monitor	The BCM input/output signals are displayed.
Active Test	The signals used to activate each device are forcibly supplied from BCM.
Ecu Identification	The BCM part number is displayed.
Configuration	- Read and save the vehicle specification. - Write the vehicle specification when replacing BCM.

SYSTEM APPLICATION

BCM can perform the following functions for each system.

NOTE:

It can perform the diagnosis modes except the following for all sub system selection items.

×: Applicable item

System	Sub system selection item	Diagnosis mode		
		Work Support	Data Monitor	Active Test
Door lock	DOOR LOCK	×	×	×
Rear window defogger	REAR DEFOGGER		×	×
Warning chime	BUZZER		×	×
Interior room lamp timer	INT LAMP	×	×	×
Exterior lamp	HEAD LAMP	×	×	×
Wiper and washer	WIPER	×	×	×
Turn signal and hazard warning lamps	FLASHER	×	×	×
—	AIR CONDITONER*			
- Intelligent Key system - Engine start system	INTELLIGENT KEY	×	×	×
Combination switch	COMB SW		×	
Body control system	BCM	×		
IVIS - NATS	IMMU		×	×
Interior room lamp battery saver	BATTERY SAVER	×	×	×
Back door open	TRUNK		×	×
Vehicle security system	THEFT ALM	×	×	×
RAP system	RETAINED PWR		×	
Signal buffer system	SIGNAL BUFFER		×	×

NOTE:

*: This item is displayed, but is not used.

FREEZE FRAME DATA (FFD)

The BCM records the following vehicle condition at the time a particular DTC is detected, and displays on CONSULT.

DIAGNOSIS SYSTEM (BCM)

< SYSTEM DESCRIPTION >

CONSULT screen item	Indication/Unit	Description	
Vehicle Speed	km/h	Vehicle speed of the moment a particular DTC is detected	
Odo/Trip Meter	km	Total mileage (Odometer value) of the moment a particular DTC is detected	
Vehicle Condition	SLEEP>LOCK	Power position status of the moment a particular DTC is detected*	While turning BCM status from low power consumption mode to normal mode (Power supply position is "LOCK"*)
	SLEEP>OFF		While turning BCM status from low power consumption mode to normal mode (Power supply position is "OFF".)
	LOCK>ACC		While turning power supply position from "LOCK" to "ACC"
	ACC>ON		While turning power supply position from "ACC" to "IGN"
	RUN>ACC		While turning power supply position from "RUN" to "ACC" (Vehicle is stopping and selector lever is except P position.)
	CRANK>RUN		While turning power supply position from "CRANKING" to "RUN" (From cranking up the engine to run it)
	RUN>URGENT		While turning power supply position from "RUN" to "ACC" (Emergency stop operation)
	ACC>OFF		While turning power supply position from "ACC" to "OFF"
	OFF>LOCK		While turning power supply position from "OFF" to "LOCK"*
	OFF>ACC		While turning power supply position from "OFF" to "ACC"
	ON>CRANK		While turning power supply position from "IGN" to "CRANKING"
	OFF>SLEEP		While turning BCM status from normal mode (Power supply position is "OFF".) to low power consumption mode
	LOCK>SLEEP		While turning BCM status from normal mode (Power supply position is "LOCK"*) to low power consumption mode
	LOCK		Power supply position is "LOCK"*
	OFF		Power supply position is "OFF" (Ignition switch OFF)
	ACC		Power supply position is "ACC" (Ignition switch ACC)
	ON		Power supply position is "IGN" (Ignition switch ON with engine stopped)
	ENGINE RUN		Power supply position is "RUN" (Ignition switch ON with engine running)
	CRANKING		Power supply position is "CRANKING" (At engine cranking)
IGN Counter	0 - 39	The number of times that ignition switch is turned ON after DTC is detected • The number is 0 when a malfunction is detected now. • The number increases like 1 → 2 → 3...38 → 39 after returning to the normal condition whenever ignition switch OFF → ON. • The number is fixed to 39 until the self-diagnosis results are erased if it is over 39.	

NOTE:

*: Power supply position shifts to "LOCK" from "OFF", when ignition switch is in the OFF position, selector lever is in the P position, and any of the following conditions are met.

- Closing door
- Opening door
- Door is locked using door request switch
- Door is locked using Intelligent Key

The power supply position shifts to "ACC" when the push-button ignition switch (push switch) is pushed at "LOCK".

INT LAMP

INT LAMP : CONSULT Function (BCM - INT LAMP)

INFOID:0000000010584912

WORK SUPPORT

DIAGNOSIS SYSTEM (BCM)

< SYSTEM DESCRIPTION >

Service item	Setting item	Setting	
SET I/L D-UNLCK INTCON	On*	Interior room lamps link with door unlock. (Interior room lamp timer function)	
	Off	Interior room lamps do not link with door unlock.	
ROOM LAMP TIMER SET	MODE 2	7.5 sec.	Interior room lamp ON time after door are unlocked.
	MODE 3*	15 sec.	
	MODE 4	30 sec.	
ROOM LAMP ON TIME SET	MODE 1	NOTE: The item is indicated, but not used.	
	MODE 2		
	MODE 3		
	MODE 4		
	MODE 5*		
ROOM LAMP OFF TIME SET	MODE 1	NOTE: The item is indicated, but not used.	
	MODE 2		
	MODE 3		
	MODE 4		
	MODE 5*		
R LAMP TIMER LOGIC SET	MODE 1*	Interior room lamp timer activates by synchronizing all doors.	
	MODE 2	Interior room lamp timer activates by synchronizing the driver door only.	

*: Factory setting

DATA MONITOR

NOTE:

The following table includes information (items) inapplicable to this vehicle. For information (items) applicable to this vehicle, refer to CONSULT display items.

Monitor item [Unit]	Description
REQ SW-DR [On/Off]	The switch status input from request switch (driver side)
REQ SW-AS [On/Off]	The switch status input from request switch (passenger side)
REQ SW-RR [On/Off]	NOTE: The item is indicated, but not monitored.
REQ SW-RL [On/Off]	
PUSH SW [On/Off]	The switch status input from push-button ignition switch
UNLK SEN-DR [On/Off]	Driver door unlock status input from unlock sensor
KEY SW-SLOT [On/Off]	Key switch status input from key slot
DOOR SW-DR [On/Off]	The switch status input from front door switch (driver side)
DOOR SW-AS [On/Off]	The switch status input from front door switch (passenger side)
DOOR SW-RR [On/Off]	The switch status input from rear door switch (RH)
DOOR SW- RL [On/Off]	The switch status input from rear door switch (LH)

DIAGNOSIS SYSTEM (BCM)

< SYSTEM DESCRIPTION >

Monitor item [Unit]	Description
DOOR SW-BK [On/Off]	The switch status input from back door switch
CDL LOCK SW [On/Off]	Lock switch status received from door lock/unlock switch by power window switch serial link
CDL UNLOCK SW [On/Off]	Unlock switch status received from door lock/unlock switch by power window switch serial link
KEY CYL LK-SW [On/Off]	Lock switch status received from key cylinder switch by power window switch serial link
KEY CYL UN-SW [On/Off]	Unlock switch status received from key cylinder switch by power window switch serial link
TRNK/HAT MNTR [On/Off]	The switch status input from trunk room lamp switch
RKE-LOCK [On/Off]	Lock signal status received from remote keyless entry receiver
RKE-UNLOCK [On/Off]	Unlock signal status received from remote keyless entry receiver

ACTIVE TEST

Test item	Operation	Description
INT LAMP	On	Outputs the room lamp timer signal to the total illumination control unit to activate interior room lamps. (Hospitality lighting functioning table "Scene 1")
	Off	Stops the room lamp timer signal.
STEP LAMP TEST	On	Outputs the step lamp control signal to turn step lamp ON.
	Off	Stops the step lamp control signal to turn step lamp OFF.
LUGGAGE LAMP TEST	On	NOTE: The item is indicated, but not used.
	Off	

BATTERY SAVER

BATTERY SAVER : CONSULT Function (BCM - BATTERY SAVER)

INFOID:0000000010584913

WORK SUPPORT

Service item	Setting item	Setting	
ROOM LAMP BAT SAV SET	On*	With the interior room lamp battery saver function	
	Off	Without the interior room lamp battery saver function	
ROOM LAMP TIMER SET	MODE 1	30 min.	Sets the interior room lamp battery saver timer operating time.
	MODE 2	60 min.	
	MODE 3*	15 min.	
BATTERY SAVER SET	On*	With the exterior lamp battery saver function	
	Off	Without the exterior lamp battery saver function	

*: Factory setting

DATA MONITOR

NOTE:

The following table includes information (items) inapplicable to this vehicle. For information (items) applicable to this vehicle, refer to CONSULT display items.

DIAGNOSIS SYSTEM (BCM)

< SYSTEM DESCRIPTION >

Monitor item [Unit]	Description
REQ SW-DR [On/Off]	The switch status input from request switch (driver side)
REQ SW-AS [On/Off]	The switch status input from request switch (passenger side)
REQ SW-RR [On/Off]	NOTE: The item is indicated, but not monitored.
REQ SW-RL [On/Off]	
PUSH SW [On/Off]	The switch status input from push-button ignition switch
UNLK SEN-DR [On/Off]	Driver door unlock status input from unlock sensor
KEY SW-SLOT [On/Off]	Key switch status input from key slot
DOOR SW-DR [On/Off]	The switch status input from front door switch (driver side)
DOOR SW-AS [On/Off]	The switch status input from front door switch (passenger side)
DOOR SW-RR [On/Off]	The switch status input from rear door switch (RH)
DOOR SW- RL [On/Off]	The switch status input from rear door switch (LH)
DOOR SW-BK [On/Off]	The switch status input from back door switch
CDL LOCK SW [On/Off]	Lock switch status received from door lock/unlock switch by power window switch serial link
CDL UNLOCK SW [On/Off]	Unlock switch status received from door lock/unlock switch by power window switch serial link
KEY CYL LK-SW [On/Off]	Lock switch status received from key cylinder switch by power window switch serial link
KEY CYL UN-SW [On/Off]	Unlock switch status received from key cylinder switch by power window switch serial link
TRNK/HAT MNTR [On/Off]	The switch status input from trunk room lamp switch
RKE-LOCK [On/Off]	Lock signal status received from remote keyless entry receiver
RKE-UNLOCK [On/Off]	Unlock signal status received from remote keyless entry receiver

ACTIVE TEST

Test item	Operation	Description
BATTERY SAVER	Off	Cuts the interior room lamp power supply (battery saver signal).
	On	Provides the interior room lamp power supply (battery saver signal).

POWER SUPPLY AND GROUND CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

DTC/CIRCUIT DIAGNOSIS

POWER SUPPLY AND GROUND CIRCUIT

TOTAL ILLUMINATION CONTROL UNIT

TOTAL ILLUMINATION CONTROL UNIT : Diagnosis Procedure

INFOID:0000000010584914

1.FUSE INSPECTION

Check that the following fuses are not fusing.

Signal name	Connection position	Fuse No.	Capacity
Battery power supply	FUSE BLOCK (J/B)	10	10 A
Ignition switch ACC	FUSE BLOCK (J/B)	19	10 A
Ignition switch ON	IPDM E/R	44	10 A

Is the fuse fusing?

- YES >> Repair the applicable circuit. And then replace the fuse.
NO >> GO TO 2.

2.CHECK POWER SUPPLY CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect the total illumination control unit harness connector.
3. Check voltage between the total illumination control unit harness connector and ground.

Terminals		Condition	Voltage (Approx.)
(+)	(-)		
Total illumination control unit		Ignition switch	Battery voltage
Connector	Terminal		
M129	21		
	5		
	7		
Ground		OFF	Battery voltage
		ACC	
		ON	

Is the measurement value normal?

- YES >> GO TO 3.
NO >> Repair harness or connector.

3.CHECK GROUND CIRCUIT

1. Turn ignition switch OFF.
2. Check continuity between the total illumination control unit harness connector and ground.

Total illumination control unit		Ground	Continuity
Connector	Terminal		
M129	23		Existed

Does continuity exist?

- YES >> Power supply and ground circuit are normal.
NO >> Repair harness or connector.

BCM

BCM : Diagnosis Procedure

INFOID:0000000010584915

1.CHECK FUSE AND FUSIBLE LINK

Check that the following fuse and fusible link are not blown.

POWER SUPPLY AND GROUND CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

Signal name	Fuse and fusible link No.
Battery power supply	L
	10

Is the fuse fusing?

YES >> Replace the blown fuse or fusible link after repairing the affected circuit if a fuse or fusible link is blown.

NO >> GO TO 2.

2.CHECK POWER SUPPLY CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect BCM connectors.
3. Check voltage between BCM harness connector and ground.

Terminals		Voltage (Approx.)
(+)	(-)	
BCM		Ground Battery voltage
Connector	Terminal	
M118	1	
M119	11	

Is the measurement value normal?

YES >> GO TO 3.

NO >> Repair harness or connector.

3.CHECK GROUND CIRCUIT

Check continuity between BCM harness connector and ground.

BCM		Ground	Continuity
Connector	Terminal		
M119	13		Existed

Does continuity exist?

YES >> INSPECTION END

NO >> Repair harness or connector.

INTERIOR ROOM LAMP POWER SUPPLY CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

INTERIOR ROOM LAMP POWER SUPPLY CIRCUIT

Description

INFOID:0000000010584916

BCM provides the step lamp power supply. Also BCM outputs it as the battery saver signal to total illumination control unit. And BCM cuts the power supply when the interior room lamp battery saver is activated.

Diagnosis Procedure

INFOID:0000000010584917

1.CHECK INTERIOR ROOM LAMP POWER SUPPLY OUTPUT

CONSULT ACTIVE TEST

1. Turn ignition switch ON.
2. Select "BATTERY SAVER" of BCM (BATTERY SAVER) active test item.
3. While operating the test item, check voltage between BCM harness connector and ground.

Terminals		Test item	Voltage (Approx.)
(+)	(-)		
BCM		BATTERY SAVER	
Connector	Terminal		
M119	4	Off	0 V
		On	12 V

Is the measurement value normal?

YES >> GO TO 2.

NO >> GO TO 3.

2.CHECK INTERIOR ROOM LAMP POWER SUPPLY CIRCUIT FOR OPEN

1. Turn ignition switch OFF.
2. Disconnect the following connectors.
 - BCM
 - Total illumination control unit
 - Step lamp (Driver side)
 - Step lamp (Passenger side)
 - Step lamp (Rear LH)
 - Step lamp (Rear RH)
 - Luggage room lamp (Luggage side)
 - Luggage room lamp (Back door side)
 - Automatic back door close switch
3. Check continuity between BCM harness connector and each interior room lamp harness connector.

INTERIOR ROOM LAMP POWER SUPPLY CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

BCM		Each interior room lamp and total illumination control unit			Continuity
Connector	Terminal	Connector		Terminal	
M119	4	Total illumination control unit	M129	6	Existed
		Step lamp (Driver side)	D12	1	
		Step lamp (Passenger side)	D42	1	
		Step lamp (Rear LH)	D59	1	
		Step lamp (Rear RH)	D79	1	
		Luggage room lamp (Luggage side)	B229	2	
		Luggage room lamp (Back door side)	D110	2	
		Automatic back door close switch	D113	3	

Does continuity exist?

YES >> Interior room lamp power supply circuit is normal.

NO >> Repair the harnesses or connectors.

3. CHECK INTERIOR ROOM LAMP POWER SUPPLY CIRCUIT FOR SHORT

1. Turn ignition switch OFF.
2. Disconnect the following connectors.
 - BCM
 - Total illumination control unit
 - Step lamp (Driver side)
 - Step lamp (Passenger side)
 - Step lamp (Rear LH)
 - Step lamp (Rear RH)
 - Luggage room lamp (Luggage side)
 - Luggage room lamp (Back door side)
 - Automatic back door close switch
3. Check continuity between BCM harness connector and ground.

BCM		Ground	Continuity
Connector	Terminal		
M119	4		Not existed

Does continuity exist?

YES >> Repair the harnesses or connectors.

NO >> Replace BCM.

BATTERY SAVER SIGNAL CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

BATTERY SAVER SIGNAL CIRCUIT

Description

INFOID:0000000010584918

BCM cuts the interior room lamp power supply depending on the vehicle condition. Total illumination control unit cuts the hospitality lighting power supply according to interior room lamp power supply (battery saver signal). This function prevents the battery from over-discharging if the driver neglects turning OFF any lamps.

Diagnosis Procedure

INFOID:0000000010584919

1.CHECK BATTERY SAVER SIGNAL INPUT

CONSULT ACTIVE TEST

1. Turn ignition switch ON.
2. Select "BATTERY SAVER" of BCM (BATTERY SAVER) active test item.
3. While operating the test item, check voltage between total illumination control unit harness connector and ground.

Terminals		Test item	Voltage (Approx.)
(+)	(-)		
Total illumination control unit		BATTERY SAVER	
Connector	Terminal		
M129	6	Off	0 V
		On	12 V

Is the measurement value normal?

YES >> GO TO 2.

NO >> Check the interior room lamp power supply circuit. Refer to [INL-29, "Description"](#).

2.CHECK BATTERY SAVER SIGNAL BY CONSULT

CONSULT DATA MONITOR

1. Turn ignition switch ON.
2. Select "BAT SAVER SIGNAL" of TOTAL ILLUM C/U data monitor item.
3. Check the monitor status.

Monitor item	Monitor status
BAT SAVER SIGNAL	On

4. Turn ignition switch OFF.
5. Disconnect the BCM (M119) connector.
6. Turn ignition switch ON.
7. Check the monitor status.

Monitor item	Monitor status
BAT SAVER SIGNAL	Off

Is the item status normal?

YES >> Battery saver signal circuit is normal.

NO >> Replace the total illumination control unit.

HOSPITALITY LIGHTING POWER SUPPLY CIRCUIT 1

< DTC/CIRCUIT DIAGNOSIS >

HOSPITALITY LIGHTING POWER SUPPLY CIRCUIT 1

Description

INFOID:0000000010584920

Total illumination control unit provides the following lamps power supply according to the battery saver signal from BCM.

- Mood lamps (rear door armrest)
- Foot lamps
- Map lamps
- Center console indirect illumination (Ambience lamp)
- Personal lamps
- Vanity mirror lamps
- Push-button ignition switch illumination

Diagnosis Procedure

INFOID:0000000010584921

CAUTION:

Check the following circuit first if the other room lamps (Puddle lamps, push-button ignition switch illumination, etc.) are not turned ON.

- Power supply and ground circuit of total illumination control unit: Refer to [INL-27, "TOTAL ILLUMINATION CONTROL UNIT : Diagnosis Procedure"](#).
- Battery saver signal circuit: Refer to [INL-31, "Description"](#).

1. CHECK HOSPITALITY LIGHTING POWER SUPPLY 1 OUTPUT

CONSULT ACTIVE TEST

1. Turn ignition switch ON.
2. Select "BATTERY SAVER" of BCM (BATTERY SAVER) active test item.
3. While operating the test item, check voltage between total illumination control unit harness connector and ground.

Terminals		Test item	Voltage (Approx.)
(+)	(-)		
Total illumination control unit		BATTERY SAVER	
Connector	Terminal		
M129	35	Off	0 V
		On	12 V

Is the measurement value normal?

YES >> GO TO 2.

NO >> GO TO 4.

2. CHECK HOSPITALITY LIGHTING POWER SUPPLY 1 CIRCUIT FOR OPEN

1. Turn ignition switch OFF.
2. Disconnect the following connectors.
 - Total illumination control unit
 - Roof module
 - Foot lamp (driver side)
 - Foot lamp (passenger side)
 - Mood lamp (rear door armrest LH)
 - Mood lamp (rear door armrest RH)
 - Push-button ignition switch
3. Check continuity between total illumination control unit harness connector and each lamp harness connectors.

HOSPITALITY LIGHTING POWER SUPPLY CIRCUIT 1

< DTC/CIRCUIT DIAGNOSIS >

Total illumination control unit		Each interior room lamp			Continuity
Connector	Terminal	Connector		Terminal	
M129	35	Roof module	R2	12	Existed
		Foot lamp (driver side)	M30	1	
		Foot lamp (passenger side)	M130	1	
		Mood lamp (rear door armrest LH)	D58	1	
		Mood lamp (rear door armrest RH)	D78	1	
		Push-button ignition switch	M50	3	

Does continuity exist?

YES >> GO TO 3.

NO >> Repair the harnesses or connectors.

3.CHECK ROOF MODULE CIRCUIT FOR OPEN

1. Turn ignition switch OFF.
2. Disconnect the following connectors.
 - Map lamp
 - Vanity mirror lamp (LH)
 - Vanity mirror lamp (RH)
 - Personal lamp
3. Check continuity between the roof module harness connector and each lamp harness connectors.

Roof module		Each interior room lamp			Continuity
Connector	Terminal	Connector		Terminal	
R11	12	Map lamp	R15	10	Existed
				5	
		Vanity mirror lamp (LH)	R12	2	
		Vanity mirror lamp (RH)	R13	2	
		Personal lamp	R14	4	

Is the measurement value normal?

YES >> Hospitality lighting power supply 1 circuit is normal.

NO >> Repair the harnesses or connectors.

4.CHECK HOSPITALITY LIGHTING POWER SUPPLY 1 CIRCUIT FOR SHORT

1. Turn ignition switch OFF.
2. Disconnect the following connectors.
 - Total illumination control unit
 - Roof module
 - Foot lamp (driver side)
 - Foot lamp (passenger side)
 - Mood lamp (rear door armrest LH)
 - Mood lamp (rear door armrest RH)
 - Push-button ignition switch
3. Check continuity between total illumination control unit harness connector and ground.

HOSPITALITY LIGHTING POWER SUPPLY CIRCUIT 1

< DTC/CIRCUIT DIAGNOSIS >

Total illumination control unit		Ground	Continuity
Connector	Terminal		
M129	35		Not existed

Does continuity exist?

YES >> Repair the harnesses or connectors.

NO >> GO TO 5.

5.CHECK ROOF MODULE CIRCUIT FOR SHORT

1. Disconnect the following connectors.
 - Map lamp
 - Vanity mirror lamp (LH)
 - Vanity mirror lamp (RH)
 - Personal lamp
2. Check continuity between roof module harness connector and ground.

Roof module		Ground	Continuity
Connector	Terminal		
R11	12		Not existed

Does continuity exist?

YES >> Repair the harnesses or connectors.

NO >> Replace the total illumination control unit.

HOSPITALITY LIGHTING POWER SUPPLY CIRCUIT 2

< DTC/CIRCUIT DIAGNOSIS >

HOSPITALITY LIGHTING POWER SUPPLY CIRCUIT 2

Description

INFOID:0000000010584922

Total illumination control unit provides the following lamps power supply according to the battery saver signal from BCM.

- Puddle lamp
- Mood lamp (front door armrest)

Diagnosis Procedure

INFOID:0000000010584923

CAUTION:

Check the following circuit first if the other room lamps (Map lamp, personal lamps, foot lamps, each illumination, etc.) are not turned ON.

- Power supply and ground circuit of total illumination control unit: Refer to [INL-27, "TOTAL ILLUMINATION CONTROL UNIT : Diagnosis Procedure"](#).
- Battery saver signal circuit: Refer to [INL-31, "Description"](#).

1. CHECK HOSPITALITY LIGHTING POWER SUPPLY 2 OUTPUT

CONSULT ACTIVE TEST

1. Turn ignition switch ON.
2. Select "BATTERY SAVER" of BCM (BATTERY SAVER) active test item.
3. While operating the test item, check voltage between total illumination control unit harness connector and ground.

Terminals		Test item	Voltage (Approx.)
(+)	(-)		
Total illumination control unit		BATTERY SAVER	
Connector	Terminal		
M129	34	Off	0 V
		On	12 V

Is the measurement value normal?

YES >> GO TO 2.

NO >> GO TO 3.

2. CHECK HOSPITALITY LIGHTING POWER SUPPLY 2 CIRCUIT FOR OPEN

1. Turn ignition switch OFF.
2. Disconnect the following connectors.
 - Total illumination control unit
 - Door mirror (driver side)
 - Door mirror (passenger side)
 - Mood lamp (front door armrest LH)
 - Mood lamp (front door armrest RH)
3. Check continuity between total illumination control unit harness connector and each lamp harness connectors.

HOSPITALITY LIGHTING POWER SUPPLY CIRCUIT 2

< DTC/CIRCUIT DIAGNOSIS >

Total illumination control unit		Each interior room lamp			Continuity
Connector	Terminal	Connector		Terminal	
M129	34	Door mirror (driver side)	D3	2	Existed
		Door mirror (passenger side)	D33	2	
		Mood lamp (front door armrest LH)	D16	1	
		Mood lamp (front door armrest RH)	D46	1	

Does continuity exist?

YES >> Hospitality lighting power supply 2 circuit is normal.

NO >> Repair the harnesses or connectors.

3. CHECK HOSPITALITY LIGHTING POWER SUPPLY 2 CIRCUIT FOR SHORT

Check continuity between total illumination control unit harness connector and ground.

Total illumination control unit		Ground	Continuity
Connector	Terminal		
M129	34		Not existed

Does continuity exist?

YES >> Repair the harnesses or connectors.

NO >> Replace the total illumination control unit.

HOSPITALITY LIGHTING POWER SUPPLY CIRCUIT 3

< DTC/CIRCUIT DIAGNOSIS >

HOSPITALITY LIGHTING POWER SUPPLY CIRCUIT 3

Description

INFOID:0000000010584924

Total illumination control unit provides the following illuminations power supply according to the battery saver signal from BCM.

Illuminations

- Trip computer switch
- Illumination control switch
- Multifunction switch
- Climate controlled seat switch
- LDW switch
- Snow mode switch
- Door mirror remote control switch
- AFS OFF switch
- Headlamp aiming switch
- Clock
- Steering switch
- IBA OFF switch
- DCA switch
- VDC OFF switch

Diagnosis Procedure

INFOID:0000000010584925

CAUTION:

Check the following circuit first if the other room lamps (Map lamp, personal lamps, foot lamps, puddle lamps, etc.) are not turned ON.

- Power supply and ground circuit of total illumination control unit: Refer to [INL-27, "TOTAL ILLUMINATION CONTROL UNIT : Diagnosis Procedure"](#).
- Battery saver signal circuit: Refer to [INL-31, "Description"](#).

1.CHECK HOSPITALITY LIGHTING POWER SUPPLY 3 OUTPUT

CONSULT ACTIVE TEST

1. Turn ignition switch ON.
2. Set the illumination control switch in maximum.
3. Select "BATTERY SAVER" of BCM (BATTERY SAVER) active test item.
4. While operating the test item, check voltage between total illumination control unit harness connector and ground.

Terminals		Test item	Voltage (Approx.)
(+)	(-)		
Total illumination control unit		BATTERY SAVER	
Connector	Terminal		
M129	33	Ground	Off
			On

Is the measurement value normal?

- YES >> GO TO 2.
NO >> GO TO 3.

2.CHECK HOSPITALITY LIGHTING POWER SUPPLY 3 CIRCUIT FOR OPEN

1. Turn ignition switch OFF.
2. Disconnect the total illumination control unit connector and each illumination connectors.
3. Check continuity between total illumination control unit harness connector and each illumination harness connectors.

HOSPITALITY LIGHTING POWER SUPPLY CIRCUIT 3

< DTC/CIRCUIT DIAGNOSIS >

Total illumination control unit		Illuminations			Continuity
Connector	Terminal	Connector		Terminal	
M129	33	Meter control switch	M54	4	Existed
		Multifunction switch	M72	4	
		Climate controlled seat switch (driver side)	M177	7	
		Climate controlled seat switch (passenger side)	M178	7	
		LDW switch	M29	5	
		Snow mode switch	M176	5	
		Door mirror remote control switch	M20	16	
		AFS OFF switch	M21	5	
		Headlamp aiming switch	M15	3	
		Clock	M74	2	
		Combination switch	M36	23	
		IBA OFF switch	M184	5	
		DCA switch	M18	3	
		VDC OFF switch	M19	3	

Does continuity exist?

YES >> Hospitality lighting power supply 3 circuit is normal.

NO >> Repair the harnesses or connectors.

3.CHECK HOSPITALITY LIGHTING POWER SUPPLY 3 CIRCUIT FOR SHORT

Check continuity between total illumination control unit harness connector and ground.

Total illumination control unit		Ground	Continuity
Connector	Terminal		
M129	33		Not existed

Does continuity exist?

YES >> Repair the harnesses or connectors.

NO >> Replace the total illumination control unit.

MAP LAMP CIRCUIT


< DTC/CIRCUIT DIAGNOSIS >

MAP LAMP CIRCUIT

Description

INFOID:0000000010584926

Controls the lamp (ground side) by PWM signal (duty) when the map lamp main switch is DOOR.



Component Function Check

INFOID:0000000010584927

CAUTION:

Check the following item first.

- Hospitality lighting power supply 1 circuit (When both side lamps are not turned ON.)
- Map lamp bulbs

1.CHECK MAP LAMP CONTROL FUNCTION

CONSULT ACTIVE TEST

1. Turn ignition switch ON.
2. Select "MAP LAMP-DR" or "MAP LAMP-AS" of TOTAL ILLUM C/U active test item.
3. While operating the test items, check map lamps operation.

Test item		Operation	
MAP LAMP-DR	On	Map lamp (driver side)	ON
	Off		OFF
MAP LAMP-AS	On	Map lamp (passenger side)	ON
	Off		OFF

Are the map lamps turned ON/OFF?

YES >> Map lamp circuit is normal.

NO >> Refer to [INL-39, "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:0000000010584928

1.CHECK MAP LAMP CONTROL OUTPUT

CONSULT ACTIVE TEST

1. Turn ignition switch ON.
2. Switch map lamp main switch DOOR.
3. Select "MAP LAMP-DR" or "MAP LAMP-AS" of TOTAL ILLUM C/U active test item.
4. While operating the test items, check voltage between total illumination control unit harness connector and ground.

Driver side

Total illumination control unit		Ground	Test item	Voltage (Approx.)
Connector	Terminal		MAP LAMP-DR	
M129	18		On	0 V
			Off	12 V

MAP LAMP CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

Passenger side

Total illumination control unit		Ground	Test item	Voltage (Approx.)
Connector	Terminal		MAP LAMP-AS	
M129	12		On	0 V
			Off	12 V

Is the measurement value normal?

Fixed at 12 V>>Replace the total illumination control unit.

Fixed at 0 V>>GO TO 2.

2.CHECK THE SYMPTOM

Check that the lamp fixed to ON or OFF.

Fixed OFF>>GO TO 3.

Fixed ON>>GO TO 4.

3.CHECK MAP LAMP CONTROL CIRCUIT FOR OPEN

1. Turn ignition switch OFF.
2. Disconnect the total illumination control unit and map lamp connector.
3. Check continuity between the total illumination control unit harness connector and map lamp harness connector.

Total illumination control unit		Map lamp		Continuity
Connector	Terminal	Connector	Terminal	
Driver side	M129	R15	7	Existed
Passenger side			9	

Does continuity exist?

YES >> Replace the map lamp assembly.

NO >> Repair the harnesses or connectors.

4.CHECK MAP LAMP CONTROL CIRCUIT FOR SHORT

1. Turn ignition switch OFF.
2. Disconnect the total illumination control unit and map lamp connector.
3. Check continuity between the total illumination control unit harness connector and ground.

Total illumination control unit			Ground	Continuity
Connector		Terminal		Not existed
Driver side	M129	18		
Passenger side		12		

Does continuity exist?

YES >> Repair the harnesses or connectors.

NO >> Replace the total illumination control unit.

PERSONAL LAMP CIRCUIT


< DTC/CIRCUIT DIAGNOSIS >

PERSONAL LAMP CIRCUIT

Description

INFOID:0000000010584929

Controls the lamp (ground side) by PWM signal (duty) when map lamp main switch is DOOR.



Component Function Check

INFOID:0000000010584930

CAUTION:

Before performing the diagnosis, check that the following items are normal.

- Hospitality lighting power supply 1 circuit (When both sides lamp are not turned ON.)
- Personal lamp bulbs

1.CHECK PERSONAL LAMP CONTROL FUNCTION

CONSULT ACTIVE TEST

1. Turn ignition switch ON.
2. Select "PERSONAL LAMP-RR" or "PERSONAL LAMP-RL" of TOTAL ILLUM C/U active test item.
3. While operating the test items, check personal lamps operation.

Test item		Operation	
PERSONAL LAMP-RR	On	Personal lamp (RH)	ON
	Off		OFF
PERSONAL LAMP-RL	On	Personal lamp (LH)	ON
	Off		OFF

Are the personal lamps turned ON/OFF?

YES >> Personal lamp circuit is normal.

NO >> Refer to [INL-41, "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:0000000010584931

1.CHECK PERSONAL LAMP CONTROL OUTPUT

CONSULT ACTIVE TEST

1. Turn ignition switch ON.
2. Select "PERSONAL LAMP-RR" or "PERSONAL LAMP-RR" of TOTAL ILLUM C/U active test item.
3. While operating the test items, check voltage between total illumination control unit harness connector and ground.

Personal lamp RH

Total illumination control unit		Ground	Test item	Voltage (Approx.)
Connector	Terminal		PERSONAL LAMP-RR	
M129	14		On	0 V
			Off	12 V

PERSONAL LAMP CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

Personal lamp LH

Total illumination control unit		Ground	Test item	Voltage (Approx.)
Connector	Terminal		PERSONAL LAMP-RL	
M129	13		On	0 V
			Off	12 V

Is the measurement value normal?

Fixed at 12 V>>Replace the total illumination control unit.

Fixed at 0 V>>GO TO 2.

2.CHECK THE SYMPTOM

Check that the lamp fixed to ON or OFF.

Fixed OFF>>GO TO 3.

Fixed ON>>GO TO 4.

3.CHECK PERSONAL LAMP CONTROL CIRCUIT FOR OPEN

1. Turn ignition switch OFF.
2. Disconnect the total illumination control unit and personal lamp connectors.
3. Check continuity between the total illumination control unit harness connector and personal lamp harness connector.

Total illumination control unit		Personal lamp		Continuity
Connector	Terminal	Connector	Terminal	
RH	M129	R14	3	Existed
LH			1	

Does continuity exist?

YES >> Replace the personal lamp assembly.

NO >> Repair the harnesses or connectors.

4.CHECK PERSONAL LAMP CONTROL CIRCUIT FOR SHORT

1. Turn ignition switch OFF.
2. Disconnect the total illumination control unit and personal lamp connectors.
3. Check continuity between the total illumination control unit harness connector and ground.

Total illumination control unit			Ground	Continuity
Connector		Terminal		
RH	M129	14		Not existed
LH		13		

Does continuity exist?

YES >> Repair the harnesses or connectors.

NO >> Replace the total illumination control unit.

CENTER CONSOLE INDIRECT ILLUMINATION CIRCUIT


< DTC/CIRCUIT DIAGNOSIS >

CENTER CONSOLE INDIRECT ILLUMINATION CIRCUIT

Description

INFOID:0000000010584932

Controls the lamp (ground side) by PWM signal (duty).



Component Function Check

INFOID:0000000010584933

1.CHECK CENTER CONSOLE INDIRECT ILLUMINATION CONTROL FUNCTION

CONSULT ACTIVE TEST

1. Turn ignition switch ON.
2. Select "AMBIENCE LAMP" of TOTAL ILLUM C/U active test item.
3. While operating the test items, check center console indirect illumination operation.

Test item		Operation	
AMBIENCE LAMP	On	Center console indirect illumination	ON
	Off		OFF

Is the center console indirect illumination turned ON/OFF?

- YES >> Center console indirect illumination circuit is normal.
- NO >> Refer to [INL-43, "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:0000000010584934

1.CHECK CENTER CONSOLE INDIRECT ILLUMINATION CONTROL OUTPUT

CONSULT ACTIVE TEST

1. Turn ignition switch ON.
2. Select "AMBIENCE LAMP" of TOTAL ILLUM C/U active test item.
3. While operating the test items, check voltage between total illumination control unit harness connector and ground.

Total illumination control unit		Ground	Test item	Voltage (Approx.)
Connector	Terminal		AMBIENCE LAMP	
M129	20		On	0 V
			Off	12 V

Is the measurement value normal?

- Fixed at 12 V>>Replace the total illumination control unit.
- Fixed at 0 V>>GO TO 2.

2.CHECK THE SYMPTOM

Check that the lamp fixed to ON or OFF.

- Fixed OFF>>GO TO 3.
- Fixed ON>>GO TO 5.

CENTER CONSOLE INDIRECT ILLUMINATION CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

3.CHECK CENTER CONSOLE INDIRECT ILLUMINATION POWER SUPPLY

1. Turn ignition switch OFF.
2. Disconnect the map lamp connector.
3. Turn ignition switch ON.
4. Check voltage between the map lamp harness connector and ground.

Map lamp		Ground	Voltage (Approx.)
Connector	Terminal		
R15	5		12 V

Is the measurement value normal?

YES >> GO TO 4.

NO >> Check the hospitality lighting power supply circuit 1. Refer to [INL-32. "Diagnosis Procedure"](#).

4.CHECK CENTER CONSOLE INDIRECT ILLUMINATION CONTROL CIRCUIT FOR OPEN

1. Turn ignition switch OFF.
2. Disconnect the total illumination control unit connector.
3. Check continuity between the total illumination control unit harness connector and map lamp harness connector.

Total illumination control unit		Map lamp		Continuity
Terminal		Connector	Terminal	
M129	20	R15	6	Existed

Does continuity exist?

YES >> Replace the map lamp assembly.

NO >> Repair the harnesses or connectors.

5.CHECK CENTER CONSOLE INDIRECT ILLUMINATION CONTROL CIRCUIT FOR SHORT

1. Turn ignition switch OFF.
2. Disconnect the total illumination control unit and map lamp connectors.
3. Check continuity between the total illumination control unit harness connector and ground.

Total illumination control unit		Ground	Continuity
Connector	Terminal		
M129	20		Not existed

Does continuity exist?

YES >> Repair the harnesses or connectors.

NO >> Replace the total illumination control unit.

FOOT LAMP CIRCUIT


< DTC/CIRCUIT DIAGNOSIS >

FOOT LAMP CIRCUIT

Description

INFOID:0000000010584935

Controls the lamp (ground side) by PWM signal (duty).



Component Function Check

INFOID:0000000010584936

CAUTION:

Check foot lamp bulbs first.

1.CHECK FOOT LAMP CONTROL FUNCTION

CONSULT ACTIVE TEST

1. Turn ignition switch ON.
2. Select "FOOT LAMP" of TOTAL ILLUM C/U active test item.
3. While operating the test items, check foot lamps operation.

Test item		Operation	
FOOT LAMP	On	Foot lamps	ON
	Off		OFF

Are the foot lamps turned ON/OFF?

YES >> Foot lamp circuit is normal.

NO >> Refer to [INL-50. "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:0000000010584937

1.CHECK FOOT LAMP CONTROL OUTPUT

CONSULT ACTIVE TEST

1. Turn ignition switch ON.
2. Select "FOOT LAMP" of TOTAL ILLUM C/U active test item.
3. While operating the test items, check voltage between total illumination control unit harness connector and ground.

Driver side

Total illumination control unit		Ground	Test item	Voltage (Approx.)
Connector	Terminal		FOOT LAMP	
M129	36		On	0 V
			Off	12 V

Passenger side

Total illumination control unit		Ground	Test item	Voltage (Approx.)
Connector	Terminal		FOOT LAMP	
M129	16		On	0 V
			Off	12 V

FOOT LAMP CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

Is the measurement value normal?

Fixed at 12 V>>Replace the total illumination control unit.

Fixed at 0 V>>GO TO 2.

2.CHECK THE SYMPTOM

Check that the lamp fixed to ON or OFF.

Fixed OFF>>GO TO 3.

Fixed ON>>GO TO 5.

3.CHECK FOOT LAMP POWER SUPPLY

1. Turn ignition switch OFF.
2. Disconnect the foot lamp connector.
3. Turn ignition switch ON.
4. Check voltage between the foot lamp harness connector and ground.

Foot lamp			Ground	Voltage (Approx.)
Connector		Terminal		12 V
Driver side	M30	1		
Passen- ger side	M130	1		

Is the measurement value normal?

YES >> GO TO 4.

NO >> Check the hospitality lighting power supply circuit 1. Refer to [INL-32, "Diagnosis Procedure"](#).

4.CHECK FOOT LAMP CONTROL CIRCUIT FOR OPEN

1. Turn ignition switch OFF.
2. Disconnect the total illumination control unit connector.
3. Check continuity between the total illumination control unit harness connector and foot lamp harness connector.

Total illumination control unit			Foot lamp		Continuity
Connector		Terminal	Connector	Terminal	
Driver side	M129	36	M30	2	Existed
Passenger side		16	M130	2	

Does continuity exist?

YES >> Replace the foot lamp.

NO >> Repair the harnesses or connectors.

5.CHECK FOOT LAMP CONTROL CIRCUIT FOR SHORT

1. Turn ignition switch OFF.
2. Disconnect the total illumination control unit and foot lamp connectors.
3. Check continuity between the total illumination control unit harness connector and ground.

Total illumination control unit			Ground	Continuity
Connector		Terminal		Not existed
Driver side	M129	36		
Passenger side		16		

Does continuity exist?

FOOT LAMP CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

YES >> Repair the harnesses or connectors.

NO >> Replace the total illumination control unit.

A

B

C

D

E

F

G

H

I

J

K

INL

M

N

O

P

PUDDLE LAMP CIRCUIT


< DTC/CIRCUIT DIAGNOSIS >

PUDDLE LAMP CIRCUIT

Description

INFOID:0000000010584938

Controls the lamp (ground side) by PWM signal (duty).



Component Function Check

INFOID:0000000010584939

1.CHECK PUDDLE LAMP CONTROL FUNCTION

CONSULT ACTIVE TEST

1. Turn ignition switch ON.
2. Select "PUDDLE LAMP" of TOTAL ILLUM C/U active test item.
3. While operating the test items, check puddle lamps operation.

Test item		Operation	
PUDDLE LAMP	On	Puddle lamps	ON
	Off		OFF

Are the puddle lamps turned ON/OFF?

- YES >> Puddle lamp circuit is normal.
NO >> Refer to [INL-48, "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:0000000010584940

1.CHECK PUDDLE LAMP CONTROL OUTPUT

CONSULT ACTIVE TEST

1. Turn ignition switch ON.
2. Select "PUDDLE LAMP" of TOTAL ILLUM C/U active test item.
3. While operating the test items, check voltage between total illumination control unit harness connector and ground.

Driver side

Total illumination control unit		Ground	Test item	Voltage (Approx.)
Connector	Terminal		PUDDLE LAMP	
M129	40		On	0 V
			Off	12 V

Passenger side

Total illumination control unit		Ground	Test item	Voltage (Approx.)
Connector	Terminal		PUDDLE LAMP	
M129	39		On	0 V
			Off	12 V

Is the measurement value normal?

PUDDLE LAMP CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

Fixed at 12 V>>Replace the total illumination control unit.

Fixed at 0 V>>GO TO 2.

2.CHECK THE SYMPTOM

Check that the lamp fixed to ON or OFF.

Fixed OFF>>GO TO 3.

Fixed ON>>GO TO 5.

3.CHECK PUDDLE LAMP POWER SUPPLY

1. Turn ignition switch OFF.
2. Disconnect the door mirror connector.
3. Turn ignition switch ON.
4. Check voltage between the door mirror lamp harness connector and ground.

Door mirror			Ground	Voltage (Approx.)
Connector		Terminal		
Driver side	D3	2		12 V
Passenger side	D33	2		

Is the measurement value normal?

YES >> GO TO 4.

NO >> Check the hospitality lighting power supply circuit 2. Refer to [INL-32. "Diagnosis Procedure"](#).

4.CHECK PUDDLE LAMP CONTROL CIRCUIT FOR OPEN

1. Turn ignition switch OFF.
2. Disconnect the total illumination control unit connector.
3. Check continuity between the total illumination control unit harness connector and door mirror harness connector.

Total illumination control unit			Door mirror		Continuity
Connector		Terminal	Connector	Terminal	
Driver side	M129	40	D3	14	Existed
Passenger side		39	D33	14	

Does continuity exist?

YES >> Replace the puddle lamp.

NO >> Repair the harnesses or connectors.

5.CHECK PUDDLE LAMP CONTROL CIRCUIT FOR SHORT

1. Turn ignition switch OFF.
2. Disconnect the total illumination control unit and puddle lamp connector.
3. Check continuity between the total illumination control unit harness connector and ground.

Total illumination control unit			Ground	Continuity
Connector		Terminal		
Driver side	M129	40		Not existed
Passenger side		39		

Does continuity exist?

YES >> Repair the harnesses or connectors.

NO >> Replace the total illumination control unit.

MOOD LAMP (FRONT DOOR ARMREST) CIRCUIT


< DTC/CIRCUIT DIAGNOSIS >

MOOD LAMP (FRONT DOOR ARMREST) CIRCUIT

Description

INFOID:0000000010584941

Controls the lamp (ground side) by PWM signal (duty).



Component Function Check

INFOID:0000000010584942

1.CHECK MOOD LAMP (FRONT DOOR ARMREST) CONTROL FUNCTION

CONSULT ACTIVE TEST

1. Turn ignition switch ON.
2. Select "MOOD LAMP" of TOTAL ILLUM C/U active test item.
3. While operating the test items, check mood lamp (front door armrest) operation.

Test item		Operation	
MOOD LAMP	On	Mood lamp (front door armrest)	ON
	Off		OFF

Are the mood lamps (front door armrest) turned ON/OFF?

- YES >> Mood lamp (front door armrest) circuit is normal.
NO >> Refer to [INL-50, "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:0000000010584943

1.CHECK MOOD LAMP (FRONT DOOR ARMREST) CONTROL OUTPUT

CONSULT ACTIVE TEST

1. Turn ignition switch ON.
2. Select "MOOD LAMP" of TOTAL ILLUM C/U active test item.
3. While operating the test items, check voltage between total illumination control unit harness connector and ground.

Mood lamp (front door armrest RH)

Total illumination control unit		Ground	Test item	Voltage (Approx.)
Connector	Terminal		MOOD LAMP	
M129	10		On	0 V
			Off	12 V

Mood lamp (front door armrest LH)

Total illumination control unit		Ground	Test item	Voltage (Approx.)
Connector	Terminal		MOOD LAMP	
M129	30		On	0 V
			Off	12 V

Is the measurement value normal?

Fixed at 12 V>>Replace the total illumination control unit.

MOOD LAMP (FRONT DOOR ARMREST) CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

Fixed at 0 V>>GO TO 2.

2.CHECK THE SYMPTOM

Check that the lamp fixed to ON or OFF.

Fixed OFF>>GO TO 3.

Fixed ON>>GO TO 5.

3.CHECK MOOD LAMP (FRONT DOOR ARMREST) POWER SUPPLY

1. Turn ignition switch OFF.
2. Disconnect the mood lamp (front door armrest) connector.
3. Turn ignition switch ON.
4. Check voltage between the mood lamp (front door armrest) harness connector and ground.

Mood lamp (front door armrest)			Ground	Voltage (Approx.)
Connector		Terminal		
RH	D46	1		12 V
LH	D16	1		

Is the measurement value normal?

YES >> GO TO 4.

NO >> Check the hospitality lighting power supply circuit 2. Refer to [INL-32. "Diagnosis Procedure"](#).

4.CHECK MOOD LAMP (FRONT DOOR ARMREST) CONTROL CIRCUIT FOR OPEN

1. Turn ignition switch OFF.
2. Disconnect the total illumination control unit connector.
3. Check continuity between the total illumination control unit harness connector and mood lamp (front door armrest) harness connector.

Total illumination control unit		Mood lamp (front door armrest)		Continuity
Connector	Terminal	Connector	Terminal	
RH	M129	D46	2	Existed
LH		D16	2	

Does continuity exist?

YES >> Replace the mood lamp (front door armrest).

NO >> Repair the harnesses or connectors.

5.CHECK MOOD LAMP (FRONT DOOR ARMREST) CONTROL CIRCUIT FOR SHORT

1. Turn ignition switch OFF.
2. Disconnect the total illumination control unit and mood lamp (front door armrest) connectors.
3. Check continuity between the total illumination control unit harness connector and ground.

Total illumination control unit			Ground	Continuity
Connector		Terminal		Not existed
RH	M129	10		
LH		30		

Does continuity exist?

YES >> Repair the harnesses or connectors.

NO >> Replace the total illumination control unit.

PUSH-BUTTON IGNITION SWITCH ILLUMINATION CIRCUIT


< DTC/CIRCUIT DIAGNOSIS >

PUSH-BUTTON IGNITION SWITCH ILLUMINATION CIRCUIT

Description

INFOID:0000000010584944

Controls the lamp (ground side) by PWM signal (duty).



Component Function Check

INFOID:0000000010584945

1.CHECK PUSH-BUTTON IGNITION SWITCH ILLUMINATION OPERATION

CONSULT ACTIVE TEST

1. Turn ignition switch ON.
2. Select "ENGINE SWITCH ILLUMINATION" of TOTAL ILLUM C/U active test item.
3. While operating the test items, check the push-button ignition switch illumination operation.

Test item		Operation	
ENGINE SWITCH ILLUMINATION	On	Push-button ignition switch illumination	ON
	Off		OFF

Is the push-button ignition switch illumination turned ON/OFF?

- YES >> Push-button ignition switch illumination circuit is normal.
NO >> Refer to [INL-52, "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:0000000010584946

1.CHECK PUSH-BUTTON IGNITION SWITCH ILLUMINATION CONTROL OUTPUT

CONSULT ACTIVE TEST

1. Turn ignition switch ON.
2. Select "ENGINE SWITCH ILLUMINATION" of TOTAL ILLUM C/U active test item.
3. While operating the test items, check voltage between total illumination control unit harness connector and ground.

Driver side

Total illumination control unit		Ground	Test item	Voltage (Approx.)
Connector	Terminal		ENGINE SWITCH ILLUMINATION	
M129	19		On	0 V
			Off	12 V

Is the measurement value normal?

- Fixed at 12 V>>Replace the total illumination control unit.
Fixed at 0 V>>GO TO 2.

2.CHECK THE SYMPTOM

Check that the lamp fixed to ON or OFF.

Fixed OFF>>GO TO 3.

PUSH-BUTTON IGNITION SWITCH ILLUMINATION CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

Fixed ON>>GO TO 5.

3.CHECK PUSH-BUTTON IGNITION SWITCH ILLUMINATION POWER SUPPLY

1. Turn ignition switch OFF.
2. Disconnect the push-button ignition switch connector.
3. Turn ignition switch ON.
4. Check voltage between the push-button ignition switch harness connector and ground.

Push-button ignition switch		Ground	Voltage (Approx.)
Connector	Terminal		
M50	3		12 V

Is the measurement value normal?

YES >> GO TO 4.

NO >> Check the hospitality lighting power supply circuit 1. Refer to [INL-32. "Diagnosis Procedure"](#).

4.CHECK PUSH-BUTTON IGNITION SWITCH ILLUMINATION CONTROL CIRCUIT FOR OPEN

1. Turn ignition switch OFF.
2. Disconnect the total illumination control unit connector.
3. Check continuity between the total illumination control unit harness connector and push-button ignition switch illumination harness connector.

Total illumination control unit		Push-button ignition switch		Continuity
Connector	Terminal	Connector	Terminal	
M129	19	M50	2	Existed

Does continuity exist?

YES >> Repair the harnesses or connectors.

NO >> Replace the push-button ignition switch.

5.CHECK PUSH-BUTTON IGNITION SWITCH ILLUMINATION CONTROL CIRCUIT FOR SHORT

1. Turn ignition switch OFF.
2. Disconnect the total illumination control unit and push-button ignition switch connectors.
3. Check continuity between the total illumination control unit harness connector and ground.

Total illumination control unit		Ground	Continuity
Connector	Terminal		
M129	19		Not existed

Does continuity exist?

YES >> Repair the harnesses or connectors.

NO >> Replace the total illumination control unit.

MOOD LAMP (REAR DOOR ARMREST) CIRCUIT


< DTC/CIRCUIT DIAGNOSIS >

MOOD LAMP (REAR DOOR ARMREST) CIRCUIT

Description

INFOID:0000000010584947

Controls the lamp (ground side) by PWM signal (duty).



Component Function Check

INFOID:0000000010584948

1.CHECK MOOD LAMP (REAR DOOR ARMREST) CONTROL FUNCTION

CONSULT ACTIVE TEST

1. Turn ignition switch ON.
2. Select "MOOD LAMP" of TOTAL ILLUM C/U active test item.
3. While operating the test items, check mood lamp (rear door armrest) operation.

Test item		Operation	
MOOD LAMP	On	Mood lamp (rear door armrest)	ON
	Off		OFF

Are the mood lamps (rear door armrest) turned ON/OFF?

- YES >> Mood lamp (rear door armrest) circuit is normal.
NO >> Refer to [INL-54, "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:0000000010584949

1.CHECK MOOD LAMP (REAR DOOR ARMREST) CONTROL OUTPUT

CONSULT ACTIVE TEST

1. Turn ignition switch ON.
2. Select "MOOD LAMP" of TOTAL ILLUM C/U active test item.
3. While operating the test items, check voltage between total illumination control unit harness connector and ground.

Mood lamp (rear door armrest RH)

Total illumination control unit		Ground	Test item	Voltage (Approx.)
Connector	Terminal		MOOD LAMP	
M129	11		On	0 V
			Off	12 V

Mood lamp (rear door armrest LH)

Total illumination control unit		Ground	Test item	Voltage (Approx.)
Connector	Terminal		MOOD LAMP	
M129	31		On	0 V
			Off	12 V

Is the measurement value normal?

Fixed at 12 V>>Replace the total illumination control unit.

MOOD LAMP (REAR DOOR ARMREST) CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

Fixed at 0 V>>GO TO 2.

2.CHECK THE SYMPTOM

Check that the lamp fixed to ON or OFF.

Fixed OFF>>GO TO 3.

Fixed ON>>GO TO 5.

3.CHECK MOOD LAMP (REAR DOOR ARMREST) POWER SUPPLY

1. Turn ignition switch OFF.
2. Connect the total illumination control unit connector.
3. Disconnect the mood lamp (rear door armrest) connector.
4. Turn ignition switch ON.
5. Check voltage between the mood lamp (rear door armrest) harness connector and ground.

Mood lamp (rear door armrest)			Ground	Voltage (Approx.)
Connector		Terminal		
RH	D78	1		12 V
LH	D58	1		

Is the measurement value normal?

YES >> GO TO 4.

NO >> Check the hospitality lighting power supply circuit 1. Refer to [INL-32. "Diagnosis Procedure"](#).

4.CHECK MOOD LAMP (REAR DOOR ARMREST) CONTROL CIRCUIT FOR OPEN

1. Turn ignition switch OFF.
2. Disconnect the total illumination control unit connector.
3. Check continuity between the total illumination control unit harness connector and mood lamp (rear door armrest) harness connector.

Total illumination control unit		Mood lamp (rear door armrest)		Continuity
Connector	Terminal	Connector	Terminal	
RH	M129	D78	2	Existed
LH		D58	2	

Does continuity exist?

YES >> Replace the mood lamp (rear door armrest).

NO >> Repair the harnesses or connectors.

5.CHECK MOOD LAMP (REAR DOOR ARMREST) CONTROL CIRCUIT FOR SHORT

1. Turn ignition switch OFF.
2. Disconnect the total illumination control unit and mood lamp (rear door armrest) connectors.
3. Check continuity between the total illumination control unit harness connector and ground.

Total illumination control unit			Ground	Continuity
Connector		Terminal		
RH	M129	11		Not existed
LH		31		

Does continuity exist?

YES >> Repair the harnesses or connectors.

NO >> Replace the total illumination control unit.

HOSPITALITY ILLUMINATION CIRCUIT


< DTC/CIRCUIT DIAGNOSIS >

HOSPITALITY ILLUMINATION CIRCUIT

Description

INFOID:0000000010584950

Controls the lamp (ground side) by PWM signal (duty).



Component Function Check

INFOID:0000000010584951

1.CHECK ILLUMINATION CONTROL FUNCTION

CONSULT ACTIVE TEST

1. Turn ignition switch ON.
2. Select "HSPL ILLUMINATION" of TOTAL ILLUM C/U active test item.
3. While operating the test items, check the illuminations operation.

Test item		Operation	
HSPL ILLUMINATION	On	Illuminations	ON
	Off		OFF

Are the illuminations turned ON/OFF?

- YES >> Hospitality illumination circuit is normal.
NO >> Refer to [INL-56, "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:0000000010584952

1.CHECK ILLUMINATION CONTROL OUTPUT

CONSULT ACTIVE TEST

1. Turn ignition switch ON.
2. Select "HSPL ILLUMINATION" of TOTAL ILLUM C/U active test item.
3. While operating the test items, check voltage between total illumination control unit harness connector and ground.

Total illumination control unit		Ground	Test item	Voltage (Approx.)
Connector	Terminal		HSPL ILLU-MINATION	
M129	17		On	0 V
			Off	12 V

Is the measurement value normal?

- Fixed at 12 V>>Replace the total illumination control unit.
Fixed at 0 V>>GO TO 2.

2.CHECK THE SYMPTOM

Check that each illumination fixed to ON or OFF.

- Fixed OFF>>GO TO 3.
Fixed ON>>GO TO 5.

HOSPITALITY ILLUMINATION CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

3.CHECK EACH ILLUMINATION POWER SUPPLY

1. Turn ignition switch OFF.
2. Disconnect each illumination connectors.
3. Turn ignition switch ON.
4. Check voltage between each illumination harness connectors and ground.

Illuminations				Voltage (Approx.)
Connector		Terminal		
Meter control switch	M54	4	Ground	12 V
Multifunction switch	M72	4		
Climate controlled seat switch (driver side)	M177	7		
Climate controlled seat switch (passenger side)	M178	7		
LDW switch	M29	5		
Snow mode switch	M176	5		
Door mirror remote control switch	M20	16		
AFS OFF switch	M21	5		
Headlamp aiming switch	M15	3		
Clock	M74	2		
Combination switch	M36	23		
IBA OFF switch	M184	5		
DCA switch	M18	3		
VDC OFF switch	M19	3		

Is the measurement value normal?

YES >> GO TO 4.

NO >> Check the hospitality lighting power supply circuit 3. Refer to [INL-32. "Diagnosis Procedure"](#).

4.CHECK ILLUMINATION CONTROL CIRCUIT FOR OPEN

1. Turn ignition switch OFF.
2. Disconnect the total illumination control unit connector.
3. Check continuity between the total illumination control unit harness connector and each illumination harness connectors.

HOSPITALITY ILLUMINATION CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

Total illumination control unit		Illuminations			Continuity
Connector	Terminal	Connector		Terminal	
M129	17	Meter control switch	M54	5	Existed
		Multifunction switch	M72	5	
		Climate controlled seat switch (driver side)	M177	8	
		Climate controlled seat switch (passenger side)	M178	8	
		LDW switch	M29	4	
		Snow mode switch	M176	6	
		Door mirror remote control switch	M20	15	
		AFS OFF switch	M21	6	
		Headlamp aiming switch	M15	4	
		Clock	M74	1	
		Combination switch	M36	26	
		IBA OFF switch	M184	4	
		DCA switch	M18	4	
		VDC OFF switch	M19	4	

Does continuity exist?

YES >> Replace each illumination.

NO >> Repair the harnesses or connectors.

5.CHECK ILLUMINATION CONTROL CIRCUIT FOR SHORT

1. Turn ignition switch OFF.
2. Disconnect the total illumination control unit connector and each illumination connectors.
3. Check continuity between the total illumination control unit harness connector and ground.

Total illumination control unit		Ground	Continuity
Connector	Terminal		
M129	17		Not existed

Does continuity exist?

YES >> Repair the harnesses or connectors.

NO >> Replace the total illumination control unit.

STEP LAMP CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

STEP LAMP CIRCUIT

Description

INFOID:0000000010584953

Controls the step lamp (ground side) to turn the step lamp ON and OFF.

Component Function Check

INFOID:0000000010584954

CAUTION:

Check step lamp bulbs first.

1.CHECK STEP LAMP OPERATION

CONSULT ACTIVE TEST

1. Turn ignition switch ON.
2. Select "STEP LAMP TEST" of BCM (INT LAMP) active test item.
3. While operating the test items, check the step lamp operation.

Test item		Operation	
STEP LAMP TEST	On	Step lamps	ON
	Off		OFF

Are the step lamps turned ON/OFF?

- YES >> Step lamp circuit is normal.
NO >> Refer to [INL-59, "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:0000000010584955

1.CHECK STEP LAMP OUTPUT

CONSULT ACTIVE TEST

1. Turn ignition switch ON.
2. Select "STEP LAMP TEST" of BCM (INT LAMP) active test item.
3. While operating the test item, check continuity between BCM harness connector and ground.

BCM		Ground	Test item	Continuity
Connector	Terminal		STEP LAMP TEST	
M119	7		On	0 V
			Off	12 V

Is the measurement value normal?

- Fixed at 12 V>>Replace BCM.
Fixed at 0 V>>GO TO 2.

2.CHECK THE SYMPTOM

Check that the lamp fixed to ON or OFF.

- Fixed OFF>>GO TO 3.
Fixed ON>>GO TO 5.

3.CHECK STEP LAMP POWER SUPPLY

1. Turn ignition switch OFF.
2. Disconnect the step lamp connector.
3. Turn ignition switch ON.
4. Check voltage between the step lamp harness connector and ground.

STEP LAMP CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

Step lamp				Voltage (Approx.)
Connector		Terminal		
Driver side	D12	1	Ground	12 V
Passenger side	D42	1		
Rear LH	D59	1		
Rear RH	D79	1		

Is the measurement value normal?

YES >> GO TO 4.

NO >> Check the interior room lamp power supply. Refer to [INL-29, "Diagnosis Procedure"](#).

4.CHECK STEP LAMP OPEN CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect BCM connector.
3. Check continuity between BCM harness connector and step lamp harness connector.

BCM		Step lamp			Continuity
Connector	Terminal	Connector		Terminal	
M119	7	Driver side	D12	2	Existed
		Passenger side	D42	2	
		Rear LH	D59	2	
		Rear RH	D79	2	

Does continuity exist?

YES >> Replace the step lamp.

NO >> Repair the harnesses or connectors.

5.CHECK STEP LAMP SHORT CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect BCM and step lamp connectors.
3. Check continuity between BCM harness connector and ground.

BCM		Ground	Continuity
Connector	Terminal		
M119	7		Not existed

Does continuity exist?

YES >> Repair the harnesses or connectors.

NO >> Replace BCM.

TAIL LAMP SIGNAL CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

TAIL LAMP SIGNAL CIRCUIT

Description

INFOID:0000000010584956

Total illumination control unit inputs tail lamp signal from IPDM E/R.

Component Function Check

INFOID:0000000010584957

NOTE:

Check the tail lamp circuit if the tail lamp is not turned ON. Refer to [EXL-89, "Component Function Check"](#).

1.CHECK TAIL LAMP SIGNAL INPUT WITH CONSULT

CONSULT DATA MONITOR

1. Turn ignition switch ON.
2. Select "TAIL LAMP SIGNAL" of TOTAL ILLUM C/U data monitor item.
3. While operating the lighting switch, check the monitor status.

Monitor item	Condition	Monitor status
	Lighting switch	
TAIL LAMP SIGNAL	OFF	Off
	1ST	On

Is the measurement value normal?

YES >> Tail lamp signal circuit is normal.

NO >> Refer to [INL-61, "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:0000000010584958

1.CHECK TAIL LAMP INPUT SIGNAL

CONSULT ACTIVE TEST

1. Turn ignition switch ON.
2. Select "EXTERNAL LAMPS" of IPDM E/R active test item.
3. While operating the test item, check the voltage between the total illumination control unit and ground.

Terminals		Test item	Voltage (Approx.)
(+)	(-)		
Total illumination control unit		EXTERNAL LAMPS	Battery voltage
Connector	Terminal		
M129	4	TAIL	Battery voltage
		Off	0 V

Is the measurement value normal?

YES >> Replace the total illumination control unit.

NO >> GO TO 2.

2.CHECK TAIL LAMP SIGNAL CIRCUIT FOR OPEN

1. Turn ignition switch OFF.
2. Disconnect the IPDM E/R harness connector and total illumination harness connector.
3. Check continuity between the IPDM E/R harness connector and total illumination harness connector.

IPDM E/R		Total illumination control unit		Continuity
Connector	Terminal	Connector	Terminal	
E5	7	M129	4	Existed

Does continuity exist?

TAIL LAMP SIGNAL CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

YES >> GO TO 3.

NO >> Repair the harnesses or connectors.

3.CHECK TAIL LAMP SIGNAL CIRCUIT FOR SHORT

Check continuity between the total illumination control unit and ground.

Total illumination control unit		Ground	Continuity
Connector	Terminal		
M129	4		Not existed

Does continuity exist?

YES >> Repair the harnesses or connectors.

NO >> Replace the IPDM E/R.

ILLUMINATION CONTROL SIGNAL CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

ILLUMINATION CONTROL SIGNAL CIRCUIT

Component Function Check

INFOID:0000000010584959

1.CHECK ILLUMINATION CONTROL SIGNAL INPUT BY CONSULT

CONSULT DATA MONITOR

1. Turn ignition switch ON.
2. Switch the lighting switch 1ST.
3. Select "ILLUM CONT SIGNAL" of TOTAL ILLUM C/U data monitor item.
4. While operating the illumination control switch, check the monitor status.

Monitor item	Condition		Monitor status
ILLUM CONT SIGNAL	Brightness level	Maximum	100 %
		Midway	50 %
		Minimum	0 %

Is the item status normal?


- YES >> Illumination control signal circuit is normal.
NO >> Refer to [INL-63, "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:0000000010584960

1.CHECK ILLUMINATION CONTROL SIGNAL INPUT

1. Switch the lighting switch 1ST.
2. While operating the illumination control switch, check the voltage between the total illumination control unit harness connector and the ground.

Terminals		Condition	Voltage (Approx.)
(+)	(-)		
Total illumination control unit		Brightness level	
Connector	Terminal	Maximum	0 V
		Midway	
		Minimum	
M129	24	Ground	8 V

Is the measurement value normal?

- YES >> Replace the total illumination control unit.
NO >> GO TO 2.

2.CHECK ILLUMINATION CONTROL SIGNAL CIRCUIT FOR OPEN

1. Turn ignition switch OFF.
2. Disconnect the total illumination control unit connector and the combination meter connector.
3. Check continuity between the total illumination control unit harness connector and the combination meter harness connector.

ILLUMINATION CONTROL SIGNAL CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

Total illumination control unit		Combination meter		Continuity
Connector	Terminal	Connector	Terminal	
M129	24	M53	34	Existed

Does continuity exist?

YES >> GO TO 3.

NO >> Repair the harnesses or connectors.

3.CHECK ILLUMINATION CONTROL SIGNAL SHORT CIRCUIT

1. Disconnect the selector lever position indicator connector.
2. Check continuity between the total illumination control unit harness connector and the ground.

Total illumination control unit		Ground	Continuity
Connector	Terminal		
M129	24		Not existed

Does continuity exist?

YES >> Repair the harnesses or connectors.

NO >> Replace the total illumination control unit.

MAP LAMP SWITCH CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

MAP LAMP SWITCH CIRCUIT

Component Function Check

INFOID:0000000010584961

1.CHECK MAP LAMP SWITCH SIGNAL BY CONSULT

CONSULT DATA MONITOR

1. Turn ignition switch ON.
2. Select "MAP LAMP SW" of TOTAL ILLUM C/U data monitor item.
3. While operating the map lamp main switch, check the monitor status.

Monitor item	Condition		Monitor status
MAP LAMP SW	Map lamp main switch	DOOR	Door
		ON	All On
		OFF	Off

Is the item status normal?

- YES >> Map lamp main switch circuit is normal.
NO >> Refer to [INL-65. "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:0000000010584962

1.CHECK MAP LAMP SWITCH SIGNAL INPUT

1. Turn ignition switch ON.
2. While operating the map lamp main switch, check the voltage between the total illumination control unit harness connector and ground.

Terminals		Condition	Voltage (Approx.)
(+)	(-)		
Total illumination control unit		Map lamp main switch	
Connector	Terminal		
M129	26	DOOR	0 V
		OFF or ALL ON	5 V
	27	ALL ON	0 V
		OFF or DOOR	5 V

Is the measurement value normal?

- YES >> Replace the total illumination control unit.
NO >> GO TO 2.

2.CHECK MAP LAMP MAIN SWITCH

1. Turn ignition switch OFF.
2. Disconnect total illumination control unit connector.
3. While operating the map lamp main switch, check continuity between the total illumination control unit harness connector and ground.

MAP LAMP SWITCH CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

Total illumination control unit		Ground	Condition	Continuity
Connector	Terminal		Map lamp main switch	
M129	26		DOOR	Existed
			ALL ON	Not existed
			OFF	Not existed
	27		DOOR	Not existed
			ALL ON	Existed
			OFF	Not existed

Is the measurement value normal?

YES >> Replace the total illumination control unit.

NO >> GO TO 3.

3.CHECK MAP LAMP SWITCH SIGNAL CIRCUIT FOR OPEN

1. Turn ignition switch OFF.
2. Disconnect the map lamp connector.
3. Check continuity between the total illumination control unit harness connector and map lamp harness connector.

Total illumination control unit		Map lamp		Continuity
Connector	Terminal	Connector	Terminal	
M129	26	R15	1	Existed
	27		2	

Does continuity exist?

YES >> GO TO 4.

NO >> Repair the harnesses or connectors.

4.CHECK MAP LAMP SWITCH SIGNAL CIRCUIT FOR SHORT

Check continuity between the total illumination control unit harness connector and ground.

Total illumination control unit		Ground	Continuity
Connector	Terminal		
M129	26		Not existed
	27		

Does continuity exist?

YES >> Repair the harnesses or connectors.

NO >> GO TO 5.

5.CHECK MAP LAMP MAIN SWITCH GROUND CIRCUIT FOR OPEN

Check continuity between the map lamp harness connector and ground.

Map lamp		Ground	Continuity
Connector	Terminal		
R15	3		Existed

Does continuity exist?

YES >> Replace the map lamp assembly (map lamp main switch).

NO >> Repair the harness or connector.

DOOR SWITCH CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

DOOR SWITCH CIRCUIT

Component Function Check

INFOID:0000000010584963

1.CHECK EACH DOOR SWITCH SIGNAL BY CONSULT

CONSULT DATA MONITOR

1. Turn ignition switch ON.
2. Select "DOOR SW-DR", "DOOR SW-AS", "DOOR SW-RR" and "DOOR SW-RL" of TOTAL ILLUM C/U data monitor item.
3. While operating each door switch, check the monitor status.

Monitor item	Condition		Monitor status
DOOR-SW-DR	Front door (driver side)	Open	On
		Close	Off
DOOR-SW-AS	Front door (passenger side)	Open	On
		Close	Off
DOOR-SW-RR	Rear door (RH)	Open	On
		Close	Off
DOOR-SW-RL	Rear door (LH)	Open	On
		Close	Off

Is the item status normal?

- YES >> Each door switch circuit is normal.
NO >> Refer to [INL-67, "Diagnosis Procedure"](#).


Diagnosis Procedure

INFOID:0000000010584964

1.CHECK EACH DOOR SWITCH INPUT SIGNAL

While operating each door switch, check the voltage between the total illumination control unit harness connector and the ground.


Front door (driver side)

Terminals		Condition	Voltage (Approx.)
(+)	(-)		
Total illumination control unit		Door	
Connector	Terminal	Open	0 V
M129	29	Close	 8.5 - 9.0 V


DOOR SWITCH CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >


Front door (passenger side)

Terminals		Condition	Voltage (Approx.)
(+)	(-)		
Total illumination control unit		Door	
Connector	Terminal	Open	0 V
M129	8	Close	 JPMIA0594GB 8.5 - 9.0 V

Rear door (LH)

Terminals		Condition	Voltage (Approx.)
(+)	(-)		
Total illumination control unit		Door	
Connector	Terminal	Open	0 V
M129	9	Close	 JPMIA0594GB 8.5 - 9.0 V

Rear door (RH)

Terminals		Condition	Voltage (Approx.)
(+)	(-)		
Total illumination control unit		Door	
Connector	Terminal	Open	0 V
M129	25	Close	 JPMIA0594GB 8.5 - 9.0 V

Is the measurement value normal?

Fixed at 8.5 - 9.5 V>>Replace the total illumination control unit.

Fixed at 0 V>>GO TO 2.


2.CHECK TOTAL ILLUMINATION CONTROL UNIT (INTERNAL SHORT)

1. Turn ignition switch OFF.

DOOR SWITCH CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

2. Disconnect the total illumination control unit connector.
3. Turn ignition switch ON.
4. Check voltage between the total illumination control unit harness connector and ground.

Total illumination control unit			Voltage (Approx.)
Connector	Terminal		
Front door (driver side)	29	Ground	 JPMA0594GB 8.5 - 9.0 V
Front door (passenger side)	8		
Rear door (LH)	9		
Rear door (RH)	25		

Does continuity exist?

- YES >> Replace the total illumination control unit.
 NO >> GO TO3.

3.CHECK EACH DOOR SWITCH SIGNAL CIRCUIT FOR OPEN

1. Turn ignition switch OFF.
2. Disconnect each door switch connector.
3. Check continuity between the total illumination control unit harness connector and each door switch harness connector.

Total illumination control unit		Door switch		Continuity
Connector	Terminal	Connector	Terminal	
Front door (driver side)	29	B16	2	Existed
Front door (passenger side)	8	B216	2	
Rear door (LH)	9	B23	2	
Rear door (RH)	25	B223	2	

Does continuity exist?

- YES >> GO TO 4.
 NO >> Repair the harnesses or connectors.

4.CHECK EACH DOOR SWITCH SIGNAL CIRCUIT FOR SHORT

Check continuity between total illumination control unit harness connector and ground.

Total illumination control unit			Continuity
Connector	Terminal		
Front door (driver side)	29	Ground	Not existed
Front door (passenger side)	8		
Rear door (LH)	9		
Rear door (RH)	25		

DOOR SWITCH CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

Does continuity exist?

YES >> Repair the harnesses or connectors.

NO >> Check each door switch. Refer to [DLK-109, "Component Inspection"](#).

ROOM LAMP REQUEST SIGNAL CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

ROOM LAMP REQUEST SIGNAL CIRCUIT

Component Function Check

INFOID:0000000010584965

1.CHECK ROOM LAMP TIMER SETTING

CONSULT WORK SUPPORT

1. Select "SET I/L D-UNLCK INTCON" of BCM (INT LAMP) work support item.
2. Check the setting status.

Work support item	Setting status
SET I/L D-UNLCK INTCON	On

Is the setting "On"?

- YES >> GO TO 2.
NO >> Change the setting to "On"

2.CHECK ROOM LAMP TIMER SIGNAL BY CONSULT

CONSULT DATA MONITOR

1. Turn ignition switch OFF.
2. Select "ROOM LAMP REQ" of TOTAL ILLUM C/U data monitor item.
3. While operating the door lock/door unlock, check the monitor status.

Monitor item	Condition	Monitor status
ROOM LAMP REQ	Door is unlocked	On
	Door is locked	Off

Is the item status normal?

- YES >> Room lamp timer signal circuit is normal.
NO >> Refer to [INL-71, "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:0000000010584966

1.CHECK ROOM LAMP TIMER SIGNAL INPUT

CONSULT ACTIVE TEST

1. Turn ignition switch ON.
2. Select "INT LAMP" of BCM (INT LAMP) active test item.
3. While operating the test items, check voltage between total illumination control unit harness connector and ground.

Total illumination control unit		Ground	Test item	Voltage (Approx.)
Connector	Terminal		INT LAMP	
M129	28		On	5 V
			Off	0 V

Is the measurement value normal?

- YES >> Replace the total illumination control unit.
NO >> GO TO 2.

2.CHECK ROOM LAMP TIMER SIGNAL CIRCUIT FOR OPEN

1. Turn ignition switch OFF.
2. Disconnect the total illumination control unit and BCM connectors.
3. Check continuity between the total illumination control unit harness connector and BCM harness connector.

ROOM LAMP REQUEST SIGNAL CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

Total illumination control unit		BCM		Continuity
Connector	Terminal	Connector	Terminal	
M129	28	M119	19	Existed

Does continuity exist?

YES >> GO TO 3.

NO >> Repair the harnesses or connectors.

3.CHECK ROOM LAMP TIMER SIGNAL FOR SHORT

Check continuity between the total illumination control unit harness connector and ground.

Total illumination control unit		Ground	Continuity
Connector	Terminal		
M129	28		Not existed

Does continuity exist?

YES >> Repair the harnesses or connectors.

NO >> Replace the BCM.

Diagnosis Procedure

INFOID:0000000010584967

INTERIOR ROOM LAMP CONTROL SYSTEM


< DTC/CIRCUIT DIAGNOSIS >

INTERIOR ROOM LAMP CONTROL SYSTEM

Wiring Diagram - INTERIOR ROOM LAMP -

INFOID:000000010584968


INTERIOR ROOM LAMP CONTROL SYSTEM



2014/03/18


JRLWD6050GB

< DTC/CIRCUIT DIAGNOSIS >



INTERIOR ROOM LAMP CONTROL SYSTEM

< DTC/CIRCUIT DIAGNOSIS >



INTERIOR ROOM LAMP CONTROL SYSTEM

< DTC/CIRCUIT DIAGNOSIS >

INTERIOR ROOM LAMP CONTROL SYSTEM

Connector No.	B1
Connector Name	WIRE TO WIRE
Connector Type	TH80FW-CS16-TM4




Terminal No.	Color Of Wire	Signal Name [Specification]
1	G	-
2	L	-
3	W	-
4	G	-
5	P	-
6	BG	-
7	SB	-
8	SB	-
9	SB	-
10	SB	-
11	SB	-
12	B	-
13	G	-
14	R	-
15	W	-
16	SHIELD	-
17	L	-
18	P	-
19	G	-
20	Y	-
21	W	-
23	V	-
24	P	-
25	BR	-
26	GR	-
27	BG	-
28	W	-
38	B	-
39	B	-
43	SB	-
44	V	-
45	GR	-
51	V	-
52	SB	-
53	SHIELD	-
54	BR	-
55	Y	-
56	SHIELD	-

Connector No.	B16
Connector Name	FRONT DOOR SWITCH (DRIVER SIDE)
Connector Type	A03FW



Terminal No.	Color Of Wire	Signal Name [Specification]
2	GR	-



Connector No.	B18
Connector Name	WIRE TO WIRE
Connector Type	NH10FW-CS10




6	5	4	3	2	1
20	19	18	17	16	15
14	13	12	11	10	9
8	7	6	5	4	3
2	1	0	9	8	7

Terminal No.	Color Of Wire	Signal Name [Specification]
2	V	-
3	W	-
4	GR	-
5	Y	-
6	B	-
8	BR	-
12	LG	-
13	P	-
17	L	-
18	BG	-
19	G	-
20	W	-

Connector No.	B23
Connector Name	REAR DOOR SWITCH LH
Connector Type	A03FW



Terminal No.	Color Of Wire	Signal Name [Specification]
2	W	-



Connector No.	B27
Connector Name	WIRE TO WIRE
Connector Type	N08MW-GY-LC



1	2	3	4
5	6	7	8

Terminal No.	Color Of Wire	Signal Name [Specification]
1	G	-
2	B	-
3	W	-
4	B	-
6	BR	-
7	G	-
8	SHIELD	-

INTERIOR ROOM LAMP CONTROL SYSTEM

< DTC/CIRCUIT DIAGNOSIS >

INTERIOR ROOM LAMP CONTROL SYSTEM

Connector No.	B28
Connector Name	WIPE TO WIRE
Connector Type	TH32MW-AH



1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24	25	26	27	28	29	30	31	32
---	---	---	---	---	---	---	---	---	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----



Connector No.	B47
Connector Name	DIODE
Connector Type	24335_C9900



Terminal No.	Color Of Wire	Signal Name [Specification]
1	R	-
2	B	-
3	W	-
4	SHIELD	-
5	G	-
6	L	-
7	R	-
8	SHIELD	-
9	W	-
10	B	-
11	G	-
12	L	-
13	W	-
14	LG	-
15	BG	-
16	G	-
17	BG	-
18	V	-
19	W	-
20	B	-
21	G	-
22	LG	-
23	R	-
24	BG	-
25	BR	-
26	GR	-
27	L	-
32	BG	-

Connector No.	B67
Connector Name	WIPE TO WIRE
Connector Type	NS16BR-CS



1	2	3	4	5	6	7
8	9	10	11	12	13	14
15	16	17	18	19	20	21

Terminal No.	Color Of Wire	Signal Name [Specification]
1	BR	-
2	G	-
3	SHIELD	-
5	G	-
8	BR	-
9	G	-
10	SHIELD	-
11	L	-
12	GR	-
13	R	-
14	R	-

Connector No.	B201
Connector Name	WIPE TO WIRE
Connector Type	TH80FM-CS16-TM4



1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24	25	26	27	28	29	30	31	32
---	---	---	---	---	---	---	---	---	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----

Terminal No.	Color Of Wire	Signal Name [Specification]
1	G	-
2	R	-
3	BR	-
4	SB	-
6	BG	-
7	GR	-
8	W	-
10	G	-
11	SHIELD	-
20	L	-
21	P	-
22	GR	-
23	LG	-
24	W	-
25	V	-
26	G	-
27	Y	-
28	SHIELD	-
31	W	-
32	GR	-
33	SB	-
36	L	-
37	P	-
38	L	-
39	P	-
40	LG	- [With ICC]
40	V	- [Without ICC]
41	SB	- [With ICC]
41	Y	- [Without ICC]
42	V	- [With ICC]
42	W	- [Without ICC]
43	B	- [Without ICC]
43	BR	- [With ICC]
44	R	-
45	G	-
46	BG	- [With ICC]


46	SHIELD	- [Without ICC]
47	B	- [Without ICC]
47	L	- [With ICC]
48	P	- [With ICC]
48	R	- [Without ICC]
49	G	- [With ICC]
49	W	- [Without ICC]
50	SHIELD	-
51	W	-
52	R	-
53	G	-
54	L	-
55	SB	-
60	GR	-
61	LG	-
62	SB	-
63	P	-
64	BR	-
66	BG	-
66	Y	-
67	W	-
69	G	-
71	SB	-
72	V	-
73	LG	-
74	W	-
75	BR	-
76	V	-
77	LG	-
80	BG	-
82	P	-
83	Y	-
84	R	-
85	SB	-
86	GR	-
87	L	-
91	V	-
92	W	-
93	R	-
94	LG	-
95	GR	-
96	W	-
97	G	-
98	BG	-
99	L	-

INTERIOR ROOM LAMP CONTROL SYSTEM

< DTC/CIRCUIT DIAGNOSIS >


INTERIOR ROOM LAMP CONTROL SYSTEM

Connector No.	B216
Connector Name	FRONT DOOR SWITCH (PASSENGER SIDE)
Connector Type	A03FW




Terminal No.	Color Of Wire	Signal Name [Specification]
2	GR	-

Connector No.	B218
Connector Name	WIRE TO WIRE
Connector Type	NH10FW-CS10



Terminal No.	Color Of Wire	Signal Name [Specification]
2	GR	-
3	W	-
4	R	-
5	SB	-
6	B	-
8	G	-
12	LG	-
13	P	-
17	SB	-
18	BR	-
19	BR	-
20	LG	-

Connector No.	B223
Connector Name	REAR DOOR SWITCH RH
Connector Type	A03FW



Terminal No.	Color Of Wire	Signal Name [Specification]
2	BG	-

Connector No.	B229
Connector Name	LUGGAGE ROOM LAMP (LUGGAGE SIDE)
Connector Type	TK03FW




Terminal No.	Color Of Wire	Signal Name [Specification]
1	W	-
2	L	-

Connector No.	B241
Connector Name	WIRE TO WIRE
Connector Type	NS16FBR-CS



Terminal No.	Color Of Wire	Signal Name [Specification]
1	BR	-
2	G	-
3	SHIELD	-
5	G	-
8	L/Y	-
9	L/B	-
10	SHIELD	-
11	L	-
12	W	-
13	P	-
14	R	-

Connector No.	D1
Connector Name	WIRE TO WIRE
Connector Type	TH40FW-CS15



Terminal No.	Color Of Wire	Signal Name [Specification]
1	B	-
3	G	-
6	GR	-
7	W	-
8	SB	-
9	BR	-
10	O	-
11	R	-
12	LG	-
13	Y	-
14	P	-
15	L	-
20	V	-
21	Y	-
22	GR	-
23	SB	-
24	LG	-
26	G	-
27	V	-
28	P	-
29	Y	-

30	LG	-
31	O	-
32	BR	-
33	L	-
34	GR	-
35	B	-
36	R	-
37	G	-
38	SHIELD	-
39	W	-
40	B	-
41	SHIELD	-
42	G	-
43	R	-
44	BR	-
45	V	-
46	P	-
47	W	-
48	GR	-
49	R	-
50	B	-
51	SB	-
52	L	-
53	G	-
54	O	-
55	GR	-

Connector No.	D3
Connector Name	DOOR MIRROR (DRIVER SIDE)
Connector Type	TH24MW-NH



Terminal No.	Color Of Wire	Signal Name [Specification]
2	R	-
3	W	-
5	G	-
6	R	-
7	GR	-
8	SB	-
9	L	-
10	G	-

INTERIOR ROOM LAMP CONTROL SYSTEM

< DTC/CIRCUIT DIAGNOSIS >

INTERIOR ROOM LAMP CONTROL SYSTEM


Connector No.	D9
11	GR
12	O
14	B
17	SHIELD
18	B
19	B
21	P
22	BR
23	W
24	V




Connector No.	D13
Connector Name	FRONT OUTSIDE HANDLE LH (REQUEST SWITCH)
Connector Type	RK02FL-B



Connector No.	D15
Connector Name	FRONT DOOR LOCK ASSEMBLY (DRIVER SIDE)
Connector Type	ED0FGY-RS



Connector No.	D8
Connector Name	POWER WINDOW MAIN SWITCH
Connector Type	NS16FW-CS



Terminal No.	Color Of Wire	Signal Name [Specification]
17	B	-
19	Y	-

Terminal No.	Color Of Wire	Signal Name [Specification]
1	G	-
2	B	-

Terminal No.	Color Of Wire	Signal Name [Specification]
1	LG	-
2	R	-
3	G	-
4	B	-
5	Y	-
6	V	-

Connector No.	D12
Connector Name	STEP LAMP (DRIVER SIDE)
Connector Type	TB02FW



Connector No.	D14
Connector Name	FRONT OUTSIDE HANDLE LH (OUTSIDE KEY ANTENNA)
Connector Type	RK02MGY



Connector No.	D16
Connector Name	MOOD LAMP (FR DOOR ARMREST LH)
Connector Type	TK02FGY



Terminal No.	Color Of Wire	Signal Name [Specification]
1	W	-
2	LG	-
3	GR	-
4	V	-
5	SB	-
6	Y	-
7	BR	-
8	L	-
9	W	-
10	O	-
11	G	-
13	P	-
14	V	-
15	W	-

Terminal No.	Color Of Wire	Signal Name [Specification]
1	LG	-
2	SB	-

Terminal No.	Color Of Wire	Signal Name [Specification]
1	P	-
2	V	-

Terminal No.	Color Of Wire	Signal Name [Specification]
1	GR	-
2	Y	-

JRLW06056GB

A
B
C
D
E
F
G
H
I
J
K
INL
M
N
O
P

INTERIOR ROOM LAMP CONTROL SYSTEM

< DTC/CIRCUIT DIAGNOSIS >

INTERIOR ROOM LAMP CONTROL SYSTEM

Connector No.	D46
Connector Name	MOOD LAMP (FR DOOR ARMREST RH)
Connector Type	TK02FGY



Terminal No.	Color Of Wire	Signal Name [Specification]
1	GR	-
2	Y	-

Connector No.	D51
Connector Name	WIRE TO WIRE
Connector Type	NH10MW-CS10



1	2	3	4	5	6
7	8	9	10	11	12
13	14	15	16	17	18
19	20				

Terminal No.	Color Of Wire	Signal Name [Specification]
2	V	-
3	L	-
4	R	-
5	SB	-
6	B	-
8	G	-
12	L	-
13	Y	-
17	O	-
18	BR	-
19	V	-
20	W	-

Connector No.	D58
Connector Name	MOOD LAMP (RR DOOR ARMREST LH)
Connector Type	TK02FGY



Terminal No.	Color Of Wire	Signal Name [Specification]
1	Y	-
2	BR	-

Connector No.	D59
Connector Name	STEP LAMP (REAR LH)
Connector Type	TB02FW



Terminal No.	Color Of Wire	Signal Name [Specification]
1	L	-
2	O	-

Connector No.	D71
Connector Name	WIRE TO WIRE
Connector Type	NH10MW-CS10



1	2	3	4	5	6
7	8	9	10	11	12
13	14	15	16	17	18
19	20				

Terminal No.	Color Of Wire	Signal Name [Specification]
2	L	-
3	P	-
4	R	-
5	SB	-
6	B	-
8	G	-
12	L	-
13	Y	-
17	O	-
18	BR	-
19	V	-
20	W	-

Connector No.	D78
Connector Name	MOOD LAMP (RR DOOR ARMREST RH)
Connector Type	TK02FGY



Terminal No.	Color Of Wire	Signal Name [Specification]
1	Y	-
2	BR	-

Connector No.	D79
Connector Name	STEP LAMP (REAR RH)
Connector Type	TB02FW



Terminal No.	Color Of Wire	Signal Name [Specification]
1	L	-
2	O	-

Connector No.	D101
Connector Name	WIRE TO WIRE
Connector Type	MA02FW-GY-LC



4	3	2	1
8	7	6	5

Terminal No.	Color Of Wire	Signal Name [Specification]
1	G	-
2	B	-
3	R	-
4	GR	-
6	L/W	-
7	L/B	-
8	SHIELD	-

JRLWD6058GB

INTERIOR ROOM LAMP CONTROL SYSTEM

< DTC/CIRCUIT DIAGNOSIS >

INTERIOR ROOM LAMP CONTROL SYSTEM

Connector No.	D102
Connector Name	WIRE TO WIRE
Connector Type	TH32FW-NH



16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1
32	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17

Connector No.	D107
Connector Name	BACK DOOR LOCK ASSEMBLY
Connector Type	NS08FW-CS



1		2	
4	5	6	7
			8

INTERIOR ROOM LAMP CONTROL SYSTEM

< DTC/CIRCUIT DIAGNOSIS >

INTERIOR ROOM LAMP CONTROL SYSTEM

Connector No.	E5
Connector Name	(POWER INTELLIGENT POWER DISTRIBUTION MODULE (ENGINE ROOM))
Connector Type	TH8FWM-NH




Connector No.	E106
Connector Name	WIPE TO WIRE
Connector Type	TH8FWM-CS16-TM4



Terminal No.	Color Of Wire	Signal Name [Specification]
39	P	-
40	L	-
41	B	-
42	Y	-
43	SB	-
44	W	-
45	G	-
46	BR	-

Connector No.	E103
Connector Name	FUSE BLOCK (J/B)
Connector Type	NS16FWM-CS




Terminal No.	Color Of Wire	Signal Name [Specification]
10F	L	-
1F	SB	-
2F	W	-
3F	Y	-
4F	G	-
6F	BG	-
8F	L	-
9F	R	-

37	Y	-
38	GR	-
39	LG	-
41	LG	-
42	V	-
43	R	-
44	G	-
45	GR	-
46	W	-
47	L	-
48	P	-
49	SB	-
50	BR	-
51	B	-
52	Y	-
53	BG	-
54	R	-
55	SB	-
58	P	-
60	SB	-
61	V	-
62	P	-
63	LG	-
64	L	-
65	BG	-
69	L	-
70	SHIELD	-
71	G	-
72	G	-
73	R	-
74	BR	-
76	L	-
77	W	-
78	Y	-
80	SB	-
81	L	-
82	W	-
83	LG	-
84	GR	-
85	G	-
86	P	-
87	W	-
88	BG	-
89	LG	-
90	BR	-
91	GR	-
92	BR	-
93	SB	-
95	Y	-
96	W	-


97	W	-
98	SHIELD	-
100	Y	-

Connector No.	M1
Connector Name	FUSE BLOCK (J/B)
Connector Type	NS06FWM-M2



Terminal No.	Color Of Wire	Signal Name [Specification]
1A	BG	-
2A	G	-
3A	L	-
4A	R	-
5A	V	-
6A	Y	-
7A	R	-
8A	L	-

Connector No.	M2
Connector Name	FUSE BLOCK (J/B)
Connector Type	NS10FWM-CS



Terminal No.	Color Of Wire	Signal Name [Specification]
1B	LG	-
3B	P	-
4B	G	-
5B	BG	-
6B	Y	-
7B	L	-
8B	R	-


INTERIOR ROOM LAMP CONTROL SYSTEM

< DTC/CIRCUIT DIAGNOSIS >

INTERIOR ROOM LAMP CONTROL SYSTEM


9B	BR	-
----	----	---

Connector No.	M3
Connector Name	FUSE BLOCK (J/B)
Connector Type	MS12FW-CS



Terminal No.	Color Of Wire	Signal Name [Specification]
10C	L	-
11C	LG	-
12C	R	-
13C	P	-
14C	B	-
15C	BG	-

Connector No.	M5
Connector Name	WIRE TO WIRE
Connector Type	TH40MW-CS15



Terminal No.	Color Of Wire	Signal Name [Specification]
1	B	-
3	SB	-
6	R	-
7	W	-
8	G	-
9	L	-
10	BG	-
11	G	-
12	V	-
13	Y	-
14	P	-

Connector No.	M6
Connector Name	WIRE TO WIRE
Connector Type	TH40MW-CS16-TM4



Terminal No.	Color Of Wire	Signal Name [Specification]
1	G	-
2	BG	-
3	LG	- [Without Auto aircon seat]
4	SB	- [With Auto aircon seat]
5	LG	-
6	GR	-
7	W	-
8	G	-
9	P	-
10	BR	-
11	B	-
12	G	-
13	R	-
14	W	-
15	SHIELD	-
16	BR	-
17	L	-
18	P	-
19	G	-
20	GR	- [Without ICC]
21	W	- [With ICC]
22	BR	- [Without ICC]
23	R	- [With ICC]
24	L	- [Without ICC]
25	P	- [With ICC]
26	Y	- [Without ICC]
27	SHIELD	-
28	GR	-
29	V	-
30	BG	-
31	W	-


33	Y	-
34	L	-
37	G	-
38	R	-
39	G	-
41	L	-
42	W	-
43	R	-
44	LG	-
45	GR	-
46	W	-
47	L	-
48	P	-
49	BG	-
50	LG	-
51	SB	-
52	Y	-
53	BG	-
54	BR	-
55	SB	-
58	SB	-
60	SB	-
61	V	-
62	P	-
63	R	-
64	L	-
65	BG	-
69	V	-
70	SHIELD	-
71	BG	-
72	GR	-
73	W	-
74	SB	-
76	V	-
77	V	-
78	Y	-
80	BG	-
81	L	-
82	W	-
83	Y	-
84	L	-
85	P	-
86	BR	-
87	P	-
88	V	-
89	G	-
90	P	-
91	R	-
92	R	-
93	GR	-

< DTC/CIRCUIT DIAGNOSIS >

Terminal	Color Of Wire	Signal Name (Specification)
1	G	- (With Auto aircon seat)
1	Y	- (Without Auto aircon seat)
2	B	-
3	W	-
6	P	-
7	V	-
8	BG	-
10	W	-
11	BG	-
12	B	-
13	G	-
14	R	-
15	W	-
16	SHIELD	-
17	L	-
18	P	-
19	G	-
20	R	-
21	LG	-
23	V	-
24	P	-
25	BR	-
26	GR	-
27	BG	-
28	W	-
38	B	-
39	B	-
43	SB	-
44	W	-


45	B	-
51	V	-
52	LG	-
53	SHIELD	-
54	R	-
55	V	-
56	SHIELD	-
57	P	-
58	L	-
59	SHIELD	-
60	L	-
61	BR	-
62	R	-
63	Y	-
64	L	-
65	W	-
66	V	-
67	LG	-
68	V	-
69	G	-
70	V	-
71	W	-
72	B	-
73	W	-
74	LG	-
75	P	-
76	LG	-
77	SB	-
78	GR	-
79	R	-
80	B	-
81	L	-
82	P	-
83	SB	-
84	SB	-
85	V	-
86	B	-
87	B	-
88	B	-
89	B	-
90	C	-
91	C	-
92	B	-
93	BR	-
94	L	-
95	B	-
97	W	-
98	C	-

Connector No.	M22
Connector Name	KEY SLOT
Connector Type	TH12FW-NH



Terminal No.	Color Of Wire	Signal Name [Specification]
1	R	BAT
2	GR	CLOCK
3	W	DATA
5	Y	ILL BAT
6	LG	ILL
7	B	GROUND
11	BR	KEY SWITCH SIGNAL

Connector No.	M24
Connector Name	DATA LINK CONNECTOR
Connector Type	BD16FW




Terminal No.	Color Of Wire	Signal Name [Specification]
3	LG	-
4	B	-
5	B	-
6	L	-
7	GR	-
8	G	-
11	SB	-
12	P	-
13	L	-
14	P	-
16	SC	-

Connector No.	M30
Connector Name	FOOT LAMP (DRIVER SIDE)
Connector Type	C02FW



Terminal No.	Color Of Wire	Signal Name [Specification]
1	V	-
2	L	-

Connector No.	M50
Connector Name	PUSH-BUTTON IGNITION SWITCH
Connector Type	TK08FBR



Terminal No.	Color Of Wire	Signal Name [Specification]
1	B	-
2	R	-
3	B/G	-
4	SB	-
5	GR	-
6	Y	-
7	V	-
8	P	-

INTERIOR ROOM LAMP CONTROL SYSTEM

< DTC/CIRCUIT DIAGNOSIS >

INTERIOR ROOM LAMP CONTROL SYSTEM

Connector No.	M104
Connector Name	REMOTE KEYLESS ENTRY RECEIVER
Connector Type	JAB04FB



Terminal No.	Color Of Wire	Signal Name [Specification]
1	B	GROUND
2	GR	SIGNAL OUTPUT
4	BR	BATTERY

Connector No.	M106
Connector Name	WIRE TO WIRE
Connector Type	NH10MW-CS10



1	2	3	4	5	6
7	8	9	10	11	12
13	14	15	16	17	18
19	20				

Terminal No.	Color Of Wire	Signal Name [Specification]
1	V	-
2	BR	-
3	GR	-
4	SHIELD	-
5	G	-
6	BR	-
9	P	-
10	G	-
11	Y	-
12	BR	-
13	L	-
14	L	-
15	R	-
16	R	-
17	B	-
20	BG	-

Connector No.	M117
Connector Name	WIRE TO WIRE
Connector Type	TH0MMW-CS16-TM4



1	2	3	4	5	6
7	8	9	10	11	12
13	14	15	16	17	18
19	20	21	22	23	24
25	26	27	28	29	30
31	32	33	34	35	36
37	38	39	40	41	42
43	44	45	46	47	48
49	50	51	52	53	54
55	56	57	58	59	60
61	62	63	64	65	66
67	68	69	70	71	72
73	74	75	76	77	78
79	80	81	82	83	84
85	86	87	88	89	90
91	92	93	94	95	96
97	98	99	100		

Terminal No.	Color Of Wire	Signal Name [Specification]
1	GR	-
2	BR	-
3	V	-
4	SB	-
6	Y	-
7	B	-
8	W	-
10	W	-
11	SHIELD	-
20	R	-
21	G	-
22	GR	-
23	V	-
24	W	-
25	R	-
26	P	-
27	L	-
28	SHIELD	-
31	W	-
32	W	-
33	SB	-
36	L	-
37	P	-
38	L	-
39	P	-
40	V	-
41	SB	- [With ICC]
41	Y	- [Without ICC]
42	V	- [With ICC]
42	W	- [Without ICC]
43	B	- [With ICC]
43	P	- [Without ICC]
44	R	- [With ICC]
44	R	- [Without ICC]
45	G	- [With ICC]
45	L	- [Without ICC]
46	BG	- [With ICC]
46	BG	- [Without ICC]

Terminal No.	Color Of Wire	Signal Name [Specification]
46	SHIELD	- [Without ICC]
47	B	- [Without ICC]
47	L	- [With ICC]
48	P	- [With ICC]
48	R	- [Without ICC]
49	G	- [With ICC]
49	W	- [Without ICC]
50	SHIELD	-
51	BG	-
52	GR	-
53	G	-
54	L	-
55	P	-
60	LG	-
61	R	-
62	SB	-
63	V	-
64	Y	-
65	BR	-
66	BG	-
67	W	-
69	G	-
71	SB	-
72	V	-
73	V	-
74	LG	-
75	BR	-
76	V	-
77	LG	-
80	R	-
82	Y	-
83	BG	-
84	W	-
85	SB	-
86	B	-
87	P	-
91	L	-
92	L	-
93	G	-
94	BG	-
95	V	-
96	G	-
97	G	-
98	L	-
99	LG	-

Connector No.	M118
Connector Name	BCM (BODY CONTROL MODULE)
Connector Type	M03FB-LC



Terminal No.	Color Of Wire	Signal Name [Specification]
1	W	BAT (E/L)
2	Y	POWER WINDOW POWER SUPPLY (BAT)
3	BG	POWER WINDOW POWER SUPPLY (BAT)

Connector No.	M119
Connector Name	BCM (BODY CONTROL MODULE)
Connector Type	NS16FM-CS



4	5	7	8	9	10
11	13	15	17	18	19


Terminal No.	Color Of Wire	Signal Name [Specification]
4	P	INT ROOM LAMP PWR SUPPLY (BAT SAVE)
5	V	PASSENGER DOOR UNLOCK OUTPUT
7	Y	STEP LAMP OUTPUT
8	V	ALL DOOR FUEL LID LOCK OUTPUT
9	G	DRIVER DOOR FUEL LID UNLOCK OUTPUT
10	BR	REAR DOOR UNLOCK OUTPUT
11	R	BAT (FUSE)
13	B	GROUND
15	Y	ACC NO
17	W	TURN SIGNAL RH (FRONT)
18	BG	TURN SIGNAL LH (FRONT)
19	SB	ROOM LAMP TIMER

INTERIOR ROOM LAMP CONTROL SYSTEM

< DTC/CIRCUIT DIAGNOSIS >


INTERIOR ROOM LAMP CONTROL SYSTEM

Connector No.	M121
Connector Name	BCM (BODY CONTROL MODULE)
Connector Type	TH40FGY-NH



Terminal No.	Color Of Wire	Signal Name [Specification]
34	SB	LUGGAGE ROOM ANT-
35	V	LUGGAGE ROOM ANT+
38	B	BACK DOOR ANT-
39	W	BACK DOOR ANT+
47	Y	IGN RELAY (PDM/ER) CONT
52	LG	STARTER RELAY CONT
60	SB	ENG START SW
61	W	TRUNK REQUEST SW
64	L	LKEY WARN BUZZER (ENG ROOM)
65	BG	REAR WIPER STOP POSITION
66	LG	BACK DOOR SW
67	P	BACK DOOR OPENER SW
68	BR	REAR RH DOOR SW
69	R	REAR LH DOOR SW


Connector No.	M122
Connector Name	BCM (BODY CONTROL MODULE)
Connector Type	TH40FB-NH



Terminal No.	Color Of Wire	Signal Name [Specification]
74	SB	PASSENGER DOOR ANT-
75	BR	PASSENGER DOOR ANT+
76	V	DRIVER DOOR ANT-
77	LG	DRIVER DOOR ANT+
78	Y	ROOM ANT-
79	BR	ROOM ANT+

Terminal No.	Color Of Wire	Signal Name [Specification]
80	GR	NATS ANT AMP.
81	W	NATS ANT AMP.
82	P	IGN RELAY (FBI) CONT
83	GR	KEYLESS ENTRY RECEIVER SIGNAL
144	G	COMBI SW OUTPUT 1
145	L	COMBI SW OUTPUT 2
88	V	COMBI SW INPUT 5
87	W	COMBI SW INPUT 3
90	P	CAN-L
91	L	CAN-H
92	LG	KEY SLOT ILL
93	V	ON IND
95	BG	ACC RELAY CONT
96	GR	AT SHIFT SELECTOR POWER SUPPLY
99	R	SHIFT P
100	G	PASSENGER DOOR REQUEST SW
101	SB	DRIVER DOOR REQUEST SW
102	BG	BLOWER FAN MOTOR RELAY CONT
103	BR	KEYLESS ENTRY RECEIVER POWER SUPPLY
107	LG	COMBI SW INPUT 1
108	R	COMBI SW INPUT 4
109	Y	COMBI SW INPUT 2
110	G	HAZARD SW


Connector No.	M123
Connector Name	BCM (BODY CONTROL MODULE)
Connector Type	TH40FG-NH



Terminal No.	Color Of Wire	Signal Name [Specification]
112	GR	RAIN SENSOR SERIAL LINK
113	P	OPTICAL SENSOR
116	BR	STOP LAMP SW 1
118	P	STOP LAMP SW 2
119	SB	DR DOOR UNLOCK SENSOR
121	BR	KEY SLOT SW
123	W	IGN F/B
124	LG	PASSENGER DOOR SW
132	BG	POWER WINDOW SW COMM
134	GR	LOCK IND
137	B	RECEIVER SENSOR GND
138	Y	SENSOR POWER SUPPLY
140	R	SHIFT NP

Terminal No.	Color Of Wire	Signal Name [Specification]
141	G	SECURITY INDICATOR OUTPUT
142	BG	COMBI SW OUTPUT 5
143	P	COMBI SW OUTPUT 1
144	G	COMBI SW OUTPUT 2
145	L	COMBI SW OUTPUT 3
146	SB	COMBI SW OUTPUT 4
150	GR	DRIVER DOOR SW
151	G	REAR WINDOW DEFROGGER RELAY CONT


Connector No.	M124
Connector Name	WIRE TO WIRE
Connector Type	TH40MW-CS15



Terminal No.	Color Of Wire	Signal Name [Specification]
3	Y	-
4	LG	-
5	SB	-
6	BR	-
7	G	-
8	V	-
9	LG	-
13	B	-
14	BG	-
15	W	-
19	G	-
20	LG	-
22	W	-
23	B	-
24	SHIELD	-
25	G	-
26	R	-
31	BG	-
32	Y	-
33	LG	-
34	SB	-
35	V	-
36	BG	-
37	GR	-
38	G	- [Without automatic drive positioner]
	R	- [With automatic drive positioner]

Terminal No.	Color Of Wire	Signal Name [Specification]
39	B	-
40	R	-
41	P	-
42	LG	-
43	L	-
44	Y	-
45	R	-
46	W	-
47	Y	-
48	BR	-
49	SHIELD	-

Connector No.	M129
Connector Name	TOTAL ILLUMINATION CONTROL UNIT
Connector Type	TH40FW-NH



Terminal No.	Color Of Wire	Signal Name [Specification]
3	V	DDL2
4	L	TAIL LAMP SIGNAL
5	V	ACC SIGNAL
6	P	BAT SAVER SIGNAL
7	W	IGN SIGNAL
8	G	DOOR SW (AS)
9	BG	DOOR SW (RL)
10	SB	MOOD LAMP (FR ARMREST RH)
11	Y	MOOD LAMP (RR ARMREST RH)
12	P	MAP LAMP (AS)
13	G	PERSONAL LAMP (LH)
14	R	PERSONAL LAMP (RH)
16	GR	FOOT LAMP (RH)
17	LG	HSPILL ILLUMINATIONS
18	L	MAP LAMP (DR)
19	R	PUSH ENG START SW LED
20	Y	AMBIENCE LAMP
21	R	BAT POWER SUPPLY
23	B	GROUND
24	B	ILL CONT INPUT
25	BR	DOOR SW (RR)
26	BR	MAP LAMP SW (DOOR)
27	R	MAP LAMP SW (ALL ON)

INTERIOR ROOM LAMP CONTROL SYSTEM

< DTC/CIRCUIT DIAGNOSIS >

INTERIOR ROOM LAMP CONTROL SYSTEM

Connector No.	M130
Connector Name	ROOM LAMP TIMER
Connector Type	DOOR SW (DR)
28	SB
29	GR
30	LG
31	BG
33	W
34	R
35	V
36	L
39	B
40	BG



Connector No.	M130
Connector Name	FOOT LAMP (PASSENGER SIDE)
Connector Type	CO2FW



Terminal Color Of No.	Wire	Signal Name [Specification]
1	V	-
2	GR	-

Connector No.	M151
Connector Name	WIRE TO WIRE
Connector Type	M03FW-LC



Terminal Color Of No.	Wire	Signal Name [Specification]
1	W	-
2	Y	-
3	R	-

Connector No.	M152
Connector Name	WIRE TO WIRE
Connector Type	M03MW-LC



Terminal Color Of No.	Wire	Signal Name [Specification]
1	W	-
2	Y	-
3	R	-

Connector No.	R1
Connector Name	WIRE TO WIRE
Connector Type	NH10FW-CS10



6	5	4	3	2	1
20	19	18	17	16	15
14	13	12	11	10	9
8	7	6	5	4	3

Terminal Color Of No.	Wire	Signal Name [Specification]
1	V	-
2	BR	-
3	GR	-
4	SHIELD	-
5	G	-
6	BR	-
9	P	-
10	G	-
11	Y	-
12	BR	-
13	L	-
14	L	-
15	R	-
16	R	-
17	B	-
20	Y	-

Connector No.	R2
Connector Name	WIRE TO WIRE
Connector Type	TH24FW-AH



Terminal Color Of No.	Wire	Signal Name [Specification]
1	P	-
2	GR	-
8	SHIELD	-
9	R	-
10	G	-
11	B	-
12	V	-
17	Y	-
18	G	-
19	R	-
20	L	-
21	P	-
22	R	-
23	BR	-
24	B	-

Connector No.	R11
Connector Name	WIRE TO WIRE
Connector Type	TH24MW-AH



Terminal Color Of No.	Wire	Signal Name [Specification]
1	LG	-
2	GR	-
8	SHIELD	-
9	L	-
10	R	-

11	B
12	V
17	Y
18	G
19	SB
20	P
21	L
22	R
23	BR
24	O

Connector No.	R12
Connector Name	VANITY MIRROR LAMP LH
Connector Type	MCA02FW



Terminal Color Of No.	Wire	Signal Name [Specification]
1	B	-
2	V	-

Connector No.	R13
Connector Name	VANITY MIRROR LAMP RH
Connector Type	MCA02FW



Terminal Color Of No.	Wire	Signal Name [Specification]
1	B	-
2	V	-

INTERIOR ROOM LAMP CONTROL SYSTEM

< DTC/CIRCUIT DIAGNOSIS >


INTERIOR ROOM LAMP CONTROL SYSTEM

Connector No.	R14
Connector Name	PERSONAL LAMP
Connector Type	TH34FW-NH



Terminal No.	Color Of Wire	Signal Name [Specification]
1	G	-
2	B	-
3	SB	-
4	V	-

Connector No.	R15
Connector Name	MAP LAMP
Connector Type	TK10FW



Terminal No.	Color Of Wire	Signal Name [Specification]
1	BR	DOOR ON SIG
2	R	ALL ON SIG
3	B	GROUND
5	V	LED+
6	Y	LED-
7	P	DOOR SIG L
8	B	GROUND
9	L	DOOR SIG R
10	V	BAT

JRLW06066GB

A
B
C
D
E
F
G
H
I
J
K
M
N
O
P

INL


ILLUMINATION

< DTC/CIRCUIT DIAGNOSIS >

ILLUMINATION

Wiring Diagram - ILLUMINATION -



INFOID:000000010584969



ILLUMINATION

< DTC/CIRCUIT DIAGNOSIS >

(IC) : With ICC
 (WS) : With climate controlled seat




A
B
C
D
E
F
G
H
I
J
K
INL
M
N
O
P

ILLUMINATION

< DTC/CIRCUIT DIAGNOSIS >

◊HS◊ : With heated seat
 ◊PM◊ : With automatic drive positioner
 ◊OP◊ : Without automatic drive positioner




JRLWD6069GB

ILLUMINATION

< DTC/CIRCUIT DIAGNOSIS >

IC : With ICC

★ : This connector is not shown in "Harness Layout".




JRLWD6070GB

A
B
C
D
E
F
G
H
I
J
K
INL
M
N
O
P

ILLUMINATION

< DTC/CIRCUIT DIAGNOSIS >




ILLUMINATION

< DTC/CIRCUIT DIAGNOSIS >


ILLUMINATION

Connector No.	B1
Connector Name	WIRE TO WIRE
Connector Type	TH08FW-CS16-TM4



Terminal No.	Color	Wire	Signal Name [Specification]
1	G	-	-
2	L	-	-
3	W	-	-
4	G	-	-
5	P	-	-
6	BG	-	-
7	SB	-	-
8	GR	-	-
9	B	-	-
10	G	-	-
11	R	-	-
12	W	-	-
13	LG	-	-
14	Y	-	-
15	SHIELD	-	-
16	L	-	-
17	P	-	-
18	G	-	-
19	Y	-	-
20	W	-	-
21	V	-	-
22	P	-	-
23	BR	-	-
24	GR	-	-
25	B	-	-
26	W	-	-
27	BG	-	-
28	Y	-	-
29	B	-	-
30	SB	-	-
31	V	-	-
32	GR	-	-
33	W	-	-
34	LG	-	-
35	Y	-	-
36	SHIELD	-	-

Connector No.	B16
Connector Name	FRONT DOOR SWITCH (DRIVER SIDE)
Connector Type	A03FW



Terminal No.	Color	Wire	Signal Name [Specification]
2	GR	-	-

Connector No.	E5
Connector Name	ENGINE INTELLIGENT POWER DISTRIBUTION MODULE (ENGINE ROOM)
Connector Type	TH08FW-CS12-M4-TV



Terminal No.	Color	Wire	Signal Name [Specification]
4	V	-	-
5	L	-	-
7	R	-	-
10	SB	-	-
12	B	-	-
13	Y	-	-
16	LG	-	-
19	W	-	-
25	G	-	-
26	R	-	-
27	Y	-	-
28	BG	-	-
30	GR	-	-
36	G	-	-

Connector No.	E6
Connector Name	ENGINE INTELLIGENT POWER DISTRIBUTION MODULE (ENGINE ROOM)
Connector Type	TH08FW-AH



Terminal No.	Color	Wire	Signal Name [Specification]
39	P	-	-
40	L	-	-
41	B	-	-
42	Y	-	-
43	SB	-	-
44	W	-	-
45	G	-	-
46	BR	-	-


Connector No.	E103
Connector Name	FUSE BLOCK (J/B)
Connector Type	NS16FW-CS



Terminal No.	Color	Wire	Signal Name [Specification]
10F	L	-	-
1F	SB	-	-
2F	W	-	-
3F	Y	-	-
4F	G	-	-
6F	BG	-	-
8F	L	-	-
9F	R	-	-

ILLUMINATION


< DTC/CIRCUIT DIAGNOSIS >

ILLUMINATION		IE106	
Connector No.	WIRE TO WIRE		
Connector Name	TH80FW-CS16-TM4		
Connector Type	TH80FW-CS16-TM4		
			
Terminal No.	Wire	Signal Name [Specification]	
1	G	-	
2	BG	-	
3	SB	-	
4	LG	-	
5	Y	-	
6	W	-	
7	G	-	
8	V	-	
9	R	-	
10	BR	-	
11	B	-	
12	G	-	
13	R	-	
14	W	-	
15	SHIELD	-	
16	SB	-	
17	L	-	
18	P	-	
19	G	-	
20	W	- [With ICC]	
21	BR	- [Without ICC]	
22	R	- [With ICC]	
23	V	- [Without ICC]	
24	L	- [With ICC]	
25	P	- [Without ICC]	
26	SHIELD	- [With ICC]	
27	G	-	
28	LG	-	
29	BG	-	
30	W	-	
31	Y	-	
32	B	-	
33	R	-	
34	BG	-	

Terminal No.	Wire	Signal Name [Specification]	
37	Y	-	
38	GR	-	
39	LG	-	
41	LG	-	
42	V	-	
43	R	-	
44	G	-	
45	GR	-	
46	W	-	
47	L	-	
48	P	-	
49	SB	-	
50	BR	-	
51	B	-	
52	Y	-	
53	BG	-	
54	R	-	
55	SB	-	
56	P	-	
60	SB	-	
61	V	-	
62	P	-	
63	LG	-	
64	L	-	
65	BG	-	
69	L	-	
70	SHIELD	-	
71	G	-	
72	G	-	
73	R	-	
74	BR	-	
76	L	-	
77	W	-	
78	Y	-	
80	SB	-	
81	L	-	
82	W	-	
83	LG	-	
84	GR	-	
85	G	-	
86	P	-	
87	W	-	
88	BG	-	
89	LG	-	
90	BR	-	
91	GR	-	
92	BR	-	
93	SB	-	
95	Y	-	
96	W	-	


Terminal No.	Wire	Signal Name [Specification]	
97	W	-	
98	SHIELD	-	
100	Y	-	

Connector No.	M1
Connector Name	FUSE BLOCK (J/B)
Connector Type	NS06FM-A2

			
---	--	---	--

Terminal No.	Wire	Signal Name [Specification]	
1A	BG	-	
2A	G	-	
3A	L	-	
4A	R	-	
5A	V	-	
6A	Y	-	
7A	R	-	
8A	L	-	


Connector No.	M2
Connector Name	FUSE BLOCK (J/B)
Connector Type	NS10FM-CS

			
---	--	---	--

Terminal No.	Wire	Signal Name [Specification]	
1B	LG	-	
3B	P	-	
4B	G	-	
5B	BG	-	
6B	Y	-	
7B	L	-	
8B	R	-	

Terminal No.	Wire	Signal Name [Specification]	
1	G	-	
2	BG	-	
3	LG	- [Without Auto aircon seat] - [With Auto aircon seat]	
4	LG	-	
5	GR	-	
6	W	-	
7	G	-	
8	W	-	
9	P	-	
10	BR	-	

Connector No.	M6
Connector Name	WIRE TO WIRE
Connector Type	TH80MW-CS16-TM4

			
---	--	---	--

JRLWD6073GB

ILLUMINATION

< DTC/CIRCUIT DIAGNOSIS >

ILLUMINATION

11	B	-
12	G	-
13	R	-
14	W	-
15	SHIELD	-
16	BR	-
17	L	-
18	P	-
19	G	-
20	GR	- [Without ICC] - [With ICC]
21	W	- [Without ICC] - [With ICC]
22	R	- [Without ICC] - [With ICC]
23	G	- [Without ICC] - [With ICC]
24	L	- [Without ICC] - [With ICC]
25	W	- [Without ICC] - [With ICC]
26	SHIELD	-
28	GR	-
29	V	-
30	BG	-
32	W	-
33	Y	-
34	L	-
37	G	-
38	R	-
39	G	-
41	L	-
42	W	-
43	R	-
44	LG	-
45	GR	-
46	W	-
47	L	-
48	P	-
49	BG	-
50	LG	-
51	SB	-
52	Y	-
53	BG	-
54	BR	-
55	SB	-
59	SB	-
60	SB	-
61	V	-
62	P	-
63	R	-

64	L	-
65	BG	-
69	V	-
70	SHIELD	-
71	BG	-
72	GR	-
73	W	-
74	SB	-
76	V	-
77	V	-
78	Y	-
80	BG	-
81	L	-
82	W	-
83	Y	-
84	L	-
85	P	-
86	BR	-
87	P	-
88	V	-
89	G	-
90	P	-
91	R	-
92	R	-
93	GR	-
95	G	-
96	W	-
97	W	-
98	SHIELD	-
100	Y	-

Connector No.	M7
Connector Name	WIRE TO WIRE
Connector Type	TH80MW-CS16-TM4



Terminal No.	Color Of Wire	Signal Name [Specification]
1	G	- [With Auto aircon seat]
2	B	- [Without Auto aircon seat]
3	W	-

6	P	-
7	V	-
8	BG	-
10	W	-
11	BG	-
12	B	-
13	G	-
14	R	-
15	W	-
16	SHIELD	-
17	L	-
18	P	-
19	G	-
20	R	-
21	LG	-
23	V	-
24	P	-
25	BR	-
26	GR	-
27	BG	-
28	W	-
38	B	-
39	B	-
43	SB	-
44	W	-
45	B	-
51	V	-
52	LG	-
53	SHIELD	-
54	BR	-
55	Y	-
56	SHIELD	-
57	P	-
58	L	-
59	SHIELD	-
60	L	-
61	BR	-
62	R	-
63	Y	-
64	L	-
65	W	-
66	V	-
67	LG	-
68	Y	-
69	G	-
70	V	-
71	W	-
72	B	-
73	W	-
74	LG	-

Connector No.	M15
Connector Name	HEADLAMP AIMING SWITCH
Connector Type	A04FW



Terminal No.	Color Of Wire	Signal Name [Specification]
1	SB	-
2	B	-
3	R	-
4	R	-


A
B
C
D
E
F
G
H
I
J
K
INL
M
N
O
P

ILLUMINATION

< DTC/CIRCUIT DIAGNOSIS >


ILLUMINATION

Connector No.	M19
Connector Name	VDC OFF SWITCH
Connector Type	TK08FGY




Terminal No.	Color Of Wire	Signal Name [Specification]
1	BR	-
2	B	-
3	W	-
4	LG	-

Connector No.	M20
Connector Name	DOOR MIRROR REMOTE CONTROL SWITCH
Connector Type	TK16FW



Terminal No.	Color Of Wire	Signal Name [Specification]
2	LG	-
3	BG	-
4	GR	-
5	L	-
6	Y	-
7	G	-
8	R	-
9	P	-
10	SB	-
11	LG	-
12	B	-
13	G	-
14	BG	-
15	W	-

Connector No.	M26
Connector Name	DOOR MIRROR REMOTE CONTROL SWITCH
Connector Type	TK16FBR




Terminal No.	Color Of Wire	Signal Name [Specification]
2	P	-
3	LG	-
4	BR	-
5	V	-
6	G	-
8	SB	-
9	LG	-
10	R	-
11	P	-
12	G	-
13	B	-
14	SB	-
15	BG	-
16	W	-

Connector No.	M29
Connector Name	WARNING SYSTEMS SWITCH
Connector Type	TK08FGY



Terminal No.	Color Of Wire	Signal Name [Specification]
2	SB	-
3	Y	-
4	R	-
5	B	-
6	R	-
7	V	-

Connector No.	M32
Connector Name	AUTOMATIC BACK DOOR MAIN SWITCH
Connector Type	TK08FW




Terminal No.	Color Of Wire	Signal Name [Specification]
1	BG	-
2	LG	-
3	B	-
4	W	-

Connector No.	M33
Connector Name	COMBINATION SWITCH
Connector Type	TH16FW-HH



Terminal No.	Color Of Wire	Signal Name [Specification]
1	P	FR WASHER (-)
2	SB	OUTPUT 4
3	BG	FR WASHER (+)
4	G	IGN
5	L	OUTPUT 3
6	B	GROUND
7	V	INPUT 3
8	BG	OUTPUT 5
9	Y	INPUT 2
10	R	INPUT 4
11	LG	INPUT 1
12	P	OUTPUT 1
13	BR	INPUT 5
14	G	OUTPUT 2

Connector No.	M34
Connector Name	AUTOMATIC BACK DOOR SWITCH
Connector Type	TK08FGY



Terminal No.	Color Of Wire	Signal Name [Specification]
1	Y	-
2	B	-
3	W	-
4	LG	-

Connector No.	M35
Connector Name	COMBINATION SWITCH (SPIRAL CABLE)
Connector Type	TK08FY-EX-TV



Terminal No.	Color Of Wire	Signal Name [Specification]
23	R	-
28	Y	-
29	Y	-
30	Y	-

ILLUMINATION

< DTC/CIRCUIT DIAGNOSIS >


ILLUMINATION

Connector No.	M36
Connector Name	COMBINATION SWITCH (SPRAL CABLE)
Connector Type	TK08FGY-1V




Terminal No.	Color Of Wire	Signal Name [Specification]
24	P	-
25	SB	-
26	B	-
31	L	-
32	V	-
33	B	-
34	G	-

Connector No.	M50
Connector Name	PUSH-BUTTON IGNITION SWITCH
Connector Type	TK08FBR



Terminal No.	Color Of Wire	Signal Name [Specification]
1	B	-
2	R	-
3	BG	-
4	SB	-
5	GR	-
6	Y	-
7	V	-
8	P	-

Connector No.	M53
Connector Name	COMBINATION METER
Connector Type	TH40FW-NH




Terminal No.	Color Of Wire	Signal Name [Specification]
1	BG	BATTERY POWER SUPPLY
2	LG	COMMUNICATION SIGNAL (METER->AMP)
3	GR	COMMUNICATION SIGNAL (AMP->METER)
5	B	GROUND
6	W	ALTERNATOR SIGNAL
7	P	AIR BAG SIGNAL
10	G	SECURITY INDICATOR SIGNAL
15	B	GROUND
16	B	METER CONTROL SWITCH GROUND
21	R	IGNITION SIGNAL
24	BR	COMMUNICATION SIGNAL (LCD->AMP)
25	Y	COMMUNICATION SIGNAL (AMP->LCD)
26	R	VEHICLE SPEED SIGNAL (8-PULSE)
27	V	PARKING BRAKE SWITCH SIGNAL
28	W	BRAKE FLUID LEVEL SWITCH SIGNAL
29	SB	SEAT BELT BUCKLE SWITCH SIGNAL (DRIVER SEEL)
30	G	PASSENGER SEAT BELT WARNING SIGNAL
31	L	WASHER LEVEL SWITCH SIGNAL
34	B	ILLUMINATION CONTROL SIGNAL
36	LG	SELECT SWITCH SIGNAL
37	SB	ENTER SWITCH SIGNAL
38	L	TRIP AIR RESET SWITCH SIGNAL
39	P	ILLUMINATION CONTROL SWITCH SIGNAL (-)
40	BG	ILLUMINATION CONTROL SWITCH SIGNAL (+)

Connector No.	M54
Connector Name	METER CONTROL SWITCH
Connector Type	TH12MW-NH



Terminal No.	Color Of Wire	Signal Name [Specification]
1	BG	-
2	B	-
3	P	-
4	R	-
5	B	-
6	LG	-
7	SB	-


Connector No.	M66
Connector Name	UNIFIED METER AND A/C AMP.
Connector Type	TH40FW-NH



Terminal No.	Color Of Wire	Signal Name [Specification]
5	L	MANUAL MODE SHIFT UP SIGNAL
6	BG	PADDLE SHIFTER UP SIGNAL
7	GR	COMMUNICATION SIGNAL (AMP->METER)
8	L	VEHICLE SPEED SIGNAL (2-PULSE)
9	SB	SEAT BELT BUCKLE SWITCH SIGNAL (DRIVER SEEL)
10	W	MANUAL MODE SIGNAL
11	G	NON-MANUAL MODE SIGNAL
14	BR	COMMUNICATION SIGNAL (LCD->AMP)
20	L	IGN SENSOR SIGNAL
23	Y	AT SNOW SWITCH SIGNAL
25	V	MANUAL MODE SHIFT DOWN SIGNAL
26	G	PADDLE SHIFTER DOWN SIGNAL
27	LG	COMMUNICATION SIGNAL (METER->AMP)

28	R	VEHICLE SPEED SIGNAL (8-PULSE)
30	V	PARKING BRAKE SWITCH SIGNAL
34	Y	COMMUNICATION SIGNAL (AMP->LCD)
38	L	BLOWER MOTOR CONTROL SIGNAL

Connector No.	M67
Connector Name	UNIFIED METER AND A/C AMP.
Connector Type	TH32FW-NH



Terminal No.	Color Of Wire	Signal Name [Specification]
41	V	ACC POWER SUPPLY
42	Y	FUEL LEVEL SENSOR SIGNAL
43	R	INTAKE SENSOR SIGNAL
44	LG	IN-VEHICLE SENSOR SIGNAL
45	P	AMBIENT SENSOR SIGNAL
46	BG	SUNLOAD SENSOR SIGNAL
47	V	GAS SENSOR SIGNAL
53	G	IGNITION POWER SUPPLY
54	BG	BATTERY POWER SUPPLY
55	B	GROUND
56	L	CAN-H
57	W	BRAKE FLUID LEVEL SWITCH SIGNAL
58	B	FUEL LEVEL SENSOR GROUND
59	GR	INTAKE SENSOR GROUND
60	L	IN-VEHICLE SENSOR GROUND
61	BR	AMBIENT SENSOR GROUND
62	SB	SUNLOAD SENSOR GROUND
63	R	ION MODE SIGNAL
65	BG	ECV SIGNAL
69	L	AC/LAN SIGNAL
70	R	EACH DOOR MOTOR POWER SUPPLY
71	B	GROUND
72	P	CAN-L

JRLWLD6076GB


A
B
C
D
E
F
G
H
I
J
K
INL
M
N
O
P

ILLUMINATION

< DTC/CIRCUIT DIAGNOSIS >

ILLUMINATION

Connector No.	M72
Connector Name	MULTIFUNCTION SWITCH
Connector Type	TH16FW-LNH



Terminal No.	Color Of Wire	Signal Name [Specification]
1	B	GROUND
3	V	ACC
4	R	ILL
5	R	ILL CONT
6	SB	AV COM1 (H)
8	LG	AV COM1 (L)
9	BR	SW GND
14	SB	DISK EJECT SIGNAL
16	G	HAZARD ON

Connector No.	M74
Connector Name	CLOCK
Connector Type	TH16FW-LNH




Terminal No.	Color Of Wire	Signal Name [Specification]
1	B	ILLUMINATION (-)
2	R	ILLUMINATION (+)
3	B	GROUND
4	Y	BATTERY POWER SUPPLY

Connector No.	M102
Connector Name	GLOVE BOX LAMP
Connector Type	A02FW



Terminal No.	Color Of Wire	Signal Name [Specification]
1	R	-
2	B	-

Connector No.	M106
Connector Name	WIRE TO WIRE
Connector Type	NH10MW-CS10




Terminal No.	Color Of Wire	Signal Name [Specification]
1	V	-
2	BR	-
3	GR	-
4	SHIELD	-
5	G	-
6	BR	-
9	P	-
10	G	-
11	Y	-
12	BR	-
13	L	-
14	L	-
15	R	-
16	R	-
17	B	-
20	BG	-

Connector No.	M118
Connector Name	BCM (BODY CONTROL MODULE)
Connector Type	M03FB-LC




Terminal No.	Color Of Wire	Signal Name [Specification]
1	W	BAT (E/L)
2	Y	POWER WINDOW POWER SUPPLY (BAT)
3	BG	POWER WINDOW POWER SUPPLY (BAP)

Connector No.	M119
Connector Name	BCM (BODY CONTROL MODULE)
Connector Type	NS16FW-CS




Terminal No.	Color Of Wire	Signal Name [Specification]
4	P	INT ROOM LAMP PWR SUPPLY (BAT SAVE)
5	V	PASSENGER DOOR UNLOCK OUTPUT
7	Y	STEP LAMP OUTPUT
8	V	ALL DOOR FUEL LID LOCK OUTPUT
9	G	DRIVER DOOR FUEL LID UNLOCK OUTPUT
10	BR	REAR DOOR UNLOCK OUTPUT
11	R	BAT (FUSE)
13	B	GROUND
15	Y	ACC IND
17	W	TURN SIGNAL RH (FRONT)
18	BG	TURN SIGNAL LH (FRONT)
19	SB	ROOM LAMP TIMER

Connector No.	M122
Connector Name	BCM (BODY CONTROL MODULE)
Connector Type	TH16FB-LNH




ILLUMINATION

Connector No.	M123
Connector Name	BCM (BODY CONTROL MODULE)
Connector Type	TH40FG-NH




Connector No.	M129
Connector Name	TOTAL ILLUMINATION CONTROL UNIT
Connector Type	TH40FM-NH



Connector No.	M132
Connector Name	FRONT POWER SOCKET
Connector Type	NS03FM-CS



Connector No.	M151
Connector Name	WIRE TO WIRE
Connector Type	M03FW-LC




Terminal No.	Color Of Wire	Signal Name [Specification]
112	GR	RAIN SENSOR SERIAL LINK
113	P	OPTICAL SENSOR
116	BR	STOP LAMP SW 1
118	P	STOP LAMP SW 2
119	SB	DR DOOR UNLOCK SENSOR
121	BR	KEY SLOT SW
123	W	IGN F/B
124	LG	PASSENGER DOOR SW
132	BG	POWER WINDOW SW COMM
134	GR	LOCK IND
137	B	RECEIVER/SENSOR GND
138	Y	SENSOR POWER SUPPLY
140	R	SHIFT NP
141	G	SECURITY INDICATOR OUTPUT
142	BG	COMBI SW OUTPUT 5
143	P	COMBI SW OUTPUT 1
144	G	COMBI SW OUTPUT 2
145	L	COMBI SW OUTPUT 3
146	SB	COMBI SW OUTPUT 4
150	GR	DRIVER DOOR SW
151	G	REAR WINDOW DEFOGGER RELAY CONT

Terminal No.	Color Of Wire	Signal Name [Specification]
3	V	DDL2
4	L	TAIL LAMP SIGNAL
5	V	ACC SIGNAL
6	P	BAT SAVER SIGNAL
7	W	IGN SIGNAL
8	G	DOOR SW (AS)
9	BG	DOOR SW (RL)
10	SB	MOOD LAMP (FR ARMREST RH)
11	Y	MOOD LAMP (RR ARMREST RH)
12	P	MAP LAMP (AS)
13	G	PERSONAL LAMP (LH)
14	R	PERSONAL LAMP (RH)
16	GR	FOOT LAMP (RH)
17	LG	HSPL ILLUMINATIONS
18	L	MAP LAMP (DR)
19	R	PUSH ENG START SW LED
20	Y	AMBIENCE LAMP
21	R	BAT POWER SUPPLY
23	B	GROUND
24	B	ILL CONT INPUT
25	BR	DOOR SW (RR)
26	BR	MAP LAMP SW (DOOR)
27	R	MAP LAMP SW (ALL ON)
28	SB	ROOM LAMP TIMER
29	GR	DOOR SW (DR)
30	LG	MOOD LAMP (FR ARMREST LH)
31	BG	MOOD LAMP (RR ARMREST LH)
33	W	HSPL POWER SUPPLY 3
34	R	HSPL POWER SUPPLY 2
35	V	HSPL POWER SUPPLY 1
36	L	FOOT LAMP (LH)
39	B	PUDDLE LAMP (RH)
40	BG	PUDDLE LAMP (LH)

Terminal No.	Color Of Wire	Signal Name [Specification]
1	W	
2	Y	
3	R	

Terminal No.	Color Of Wire	Signal Name [Specification]
1	B	
2	R	
3	L	

Connector No.	M137
Connector Name	AT SHIFT SELECTOR
Connector Type	TH12FM-NH



Connector No.	M152
Connector Name	WIRE TO WIRE
Connector Type	M03MW-LC



Terminal No.	Color Of Wire	Signal Name [Specification]
1	W	
2	V	
3	L	
4	B	
5	G	
7	BG	
8	SB	
9	B	
10	GR	
11	R	

Terminal No.	Color Of Wire	Signal Name [Specification]
1	W	
2	Y	
3	R	


JRLW06078GB

ILLUMINATION

< DTC/CIRCUIT DIAGNOSIS >


ILLUMINATION

Connector No.	M172
Connector Name	HEATED SEAT SWITCH (DRIVER SIDE)
Connector Type	TK10FW




Terminal No.	Color Of Wire	Signal Name [Specification]
1	GR	-
2	BR	-
3	R	-
4	R	-
5	Y	-
6	B	-

Connector No.	M173
Connector Name	HEATED SEAT SWITCH (PASSENGER SIDE)
Connector Type	TK08FBR




Terminal No.	Color Of Wire	Signal Name [Specification]
1	GR	-
2	BG	-
3	R	-
4	R	-
5	Y	-
6	B	-

Connector No.	M176
Connector Name	SNOW MODE SWITCH
Connector Type	TK08FW-L




Terminal No.	Color Of Wire	Signal Name [Specification]
1	BR	-
2	B	-
4	Y	-
5	R	-
6	GR	-

Connector No.	M177
Connector Name	CLIMATE CONTROLLED SEAT SWITCH (DRIVER SIDE)
Connector Type	TK10FW



Terminal No.	Color Of Wire	Signal Name [Specification]
1	BG	-
2	V	-
3	P	-
4	BR	-
5	GR	-
6	B	-
7	R	-
8	R	-

Connector No.	M178
Connector Name	CLIMATE CONTROLLED SEAT SWITCH (PASSENGER SIDE)
Connector Type	TK08FBR




Terminal No.	Color Of Wire	Signal Name [Specification]
1	P	-
2	G	-
3	I	-
4	BG	-
5	GR	-
6	B	-
7	R	-
8	R	-

Connector No.	M184
Connector Name	IBA OFF SWITCH
Connector Type	TK08FGY




Terminal No.	Color Of Wire	Signal Name [Specification]
4	Y	-
5	BG	-
6	B	-
7	SB	-

Connector No.	M201
Connector Name	AV CONTROL UNIT
Connector Type	TH18FW-CS2



Terminal No.	Color Of Wire	Signal Name [Specification]
6	P	STRG SW A
7	V	ACC
9	R	ILLUMINATION SIGNAL
15	B	STRG SW GND
16	L	STRG SW B
19	Y	BATTERY
20	B	GROUND

Connector No.	M202
Connector Name	AV CONTROL UNIT
Connector Type	TH24FW-NH



Terminal No.	Color Of Wire	Signal Name [Specification]
36	BG	SIGNAL VCC
37	LG	SIGNAL GND
38	R	HP
39	BR	COMM (DSP->CONT)
40	B	RGB AREA (YS) SIGNAL
41	SHIELD	SHIELD
42	G	RGB SYNC
43	B	RGB (R-RED) SIGNAL
44	W	RGB (G-GREEN) SIGNAL
45	R	RGB (B-BLUE) SIGNAL
46	BG	COMPOSITE IMAGE SIGNAL GND
47	SB	COMPOSITE IMAGE SIGNAL
48	Y	INVERTER VCC

ILLUMINATION

49	BR	INVERTER GND
50	W	VP
51	Y	COMM (CONT->DISP)
52	SB	SHIELD
57	SHIELD	SHIELD

Connector No.	M210
Connector Name	AV CONTROL UNIT
Connector Type	TH32FW-NH



																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																		</
--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	----

Terminal No.	Color Of Wire	Signal Name [Specification]
65	V	PARKING BRAKE SIGNAL
67	B	COMPOSITE IMAGE SIGNAL GND
68	R	COMPOSITE IMAGE SIGNAL
71	SHIELD	MICROPHONE SHIELD
72	G	MICROPHONE VCC
73	R	COMM (CONT->DISP)
74	P	CAN-L
75	LG	AV COMM (L)
76	LG	AV COMM (L)
79	R	ILLUMINATION
80	G	IGNITION SIGNAL
81	BG	REVERSE SIGNAL
82	R	VEHICLE SPEED SIGNAL (6-PULSE)
87	R	MICROPHONE SIGNAL
88	B	SHIELD
89	G	COMM (DISP->CONT)
90	L	CAN-H
91	SB	AV COMM (H)
92	SB	AV COMM (H)

Connector No.	M221
Connector Name	SHIFT POSITION SWITCH
Connector Type	TH12FW



6	5	4	3	2
11	10	9	7	

Terminal No.	Color Of Wire	Signal Name [Specification]
2	L	N
3	BR	D
4	G	R
5	P	P
6	V	M
7	O	AT
9	Y	MT
10	R	ILL
11	B	GROUND

Connector No.	M223
Connector Name	SELECTOR LEVER POSITION INDICATOR
Connector Type	XARP-09V



9	8	7	6	5	4	3	2	1
---	---	---	---	---	---	---	---	---

Terminal No.	Color Of Wire	Signal Name [Specification]
1	R	ILL
2	Y	MT
3	L	N
4	BR	D
5	G	R
6	V	M
7	P	P
8	O	AT
9	B	GROUND

Connector No.	M303
Connector Name	COMBINATION SWITCH (SPRNL CABLE)
Connector Type	TK08FGY



20	19	18	17	16	15	14	13
----	----	----	----	----	----	----	----

Terminal No.	Color Of Wire	Signal Name [Specification]
13	R	-
14	W	-
15	L	-
16	B	-
17	BR	-
18	G	-
19	P	-
20	Y	-

Connector No.	R1
Connector Name	WIRE TO WIRE
Connector Type	NH10FW-CST0



6	5	4		3	2	1
20	19	18	17	16	8	7
		13	12	11	10	9

Terminal No.	Color Of Wire	Signal Name [Specification]
1	V	-
2	BR	-
3	GR	-
4	SHIELD	-
5	G	-
6	BR	-
8	P	-
10	G	-
11	Y	-
12	BR	-
13	L	-
14	L	-

15	R	-
16	R	-
17	B	-
20	Y	-

Connector No.	R2
Connector Name	WIRE TO WIRE
Connector Type	TH24FW-NH



12	11	10	9	8	7	6	5	4	3	2	1
24	23	22	21	20	19	18	17	16	15	14	13

Terminal No.	Color Of Wire	Signal Name [Specification]
1	P	-
2	GR	-
8	SHIELD	-
9	R	-
10	G	-
11	B	-
12	V	-
17	Y	-
18	G	-
19	R	-
20	L	-
21	P	-
22	R	-
23	BR	-
24	B	-

ILLUMINATION

< DTC/CIRCUIT DIAGNOSIS >

ILLUMINATION

Connector No.	R11
Connector Name	WIPE TO WIRE
Connector Type	TH24MV-NH



1	2	3	4	5	6	7	8	9	10	11	12
13	14	15	16	17	18	19	20	21	22	23	24

Terminal No.	Color Of Wire	Signal Name [Specification]
1	LG	-
2	GR	-
8	SHIELD	-
9	-	-
10	R	-
11	B	-
12	Y	-
17	G	-
18	SB	-
19	P	-
20	L	-
21	R	-
22	BR	-
23	O	-
24	-	-

Connector No.	R15
Connector Name	MAP LAMP
Connector Type	TK10FW



1	2	3
5	6	7
8	9	10

Terminal No.	Color Of Wire	Signal Name [Specification]
1	BR	DOOR ON SIG
2	R	ALL ON SIG
3	B	GROUND
5	Y	LED+
6	Y	LED-

7	P	DOOR SIG L
8	B	GROUND
9	L	DOOR SIG R
10	V	BAT

JRLWD6081GB

TOTAL ILLUMINATION CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >

ECU DIAGNOSIS INFORMATION

TOTAL ILLUMINATION CONTROL UNIT

Reference Value

INFOID:0000000010584970

VALUES ON THE DIAGNOSIS TOOL

CONSULT MONITOR ITEM


Monitor Item	Condition	Value/Status
BAT SAVER SIGNAL	Interior room lamp battery saver is activated. (BCM cuts the interior room lamp power supply.)	Off
	Interior room lamp battery saver is not activated. (BCM outputs the interior room lamp power supply.)	On
IGN SIGNAL	Ignition switch OFF or ACC	Off
	Ignition switch ON	On
ACC SIGNAL	Ignition switch OFF	Off
	Ignition switch ACC or ON	On
ROOM LAMP REQ	Other than the conditions as per the following	Off
	Hospitality lighting function table "Scene 1" • Interior room lamp timer is activated. (Door is unlocked. etc.) • Welcome light function is activated.	On
TAIL LAMP SIGNAL	Tail lamps are OFF.	Off
	Tail lamps are ON condition.	On
DOOR SW-DR	Driver door close	Off
	Driver door open	On
DOOR SW-AS	Passenger door close	Off
	Passenger door open	On
DOOR SW-RR	Rear RH door close	Off
	Rear RH door open	On
DOOR SW-RL	Rear LH door close	Off
	Rear LH door open	On
MAP LAMP SW	Map lamp main switch OFF	Off
	Map lamp main switch ALL ON	ALL ON
	Map lamp main switch DOOR	DOOR
ENGINE SW ILLUMI	Engine switch illumination OFF	Off
	While engine switch illumination heart beat function	PULSE
	Ignition switch ON or tail lamps ON	STEADY
FOOT LAMP	Foot lamp OFF	0%
	Any door open (Ignition switch OFF)	80%
	Engine running (Tail lamps OFF)	10%
MAP LAMP-DR	Map lamp main switch OFF	0%
	Any door open and driver door close (Map lamp main switch DOOR)	30%
	Driver door open (Map lamp main switch DOOR)	90%
	Map lamp main switch ALL ON	100%

TOTAL ILLUMINATION CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >

Monitor Item	Condition	Value/Status
MAP LAMP-AS	Map lamp main switch OFF	0%
	Any door open and passenger door close (Map lamp main switch DOOR)	30%
	Passenger door open (Map lamp main switch DOOR)	90%
	Map lamp main switch ALL ON	100%
PERSONAL LMP-RR	Map lamp main switch OFF	0%
	Any door open and rear RH door close (Map lamp main switch DOOR)	30%
	Rear RH door open (Map lamp main switch DOOR)	90%
	Map lamp main switch ALL ON	100%
PERSONAL LMP-RL	Map lamp main switch OFF	0%
	Any door open and rear LH door close (Map lamp main switch DOOR)	30%
	Rear LH door open (Map lamp main switch DOOR)	90%
	Map lamp main switch ALL ON	100%
PUDDLE LAMP	Puddle lamp OFF	0%
	Puddle lamp ON	100%
MOOD LAMP	Mood lamp OFF	0%
	Any door open	100%
AMBIENCE LAMP	Center console indirect illumination (ambience lamp) OFF	0%
	Ignition switch ON (Tail lamp OFF)	10%
	Map lamp main switch ALL ON	100%
HSPL ILLUMI	Each illumination (linked with hospitality lighting) OFF	0%
	Tail lamps ON	0 – 100% (Linked to illumination control switch)
ILLUM CONT SIGNAL	Tail lamps ON	0 – 100% (Linked to illumination control switch)

TERMINAL LAYOUT







PHYSICAL VALUES

Terminal No. (Wire color)		Description		Condition		Value (Approx.)
+	–	Signal name	Input/ Output			
3 (V)	Ground	DDL2 communica- tion line	—	—		—
4 (L)	Ground	Tail lamp signal	Input	Tail lamps	ON	Battery voltage
					OFF	0 V
5 (V)	Ground	Ignition switch ACC	Input	Ignition switch	ACC or ON	Battery voltage
					OFF	0 V




TOTAL ILLUMINATION CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)		Description		Condition		Value (Approx.)
+	-	Signal name	Input/ Output			
6 (P)	Ground	Battery saver	Input	Interior room lamp battery saver is activated. (Cuts the interior room lamp power supply)		0 V
				Interior room lamp battery saver is not activated. (Outputs the interior room lamp power supply)		12 V
7 (W)	Ground	Ignition switch ON	Input	Ignition switch	ON	Battery voltage
					OFF or ACC	0 V
8 (G)	Ground	Passenger door switch	Input	Passenger door switch	OFF (Door close)	 JPMIA0594GB 8.5 - 9.0 V
					ON (Door open)	0 V
9 (BG)	Ground	Rear LH door switch	Input	Rear LH door switch	OFF (Door close)	 JPMIA0594GB 8.5 - 9.0 V
					ON (Door open)	0 V
10 (SB)	Ground	Mood lamp (Front door armrest RH)	Output	Mood lamp OFF		12 V
				Any door open		0 V
11 (Y)	Ground	Mood lamp (Rear door armrest RH)	Output	Mood lamp OFF		12 V
				Any door open		0 V
12 (P)	Ground	Map lamp (Passenger side)	Output	Map lamp main switch OFF		12 V
				Any door open and passenger door close (Map lamp main switch DOOR)		 JPLIA1190ZZ 8.4 V
				Passenger door open (Map lamp main switch DOOR)		 JPLIA1191ZZ 1.2 V
				Map lamp main switch ALL ON		0 V






TOTAL ILLUMINATION CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)		Description		Condition	Value (Approx.)
+	-	Signal name	Input/ Output		
13 (G)	Ground	Personal lamp (LH)	Output	Map lamp main switch OFF	12 V
				Any door open and rear LH door close (Map lamp main switch DOOR)	 JPLIA1190ZZ 8.4 V
				Rear LH door open (Map lamp main switch DOOR)	 JPLIA1191ZZ 1.2 V
				Map lamp main switch ALL ON	0 V
14 (R)	Ground	Personal lamp (RH)	Output	Map lamp main switch OFF	12 V
				Any door open and rear RH door close (Map lamp main switch DOOR)	 JPLIA1190ZZ 8.4 V
				Rear RH door open (Map lamp main switch DOOR)	 JPLIA1191ZZ 1.2 V
				Map lamp main switch ALL ON	0 V




TOTAL ILLUMINATION CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)		Description		Condition	Value (Approx.)
+	-	Signal name	Input/ Output		
16 (GR)	Ground	Foot lamp (RH)	Output	Foot lamp OFF	12 V
				Any door open (Ignition switch OFF)	 2.4 V
				Ignition switch ON (Tail lamps OFF)	 10.8 V
17 (LG)	Ground	Each illumination (Linked with hospital- ity lighting)	Output	Ignition switch OFF	12 V
				Tail lamp ON	NOTE: Illumination control brightness level is midway 
18 (L)	Ground	Map lamp (Driver side)	Output	Map lamp main switch OFF	12 V
				Any door open and driver door close (Map lamp main switch DOOR)	 8.4 V
				Driver door open (Map lamp main switch DOOR)	 1.2 V
				Map lamp main switch ALL ON	0 V




TOTAL ILLUMINATION CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)		Description		Condition		Value (Approx.)
+	-	Signal name	Input/ Output			
19 (R)	Ground	Engine switch illumination	Output	Engine switch illumination OFF		12 V
				While engine switch illumination heart beat function		 JPLIA1195ZZ
				Engine switch illumination ON (Tail lamp OFF)		0 V
20 (Y)	Ground	Ambience lamp (Center console indirect illumination)	Output	Center console indirect illumination (ambience lamp) OFF		12 V
				Ignition switch ON (Tail lamp OFF)		 JPLIA1196ZZ 10.8 V
				Map lamp main switch ALL ON		0 V
21 (R)	Ground	Battery power supply	Input	Ignition switch OFF		Battery voltage
23 (B)	Ground	Ground	—	Ignition switch ON		0 V
24 (B)	Ground	Illumination control signal	Input	Tail lamp OFF		5 V
				Tail lamp ON	Illumination control brightness level is minimum	8 V
					Illumination control brightness level is midway	 JPLIA1199ZZ
					Illumination control brightness level is maximum	0 V
25 (BR)	Ground	Rear RH door switch	Input	Rear RH door switch	OFF (Door close)	 JPMIA0594GB 8.5 - 9.0 V
					ON (Door open)	0 V
26 (BR)	Ground	Map lamp switch (DOOR)	Input	Map lamp main switch	OFF or ALL ON	5 V
					DOOR	0 V


TOTAL ILLUMINATION CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)		Description		Condition		Value (Approx.)
+	-	Signal name	Input/ Output			
27 (R)	Ground	Map lamp switch (ALL ON)	Input	Map lamp main switch	OFF or DOOR ALL ON	5 V 0 V
28 (SB)	Ground	Room lamp timer	Input	Other than the conditions as per the following		5 V
				Hospitality lighting function table "scene 1"		0 V
				- Interior room lamp timer is activated. (Door is unlocked. etc.) - Welcome light function is activated.		
29 (GR)	Ground	Driver door switch	Input	Driver door switch	OFF (Door close)	 JPMIA0594GB 8.5 - 9.0 V
					ON (Door open)	0 V
30 (LG)	Ground	Mood lamp (Front door armrest LH)	Output	Mood lamp OFF		12 V
				Any door open		0 V
				Engine running (Tail lamps OFF)		 JPLIA1189ZZ 8.4 V
31 (BG)	Ground	Mood lamp (Rear door armrest LH)	Output	Mood lamp OFF		12 V
				Any door open		0 V
				Engine running (Tail lamps OFF)		 JPLIA1189ZZ 8.4 V
33 (W)	Ground	Hospitality lighting power supply 3	Output	Interior room lamp battery saver is activated.		0 V
				Interior room lamp battery saver is not activated.		12 V
34 (R)	Ground	Hospitality lighting power supply 2	Output	Interior room lamp battery saver is activated.		0 V
				Interior room lamp battery saver is not activated.		12 V
35 (V)	Ground	Hospitality lighting power supply 1	Output	Interior room lamp battery saver is activated.		0 V
				Interior room lamp battery saver is not activated.		12 V

TOTAL ILLUMINATION CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)		Description		Condition		Value (Approx.)
+	-	Signal name	Input/ Output			
36 (L)	Ground	Foot lamp (LH)	Output	Foot lamp OFF		12 V
				Any door open (ignition switch OFF)		 2.4 V
				Ignition switch ON (Tail lamps OFF)		 10.8 V
39 (B)	Ground	Puddle lamp (RH)	Output	Puddle lamp (RH)	OFF	12 V
					ON	0 V
40 (BG)	Ground	Puddle lamp (LH)	Output	Puddle lamp (LH)	OFF	12 V
					ON	0 V


TOTAL ILLUMINATION CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >

Wiring Diagram - INTERIOR ROOM LAMP -

INFOID:000000011016160

INTERIOR ROOM LAMP CONTROL SYSTEM




2014/03/18

JRLWD6050GB

TOTAL ILLUMINATION CONTROL UNIT


< ECU DIAGNOSIS INFORMATION >



JRLW6051GB

TOTAL ILLUMINATION CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >



TOTAL ILLUMINATION CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >

INTERIOR ROOM LAMP CONTROL SYSTEM

Connector No.	B1
Connector Name	WIRE TO WIRE
Connector Type	TH80FW-CS16-TM4




Terminal No.	Color Of Wire	Signal Name [Specification]
1	G	-
2	L	-
3	W	-
4	G	-
5	P	-
6	BG	-
7	SB	-
8	SB	-
9	SB	-
10	SB	-
11	SB	-
12	B	-
13	G	-
14	R	-
15	W	-
16	SHIELD	-
17	L	-
18	P	-
19	G	-
20	Y	-
21	W	-
23	V	-
24	P	-
25	BR	-
26	GR	-
27	BG	-
28	W	-
38	B	-
39	B	-
43	SB	-
44	V	-
45	GR	-
51	V	-
52	SB	-
53	SHIELD	-
54	BR	-
55	Y	-
56	SHIELD	-

Connector No.	B16
Connector Name	FRONT DOOR SWITCH (DRIVER SIDE)
Connector Type	IA03FW



Terminal No.	Color Of Wire	Signal Name [Specification]
2	GR	-

Connector No.	B18
Connector Name	WIRE TO WIRE
Connector Type	NH10FM-CS10



Terminal No.	Color Of Wire	Signal Name [Specification]
2	V	-
3	W	-
4	GR	-
5	Y	-
6	B	-
8	BR	-
12	LG	-
13	P	-
17	L	-
18	BG	-
19	G	-
20	W	-

Connector No.	B23
Connector Name	REAR DOOR SWITCH LH
Connector Type	IA03FW



Terminal No.	Color Of Wire	Signal Name [Specification]
2	W	-

Connector No.	B27
Connector Name	WIRE TO WIRE
Connector Type	NO8MM-GY-LC




Terminal No.	Color Of Wire	Signal Name [Specification]
1	G	-
2	B	-
3	W	-
4	B	-
6	BR	-
7	G	-
8	SHIELD	-

TOTAL ILLUMINATION CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >

INTERIOR ROOM LAMP CONTROL SYSTEM


Connector No.	B28
Connector Name	WIPE TO WIRE
Connector Type	TH32MW-AH



Connector No.	B47
Connector Name	DIODE
Connector Type	24335_C9900



Connector No.	B201
Connector Name	WIPE TO WIRE
Connector Type	TH80FM-CS16-TM4




46	SHIELD	- [Without ICC]
47	B	- [Without ICC]
48	L	- [With ICC]
49	R	- [Without ICC]
50	W	- [Without ICC]
51	W	-
52	R	-
53	G	-
54	L	-
55	SB	-
60	GR	-
61	LG	-
62	SB	-
63	P	-
64	BR	-
65	GR	-
66	Y	-
67	W	-
69	G	-
71	SB	-
72	V	-
73	LG	-
74	W	-
75	BR	-
76	V	-
77	LG	-
80	BG	-
82	P	-
83	Y	-
84	R	-
85	SB	-
86	GR	-
87	L	-
91	V	-
92	W	-
93	R	-
94	LG	-
95	GR	-
96	W	-
97	G	-
98	BG	-
99	L	-

Terminal No.	Wire	Signal Name [Specification]
1	R	-
2	B	-
3	W	-
4	SHIELD	-
5	G	-
6	L	-
7	R	-
8	SHIELD	-
9	W	-
10	B	-
11	G	-
12	L	-
13	W	-
14	LG	-
15	BG	-
16	G	-
17	BG	-
18	V	-
19	W	-
20	B	-
21	G	-
22	LG	-
23	R	-
24	BG	-
25	BR	-
26	GR	-
27	L	-
32	BG	-

Terminal No.	Wire	Signal Name [Specification]
1	GR	-
2	V	-

Connector No.	B87
Connector Name	WIPE TO WIRE
Connector Type	NS16MR-CS



Terminal No.	Wire	Signal Name [Specification]
1	BR	-
2	G	-
3	SHIELD	-
5	G	-
8	BR	-
9	G	-
10	SHIELD	-
11	L	-
12	GR	-
13	R	-
14	R	-


Terminal No.	Wire	Signal Name [Specification]
1	G	-
2	R	-
3	BR	-
4	SB	-
6	BG	-
7	GR	-
8	W	-
10	G	-
11	SHIELD	-
20	L	-
21	P	-
22	GR	-
23	LG	-
24	W	-
25	V	-
26	G	-
27	Y	-
28	SHIELD	-
31	W	-
32	GR	-
33	SB	-
36	L	-
37	P	-
38	L	-
39	P	-
40	LG	- [With ICC]
40	V	- [Without ICC]
41	SB	- [With ICC]
41	Y	- [Without ICC]
42	V	- [With ICC]
42	W	- [Without ICC]
43	B	- [Without ICC]
43	BR	- [With ICC]
44	R	-
45	G	-
46	BG	- [With ICC]

TOTAL ILLUMINATION CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >


INTERIOR ROOM LAMP CONTROL SYSTEM

Connector No.	Signal Name [Specification]
B216	FRONT DOOR SWITCH (PASSENGER SIDE)
A03FW	




Terminal No.	Color Of Wire	Signal Name [Specification]
2	GR	-

Connector No.	Signal Name [Specification]
B218	WIRE TO WIRE
NH10FW-CS10	



Terminal No.	Color Of Wire	Signal Name [Specification]
2	GR	-
3	W	-
4	R	-
5	SB	-
6	B	-
8	G	-
12	LG	-
13	P	-
17	SB	-
18	BR	-
19	BR	-
20	LG	-

Connector No.	Signal Name [Specification]
B223	REAR DOOR SWITCH RH
A03FW	




Terminal No.	Color Of Wire	Signal Name [Specification]
2	BG	-

Connector No.	Signal Name [Specification]
B229	LUGGAGE ROOM LAMP (LUGGAGE SIDE)
TK03FW	




Terminal No.	Color Of Wire	Signal Name [Specification]
1	W	-
2	L	-

Connector No.	Signal Name [Specification]
B241	WIRE TO WIRE
NS16FBR-CS	



Terminal No.	Color Of Wire	Signal Name [Specification]
1	BR	-
2	G	-
3	SHIELD	-
5	G	-
8	L/Y	-
9	L/B	-
10	SHIELD	-
11	L	-
12	W	-
13	P	-
14	R	-


Connector No.	Signal Name [Specification]
D1	WIRE TO WIRE
TH40FW-CS15	



Terminal No.	Color Of Wire	Signal Name [Specification]
1	B	-
3	G	-
6	GR	-
7	W	-
8	SB	-
9	BR	-
10	O	-
11	R	-
12	LG	-
13	Y	-
14	P	-
15	L	-
20	V	-
21	Y	-
22	GR	-
23	SB	-
24	LG	-
26	G	-
27	V	-
28	P	-
29	Y	-

Terminal No.	Color Of Wire	Signal Name [Specification]
30	LG	-
31	O	-
32	BR	-
33	L	-
34	GR	-
35	B	-
36	R	-
37	G	-
38	SHIELD	-
39	W	-
40	B	-
41	SHIELD	-
42	G	-
43	R	-
44	BR	-
45	V	-
46	P	-
47	W	-
48	GR	-
49	R	-
50	B	-
51	SB	-
52	L	-
53	G	-
54	O	-
55	GR	-

Connector No.	Signal Name [Specification]
D3	DOOR MIRROR (DRIVER SIDE)
TH24MW-NH	



Terminal No.	Color Of Wire	Signal Name [Specification]
2	R	-
3	W	-
5	G	-
6	R	-
7	GR	-
8	SB	-
9	L	-
10	G	-

TOTAL ILLUMINATION CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >

INTERIOR ROOM LAMP CONTROL SYSTEM


Connector No.	D9
11	GR
12	O
14	B
17	SHELD
18	B
19	B
21	P
22	BR
23	W
24	V




Connector No.	D13
Connector Name	FRONT OUTSIDE HANDLE LH (REQUEST SWITCH)
Connector Type	RK02FL-B



Connector No.	D15
Connector Name	FRONT DOOR LOCK ASSEMBLY (DRIVER SIDE)
Connector Type	ED0FGY-RS



Connector No.	D8
Connector Name	POWER WINDOW MAIN SWITCH
Connector Type	NS16FW-CS



Terminal No.	Color Of Wire	Signal Name [Specification]
17	B	-
19	Y	-

Terminal No.	Color Of Wire	Signal Name [Specification]
1	G	-
2	B	-

Terminal No.	Color Of Wire	Signal Name [Specification]
1	LG	-
2	R	-
3	G	-
4	B	-
5	Y	-
6	V	-

Connector No.	D12
Connector Name	STEP LAMP (DRIVER SIDE)
Connector Type	TB02FW



Connector No.	D14
Connector Name	FRONT OUTSIDE HANDLE LH (OUTSIDE KEY ANTENNA)
Connector Type	RK02MGY



Connector No.	D16
Connector Name	MOOD LAMP (FR DOOR ARMREST LH)
Connector Type	TK02FGY



Terminal No.	Color Of Wire	Signal Name [Specification]
1	W	-
2	LG	-
3	GR	-
4	V	-
5	SB	-
6	Y	-
7	BR	-
8	L	-
9	W	-
10	O	-
11	G	-
13	P	-
14	V	-
15	W	-

Terminal No.	Color Of Wire	Signal Name [Specification]
1	LG	-
2	SB	-

Terminal No.	Color Of Wire	Signal Name [Specification]
1	P	-
2	V	-

Terminal No.	Color Of Wire	Signal Name [Specification]
1	GR	-
2	Y	-


JRLW06056GB

TOTAL ILLUMINATION CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >

INTERIOR ROOM LAMP CONTROL SYSTEM


Connector No.	D31
Connector Name	WIRE TO WIRE
Connector Type	TH40FW-CS15



Connector No.	D33
Connector Name	DOOR MIRROR (PASSENGER SIDE)
Connector Type	TH24MW-AH



Connector No.	D38
Connector Name	FRONT POWER WINDOW SWITCH (PASSENGER SIDE)
Connector Type	NS16FW-CS




Connector No.	D43
Connector Name	FRONT OUTSIDE HANDLE RH (REQUEST SWITCH)
Connector Type	RK02FL-B



Terminal No.	Color Of Wire	Signal Name [Specification]
3	P	-
4	L	-
5	W	-
6	P	-
7	G	-
8	R	-
9	LG	-
13	B	-
14	V	-
15	Y	-
19	G	-
20	LG	-
22	W	-
23	B	-
24	SHIELD	-
25	G	-
26	R	-
31	LG	-
32	R	-
33	SB	-
34	Y	-
35	GR	-
36	O	-
37	GR	-
38	G	-
39	O	-
40	Y	-
41	L	-
42	O	-
43	BR	-
44	V	-
45	P	-
46	W	-
47	R	-
48	G	-
49	SHIELD	-

Terminal No.	Color Of Wire	Signal Name [Specification]
2	Y	-
3	W	-
4	LG	-
5	G	-
6	R	-
7	LG	-
8	O	-
9	L	-
10	G	-
11	GR	-
12	O	-
14	O	-
16	G	-
17	SHIELD	-
18	B	-
19	B	-
21	P	-
22	BR	-
23	W	-
24	V	-

Terminal No.	Color Of Wire	Signal Name [Specification]
3	LG	-
4	W	-
8	L	-
9	G	-
10	Y	-
11	B	-
12	P	-
15	R	-
16	V	-



Connector No.	D44
Connector Name	FRONT OUTSIDE HANDLE RH (OUTSIDE KEY ANTENNA)
Connector Type	RK02MGY



Connector No.	D42
Connector Name	STEP LAMP (PASSENGER SIDE)
Connector Type	TB02FW



Terminal Color Of Wire	Signal Name [Specification]
1	P
2	W

Terminal Color Of Wire	Signal Name [Specification]
1	SB
2	R

JRLWD6057GB

TOTAL ILLUMINATION CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >

INTERIOR ROOM LAMP CONTROL SYSTEM

Connector No.	D46
Connector Name	MOOD LAMP (FR DOOR ARMREST RH)
Connector Type	TK02FGY



Terminal No.	Color Of Wire	Signal Name [Specification]
1	GR	-
2	Y	-

Connector No.	D51
Connector Name	WIRE TO WIRE
Connector Type	NH10MW-CS10



1	2	3	4	5	6
7	8	9	10	11	12
13	14	15	16	17	18
19	20				

Terminal No.	Color Of Wire	Signal Name [Specification]
2	V	-
3	L	-
4	R	-
5	SB	-
6	B	-
8	G	-
12	L	-
13	Y	-
17	O	-
18	BR	-
19	V	-
20	W	-

Connector No.	D58
Connector Name	MOOD LAMP (RR DOOR ARMREST LH)
Connector Type	TK02FGY



Terminal No.	Color Of Wire	Signal Name [Specification]
1	Y	-
2	BR	-

Connector No.	D59
Connector Name	STEP LAMP (REAR LH)
Connector Type	TB02FW



Terminal No.	Color Of Wire	Signal Name [Specification]
1	L	-
2	O	-

Connector No.	D71
Connector Name	WIRE TO WIRE
Connector Type	NH10MW-CS10



1	2	3	4	5	6
7	8	9	10	11	12
13	14	15	16	17	18
19	20				

Terminal No.	Color Of Wire	Signal Name [Specification]
2	L	-
3	P	-
4	B	-
5	SB	-
6	B	-
8	G	-
12	L	-
13	Y	-
17	O	-
18	BR	-
19	V	-
20	W	-

Connector No.	D78
Connector Name	MOOD LAMP (RR DOOR ARMREST RH)
Connector Type	TK02FGY



Terminal No.	Color Of Wire	Signal Name [Specification]
1	Y	-
2	BR	-

Connector No.	D79
Connector Name	STEP LAMP (REAR RH)
Connector Type	TB02FW



Terminal No.	Color Of Wire	Signal Name [Specification]
1	L	-
2	O	-

Connector No.	D101
Connector Name	WIRE TO WIRE
Connector Type	MA06PW-GY-LC



4	3	2	1
8	7	6	5

Terminal No.	Color Of Wire	Signal Name [Specification]
1	G	-
2	B	-
3	R	-
4	GR	-
6	L/W	-
7	L/B	-
8	SHIELD	-

JRLWD6058GB

TOTAL ILLUMINATION CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >

INTERIOR ROOM LAMP CONTROL SYSTEM

Connector No.	D102
Connector Name	WIRE TO WIRE
Connector Type	TH32FW-NH



16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1
32	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17

Connector No.	D107
Connector Name	BACK DOOR LOCK ASSEMBLY
Connector Type	NS08FW-CS



1		2	
4	5	6	7
			8

TOTAL ILLUMINATION CONTROL UNIT


< ECU DIAGNOSIS INFORMATION >

INTERIOR ROOM LAMP CONTROL SYSTEM

Connector No.	E5
Connector Name	(POWER INTELLIGENT POWER DISTRIBUTION MODULE (ENGINE ROOM))
Connector Type	TH8FWM-NH



Connector No.	E106
Connector Name	WIRE TO WIRE
Connector Type	TH8FWM-CS16-TM4



Terminal No.	Color Of Wire	Signal Name [Specification]
39	P	-
40	L	-
41	B	-
42	Y	-
43	SB	-
44	W	-
45	G	-
46	BR	-

Connector No.	E103
Connector Name	FUSE BLOCK (J/B)
Connector Type	NS16FWM-CS




Terminal No.	Color Of Wire	Signal Name [Specification]
10F	L	-
1F	SB	-
2F	W	-
3F	Y	-
4F	G	-
6F	BG	-
8F	L	-
9F	R	-

37	Y	-
38	GR	-
39	LG	-
41	LG	-
42	V	-
43	R	-
44	G	-
45	GR	-
46	W	-
47	L	-
48	P	-
49	SB	-
50	BR	-
51	B	-
52	Y	-
53	BG	-
54	R	-
55	SB	-
56	P	-
58	SB	-
60	V	-
61	G	-
62	P	-
63	LG	-
64	L	-
65	BG	-
69	L	-
70	SHIELD	-
71	G	-
72	G	-
73	R	-
74	BR	-
76	L	-
77	W	-
78	Y	-
80	SB	-
81	L	-
82	W	-
83	LG	-
84	GR	-
85	G	-
86	P	-
87	W	-
88	BG	-
89	LG	-
90	BR	-
91	GR	-
92	BR	-
93	SB	-
95	Y	-
96	W	-

97	W	-
98	SHIELD	-
100	Y	-




Connector No.	M1
Connector Name	FUSE BLOCK (J/B)
Connector Type	NS06FWM-M2



Terminal No.	Color Of Wire	Signal Name [Specification]
1A	BG	-
2A	G	-
3A	L	-
4A	R	-
5A	V	-
6A	Y	-
7A	R	-
8A	L	-

Connector No.	M2
Connector Name	FUSE BLOCK (J/B)
Connector Type	NS10FWM-CS



Terminal No.	Color Of Wire	Signal Name [Specification]
1B	LG	-
3B	P	-
4B	G	-
5B	BG	-
6B	Y	-
7B	L	-
8B	R	-


TOTAL ILLUMINATION CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >

INTERIOR ROOM LAMP CONTROL SYSTEM


9B	BR	-
----	----	---

Connector No.	M3
Connector Name	FUSE BLOCK (J/B)
Connector Type	MS12FW-CS




Terminal No.	Color Of Wire	Signal Name [Specification]
10C	L	-
11C	LG	-
12C	R	-
9C	P	-
7C	B	-
9C	BG	-

Connector No.	M5
Connector Name	WIRE TO WIRE
Connector Type	TH40MW-CS15



Terminal No.	Color Of Wire	Signal Name [Specification]
1	B	-
3	SB	-
6	R	-
7	W	-
8	G	-
9	L	-
10	BG	-
11	G	-
12	V	-
13	Y	-
14	P	-

Connector No.	M6
Connector Name	WIRE TO WIRE
Connector Type	TH40MW-CS16-TM4



Terminal No.	Color Of Wire	Signal Name [Specification]
1	G	-
2	BG	-
3	LG	- [Without Auto aircon seat]
3	SB	- [With Auto aircon seat]
4	LG	-
5	GR	-
6	W	-
7	G	-
8	W	-
9	P	-
10	BR	-
11	B	-
12	G	-
13	R	-
14	W	-
15	SHIELD	-
16	BR	-
17	L	-
18	P	-
19	G	-
20	GR	- [Without ICC]
20	W	- [With ICC]
21	BR	- [Without ICC]
21	R	- [With ICC]
22	L	- [Without ICC]
22	R	- [With ICC]
23	G	-
24	L	- [Without ICC]
24	P	- [With ICC]
25	W	- [Without ICC]
25	Y	- [With ICC]
26	SHIELD	-
28	GR	-
29	V	-
30	BG	-
32	W	-

33	Y	-
34	L	-
37	G	-
38	R	-
39	G	-
41	L	-
42	W	-
43	R	-
44	LG	-
45	GR	-
46	W	-
47	L	-
48	P	-
49	BG	-
50	LG	-
51	SB	-
52	Y	-
53	BG	-
54	BR	-
55	SB	-
59	SB	-
60	SB	-
61	V	-
62	P	-
63	R	-
64	L	-
65	BG	-
69	V	-
70	SHIELD	-
71	BG	-
72	GR	-
73	W	-
74	SB	-
76	V	-
77	V	-
78	Y	-
80	BG	-
81	L	-
82	W	-
83	Y	-
84	L	-
85	P	-
86	BR	-
87	P	-
88	V	-
89	G	-
90	P	-
91	R	-
92	R	-
93	GR	-

JRLWD6061GB


TOTAL ILLUMINATION CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >

INTERIOR ROOM LAMP CONTROL SYSTEM

95	G	-
96	W	-
97	W	-
98	SHIELD	-
100	Y	-


Connector No.	M7
Connector Name	WIRE TO WIRE
Connector Type	TH60MW-CS16-TM4



Terminal No.	Color Of Wire	Signal Name [Specification]
1	G	- [With Auto aircon seat]
1	Y	- [Without Auto aircon seat]
2	B	-
3	W	-
6	P	-
7	V	-
8	BG	-
10	W	-
11	BG	-
12	B	-
13	G	-
14	R	-
15	W	-
16	SHIELD	-
17	L	-
18	P	-
19	G	-
20	R	-
21	LG	-
23	V	-
24	P	-
25	BR	-
26	GR	-
27	BG	-
28	W	-
38	B	-
39	B	-
43	SB	-
44	W	-


45	B	-
51	V	-
52	LG	-
53	SHIELD	-
54	BR	-
55	Y	-
56	SHIELD	-
57	P	-
58	L	-
59	SHIELD	-
60	L	-
61	BR	-
62	R	-
63	Y	-
64	L	-
65	W	-
66	V	-
67	LG	-
68	Y	-
69	G	-
70	V	-
71	W	-
72	B	-
73	W	-
74	LG	-
75	P	-
76	LG	-
77	SB	-
78	GR	-
79	R	-
80	L	-
81	P	-
82	L	-
83	P	-
84	SB	-
85	W	-
86	Y	-
87	B	-
88	G	-
89	BG	-
91	R	-
92	BG	-
93	BR	-
94	V	-
96	BG	-
97	W	-
98	R	-
99	BG	-

Connector No.	M22
Connector Name	KEY SLOT
Connector Type	TH12FM-AH



Terminal No.	Color Of Wire	Signal Name [Specification]
1	R	BAT
2	GR	CLOCK
3	W	DATA
6	Y	ILL BAT
8	LG	ILL BAT
7	B	GROUND
11	BR	KEY SWITCH SIGNAL

Connector No.	M24
Connector Name	DATA LINK CONNECTOR
Connector Type	BD16FW




Terminal No.	Color Of Wire	Signal Name [Specification]
3	LG	-
4	B	-
5	B	-
6	L	-
7	GR	-
8	G	-
11	SB	-
12	P	-
13	L	-
14	P	-
16	BG	-

Connector No.	M30
Connector Name	FOOT LAMP (DRIVER SIDE)
Connector Type	C02FW



Terminal No.	Color Of Wire	Signal Name [Specification]
1	V	-
2	L	-

Connector No.	M50
Connector Name	PUSH-BUTTON IGNITION SWITCH
Connector Type	TK08FBR



Terminal No.	Color Of Wire	Signal Name [Specification]
1	B	-
2	R	-
3	BG	-
4	SB	-
5	GR	-
6	Y	-
7	V	-
8	P	-

TOTAL ILLUMINATION CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >


INTERIOR ROOM LAMP CONTROL SYSTEM

Connector No.	M104
Connector Name	REMOTE KEYLESS ENTRY RECEIVER
Connector Type	JAB04FB



Terminal No.	Color Of Wire	Signal Name [Specification]
1	B	GROUND
2	GR	SIGNAL OUTPUT
4	BR	BATTERY

Connector No.	M106
Connector Name	WIRE TO WIRE
Connector Type	NH10MW-CS10



Terminal No.	Color Of Wire	Signal Name [Specification]
1	V	-
2	BR	-
3	GR	-
4	SHIELD	-
5	G	-
6	BR	-
9	P	-
10	G	-
11	Y	-
12	BR	-
13	L	-
14	L	-
15	R	-
16	R	-
17	B	-
20	BG	-

Connector No.	M117
Connector Name	WIRE TO WIRE
Connector Type	TH80MW-CS16-TM4



Terminal No.	Color Of Wire	Signal Name [Specification]
1	GR	-
2	BR	-
3	V	-
4	SB	-
6	Y	-
7	B	-
8	W	-
10	W	-
11	SHIELD	-
20	R	-
21	G	-
22	GR	-
23	V	-
24	W	-
25	R	-
26	P	-
27	L	-
28	SHIELD	-
31	W	-
32	W	-
33	SB	-
36	L	-
37	P	-
38	L	-
39	P	-
40	V	-
41	SB	- [With ICC]
41	Y	- [Without ICC]
42	V	- [With ICC]
42	W	- [Without ICC]
43	B	- [With ICC]
43	P	- [Without ICC]
44	R	- [With ICC]
44	R	- [Without ICC]
45	G	- [With ICC]
45	L	- [Without ICC]
46	BG	- [With ICC]
46	BG	- [Without ICC]


46	SHIELD	- [Without ICC]
47	B	- [Without ICC]
47	L	- [With ICC]
48	P	- [With ICC]
48	R	- [Without ICC]
49	G	- [With ICC]
49	W	- [Without ICC]
50	SHIELD	-
51	BG	-
52	GR	-
53	G	-
54	L	-
55	P	-
60	LG	-
61	R	-
62	SB	-
63	V	-
64	Y	-
65	BR	-
66	BG	-
67	W	-
69	G	-
71	SB	-
72	V	-
73	V	-
74	LG	-
75	BR	-
76	V	-
77	LG	-
80	R	-
82	Y	-
83	BG	-
84	W	-
85	SB	-
86	B	-
87	P	-
91	L	-
92	L	-
93	G	-
94	BG	-
95	V	-
96	G	-
97	G	-
98	L	-
99	LG	-

Connector No.	M118
Connector Name	BCM (BODY CONTROL MODULE)
Connector Type	M03FB-LC



Terminal No.	Color Of Wire	Signal Name [Specification]
1	W	BAT (E/L)
2	Y	POWER WINDOW POWER SUPPLY (BAT)
3	BG	POWER WINDOW POWER SUPPLY (BAT)

Connector No.	M119
Connector Name	BCM (BODY CONTROL MODULE)
Connector Type	NS16FM-CS




Terminal No.	Color Of Wire	Signal Name [Specification]
4	P	INT ROOM LAMP PWR SUPPLY (BAT SAVE)
5	V	PASSENGER DOOR UNLOCK OUTPUT
7	Y	STEP LAMP OUTPUT
8	V	ALL DOOR FUEL LID LOCK OUTPUT
9	G	DRIVER DOOR FUEL LID UNLOCK OUTPUT
10	BR	REAR DOOR UNLOCK OUTPUT
11	R	BAT (FUSE)
13	B	GROUND
15	Y	ACC NO
17	W	TURN SIGNAL RH (FRONT)
18	BG	TURN SIGNAL LH (FRONT)
19	SB	ROOM LAMP TIMER

TOTAL ILLUMINATION CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >

INTERIOR ROOM LAMP CONTROL SYSTEM

Connector No.	M121
Connector Name	BCM (BODY CONTROL MODULE)
Connector Type	TH40FGY-NH



Terminal No.	Color Of Wire	Signal Name [Specification]
34	SB	LUGGAGE ROOM ANT-
35	V	LUGGAGE ROOM ANT+
38	B	BACK DOOR ANT-
39	W	BACK DOOR ANT+
47	Y	IGN RELAY (PDM/ER) CONT
52	LG	STARTER RELAY CONT
60	SB	ENG START SW
61	W	TRUNK REQUEST SW
64	L	1KEY WARN BUZZER (ENG ROOM)
65	BG	REAR WIPER STOP POSITION
66	LG	BACK DOOR SW
67	P	BACK DOOR OPENER SW
68	BR	REAR RH DOOR SW
69	R	REAR LH DOOR SW


Connector No.	M122
Connector Name	BCM (BODY CONTROL MODULE)
Connector Type	TH40FB-NH



Terminal No.	Color Of Wire	Signal Name [Specification]
74	SB	PASSENGER DOOR ANT-
75	BR	PASSENGER DOOR ANT+
76	V	DRIVER DOOR ANT-
77	LG	DRIVER DOOR ANT+
78	Y	ROOM ANT-
79	BR	ROOM ANT+

Terminal No.	Color Of Wire	Signal Name [Specification]
80	GR	NATS ANT AMP.
81	W	NATS ANT AMP.
82	P	IGN RELAY (FBI) CONT
83	GR	KEYLESS ENTRY RECEIVER SIGNAL
144	G	COMBI SW OUTPUT 1
145	L	COMBI SW OUTPUT 2
146	V	COMBI SW OUTPUT 3
88	P	COMBI SW INPUT 5
87	W	COMBI SW INPUT 3
90	P	CAN-L
91	L	CAN-H
92	LG	KEY SLOT ILL
93	V	ON IND
95	BG	ACC RELAY CONT
96	GR	AT SHIFT SELECTOR POWER SUPPLY
99	R	SHIFT P
100	G	PASSENGER DOOR REQUEST SW
101	SB	DRIVER DOOR REQUEST SW
102	BG	BLOWER FAN MOTOR RELAY CONT
103	BR	KEYLESS ENTRY RECEIVER POWER SUPPLY
107	LG	COMBI SW INPUT 1
108	R	COMBI SW INPUT 4
109	Y	COMBI SW INPUT 2
110	G	HAZARD SW


Connector No.	M123
Connector Name	BCM (BODY CONTROL MODULE)
Connector Type	TH40FG-NH



Terminal No.	Color Of Wire	Signal Name [Specification]
112	GR	RAIN SENSOR SERIAL LINK
113	P	OPICAL SENSOR
116	BR	STOP LAMP SW 1
118	P	STOP LAMP SW 2
119	SB	DR DOOR UNLOCK SENSOR
121	BR	KEY SLOT SW
123	W	IGN F/B
124	LG	PASSENGER DOOR SW
132	BG	POWER WINDOW SW COMM
134	GR	LOCK IND
137	B	RECEIVER SENSOR GND
138	Y	SENSOR POWER SUPPLY
140	R	SHIFT NP

Terminal No.	Color Of Wire	Signal Name [Specification]
141	G	SECURITY INDICATOR OUTPUT
142	BG	COMBI SW OUTPUT 5
143	P	COMBI SW OUTPUT 1
144	G	COMBI SW OUTPUT 2
145	L	COMBI SW OUTPUT 3
146	SB	COMBI SW OUTPUT 4
150	GR	DRIVER DOOR SW
151	G	REAR WINDOW DEFROGGER RELAY CONT

Connector No.	M124
Connector Name	WIRE TO WIRE
Connector Type	TH40MW-CS15



Terminal No.	Color Of Wire	Signal Name [Specification]
3	Y	-
4	LG	-
5	SB	-
6	BR	-
7	G	-
8	V	-
9	LG	-
13	B	-
14	BG	-
15	W	-
19	G	-
20	LG	-
22	W	-
23	B	-
24	SHIELD	-
25	G	-
26	R	-
31	BG	-
32	Y	-
33	LG	-
34	SB	-
35	V	-
36	BG	-
37	GR	-
38	G	- [Without automatic drive positioner]
38	R	- [With automatic drive positioner]

Terminal No.	Color Of Wire	Signal Name [Specification]
3	V	DDL2
4	L	TAIL LAMP SIGNAL
5	V	ACC SIGNAL
6	P	BAT SAVER SIGNAL
7	W	IGN SIGNAL
8	G	DOOR SW (AS)
9	BG	DOOR SW (RL)
10	SB	MOOD LAMP (FR ARMREST RH)
11	Y	MOOD LAMP (RR ARMREST RH)
12	P	MAP LAMP (AS)
13	G	PERSONAL LAMP (LH)
14	R	PERSONAL LAMP (RH)
16	GR	FOOT LAMP (RH)
17	LG	HSPILL ILLUMINATIONS
18	L	MAP LAMP (DR)
19	R	PUSH ENG START SW LED
20	Y	AMBIENCE LAMP
21	R	BAT POWER SUPPLY
23	B	GROUND
24	B	ILL CONT INPUT
25	BR	DOOR SW (RR)
26	BR	MAP LAMP SW (DOOR)
27	R	MAP LAMP SW (ALL ON)

A
B
C
D
E
F
G
H
I
J
K
INL
M
N
O
P

TOTAL ILLUMINATION CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >

INTERIOR ROOM LAMP CONTROL SYSTEM

Connector No.	M130
Connector Name	ROOM LAMP TIMER
Connector Type	DOOR SW (DR)
28	SB
29	GR
30	LG
31	BG
33	W
34	R
35	V
36	L
39	B
40	BG



Connector No.	M130
Connector Name	FOOT LAMP (PASSENGER SIDE)
Connector Type	CO2FW



Terminal Color Of No.	Wire	Signal Name [Specification]
1	V	-
2	GR	-

Connector No.	M151
Connector Name	WIRE TO WIRE
Connector Type	M03FW-LC



Terminal Color Of No.	Wire	Signal Name [Specification]
1	W	-
2	Y	-
3	R	-

Connector No.	M152
Connector Name	WIRE TO WIRE
Connector Type	M03MW-LC



Terminal Color Of No.	Wire	Signal Name [Specification]
1	W	-
2	Y	-
3	R	-

Connector No.	R1
Connector Name	WIRE TO WIRE
Connector Type	NH10FW-CS10



Terminal Color Of No.	Wire	Signal Name [Specification]
1	V	-
2	BR	-
3	GR	-
4	SHIELD	-
5	G	-
6	BR	-
9	P	-
10	G	-
11	Y	-
12	BR	-
13	L	-
14	L	-
15	R	-
16	R	-
17	R	-
20	Y	-

Connector No.	R2
Connector Name	WIRE TO WIRE
Connector Type	TH24FW-AH



Terminal Color Of No.	Wire	Signal Name [Specification]
1	P	-
2	GR	-
8	SHIELD	-
9	R	-
10	G	-
11	B	-
12	V	-
17	Y	-
18	G	-
19	R	-
20	L	-
21	P	-
22	R	-
23	BR	-
24	B	-

Connector No.	R11
Connector Name	WIRE TO WIRE
Connector Type	TH24MW-AH



Terminal Color Of No.	Wire	Signal Name [Specification]
1	LG	-
2	GR	-
8	SHIELD	-
9	L	-
10	R	-

Terminal Color Of No.	Wire	Signal Name [Specification]
11	B	-
12	V	-
17	Y	-
18	G	-
19	SB	-
20	P	-
21	L	-
22	R	-
23	BR	-
24	O	-

Connector No.	R12
Connector Name	VANITY MIRROR LAMP LH
Connector Type	MCA02FW



Terminal Color Of No.	Wire	Signal Name [Specification]
1	B	-
2	V	-

Connector No.	R13
Connector Name	VANITY MIRROR LAMP RH
Connector Type	MCA02FW



Terminal Color Of No.	Wire	Signal Name [Specification]
1	B	-
2	V	-

TOTAL ILLUMINATION CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >


INTERIOR ROOM LAMP CONTROL SYSTEM

Connector No.	R14
Connector Name	PERSONAL LAMP
Connector Type	TH34FW-NH



Terminal No.	Color Of Wire	Signal Name [Specification]
1	G	-
2	B	-
3	SB	-
4	V	-

Connector No.	R15
Connector Name	MAP LAMP
Connector Type	TK10FW



Terminal No.	Color Of Wire	Signal Name [Specification]
1	BR	DOOR ON SIG
2	R	ALL ON SIG
3	B	GROUND
5	V	LED+
6	Y	LED-
7	P	DOOR SIG L
8	B	GROUND
9	L	DOOR SIG R
10	V	BAT

JRLWD6066GB


A
B
C
D
E
F
G
H
I
J
K
INL
M
N
O
P

TOTAL ILLUMINATION CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >

Wiring Diagram - ILLUMINATION -

INFOID:000000011016161





2014/03/18

JRLWD6067GB

TOTAL ILLUMINATION CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >

IC : With ICC
WS : With climate controlled seat




JRLWD6068GB

A
B
C
D
E
F
G
H
I
J
K
INL
M
N
O
P

TOTAL ILLUMINATION CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >

◁HS▷ : With heated seat
◁PM▷ : With automatic drive positioner
◁OP▷ : Without automatic drive positioner




JRLWD6069GB

TOTAL ILLUMINATION CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >

⬡ : With ICC

★ : This connector is not shown in "Harness Layout".




JRLWD6070GB

A
B
C
D
E
F
G
H
I
J
K
INL
M
N
O
P

TOTAL ILLUMINATION CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >




TOTAL ILLUMINATION CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >

ILLUMINATION


Connector No.	B1
Connector Name	WIRE TO WIRE
Connector Type	TH08FW-CS16-TM4



Terminal No.	Color	Wire	Signal Name [Specification]
1	G	-	-
2	L	-	-
3	W	-	-
4	G	-	-
5	P	-	-
6	BG	-	-
7	SB	-	-
8	W	-	-
9	R	-	-
10	G	-	-
11	B	-	-
12	W	-	-
13	L	-	-
14	R	-	-
15	W	-	-
16	SHIELD	-	-
17	L	-	-
18	P	-	-
19	G	-	-
20	Y	-	-
21	W	-	-
23	V	-	-
24	P	-	-
25	BR	-	-
26	GR	-	-
27	BG	-	-
28	W	-	-
38	B	-	-
39	B	-	-
43	SB	-	-
44	V	-	-
45	GR	-	-
51	V	-	-
52	SB	-	-
53	SHIELD	-	-
54	BR	-	-
55	Y	-	-
56	SHIELD	-	-

57	P	-	-
58	L	-	-
59	SHIELD	-	-
60	L	-	-
61	P	-	-
62	GR	-	-
63	G	-	-
64	BG	-	-
65	W	-	-
66	V	-	-
67	LG	-	-
68	Y	-	-
69	G	-	-
70	GR	-	-
71	G	-	-
72	B	-	-
73	W	-	-
74	V	-	-
75	BG	-	-
76	LG	-	-
77	L	-	-
78	GR	-	-
79	W	-	-
80	L	-	-
81	P	-	-
82	L	-	-
83	P	-	-
84	SB	-	-
85	R	-	-
86	Y	-	-
87	B	-	-
88	G	-	-
89	BR	-	-
91	R	-	-
92	BG	-	-
93	BR	-	-
94	V	-	-
96	BG	-	-
97	W	-	-
98	GR	-	-
99	W	-	-

Connector No.	B16
Connector Name	FRONT DOOR SWITCH (DRIVER SIDE)
Connector Type	A03FW



Terminal No.	Color	Wire	Signal Name [Specification]
2	GR	-	-

Connector No.	E5
Connector Name	ENGINE INTELLIGENT POWER DISTRIBUTION MODULE (ENGINE ROOM)
Connector Type	TH08FW-CS2-M4-TV



Terminal No.	Color	Wire	Signal Name [Specification]
4	V	-	-
5	L	-	-
7	R	-	-
10	SB	-	-
12	B	-	-
13	Y	-	-
16	LG	-	-
19	W	-	-
25	G	-	-
26	R	-	-
27	Y	-	-
28	BG	-	-
30	GR	-	-
36	G	-	-

Connector No.	E6
Connector Name	ENGINE INTELLIGENT POWER DISTRIBUTION MODULE (ENGINE ROOM)
Connector Type	TH08FW-AH



Terminal No.	Color	Wire	Signal Name [Specification]
39	P	-	-
40	L	-	-
41	B	-	-
42	Y	-	-
43	SB	-	-
44	W	-	-
45	G	-	-
46	BR	-	-

Connector No.	E103
Connector Name	FUSE BLOCK (J/B)
Connector Type	NS16FW-CS




Terminal No.	Color	Wire	Signal Name [Specification]
10F	L	-	-
1F	SB	-	-
2F	W	-	-
3F	Y	-	-
4F	G	-	-
6F	BG	-	-
8F	L	-	-
9F	R	-	-

TOTAL ILLUMINATION CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >

ILLUMINATION

Connector No.	IE106
Connector Name	WIRE TO WIRE
Connector Type	TH80FW-CS16-TM4



Terminal No.	Color Of Wire	Signal Name [Specification]
1	G	-
2	BG	-
3	SB	-
4	LG	-
5	Y	-
6	W	-
7	G	-
8	V	-
9	R	-
10	BR	-
11	B	-
12	G	-
13	R	-
14	W	-
15	SHIELD	-
16	SB	-
17	L	-
18	P	-
19	G	-
20	W	- [With ICC]
21	BR	- [Without ICC]
22	R	- [With ICC]
23	V	- [Without ICC]
24	L	- [With ICC]
25	P	- [Without ICC]
26	SHIELD	- [With ICC]
28	G	-
29	LG	-
30	BG	-
32	W	-
33	Y	-
34	BG	-

37	Y	-
38	GR	-
39	LG	-
41	LG	-
42	V	-
43	R	-
44	G	-
45	GR	-
46	W	-
47	L	-
48	P	-
49	SB	-
50	BR	-
51	B	-
52	Y	-
53	BG	-
54	R	-
55	SB	-
59	P	-
60	SB	-
61	V	-
62	P	-
63	LG	-
64	L	-
65	BG	-
69	L	-
70	SHIELD	-
71	G	-
72	G	-
73	R	-
74	BR	-
76	L	-
77	W	-
78	Y	-
80	SB	-
81	L	-
82	W	-
83	LG	-
84	GR	-
85	G	-
86	P	-
87	W	-
88	BG	-
89	LG	-
90	BR	-
91	GR	-
92	BR	-
93	SB	-
95	Y	-
96	W	-


97	W	-
98	SHIELD	-
100	Y	-

Connector No.	M1
Connector Name	FUSE BLOCK (J/B)
Connector Type	NS06FW-M2



Terminal No.	Color Of Wire	Signal Name [Specification]
1A	BG	-
2A	G	-
3A	L	-
4A	R	-
5A	V	-
6A	Y	-
7A	R	-
8A	L	-


Connector No.	M2
Connector Name	FUSE BLOCK (J/B)
Connector Type	NS10FW-CS



Terminal No.	Color Of Wire	Signal Name [Specification]
1B	LG	-
3B	P	-
4B	G	-
5B	BG	-
6B	Y	-
7B	L	-
8B	R	-

9B	BR	-
----	----	---

Connector No.	M3
Connector Name	FUSE BLOCK (J/B)
Connector Type	NS12FW-CS



Terminal No.	Color Of Wire	Signal Name [Specification]
10C	L	-
11C	LG	-
12C	R	-
6C	P	-
7C	B	-
9C	BG	-

Connector No.	M6
Connector Name	WIRE TO WIRE
Connector Type	TH80MW-CS16-TM4



Terminal No.	Color Of Wire	Signal Name [Specification]
1	G	-
2	BG	-
3	LG	- [Without Auto aircon seat]
4	LG	- [With Auto aircon seat]
5	GR	-
6	W	-
7	G	-
8	W	-
9	P	-
10	BR	-

TOTAL ILLUMINATION CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >

ILLUMINATION

11	B	-
12	G	-
13	R	-
14	W	-
15	SHIELD	-
16	BR	-
17	L	-
18	P	-
19	G	-
20	GR	- [Without ICC] - [With ICC]
21	BR	- [Without ICC] - [With ICC]
22	L	- [Without ICC] - [With ICC]
23	R	- [Without ICC] - [With ICC]
24	P	- [Without ICC] - [With ICC]
25	W	- [Without ICC] - [With ICC]
26	SHIELD	-
28	GR	-
29	V	-
30	BG	-
32	W	-
33	Y	-
34	L	-
37	G	-
38	R	-
39	G	-
41	L	-
42	W	-
43	R	-
44	LG	-
45	GR	-
46	W	-
47	L	-
48	P	-
49	BG	-
50	LG	-
51	SB	-
52	Y	-
53	BG	-
54	BR	-
55	SB	-
59	SB	-
60	SB	-
61	V	-
62	P	-
63	R	-

64	L	-
65	BG	-
69	V	-
70	SHIELD	-
71	BG	-
72	GR	-
73	W	-
74	SB	-
76	V	-
77	V	-
78	Y	-
80	BG	-
81	L	-
82	W	-
83	Y	-
84	L	-
85	P	-
86	BR	-
87	P	-
88	V	-
89	G	-
90	P	-
91	R	-
92	R	-
93	GR	-
95	G	-
96	W	-
97	W	-
98	SHIELD	-
100	Y	-

Connector No.	M7
Connector Name	WIRE TO WIRE
Connector Type	TH80MW-CS16-TM4



Terminal No.	Color Of Wire	Signal Name [Specification]
1	G	- [With Auto aircon seat]
2	B	- [Without Auto aircon seat]
3	W	-

6	P	-
7	V	-
8	BG	-
10	W	-
11	BG	-
12	B	-
13	G	-
14	R	-
15	W	-
16	SHIELD	-
17	L	-
18	P	-
19	G	-
20	R	-
21	LG	-
23	V	-
24	P	-
25	BR	-
26	GR	-
27	BG	-
28	W	-
38	B	-
39	B	-
43	SB	-
44	W	-
45	B	-
51	V	-
52	LG	-
53	SHIELD	-
54	BR	-
55	Y	-
56	SHIELD	-
57	P	-
58	L	-
59	SHIELD	-
60	L	-
61	BR	-
62	R	-
63	Y	-
64	L	-
65	W	-
66	V	-
67	LG	-
68	Y	-
69	G	-
70	V	-
71	W	-
72	B	-
73	W	-
74	LG	-

Connector No.	M15
Connector Name	HEADLAMP AIMING SWITCH
Connector Type	A04FW



Terminal No.	Color Of Wire	Signal Name [Specification]
1	SB	-
2	B	-
3	R	-
4	R	-


A
B
C
D
E
F
G
H
I
J
K
INL
M
N
O
P

TOTAL ILLUMINATION CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >


ILLUMINATION

Connector No.	M19
Connector Name	VDC OFF SWITCH
Connector Type	TK08FGY




Terminal No.	Color Of Wire	Signal Name [Specification]
1	BR	-
2	B	-
3	W	-
4	LG	-

Connector No.	M20
Connector Name	DOOR MIRROR REMOTE CONTROL SWITCH
Connector Type	TK16FW



Terminal No.	Color Of Wire	Signal Name [Specification]
2	LG	-
3	BG	-
4	GR	-
5	L	-
6	Y	-
7	G	-
8	R	-
9	P	-
10	SB	-
11	LG	-
12	B	-
13	G	-
14	BG	-
15	W	-

Connector No.	M26
Connector Name	DOOR MIRROR REMOTE CONTROL SWITCH
Connector Type	TK16FBR




Terminal No.	Color Of Wire	Signal Name [Specification]
2	P	-
3	LG	-
4	BR	-
5	V	-
6	G	-
8	SB	-
9	LG	-
10	R	-
11	P	-
12	G	-
13	B	-
14	SB	-
15	BG	-
16	W	-

Connector No.	M29
Connector Name	WARNING SYSTEMS SWITCH
Connector Type	TK08FGY



Terminal No.	Color Of Wire	Signal Name [Specification]
2	SB	-
3	Y	-
4	R	-
5	B	-
6	R	-
7	V	-

Connector No.	M32
Connector Name	AUTOMATIC BACK DOOR MAIN SWITCH
Connector Type	TK08FW




Terminal No.	Color Of Wire	Signal Name [Specification]
1	BG	-
2	LG	-
3	B	-
4	W	-

Connector No.	M33
Connector Name	COMBINATION SWITCH
Connector Type	TH16FW-HH



Terminal No.	Color Of Wire	Signal Name [Specification]
1	P	FR WASHER (-)
2	SB	OUTPUT 4
3	BG	FR WASHER (+)
4	G	IGN
5	L	OUTPUT 3
6	B	GROUND
7	V	INPUT 3
8	BG	OUTPUT 5
9	Y	INPUT 2
10	R	INPUT 4
11	LG	INPUT 1
12	P	OUTPUT 1
13	BR	INPUT 5
14	G	OUTPUT 2

Connector No.	M34
Connector Name	AUTOMATIC BACK DOOR SWITCH
Connector Type	TK08FGY



Terminal No.	Color Of Wire	Signal Name [Specification]
1	Y	-
2	B	-
3	W	-
4	LG	-

Connector No.	M35
Connector Name	COMBINATION SWITCH (SPIRAL CABLE)
Connector Type	TK08FY-EX-TV



Terminal No.	Color Of Wire	Signal Name [Specification]
23	R	-
28	Y	-
29	Y	-
30	Y	-

TOTAL ILLUMINATION CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >

ILLUMINATION

Connector No.	M36
Connector Name	COMBINATION SWITCH (SPRAL CABLE)
Connector Type	TK08FGY-1V




Terminal No.	Color Of Wire	Signal Name [Specification]
24	P	-
25	SB	-
26	B	-
31	L	-
32	V	-
33	B	-
34	G	-

Connector No.	M50
Connector Name	PUSH-BUTTON IGNITION SWITCH
Connector Type	TK08FBR



Terminal No.	Color Of Wire	Signal Name [Specification]
1	B	-
2	R	-
3	BG	-
4	SB	-
5	GR	-
6	Y	-
7	V	-
8	P	-

Connector No.	M53
Connector Name	COMBINATION METER
Connector Type	TH40FW-NH




Terminal No.	Color Of Wire	Signal Name [Specification]
1	BG	BATTERY POWER SUPPLY
2	LG	COMMUNICATION SIGNAL (METER->AMP)
3	GR	COMMUNICATION SIGNAL (AMP->METER)
5	B	GROUND
6	W	ALTERNATOR SIGNAL
7	P	AIR BAG SIGNAL
10	G	SECURITY INDICATOR SIGNAL
15	B	GROUND
16	B	METER CONTROL SWITCH GROUND
21	R	IGNITION SIGNAL
24	BR	COMMUNICATION SIGNAL (LCD->AMP)
25	Y	COMMUNICATION SIGNAL (AMP->LCD)
26	R	VEHICLE SPEED SIGNAL (8-PULSE)
27	V	PARKING BRAKE SWITCH SIGNAL
28	W	BRAKE FLUID LEVEL SWITCH SIGNAL
29	SB	SEAT BELT BUCKLE SWITCH SIGNAL (DRIVER SEEL)
30	G	PASSENGER SEAT BELT WARNING SIGNAL
31	L	WASHER LEVEL SWITCH SIGNAL
34	B	ILLUMINATION CONTROL SIGNAL
36	LG	SELECT SWITCH SIGNAL
37	SB	ENTER SWITCH SIGNAL
38	L	TRIP AIR RESET SWITCH SIGNAL
39	P	ILLUMINATION CONTROL SWITCH SIGNAL (-)
40	BG	ILLUMINATION CONTROL SWITCH SIGNAL (+)

Connector No.	M54
Connector Name	METER CONTROL SWITCH
Connector Type	TH12MW-NH



Terminal No.	Color Of Wire	Signal Name [Specification]
1	BG	-
2	B	-
3	P	-
4	R	-
5	B	-
6	LG	-
7	SB	-


Connector No.	M66
Connector Name	UNIFIED METER AND A/C AMP.
Connector Type	TH40FW-NH



Terminal No.	Color Of Wire	Signal Name [Specification]
5	L	MANUAL MODE SHIFT UP SIGNAL
6	BG	PADDLE SHIFTER UP SIGNAL
7	GR	COMMUNICATION SIGNAL (AMP->METER)
8	L	VEHICLE SPEED SIGNAL (2-PULSE)
9	SB	SEAT BELT BUCKLE SWITCH SIGNAL (DRIVER SEEL)
10	W	MANUAL MODE SIGNAL
11	G	NON-MANUAL MODE SIGNAL
14	BR	COMMUNICATION SIGNAL (LCD->AMP)
20	L	ION SENSOR SIGNAL
23	Y	AT SNOW SWITCH SIGNAL
25	V	MANUAL MODE SHIFT DOWN SIGNAL
26	G	PADDLE SHIFTER DOWN SIGNAL
27	LG	COMMUNICATION SIGNAL (METER->AMP)

28	R	VEHICLE SPEED SIGNAL (8-PULSE)
30	V	PARKING BRAKE SWITCH SIGNAL
34	Y	COMMUNICATION SIGNAL (AMP->LCD)
38	L	BLOWER MOTOR CONTROL SIGNAL

Connector No.	M67
Connector Name	UNIFIED METER AND A/C AMP.
Connector Type	TH32FW-NH



Terminal No.	Color Of Wire	Signal Name [Specification]
41	V	ACC POWER SUPPLY
42	Y	FUEL LEVEL SENSOR SIGNAL
43	R	INTAKE SENSOR SIGNAL
44	LG	IN-VEHICLE SENSOR SIGNAL
45	P	AMBIENT SENSOR SIGNAL
46	BG	SUNLOAD SENSOR SIGNAL
47	V	GAS SENSOR SIGNAL
53	G	IGNITION POWER SUPPLY
54	BG	BATTERY POWER SUPPLY
55	B	GROUND
56	L	CAN-H
57	W	BRAKE FLUID LEVEL SWITCH SIGNAL
58	B	FUEL LEVEL SENSOR GROUND
59	GR	INTAKE SENSOR GROUND
60	L	IN-VEHICLE SENSOR GROUND
61	BR	AMBIENT SENSOR GROUND
62	SB	SUNLOAD SENSOR GROUND
63	R	ION MODE SIGNAL
65	BG	ECV SIGNAL
69	L	AC/LAN SIGNAL
70	R	EACH DOOR MOTOR POWER SUPPLY
71	B	GROUND
72	P	CAN-L


JRLWLD6076GB

TOTAL ILLUMINATION CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >

ILLUMINATION

Connector No.	M172
Connector Name	MULTIFUNCTION SWITCH
Connector Type	TH16FW-LNH



Terminal No.	Color Of Wire	Signal Name [Specification]
1	B	GROUND
3	V	ACC
4	R	ILL
5	R	ILL CONT
8	SB	AV COMM (H)
9	LG	AV COMM (L)
14	SB	SW GND
16	G	DISK EJECT SIGNAL
		HAZARD ON

Connector No.	M174
Connector Name	CLOCK
Connector Type	TH16FW-LNH




Terminal No.	Color Of Wire	Signal Name [Specification]
1	B	ILLUMINATION (-)
2	R	ILLUMINATION (+)
3	B	GROUND
4	Y	BATTERY POWER SUPPLY

Connector No.	M102
Connector Name	GLOVE BOX LAMP
Connector Type	A02FW



Terminal No.	Color Of Wire	Signal Name [Specification]
1	R	-
2	B	-

Connector No.	M106
Connector Name	WIRE TO WIRE
Connector Type	NH10MW-CS10



Terminal No.	Color Of Wire	Signal Name [Specification]
1	V	-
2	BR	-
3	GR	-
4	SHIELD	-
5	G	-
6	BR	-
9	P	-
10	G	-
11	Y	-
12	BR	-
13	L	-
14	L	-
15	R	-
16	R	-
17	B	-
20	BG	-

Connector No.	M118
Connector Name	BCM (BODY CONTROL MODULE)
Connector Type	M03FB-LC




Terminal No.	Color Of Wire	Signal Name [Specification]
1	W	BAT (E/L)
2	Y	POWER WINDOW POWER SUPPLY (BAT)
3	BG	POWER WINDOW POWER SUPPLY (BAP)

Connector No.	M119
Connector Name	BCM (BODY CONTROL MODULE)
Connector Type	NS16FW-CS



Terminal No.	Color Of Wire	Signal Name [Specification]
4	P	INT ROOM LAMP PWR SUPPLY (BAT SAVE)
5	V	PASSENGER DOOR UNLOCK OUTPUT
7	Y	STEP LAMP OUTPUT
8	V	ALL DOOR FUEL LID LOCK OUTPUT
9	G	DRIVER DOOR FUEL LID UNLOCK OUTPUT
10	BR	REAR DOOR UNLOCK OUTPUT
11	R	BAT (FUSE)
13	B	GROUND
15	Y	ACC IND
17	W	TURN SIGNAL RH (FRONT)
18	BG	TURN SIGNAL LH (FRONT)
19	SB	ROOM LAMP TIMER

Connector No.	M122
Connector Name	BCM (BODY CONTROL MODULE)
Connector Type	TH10FB-LNH




Terminal No.	Color Of Wire	Signal Name [Specification]
74	SB	PASSENGER DOOR ANT-
75	BR	PASSENGER DOOR ANT+
76	V	DRIVER DOOR ANT-
77	LG	DRIVER DOOR ANT+
78	Y	ROOM ANT-
79	BR	ROOM ANT+
80	GR	WATS ANT AMP-
81	W	WATS ANT AMP+
82	P	IGN RELAY (F/B) CONT
83	GR	KEYLESS ENTRY RECEIVER SIGNAL
87	BR	COMBI SW INPUT 5
88	V	COMBI SW INPUT 3
90	P	CANL
91	L	CANH
92	LG	KEY SLOT ILL
93	V	ON IND
95	BG	ACC RELAY CONT
96	GR	A/T SHIFT SELECTOR POWER SUPPLY
99	R	SHIFT P
100	G	PASSENGER DOOR REQUEST SW
101	SB	DRIVER DOOR REQUEST SW
102	BG	BLOWER FAN MOTOR RELAY CONT
103	BR	KEYLESS ENTRY RECEIVER POWER SUPPLY
107	LG	COMBI SW INPUT 1
108	R	COMBI SW INPUT 4
109	Y	COMBI SW INPUT 2
110	G	HAZARD SW

TOTAL ILLUMINATION CONTROL UNIT


< ECU DIAGNOSIS INFORMATION >

ILLUMINATION

Connector No.	M123
Connector Name	BCM (BODY CONTROL MODULE)
Connector Type	TH40FG-NH




Connector No.	M129
Connector Name	TOTAL ILLUMINATION CONTROL UNIT
Connector Type	TH40FM-NH



Connector No.	M132
Connector Name	FRONT POWER SOCKET
Connector Type	NS03FM-CS



Connector No.	M151
Connector Name	WIRE TO WIRE
Connector Type	M03FW-LC



Terminal No.	Color Of Wire	Signal Name [Specification]
112	GR	RAIN SENSOR SERIAL LINK
113	P	OPTICAL SENSOR
116	BR	STOP LAMP SW 1
118	P	STOP LAMP SW 2
119	SB	DR DOOR UNLOCK SENSOR
121	BR	KEY SLOT SW
123	W	IGN F/B
124	LG	PASSENGER DOOR SW
132	BG	POWER WINDOW SW COMM
134	GR	LOCK IND
137	B	RECEIVER/SENSOR GND
138	Y	SENSOR POWER SUPPLY
140	R	SHIFT NP
141	G	SECURITY INDICATOR OUTPUT
142	BG	COMBI SW OUTPUT 5
143	P	COMBI SW OUTPUT 1
144	G	COMBI SW OUTPUT 2
145	L	COMBI SW OUTPUT 3
146	SB	COMBI SW OUTPUT 4
150	GR	DRIVER DOOR SW
151	G	REAR WINDOW DEFROGGER RELAY CONT

Terminal No.	Color Of Wire	Signal Name [Specification]
3	V	DDL2
4	L	TAIL LAMP SIGNAL
5	V	ACC SIGNAL
6	P	BAT SAVER SIGNAL
7	W	IGN SIGNAL
8	G	DOOR SW (AS)
9	BG	DOOR SW (RL)
10	SB	MOOD LAMP (FR ARMREST RH)
11	Y	MOOD LAMP (RR ARMREST RH)
12	P	MAP LAMP (AS)
13	G	PERSONAL LAMP (LH)
14	R	PERSONAL LAMP (RH)
16	GR	FOOT LAMP (RH)
17	LG	HSPL ILLUMINATIONS
18	L	MAP LAMP (DR)
19	R	PUSH ENG START SW LED
20	Y	AMBIENCE LAMP
21	R	BAT POWER SUPPLY
23	B	GROUND
24	B	ILL CONT INPUT
25	BR	DOOR SW (RR)
26	BR	MAP LAMP SW (DOOR)
27	R	MAP LAMP SW (ALL ON)
28	SB	ROOM LAMP TIMER
29	GR	DOOR SW (DR)
30	LG	MOOD LAMP (FR ARMREST LH)
31	BG	MOOD LAMP (RR ARMREST LH)
33	W	HSPL POWER SUPPLY 3
34	R	HSPL POWER SUPPLY 2
35	V	HSPL POWER SUPPLY 1
36	L	FOOT LAMP (LH)
39	B	PUDDLE LAMP (RH)
40	BG	PUDDLE LAMP (LH)

Terminal No.	Color Of Wire	Signal Name [Specification]
1	W	
2	Y	
3	R	

Terminal No.	Color Of Wire	Signal Name [Specification]
1	B	
2	R	
3	L	

Terminal No.	Color Of Wire	Signal Name [Specification]
1	B	
2	R	
3	L	

Terminal No.	Color Of Wire	Signal Name [Specification]
1	B	
2	R	
3	L	

Terminal No.	Color Of Wire	Signal Name [Specification]
1	B	
2	R	
3	L	

Terminal No.	Color Of Wire	Signal Name [Specification]
1	B	
2	R	
3	L	

Terminal No.	Color Of Wire	Signal Name [Specification]
1	W	
2	Y	
3	R	

Terminal No.	Color Of Wire	Signal Name [Specification]
1	B	
2	R	
3	L	

Terminal No.	Color Of Wire	Signal Name [Specification]
1	B	
2	R	
3	L	

Terminal No.	Color Of Wire	Signal Name [Specification]
1	B	
2	R	
3	L	

Terminal No.	Color Of Wire	Signal Name [Specification]
1	B	
2	R	
3	L	

Terminal No.	Color Of Wire	Signal Name [Specification]
1	B	
2	R	
3	L	

Terminal No.	Color Of Wire	Signal Name [Specification]
1	W	
2	Y	
3	R	

Terminal No.	Color Of Wire	Signal Name [Specification]
1	B	
2	R	
3	L	

Terminal No.	Color Of Wire	Signal Name [Specification]
1	B	
2	R	
3	L	

Terminal No.	Color Of Wire	Signal Name [Specification]
1	B	
2	R	
3	L	

Terminal No.	Color Of Wire	Signal Name [Specification]
1	B	
2	R	
3	L	

Terminal No.	Color Of Wire	Signal Name [Specification]
1	B	
2	R	
3	L	

Terminal No.	Color Of Wire	Signal Name [Specification]
1	W	
2	Y	
3	R	

Terminal No.	Color Of Wire	Signal Name [Specification]
1	B	
2	R	
3	L	

Terminal No.	Color Of Wire	Signal Name [Specification]
1	B	
2	R	
3	L	

Terminal No.	Color Of Wire	Signal Name [Specification]
1	B	
2	R	
3	L	

Terminal No.	Color Of Wire	Signal Name [Specification]
1	B	
2	R	
3	L	

Terminal No.	Color Of Wire	Signal Name [Specification]
1	B	
2	R	
3	L	

Terminal No.	Color Of Wire	Signal Name [Specification]
1	W	
2	Y	
3	R	

Terminal No.	Color Of Wire	Signal Name [Specification]
1	B	
2	R	
3	L	

Terminal No.	Color Of Wire	Signal Name [Specification]
1	B	
2	R	
3	L	

Terminal No.	Color Of Wire	Signal Name [Specification]
1	B	
2	R	
3	L	

Terminal No.	Color Of Wire	Signal Name [Specification]
1	B	
2	R	
3	L	

Terminal No.	Color Of Wire	Signal Name [Specification]
1	B	
2	R	
3	L	

Terminal No.	Color Of Wire	Signal Name [Specification]
1	W	
2	Y	
3	R	

Terminal No.	Color Of Wire	Signal Name [Specification]
1	B	
2	R	
3	L	

Terminal No.	Color Of Wire	Signal Name [Specification]
1	B	
2	R	
3	L	

Terminal No.	Color Of Wire	Signal Name [Specification]
1	B	
2	R	
3	L	

Terminal No.	Color Of Wire	Signal Name [Specification]
1	B	
2	R	
3	L	

Terminal No.	Color Of Wire	Signal Name [Specification]
1	B	
2	R	
3	L	

Terminal No.	Color Of Wire	Signal Name [Specification]
1	W	
2	Y	
3	R	

Terminal No.	Color Of Wire	Signal Name [Specification]
1	B	
2	R	
3	L	

Terminal No.	Color Of Wire	Signal Name [Specification]
1	B	
2	R	
3	L	

Terminal No.	Color Of Wire	Signal Name [Specification]
1	B	
2	R	
3	L	

Terminal No.	Color Of Wire	Signal Name [Specification]
1	B	
2	R	
3	L	

Terminal No.	Color Of Wire	Signal Name [Specification]
1	B	
2	R	
3	L	

Terminal No.	Color Of Wire	Signal Name [Specification]
1	W	
2	Y	
3	R	

Terminal No.	Color Of Wire	Signal Name [Specification]
1	B	
2	R	
3	L	

Terminal No.	Color Of Wire	Signal Name [Specification]
1	B	
2	R	
3	L	

Terminal No.	Color Of Wire	Signal Name [Specification]
1	B	
2	R	
3	L	

Terminal No.	Color Of Wire	Signal Name [Specification]
1	B	
2	R	
3	L	

Terminal No.	Color Of Wire	Signal Name [Specification]
1	B	
2	R	
3	L	

Terminal No.	Color Of Wire	Signal Name [Specification]
1	W	
2	Y	
3	R	

Terminal No.	Color Of Wire	Signal Name [Specification]
1	B	
2	R	
3	L	

Terminal No.	Color Of Wire	Signal Name [Specification]
1	B	
2	R	
3	L	

Terminal No.	Color Of Wire	Signal Name [Specification]
1	B	
2	R	
3	L	

Terminal No.	Color Of Wire	Signal Name [Specification]
1	B	
2	R	
3	L	

Terminal No.	Color Of Wire	Signal Name [Specification]
1	B	
2	R	
3	L	

Terminal No.	Color Of Wire	Signal Name [Specification]
1	W	
2	Y	
3	R	

Terminal No.	Color Of Wire	Signal Name [Specification]
1	B	
2	R	
3	L	

Terminal No.	Color Of Wire	Signal Name [Specification]
1	B	
2	R	
3	L	

Terminal No.	Color Of Wire	Signal Name [Specification]
1	B	
2	R	
3	L	

Terminal No.	Color Of Wire	Signal Name [Specification]
1	B	
2	R	
3	L	

Terminal No.	Color Of Wire	Signal Name [Specification]
1	B	
2	R	
3	L	

Terminal No.	Color Of Wire	Signal Name [Specification]
1	W	
2	Y	
3	R	

Terminal No.	Color Of Wire	Signal Name [Specification]
1	B	
2	R	
3	L	

Terminal No.	Color Of Wire	Signal Name [Specification]
1	B	
2	R	
3	L	

Terminal No.	Color Of Wire	Signal Name [Specification]
1	B	
2	R	
3	L	

Terminal No.	Color Of Wire	Signal Name [Specification]
1	B	
2	R	
3	L	

Terminal No.	Color Of Wire	Signal Name [Specification]
1	B	
2	R	
3	L	

Terminal No.	Color Of Wire	Signal Name [Specification]
1	W	
2	Y	
3	R	

Terminal No.	Color Of Wire	Signal Name [Specification]
1	B	
2	R	
3	L	

Terminal No.	Color Of Wire	Signal Name [Specification]
1	B	
2	R	
3	L	

Terminal No.	Color Of Wire	Signal Name [Specification]
1	B	
2	R	
3	L	

Terminal No.	Color Of Wire	Signal Name [Specification]
1	B	
2	R	
3	L	

Terminal No.	Color Of Wire	Signal Name [Specification]
1	B	
2	R	
3	L	

Terminal No.	Color Of Wire	Signal Name [Specification]
1	W	
2	Y	
3	R	

Terminal No.	Color Of Wire	Signal Name [Specification]
1	B	
2	R	
3	L	

Terminal No.	Color Of Wire	Signal Name [Specification]
1	B	
2	R	
3	L	


Terminal No.	Color Of Wire	Signal Name [Specification]
1	B	
2	R	
3	L	

TOTAL ILLUMINATION CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >


ILLUMINATION

Connector No.	M172
Connector Name	HEATED SEAT SWITCH (DRIVER SIDE)
Connector Type	TK10FW




Terminal No.	Color Of Wire	Signal Name [Specification]
1	GR	-
2	BR	-
3	R	-
4	R	-
5	Y	-
6	B	-

Connector No.	M173
Connector Name	HEATED SEAT SWITCH (PASSENGER SIDE)
Connector Type	TK08FBR




Terminal No.	Color Of Wire	Signal Name [Specification]
1	GR	-
2	BG	-
3	R	-
4	R	-
5	Y	-
6	B	-

Connector No.	M176
Connector Name	SNOW MODE SWITCH
Connector Type	TK08FW-L




Terminal No.	Color Of Wire	Signal Name [Specification]
1	BR	-
2	B	-
4	Y	-
5	R	-
6	GR	-

Connector No.	M177
Connector Name	CLIMATE CONTROLLED SEAT SWITCH (DRIVER SIDE)
Connector Type	TK10FW




Terminal No.	Color Of Wire	Signal Name [Specification]
1	BG	-
2	V	-
3	P	-
4	BR	-
5	GR	-
6	B	-
7	R	-
8	R	-

Connector No.	M178
Connector Name	CLIMATE CONTROLLED SEAT SWITCH (PASSENGER SIDE)
Connector Type	TK08FBR



Terminal No.	Color Of Wire	Signal Name [Specification]
1	P	-
2	G	-
3	I	-
4	BG	-
5	GR	-
6	B	-
7	R	-
8	R	-

Connector No.	M184
Connector Name	IBA OFF SWITCH
Connector Type	TK08FGY




Terminal No.	Color Of Wire	Signal Name [Specification]
4	Y	-
5	BG	-
6	B	-
7	SB	-

Connector No.	M201
Connector Name	AV CONTROL UNIT
Connector Type	TH18FW-CS2



Terminal No.	Color Of Wire	Signal Name [Specification]
6	P	STRG SW A
7	V	ACC
9	R	ILLUMINATION SIGNAL
15	B	STRG SW GND
16	L	STRG SW B
19	Y	BATTERY
20	B	GROUND

Connector No.	M202
Connector Name	AV CONTROL UNIT
Connector Type	TH24FW-NH



Terminal No.	Color Of Wire	Signal Name [Specification]
36	BG	SIGNAL VCC
37	LG	SIGNAL GND
38	R	HP
39	BR	COMM (DSP->CONT)
40	B	RGB AREA (YS) SIGNAL
41	SHIELD	SHIELD
42	G	RGB SYNC
43	B	RGB (RED) SIGNAL
44	W	RGB (GREEN) SIGNAL
45	R	RGB (BLUE) SIGNAL
46	BG	COMPOSITE IMAGE SIGNAL GND
47	SB	COMPOSITE IMAGE SIGNAL
48	Y	INVERTER VCC

TOTAL ILLUMINATION CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >

ILLUMINATION

49	BR	INVERTER GND
50	W	VP
51	Y	COMM (CONT->DISP)
52	SB	SHIELD
57	SHIELD	SHIELD

Connector No.	M210
Connector Name	AV CONTROL UNIT
Connector Type	TH32FW-NH



73	81	82	74	75	76	77	78	79	80	81	82	83	84	85	86	87	88	89	90	91	92
----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----

Terminal No.	Color Of Wire	Signal Name [Specification]
65	V	PARKING BRAKE SIGNAL
67	B	COMPOSITE IMAGE SIGNAL GND
68	R	COMPOSITE IMAGE SIGNAL
71	SHIELD	MICROPHONE SHIELD
72	G	MICROPHONE VCC
73	R	COMM (CONT->DISP)
74	P	CAN-L
75	LG	AV COMM (L)
76	LG	AV COMM (L)
79	R	ILLUMINATION
80	G	IGNITION SIGNAL
81	BG	REVERSE SIGNAL
82	R	VEHICLE SPEED SIGNAL (6-PULSE)
87	R	MICROPHONE SIGNAL
88	B	SHIELD
89	G	COMM (DISP->CONT)
90	L	CAN-H
91	SB	AV COMM (H)
92	SB	AV COMM (H)

Connector No.	M221
Connector Name	SHIFT POSITION SWITCH
Connector Type	TH12FW



6	5	4	3	2	1
11	10	9	7		

Terminal No.	Color Of Wire	Signal Name [Specification]
2	L	N
3	BR	D
4	G	R
5	P	P
6	V	M
7	O	AT
9	Y	MT
10	R	ILL
11	B	GROUND

Connector No.	M223
Connector Name	SELECTOR LEVER POSITION INDICATOR
Connector Type	XARP-09V



9	8	7	6	5	4	3	2	1
---	---	---	---	---	---	---	---	---

Terminal No.	Color Of Wire	Signal Name [Specification]
1	R	ILL
2	Y	MT
3	L	N
4	BR	D
5	G	R
6	V	M
7	P	P
8	O	AT
9	B	GROUND

Connector No.	M303
Connector Name	COMBINATION SWITCH (SPRNL CABLE)
Connector Type	TK08FGY



20	19	18	17	16	15	14	13
----	----	----	----	----	----	----	----

Terminal No.	Color Of Wire	Signal Name [Specification]
13	R	-
14	W	-
15	L	-
16	B	-
17	BR	-
18	G	-
19	P	-
20	Y	-

Connector No.	R1
Connector Name	WIRE TO WIRE
Connector Type	NH10FW-CST0



6	5	4		3	2	1
20	19	18	17	16	15	14
		13	12	11	10	9
						8
						7

Terminal No.	Color Of Wire	Signal Name [Specification]
1	V	-
2	BR	-
3	GR	-
4	SHIELD	-
5	G	-
6	BR	-
8	P	-
10	G	-
11	Y	-
12	BR	-
13	L	-
14	L	-

15	R	-
16	R	-
17	B	-
20	Y	-

Connector No.	R2
Connector Name	WIRE TO WIRE
Connector Type	TH24FW-NH



12	11	10	9	8	7	6	5	4	3	2	1
24	23	22	21	20	19	18	17	16	15	14	13

Terminal No.	Color Of Wire	Signal Name [Specification]
1	P	-
2	GR	-
8	SHIELD	-
9	R	-
10	G	-
11	B	-
12	V	-
17	Y	-
18	G	-
19	R	-
20	L	-
21	P	-
22	R	-
23	BR	-
24	B	-

TOTAL ILLUMINATION CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >

ILLUMINATION

Connector No.	R11
Connector Name	WIRE TO WIRE
Connector Type	TH24MV-NH



1	2	3	4	5	6	7	8	9	10	11	12
13	14	15	16	17	18	19	20	21	22	23	24

7	P	DOOR SIG L
8	B	GROUND
9	L	DOOR SIG R
10	V	BAT

Terminal No.	Color Of Wire	Signal Name [Specification]
1	LG	-
2	GR	-
8	SHIELD	-
9	-	-
10	R	-
11	B	-
12	V	-
17	Y	-
18	G	-
19	SB	-
20	P	-
21	L	-
22	R	-
23	BR	-
24	O	-



1	2	3
5	6	7
8	9	10

Connector No.	R15
Connector Name	MAP LAMP
Connector Type	TK10FW

Terminal No.	Color Of Wire	Signal Name [Specification]
1	BR	DOOR ON SIG
2	R	ALL ON SIG
3	B	GROUND
5	V	LED+
6	Y	LED-

JRLWD6081GB

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

BCM (BODY CONTROL MODULE)

Reference Value

INFOID:0000000011016162

VALUES ON THE DIAGNOSIS TOOL

NOTE:

The following table includes information (items) inapplicable to this vehicle. For information (items) applicable to this vehicle, refer to CONSULT display items.

CONSULT MONITOR ITEM

Monitor Item	Condition	Value/Status
FR WIPER HI	Other than front wiper switch HI	Off
	Front wiper switch HI	On
FR WIPER LOW	Other than front wiper switch LO	Off
	Front wiper switch LO	On
FR WASHER SW	Front washer switch OFF	Off
	Front washer switch ON	On
FR WIPER INT	Other than front wiper switch INT/AUTO	Off
	Front wiper switch INT/AUTO	On
FR WIPER STOP	Front wiper is not in STOP position	Off
	Front wiper is in STOP position	On
INT VOLUME	Wiper volume dial is in a dial position 1 - 7	Wiper volume dial position
RR WIPER ON	Other than rear wiper switch ON	Off
	Rear wiper switch ON	On
RR WIPER INT	Other than rear wiper switch INT	Off
	Rear wiper switch INT	On
RR WASHER SW	Rear washer switch OFF	Off
	Rear washer switch ON	On
RR WIPER STOP	Rear wiper is in STOP position	Off
	Rear wiper is not in STOP position	On
TURN SIGNAL R	Other than turn signal switch RH	Off
	Turn signal switch RH	On
TURN SIGNAL L	Other than turn signal switch LH	Off
	Turn signal switch LH	On
TAIL LAMP SW	Other than lighting switch 1ST and 2ND	Off
	Lighting switch 1ST or 2ND	On
HI BEAM SW	Other than lighting switch HI	Off
	Lighting switch HI	On
HEAD LAMP SW 1	Other than lighting switch 2ND	Off
	Lighting switch 2ND	On
HEAD LAMP SW 2	Other than lighting switch 2ND	Off
	Lighting switch 2ND	On
PASSING SW	Other than lighting switch PASS	Off
	Lighting switch PASS	On
AUTO LIGHT SW	Other than lighting switch AUTO	Off
	Lighting switch AUTO	On

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

Monitor Item	Condition	Value/Status
FR FOG SW	Front fog lamp switch OFF	Off
	Front fog lamp switch ON	On
RR FOG SW	NOTE: The item is indicated, but not monitored.	Off
DOOR SW-DR	Driver door closed	Off
	Driver door opened	On
DOOR SW-AS	Passenger door closed	Off
	Passenger door opened	On
DOOR SW-RR	Rear RH door closed	Off
	Rear RH door opened	On
DOOR SW-RL	Rear LH door closed	Off
	Rear LH door opened	On
DOOR SW-BK	Back door closed	Off
	Back door opened	On
CDL LOCK SW	Other than power door lock switch LOCK	Off
	Power door lock switch LOCK	On
CDL UNLOCK SW	Other than power door lock switch UNLOCK	Off
	Power door lock switch UNLOCK	On
KEY CYL LK-SW	Other than driver door key cylinder LOCK position	Off
	Driver door key cylinder LOCK position	On
KEY CYL UN-SW	Other than driver door key cylinder UNLOCK position	Off
	Driver door key cylinder UNLOCK position	On
KEY CYL SW-TR	NOTE: The item is indicated, but not monitored.	Off
HAZARD SW	Hazard switch is OFF	Off
	Hazard switch is ON	On
REAR DEF SW	NOTE: The item is indicated, but not monitored.	Off
TR CANCEL SW	NOTE: The item is indicated, but not monitored.	Off
TR/BD OPEN SW	Back door opener switch OFF	Off
	While the back door opener switch is turned ON	On
TRNK/HAT MNTR	NOTE: The item is indicated, but not monitored.	Off
REVERSE SW	NOTE: The item is indicated, but not monitored.	Off
RKE-LOCK	LOCK button of the Intelligent Key is not pressed	Off
	LOCK button of the Intelligent Key is pressed	On
RKE-UNLOCK	UNLOCK button of the Intelligent Key is not pressed	Off
	UNLOCK button of the Intelligent Key is pressed	On
RKE-TR/BD	NOTE: The item is indicated, but not monitored.	Off
RKE-PANIC	PANIC button of the Intelligent Key is not pressed	Off
	PANIC button of the Intelligent Key is pressed	On
RKE-P/W OPEN	UNLOCK button of the Intelligent Key is not pressed	Off
	UNLOCK button of the Intelligent Key is pressed and held	On

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

Monitor Item	Condition	Value/Status
RKE-MODE CHG	LOCK/UNLOCK button of the Intelligent Key is not pressed and held simultaneously	Off
	LOCK/UNLOCK button of the Intelligent Key is pressed and held simultaneously	On
OPTICAL SENSOR	Bright outside of the vehicle	Close to 5 V
	Dark outside of the vehicle	Close to 0 V
REQ SW -DR	Driver door request switch is not pressed	Off
	Driver door request switch is pressed	On
REQ SW -AS	Passenger door request switch is not pressed	Off
	Passenger door request switch is pressed	On
REQ SW -RR	NOTE: The item is indicated, but not monitored.	Off
REQ SW -RL	NOTE: The item is indicated, but not monitored.	Off
REQ SW -BD/TR	Back door request switch is not pressed	Off
	Back door request switch is pressed	On
PUSH SW	Push-button ignition switch (push switch) is not pressed	Off
	Push-button ignition switch (push switch) is pressed	On
IGN RLY2 -F/B	NOTE: The item is indicated, but not monitored.	Off
ACC RLY -F/B	NOTE: The item is indicated, but not monitored.	Off
CLUCH SW	NOTE: The item is indicated, but not monitored.	Off
BRAKE SW 1	The brake pedal is depressed when No. 7 fuse is blown	Off
	The brake pedal is not depressed when No. 7 fuse is blown, or No. 7 fuse is normal	On
BRAKE SW 2	The brake pedal is not depressed	Off
	The brake pedal is depressed	On
DETE/CANCL SW	Selector lever in P position	Off
	Selector lever in any position other than P	On
SFT PN/N SW	Selector lever in any position other than P and N	Off
	Selector lever in P or N position	On
S/L -LOCK	NOTE: The item is indicated but not monitored.	Off
S/L -UNLOCK	NOTE: The item is indicated but not monitored.	Off
S/L RELAY-F/B	NOTE: The item is indicated but not monitored.	Off
UNLK SEN -DR	Driver door is unlocked	Off
	Driver door is locked	On
PUSH SW -IPDM	Push-button ignition switch (push-switch) is not pressed	Off
	Push-button ignition switch (push-switch) is pressed	On
IGN RLY1 -F/B	Ignition switch in OFF or ACC position	Off
	Ignition switch in ON position	On
DETE SW -IPDM	Selector lever in any position other than P	Off
	Selector lever in P position	On
SFT PN -IPDM	Selector lever in any position other than P and N	Off
	Selector lever in P or N position	On

A

B

C

D

E

F

G

H

I

J

K

INL

M

N

O

P

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

Monitor Item	Condition	Value/Status
SFT P -MET	Selector lever in any position other than P	Off
	Selector lever in P position	On
SFT N -MET	Selector lever in any position other than N	Off
	Selector lever in N position	On
ENGINE STATE	Engine stopped	Stop
	While the engine stalls	Stall
	At engine cranking	Crank
	Engine running	Run
S/L LOCK-IPDM	NOTE: The item is indicated but not monitored.	Off
S/L UNLK-IPDM	NOTE: The item is indicated but not monitored.	Off
S/L RELAY-REQ	NOTE: The item is indicated but not monitored.	Off
VEH SPEED 1	While driving	Equivalent to speedometer reading
VEH SPEED 2	While driving	Equivalent to speedometer reading
DOOR STAT-DR	Driver door is locked	LOCK
	Wait with selective UNLOCK operation (5 seconds)	READY
	Driver door is unlocked	UNLOCK
DOOR STAT-AS	Passenger door is locked	LOCK
	Wait with selective UNLOCK operation (5 seconds)	READY
	Passenger door is unlocked	UNLOCK
ID OK FLAG	Driver side door is open after ignition switch is turned OFF (Selector lever is in the P position)	Reset
	Ignition switch ON	Set
PRMT ENG STRT	The engine start is prohibited	Reset
	The engine start is permitted	Set
PRMT RKE STRT	NOTE: The item is indicated, but not monitored.	Reset
KEY SW -SLOT	The Intelligent Key is not inserted into key slot	Off
	The Intelligent Key is inserted into key slot	On
RKE OPE COUN1	During the operation of the Intelligent Key	Operation frequency of the Intelligent Key
RKE OPE COUN2	NOTE: The item is indicated, but not monitored.	—
CONFIRM ID ALL	The key ID that the key slot receives is not recognized by any key ID registered to BCM.	Yet
	The key ID that the key slot receives accords with any key ID registered to BCM.	Done
CONFIRM ID4	The key ID that the key slot receives is not recognized by the fourth key ID registered to BCM.	Yet
	The key ID that the key slot receives is recognized by the fourth key ID registered to BCM.	Done
CONFIRM ID3	The key ID that the key slot receives is not recognized by the third key ID registered to BCM.	Yet
	The key ID that the key slot receives is recognized by the third key ID registered to BCM.	Done

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

Monitor Item	Condition	Value/Status
CONFIRM ID2	The key ID that the key slot receives is not recognized by the second key ID registered to BCM.	Yet
	The key ID that the key slot receives is recognized by the second key ID registered to BCM.	Done
CONFIRM ID1	The key ID that the key slot receives is not recognized by the first key ID registered to BCM.	Yet
	The key ID that the key slot receives is recognized by the first key ID registered to BCM.	Done
TP 4	The ID of fourth Intelligent Key is not registered to BCM	Yet
	The ID of fourth Intelligent Key is registered to BCM	Done
TP 3	The ID of third Intelligent Key is not registered to BCM	Yet
	The ID of third Intelligent Key is registered to BCM	Done
TP 2	The ID of second Intelligent Key is not registered to BCM	Yet
	The ID of second Intelligent Key is registered to BCM	Done
TP 1	The ID of first Intelligent Key is not registered to BCM	Yet
	The ID of first Intelligent Key is registered to BCM	Done

A

B

C

D

E

F

G

H

I

J

K

INL

M

N


O

P

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >


TERMINAL LAYOUT



PHYSICAL VALUES






BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)		Description		Condition		Value (Approx.)
+	-	Signal name	Input/ Output			
1 (W)	Ground	Battery power supply	Input	Ignition switch OFF		Battery voltage
2 (Y)	Ground	P/W power supply (BAT)	Output	Ignition switch OFF		12 V
3 (BG)	Ground	P/W power supply (IGN)	Output	Ignition switch ON		12 V
4 (P)	Ground	Interior room lamp power supply	Output	Interior room lamp battery saver is activated. (Cuts the interior room lamp power supply)		0 V
				Interior room lamp battery saver is not activated. (Outputs the interior room lamp power supply)		12 V
5 (V)	Ground	Passenger door UN- LOCK	Output	Passenger door	UNLOCK (Actuator is activated)	12 V
					Other than UNLOCK (Actuator is not activated)	0 V
7 (Y)	Ground	Step lamp control	Output	Step lamp	ON	0 V
					OFF	12 V
8 (V)	Ground	All doors, fuel lid LOCK	Output	All doors, fuel lid	LOCK (Actuator is activated)	12 V
					Other than LOCK (Actuator is not activated)	0 V
9 (G)	Ground	Driver door, fuel lid UNLOCK	Output	Driver door, fuel lid	UNLOCK (Actuator is activated)	12 V
					Other than UNLOCK (Actuator is not activated)	0 V
10 (BR)	Ground	Rear RH door and rear LH door UN- LOCK	Output	Rear RH door and rear LH door	UNLOCK (Actuator is activated)	12 V
					Other than UNLOCK (Actuator is not activated)	0 V
11 (R)	Ground	Battery power supply	Input	Ignition switch OFF		Battery voltage
13 (B)	Ground	Ground	—	Ignition switch ON		0 V
15 (Y)	Ground	ACC indicator lamp	Output	Ignition switch	OFF (LOCK indicator is not illuminated)	Battery voltage
					ACC or ON	0 V
17 (W)	Ground	Turn signal RH (Front)	Output	Ignition switch ON	Turn signal switch OFF	0 V
					Turn signal switch RH	

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)		Description		Condition		Value (Approx.)
+	-	Signal name	Input/ Output			
18 (BG)	Ground	Turn signal LH (Front)	Output	Ignition switch ON	Turn signal switch OFF	0 V
					Turn signal switch LH	 PKID0926E 6.5 V
19 (SB)	Ground	Interior room lamp control	Output	Other than under condition		5.0 V
				- Interior room lamp timer is activated. (Door is unlocked. etc...) - Welcome light function is activated.		0 V
20 (V)	Ground	Turn signal RH (Rear)	Output	Ignition switch ON	Turn signal switch OFF	0 V
					Turn signal switch RH	 PKID0926E 6.5 V
25 (G)	Ground	Turn signal LH (Rear)	Output	Ignition switch ON	Turn signal switch OFF	0 V
					Turn signal switch LH	 PKID0926E 6.5 V
26 (P)	Ground	Rear wiper	Output	Rear wiper	OFF (Stopped)	0 V
					ON (Operated)	12 V
34 (SB)	Ground	Luggage room anten- na (-)	Output	Ignition switch OFF	When Intelligent Key is in the passenger compart- ment	 JMKIA0062GB
					When Intelligent Key is not in the passenger com- partment	 JMKIA0063GB





BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)		Description		Condition		Value (Approx.)
+	-	Signal name	Input/ Output			
35 (V)	Ground	Luggage room antenna (+)	Output	Ignition switch OFF	When Intelligent Key is in the passenger compartment	
					When Intelligent Key is not in the passenger compartment	
38 (B)	Ground	Back door antenna (-)	Output	When the back door opener request switch is operated with ignition switch OFF	When Intelligent Key is in the antenna detection area	
					When Intelligent Key is not in the antenna detection area	
39 (W)	Ground	Back door antenna (+)	Output	When the back door opener request switch is operated with ignition switch OFF	When Intelligent Key is in the antenna detection area	
					When Intelligent Key is not in the antenna detection area	
47 (Y)	Ground	Ignition relay (IPDM E/R) control	Output	Ignition switch	OFF or ACC	12 V
					ON	0 V






BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)		Description		Condition		Value (Approx.)
+	-	Signal name	Input/ Output			
52 (LG)	Ground	Starter relay control	Output	Ignition switch ON	When selector lever is in P or N position	12 V
					When selector lever is not in P or N position	0 V
60 (SB)	Ground	Push-button ignition switch (Push switch)	Input	Push-button ig- nition switch (Push switch)	Pressed	0 V
					Not pressed	12 V
61 (W)	Ground	Back door opener re- quest switch	Input	Back door re- quest switch	ON (Pressed)	0 V
					OFF (Not pressed)	 JPMIA0016GB 1.0 V
64 (L)	Ground	Intelligent Key warn- ing buzzer (Engine room)	Output	Intelligent Key warning buzzer (Engine room)	Sounding	0 V
					Not sounding	12 V
65 (BG)	Ground	Rear wiper stop posi- tion	Input	Rear wiper	In stop position	 JPMIA0016GB 1.0 V
					Not in stop position	0 V
66 (LG)	Ground	Back door switch	Input	Back door switch	OFF (Door close)	12 V
					ON (Door open)	0 V
67 (P)	Ground	Back door opener switch	Input	Back door open- er switch	Pressed	0 V
					Not pressed	 JPMIA0594GB 8.5 - 9.0 V
68 (BR)	Ground	Rear RH door switch	Input	Rear RH door switch	OFF (Door close)	 JPMIA0594GB 8.5 - 9.0 V
					ON (Door open)	0 V







BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)		Description		Condition		Value (Approx.)
+	-	Signal name	Input/ Output			
69 (R)	Ground	Rear LH door switch	Input	Rear LH door switch	OFF (Door close)	 8.5 - 9.0 V
					ON (Door open)	0 V
74 (SB)	Ground	Passenger door antenna (-)	Output	When the passenger door request switch is operated with ignition switch OFF	When Intelligent Key is in the antenna detection area	 JMKIA0062GB
					When Intelligent Key is not in the antenna detection area	 JMKIA0063GB
75 (BR)	Ground	Passenger door antenna (+)	Output	When the passenger door request switch is operated with ignition switch OFF	When Intelligent Key is in the antenna detection area	 JMKIA0062GB
					When Intelligent Key is not in the antenna detection area	 JMKIA0063GB





BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)		Description		Condition		Value (Approx.)
+	-	Signal name	Input/ Output			
76 (V)	Ground	Driver door antenna (-)	Output	When the driver door request switch is operat- ed with ignition switch OFF	When Intelligent Key is in the antenna detection area	 JMKIA0062GB
					When Intelligent Key is not in the antenna detec- tion area	 JMKIA0063GB
77 (LG)	Ground	Driver door antenna (+)	Output	When the driver door request switch is operat- ed with ignition switch OFF	When Intelligent Key is in the antenna detection area	 JMKIA0062GB
					When Intelligent Key is not in the antenna detec- tion area	 JMKIA0063GB
78 (Y)	Ground	Room antenna (-) (Instrument panel)	Output	Ignition switch OFF	When Intelligent Key is in the passenger compart- ment	 JMKIA0062GB
					When Intelligent Key is not in the passenger compart- ment	 JMKIA0063GB





BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)		Description		Condition		Value (Approx.)
+	-	Signal name	Input/ Output			
79 (BR)	Ground	Room antenna (+) (Instrument panel)	Output	Ignition switch OFF	When Intelligent Key is in the passenger compart- ment	 JMKIA0062GB
					When Intelligent Key is not in the passenger compart- ment	 JMKIA0063GB
80 (GR)	Ground	NATS antenna amp.	Input/ Output	During waiting	Ignition switch is pressed while inserting the Intelli- gent Key into the key slot.	Just after pressing ignition switch. Pointer of tester should move.
81 (W)	Ground	NATS antenna amp.	Input/ Output	During waiting	Ignition switch is pressed while inserting the Intelli- gent Key into the key slot.	Just after pressing ignition switch. Pointer of tester should move.
82 (P)	Ground	Ignition relay [Fuse block (J/B)] control	Output	Ignition switch	OFF or ACC	0 V
					ON	12 V
83 (GR)	Ground	Remote keyless entry receiver communica- tion	Input/ Output	During waiting		 JMKIA0064GB
				When operating either button on the Intelli- gent Key		 JMKIA0065GB





BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)		Description		Condition	Value (Approx.)
+	-	Signal name	Input/ Output		
87 (BR)	Ground	Combination switch INPUT 5	Input	Combination switch	 1.4 V
				Front fog lamp switch ON (Wiper volume dial 4)	 1.3 V
				Rear wiper switch ON (Wiper volume dial 4)	 1.3 V
				Any of the conditions below with all switches OFF • Wiper volume dial 1 • Wiper volume dial 2 • Wiper volume dial 6 • Wiper volume dial 7	 1.3 V

BCM (BODY CONTROL MODULE)




< ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)		Description		Condition	Value (Approx.)
+	-	Signal name	Input/ Output		
88 (V)	Ground	Combination switch INPUT 3	Input	Combination switch	All switches OFF (Wiper volume dial 4)  1.4 V
					Lighting switch HI (Wiper volume dial 4)  1.3 V
					Lighting switch 2ND (Wiper volume dial 4)  1.3 V
					Rear washer switch ON (Wiper volume dial 4)  1.3 V
					Any of the conditions below with all switches OFF • Wiper volume dial 1 • Wiper volume dial 2 • Wiper volume dial 3  1.3 V
90 (P)	Ground	CAN-L	Input/ Output	—	—
91 (L)	Ground	CAN-H	Input/ Output	—	—

A
B
C
D
E
F
G
H
I
J
K
INL
M
N
O
P




BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)		Description		Condition		Value (Approx.)
+	-	Signal name	Input/ Output			
92 (LG)	Ground	Key slot illumination	Output	Key slot illumination	OFF	12 V
					Blinking	 JPMIA0015GB 6.5 V
					ON	0 V
93 (V)	Ground	ON indicator lamp	Output	Ignition switch	OFF (LOCK indicator is not illuminated)	Battery voltage
					ON or ACC	0 V
95 (BG)	Ground	ACC relay control	Output	Ignition switch	OFF	0 V
					ACC or ON	12 V
96 (GR)	Ground	A/T shift selector (Detention switch) power supply	Output	—	—	12 V
99 (R)	Ground	Selector lever P position switch	Input	Selector lever	P position	0 V
					Any position other than P	12 V
100 (G)	Ground	Passenger door request switch	Input	Passenger door request switch	ON (Pressed)	0 V
					OFF (Not pressed)	 JPMIA0016GB 1.0 V
101 (SB)	Ground	Driver door request switch	Input	Driver door request switch	ON (Pressed)	0 V
					OFF (Not pressed)	 JPMIA0016GB 1.0 V
102 (BG)	Ground	Blower fan motor relay control	Output	Ignition switch	OFF or ACC	0 V
					ON	12 V
103 (BR)	Ground	Remote keyless entry receiver power supply	Output	Ignition switch OFF	—	12 V

BCM (BODY CONTROL MODULE)




< ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)		Description		Condition	Value (Approx.)
+	-	Signal name	Input/ Output		
107 (LG)	Ground	Combination switch INPUT 1	Input	Combination switch (Wiper volume dial 4)	All switches OFF  JPMIA0041GB 1.4 V
					Turn signal switch LH  JPMIA0037GB 1.3 V
					Turn signal switch RH  JPMIA0036GB 1.3 V
					Front wiper switch LO  JPMIA0038GB 1.3 V
					Front washer switch ON  JPMIA0039GB 1.3 V

A
B
C
D
E
F
G
H
I
J
K
INL
M
N
O
P





BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)		Description		Condition	Value (Approx.)
+	-	Signal name	Input/ Output		
108 (R)	Ground	Combination switch INPUT 4	Input	Combination switch	 1.4 V
				Lighting switch AUTO (Wiper volume dial 4)	 1.3 V
				Lighting switch 1ST (Wiper volume dial 4)	 1.3 V
				Rear wiper switch INT (Wiper volume dial 4)	 1.3 V
				Any of the conditions below with all switches OFF - Wiper volume dial 1 - Wiper volume dial 5 - Wiper volume dial 6	 1.3 V

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)		Description		Condition	Value (Approx.)
+	-	Signal name	Input/ Output		
109 (Y)	Ground	Combination switch INPUT 2	Input	Combination switch (Wiper volume dial 4)	All switches OFF  JPMIA0041GB 1.4 V
					Lighting switch PASS  JPMIA0037GB 1.3 V
					Lighting switch 2ND  JPMIA0036GB 1.3 V
					Front wiper switch INT/ AUTO  JPMIA0038GB 1.3 V
					Front wiper switch HI  JPMIA0040GB 1.3 V
					ON 0 V
110 (G)	Ground	Hazard switch	Input	Hazard switch	OFF  JPMIA0012GB 1.1 V

A

B

C

D

E

F

G

H

I

J

K

INL

M




N

O

P





BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)		Description		Condition		Value (Approx.)
+	−	Signal name	Input/ Output			
112 (GR)	Ground	Rain sensor serial link	Input/ Output	Ignition switch ON		 8.7 V
113 (P)	Ground	Optical sensor	Input	Ignition switch ON	When bright outside of the vehicle	Close to 5 V
					When dark outside of the vehicle	Close to 0 V
116 (BR)	Ground	Stop lamp switch 1	Input	—		Battery voltage
118 (P)	Ground	Stop lamp switch 2 (Without ICC)	Input	Stop lamp switch	OFF (Brake pedal is not depressed)	0 V
					ON (Brake pedal is depressed)	Battery voltage
		Stop lamp switch 2 (With ICC)	Input	Stop lamp switch OFF (Brake pedal is not depressed) and ICC brake hold relay OFF		0 V
				Stop lamp switch ON (Brake pedal is depressed) or ICC brake hold relay ON		Battery voltage
119 (SB)	Ground	Front door lock assembly driver side (Unlock sensor)	Input	Driver door	LOCK status (Unlock sensor switch OFF)	 8.5 - 9.0 V
					UNLOCK status (Unlock switch sensor ON)	0 V
121 (BR)	Ground	Key slot switch	Input	When the Intelligent Key is inserted into key slot		12 V
				When the Intelligent Key is not inserted into key slot		0 V
123 (W)	Ground	IGN feedback	Input	Ignition switch	OFF or ACC	0 V
					ON	Battery voltage
124 (LG)	Ground	Passenger door switch	Input	Passenger door switch	OFF (Door close)	 8.5 - 9.0 V
					ON (Door open)	0 V





BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)		Description		Condition		Value (Approx.)	
+	−	Signal name	Input/ Output				
132 (BG)	Ground	Power window switch communication	Input/ Output	Ignition switch ON		 10.2 V	
				Ignition switch OFF or ACC		12 V	
134 (GR)	Ground	LOCK indicator lamp	Output	LOCK indicator lamp	OFF	Battery voltage	
					ON	0 V	
137 (B)	Ground	Receiver and sensor ground	Input	Ignition switch ON		0 V	
138 (Y)	Ground	Sensor power supply	Output	Ignition switch	OFF	0 V	
					ACC or ON	5.0 V	
140 (R)	Ground	Selector lever P/N position	Input	Selector lever	P or N position	12 V	
					Except P and N positions	0 V	
141 (G)	Ground	Security indicator lamp	Output		ON	0 V	
				Security indica- tor lamp	Blinking	 11.3 V	
					OFF	12 V	
142 (BG)	Ground	Combination switch OUTPUT 5	Output		All switches OFF	0 V	
				Combination switch (Wiper volume dial 4)	Lighting switch 1ST	 10.7 V	
					Lighting switch HI		
					Lighting switch 2ND		
					Turn signal switch RH		
143 (P)	Ground	Combination switch OUTPUT 1	Output	Combination switch	All switches OFF (Wiper volume dial 4)	0 V	
					Front wiper switch HI (Wiper volume dial 4)	 10.7 V	
					Rear wiper switch INT (Wiper volume dial 4)		
					Any of the conditions be- low with all switches OFF		
					• Wiper volume dial 1 • Wiper volume dial 2 • Wiper volume dial 3 • Wiper volume dial 6 • Wiper volume dial 7		

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >


Terminal No. (Wire color)		Description		Condition		Value (Approx.)
+	-	Signal name	Input/ Output			
144 (G)	Ground	Combination switch OUTPUT 2	Output	Combination switch	All switches OFF (Wiper volume dial 4)	0 V
					Front washer switch ON (Wiper volume dial 4)	
					Rear wiper switch ON (Wiper volume dial 4)	
					Rear washer switch ON (Wiper volume dial 4)	
					Any of the conditions below with all switches OFF • Wiper volume dial 1 • Wiper volume dial 5 • Wiper volume dial 6	10.7 V
145 (L)	Ground	Combination switch OUTPUT 3	Output	Combination switch (Wiper volume dial 4)	All switches OFF	0 V
					Front wiper switch INT/ AUTO	
					Front wiper switch LO	
					Lighting switch AUTO	
146 (SB)	Ground	Combination switch OUTPUT 4	Output	Combination switch (Wiper volume dial 4)	All switches OFF	0 V
					Front fog lamp switch ON	
					Lighting switch 2ND	
					Lighting switch PASS	
					Turn signal switch LH	
150 (GR)	Ground	Driver door switch	Input	Driver door switch	OFF (Door close)	 8.5 - 9.0 V
					ON (Door open)	0 V
151 (G)	Ground	Rear window defog- ger relay control	Output	Rear window de- fogger	Active	0 V
					Not activated	Battery voltage

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

Wiring Diagram - BCM -

INFOID:0000000011016163




2014/03/18

JRMWF4484GB

A
B
C
D
E
F
G
H
I
J
K
INL
M
N
O
P

BCM (BODY CONTROL MODULE)


< ECU DIAGNOSIS INFORMATION >



JRMWF4485GB

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >




JRMWF4486GB

A
B
C
D
E
F
G
H
I
J
K
INL
M
N
O
P

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >


IC : With ICC
OI : Without ICC



JRMWF4487GB

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >



JRMWF4488GB


A
B
C
D
E
F
G
H
I
J
K
INL
M
N
O
P

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

BCM (BODY CONTROL MODULE)


Terminal No.	Wire	Signal Name [Specification]
1	GR	FRONT DOOR SWITCH (DRIVER SIDE)
2	GR	FRONT DOOR SWITCH (DRIVER SIDE)



Connector No.	Wire	Signal Name [Specification]
B16	GR	FRONT DOOR SWITCH (DRIVER SIDE)
A03FW	GR	FRONT DOOR SWITCH (DRIVER SIDE)

Terminal No.	Wire	Signal Name [Specification]
2	GR	FRONT DOOR SWITCH (DRIVER SIDE)

Connector No.	Wire	Signal Name [Specification]
B23	GR	REAR DOOR SWITCH LH
A03FW	GR	REAR DOOR SWITCH LH




Terminal No.	Wire	Signal Name [Specification]
2	W	REAR DOOR SWITCH LH

Connector No.	Wire	Signal Name [Specification]
B47	DIODE	DIODE
A03FW	DIODE	DIODE




Terminal No.	Wire	Signal Name [Specification]
1	GR	REAR DOOR SWITCH RH
2	V	REAR DOOR SWITCH RH



Connector No.	Wire	Signal Name [Specification]
B223	GR	REAR DOOR SWITCH RH
A03FW	GR	REAR DOOR SWITCH RH

Terminal No.	Wire	Signal Name [Specification]
2	GR	REAR DOOR SWITCH RH

Connector No.	Wire	Signal Name [Specification]
B228	GR	INSIDE KEY ANTENNA (LUGGAGE ROOM)
A03FW	GR	INSIDE KEY ANTENNA (LUGGAGE ROOM)




Terminal No.	Wire	Signal Name [Specification]
1	R	INSIDE KEY ANTENNA (LUGGAGE ROOM)
2	LG	INSIDE KEY ANTENNA (LUGGAGE ROOM)
3	G	INSIDE KEY ANTENNA (LUGGAGE ROOM)
4	B	INSIDE KEY ANTENNA (LUGGAGE ROOM)

Connector No.	Wire	Signal Name [Specification]
B216	GR	FRONT DOOR SWITCH (PASSENGER SIDE)
A03FW	GR	FRONT DOOR SWITCH (PASSENGER SIDE)

Terminal No.	Wire	Signal Name [Specification]
2	GR	FRONT DOOR SWITCH (PASSENGER SIDE)

Terminal No.	Wire	Signal Name [Specification]
1	P	REAR COMBINATION LAMP RH
2	LG	REAR COMBINATION LAMP RH
3	V	REAR COMBINATION LAMP RH
4	B	REAR COMBINATION LAMP RH



Connector No.	Wire	Signal Name [Specification]
B229	P	REAR COMBINATION LAMP RH
A03FW	P	REAR COMBINATION LAMP RH


Terminal No.	Wire	Signal Name [Specification]
2	BG	REAR COMBINATION LAMP RH

Connector No.	Wire	Signal Name [Specification]
B222	GR	REAR COMBINATION LAMP RH
A03FW	GR	REAR COMBINATION LAMP RH



Terminal No.	Wire	Signal Name [Specification]
1	P	REAR COMBINATION LAMP RH
2	LG	REAR COMBINATION LAMP RH
3	V	REAR COMBINATION LAMP RH
4	B	REAR COMBINATION LAMP RH

Terminal No.	Wire	Signal Name [Specification]
1	P	REAR COMBINATION LAMP RH
2	LG	REAR COMBINATION LAMP RH
3	V	REAR COMBINATION LAMP RH
4	B	REAR COMBINATION LAMP RH



Terminal No.	Wire	Signal Name [Specification]
1	W	REAR COMBINATION LAMP RH
2	L	REAR COMBINATION LAMP RH

Connector No.	Wire	Signal Name [Specification]
B222	GR	REAR COMBINATION LAMP RH
A03FW	GR	REAR COMBINATION LAMP RH



Terminal No.	Wire	Signal Name [Specification]
1	P	REAR COMBINATION LAMP RH
2	LG	REAR COMBINATION LAMP RH
3	V	REAR COMBINATION LAMP RH
4	B	REAR COMBINATION LAMP RH

JRMWF4489GB

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

BCM (BODY CONTROL MODULE)

Connector No.	B242
Connector Name	FUEL LID LOCK ACTUATOR
Connector Type	MD4FW-LC




Terminal No.	Color Of Wire	Signal Name [Specification]
1	W	-
2	V	-

Connector No.	B249
Connector Name	BRAKE BOOSTER CONTROL UNIT
Connector Type	TK2AFGY




Terminal No.	Color Of Wire	Signal Name [Specification]
33	G	IGNITION
40	SB	IBA OFF SW
42	G	IGNITION
46	B	GROUND
47	LG	BRAKE HOLD RLY DRIVE SIGNAL

Connector No.	B414
Connector Name	POWER SEAT SWITCH
Connector Type	NS10FW-CS



Terminal No.	Color Of Wire	Signal Name [Specification]
3	GY	-
4	P	-
5	W	-
6	V	-
7	LY	-
8	L	-
9	L/R	-
10	GW	-
33	R	-
48	B	-


Connector No.	B451
Connector Name	DRIVER SEAT CONTROL UNIT
Connector Type	TH32FW



Terminal No.	Color Of Wire	Signal Name [Specification]
1	LW	RX
3	RY	CANH
9	W/G	PULSE (RECLINING)
10	P/B	PULSE (RR LIFTING)
11	BR	SLIDING SW (BACKWARD)
12	SB	RECLINING SW (BACKWARD)
13	LG/R	FRONT LIFTING SW (DOWNWARD)
14	GB	REAR LIFTING SW (DOWNWARD)
16	O	VCC
17	Y/R	TX


19	V	CAN-L
21	LY	P RANGE SW
24	R	PULSE (SLIDING)
25	Y/B	PULSE (RR LIFTING)
26	Y	SLIDING SW (FORWARD)
27	R/G	RECLINING SW (FORWARD)
28	W/B	FRONT LIFTING SW (UPWARD)
29	P/L	REAR LIFTING SW (UPWARD)
31	GR	SENSOR GND
32	B/W	GND (SIGNAL)

Connector No.	B457
Connector Name	LUMBAR SUPPORT SWITCH
Connector Type	NS04FW-CS



Terminal No.	Color Of Wire	Signal Name [Specification]
33	R	-
48	B	-
57	W	-
58	L	-


Connector No.	D8
Connector Name	POWER WINDOW MAIN SWITCH
Connector Type	NS16FW-CS



Terminal No.	Color Of Wire	Signal Name [Specification]
1	W	-
2	LG	-
3	GR	-
4	V	-


5	SB	-
6	Y	-
7	BR	-
8	L	-
9	W	-
10	O	-
11	G	-
13	P	-
14	V	-
15	W	-

Connector No.	D9
Connector Name	POWER WINDOW MAIN SWITCH
Connector Type	NS03FW-CS



Terminal No.	Color Of Wire	Signal Name [Specification]
17	B	-
19	Y	-

Connector No.	D12
Connector Name	STEP LAMP (DRIVER SIDE)
Connector Type	TB02FW



Terminal No.	Color Of Wire	Signal Name [Specification]
1	LG	-
2	SB	-

JRMWF4490GB

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

BCM (BODY CONTROL MODULE)

Connector No.	D13
Connector Name	FRONT OUTSIDE HANDLE LH (REQUEST SWITCH)
Connector Type	RK02FL-B




Terminal No.	Color Of Wire	Signal Name [Specification]
1	G	-
2	B	-

Connector No.	D14
Connector Name	FRONT OUTSIDE HANDLE LH (OUTSIDE KEY ANTENNA)
Connector Type	RK02MGY




Terminal No.	Color Of Wire	Signal Name [Specification]
1	P	-
2	V	-

Connector No.	D15
Connector Name	FRONT DOOR LOCK ASSEMBLY (DRIVER SIDE)
Connector Type	E06FGY-RS



Terminal No.	Color Of Wire	Signal Name [Specification]
1	LG	-
2	R	-
3	G	-
4	B	-
5	V	-
6	V	-

Connector No.	D38
Connector Name	FRONT POWER WINDOW SWITCH (PASSENGER SIDE)
Connector Type	NS16FW-CS



Terminal No.	Color Of Wire	Signal Name [Specification]
3	LG	-
4	W	-
8	L	-
9	G	-
10	Y	-
11	B	-
12	P	-
15	R	-
16	V	-

Connector No.	D42
Connector Name	STEP LAMP (PASSENGER SIDE)
Connector Type	TB02FW



Terminal No.	Color Of Wire	Signal Name [Specification]
1	SB	-
2	R	-

Connector No.	D43
Connector Name	FRONT OUTSIDE HANDLE RH (REQUEST SWITCH)
Connector Type	RK02FL-B




Terminal No.	Color Of Wire	Signal Name [Specification]
1	G	-
2	B	-

Connector No.	D44
Connector Name	FRONT OUTSIDE HANDLE RH (OUTSIDE KEY ANTENNA)
Connector Type	RK02MGY



Terminal No.	Color Of Wire	Signal Name [Specification]
1	P	-
2	W	-

Connector No.	D45
Connector Name	FRONT DOOR LOCK ASSEMBLY (PASSENGER SIDE)
Connector Type	E06FGY-RS



Terminal No.	Color Of Wire	Signal Name [Specification]
1	R	-
2	LG	-

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

BCM (BODY CONTROL MODULE)

Connector No.	D54
Connector Name	REAR POWER WINDOW SWITCH LH
Connector Type	NS08FW-CS



Terminal No.	Color Of Wire	Signal Name [Specification]
1	W	-
2	L	-
3	R	-
4	L	-
5	G	-
6	B	-
7	B	-

Connector No.	D55
Connector Name	REAR DOOR LOCK ASSEMBLY LH
Connector Type	E06FGY-RS



Terminal No.	Color Of Wire	Signal Name [Specification]
1	V	-
2	G	-

Connector No.	D59
Connector Name	STEP LAMP (REAR LH)
Connector Type	TB02FW



Terminal No.	Color Of Wire	Signal Name [Specification]
1	L	-
2	O	-

Connector No.	D74
Connector Name	REAR POWER WINDOW SWITCH RH
Connector Type	NS08FW-CS



Terminal No.	Color Of Wire	Signal Name [Specification]
1	W	-
2	P	-
3	R	-
4	L	-
5	G	-
6	B	-
7	B	-

Connector No.	D75
Connector Name	REAR DOOR LOCK ASSEMBLY RH
Connector Type	E06FGY-RS



Terminal No.	Color Of Wire	Signal Name [Specification]
1	G	-
2	L	-

Connector No.	D79
Connector Name	STEP LAMP (REAR RH)
Connector Type	TB02FW



Terminal No.	Color Of Wire	Signal Name [Specification]
1	L	-
2	O	-

Connector No.	D107
Connector Name	BACK DOOR LOCK ASSEMBLY
Connector Type	NS08FW-CS



Terminal No.	Color Of Wire	Signal Name [Specification]
1	LW	-
2	LB	-
3	G	-
4	L	-
5	W	-
6	LG	-
7	GR	-
8	GR	-

Connector No.	D110
Connector Name	LUGGAGE ROOM LAMP (BACK DOOR SIDE)
Connector Type	TK03FW



Terminal No.	Color Of Wire	Signal Name [Specification]
1	GR	-
2	L	-

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

BCM (BODY CONTROL MODULE)

Connector No.	D114
Connector Name	BACK DOOR OPENER SWITCH
Connector Type	TK02MBR-P



Terminal No.	Color Of Wire	Signal Name [Specification]
1	W	-
2	B	-

Connector No.	D115
Connector Name	REAR WIPER MOTOR
Connector Type	CJ04FM-IV



Terminal No.	Color Of Wire	Signal Name [Specification]
2	G	-
3	BG	-
4	B	-

Connector No.	D116
Connector Name	BACK DOOR OPENER REQUEST SWITCH
Connector Type	TK02MBR-P



Terminal No.	Color Of Wire	Signal Name [Specification]
1	V	-
2	B	-

Connector No.	D118
Connector Name	OUTSIDE KEY ANTENNA (BACK DOOR)
Connector Type	RG02EGY




Terminal No.	Color Of Wire	Signal Name [Specification]
1	BR	-
2	R	-

Connector No.	E5
Connector Name	IPDM/ER INTELLIGENT POWER DISTRIBUTION MODULE (ENGINE ROOM)
Connector Type	TH02FM-LCS12-M4-1V



Terminal No.	Color Of Wire	Signal Name [Specification]
4	V	-
5	L	-
7	R	-
10	SB	-
12	B	-
13	Y	-
16	LG	-
19	W	-
25	G	-
26	R	-
27	Y	-
28	BG	-
30	GR	-
36	G	-

Connector No.	E6
Connector Name	IPDM/ER INTELLIGENT POWER DISTRIBUTION MODULE (ENGINE ROOM)
Connector Type	TH08FM-AH



Terminal No.	Color Of Wire	Signal Name [Specification]
39	P	-
40	L	-
41	B	-
42	Y	-
43	SB	-
44	W	-


45	G
46	BR

Connector No.	E28
Connector Name	FRONT COMBINATION LAMP RH
Connector Type	RS04FB-PR



Terminal No.	Color Of Wire	Signal Name [Specification]
1	BR	-
2	V	-
3	B	-
4	P	-

Connector No.	E41
Connector Name	ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)
Connector Type	BAA42FB-AH24-LH



Terminal No.	Color Of Wire	Signal Name [Specification]
1	B	GROUND
2	G	LBWR
3	R	LBVR
4	B	GROUND
5	Y	DS FL
6	BG	DP RL
7	BR	DP BR
9	B	DP FR
10	W	DS FR
12	L	VAC
14	P	CANL
15	SHIELD	AGND

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

BCM (BODY CONTROL MODULE)

Connector No.	Signal Name [Specification]
19 P	UST
25 Y	BUS-L
26 R	DP FL
27 GR	DS RL
28 G	UZ
29 LG	DS RR
30 SB	BLS
31 R	VDC OFF SW
35 L	CANH
45 B	BUS-H

Connector No.	Signal Name [Specification]
E58	FRONT COMBINATION LAMP LH
ES04EB-FR	



Terminal No.	Color Of Wire	Signal Name [Specification]
1	Y	-
2	G	-
3	B	-
4	BG	-

Connector No.	Signal Name [Specification]
E80	INTELLIGENT KEY WARNING BUZZER (BUZZER ROOM)
RK03FBR	




Terminal No.	Color Of Wire	Signal Name [Specification]
1	LG	+BAT (VOL SMALL)
3	GR	BUZZER SIGNAL

Connector No.	Signal Name [Specification]
E91	ICC BRAKE HOLD RELAY
M06FGY-R-US	




Terminal No.	Color Of Wire	Signal Name [Specification]
1	L	-
2	B	-
3	G	-
4	G	-
6	W	-
7	L	-

Connector No.	Signal Name [Specification]
E103	FUSE BLOCK (J/B)
NS16FW-CS	




Terminal No.	Color Of Wire	Signal Name [Specification]
10F	L	-
2F	SB	-
3F	W	-
4F	Y	-
6F	BG	-
8F	L	-
9F	R	-

Connector No.	Signal Name [Specification]
E110	STOP LAMP SWITCH
M04FW-LC	




Terminal No.	Color Of Wire	Signal Name [Specification]
1	L	-
2	W	-
3	G	-
4	BR	-

Connector No.	Signal Name [Specification]
F51	AT ASSEMBLY
RK10FG-DGY	




Terminal No.	Color Of Wire	Signal Name [Specification]
1	Y	IGNITION POWER SUPPLY
2	R	BATTERY POWER SUPPLY (MEMORY BACKUP)
3	L	CANH
4	V	K-LINE
5	B	GROUND
6	Y	IGNITION POWER SUPPLY
7	R	BACK-UP LAMP RELAY
8	P	CANH
9	GR	STARTER RELAY (With VQ engine)
9	LG	STARTER RELAY (With VK engine)
10	B	GROUND

Connector No.	Signal Name [Specification]
F151	TCM
SP10FG	



Terminal No.	Color Of Wire	Signal Name [Specification]
1	W	IGNITION POWER SUPPLY
2	B	BATTERY POWER SUPPLY (MEMORY BACKUP)
3	R	CANH
4	O	K-LINE
5	G	GROUND
6	GR	IGNITION POWER SUPPLY
7	L	BACK-UP LAMP RELAY
8	BR	CANH
9	Y	STARTER RELAY
10	W/B	GROUND

Connector No.	Signal Name [Specification]
M1	FUSE BLOCK (J/B)
NS08FM-M2	



Terminal No.	Color Of Wire	Signal Name [Specification]
1A	BG	-
2A	G	-
3A	L	-
4A	R	-
5A	V	-
6A	Y	-
7A	R	-
8A	L	-

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

BCM (BODY CONTROL MODULE)

Connector No.	M2
Connector Name	FUSE BLOCK (J/B)
Connector Type	NS10FW-CS




Terminal No.	Color Of Wire	Signal Name [Specification]
1B	LG	-
3B	P	-
4B	G	-
5B	BG	-
6B	Y	-
7B	L	-
8B	R	-
9B	BR	-

Connector No.	M3
Connector Name	FUSE BLOCK (J/B)
Connector Type	NS12FW-CS



Terminal No.	Color Of Wire	Signal Name [Specification]
10C	L	-
11C	LG	-
12C	R	-
6C	P	-
7C	B	-
9C	BG	-

Connector No.	M22
Connector Name	KEY SLOT
Connector Type	TH12FW-AH



Terminal No.	Color Of Wire	Signal Name [Specification]
1	R	BAT
2	GR	CLOCK
3	W	DATA
4	Y	ILL BAT
5	LG	ILL
6	L	GROUND
7	B	KEY SWITCH SIGNAL
11	BR	-

Connector No.	M24
Connector Name	DATA LINK CONNECTOR
Connector Type	BD16FW




Terminal No.	Color Of Wire	Signal Name [Specification]
3	LG	-
4	B	-
5	B	-
6	L	-
7	GR	-
8	G	-
11	SB	-
12	P	-
13	L	-
14	P	-
16	BG	-

Connector No.	M33
Connector Name	COMBINATION SWITCH
Connector Type	TH16FW-AH



Terminal No.	Color Of Wire	Signal Name [Specification]
1	P	FR WASHER (-)
2	SB	OUTPUT 4
3	BG	FR WASHER (+)
4	G	IGN
5	L	OUTPUT 3
6	B	GROUND
7	V	INPUT 3
8	BG	OUTPUT 5
9	Y	INPUT 2
10	R	INPUT 4
11	LG	INPUT 1
12	P	OUTPUT 1
13	BR	INPUT 5
14	G	OUTPUT 2


Connector No.	M50
Connector Name	PUSH-BUTTON IGNITION SWITCH
Connector Type	TK08FBR



Terminal No.	Color Of Wire	Signal Name [Specification]
1	B	-
2	R	-
3	BG	-
4	SB	-
5	GR	-
6	Y	-

7	V
8	P

Connector No.	M53
Connector Name	COMBINATION METER
Connector Type	TH40FW-AH




Terminal No.	Color Of Wire	Signal Name [Specification]
1	BG	BATTERY POWER SUPPLY
2	LG	COMMUNICATION SIGNAL (METER->AMP)
3	GR	COMMUNICATION SIGNAL (AMP->METER)
4	B	GROUND
5	W	ALTERNATOR SIGNAL
6	P	AIR BAG SIGNAL
7	G	SECURITY INDICATOR SIGNAL
15	B	GROUND
16	B	METER CONTROL SWITCH GROUND
21	R	IGNITION SIGNAL
24	BR	COMMUNICATION SIGNAL (LCD->AMP)
25	Y	COMMUNICATION SIGNAL (AMP->LCD)
26	R	VEHICLE SPEED SIGNAL (8-PULSE)
27	V	PARKING BRAKE SWITCH SIGNAL
28	W	BRAKE FLUID LEVEL SWITCH SIGNAL
29	SB	SEAT BELT BUCKLE SWITCH SIGNAL (DRIVER SIDE)
30	G	PASSENGER SEAT BELT WARNING SIGNAL
31	L	WASHER LEVEL SWITCH SIGNAL
34	B	ILLUMINATION CONTROL SIGNAL
36	LG	SELECT SWITCH SIGNAL
37	SB	ENTER SWITCH SIGNAL
38	L	TRIP AB RESET SWITCH SIGNAL
39	P	ILLUMINATION CONTROL SWITCH SIGNAL (-)
40	BG	ILLUMINATION CONTROL SWITCH SIGNAL (+)

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >


BCM (BODY CONTROL MODULE)

Connector No.	M67
Connector Name	UNIFIED METER AND A/C AMP.
Connector Type	TH32FM-NH




Terminal No.	Color Of Wire	Signal Name [Specification]
41	V	ACC POWER SUPPLY
42	Y	FUEL LEVEL SENSOR SIGNAL
43	R	INTAKE SENSOR SIGNAL
44	LG	IN-VEHICLE SENSOR SIGNAL
45	P	AMBIENT SENSOR SIGNAL
46	BG	SUNLOAD SENSOR SIGNAL
47	V	GAS SENSOR SIGNAL
53	G	IGNITION POWER SUPPLY
54	BG	BATTERY POWER SUPPLY
55	B	GROUND
56	L	CANH
57	W	BRAKE FLUID LEVEL SWITCH SIGNAL
58	B	FUEL LEVEL SENSOR GROUND
59	GR	INTAKE SENSOR GROUND
60	L	IN-VEHICLE SENSOR GROUND
61	BR	AMBIENT SENSOR GROUND
62	SB	SUNLOAD SENSOR GROUND
63	R	ION MODE SIGNAL
65	BG	ECV SIGNAL
69	L	A/C LAN SIGNAL
70	R	EACH DOOR MOTOR POWER SUPPLY
71	B	GROUND
72	P	CANH

Connector No.	M72
Connector Name	MULTIFUNCTION SWITCH
Connector Type	TH16FM-NH



Terminal No.	Color Of Wire	Signal Name [Specification]
1	B	GROUND
3	V	ACC
4	R	ILL
5	R	ILL CONT
6	SB	AV COMM (H)
8	LG	AV COMM (L)
9	BR	SW GND
14	SB	DISK EJECT SIGNAL
16	G	HAZARD ON

Connector No.	M79
Connector Name	ACCESSORY RELAY (2)
Connector Type	MS02FL-M2-LC




Terminal No.	Color Of Wire	Signal Name [Specification]
1	G	-
2	B	-
3	LG	-
5	L	-

Connector No.	M94
Connector Name	OPTICAL SENSOR
Connector Type	TK03FW



Terminal No.	Color Of Wire	Signal Name [Specification]
1	Y	POWER
2	P	OUTPUT
3	B	GROUND

Connector No.	M96
Connector Name	LOW TIRE PRESSURE WARNING CONTROL UNIT
Connector Type	TH02FM-NH



Terminal No.	Color Of Wire	Signal Name [Specification]
1	P	CAN- (L)
2	L	CAN+ (H)
3	BG	RR TUNER (SIG)
4	L	RL TUNER (SIG)
5	R	FR TUNER (SIG)
6	P	FL TUNER (SIG)
7	SB	RR TUNER (VCC)
8	R	RL TUNER (VCC)
9	GR	FR TUNER (VCC)
10	G	FL TUNER (VCC)
15	Y	IGN
19	W	RR TUNER (RSSI)
20	BR	RL TUNER (RSSI)
21	LG	FR TUNER (RSSI)
22	V	FL TUNER (RSSI)
23	B	RR TUNER (GND)
24	Y	RL TUNER (GND)


25	W	FR TUNER (GND)
26	P	FL TUNER (GND)
30	LG	BCM FLASHER
32	B	GROUND

Connector No.	M104
Connector Name	REMOTE KEYLESS ENTRY RECEIVER
Connector Type	JAB04FB



Terminal No.	Color Of Wire	Signal Name [Specification]
1	B	GROUND
2	GR	SIGNAL OUTPUT
4	BR	BATTERY

Connector No.	M118
Connector Name	BCM (BODY CONTROL MODULE)
Connector Type	IM03FB-LC



Terminal No.	Color Of Wire	Signal Name [Specification]
1	W	BAT (F/L)
2	Y	POWER WINDOW POWER SUPPLY (BAT)
3	BG	POWER WINDOW POWER SUPPLY (RAP)

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

Connector No.	M119
Connector Name	BCM (BODY CONTROL MODULE)
Connector Type	NS16FW-CS



4	5	7	8	9	10
11	13	15	17	18	19

Terminal No.	Color Of Wire	Signal Name [Specification]
4	P	INT ROOM LAMP PWR SUPPLY (BAT SAVE)
5	V	PASSENGER DOOR UNLOCK OUTPUT
7	Y	STEP LAMP OUTPUT
8	V	ALL DOOR FUEL LID LOCK OUTPUT
9	G	DRIVER DOOR FUEL LID UNLOCK OUTPUT
10	BR	REAR DOOR UNLOCK OUTPUT
11	R	BAT (FUSE)
13	B	GROUND
15	Y	ACC IND
17	W	TURN SIGNAL RH (FRONT)
18	BG	TURN SIGNAL LH (FRONT)
19	SB	ROOM LAMP TIMER

Connector No.	M120
Connector Name	BCM (BODY CONTROL MODULE)
Connector Type	NS12FW-CS



20	25	26
----	----	----

Terminal No.	Color Of Wire	Signal Name [Specification]
20	V	TURN SIGNAL RH (REAR)
25	G	TURN SIGNAL LH (REAR)
26	P	REAR WIPER OUTPUT

Connector No.	M121
Connector Name	BCM (BODY CONTROL MODULE)
Connector Type	TH40FG-NH



1	2	3	4	5	6
7	8	9	10	11	12

Terminal No.	Color Of Wire	Signal Name [Specification]
34	SB	LUGGAGE ROOM ANT-
35	V	LUGGAGE ROOM ANT+
38	B	BACK DOOR ANT-
39	W	BACK DOOR ANT+
47	Y	IGN RELAY (PRM FIB) CONT
52	LG	STARTER RELAY CONT
60	SB	END START SW
61	W	TRUNK REQUEST SW
64	L	LKEY WARN BUZZER (ENG ROOM)
65	BG	REAR WIPER STOP POSITION
66	LG	BACK DOOR SW
67	P	BACK DOOR OPENER SW
68	BR	REAR RH DOOR SW
69	R	REAR LH DOOR SW

Connector No.	M122
Connector Name	BCM (BODY CONTROL MODULE)
Connector Type	TH40FB-NH



1	2	3	4	5	6
7	8	9	10	11	12

Terminal No.	Color Of Wire	Signal Name [Specification]
74	SB	PASSENGER DOOR ANT-
75	BR	PASSENGER DOOR ANT+
76	V	DRIVER DOOR ANT-
77	LG	DRIVER DOOR ANT+
78	Y	ROOM ANT-
79	BR	ROOM ANT+

80	GR	NATS ANT AMP.
81	W	NATS ANT AMP.
82	P	IGN RELAY (FIB) CONT
83	GR	KEYLESS ENTRY RECEIVER SIGNAL
87	BR	COMBI SW INPUT 5
88	V	COMBI SW INPUT 3
90	P	CAN-L
91	L	CAN-H
92	LG	KEY SLOT ILL
93	V	ON IND
95	BG	ACC RELAY CONT
96	GR	AT SHIFT SELECTOR POWER SUPPLY
99	R	SHIFT P
100	R	PASSENGER DOOR REQUEST SW
101	SB	DRIVER DOOR REQUEST SW
102	BG	BLOWER FAN MOTOR RELAY CONT
103	BR	KEYLESS ENTRY RECEIVER POWER SUPPLY
107	LG	COMBI SW INPUT 1
108	R	COMBI SW INPUT 4
109	Y	COMBI SW INPUT 2
110	G	HAZARD SW

Connector No.	M123
Connector Name	BCM (BODY CONTROL MODULE)
Connector Type	TH40FG-NH



1	2	3	4	5	6
7	8	9	10	11	12

Terminal No.	Color Of Wire	Signal Name [Specification]
112	GR	RAIN SENSOR SERIAL LINK
113	P	OPTICAL SENSOR
116	BR	STOP LAMP SW 1
118	P	STOP LAMP SW 2
119	SB	DR DOOR UNLOCK SENSOR
121	BR	KEY SLOT SW
123	W	IGN FIB
124	LG	PASSENGER DOOR SW
132	BG	POWER WINDOW SW COMM
134	GR	LOCK IND
137	B	RECEIVER SENSOR GND
138	Y	SENSOR POWER SUPPLY
140	R	SHIFT NP

141	G	SECURITY INDICATOR OUTPUT
142	BG	COMBI SW OUTPUT 5
143	P	COMBI SW OUTPUT 1
144	G	COMBI SW OUTPUT 2
145	L	COMBI SW OUTPUT 3
146	SB	COMBI SW OUTPUT 4
150	GR	DRIVER DOOR SW
151	G	REAR WINDOW DEFOGGER RELAY CONT

Connector No.	M125
Connector Name	CAN GATEWAY
Connector Type	TH12FW-NH



1	3	4	5	6
7	9	10	11	12


Terminal No.	Color Of Wire	Signal Name [Specification]
1	L	CAN-H
3	GR	BATTERY
4	L	CAN-H
5	B	GROUND
6	L	CAN-H
7	P	CAN-L
9	LG	IGNITION
10	P	CAN-L
11	B	GROUND
12	P	CAN-L

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

BCM (BODY CONTROL MODULE)

Connector No.	M123
Connector Name	TOTAL ILLUMINATION CONTROL UNIT
Connector Type	TH40FW-NH



Terminal No.	Color	Wire	Signal Name [Specification]
3	V		DDL2
4	L		TAIL LAMP SIGNAL
5	V		ACC SIGNAL
6	P		BAT SAVING SIGNAL
7	W		IGN SIGNAL
8	G		DOOR SW (AS)
9	BG		DOOR SW (RL)
10	SB		MOOD LAMP (FR ARMREST RH)
11	Y		MOOD LAMP (RR ARMREST RH)
12	P		MAP LAMP (AS)
13	G		PERSONAL LAMP (LH)
14	R		PERSONAL LAMP (RH)
16	GR		FOOT LAMP (RH)
17	LG		HSPL ILLUMINATIONS
18	L		MAP LAMP (DR)
19	R		PUSH ENG START SW LED
20	Y		AMBIENCE LAMP
21	R		BAT POWER SUPPLY
23	B		GROUND
24	B		ILL CONT INPUT
25	BR		DOOR SW (RR)
26	BR		MAP LAMP SW (DOOR)
27	R		MAP LAMP SW (ALL ON)
28	BR		ROOM LAMP TIMER
29	GR		DOOR SW (DR)
30	LG		MOOD LAMP (FR ARMREST LH)
31	BG		MOOD LAMP (RR ARMREST LH)
33	W		HSPL POWER SUPPLY 3
34	R		HSPL POWER SUPPLY 2
35	V		HSPL POWER SUPPLY 1
36	L		FOOT LAMP (LH)
39	B		PUDDLE LAMP (RH)
40	BG		PUDDLE LAMP (LH)

Connector No.	M131
Connector Name	INSIDE KEY ANTENNA (INSTRUMENT CENTER)
Connector Type	RK02MGY




Terminal No.	Color	Wire	Signal Name [Specification]
1	BR		-
2	Y		-

Connector No.	M137
Connector Name	AT SHIFT SELECTOR
Connector Type	TH12FW-NH




Terminal No.	Color	Wire	Signal Name [Specification]
1	W		-
2	V		-
3	L		-
4	B		-
5	G		-
7	BG		-
8	SB		-
9	B		-
10	GR		-
11	R		-

Connector No.	M160
Connector Name	ECM
Connector Type	RH24FGY-R28-LH-Z



Terminal No.	Color	Wire	Signal Name [Specification]
97	R		ENGINE SPEED SIGNAL OUTPUT
99	G		SENSOR POWER SUPPLY
100	L		SENSOR POWER SUPPLY
101	P		CAN COMMUNICATION LINE
102	SB		ASC/DC STEERING SWITCH
104	R		ACCELERATOR PEDAL POSITION SENSOR 1
105	L		CAN COMMUNICATION LINE
106	P		IGNITION SWITCH
108	P		ACCELERATOR PEDAL POSITION SENSOR 2
110	P		STOP LAMP SWITCH
111	V		SENSOR GROUND
112	LG		FUEL PUMP CONTROL MODULE (FFCM) CHECK
114	GR		DATA LINK CONNECTOR
115	GR		SENSOR GROUND
116	G		TRANSMISSION RANGE SWITCH
117	BR		ASC/DC BRAKE SWITCH
118	R		POWER SUPPLY FOR ECM (BACK-UP)
119	W		SENSOR GROUND
120	W		FUEL TANK TEMPERATURE SENSOR
121	GR		POWER SUPPLY FOR ECM
123	B		ECM GROUND
125	R		FUEL PUMP CONTROL MODULE (FFCM)
128	B		ECM GROUND

Connector No.	M164
Connector Name	ECM
Connector Type	RH24FGY-R28-LH-Z




Terminal No.	Color	Wire	Signal Name [Specification]
97	R		ACCELERATOR PEDAL POSITION SENSOR 1
98	P		ACCELERATOR PEDAL POSITION SENSOR 2
99	Y		ACCELERATOR PEDAL POSITION SENSOR 3
99	G		SENSOR POWER SUPPLY (With NAVI)
99	L		SENSOR POWER SUPPLY (Without NAVI)
100	W		SENSOR GROUND
101	SB		ASC/DC STEERING SWITCH
102	LG		EVAP CONTROL SYSTEM PRESSURE SENSOR
103	G		SENSOR POWER SUPPLY (With NAVI)
103	L		SENSOR POWER SUPPLY (Without NAVI)
104	BR		SENSOR GROUND (With NAVI)
104	GR		SENSOR GROUND (Without NAVI)
105	L		REFRIGERANT PRESSURE SENSOR
106	W		FUEL TANK TEMPERATURE SENSOR
107	BG		SENSOR POWER SUPPLY
108	V		SENSOR GROUND
109	G		PNP SIGNAL
110	R		ENGINE SPEED OUTPUT SIGNAL
112	V		ENGINE CANISTER VENT CONTROL SYSTEM PRESSURE SENSOR
112	W		ENGINE CANISTER VENT CONTROL SYSTEM PRESSURE SENSOR
113	P		CAN COMMUNICATION LINE
114	L		CAN COMMUNICATION LINE
117	GR		DATA LINK CONNECTOR
121	LG		EVAP CANISTER VENT CONTROL VALVE
122	P		STOP LAMP SWITCH
123	B		ECM GROUND
124	B		ECM GROUND
125	GR		POWER SUPPLY FOR ECM
126	BR		ASC/DC BRAKE SWITCH
127	B		ECM GROUND
128	B		ECM GROUND

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

BCM (BODY CONTROL MODULE)

Connector No.	M204
Connector Name	AV CONTROL UNIT
Connector Type	TH32FW-NH



Terminal No.	Color Of Wire	Signal Name [Specification]
76	LG	AV COMM (L)
77	SB	AV COMM (H)
78	LG	AV COMM (L)
79	SB	AV COMM (H)
80	P	CANL
81	I	CANH
82	BR	SW GND
86	SHIELD	SHIELD
87	L	TEL VOICE SIGNAL (+)
88	P	TEL VOICE SIGNAL (-)
92	R	VEHICLE SPEED SIGNAL (8-PULSE)
93	V	PARKING BRAKE SIGNAL
94	BG	REVERSE SIGNAL
95	G	IGNITION SIGNAL
96	SB	DISK EJECT SIGNAL
102	B	AUX GND
103	W	AUX AUDIO LH+
104	R	AUX AUDIO RH+

Connector No.	M210
Connector Name	AV CONTROL UNIT
Connector Type	TH32FW-NH



Connector No.	R9
Connector Name	RAIN SENSOR
Connector Type	IAEB03FB



Terminal No.	Color Of Wire	Signal Name [Specification]
1	BR	RAIN SENSOR
2	GR	GR
3	B	GROUND

Connector No.	R4
Connector Name	SUNROOF MOTOR ASSEMBLY
Connector Type	YEA10FGY



Terminal No.	Color Of Wire	Signal Name [Specification]
1	GR	SW-BIT1
5	P	SW-BIT0
7	BR	4B
8	L	SPEED SENSOR (2P)
9	Y	TIMER (+IGN)
10	G	GROUND

Fail-safe

FAIL-SAFE CONTROL BY DTC

BCM performs fail-safe control when any DTC are detected.

JRMWF4499GB

INFOID:0000000011016164

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

Display contents of CONSULT	Fail-safe	Cancellation
B2190: NATS ANTENNA AMP	Inhibit engine cranking	Erase DTC
B2191: DIFFERENCE OF KEY	Inhibit engine cranking	Erase DTC
B2192: ID DISCORD BCM-ECM	Inhibit engine cranking	Erase DTC
B2193: CHAIN OF BCM-ECM	Inhibit engine cranking	Erase DTC
B2195: ANTI SCANNING	Inhibit engine cranking	Ignition switch ON → OFF
B2560: STARTER CONT RELAY	Inhibit engine cranking	500 ms after the following CAN signal communication status becomes consistent - Starter control relay signal - Starter relay status signal
B2608: STARTER RELAY	Inhibit engine cranking	500 ms after the following signal communication status becomes consistent - Starter relay control signal - Starter relay status signal (CAN)
B260A: IGNITION RELAY	Inhibit engine cranking	500 ms after the following conditions are fulfilled - IGN relay (IPDM E/R) control signal: OFF (Battery voltage) - Ignition ON signal (CAN to IPDM E/R): OFF (Request signal) - Ignition ON signal (CAN from IPDM E/R): OFF (Condition signal)
B260F: ENG STATE SIG LOST	Maintains the power supply position attained at the time of DTC detection	When any of the following conditions are fulfilled - Power position changes to ACC - Receives engine status signal (CAN)
B2617: STARTER RELAY CIRC	Inhibit engine cranking	1 second after the starter relay control inside BCM becomes normal
B2618: BCM	Inhibit engine cranking	1 second after the ignition relay (IPDM E/R) control inside BCM becomes normal
B261E: VEHICLE TYPE	Inhibit engine cranking	BCM initialization

FAIL-SAFE CONTROL BY RAIN SENSOR MALFUNCTION

- BCM judges the rain sensor serial link error by the rain sensor serial link condition and detects the rain sensor malfunction by rain sensor malfunction signal.
- When BCM detects the rain sensor serial link error or the rain sensor malfunction while front wiper AUTO operation, BCM operates a fail-safe control.

NOTE:

If rain sensor malfunction is detected when ignition switch is turned OFF ⇒ ON and front wiper switch is INT position, BCM operates a fail-safe control.

REAR WIPER MOTOR PROTECTION

BCM detects the rear wiper stopping position according to the rear wiper stop position signal.

When the rear wiper stop position signal does not change for more than 5 seconds while driving the rear wiper, BCM stops power supply to protect the rear wiper motor.

Condition of cancellation

- More than 1 minute is passed after the rear wiper stops.
- Turn rear wiper switch OFF.
- Operate the rear wiper switch or rear washer switch.

DTC Inspection Priority Chart

INFOID:0000000011016165

If some DTCs are displayed at the same time, perform inspections one by one based on the following priority chart.

Priority	DTC
1	B2562: LOW VOLTAGE
2	- U1000: CAN COMM - U1010: CONTROL UNIT(CAN)

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

Priority	DTC
3	• B2190: NATS ANTENNA AMP • B2191: DIFFERENCE OF KEY • B2192: ID DISCORD BCM-ECM • B2193: CHAIN OF BCM-ECM • B2195: ANTI SCANNING
4	• B2553: IGNITION RELAY • B2555: STOP LAMP • B2556: PUSH-BTN IGN SW • B2557: VEHICLE SPEED • B2560: STARTER CONT RELAY • B2601: SHIFT POSITION • B2602: SHIFT POSITION • B2603: SHIFT POSI STATUS • B2604: PNP/CLUTCH SW • B2605: PNP/CLUTCH SW • B2608: STARTER RELAY • B260A: IGNITION RELAY • B260F: ENG STATE SIG LOST • B2614: BCM • B2615: BCM • B2616: BCM • B2617: BCM • B2618: BCM • B261A: PUSH-BTN IGN SW • B261E: VEHICLE TYPE • B26EA: KEY REGISTRATION • U0415: VEHICLE SPEED SIG
5	• B2621: INSIDE ANTENNA • B2623: INSIDE ANTENNA
6	B26E7: TPMS CAN COMM

DTC Index

INFOID:0000000011016166

NOTE:

The details of time display are as follows.

- CRNT: A malfunction is detected now.
- PAST: A malfunction was detected in the past.

IGN counter is displayed on Freeze Frame Data. For details of Freeze Frame Data, refer to [BCS-20, "COMMON ITEM : CONSULT Function \(BCM - COMMON ITEM\)"](#).

CONSULT display	Fail-safe	Freeze Frame Data •Vehicle Speed •Odo/Trip Meter •Vehicle Condition	Intelligent Key warn- ing lamp ON	Reference
No DTC is detected. Further testing may be required.	—	—	—	—
U1000: CAN COMM	—	—	—	BCS-39
U1010: CONTROL UNIT(CAN)	—	—	—	BCS-40
U0415: VEHICLE SPEED SIG	—	—	—	BCS-41
B2190: NATS ANTENNA AMP	×	—	—	SEC-47
B2191: DIFFERENCE OF KEY	×	—	—	SEC-50
B2192: ID DISCORD BCM-ECM	×	—	—	SEC-51
B2193: CHAIN OF BCM-ECM	×	—	—	SEC-53
B2195: ANTI SCANNING	×	—	—	SEC-54
B2553: IGNITION RELAY	—	×	—	PCS-53
B2555: STOP LAMP	—	×	—	SEC-55

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

CONSULT display	Fail-safe	Freeze Frame Data •Vehicle Speed •Odo/Trip Meter •Vehicle Condition	Intelligent Key warn- ing lamp ON	Reference	
B2556: PUSH-BTN IGN SW	—	×	×	SEC-57	A
B2557: VEHICLE SPEED	×	×	×	SEC-59	B
B2560: STARTER CONT RELAY	×	×	×	SEC-60	
B2562: LOW VOLTAGE	—	×	—	BCS-42	C
B2601: SHIFT POSITION	×	×	×	SEC-61	
B2602: SHIFT POSITION	×	×	×	SEC-64	D
B2603: SHIFT POSI STATUS	×	×	×	SEC-66	
B2604: PNP/CLUTCH SW	×	×	×	SEC-69	
B2605: PNP/CLUTCH SW	×	×	×	SEC-71	E
B2608: STARTER RELAY	×	×	×	SEC-73	
B260A: IGNITION RELAY	×	×	×	PCS-55	F
B260F: ENG STATE SIG LOST	×	×	×	SEC-75	
B2614: BCM	—	×	×	PCS-57	
B2615: BCM	—	×	×	PCS-59	G
B2616: BCM	—	×	×	PCS-61	
B2617: BCM	×	×	×	SEC-77	
B2618: BCM	×	×	×	PCS-63	H
B261A: PUSH-BTN IGN SW	—	×	×	SEC-79	
B261E: VEHICLE TYPE	×	×	× (Turn ON for 15 seconds)	SEC-82	I
B2621: INSIDE ANTENNA	—	×	—	DLK-101	
B2623: INSIDE ANTENNA	—	×	—	DLK-103	J
B26E7: TPMS CAN COMM	—	—	—	BCS-43	
B26EA: KEY REGISTRATION	—	×	× (Turn ON for 15 seconds)	SEC-76	K

INL

M

N

O

P

INTERIOR LIGHTING SYSTEM SYMPTOMS

< SYMPTOM DIAGNOSIS >

SYMPTOM DIAGNOSIS

INTERIOR LIGHTING SYSTEM SYMPTOMS

Symptom Table

INFOID:0000000010584978

CAUTION:

Perform the self-diagnosis with CONSULT before the symptom diagnosis. Perform the trouble diagnosis if any DTC are detected.

SYMPTOMS BY ITEM

1. Identify the malfunctioning by checking each lamp (whether it can turn ON or not).
2. Check the malfunction combinations.
3. Identify the malfunctioning part from the agreed combination and repair or replace the part.

NOTE:

When a lamp other than those in the following table is not turned ON/OFF, check the bulb, the lamp housing, and the direct circuit.

Malfunction item: ×

Map lamps*1	Personal lamps*1	Center console indirect illumination	Vanity mirror lamp	Foot lamps	Push-button ignition switch illumination	Mood lamp (Rear door armrest)	Puddle lamps	Mood lamp (Front door armrest)	Linked illuminations*2	Step lamps	Luggage room lamps	Automatic back door close switch (illumination)	Inspection item (Reference)
×	×	×	×	×	×	×	×	×	×	×	×	×	Interior room lamp power supply circuit (INL-29)
×	×	×	×	×	×	×	×	×	×				1. Power supply and ground circuit of total illumination control unit (INL-27) 2. Battery saver signal circuit (INL-31)
×	×	×	×	×	×	×							Hospitality lighting power supply 1 circuit (INL-32)
							×	×					Hospitality lighting power supply 2 circuit (INL-35)
×	×												Map lamp main switch circuit (INL-65)
×													Map lamp circuit (INL-39)
	×												Personal lamp circuit (INL-41)
		×											Center console indirect illumination circuit (INL-43)
			×										The lamp housing and the direct circuit (INL-73)
				×									Foot lamp circuit (INL-45)
					×								Push-button ignition switch illumination circuit (INL-52)
						×							Mood lamp (Rear door armrest) circuit (INL-54)
							×						Puddle lamp circuit (INL-48)
								×					Mood lamp (Front door armrest) circuit (INL-50)
									×				1. Hospitality lighting power supply 3 circuit (INL-37) 2. Hospitality illumination circuit (INL-56)
													Hospitality lighting power supply 3 circuit (INL-37)
										×			Step lamp circuit (INL-59)
											×	×	The lamp housing and the direct circuit (INL-73)

*1: Map lamp main switch ALL ON or DOOR

*2: Refer to INL-37, "Description" for linked illuminations.

INTERIOR LIGHTING SYSTEM SYMPTOMS

< SYMPTOM DIAGNOSIS >

SYMPTOMS BY FUNCTION

Symptom	Inspection item (Reference)
When any door is opened, applicable map lamp or personal lamp is not turned ON. (It is turned ON when turning the map lamp main switch ALL ON.)	Door switch circuit (INL-67)
Interior room lamp timer does not activate. (It is turned ON/OFF when turning the map lamp main switch ALL ON/OFF.)	Room lamp timer circuit (INL-71).
Illuminations are not turned ON when tail lamp is ON. [They are turned ON when hospitality lighting is operated. (Hospitality lighting functioning table "Scene 3")]	Tail lamp signal circuit (INL-61)
Brightness of illuminations is not adjustable by the illumination control switch when tail lamp is ON. (Meter illumination control is normal.)	Illumination control signal circuit (INL-63)
Interior room lamp battery saver does not activate.	Check the interior room lamp battery saver setting. (INL-25)

A

B

C

D

E

F

G

H

I

J

K

INL

M

N

O

P

PRECAUTIONS

< PRECAUTION >

PRECAUTION

PRECAUTIONS

Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"

INFOID:000000010584979

The Supplemental Restraint System such as "AIR BAG" and "SEAT BELT PRE-TENSIONER", used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. This system includes seat belt switch inputs and dual stage front air bag modules. The SRS system uses the seat belt switches to determine the front air bag deployment, and may only deploy one front air bag, depending on the severity of a collision and whether the front occupants are belted or unbelted. Information necessary to service the system safely is included in the "SRS AIR BAG" and "SEAT BELT" of this Service Manual.

WARNING:

Always observe the following items for preventing accidental activation.

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision that would result in air bag inflation, all maintenance must be performed by an authorized NISSAN/INFINITI dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see "SRS AIR BAG".
- Never use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harnesses or harness connectors.

PRECAUTIONS WHEN USING POWER TOOLS (AIR OR ELECTRIC) AND HAMMERS

WARNING:

Always observe the following items for preventing accidental activation.

- When working near the Air Bag Diagnosis Sensor Unit or other Air Bag System sensors with the ignition ON or engine running, never use air or electric power tools or strike near the sensor(s) with a hammer. Heavy vibration could activate the sensor(s) and deploy the air bag(s), possibly causing serious injury.
- When using air or electric power tools or hammers, always switch the ignition OFF, disconnect the battery, and wait at least 3 minutes before performing any service.

Precautions For Xenon Headlamp Service

INFOID:000000010755188

WARNING:

Comply with the following warnings to prevent any serious accident.

- Disconnect the battery cable (negative terminal) or the power supply fuse before installing, removing, or touching the xenon headlamp (bulb included). The xenon headlamp contains high-voltage generated parts.
- Never work with wet hands.
- Check the xenon headlamp ON-OFF status after assembling it to the vehicle. Never turn the xenon headlamp ON in other conditions. Connect the power supply to the vehicle-side connector. (Turning it ON outside the lamp case may cause fire or visual impairments.)
- Never touch the bulb glass immediately after turning it OFF. It is extremely hot.

CAUTION:

Comply with the following cautions to prevent any error and malfunction.

- Install the xenon bulb securely. (Insufficient bulb socket installation may melt the bulb, the connector, the housing, etc. by high-voltage leakage or corona discharge.)
- Never perform HID circuit inspection with a tester.
- Never touch the xenon bulb glass with hands. Never put oil and grease on it.
- Dispose of the used xenon bulb after packing it in thick vinyl without breaking it.
- Never wipe out dirt and contamination with organic solvent (thinner, gasoline, etc.).

PRECAUTIONS

< PRECAUTION >

Precautions for Removing Battery Terminal

INFOID:0000000010755189

- When removing the 12V battery terminal, turn OFF the ignition switch and wait at least 30 seconds.

NOTE:

ECU may be active for several tens of seconds after the ignition switch is turned OFF. If the battery terminal is removed before ECU stops, then a DTC detection error or ECU data corruption may occur.

- For vehicles with the 2-batteries, be sure to connect the main battery and the sub battery before turning ON the ignition switch.


NOTE:

If the ignition switch is turned ON with any one of the terminals of main battery and sub battery disconnected, then DTC may be detected.

- After installing the 12V battery, always check "Self Diagnosis Result" of all ECUs and erase DTC.

NOTE:

The removal of 12V battery may cause a DTC detection error.



A
B
C
D
E
F
G
H
I
J
K
INL
M
N
O
P

MAP LAMP


< REMOVAL AND INSTALLATION >

REMOVAL AND INSTALLATION

MAP LAMP

Exploded View

INFOID:0000000010584980



1. Map lamp assembly

2. Bulb

3. Lens

Removal and Installation

INFOID:0000000010584981

Refer to [INT-25, "Exploded View"](#) for the map lamp assembly installation/removal.

Replacement

INFOID:0000000010584982

CAUTION:

- Disconnect the battery negative terminal or remove the fuse.
- Never touch the glass of bulb directly by hand. Keep grease and other oily matters away from it. Never touch bulb by hand while it is lit or right after it turns OFF.
- Never leave bulb out of lamp reflector for a long time because dust, moisture, smoke, etc. may affect the performance of lamp. When replacing bulb, always replace it with new one.

MAP LAMP BULB

1. Insert any appropriate tool into the gap between the lens. Remove the lens.
2. Remove the bulb.


VANITY MIRROR LAMP

< REMOVAL AND INSTALLATION >

VANITY MIRROR LAMP

Exploded View

INFOID:000000010584983



1. Lens

2. Bulb

Replacement

INFOID:000000010584984

CAUTION:

- Disconnect the battery negative terminal or remove the fuse.
- Never touch the glass of bulb directly by hand. Keep grease and other oily matters away from it. Never touch bulb by hand while it is lit or right after it turns OFF.
- Never leave bulb out of lamp reflector for a long time because dust, moisture, smoke, etc. may affect the performance of lamp. When replacing bulb, always replace it with new one.

VANITY MIRROR LAMP BULB

1. Insert any appropriate tool into the gap between the lens. Remove the lens.
2. Remove the bulb.

INL


ASHTRAY ILLUMINATION

< REMOVAL AND INSTALLATION >

ASHTRAY ILLUMINATION

Exploded View

INFOID:0000000010584985



1. Bulb socket

2. Bulb

Replacement

INFOID:0000000010584986

CAUTION:

- Disconnect the battery negative terminal or remove the fuse.
- Never touch the glass of bulb directly by hand. Keep grease and other oily matters away from it. Never touch bulb by hand while it is lit or right after it turns OFF.
- Never leave bulb out of lamp reflector for a long time because dust, moisture, smoke, etc. may affect the performance of lamp. When replacing bulb, always replace it with new one.

ASHTRAY ILLUMINATION BULB

1. Remove the console pocket assembly. Refer to [IP-23, "Exploded View"](#).
2. Rotate the bulb socket counterclockwise and unlock it.
3. Remove the bulb.


GLOVE BOX LAMP

< REMOVAL AND INSTALLATION >

GLOVE BOX LAMP

Exploded View

INFOID:0000000010584987



1. Bulb socket

2. Bulb

Replacement

INFOID:0000000010584988

CAUTION:

- Disconnect the battery negative terminal or remove the fuse.
- Never touch the glass of bulb directly by hand. Keep grease and other oily matters away from it. Never touch bulb by hand while it is lit or right after it turns OFF.
- Never leave bulb out of lamp reflector for a long time because dust, moisture, smoke, etc. may affect the performance of lamp. When replacing bulb, always replace it with new one.

GLOVE BOX LAMP BULB

1. Remove the glove box assembly. Refer to [IP-12, "Exploded View"](#).
2. Rotate the bulb socket counterclockwise and unlock it.
3. Remove the bulb.

INL


TOTAL ILLUMINATION CONTROL UNIT

< REMOVAL AND INSTALLATION >

TOTAL ILLUMINATION CONTROL UNIT

Exploded View

INFOID:0000000010584989



1. Total illumination control unit

Removal and Installation

INFOID:0000000010584990

CAUTION:

Disconnect the battery negative terminal or remove the fuse.

REMOVAL

1. Remove the instrument lower cover RH. Refer to [IP-12, "Exploded View"](#).
2. Remove the screw. And then remove the total illumination control unit.

INSTALLATION

Install in the reverse order of removal.


FOOT LAMP

< REMOVAL AND INSTALLATION >

FOOT LAMP DRIVER SIDE

DRIVER SIDE : Exploded View

INFOID:0000000010584991



1. Foot lamp case (driver side)

2. Bulb

3. Lens

DRIVER SIDE : Removal and Installation

INFOID:0000000010584992

CAUTION:

Disconnect the battery negative terminal or remove the fuse.

REMOVAL

1. Insert any appropriate tool into the gap between the foot lamp and the instrument lower cover LH. Remove the foot lamp.
2. Disconnect the foot lamp connector.

INSTALLATION

Install in the reverse order of removal.

DRIVER SIDE : Replacement

INFOID:0000000010584993

CAUTION:

- **Disconnect the battery negative terminal or remove the fuse.**
- **Never touch the glass of bulb directly by hand. Keep grease and other oily matters away from it. Never touch bulb by hand while it is lit or right after it turns OFF.**
- **Never leave bulb out of lamp reflector for a long time because dust, moisture, smoke, etc. may affect the performance of lamp. When replacing bulb, always replace it with new one.**

FOOT LAMP BULB (DRIVER SIDE)

1. Insert any appropriate tool into the gap between the lens. Remove the lens.
2. Remove the bulb.


PASSENGER SIDE

FOOT LAMP

< REMOVAL AND INSTALLATION >

PASSENGER SIDE : Exploded View

INFOID:0000000010584994



1. Foot lamp case (passenger side)

2. Bulb

3. Lens

PASSENGER SIDE : Removal and Installation

INFOID:0000000010584995

CAUTION:

Disconnect the battery negative terminal or remove the fuse.

REMOVAL

1. Insert any appropriate tool into the gap between the foot lamp and the instrument lower cover RH. Remove the foot lamp.
2. Disconnect the foot lamp connector.

INSTALLATION

Install in the reverse order of removal.

PASSENGER SIDE : Replacement

INFOID:0000000010584996

CAUTION:

- **Disconnect the battery negative terminal or remove the fuse.**
- **Never touch the glass of bulb directly by hand. Keep grease and other oily matters away from it. Never touch bulb by hand while it is lit or right after it turns OFF.**
- **Never leave bulb out of lamp reflector for a long time because dust, moisture, smoke, etc. may affect the performance of lamp. When replacing bulb, always replace it with new one.**

FOOT LAMP BULB (PASSENGER SIDE)

1. Insert any appropriate tool into the gap between the lens. Remove the lens.
2. Remove the bulb.

MOOD LAMP


< REMOVAL AND INSTALLATION >

MOOD LAMP

FRONT DOOR ARMREST

FRONT DOOR ARMREST : Exploded View

INFOID:000000010584997



1. Mood lamp (front door armrest)

FRONT DOOR ARMREST : Replacement

INFOID:000000010584998

CAUTION:

Disconnect the battery negative terminal or remove the fuse.


MOOD LAMP (FRONT DOOR ARMREST)

1. Remove the front door finisher. Refer to [INT-12, "Exploded View"](#).
2. Remove the front door armrest finisher. Refer to [INT-12, "Exploded View"](#).
3. Remove the mood lamp (front door armrest) from the front door finisher.

REAR DOOR ARMREST

REAR DOOR ARMREST : Exploded View

INFOID:000000010584999



1. Mood lamp (rear door armrest)

MOOD LAMP

< REMOVAL AND INSTALLATION >

REAR DOOR ARMREST : Replacement

INFOID:0000000010585000

CAUTION:

Disconnect the battery negative terminal or remove the fuse.

MOOD LAMP (REAR DOOR ARMREST)

1. Remove the rear door finisher. Refer to [INT-15, "Exploded View"](#).
2. Remove the rear door armrest finisher. Refer to [INT-15, "Exploded View"](#).
3. Remove the mood lamp (rear door armrest) from the rear door finisher.


STEP LAMP

< REMOVAL AND INSTALLATION >

STEP LAMP

Exploded View

INFOID:0000000010585001



1. Step lamp case

2. Bulb

3. Lens

A Metal clip

Removal and Installation

INFOID:0000000010585002

CAUTION:

Disconnect the battery negative terminal or remove the fuse.

REMOVAL

1. Insert any appropriate tool into the gap between the step lamp and the door trim. Remove the step lamp.
2. Disconnect the step lamp connector.

INSTALLATION

Install in the reverse order of removal.

Replacement

INFOID:0000000010585003

CAUTION:

- **Disconnect the battery negative terminal or remove the fuse.**
- **Never touch the glass of bulb directly by hand. Keep grease and other oily matters away from it. Never touch bulb by hand while it is lit or right after it turns OFF.**
- **Never leave bulb out of lamp reflector for a long time because dust, moisture, smoke, etc. may affect the performance of lamp. When replacing bulb, always replace it with new one.**

STEP LAMP BULB

1. Remove the step lamp. Refer to [INL-199, "Exploded View"](#).
2. Remove the lens.
3. Remove the bulb.


PERSONAL LAMP

< REMOVAL AND INSTALLATION >

PERSONAL LAMP

Exploded View

INFOID:0000000010585004



1. Personal lamp case
2. Personal lamp finisher
3. Lens
4. Bulb

NOTE:

Replace the personal lamp case as a set (right and left). After removing the headlining assembly, remove the personal lamp case. Refer to [INT-25, "Exploded View"](#).

Removal and Installation

INFOID:0000000010585005

CAUTION:


Disconnect the battery negative terminal or remove the fuse.

REMOVAL

1. Remove the headlining assembly. Refer to [INT-25, "Exploded View"](#).
2. Insert any appropriate tool into the gap between the lens. Remove the lens.
3. Press both side pawls (A) in the direction of the arrow (←). Remove the personal lamp finisher.
4. Remove the personal lamp case from the headlining assembly.

NOTE:

Replace the personal lamp case as a set (right and left).



INSTALLATION

Install in the reverse order of removal.


NOTE:

The following item is an easier way to install the personal lamp finisher.

PERSONAL LAMP

< REMOVAL AND INSTALLATION >

- Press the personal lamp finisher to the headlining. Pull the personal lamp case pawl in the direction of the arrow (←) with any appropriate tool.



Replacement

INFOID:0000000010585006

CAUTION:

- **Disconnect the battery negative terminal or remove the fuse.**
- **Never touch the glass of bulb directly by hand. Keep grease and other oily matters away from it. Never touch bulb by hand while it is lit or right after it turns OFF.**
- **Never leave bulb out of lamp reflector for a long time because dust, moisture, smoke, etc. may affect the performance of lamp. When replacing bulb, always replace it with new one.**

PERSONAL LAMP BULB

1. Insert any appropriate tool into the gap between the lens. Remove the lens.
2. Remove the bulb.

A
B
C
D
E
F
G
H
I
J
K
INL
M
N
O
P

PUDDLE LAMP

< REMOVAL AND INSTALLATION >

PUDDLE LAMP

Exploded View

INFOID:0000000010585007

Puddle lamp is integrated into the door mirror assembly.

- With ADP. Refer to [MIR-75, "Exploded View"](#).
- Without ADP. Refer to [MIR-99, "Exploded View"](#).

LUGGAGE ROOM LAMP


< REMOVAL AND INSTALLATION >

LUGGAGE ROOM LAMP

LUGGAGE SIDE

LUGGAGE SIDE : Exploded View

INFOID:0000000010585008



1. Luggage room lamp (luggage side) housing

2. Bulb

3. Lens

LUGGAGE SIDE : Removal and Installation

INFOID:0000000010585009

CAUTION:

Disconnect the battery negative terminal or remove the fuse.

REMOVAL

1. Insert any appropriate tool into the gap between the luggage room lamp (luggage side) and luggage side finisher lower. And then remove the luggage room lamp (luggage side).
2. Disconnect the luggage room lamp (luggage side) connector.

INSTALLATION

Install in the reverse order of removal.

LUGGAGE SIDE : Replacement

INFOID:0000000010585010

CAUTION:

- **Disconnect the battery negative terminal or remove the fuse.**
- **Never touch the glass of bulb directly by hand. Keep grease and other oily matters away from it. Never touch bulb by hand while it is lit or right after it turns OFF.**
- **Never leave bulb out of lamp reflector for a long time because dust, moisture, smoke, etc. may affect the performance of lamp. When replacing bulb, always replace it with new one.**

LUGGAGE ROOM LAMP (LUGGAGE SIDE) BULB

1. Remove the luggage room lamp (luggage side). Refer to [INL-203, "LUGGAGE SIDE : Exploded View"](#).
2. Remove the screw. And then remove the lens.
3. Remove the bulb.


BACK DOOR SIDE

LUGGAGE ROOM LAMP

< REMOVAL AND INSTALLATION >

BACK DOOR SIDE : Exploded View

INFOID:0000000010585011



1. Luggage room lamp (back door side) assembly 2. Lens 3. Bulb

BACK DOOR SIDE : Removal and Installation

INFOID:0000000010585012

CAUTION:

Disconnect the battery negative terminal or remove the fuse.

REMOVAL

1. Insert any appropriate tool into the gap between the luggage room lamp (back door side) assembly and back door finisher inner. Remove the luggage room lamp (back door side) assembly.
2. Disconnect the luggage room lamp (back door side) connector.

INSTALLATION

Install in the reverse order of removal.

BACK DOOR SIDE : Replacement

INFOID:0000000010585013

CAUTION:

- **Disconnect the battery negative terminal or remove the fuse.**
- **Never touch the glass of bulb directly by hand. Keep grease and other oily matters away from it. Never touch bulb by hand while it is lit or right after it turns OFF.**
- **Never leave bulb out of lamp reflector for a long time because dust, moisture, smoke, etc. may affect the performance of lamp. When replacing bulb, always replace it with new one.**

LUGGAGE ROOM LAMP BULB

1. Remove the luggage room lamp (back door side). Refer to [INL-204, "BACK DOOR SIDE : Exploded View"](#).
2. Remove the screw. And then remove the lens.
3. Remove the bulb.

SERVICE DATA AND SPECIFICATIONS (SDS)

< SERVICE DATA AND SPECIFICATIONS (SDS)

SERVICE DATA AND SPECIFICATIONS (SDS)

SERVICE DATA AND SPECIFICATIONS (SDS)

Bulb Specifications

INFOID:0000000010585014

Item	Type	Wattage (W)
Push-button ignition switch illumination	LED	—
Map lamp	Wedge	8
Console lamp (integrated into the map lamp assembly)	LED	—
Puddle lamp	LED	—
Vanity mirror lamp	—	2
Cigarette lighter illumination	Wedge	1.4
Glove box lamp	Wedge	1.4
Foot lamp	Wedge	3.4
Mood lamp (door armrest)	LED	—
Step lamp	Wedge	5
Personal lamp	Wedge	8
Luggage room lamp	—	8