

SECTION **LU**

ENGINE LUBRICATION SYSTEM

CONTENTS

VQ37VHR	UNIT DISASSEMBLY AND ASSEMBLY ...17	F
SYSTEM DESCRIPTION 3	OIL PUMP17	
DESCRIPTION 3	Exploded View17	G
Engine Lubrication System3	Disassembly and Assembly17	
Engine Lubrication System Schematic3	Inspection18	
PRECAUTION 5	SERVICE DATA AND SPECIFICATIONS	H
PRECAUTIONS 5	(SDS)20	
Precautions for Removing Battery Terminal5	SERVICE DATA AND SPECIFICATIONS	I
Liquid Gasket5	(SDS)20	
Precautions For Engine Service5	Periodical Maintenance Specification20	
PREPARATION 7	Engine Oil Pressure20	J
PREPARATION 7	Oil Pump20	
Special Service Tools7	Regulator Valve20	
Commercial Service Tools7	VK50VE	K
PERIODIC MAINTENANCE 8	SYSTEM DESCRIPTION21	
ENGINE OIL 8	DESCRIPTION21	L
Inspection8	Engine Lubrication System21	
Draining10	Engine Lubrication System Schematic22	
Refilling10	PRECAUTION23	M
OIL FILTER11	PRECAUTIONS23	
Removal and Installation11	Precautions for Removing Battery Terminal23	N
Inspection12	Liquid Gasket23	
REMOVAL AND INSTALLATION13	Precautions For Engine Service23	
OIL FILTER BRACKET13	PREPARATION25	O
Exploded View13	PREPARATION25	
Removal and Installation13	Special Service Tools25	P
Inspection14	Commercial Service Tools25	
OIL COOLER15	PERIODIC MAINTENANCE26	
Exploded View15	ENGINE OIL26	
Removal and Installation15	Inspection26	
Inspection16	Draining27	

Refilling	28	OIL PUMP	32
OIL FILTER	29	Exploded View	32
Removal and Installation	29	Disassembly and Assembly	32
Inspection	29	Inspection	32
REMOVAL AND INSTALLATION	30	SERVICE DATA AND SPECIFICATIONS	
OIL COOLER	30	(SDS)	34
Exploded View	30	SERVICE DATA AND SPECIFICATIONS	
Removal and Installation	30	(SDS)	34
Inspection	31	Periodical Maintenance Specification	34
UNIT DISASSEMBLY AND ASSEMBLY ...	32	Engine Oil Pressure	34


SYSTEM DESCRIPTION

DESCRIPTION

Engine Lubrication System

INFOID:0000000010581909

LU




JPBIA1139GB

NOTE:

Without oil cooler for 2WD models

Engine Lubrication System Schematic

INFOID:0000000010581910



JPBIA1140GB

NOTE:

Without oil cooler for 2WD models

PRECAUTION

PRECAUTIONS

Precautions for Removing Battery Terminal

INFOID:0000000011004990

- When removing the 12V battery terminal, turn OFF the ignition switch and wait at least 30 seconds.

NOTE:

ECU may be active for several tens of seconds after the ignition switch is turned OFF. If the battery terminal is removed before ECU stops, then a DTC detection error or ECU data corruption may occur.

- For vehicles with the 2-batteries, be sure to connect the main battery and the sub battery before turning ON the ignition switch.


NOTE:

If the ignition switch is turned ON with any one of the terminals of main battery and sub battery disconnected, then DTC may be detected.

- After installing the 12V battery, always check "Self Diagnosis Result" of all ECUs and erase DTC.

NOTE:

The removal of 12V battery may cause a DTC detection error.



Liquid Gasket

INFOID:0000000010581911

LIQUID GASKET APPLICATION PROCEDURE

- Remove old liquid gasket adhering to the liquid gasket application surface and the mating surface.
 - Remove liquid gasket completely from the liquid gasket application surface, mounting bolts, and bolt holes.
- Wipe the liquid gasket application surface and the mating surface with white gasoline (lighting and heating use) to remove adhering moisture, grease and foreign materials.
- Apply liquid gasket to the liquid gasket application surface.

Use Genuine Liquid Gasket or equivalent.

 - Within five minutes of liquid gasket application, install the mating component.
 - If liquid gasket protrudes, wipe it off immediately.
 - Do not retighten mounting bolts or nuts after the installation.
 - After 30 minutes or more have passed from the installation, fill engine oil and engine coolant.

Precautions For Engine Service

INFOID:0000000010581912

DISCONNECTING FUEL PIPING

- Before starting work, check no fire or spark producing items are in the work area.
- Release fuel pressure before disconnecting and disassembly.
- After disconnecting pipes, plug openings to stop fuel leakage.

DRAINING ENGINE COOLANT

Drain engine coolant and engine oil when the engine is cooled.

INSPECTION, REPAIR AND REPLACEMENT

Before repairing or replacing, thoroughly inspect parts. Inspect new replacement parts in the same way, and replace if necessary.

REMOVAL AND DISASSEMBLY

- When instructed to use SST, use specified tools. Always be careful to work safely, avoid forceful or uninstructed operations.
- Exercise maximum care to avoid damage to mating or sliding surfaces.
- Dowel pins are used for several parts alignment. When replacing and reassembling parts with dowel pins, check that dowel pins are installed in the original position.

PRECAUTIONS

< PRECAUTION >

[VQ37VHR]

- Must cover openings of engine system with a tape or equivalent, to seal out foreign materials.
- Mark and arrange disassembly parts in an organized way for easy troubleshooting and reassembly.
- When loosening nuts and bolts, as a basic rule, start with the one furthest outside, then the one diagonally opposite, and so on. If the order of loosening is specified, do exactly as specified. Power tools may be used in the step.

ASSEMBLY AND INSTALLATION

- Use torque wrench to tighten bolts or nuts to specification.
- When tightening nuts and bolts, as a basic rule, equally tighten in several different steps starting with the ones in center, then ones on inside and outside diagonally in this order. If the order of tightening is specified, do exactly as specified.
- Replace with new gasket, packing, oil seal or O-ring.
- Thoroughly wash, clean, and air-blow each part. Carefully check engine oil or engine coolant passages for any restriction and blockage.
- Avoid damaging sliding or mating surfaces. Completely remove foreign materials such as cloth lint or dust. Before assembly, oil sliding surfaces well.
- After disassembling, or exposing any internal engine parts, change engine oil and replace oil filter with a new one.
- Release air within route when refilling after draining engine coolant.
- After repairing, start the engine and increase engine speed to check engine coolant, fuel, engine oil, and exhaust gases for leakage.

PREPARATION

< PREPARATION >

[VQ37VHR]

PREPARATION



PREPARATION

Special Service Tools

INFOID:0000000010581913

A

LU

Tool number Tool name	Description
ST25051001 Oil pressure gauge	Measuring oil pressure Maximum measuring range: 2,452 kPa (24.52 bar, 25 kg/cm², 356 psi)
 NT050	
ST25052000 Hose	Adapting oil pressure gauge to oil pan (upper)
 S-NT559	
KV10115801 Oil filter wrench	Removing and installing oil filter a: 64.3 mm (2.531 in)
 S-NT375	

C

D

E

F

G

H



I

J

Commercial Service Tools

INFOID:0000000010581914

K

Tool name	Description
Power tools	Loosening bolts and nuts
 PBIC0190E	
Deep socket	Removing and installing oil pressure switch 27 mm (1.06 in)
 PBIC4066E	

L

M

N

O

P

PERIODIC MAINTENANCE

ENGINE OIL

Inspection


INFOID:0000000010581915

ENGINE OIL LEVEL

NOTE:

Before starting engine, put vehicle horizontally and check the engine oil level. If engine is already started, stop it and allow 10 minutes before checking.

1. Pull out oil level gauge and wipe it clean.
2. Insert oil level gauge and check the engine oil level is within the range (A) shown in the figure.
3. If it is out of range, adjust it.




NOTE:

When checking the engine oil level, insert oil level gauge (1) with its tip aligned with oil level gauge guide.

2 : Engine cover

⇐ : Engine front



ENGINE OIL APPEARANCE

- Check engine oil for white turbidity or heavy contamination.
- If engine oil becomes turbid and white, it is highly probable that it is contaminated with engine coolant. Repair or replace damaged parts.

ENGINE OIL LEAKAGE

Check for engine oil leakage around the following areas:

- Oil pans (lower and upper)
- Oil pan drain plug
- Oil pressure switch
- Oil temperature sensor
- Oil filter
- Oil cooler
- Oil filter bracket
- Valve timing control cover
- Mating surface between cylinder head and rocker cover
- Mating surface between front timing chain case and rear timing chain case
- Mating surface between rear timing chain case and cylinder head
- Mating surface between rear timing chain case and cylinder block
- Mating surface between rear timing chain case and oil pan (upper)
- Mating surface between cylinder block and cylinder head
- Mating surface between lower cylinder block and cylinder block
- Crankshaft oil seals (front and rear)

ENGINE OIL

< PERIODIC MAINTENANCE >

[VQ37VHR]

- Camshaft position sensor (PHASE) and intake valve timing control solenoid valve

OIL PRESSURE CHECK

WARNING:

- **Be careful not to get burn yourself, as engine oil may be hot.**
- **Oil pressure check should be done in "Parking position".**


1. Check the engine oil level.
2. Remove engine undercover with power tool.
3. Disconnect harness connector at oil pressure switch, and remove oil pressure switch (1) using deep socket (commercial service tool).

CAUTION:

Never drop or shock oil pressure switch.


- 2WD models

- 1 : Oil pressure switch
A : Vehicle under view
⇐ : Engine front




- AWD models

- A : Vehicle under view
⇐ : Vehicle front



4. Install the oil pressure gauge [SST: ST25051001] (A) and hose [SST: ST25052000] (B).



5. Start the engine and warm it up to normal operating temperature.
6. Check the engine oil pressure with engine running under no-load.

NOTE:

When the engine oil temperature is low, the engine oil pressure becomes high.

Engine oil pressure : Refer to [LU-20, "Engine Oil Pressure"](#).

If difference is extreme, check engine oil passage and oil pump for engine oil leakage.

7. After the inspections, install oil pressure switch as follows:
 - a. Remove old liquid gasket adhering to oil pressure switch and the mating surface.

- b. Apply liquid gasket and tighten oil pressure switch to the specification.
Use Genuine Liquid Gasket or equivalent.

Tightening torque : Refer to [LU-13, "Exploded View"](#).

- c. After warming up engine, check there is no leakage of engine oil with running engine.

Draining

INFOID:0000000010581916

WARNING:

- Be careful not to get burn yourself, as engine oil may be hot.
 - Prolonged and repeated contact with used engine oil may cause skin cancer. Try to avoid direct skin contact with used engine oil. If skin contact is made, wash thoroughly with soap or hand cleaner as soon as possible.
1. Warm up the engine, and check for engine oil leakage from engine components. Refer to [LU-8, "Inspection"](#).
 2. Stop the engine and wait for 10 minutes.
 3. Loosen oil filler cap.
 4. Remove undercover with power tool.
 5. Remove drain plug and then drain engine oil.

Refilling

INFOID:0000000010581917

1. Install drain plug with new washer. Refer to [EM-47, "Exploded View"](#).

CAUTION:

Be sure to clean drain plug and install with new washer.

Tightening torque

2WD models : Refer to [EM-47, "Exploded View"](#).

AWD models : Refer to [EM-47, "Exploded View"](#).

2. Refill with new engine oil.

Engine oil specification and viscosity: Refer to [MA-17, "FOR NORTH AMERICA : Fluids and Lubricants"](#) (For North America) or [MA-18, "FOR MEXICO : Fluids and Lubricants"](#) (For Mexico).

Engine oil capacity : Refer to [LU-20, "Periodical Maintenance Specification"](#).

CAUTION:

- When filling engine oil, never pull out oil level gauge.
 - The refill capacity depends on the engine oil temperature and drain time. Use these specifications for reference only.
 - Always use oil level gauge to determine the proper amount of engine oil in engine.
3. Warm up the engine and check area around drain plug and oil filter for engine oil leakage.
 4. Stop the engine and wait for 10 minutes.
 5. Check the engine oil level. Refer to [LU-8, "Inspection"](#).

OIL FILTER

Removal and Installation

INFOID:000000010581918

REMOVAL

CAUTION:


- Oil filter is provided with relief valve. Use genuine NISSAN oil filter or equivalent.
- Be careful not to get burned when engine and engine oil may be hot.
- When removing, prepare a shop cloth to absorb any engine oil leakage or spillage.
- Never allow engine oil to adhere to drive belt.
- Completely wipe off any engine oil that adheres to engine and vehicle.

1. Remove engine undercover with power tool.
 2. Using oil filter wrench [SST: KV10115801] (B), remove oil filter.
- 2WD models

A : Vehicle under view

B : Oil filter wrench

⇐ : Engine front




- AWD models

A : Vehicle under view


B : Oil filter wrench

⇐ : Engine front



INSTALLATION

1. Remove foreign materials adhering to oil filter installation surface.
2. Apply engine oil to the oil seal contact surface of new oil filter.



OIL FILTER


< PERIODIC MAINTENANCE >

[VQ37VHR]

3. Screw oil filter manually until it touches the installation surface, then tighten it by 2/3 turn (A). Or tighten to the specification.

Oil filter:

: 17.7 N·m (1.8 kg-m, 13 ft-lb)



INFOID:0000000010581919

Inspection

INSPECTION AFTER INSTALLATION

1. Check the engine oil level. Refer to [LU-8, "Inspection"](#).
2. Start the engine, and check there is no leakage of engine oil.
3. Stop the engine and wait for 10 minutes.
4. Check the engine oil level, and adjust the level. Refer to [LU-8, "Inspection"](#).

OIL FILTER BRACKET

< REMOVAL AND INSTALLATION >


[VQ37VHR]

REMOVAL AND INSTALLATION

OIL FILTER BRACKET

Exploded View

INFOID:0000000010581920



- | | | |
|---|---|------------------------|
| 1. Oil pan (upper) | 2. Gasket | 3. Relief valve |
| 4. Washer | 5. Oil temperature sensor | 6. Oil pressure switch |
| 7. Oil filter bracket | 8. O-ring | 9. Oil cooler |
| 10. Connector bolt | 11. Oil filter | |
| A. Comply with the installation procedure when tightening. Refer to LU-16 | B. Comply with the installation procedure when tightening. Refer to LU-11 | |

↩ : Engine front

Refer to [GI-4. "Components"](#) for symbols in the figure.

Removal and Installation

INFOID:0000000010581921

REMOVAL

WARNING:

Be careful not to get burn yourself, as engine oil may be hot.

1. Remove engine undercover with power tool.
2. Using the oil filter wrench [SST: KV10115801], remove oil filter. Refer to [LU-11. "Removal and Installation"](#).

CAUTION:

Never spill engine oil on drive belt.

3. Remove connector bolt, and then remove oil cooler without disconnecting water hoses.
4. Disconnect oil pressure switch harness connector and oil temperature sensor harness connector.
5. Remove oil filter bracket from oil pan (upper).
6. Remove oil pressure switch and oil temperature sensor from oil filter bracket.

OIL FILTER BRACKET

[VQ37VHR]

< REMOVAL AND INSTALLATION >

INSTALLATION

CAUTION:

Do not reuse O-rings or washers.

- Install oil pressure switch as follows:
 - Remove old liquid gasket adhering to oil filter bracket.
 - Apply liquid gasket and install oil pressure switch.

Use Genuine Liquid Gasket or equivalent.

Inspection

INFOID:0000000010581922

INSPECTION AFTER INSTALLATION

1. Check the engine oil level and add engine oil. Refer to [LU-8, "Inspection"](#).
2. Start the engine, and check there is no leakage of engine oil.
3. Stop the engine and wait for 10 minutes.
4. Check the engine oil level again. Refer to [LU-8, "Inspection"](#).

OIL COOLER


< REMOVAL AND INSTALLATION >

[VQ37VHR]

OIL COOLER

Exploded View

INFOID:0000000010581923



- | | | |
|-----------------------|-----------------|-------------------|
| 1. Oil filter bracket | 2. Relief valve | 3. O-ring |
| 4. Gasket | 5. Oil cooler | 6. Clamp |
| 7. Water hose | 8. Water hose | 9. Connector bolt |
| 10. Oil filter | 11. Water pipe | 12. Water hose |
| 13. Water hose | 14. Water pipe | 15. Heater pipe |

A. Comply with the installation procedure when tightening. Refer to [LU-11](#)

⇐ : Engine front

Refer to [GI-4, "Components"](#) for symbols in the figure.

Removal and Installation

INFOID:0000000010581924

REMOVAL

WARNING:

Be careful not to get burn yourself, as engine oil and engine coolant may be hot.

NOTE:

When removing oil cooler only, step 2 is unnecessary.

1. Remove engine undercover with power tool.
2. Drain engine coolant from radiator and cylinder block. Refer to [CO-10, "Draining"](#) and [EM-83, "Setting"](#).

NOTE:

Perform this step when removing water pipes.

3. Disconnect water hoses from oil cooler.

OIL COOLER

[VQ37VHR]

< REMOVAL AND INSTALLATION >

- When removing oil cooler only, pinching water hoses near oil cooler to prevent engine coolant from spilling out.
 - Remaining engine coolant in piping will come out. Use a tray to collect it.
- CAUTION:**
- **Perform this step when the engine is cold.**
 - **Never spill engine coolant on drive belt.**
4. Using oil filter wrench [SST: KV10115801], remove oil filter. Refer to [LU-11, "Removal and Installation"](#).
- CAUTION:**
- Never spill engine oil on drive belt.**
5. Remove connector bolt, and oil cooler.
- CAUTION:**
- Never spill engine oil to rubber parts such as drive belt and engine mounting insulator.**
6. Remove water pipes if necessary.

INSTALLATION


Note the following, and install in the reverse order of removal.

CAUTION:

Do not reuse O-rings.

- Check that no foreign objects are adhering to the installation planes of oil filter and oil cooler bracket.
- Align cutout (B) on oil cooler (1) with protrusion (A) on oil filter bracket (2) side, and tighten connector bolt (3).

⇐ : Engine front



INFOID:0000000010581925

Inspection

INSPECTION AFTER REMOVAL

Oil Cooler

Check oil cooler for cracks. Check oil cooler for clogging by blowing through engine coolant inlet. If necessary, replace oil cooler.

Relief Valve

Check relief valve with the following procedure.

- Press steel ball of relief valve using a clean plastic stick. Check that valve moves smoothly and proper spring repulsion is felt.
- Replace relief valve, if necessary, with the following procedure.
- Remove the relief valve by prying using a screwdriver.

CAUTION:

Be careful not to damage the mounting hole.

- Press in the relief valve until it reaches a depth of 7 mm (0.28 in) from end surface of oil filter bracket using approximately 10 mm (0.39 in) diameter drift.

CAUTION:

Carefully press in the relief valve by aligning its mounting hole side with the axle center so as not to cause deformation.

INSPECTION AFTER INSTALLATION


1. Check the engine oil level and the engine coolant level and add engine oil and engine coolant. Refer to [LU-8, "Inspection"](#) and [CO-10, "Inspection"](#).
2. Start the engine, and check there is no leakage of engine oil or engine coolant.
3. Stop the engine and wait for 10 minutes.
4. Check the engine oil level and the engine coolant level again. Refer to [LU-8, "Inspection"](#) and [CO-10, "Inspection"](#).

UNIT DISASSEMBLY AND ASSEMBLY

OIL PUMP

Exploded View

INFOID:000000010581926



- | | | |
|---------------------------|-------------------------|---------------------------|
| 1. Oil pump body | 2. Oil pump outer rotor | 3. Oil pump inner rotor |
| 4. Oil pump cover | 5. Regulator valve plug | 6. Regulator valve spring |
| 7. Regulator valve spring | 8. Regulator valve | |

Refer to [GI-4, "Components"](#) for symbols in the figure.

Disassembly and Assembly

INFOID:000000010581927

DISASSEMBLY

1. Remove oil pan (lower). Refer to [EM-47, "Exploded View"](#).
2. Remove oil pan (upper). Refer to [EM-47, "Exploded View"](#).
3. Remove front timing chain case and timing chain (primary). Refer to [EM-54, "Exploded View"](#).
4. Remove oil pump assembly.
5. Remove oil pump cover.
6. Remove oil pump inner rotor and oil pump outer rotor from oil pump body.
7. After removing regulator valve plug, remove regulator valve spring and regulator valve.

ASSEMBLY

Note the following, and assemble in the reverse order of disassembly.


CAUTION:

Before assembly, apply new engine oil to the parts as instructed in the figure.

- Install oil pump inner rotor with the groove faced to oil pump cover side.

- | | |
|---|-----------------------|
| A | : Oil pump body side |
| B | : Oil pump cover side |
| C | : Groove |

- When installing oil pump, align crankshaft flat faces with oil pump inner rotor flat faces.



JP8IA0084ZZ

Inspection

INSPECTION AFTER DISASSEMBLY

Oil Pump Clearance

- Measure the clearance with feeler gauge (C).
- Clearance between oil pump outer rotor and oil pump body [position (B)]

Standard : Refer to [LU-20, "Oil Pump"](#).

- Tip clearance between oil pump inner rotor and oil pump outer rotor [position (A)]



Standard : Refer to [LU-20, "Oil Pump"](#).

- Measure the clearance with feeler gauge and straightedge (A).
- Side clearance between oil pump inner rotor and oil pump body [position (C)]

Standard : Refer to [LU-20, "Oil Pump"](#).

- Side clearance between oil pump outer rotor and oil pump body [position (B)]

Standard : Refer to [LU-20, "Oil Pump"](#).




- Calculate the clearance between oil pump inner rotor and oil pump body as follows:

OIL PUMP BODY INNER DIAMETER

- Measure the inner diameter of oil pump body with inside micrometer. [position (A)]

OIL PUMP INNER ROTOR OUTER DIAMETER

- Measure the outer diameter of protruded portion of oil pump inner rotor (1) with micrometer. [position (B)]



OIL PUMP INNER ROTOR TO OIL PUMP BODY CLEARANCE

- (Clearance) = (Oil pump body inner diameter) – (Oil pump inner rotor outer diameter)

Standard : Refer to [LU-20, "Oil Pump"](#).

- If measured/calculated values are out of the standard, replace oil pump assembly.

Regulator Valve Clearance

OIL PUMP

< UNIT DISASSEMBLY AND ASSEMBLY >

[VQ37VHR]

(Clearance) = (Regulator valve hole diameter) – (Regulator valve outer diameter)

- 1 : Regulator valve
- 2 : Oil pump body

Standard : Refer to [LU-20, "Regulator Valve"](#).


- If the calculated value is out of the standard, replace oil pump assembly.

CAUTION:

- Coat regulator valve with engine oil.
- Check that it falls smoothly into valve hole by its own weight.

INSPECTION AFTER INSTALLATION

1. Check the engine oil level. Refer to [LU-8, "Inspection"](#).
2. Start the engine, and check there is no leakage of engine oil.
3. Stop the engine and wait for 10 minutes.
4. Check the engine oil level and adjust the level. Refer to [LU-8, "Inspection"](#).



A

LU

C

D

E

F

G

H

I

J

K

L

M

N

O

P

SERVICE DATA AND SPECIFICATIONS (SDS)

< SERVICE DATA AND SPECIFICATIONS (SDS)

[VQ37VHR]

SERVICE DATA AND SPECIFICATIONS (SDS)

SERVICE DATA AND SPECIFICATIONS (SDS)

Periodical Maintenance Specification

INFOID:0000000010581929

ENGINE OIL CAPACITY (APPROXIMATELY)

Unit: ℓ (US qt, Imp qt)

Drain and refill	With oil filter change	4.9 (5-1/8, 4-1/4)
	Without oil filter change	4.6 (4-7/8, 4)
Dry engine (Overhaul)		5.7 (6, 5)

Engine Oil Pressure

INFOID:0000000010581930

Unit: kPa (bar, kg/cm², psi)

Engine speed	Approximate discharge pressure*
Idle speed	More than 98 (0.98, 1.0, 14)
2,000 rpm	More than 294 (2.94, 3.0, 43)

*: Engine oil temperature at 80°C (176°F)

Oil Pump

INFOID:0000000010581931

Unit: mm (in)

Oil pump body to oil pump outer rotor radial clearance	0.114 - 0.260 (0.0045 - 0.0102)
Oil pump inner rotor to oil pump outer rotor tip clearance	Below 0.180 (0.0071)
Oil pump body to oil pump inner rotor axial clearance	0.030 - 0.070 (0.0012 - 0.0028)
Oil pump body to oil pump outer rotor axial clearance	0.030 - 0.090 (0.0012 - 0.0035)
Oil pump inner rotor to brazed portion of housing clearance	0.045 - 0.091 (0.0018 - 0.0036)

Regulator Valve

INFOID:0000000010581932

Unit: mm (in)


Regulator valve to oil pump body clearance	0.040 - 0.097 (0.0016 - 0.0038)
--	---------------------------------

SYSTEM DESCRIPTION

DESCRIPTION

Engine Lubrication System

INFOID:000000010581933




DESCRIPTION

< SYSTEM DESCRIPTION >

[VK50VE]

Engine Lubrication System Schematic

INFOID:000000010581934



PRECAUTION

PRECAUTIONS

Precautions for Removing Battery Terminal

INFOID:0000000011004991

- When removing the 12V battery terminal, turn OFF the ignition switch and wait at least 30 seconds.

NOTE:

ECU may be active for several tens of seconds after the ignition switch is turned OFF. If the battery terminal is removed before ECU stops, then a DTC detection error or ECU data corruption may occur.

- For vehicles with the 2-batteries, be sure to connect the main battery and the sub battery before turning ON the ignition switch.


NOTE:

If the ignition switch is turned ON with any one of the terminals of main battery and sub battery disconnected, then DTC may be detected.

- After installing the 12V battery, always check "Self Diagnosis Result" of all ECUs and erase DTC.

NOTE:

The removal of 12V battery may cause a DTC detection error.



Liquid Gasket

INFOID:0000000010581935

LIQUID GASKET APPLICATION PROCEDURE

- Remove old liquid gasket adhering to the liquid gasket application surface and the mating surface.
 - Remove liquid gasket completely from the liquid gasket application surface, mounting bolts, and bolt holes.
- Wipe the liquid gasket application surface and the mating surface with white gasoline (lighting and heating use) to remove adhering moisture, grease and foreign matter.
- Apply liquid gasket to the liquid gasket application surface.

Use Genuine RTV Silicone Sealant or an equivalent. Refer to [GI-24, "Recommended Chemical Products and Sealants"](#).

 - Within five minutes of liquid gasket application, install the mating component.
 - If liquid gasket protrudes, wipe it off immediately.
 - Do not retighten mounting bolts or nuts after the installation.
 - After 30 minutes or more have passed from the installation, fill engine oil and engine coolant.

Precautions For Engine Service

INFOID:0000000010581936

DISCONNECTING FUEL PIPING

- Before starting work, check no fire or spark producing items are in the work area.
- Release fuel pressure before disconnecting and disassembly.
- After disconnecting pipes, plug openings to stop fuel leakage.

DRAINING ENGINE COOLANT

Drain engine coolant and engine oil when the engine is cooled.

INSPECTION, REPAIR AND REPLACEMENT

Before repairing or replacing, thoroughly inspect parts. Inspect new replacement parts in the same way, and replace if necessary.

REMOVAL AND DISASSEMBLY

- When instructed to use SST, use specified tools. Always be careful to work safely, avoid forceful or uninstructed operations.
- Exercise maximum care to avoid damage to mating or sliding surfaces.

PRECAUTIONS

[VK50VE]

< PRECAUTION >

- Dowel pins are used for several parts alignment. When replacing and reassembling parts with dowel pins, check that dowel pins are installed in the original position.
- Must cover openings of engine system with a tape or equivalent, to seal out foreign materials.
- Mark and arrange disassembly parts in an organized way for easy troubleshooting and reassembly.
- When loosening nuts and bolts, as a basic rule, start with the one furthest outside, then the one diagonally opposite, and so on. If the order of loosening is specified, do exactly as specified. Power tools may be used in the step.

ASSEMBLY AND INSTALLATION

- Use torque wrench to tighten bolts or nuts to specification.
- When tightening nuts and bolts, as a basic rule, equally tighten in several different steps starting with the ones in center, then ones on inside and outside diagonally in this order. If the order of tightening is specified, do exactly as specified.
- Replace with new gasket, packing, oil seal or O-ring.
- Thoroughly wash, clean, and air-blow each part. Carefully check engine oil or engine coolant passages for any restriction and blockage.
- Avoid damaging sliding or mating surfaces. Completely remove foreign materials such as cloth lint or dust. Before assembly, oil sliding surfaces well.
- After disassembling, or exposing any internal engine parts, change engine oil and replace oil filter with a new one.
- Release air within route when refilling after draining engine coolant.
- After repairing, start the engine and increase engine speed to check engine coolant, fuel, engine oil, and exhaust gases for leakage.

PREPARATION

< PREPARATION >

[VK50VE]




PREPARATION

PREPARATION

Special Service Tools


INFOID:0000000010581937

The actual shapes of TechMate tools may differ from those of special service tools illustrated here.

Tool number (TechMate No.) Tool name	Description
ST25051001 (J25695-1) Oil pressure gauge	Measuring oil pressure Maximum measuring range: 2,452 kPa (25 kg/cm², 356 psi)
NT050	
ST25052000 (J25695-2) Hose	Adapting oil pressure gauge to oil pan (upper)
S-NT559	
KV10115801 (J38956) Oil filter wrench	Removing and installing oil filter a: 64.3 mm (2.531 in)
S-NT375	

Commercial Service Tools

INFOID:0000000010581938

Tool name	Description
Power tools	Loosening bolts and nuts
PBIC0190E	

PERIODIC MAINTENANCE

ENGINE OIL

Inspection


INFOID:000000010581939

ENGINE OIL LEVEL

NOTE:

Before starting engine, put vehicle horizontally and check the engine oil level. If engine is already started, stop it and allow 10 minutes before checking.

1. Pull out oil level gauge and wipe it clean.
2. Insert oil level gauge and check the engine oil level is within the range (A) shown in the figure.
3. If it is out of range, adjust it.




JPBIA0070ZZ

NOTE:

When checking the engine oil level, insert oil level gauge (1) with its tip aligned with oil level gauge guide.

↔ : Vehicle front



JPBIA2330ZZ

ENGINE OIL APPEARANCE

- Check engine oil for white turbidity or heavy contamination.
- If engine oil becomes turbid and white, it is highly probable that it is contaminated with engine coolant. Repair or replace damaged parts.

ENGINE OIL LEAKAGE

Check for engine oil leakage around the following areas:

- Oil pans (lower and upper)
- Oil pan drain plug
- Oil pressure switch
- Oil temperature sensor
- Oil filter
- Oil cooler
- Front cover
- Valve timing control cover
- Timing chain tensioner cover
- VVEL actuator sub assembly
- Crankshaft oil seals (front and rear)
- Camshaft position sensor and valve timing control solenoid valve (INT and EXH)
- Mating surface between cylinder head and VVEL ladder assembly
- Mating surface between VVEL ladder assembly and rocker cover
- Mating surface between cylinder block and cylinder head

OIL PRESSURE CHECK

ENGINE OIL

< PERIODIC MAINTENANCE >

[VK50VE]

WARNING:


- Be careful not to get burned, as engine oil may be hot.
- Oil pressure check should be done in "Parking position".

1. Check the engine oil level.
2. Remove engine undercover with power tool.
3. Disconnect harness connector at oil pressure switch (1), and remove oil pressure switch.


⇐ : Engine front

CAUTION:

Never drop or impact oil pressure switch.



4. Install the oil pressure gauge [SST: ST25051001 (J25695-1)] (A) and hose [SST: ST25052000 (J25695-2)] (B).



5. Start the engine and warm it up to normal operating temperature.
6. Check the engine oil pressure with engine running under no-load.

NOTE:

When the engine oil temperature is low, the engine oil pressure becomes high.

Engine oil pressure : Refer to [LU-34, "Engine Oil Pressure"](#).

If difference is extreme, check engine oil passage and oil pump for engine oil leakage.

7. After the inspections, install oil pressure switch as per the following:
 - a. Remove old liquid gasket adhering to oil pressure switch and the mating surface.
 - b. Apply liquid gasket and tighten oil pressure switch to the specification.

Use Genuine RTV Silicone Sealant or an equivalent. Refer to [GI-24, "Recommended Chemical Products and Sealants"](#).

Tightening torque : Refer to [EM-198, "Exploded View"](#).

- c. After warming up engine, check there is no leakage of engine oil with running engine.

Draining

INFOID:0000000010581940

WARNING:

- Be careful not to get burned, as engine oil may be hot.
- Prolonged and repeated contact with used engine oil may cause skin cancer. Try to avoid direct skin contact with used engine oil. If skin contact is made, wash thoroughly with soap or hand cleaner as soon as possible.

1. Warm up the engine, and check for engine oil leakage from engine components. Refer to [LU-26, "Inspection"](#).
2. Stop the engine and wait for 15 minutes.
3. Loosen oil filler cap.

4. Remove drain plug and then drain engine oil.

Refilling

INFOID:0000000010581941

1. Install drain plug with new washer.

CAUTION:

Be sure to clean drain plug and install with new washer.

Tightening torque : Refer to [EM-198, "Exploded View"](#).

2. Refill with new engine oil.

Engine oil specification and viscosity:

Refer to [MA-17, "FOR NORTH AMERICA : Fluids and Lubricants"](#).

Engine oil capacity : Refer to [LU-34, "Periodical Maintenance Specification"](#).

CAUTION:

- The refill capacity depends on the engine oil temperature and drain time. Use these specifications for reference only.
- Always use oil level gauge to determine the proper amount of engine oil in engine.

3. Warm up the engine and check area around drain plug and oil filter for engine oil leakage.
4. Stop the engine and wait for 15 minutes.
5. Check the engine oil level. Refer to [LU-26, "Inspection"](#).

OIL FILTER

Removal and Installation


INFOID:000000010581942

REMOVAL

CAUTION:


- Oil filter is provided with relief valve. Use genuine NISSAN oil filter or an equivalent.
- Be careful not to get burned when engine and engine oil may be hot.
- When removing, prepare a shop cloth to absorb any engine oil leakage or spillage.
- Never allow engine oil to adhere to drive belts.
- Completely wipe off any engine oil that adheres to engine and vehicle.

1. Remove engine undercover with power tool.
2. Using oil filter wrench [SST: KV10115801 (J38956)] (A), remove oil filter.



INSTALLATION


1. Remove foreign matter adhering to oil filter installation surface.
2. Apply engine oil to the oil seal contact surface of new oil filter.



3. Screw oil filter manually until it touches the installation surface, then tighten it by 2/3 turn (A). Or tighten to the specification.

Oil filter:

: 17.7 N·m (1.8 kg-m, 13 ft-lb)



Inspection

INFOID:000000010581943

INSPECTION AFTER INSTALLATION


1. Check the engine oil level. Refer to [LU-26, "Inspection"](#).
2. Start the engine, and check there is no leakage of engine oil.
3. Stop the engine and wait for 15 minutes.
4. Check the engine oil level, and adjust the level. Refer to [LU-26, "Inspection"](#).

REMOVAL AND INSTALLATION

OIL COOLER

Exploded View

INFOID:0000000010581944



- | | | |
|-------------------|--------------------------|---|
| 1. Clamp | 2. Water pipe | 3. Water hose |
| 4. Oil filter | 5. Connector bolt | 6. Oil cooler |
| 7. Relief valve | 8. Water hose | |
| A. To water inlet | B. To thermostat housing | C. Comply with the installation procedure when tightening. Refer to LU-29 |

↩ : Engine front

Refer to [GI-4, "Components"](#) for symbols in the figure.

Removal and Installation

INFOID:0000000010581945

REMOVAL

WARNING:

Be careful not to get burned, as engine oil and engine coolant may be hot.

1. Remove engine undercover with power tool.
2. Drain engine coolant from radiator. Refer to [LU-27, "Draining"](#).
3. Remove the following parts:
 - Engine room cover: Refer to [EM-184, "Exploded View"](#).
 - Reservoir tank: Refer to [CO-43, "Exploded View"](#).
 - Alternator, water pump and A/C compressor belt: Refer to [EM-173, "Exploded View"](#).
4. Remove water suction pipe mounting bolt. Refer to [CO-51, "Exploded View"](#).
5. Disconnect water hoses and water pipe.
 - When removing oil cooler only, pinch water hoses near oil cooler to prevent engine coolant from spilling out.

OIL COOLER

< REMOVAL AND INSTALLATION >

[VK50VE]

- Remaining engine coolant in piping will come out. Use a tray to collect it.

CAUTION:

- **Perform this step when the engine is cold.**
- **Never spill engine coolant on drive belts.**

6. Remove oil filter. Refer to [LU-29, "Removal and Installation"](#).

7. Loosen connector bolt, and remove oil cooler.

CAUTION:


Never spill engine oil on rubber parts such as drive belts and engine mounting insulator.

INSTALLATION

Note the following items, and install in the reverse order of removal.

- Check that no foreign objects are adhering to the installation planes of oil filter and oil pan (upper).
- Align cutout (A) on oil cooler (1) with protrusion (B) on oil pan (upper) side, and tighten connector bolt.

⇐ : Engine front



INFOID:000000010581946

Inspection

INSPECTION AFTER REMOVAL

Oil Cooler

Check oil cooler for cracks. Check oil cooler for clogging by blowing through engine coolant inlet. If necessary, replace oil cooler.

Relief Valve

Check relief valve with the following procedure.

- Press steel ball of relief valve using a clean plastic stick. Check that valve moves smoothly and proper spring repulsion is felt.
- Replace relief valve, if necessary, with the following procedure.
- Remove the relief valve by prying using a screwdriver.

CAUTION:

Be careful not to damage the mounting hole.

- Press in the relief valve until it reaches a depth of 7 mm (0.28 in) from end surface of oil pan (upper) using approximately 12 mm (0.47 in) diameter drift.

CAUTION:

Carefully press in the relief valve by aligning its mounting hole side with the axle center so as not to cause deformation.

INSPECTION AFTER INSTALLATION


1. Check the engine oil level and the engine coolant level and add engine oil and engine coolant. Refer to [CO-37, "Inspection"](#) and [LU-26, "Inspection"](#).
2. Start the engine, and check there is no leaks of engine oil or engine coolant.
3. Stop the engine and wait for 15 minutes.
4. Check the engine oil level and the engine coolant level again. Refer to [CO-37, "Inspection"](#) and [LU-26, "Inspection"](#).

UNIT DISASSEMBLY AND ASSEMBLY

OIL PUMP

Exploded View

INFOID:000000010581947



- | | | |
|-------------------------|--------------------------------------|-----------------|
| 1. Oil pump drive chain | 2. Oil pump sprocket (oil pump side) | 3. Oil strainer |
| 4. Gasket | 5. Oil pump | |

Refer to [GI-4, "Components"](#) for symbols in the figure.

Disassembly and Assembly

INFOID:000000010581948

DISASSEMBLY

1. Remove oil pan (lower) and oil strainer. Refer to [EM-198, "Exploded View"](#).
2. Remove oil pan (upper). Refer to [EM-219, "Exploded View"](#).
3. Remove front cover. Refer to [EM-223, "Exploded View"](#).
4. Remove oil pump drive chain.
 - Instruction for oil pump drive chain. Refer to [EM-224, "Disassembly and Assembly"](#).
5. Remove oil pump.

CAUTION:

Never disassembly oil pump.

ASSEMBLY

Assembly is the reverse order of disassembly.

Inspection

INFOID:000000010581949

INSPECTION AFTER INSTALLATION

1. Check the engine oil level. Refer to [LU-26, "Inspection"](#).
2. Start the engine, and check there is no leakage of engine oil.
3. Stop the engine and wait for 15 minutes.

OIL PUMP

< UNIT DISASSEMBLY AND ASSEMBLY >

[VK50VE]

4. Check the engine oil level and adjust the level. Refer to [LU-26. "Inspection"](#).

A

LU

C

D

E

F

G

H

I

J

K

L

M

N

O

P

SERVICE DATA AND SPECIFICATIONS (SDS)

< SERVICE DATA AND SPECIFICATIONS (SDS)

[VK50VE]

SERVICE DATA AND SPECIFICATIONS (SDS)

SERVICE DATA AND SPECIFICATIONS (SDS)

Periodical Maintenance Specification

INFOID:0000000010581950

ENGINE OIL CAPACITY (APPROXIMATELY)

Unit: ℓ (US qt, Imp qt)

Drain and refill	With oil filter change	6.7 (7-1/8, 5-7/8)
	Without oil filter change	5.8 (6-1/8, 5-1/8)
Dry engine (Overhaul)		7.2 (7-5/8, 6-3/8)

Engine Oil Pressure

INFOID:0000000010581951

Unit: kPa (kg/cm², psi)

Engine speed	Approximate discharge pressure*
600 rpm	More than 98 (1.0, 14)
2,000 rpm	More than 294 (3.0, 43)

*: Engine oil temperature at 80°C (176°F)