

SECTION **EI**

EXTERIOR & INTERIOR

CONTENTS

PRECAUTIONS	3	COWL TOP	20
Precautions for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"	3	Removal and Installation	20
Precautions	3	REMOVAL	20
		INSTALLATION	20
PREPARATION	4	FENDER PROTECTOR	21
Commercial Service Tools	4	Removal and Installation	21
SQUEAK AND RATTLE TROUBLE DIAGNOSES	5	REMOVAL	21
Work Flow	5	INSTALLATION	21
CUSTOMER INTERVIEW	5	DOOR OUTSIDE MOLDING	22
DUPLICATE THE NOISE AND TEST DRIVE	6	Removal and Installation	22
CHECK RELATED SERVICE BULLETINS	6	REMOVAL	22
LOCATE THE NOISE AND IDENTIFY THE ROOT CAUSE	6	INSTALLATION	23
REPAIR THE CAUSE	6	SIDE GUARD MOLDING	24
CONFIRM THE REPAIR	7	Removal and Installation	24
Generic Squeak and Rattle Troubleshooting	7	REMOVAL	24
INSTRUMENT PANEL	7	INSTALLATION	24
CENTER CONSOLE	7	DOOR OUTSIDE LOWER MOLDING	25
DOORS	7	Removal and Installation	25
TRUNK	8	REMOVAL	25
SUNROOF/HEADLINING	8	INSTALLATION	25
SEATS	8	SIDE SILL PROTECTOR	26
UNDERHOOD	8	Removal and Installation	26
Diagnostic Worksheet	9	REMOVAL	26
CLIP AND FASTENER	11	INSTALLATION	26
Clip and Fastener	11	ROOF RAIL	27
FRONT BUMPER	14	Removal and Installation (for Hyper Roof Rail)	27
Removal and Installation	14	REMOVAL	27
REMOVAL	16	INSTALLATION	27
INSTALLATION	16	Removal and Installation (for Roof Rail)	28
REAR BUMPER	17	REMOVAL	28
Removal and Installation	17	INSTALLATION	29
REMOVAL	17	ROOF SPOILER	30
INSTALLATION	18	Removal and Installation	30
FRONT GRILLE	19	REMOVAL	30
Removal and Installation	19	INSTALLATION	30
REMOVAL	19	LICENSE LAMP FINISHER	31
INSTALLATION	19	Removal and Installation	31
		REMOVAL	31
		INSTALLATION	31

DOOR FINISHER	32	FLOOR TRIM	38
Removal and Installation	32	Removal and Installation	38
FRONT AND REAR	32	REMOVAL	38
BACK DOOR TRIM	34	INSTALLATION	38
Removal and Installation	34	HEADLINING	39
REMOVAL	34	Removal and Installation	39
INSTALLATION	34	REMOVAL	39
BODY SIDE TRIM	35	INSTALLATION	40
Removal and Installation	35		
CENTER PILLAR LOWER GARNISH	36		
CENTER PILLAR UPPER GARNISH	36		
LUGGAGE SIDE LOWER FINISHER	36		
REAR PILLAR FINISHER	36		
DASHBOARD SIDE FINISHER	36		
BODY SIDE WELT	36		

PRECAUTIONS

PRECAUTIONS

PFP:00001

Precautions for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"

EIS0047M

The Supplemental Restraint System such as "AIR BAG" and "SEAT BELT PRE-TENSIONER", used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. Information necessary to service the system safely is included in the SRS and SB section of this Service Manual.

WARNING:

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision which would result in air bag inflation, all maintenance must be performed by an authorized NISSAN/INFINITI dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see the SRS section.
- Do not use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harnesses or harness connectors.

Precautions

EIS001NX

- When removing or disassembling any part, be careful not to damage or deform it. Protect parts, which may get in the way with cloth.
- When removing parts with a screwdriver or other tool, protect parts by wrapping them with vinyl or tape.
- Keep removed parts protected with cloth.
- If a clip is deformed or damaged, replace it.
- If an unreusable part is removed, replace it with a new one.
- Tighten bolts and nuts firmly to the specified torque.
- After re-assembly has been completed, make sure each part functions correctly.
- Remove stains in the following way.

Water-soluble stains:

Dip a soft cloth in warm water, and then squeeze it tightly. After wiping the stain, wipe with a soft dry cloth.

Oil stain:

Dissolve a synthetic detergent in warm water (density of 2 to 3% or less), dip the cloth, then clean off the stain with the cloth. Next, dip the cloth in fresh water and squeeze it tightly. Then clean off the detergent completely. Then wipe the area with a soft dry cloth.

- Do not use any organic solvent, such as thinner or benzine.

A

B

C

D

E

F

G

H

EI

J

K

L

M


PREPARATION

PREPARATION

PFP:00002

Commercial Service Tools

EIS008NS

Tool name	Description
Engine ear  SIIA0995E	Location the noise

SQUEAK AND RATTLE TROUBLE DIAGNOSES


SQUEAK AND RATTLE TROUBLE DIAGNOSES

PFP:00000

Work Flow

EIS008NT

A
B
C
D
E
F
G
H
I
J
K
L
M



CUSTOMER INTERVIEW

Interview the customer if possible, to determine the conditions that exist when the noise occurs. Use the Diagnostic Worksheet during the interview to document the facts and conditions when the noise occurs and any customer's comments; refer to [EI-9, "Diagnostic Worksheet"](#). This information is necessary to duplicate the conditions that exist when the noise occurs.

- The customer may not be able to provide a detailed description or the location of the noise. Attempt to obtain all the facts and conditions that exist when the noise occurs (or does not occur).
- If there is more than one noise in the vehicle, be sure to diagnose and repair the noise that the customer is concerned about. This can be accomplished by test driving the vehicle with the customer.
- After identifying the type of noise, isolate the noise in terms of its characteristics. The noise characteristics are provided so the customer, service adviser and technician are all speaking the same language when defining the noise.
- **Squeak**—(Like tennis shoes on a clean floor)
Squeak characteristics include the light contact/fast movement/brought on by road conditions/hard surfaces=higher pitch noise/softer surfaces=lower pitch noises/edge to surface=chirping
- **Creak**—(Like walking on an old wooden floor)
Creak characteristics include firm contact/slow movement/twisting with a rotational movement/pitch dependent on materials/often brought on by activity.
- **Rattle**—(Like shaking a baby rattle)
Rattle characteristics include the fast repeated contact/vibration or similar movement/loose parts/missing clip or fastener/incorrect clearance.
- **Knock**—(Like a knock on a door)
Knock characteristics include hollow sounding/sometimes repeating/often brought on by driver action.
- **Tick**—(Like a clock second hand)
Tick characteristics include gentle contacting of light materials/loose components/can be caused by driver action or road conditions.
- **Thump**—(Heavy, muffled knock noise)
Thump characteristics include softer knock/dead sound often brought on by activity.
- **Buzz**—(Like a bumble bee)
Buzz characteristics include high frequency rattle/firm contact.
- Often the degree of acceptable noise level will vary depending upon the person. A noise that you may judge as acceptable may be very irritating to the customer.
- Weather conditions, especially humidity and temperature, may have a great effect on noise level.

SQUEAK AND RATTLE TROUBLE DIAGNOSES

DUPLICATE THE NOISE AND TEST DRIVE

If possible, drive the vehicle with the customer until the noise is duplicated. Note any additional information on the Diagnostic Worksheet regarding the conditions or location of the noise. This information can be used to duplicate the same conditions when you confirm the repair.

If the noise can be duplicated easily during the test drive, to help identify the source of the noise, try to duplicate the noise with the vehicle stopped by doing one or all of the following:

- 1) Close a door.
 - 2) Tap or push/pull around the area where the noise appears to be coming from.
 - 3) Rev the engine.
 - 4) Use a floor jack to recreate vehicle "twist".
 - 5) At idle, apply engine load (electrical load, half-clutch on M/T model, drive position on A/T model).
 - 6) Raise the vehicle on a hoist and hit a tire with a rubber hammer.
- Drive the vehicle and attempt to duplicate the conditions the customer states exist when the noise occurs.
 - If it is difficult to duplicate the noise, drive the vehicle slowly on an undulating or rough road to stress the vehicle body.

CHECK RELATED SERVICE BULLETINS

After verifying the customer concern or symptom, check ASIST for Technical Service Bulletins (TSBs) related to that concern or symptom.

If a TSB relates to the symptom, follow the procedure to repair the noise.

LOCATE THE NOISE AND IDENTIFY THE ROOT CAUSE

1. Narrow down the noise to a general area. To help pinpoint the source of the noise, use a listening tool (Engine Ear or mechanics stethoscope).
2. Narrow down the noise to a more specific area and identify the cause of the noise by:
 - removing the components in the area that you suspect the noise is coming from.
Do not use too much force when removing clips and fasteners, otherwise clips and fastener can be broken or lost during the repair, resulting in the creation of new noise.
 - tapping or pushing/pulling the component that you suspect is causing the noise.
Do not tap or push/pull the component with excessive force, otherwise the noise will be eliminated only temporarily.
 - feeling for a vibration with your hand by touching the component(s) that you suspect is (are) causing the noise.
 - placing a piece of paper between components that you suspect are causing the noise.
 - looking for loose components and contact marks.

Refer to [EI-7, "Generic Squeak and Rattle Troubleshooting"](#) .

REPAIR THE CAUSE

- If the cause is a loose component, tighten the component securely.
- If the cause is insufficient clearance between components:
 - separate components by repositioning or loosening and retightening the component, if possible.
 - insulate components with a suitable insulator such as urethane pads, foam blocks, felt cloth tape or urethane tape are available through your authorized Nissan Parts Department.

CAUTION:

Do not use excessive force as many components are constructed of plastic and may be damaged.

NOTE:

Always check with the Parts Department for the latest parts information.

Each item can be ordered separately as needed.

URETHANE PADS [1.5 mm (0.059 in) thick]

Insulates connectors, harness, etc.

76268-9E005: 100 × 135 mm (3.94 × 5.31 in)/76884-71L01: 60×85 mm (2.36 × 3.35 in)/76884-71L02: 15 × 25 mm (0.59 × 0.98 in)

INSULATOR (Foam blocks)

Insulates components from contact. Can be used to fill space behind a panel.

73982-9E000: 45 mm (1.77 in) thick, 50 × 50 mm (1.97 × 1.97 in)/73982-50Y00: 10 mm (0.39 in) thick, 50 × 50 mm (1.97 × 1.97 in)

INSULATOR (Light foam block)

80845-71L00: 30 mm (1.18 in) thick, 30 × 50 mm (1.18 × 1.97 in)

SQUEAK AND RATTLE TROUBLE DIAGNOSES

FELT CLOTHTAPE

Used to insulate where movement does not occur. Ideal for instrument panel applications.

68370-4B000: 15 × 25 mm (0.59 × 0.98 in) pad/68239-13E00: 5 mm (0.20 in) wide tape roll

The following materials, not available through NISSAN Parts Department, can also be used to repair squeaks and rattles.

UHMW(TEFLON) TAPE

Insulates where slight movement is present. Ideal for instrument panel applications.

SILICONE GREASE

Used in of UHMW tape that will be visible or not fit.

Note: Will only last a few months.

SILICONE SPRAY

Use when grease cannot be applied.

DUCT TAPE

Use to eliminate movement.

A

B

C

D

E

F

EIS008NU

G

H

EI

J

K

L

M

CONFIRM THE REPAIR

Confirm that the cause of a noise is repaired by test driving the vehicle. Operate the vehicle under the same conditions as when the noise originally occurred. Refer to the notes on the Diagnostic Worksheet.

Generic Squeak and Rattle Troubleshooting

Refer to Table of Contents for specific component removal and installation information.

INSTRUMENT PANEL

Most incidents are caused by contact and movement between:

1. Cluster lid A and instrument panel
2. Acrylic lens and combination meter housing
3. Instrument panel to front pillar garnish
4. Instrument panel to windshield
5. Instrument panel mounting pins
6. Wiring harnesses behind the combination meter
7. A/C defroster duct and duct joint

These incidents can usually be located by tapping or moving the components to duplicate the noise or by pressing on the components while driving to stop the noise. Most of these incidents can be repaired by applying felt cloth tape or silicon spray (in hard to reach areas). Urethane pads can be used to insulate wiring harness.

CAUTION:

Do not use silicone spray to isolate a squeak or rattle. If you saturate the area with silicone, you will not be able to recheck the repair.

CENTER CONSOLE

Components to pay attention to include:

1. Shifter assembly cover to finisher
2. A/C control unit and cluster lid C
3. Wiring harnesses behind audio and A/C control unit

The instrument panel repair and isolation procedures also apply to the center console.

DOORS

Pay attention to the:

1. Finisher and inner panel making a slapping noise
2. Inside handle escutcheon to door finisher
3. Wiring harnesses tapping
4. Door striker out of alignment causing a popping noise on starts and stops

Tapping or moving the components or pressing on them while driving to duplicate the conditions can isolate many of these incidents. You can usually insulate the areas with felt cloth tape or insulator foam blocks to repair the noise.

SQUEAK AND RATTLE TROUBLE DIAGNOSES

TRUNK

Trunk noises are often caused by a loose jack or loose items put into the trunk by the owner.

In addition look for:

1. Trunk lid dumpers out of adjustment
2. Trunk lid striker out of adjustment
3. Trunk lid torsion bars knocking together
4. A loose license plate or bracket

Most of these incidents can be repaired by adjusting, securing or insulating the item(s) or component(s) causing the noise.

SUNROOF/HEADLINING

Noises in the sunroof/headlining area can often be traced to one of the following:

1. Sunroof lid, rail, linkage or seals making a rattle or light knocking noise
2. Sun-visor shaft shaking in the holder
3. Front or rear windshield touching headlining and squeaking

Again, pressing on the components to stop the noise while duplicating the conditions can isolate most of these incidents. Repairs usually consist of insulating with felt cloth tape.

SEATS

When isolating seat noise it's important to note the position the seat is in and the load placed on the seat when the noise is present. These conditions should be duplicated when verifying and isolating the cause of the noise.

Cause of seat noise include:

1. Headrest rods and holder
2. A squeak between the seat pad cushion and frame
3. Rear seat back lock and bracket

These noises can be isolated by moving or pressing on the suspected components while duplicating the conditions under which the noise occurs. Most of these incidents can be repaired by repositioning the component or applying urethane tape to the contact area.

UNDERHOOD

Some interior noise may be caused by components under the hood or on the engine wall. The noise is then transmitted into the passenger compartment.

Causes of transmitted under-hood noise include:

1. Any component mounted to the engine wall
2. Components that pass through the engine wall
3. Engine wall mounts and connectors
4. Loose radiator mounting pins
5. Hood bumpers out of adjustment
6. Hood striker out of adjustment

These noise can be difficult to isolate since they cannot be reached from the interior of the vehicle. The best method is to secure, move or insulate one component at a time and test drive the vehicle. Also, engine RPM or load can be changed to isolate the noise. Repairs can usually be made by moving, adjusting securing, or insulating the component causing the noise.

SQUEAK AND RATTLE TROUBLE DIAGNOSES

Diagnostic Worksheet

EIS008NV


SQUEAK & RATTLE DIAGNOSTIC WORKSHEET

Dear Nissan Customer:

We are concerned about your satisfaction with your Nissan vehicle. Repairing a squeak or rattle sometimes can be very difficult. To help us fix your Nissan right the first time, please take a moment to note the area of the vehicle where the squeak or rattle occurs and under what conditions. You may be asked to take a test drive with a service advisor or technician to ensure we confirm the noise you are hearing.

I. WHERE DOES THE NOISE COME FROM? (circle the area of the vehicle)

The illustrations are for reference only, and may not reflect the actual configuration of your vehicle.



Continue to the back of the worksheet and briefly describe the location of the noise or rattle. In addition, please indicate the conditions which are present when the noise occurs.

PIIB0723E

SQUEAK AND RATTLE TROUBLE DIAGNOSES

SQUEAK & RATTLE DIAGNOSTIC WORKSHEET- page 2

Briefly describe the location where the noise occurs:

II. WHEN DOES IT OCCUR? (check the boxes that apply)

- | | |
|--|---|
| <input type="checkbox"/> anytime | <input type="checkbox"/> after sitting out in the sun |
| <input type="checkbox"/> 1 st time in the morning | <input type="checkbox"/> when it is raining or wet |
| <input type="checkbox"/> only when it is cold outside | <input type="checkbox"/> dry or dusty conditions |
| <input type="checkbox"/> only when it is hot outside | <input type="checkbox"/> other: _____ |

III. WHEN DRIVING:

- | | |
|---|--|
| <input type="checkbox"/> through driveways | <input type="checkbox"/> squeak (like tennis shoes on a clean floor) |
| <input type="checkbox"/> over rough roads | <input type="checkbox"/> creak (like walking on an old wooden floor) |
| <input type="checkbox"/> over speed bumps | <input type="checkbox"/> rattle (like shaking a baby rattle) |
| <input type="checkbox"/> only at about _____ mph | <input type="checkbox"/> knock (like a knock on a door) |
| <input type="checkbox"/> on acceleration | <input type="checkbox"/> tick (like a clock second hand) |
| <input type="checkbox"/> coming to a stop | <input type="checkbox"/> thump (heavy, muffled knock noise) |
| <input type="checkbox"/> on turns : left, right or either (circle) | <input type="checkbox"/> buzz (like a bumble bee) |
| <input type="checkbox"/> with passengers or cargo | |
| <input type="checkbox"/> other: _____ | |
| <input type="checkbox"/> after driving _____ miles or _____ minutes | |

IV. WHAT TYPE OF NOISE?

- | | |
|--|--|
| <input type="checkbox"/> over speed bumps | <input type="checkbox"/> squeak (like tennis shoes on a clean floor) |
| <input type="checkbox"/> only at about _____ mph | <input type="checkbox"/> creak (like walking on an old wooden floor) |
| <input type="checkbox"/> on acceleration | <input type="checkbox"/> rattle (like shaking a baby rattle) |
| <input type="checkbox"/> coming to a stop | <input type="checkbox"/> knock (like a knock on a door) |
| <input type="checkbox"/> on turns : left, right or either (circle) | <input type="checkbox"/> tick (like a clock second hand) |
| <input type="checkbox"/> with passengers or cargo | <input type="checkbox"/> thump (heavy, muffled knock noise) |
| <input type="checkbox"/> other: _____ | <input type="checkbox"/> buzz (like a bumble bee) |

TO BE COMPLETED BY DEALERSHIP PERSONNEL

Test Drive Notes:

Initials of person
performing

YES NO

- | | | | |
|--|--------------------------|--------------------------|-------|
| Vehicle test driven with customer | <input type="checkbox"/> | <input type="checkbox"/> | _____ |
| - Noise verified on test drive | <input type="checkbox"/> | <input type="checkbox"/> | _____ |
| - Noise source located and repaired | <input type="checkbox"/> | <input type="checkbox"/> | _____ |
| - Follow up test drive performed to confirm repair | <input type="checkbox"/> | <input type="checkbox"/> | _____ |

VIN: _____ Customer Name: _____

W.O. #: _____ Date: _____

This form must be attached to Work Order

CLIP AND FASTENER











CLIP AND FASTENER

PFP:76906

Clip and Fastener









EIS000MW

A
B
C
D
E
F
G
H
EI
J
K
L
M





Symbol No.	Shapes	Removal & Installation
C101		<p>Removal: Remove by bending up with flat-bladed screwdrivers or clip remover.</p> 
C103		<p>Removal: Remove with a clip remover.</p> 
C203		<p>Removal: Push center pin to catching position. (Do not remove center pin by hitting it.)</p>  <p>Installation:</p> 
C205		<p>Removal:</p> 
C206		<p>Removal:</p> 

SIIA0315E

CLIP AND FASTENER

Symbol No.	Shapes	Removal & Installation
CE103		Removal: 
CF110		Removal: 
CF118		Removal: 
CR103		Removal: Holder portion of clip must be spread out to remove rod. 
CS101		Removal: 1. Screw out with a Phillips screwdriver. 2. Remove female portion with flat-bladed screwdriver. 

CLIP AND FASTENER

Symbol No.	Shapes	Removal & Installation	
CG101 	 	Removal:  Rotate 45° to remove	Installation:  Removal: 
CS102 			
CS113 		Removal: Disconnect upper connection of clip with a flat-bladed screwdriver, then remove clip while inserting a flat-bladed screwdriver between body panel and clip.	
C111 			

A
B
C
D
E
F
G
H
EI
J
K
L
M

FRONT BUMPER

FRONT BUMPER

PFP:F2022

Removal and Installation







EIS0098W

CAUTION:

Bumper fascia is made of resin. Do not apply strong force to it, and be careful to prevent contact with oil.

FRONT BUMPER

SEC. 620



PIIA0143E

[N] : N·m (kg-m, in-lb)

[C] : N·m (kg-m, ft-lb)

★ : Bumper assembly mounting bolts, nuts and clips

1. Front bumper fascia
2. Energy shock absorber
3. Bumper reinforcement
4. Bumper upper retainer
5. Bumper stay

A
B
C
D
E
F
G
H
EI
J
K
L
M

FRONT BUMPER

REMOVAL

1. Remove front grille. Refer to [EI-19, "Removal and Installation"](#) .
2. Remove mounting screws and clips on RH/LH front fender protector.
3. Remove front bumper fascia mounting screws from RH/LH front fender.
4. Remove clips from the top surface of front bumper and bolts from the lower surface.
5. Press down tabs A (1 each on left/right sides) on bumper fascia to remove. Then disengage tabs B (1 each on left/right sides) on the fender and remove bumper fascia assembly.

CAUTION:

When removing bumper fascia, 2 workers are required so as to prevent it from dropping.

6. Remove energy shock absorber.
7. Remove mounting nuts from bumper reinforcement assembly.
8. Remove mounting nuts from bumper upper retainer assembly.
9. Remove mounting bolts from bumper stay assembly.

INSTALLATION

Installation is in the reverse order of removal.

NOTE:

After installation, adjust the clearance.

REAR BUMPER

REAR BUMPER

PFP:H5022



Removal and Installation

EIS000MY


CAUTION:

Bumper fascia is made of resin. Do not apply strong force to it, and be careful to prevent contact with oil.

SEC. 850





Clearance mm (in)
A: 3.0±1.5 (0.118±0.059)



: N·m (kg-m, ft-lb)

: N·m (kg-m, in-lb)

★ : Bumper assembly mounting bolts, nuts and clips



PIIB0590E

- | | | |
|-------------------------|--------------------------------|--------------------------|
| 1. Rear bumper fascia | 2. Reflector | 3. Chipping protector |
| 4. Bumper stay | 5. Rear bumper energy absorber | 6. Rear bumper protector |
| 7. Rear bumper finisher | 8. Rear fog lamp | |

REMOVAL

1. Remove mounting nuts on rear bumper protector.
2. Remove RH/LH chipping protector.
3. Remove mounting screws on RH/LH rear fender protector.

REAR BUMPER

4. Remove mounting bolts and clips on rear bumper fascia.
5. Spread bumper fascia toward the outside and remove it from the side clips.
6. Remove rear fog lamp connectors. Pull bumper fascia assembly straight rearward to remove.

CAUTION:

When removing bumper fascia, 2 workers are required so as to prevent it from dropping.

7. Remove mounting bolts on bumper stay.
8. Remove rear bumper finisher, or rear fog lamps, and the reflectors from bumper.

INSTALLATION

Installation is in the reverse order of removal.

NOTE:

After installation, adjust the clearance.

FRONT GRILLE


FRONT GRILLE

PFP:62310

Removal and Installation

EIS000MZ

SEC. 620



REMOVAL

CAUTION:

Apply protection tape around outer circumference of front grille (bumper fascia side).

1. Remove installation clips from top edge of grille.
2. Remove clips from the lower surface of grille, and lift upwards to remove.

INSTALLATION

Installation is in the reverse order of removal.

A
B
C
D
E
F
G
H

EI

J
K
L
M


COWL TOP

PFP:66100

Removal and Installation

REMOVAL

1. Remove wiper arms (left and right). Refer to [WW-8, "Removal and Installation of Front Wiper Arms, Adjustment for Wiper Arms Stop Location"](#).
2. Remove cowl top seal rubber.
3. Remove cowl top rubber mounting clips. Then remove cowl top cover.



INSTALLATION

Installation is in the reverse order of removal.

CAUTION:

- When installing cowl top cover, make sure that blind clips are securely fitted in panel holes on body, and then press them in.
- Refer to [WW-8, "Removal and Installation of Front Wiper Arms, Adjustment for Wiper Arms Stop Location"](#) in WW section for wiper arm installation.


FENDER PROTECTOR

FENDER PROTECTOR Removal and Installation

PFP:63840

EIS000N1

A
B
C
D
E
F
G
H
EI
J
K
L
M



REMOVAL

1. Remove screws and clips of fender protector.
2. Remove fender protector (front/rear).

INSTALLATION

Installation is in the reverse order of removal.


DOOR OUTSIDE MOLDING

DOOR OUTSIDE MOLDING

PFP:82820

Removal and Installation

EIS0015E




REMOVAL

Front door outside molding

1. Roll the front door window all the way up.
2. Remove front door finisher. Refer to [EI-32, "Removal and Installation"](#) .
3. Remove corner cover and door mirror. Refer to [GW-91, "Removal and Installation"](#) .
4. Disengage front door outside molding pawl.
5. Reaching from inner side of door, use a clip clamp tool to disengage front door outside molding from the pawl.

NOTE:

Insert clip clamp tool into the door tab, then disengage by pressing in the direction of arrow. (See figure on the right.)



Rear door outside molding


1. Roll the rear door window all the way up.
2. Remove rear door finisher. Refer to [EI-32, "Removal and Installation"](#) .
3. Remove corner inner cover and corner outer cover. Refer to [GW-83, "Removal and Installation"](#) .
4. Disengage rear door outside mold pawl.

DOOR OUTSIDE MOLDING

5. Reaching from inner side of door, use a clip clamp tool to disengage rear door outside molding from the pawl.

NOTE:

Insert clip clamp tool into the door pawl, then disengage by pressing in the direction of arrow. (See figure on the right.)



INSTALLATION

To install, press molding into the outer panel flange and engage the pawls.

CAUTION:

- Be careful not to apply excessive force when removing because it is easy to deform parts.
- After removal, visually inspect molding, and if it is deformed, replace it with new molding.

A
B
C
D

E

F

G

H

EI

J

K

L

M


SIDE GUARD MOLDING

SIDE GUARD MOLDING

PFP:76840

Removal and Installation

EIS000N3



SIIA0204E

1. Side guard molding (front door)
2. Side guard molding (rear door)

REMOVAL

Side guard molding (front/rear)

1. Apply masking tape around outer circumference of side guard molding.
2. Remove double-faced adhesive tapes with (wide) resin spatula. Disengage clips and remove side guard molding.

INSTALLATION

1. Remove double-faced adhesive tape remaining on vehicle.
2. Clean contact surface of vehicle (to side guard molding), and install side guard molding to vehicle.

NOTE:

To re-use side guard molding, follow above steps 1 and 2 as well, clean surface after removing double-faced adhesive tape, apply new double-faced adhesive tape as shown in the figure, then install side guard molding to vehicle.

CAUTION:

- Do not let air between contact surfaces when installing.
- To secure contact, do not wash vehicle within 24 hours after installation.


DOOR OUTSIDE LOWER MOLDING

DOOR OUTSIDE LOWER MOLDING

PFP:82877

Removal and Installation

EIS000N4



1. Door outside lower molding (front door)

2. Door outside lower molding (rear door)

REMOVAL

Door outside molding (front/rear)

1. Remove clips of door outside molding.
2. Remove door outside molding (front/rear).

INSTALLATION

Installation is in the reverse order of removal.

CAUTION:

When installing door outside molding, make sure that blind clips are securely fitted in panel hole on body and then press them in.

A
B
C
D
E
F
G
H

EI

J
K
L
M

SIDE SILL PROTECTOR


SIDE SILL PROTECTOR

PFP:86856

Removal and Installation REMOVAL

EIS000N5

1. Remove screw and clip of side sill protector.
2. Remove side sill protector.



INSTALLATION

Installation is in the reverse order of removal.


ROOF RAIL

ROOF RAIL

PFP:73820

Removal and Installation (for Hyper Roof Rail)

EIS000N6



- 1. Roof rail
- 2. Rear spoiler
- 3. Hyper roof rail rear cap
- 4. Rear spoiler bracket
- 5. Hyper roof rail center bracket (rear)
- 6. Hyper roof rail center bracket (front)
- 7. Hyper roof rail bracket (rear)
- 8. Hyper roof rail bracket (front)
- 9. Hyper roof rail front cap
- 10. Side rail
- 11. Driving lamp cap (rear)
- 12. Driving lamp assembly
- 13. Driving lamp cap (front)
- 14. Driving lamp bracket

CAUTION:

Be careful not to damage the body.

REMOVAL

1. Remove driving lamp cap (front).
2. Remove driving lamp mounting nuts.
3. Pull driving lamp upward to disconnect clips of driving lamp from roof panel.
4. Disconnect driving lamp harness connector.
5. Remove driving lamp assembly.
6. Remove hyper roof rail caps (front and rear).
7. Remove side rail mounting bolts and nuts, then remove side rail.
8. Remove rear spoiler mounting bolts, then remove rear spoiler.
9. Remove hyper roof rail mounting nuts, then remove hyper roof rail assembly.
10. Remove headlining. Refer to [EI-39, "HEADLINING"](#).
11. Remove driving lamp bracket, hyper roof rail bracket (front and rear) and roof spoiler bracket.

INSTALLATION

Installation is in the reverse order of removal.


A
B
C
D
E
F
G
H
EI
J
K
L
M

ROOF RAIL

Removal and Installation (for Roof Rail)

EIS0080Q

SEC. 766



SIIA0265E


- 1. Roof rail
- 2. Front cap
- 3. Rear cap
- 4. Roof rail cover
- 5. Roof rail bracket (front)
- 6. Roof rail bracket (rear)

CAUTION:

Be careful not to damage the body.

REMOVAL


1. Remove headlining. Refer to [EI-35, "BODY SIDE TRIM"](#).
2. Remove roof rail mounting nuts and roof rail covers (or roof spoiler) mounting nuts.



SIIA0214E

ROOF RAIL

3. Remove roof rail bracket mounting nuts (front and rear).



4. Remove roof rail covers (or roof spoiler). For removal of roof spoiler, refer to [EI-30, "ROOF SPOILER"](#) .
5. Remove roof rail mounting clips, and remove roof rails.

INSTALLATION

Installation is in the reverse order of removal.

A
B
C
D

E

F

G

H

EI

J

K

L

M


ROOF SPOILER

ROOF SPOILER

PFP:96030

Removal and Installation

EIS000N7



1. Cover (left)

2. Cover (right)

3. Roof spoiler

CAUTION:

Be careful not to damage the body.

REMOVAL

1. Remove headlining. Refer to [EI-39, "Removal and Installation"](#) .
2. Remove covers (left and right).
3. Remove roof spoiler mounting nuts (upper and lower roof surfaces).
4. Pull roof spoiler upwards. Remove tabs (1 each on left/right) which are engaged with the roof rails. Remove roof spoiler.

INSTALLATION

Installation is in the reverse order of removal.

LICENSE LAMP FINISHER


LICENSE LAMP FINISHER

PFP:84810

Removal and Installation

EIS001NV

SEC. 900



1. License lamp finisher

REMOVAL

1. Remove back door finisher. Refer to [EI-34, "Removal and Installation"](#) .
2. Remove license plate lamp. Refer to [LT-107, "LICENSE PLATE LAMP"](#) .
3. Remove license lamp finisher mounting nuts and clips and then remove finisher.

INSTALLATION

Installation is in the reverse order of removal.

A
B
C
D
E
F
G
H

EI

J
K
L
M

DOOR FINISHER


DOOR FINISHER

PFP:80900


Removal and Installation

EIS000N9


SEC. 805•809•825•828



Inside handle escutcheon



Power window switch finisher




SIIA0203E

- | | | |
|------------------------|-----------------------------|-----------------------|
| 1. Front door finisher | 2. Inside handle escutcheon | 3. Front door armrest |
| 4. Rear door finisher | 5. Inside handle escutcheon | 6. Rear door armrest |

FRONT AND REAR

Removal


1. Insert a screwdriver, wrapped with a cloth, into door trim cutout on the inside handle escutcheon. Disengage the pawls on the front, upper side (2) and lower side (2). Slide rearwards and disengage the rear-side pawls to remove.




SIIA0391E

DOOR FINISHER


2. Insert a screwdriver, wrapped with a cloth, into the cutout on the front edge of power window switch finisher. Unfasten the metal clip on the front side.



3. Insert the screwdriver into the gap and remove metal clips, moving from front to rear.
4. Disconnect and remove power window switch connector.




5. Remove door finisher mounting screw.
6. Insert a screwdriver, wrapped with a cloth, into the cutout on the lower part of door finisher. Unfasten the clips.



CAUTION:

- Insert a clip driver or clip clamp remover into the part shown by the arrow (between the body side panel and the clips). Remove finisher.
- To install the finisher, confirm clips are surely aligned with the holes on the body side panel, then press in.



7. Pull the door finisher upwards to remove.

Installation

Installation is in the reverse order of removal.


BACK DOOR TRIM

BACK DOOR TRIM

PFP:90900


Removal and Installation REMOVAL

1. Remove clips of back door trim.
2. Remove back door trim.



CAUTION:

- Insert a clip driver or clip clamp remover into the part shown by the arrow (between the clips and the body side panel). Remove clips.
- When installing, confirm clips are surely aligned with the holes on the body side panel, then press in.



INSTALLATION

Installation is in the reverse order of removal.

BODY SIDE TRIM

BODY SIDE TRIM


PFP:76913

Removal and Installation

EIS000NB

CAUTION:

Wrap the tip of flat-bladed screwdriver with a cloth when removing metal clips from garnishes.



1. Front pillar garnish
2. Dashboard side finisher
3. Front body side welt
4. Front kick panel
5. Center pillar upper garnish
6. Center pillar lower garnish
7. Rear body side welt
8. Rear kick panel
9. Rear pillar finisher
10. Luggage side lower finisher
11. Front luggage floorboard
12. Luggage floor rear spacer (right)
13. Luggage floor rear spacer (center)
14. Luggage floor rear spacer (left)
15. Luggage floorboard (right)
16. Rear luggage floorboard
17. Luggage floorboard (left)
18. Luggage rear plate
19. Back door weather strip
20. Hook
21. Net
22. Tonneau cover

A
B
C
D
E
F
G
H
EI
J
K
L
M

CENTER PILLAR LOWER GARNISH

Removal

Remove front and rear kick panels.

Installation

Installation is in the reverse order of removal.

CENTER PILLAR UPPER GARNISH

Removal

1. Remove seat belt shoulder anchor bolt. Refer to [SB-3, "Removal and Installation of Front Seat Belt"](#) .
2. Remove front and rear kick panels.
3. Remove center pillar lower garnish.


Installation

Installation is in the reverse order of removal.

LUGGAGE SIDE LOWER FINISHER

Removal

1. Remove luggage floorboards and luggage floor spacers.
2. Remove luggage rear plate.
3. Remove rear kick panel.



NOTE:

When removing or installing, pay attention to pawl engagement with the rear pillar finisher.

Installation

Installation is in the reverse order of removal.

REAR PILLAR FINISHER

Removal

1. Removal luggage side lower finisher.
2. Removal rear seat belt shoulder anchor. Refer to [SB-4, "Removal and Installation of Rear Seat Belt"](#) .

Installation

Installation is in the reverse order of removal.

DASHBOARD SIDE FINISHER

Removal

Removal dash side finisher.

Installation

Installation is in the reverse order of removal.

BODY SIDE WELT


Removal

1. Remove kick panels.
2. Remove center pillar lower garnish.
3. Remove center pillar upper garnish.

BODY SIDE TRIM

CAUTION:

- Insert a screwdriver, wrapped with a cloth, into the part shown by an arrow (between the body side panel and clips). Remove clips.
- When installing, confirm clips are aligned with the body side panel holes, and then press in.



Installation

Installation is in the reverse order of removal.

A
B
C
D

E
F

G

H

EI

J

K

L


M

FLOOR TRIM

PFP:74902

Removal and Installation

EIS000NC



- 1. Floor carpet
- 2. Foot rest
- 3. Carpet hook
- 4. Model number plate cover
- 5. Rear floor carpet

REMOVAL

1. Remove front seat and rear seat cushions. Refer to [SE-26, "Removal and Installation"](#) and [SE-34, "Removal and Installation"](#) .
2. Remove clips and remove rear floor carpet.
3. Remove center console.
4. Remove lower instrument cover.
5. Remove lower instrument center panel.
6. Remove floor anchor bolt of front seat belt. Refer to [SB-3, "Removal and Installation of Front Seat Belt"](#) .
7. Remove front and rear kick panels.
8. Remove center pillar lower garnish.
9. Remove front and rear body-side welts.
10. Remove the dashboard side finisher.
11. Remove footrest.
12. Remove carpet hooks and clips.
13. Remove carpet from the carpet anchor clips.
14. Remove floor carpet.

NOTE:

- For steps 3-5, refer to [IP-10, "INSTRUMENT PANEL ASSEMBLY"](#) .
- For steps 7-10, refer to [EI-35, "Removal and Installation"](#) .

INSTALLATION

Installation is in the reverse order of removal.

HEADLINING


HEADLINING

PFP:73910

Removal and Installation

EIS000ND

SEC. 251•264•738•963•964



- | | | |
|--|--------------------------|---------------------------------|
| 1. Headlining (standard) | 2. Sun-visor (left) | 3. Sun-visor (right) |
| 4. Sun-visor holder | 5. Inside mirror | 6. Inside mirror cover |
| 7. Map lamp | 8. Interior lamp | 9. Assistance grip (fixed type) |
| 10. Luggage compartment lamp | 11. Headlining (sunroof) | 12. Sunroof switch and map lamp |
| 13. Assistance grip (retractable type) | 14. Sunroof welt | |

REMOVAL


1. Remove front pillar and center pillar garnishes. Refer to [EI-35, "Removal and Installation"](#) .
2. Remove body side welt. Refer to [EI-35, "Removal and Installation"](#) .
3. Remove rear pillar finisher. Refer to [EI-35, "Removal and Installation"](#) .

HEADLINING

4. Remove assistance grip.

NOTE:

When removing the assistant's grip cover from a car with a sunroof, use a clip clamp tool to disengage the upper and lower tabs, then slide inwards and remove screws (1 each on left/right).



5. Remove map lamp, interior lamp, and luggage compartment lamp. Refer to [LT-150, "Removal and Installation"](#) and [LT-143, "Removal and Installation"](#).
6. Remove inside mirror cover.
7. Remove mounting screw on inside mirror.
8. Remove sun visors (driver side and passenger side).
9. Remove headlining rear clips.
10. Remove sun visor holder.


NOTE:

Insert a screwdriver into the cutout and rotate 90° to remove.

11. Remove headlining through the back door opening.

CAUTION:

- Always remove or install in a pair.
- Cover surroundings with waste to avoid scratches or damages.
- Do not bend headlining too hard.



INSTALLATION

Installation is in the reverse order of removal.

CAUTION:

When installing, insert the protrusions on the headlining into the holes in the upper part of center pillar.

