

PWC

SECTION

POWER WINDOW CONTROL SYSTEM

CONTENTS

PRECAUTION	4	List of ECU Reference	19
PRECAUTIONS	4	POWER WINDOW MAIN SWITCH	20
Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"	4	Reference Value	20
PREPARATION	5	Fail-safe	21
PREPARATION	5	FRONT POWER WINDOW SWITCH (PASSENGER SIDE)	22
Commercial Service Tools	5	Reference Value	22
SYSTEM DESCRIPTION	6	Fail-safe	23
COMPONENT PARTS	6	REAR POWER WINDOW SWITCH LH	24
Component Parts Location	6	Reference Value	24
Power Window Main Switch	7	Fail-safe	25
Front Power Window Switch (Passenger side)	7	REAR POWER WINDOW SWITCH RH	26
Rear Power Window Switch	7	Reference Value	26
Power Window Motor	8	Fail-safe	27
SYSTEM	9	WIRING DIAGRAM	28
System Description	9	POWER WINDOW SYSTEM	28
Circuit Diagram	11	Wiring Diagram	28
Fail-safe	11	BASIC INSPECTION	37
DIAGNOSIS SYSTEM (BCM)	13	DIAGNOSIS AND REPAIR WORK FLOW	37
COMMON ITEM	13	Work Flow	37
COMMON ITEM : CONSULT Function (BCM - COMMON ITEM)	13	ADDITIONAL SERVICE WHEN REMOVING BATTERY NEGATIVE TERMINAL	38
RETAIND PWR	14	Description	38
RETAIND PWR : CONSULT Function (BCM - RETAINED PWR)	14	Work Procedure	38
INTELLIGENT KEY	15	ADDITIONAL SERVICE WHEN REPLACING POWER WINDOW MAIN SWITCH	39
INTELLIGENT KEY : CONSULT Function (BCM - INTELLIGENT KEY)	15	Description	39
ECU DIAGNOSIS INFORMATION	19	Work Procedure	39
BCM (BODY CONTROL MODULE)	19	SYSTEM INITIALIZATION	40
		Description	40
		Work Procedure	40

A

B

C

D

E

F

G

H

I

J

PWC

L

M

N

O

P

CHECK ANTI-PINCH FUNCTION	41	POWER WINDOW SERIAL LINK	61
Description	41	POWER WINDOW MAIN SWITCH	61
Work Procedure	41	POWER WINDOW MAIN SWITCH : Diagnosis	
DTC/CIRCUIT DIAGNOSIS	42	Procedure	61
POWER SUPPLY AND GROUND CIRCUIT	42	FRONT POWER WINDOW SWITCH (PASSEN-	
POWER WINDOW MAIN SWITCH	42	GER SIDE)	62
POWER WINDOW MAIN SWITCH : Diagnosis		FRONT POWER WINDOW SWITCH (PASSEN-	
Procedure	42	GER SIDE) : Diagnosis Procedure	62
FRONT POWER WINDOW SWITCH (PASSEN-		REAR POWER WINDOW SWITCH LH	63
GER SIDE)	43	REAR POWER WINDOW SWITCH LH : Diagno-	
FRONT POWER WINDOW SWITCH (PASSEN-		sis Procedure	63
GER SIDE) : Diagnosis Procedure	43	REAR POWER WINDOW SWITCH RH	64
REAR POWER WINDOW SWITCH	44	REAR POWER WINDOW SWITCH RH : Diagno-	
REAR POWER WINDOW SWITCH : Diagnosis		sis Procedure	64
Procedure	44	SYMPTOM DIAGNOSIS	66
POWER WINDOW MOTOR	46	NONE OF THE POWER WINDOWS CAN BE	
DRIVER SIDE	46	OPERATED USING ANY SWITCH	66
DRIVER SIDE : Component Function Check	46	Diagnosis Procedure	66
DRIVER SIDE : Diagnosis Procedure	46	DRIVER SIDE POWER WINDOW ALONE	
PASSENGER SIDE	46	DOES NOT OPERATE	67
PASSENGER SIDE : Component Function Check		Diagnosis Procedure	67
... 47	47	FRONT PASSENGER SIDE POWER WIN-	
PASSENGER SIDE : Diagnosis Procedure	47	DOW DOES NOT OPERATE	68
REAR LH	47	WHEN BOTH POWER WINDOW MAIN SWITCH	
REAR LH : Component Function Check	48	AND FRONT POWER WINDOW SWITCH ARE	
REAR LH : Diagnosis Procedure	48	OPERATED	68
REAR RH	48	WHEN BOTH POWER WINDOW MAIN SWITCH	
REAR RH : Component Function Check	48	AND FRONT POWER WINDOW SWITCH ARE	
REAR RH : Diagnosis Procedure	49	OPERATED : Diagnosis Procedure	68
ENCODER	50	WHEN FRONT POWER WINDOW SWITCH (PAS-	
DRIVER SIDE	50	SENGER SIDE) IS OPERATED	68
DRIVER SIDE : Component Function Check	50	WHEN FRONT POWER WINDOW SWITCH	
DRIVER SIDE : Diagnosis Procedure	50	(PASSENGER SIDE) IS OPERATED : Diagnosis	
PASSENGER SIDE	52	Procedure	68
PASSENGER SIDE : Component Function Check		WHEN POWER WINDOW MAIN SWITCH IS OP-	
... 52	52	ERATED	68
PASSENGER SIDE : Diagnosis Procedure	52	WHEN POWER WINDOW MAIN SWITCH IS OP-	
REAR LH	54	ERATED : Diagnosis Procedure	68
REAR LH : Component Function Check	54	REAR LH SIDE POWER WINDOW ALONE	
REAR LH : Diagnosis Procedure	54	DOES NOT OPERATE	69
REAR RH	56	WHEN BOTH POWER WINDOW MAIN SWITCH	
REAR RH : Component Function Check	56	AND REAR POWER WINDOW SWITCH LH ARE	
REAR RH : Diagnosis Procedure	56	OPERATED	69
DOOR KEY CYLINDER SWITCH	59	WHEN BOTH POWER WINDOW MAIN SWITCH	
Component Function Check	59	AND REAR POWER WINDOW SWITCH LH ARE	
Diagnosis Procedure	59	OPERATED : Diagnosis Procedure	69
Component Inspection	60	WHEN REAR POWER WINDOW SWITCH LH IS	
		OPERATED	69

WHEN REAR POWER WINDOW SWITCH LH IS OPERATED : Diagnosis Procedure	69	
WHEN POWER WINDOW MAIN SWITCH IS OPERATED	69	
WHEN POWER WINDOW MAIN SWITCH IS OPERATED : Diagnosis Procedure	69	
REAR RH SIDE POWER WINDOW ALONE DOES NOT OPERATE	70	
WHEN BOTH POWER WINDOW MAIN SWITCH AND REAR POWER WINDOW SWITCH RH ARE OPERATED	70	
WHEN BOTH POWER WINDOW MAIN SWITCH AND REAR POWER WINDOW SWITCH RH ARE OPERATED : Diagnosis Procedure	70	
WHEN REAR POWER WINDOW SWITCH RH IS OPERATED	70	
WHEN REAR POWER WINDOW SWITCH RH IS OPERATED : Diagnosis Procedure	70	
WHEN POWER WINDOW MAIN SWITCH IS OPERATED	70	
WHEN POWER WINDOW MAIN SWITCH IS OPERATED : Diagnosis Procedure	70	
AUTO OPERATION DOES NOT OPERATE BUT MANUAL OPERATE NORMALLY	71	
DRIVER SIDE	71	
DRIVER SIDE : Diagnosis Procedure	71	
PASSENGER SIDE	71	
PASSENGER SIDE : Diagnosis Procedure	71	
REAR LH	71	
REAR LH : Diagnosis Procedure	71	
REAR RH	72	
REAR RH : Diagnosis Procedure	72	
ANTI-PINCH FUNCTION DOES NOT OPERATE	73	A
Diagnosis Procedure	73	
POWER WINDOW RETAINED POWER OPERATION DOES NOT OPERATE PROPERLY	74	B
Diagnosis Procedure	74	
DOOR KEY CYLINDER SWITCH DOES NOT OPERATE POWER WINDOWS	75	C
Diagnosis Procedure	75	
KEYLESS POWER WINDOW DOWN DOES NOT OPERATE	76	D
Diagnosis Procedure	76	
POWER WINDOW LOCK SWITCH DOES NOT FUNCTION	77	E
Diagnosis Procedure	77	
POWER WINDOW SWITCH ILLUMINATION DOES NOT ILLUMINATE	78	F
DRIVER SIDE	78	G
DRIVER SIDE : Diagnosis Procedure	78	
PASSENGER SIDE	78	H
PASSENGER SIDE : Diagnosis Procedure	78	
REAR LH	78	I
REAR LH : Diagnosis Procedure	78	
REAR RH	78	J
REAR RH : Diagnosis Procedure	78	
REMOVAL AND INSTALLATION	79	PWC
POWER WINDOW MAIN SWITCH	79	L
Removal and Installation	79	
REAR POWER WINDOW SWITCH	80	M
Removal and Installation	80	
		N
		O
		P

PRECAUTIONS

< PRECAUTION >

PRECAUTION

PRECAUTIONS

Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"

INFOID:000000009471806

The Supplemental Restraint System such as "AIR BAG" and "SEAT BELT PRE-TENSIONER", used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. This system includes seat belt switch inputs and dual stage front air bag modules. The SRS system uses the seat belt switches to determine the front air bag deployment, and may only deploy one front air bag, depending on the severity of a collision and whether the front occupants are belted or unbelted. Information necessary to service the system safely is included in the "SRS AIR BAG" and "SEAT BELT" of this Service Manual.

WARNING:

Always observe the following items for preventing accidental activation.

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision that would result in air bag inflation, all maintenance must be performed by an authorized NISSAN/INFINITI dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see "SRS AIR BAG".
- Never use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harnesses or harness connectors.

PRECAUTIONS WHEN USING POWER TOOLS (AIR OR ELECTRIC) AND HAMMERS

WARNING:

Always observe the following items for preventing accidental activation.

- When working near the Air Bag Diagnosis Sensor Unit or other Air Bag System sensors with the ignition ON or engine running, never use air or electric power tools or strike near the sensor(s) with a hammer. Heavy vibration could activate the sensor(s) and deploy the air bag(s), possibly causing serious injury.
- When using air or electric power tools or hammers, always switch the ignition OFF, disconnect the battery, and wait at least 3 minutes before performing any service.

PREPARATION


< PREPARATION >

PREPARATION

PREPARATION

Commercial Service Tools

INFOID:0000000009300996

Tool name	Description
Remover tool  JMKA3050ZZ	Removes the clips, pawls and metal clips

PWC

COMPONENT PARTS


< SYSTEM DESCRIPTION >

SYSTEM DESCRIPTION

COMPONENT PARTS

Component Parts Location

INFOID:000000009300997



JMKIB1796ZZ

No.	Component	Function
①	Power window main switch	Refer to PWC-7, "Power Window Main Switch" .
②	Front power window motor (driver side)	Refer to PWC-8, "Power Window Motor" .
③	Front door lock assembly (driver side) (door key cylinder switch)	Transmits operation condition of door key cylinder switch to power window main switch. Refer to DLK-12, "DOOR LOCK SYSTEM : Front Door Lock Assembly" .
④	Front door switch (driver side)	Detects door open/close condition and transmits to BCM. Refer to DLK-11, "DOOR LOCK SYSTEM : Door Switch" .
⑤	Rear power window motor LH	Refer to PWC-8, "Power Window Motor" .
⑥	Rear power window switch LH	Refer to PWC-7, "Rear Power Window Switch" .
⑦	Rear power window switch RH	Refer to PWC-7, "Rear Power Window Switch" .
⑧	Rear power window motor RH	Refer to PWC-8, "Power Window Motor" .
⑨	Front power window motor (passenger side)	Refer to PWC-8, "Power Window Motor" .
⑩	Front power window switch (passenger side)	Refer to PWC-7, "Front Power Window Switch (Passenger side)" .

COMPONENT PARTS


< SYSTEM DESCRIPTION >

No.	Component	Function
⑪	BCM	- Supplies power supply to power window switch. - Controls retained power. - Receives key ID signal from remote keyless entry receiver. - Controls keyless power window operation via serial link. Refer to BCS-4, "BODY CONTROL SYSTEM : Component Parts Location" .
⑫	Remote keyless entry receiver	Receives key ID signal from the Intelligent Key, and then transmits to BCM. Refer to DLK-13, "DOOR LOCK SYSTEM : Remote Keyless Entry Receiver" .

Power Window Main Switch

INFOID:000000009300998


- Integrates the module.
- Power window main switch controls all power windows.
- Power window main switch integrates UP/DOWN switch, power window lock switch, door mirror remote control switch, and door lock/unlock switch.
- Power window main switch controls power window lock function, AUTO UP/DOWN function.
- Receives encoder pulse signal, and then controls anti-pinch system.



Front Power Window Switch (Passenger side)

INFOID:000000009300999


- Integrates the module.
- Front power window switch (passenger side) transmits AUTO UP/DOWN signal to power window motor (passenger side).
- Receives AUTO UP/DOWN signal from BCM, and then transmits to power window motor (passenger side).
- Receives encoder pulse signal, and then controls anti-pinch system.



Rear Power Window Switch

INFOID:000000009301000

- Integrates the module.
- Each power window switch transmits AUTO UP/DOWN signal to each motor.
- Receives AUTO UP/DOWN signal from BCM, and then transmits to each motor.
- Receives encoder pulse signal, and then controls anti-pinch system.



A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

PWC


COMPONENT PARTS

< SYSTEM DESCRIPTION >

Power Window Motor

INFOID:000000009301001

- Integrates the encoder.
- Starts operation according to signals from each power window switch.
- Transmits each power window motor rotation as a pulse signal to each power window switch.
- Excepting power window motor for driver door, starts operation according to signals from power window main switch or each power window switch.



SYSTEM


< SYSTEM DESCRIPTION >

SYSTEM

System Description

INFOID:000000009301003

SYSTEM DIAGRAM



POWER WINDOW OPERATION

- Power window system is activated by each power window switch when ignition switch turns ON.
- Power window main switch opens/closes all door glass.
- Front and rear power window switch opens/closes the corresponding door glass.
- AUTO UP/DOWN operation can be performed when power window main switch turns to AUTO.
- Power window lock switch can lock all power windows other than driver seat.
- If door glass receives resistance that is the specified value or more while power window of driver seat is in AUTO-UP operation, power window of driver seat operates in the reverse direction.

POWER WINDOW AUTO-OPERATION

- AUTO UP/DOWN operation can be performed when each power window switch turns to AUTO.
- Encoder continues detecting the movement of power window motor and transmits to power window switch as the encoder pulse signal while power window motor is operating.
- Power window switch reads the changes of encoder signal and stops AUTO operation when door glass is at fully opened/closed position.
- Power window motor is operable in case encoder is malfunctioning.

POWER WINDOW SERIAL LINK

- All power window switches and BCM transmit and receive the power window serial link.
- Power window serial link transmits power window UP/DOWN signal and power window lock signal.

RETAINED POWER OPERATION

Retained power operation is an additional power supply function that enables power window system to operate for 45 seconds after ignition switch turns OFF.

RETAINED POWER FUNCTION CANCEL CONDITIONS

- Front door (driver side) CLOSE (door switch OFF) → OPEN (door switch ON).

SYSTEM

< SYSTEM DESCRIPTION >

- When ignition switch turns ON again.
- When timer times out. (45 seconds)

POWER WINDOW LOCK

Ground circuit inside power window main switch shuts off when power window lock switch is ON. This inhibits power window switch operation except with the power window main switch.

ANTI-PINCH SYSTEM

- Pinch foreign material in the door glass during AUTO-UP operation, and it is the anti-pinch function that lowers the door glass [front: 150 mm (5.9 in), rear: 116 mm (4.5 in)] when detected.
- Encoder continues detecting the movement of power window motor and transmits to power window switch as the encoder pulse signal while power window motor is operating.
- Resistance is applied to the power window motor rotation that changes the frequency of encoder pulse signal if foreign material is trapped in the door glass.
- Power window switch controls to lower the window glass for [front: 150 mm (5.9 in), rear: 116 mm (4.5 in)] after it detects encoder pulse signal frequency change.

OPERATION CONDITION

- When all door glass AUTO-UP operation is performed (anti-pinch function does not operate just before the door glass closes and is fully closed)

NOTE:

Depending on environment and driving conditions, if a similar impact or load is applied to the door glass, it may lower.

DOOR KEY CYLINDER SWITCH OPERATION

Hold the door key cylinder to the LOCK or UNLOCK direction for 1 seconds or more to OPEN or CLOSE all power windows when ignition switch is OFF. In addition, it stops when key position is moved to NEUTRAL when operating.

OPERATION CONDITION

- Ignition switch OFF.
- Hold door key cylinder to LOCK position for 1 seconds or more to perform CLOSE operation of the door glass.
- Hold door key cylinder to UNLOCK position for 1 seconds or more to perform OPEN operation of the door glass.


KEYLESS POWER WINDOW DOWN FUNCTION

All power windows open when the unlock button on Intelligent Key is activated and kept pressed for more than 3 seconds with the ignition switch OFF. The windows keep opening if the unlock button is continuously pressed.

The power window opening stops when the following operations are performed.

- When encoder in power window motor detects BDC.
- When the ignition switch is turned ON while the power window opening is operated.
- When the unlock button is released.

While retained power operation activate, keyless power window down function cannot be operated.



Fail-safe

FAIL-SAFE CONTROL

Switches to fail-safe control when malfunction is detected in encoder signal that detects up/down speed and direction of door glass. Switches to fail-safe control when a signal that is out of the specified value is detected between the fully closed position and the actual position of the glass.

SYSTEM

< SYSTEM DESCRIPTION >

Malfunction	Malfunction condition
Pulse sensor malfunction	When one pulse signal that is the specified value or more is detected continuously for the specified time or more, while door glass is being operated UP or DOWN.
Both pulse sensors malfunction	When both pulse signals are not detected continuously for the specified time or more, while door glass is being operated UP or DOWN.
Pulse direction malfunction	When a pulse signal indicating that window is moving in the opposite direction against the power window motor is detected for the specified value or more, while door glass is being operated UP or DOWN.
Glass recognition position malfunction 1	When the actual door glass position that is out of specified value is detected compared to the door glass fully closed position memorized in module, while door glass is being operated UP or DOWN.
Glass recognition position malfunction 2	When pulse count that is out of the door glass full stroke value or more is detected, while door glass is being operated UP or DOWN.

If fail-safe control, the system changes to a non-initialized condition and the following function do not operate.

- Auto-up operation
- Anti-pinch function
- Retained power function

When fail-safe control is activated, perform initialization procedure to recover. If a malfunction is detected in power window switch or more, fail-safe control is activated again.

DIAGNOSIS SYSTEM (BCM)

< SYSTEM DESCRIPTION >

DIAGNOSIS SYSTEM (BCM)

COMMON ITEM

COMMON ITEM : CONSULT Function (BCM - COMMON ITEM)

INFOID:000000009315682

APPLICATION ITEM

CONSULT performs the following functions via CAN communication with BCM.

Diagnosis mode	Function Description
Work Support	Changes the setting for each system function.
Self Diagnostic Result	Displays the diagnosis results judged by BCM.
CAN Diag Support Monitor	Monitors the reception status of CAN communication viewed from BCM.
Data Monitor	The BCM input/output signals are displayed.
Active Test	The signals used to activate each device are forcibly supplied from BCM.
Ecu Identification	The BCM part number is displayed.
Configuration	- Read and save the vehicle specification. - Write the vehicle specification when replacing BCM.

SYSTEM APPLICATION

BCM can perform the following functions for each system.

NOTE:

It can perform the diagnosis modes except the following for all sub system selection items.

×: Applicable item

System	Sub system selection item	Diagnosis mode		
		Work Support	Data Monitor	Active Test
Door lock	DOOR LOCK	×	×	×
Rear window defogger	REAR DEFOGGER	×	×	×
Warning chime	BUZZER		×	×
Interior room lamp timer	INT LAMP	×	×	×
Exterior lamp	HEAD LAMP	×	×	×
Wiper and washer	WIPER	×	×	×
Turn signal and hazard warning lamps	FLASHER	×	×	×
—	AIR CONDITONER*		×	×
- Intelligent Key system - Engine start system	INTELLIGENT KEY	×	×	×
Combination switch	COMB SW		×	
Body control system	BCM	×		
IVIS - NATS	IMMU	×	×	×
Interior room lamp battery saver	BATTERY SAVER	×	×	×
Trunk lid open	TRUNK		×	
Vehicle security system	THEFT ALM	×	×	×
RAP system	RETAINED PWR		×	
Signal buffer system	SIGNAL BUFFER		×	×
TPMS	AIR PRESSURE MONITOR			×

*: This item is not used.

FREEZE FRAME DATA (FFD)

The BCM records the following vehicle condition at the time a particular DTC is detected, and displays on CONSULT.

DIAGNOSIS SYSTEM (BCM)

< SYSTEM DESCRIPTION >

CONSULT screen item	Indication/Unit	Description	
Vehicle Speed	km/h	Vehicle speed of the moment a particular DTC is detected	
Odo/Trip Meter	km	Total mileage (Odometer value) of the moment a particular DTC is detected	
Vehicle Condition	SLEEP>LOCK	Power position status of the moment a particular DTC is detected*	While turning BCM status from low power consumption mode to normal mode (Power supply position is "LOCK"*)
	SLEEP>OFF		While turning BCM status from low power consumption mode to normal mode (Power supply position is "OFF".)
	LOCK>ACC		While turning power supply position from "LOCK" *to "ACC"
	ACC>ON		While turning power supply position from "ACC" to "IGN"
	RUN>ACC		While turning power supply position from "RUN" to "ACC" (Vehicle is stopping and selector lever is except P position.)
	CRANK>RUN		While turning power supply position from "CRANKING" to "RUN" (From cranking up the engine to run it)
	RUN>URGENT		While turning power supply position from "RUN" to "ACC" (Emergency stop operation)
	ACC>OFF		While turning power supply position from "ACC" to "OFF"
	OFF>LOCK		While turning power supply position from "OFF" to "LOCK"*
	OFF>ACC		While turning power supply position from "OFF" to "ACC"
	ON>CRANK		While turning power supply position from "IGN" to "CRANKING"
	OFF>SLEEP		While turning BCM status from normal mode (Power supply position is "OFF".) to low power consumption mode
	LOCK>SLEEP		While turning BCM status from normal mode (Power supply position is "LOCK"*.) to low power consumption mode
	LOCK		Power supply position is "LOCK" (Ignition switch OFF)*
	OFF		Power supply position is "OFF" (Ignition switch OFF)
	ACC		Power supply position is "ACC" (Ignition switch ACC)
	ON		Power supply position is "IGN" (Ignition switch ON with engine stopped)
	ENGINE RUN		Power supply position is "RUN" (Ignition switch ON with engine running)
	CRANKING		Power supply position is "CRANKING" (At engine cranking)
IGN Counter	0 - 39	The number of times that ignition switch is turned ON after DTC is detected • The number is 0 when a malfunction is detected now. • The number increases like 1 → 2 → 3...38 → 39 after returning to the normal condition whenever ignition switch OFF → ON. • The number is fixed to 39 until the self-diagnosis results are erased if it is over 39.	

NOTE:

*: Power supply position shifts to "LOCK" from "OFF", when ignition switch is in the OFF position, selector lever is in the P position, and any of the following conditions are met.

- Closing door
- Opening door
- Door is locked using door request switch
- Door is locked using Intelligent Key

The power supply position shifts to "ACC" when the push-button ignition switch (push switch) is pushed at "LOCK".

RETAINED PWR

RETAINED PWR : CONSULT Function (BCM - RETAINED PWR)

INFOID:000000009238444

Data monitor

NOTE:

The following table includes information (items) inapplicable to this vehicle. For information (items) applicable to this vehicle, refer to CONSULT display items.

DIAGNOSIS SYSTEM (BCM)

< SYSTEM DESCRIPTION >

Monitor Item	Description
DOOR SW-DR	Indicates [ON/OFF] condition of driver side door switch.
DOOR SW-AS	Indicates [ON/OFF] condition of passenger side door switch.

INTELLIGENT KEY

INTELLIGENT KEY : CONSULT Function (BCM - INTELLIGENT KEY)

INFOID:000000009716236

WORK SUPPORT

Monitor item	Description
INSIDE ANT DIAGNOSIS	This function allows inside key antenna self-diagnosis
LOCK/UNLOCK BY I-KEY	Door lock function (door request switch) mode can be changed to operation in this mode - On: Operate - Off: Non-operation
ENGINE START BY I-KEY	Engine start function mode can be changed to operation with this mode - On: Operate - Off: Non-operation
TRUNK/GLASS HATCH OPEN	Reminder function (trunk lid opener request switch) mode can be changed to operation with this mode - On: Operate - Off: Non-operation
AUTO LOCK SET	Auto door lock operation time can be changed in this mode - MODE 1: OFF - MODE 2: 30 sec. - MODE 3: 1 minute - MODE 4: 2 minutes - MODE 5: 3 minutes - MODE 6: 4 minutes - MODE 7: 5 minutes
SHORT CRANKING OUTPUT	Starter motor can operate during the times below 70 msec 100 msec 200 msec
CONFIRM KEY FOB ID	It can be checked whether Intelligent Key ID code is registered or not in this mode
RETRACTABLE MIRROR SET	NOTE: This item is displayed, but cannot be used
TOUCH SENSOR UNLOCK FUNCTION SETTING	One touch unlock function can be changed to operation with this mode - On: Operate - Off: Non-operation
IGN/ACC BATTERY SAVER	Ignition battery saver system mode can be changed to operation with this mode - On: Operate - Off: Non-operation
REMOTE ENGINE STARTE	NOTE: This item is displayed, but cannot be used
INTELLIGENT KEY LINK SET	NOTE: This item is displayed, but cannot be used
ANSWER BACK	Reminder function (door request switch and Intelligent Key) mode can be selected from the following with this mode - On: S mode (buzzer or horn reminder non-operation) - Off: C mode (buzzer or horn operate)
ANSWER BACK I-KEY LOCK UNLOCK	Reminder function (door request switch) mode can be selected from the following with this mode - BUZZER: Sound Intelligent Key warning buzzer - HORN: Sound horn - Off: Only hazard warning lamp operate - INVALID: This item is displayed, but cannot be used

DIAGNOSIS SYSTEM (BCM)

< SYSTEM DESCRIPTION >

Monitor item	Description
ANSWERBACK KEYLESS LOCK UNLOCK	Reminder function (Intelligent Key) mode can be selected from the following with this mode • On: Horn and hazard warning lamp operate • Off: Only hazard warning lamp operate
WELCOME LIGHT OP SET	NOTE: This item is displayed, but cannot be used

SELF-DIAG RESULT

Refer to [BCS-62. "DTC Index"](#).

DATA MONITOR

NOTE:

The following table includes information (items) inapplicable to this vehicle. For information (items) applicable to this vehicle, refer to CONSULT display items.

Monitor Item	Condition
REQ SW -DR	Indicates [On/Off] condition of front door request switch (driver side)
REQ SW -AS	Indicates [On/Off] condition of front door request switch (passenger side)
REQ SW -BD/TR	Indicates [On/Off] condition of trunk lid opener request switch
PUSH SW	Indicates [On/Off] condition of push-button ignition switch
SHFTLCK SLNID PWR SPLY	Indicates [On/Off] condition of the power supply from BCM to shift lock solenoid
CLUCH SW	NOTE: This item is displayed, but cannot be monitored
BRAKE SW 1	Indicates [On/Off]* condition of stop lamp switch power supply
BRAKE SW 2	Indicates [On/Off] condition of stop lamp switch
DETE/CANCL SW	Indicates [On/Off] condition of P position
SFT PN/N SW	Indicates [On/Off] condition of P or N position
UNLK SEN -DR	Indicates [On/Off] condition of driver door UNLOCK status
PUSH SW -IPDM	Indicates [On/Off] condition of push-button ignition switch
IGN RLY1 -F/B	Indicates [On/Off] condition of ignition relay 1
DETE SW -IPDM	Indicates [On/Off] condition of P position
SFT PN -IPDM	Indicates [On/Off] condition of P or N position
SFT P -MET	Indicates [On/Off] condition of P position
SFT N -MET	Indicates [On/Off] condition of N position
ENGINE STATE	Indicates [STOP/STALL/CRANK/RUN] condition of engine states
VEH SPEED 1	Display the vehicle speed signal received from combination meter by numerical value [km/h]
VEH SPEED 2	Display the vehicle speed signal received from ABS or VDC or TCM by numerical value [km/h]
DOOR STAT-DR	Indicates [LOCK/READY/UNLK] condition of driver door status
DOOR STAT-AS	Indicates [LOCK/READY/UNLK] condition of passenger door status
DOOR STAT-RR	Indicates [LOCK/READY/UNLK] condition of rear door RH status
DOOR STAT-RL	Indicates [LOCK/READY/UNLK] condition of rear door LH status
BK DOOR STATE	NOTE: This item is displayed, but cannot be monitored
ID OK FLAG	Indicates [Set/Reset] condition of Intelligent Key ID
PRMT ENG STRT	Indicates [Set/Reset] condition of engine start possibility
PRMT RKE STRT	NOTE: This item is displayed, but cannot be monitored
I-KEY OK FLAG	Indicates [KEY On/NOT On] condition of Intelligent Key ID and Intelligent Key is detected inside vehicle
PRBT ENG STRT	Indicates whether or not the engine is in start prohibited status

DIAGNOSIS SYSTEM (BCM)

< SYSTEM DESCRIPTION >

Monitor Item	Condition
ID AUTHENT CANCEL TIMER	Indicates whether or not it is in engine start possible status when Intelligent Key verification is unnecessary
ACC BATTERY SAVER	Indicates [On/Off] whether or not ignition battery saver is in operation
CRNK PRBT TMR	Indicates [On/Off] whether or not in cranking prohibited status due to starter motor protection function operation
AUT CRANK TMR	Indicates [On/Off] whether or not in AUTO CRANKING MODE status
CRNK PRBT TME	Indicates the time for changing from cranking prohibited status to cranking possible status
AUT CRANK TMR	Indicates the time that AUTO CRANKING MODE operates
CRANKING TME	Indicates the cranking operation time
SHORT CRANK	NOTE: This item is displayed, but not used
DETE SW PWR	Indicates [On/Off] condition of the power supply from BCM to the A/T shift selector (detention switch)
IGN RLY3-REQ	Indicates [On/Off] condition of blower relay control signal
ACC RLY-REQ	Indicates [On/Off] condition of accessory relay control signal
RKE OPE COUN1	When remote keyless entry receiver receives the signal transmitted while operating on Intelligent Key, the numerical value start changing
RKE OPE COUN2	NOTE: This item is displayed, but cannot be monitored
TRNK/HAT MNTR	Indicates [On/Off] condition of trunk room lamp switch
RKE-LOCK	Indicates [On/Off] condition of LOCK signal from Intelligent Key
RKE-UNLOCK	Indicates [On/Off] condition of UNLOCK signal from Intelligent Key
RKE-TR/BD	Indicates [On/Off] condition of trunk open signal from Intelligent Key
RKE-PANIC	Indicates [On/Off] condition of panic alarm signal from Intelligent Key
RKE-MODE CHG	NOTE: This item is displayed, but cannot be monitored
RKE PBD	NOTE: This item is displayed, but cannot be monitored

*: OFF is displayed when brake pedal is depressed while brake switch power supply is OFF.

ACTIVE TEST

Test item	Description
OUTSIDE BUZZER	This test is able to check Intelligent Key warning buzzer operation - On: Operates - Off: Non-operation
INSIDE BUZZER	This test is able to check warning chime in combination meter operation - Take Out: Take away warning chime sounds when CONSULT screen is touched - Key: Key warning chime sounds when CONSULT screen is touched - Knob: OFF position warning chime sounds when CONSULT screen is touched - Off: Non-operation
INDICATOR	This test is able to check information display (combination meter) operation - KEY ON: [Intelligent Key system malfunction] displays when CONSULT screen is touched - KEY IND: [Steering lock unit ID registration complete] displays when CONSULT screen is touched - Off: Non-operation
INT LAMP	This test is able to check interior room lamp operation - On: Operates - Off: Non-operation
FLASHER	This test is able to check hazard warning lamp operation The hazard warning lamps are activated after "LH/RH/Off" on CONSULT screen is touched

DIAGNOSIS SYSTEM (BCM)

< SYSTEM DESCRIPTION >

Test item	Description
HORN	This test is able to check horn operation • On: Operates
IGN CONT2	This test is able to operate the blower relay in fuse block (J/B) • On: Operates • Off: Non-operation
ENGINE SW ILLUMI	This test is able to check push-ignition switch illumination operation Push-ignition switch illumination illuminates when "On" on CONSULT screen is touched
PUSH SWITCH INDICATOR	This test is able to check push-ignition switch indicator operation when "On" on CONSULT screen is touched
ACC CONT	This test is able to operate the accessory relay in fuse block (J/B) • On: Operates • Off: Non-operation
IGN CONT1	This test is able to operate the ignition relay in IPDM E/R • On: Operates • Off: Non-operation
IGNITION RELAY	This test is able to operate the ignition relay in fuse block (J/B) • On: Operates • Off: Non-operation
ST CONT LOW	This test is able to operate the starter relay in IPDM E/R • On: Non-operation • Off: Operates
BATTERY SAVER	This test is able to check interior room lamp battery saver operation • On: Outputs interior room lamp power supply to turn interior room lamps ON. • Off: Cuts interior room lamp power supply to turn interior room lamps OFF.
TRUNK/BACK DOOR	This test is able to check trunk lid open operation. This actuator opens when "Open" on CONSULT screen is touched.
RETRACTABLE MIRROR	NOTE: This item is displayed, but cannot be used
INTELLIGENT KEY LINK(CAN)	NOTE: This item is displayed, but cannot be used
REVERSE LAMP TEST	NOTE: This item is displayed, but cannot be used
DOOR HANDLE LAMP TEST	This test is able to check outside handle lamp operation • On: Operates • Off: Non-operation
DR SEAT LAMP TEST	NOTE: This item is displayed, but cannot be used
AS SEAT LAMP TEST	NOTE: This item is displayed, but cannot be used
SHIFT SPOT LAMP TEST	NOTE: This item is displayed, but cannot be used
TRUNK/LUGGAGE LAMP TEST	This test is able to check trunk room lamp operation • On: Operates • Off: Non-operation
KEYFOB P/W TEST	This test is able to check keyless power window up/down operation • Up: Non-operation • Down*: Power window and sunroof open • Off: Non-operation
SHIFTLOCK SORENOID TEST	NOTE: This item is displayed, but cannot be used

*: When ignition switch is OFF, driver door opened, power window and sunroof is closed.

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

ECU DIAGNOSIS INFORMATION

BCM (BODY CONTROL MODULE)

List of ECU Reference

INFOID:0000000009238445

ECU	Reference
BCM	BCS-35, "Reference Value"
	BCS-60, "Fail-safe"
	BCS-61, "DTC Inspection Priority Chart"
	BCS-62, "DTC Index"

PWC

POWER WINDOW MAIN SWITCH


< ECU DIAGNOSIS INFORMATION >

POWER WINDOW MAIN SWITCH



Reference Value

INFOID:000000009238446

TERMINAL LAYOUT




PHYSICAL VALUES

Terminal No. (wire color)		Description		Condition	Voltage (V)
+	-	Signal name	Input/ Output		
3 (V)	Ground	Encoder power supply	Output	When ignition switch ON or power window timer op- erates.	9 - 16
4 (Y)	Ground	Ignition power supply	Input	Ignition switch ON	9 - 16
				Other than above	0 - 1
5 (G)	Ground	Front power window motor (driver side) DOWN signal	Output	When front switch (driver side) in power window main switch is operated DOWN	9 - 16
6 (L)	Ground	Front power window motor (driver side) UP signal	Output	When front switch (driver side) in power window main switch is operated UP	9 - 16
7 (B)	Ground	Ground	—	—	0 - 1
9 (BR)	Ground	Battery power supply	Input	—	9 - 16
10 (B)	Ground	Encoder ground	—	—	0 - 1
11 (GR)	Ground	Encoder pulse signal 1	Input	When power window mo- tor operates.	 JMKIA0070GB
12 (BR)	Ground	Encoder pulse signal 2	Input	When power window mo- tor operates.	 JMKIA0070GB

POWER WINDOW MAIN SWITCH

< ECU DIAGNOSIS INFORMATION >

Terminal No. (wire color)		Description		Condition	Voltage (V)
+	-	Signal name	Input/ Output		
13 (SB)	Ground	Power window serial link	Input/ Output	IGN SW ON or power window timer operating.	
15 (V)	Ground	Door key cylinder switch LOCK signal	Input	Key position (Neutral →Locked)	4 - 6 → 0 - 1
16 (Y)	Ground	Door key cylinder switch UN-LOCK signal	Input	Key position (Neutral →Unlocked)	4 - 6 → 0 - 1

Fail-safe

INFOID:000000009238447

FAIL-SAFE CONTROL

Switches to fail-safe control when malfunction is detected in encoder signal that detects up/down speed and direction of door glass. Switches to fail-safe control when a signal that is out of the specified value is detected between the fully closed position and the actual position of the glass.

Malfunction	Malfunction condition
Pulse sensor malfunction	When one pulse signal that is the specified value or more is detected continuously for the specified time or more, while door glass is being operated UP or DOWN.
Both pulse sensors malfunction	When both pulse signals are not detected continuously for the specified time or more, while door glass is being operated UP or DOWN.
Pulse direction malfunction	When a pulse signal indicating that window is moving in the opposite direction against the power window motor is detected for the specified value or more, while door glass is being operated UP or DOWN.
Glass recognition position malfunction 1	When the actual door glass position that is out of specified value is detected compared to the door glass fully closed position memorized in module, while door glass is being operated UP or DOWN.
Glass recognition position malfunction 2	When pulse count that is out of the door glass full stroke value or more is detected, while door glass is being operated UP or DOWN.

If fail-safe control, the system changes to a non-initialized condition and the following function do not operate.

- Auto-up operation
- Anti-pinch function
- Retained power function

When fail-safe control is activated, perform initialization procedure to recover. If a malfunction is detected in power window switch or more, fail-safe control is activated again.

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

PWC

FRONT POWER WINDOW SWITCH (PASSENGER SIDE)


< ECU DIAGNOSIS INFORMATION >

FRONT POWER WINDOW SWITCH (PASSENGER SIDE)


Reference Value

INFOID:000000009238448

TERMINAL LAYOUT





PHYSICAL VALUES

Terminal No. (wire color)		Description		Condition	Voltage (V)
+	-	Signal name	Input/ Output		
3 (LG)	Ground	Encoder ground	—	—	0 - 1
4 (V)	Ground	Encoder power supply	Output	When ignition switch ON or power window timer operates	9 - 16
8 (L)	Ground	Front power window motor (passenger side) UP signal	Output	When front power window mo- tor (passenger side) is operat- ed UP	9 - 16
9 (G)	Ground	Front power window motor (passenger side) DOWN signal	Output	When front power window mo- tor (passenger side) is operat- ed DOWN	9 - 16
10 (Y)	Ground	Ignition power supply	Input	Ignition switch ON	9 - 16
				Other than above	9 - 16
11 (B)	Ground	Ground	—	—	0 - 1
12 (GR)	Ground	Encoder pulse signal 1	Input	When power window motor operates	

JMKIA0070GB

FRONT POWER WINDOW SWITCH (PASSENGER SIDE)

< ECU DIAGNOSIS INFORMATION >

Terminal No. (wire color)		Description		Condition	Voltage (V)
+	-	Signal name	Input/ Output		
15 (BR)	Ground	Encoder pulse signal 2	Input	When power window motor operates	 JMKIA0070GB
16 (GR)	Ground	Power window serial link	Input/ Output	When ignition switch ON or power window timer operates	 PKIA7023E

Fail-safe

INFOID:0000000009724848

FAIL-SAFE CONTROL

Switches to fail-safe control when malfunction is detected in encoder signal that detects up/down speed and direction of door glass. Switches to fail-safe control when a signal that is out of the specified value is detected between the fully closed position and the actual position of the glass.

Malfunction	Malfunction condition
Pulse sensor malfunction	When one pulse signal that is the specified value or more is detected continuously for the specified time or more, while door glass is being operated UP or DOWN.
Both pulse sensors malfunction	When both pulse signals are not detected continuously for the specified time or more, while door glass is being operated UP or DOWN.
Pulse direction malfunction	When a pulse signal indicating that window is moving in the opposite direction against the power window motor is detected for the specified value or more, while door glass is being operated UP or DOWN.
Glass recognition position malfunction 1	When the actual door glass position that is out of specified value is detected compared to the door glass fully closed position memorized in module, while door glass is being operated UP or DOWN.
Glass recognition position malfunction 2	When pulse count that is out of the door glass full stroke value or more is detected, while door glass is being operated UP or DOWN.

If fail-safe control, the system changes to a non-initialized condition and the following function do not operate.

- Auto-up operation
- Anti-pinch function
- Retained power function

When fail-safe control is activated, perform initialization procedure to recover. If a malfunction is detected in power window switch or more, fail-safe control is activated again.

REAR POWER WINDOW SWITCH LH


< ECU DIAGNOSIS INFORMATION >

REAR POWER WINDOW SWITCH LH

Reference Value

INFOID:000000009238450

TERMINAL LAYOUT





PHYSICAL VALUES

Terminal No. (wire color)		Description		Condition	Voltage (V)
+	-	Signal name	Input/ Output		
3 (BR)	Ground	Encoder ground	—	—	0 - 1
4 (SB)	Ground	Encoder power supply	Output	When ignition switch ON or power window timer operates	9 - 16
8 (R)	Ground	Rear power window motor LH UP signal	Output	When rear power window motor LH is operated UP	9 - 16
9 (L)	Ground	Rear power window motor LH DOWN signal	Output	When rear power window motor LH is operated DOWN	9 - 16
10 (W)	Ground	Ignition power supply	Input	Ignition switch ON	9 - 16
				Other than above	0 - 1
11 (B)	Ground	Ground	—	—	0 - 1
12 (GR)	Ground	Encoder pulse signal 1	Input	When power window motor operates	

JMK1A0070GB

REAR POWER WINDOW SWITCH LH

< ECU DIAGNOSIS INFORMATION >

Terminal No. (wire color)		Description		Condition	Voltage (V)
+	-	Signal name	Input/ Output		
15 (BG)	Ground	Encoder pulse signal 2	Input	When power window motor operates.	 JMKIA0070GB
16 (Y)	Ground	Power window serial link	Input/ Output	When ignition switch ON or power window timer operates	 PKIA7023E

Fail-safe

INFOID:000000009724849

FAIL-SAFE CONTROL

Switches to fail-safe control when malfunction is detected in encoder signal that detects up/down speed and direction of door glass. Switches to fail-safe control when a signal that is out of the specified value is detected between the fully closed position and the actual position of the glass.

Malfunction	Malfunction condition
Pulse sensor malfunction	When one pulse signal that is the specified value or more is detected continuously for the specified time or more, while door glass is being operated UP or DOWN.
Both pulse sensors malfunction	When both pulse signals are not detected continuously for the specified time or more, while door glass is being operated UP or DOWN.
Pulse direction malfunction	When a pulse signal indicating that window is moving in the opposite direction against the power window motor is detected for the specified value or more, while door glass is being operated UP or DOWN.
Glass recognition position malfunction 1	When the actual door glass position that is out of specified value is detected compared to the door glass fully closed position memorized in module, while door glass is being operated UP or DOWN.
Glass recognition position malfunction 2	When pulse count that is out of the door glass full stroke value or more is detected, while door glass is being operated UP or DOWN.

If fail-safe control, the system changes to a non-initialized condition and the following function do not operate.

- Auto-up operation
- Anti-pinch function
- Retained power function

When fail-safe control is activated, perform initialization procedure to recover. If a malfunction is detected in power window switch or more, fail-safe control is activated again.

REAR POWER WINDOW SWITCH RH


< ECU DIAGNOSIS INFORMATION >

REAR POWER WINDOW SWITCH RH

Reference Value

INFOID:000000009641465

TERMINAL LAYOUT





PHYSICAL VALUES

Terminal No. (wire color)		Description		Condition	Voltage (V)
+	-	Signal name	Input/ Output		
3 (V)	Ground	Encoder ground	—	—	0 - 1
4 (SB)	Ground	Encoder power supply	Output	When ignition switch ON or power window timer operates	9 - 16
8 (R)	Ground	Rear power window motor RH UP signal	Output	When rear power window motor RH is operated UP	9 - 16
9 (L)	Ground	Rear power window motor RH DOWN signal	Output	When rear power window motor RH is operated DOWN	9 - 16
10 (W)	Ground	Ignition power supply	Input	Ignition switch ON	9 - 16
				Other than above	0 - 1
11 (B)	Ground	Ground	—	—	0 - 1
12 (GR)	Ground	Encoder pulse signal 1	Input	When power window motor operates	

JMK1A0070GB

REAR POWER WINDOW SWITCH RH

< ECU DIAGNOSIS INFORMATION >

Terminal No. (wire color)		Description		Condition	Voltage (V)
+	-	Signal name	Input/ Output		
15 (BG)	Ground	Encoder pulse signal 2	Input	When power window motor operates.	 JMKIA0070GB
16 (Y)	Ground	Power window serial link	Input/ Output	When ignition switch ON or power window timer operates	 PKIA7023E

Fail-safe

INFOID:0000000009724850

FAIL-SAFE CONTROL

Switches to fail-safe control when malfunction is detected in encoder signal that detects up/down speed and direction of door glass. Switches to fail-safe control when a signal that is out of the specified value is detected between the fully closed position and the actual position of the glass.

Malfunction	Malfunction condition
Pulse sensor malfunction	When one pulse signal that is the specified value or more is detected continuously for the specified time or more, while door glass is being operated UP or DOWN.
Both pulse sensors malfunction	When both pulse signals are not detected continuously for the specified time or more, while door glass is being operated UP or DOWN.
Pulse direction malfunction	When a pulse signal indicating that window is moving in the opposite direction against the power window motor is detected for the specified value or more, while door glass is being operated UP or DOWN.
Glass recognition position malfunction 1	When the actual door glass position that is out of specified value is detected compared to the door glass fully closed position memorized in module, while door glass is being operated UP or DOWN.
Glass recognition position malfunction 2	When pulse count that is out of the door glass full stroke value or more is detected, while door glass is being operated UP or DOWN.

If fail-safe control, the system changes to a non-initialized condition and the following function do not operate.

- Auto-up operation
- Anti-pinch function
- Retained power function

When fail-safe control is activated, perform initialization procedure to recover. If a malfunction is detected in power window switch or more, fail-safe control is activated again.

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

PWC


< WIRING DIAGRAM >

WIRING DIAGRAM

POWER WINDOW SYSTEM

Wiring Diagram

INFOID:0000000009238452



2013/05/17


JRKWC4335GB

POWER WINDOW SYSTEM

< WIRING DIAGRAM >


POWER WINDOW SYSTEM

Connector No.	B13
Connector Name	WIRE TO WIRE
Connector Type	NH10FW-GS10



Terminal No.	Color Of Wire	Signal Name [Specification]
1	LG	-
2	GR	-
3	R	-
4	V	-
7	BR	- [With BOSE system]
19	LG	- [Without BOSE system]
20	R	- [Without BOSE system]
21	SB	- [Without BOSE system]

Connector No.	B18
Connector Name	WIRE TO WIRE
Connector Type	TH80FW-GS10-TM4



Terminal No.	Color Of Wire	Signal Name [Specification]
1	Y	-
2	G	-
3	L	-
4	LG	-
6	R	-
7	V	-
8	LG	-
9	BR	-
10	P	-
11	BG	-


12	LG	-
13	GR	-
24	V	-
25	W	-
26	B	-
27	B	-
28	B	-
29	B	-
30	B	-
31	B	-
32	B	-
33	B	-
34	LG	-
35	P	-
36	W	-
37	SB	-
38	LG	-
40	P	-
41	SB	-
42	BR	-
43	BG	-
44	BG	-
46	R	-
51	SB	-
52	V	-
54	R	-
55	R	-
57	W	-
58	V	-
59	GR	-
62	BG	-
63	BR	-
64	Y	-
65	W	-
70	R	-
71	W	-
72	G	-
73	V	-
75	L	-
76	BR	-
77	B	-
81	B	-
83	BG	-
84	L	-
85	V	-
86	B	-
88	G	-
91	GR	-
94	GR	-
96	Y	-
97	V	-
98	BR	-

Connector No.	B42
Connector Name	FRONT DOOR SWITCH (DRIVER SIDE)
Connector Type	TH84FW-NH



Terminal No.	Color Of Wire	Signal Name [Specification]
3	V	-

Connector No.	B57
Connector Name	WIRE TO WIRE
Connector Type	NH10FW-GS10



Terminal No.	Color Of Wire	Signal Name [Specification]
2	LG	-
3	R	-
4	V	-
7	B	-
19	L	-
20	P	-

Connector No.	B42
Connector Name	WIRE TO WIRE
Connector Type	TH80FW-GS10-TM4



Terminal No.	Color Of Wire	Signal Name [Specification]
1	R	-
2	L	-
3	R	- [With BOSE system]
4	W	- [Without BOSE system]
5	G	-
6	W	-
7	BR	- [Without BOSE system]
8	B	- [With BOSE system]
9	Y	- [Without BOSE system]
10	V	-
11	GR	-
12	Y	-
13	R	-
14	BG	-
15	GR	-
16	V	-
17	P	-
18	L	-
19	B	-
20	GR	-
21	R	-
22	P	-
23	W	-
24	V	-
25	SB	-
26	G	-
29	P	-
30	LG	-
35	R	-
37	R	-
38	W	-
39	W	-

JRKWC4336GB

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

PWC


POWER WINDOW SYSTEM

< WIRING DIAGRAM >

POWER WINDOW SYSTEM

45	G	-
46	SHIELD	-
47	G	-
48	BG	-
49	G	-
50	R	-
51	R	-
52	Y	-
53	R	-
54	GR	-
55	R	-
56	P	-
57	R	-
58	P	-
59	LG	-
60	P	-
61	P	-
62	P	-
63	L	-
64	W	-
65	LG	-
66	LG	-
67	L	-
68	P	-
69	P	-
70	R	-
71	R	-
72	G	-
73	SHIELD	-
74	GR	-
75	GR	-
76	GR	-
77	BG	-
78	W	-
79	LG	-
80	V	-
81	W	-
82	R	-
83	R	-
84	W	-
85	Y	-
86	L	-
87	BR	-
88	BR	-
89	BR	-
90	BR	-

Connector No.	D1
Connector Name	FRONT DOOR LOCK ASSEMBLY (DRIVER SIDE)
Connector Type	TE08FY-RS



Terminal No.	Color Of Wire	Signal Name [Specification]
1	P	-
2	LG	-
3	W	-
4	B	-
5	Y	-
6	V	-

Connector No.	D4
Connector Name	WIRE TO WIRE
Connector Type	NH60FW-TS12



Terminal No.	Color Of Wire	Signal Name [Specification]
2	R	- [With DRPO]
3	SB	- [Without DRPO]
4	BG	- [With DRPO]
5	R	- [Without DRPO]
6	V	- [With DRPO]
7	LG	- [Without DRPO]
8	G	-
9	GR	-
10	Y	-
11	SHIELD	-
12	BG	-
13	L	-
14	B	-


15	Y	-
16	GR	-
17	GR	-
18	GR	-
19	R	-
20	W	-
21	LG	-
22	W	-
23	L	-
24	G	-
25	BR	-
26	R	-
27	BR	-
28	V	-
29	B	-
30	W	-
31	P	-
32	Y	-
33	BR	-
34	L	-
35	R	-
36	GR	-
37	G	-
38	P	-
39	L	-
40	P	-
41	L	-
42	BG	-
43	Y	-
44	Y	-
45	W	-
46	R	-
47	BR	-
48	Y	-
49	Y	-
50	GR	-
51	GR	-
52	GR	-
53	GR	-
54	GR	-
55	GR	-
56	BR	-
57	R	-
58	L	-
59	V	-
60	G	-
61	BG	-
62	Y	-
63	S5	-
64	B	-
65	Y	-
66	BR	-
67	Y	-
68	Y	-
69	L	-
70	W	-
71	LG	-
72	P	-

Connector No.	D7
Connector Name	FRONT POWER WINDOW MOTOR (DRIVER SIDE)
Connector Type	TE08FW-TV-LG



Terminal No.	Color Of Wire	Signal Name [Specification]
1	G	-
2	L	-
3	B	-
4	GR	-
5	V	-
6	BR	-

Connector No.	D8
Connector Name	POWER WINDOW MAIN SWITCH
Connector Type	NS16FW-CS



Terminal No.	Color Of Wire	Signal Name [Specification]
3	V	ENCODER +
4	Y	+B
5	G	DN
6	L	UP
7	B	-
8	BR	IGN
9	BR	ENCODER GND
10	B	ENCODER SIG1
11	GR	ENCODER SIG2
12	BR	COM
13	SB	LOCK SW
14	V	UNLOCK SW
15	Y	-
16	P	-


JRKWC4337GB

POWER WINDOW SYSTEM

< WIRING DIAGRAM >

POWER WINDOW SYSTEM

Connector No.	D18
Connector Name	WIRE TO WIRE
Connector Type	NH60FW-TS12



Terminal No.	Color Of Wire	Signal Name [Specification]
1	GR	-
2	P	-
4	SB	-
5	BR	-
6	Y	-
7	LG	-
8	W	-
9	L	-
10	L	-
11	GR	-
13	Y	-
14	R	-
16	R	-
17	B	-
18	W	-
19	G	-
20	GR	-
21	SHIELD	-
22	GR	-
23	BR	-
24	B	-
25	BR	-
26	V	-
27	G	-
28	V	-
29	Y	-
30	R	-
49	LG	-
52	P	-
55	L	-
56	Y	-
57	R	-
58	SB	-
59	R	-
60	G	-
63	B	-

64	Y	-
65	BR	-
66	GR	-
68	W	-
69	L	-
70	GR	-
71	BG	-
72	Y	-

Connector No.	D21
Connector Name	FRONT POWER WINDOW SWITCH (PASSENGER SIDE)
Connector Type	NS16FW-CS

3	4	15	16
8	9	10	11
12	13	14	15



Terminal No.	Color Of Wire	Signal Name [Specification]
3	LG	ENCODER GND
4	V	ENCODER +
8	L	UP
9	G	DOWN
10	Y	+B
11	B	-
12	GR	ENCODER SIG1
13	BR	ENCODER SIG2
16	GR	COM

Connector No.	D25
Connector Name	FRONT POWER WINDOW MOTOR (PASSENGER SIDE)
Connector Type	TEB06FW-IV-LC

2	1	3	4	5	6
---	---	---	---	---	---



Terminal No.	Color Of Wire	Signal Name [Specification]
1	G	-
2	L	-
3	GR	-
4	GR	-
5	V	-
6	BR	-

Connector No.	D31
Connector Name	WIRE TO WIRE
Connector Type	NH10MW-CS10

1	2	3	4	19	20
7					



Terminal No.	Color Of Wire	Signal Name [Specification]
1	BR	-
2	Y	-
3	W	-
4	V	-
7	B	-
19	P	- [With EUSE system]
19	R	- [Without EUSE system]
20	BR	- [With EUSE system]
20	L	- [Without EUSE system]

Connector No.	D33
Connector Name	REAR POWER WINDOW SWITCH LH
Connector Type	NS16FW-CS

3	4	15	16
8	9	10	11
12	13	14	15



Terminal No.	Color Of Wire	Signal Name [Specification]
3	BR	-
4	SB	ENCODER +
5	L	ENCODER -
8	R	MOTOR ON
10	W	+B
11	B	-
12	GR	ENCODER SIG1
15	BG	ENCODER SIG2
16	Y	COM

Connector No.	D38
Connector Name	REAR POWER WINDOW MOTOR LH
Connector Type	TEB06FW-IV-LC

2	1	3	4	5	6
---	---	---	---	---	---



Terminal No.	Color Of Wire	Signal Name [Specification]
1	L	-
2	R	-
3	BR	-
4	BR	-
5	SB	-
6	BG	-

Connector No.	D40
Connector Name	WIRE TO WIRE
Connector Type	NH10MW-CS10

1	2	3	4	19	20
7					



JRKWC4338GB

A
B
C
D
E
F
G
H
I
J
PWC
L
M
N
O
P

POWER WINDOW SYSTEM

< WIRING DIAGRAM >

POWER WINDOW SYSTEM

Terminal No.	Color Of Wire	Signal Name [Specification]
1	BR	-
2	GR	-
3	W	-
4	V	-
7	B	-
19	P	- [With BOSE system]
19	R	- [Without BOSE system]
20	BR	- [With BOSE system]
20	L	- [Without BOSE system]

Connector No.	D43
Connector Name	REAR POWER WINDOW SWITCH RH
Connector Type	NS18FW-CS

8	9	10	11	12	15	16
---	---	----	----	----	----	----

HS

Terminal No.	Color Of Wire	Signal Name [Specification]
3	V	ENCODER GND
4	SB	ENCODER +
6	R	MOTOR UP
8	T	MOTOR DN
10	W	GND
11	B	ENCODER SIG1
12	GR	ENCODER SIG2
15	BG	COM
16	Y	COM

Connector No.	D45
Connector Name	REAR POWER WINDOW MOTOR RH
Connector Type	TE80FW-IV-LG

1	2	3	4	5	6
---	---	---	---	---	---

HS

Terminal No.	Color Of Wire	Signal Name [Specification]
1	L	-
2	R	-
3	V	-
4	GR	-
5	SB	-
6	BG	-

Connector No.	E25
Connector Name	WIRE TO WIRE
Connector Type	TH80FW-CS16-TM4

1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18
---	---	---	---	---	---	---	---	---	----	----	----	----	----	----	----	----	----

HS

Terminal No.	Color Of Wire	Signal Name [Specification]
2	W	-
3	LG	-
4	BR	-
6	V	-
7	L	-
10	BR	-
11	L	-
12	GR	-
13	W	-
14	B	-
15	SB	-
16	Y	-
17	BR	-
18	P	-

31	Y	-
32	GR	-
33	GR	-
34	V	-
35	L	-
36	Y	-
37	SB	-
38	W	-
39	B	-
40	SB	-
41	LG	-
44	Y	-
45	W	-
46	B	-
47	G	-
48	SHIELD	-
49	R	-
50	BR	-
51	L	-
52	W	-
53	V	-
54	P	-
55	W	-
56	SB	-
57	BG	-
58	B	-
59	W	-
61	R	-
64	Y	-
65	SB	-
66	GR	-
67	LG	-
68	BG	-
69	V	-
72	V	-
73	G	-
74	BR	-
75	V	-
76	P	-
78	SB	-
83	R	-
86	BG	-
91	G	-
92	Y	-
94	GR	-
95	BG	-
96	W	-
97	LG	-
98	L	-
99	P	-
100	SHIELD	-

Connector No.	M13
Connector Name	BCM (BODY CONTROL MODULE)
Connector Type	TH40FG-2H

1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20
---	---	---	---	---	---	---	---	---	----	----	----	----	----	----	----	----	----	----	----

HS

Terminal No.	Color Of Wire	Signal Name [Specification]
1	R	PUSH SW
3	Y	SENS PWR SPLY
4	BG	OPTICAL SENSOR
5	LG	-
10	W	COMET SW OUTPUT 5
11	SB	COMET SW OUTPUT 4
12	L	COMET SW OUTPUT 3
13	G	COMET SW OUTPUT 2
14	P	COMET SW OUTPUT 1
15	G	ONE TOUCH UNLK SENS (DR)
16	G	ONE TOUCH UNLK SENS (PASS)
17	P	RECEIVER SENSOR GND
18	L	SECURITY IND LAMP CONT
20	R	DETENT SW
21	SB	STEP LAMP CONT
22	R	STOP LAMP SW
23	R	EXTENDED LOCK/UNLOCK SW
24	P	STOP LAMP SW
30	W	DR DOOR UNLK SENS
33	V	TR LID OP CANCEL SW
36	G	HAZARD SW
39	BR	P/N POSITION


JRKWC4339GB

POWER WINDOW SYSTEM


< WIRING DIAGRAM >

POWER WINDOW SYSTEM

Connector No.	M14
Connector Name	BCM (BODY CONTROL MODULE)
Connector Type	TH402F-BH




Connector No.	M15
Connector Name	BCM (BODY CONTROL MODULE)
Connector Type	TH24FG-4H



Terminal No.	Color	Wire	Signal Name [Specification]
48	R		PUSH-BTN IGN SW ILL PWR
52	G		DOOR LINK
54	V		COMB LINE
55	R		RAIN SENSOR
59	P		CAN-L
60	L		CAN-H
61	G		REAR WINDOW DEF RLY CONT
62	R		STARTER RLY CONT
64	V		I-KEY WARN BUZZER
65	B		OUTS HD LAMP CONT
66	B		BLOWER FAN RLY CONT
67	W/B		IGN RLY V (F/B) CONT
68	R		DIMMER
69	GR		A/T SHIFT SELECT PWR SPLY
70	B		IGN RLY V (PDM) F/R CONT
71	G		DR DOOR REQ SW
72	SB		PASS DOOR REQ SW
73	BR		COMBI SW IN/OUT 3
75	GR		COMBI SW IN/OUT 1
76	V		COMBI SW IN/OUT 2
78	Y		COMBI SW IN/OUT 1
79	LG		TR LID OPN SW
80	L		

Terminal No.	Color	Wire	Signal Name [Specification]
82	W		REAR LH DOOR SW
83	L		TR LID OPEN REQ SW
85	P		TR ROOM LAMP CONT
91	GR		TRUNK LID OPEN
92	W		TURN SIG RH OUTPUT (SIDE REAR)
93	G		REAR RH DOOR SW
94	GR		PASSENGER DOOR SW
96	V		DRIVER DOOR SW
97	R		TR ROOM LAMP SW
99	GR		INSIDE KEY ANT (TRUNK) +
100	W		INSIDE KEY ANT (TRUNK) -
101	BG		REAR BMR ANT +
102	LG		REAR BMR ANT -
103	Y		TURN SIG LH OUTPUT (SIDE REAR)

Connector No.	M16
Connector Name	BCM (BODY CONTROL MODULE)
Connector Type	TH24FB-BH



Terminal No.	Color	Wire	Signal Name [Specification]
105	V		TURN SIG RH OUTPUT (FRONT)
107	P		PUSH-BTN IGN SW ILL GND
111	Y		ACC/ON IND
113	SB		ACC RELAY CONT
114	LG		PASSENGER DOOR ANT +
115	V		PASSENGER DOOR ANT -

116	BR		INSIDE KEY ANT (CONSOLE) +
117	W/B		TURN SIG LH OUTPUT (FRONT)
119	L		RTLS EXT RECEIV COMM
121	SS		DRIVER DOOR ANT +
122	BG		DRIVER DOOR ANT -
123	GR		INSIDE KEY ANT (INSTRUMENT LOWER) +
124	G		INSIDE KEY ANT (INSTRUMENT LOWER) -
126	W		NATS ANT AMP
127	B		NATS ANT AMP
128	GR		INSIDE KEY ANT (CONSOLE) -

Connector No.	M17
Connector Name	BCM (BODY CONTROL MODULE)
Connector Type	FEA09FW-FHAG-SA



Terminal No.	Color	Wire	Signal Name [Specification]
129	LG		INT ROOM LAMP PWR SPLY
130	P		PASS DOOR UNLK OUTPUT
131	Y		BAT (FUSE)
132	V		RR RL DOOR UNLK OUTPUT
133	BR		RR RL DOOR UNLK OUTPUT
134	G		GND
135	GR		FRONT DOOR FL UNLK OUTPUT
136	V		INT ROOM LAMP CONT
137	LG		FRONT DOOR RL UNLK OUTPUT
138	P		REAR DOORS ACT PWR SPLY
139	W		BAT (F/L)
140	BR		IGN ON
141	R		PWR SPLY (BAT)
142	R		FRONT DOORS, FL LID ACT PWR SPLY
143	B		GND

Connector No.	M19
Connector Name	WIRE TO WIRE
Connector Type	TH60MH-CS16-TM



Terminal No.	Color	Wire	Signal Name [Specification]
1	Y		
2	G		
3	SB		
4	BR		
5	R		
6	R		
7	W		
8	V		
9	BR		
10	P		
11	BR		
12	LG		
13	GR		
24	Y		
25	W		
31	BR		
32	B		
33	B		
34	Y		
35	GR		
36	W		
37	SB		
38	LG		
40	P		
41	G		
42	BR		
43	BR		
44	BR		
46	BG		
51	Y		
52	V		
54	R		
55	R		
57	W		
58	V		
59	BG		
62	BG		

JRKWC4340GB


POWER WINDOW SYSTEM

< WIRING DIAGRAM >

POWER WINDOW SYSTEM

83	BR	-
84	W	-
85	W	-
86	LG	- [With DDM]
87	W	- [Without DDM]
88	BR	-
89	W	-
90	W	-
91	GR	-
92	W	-
93	W	-
94	GR	-
95	W	-
96	W	-
97	V	-
98	BR	-

Connector No.	M22
Connector Name	WIRE TO WIRE
Connector Type	TH80MW-CS16-TM4



Terminal No.	Color Of Wire	Signal Name [Specification]
1	LG	-
2	L	-
3	R	-
4	SHIELD	-
5	G	-
6	BR	-
7	LG	-
8	P	-
9	SHIELD	-
10	V	-
11	GR	-
12	V	-
13	LG	-

14	LG	-
15	SB	- [With DDM]
16	Y	- [Without DDM]
17	Y	-
18	L	-
19	G	-
20	GR	-
21	R	-
22	W	-
23	L	-
24	V	-
25	LG	-
26	GR	-
27	SB	-
28	LG	-
29	R	-
30	LG	-
31	R	-
32	R	-
33	W	-
34	V	-
35	G	-
36	SHIELD	-
37	G	-
38	SHIELD	-
39	V	-
40	G	-
41	G	-
42	BR	-
43	SB	-
44	Y	-
45	R	-
46	GR	-
47	R	-
48	SB	-
49	SB	-
50	Y	-
51	R	-
52	R	-
53	GR	-
54	GR	-
55	R	-
56	SB	-
57	LG	-
58	Y	-
59	L	-
60	W	-
61	R	-
62	L	-
63	P	-
64	R	-
65	L	-
66	R	-
67	L	-
68	P	-
69	R	-
70	G	-
71	SHIELD	-
72	V	-
73	BR	-
74	BR	-
75	V	-
76	V	-
77	BR	-
78	BR	-
79	BR	-
80	V	-
81	LG	-
82	BR	-
83	BR	-
84	BR	-
85	V	-
86	V	-
87	V	-
88	V	-
89	V	-
90	V	-
91	V	-
92	W	-
93	R	-
94	R	-

95	Y	-
96	W	-
97	W	-
98	BR	-
99	BR	-
100	BR	-

Connector No.	M33
Connector Name	WIRE TO WIRE
Connector Type	NH80MW-TS12



Terminal No.	Color Of Wire	Signal Name [Specification]
1	W	-
2	W	-
3	G	- [With DRPO]
4	G	- [Without DRPO]
5	G	-
6	R	-
7	R	-
8	GR	-
9	GR	-
10	GR	-
11	SHIELD	-
12	SB	-
13	SB	-
14	LG	-
15	Y	-
16	Y	-
17	P	-
18	W/B	-
19	Y	- [With DRPO]
20	V	- [Without DRPO]
21	B	-
22	EG	-
23	G	- [With DRPO]
24	L	-
25	Y	-
26	EG	-
27	L	-
28	Y	-
29	Y	-
30	Y	-
31	Y	-
32	Y	-
33	Y	-
34	Y	-
35	Y	-
36	Y	-
37	Y	-
38	Y	-
39	Y	-
40	Y	-
41	Y	-
42	Y	-
43	Y	-
44	Y	-
45	Y	-
46	Y	-
47	Y	-
48	Y	-
49	Y	-
50	Y	-
51	Y	-
52	Y	-
53	Y	-
54	Y	-
55	Y	-
56	Y	-
57	Y	-
58	Y	-
59	Y	-
60	Y	-
61	Y	-
62	Y	-
63	Y	-
64	Y	-
65	Y	-
66	Y	-
67	Y	-
68	Y	-
69	Y	-
70	Y	-
71	Y	-
72	Y	-


JRKWC4341GB

POWER WINDOW SYSTEM

< WIRING DIAGRAM >

POWER WINDOW SYSTEM

Connector No.	M44
Connector Name	WIRE TO WIRE
Connector Type	TH460MW-TS12



Terminal No.	Color Of Wire	Signal Name [Specification]
1	V	-
2	R	-
4	G	- [With DRPO]
5	SB	- [Without DRPO]
6	R	-
7	R	-
8	W	-
9	GR	-
10	V	-
11	Y	-
13	LG	-
14	W	-
16	G	-
17	B	-
18	W	-
19	B	-
20	SB	- [With DRPO]
20	Y	- [Without DRPO]
21	SHIELD	-
22	B	-
23	B	-
23	B	- [Without DRPO]
23	P	- [With DRPO]
24	G	-
25	LG	-
26	B	-
26	B	- [Without DRPO]
26	B	- [With DRPO]
27	R	-
28	SB	-
29	B	-
29	B	- [Without DRPO]
29	W/B	- [With DRPO]
30	L	-
49	P	-
52	V	-
55	B	-
56	SB	-

POWER WINDOW SYSTEM

Connector No.	M113
Connector Name	REMOTE KEYLESS ENTRY RECEIVER
Connector Type	AAG04FB



Terminal No.	Color Of Wire	Signal Name [Specification]
1	W	+12V
2	L	SIGNAL
3	P	GND

POWER WINDOW SYSTEM

Connector No.	M133
Connector Name	FUSE BLOCK (J/B)
Connector Type	TH40FM-NH



Terminal No.	Color Of Wire	Signal Name [Specification]
1	W	+12V
2	L	SIGNAL
3	P	GND

POWER WINDOW SYSTEM

Connector No.	M40
Connector Name	WIRE TO WIRE
Connector Type	TH80MW-CS16-TM4



Terminal No.	Color Of Wire	Signal Name [Specification]
2	GR	-
3	L	-
4	W/B	-
7	W	-
10	W	-
11	W	-
12	B	-
13	GR	-
14	B	-
15	SB	-
16	B	-
17	LG	-
18	B	-
31	W	-
32	V	-
35	B	-
36	G	-
37	B	-
38	L	-
39	Y	-
40	GR	-

POWER WINDOW SYSTEM

Connector No.	M133
Connector Name	FUSE BLOCK (J/B)
Connector Type	TH40FM-NH



Terminal No.	Color Of Wire	Signal Name [Specification]
1	W	+12V
2	L	SIGNAL
3	P	GND

JRKWC4342GB

POWER WINDOW SYSTEM

< WIRING DIAGRAM >

POWER WINDOW SYSTEM		
28C	W	-
29C	W	-
30C	R	-
31C	W	-
32C	R	-
33C	R	-
34C	W/B	-
35C	SB	-
36C	R	-
37C	W	-
38C	SB	-
39C	V	-
40C	P	-
41C	G	-
42C	P	-
43C	P	-
44C	G	-
45C	G	-
46C	V	-
47C	V	-
48C	V	-

JRKWC4343GB

DIAGNOSIS AND REPAIR WORK FLOW

< BASIC INSPECTION >

BASIC INSPECTION

DIAGNOSIS AND REPAIR WORK FLOW

Work Flow

INFOID:000000009238453

DETAILED FLOW

1.OBTAIN INFORMATION ABOUT SYMPTOM

Interview the customer to obtain as much malfunction information (conditions and environment when the malfunction occurred) as possible when the customer brings the vehicle in.

>> GO TO 2.

2.REPRODUCE THE MALFUNCTION INFORMATION

Check the malfunction on the vehicle that the customer describes.
Inspect the relation of the symptoms and the condition when the symptoms occur.

>> GO TO 3.

3.IDENTIFY THE MALFUNCTIONING SYSTEM WITH "SYMPTOM DIAGNOSIS"

Use "Symptom diagnosis" from the symptom inspection result in step 2. Then identify where to start the diagnosis based on possible causes and symptoms.

>> GO TO 4.

4.IDENTIFY MALFUNCTIONING PARTS WITH "DTC/CIRCUIT DIAGNOSIS"

Perform the diagnosis with "DTC/CIRCUIT DIAGNOSIS" of the applicable system.

>> GO TO 5.

5.REPAIR OR REPLACE THE MALFUNCTIONING PARTS

Repair or replace the specified malfunctioning parts.

>> GO TO 6.

6.FINAL CHECK

Check that malfunctions are not reproduced when obtaining the malfunction information from the customer, referring to the symptom inspection result in step 2.

Is the malfunctioning part repaired or replaced?

YES >> Trouble diagnosis is completed.

NO >> GO TO 3.

A
B
C
D
E
F
G
H
I
J
PWC
L
M
N
O
P

ADDITIONAL SERVICE WHEN REMOVING BATTERY NEGATIVE TERMINAL

< BASIC INSPECTION >

ADDITIONAL SERVICE WHEN REMOVING BATTERY NEGATIVE TERMINAL

Description

INFOID:000000009238454

Initialize the system if any of the following work has been done.

- When control unit replaced.
- Electric power supply to power window switch or motor is interrupted by blown fuse or disconnection and connection of the negative terminal of battery, etc.
- Removal and installation of regulator assembly.
- Power supply to the power window main switch or power window motor is cut off by the removal of battery terminal or if the battery fuse is blown.
- Disconnection and connection of power window main switch harness connector.
- Removal and installation of motor from regulator assembly.
- Operation of regulator assembly as an independent unit.
- Removal and installation of door glass.
- Removal and installation of door glass run.

The following specified operations can not be performed under the non-initialized condition.

- Auto-up operation
- Anti-pinch function

Work Procedure

INFOID:000000009238455

1.SYSTEM INITIALIZATION

Perform system initialization. Refer to [PWC-40. "Work Procedure"](#).

>> GO TO 2.

2.CHECK ANTI-PINCH FUNCTION

Check anti-pinch function. Refer to [PWC-41. "Work Procedure"](#).

>> END

ADDITIONAL SERVICE WHEN REPLACING POWER WINDOW MAIN SWITCH

< BASIC INSPECTION >

ADDITIONAL SERVICE WHEN REPLACING POWER WINDOW MAIN SWITCH

Description

INFOID:0000000009728009

When the control unit replaced, the initialization is necessary for normal operation of power window system.

CAUTION:

The following specified operations can not be performed under the non-initialized condition.

- Auto-up operation
- Anti-pinch function

Work Procedure

INFOID:0000000009728010

1.SYSTEM INITIALIZATION

Perform system initialization. Refer to [PWC-40. "Work Procedure"](#).

>> GO TO 2.

2.CHECK ANTI-PINCH FUNCTION

Check anti-pinch function. Refer to [PWC-41. "Work Procedure"](#).

>> END

PWC

SYSTEM INITIALIZATION

< BASIC INSPECTION >

SYSTEM INITIALIZATION

Description

INFOID:000000009238458

Initialize the system if any of the following work has been done.

- When control unit replaced.
- Electric power supply to power window switch or motor is interrupted by blown fuse or disconnection and connection of the negative terminal of battery, etc.
- Removal and installation of regulator assembly.
- Power supply to the power window main switch or power window motor is cut off by the removal of battery terminal or if the battery fuse is blown.
- Disconnection and connection of power window main switch harness connector.
- Removal and installation of motor from regulator assembly.
- Operation of regulator assembly as an independent unit.
- Removal and installation of door glass.
- Removal and installation of door glass run.

The following specified operations can not be performed under the non-initialized condition.

- Auto-up operation
- Anti-pinch function

Work Procedure

INFOID:000000009238459

1.STEP 1

1. Turn ignition switch ON.
2. Operate power window switch to fully open the window. (This operation is unnecessary if the window is already fully open)

>> GO TO 2.

2.STEP 2

Continue pulling the power window switch UP (AUTO-UP operation). Even after glass stops at fully closed position, keep pulling the switch for 2 seconds or more.

>> GO TO 3.

3.STEP 3

Check that auto-up function operates normally.

>> GO TO 4.

4.STEP 4

Check anti-pinch function. Refer to [PWC-41, "Work Procedure"](#).

>> END

CHECK ANTI-PINCH FUNCTION

< BASIC INSPECTION >

CHECK ANTI-PINCH FUNCTION

Description

INFOID:000000009238460

Initialize the system if any of the following work has been done.

- When control unit replaced.
- Electric power supply to power window switch or motor is interrupted by blown fuse or disconnection and connection of the negative terminal of battery, etc.
- Removal and installation of regulator assembly.
- Power supply to the power window main switch or power window motor is cut off by the removal of battery terminal or if the battery fuse is blown.
- Disconnection and connection of power window main switch harness connector.
- Removal and installation of motor from regulator assembly.
- Operation of regulator assembly as an independent unit.
- Removal and installation of door glass.
- Removal and installation of door glass run.

The following specified operations can not be performed under the non-initialized condition.

- Auto-up operation
- Anti-pinch function

Work Procedure

INFOID:000000009238461

1.STEP 1

Fully open the door window.

>> GO TO 2.

2.STEP 2

Place a piece of wood near fully closed position.

>> GO TO 3.

3.STEP 3

Close door glass completely with AUTO-UP.

>> GO TO 4.

4.STEP 4

Check the following conditions

- Check that glass lowers for approximately [front: 150 mm (5.9 in), rear: 116 mm (4.5 in)] without pinching piece of wood and stops.
- Check that glass does not rise not when operating the power window main switch while lowering.

CAUTION:

- **Perform initial setting when auto-up operation or anti-pinch function does not operate normally.**
- **Check that AUTO-UP operates before inspection when system initialization is performed.**
- **Do not check with hands and other body parts because they may be pinched. Do not get pinched.**
- **It may switch to fail-safe mode if open/close operation is performed continuously without full close. Perform initial setting in that situation. Refer to [PWC-40, "Work Procedure"](#).**

>> END

A
B
C
D
E
F
G
H
I
J
PWC
L
M
N
O
P

POWER SUPPLY AND GROUND CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

DTC/CIRCUIT DIAGNOSIS

POWER SUPPLY AND GROUND CIRCUIT

POWER WINDOW MAIN SWITCH

POWER WINDOW MAIN SWITCH : Diagnosis Procedure

INFOID:000000009238463

1.CHECK POWER SUPPLY CIRCUIT 1

1. Turn ignition switch OFF.
2. Disconnect power window main switch connectors.
3. Turn ignition switch ON.
4. Check voltage between power window main switch harness connector and ground.

(+)		(-)	Voltage (V)
Power window main switch			
Connector	Terminal		
D8	4	Ground	9 - 16
	9		

Is the inspection result normal?

YES >> GO TO 2.

NO >> GO TO 3.

2.CHECK GROUND CIRCUIT

1. Turn ignition switch OFF.
2. Check continuity between power window main switch harness connector and ground.

Power window main switch		Ground	Continuity
Connector	Terminal		
D8	7		Existed

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair or replace harness.

3.CHECK POWER SUPPLY CIRCUIT 2

1. Turn ignition switch OFF.
2. Disconnect BCM connector.
3. Check continuity between BCM harness connector and power window main switch harness connector.

BCM		Power window main switch		Continuity
Connector	Terminal	Connector	Terminal	
M17	140	D8	9	Existed
	141		4	

4. Check continuity between BCM harness connector and ground.

BCM		Ground	Continuity
Connector	Terminal		
M17	140		Not existed
	141		

Is the inspection result normal?

YES >> Replace BCM. Refer to [BCS-98, "Removal and Installation"](#) .

NO >> Repair or replace harness.

4.CHECK INTERMITTENT INCIDENT

POWER SUPPLY AND GROUND CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

Refer to [GI-43, "Intermittent Incident"](#).

>> INSPECTION END

FRONT POWER WINDOW SWITCH (PASSENGER SIDE)

FRONT POWER WINDOW SWITCH (PASSENGER SIDE) : Diagnosis Procedure

INFOID:000000009238464

1.CHECK POWER SUPPLY CIRCUIT 1

1. Turn ignition switch OFF.
2. Disconnect front power window switch (passenger side) connector.
3. Turn ignition switch ON.
4. Check voltage between front power window switch (passenger side) harness connector and ground.

(+)		(-)	Voltage (V)
Front power window switch (passenger side)			
Connector	Terminal		
D21	10	Ground	9 - 16

Is the inspection result normal?

YES >> GO TO 2.

NO >> GO TO 3.

2.CHECK GROUND CIRCUIT

1. Turn ignition switch OFF.
2. Check continuity between front power window switch (passenger side) harness connector and ground.

Front power window switch (passenger side)		Ground	Continuity
Connector	Terminal		
D21	11		Existed

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair or replace harness.

3.CHECK POWER SUPPLY CIRCUIT 2

1. Turn ignition switch OFF.
2. Disconnect BCM connector.
3. Check continuity between BCM harness connector and front power window switch (passenger side) harness connector.

BCM		Front power window switch (passenger side)		Continuity
Connector	Terminal	Connector	Terminal	
M17	141	D21	10	Existed

4. Check continuity between BCM harness connector and ground.

BCM		Ground	Continuity
Connector	Terminal		
M17	141		Not existed

Is the inspection result normal?

YES >> Replace BCM. Refer to [BCS-98, "Removal and Installation"](#).

NO >> Repair or replace harness.

4.CHECK INTERMITTENT INCIDENT

Refer to [GI-43, "Intermittent Incident"](#).

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

PWC

POWER SUPPLY AND GROUND CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

>> INSPECTION END

REAR POWER WINDOW SWITCH

REAR POWER WINDOW SWITCH : Diagnosis Procedure

INFOID:000000009238465

1.CHECK POWER SUPPLY CIRCUIT 1

1. Turn ignition switch OFF.
2. Disconnect rear power window switch connector.
3. Turn ignition switch ON.
4. Check voltage between rear power window switch harness connector and ground.

(+) Rear power window switch		Terminal	(-)	Voltage (V)
Connector				
LH	D33	10	Ground	9 - 16
RH	D43			

Is the inspection result normal?

YES >> GO TO 2.

NO >> GO TO 3.

2.CHECK GROUND CIRCUIT

1. Turn ignition switch OFF.
2. Check continuity between rear power window switch harness connector and ground.

Rear power window switch		Terminal	Ground	Continuity
Connector				
LH	D33	11		Existed
RH	D43			

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair or replace harness.

3.CHECK POWER SUPPLY CIRCUIT 2

1. Turn ignition switch OFF.
2. Disconnect BCM connector.
3. Check continuity between BCM harness connector and rear power window switch harness connector.

BCM		Rear power window switch		Continuity
Connector	Terminal	Connector	Terminal	
M17	141	LH	D33	Existed
		RH	D43	

4. Check continuity between BCM harness connector and ground.

BCM		Ground	Continuity
Connector	Terminal		
M17	141		Not existed

Is the inspection result normal?

YES >> Replace BCM. Refer to [BCS-98, "Removal and Installation"](#).

NO >> Repair or replace harness.

4.CHECK INTERMITTENT INCIDENT

Refer to [GI-43, "Intermittent Incident"](#).

POWER SUPPLY AND GROUND CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

>> INSPECTION END

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

PWC

POWER WINDOW MOTOR

< DTC/CIRCUIT DIAGNOSIS >

POWER WINDOW MOTOR DRIVER SIDE

DRIVER SIDE : Component Function Check

INFOID:000000009238466

1.CHECK POWER WINDOW MOTOR CIRCUIT

Check front power window motor (driver side) operation with power window main switch.

Is the inspection result normal?

YES >> Front power window motor (driver side) is OK.

NO >> Refer to [PWC-46. "DRIVER SIDE : Diagnosis Procedure"](#).

DRIVER SIDE : Diagnosis Procedure

INFOID:000000009238467

1.CHECK FRONT POWER WINDOW MOTOR INPUT SIGNAL

1. Turn ignition switch OFF.
2. Disconnect front power window motor (driver side) connector.
3. Turn ignition switch ON.
4. Check voltage between front power window motor (driver side) harness connector and ground.

(+) Front power window motor (driver side)		(-)	Condition		Voltage (V)
Connector	Terminal				
D7	2	Ground	Power window main switch	NEUTRAL	0 - 1
				UP	9 - 16
	1			NEUTRAL	0 - 1
				DOWN	9 - 16

Is the inspection result normal?

YES >> Replace front power window motor (driver side). Refer to [GW-37. "Removal and Installation"](#).

NO >> GO TO 2.

2.CHECK POWER WINDOW MOTOR CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect power window main switch connector.
3. Check continuity between power window main switch harness connector and front power window motor (driver side) harness connector.

Power window main switch		Front power window motor (driver side)		Continuity
Connector	Terminal	Connector	Terminal	
D8	5	D7	1	Existed
	6		2	

4. Check continuity between power window main switch harness connector and ground.

Power window main switch		Ground	Continuity
Connector	Terminal		
D8	5		Not existed
	6		

Is the inspection result normal?

YES >> Replace power window main switch. Refer to [PWC-79. "Removal and Installation"](#).

NO >> Repair or replace harness.

PASSENGER SIDE

POWER WINDOW MOTOR

< DTC/CIRCUIT DIAGNOSIS >

PASSENGER SIDE : Component Function Check

INFOID:000000009238468

1. CHECK POWER WINDOW MOTOR CIRCUIT

Check front power window motor (passenger side) operation with power window main switch or front power window switch (passenger side).

Is the inspection result normal?

- YES >> Front power window motor (passenger side) is OK.
NO >> Refer to [PWC-47, "PASSENGER SIDE : Diagnosis Procedure"](#).

PASSENGER SIDE : Diagnosis Procedure

INFOID:000000009238469

1.CHECK FRONT POWER WINDOW MOTOR INPUT SIGNAL

1. Turn ignition switch OFF.
2. Disconnect front power window motor (passenger side) connector.
3. Turn ignition switch ON.
4. Check voltage between front power window motor (passenger side) harness connector and ground.

(+) Front power window motor (passenger side)		(-)	Condition		Voltage (V)
Connector	Terminal				
D25	2	Ground	Front power window switch (passenger side)	NEUTRAL	0 - 1
				UP	9 - 16
	1			NEUTRAL	0 - 1
				DOWN	9 - 16

Is the inspection result normal?

- YES >> Replace front power window motor (passenger side). Refer to [GW-37, "Removal and Installation"](#).
NO >> GO TO 2.

2.CHECK POWER WINDOW MOTOR CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect front power window switch (passenger side) connector.
3. Check continuity between front power window switch (passenger side) harness connector and front power window motor (passenger side) harness connector.

Front power window switch (passenger side)		Front power window motor (passenger side)		Continuity
Connector	Terminal	Connector	Terminal	
D21	8	D25	2	Existed
	9		1	

4. Check continuity between front power window switch (passenger side) connector and ground.

Front power window switch (passenger side)		Ground	Continuity
Connector	Terminal		
D21	8		Not existed
	9		

Is the inspection result normal?

- YES >> Replace front power window switch (passenger side). Refer to [PWC-79, "Removal and Installation"](#).
NO >> Repair or replace harness.

REAR LH

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

PWC

POWER WINDOW MOTOR

< DTC/CIRCUIT DIAGNOSIS >

REAR LH : Component Function Check

INFOID:000000009238470

1.CHECK POWER WINDOW MOTOR CIRCUIT

Check rear power window motor LH operation with power window main switch or rear power window switch LH.

Is the inspection result normal?

YES >> Rear power window motor LH is OK.

NO >> Refer to [PWC-48, "REAR LH : Diagnosis Procedure"](#).

REAR LH : Diagnosis Procedure

INFOID:000000009238471

1.CHECK REAR POWER WINDOW MOTOR INPUT SIGNAL

1. Turn ignition switch OFF.
2. Disconnect rear power window motor LH connector.
3. Turn ignition switch ON.
4. Check voltage between rear power window motor LH harness connector and ground.

(+)Rear power window motor LH		(-)	Condition		Voltage (V)
Connector	Terminal				
D36	2	Ground	Rear power window switch LH	NEUTRAL	0 - 1
				UP	9 - 16
	1			NEUTRAL	0 - 1
				DOWN	9 - 16

Is the inspection result normal?

YES >> Replace rear power window motor LH. Refer to [GW-44, "Removal and Installation"](#).

NO >> GO TO 2.

2.CHECK POWER WINDOW MOTOR CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect rear power window switch LH connector.
3. Check continuity between rear power window switch LH harness connector and rear power window motor LH harness connector.

Rear power window switch LH		Rear power window motor LH		Continuity
Connector	Terminal	Connector	Terminal	
D33	8	D36	2	Existed
	9		1	

4. Check continuity between rear power window switch LH harness connector and ground.

Rear power window switch LH		Ground	Continuity
Connector	Terminal		
D33	8		Not existed
	9		

Is the inspection result normal?

YES >> Replace rear power window switch LH. Refer to [PWC-80, "Removal and Installation"](#).

NO >> Repair or replace harness.

REAR RH

REAR RH : Component Function Check

INFOID:000000009238472

1. CHECK POWER WINDOW MOTOR CIRCUIT

POWER WINDOW MOTOR

< DTC/CIRCUIT DIAGNOSIS >

Check rear power window motor RH operation with power window main switch or rear power window switch RH.

Is the inspection result normal?

- YES >> Rear power window motor RH is OK.
NO >> Refer to [PWC-49, "REAR RH : Diagnosis Procedure"](#).

REAR RH : Diagnosis Procedure

INFOID:000000009238473

1.CHECK REAR POWER WINDOW MOTOR INPUT SIGNAL

1. Turn ignition switch OFF.
2. Disconnect rear power window motor RH connector.
3. Turn ignition switch ON.
4. Check voltage between rear power window motor RH harness connector and ground.

(+)		(−)	Condition		Voltage (V)
Rear power window motor RH					
Connector	Terminal				
D45	2	Ground	Rear power window switch RH	NEUTRAL	0 - 1
				UP	9 - 16
	1			NEUTRAL	0 - 1
				DOWN	9 - 16

Is the inspection result normal?

- YES >> Replace rear power window motor RH. Refer to [GW-44, "Removal and Installation"](#).
NO >> GO TO 2.

2.CHECK POWER WINDOW MOTOR CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect rear power window switch RH connector.
3. Check continuity between rear power window switch RH harness connector and rear power window motor RH harness connector.

Rear power window switch RH		Rear power window motor RH		Continuity
Connector	Terminal	Connector	Terminal	
D43	8	D45	2	Existed
	9		1	

4. Check continuity between rear power window switch RH harness connector and ground.

Rear power window switch RH		Ground	Continuity
Connector	Terminal		
D43	8		Not existed
	9		

Is the inspection result normal?

- YES >> Replace rear power window switch RH. Refer to [PWC-80, "Removal and Installation"](#).
NO >> Repair or replace harness.

ENCODER

< DTC/CIRCUIT DIAGNOSIS >

ENCODER

DRIVER SIDE

DRIVER SIDE : Component Function Check

INFOID:000000009238474

1.CHECK ENCODER

Check that driver side door glass performs AUTO open/close operation normally by power window main switch.

Is the inspection result normal?

YES >> Encoder is OK.

NO >> Refer to [PWC-50, "DRIVER SIDE : Diagnosis Procedure"](#).


DRIVER SIDE : Diagnosis Procedure

INFOID:000000009238475

1.CHECK ENCODER SIGNAL

1. Turn ignition switch ON.
2. Check signal between power window main switch harness connector and ground with oscilloscope.

(+) Power window main switch		(-)	Signal (Reference value)
Connector	Terminal		
D8	11	Ground	Refer to following signal
	12		



Is the inspection result normal?

YES >> Replace power window main switch. Refer to [PWC-79, "Removal and Installation"](#).

NO >> GO TO 2.

2.CHECK ENCODER SIGNAL CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect power window main switch connector and front power window motor (driver side) connector.
3. Check continuity between power window main switch harness connector and front power window motor (driver side) harness connector.

Power window main switch		Front power window motor (driver side)		Continuity
Connector	Terminal	Connector	Terminal	
D8	11	D7	4	Existed
	12		6	

4. Check continuity between power window main switch harness connector and ground.

ENCODER

< DTC/CIRCUIT DIAGNOSIS >

Power window main switch		Ground	Continuity
Connector	Terminal		
D8	11		Not existed
	12		

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace harness.

3.CHECK ENCODER POWER SUPPLY CIRCUIT 1

1. Connect power window main switch connector.
2. Turn ignition switch ON.
3. Check voltage between front power window motor (driver side) harness connector and ground.

(+)		(-)	Voltage (V)
Front power window motor (driver side)			
Connector	Terminal		
D7	5	Ground	9 - 16

Is the inspection result normal?

YES >> GO TO 5.

NO >> GO TO 4.

4.CHECK ENCODER POWER SUPPLY CIRCUIT 2

1. Turn ignition switch OFF.
2. Disconnect power window main switch connector.
3. Check continuity between power window main switch harness connector and front power window motor (driver side) harness connector.

Power window main switch		Front power window motor (driver side)		Continuity
Connector	Terminal	Connector	Terminal	
D8	3	D7	5	Existed

4. Check continuity between power window main switch harness connector and ground.

Power window main switch		Ground	Continuity
Connector	Terminal		
D8	3		Not existed

Is the inspection result normal?

YES >> Replace power window main switch. Refer to [PWC-79. "Removal and Installation"](#).

NO >> Repair or replace harness.

5.CHECK GROUND CIRCUIT 1

1. Turn ignition switch OFF.
2. Check continuity between front power window motor (driver side) harness connector and ground.

Front power window motor (driver side)		Ground	Continuity
Connector	Terminal		
D7	3		Existed

Is the inspection result normal?

YES >> Replace front power window motor (driver side). Refer to [GW-37. "Removal and Installation"](#).

NO >> GO TO 6.

6.CHECK GROUND CIRCUIT 2

1. Disconnect power window main switch connector.

ENCODER

< DTC/CIRCUIT DIAGNOSIS >

- Check continuity between power window main switch harness connector and front power window motor (driver side) harness connector.

Power window main switch		Front power window motor (driver side)		Continuity
Connector	Terminal	Connector	Terminal	
D8	10	D7	3	Existed

- Check continuity between power window main switch harness connector and ground.

Power window main switch		Ground	Continuity
Connector	Terminal		
D8	10		Not existed

Is the inspection result normal?

YES >> Replace power window main switch. Refer to [PWC-79, "Removal and Installation"](#).

NO >> Repair or replace harness.

PASSENGER SIDE

PASSENGER SIDE : Component Function Check

INFOID:000000009238476

1.CHECK ENCODER

Check that passenger side door glass performs AUTO open/close operation normally by power window main switch or front power window switch (passenger side).

Is the inspection result normal?

YES >> Encoder is OK.

NO >> Refer to [PWC-52, "PASSENGER SIDE : Diagnosis Procedure"](#).


PASSENGER SIDE : Diagnosis Procedure

INFOID:000000009238477

1.CHECK ENCODER SIGNAL

- Turn ignition switch ON.
- Check signal between front power window switch (passenger side) harness connector and ground with oscilloscope.

(+) Front power window switch (passenger side)		(-)	Signal (Reference value)
Connector	Terminal		
D21	12	Ground	Refer to following signal
	15		



Is the inspection result normal?

YES >> Replace front power window switch (passenger side). Refer to [PWC-79, "Removal and Installation"](#).

NO >> GO TO 2.

2.CHECK ENCODER SIGNAL CIRCUIT

- Turn ignition switch OFF.

ENCODER

< DTC/CIRCUIT DIAGNOSIS >

- Disconnect front power window switch (passenger side) connector and front power window motor (passenger side) connector.
- Check continuity between front power window switch (passenger side) harness connector and front power window motor (passenger side) harness connector.

Front power window switch (passenger side)		Front power window motor (passenger side)		Continuity
Connector	Terminal	Connector	Terminal	
D21	12	D25	4	Existed
	15		6	

- Check continuity between front power window switch (passenger side) harness connector and ground.

Front power window switch (passenger side)		Ground	Continuity
Connector	Terminal		
D21	12		Not existed
	15		

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace harness.

3.CHECK ENCODER POWER SUPPLY CIRCUIT 1

- Connect front power window switch (passenger side) connector.
- Turn ignition switch ON.
- Check voltage between front power window motor (passenger side) harness connector and ground.

(+)		(-)	Voltage (V)
Front power window motor (passenger side)			
Connector	Terminal		
D25	5	Ground	9 - 16

Is the inspection result normal?

YES >> GO TO 4.

NO >> GO TO 5.

4.CHECK GROUND CIRCUIT 1

- Turn ignition switch OFF.
- Check continuity between front power window motor (passenger side) harness connector and ground.

Front power window motor (passenger side)		Ground	Continuity
Connector	Terminal		
D25	3		Existed

Is the inspection result normal?

YES >> Replace front power window motor (passenger side). Refer to [GW-37, "Removal and Installation"](#).

NO >> GO TO 6.

5.CHECK ENCODER POWER SUPPLY CIRCUIT 2

- Turn ignition switch OFF.
- Disconnect front power window switch (passenger side) connector.
- Check continuity between front power window switch (passenger side) harness connector and front power window motor (passenger side) harness connector.

Front power window switch (passenger side)		Front power window motor (passenger side)		Continuity
Connector	Terminal	Connector	Terminal	
D21	4	D25	5	Existed

- Check continuity between front power window switch (passenger side) harness connector and ground.

ENCODER

< DTC/CIRCUIT DIAGNOSIS >

Front power window switch (passenger side)		Ground	Continuity
Connector	Terminal		
D21	4		Not existed

Is the inspection result normal?

YES >> Replace front power window switch (passenger side). Refer to [PWC-79, "Removal and Installation"](#).

NO >> Repair or replace harness.

6.CHECK GROUND CIRCUIT 2

1. Disconnect front power window switch (passenger side) connector.
2. Check continuity between front power window switch (passenger side) harness connector and front power window motor (passenger side) harness connector.

Front power window switch (passenger side)		Front power window motor (passenger side)		Continuity
Connector	Terminal	Connector	Terminal	
D21	3	D25	3	Existed

3. Check continuity between front power window switch (passenger side) harness connector and ground.

Front power window switch (passenger side)		Ground	Continuity
Connector	Terminal		
D21	3		Not existed

Is the inspection result normal?

YES >> Replace front power window switch (passenger side). Refer to [PWC-79, "Removal and Installation"](#).

NO >> Repair or replace harness.

REAR LH

REAR LH : Component Function Check

INFOID:000000009238478

1.CHECK ENCODER OPERATION

Check that rear door LH glass performs AUTO open/close operation normally by power window main switch or rear power window switch LH.

Is the inspection result normal?

YES >> Encoder operation is OK.

NO >> Refer to [PWC-54, "REAR LH : Diagnosis Procedure"](#).

REAR LH : Diagnosis Procedure

INFOID:000000009238479


1.CHECK ENCODER SIGNAL

1. Turn ignition switch ON.
2. Check signal between rear power window switch LH harness connector and ground with oscilloscope.

(+)		(-)	Signal (Reference value)
Rear power window switch LH			
Connector	Terminal		
D33	12	Ground	Refer to following signal
	15		

ENCODER

< DTC/CIRCUIT DIAGNOSIS >



Is the inspection result normal?

- YES >> Replace rear power window switch LH. Refer to [PWC-80, "Removal and Installation"](#).
 NO >> GO TO 2.

2.CHECK ENCODER SIGNAL CIRCUIT

- Turn ignition switch OFF.
- Disconnect rear power window switch LH connector and rear power window motor LH connector.
- Check continuity between rear power window switch LH harness connector and rear power window motor LH harness connector.

Rear power window switch LH		Rear power window motor LH		Continuity
Connector	Terminal	Connector	Terminal	
D33	12	D36	4	Existed
	15		6	

- Check continuity rear power window switch LH harness connector and ground.

Rear power window switch LH		Ground	Continuity
Connector	Terminal		
D33	12		Not existed
	15		

Is the inspection result normal?

- YES >> GO TO 3.
 NO >> Repair or replace harness.

3.CHECK ENCODER POWER SUPPLY CIRCUIT 1

- Connect rear power window switch LH connector.
- Turn ignition switch ON.
- Check voltage between rear power window motor LH harness connector and ground.

(+)		(-)	Voltage (V)
Rear power window motor LH			
Connector	Terminal		
D36	5	Ground	9 - 16

Is the inspection result normal?

- YES >> GO TO 4.
 NO >> GO TO 5.

4.CHECK GROUND CIRCUIT 1

- Turn ignition switch OFF.
- Check continuity between rear power window motor LH harness connector and ground.

Rear power window motor LH		Ground	Continuity
Connector	Terminal		
D36	3		Existed

ENCODER

< DTC/CIRCUIT DIAGNOSIS >

Is the inspection result normal?

- YES >> Replace rear power window motor LH. Refer to [GW-44, "Removal and Installation"](#).
NO >> GO TO 6.

5.CHECK ENCODER POWER SUPPLY CIRCUIT2

1. Turn ignition switch OFF.
2. Disconnect rear power window switch LH connector.
3. Check continuity between rear power window switch LH harness connector and rear power window motor LH harness connector.

Rear power window switch LH		Rear power window motor LH		Continuity
Connector	Terminal	Connector	Terminal	
D33	4	D36	5	Existed

4. Check continuity between rear power window switch LH harness connector and ground.

Rear power window switch LH		Ground	Continuity
Connector	Terminal		
D33	4		Not existed

Is the inspection result normal?

- YES >> Replace rear power window switch LH. Refer to [PWC-80, "Removal and Installation"](#).
NO >> Repair or replace harness.

6.CHECK GROUND CIRCUIT 2

1. Disconnect rear power window switch LH harness connector.
2. Check continuity between rear power window switch LH harness connector and rear power window motor LH harness connector.

Rear power window switch LH		Rear power window motor LH		Continuity
Connector	Terminal	Connector	Terminal	
D33	3	D36	3	Existed

3. Check continuity between rear power window switch LH harness connector and ground.

Rear power window switch LH		Ground	Continuity
Connector	Terminal		
D33	3		Not existed

Is the inspection result normal?

- YES >> Replace rear power window switch LH. Refer to [PWC-80, "Removal and Installation"](#).
NO >> Repair or replace harness.

REAR RH

REAR RH : Component Function Check

INFOID:000000009238480

1.CHECK ENCODER OPERATION

Check that rear door RH glass performs AUTO open/close operation normally by power window main switch or rear power window switch RH.

Is the inspection result normal?

- YES >> Encoder operation is OK.
NO >> Refer to [PWC-56, "REAR RH : Diagnosis Procedure"](#).

REAR RH : Diagnosis Procedure

INFOID:000000009238481


1.CHECK ENCODER SIGNAL

1. Turn ignition switch ON.
2. Check signal between rear power window switch RH harness connector and ground with oscilloscope.

ENCODER

< DTC/CIRCUIT DIAGNOSIS >

(+)		(-)	Signal (Reference value)
Rear power window switch RH			
Connector	Terminal		
D43	12	Ground	Refer to following signal
	15		



Is the inspection result normal?

YES >> Replace rear power window switch RH. Refer to [PWC-80, "Removal and Installation"](#).

NO >> GO TO 2.

2.CHECK ENCODER SIGNAL CIRCUIT

- Turn ignition switch OFF.
- Disconnect rear power window switch RH connector and rear power window motor RH connector.
- Check continuity between rear power window switch RH harness connector and rear power window motor RH harness connector.

Rear power window switch RH		Rear power window motor RH		Continuity
Connector	Terminal	Connector	Terminal	
D43	12	D45	4	Existed
	15		6	

- Check continuity rear power window switch RH harness connector and ground.

Rear power window switch RH		Ground	Continuity
Connector	Terminal		
D43	12		Not existed
	15		

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace harness.

3.CHECK ENCODER POWER SUPPLY CIRCUIT 1

- Connect rear power window switch RH connector.
- Turn ignition switch ON.
- Check voltage between rear power window motor RH harness connector and ground.

(+)		(-)	Voltage (V)
Rear power window motor RH			
Connector	Terminal		
D45	5	Ground	9 - 16

Is the inspection result normal?

YES >> GO TO 4.

NO >> GO TO 5.

ENCODER

< DTC/CIRCUIT DIAGNOSIS >

4.CHECK GROUND CIRCUIT 1

1. Turn ignition switch OFF.
2. Check continuity between rear power window motor RH harness connector and ground.

Rear power window motor RH		Ground	Continuity
Connector	Terminal		
D45	3		Existed

Is the inspection result normal?

- YES >> Replace rear power window motor RH. Refer to [GW-44, "Removal and Installation"](#).
NO >> GO TO 6.

5.CHECK ENCORDER POWER SUPPLY CIRCUIT 2

1. Turn ignition switch OFF.
2. Disconnect rear power window switch RH connector.
3. Check continuity between rear power window switch RH harness connector and rear power window motor RH harness connector.

Rear power window switch RH		Rear power window motor RH		Continuity
Connector	Terminal	Connector	Terminal	
D43	4	D45	5	Existed

4. Check continuity between rear power window switch RH harness connector and ground.

Rear power window switch RH		Ground	Continuity
Connector	Terminal		
D43	4		Not existed

Is the inspection result normal?

- YES >> Replace rear power window switch RH. Refer to [PWC-80, "Removal and Installation"](#).
NO >> Repair or replace harness.

6.CHECK GROUND CIRCUIT 2

1. Disconnect rear power window switch RH harness connector.
2. Check continuity between rear power window switch RH harness connector and rear power window motor RH harness connector.

Rear power window switch RH		Rear power window motor RH		Continuity
Connector	Terminal	Connector	Terminal	
D43	3	D45	3	Existed

3. Check continuity between rear power window switch RH harness connector and ground.

Rear power window switch RH		Ground	Continuity
Connector	Terminal		
D43	3		Not existed

Is the inspection result normal?

- YES >> Replace rear power window switch RH. Refer to [PWC-80, "Removal and Installation"](#).
NO >> Repair or replace harness.

DOOR KEY CYLINDER SWITCH

< DTC/CIRCUIT DIAGNOSIS >

DOOR KEY CYLINDER SWITCH

Component Function Check

INFOID:000000009238482

1.CHECK DOOR KEY CYLINDER SWITCH INPUT SIGNAL

Refer to [DLK-100. "Component Function Check"](#).

Is the inspection result normal?

- YES >> Door key cylinder switch is OK.
NO >> Refer to [PWC-59. "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:000000009238483

1.CHECK DOOR KEY CYLINDER SWITCH SIGNAL

1. Turn ignition switch OFF.
2. Disconnect front door lock assembly (driver side) (door key cylinder switch) connect.
3. Turn ignition switch ON.
4. Check voltage between front door lock assembly (driver side) (door key cylinder switch) harness connector and ground.

(+) Front door lock assembly (driver side) (door key cylinder switch)		(-)	Voltage (V)
Connector	Terminal		
D1	5	Ground	4 - 6
	6		

Is the inspection result normal?

- YES >> GO TO 3.
NO >> GO TO 2.

2.CHECK DOOR KEY CYLINDER SWITCH CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect power window main switch connector.
3. Check continuity between power window main switch harness connector and front door lock assembly (driver side) (door key cylinder switch) harness connector.

Power window main switch		Front door lock assembly (driver side) (door key cylinder switch)		Continuity
Connector	Terminal	Connector	Terminal	
D8	15	D1	6	Existed
	16		5	

4. Check continuity between power window main switch harness connector and ground.

Power window main switch		Ground	Continuity
Connector	Terminal		
D8	15		Not existed
	16		

Is the inspection result normal?

- YES >> Replace power window main switch. Refer to [PWC-79. "Removal and Installation"](#).
NO >> Repair or replace harness.

3.CHECK DOOR KEY CYLINDER SWITCH GROUND CIRCUIT

Check continuity between front door lock assembly (driver side) (door key cylinder switch) harness connector and ground.

A
B
C
D
E
F
G
H
I
J
PWC
L
M
N
O
P

DOOR KEY CYLINDER SWITCH

< DTC/CIRCUIT DIAGNOSIS >

Front door lock assembly (driver side) (door key cylinder switch)		Ground	Continuity
Connector	Terminal		
D1	4		Existed

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair or replace harness.

4.CHECK DOOR KEY CYLINDER SWITCH

Check front door lock assembly (driver side) (door key cylinder switch).

Refer to [PWC-60, "Component Inspection"](#).

Is the inspection result normal?

YES >> GO TO 5.

NO >> Replace front door lock assembly (driver side) (door key cylinder switch). Refer to [DLK-223, "DOOR LOCK : Removal and Installation"](#).

5.CHECK INTERMITTENT INCIDENT

Refer to [GI-43, "Intermittent Incident"](#).

>> INSPECTION END

Component Inspection

INFOID:000000009238484

COMPONENT INSPECTION

1.CHECK DOOR KEY CYLINDER SWITCH

1. Turn ignition switch OFF.
2. Disconnect front door lock assembly (driver side) (door key cylinder switch) connector.
3. Check front door lock assembly (driver side) (door key cylinder switch).

Front door lock assembly (driver side) (door key cylinder switch)		Key position	Continuity
Terminal			
5	4	Unlock	Existed
		Neutral / Lock	Not existed
6		Lock	Existed
		Neutral / Unlock	Not existed

Is the inspection result normal?

YES >> INSPECTION END

NO >> Replace front door lock assembly (driver side) (door key cylinder switch). Refer to [DLK-224, "OUTSIDE HANDLE : Removal and Installation"](#).

POWER WINDOW SERIAL LINK

< DTC/CIRCUIT DIAGNOSIS >

POWER WINDOW SERIAL LINK

POWER WINDOW MAIN SWITCH

POWER WINDOW MAIN SWITCH : Diagnosis Procedure

INFOID:000000009238486

1.CHECK POWER WINDOW SWITCH INPUT SIGNAL

1. Turn ignition switch ON.
2. Check signal between power window main switch harness connector and ground with oscilloscope.

(+)		(-)	Signal (Reference value)
power window main switch			
Connector	Terminal		
D8	13	Ground	

Is the inspection result normal?

- YES >> GO TO 4.
NO >> GO TO 2.

2.CHECK POWER WINDOW SERIAL LINK SIGNAL

1. Turn ignition switch OFF.
2. Disconnect power window main switch connector.
3. Turn ignition switch ON.
4. Check voltage between power window main switch harness connector and ground.

(+)		(-)	Voltage (V)
Power window main switch			
Connector	Terminal		
D8	13	Ground	9 - 16

Is the inspection result normal?

- YES >> Replace power window main switch. Refer to [PWC-79, "Removal and Installation"](#).
NO >> GO TO 3.

3.CHECK POWER WINDOW SERIAL LINK CIRCUIT

1. Disconnect BCM connector and power window main switch connector.
2. Check continuity between BCM harness connector and power window main switch harness connector.

BCM		Power window main switch		Continuity
Connector	Terminal	Connector	Terminal	
M14	54	D8	13	Existed

3. Check continuity between BCM harness connector and ground.

BCM		Ground	Continuity
Connector	Terminal		
M14	54		Not existed

Is the inspection result normal?

- YES >> Replace BCM. Refer to [BCS-98, "Removal and Installation"](#).
NO >> Repair or replace harness.

POWER WINDOW SERIAL LINK

< DTC/CIRCUIT DIAGNOSIS >

4.CHECK INTERMITTENT INCIDENT

Refer to [GI-43, "Intermittent Incident"](#).

>> INSPECTION END


FRONT POWER WINDOW SWITCH (PASSENGER SIDE)

FRONT POWER WINDOW SWITCH (PASSENGER SIDE) : Diagnosis Procedure

INFOID:000000009238488

1.CHECK POWER WINDOW SWITCH INPUT SIGNAL

1. Turn ignition switch ON.
2. Check signal between front power window switch (passenger side) harness connector and ground with oscilloscope.

(+) Front power window switch (passenger side)		(-)	Signal (Reference value)
Connector	Terminal		
D21	16	Ground	

Is the inspection result normal?

YES >> Replace front power window switch (passenger side). Refer to [PWC-79, "Removal and Installation"](#).

NO >> GO TO 2.

2.CHECK POWER WINDOW SERIAL LINK SIGNAL

1. Turn ignition switch OFF.
2. Disconnect front power window switch (passenger side) connector.
3. Turn ignition switch ON.
4. Check voltage between front power window switch (passenger side) harness connector and ground.

(+) Front power window switch (passenger side)		(-)	Voltage (V)
Connector	Terminal		
D21	16	Ground	9 - 16

Is the inspection result normal?

YES >> Replace power window main switch. Refer to [PWC-79, "Removal and Installation"](#).

NO >> GO TO 3.

3.CHECK POWER WINDOW SERIAL LINK CIRCUIT

1. Disconnect power window main switch connector.
2. Check continuity between power window main switch harness connector and front power window switch (passenger side) harness connector.

Power window main switch		Front power window switch (passenger side)		Continuity
Connector	Terminal	Connector	Terminal	
D8	13	D21	16	Existed

3. Check continuity between power window main switch harness connector and ground.

POWER WINDOW SERIAL LINK

< DTC/CIRCUIT DIAGNOSIS >

Power window main switch		Ground	Continuity
Connector	Terminal		
D8	13		Not existed

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair or replace harness.

4.CHECK INTERMITTENT INCIDENT

Refer to [GI-43, "Intermittent Incident"](#).

>> INSPECTION END


REAR POWER WINDOW SWITCH LH

REAR POWER WINDOW SWITCH LH : Diagnosis Procedure

INFOID:0000000009238490

1.CHECK POWER WINDOW SWITCH INPUT SIGNAL

1. Turn ignition switch ON.
2. Check signal between rear power window switch LH harness connector and ground with oscilloscope.

(+)		(-)	Signal (Reference value)
Rear power window switch LH			
Connector	Terminal		
D33	16	Ground	 PKIA7023E

Is the inspection result normal?

YES >> Replace rear power window switch LH. Refer to [PWC-80, "Removal and Installation"](#).

NO >> GO TO 2.

2.CHECK POWER WINDOW SERIAL LINK SIGNAL

1. Turn ignition switch OFF.
2. Disconnect rear power window switch LH connector.
3. Turn ignition switch ON.
4. Check voltage between rear power window switch LH harness connector and ground.

(+)		(-)	Voltage (V)
Rear power window switch LH			
Connector	Terminal		
D33	16	Ground	9 - 16

Is the inspection result normal?

YES >> Replace power window main switch. Refer to [PWC-79, "Removal and Installation"](#).

NO >> GO TO 3.

3.CHECK POWER WINDOW SERIAL LINK CIRCUIT

1. Disconnect power window main switch connector.
2. Check continuity between power window main switch harness connector and rear power window switch LH harness connector.

POWER WINDOW SERIAL LINK

< DTC/CIRCUIT DIAGNOSIS >

Power window main switch		Rear power window switch LH		Continuity
Connector	Terminal	Connector	Terminal	
D8	13	D33	16	Existed

- Check continuity between power window main switch harness connector and ground.

Power window main switch		Ground	Continuity
Connector	Terminal		
D8	13		Not existed

Is the inspection result normal?

- YES >> GO TO 4.
NO >> Repair or replace harness.

4.CHECK INTERMITTENT INCIDENT

Refer to [GI-43. "Intermittent Incident"](#).

>> INSPECTION END


REAR POWER WINDOW SWITCH RH

REAR POWER WINDOW SWITCH RH : Diagnosis Procedure

INFOID:000000009238492

1.CHECK POWER WINDOW SWITCH INPUT SIGNAL

- Turn ignition switch ON.
- Check signal between rear power window switch RH harness connector and ground with oscilloscope.

(+) Rear power window switch RH		(-)	Signal (Reference value)
Connector	Terminal		
D43	16	Ground	

Is the inspection result normal?

- YES >> Replace rear power window switch RH. Refer to [PWC-80. "Removal and Installation"](#).
NO >> GO TO 2.

2.CHECK POWER WINDOW SERIAL LINK SIGNAL

- Turn ignition switch OFF.
- Disconnect rear power window switch RH connector.
- Turn ignition switch ON.
- Check voltage between rear power window switch RH harness connector and ground.

(+) Rear power window switch RH		(-)	Voltage (V)
Connector	Terminal		
D43	16	Ground	9 - 16

Is the inspection result normal?

- YES >> Replace power window main switch. Refer to [PWC-79. "Removal and Installation"](#).
NO >> GO TO 3.

POWER WINDOW SERIAL LINK

< DTC/CIRCUIT DIAGNOSIS >

3.CHECK POWER WINDOW SERIAL LINK CIRCUIT

1. Disconnect power window main switch connector.
2. Check continuity between power window main switch harness connector and rear power window switch RH harness connector.

Power window main switch		Rear power window switch RH		Continuity
Connector	Terminal	Connector	Terminal	
D8	13	D43	16	Existed

3. Check continuity between power window main switch harness connector and ground.

Power window main switch		Ground	Continuity
Connector	Terminal		
D8	13		Not existed

Is the inspection result normal?

- YES >> GO TO 4.
NO >> Repair or replace harness.

4.CHECK INTERMITTENT INCIDENT

Refer to [GI-43, "Intermittent Incident"](#).

>> INSPECTION END

PWC

NONE OF THE POWER WINDOWS CAN BE OPERATED USING ANY SWITCH

< SYMPTOM DIAGNOSIS >

SYMPTOM DIAGNOSIS

NONE OF THE POWER WINDOWS CAN BE OPERATED USING ANY SWITCH

Diagnosis Procedure

INFOID:000000009238493

1.CHECK BCM POWER SUPPLY AND GROUND CIRCUIT

Check BCM power supply and ground circuit.

Refer to [BCS-91, "Diagnosis Procedure"](#).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace the malfunctioning parts.

2.CHECK POWER WINDOW MAIN SWITCH POWER SUPPLY AND GROUND CIRCUIT

Check power window switch power supply and ground circuit.

Refer to [PWC-42, "POWER WINDOW MAIN SWITCH : Diagnosis Procedure"](#).

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace the malfunctioning parts.

3.CONFIRM THE OPERATION

Confirm the operation again.

Is the result normal?

YES >> Check intermittent incident. Refer to [GI-43, "Intermittent Incident"](#).

NO >> GO TO 1.

DRIVER SIDE POWER WINDOW ALONE DOES NOT OPERATE

< SYMPTOM DIAGNOSIS >

DRIVER SIDE POWER WINDOW ALONE DOES NOT OPERATE

Diagnosis Procedure

INFOID:000000009238494

1.CHECK DRIVER SIDE POWER WINDOW MOTOR

Check front power window motor (driver side).

Refer to [PWC-46, "DRIVER SIDE : Component Function Check"](#).

Is the measurement value within the specification?

YES >> GO TO 2.

NO >> Repair or replace the malfunctioning parts.

2.CONFIRM THE OPERATION

Confirm the operation again.

Is the result normal?

YES >> Check intermittent incident. Refer to [GI-43, "Intermittent Incident"](#).

NO >> GO TO 1.

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

PWC

FRONT PASSENGER SIDE POWER WINDOW DOES NOT OPERATE

< SYMPTOM DIAGNOSIS >

FRONT PASSENGER SIDE POWER WINDOW DOES NOT OPERATE WHEN BOTH POWER WINDOW MAIN SWITCH AND FRONT POWER WINDOW SWITCH ARE OPERATED

WHEN BOTH POWER WINDOW MAIN SWITCH AND FRONT POWER WINDOW
SWITCH ARE OPERATED : Diagnosis Procedure

INFOID:000000009238495

1. CHECK FRONT POWER WINDOW SWITCH (PASSENGER SIDE) POWER SUPPLY AND GROUND CIR- CUIT

Check front power window switch (passenger side) power supply and ground circuit.

Refer to [PWC-43. "FRONT POWER WINDOW SWITCH \(PASSENGER SIDE\) : Diagnosis Procedure"](#).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace the malfunctioning parts.

2. CHECK PASSENGER SIDE POWER WINDOW MOTOR CIRCUIT

Check front power window motor (passenger side) circuit.

Refer to [PWC-47. "PASSENGER SIDE : Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace the malfunctioning parts.

3. CONFIRM THE OPERATION

Confirm the operation again.

Is the result normal?

YES >> Check intermittent incident. Refer to [GI-43. "Intermittent Incident"](#).

NO >> GO TO 1.

WHEN FRONT POWER WINDOW SWITCH (PASSENGER SIDE) IS OPERATED

WHEN FRONT POWER WINDOW SWITCH (PASSENGER SIDE) IS OPERATED :
Diagnosis Procedure

INFOID:000000009238496

1. REPLACE FRONT POWER WINDOW SWITCH (PASSENGER SIDE)

Replace front power window switch (passenger side).

Refer to [PWC-79. "Removal and Installation"](#).

>> INSPECTION END

WHEN POWER WINDOW MAIN SWITCH IS OPERATED

WHEN POWER WINDOW MAIN SWITCH IS OPERATED : Diagnosis Procedure

INFOID:000000009238497

1. CHECK FRONT POWER WINDOW SWITCH (PASSENGER SIDE) SERIAL LINK CIRCUIT

Check front power window switch (passenger side) serial link circuit.

Refer to [PWC-62. "FRONT POWER WINDOW SWITCH \(PASSENGER SIDE\) : Diagnosis Procedure"](#).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace the malfunctioning parts.

2. CONFIRM THE OPERATION

Confirm the operation again.

Is the result normal?

YES >> Check intermittent incident. Refer to [GI-43. "Intermittent Incident"](#).

NO >> GO TO 1.

REAR LH SIDE POWER WINDOW ALONE DOES NOT OPERATE

< SYMPTOM DIAGNOSIS >

REAR LH SIDE POWER WINDOW ALONE DOES NOT OPERATE
WHEN BOTH POWER WINDOW MAIN SWITCH AND REAR POWER WINDOW
SWITCH LH ARE OPERATED

WHEN BOTH POWER WINDOW MAIN SWITCH AND REAR POWER WINDOW
SWITCH LH ARE OPERATED : Diagnosis Procedure

INFOID:000000009238498

1.CHECK REAR POWER WINDOW SWITCH POWER SUPPLY AND GROUND CIRCUIT

Check rear power window switch power supply and ground circuit.

Refer to [PWC-44, "REAR POWER WINDOW SWITCH : Diagnosis Procedure"](#).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace the malfunctioning parts.

2.CHECK REAR POWER WINDOW MOTOR LH

Check rear power window motor LH.

Refer to [PWC-48, "REAR LH : Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace the malfunctioning parts.

3.CONFIRM THE OPERATION

Confirm the operation again.

Is the result normal?

YES >> Check intermittent incident. Refer to [GI-43, "Intermittent Incident"](#).

NO >> GO TO 1.

WHEN REAR POWER WINDOW SWITCH LH IS OPERATED

WHEN REAR POWER WINDOW SWITCH LH IS OPERATED : Diagnosis Procedure

INFOID:000000009238499

1.REPLACE REAR POWER WINDOW SWITCH LH

Replace rear power window switch LH.

Refer to [PWC-80, "Removal and Installation"](#).

>> INSPECTION END

WHEN POWER WINDOW MAIN SWITCH IS OPERATED

WHEN POWER WINDOW MAIN SWITCH IS OPERATED : Diagnosis Procedure

INFOID:000000009238500

1.CHECK REAR POWER WINDOW SWITCH LH SERIAL LINK CIRCUIT

Check rear power window switch LH serial link circuit.

Refer to [PWC-63, "REAR POWER WINDOW SWITCH LH : Diagnosis Procedure"](#).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace the malfunctioning parts.

2.CONFIRM THE OPERATION

Confirm the operation again.

Is the result normal?

YES >> Check intermittent incident. Refer to [GI-43, "Intermittent Incident"](#).

NO >> GO TO 1.

REAR RH SIDE POWER WINDOW ALONE DOES NOT OPERATE

< SYMPTOM DIAGNOSIS >

REAR RH SIDE POWER WINDOW ALONE DOES NOT OPERATE
WHEN BOTH POWER WINDOW MAIN SWITCH AND REAR POWER WINDOW
SWITCH RH ARE OPERATED

WHEN BOTH POWER WINDOW MAIN SWITCH AND REAR POWER WINDOW
SWITCH RH ARE OPERATED : Diagnosis Procedure

INFOID:000000009238501

1.CHECK REAR POWER WINDOW SWITCH POWER SUPPLY AND GROUND CIRCUIT

Check rear power window switch power supply and ground circuit.

Refer to [PWC-44, "REAR POWER WINDOW SWITCH : Diagnosis Procedure"](#).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace the malfunctioning parts.

2.CHECK REAR POWER WINDOW MOTOR RH

Check rear power window motor RH.

Refer to [PWC-48, "REAR RH : Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace the malfunctioning parts.

3.CONFIRM THE OPERATION

Confirm the operation again.

Is the result normal?

YES >> Check intermittent incident. Refer to [GI-43, "Intermittent Incident"](#).

NO >> GO TO 1.

WHEN REAR POWER WINDOW SWITCH RH IS OPERATED

WHEN REAR POWER WINDOW SWITCH RH IS OPERATED : Diagnosis Procedure

INFOID:000000009238502

1.REPLACE REAR POWER WINDOW SWITCH RH

Replace rear power window switch RH.

Refer to [PWC-80, "Removal and Installation"](#)

>> INSPECTION END

WHEN POWER WINDOW MAIN SWITCH IS OPERATED

WHEN POWER WINDOW MAIN SWITCH IS OPERATED : Diagnosis Procedure

INFOID:000000009238503

1.CHECK REAR POWER WINDOW SWITCH RH SERIAL LINK CIRCUIT

Check rear power window switch RH serial link circuit.

Refer to [PWC-64, "REAR POWER WINDOW SWITCH RH : Diagnosis Procedure"](#).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace the malfunctioning parts.

2.CONFIRM THE OPERATION

Confirm the operation again.

Is the result normal?

YES >> Check intermittent incident. Refer to [GI-43, "Intermittent Incident"](#).

NO >> GO TO 1.

AUTO OPERATION DOES NOT OPERATE BUT MANUAL OPERATE NORMALLY

< SYMPTOM DIAGNOSIS >

AUTO OPERATION DOES NOT OPERATE BUT MANUAL OPERATE NORMALLY

DRIVER SIDE

DRIVER SIDE : Diagnosis Procedure

INFOID:000000009238504

1.PERFORM INITIALIZATION PROCEDURE

Initialization procedure is performed and operation is confirmed.

Refer to [PWC-38, "Work Procedure"](#).

Is the inspection result normal?

YES >> INSPECTION END

NO >> GO TO 2.

2.CHECK ENCODER (DRIVER SIDE) CIRCUIT

Check encoder (driver side) circuit.

Refer to [PWC-50, "DRIVER SIDE : Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace the malfunctioning parts.

3.CONFIRM THE OPERATION

Confirm the operation again.

Is the result normal?

YES >> Check intermittent incident. Refer to [GI-43, "Intermittent Incident"](#).

NO >> GO TO 1.

PASSENGER SIDE

PASSENGER SIDE : Diagnosis Procedure

INFOID:000000009238505

1.PERFORM INITIALIZATION PROCEDURE

Initialization procedure is performed and operation is confirmed.

Refer to [PWC-38, "Work Procedure"](#).

Is the inspection result normal?

YES >> INSPECTION END

NO >> GO TO 2.

2.CHECK ENCODER (PASSENGER SIDE) CIRCUIT

Check encoder (passenger side) circuit.

Refer to [PWC-52, "PASSENGER SIDE : Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace the malfunctioning parts.

3.CONFIRM THE OPERATION

Confirm the operation again.

Is the result normal?

YES >> Check intermittent incident. Refer to [GI-43, "Intermittent Incident"](#).

NO >> GO TO 1.

REAR LH

REAR LH : Diagnosis Procedure

INFOID:000000009238506

1.PERFORM INITIALIZATION PROCEDURE

Initialization procedure is performed and operation is confirmed.

A

B

C

D

E

F

G

H

I

J

PWC

L

M

N

O

P

AUTO OPERATION DOES NOT OPERATE BUT MANUAL OPERATE NORMALLY

< SYMPTOM DIAGNOSIS >

Refer to [PWC-38. "Work Procedure"](#)

Is the inspection result normal?

YES >> INSPECTION END

NO >> GO TO 2.

2.CHECK ENCODER (REAR LH) CIRCUIT

Check encoder (rear LH) circuit.

Refer to [PWC-54. "REAR LH : Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace the malfunctioning parts.

3.CONFIRM THE OPERATION

Confirm the operation again.

Is the result normal?

YES >> Check intermittent incident. Refer to [GI-43. "Intermittent Incident"](#).

NO >> GO TO 1.

REAR RH

REAR RH : Diagnosis Procedure

INFOID:000000009238507

1.PERFORM INITIALIZATION PROCEDURE

Initialization procedure is performed and operation is confirmed.

Refer to [PWC-38. "Work Procedure"](#).

Is the inspection result normal?

YES >> INSPECTION END

NO >> GO TO 2.

2.CHECK ENCODER (REAR RH) CIRCUIT

Check encoder (rear RH) circuit.

Refer to [PWC-56. "REAR RH : Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace the malfunctioning parts.

3.CONFIRM THE OPERATION

Confirm the operation again.

Is the result normal?

YES >> Check intermittent incident. Refer to [GI-43. "Intermittent Incident"](#).

NO >> GO TO 1.

ANTI-PINCH FUNCTION DOES NOT OPERATE

< SYMPTOM DIAGNOSIS >

ANTI-PINCH FUNCTION DOES NOT OPERATE

Diagnosis Procedure

INFOID:000000009238508

1.CHECK POWER WINDOW AUTO OPERATION

Check AUTO operation of the door when anti-pinch function does not operate.

Is the inspection result normal?

YES >> GO TO 2.

NO >> Refer to [PWC-71, "DRIVER SIDE : Diagnosis Procedure"](#) (driver side), [PWC-71, "PASSENGER SIDE : Diagnosis Procedure"](#) (passenger side), [PWC-71, "REAR LH : Diagnosis Procedure"](#) (rear LH), [PWC-72, "REAR RH : Diagnosis Procedure"](#) (rear RH).

2.CONFIRM THE OPERATION

Confirm the operation again.

Is the inspection result normal?

YES >> Check intermittent incident. Refer to [GI-43, "Intermittent Incident"](#).

NO >> GO TO 1.

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

PWC

POWER WINDOW RETAINED POWER OPERATION DOES NOT OPERATE PROPERLY

< SYMPTOM DIAGNOSIS >

POWER WINDOW RETAINED POWER OPERATION DOES NOT OPERATE PROPERLY

Diagnosis Procedure

INFOID:000000009238509

1.CHECK DOOR SWITCH

Check door switch.

Refer to [DLK-111, "Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace the malfunctioning parts.

2.CHECK POWER WINDOW MAIN SWITCH SERIAL LINK CIRCUIT

Check power window main switch serial link circuit.

Refer to [PWC-61, "POWER WINDOW MAIN SWITCH : Diagnosis Procedure"](#).

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace the malfunctioning parts.

3.CONFIRM THE OPERATION

Confirm the operation again.

Is the result normal?

YES >> Check intermittent incident. Refer to [GI-43, "Intermittent Incident"](#).

NO >> GO TO 1.

DOOR KEY CYLINDER SWITCH DOES NOT OPERATE POWER WINDOWS

< SYMPTOM DIAGNOSIS >

DOOR KEY CYLINDER SWITCH DOES NOT OPERATE POWER WINDOWS

Diagnosis Procedure

INFOID:000000009238510

1.PERFORM INITIALIZATION PROCEDURE

Perform Initialization procedure and check that inspection result is normal.

Refer to [PWC-38, "Work Procedure"](#)

Is the inspection result normal?

YES >> INSPECTION END

NO >> GO TO 2.

2.CHECK DRIVER SIDE DOOR LOCK ASSEMBLY (DOOR KEY CYLINDER SWITCH)

Check driver side door lock assembly (door key cylinder switch).

Refer to [PWC-59, "Component Function Check"](#)

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace the malfunctioning parts.

3.CONFIRM THE OPERATION

Confirm the operation again.

Is the result normal?

YES >> Check intermittent incident. Refer to [GI-43, "Intermittent Incident"](#)

NO >> GO TO 1.

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

PWC

KEYLESS POWER WINDOW DOWN DOES NOT OPERATE

< SYMPTOM DIAGNOSIS >

KEYLESS POWER WINDOW DOWN DOES NOT OPERATE

Diagnosis Procedure

INFOID:000000009238512

1.CHECK POWER WINDOW OPERATION

Check power window operation.

Does power window up/down with power window main switch?

YES >> GO TO 2.

NO >> Refer to [PWC-66, "Diagnosis Procedure"](#).

2.CHECK DOOR LOCK OPERATION

Check door lock/unlock using Intelligent Key.

Does door lock/unlock using Intelligent Key?

YES >> GO TO 3.

NO >> Refer to [DLK-146, "Diagnosis Procedure"](#).

3.CHECK "KEYFOB P/W TEST" IN "ACTIVE TEST"

Check "KEYFOB P/W TEST" in "ACTIVE TEST".

Refer to [DLK-51, "INTELLIGENT KEY : CONSULT Function \(BCM - INTELLIGENT KEY\)"](#).

Is the inspection result normal?

YES >> Replace power window main switch. Refer to [PWC-79, "Removal and Installation"](#).

NO >> GO TO 4.

4.REPLACE POWER WINDOW MAIN SWITCH

1. Replace power window main switch. Refer to [PWC-79, "Removal and Installation"](#).

2. Confirm the operation again.

Is the inspection result normal?

YES >> INSPECTION END.

NO >> Replace BCM. Refer to [BCS-98, "Removal and Installation"](#).

POWER WINDOW LOCK SWITCH DOES NOT FUNCTION

< SYMPTOM DIAGNOSIS >

POWER WINDOW LOCK SWITCH DOES NOT FUNCTION

Diagnosis Procedure

INFOID:000000009238513

1.REPLACE POWER WINDOW MAIN SWITCH

Replace power window main switch. Refer to [PWC-79, "Removal and Installation"](#).

>> INSPECTION END

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

PWC

POWER WINDOW SWITCH ILLUMINATION DOES NOT ILLUMINATE

< SYMPTOM DIAGNOSIS >

POWER WINDOW SWITCH ILLUMINATION DOES NOT ILLUMINATE DRIVER SIDE

DRIVER SIDE : Diagnosis Procedure

INFOID:0000000009642105

1.REPLACE POWER WINDOW MAIN SWITCH

Replace power window main switch.

Refer to [PWC-79, "Removal and Installation"](#).

>> INSPECTION END

PASSENGER SIDE

PASSENGER SIDE : Diagnosis Procedure

INFOID:0000000009642106

1.REPLACE FRONT POWER WINDOW SWITCH (PASSENGER SIDE)

Replace front power window switch (passenger side).

Refer to [PWC-79, "Removal and Installation"](#).

>> INSPECTION END

REAR LH

REAR LH : Diagnosis Procedure

INFOID:0000000009642107

1.REPLACE REAR POWER WINDOW SWITCH LH

Replace rear power window switch LH.

Refer to [PWC-80, "Removal and Installation"](#).

>> INSPECTION END

REAR RH

REAR RH : Diagnosis Procedure

INFOID:0000000009642108

1.REPLACE REAR POWER WINDOW SWITCH RH

Replace rear power window switch RH.

Refer to [PWC-80, "Removal and Installation"](#).

>> INSPECTION END

POWER WINDOW MAIN SWITCH

< REMOVAL AND INSTALLATION >

REMOVAL AND INSTALLATION


POWER WINDOW MAIN SWITCH

Removal and Installation

INFOID:000000009315770

REMOVAL

1. Remove front door finisher. Refer to [INT-13. "FRONT DOOR FINISHER : Removal and Installation"](#).
2. Remove power window main switch mounting screws (A), and then remove power window main switch (1) from front door finisher (2).



INSTALLATION

Install in the reverse order of removal.

NOTE:

- If power window main switch is replaced or is removed, it is necessary to perform the initialization procedure. Refer to [PWC-40. "Work Procedure"](#).
- The same procedure is also performed for front power window switch (passenger side).

PWC

REAR POWER WINDOW SWITCH

< REMOVAL AND INSTALLATION >

REAR POWER WINDOW SWITCH

Removal and Installation

INFOID:000000009315772


CAUTION:

Never bend the pawl of rear door finisher.

REMOVAL

1. Remove rear door finisher. Refer to [INT-18, "REAR DOOR FINISHER : Removal and Installation"](#).
2. Remove rear power window switch ① from rear door finisher ②.

 : Pawl



INSTALLATION

Install in the reverse order of removal.