

TM

SECTION

TRANSAXLE & TRANSMISSION

A

B

C

TM

CONTENTS

E

CVT: RE0F10J

PRECAUTION 6

PRECAUTIONS 6

Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"	6
Precaution for Procedure without Cowl Top Cover.....	6
Precautions for Removing Battery Terminal	7
Precaution for On Board Diagnosis (OBD) System of CVT and Engine	7
Precaution for TCM and Transaxle Assembly Replacement	7
Removal and Installation Procedure for CVT Unit Connector	7
Precaution	8
Service Notice or Precaution	9

PREPARATION 10

PREPARATION 10

Special Service Tools	10
Commercial Service Tools	10

SYSTEM DESCRIPTION 11

COMPONENT PARTS 11

CVT CONTROL SYSTEM 11

CVT CONTROL SYSTEM : Component Parts Location	11
CVT CONTROL SYSTEM : TCM	13
CVT CONTROL SYSTEM : Transmission Range Switch	13
CVT CONTROL SYSTEM : Primary Speed Sensor	13
CVT CONTROL SYSTEM : Output Speed Sensor... ..	13
CVT CONTROL SYSTEM : Input Speed Sensor	14
CVT CONTROL SYSTEM : CVT Fluid Temperature Sensor	14

CVT CONTROL SYSTEM : Primary Pressure Sensor	14
--	----

CVT CONTROL SYSTEM : Secondary Pressure Sensor	15
--	----

CVT CONTROL SYSTEM : Primary Pressure Solenoid Valve	15
--	----

CVT CONTROL SYSTEM : Secondary Pressure Solenoid Valve	15
--	----

CVT CONTROL SYSTEM : Select Solenoid Valve	16
--	----

CVT CONTROL SYSTEM : Torque Converter Clutch Solenoid Valve	16
---	----

CVT CONTROL SYSTEM : Line Pressure Solenoid Valve	16
---	----

CVT CONTROL SYSTEM : Overdrive Control Switch	16
---	----

CVT CONTROL SYSTEM : O/D OFF Indicator Lamp	16
---	----

CVT CONTROL SYSTEM : Shift Position Indicator	17
---	----

CVT CONTROL SYSTEM : G Sensor	17
-------------------------------------	----

SHIFT LOCK SYSTEM 17

SHIFT LOCK SYSTEM : Component Parts Location	18
--	----

STRUCTURE AND OPERATION 19

TRANSAXLE 19

TRANSAXLE : Cross-Sectional View	19
TRANSAXLE : Operation Status	20
TRANSAXLE : Transaxle Mechanism	20
TRANSAXLE : Oil Pressure System	22
TRANSAXLE : Component Description	23

FLUID COOLER & FLUID WARMER SYSTEM 23

FLUID COOLER & FLUID WARMER SYSTEM : System Description	24
---	----

SHIFT LOCK SYSTEM 24

SHIFT LOCK SYSTEM : System Description	25
--	----

F

G

H

I

J

K

L

M

N

O

P

SYSTEM	27	ADDITIONAL SERVICE WHEN REPLACING	
CVT CONTROL SYSTEM	27	TRANSAXLE ASSEMBLY	74
CVT CONTROL SYSTEM : System Description ...	27	Description	74
CVT CONTROL SYSTEM : Fail-safe	28	Work Procedure	74
CVT CONTROL SYSTEM : Protection Control	31	ADDITIONAL SERVICE WHEN REPLACING	
LINE PRESSURE CONTROL	32	TCM AND TRANSAXLE ASSEMBLY	76
LINE PRESSURE CONTROL : System Description	32	Description	76
SHIFT CONTROL	33	Work Procedure	76
SHIFT CONTROL : System Description	33	CALIBRATION OF G SENSOR	78
SELECT CONTROL	35	Description	78
SELECT CONTROL : System Description	35	Work Procedure	78
LOCK-UP CONTROL	36	IDLE NEUTRAL CONTROL LEARNING	79
LOCK-UP CONTROL : System Description	36	Description	79
ON BOARD DIAGNOSTIC (OBD) SYSTEM	38	Work Procedure	79
Diagnosis Description	38	STALL TEST	80
GST (Generic Scan Tool)	38	Work Procedure	80
DIAGNOSIS SYSTEM (TCM)	39	CVT POSITION	81
DIAGNOSIS DESCRIPTION	39	Inspection and Adjustment	81
DIAGNOSIS DESCRIPTION : 1 Trip Detection Diagnosis and 2 Trip Detection Diagnosis	39	HOW TO ERASE PERMANENT DTC	82
DIAGNOSIS DESCRIPTION : DTC and DTC of 1st Trip	39	Description	82
DIAGNOSIS DESCRIPTION : Malfunction Indicator Lamp (MIL)	39	DTC/CIRCUIT DIAGNOSIS	83
DIAGNOSIS DESCRIPTION : Counter System	39	U0073 COMMUNICATION BUS A OFF	83
CONSULT Function	41	DTC Logic	83
ECU DIAGNOSIS INFORMATION	47	Diagnosis Procedure	83
TCM	47	U0100 LOST COMMUNICATION (ECM A)	84
Reference Value	47	DTC Logic	84
Fail-safe	53	Diagnosis Procedure	84
Protection Control	56	U0140 LOST COMMUNICATION (BCM)	85
DTC Inspection Priority Chart	57	DTC Logic	85
DTC Index	58	Diagnosis Procedure	85
WIRING DIAGRAM	60	U0141 LOST COMMUNICATION (BCM A)	86
CVT CONTROL SYSTEM	60	DTC Logic	86
Wiring diagram	60	Diagnosis Procedure	86
CVT SHIFT LOCK SYSTEM	66	U0155 LOST COMMUNICATION (IPC)	87
Wiring Diagram	66	DTC Logic	87
BASIC INSPECTION	69	Diagnosis Procedure	87
DIAGNOSIS AND REPAIR WORK FLOW	69	U0300 CAN COMMUNICATION DATA	88
Flowchart of Trouble Diagnosis	69	DTC Logic	88
Question sheet	70	Diagnosis Procedure	88
ADDITIONAL SERVICE WHEN REPLACING		U1000 CAN COMM CIRCUIT	89
TCM	72	Description	89
Description	72	DTC Logic	89
Work Procedure	72	Diagnosis Procedure	89
		U1117 LOST COMMUNICATION (ABS)	90
		DTC Logic	90
		Diagnosis Procedure	90

P062F EEPROM	91	Diagnosis Procedure	126
Description	91		
DTC Logic	91	P0779 PRESSURE CONTROL SOLENOID B. 128	
Diagnosis Procedure	91	DTC Logic	128
		Diagnosis Procedure	128
P0705 TRANSMISSION RANGE SENSOR A.... 92		P0841 TRANSMISSION FLUID PRESSURE	
DTC Logic	92	SEN/SW A	130
Diagnosis Procedure	92	DTC Logic	130
Component Inspection	96	Diagnosis Procedure	130
P0706 TRANSMISSION RANGE SENSOR A.... 98		P0847 TRANSMISSION FLUID PRESSURE	
DTC Logic	98	SEN/SW B	131
Diagnosis Procedure	98	DTC Logic	131
Component Inspection	100	Diagnosis Procedure	131
P0711 TRANSMISSION FLUID TEMPERA-		P0848 TRANSMISSION FLUID PRESSURE	
TURE SENSOR A	101	SEN/SW B	133
DTC Logic	101	DTC Logic	133
Diagnosis Procedure	104	Diagnosis Procedure	133
P0712 TRANSMISSION FLUID TEMPERA-		P084C TRANSMISSION FLUID PRESSURE	
TURE SENSOR A	106	SEN/SW H	135
DTC Logic	106	DTC Logic	135
Diagnosis Procedure	106	Diagnosis Procedure	135
Component Inspection	106	P084D TRANSMISSION FLUID PRESSURE	
P0713 TRANSMISSION FLUID TEMPERA-		SEN/SW H	137
TURE SENSOR A	108	DTC Logic	137
DTC Logic	108	Diagnosis Procedure	137
Diagnosis Procedure	108	P0863 TCM COMMUNICATION	139
Component Inspection	109	DTC Logic	139
P0715 INPUT SPEED SENSOR A	110	Diagnosis Procedure	139
DTC Logic	110	P0890 TCM	140
Diagnosis Procedure	111	DTC Logic	140
P0717 INPUT SPEED SENSOR A	113	Diagnosis Procedure	140
DTC Logic	113	P0962 PRESSURE CONTROL SOLENOID A. 141	
Diagnosis Procedure	114	DTC Logic	141
P0740 TORQUE CONVERTER	116	Diagnosis Procedure	141
DTC Logic	116	P0963 PRESSURE CONTROL SOLENOID A. 143	
Diagnosis Procedure	117	DTC Logic	143
P0743 TORQUE CONVERTER	118	Diagnosis Procedure	143
DTC Logic	118	P0965 PRESSURE CONTROL SOLENOID B. 145	
Diagnosis Procedure	119	DTC Logic	145
P0744 TORQUE CONVERTER	120	Diagnosis Procedure	146
DTC Logic	120	P0966 PRESSURE CONTROL SOLENOID B. 147	
Diagnosis Procedure	121	DTC Logic	147
P0746 PRESSURE CONTROL SOLENOID A. 122		Diagnosis Procedure	147
DTC Logic	122	P0967 PRESSURE CONTROL SOLENOID B. 149	
Diagnosis Procedure	123	DTC Logic	149
P0776 PRESSURE CONTROL SOLENOID B. 124		Diagnosis Procedure	149
DTC Logic	124	P1586 G SENSOR	151
Diagnosis Procedure	125	DTC Logic	151
P0778 PRESSURE CONTROL SOLENOID B. 126		Diagnosis Procedure	151
DTC Logic	126		

P1588 G SENSOR	154	Exploded View	185
DTC Logic	154	Removal and Installation	185
Diagnosis Procedure	155	Disassembly and Assembly	186
P2765 INPUT SPEED SENSOR B	156	Inspection and Adjustment	187
DTC Logic	156	CONTROL CABLE	188
Diagnosis Procedure	157	Exploded View	188
P2813 SELECT SOLENOID	159	Removal and Installation	188
DTC Logic	159	Inspection and Adjustment	189
Diagnosis Procedure	160	TCM	190
P2814 SELECT SOLENOID	161	Exploded View	190
DTC Logic	161	Removal and Installation	190
Diagnosis Procedure	161	Adjustment	190
P2815 SELECT SOLENOID	163	CONTROL VALVE	191
DTC Logic	163	Exploded View	191
Diagnosis Procedure	163	Removal and Installation	192
MAIN POWER SUPPLY AND GROUND CIRCUIT	165	Inspection	196
Diagnosis Procedure	165	G SENSOR	197
SHIFT POSITION INDICATOR CIRCUIT	167	Exploded View	197
Component Function Check	167	Removal and Installation	197
Diagnosis Procedure	167	Adjustment	197
OVERDRIVE CONTROL SWITCH	168	INPUT SPEED SENSOR	198
Component Function Check	168	Exploded View	198
Diagnosis Procedure	168	Removal and Installation	198
Component Inspection (Overdrive Control Switch)	169	Inspection and Adjustment	198
OD OFF INDICATOR LAMP	170	PRIMARY SPEED SENSOR	200
Component Function Check	170	Exploded View	200
Diagnosis Procedure	170	Removal and Installation	200
SHIFT LOCK SYSTEM	171	Inspection and Adjustment	200
Component Function Check	171	OUTPUT SPEED SENSOR	201
Diagnosis Procedure	171	Exploded View	201
Component Inspection (Stop Lamp Switch)	173	Removal and Installation	201
Component Inspection (Shift Lock Solenoid)	173	Inspection and Adjustment	201
SYMPTOM DIAGNOSIS	174	AIR BREATHER HOSE	202
CVT CONTROL SYSTEM	174	Exploded View	202
Symptom Table	174	Removal and Installation	202
PERIODIC MAINTENANCE	178	DIFFERENTIAL SIDE OIL SEAL	204
CVT FLUID	178	Exploded View	204
Inspection	178	Removal and Installation	204
Replacement	178	Inspection and Adjustment	205
Adjustment	180	CVT OIL WARMER SYSTEM	206
CVT FLUID COOLER SYSTEM	182	WATER HOSE	206
Cleaning	182	WATER HOSE : Exploded View	206
REMOVAL AND INSTALLATION	185	WATER HOSE : Removal and Installation	206
CVT SHIFT SELECTOR	185	WATER HOSE : Inspection	208
		CVT FLUID COOLER HOSE	208
		CVT FLUID COOLER HOSE : Exploded View	208
		CVT FLUID COOLER HOSE : Removal and Installation	209
		CVT FLUID COOLER HOSE : Inspection	210

CVT OIL WARMER	210	
CVT OIL WARMER : Exploded View	210	
CVT OIL WARMER : Removal and Installation ...	210	
CVT OIL WARMER : Inspection	211	
PLUG	212	
Description	212	
Exploded View	212	
Removal and Installation	212	
Inspection and Adjustment	212	
UNIT REMOVAL AND INSTALLATION ...	213	
TRANSAXLE ASSEMBLY	213	
Exploded View	213	
Removal and Installation	213	
Inspection and Adjustment	215	
UNIT DISASSEMBLY AND ASSEMBLY .	217	
TORQUE CONVERTER AND CONVERTER HOUSING OIL SEAL	217	A
Exploded View	217	
Disassembly	217	
Assembly	217	B
Inspection	218	
SERVICE DATA AND SPECIFICATIONS (SDS)	220	C
SERVICE DATA AND SPECIFICATIONS (SDS)	220	TM
General Specification	220	
Shift Characteristics	220	
Stall Speed	220	E
Torque Converter	220	
Heater Thermostat	220	F
		G
		H
		I
		J
		K
		L
		M
		N
		O
		P

PRECAUTION

PRECAUTIONS

Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"

INFOID:000000011322797

The Supplemental Restraint System such as "AIR BAG" and "SEAT BELT PRE-TENSIONER", used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. This system includes seat belt switch inputs and dual stage front air bag modules. The SRS system uses the seat belt switches to determine the front air bag deployment, and may only deploy one front air bag, depending on the severity of a collision and whether the front occupants are belted or unbelted. Information necessary to service the system safely is included in the "SRS AIR BAG" and "SEAT BELT" of this Service Manual.

WARNING:

Always observe the following items for preventing accidental activation.

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision that would result in air bag inflation, all maintenance must be performed by an authorized NISSAN/INFINITI dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see "SRS AIR BAG".
- Never use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harnesses or harness connectors.

PRECAUTIONS WHEN USING POWER TOOLS (AIR OR ELECTRIC) AND HAMMERS

WARNING:


Always observe the following items for preventing accidental activation.

- When working near the Air Bag Diagnosis Sensor Unit or other Air Bag System sensors with the ignition ON or engine running, never use air or electric power tools or strike near the sensor(s) with a hammer. Heavy vibration could activate the sensor(s) and deploy the air bag(s), possibly causing serious injury.
- When using air or electric power tools or hammers, always switch the ignition OFF, disconnect the battery, and wait at least 3 minutes before performing any service.

Precaution for Procedure without Cowl Top Cover

INFOID:000000011322798

When performing the procedure after removing cowl top cover, cover the lower end of windshield with urethane, etc to prevent damage to windshield.



PRECAUTIONS

< PRECAUTION >

[CVT: RE0F10J]

Precautions for Removing Battery Terminal

INFOID:0000000011322799

- When removing the 12V battery terminal, turn OFF the ignition switch and wait at least 30 seconds.

NOTE:

ECU may be active for several tens of seconds after the ignition switch is turned OFF. If the battery terminal is removed before ECU stops, then a DTC detection error or ECU data corruption may occur.

- For vehicles with the 2-batteries, be sure to connect the main battery and the sub battery before turning ON the ignition switch.


NOTE:

If the ignition switch is turned ON with any one of the terminals of main battery and sub battery disconnected, then DTC may be detected.

- After installing the 12V battery, always check "Self Diagnosis Result" of all ECUs and erase DTC.

NOTE:

The removal of 12V battery may cause a DTC detection error.



Precaution for On Board Diagnosis (OBD) System of CVT and Engine

INFOID:0000000011322800

The ECM has an on board diagnostic system. It will illuminate the malfunction indicator lamp (MIL) to warn the driver of a malfunction causing emission deterioration.

CAUTION:

- Always to turn the ignition switch OFF and disconnect the negative battery cable before any repair or inspection work. The open/short circuit of related switches, sensors, solenoid valves, etc. will cause the MIL to illuminate.
- Always to connect and lock the connectors securely after work. A loose (unlocked) connector will cause the MIL to illuminate due to the open circuit. (Be sure the connector is free from water, grease, dirt, bent terminals, etc.)
- Always route and secure the harnesses properly after work. The interference of the harness with a bracket, etc. may cause the MIL to illuminate due to the short circuit.
- Always to connect rubber tubes properly after work. A misconnected or disconnected rubber tube may cause the MIL to illuminate due to the malfunction of the EVAP system or fuel injection system, etc.
- Always to erase the unnecessary malfunction information (repairs completed) from the TCM and ECM before returning the vehicle to the customer.

Precaution for TCM and Transaxle Assembly Replacement

INFOID:0000000011322801


- When replaced the TCM, refer to [TM-72, "Description"](#).
- When replaced the transaxle assembly, refer to [TM-74, "Description"](#).

Removal and Installation Procedure for CVT Unit Connector

INFOID:0000000011322802

REMOVAL

Rotate bayonet ring counterclockwise. Pull out CVT unit harness connector upward and remove it.




INSTALLATION

PRECAUTIONS


< PRECAUTION >

[CVT: RE0F10J]

1. Align Δ marking on CVT unit harness connector terminal body with $\square$ marking on bayonet ring. Insert CVT unit harness connector. Then rotate bayonet ring clockwise.




2. Rotate bayonet ring clockwise until Δ marking on CVT unit harness connector terminal body is aligned with the slit on bayonet ring as shown in the figure (correctly fitting condition). Install CVT unit harness connector to CVT unit harness connector terminal body.



CAUTION:


- Securely align Δ marking on CVT unit harness connector terminal body with bayonet ring slit. Then, be careful not to make a half fit condition as shown in the figure.
- Never mistake the slit of bayonet ring for other dent portion.



Precaution

INFOID:0000000011322803

- Turn ignition switch OFF and disconnect negative battery cable before connecting or disconnecting the TCM harness connector. Because battery voltage is applied to TCM even if ignition switch is turned OFF.




PRECAUTIONS


< PRECAUTION >

[CVT: RE0F10J]


- When connecting or disconnecting pin connectors into or from TCM, do not damage pin terminals (bend or break). Check that there are not any bends or breaks on TCM pin terminal, when connecting pin connectors.



- Perform TCM input/output signal inspection and check whether TCM functions normally or not before replacing TCM. [TM-47, "Reference Value"](#).



- Perform "DTC Confirmation Procedure" after performing each TROUBLE DIAGNOSIS. If the repair is completed the DTC should not be displayed in the "DTC Confirmation Procedure".
- Always use the specified brand of CVT fluid. Refer to [MA-10, "Fluids and Lubricants"](#).
- Use lint-free paper, not cloth rags, during work.
- Dispose of the waste oil using the methods prescribed by law, ordinance, etc. after replacing the CVT fluid.



Service Notice or Precaution

INFOID:0000000011322804

OBD-II SELF-DIAGNOSIS

- CVT self-diagnosis is performed by the TCM in combination with the ECM. The results can be read through the blinking pattern of the Malfunction Indicator Lamp (MIL). Refer to the table on [TM-41, "CONSULT Function"](#) for the indicator used to display each self diagnostic result.
- The self diagnostic results indicated by the MIL are automatically stored in both the ECM and TCM memories.

Always perform the procedure on [TM-38, "Diagnosis Description"](#) to complete the repair and avoid unnecessary blinking of the MIL.

For details of OBD-II, refer to [EC-62, "Diagnosis Description"](#).

- Certain systems and components, especially those related to OBD, may use the new style slide-locking type harness connector. For description and how to disconnect, refer to [PG-6, "Harness Connector"](#).

PREPARATION

< PREPARATION >

[CVT: RE0F10J]



PREPARATION

PREPARATION

Special Service Tools



INFOID:000000011322805

The actual shapes of TechMate tools may differ from those of special service tools illustrated here.

Tool number (TechMate No.) Tool name		Description
— (OTC3492) Oil pressure gauge set	 SCIA7531E	Measuring line pressure
ST33400001 (J-26082) Drift a: 60 mm (2.36 in) dia. b: 47 mm (1.85 in) dia.	 ZZA0814D	Installing differential side oil seal
KV40100621 (J-25405) Drift a: 76 mm (2.99 in) dia. b: 69 mm (2.72 in) dia.	 ZZA0814D	Installing side oil seal (transfer joint)

Commercial Service Tools

INFOID:000000011322806

Tool number Tool name		Description
Power tool	 PBIC0190E	Loosening nuts and bolts
31197CA000 Drive plate location guide a: 14 mm (0.55 in) dia.	 SCIA2013E	Installing transaxle assembly


SYSTEM DESCRIPTION

COMPONENT PARTS

CVT CONTROL SYSTEM

CVT CONTROL SYSTEM : Component Parts Location

INFOID:0000000011519440



No.	Component	Function
①	Overdrive control switch	TM-16, "CVT CONTROL SYSTEM : Overdrive Control Switch"
②	BCM	Refer to BCS-4, "BODY CONTROL SYSTEM : Component Parts Location" for detailed installation location.

COMPONENT PARTS

< SYSTEM DESCRIPTION >

[CVT: RE0F10J]

No.	Component	Function
③	ECM	- For purposes including improving the feeling when shifting speeds and preventing drops in engine speed, control signals are exchanged between the ECM and TCM, and real-time cooperative control is performed according to the vehicle driving conditions. (Engine and CVT integrated control) - Engine and CVT integrated control signal NOTE: General term for the communication (torque-down permission, torque-down request, etc.) exchanged between the ECM and TCM. - The TCM receives the following signal via CAN communications from the ECM. - Engine speed signal - Accelerator pedal position signal - Closed throttle position signal - The TCM transmits the following signal via CAN communications to the ECM. - Malfunctioning indicator lamp signal Refer to EC-16, "ENGINE CONTROL SYSTEM : Component Parts Location" for detailed installation location.
④	Combination meter	The TCM receives the following signal via CAN communications from the combination meter for judging the driving request from the driver. - Overdrive control switch signal - Vehicle speed signal The TCM transmits the following signal via CAN communications to the combination meter. - O/D OFF indicator signal - Shift position indicator signal Refer to MWI-6, "METER SYSTEM : Component Parts Location" for detailed installation location.
⑤	Shift position indicator	TM-17, "CVT CONTROL SYSTEM : Shift Position Indicator"
⑥	O/D OFF indicator lamp	TM-16, "CVT CONTROL SYSTEM : O/D OFF Indicator Lamp"
⑦	Malfunction indicator lamp (MIL)	TM-39, "DIAGNOSIS DESCRIPTION : Malfunction Indicator Lamp (MIL)"
⑧	TCM	TM-13, "CVT CONTROL SYSTEM : TCM"
⑨	Transmission range switch	TM-13, "CVT CONTROL SYSTEM : Transmission Range Switch"
⑩	Input speed sensor	TM-14, "CVT CONTROL SYSTEM : Input Speed Sensor"
⑪	CVT unit connector	—
⑫	Control valve	CVT fluid temperature sensor*
		Primary pressure sensor*
		Secondary pressure sensor*
		Primary pressure solenoid valve*
		Secondary pressure solenoid valve*
		Select solenoid valve*
		Torque converter clutch solenoid valve*
		Line pressure solenoid valve*
⑬	Primary speed sensor	TM-13, "CVT CONTROL SYSTEM : Primary Speed Sensor"
⑭	Output speed sensor	TM-13, "CVT CONTROL SYSTEM : Output Speed Sensor"
⑮	G sensor	TM-17, "CVT CONTROL SYSTEM : G Sensor"

*: These components are included in control valve assembly.

COMPONENT PARTS

< SYSTEM DESCRIPTION >

[CVT: RE0F10J]

CVT CONTROL SYSTEM : TCM

INFOID:0000000011519441

- The vehicle driving status is judged based on the signals from the sensors, switches, and other control units, and the optimal transaxle control is performed.
- For TCM control items, refer to [TM-27, "CVT CONTROL SYSTEM : System Description"](#).

CVT CONTROL SYSTEM : Transmission Range Switch


INFOID:0000000011519442

- The transmission range switch is installed to upper part of transaxle case.
- The transmission range switch detects the selector lever position.

CVT CONTROL SYSTEM : Primary Speed Sensor

INFOID:0000000011519443


- The primary speed sensor is installed to side cover of transaxle.
- The primary speed sensor detects primary pulley speed.
- The primary speed sensor generates an ON-OFF pulse signal according to the rotating body speed. TCM judges the rotating body speed from the pulse signal.



CVT CONTROL SYSTEM : Output Speed Sensor

INFOID:0000000011519444


- The output speed sensor is installed to back side of transaxle.
- The output speed sensor detects final gear speed.
- The output speed sensor generates the ON-OFF pulse (short waveform) in proportion to the rotating body speed which is "The higher the rotating body speed is, the faster the change cycle is". The TCM judges the rotating speed from the changing cycle of this pulse signal.



CVT CONTROL SYSTEM : Input Speed Sensor

INFOID:000000011519445


- The input speed sensor is installed to the front side of transaxle case.
- The input speed sensor detects input shaft speed.
- The input speed sensor generates an ON-OFF pulse signal according to the rotating body speed. TCM judges the rotating body speed from the pulse signal.



CVT CONTROL SYSTEM : CVT Fluid Temperature Sensor

INFOID:000000011519446

- The CVT fluid temperature sensor is installed to control valve.
- The CVT fluid temperature sensor detects CVT fluid temperature in oil pan.
- The fluid temperature sensor uses a thermistor, and changes the signal voltage by converting changes in the CVT fluid temperature to a resistance value. TCM evaluates the CVT fluid temperature from the signal voltage value.



CVT CONTROL SYSTEM : Primary Pressure Sensor

INFOID:000000011519447


- The primary pressure sensor is installed to control valve.
- The primary pressure sensor detects the pressure applied to the primary pulley.

COMPONENT PARTS

< SYSTEM DESCRIPTION >

[CVT: RE0F10J]


- When pressure is applied to the ceramic device in the primary pressure sensor, the ceramic device is deformed, resulting in voltage change. TCM evaluates the primary pressure from its voltage change. Voltage is increased along with pressure increase.



CVT CONTROL SYSTEM : Secondary Pressure Sensor

INFOID:0000000011519448

- The secondary pressure sensor is installed to control valve.
- The secondary pressure sensor detects the pressure applied to the secondary pulley.
- When pressure is applied to the metal diaphragm in the secondary pressure sensor, the metal diaphragm is deformed, resulting in voltage change. TCM evaluates the secondary pressure from its voltage change. Voltage is increased along with pressure increase.



CVT CONTROL SYSTEM : Primary Pressure Solenoid Valve

INFOID:0000000011519449

- The primary pressure solenoid valve is installed to control valve.
- The primary pressure solenoid valve controls the primary reducing valve. For information about the primary reducing valve, refer to [TM-23, "TRANSAXLE : Component Description"](#).
- The primary pressure solenoid valve uses the linear solenoid valve [N/H (normal high) type].

NOTE:

- The principle of the linear solenoid valve utilizes the fact that the force pressing on the valve spool installed inside the coil increases nearly in proportion to the current. This allows it to produce a fluid pressure that is proportional to this pressing force.
- The N/H (normal high) produces hydraulic control when the coil is not energized.

CVT CONTROL SYSTEM : Secondary Pressure Solenoid Valve

INFOID:0000000011519450

- The secondary pressure solenoid valve is installed to control valve.
- The secondary pressure solenoid valve controls the secondary reducing valve. For information about the secondary reducing valve, refer to [TM-23, "TRANSAXLE : Component Description"](#).
- The secondary pressure solenoid valve uses the linear solenoid valve [N/H (normal high) type].

NOTE:

- The principle of the linear solenoid valve utilizes the fact that the force pressing on the valve spool installed inside the coil increases nearly in proportion to the current. This allows it to produce a fluid pressure that is proportional to this pressing force.
- The N/H (normal high) produces hydraulic control when the coil is not energized.

CVT CONTROL SYSTEM : Select Solenoid Valve

INFOID:000000011519451

- The select solenoid valve is installed to control valve.
- The select solenoid valve adjusts the tightening pressure of the forward clutch and reverse brake. For information about the forward clutch and reverse brake, refer to [TM-23, "TRANSAXLE : Component Description"](#).
- The select solenoid valve uses the linear solenoid valve [N/H (normal high) type].

NOTE:

- The principle of the linear solenoid valve utilizes the fact that the force pressing on the valve spool installed inside the coil increases nearly in proportion to the current. This allows it to produce a fluid pressure that is proportional to this pressing force.
- The N/H (normal high) type produces hydraulic control when the coil is not energized.

CVT CONTROL SYSTEM : Torque Converter Clutch Solenoid Valve

INFOID:000000011519452

- The torque converter clutch solenoid valve is installed to control valve.
- The torque converter clutch solenoid valve controls the torque converter clutch control valve. For information about the torque converter clutch control valve, refer to [TM-23, "TRANSAXLE : Component Description"](#).
- The torque converter clutch solenoid valve utilizes a linear solenoid valve [N/L (normal low) type].

NOTE:

- The principle of the linear solenoid valve utilizes the fact that the force pressing on the valve spool installed inside the coil increases nearly in proportion to the current. This allows it to produce a fluid pressure that is proportional to this pressing force.
- The N/L (normal low) type does not produce hydraulic control when the coil is not energized.

CVT CONTROL SYSTEM : Line Pressure Solenoid Valve

INFOID:000000011519453

- The line pressure solenoid valve is installed to control valve.
- The line pressure solenoid valve controls the pressure regulator valve. For information about the pressure regulator valve, refer to [TM-23, "TRANSAXLE : Component Description"](#).
- The line pressure solenoid valve uses the linear solenoid valve [N/H (normal high) type].

NOTE:

- The principle of the linear solenoid valve utilizes the fact that the force pressing on the valve spool installed inside the coil increases nearly in proportion to the current. This allows it to produce a fluid pressure that is proportional to this pressing force.
- The N/H (normal high) produces hydraulic control when the coil is not energized.

CVT CONTROL SYSTEM : Overdrive Control Switch

INFOID:000000011519454

- The overdrive control switch is installed to the selector lever knob.
- If the overdrive control switch is pressed when the O/D OFF indicator lamp on the combination meter is not lit, the status changes to overdrive OFF and the O/D OFF indicator lamp illuminates.
- If the overdrive control switch is pressed when the O/D OFF indicator lamp on the combination meter is lit, the overdrive OFF status is canceled and the O/D OFF indicator lamp turns off.

CVT CONTROL SYSTEM : O/D OFF Indicator Lamp

INFOID:000000011519455

- O/D OFF indicator lamp is positioned on the combination meter.
- The O/D OFF indicator lamp illuminates when the overdrive function is deactivated (O/D OFF).
- For checking the bulb, this lamp turns on for a certain period of time when the ignition switch turns ON, and then turns off.

Condition (status)	O/D OFF indicator lamp
Ignition switch OFF.	OFF
Ignition switch ON.	ON (Approx. 2 seconds)

COMPONENT PARTS

< SYSTEM DESCRIPTION >

[CVT: RE0F10J]

Condition (status)	O/D OFF indicator lamp
Overdrive control switch is pressed when the selector lever is in the D position and the O/D OFF indicator lamp is OFF (when system is normal).	ON
Overdrive control switch is pressed when the selector lever is in the D position and the O/D OFF indicator lamp is ON.	OFF
Selector lever is shifted from the D position to another position when the O/D OFF indicator lamp is ON.	OFF

CVT CONTROL SYSTEM : Shift Position Indicator


INFOID:0000000011519456

TCM transmits shift position signal to combination meter via CAN communication. The actual shift position is displayed on combination meter according to the signal.

CVT CONTROL SYSTEM : G Sensor

INFOID:0000000011551815

- G sensor detects front/rear G and inclination applied to the vehicle.
- G sensor converts front/rear G and inclination applied to the vehicle to voltage signal. TCM evaluates front/rear G and inclination angle of the vehicle from the voltage signal.



SHIFT LOCK SYSTEM


COMPONENT PARTS

< SYSTEM DESCRIPTION >

[CVT: RE0F10J]

SHIFT LOCK SYSTEM : Component Parts Location

INFOID:000000011519457




No.	Component	Function
①	Stop lamp switch	- The stop lamp switch turns ON when the brake pedal is depressed. - When the stop lamp switch turns ON, the shift lock solenoid is energized.
②	Shift lock solenoid	It operates according to the signal from the stop lamp switch and moves the lock lever.
③	Park position switch	It detects that the selector lever is in "P" position.
④	Shift lock release button	Forcibly releases the shift lock when pressed.

STRUCTURE AND OPERATION TRANSAXLE

TRANSAXLE : Cross-Sectional View

INFOID:0000000011541434



- | | | |
|---------------------|---------------------|-------------------|
| ① Converter housing | ② Oil pump | ③ Planetary gear |
| ④ Control valve | ⑤ Oil pan | ⑥ Chain belt |
| ⑦ Primary pulley | ⑧ Secondary pulley | ⑨ Side cover |
| ⑩ Transaxle case | ⑪ Differential case | ⑫ Final gear |
| ⑬ Reduction gear | ⑭ Idler gear | ⑮ Output gear |
| ⑯ Drive sprocket | ⑰ Torque converter | ⑱ Driven sprocket |
| ⑲ Oil pump chain | | |

JSDIA3719ZZ

STRUCTURE AND OPERATION

< SYSTEM DESCRIPTION >

[CVT: RE0F10J]

TRANSAXLE : Operation Status

INFOID:000000011541436

×: Engaged or applied.

Selector lever position	Parking mechanism	Forward clutch	Reverse brake	Primary pulley	Secondary pulley	Chain belt	Final drive
P	×						
R			×	×	×	×	×
N							
D		×		×	×	×	×
L		×		×	×	×	×

TRANSAXLE : Transaxle Mechanism

INFOID:000000011541436

TORQUE CONVERTER (WITH LOCK-UP FUNCTION)

In the same way as a conventional A/T, the torque converter is a system that increases the engine torque and transmits the torque to the transaxle. A symmetrical 3-element, 1-stage, 2-phase type is used here.


OIL PUMP

Utilizes a vane-type oil pump that is driven by the engine through the oil pump drive chain in order to increase efficiency of pump discharge volume in low-speed zone and optimize pump discharge volume in high-speed zone. Discharged oil from oil pump is transmitted to control valve. It is used as the oil of primary and secondary pulley operation, the oil of clutch operation, and the lubricant for each part.

PLANETARY GEAR

- A planetary gear type of forward/reverse selector mechanism is installed between the torque converter and primary pulley.
- The power from the torque converter is input via the input shaft, operating a wet multi-plate clutch by means of hydraulic pressure to switch between forward and reverse driving.

Operation of Planetary gear



BELT & PULLEY

It is composed of a pair of pulleys (the groove width is changed freely in the axial direction) and the chain belt. The groove width changes according to wrapping radius of chain belt and pulley from low status to overdrive status continuously with non-step. It is controlled with the oil pressures of primary pulley and secondary pulley.


Chain belt

STRUCTURE AND OPERATION

< SYSTEM DESCRIPTION >

[CVT: RE0F10J]


The chain belt consists of approximately 150 locker pins ① and 1,000 link plates ②. Chains are rotated by locker pins sandwiched by pulleys. This produces tension difference in chains among pulleys. Accordingly, the power is transferred by the tension.



Pulley

The primary pulley (input shaft side) and the secondary pulley (output shaft side) have the shaft with slope (fixed cone surface), movable sheave (movable cone surface that can move in the axial direction) and oil pressure chamber at the back of the movable sheave.

The movable sheave slides on the shaft to change the groove width of the pulley. Input signals of engine load (accelerator pedal opening), primary pulley speed and secondary pulley speed change the operation pressures of the primary pulley and the secondary pulley, and controls the pulley groove width.




FINAL DRIVE AND DIFFERENTIAL

STRUCTURE AND OPERATION

< SYSTEM DESCRIPTION >

[CVT: RE0F10J]


The deceleration gears are composed of 2 stages: primary deceleration (output gear, idler gear pair) and secondary deceleration (reduction gear, final gear pair). All of these gears are helical gears. The lubrication oil is the same as the CVT fluid which lubricates the entire transaxle.



TRANSAXLE : Oil Pressure System

INFOID:000000011541437

Oil pressure required for operation of the transaxle transmission mechanism is generated by oil pump, oil pressure control valve, solenoid valve, etc.



STRUCTURE AND OPERATION

< SYSTEM DESCRIPTION >

[CVT: RE0F10J]

TRANSAXLE : Component Description

INFOID:0000000011541438


Part name	Function
Torque converter	Increases engine torque and transmits it to the transaxle.
Oil pump	Utilizes a vane-type oil pump that is driven by the engine through the oil pump drive chain in order to increase efficiency of pump discharge volume in low-speed zone and optimize pump discharge volume in high-speed zone. Discharged oil from oil pump is transmitted to control valve. It is used as the oil of primary and secondary pulley operation, the oil of clutch operation, and the lubricant for each part.
Forward clutch	The forward clutch is wet and multiple plate type clutch that consists of clutch drum, piston, drive plate, and driven plate. It is a clutch to move the vehicle forward by activating piston hydraulically, engaging plates, and directly connecting sun gear and input shaft.
Reverse brake	The reverse brake is a wet multiple-plate type brake that consists of transaxle case, piston, drive plate, and driven plate. It is a brake to move the vehicle in reverse by activating piston hydraulically, engaging plates, and fixing planetary gear.
Internal gear	The internal gear is directly connected to forward clutch drum. It is a gear that moves the outer edge of pinion planet of planet carrier. It transmits power to move the vehicle in reverse when the planet carrier is fixed.
Planet carrier	Composed of a carrier, pinion planet, and pinion shaft. This gear fixes and releases the planet carrier in order to switch between forward and reverse driving.
Sun gear	Sun gear is a set part with planet carrier and internal gear. It transmits transmitted force to primary fixed sheave. It rotates in forward or reverse direction according to activation of either forward clutch or reverse brake.
Input shaft	The input shaft is directly connected to forward clutch drum and transmits traction force from torque converter. In shaft center, there are holes for hydraulic distribution to primary pulley and hydraulic distribution for lockup ON/OFF.
Primary pulley	It is composed of a pair of pulleys (the groove width is changed freely in the axial direction) and the chain belt. The groove width changes according to wrapping radius of steel belt and pulley from low status to overdrive status continuously with non-step. It is controlled with the oil pressures of primary pulley and secondary pulley.
Secondary pulley	
Chain belt	
Manual shaft	When the manual shaft is in the P position, the parking rod that is linked to the manual shaft rotates the parking pole. When the parking pole rotates, it engages with the parking gear, fixing the parking gear. As a result, the secondary pulley that is integrated with the parking gear is fixed.
Parking rod	
Parking pawl	
Parking gear	
Output gear	The deceleration gears are composed of 2 stages: primary deceleration (output gear, idler gear pair) and secondary deceleration (reduction gear, final gear pair). All of these gears are helical gears.
Idler gear	
Reduction gear	
Differential	
Torque converter regulator valve	Adjusts the feed pressure to the torque converter to the optimum pressure corresponding to the driving condition.
Pressure regulator valve	Adjusts the discharge pressure from the oil pump to the optimum pressure (line pressure) corresponding to the driving condition.
Torque converter clutch control valve	Adjusts the torque converter engage and disengage pressures.
Manual valve	Distributes the clutch operation pressure to each circuit according to the selector lever position.
Secondary reducing valve	Reduces line pressure and adjusts secondary pressure.
Primary reducing valve	Reduces line pressure and adjusts primary pressure.
Pilot valve A	Reduces line pressure and adjusts pilot pressure to the solenoid valves listed below. • Primary pressure solenoid valve • Secondary pressure solenoid valve • Select solenoid valve • Line pressure solenoid valve
Pilot valve B	Reduces pilot pressure and adjusts pilot pressure to the torque converter clutch solenoid valve.

FLUID COOLER & FLUID WARMER SYSTEM

FLUID COOLER & FLUID WARMER SYSTEM : System Description

INFOID:000000011519463


CVT FLUID COOLER SCHEMATIC



COMPONENT DESCRIPTION


CVT Oil Warmer

- The CVT oil warmer (1) is installed on the front part of transaxle assembly.
- When engine is started while engine and CVT are cold, engine coolant temperature rises more quickly than CVT fluid temperature. CVT oil warmer is provided with two circuits for CVT and engine coolant respectively so that warmed engine coolant warms CVT quickly. This helps shorten CVT warming up time, improving fuel economy.
- A cooling effect is obtained when CVT fluid temperature is high.



Heater Thermostat

- The heater thermostat (1) is installed on the front part of transaxle assembly.
- The heater thermostat open and close with set temperature.




SHIFT LOCK SYSTEM

SHIFT LOCK SYSTEM : System Description

INFOID:0000000011519464

The selector lever cannot be shifted from the P position unless the brake pedal is depressed while the ignition switch is set to ON. The shift lock is unlocked by turning the shift lock solenoid ON when the ignition switch is set to ON, the park position switch is turned ON (selector lever is in P position), and the stop lamp switch is turned ON (brake pedal is depressed) as shown in the operation chart in the figure. Therefore, the shift lock solenoid receives no ON signal and the shift lock remains locked if all of the above conditions are not fulfilled. (However, selector operation is allowed if the shift lock release button is pressed.).




SHIFT LOCK OPERATION AT "P" POSITION

When Brake Pedal Is Not Depressed (No Selector Operation Allowed)


The shift lock solenoid (1) is turned OFF (not energized) and the solenoid rod (A) is extended with the spring when the brake pedal is not depressed (no selector operation allowed) with the ignition switch ON.

The connecting lock lever (B) is located at the position shown in the figure when the solenoid rod is extended. It prevents the movement of the detent rod (C). For these reasons, the selector lever cannot be shifted from the P position.



When Brake Pedal Is Depressed (Shift Operation Allowed)

The shift lock solenoid (1) is turned ON (energized) when the brake pedal is depressed with the ignition switch ON. The solenoid rod (A) is compressed by the electromagnetic force. The connecting lock lever (B) rotates when the solenoid is activated. Therefore, the detent rod (C) can be moved. For these reasons, the selector lever can be shifted to other positions.



"P" POSITION HOLD MECHANISM (IGNITION SWITCH LOCK)

STRUCTURE AND OPERATION


< SYSTEM DESCRIPTION >

[CVT: RE0F10J]

The shift lock solenoid (1) is not energized when the ignition switch is in any position other than ON. In this condition, the shift mechanism is locked and P position is held. The operation cannot be performed from P position if the brake pedal is depressed with the ignition switch ON when the operation system of shift lock solenoid is malfunctioning. However, the lock lever (B) is forcibly rotated and the shift lock is released when the shift lock release button (A) is pressed from above. Then the selector operation from P position can be performed.

CAUTION:

Use the shift lock release button only when the selector lever cannot be operated even if the brake pedal is depressed with the ignition switch ON.



SYSTEM

< SYSTEM DESCRIPTION >

[CVT: RE0F10J]


SYSTEM

CVT CONTROL SYSTEM

CVT CONTROL SYSTEM : System Description

INFOID:0000000011519465

SYSTEM DIAGRAM



MAIN CONTROL CONTENTS OF TCM

Controls	Reference
Line pressure control	<u>TM-32, "LINE PRESSURE CONTROL : System Description"</u>
Shift control	<u>TM-33, "SHIFT CONTROL : System Description"</u>
Select control	<u>TM-35, "SELECT CONTROL : System Description"</u>
Lock-up control	<u>TM-36, "LOCK-UP CONTROL : System Description"</u>
Fail-safe	<u>TM-53, "Fail-safe"</u>
Self-diagnosis function	<u>TM-41, "CONSULT Function"</u>
Communication function with CONSULT	<u>TM-41, "CONSULT Function"</u>

SYSTEM DESCRIPTION

SYSTEM

< SYSTEM DESCRIPTION >

[CVT: RE0F10J]

- CVT detects the vehicle driving status from switches, sensors and signals, and controls the vehicle so that the optimum shift position and shift timing may always be achieved. It also controls the vehicle to reduce shift and lockup shock, etc.
- Receives input signals from switches and sensors.
- Sends the output signal necessary for operation of solenoid valves, and evaluates the line pressure, shift timing, lockup operation, engine brake performance, etc.
- If a malfunction occurs on the electric system, activate the fail-safe mode only to drive the vehicle.

LIST OF CONTROL ITEMS AND INPUT/OUTPUT

Control Item		Shift control	Line pressure control	Select control	Lock-up control	Fail-safe function*
Input	Engine torque signal (CAN communication)	×	×	×	×	×
	Engine speed signal (CAN communication)	×	×	×	×	×
	Accelerator pedal position signal (CAN communication)	×	×	×	×	
	Closed throttle position signal (CAN communication)	×	×		×	
	Stop lamp switch signal (CAN communication)	×	×	×	×	
	Primary pressure sensor					×
	Secondary pressure sensor	×	×			×
	CVT fluid temperature sensor	×	×	×	×	×
	Primary speed sensor	×	×	×	×	×
	Output speed sensor	×	×		×	×
	Input speed sensor	×	×	×	×	×
	Transmission range switch	×	×	×	×	×
	Overdrive control switch (CAN communication)	×	×		×	
Output	Line pressure solenoid valve	×	×	×		×
	Primary pressure solenoid valve	×	×			×
	Torque converter clutch solenoid valve				×	×
	Secondary pressure solenoid valve	×	×			×
	Select solenoid valve	×		×		×
	Shift position indicator (CAN communication)			×		
	O/D OFF indicator lamp (CAN communication)	×				

*: If these input/output signals show errors, TCM activates the fail-safe function.

CVT CONTROL SYSTEM : Fail-safe

INFOID:000000011552039

TCM has a fail-safe mode. The mode functions so that operation can be continued even if the signal circuit of the main electronically controlled input/output parts is damaged.

If the vehicle shows following behaviors including “poor acceleration”, a malfunction of the applicable system is detected by TCM and the vehicle may be in a fail-safe mode. At this time, check the DTC code and perform inspection and repair according to the malfunction diagnosis procedures.

Fail-safe function

SYSTEM

< SYSTEM DESCRIPTION >

[CVT: RE0F10J]

DTC	Vehicle behavior	Conditions of vehicle	
P062F	Not changed from normal driving	—	A
P0705	- Shift position indicator on combination meter is not displayed - Selector shock is large - Start is slow - Acceleration is slow - Lock-up is not performed	—	B
P0706	- Shift position indicator on combination meter is not displayed - Selector shock is large - Start is slow - Acceleration is slow - Lock-up is not performed	—	C
P0711	- Start is slow - Acceleration is slow	Engine coolant temperature when engine start: Temp. $\geq 10^{\circ}\text{C}$ (50°F)	TM
P0711	- Selector shock is large - Start is slow - Acceleration is slow	Engine coolant temperature when engine start: -35°C (-31°F) $\leq$ Temp. $< 10^{\circ}\text{C}$ (50°F)	E
P0711	- Selector shock is large - Start is slow - Acceleration is slow	Engine coolant temperature when engine start: Temp. $< -35^{\circ}\text{C}$ (-31°F)	F
P0712	- Start is slow - Acceleration is slow	Engine coolant temperature when engine start: Temp. $\geq 10^{\circ}\text{C}$ (50°F)	G
P0712	- Selector shock is large - Start is slow - Acceleration is slow	Engine coolant temperature when engine start: -35°C (-31°F) $\leq$ Temp. $< 10^{\circ}\text{C}$ (50°F)	H
P0712	- Selector shock is large - Start is slow - Acceleration is slow	Engine coolant temperature when engine start: Temp. $< -35^{\circ}\text{C}$ (-31°F)	I
P0713	- Start is slow - Acceleration is slow	Engine coolant temperature when engine start: Temp. $\geq 10^{\circ}\text{C}$ (50°F)	J
P0713	- Selector shock is large - Start is slow - Acceleration is slow	Engine coolant temperature when engine start: -35°C (-31°F) $\leq$ Temp. $< 10^{\circ}\text{C}$ (50°F)	K
P0713	- Selector shock is large - Start is slow - Acceleration is slow	Engine coolant temperature when engine start: Temp. $< -35^{\circ}\text{C}$ (-31°F)	L
P0715	- Start is slow - Acceleration is slow - Lock-up is not performed	—	M
P0717	- Start is slow - Acceleration is slow - Lock-up is not performed	—	N
P0740	- Start is slow - Acceleration is slow - Lock-up is not performed	—	O
P0743	- Start is slow - Acceleration is slow - Lock-up is not performed	—	P
P0744	- Start is slow - Acceleration is slow - Lock-up is not performed	—	
P0746	- Selector shock is large - Start is slow - Acceleration is slow - Lock-up is not performed	—	

SYSTEM

< SYSTEM DESCRIPTION >

[CVT: RE0F10J]

DTC	Vehicle behavior	Conditions of vehicle
P0776	- Selector shock is large - Start is slow - Acceleration is slow - Lock-up is not performed - Vehicle speed is not increased	When a malfunction occurs on the low oil pressure side
	- Selector shock is large - Start is slow - Acceleration is slow - Lock-up is not performed	When a malfunction occurs on the high oil pressure side
P0778	- Selector shock is large - Start is slow - Acceleration is slow - Lock-up is not performed	—
P0779	- Selector shock is large - Start is slow - Acceleration is slow - Lock-up is not performed	—
P0841	Not changed from normal driving	—
P0847	Not changed from normal driving	—
P0848	Not changed from normal driving	—
P084C	Not changed from normal driving	—
P084D	Not changed from normal driving	—
P0863	- Selector shock is large - Start is slow - Acceleration is slow - Lock-up is not performed	—
P0890	- Selector shock is large - Start is slow - Acceleration is slow - Lock-up is not performed - Vehicle speed is not increased	—
P0962	- Selector shock is large - Start is slow - Acceleration is slow - Lock-up is not performed	—
P0963	- Selector shock is large - Start is slow - Acceleration is slow - Lock-up is not performed	—
P0965	- Selector shock is large - Start is slow - Acceleration is slow - Lock-up is not performed	When a malfunction occurs on the low oil pressure side
	- Selector shock is large - Lock-up is not performed	When a malfunction occurs on the high oil pressure side
P0966	- Selector shock is large - Start is slow - Acceleration is slow - Lock-up is not performed	—
P0967	- Selector shock is large - Start is slow - Acceleration is slow - Lock-up is not performed	—
P1586	—	—
P1588	—	—

SYSTEM

< SYSTEM DESCRIPTION >

[CVT: RE0F10J]

DTC	Vehicle behavior	Conditions of vehicle
P2765	- Start is slow - Acceleration is slow - Lock-up is not performed	—
P2813	- Selector shock is large - Start is slow - Acceleration is slow - Vehicle speed is not increased	When a malfunction occurs on the low oil pressure side
	Selector shock is large	When a malfunction occurs on the high oil pressure side
P2814	Selector shock is large	—
P2815	Selector shock is large	—
U0073	- Selector shock is large - Start is slow - Acceleration is slow - Lock-up is not performed	—
U0100	- Selector shock is large - Start is slow - Acceleration is slow - Lock-up is not performed	—
U0140	Not changed from normal driving	—
U0141	Not changed from normal driving	—
U0155	Not changed from normal driving	—
U0300	- Selector shock is large - Start is slow - Acceleration is slow - Lock-up is not performed	—
U1000	Not changed from normal driving	—
U1117	Not changed from normal driving	—

CVT CONTROL SYSTEM : Protection Control

INFOID:0000000011552040

The TCM becomes the protection control status temporarily to protect the safety when the safety of TCM and transmission is lost. It automatically returns to the normal status if the safety is secured.
The TCM has the following protection control.

CONTROL FOR WHEEL SPIN

Control	When a wheel spin is detected, the engine output and gear ratio are limited and the line pressure is increased. Limits engine output when a wheel spin occurs in any of right and left drive wheels.
Vehicle behavior in control	If the accelerator is kept depressing during wheel spin, the engine revolution and vehicle speed are limited to a certain degree.
Normal return condition	Wheel spin convergence returns the control to the normal control.

TORQUE IS REDUCED WHEN DRIVING WITH THE REVERSE GEAR

Control	Engine output is controlled according to a vehicle speed while reversing the vehicle.
Vehicle behavior in control	Power performance may be lowered while reversing the vehicle.
Normal return condition	Torque returns to normal by positioning the selector lever in a range other than "R" position.

CONTROL WHEN FLUID TEMPERATURE IS HIGH

SYSTEM

< SYSTEM DESCRIPTION >

[CVT: RE0F10J]

Control	When the CVT fluid temperature is high, the gear shift permission maximum revolution and the maximum torque are reduced than usual to prevent increase of the oil temperature.
Vehicle behavior in control	Power performance may be lowered, compared to normal control.
Normal return condition	The control returns to the normal control when CVT fluid temperature is lowered.

REVERSE PROHIBIT CONTROL


Control	The reverse brake is controlled to avoid becoming engaged when the selector lever is set in "R" position while driving in forward direction at more than the specified speed.
Vehicle behavior in control	If the selector lever is put at "R" position when driving with the forward gear, the gear becomes neutral, not reverse.
Normal return condition	The control returns to normal control when the vehicle is driven at low speeds. (The reverse brake becomes engaged.)

LINE PRESSURE CONTROL

LINE PRESSURE CONTROL : System Description

INFOID:0000000011519468

SYSTEM DIAGRAM



DESCRIPTION

Highly accurate line pressure control (secondary pressure control) reduces friction for improvement of fuel economy.

Normal Oil Pressure Control

Appropriate line pressure and secondary pressure suitable for driving condition are determined based on the accelerator pedal position, engine speed, primary pulley (input) speed, secondary pulley (output) speed, vehi-

SYSTEM

< SYSTEM DESCRIPTION >

[CVT: RE0F10J]

cle speed, input torque, stop lamp switch signal, transmission range switch signal, lock-up signal, power voltage, target shift ratio, oil temperature, oil pressure, and overdrive control switch signal.

Secondary Pressure Feedback Control


In normal oil pressure control and oil pressure control in shifting, highly accurate secondary pressure is determined by detecting the secondary pressure using an oil pressure sensor and by feedback control.

SHIFT CONTROL

SHIFT CONTROL : System Description

INFOID:0000000011519469

SYSTEM DIAGRAM



DESCRIPTION

SYSTEM


< SYSTEM DESCRIPTION >

[CVT: RE0F10J]

To select the gear ratio that can give the driving force to meet driver's intent or vehicle situation, the vehicle driving condition such as vehicle speed or accelerator pedal position is detected and the most appropriate gear ratio is selected and the shifting method before reaching the speed is determined. The information is output to the primary pressure solenoid valve and secondary pressure solenoid valve to control the line pressure input/output to the pulley, to determine the pulley (movable pulley) position and to control the gear position.


D Position (Normal)

Gear shifting is performed in all shifting ranges from the lowest to the highest gear ratio.




D Position (O/D OFF)

The gear ratio is generally high by limiting the shifting range on the high side, and this always generates a large driving power.



L Position

By limiting the shifting range only to the lowest of the gear ratio, a large driving force and engine brake are obtained.



Hill Climbing And Descending Control

If a downhill is detected with the accelerator pedal is released, the system performs downshift to increase the engine brake force so that vehicle may not be accelerated more than necessary. If a climbing hill is detected, the system improves the acceleration performance in re-acceleration by limiting the gear shift range on the high side.


NOTE:

SYSTEM

< SYSTEM DESCRIPTION >

[CVT: RE0F10J]


For engine brake control on a downhill, the control can be stopped with CONSULT.



Control In Acceleration

From change of the vehicle speed or accelerator pedal position, the acceleration request level of the driver or driving scene is evaluated. In start or acceleration during driving, the gear shift characteristics with linearity of revolution increase and vehicle speed increase are gained to improve the acceleration feel.

- When the accelerator pedal is depressed 4/8 or more in D position, CVT performs step shifting to allow the vehicle speed and engine speed to increase simultaneously. This improves the feel of acceleration and enables the fuel economy by preventing unnecessary rise in engine speed, compared to the conventional-shifting.




SELECT CONTROL

SELECT CONTROL : System Description

INFOID:0000000011519470

SYSTEM DIAGRAM



DESCRIPTION


Based on accelerator pedal angle, engine speed, primary pulley speed, and the input speed, the optimum operating pressure is set to reduce impact of a selector lever operation while shifting from "N" ("P") to "D" ("R") position.

LOCK-UP CONTROL

LOCK-UP CONTROL : System Description

INFOID:0000000011519471

SYSTEM DIAGRAM



DESCRIPTION

- Controls for improvement of the transmission efficiency by engaging the torque converter clutch in the torque converter and eliminating slip of the converter. Achieves comfortable driving with slip control of the torque converter clutch.
- The oil pressure feed circuit for the torque converter clutch piston chamber is connected to the torque converter clutch control valve. The torque converter clutch control valve is switched by the torque converter clutch solenoid valve with the signal from TCM. This controls the oil pressure circuit, which is supplied to the torque converter clutch piston chamber, to the release side or engagement side.
- If the CVT fluid temperature is low or the vehicle is in fail-safe mode due to malfunction, lock-up control is prohibited.

Lock-up engagement

In lock-up engagement, the torque converter clutch solenoid valve makes the torque converter clutch control valve locked up to generate the lock-up apply pressure. This pushes the torque converter clutch piston for engagement.

Lock-up release condition

In lock-up release, the torque converter clutch solenoid valve makes the torque converter clutch control valve non-locked up to drain the lock-up apply pressure. This does not engage the torque converter clutch piston.

ON BOARD DIAGNOSTIC (OBD) SYSTEM

< SYSTEM DESCRIPTION >

[CVT: RE0F10J]

ON BOARD DIAGNOSTIC (OBD) SYSTEM

Diagnosis Description

INFOID:0000000011519472

This is an on board diagnosis system which records diagnosis information related to the exhaust gases. It detects malfunctions related to sensors and actuators. The malfunctions are indicated by means of the malfunction indicator lamp (MIL) and are stored as DTC in the ECU memory. The diagnosis information can be checked using a diagnosis tool (GST: Generic Scan Tool).

GST (Generic Scan Tool)

INFOID:0000000011519473

The GST is connected to the diagnosis connector on the vehicle and communicates with the on-board control units to perform diagnosis. The diagnosis connector is the same as for CONSULT. Refer to [GI-50, "Description"](#).

DIAGNOSIS SYSTEM (TCM)

DIAGNOSIS DESCRIPTION

DIAGNOSIS DESCRIPTION : 1 Trip Detection Diagnosis and 2 Trip Detection Diagnosis

INFOID:0000000011519474

NOTE:

"Start the engine and turn OFF the ignition switch after warm-up." This is defined as 1 trip.

1 TRIP DETECTION DIAGNOSIS

When initial malfunction is detected, TCM memorizes DTC. In these diagnoses, some illuminate MIL and some do not. Refer to [TM-58, "DTC Index"](#).

2 TRIP DETECTION DIAGNOSIS

When initial malfunction is detected, TCM memorizes DTC of the 1st trip. MIL does not light at this stage. <1 trip>

If the same malfunction is detected again in next driving, TCM memorizes DTC. When DTC is memorized, MIL lights. <2 trip>

"Trip" of the "2 trip detection diagnosis" indicates the driving mode that executes self-diagnosis during driving.

×: Check possible —: Check not possible

Item	DTC at the 1st trip		DTC		MIL	
	Display at the 1st trip	Display at the 2nd trip	Display at the 1st trip	Display at the 2nd trip	Illumination at the 1st trip	Illumination at the 2nd trip
1 trip detection diagnosis (Refer to TM-58, "DTC Index")	—	—	×	—	×	—
2 trip detection diagnosis (Refer to TM-58, "DTC Index")	×	—	—	×	—	×

DIAGNOSIS DESCRIPTION : DTC and DTC of 1st Trip

INFOID:0000000011519475

2 TRIP DETECTION DIAGNOSIS THAT ILLUMINATES MIL

- The DTC number of the 1st trip is the same as the DTC number.
- When a malfunction is detected at the 1st trip, TCM memorizes DTC of the 1st trip. MIL does not light at this stage. If the same malfunction is not detected at the 2nd trip (conforming to necessary driving conditions), DTC at the 1st trip is erased from TCM. If the same malfunction is detected at the 2nd trip, TCM memorizes DTC and MIL lights at the same time.
- The DTC of the 1st trip is specified in Service \$01 of SAE J1979/ISO 15031-5. Since detection of DTC at the 1st trip does not illuminate MIL, warning for a problem is not given to a driver.
- For procedure to delete DTC and 1st trip DTC from TCM, refer to [TM-41, "CONSULT Function"](#).
- If DTC of the 1st trip is detected, it is necessary to check the cause according to the "Diagnosis flow". Refer to [TM-69, "Flowchart of Trouble Diagnosis"](#).

DIAGNOSIS DESCRIPTION : Malfunction Indicator Lamp (MIL)

INFOID:0000000011519476

- TCM not only detects DTC, but also sends the MIL signal to ECM through CAN communication. ECM sends the MIL signal to the combination meter through CAN communication according to the signal, and illuminates MIL.
- For malfunction indicator lamp (MIL) description, refer to [EC-20, "Malfunction Indicator lamp \(MIL\)"](#).

DIAGNOSIS DESCRIPTION : Counter System

INFOID:0000000011519477

RELATION BETWEEN DTC AT 1ST TRIP/DTC/MIL AND DRIVING CONDITIONS (FOR 2 TRIP DETECTION DIAGNOSIS THAT ILLUMINATES MIL)

- When initial malfunction is detected, TCM memorizes DTC of the 1st trip. MIL does not light at this stage.
- If the same malfunction is detected at the 2nd trip, TCM memorizes DTC and MIL lights at the same time.
- Then, MIL goes after driving the vehicle for 3 trips under "Driving condition B" without malfunction.
- DTC is displayed until 40 trips of "Driving condition A" are satisfied without detecting the same malfunction. DTC is erased when 40 trips are satisfied.

DIAGNOSIS SYSTEM (TCM)

< SYSTEM DESCRIPTION >

[CVT: RE0F10J]

- When the self-diagnosis result is acceptable at the 2nd trip (conforming to driving condition B), DTC of the 1st trip is erased.

COUNTER SYSTEM LIST

Item	Driving condition	Trip
MIL (OFF)	B	3
DTC (clear)	A	40
DTC at 1st trip (clear)	B	1

DRIVING CONDITION

Driving condition A

Driving condition A is the driving condition that provides warm-up.

In specific, count-up is performed when all of the following conditions are satisfied.

- Engine speed is 400 rpm or more.
- After start of the engine, the water temperature increased by 20°C (36°F) or more.
- Water temperature was 70°C (158°F) or more.
- The ignition switch was changed from ON to OFF.

NOTE:

- If the same malfunction is detected regardless of the driving condition, reset the A counter.
- When the above is satisfied without detecting the same malfunction, count up the A counter.
- When MIL goes off due to the malfunction and the A counter reaches 40, the DTC is erased.

Driving condition B

Driving condition B is the driving condition that performs all diagnoses once.

In specific, count-up is performed when all of the following conditions are satisfied.

- Engine speed is 400 rpm or more.
- Water temperature was 70°C (158°F) or more.
- In closed loop control, vehicle speed of 70 – 120 km/h (43 – 75 MPH) continued for 60 seconds or more.
- In closed loop control, vehicle speed of 30 – 60 km/h (19 – 37 MPH) continued for 10 seconds or more.
- In closed loop control, vehicle speed of 4 km/h (2 MPH) or less and idle determination ON continued for 12 seconds or more.
- After start of the engine, 22 minutes or more have passed.
- The condition that the vehicle speed is 10 km/h (6 MPH) or more continued for 10 seconds or more in total.
- The ignition switch was changed from ON to OFF.

NOTE:


- If the same malfunction is detected regardless of the driving condition, reset the B counter.
- When the above is satisfied without detecting the same malfunction, count up the B counter.
- When the B counter reaches 3 without malfunction, MIL goes off.
- When the B counter is counted once without detecting the same malfunction after TCM memorizes DTC of the 1st trip, DTC of the 1st trip is erased.

DIAGNOSIS SYSTEM (TCM)

< SYSTEM DESCRIPTION >

[CVT: RE0F10J]

TIME CHART



CONSULT Function

INFOID:0000000011519478

CAUTION:

After disconnecting the CONSULT vehicle interface (VI) from the data link connector, the ignition must be cycled OFF → ON (for at least 5 seconds) → OFF. If this step is not performed, the BCM may not go to "sleep mode", potentially causing a discharged battery and a no-start condition.

APPLICABLE ITEM

DIAGNOSIS SYSTEM (TCM)

< SYSTEM DESCRIPTION >

[CVT: RE0F10J]

Conditions	Function
Work Support	The settings for ECU functions can be changed.
Self Diagnostic Results	The ECU self diagnostic results are displayed.
Data Monitor	The ECU input/output data is displayed in real time.
CAN Diagnosis Support Monitor	The result of transmit/receive diagnosis of CAN communication is displayed.
Active Test	The ECU activates outputs to test components.
ECU Identification	The ECU part number is displayed.
CALIB DATA	The calibration data status of TCM can be checked.

SELF DIAGNOSTIC RESULTS

Display Item List

Refer to [TM-58, "DTC Index"](#).

DTC at 1st trip and method to read DTC

- DTC (P0705, P0711, P0720, etc.) is specified by SAE J2012/ISO 15031-6.
- DTC and DTC at 1st trip are displayed on "Self Diagnostic results" of CONSULT.
When DTC is currently detected, "CRNT" is displayed. If "PAST" is displayed, it shows a malfunction occurred in the past. The trip number of drive without malfunction of concerned DTC can be confirmed with "IGN counter" inside "FFD".
- When the DTC at the 1st trip is detected, "1t" is displayed.

DTC deletion method

NOTE:

If the ignition switch is left ON after repair, turn OFF the ignition switch and wait for 10 seconds or more. Then, turn the ignition ON again. (Engine stop)

1. Touch "TRANSMISSION" of CONSULT.
2. Touch "Self Diagnostic Result".
3. Touch "Erase". (DTC memorized in TCM is erased.)

IGN counter

The ignition counter is displayed in "FFD" and the number of times of satisfied "Driving condition A" is displayed after normal recovery of DTC. Refer to [TM-39, "DIAGNOSIS DESCRIPTION : Counter System"](#).

- If malfunction (DTC) is currently detected, "0" is displayed.
- After normal recovery, every time "Driving condition A" is satisfied, the display value increases from 1 → 2 → 3...38 → 39.
- When MIL turns OFF due to the malfunction and the counter reaches 40, the DTC is erased.

NOTE:

The counter display of "40" cannot be checked.

DATA MONITOR

NOTE:

The following table includes information (items) inapplicable to this vehicle. For information (items) applicable to this vehicle, refer to CONSULT display items.

×: Application ▼: Optional selection

Monitored item	(Unit)	Remarks
VSP SENSOR	(km/h or mph)	Displays the vehicle speed calculated from the CVT output shaft speed.
ESTM VSP SIG	(km/h or mph)	• Displays the vehicle speed signal (ABS) received through CAN communication. • Models with ABS are displayed.
INPUT SPEED SENSOR	(rpm)	Displays the input speed calculated from the pulse signal of the input speed sensor.
PRI SPEED SEN	(rpm)	Displays the primary pulley speed calculated from the pulse signal of the primary speed sensor.
SEC REV SENSOR	(rpm)	Displays the secondary pulley speed calculated from the pulse signal of the output speed sensor.
ENG SPEED SIG	(rpm)	Displays the engine speed received through CAN communication.
SEC PRESSURE SEN	(V)	Displays the signal voltage of the secondary pressuresensor.

DIAGNOSIS SYSTEM (TCM)

< SYSTEM DESCRIPTION >

[CVT: RE0F10J]

Monitored item	(Unit)	Remarks
PRI PRESSURE SEN	(V)	Displays the signal voltage of the primary pressuresensor.
ATF TEMP SEN	(V)	Displays the signal voltage of the CVT fluid temperature sensor.
G SENSOR	(G)	Displays the signal voltage of the G sensor.
VIGN SEN	(V)	Displays the battery voltage applied to TCM.
PVIGN VOLT	(V)	Displays the backup voltage of TCM.
VEHICLE SPEED	(km/h or mph)	Displays the vehicle speed recognized by TCM.
INPUT REV	(rpm)	Displays the input shaft speed of CVT recognized by TCM.
PRI SPEED	(rpm)	Displays the primary pulley speed recognized by TCM.
SEC SPEED	(rpm)	Displays the secondary pulley speed recognized by TCM.
ENG SPEED	(rpm)	Displays the engine speed recognized by TCM.
SLIP REV	(rpm)	Displays the speed difference between the input shaft speed of CVT and the engine speed.
PULLEY GEAR RATIO		Displays the pulley gear ratio calculated from primary pulley speed/secondary pulley speed.
G SPEED	(G)	Displays the acceleration and deceleration speed of the vehicle calculated from vehicle speed change.
ACCEL POSI SEN 1	(deg)	Displays the estimated throttle position received through CAN communication.
VENG TRQ	(Nm)	Display the engine torque recognized by TCM.
PRI TRQ	(Nm)	Display the input shaft torque of CVT.
TRQ RTO		Display the torque ratio of torque converter.
SEC PRESSURE	(MPa)	Displays the secondary pressure calculated from the signal voltage of the secondary pressure sensor.
PRI PRESSURE	(MPa)	Displays the primary pressure calculated from the signal voltage of the primary pressure sensor.
FLUID TEMP	(°C or °F)	Displays the CVT fluid temperature calculated from the signal voltage of the CVT fluid temperature sensor.
DSR REV	(rpm)	Displays the target primary pulley speed calculated from processing of gear shift control.
TGT PLY GR RATIO		Displays the target gear ratio of the pulley from processing of gear shift control.
LU PRS	(MPa)	Displays the target oil pressure of the torque converter clutch solenoid valve calculated from oil pressure processing of gear shift control.
LINE PRS	(MPa)	Displays the target oil pressure of the line pressure solenoid valve calculated from oil pressure processing of gear shift control.
TRGT PRI PRESSURE	(MPa)	Displays the target oil pressure of the primary pressure solenoid valve calculated from oil pressure processing of gear shift control.
TARGET SELECT PRESSURE	(MPa)	Displays the target oil pressure of the select solenoid valve calculated from oil pressure processing of gear shift control.
TARGET SEC PRESSURE	(MPa)	Displays the target oil pressure of the secondary pressure solenoid valve calculated from oil pressure processing of gear shift control.
ISOLT1	(A)	Displays the command current from TCM to the torque converter clutch solenoid valve.
ISOLT2	(A)	Displays the command current from TCM to the line pressure solenoid valve.
PRI SOLENOID	(A)	Displays the command current from TCM to the primary pressure solenoid valve.
SEC SOLENOID CURRENT	(A)	Displays the command current from TCM to the secondary pressure solenoid valve.
SELECT SOLENOID CURRENT	(A)	Displays the command current from TCM to the select solenoid valve.
SOLMON1	(A)	Monitors the command current from TCM to the torque converter clutch solenoid valve and displays the monitored value.

A

B

C

TM

E

F

G

H

I

J

K

L

M

N

O

P

DIAGNOSIS SYSTEM (TCM)

< SYSTEM DESCRIPTION >

[CVT: RE0F10J]

Monitored item	(Unit)	Remarks
SOLMON2	(A)	Monitors the command current from TCM to the line pressure solenoid valve and displays the monitored value.
PRI SOL MON	(A)	Monitors the command current from TCM to the primary pressure solenoid valve and displays the monitored value.
SEC SOL MON CURRENT	(A)	Monitors the command current from TCM to the secondary pressure solenoid valve and displays the monitored value.
SELECT SOL MON CURRENT	(A)	Monitors the command current from TCM to the select solenoid valve and displays the monitored value.
D POSITION SW	(On/Off)	Displays the operation status of the transmission range switch (D position).
N POSITION SW	(On/Off)	Displays the operation status of the transmission range switch (N position).
R POSITION SW	(On/Off)	Displays the operation status of the transmission range switch (R position).
P POSITION SW	(On/Off)	Displays the operation status of the transmission range switch (P position).
L POSITION SW	(On/Off)	Displays the operation status of the transmission range switch (L position).
DS RANGE SW*	(On/Off)	Displays the operation status of the transmission range switch (Ds position).
BRAKESW	(On/Off)	Displays the reception status of the stop lamp switch signal received through CAN communication.
IDLE SW	(On/Off)	Displays the reception status of the closed throttle position signal received through CAN communication.
SPORT MODE SW	(On/Off)	Displays the reception status of the overdrive control switch signal received through CAN communication.
ECO MODE SW*	(On/Off)	Displays the reception status of the ECO mode switch signal received through CAN communication.
STRDWNSW*	(On/Off)	Displays the operation status of the paddle shifter (down switch).
STRUPSW*	(On/Off)	Displays the operation status of the paddle shifter (up switch).
DOWNLVR*	(On/Off)	Displays the operation status of the selector lever (down switch).
UPLVR*	(On/Off)	Displays the operation status of the selector lever (up switch).
NONMMODE*	(On/Off)	Displays if the selector lever position is not at the manual shift gate.
MMODE*	(On/Off)	Displays if the selector lever position is at the manual shift gate.
TOW MODE SW*	(On/Off)	Displays the reception status of the TOW mode switch signal received through CAN communication.
SHIFT IND SIGNAL		Displays the transaxle value of shift position signal transmitted via CAN communication.
CVT LAMP*	(On/Off)	Displays the transaxle status of the CVT warning lamp signal transmitted through CAN communication.
SPORT MODE IND	(On/Off)	Displays the transaxle status of the O/D OFF indicator lamp signal transmitted through CAN communication.
MANU MODE SIGNAL *	(On/Off)	Displays the transaxle status of the manual mode signal transmitted through CAN communication.
DS RANGE SIGNAL *	(On/Off)	Displays the shift position signal status from transmission range switch (DS position).
ECO MODE SIGNAL*	(On/Off)	Displays the transaxle status of the ECO mode signal transmitted through CAN communication.
VDC ON	(On/Off)	Displays the reception status of the VDC operation signal received through CAN communication.
TCS ON	(On/Off)	Displays the reception status of the TCS operation signal received through CAN communication.
ABS FAIL SIGNAL	(On/Off)	Displays the reception status of the ABS malfunction signal received through CAN communication.
ABS ON	(On/Off)	Displays the reception status of the ABS operation signal received through CAN communication.

DIAGNOSIS SYSTEM (TCM)

< SYSTEM DESCRIPTION >

[CVT: RE0F10J]

Monitored item	(Unit)	Remarks
RANGE		Displays the gear position recognized by TCM.
M GEAR POS*		Display the target gear of manual mode
G SEN SLOPE	(%)	Displays the gradient angle calculated from the G sensor signal voltage.
G SEN CALIBRATION	(YET/DONE)	Displays the status of "G SENSOR CALIBRATION" in "Work Support".
N IDLE STATUS*	(On/Off)	Displays idle neutral status.
ENGBRKLVL	(On/Off)	Displays the setting of "ENGINE BRAKE ADJ" in "Work Support".
DRIVE MODE STATS*		Displays the drive mode status recognized by TCM.
SNOW MODE*	(On/Off)	Displays whether it is the SNOW mode.
ECO MODE*	(On/Off)	Displays whether it is the ECO mode.
NORMAL MODE*	(On/Off)	Displays whether it is the NORMAL mode.
SPORT MODE*	(On/Off)	Displays whether it is the SPORT mode.
AIR BLDING STATE*	(INCOMP/COMP)	Displays the status of "ELECTRIC O.P. AIR BLEEDING" in "Work Support".
ELECTRIC OP DUTY*	(%)	Displays the command signal value (duty) of the electric oil pump transmitted from TCM.
E-OP DUTY MON*	(%)	Monitors the status signal value (duty) transmitted from the electric oil pump and displays the monitored value.
ELECTRIC OP RELAY*	(On/Off)	Displays the command status from TCM to the electric oil pump relay.
E-OP RELAY MON*	(On/Off)	Monitors the command status from TCM to the oil pump relay and displays the monitored value.
CVT-B		- Displays CVT fluid temperature count. - This monitor item does not use.
CVT-A		- Displays CVT fluid temperature count. - This monitor item does not use.
G SENSOR	(V)	Displays the signal voltage of the G sensor.

*: Not applicable but displayed.

WORK SUPPORT

Item name	Description
CONFORM CVTF DETERIORTN	Checks the degradation level of the CVT fluid under severe conditions.
ERASE MEMORY DATA	Performs "erasing of the calibration data" and "erasing of the learned value" at the same time.
G SENSOR CALIBRATION	Compensates the G sensor.
ERASE LEARNING VALUE	Erases learning value memorized by TCM.
ENGINE BRAKE ADJ.	Although there is no malfunction on the transaxle and the CVT system, if a customer make a complaint like "I do not feel comfortable with automatic operation of the engine brake on downhill", the engine brake may be cancelled with "engine brake adjustment".
ERASE CALIBRATION DATA	Erases calibration data memorized by TCM.
WRITE IP CHARA - REPLACEMENT AT/CVT	Writes IP characteristics when transaxle assembly is replaced.
READ IP CHARA - REPLACEMENT TCM	Reads IP characteristics when TCM is replaced.
WRITE IP CHARA - REPLACEMENT TCM	Writes IP characteristics when TCM is replaced.

Engine brake adjustment

ENGINE BRAKE LEVEL

ON : Turn ON the engine brake control.

OFF : Turn OFF the engine brake control.

Check the degradation level of the CVT fluid.

DIAGNOSIS SYSTEM (TCM)

< SYSTEM DESCRIPTION >

[CVT: RE0F10J]

CVTF degradation level data

210,000 or more : Replacement of the CVT fluid is required.

Less than 210,000 : Replacement of the CVT fluid is not required.

ACTIVE TEST

Item name	Description
CVT OIL COOLER FAN CIRCUIT	Checks the operation of CVT oil cooler fan relay.

ECU DIAGNOSIS INFORMATION

TCM

Reference Value

INFOID:0000000011519479

CONSULT DATA MONITOR STANDARD VALUE

- In CONSULT, electric shift timing or lock-up timing, i.e. operation timing of each solenoid valve, is displayed. Therefore, if there is an obvious difference between the shift timing estimated from a shift shock (or engine speed variations) and that shown on the CONSULT, the mechanism parts (including the hydraulic circuit) excluding the solenoids and sensors may be malfunctioning. In this case, check the mechanical parts following the appropriate diagnosis procedure.
- Shift point (gear position) displayed on CONSULT slightly differs from shift pattern described in Service Manual. This is due to the following reasons.
 - Actual shift pattern may vary slightly within specified tolerances.
 - While shift pattern described in Service Manual indicates start of each shift, CONSULT shows gear position at end of shift.
 - The solenoid display (ON/OFF) on CONSULT is changed at the start of gear shifting. In contrast, the gear position display is changed at the time when gear shifting calculated in the control unit is completed.

NOTE:

The following table includes information (items) inapplicable to this vehicle. For information (items) applicable to this vehicle, refer to CONSULT display items.

Monitor item	Condition	Value/Status (Approx.)
VSP SENSOR	While driving	Almost same as the speedometer display.
ESTM VSP SIG	While driving	Almost same as the speedometer display.
INPUT SPEED SENSOR	In driving (lock-up ON)	Approximately matches the engine speed.
PRI SPEED SEN	In driving (lock-up ON)	Approximately matches the engine speed.
SEC REV SENSOR	While driving	VSP SENSOR × 40
ENG SPEED SIG	Engine running	Almost same reading as tachometer
SEC PRESSURE SEN	• After engine warm up • Selector lever: "N" position • At idle	1.7 – 1.8 V
PRI PRESSURE SEN	• After engine warm up • Selector lever: "N" position • At idle	1.32 – 1.34 V
ATF TEMP SEN	CVT fluid: Approx. 20°C (68°F)	2.01 – 2.05 V
	CVT fluid: Approx. 50°C (122°F)	1.45 – 1.50 V
	CVT fluid: Approx. 80°C (176°F)	0.90 – 0.94 V
G SENSOR	• Vehicle stopped • Vehicle is level	0 G
	During acceleration	The value changes to the positive side along with acceleration.
	During deceleration	The value changes to the positive side along with deceleration.
VIGN SEN	Ignition switch: ON	10 – 16 V
PVIGN VOLT	Ignition switch: ON	10 – 16 V
VEHICLE SPEED	While driving	Almost same as the speedometer display.
INPUT REV	In driving (lock-up ON)	Almost same as the engine speed.
PRI SPEED	In driving (lock-up ON)	Approximately matches the engine speed.
SEC SPEED	While driving	VSP SENSOR × 40
ENG SPEED	Engine running	Almost same reading as tachometer
SLIP REV	While driving	Engine speed – Input speed

TCM

< ECU DIAGNOSIS INFORMATION >

[CVT: RE0F10J]

Monitor item	Condition	Value/Status (Approx.)
PULLEY GEAR RATIO	In driving (forward)	2.70 – 0.38
	In driving (reverse)	2.70
G SPEED	Vehicle stopped	0.00 G
	During acceleration	The value changes to the positive side along with acceleration.
	During deceleration	The value changes to the positive side along with deceleration.
ACCEL POSI SEN 1	Accelerator pedal released	0.00 deg
	Accelerator pedal fully depressed	80.00 deg
VENG TRQ	While driving	The value changes along with acceleration/ deceleration.
PRI TRQ	While driving	The value changes along with acceleration/ deceleration.
TRQ RTO	While driving	The value changes along with acceleration/ deceleration.
SEC PRESSURE	- After engine warm up - Selector lever: "N" position - At idle	1.8 MPa
PRI PRESSURE	- After engine warm up - Selector lever: "N" position - At idle	1.2 MPa
FLUID TEMP	Ignition switch ON.	Displays the CVT fluid temperature.
DSR REV	While driving	It varies along with the driving condition.
TGT PLY GR RATIO	In driving (forward)	2.70 – 0.38
	In driving (reverse)	2.70
LU PRS	- Engine started - Vehicle is stopped.	–0.500 MPa
	- Selector lever: "D" position - Accelerator pedal position: 1/8 or less - Vehicle speed: 20 km/h (12 MPH) or more	0.650 MPa
LINE PRS	- After engine warm up - Selector lever: "N" position - At idle	1.8 MPa
TRGT PRI PRESSURE	- After engine warm up - Selector lever: "N" position - At idle	1.2 MPa
TARGET SELECT PRESSURE	- After engine warm up - Selector lever: "N" position - At idle	0 MPa
	- Selector lever: "D" position - At idle	0.3 – 0.5 MPa
TARGET SEC PRESSURE	- After engine warm up - Selector lever: "N" position - At idle	1.8 MPa
ISOLT1*	—	—
ISOLT2*	—	—
PRI SOLENOID*	—	—
SEC SOLENOID CURRENT*	—	—
SELECT SOLENOID CURRENT*	—	—
SOLMON1*	—	—

TCM

< ECU DIAGNOSIS INFORMATION >

[CVT: RE0F10J]

Monitor item	Condition	Value/Status (Approx.)
SOLMON2*	—	—
PRI SOL MON*	—	—
SEC SOL MON CURRENT*	—	—
SELECT SOL MON CURRENT*	—	—
D POSITION SW	Selector lever: "D" position	On
	Other than the above	Off
N POSITION SW	Selector lever: "N" position	On
	Other than the above	Off
R POSITION SW	Selector lever: "R" position	On
	Other than the above	Off
P POSITION SW	Selector lever: "P" position	On
	Other than the above	Off
L POSITION SW	Selector lever: "L" position	On
	Other than the above	Off
DS RANGE SW	Always	Off
BRAKESW	Brake pedal is depressed	On
	Brake pedal is released	Off
IDLE SW	Accelerator pedal is fully depressed	On
	Accelerator pedal is released	Off
SPORT MODE SW	Press the overdrive control switch	On
	Release the overdrive control switch	Off
ECO MODE SW	Always	Off
STRDWNSW	Always	Off
STRUPSW	Always	Off
DOWNLVR	Always	Off
UPLVR	Always	Off
NONMMODE	Always	On
MMODE	Always	Off
TOW MODE SW	Always	Off
SHIFT IND SIGNAL	When the selector lever is positioned in between each position.	OFF
	Selector lever: P position	P
	Selector lever: R position	R
	Selector lever: N position	N
	Selector lever: D position	D
	Selector lever: L position	L
CVT LAMP	Approx. 2 seconds after ignition switch ON	On
	Other than the above	Off
SPORT MODE IND	In overdrive off	On
	Other than the above	Off
MANU MODE SIGNAL	Always	Off
DS RANGE SIGNAL	Always	Off
ECO MODE SIGNAL	Always	Off
VDC ON	When VDC malfunction signal is received	On
	Other than the above	Off

A

B

C

TM

E

F

G

H

I

J

K

L

M

N

O

P

TCM


< ECU DIAGNOSIS INFORMATION >

[CVT: RE0F10J]


Monitor item	Condition	Value/Status (Approx.)
TCS ON	When TCS malfunction signal is received	On
	Other than the above	Off
ABS FAIL SIGNAL	When ABS malfunction signal is received	On
	Other than the above	Off
ABS ON	ABS is activated	On
	Other than the above	Off
RANGE	Selector lever: P and N positions	N/P
	Selector lever: R position	R
	Selector lever: D position	D
	Selector lever: D position (in O/D OFF)	S
	Selector lever: L position	L
M GEAR POS	Always	1
G SEN SLOPE	Flat road	0%
	Uphill gradient	The value changes to the positive side along with uphill gradient. (Maximum 40.45%)
	Downhill gradient	The value changes to the negative side along with downhill gradient. (Minimum – 40.45%)
G SEN CALIBRATION	When G sensor calibration is completed	DONE
	When G sensor calibration is not completed	YET
N IDLE STATUS	Always	Off
ENGBRKLVL	When the engine brake level of “ENGINE BRAKE ADJ”. in “Work Support” is ON	On
	When the engine brake level of “ENGINE BRAKE ADJ”. in “Work Support” is OFF	Off
DRIVE MODE STATS	While driving in D position	AUTO
SNOW MODE	Always	Off
ECO MODE	Always	Off
NORMAL MODE	Always	Off
SPORT MODE	Always	Off
AIR BLDING STATE	Always	INCOMP
ELECTRIC OP DUTY	Always	0%
E-OP DUTY MON	Always	0%
ELECTRIC OP RELAY	Always	Off
E-OP RELAY MON	Always	Off
CVT-B*	—	—
CVT-A*	—	—
G SENSOR	- Vehicle stopped - Vehicle is level	2.5 V
	During acceleration	Positive value
	During deceleration	Negative value

*: These monitor items do not use.

TERMINAL LAYOUT








INPUT/OUTPUT SIGNAL STANDARD

Terminal No. (Wire color)		Description		Condition		Value (Approx.)
+	—	Signal	Input/ Output			
2 (GR)	Ground	L position switch	Input	Ignition switch ON	Selector lever: “L” position	10 – 16 V
					Other than the above	0 V
4 (G/O)	Ground	D position switch	Input		Selector lever: “D” position	10 – 16 V
					Other than the above	0 V
5 (P/L)	Ground	N position switch	Input		Selector lever: “N” position	10 – 16 V
					Other than the above	0 V
6 (P/B)	Ground	R position switch	Input		Selector lever: “R” position	10 – 16 V
					Other than the above	0 V
7 (BR/W)	Ground	P position switch	Input		Selector lever: “P” position	10 – 16 V
				Other than the above	0 V	
11 (W/R)	Ground	Sensor ground	Input	Always		0 V
12 (V)	Ground	CVT fluid tempera- ture sensor	Input	Ignition switch ON	CVT fluid: Approx. 20°C (68°F)	2.01 – 2.05 V
					CVT fluid: Approx. 50°C (122°F)	1.45 – 1.50 V
					CVT fluid: Approx. 80°C (176°F)	0.90 – 0.94 V
14 (W)	Ground	G sensor	Input	Ignition switch ON	• Vehicle stopped • Vehicle is level	2.5 V
16 (V/W)	Ground	Secondary pres- sure sensor	Input	• After engine warm up • Selector lever: “N” position • At idle		1.7 – 1.8 V
17 (LG)	Ground	Primary pressure sensor	Input	• After engine warm up • Selector lever: “N” position • At idle		1.32 – 1.34 V
23 (P)	—	CAN-L	Input/ Output	—		—
24 (BR)	Ground	Input speed sensor	Input	• Selector lever: “L” position • Vehicle speed: 20 km/h (12 MPH)		880 Hz 1mSec/div  5V/div JSDIA3769GB

TCM

< ECU DIAGNOSIS INFORMATION >





[CVT: RE0F10J]

Terminal No. (Wire color)		Description		Condition	Value (Approx.)
+	—	Signal	Input/ Output		
26 (L/O)	Ground	Sensor power supply	Output	Ignition switch: ON	5.0 V
				Ignition switch: OFF	0 V
30 (R/Y)	Ground	Line pressure solenoid valve	Output	- After engine warming up - Selector lever: "N" position - At idle	 JSDIA1897GB
				- After engine warming up - Selector lever: "N" position - Depress the accelerator pedal fully	 JSDIA1898GB
33 (L)	—	CAN-H	Input/ Output	—	—
34 (LG/R)	Ground	Output speed sensor	Input	- Selector lever: "L" position - Vehicle speed: 20 km/h (12 MPH)	 JSDIA1904GB
35 (LG)	Ground	Primary speed sensor	Input	- Selector lever: "L" position - Vehicle speed: 20 km/h (12 MPH)	 JSDIA1905GB
37 (L/W)	Ground	Select solenoid valve	Output	- Engine started - Vehicle is stopped - Selector lever: "N" position	 JSDIA1897GB

TCM

< ECU DIAGNOSIS INFORMATION >

[CVT: RE0F10J]

Terminal No. (Wire color)		Description		Condition	Value (Approx.)
+	—	Signal	Input/ Output		
38 (V/R)	Ground	Torque converter clutch solenoid valve	Output	- Selector lever: "D" position - Accelerator pedal position: 1/8 or less - Vehicle speed: 20 km/h (12 MPH) or more	
				- Engine started - Vehicle is stopped	
39 (W/B)	Ground	Secondary pres- sure solenoid valve	Output	- Selector lever: "L" position - Vehicle speed: 20 km/h (12 MPH)	
40 (B/R)	Ground	Primary pressure solenoid valve	Output	- Selector lever: "L" position - Vehicle speed: 20 km/h (12 MPH)	
41 (B)	Ground	Ground	Output	Always	0 V
42 (B)	Ground	Ground	Output	Always	0 V
45 (LG)	Ground	Battery power sup- ply (backup)	Input	Always	10 – 16 V
46 (LG)	Ground	Battery power sup- ply (backup)	Input	Always	10 – 16 V
47 (Y)	Ground	Ignition power sup- ply	Input	Ignition switch: ON	10 – 16 V
				Ignition switch: OFF	0 V
48 (Y)	Ground	Ignition power sup- ply	Input	Ignition switch: ON	10 – 16 V
				Ignition switch: OFF	0 V

Fail-safe

INFOID:0000000011519480

TCM has a fail-safe mode. The mode functions so that operation can be continued even if the signal circuit of the main electronically controlled input/output parts is damaged.

If the vehicle shows following behaviors including "poor acceleration", a malfunction of the applicable system is detected by TCM and the vehicle may be in a fail-safe mode. At this time, check the DTC code and perform inspection and repair according to the malfunction diagnosis procedures.

Fail-safe function

DTC	Vehicle behavior	Conditions of vehicle
P062F	Not changed from normal driving	—
P0705	- Shift position indicator on combination meter is not displayed - Selector shock is large - Start is slow - Acceleration is slow - Lock-up is not performed	—
P0706	- Shift position indicator on combination meter is not displayed - Selector shock is large - Start is slow - Acceleration is slow - Lock-up is not performed	—
P0711	- Start is slow - Acceleration is slow	Engine coolant temperature when engine start: Temp. $\geq 10^{\circ}\text{C}$ (50°F)
	- Selector shock is large - Start is slow - Acceleration is slow	Engine coolant temperature when engine start: -35°C (-31°F) $\leq$ Temp. $< 10^{\circ}\text{C}$ (50°F)
	- Selector shock is large - Start is slow - Acceleration is slow	Engine coolant temperature when engine start: Temp. $< -35^{\circ}\text{C}$ (-31°F)
P0712	- Start is slow - Acceleration is slow	Engine coolant temperature when engine start: Temp. $\geq 10^{\circ}\text{C}$ (50°F)
	- Selector shock is large - Start is slow - Acceleration is slow	Engine coolant temperature when engine start: -35°C (-31°F) $\leq$ Temp. $< 10^{\circ}\text{C}$ (50°F)
	- Selector shock is large - Start is slow - Acceleration is slow	Engine coolant temperature when engine start: Temp. $< -35^{\circ}\text{C}$ (-31°F)
P0713	- Start is slow - Acceleration is slow	Engine coolant temperature when engine start: Temp. $\geq 10^{\circ}\text{C}$ (50°F)
	- Selector shock is large - Start is slow - Acceleration is slow	Engine coolant temperature when engine start: -35°C (-31°F) $\leq$ Temp. $< 10^{\circ}\text{C}$ (50°F)
	- Selector shock is large - Start is slow - Acceleration is slow	Engine coolant temperature when engine start: Temp. $< -35^{\circ}\text{C}$ (-31°F)
P0715	- Start is slow - Acceleration is slow - Lock-up is not performed	—
P0717	- Start is slow - Acceleration is slow - Lock-up is not performed	—
P0740	- Start is slow - Acceleration is slow - Lock-up is not performed	—
P0743	- Start is slow - Acceleration is slow - Lock-up is not performed	—
P0744	- Start is slow - Acceleration is slow - Lock-up is not performed	—
P0746	- Selector shock is large - Start is slow - Acceleration is slow - Lock-up is not performed	—

DTC	Vehicle behavior	Conditions of vehicle	
P0776	- Selector shock is large - Start is slow - Acceleration is slow - Lock-up is not performed - Vehicle speed is not increased	When a malfunction occurs on the low oil pressure side	A
	- Selector shock is large - Start is slow - Acceleration is slow - Lock-up is not performed	When a malfunction occurs on the high oil pressure side	B
P0778	- Selector shock is large - Start is slow - Acceleration is slow - Lock-up is not performed	—	C
P0779	- Selector shock is large - Start is slow - Acceleration is slow - Lock-up is not performed	—	TM
P0841	Not changed from normal driving	—	E
P0847	Not changed from normal driving	—	F
P0848	Not changed from normal driving	—	G
P084C	Not changed from normal driving	—	
P084D	Not changed from normal driving	—	
P0863	- Selector shock is large - Start is slow - Acceleration is slow - Lock-up is not performed	—	H
P0890	- Selector shock is large - Start is slow - Acceleration is slow - Lock-up is not performed - Vehicle speed is not increased	—	I
P0962	- Selector shock is large - Start is slow - Acceleration is slow - Lock-up is not performed	—	J
P0963	- Selector shock is large - Start is slow - Acceleration is slow - Lock-up is not performed	—	K
P0965	- Selector shock is large - Start is slow - Acceleration is slow - Lock-up is not performed	When a malfunction occurs on the low oil pressure side	L
	- Selector shock is large - Lock-up is not performed	When a malfunction occurs on the high oil pressure side	M
P0966	- Selector shock is large - Start is slow - Acceleration is slow - Lock-up is not performed	—	N
P0967	- Selector shock is large - Start is slow - Acceleration is slow - Lock-up is not performed	—	O
P1586	—	—	P
P1588	—	—	

DTC	Vehicle behavior	Conditions of vehicle
P2765	- Start is slow - Acceleration is slow - Lock-up is not performed	—
P2813	- Selector shock is large - Start is slow - Acceleration is slow - Vehicle speed is not increased	When a malfunction occurs on the low oil pressure side
	Selector shock is large	When a malfunction occurs on the high oil pressure side
P2814	Selector shock is large	—
P2815	Selector shock is large	—
U0073	- Selector shock is large - Start is slow - Acceleration is slow - Lock-up is not performed	—
U0100	- Selector shock is large - Start is slow - Acceleration is slow - Lock-up is not performed	—
U0140	Not changed from normal driving	—
U0141	Not changed from normal driving	—
U0155	Not changed from normal driving	—
U0300	- Selector shock is large - Start is slow - Acceleration is slow - Lock-up is not performed	—
U1000	Not changed from normal driving	—
U1117	Not changed from normal driving	—

Protection Control

INFOID:000000011519481

The TCM becomes the protection control status temporarily to protect the safety when the safety of TCM and transmission is lost. It automatically returns to the normal status if the safety is secured.

The TCM has the following protection control.

CONTROL FOR WHEEL SPIN

Control	When a wheel spin is detected, the engine output and gear ratio are limited and the line pressure is increased. Limits engine output when a wheel spin occurs in any of right and left drive wheels.
Vehicle behavior in control	If the accelerator is kept depressing during wheel spin, the engine revolution and vehicle speed are limited to a certain degree.
Normal return condition	Wheel spin convergence returns the control to the normal control.

TORQUE IS REDUCED WHEN DRIVING WITH THE REVERSE GEAR

Control	Engine output is controlled according to a vehicle speed while reversing the vehicle.
Vehicle behavior in control	Power performance may be lowered while reversing the vehicle.
Normal return condition	Torque returns to normal by positioning the selector lever in a range other than "R" position.

CONTROL WHEN FLUID TEMPERATURE IS HIGH

Control	When the CVT fluid temperature is high, the gear shift permission maximum revolution and the maximum torque are reduced than usual to prevent increase of the oil temperature.
Vehicle behavior in control	Power performance may be lowered, compared to normal control.
Normal return condition	The control returns to the normal control when CVT fluid temperature is lowered.

REVERSE PROHIBIT CONTROL

Control	The reverse brake is controlled to avoid becoming engaged when the selector lever is set in "R" position while driving in forward direction at more than the specified speed.
Vehicle behavior in control	If the selector lever is put at "R" position when driving with the forward gear, the gear becomes neutral, not reverse.
Normal return condition	The control returns to normal control when the vehicle is driven at low speeds. (The reverse brake becomes engaged.)

DTC Inspection Priority Chart

INFOID:0000000011519482

If multiple malfunction codes are detected at the same time, check each code according to the DTC check priority list below.

Priority	DTC (Diagnostic Trouble Code)	Reference
1	P0863 CONTROL UNIT (CAN)	TM-139, "DTC Logic"
	U0073 COMM BUS A OFF	TM-83, "DTC Logic"
	U0100 LOST COMM (ECM A)	TM-84, "DTC Logic"
	U0140 LOST COMM (BCM)	TM-85, "DTC Logic"
	U0141 LOST COMM (BCM A)	TM-86, "DTC Logic"
	U0155 LOST COMM (IPC)	TM-87, "DTC Logic"
	U0300 CAN COMM DATA	TM-88, "DTC Logic"
	U1000 CAN COMM CIRC	TM-89, "DTC Logic"
	U1117 LOST COMM (ABS)	TM-90, "DTC Logic"
2	P0740 TORQUE CONVERTER	TM-116, "DTC Logic"
	P0743 TORQUE CONVERTER	TM-118, "DTC Logic"
	P0778 PC SOLENOID B	TM-126, "DTC Logic"
	P0779 PC SOLENOID B	TM-128, "DTC Logic"
	P0962 PC SOLENOID A	TM-141, "DTC Logic"
	P0963 PC SOLENOID A	TM-143, "DTC Logic"
	P0966 PC SOLENOID B	TM-147, "DTC Logic"
	P0967 PC SOLENOID B	TM-149, "DTC Logic"
	P2814 SELECT SOLENOID	TM-161, "DTC Logic"
	P2815 SELECT SOLENOID	TM-163, "DTC Logic"

TCM

< ECU DIAGNOSIS INFORMATION >

[CVT: RE0F10J]

Priority	DTC (Diagnostic Trouble Code)	Reference
3	P062F EEPROM	TM-91, "DTC Logic"
	P0705 T/M RANGE SENSOR A	TM-92, "DTC Logic"
	P0706 T/M RANGE SENSOR A	TM-98, "DTC Logic"
	P0711 FLUID TEMP SENSOR A	TM-101, "DTC Logic"
	P0712 FLUID TEMP SENSOR A	TM-106, "DTC Logic"
	P0713 FLUID TEMP SENSOR A	TM-108, "DTC Logic"
	P0715 INPUT SPEED SENSOR A	TM-110, "DTC Logic"
	P0717 INPUT SPEED SENSOR A	TM-113, "DTC Logic"
	P0841 FLUID PRESS SEN/SW A	TM-130, "DTC Logic"
	P0847 FLUID PRESS SEN/SW B	TM-131, "DTC Logic"
	P0848 FLUID PRESS SEN/SW B	TM-133, "DTC Logic"
	P084C FLUID PRESS SEN/SW H	TM-135, "DTC Logic"
	P084D FLUID PRESS SEN/SW H	TM-137, "DTC Logic"
	P0890 TCM	TM-140, "DTC Logic"
	P1586 G SENSOR	TM-151, "DTC Logic"
	P1588 G SENSOR	TM-154, "DTC Logic"
	P2765 INPUT SPEED SENSOR B	TM-156, "DTC Logic"
4	P0744 TORQUE CONVERTER	TM-120, "DTC Logic"
	P0746 PC SOLENOID A	TM-122, "DTC Logic"
	P0776 PC SOLENOID B	TM-124, "DTC Logic"
	P0965 PC SOLENOID B	TM-145, "DTC Logic"
	P2813 SELECT SOLENOID	TM-159, "DTC Logic"

DTC Index

INFOID:0000000011519483

NOTE:

- If multiple malfunction codes are detected at the same time, check each code according to the "DTC check priority list". Refer to [TM-57, "DTC Inspection Priority Chart"](#).
- The ignition counter is displayed in "FFD". Refer to [TM-41, "CONSULT Function"](#).

DTC*1, *2		Items (CONSULT screen terms)	Trip	MIL*3	Perma- nent DTC group*4	Reference
GST	CONSULT (TRANSMISSION)					
P062F	P062F	EEPROM	1	ON	B	TM-91
P0705	P0705	T/M RANGE SENSOR A	2	ON	B	TM-92
P0706	P0706	T/M RANGE SENSOR A	2	ON	B	TM-98
P0711	P0711	FLUID TEMP SENSOR A	2	ON	A	TM-101
P0712	P0712	FLUID TEMP SENSOR A	2	ON	B	TM-106
P0713	P0713	FLUID TEMP SENSOR A	2	ON	B	TM-108
P0715	P0715	INPUT SPEED SENSOR A	2	ON	B	TM-110
P0717	P0717	INPUT SPEED SENSOR A	2	ON	B	TM-113
P0740	P0740	TORQUE CONVERTER	2	ON	B	TM-116
P0743	P0743	TORQUE CONVERTER	2	ON	B	TM-118
P0744	P0744	TORQUE CONVERTER	2	ON	B	TM-120
P0746	P0746	PC SOLENOID A	2	ON	B	TM-122
P0776	P0776	PC SOLENOID B	2	ON	B	TM-124
P0778	P0778	PC SOLENOID B	2	ON	B	TM-126

TCM

< ECU DIAGNOSIS INFORMATION >

[CVT: RE0F10J]

DTC*1, *2		Items (CONSULT screen terms)	Trip	MIL*3	Perma- nent DTC group*4	Reference
GST	CONSULT (TRANSMISSION)					
P0779	P0779	PC SOLENOID B	2	ON	B	TM-128
P0841	P0841	FLUID PRESS SEN/SW A	2	ON	B	TM-130
P0847	P0847	FLUID PRESS SEN/SW B	2	ON	B	TM-131
P0848	P0848	FLUID PRESS SEN/SW B	2	ON	B	TM-133
P084C	P084C	FLUID PRESS SEN/SW H	2	ON	B	TM-135
P084D	P084D	FLUID PRESS SEN/SW H	2	ON	B	TM-137
P0863	P0863	CONTROL UNIT (CAN)	1	ON	B	TM-139
P0890	P0890	TCM	1	ON	B	TM-140
P0962	P0962	PC SOLENOID A	2	ON	B	TM-141
P0963	P0963	PC SOLENOID A	2	ON	B	TM-143
P0965	P0965	PC SOLENOID B	2	ON	B	TM-145
P0966	P0966	PC SOLENOID B	2	ON	B	TM-147
P0967	P0967	PC SOLENOID B	2	ON	B	TM-149
—	P1586	G SENSOR	1	—	—	TM-151
—	P1588	G SENSOR	1	—	—	TM-154
P2765	P2765	INPUT SPEED SENSOR B	2	ON	B	TM-156
P2813	P2813	SELECT SOLENOID	2	ON	B	TM-159
P2814	P2814	SELECT SOLENOID	2	ON	B	TM-161
P2815	P2815	SELECT SOLENOID	2	ON	B	TM-163
U0073	U0073	COMM BUS A OFF	1	ON	B	TM-83
U0100	U0100	LOST COMM (ECM A)	1	ON	B	TM-84
—	U0140	LOST COMM (BCM)	1	—	—	TM-85
—	U0141	LOST COMM (BCM A)	1	—	—	TM-86
—	U0155	LOST COMM (IPC)	1	—	—	TM-87
—	U0300	CAN COMM DATA	1	—	—	TM-88
—	U1000	CAN COMM CIRC	1	—	—	TM-89
—	U1117	LOST COMM (ABS)	1	—	—	TM-90

*1: These numbers are specified by SAE J2012/ISO 15031-6.

*2: The DTC number of the 1st trip is the same as the DTC number.

*3: Refer to [TM-39, "DIAGNOSIS DESCRIPTION : Malfunction Indicator Lamp \(MIL\)"](#).

*4: Refer to [TM-82, "Description"](#).


< WIRING DIAGRAM >

WIRING DIAGRAM

CVT CONTROL SYSTEM

Wiring diagram

INFOID:000000011519484



*: This connector is not shown in "Harness Layout".


2014/07/25

JRDWC4105GB

CVT CONTROL SYSTEM

< WIRING DIAGRAM >

[CVT: RE0F10J]



JRDWC4106GB


CVT CONTROL SYSTEM

< WIRING DIAGRAM >

[CVT: RE0F10J]

CVT CONTROL SYSTEM

Connector No.	E4
Connector Name	WIRE TO WIRE
Connector Type	NH10MW-CS10




Terminal No.	Color Of Wire	Signal Name [Specification]
1	GR	-
2	GR	-
3	LG	-
4	P	-
5	L	-
6	R	-
7	W	-
8	B	-
9	SB	-
10	L	-
11	V	-
12	LG	-
13	V	-
14	LG	-
15	V	-
16	O	-
17	G	-
18	V	-
19	G	-
20	SB	-

Connector No.	E59
Connector Name	G SENSOR
Connector Type	HS03FB-2V



Terminal No.	Color Of Wire	Signal Name [Specification]
1	W	-
2	B	-
3	G	-

Connector No.	E6
Connector Name	WIRE TO WIRE
Connector Type	TK16MGY-1V



Terminal No.	Color Of Wire	Signal Name [Specification]
1	L	-
2	G	-
3	Y	-
4	V	-
5	GR	-
6	V	-
7	G	-
8	P	-
9	R	-
10	W	-
11	G	-
12	BR	-
13	SB	-
14	B	-
15	W	-
16	R	-

Connector No.	E11
Connector Name	RELAY-ILLUMINANT POWER DISTRIBUTION MODULE ENGINE ROOM
Connector Type	TH08FW-NH




Terminal No.	Color Of Wire	Signal Name [Specification]
40	P	-
41	B	-
42	SB	-
43	LG	-
44	W	-
45	Y	-
46	O	-

Connector No.	E15
Connector Name	STOP LAMP RELAY
Connector Type	MS02FL-3M2-LG




Terminal No.	Color Of Wire	Signal Name [Specification]
1	B/W	-
2	LG	-
3	R	-
5	P	-

Connector No.	E100
Connector Name	FUSE BLOCK (J/B)
Connector Type	NS18FW-CS



Terminal No.	Color Of Wire	Signal Name [Specification]
1	O	-
12F	V	-
1F	SB	-
2F	R	-
4F	L	-
6F	LG	-
8F	P	-
9F	BR	-

Connector No.	E104
Connector Name	WIRE TO WIRE
Connector Type	NH10FW-CS10



Terminal No.	Color Of Wire	Signal Name [Specification]
1	Y	-
2	GR	-
3	BR	-
4	L	-
5	LG	-
6	G	-
7	R	-
8	Y	-
9	L	-
10	L	-
11	P	-

CVT CONTROL SYSTEM

< WIRING DIAGRAM >

[CVT: RE0F10J]

CVT CONTROL SYSTEM


12	V	-
13	LG	-
15	V	-
16	W	-
17	W	-
18	GR	-
19	SB	-
20	V	-

Connector No.	E115
Connector Name	STOP LAMP SWITCH
Connector Type	MA4PW-LG



Terminal No.	Wire	Signal Name [Specification]
1	P	-
2	LG	-
3	O	-
4	W	-

Connector No.	F12
Connector Name	FROM ECU INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM
Connector Type	TH20PW-CS12-M4



Terminal No.	Wire	Signal Name [Specification]
48	W	-
49	R/B	-
51	LG	-
52	Y/G	-
53	R/W	-
54	G/W	-

Terminal No.	Wire	Signal Name [Specification]
2	LG	-
3	LG	-
4	BR/W	-
5	P/B	-
6	P/L	-
7	O/O	-
8	GR	-

Connector No.	F19
Connector Name	OUTPUT SPEED SENSOR
Connector Type	RK03FB




Terminal No.	Wire	Signal Name [Specification]
1	B	-
2	LG/R	-
3	Y	-

Connector No.	F21
Connector Name	INPUT SPEED SENSOR
Connector Type	RK03FB



Terminal No.	Wire	Signal Name [Specification]
1	B	-
2	BR	-
3	Y	-

Connector No.	F23
Connector Name	TCM
Connector Type	RH40EP-R23-L-RH



Terminal No.	Wire	Signal Name [Specification]
2	GR	L RANGE SW
3	GR	D RANGE SW
5	P/O	N RANGE SW
6	P/B	P RANGE SW
7	BR/W	S SENSOR GROUND
11	W/R	CVT FLUID TEMPERATURE SENSOR
12	V	G SENSOR
14	W	SECONDARY PRESSURE SENSOR
16	V/W	PRIMARY PRESSURE SENSOR
17	LG	CAN-L
23	P	INPUT SPEED SENSOR
24	BR	SENSOR POWER
26	L/O	LINE PRESSURE SOLENOID VALVE
30	R/Y	CAN-H
33	LG/R	OUTPUT SPEED SENSOR
35	LG	SELECT SOLENOID VALVE
37	L/W	TORQUE CONVERTER CLUTCH SOLENOID VALVE
38	V/R	SECONDARY PRESSURE SOLENOID VALVE
39	W/B	PRIMARY PRESSURE SOLENOID VALVE
40	B/R	GROUND
41	B	GROUND
42	B	BATTERY POWER SUPPLY
45	LG	BATTERY POWER SUPPLY
46	LG	IGNITION POWER SUPPLY
47	Y	IGNITION POWER SUPPLY
48	Y	IGNITION POWER SUPPLY


CVT CONTROL SYSTEM

< WIRING DIAGRAM >

[CVT: RE0F10J]

CVT CONTROL SYSTEM

Connector No.	F24
Connector Name	CVT UNIT
Connector Type	RK22FGY



Terminal No.	Color Of Wire	Signal Name [Specification]
1	B/W	-
2	B/R	-
3	G	-
4	B	-
5	L/O	-
6	R	-

Connector No.	F123
Connector Name	WIRE TO WIRE
Connector Type	TK18GY-TV




7	6	5	4	3	2	1
16	15	14	13	12	11	10
9	8	7	6	5	4	3
2	1	0	9	8	7	6

Terminal No.	Color Of Wire	Signal Name [Specification]
1	L	-
2	W	-
3	G/B	-
4	P/B	-
5	R	-
6	L/R	-
7	P	-
8	P	-
9	W/R	-
10	Y/B	-

11	B/W	-
12	B/R	-
13	G	-
14	B	-
15	L/O	-
16	R	-

Connector No.	F250
Connector Name	CVT UNIT
Connector Type	RK22MGY-X



Terminal No.	Color Of Wire	Signal Name [Specification]
1	-	-
2	-	-
3	-	-
4	-	-
5	-	-
6	-	-
7	-	-
8	-	-
9	-	-
10	-	-
11	-	-
12	-	-
13	-	-
14	-	-
15	-	-
16	-	-
17	-	-
18	-	-
19	-	-
20	-	-
21	-	-
22	-	-

Connector No.	F251
Connector Name	CONTROL VALVE
Connector Type	JP18FGY



1	2	3	4
5	6	7	8
9	10	11	12
13	14	15	16

Terminal No.	Color Of Wire	Signal Name [Specification]
1	GY	-
2	BR	-
3	Y	-
4	P	-
5	B	-
6	O	-
7	L	-
8	W	-
9	R	-
10	B/Y	-

Connector No.	M4
Connector Name	DATA LINK CONNECTOR
Connector Type	BD16FW



1	2	3	4	5	6	7	8
9	10	11	12	13	14	15	16

Terminal No.	Color Of Wire	Signal Name [Specification]
1	GY	-
2	BR	-
3	Y	-
4	P	-
5	B	-
6	O	-
7	L	-
8	W	-
9	R	-
10	B/Y	-

Connector No.	M7
Connector Name	FUSE BLOCK (J/B)
Connector Type	NS10FW-CS



1	2	3	4
5	6	7	8
9	10	11	12
13	14	15	16

Terminal No.	Color Of Wire	Signal Name [Specification]
1	W	-
2	W	-
3	BR	-
4	O	-
5	R/L	-
6	GR	-

Connector No.	M34
Connector Name	COMBINATION METER
Connector Type	TH40FW-NH



1	2	3	4	5	6	7	8
9	10	11	12	13	14	15	16
17	18	19	20	21	22	23	24
25	26	27	28	29	30	31	32

Terminal No.	Color Of Wire	Signal Name [Specification]
1	O	BATTERY POWER SUPPLY (With automatic drive position)
2	P	BATTERY POWER SUPPLY (Without automatic drive position)
3	G	IGNITION SIGNAL (With automatic drive position)
4	Y	IGNITION SIGNAL (Without automatic drive position)
5	B	GROUND
6	B	GROUND
7	B	GROUND
8	G	ENTER SWITCH SIGNAL (With automatic drive position)
9	SB	ENTER SWITCH SIGNAL (Without automatic drive position)
10	P	METER CONTROL SWITCH GROUND
11	G	ENTER SWITCH SIGNAL
12	BR	SELECT SWITCH SIGNAL (With automatic drive position)
13	R	SELECT SWITCH SIGNAL (Without automatic drive position)

JRDWC4109GB

CVT CONTROL SYSTEM

< WIRING DIAGRAM >

[CVT: RE0F10J]

A
B
C
TM
E
F
G
H
I
J
K
L
M
N
O
P

CVT CONTROL SYSTEM


13	W	ILLUMINATOR CONTROL (WITH SIGNAL 1) (With automatic drive position)
14	G	ILLUMINATOR CONTROL (WITH SIGNAL 1) (With automatic drive position)
15	V	ILLUMINATOR CONTROL (WITH SIGNAL 1) (With automatic drive position)
16	BR	AIR BAG SIGNAL
17	L	ENGINE COOLANT TEMPERATURE SIGNAL
18	L	AMBIENT SENSOR SIGNAL (With automatic drive position)
19	R	AMBIENT SENSOR SIGNAL (With automatic drive position)
20	G	A/C AUTO AMP CONNECTION RECOGNITION SIGNAL
21	Y	AMBIENT SENSOR GROUND (With automatic drive position)
22	L	CAN-H
23	P	CAN-L
24	B	GROUND
25	W	FUEL LEVEL SENSOR GROUND
26	BR	ALTERNATOR SIGNAL (With automatic drive position)
27	Y	A/T TEMPERATURE SIGNAL (With automatic drive position)
28	Y	PARKING BRAKE SWITCH SIGNAL
29	G	SECURITY SIGNAL
30	G	WASHER LEVEL SWITCH SIGNAL
31	SB	VEHICLE SPEED SIGNAL (8-PULSE)
32	P	OVERDRIVE CONTROL SWITCH SIGNAL
33	O	FUEL LEVEL SENSOR SIGNAL
34	BR	DRIFT DETECT (WITH SIGNAL 1) (With automatic drive position)
35	P	DRIFT DETECT (WITH SIGNAL 1) (With automatic drive position)
36	BR	PASSENGER SEAT BELT WARNING SIGNAL

Connector No.	M121
Connector Name	BCM (BODY CONTROL MODULE)
Connector Type	TH40FB-NH



Terminal No.	Color Of Wire	Signal Name [Specification]
1	W	REAR WINDOW DEF RELAY CONT
2	G	COMBI SW INPUT 1
3	G	COMBI SW INPUT 2
4	BE	COMBI SW INPUT 3
5	G	COMBI SW INPUT 4
6	W	COMBI SW INPUT 5
7	W	KEY CYL UNLOCK SW
8	GR	PW SW COMM (With auto A/C)
9	GR	KEY CYL LOCK SW (With manual A/C)
10	GR	STOP LAMP SW 1
11	GR	DOOR LK & UNLK SW LOCK
12	GR	DOOR LK & UNLK SW UNLOCK
13	BR	OPTICAL SENS
14	L	REAR WINDOW DEF SW
15	W	DRIVER'S SEAT BELT
16	Y	SECURITY SIGNAL
17	O	REAR WINDOW DEF SW
18	GR	REAR WINDOW DEF SW
19	GR	WATS ANT AMP
20	W	SECURITY IND CONT
21	B	DONGLE LINK
22	P	NATS ANT AMP
23	P	A/C ON
24	BR	BLOWER FAN ON
25	P	HAZARD SW
26	L	BL DOOR OPNR SW
27	G	DR DOOR UNLK SENS
28	R	COMBI SW OUTPUT 1
29	W	COMBI SW OUTPUT 2
30	W	COMBI SW OUTPUT 3
31	GR	COMBI SW OUTPUT 4
32	GR	COMBI SW OUTPUT 5
33	GR	DEFENT SW
34	BE	RECEIVER COMM
35	L	CAN-H
36	P	CAN-L

Connector No.	M57
Connector Name	CVT SHIFT SELECTOR
Connector Type	TH12FW-NH



Terminal No.	Color Of Wire	Signal Name [Specification]
1	W	—
2	W	—
3	W	—
4	W	—
5	W	—
6	W	—
7	W	—

CVT SHIFT LOCK SYSTEM


< WIRING DIAGRAM >

[CVT: RE0F10J]

CVT SHIFT LOCK SYSTEM

Wiring Diagram

INFOID:0000000011519485



CVT SHIFT LOCK SYSTEM

2014/07/25

JRDWC4111GB

CVT SHIFT LOCK SYSTEM

< WIRING DIAGRAM >

[CVT: RE0F10J]

CVT SHIFT LOCK SYSTEM


Connector No.	E100
Connector Name	FUSE BLOCK (J/B)
Connector Type	NS16FW-CS



16F	4F	2F	1F
16F	4F	2F	1F

Terminal No.	Color Of Wire	Signal Name [Specification]
1F	G	-
2F	SB	-
4F	R	-
6F	LG	-
8F	P	-
9F	BR	-

Connector No.	E105
Connector Name	WIRE TO WIRE
Connector Type	TH10FW-CS10-M3



Terminal No.	Color Of Wire	Signal Name [Specification]
1	SHIELD	-
2	W	-
3	B	-
4	R	-
6	LG	-
8	GR	-
9	V	-
10	BR	-
11	Y	-
12	O	-

13	W	-
14	L	-
15	P	-
31	GR	-
32	V	-
37	BR	-
38	G	-
39	P	-
40	V	-
41	L	-
42	LG	-
43	O	-
45	P	-
46	SB	-
47	V	-
48	L	-
51	SB	-
52	G	-
53	B	-
54	O	-
55	Y	-
56	SHIELD	-
61	P	-
62	G	-
63	W/L	-
64	W/R	-
66	W	-
67	Y	-
69	R	-
71	R	-
72	L	-
73	GR	-
74	Y	-
75	SB	-
76	Y	-
77	O	-
78	O	-
80	R	-
81	L	-
82	LG	-
83	R	-


Connector No.	E115
Connector Name	STOP LAMP SWITCH
Connector Type	M04FW-LC



3	4
1	2

Terminal No.	Color Of Wire	Signal Name [Specification]
1	P	-
2	O	-
4	W	-

Connector No.	M11
Connector Name	WIRE TO WIRE
Connector Type	TH10FW-CS10-M3



Terminal No.	Color Of Wire	Signal Name [Specification]
1	SHIELD	-
2	W	-
3	B	-
4	R	-
6	G	-
7	R	-
8	G	-
9	B	-
10	R	-
12	L	-
13	LG	-
14	L	-

15	P	-
31	L	-
32	LG	-
37	BR	- [With automatic drive positioner]
37	W	- [Without automatic drive positioner]
38	R	-
39	BE	- [Without automatic drive positioner]
39	Y	- [With automatic drive positioner]
40	P	-
41	L	-
42	G	-
43	W	-
45	P	-
46	V	-
47	R	-
48	G	-
51	G	-
52	W	-
53	B	-
54	LG	-
55	L	-
56	SHIELD	-
61	R	-
62	W	-
63	B	-
64	W	-
66	W	-
67	BR	-
69	P	-
71	R	-
72	L	-
73	LG	-
74	Y	-
75	Y	-
76	V	-
77	P	-
78	BR	-
80	Y	-
81	W	-
82	L	-
83	R	-

JRDWC4112GB

A
B
C
TM
E
F
G
H
I
J
K
L
M
N
O
P


CVT SHIFT LOCK SYSTEM

< WIRING DIAGRAM >

[CVT: RE0F10J]

CVT SHIFT LOCK SYSTEM

Connector No.	M57
Connector Name	CVT SHIFT SELECTOR
Connector Type	TH12FN-NH



Terminal No.	Color Of Wire	Signal Name [Specification]
1	P	-
4	B	-
6	W	-
7	B	-
8	BE	-
9	G	-

BASIC INSPECTION

DIAGNOSIS AND REPAIR WORK FLOW

Flowchart of Trouble Diagnosis

INFOID:0000000011519486

NOTE:

"DTC" includes DTC at the 1st trip.

1.OBTAIN INFORMATION ABOUT SYMPTOM

Refer to [TM-70. "Question sheet"](#) and interview the customer to obtain the malfunction information (conditions and environment when the malfunction occurred) as much as possible when the customer brings in the vehicle.

>> GO TO 2.

2.CHECK DTC

1. Before checking the malfunction, check whether any DTC exists.
2. If DTC exists, perform the following operations.
 - Records the DTCs. (Print out using CONSULT and affix to the Work Order Sheet.)
 - Erase DTCs.
 - Check the relation between the cause found by DTC and the malfunction information from customer. [TM-174. "Symptom Table"](#) can be used effectively.
3. Check the relevant information including STI, etc.

Do malfunction information and DTC exist?

Malfunction information and DTC exist.>>GO TO 3.

Malfunction information exists but no DTC.>>GO TO 4.

No malfunction information, but DTC exists.>>GO TO 5.

3.REPRODUCE MALFUCTION SYSTEM

Check the malfunction described by the customer on the vehicle.

Check if the behavior is fail safe or normal operation. Refer to [TM-53. "Fail-safe"](#).

Interview sheet can be used effectively when reproduce malfunction conditions. Refer to [TM-70. "Question sheet"](#).

Verify the relationship between the symptom and the conditions in which the malfunction described by the customer occurs.

>> GO TO 5.

4.REPRODUCE MALFUNCTION SYMPTOM

Check the malfunction described by the customer on the vehicle.

Check if the behavior is fail safe or normal operation. Refer to [TM-53. "Fail-safe"](#).

Interview sheet can be used effectively when reproduce malfunction conditions. Refer to [TM-70. "Question sheet"](#).

Verify the relationship between the symptom and the conditions in which the malfunction described by the customer occurs.

>> GO TO 6.

5.PERFORM "DTC CONFIRMATION PROCEDURE"

Perform "DTC CONFIRMATION PROCEDURE" of the appropriate DTC to check if DTC is detected again.

Refer to [TM-57. "DTC Inspection Priority Chart"](#) when multiple DTCs are detected, and then determine the order for performing the diagnosis.

Is any DTC detected?

YES >> GO TO 7.

NO >> Follow [GI-42. "Intermittent Incident"](#) to check.

6.IDENTIFY MALFUNCTIONING SYSTEM WITH "DIAGNOSIS CHART BY SYMPTOM"

DIAGNOSIS AND REPAIR WORK FLOW

< BASIC INSPECTION >

[CVT: RE0F10J]

Use [TM-174, "Symptom Table"](#) from the symptom inspection result in step 4. Then identify where to start performing the diagnosis based on possible causes and symptoms.

>> GO TO 8.

7. REPAIR OR REPLACE THE MALFUNCTIONING PARTS

Repair or replace the detected malfunctioning parts.

Reconnect parts or connector after repairing or replacing, and then erase DTC if necessary.

>> GO TO 8.

8. FINAL CHECK

Perform "DTC CONFIRMATION PROCEDURE" again to make sure that the repair is correctly performed. Check that malfunctions are not reproduced when obtaining the malfunction information from the customer, referring to the symptom inspection result in step 3 or 4.

Is DTC or malfunction symptom reproduced?

YES-1 (DTC is reproduced.)>>GO TO 5.

YES-2 (Malfunction is reproduced.)>>GO TO 6.

NO >> Before delivering the vehicle to the customer, make sure that DTC is erased.

Question sheet

INFOID:0000000011519487

DESCRIPTION

There are many operating conditions that may cause a malfunction of the transmission parts. By understanding those conditions properly, a quick and exact diagnosis can be achieved.

In general, perception of a problem varies depending on individuals. Ask the customer about his/her concerns carefully. It is important to understand the phenomenon or status. To systemize all the information for the diagnosis, prepare the question sheet referring to the question points.

In some cases, multiple conditions that appear simultaneously may cause a DTC to be detected.

KEY POINTS

WHAT Vehicle & engine model
WHEN Date, Frequencies
WHERE..... Road conditions
HOW Operating conditions,
Weather conditions,
Symptoms

SEF907L

Worksheet Sample

Question sheet						
Customer's name	MR/MS	Registration number		Initial year registration	Year	Month day
		Vehicle type		Chassis No.		
Storage date	Year	Month day	Engine	Mileage		km/mile
Symptom			☐ Vehicle does not start. (☐ R position ☐ D position ☐ L position ☐ M position)			
			☐ Upshifting does not occur. ☐ Downshifting does not occur.			
			☐ Lock-up malfunction			
			☐ Shift point is too high. ☐ Shift point is too low.			
			☐ Shift shock (☐ N⇒D ☐ Lock-up ☐ R, D, L and M position)			
			☐ Slip (☐ N⇒D ☐ Lock-up ☐ R, D, L and M position)			
			☐ Noise ☐ Vibration			
			When selector lever position is shifted, shift pattern does not change.			
			☐ Other ()			
First occurrence			☐ Recently (as from month of year)			
Frequency of occurrence			☐ Always ☐ Under certain conditions ☐ Sometimes (time(s)/day)			

DIAGNOSIS AND REPAIR WORK FLOW

< BASIC INSPECTION >

[CVT: RE0F10J]

Question sheet					
Customer's name	MR/MS	Registration number		Initial year registration	Year Month day
		Vehicle type		Chassis No.	
Storage date	Year Month day	Engine		Mileage	km/mile
Climate conditions		Irrelevant			
		☐ Clear ☐ Cloud ☐ Rain ☐ Snow ☐ Others)			
		☐ Hot ☐ Warm ☐ Cool ☐ Cold ☐ Temperature (Approx. °C/°F)			
		☐ High ☐ Moderate ☐ Low			
Transaxle condition		☐ In cold-start ☐ During warm-up (approx. °C/°F) ☐ After warm-up ☐ Engine speed: rpm			
Road conditions		☐ Urban area ☐ Suburb area ☐ Highway ☐ Mountainous road (uphill or downhill)			
Operating condition, etc.		Irrelevant ☐ When engine starts ☐ During idling ☐ During driving ☐ During acceleration ☐ At constant speed driving ☐ During deceleration ☐ During cornering (RH curve or LH curve)			
Other conditions					

A
B
C
TM
E
F
G
H
I
J
K
L
M
N
O
P

ADDITIONAL SERVICE WHEN REPLACING TCM

Description

INFOID:0000000011552526

Always perform the following items when the TCM is replaced.

TCM PROGRAMMING

- Since vehicle specifications are not yet written in a new TCM, it is necessary to write them with CONSULT.

CAUTION:

When replacing TCM, save TCM data on CONSULT before removing TCM.

SAVING AND WRITING OF TCM DATA

- TCM performs accurate control by retrieving data (inherent characteristic value) of each solenoid. For this reason, it is necessary to save data of current TCM in CONSULT before replacing the TCM. After this, the saved data must be written in new TCM.

Work Procedure

INFOID:0000000011552527

1.SAVE TCM DATA (IP CHARACTERISTICS VALUE)

NOTE:

Save necessary data stored in TCM in CONSULT according to the following instructions:

With CONSULT

1. Turn ignition switch OFF.
2. Connect all of disconnected connectors.
3. Turn ignition switch ON.
4. Select "Work Support" in "TRANSMISSION".
5. Select "READ IP CHARA - REPLACEMENT TCM".
6. Import data according to the instructions on the CONSULT screen.

>> GO TO 2.

2.SAVE TCM DATA (VEHICLE SPECIFICATIONS)

NOTE:

Save necessary data stored in TCM in CONSULT according to the following instructions:

With CONSULT

1. Turn ignition switch OFF.
2. Turn ignition switch ON.
3. Select "Re/programming, Configuration".
4. Select "AT/CVT".

NOTE:

If "AT/CVT" is not displayed and TCM data cannot be saved on CONSULT, GO TO 3.

5. Select "Programming".
6. Save TCM data on CONSULT according to the CONSULT display.

>> GO TO 3.

3.REPLACE TCM

1. Turn ignition switch OFF and wait for 10 seconds.
2. Replace TCM. Refer to [TM-190, "Removal and Installation"](#).

>> GO TO 4.

4.WRITE TCM DATA (VEHICLE SPECIFICATIONS)

NOTE:

Write data saved in CONSULT into a new TCM according to the following instructions:

With CONSULT

1. Select "Programming".
2. Perform programming according to the CONSULT display.

ADDITIONAL SERVICE WHEN REPLACING TCM

< BASIC INSPECTION >

[CVT: RE0F10J]

>> GO TO 5.

5.WRITE TCM DATA (IP CHARACTERISTICS VALUE)

NOTE:

Write data saved in CONSULT into a new TCM according to the following instructions:

With CONSULT

1. Turn ignition switch OFF and wait for 10 seconds.
2. Turn ignition switch ON.
3. Select "Work Support" in "TRANSMISSION".
4. Select "WRITE IP CHARA - REPLACEMENT TCM".
5. Write data saved in CONSULT in TCM according to the instructions on the CONSULT screen.

>> WORK END

A

B

C

TM

E

F

G

H

I

J

K

L

M

N

O

P

ADDITIONAL SERVICE WHEN REPLACING TRANSAXLE ASSEMBLY

< BASIC INSPECTION >

[CVT: RE0F10J]

ADDITIONAL SERVICE WHEN REPLACING TRANSAXLE ASSEMBLY

Description

INFOID:000000011552528

Perform the following work after the transaxle assembly is replaced.

WRITING TCM DATA

- TCM performs accurate control by retrieving data (inherent characteristic value) of each solenoid. For this reason, after replacing transaxle assembly, it is necessary to write new data in TCM.

ERASING OF CVT FLUID DEGRADATION LEVEL DATA


- TCM records the degradation level of the CVT fluid calculated from the vehicle driving status. Therefore, if the transaxle assembly is replaced, it is necessary to erase the CVT fluid degradation level data recorded by TCM.

Work Procedure

INFOID:000000011552529

1.CHECK THE SERIAL NUMBER

Write down the serial number of new transaxle assembly.



>> GO TO 2.

2.WRITE TCM DATA (IP CHARACTERISTICS VALUE)

NOTE:

Write data of new solenoid in TCM according to the following instructions:

With CONSULT

CAUTION:

When the work is interrupted, obtain data again from the supplied CD.

1. Shift the selector lever to the P position.
2. Turn ignition switch OFF and wait for 10 seconds.
3. Turn ignition switch ON.
4. Insert the supplied CD into CONSULT.
5. Select "Work Support" in "TRANSMISSION".
6. Select "WRITE IP CHARA - REPLACEMENT AT/CVT".
7. Check that the serial number displayed on CONSULT screen and those written in the memo agree.
8. Write data in TCM according to the instructions on the CONSULT screen.

NOTE:

When writing is complete, the shift position indicator of the combination meter displays P.

>> GO TO 3.

3.ERASE CVT FLUID DEGRADATION LEVEL DATA

ADDITIONAL SERVICE WHEN REPLACING TRANSAXLE ASSEMBLY

< BASIC INSPECTION >

[CVT: RE0F10J]

 With CONSULT

1. Select "WORK SUPPORT" in "TRANSMISSION".
2. Select "CONFORM CVTF DETERIORTN".
3. Touch "Clear".

>> WORK END

A
B
C
E
F
G
H
I
J
K
L
M
N
O
P

TM

ADDITIONAL SERVICE WHEN REPLACING TCM AND TRANSAXLE ASSEMBLY

< BASIC INSPECTION >

[CVT: RE0F10J]

ADDITIONAL SERVICE WHEN REPLACING TCM AND TRANSAXLE ASSEMBLY

Description

INFOID:0000000011552530

When replacing TCM and transaxle assembly as a set, perform the following work.

TCM PROGRAMMING

- Since vehicle specifications are not yet written in a new TCM, it is necessary to write them with CONSULT.

CAUTION:

When replacing TCM, save TCM data on CONSULT before removing TCM.

WRITING TCM DATA

- TCM performs accurate control by retrieving data (inherent characteristic value) of each solenoid. For this reason, after replacing TCM and transaxle assembly, it is necessary to write new data in TCM.

Work Procedure

INFOID:0000000011552531

1. SAVE TCM DATA (VEHICLE SPECIFICATIONS)

With CONSULT

- Turn ignition switch OFF.
- Connect all of disconnected connectors.
- Turn ignition switch ON.
- Select "Re/programming, Configuration".
- Select "AT/CVT".

NOTE:

If "AT/CVT" is not displayed and TCM data cannot be saved on CONSULT, GO TO 2.

- Select "Programming".
- Save TCM data on CONSULT according to the CONSULT display.


>> GO TO 2.

2. REPLACE TCM AND TRANSAXLE ASSEMBLY

- Turn ignition switch OFF and wait for 10 seconds.
- Replace TCM and transaxle assembly. Refer to [TM-190. "Removal and Installation"](#) (TCM), [TM-213. "Removal and Installation"](#) (Transaxle assembly).

CAUTION:

Write down the serial number of new transaxle assembly.



JSDIA6075GB

>> GO TO 3.

ADDITIONAL SERVICE WHEN REPLACING TCM AND TRANSAXLE ASSEMBLY

< BASIC INSPECTION >

[CVT: RE0F10J]

3.WRITE TCM DATA (VEHICLE SPECIFICATIONS)

NOTE:

Write data saved in CONSULT into a new TCM according to the following instructions:

With CONSULT

1. Select "Programming".
2. Perform programming according to the CONSULT display.

>> GO TO 4.

4.WRITE TCM DATA (IP CHARACTERISTICS VALUE)

NOTE:

Write data of new solenoid in TCM according to the following instructions:

With CONSULT

CAUTION:

When the work is interrupted, obtain data again from the supplied CD.

1. Shift the selector lever to the P position.
2. Turn ignition switch OFF and wait for 10 seconds.
3. Turn ignition switch ON.
4. Insert the supplied CD into CONSULT.
5. Select "Work Support" in "TRANSMISSION".
6. Select "WRITE IP CHARA - REPLACEMENT AT/CVT".
7. Check that the serial number displayed on CONSULT screen and those written in the memo agree.
8. Write data in TCM according to the instructions on the CONSULT screen.

NOTE:

When writing is complete, the shift position indicator of the combination meter displays P.

>> WORK END

A

B

C

TM

E

F

G

H

I

J

K

L

M

N

O

P

CALIBRATION OF G SENSOR

Description

INFOID:0000000011552522

TCM stores calibration data (inherent characteristic value) of G sensor to provide accurate control. Therefore, it is required to perform calibration of G sensor after the following work is performed.

- Removal/installation or replacement of G sensor
- Replacement of TCM
- Replacement of control valve
- Replacement of transaxle assembly
- Erasing the calibration data of TCM

Work Procedure

INFOID:0000000011552523

1. PREPARATION BEFORE CALIBRATION PROCEDURE

1. Park the vehicle on a level surface.
2. Adjust air pressure of all tires to the specified pressure. Refer to [WT-50, "Tire Air Pressure"](#).

>> GO TO 2.

2. PERFORM CALIBRATION

 With CONSULT

1. Turn ignition switch ON.
- CAUTION:**
Never start engine.
2. Select "Work Support" in "TRANSMISSION".
3. Select "G SENSOR CALIBRATION".
4. Touch "Start".

CAUTION:
Never swing the vehicle during "G sensor calibration".

Is "COMPLETED" displayed?

- YES >> GO TO 3.
NO >> Perform steps 1 and 2 again.

3. PERFORM THE SELF-DIAGNOSIS

 With CONSULT

1. Turn ignition switch OFF and wait for 10 seconds.
2. Turn ignition switch ON.
3. Select "Self Diagnostic Results" in "TRANSMISSION".

Is "P1585" detected?

- YES >> Go to [TM-58, "DTC Index"](#).
NO >> Calibration end

IDLE NEUTRAL CONTROL LEARNING

Description

INFOID:0000000011552524

TCM corrects an individual difference in clutch clearance of the transaxle assembly by performing the idle neutral control learning and enables accurate idle neutral control.

Therefore, it is required to perform idle neutral control learning after the following work is performed.

- Replacement of TCM
- Replacement of transaxle assembly

Work Procedure

INFOID:0000000011552525

1. PREPARATION BEFORE WORK

TM

 With CONSULT

1. Start the engine.

CAUTION:

Never drive the vehicle.

2. Select "DATA MONITOR" in "TRANSMISSION."
3. Select "FLUID TEMP."

Is "FLUID TEMP" 20°C (68°F) or more?

YES >> GO TO 2.

NO >> 1. Warm up the transaxle assembly until "FLUID TEMP" reaches 20°C(68°F) or more.

2. GO TO 2.

2. PERFORM IDLE NEUTRAL CONTROL LEARNING

CAUTION:

Perform this work with the flat road. ($\pm 2.6\%$ or less)

1. Shift the selector lever to "D" position.
2. Drive the vehicle at the 8 km/h (5 MPH) or more.
3. Brake pedal is depressed and stop the vehicle.
4. Maintain the following conditions for 30 seconds or more.

Stop lamp switch : ON

Accelerator pedal position sensor : OFF

Engine speed : 475 – 700 rpm

Electrical load : Not applied*

*: Rear window defogger switch, air conditioner switch, lighting switch, etc. are OFF. Steering wheel is straight ahead. (Parking lamp ON is possible)

5. Brake pedal is released and drive the vehicle.
6. Perform steps 1 and 2 again. (one time)

>> INSPECTION END

STALL TEST

< BASIC INSPECTION >

[CVT: RE0F10J]

STALL TEST

Work Procedure

INFOID:0000000011519496

INSPECTION

1. Check the engine oil level. Replenish if necessary. Refer to [LU-8, "Inspection"](#).
2. Check for leak of the CVT fluid. Refer to [TM-178, "Inspection"](#).
3. Drive for about 10 minutes to warm up the vehicle so that the CVT fluid temperature is 50 to 80°C (122 to 176°F).
4. Be sure to apply the parking brake and block the tires.
5. Start the engine, depress the brake pedal and put the selector lever to the D position.
6. While depressing the brake pedal, depress the accelerator pedal gradually.
7. Read the stall speed quickly. Then, release your foot from the accelerator pedal quickly.

CAUTION:

Do not depress the accelerator pedal for 5 seconds or more during the test.

Stall speed : Refer to [TM-220, "Stall Speed"](#).

8. Place the selector lever in the N position.
9. Cool the CVT fluid.
- CAUTION:**
Run the engine with the idle speed for at least 1 minute.
10. Put the selector lever to the R position and perform Step 6 to Step 9 again.

NARROWING-DOWN MALFUNCTIONING PARTS

	Selector lever position		Possible cause
	D	R	
Stall speed	H	O	• Forward clutch
	O	H	• Reverse brake
	L	L	• Engine • Torque converter one way clutch
	H	H	• Line pressure is low. • Primary pulley • Secondary pulley • Steel belt

O: Within the stall speed standard value.

H: Stall speed is higher than the standard value.

L: Stall speed is lower than the standard value.

CVT POSITION

Inspection and Adjustment


INFOID:000000011322868

INSPECTION

1. Turn ignition switch ON (engine stop) when selector lever is "P" position.
2. Check that selector lever can be shifted to other than "P" position when brake pedal is depressed. Also check that selector lever can be shifted from "P" position only when brake pedal is depressed.
3. Shift the selector lever and check for excessive effort, sticking, noise or rattle.
4. Check that selector lever stops at each position with the feel of engagement when it is moved through all the positions. Check that the actual position of selector lever matches the position shown by shift position indicator and manual lever on the transaxle.
5. The method of operating selector lever to individual positions correctly should be as shown.
6. When selector button is pressed in "P", "R", "N", "D" or "L" position without applying forward/backward force to selector lever, check button operation for sticking.
7. Check that back-up lamps illuminate only when selector lever is placed in the "R" position.
8. When in "R" position, check that back-up lamps do not illuminate even when the selector lever is in the "P" position.


CAUTION:**Check the lighting without pressing shift button.**

9. Check that back-up lamps do not illuminate when selector lever is pushed toward the "R" position when in the "P" or "N" position.
10. Check that the engine can only be started with selector lever in the "P" and "N" positions.
11. Check that transaxle is locked completely in "P" position.



ADJUSTMENT

1. Shift the shift selector to the "P" position.
2. Loosen the control cable nut (A) and set manual lever (B) the "P" position.
3. Position the manual lever in the "P" position.
4. Tighten the control cable nut to specified torque. Refer to [TM-188, "Exploded View"](#).

CAUTION:**Do not apply force to the manual lever.****CAUTION:****Hold manual lever securely in the "P" position when tightening control cable nut (A).**

HOW TO ERASE PERMANENT DTC

Description

INFOID:0000000011519499

Permanent DTC can be erased by driving each driving pattern. ECM recognizes each driving pattern; it transmits signals to each control module when the driving is complete. Each control module erases permanent DTC based on those signals. For details, refer to [EC-158, "Description"](#).

U0073 COMMUNICATION BUS A OFF

< DTC/CIRCUIT DIAGNOSIS >

[CVT: RE0F10J]

DTC/CIRCUIT DIAGNOSIS

U0073 COMMUNICATION BUS A OFF

DTC Logic

INFOID:0000000011519500

DTC DETECTION LOGIC

DTC	CONSULT screen terms (Trouble diagnosis content)	DTC detection condition	Possible causes
U0073	COMM BUS A OFF (Control Module Communica- tion Bus A Off)	TCM communication blockage lasts for 2 sec- onds or more when turning ON the ignition switch. (Communication not established.)	Harness or connector (CAN communication line is error)

DTC CONFIRMATION PROCEDURE

1.PREPARATION BEFORE WORK

If another "DTC CONFIRMATION PROCEDURE" occurs just before, turn ignition switch OFF and wait for at least 10 seconds, then perform the next test.

>> GO TO 2.

2.PERFORM DTC CONFIRMATION PROCEDURE

1. Start the engine and wait for at least 5 seconds.
2. Check the DTC.

Is "U0073" detected?

- YES >> Go to [TM-83, "Diagnosis Procedure"](#).
NO >> INSPECTION END

Diagnosis Procedure

INFOID:0000000011519501

For the diagnosis procedure, refer to [LAN-17, "Trouble Diagnosis Flow Chart"](#).

U0100 LOST COMMUNICATION (ECM A)

< DTC/CIRCUIT DIAGNOSIS >

[CVT: RE0F10J]

U0100 LOST COMMUNICATION (ECM A)

DTC Logic

INFOID:0000000011519502

DTC DETECTION LOGIC

DTC	CONSULT screen terms (Trouble diagnosis content)	DTC detection condition	Possible causes
U0100	LOST COMM (ECM A) (Lost Communication With ECM/PCM A)	When the ignition switch is ON, TCM is unable to receive the CAN communications signal from ECM continuously for 2 seconds or more.	- ECM - Harness or connector (CAN communication line is open or shorted)

DTC CONFIRMATION PROCEDURE

1. PREPARATION BEFORE WORK

If another "DTC CONFIRMATION PROCEDURE" occurs just before, turn ignition switch OFF and wait for at least 10 seconds, then perform the next test.

>> GO TO 2.

2. PERFORM DTC CONFIRMATION PROCEDURE

1. Start the engine and wait for at least 5 seconds.
2. Check the DTC.

Is "U0100" detected?

YES >> Go to [TM-84, "Diagnosis Procedure"](#).
NO >> INSPECTION END

Diagnosis Procedure

INFOID:0000000011519503

For the diagnosis procedure, refer to [LAN-17, "Trouble Diagnosis Flow Chart"](#).

U0140 LOST COMMUNICATION (BCM)

< DTC/CIRCUIT DIAGNOSIS >

[CVT: RE0F10J]

U0140 LOST COMMUNICATION (BCM)

DTC Logic

INFOID:0000000011519504

DTC DETECTION LOGIC

DTC	CONSULT screen terms (Trouble diagnosis content)	DTC detection condition	Possible causes
U0140	LOST COMM (BCM) (Lost Communication With Body Control Module)	When the ignition switch is ON, TCM is unable to receive the CAN communications signal from BCM continuously for 2 seconds or more.	• BCM • Harness or connector (CAN communication line is open or shorted)

DTC CONFIRMATION PROCEDURE

1. PREPARATION BEFORE WORK

If another "DTC CONFIRMATION PROCEDURE" occurs just before, turn ignition switch OFF and wait for at least 10 seconds, then perform the next test.

>> GO TO 2.

2. PERFORM DTC CONFIRMATION PROCEDURE

With CONSULT

1. Start the engine and wait for at least 5 seconds.
2. Check the DTC.

Is "U0140" detected?

- YES >> Go to [TM-85, "Diagnosis Procedure"](#).
NO >> INSPECTION END

Diagnosis Procedure

INFOID:0000000011519505

For the diagnosis procedure, refer to [LAN-17, "Trouble Diagnosis Flow Chart"](#).

U0141 LOST COMMUNICATION (BCM A)

< DTC/CIRCUIT DIAGNOSIS >

[CVT: RE0F10J]

U0141 LOST COMMUNICATION (BCM A)

DTC Logic

INFOID:0000000011519506

DTC DETECTION LOGIC

DTC	CONSULT screen terms (Trouble diagnosis content)	DTC detection condition	Possible causes
U0141	LOST COMM (BCM A) (Lost Communication With Body Control Module A)	When the ignition switch is turned ON, TCM continues no reception of the CAN communi- cation signal from IPDM E/R for 2 seconds or more.	• IPDM E/R • Harness or connector (CAN communication line is open or shorted)

DTC CONFIRMATION PROCEDURE

1. PREPARATION BEFORE WORK

If another "DTC CONFIRMATION PROCEDURE" occurs just before, turn ignition switch OFF and wait for at least 10 seconds, then perform the next test.

>> GO TO 2.

2. PERFORM DTC CONFIRMATION PROCEDURE

With CONSULT

1. Start the engine and wait for at least 5 seconds.
2. Check the DTC.

Is "U0141" detected?

- YES >> Go to [TM-86, "Diagnosis Procedure"](#).
NO >> INSPECTION END

Diagnosis Procedure

INFOID:0000000011519507

For the diagnosis procedure, refer to [LAN-17, "Trouble Diagnosis Flow Chart"](#).

U0155 LOST COMMUNICATION (IPC)

< DTC/CIRCUIT DIAGNOSIS >

[CVT: RE0F10J]

U0155 LOST COMMUNICATION (IPC)

DTC Logic

INFOID:0000000011519508

DTC DETECTION LOGIC

DTC	CONSULT screen terms [Trouble diagnosis content]	DTC detection condition	Possible causes
U0155	LOST COMM (IPC) [Lost Communication With Instrument Panel Cluster (IPC) Control Module]	When the ignition switch is ON, TCM is unable to receive the CAN communications signal from the combination meter continuously for 2 seconds or more.	- Combination meter - Harness or connector (CAN communication line is open or shorted)

A
B
C
TM

DTC CONFIRMATION PROCEDURE

1. PREPARATION BEFORE WORK

If another "DTC CONFIRMATION PROCEDURE" occurs just before, turn ignition switch OFF and wait for at least 10 seconds, then perform the next test.

>> GO TO 2.

2. PERFORM DTC CONFIRMATION PROCEDURE

- Start the engine and wait for at least 5 seconds.
- Check the DTC.

Is "U0155" detected?

- YES >> Go to [TM-87, "Diagnosis Procedure"](#).
NO >> INSPECTION END

Diagnosis Procedure

INFOID:0000000011519509

For the diagnosis procedure, refer to [LAN-17, "Trouble Diagnosis Flow Chart"](#).

J
K
L
M
N
O
P

U0300 CAN COMMUNICATION DATA

< DTC/CIRCUIT DIAGNOSIS >

[CVT: RE0F10J]

U0300 CAN COMMUNICATION DATA

DTC Logic

INFOID:0000000011519510

DTC DETECTION LOGIC

DTC	CONSULT screen terms (Trouble diagnosis content)	DTC detection condition	Possible causes
U0300	CAN COMM DATA (Internal Control Module Software Incompatibility)	When the ignition switch is ON, the data length transmitted from each control unit is shorter than the specified length and the status continues for 2 seconds or more.	Control unit other than TCM

DTC CONFIRMATION PROCEDURE

1. PREPARATION BEFORE WORK

If another "DTC CONFIRMATION PROCEDURE" occurs just before, turn ignition switch OFF and wait for at least 10 seconds, then perform the next test.

>> GO TO 2.

2. CHECK DTC DETECTION

With CONSULT

1. Start the engine and wait for 5 seconds or more.
2. Check the DTC.

Is "U0300" detected?

- YES >> Go to [TM-88, "Diagnosis Procedure"](#).
NO >> INSPECTION END

Diagnosis Procedure

INFOID:0000000011519511

1. CONTROL UNIT CHECK

Check the number of control units replaced before "U0300" is detected.

Is one control unit replaced?

- YES >> The specification of the control unit replaced may be incorrect. Check the part number and the specification.
NO >> GO TO 2.

2. CONTROL UNIT CHECK

With CONSULT

1. Remove one of the control unit replaced.
2. Assemble the old control unit before replacement.
3. Turn ignition switch ON, and wait for 2 seconds or more.
4. Select "Self Diagnostic Results" in "TRANSMISSION".

Is "U0300" detected?

- YES >> Turn OFF the ignition switch and check other control units in the same manner.
NO >> The specification of the control unit removed may be incorrect. Check the part number and the specification.

U1000 CAN COMM CIRCUIT

Description

INFOID:0000000011519512

CAN (Controller Area Network) is a serial communication line for real-time application. It is an on-vehicle multiplex communication line with high data communication speed and excellent malfunction detection ability. Many electronic control units are equipped onto a vehicle, and each control unit shares information and links with other control units during operation (not independently). In CAN communication, control units are connected with 2 communication lines (CAN-H line, CAN-L line) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads required data only.

DTC Logic

INFOID:0000000011519513

DTC DETECTION LOGIC

DTC	CONSULT screen terms (Trouble diagnosis content)	DTC detection condition	Possible causes
U1000	CAN COMM CIRCUIT (CAN Communication Line)	When the ignition switch is ON, TCM cannot send the CAN communication signal continuously for 2 seconds or more.	Harness or connector (CAN communication line is open or shorted)

DTC CONFIRMATION PROCEDURE

1. PREPARATION BEFORE WORK

If another "DTC CONFIRMATION PROCEDURE" occurs just before, turn ignition switch OFF and wait for at least 10 seconds, then perform the next test.

>> GO TO 2.

2. CHECK DTC DETECTION

With CONSULT

1. Start the engine and wait for at least 5 seconds.
2. Check the DTC.

Is "U1000" detected?

- YES >> Go to [TM-89, "Diagnosis Procedure"](#).
NO >> INSPECTION END

Diagnosis Procedure

INFOID:0000000011519514

For the diagnosis procedure, refer to [LAN-17, "Trouble Diagnosis Flow Chart"](#).

U1117 LOST COMMUNICATION (ABS)

< DTC/CIRCUIT DIAGNOSIS >

[CVT: RE0F10J]

U1117 LOST COMMUNICATION (ABS)

DTC Logic

INFOID:0000000011519515

DTC DETECTION LOGIC

DTC	CONSULT screen terms (Trouble diagnosis content)	DTC detection condition	Possible causes
U1117	LOST COMM (ABS) (Lost Communication With ABS)	When the ignition switch is ON, TCM is unable to receive the CAN communications signal from ABS actuator and electric unit (control unit) continuously for 2 seconds or more.	• ABS actuator and electric unit (control unit) • Harness or connector (CAN communication line is open or shorted)

DTC CONFIRMATION PROCEDURE

1. PREPARATION BEFORE WORK

If another "DTC CONFIRMATION PROCEDURE" occurs just before, turn ignition switch OFF and wait for at least 10 seconds, then perform the next test.

>> GO TO 2.

2. PERFORM DTC CONFIRMATION PROCEDURE

With CONSULT

1. Start the engine and wait for 5 seconds or more.
2. Check the DTC.

Is "U1117" detected?

- YES >> Go to [TM-90, "Diagnosis Procedure"](#).
NO >> INSPECTION END

Diagnosis Procedure

INFOID:0000000011519516

For the diagnosis procedure, refer to [LAN-17, "Trouble Diagnosis Flow Chart"](#).

P062F EEPROM

Description

INFOID:0000000011519517

TCM compares the calculated value stored in the flash ROM with the value stored in TCM. If the calculated value does not agree with the stored value, TCM judges this as a malfunction.

DTC Logic

INFOID:0000000011519518

DTC DETECTION LOGIC

DTC	CONSULT screen terms (Trouble diagnosis content)	DTC detection condition	Possible causes
P062F	EEPROM (Internal Control Module EEPROM Error)	Flash ROM error is detected when turning ON the ignition switch.	- TCM (Flash ROM) - Harness or connector [TCM power supply (back-up) circuit is open or shorted]

DTC CONFIRMATION PROCEDURE

1. PREPARATION BEFORE WORK

If another "DTC CONFIRMATION PROCEDURE" occurs just before, turn ignition switch OFF and wait for at least 10 seconds, then perform the next test.

>> GO TO 2.

2. CHECK DTC DETECTION

1. Start the engine.
2. Check the DTC.

Is "P062F" detected?

YES >> Go to [TM-91, "Diagnosis Procedure"](#).
 NO >> INSPECTION END

Diagnosis Procedure

INFOID:0000000011519519

1. CHECK INTERMITTENT INCIDENT

Refer to [GI-42, "Intermittent Incident"](#).

Is the inspection result normal?

YES >> Replace the TCM. Refer to [TM-190, "Removal and Installation"](#).
 NO >> Repair or replace malfunctioning parts.

P0705 TRANSMISSION RANGE SENSOR A

< DTC/CIRCUIT DIAGNOSIS >

[CVT: RE0F10J]

P0705 TRANSMISSION RANGE SENSOR A

DTC Logic

INFOID:0000000011519520

DTC DETECTION LOGIC

DTC	CONSULT screen terms (Trouble diagnosis content)	DTC detection condition	Possible causes
P0705	T/M RANGE SENSOR A [Transmission Range Sensor A Circuit (PRNDL Input)]	When all of the following conditions are satisfied and this state is maintained for 2 seconds: - Two or more range signals simultaneously stay ON continuously - TCM power supply voltage: More than 11 V	- Harness or connector (Short circuit between transmission range switch and TCM) - Transmission range switch

DTC CONFIRMATION PROCEDURE

1. PREPARATION BEFORE WORK

If another "DTC CONFIRMATION PROCEDURE" occurs just before, turn ignition switch OFF and wait for at least 10 seconds, then perform the next test.

>> GO TO 2.

2. CHECK DTC DETECTION

- Turn ignition switch ON.
- Shift the selector lever through entire positions from "P" to "L". (Hold the selector lever at each position for 5 seconds or more.)
- Check the first trip DTC.

Is "P0705" detected?

YES >> Go to [TM-92. "Diagnosis Procedure"](#).
NO >> INSPECTION END

Diagnosis Procedure

INFOID:0000000011519521

1. CHECK TCM INPUT SIGNALS

Ⓐ With CONSULT

- Turn ignition switch ON.
- Select "Data Monitor" in "TRANSMISSION".
- Select "D POSITION SW", "N POSITION SW", "R POSITION SW", "P POSITION SW" and "L RANGE SW".
- Shift the selector lever through entire positions from "P" to "L" and check ON/OFF of each monitor item.

Monitor item	Test condition	Condition
D POSITION SW	Selector lever: "D" position	On
	Other than the above	Off
N POSITION SW	Selector lever: "N" position	On
	Other than the above	Off
R POSITION SW	Selector lever: "R" position	On
	Other than the above	Off
P POSITION SW	Selector lever: "P" position	On
	Other than the above	Off
L RANGE SW	Selector lever: "L" position	On
	Other than the above	Off

Ⓑ Without CONSULT

- Turn ignition switch OFF.
- Disconnect TCM connector.

P0705 TRANSMISSION RANGE SENSOR A

< DTC/CIRCUIT DIAGNOSIS >

[CVT: RE0F10J]

- Turn ignition switch ON.
- Shift the selector lever from "P" to "L" and check voltage between TCM harness connector terminals and ground.

+		–	Test condition	Voltage
TCM				
Connector	Terminal			
F23	2	Ground	Selector lever: “L” position	10 – 16 V
			Other than the above	Approx. 0 V
	4		Selector lever: “D” position	10 – 16 V
			Other than the above	Approx. 0 V
	5		Selector lever: “N” position	10 – 16 V
			Other than the above	Approx. 0 V
	6		Selector lever: “R” position	10 – 16 V
			Other than the above	Approx. 0 V
	7		Selector lever: “P” position	10 – 16 V
			Other than the above	Approx. 0 V

Is the inspection result normal?

YES >> Check intermittent incident. Refer to [GI-42, "Intermittent Incident"](#).

NO-1 ["D POSITION SW" is "ON" when selector is not in "D" position. (Or connector terminal 4 is at power voltage.)]>>GO TO 2.

NO-2 ["N POSITION SW" is "ON" when selector is not in "N" position. (Or connector terminal 5 is at power voltage.)]>>GO TO 4.

NO-3 ["R POSITION SW" is "ON" when selector is not in "R" position. (Or connector terminal 6 is at power voltage.)]>>GO TO 6.

NO-4 ["P POSITION SW" is "ON" when selector is not in "P" position. (Or connector terminal 7 is at power voltage.)]>>GO TO 8.

NO-5 ["L POSITION SW" is "ON" when selector is not in "L" position. (Or connector terminal 2 is at power voltage.)]>>GO TO 10.

2.CHECK D POSITION SW CIRCUIT (PART 1)

- Turn ignition switch OFF.
- Disconnect TCM connector.
- Check continuity between TCM harness connector terminals.

TCM			Continuity
Connector	Terminal		
F23	4	2	Not existed
		5	
		6	
		7	

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace malfunctioning parts.

3.CHECK D POSITION SW CIRCUIT (PART 2)

- Disconnect transmission range switch connector.
- Turn ignition switch ON.
- Check voltage between TCM harness connector terminal and ground.

P0705 TRANSMISSION RANGE SENSOR A

< DTC/CIRCUIT DIAGNOSIS >

[CVT: RE0F10J]

+		-	Voltage
TCM			
Connector	Terminal		
F23	4	Ground	Approx. 0 V

Is the inspection result normal?

YES >> GO TO 12.

NO >> Repair or replace malfunctioning parts.

4.CHECK N POSITION SW CIRCUIT (PART 1)

1. Turn ignition switch OFF.
2. Disconnect TCM connector.
3. Check continuity between TCM harness connector terminals.

TCM			Continuity
Connector	Terminal		
F23	5	2	Not existed
		4	
		6	
		7	

Is the inspection result normal?

YES >> GO TO 5.

NO >> Repair or replace malfunctioning parts.

5.CHECK N POSITION SW CIRCUIT (PART 2)

1. Disconnect transmission range switch connector.
2. Turn ignition switch ON.
3. Check voltage between TCM harness connector terminal and ground.

+		–	Voltage
TCM			
Connector	Terminal		
F23	5	Ground	Approx. 0 V

Is the inspection result normal?

YES >> GO TO 12.

NO >> Repair or replace malfunctioning parts.

6.CHECK P POSITION SW CIRCUIT (PART 1)

1. Turn ignition switch OFF.
2. Disconnect TCM connector.
3. Check continuity between TCM harness connector terminals.

TCM			Continuity
Connector	Terminal		
F23	7	2	Not existed
		4	
		5	
		6	

Is the inspection result normal?

YES >> GO TO 7.

NO >> Repair or replace malfunctioning parts.

P0705 TRANSMISSION RANGE SENSOR A

< DTC/CIRCUIT DIAGNOSIS >

[CVT: RE0F10J]

7.CHECK P POSITION SW CIRCUIT (PART 2)

1. Disconnect transmission range switch connector.
2. Turn ignition switch ON.
3. Check voltage between TCM harness connector terminal and ground.

+		–	Voltage
TCM			
Connector	Terminal		
F23	7	Ground	Approx. 0 V

Is the inspection result normal?

YES >> GO TO 12.

NO >> Repair or replace malfunctioning parts.

8.CHECK R POSITION SW CIRCUIT (PART1)

1. Turn ignition switch OFF.
2. Disconnect TCM connector.
3. Check continuity between TCM harness connector terminals.

TCM			Continuity
Connector	Terminal		
F23	6	2	Not existed
		4	
		5	
		7	

Is the inspection result normal?

YES >> GO TO 9.

NO >> Repair or replace malfunctioning parts.

9.CHECK R POSITION SW CIRCUIT (PART 2)

1. Disconnect transmission range switch connector.
2. Turn ignition switch ON.
3. Check voltage between TCM harness connector terminal and ground.

+		–	Voltage
TCM			
Connector	Terminal		
F23	6	Ground	Approx. 0 V

Is the inspection result normal?

YES >> GO TO 12.

NO >> Repair or replace malfunctioning parts.

10.CHECK DS POSITION SWITCH CIRCUIT (PART 1)

1. Turn ignition switch OFF.
2. Disconnect TCM connector.
3. Check continuity between TCM harness connector terminals.

P0705 TRANSMISSION RANGE SENSOR A

< DTC/CIRCUIT DIAGNOSIS >

[CVT: RE0F10J]

TCM			Continuity
Connector	Terminal		
F23	2	4	Not existed
		5	
		6	
		7	

Is the inspection result normal?

YES >> GO TO 11.

NO >> Repair or replace malfunctioning parts.

11.CHECK DS POSITION SWITCH CIRCUIT (PART 2)

1. Disconnect transmission range switch connector.
2. Turn ignition switch ON.
3. Check voltage between TCM harness connector terminal and ground.

+		−	Voltage
TCM			
Connector	Terminal		
F23	2	Ground	Approx. 0 V

Is the inspection result normal?

YES >> GO TO 12.

NO >> Repair or replace malfunctioning parts.

12.CHECK TRANSMISSION RANGE SWITCH

Check transmission range switch. Refer to [TM-96, "Component Inspection"](#).

Is the check result normal?

YES >> Check intermittent incident. Refer to [GI-42, "Intermittent Incident"](#).

NO >> Repair or replace malfunctioning parts.

Component Inspection

INFOID:0000000011519522

1.CHECK TRANSMISSION RANGE SWITCH

Check continuity between transmission range switch connector terminals.

Transmission range switch	Condition	Continuity
Terminal		
1 – 2	Manual lever: “P” and “N” positions	Existed
	Other than the above	Not existed
3 – 4	Manual lever: “P” position	Existed
	Other than the above	Not existed
3 – 5	Manual lever: “R” position	Existed
	Other than the above	Not existed
3 – 6	Manual lever: “N” position	Existed
	Other than the above	Not existed
3 – 7	Manual lever: “D” position	Existed
	Other than the above	Not existed
3 – 8	Manual lever: “L” position	Existed
	Other than the above	Not existed

Is the inspection result normal?

P0705 TRANSMISSION RANGE SENSOR A

< DTC/CIRCUIT DIAGNOSIS >

[CVT: RE0F10J]

YES >> INSPECTION END
NO >> There is a malfunction of transmission range switch. Replace transaxle assembly. Refer to [TM-213. "Removal and Installation"](#).

A
B
C
TM
E
F
G
H
I
J
K
L
M
N
O
P

P0706 TRANSMISSION RANGE SENSOR A

< DTC/CIRCUIT DIAGNOSIS >

[CVT: RE0F10J]

P0706 TRANSMISSION RANGE SENSOR A

DTC Logic

INFOID:0000000011519523

DTC DETECTION LOGIC

DTC	CONSULT screen terms (Trouble diagnosis content)	DTC detection condition	Possible causes
P0706	T/M RANGE SENSOR A (Transmission Range Sensor A Circuit Range/Performance)	When all of the following conditions are satisfied and this state is maintained for 30 seconds: • All range signals stay OFF • TCM power supply voltage: More than 11 V	• Harness or connector (Open circuit between ignition switch and transmission range switch/open circuit between transmission range switch and TCM) • Transmission range switch • Control cable

DTC CONFIRMATION PROCEDURE

1. PREPARATION BEFORE WORK

If another "DTC CONFIRMATION PROCEDURE" occurs just before, turn ignition switch OFF and wait for at least 10 seconds, then perform the next test.

>> GO TO 2.

2. PERFORM DTC CONFIRMATION PROCEDURE

1. Turn ignition switch ON.
2. Shift the selector lever through entire positions from "P" to "L". (Hold the selector lever at each position for 40 seconds or more.)
3. Check the first trip DTC.

Is "P0706" detected?

- YES >> Go to [TM-98, "Diagnosis Procedure"](#).
NO >> INSPECTION END

Diagnosis Procedure

INFOID:0000000011519524

1. ADJUSTMENT OF CONTROL CABLE

Adjust control cable. Refer to [TM-81, "Inspection and Adjustment"](#).

>> GO TO 2.

2. PERFORM DTC CONFIRMATION PROCEDURE

Ⓔ With CONSULT

1. Turn ignition switch ON.
2. Select "Self Diagnostic Results" in "TRANSMISSION".
3. Touch "Erase".
4. Perform "DTC CONFIRMATION PROCEDURE". Refer to [TM-98, "DTC Logic"](#).

Is "P0706" detected?

- YES >> GO TO 3.
NO >> INSPECTION END

3. CHECK POWER CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect transmission range switch connector.
3. Turn ignition switch ON.
4. Check voltage between transmission range switch harness connector terminal and ground.

P0706 TRANSMISSION RANGE SENSOR A

< DTC/CIRCUIT DIAGNOSIS >

[CVT: RE0F10J]

+		–	Voltage
Transmission range switch			
Connector	Terminal		
F17	3	Ground	10 – 16 V

Is the inspection result normal?

YES >> GO TO 4.

NO >> GO TO 7.

4.CHECK CIRCUIT BETWEEN TRANSMISSION RANGE SWITCH AND TCM (PART 1)

1. Turn ignition switch OFF.
2. Disconnect TCM connector.
3. Check continuity between transmission range switch harness connector terminals and TCM harness connector terminals.

Transmission range switch		TCM		Continuity
Connector	Terminal	Connector	Terminal	
F17	4	F23	7	Existed
	5		6	
	6		5	
	7		4	
	8		2	

Is the inspection result normal?

YES >> GO TO 5.

NO >> Repair or replace malfunctioning parts.

5.CHECK CIRCUIT BETWEEN TRANSMISSION RANGE SWITCH AND TCM (PART 2)

Check continuity between transmission range switch harness connector terminals and ground.

Transmission range switch		—	Continuity
Connector	Terminal		
F17	4	Ground	Not existed
	5		
	6		
	7		
	8		

Is the inspection result normal?

YES >> GO TO 6.

NO >> Repair or replace malfunctioning parts.

6.CHECK TRANSMISSION RANGE SWITCH

Check transmission range switch. Refer to [TM-100, "Component Inspection"](#).

Is the inspection result normal?

YES >> Check intermittent incident. Refer to [GI-42, "Intermittent Incident"](#).

NO >> Repair or replace malfunctioning parts.

7.CHECK CIRCUIT BETWEEN IPDM E/R AND TRANSMISSION RANGE SWITCH (PART 1)

1. Disconnect IPDM E/R connector.
2. Check continuity between IPDM E/R harness connector and transmission range switch.

P0706 TRANSMISSION RANGE SENSOR A

< DTC/CIRCUIT DIAGNOSIS >

[CVT: RE0F10J]

IPDM E/R		Transmission range switch		Continuity
Connector	Terminal	Connector	Terminal	
F12	74	F17	3	Existed

Is the check result normal?

YES >> GO TO 8.

NO >> Repair or replace malfunctioning parts.

8.DETECT MALFUNCTIONING ITEMS

Check the following items:

- Harness open circuit or short circuit between ignition switch and IPDM E/R. Refer to [PG-56, "Wiring Diagram - IGNITION POWER SUPPLY -"](#).
- 10A fuse (No. 42, located in the IPDM E/R). Refer to [PG-95, "Fuse, Connector and Terminal Arrangement"](#).
- IPDM E/R

Is the check result normal?

YES >> Check intermittent incident. Refer to [GI-42, "Intermittent Incident"](#).

NO >> Repair or replace malfunctioning parts.

Component Inspection

INFOID:0000000011519525

1.CHECK TRANSMISSION RANGE SWITCH

Check continuity between transmission range switch connector terminals.

Transmission range switch	Condition	Continuity
Terminal		
1 – 2	Manual lever: “P” and “N” positions	Existed
	Other than the above	Not existed
3 – 4	Manual lever: “P” position	Existed
	Other than the above	Not existed
3 – 5	Manual lever: “R” position	Existed
	Other than the above	Not existed
3 – 6	Manual lever: “N” position	Existed
	Other than the above	Not existed
3 – 7	Manual lever: “D” position	Existed
	Other than the above	Not existed
3 – 8	Manual lever: “L” position	Existed
	Other than the above	Not existed

Is the inspection result normal?

YES >> INSPECTION END

NO >> There is a malfunction of transmission range switch. Replace transaxle assembly. Refer to [TM-213, "Removal and Installation"](#).

P0711 TRANSMISSION FLUID TEMPERATURE SENSOR A

< DTC/CIRCUIT DIAGNOSIS >

[CVT: RE0F10J]

P0711 TRANSMISSION FLUID TEMPERATURE SENSOR A

DTC Logic

INFOID:0000000011519526

DTC DETECTION LOGIC

DTC	CONSULT screen terms (Trouble diagnosis content)	DTC detection condition	Possible causes
P0711	FLUID TEMP SENSOR A (Transmission Fluid Temperature Sensor A Circuit Range/Performance)	When any of 1 or 2 is satisfied: - Under the following diagnosis conditions, CVT fluid temperature does not rise to 10°C (50°F) after driving for a certain period of time with the TCM-received fluid temperature sensor value between – 40°C (–40°F) and 9°C (48.2°F). - TCM power supply voltage: More than 11 V - CAN communication is normal - Engine speed: 450 rpm or more - Accelerator pedal position: 3 deg. or more - Vehicle speed: 10 km/h (7 MPH) or more - U0100, P0705 and P0706 are not detected. - Selector lever: "D" position - When the condition of the final judgment is satisfied after satisfying that of the provisional judgment: - Provisional judgment: All of the following conditions are satisfied within 2 seconds after the ignition switch is turned ON. - U0073, U0100, P0712 and P0713 are not detected. - CAN communication is normal. - TCM power supply voltage: More than 11 V - The difference between CVT fluid temperature and engine coolant temperature is 55°C (131°F) or more, or –27°C (–16°F) or less. - Final judgment: When all of the following conditions are satisfied and this state is maintained for 300 seconds: - ECM is normal. - Provisional judgment is satisfied.	CVT fluid temperature sensor

DTC CONFIRMATION PROCEDURE

CAUTION:

Always drive vehicle at a safe speed.

1. PREPARATION BEFORE WORK

If another "DTC CONFIRMATION PROCEDURE" occurs just before, turn ignition switch OFF and wait for at least 10 seconds, then perform the next test.

>> GO TO 2.

2. INSPECTION START

Is it necessary to erase permanent DTC?

YES >> GO TO 3.
NO >> GO TO 7.

3. CHECK DTC (ECM AND TCM)

Check the DTC.

Is any DTC other than "P0711" detected?

YES >> Check DTC detected item. Refer to [EC-103, "DTC Index"](#) (ECM), [TM-58, "DTC Index"](#) (TCM).
NO >> GO TO 4.

P0711 TRANSMISSION FLUID TEMPERATURE SENSOR A

< DTC/CIRCUIT DIAGNOSIS >

[CVT: RE0F10J]

4.PERFORM DTC CONFIRMATION PROCEDURE (PART 1)

TESTING CONDITION:

- While performing the following procedure, do not add fuel.
- Before performing the following procedure, check that fuel level is between 1/4 and 4/4.
- Before performing the following procedure, confirm that battery voltage is 11 V or more at idle.

With CONSULT

1. Move the vehicle to a cool place.

NOTE:

Cool the vehicle in an environment of ambient air temperature between -10°C (14°F) and 35°C (95°F).

2. Turn ignition switch OFF and leave the vehicle for 12 hours.

CAUTION:

Never turn ignition switch ON during this procedure.

NOTE:

The vehicle must be cooled with the hood open.

3. Turn ignition switch ON.

CAUTION:

Never start the engine.

4. Select "Data Monitor" in "TRANSMISSION".
5. Select "FLUID TEMP".
6. Record CVT fluid temperature.
7. Start engine and let it idle for 5 minutes or more.

CAUTION:

Never turn ignition switch OFF during idling.

8. Check 1st trip DTC.

With GST

1. Move the vehicle to a cool place.

NOTE:

Cool the vehicle in an environment of ambient air temperature between -10°C (14°F) and 35°C (95°F).

2. Turn ignition switch OFF and leave the vehicle for 12 hours.

CAUTION:

Never turn ignition switch ON during this procedure.

NOTE:

The vehicle must be cooled with the hood open.

3. Start engine and let it idle for 5 minutes or more.

CAUTION:

Never turn ignition switch OFF during idling.

4. Check 1st trip DTC.

Is "P0711" detected?

YES >> Go to [TM-104, "Diagnosis Procedure"](#).

NO-1 (With CONSULT)>>GO TO 5.

NO-2 (With GST)>>GO TO 6.

5.CHECK CVT FLUID TEMPERATURE

With CONSULT

1. Select "Data Monitor" in "TRANSMISSION".
2. Select "FLUID TEMP".

Is the value of "FLUID TEMP" 10°C (50°F) or more?

YES >> INSPECTION END

NO >> GO TO 6.

6.PERFORM DTC CONFIRMATION PROCEDURE (PART 2)

With CONSULT

1. Drive the vehicle for the total minutes specified in the Driving time column below with the following conditions satisfied.

Selector lever	: "D" position
Accelerator pedal position	: 1.0/8 or more
Vehicle speed	: 10 km/h (7 MPH) or more

P0711 TRANSMISSION FLUID TEMPERATURE SENSOR A

< DTC/CIRCUIT DIAGNOSIS >

[CVT: RE0F10J]

CVT fluid temperature before engine start	Driving time
-40°C (-40°F) – -31°C (-23.8°F)	20 minutes or more
-30°C (-22°F) – -21°C (-5.8°F)	18 minutes or more
-20°C (-4°F) – -11°C (-12.2°F)	14 minutes or more
-10°C (14°F) – -1°C (30.2°F)	10 minutes or more
0°C (32°F) – 9°C (48.2°F)	7 minutes or more

2. Stop the vehicle.
3. Check the first trip DTC.

With GST

1. Drive the vehicle and maintain the following conditions for 20 minutes or more.

Selector lever : "D" position
 Accelerator pedal position : 1.0/8 or more
 Vehicle speed : 10 km/h (7 MPH) or more

2. Stop the vehicle.
3. Check the first trip DTC.

Is "P0711" detected?

YES >> Go to [TM-104, "Diagnosis Procedure"](#).
 NO >> INSPECTION END

7. PERFORM DTC CONFIRMATION PROCEDURE

With CONSULT

1. Turn ignition switch OFF and cool the engine.
2. Turn ignition switch ON.
- CAUTION:**
Never start the engine.
3. Select "Data Monitor" in "TRANSMISSION".
4. Select "FLUID TEMP".
5. Record CVT fluid temperature.
6. Start the engine and wait for at least 2 minutes.
7. Drive the vehicle for the total minutes specified in the Driving time column below with the following conditions satisfied.

Selector lever : "D" position
 Accelerator pedal position : 1.0/8 or more
 Vehicle speed : 10 km/h (7 MPH) or more

CVT fluid temperature before engine start	Driving time
-40°C (-40°F) – -31°C (-23.8°F)	20 minutes or more
-30°C (-22°F) – -21°C (-5.8°F)	18 minutes or more
-20°C (-4°F) – -11°C (-12.2°F)	14 minutes or more
-10°C (14°F) – -1°C (30.2°F)	10 minutes or more
0°C (32°F) – 9°C (48.2°F)	7 minutes or more
Other than the above	— (Go to "8. CHECK CVT FLUID TEMPERATURE SENSOR")

8. Stop the vehicle.
9. Check the first trip DTC.

With GST

1. Turn ignition switch OFF and cool the engine.
2. Start the engine and wait for at least 2 minutes.
3. Drive the vehicle and maintain the following conditions for 20 minutes or more.

P0711 TRANSMISSION FLUID TEMPERATURE SENSOR A

< DTC/CIRCUIT DIAGNOSIS >

[CVT: RE0F10J]

Selector lever : "D" position
Accelerator pedal position : 1.0/8 or more
Vehicle speed : 10 km/h (7 MPH) or more

4. Stop the vehicle.

CAUTION:

Never turn ignition switch OFF

5. Check the first trip DTC.

Is "P0711" detected?

YES >> Go to [TM-104, "Diagnosis Procedure"](#).

NO >> GO TO 8.

8. CHECK CVT FLUID TEMPERATURE SENSOR

1. Turn ignition switch OFF.
2. Disconnect CVT unit connector.
3. Check resistance between CVT unit connector terminals.

CVT unit		Condition	Resistance (Approx.)
Connector	Terminal		
F250	18 – 12	CVT fluid temperature: 20°C (68°F)	6.5 kΩ
		CVT fluid temperature: 50°C (122°F)	2.2 kΩ
		CVT fluid temperature: 80°C (176°F)	0.87 kΩ

Is the inspection result normal?

YES >> INSPECTION END

NO >> There is a malfunction of CVT fluid temperature sensor. Replace terminal cord assembly. Refer to [TM-192, "Removal and Installation"](#).

Diagnosis Procedure

INFOID:000000011519527

1. CHECK CVT FLUID TEMPERATURE SENSOR

1. Turn ignition switch OFF.
2. Disconnect CVT unit connector.
3. Check resistance between CVT unit connector terminals.

CVT unit		Condition	Resistance (Approx.)
Connector	Terminal		
F250	18 – 12	CVT fluid temperature: 20°C (68°F)	6.5 kΩ
		CVT fluid temperature: 50°C (122°F)	2.2 kΩ
		CVT fluid temperature: 80°C (176°F)	0.87 kΩ

Is the inspection result normal?

YES >> GO TO 2.

NO >> GO TO 4.

2. CHECK CIRCUIT BETWEEN TCM AND CVT UNIT (CVT FLUID TEMPERATURE SENSOR) (PART 1)

1. Disconnect the TCM connector.
2. Check continuity between TCM harness connector terminals and CVT unit harness connector terminals.

TCM		CVT unit		Continuity
Connector	Terminal	Connector	Terminal	
F23	11	F24	18	Existed
	12		12	

Is the inspection result normal?

P0711 TRANSMISSION FLUID TEMPERATURE SENSOR A

< DTC/CIRCUIT DIAGNOSIS >

[CVT: RE0F10J]

- YES >> GO TO 3.
NO >> Repair or replace damaged parts.

3. CHECK CIRCUIT BETWEEN TCM AND CVT UNIT (CVT FLUID TEMPERATURE SENSOR) (PART 2)

Check continuity between TCM harness connector terminals and ground.

TCM		Ground	Continuity
Connector	Terminal		
F23	11	Ground	Not existed
	12		

Is the inspection result normal?

- YES >> Check intermittent incident. Refer to [GI-42, "Intermittent Incident"](#).
NO >> Repair or replace damaged parts.

4. CHECK TERMINAL CORD ASSEMBLY (PART 1)

- Remove terminal cord assembly. Refer to [TM-191, "Exploded View"](#).
- Check continuity between CVT unit harness connector terminals and control valve harness connector terminals.

CVT unit		Control valve		Continuity
Connector	Terminal	Connector	Terminal	
F250	18	F251	13	Existed
	12		5	

Is the inspection result normal?

- YES >> GO TO 5.
NO >> Repair or replace damaged parts.

5. CHECK TERMINAL CORD ASSEMBLY (PART 2)

Check terminal cord assembly harness cladding for damage.

Is the inspection result normal?

- YES >> GO TO 6.
NO >> Repair or replace damaged parts.

6. CHECK DTC (TCM)

 **With CONSULT**

- Perform "DTC CONFIRMATION PROCEDURE". Refer to [TM-101, "DTC Logic"](#).
- Select "Self Diagnostic Results" in "TRANSMISSION".

Is "P0710" detected?

- YES >> There is a malfunction of the CVT fluid temperature sensor. Replace the transaxle assembly.
Refer to [TM-213, "Removal and Installation"](#).
NO >> Check intermittent incident. Refer to [GI-42, "Intermittent Incident"](#).

P0712 TRANSMISSION FLUID TEMPERATURE SENSOR A

< DTC/CIRCUIT DIAGNOSIS >

[CVT: RE0F10J]

P0712 TRANSMISSION FLUID TEMPERATURE SENSOR A

DTC Logic

INFOID:000000011519528

DTC DETECTION LOGIC

DTC	CONSULT screen terms (Trouble diagnosis content)	DTC detection condition	Possible causes
P0712	FLUID TEMP SENSOR A (Transmission Fluid Temperature Sensor A Circuit Low)	When all of the following conditions are satisfied and this state is maintained for 5 seconds: • TCM power supply voltage : More than 11 V • Fluid temperature sensor detection voltage: 0.15 V or less	• Harness or connector (CVT fluid temperature sensor circuit is shorted to ground) • CVT fluid temperature sensor

DTC CONFIRMATION PROCEDURE

1.PREPARATION BEFORE WORK

If another "DTC CONFIRMATION PROCEDURE" occurs just before, turn ignition switch OFF and wait for at least 10 seconds, then perform the next test.

>> GO TO 2.

2.PERFORM DTC CONFIRMATION PROCEDURE

1. Start the engine and wait for 10 seconds or more.
2. Check the first trip DTC.

Is "P0712" detected?

YES >> Go to [TM-106, "Diagnosis Procedure"](#).

NO >> INSPECTION END

Diagnosis Procedure

INFOID:000000011519529

1.CHECK CIRCUIT BETWEEN TCM AND CVT UNIT

1. Turn ignition switch OFF.
2. Disconnect TCM connector and CVT unit connector.
3. Check continuity between TCM harness connector terminal and ground.

TCM		—	Continuity
Connector	Terminal		
F23	12	Ground	Not existed

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace malfunctioning part.

2.CHECK CVT FLUID TEMPERATURE SENSOR

Check CVT fluid temperature sensor. Refer to [TM-106, "Component Inspection"](#).

Is the inspection result normal?

YES >> Check intermittent incident. Refer to [GI-42, "Intermittent Incident"](#).

NO >> Repair or replace malfunctioning parts.

Component Inspection

INFOID:000000011519530

1.CHECK CVT FLUID TEMPERATURE SENSOR

Check resistance between CVT unit connector terminals.

P0712 TRANSMISSION FLUID TEMPERATURE SENSOR A

< DTC/CIRCUIT DIAGNOSIS >

[CVT: RE0F10J]

CVT unit	Condition	Resistance
Terminal		
18 – 12	CVT fluid temperature: 20°C (68°F)	Approx. 6.5 kΩ
	CVT fluid temperature: 50°C (122°F)	Approx. 2.2 kΩ
	CVT fluid temperature: 80°C (176°F)	Approx. 0.87 kΩ

Is the inspection result normal?

YES >> INSPECTION END

NO >> There is a malfunction of CVT fluid temperature sensor. Replace terminal code assembly. Refer to [TM-192. "Removal and Installation"](#).

A

B

C

TM

E

F

G

H

I

J

K

L

M

N

O

P

P0713 TRANSMISSION FLUID TEMPERATURE SENSOR A

< DTC/CIRCUIT DIAGNOSIS >

[CVT: RE0F10J]

P0713 TRANSMISSION FLUID TEMPERATURE SENSOR A

DTC Logic

INFOID:0000000011519531

DTC DETECTION LOGIC

DTC	CONSULT screen terms (Trouble diagnosis content)	DTC detection condition	Possible causes
P0713	FLUID TEMP SENSOR A (Transmission Fluid Temperature Sensor A Circuit High)	When all of the following conditions are satisfied and this state is maintained for 5 seconds: • TCM power supply voltage: More than 11 V • Vehicle speed: More than 10 km/h (7 MPH) • Fluid temperature sensor detection voltage: 2.48 V or more	• Harness or connector (CVT fluid temperature sensor circuit is open or shorted to power supply) • CVT fluid temperature sensor

DTC CONFIRMATION PROCEDURE

1.PREPARATION BEFORE WORK

If another "DTC CONFIRMATION PROCEDURE" occurs just before, turn ignition switch OFF and wait for at least 10 seconds, then perform the next test.

>> GO TO 2.

2.PERFORM DTC CONFIRMATION PROCEDURE

1. Start the engine.
2. Maintain the following condition for 10 seconds or more.

Vehicle speed : 20 km/h (12 MPH) or more

3. Stop the vehicle.
4. Check the first trip DTC.

Is "P0713" detected?

YES >> Go to [TM-108, "Diagnosis Procedure"](#).
NO >> INSPECTION END

Diagnosis Procedure

INFOID:0000000011519532

1.CHECK CIRCUIT BETWEEN TCM AND CVT UNIT (PART 1)

1. Turn ignition switch OFF.
2. Disconnect TCM connector and CVT unit connector.
3. Check continuity between TCM harness connector terminals and CVT unit harness connector terminals.

TCM		CVT unit		Continuity
Connector	Terminal	Connector	Terminal	
F23	11	F24	18	Existed
	12		12	

Is the inspection result normal?

YES >> GO TO 2.
NO >> Repair or replace malfunctioning parts.

2.CHECK CIRCUIT BETWEEN TCM AND CVT UNIT (PART 2)

1. Turn ignition switch ON.
2. Check voltage between TCM harness connector terminal and ground.

P0713 TRANSMISSION FLUID TEMPERATURE SENSOR A

< DTC/CIRCUIT DIAGNOSIS >

[CVT: RE0F10J]

+		-	Voltage
TCM			
Connector	Terminal		
F23	12	Ground	Approx. 0 V

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace malfunctioning parts.

3.CHECK CVT FLUID TEMPERATURE SENSOR

Check CVT fluid temperature sensor. Refer to [TM-109, "Component Inspection"](#).

Is the inspection result normal?

YES >> Check intermittent incident. Refer to [GI-42, "Intermittent Incident"](#).

NO >> Repair or replace malfunctioning parts.

Component Inspection

INFOID:0000000011519533

1.CHECK CVT FLUID TEMPERATURE SENSOR

Check resistance between CVT unit connector terminals.

CVT unit Terminal	Condition	Resistance
18 – 12	CVT fluid temperature: 20°C (68°F)	Approx. 6.5 kΩ
	CVT fluid temperature: 50°C (122°F)	Approx. 2.2 kΩ
	CVT fluid temperature: 80°C (176°F)	Approx. 0.87 kΩ

Is the inspection result normal?

YES >> INSPECTION END

NO >> There is a malfunction of CVT fluid temperature sensor. Replace terminal code assembly. Refer to [TM-192, "Removal and Installation"](#).

P0715 INPUT SPEED SENSOR A

< DTC/CIRCUIT DIAGNOSIS >

[CVT: RE0F10J]

P0715 INPUT SPEED SENSOR A

DTC Logic

INFOID:0000000011519534

DTC DETECTION LOGIC

DTC	CONSULT screen terms (Trouble diagnosis content)	DTC detection condition	Possible causes
P0715	INPUT SPEED SENSOR A (Input/Turbine Speed Sensor A Circuit)	When 1 is satisfied and any of 2, 3 or 4 is satisfied: - When the following conditions are satisfied: - TCM power supply voltage: More than 11 V - After range change completion, it spends 2 seconds or more. - When all of the following conditions are satisfied and this state is maintained for 5 seconds: - Primary pulley speed: Less than 150 rpm - Secondary pulley speed: 500 rpm or more - When all of the following conditions are satisfied and this state is maintained for 0.5 seconds: 10-msec-ago primary pulley speed: 1,000 rpm or more - Now primary pulley speed: 0 rpm When all of the following conditions are satisfied and this state is maintained for 5 seconds: - Range: D or DS - Engine speed: 450 rpm or more - Input speed: 300 rpm or more - Primary pulley speed: 300 rpm or more - Secondary pulley speed: 300 rpm or more - Differences between engine speed and primary pulley speed: More than 1,000 rpm - Differences between primary pulley speed and input speed: More than 1,000 rpm - Differences between engine speed and input speed: 1,000 rpm or less - Lock-up command is being given (except for slip lock-up) - DTC other than the applicable DTC is not detected.	- Harness or connector (Primary speed sensor circuit is open or shorted) - Primary speed sensor

DTC CONFIRMATION PROCEDURE

CAUTION:

Be careful of the driving speed.

1. PREPARATION BEFORE WORK

If another "DTC CONFIRMATION PROCEDURE" occurs just before, turn ignition switch OFF and wait for at least 10 seconds, then perform the next test.

>> GO TO 2.

2. CHECK DTC DETECTION

- Start the engine.
- Drive the vehicle.
- Maintain the following conditions for 10 seconds or more.

Selector lever : "D" POSITION
Engine speed : 1,200 rpm or more
Vehicle speed : 40 km/h (25 MPH) or more

- Stop the vehicle.
- Check the first trip DTC.

Is "P0715" detected?

P0715 INPUT SPEED SENSOR A

< DTC/CIRCUIT DIAGNOSIS >

[CVT: RE0F10J]

- YES >> Go to [TM-111, "Diagnosis Procedure"](#).
NO >> INSPECTION END

Diagnosis Procedure

INFOID:0000000011519535

1.CHECK PRIMARY SPEED SENSOR POWER CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect primary speed sensor connector.
3. Turn ignition switch ON.
4. Check voltage between primary speed sensor harness connector terminal and ground.

+		–	Voltage
Primary speed sensor			
Connector	Terminal		
F16	3	Ground	10 – 16 V

Is the inspection result normal?

- YES >> GO TO 2.
NO >> GO TO 6.

2.CHECK PRIMARY SPEED SENSOR GROUND CIRCUIT

Check continuity between primary speed sensor harness connector terminal and ground.

Primary speed sensor		—	Continuity
Connector	Terminal		
F16	1	Ground	Existed

Is the inspection result normal?

- YES >> GO TO 3.
NO >> Repair or replace malfunctioning parts.

3.CHECK CIRCUIT BETWEEN PRIMARY SPEED SENSOR AND TCM (PART 1)

1. Turn ignition switch OFF.
2. Disconnect TCM connector.
3. Check continuity between primary speed sensor harness connector terminal and TCM harness connector terminal.

Primary speed sensor		TCM		Continuity
Connector	Terminal	Connector	Terminal	
F16	2	F23	35	Existed

Is the inspection result normal?

- YES >> GO TO 4.
NO >> Repair or replace malfunctioning parts.

4.CHECK CIRCUIT BETWEEN PRIMARY SPEED SENSOR AND TCM (PART 2)

Check continuity between primary speed sensor harness connector terminal and ground.

Primary speed sensor		—	Continuity
Connector	Terminal		
F16	2	Ground	Not existed

Is the inspection result normal?

- YES >> GO TO 5.
NO >> Repair or replace malfunctioning parts.


5.CHECK TCM INPUT SIGNALS

P0715 INPUT SPEED SENSOR A

< DTC/CIRCUIT DIAGNOSIS >

[CVT: RE0F10J]

1. Connect all of disconnected connectors.
2. Lift the vehicle.
3. Start the engine.
4. Check frequency of primary speed sensor.

+		-	Condition	Standard
TCM				
Connector	Terminal			
F23	35	Ground	• Selector lever: “L” position • Vehicle speed: 20 km/h (12 MPH)	Approx. 700 Hz 1mSec/div  5V/div JSDIA1905GB

Is the inspection result normal?

- YES >> Check intermittent incident. Refer to [GI-42, "Intermittent Incident"](#).
- NO >> Replace primary speed sensor. Refer to [TM-200, "Removal and Installation"](#).

6.DETECT MALFUNCTIONING ITEMS

Check the following items:

- Harness open circuit or short circuit between ignition switch and IPDM E/R. Refer to [PG-56, "Wiring Diagram - IGNITION POWER SUPPLY -"](#).
- Harness open circuit or short circuit between primary speed sensor and IPDM E/R.
- 10A fuse (No.43, located in the IPDM E/R). Refer to [PG-95, "Fuse, Connector and Terminal Arrangement"](#).
- IPDM E/R

Is the check result normal?

- YES >> Check intermittent incident. Refer to [GI-42, "Intermittent Incident"](#).
- NO >> Repair or replace malfunctioning parts.

P0717 INPUT SPEED SENSOR A

< DTC/CIRCUIT DIAGNOSIS >

[CVT: RE0F10J]

P0717 INPUT SPEED SENSOR A

DTC Logic

INFOID:0000000011519536

DTC DETECTION LOGIC

DTC	CONSULT screen terms (Trouble diagnosis content)	DTC detection condition	Possible cause
P0717	INPUT SPEED SENSOR A (Input/Turbine Speed Sensor "A" Circuit No Signal)	When 1 is satisfied and any of 2, 3 or 4 is satisfied: - When the following conditions are satisfied: - TCM power supply voltage: More than 11 V - After range change completion, it spends 2 seconds or more. - When all of the following conditions are satisfied and this state is maintained for 5 seconds: - Primary pulley speed: 500 rpm or more - Input speed: Less than 150 rpm - Range: Other than P, N - P0715 is not detected - When all of the following conditions are satisfied and this state is maintained for 0.5 seconds: 10-msec-ago input speed: 1,000 rpm or more - Now input speed: 0 rpm - When all of the following conditions are satisfied and this state is maintained for 5 seconds: - Range: D or L - Engine speed: 450 rpm or more - Input speed: 300 rpm or more - Primary pulley speed: 300 rpm or more - Secondary pulley speed: 300 rpm or more - Differences between engine speed and primary pulley speed: 1,000 rpm or less - Differences between primary pulley speed and input speed: More than 1,000 rpm - Differences between engine speed and input speed: More than 1,000 rpm - Lock-up command is being given (except for slip lock-up) - DTC other than the applicable DTC is not detected.	- Harness or connectors (Input speed sensor circuit is open or shorted.) - Input speed sensor

DTC CONFIRMATION PROCEDURE

CAUTION:

Always drive vehicle at a safe speed.

1. PREPARATION BEFORE WORK

If another "DTC CONFIRMATION PROCEDURE" occurs just before, turn ignition switch OFF and wait for at least 10 seconds, then perform the next test.

>> GO TO 2.

2. CHECK DTC DETECTION

With CONSULT

- Start the engine.
- Drive the vehicle.
- Maintain the following conditions for 10 seconds or more.

Selector lever : "D" position

P0717 INPUT SPEED SENSOR A

< DTC/CIRCUIT DIAGNOSIS >

[CVT: RE0F10J]

Engine speed : 1,200 rpm or more
Vehicle speed : 40 km/h (25 MPH) or more

4. Stop the vehicle.
5. Check the first trip DTC.

Is "P0717" detected?

YES >> Go to [TM-114, "Diagnosis Procedure"](#).
NO >> INSPECTION END

Diagnosis Procedure

INFOID:0000000011519537

1.CHECK INPUT SPEED SENSOR POWER CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect input speed sensor connector.
3. Turn ignition switch ON.
4. Check voltage between input speed sensor harness connector terminal and ground.

+		–	Voltage
Input speed sensor			
Connector	Terminal		
F21	3	Ground	10 – 16 V

Is the inspection result normal?

YES >> GO TO 2.
NO >> GO TO 6.

2.CHECK INPUT SPEED SENSOR GROUND CIRCUIT

Check continuity between input speed sensor harness connector terminal and ground.

Input speed sensor		—	Continuity
Connector	Terminal		
F21	1	Ground	Existed

Is the inspection result normal?

YES >> GO TO 3.
NO >> Repair or replace malfunctioning parts.

3.CHECK CIRCUIT BETWEEN INPUT SPEED SENSOR AND TCM (PART 1)

1. Turn ignition switch OFF.
2. Disconnect TCM connector.
3. Check continuity between input speed sensor harness connector terminal and TCM harness connector terminal.

Input speed sensor		TCM		Continuity
Connector	Terminal	Connector	Terminal	
F21	2	F23	24	Existed

Is the inspection result normal?

YES >> GO TO 4.
NO >> Repair or replace malfunctioning parts.

4.CHECK CIRCUIT BETWEEN INPUT SPEED SENSOR AND TCM (PART 2)

Check continuity between input speed sensor harness connector terminal and ground.

P0717 INPUT SPEED SENSOR A

< DTC/CIRCUIT DIAGNOSIS >

[CVT: RE0F10J]

Input speed sensor		—	Continuity
Connector	Terminal		
F21	2	Ground	Not existed


Is the inspection result normal?

YES >> GO TO 5.

NO >> Repair or replace malfunctioning parts.

5.CHECK TCM INPUT SIGNALS

1. Connect all of disconnected connectors.
2. Lift the vehicle.
3. Start the engine.
4. Check frequency of input speed sensor.

+		—	Condition	Standard
TCM				
Connector	Terminal			
F23	24	Ground	• Selector lever: “L” position • Vehicle speed: 20 km/h (12 MPH)	Approx. 880 Hz 1mSec/div  5V/div JSDIA3769GB

Is the inspection result normal?

YES >> Check intermittent incident. Refer to [GI-42, "Intermittent Incident"](#).

NO >> Replace input speed sensor. Refer to [TM-198, "Removal and Installation"](#).

6.DETECT MALFUNCTIONING ITEMS

Check the following items:

- Harness open circuit or short circuit between ignition switch and IPDM E/R. Refer to [PG-56, "Wiring Diagram - IGNITION POWER SUPPLY -"](#).
- Harness open circuit or short circuit between input speed sensor and IPDM E/R.
- 10A fuse (No.43, located in the IPDM E/R). Refer to [PG-95, "Fuse, Connector and Terminal Arrangement"](#).
- IPDM E/R

Is the check result normal?

YES >> Check intermittent incident. Refer to [GI-42, "Intermittent Incident"](#).

NO >> Repair or replace malfunctioning parts.

P0740 TORQUE CONVERTER

< DTC/CIRCUIT DIAGNOSIS >

[CVT: RE0F10J]

P0740 TORQUE CONVERTER

DTC Logic

INFOID:0000000011519538

DTC DETECTION LOGIC

DTC	CONSULT screen terms (Trouble diagnosis content)	DTC detection condition	Possible causes
P0740	TORQUE CONVERTER (Torque Converter Clutch Circuit/Open)	When all of the following conditions are satisfied and this state is maintained for 5 seconds: • TCM power supply voltage: More than 11 V • P0743 is not detected. • TCM judges that solenoid valve circuit is open.	• Harness or connector (Torque converter clutch solenoid valve circuit is open or shorted to power supply) • Torque converter clutch solenoid valve

DTC CONFIRMATION PROCEDURE

CAUTION:

Be careful of the driving speed.

1. PREPARATION BEFORE WORK

If another "DTC CONFIRMATION PROCEDURE" occurs just before, turn ignition switch OFF and wait for at least 10 seconds, then perform the next test.

>> GO TO 2.

2. PREPARATION BEFORE OPERATION

With CONSULT

1. Start the engine.
2. Select "Data Monitor" in "TRANSMISSION".
3. Select "FLUID TEMP".
4. Confirm that the CVT fluid temperature is in the following range.

FLUID TEMP : 20°C (68°F) or more

With GST

1. Start the engine.
2. Set the CVT fluid to 20°C (68°F) or more.

NOTE:

When the ambient temperature is 20°C (68°F), the CVT fluid usually increases to 50 to 80°C (122 to 176°F) with driving in an urban area for approximately 10 minutes.

Is the CVT fluid 20°C (68°F) or more?

YES >> GO TO 3.

NO >> 1. Warm the transaxle.
2. GO TO 3.

3. CHECK DTC DETECTION

1. Drive the vehicle.
2. Maintain the following conditions for 10 seconds or more.

Selector lever : "D" position

Vehicle speed : 40 km/h (25 MPH) or more

3. Stop the vehicle.

4. Check the first trip DTC.

Is "P0740" detected?

YES >> Go to [TM-117, "Diagnosis Procedure"](#).

NO >> INSPECTION END

P0740 TORQUE CONVERTER

< DTC/CIRCUIT DIAGNOSIS >

[CVT: RE0F10J]

Diagnosis Procedure

INFOID:0000000011519539

1. CHECK CIRCUIT BETWEEN TCM AND CVT UNIT

1. Turn ignition switch OFF.
2. Disconnect TCM connector and CVT unit connector.
3. Check continuity between TCM harness connector terminal and CVT unit harness connector terminal.

TCM		CVT unit		Continuity
Connector	Terminal	Connector	Terminal	
F23	38	F24	5	Existed

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace malfunctioning parts.

2. CHECK CIRCUIT BETWEEN CVT UNIT AND GROUND

Check resistance between CVT unit harness connector terminal and ground.

CVT unit		—	Condition	Resistance
Connector	Terminal			
F250	5	Ground	CVT fluid temperature: 20°C (68°F)	5.5 – 7.0 Ω
			CVT fluid temperature: 50°C (122°F)	6.0 – 8.0 Ω
			CVT fluid temperature: 80°C (176°F)	6.5 – 8.5 Ω

Is the inspection result normal?

YES >> Check intermittent incident. Refer to [GI-42, "Intermittent Incident"](#).

NO >> GO TO 3.

3. CHECK CIRCUIT BETWEEN CVT UNIT AND CONTROL VALVE

1. Disconnect control valve connector. Refer to [TM-191, "Exploded View"](#).
2. Check continuity between CVT unit harness connector terminal and control valve harness connector terminal.

CVT unit		Control valve		Continuity
Connector	Terminal	Connector	Terminal	
F250	5	F251	3	Existed

Is the inspection result normal?

YES >> GO TO 4.

NO >> Replace terminal code assembly. Refer to [TM-192, "Removal and Installation"](#).

4. CHECK CIRCUIT BETWEEN CONTROL VALVE AND GROUND

Check resistance between control valve harness connector terminal and ground.

Control valve	—	Condition	Resistance
Terminal			
3	Ground	CVT fluid temperature: 20°C (68°F)	5.5 – 7.0 Ω
		CVT fluid temperature: 50°C (122°F)	6.0 – 8.0 Ω
		CVT fluid temperature: 80°C (176°F)	6.5 – 8.5 Ω

Is the inspection result normal?

YES >> Check intermittent incident. Refer to [GI-42, "Intermittent Incident"](#).

NO >> There is malfunction of torque converter clutch solenoid valve. Replace transaxle assembly. Refer to [TM-213, "Removal and Installation"](#).

P0743 TORQUE CONVERTER

< DTC/CIRCUIT DIAGNOSIS >

[CVT: RE0F10J]

P0743 TORQUE CONVERTER

DTC Logic

INFOID:0000000011519540

DTC DETECTION LOGIC

DTC	CONSULT screen terms (Trouble diagnosis content)	DTC detection condition	Possible causes
P0743	TORQUE CONVERTER (Torque Converter Clutch Circuit Electrical)	When all of the following conditions are satisfied and this state is maintained for 0.48 seconds: • TCM power supply voltage: More than 11 V • TCM judges that solenoid valve circuit is shorted to ground.	• Harness or connector (Torque converter clutch solenoid valve circuit is shorted to ground) • Torque converter clutch solenoid valve

DTC CONFIRMATION PROCEDURE

CAUTION:

Be careful of the driving speed.

1. PREPARATION BEFORE WORK

If another "DTC CONFIRMATION PROCEDURE" occurs just before, turn ignition switch OFF and wait for at least 10 seconds, then perform the next test.

>> GO TO 2.

2. PREPARATION BEFORE OPERATION

With CONSULT

1. Start the engine.
2. Select "Data Monitor" in "TRANSMISSION".
3. Select "FLUID TEMP".
4. Confirm that the CVT fluid temperature is in the following range.

FLUID TEMP : 20°C (68°F) or more

With GST

1. Start the engine.
2. Set the CVT fluid to 20°C (68°F) or more.

NOTE:

When the ambient temperature is 20°C (68°F), the CVT fluid usually increases to 50 to 80°C (122 to 176°F) with driving in an urban area for approximately 10 minutes.

Is the CVT fluid 20°C (68°F) or more?

YES >> GO TO 3.

NO >> 1. Warm the transaxle.
2. GO TO 3.

3. CHECK DTC DETECTION

1. Drive the vehicle.
2. Maintain the following conditions for 10 seconds or more.

Selector lever : "D" position
Vehicle speed : 40 km/h (25 MPH) or more

3. Stop the vehicle.
4. Check the first trip DTC.

Is "P0743" detected?

YES >> Go to [TM-119. "Diagnosis Procedure"](#).

NO >> INSPECTION END

P0743 TORQUE CONVERTER

< DTC/CIRCUIT DIAGNOSIS >

[CVT: RE0F10J]

Diagnosis Procedure

INFOID:0000000011519541

1. CHECK CIRCUIT BETWEEN TCM AND CVT UNIT

1. Turn ignition switch OFF.
2. Disconnect TCM connector and CVT unit connector.
3. Check continuity between TCM harness connector terminal and ground.

TCM		—	Continuity
Connector	Terminal		
F23	38	Ground	Not existed

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace malfunctioning parts.

2. CHECK CIRCUIT BETWEEN CVT UNIT AND GROUND

Check resistance between CVT unit harness connector terminal and ground.

CVT unit		—	Condition	Resistance
Connector	Terminal			
F250	5	Ground	CVT fluid temperature: 20°C (68°F)	5.5 – 7.0 Ω
			CVT fluid temperature: 50°C (122°F)	6.0 – 8.0 Ω
			CVT fluid temperature: 80°C (176°F)	6.5 – 8.5 Ω

Is the inspection result normal?

YES >> Check intermittent incident. Refer to [GI-42, "Intermittent Incident"](#).

NO >> GO TO 3.

3. CHECK CIRCUIT BETWEEN CVT UNIT AND CONTROL VALVE

1. Disconnect control valve connector. Refer to [TM-191, "Exploded View"](#).
2. Check continuity between CVT unit harness connector terminal and control valve harness connector terminal.

CVT unit		Control valve		Continuity
Connector	Terminal	Connector	Terminal	
F250	5	F251	3	Existed

Is the inspection result normal?

YES >> GO TO 4.

NO >> Replace terminal code assembly. Refer to [TM-192, "Removal and Installation"](#).

4. CHECK CIRCUIT BETWEEN CONTROL VALVE AND GROUND

Check resistance between control valve harness connector terminal and ground.

Control valve		—	Condition	Resistance
Terminal				
3	Ground		CVT fluid temperature: 20°C (68°F)	5.5 – 7.0 Ω
			CVT fluid temperature: 50°C (122°F)	6.0 – 8.0 Ω
			CVT fluid temperature: 80°C (176°F)	6.5 – 8.5 Ω

Is the inspection result normal?

YES >> Check intermittent incident. Refer to [GI-42, "Intermittent Incident"](#).

NO >> There is malfunction of torque converter clutch solenoid valve. Replace transaxle assembly. Refer to [TM-213, "Removal and Installation"](#).

P0744 TORQUE CONVERTER

< DTC/CIRCUIT DIAGNOSIS >

[CVT: RE0F10J]

P0744 TORQUE CONVERTER

DTC Logic

INFOID:000000011519542

DTC DETECTION LOGIC

DTC	CONSULT screen terms (Trouble diagnosis content)	DTC detection condition	Possible causes
P0744	TORQUE CONVERTER (Torque converter clutch circuit intermittent)	When all of the following conditions are satisfied and this state is maintained for 30 seconds: • TCM power supply voltage: More than 11 V • P0717 is not detected. • CAN communication is normal • Torque converter slip speed: (40+vehicle speed/2) rpm • LU pressure: More than 0.2 MPa	• Torque converter clutch solenoid valve • Control valve assembly • Torque converter

DTC CONFIRMATION PROCEDURE

CAUTION:

Be careful of the driving speed.

1. PREPARATION BEFORE WORK

If another "DTC CONFIRMATION PROCEDURE" occurs just before, turn ignition switch OFF and wait for at least 10 seconds, then perform the next test.

>> GO TO 2.

2. PREPARATION BEFORE OPERATION

With CONSULT

1. Start the engine.
2. Select "Data Monitor" in "TRANSMISSION".
3. Select "FLUID TEMP".
4. Confirm that the CVT fluid temperature is in the following range.

FLUID TEMP : 20°C (68°F) or more

With GST

1. Start the engine.
2. Set the CVT fluid to 20°C (68°F) or more.

NOTE:

When the ambient temperature is 20°C (68°F), the CVT fluid usually increases to 50 to 80°C (122 to 176°F) with driving in an urban area for approximately 10 minutes.

Is the CVT fluid 20°C (68°F) or more?

YES >> GO TO 3.

NO >> 1. Warm the transaxle.
2. GO TO 3.

3. CHECK DTC DETECTION

1. Drive the vehicle.
2. Maintain the following conditions for 10 seconds or more.

Selector lever : "D" position
Accelerator pedal position : 0.5/8 or more
Vehicle speed : 40 km/h (25 MPH) or more

3. Stop the vehicle.
4. Check the first trip DTC.

Is "P0744" detected?

YES >> Go to [TM-121, "Diagnosis Procedure"](#).

P0744 TORQUE CONVERTER

< DTC/CIRCUIT DIAGNOSIS >

[CVT: RE0F10J]

NO >> INSPECTION END

Diagnosis Procedure

INFOID:0000000011519543

1.CHECK INTERMITTENT INCIDNT

Refer to [GI-42, "Intermittent Incident"](#).

Is the inspection result normal?

- YES >> Replace transaxle assembly. Refer to [TM-213, "Removal and Installation"](#).
- NO >> Repair or replace the malfunction items.

A

B

C

TM

E

F

G

H

I

J

K

L

M

N

O

P

P0746 PRESSURE CONTROL SOLENOID A

< DTC/CIRCUIT DIAGNOSIS >

[CVT: RE0F10J]

P0746 PRESSURE CONTROL SOLENOID A

DTC Logic

INFOID:0000000011519544

DTC DETECTION LOGIC

DTC	CONSULT screen terms (Trouble diagnosis content)	DTC detection condition	Possible causes
P0746	PC SOLENOID A (Pressure Control Solenoid A Performance/Stuck Off)	The detecting condition A or detection condition B is detected twice or more (1 second or more later after detection of the first) in the same DC under the following diagnosis conditions: • Diagnosis conditions - Engine speed: More than 600 rpm - Primary pulley speed: More than 450 rpm - Idle is not being detected. - Acceleration/deceleration speed: -0.49 m/s^2 (-0.05 G) or more - The primary pulley speed experienced 300 rpm or more and the secondary pulley speed experienced 250 rpm or more at least once. - Secondary pulley speed: More than 150 rpm - TCM power supply voltage: More than 11 V • Detection condition A - Status with the shifting ratio of the primary pulley speed/secondary pulley ratio exceeding 2.981 is 0.2 sec or more continuously. • Detection condition B - Status with the shifting ratio of the primary pulley speed/secondary pulley ratio exceeding 3.781 is 0.1 sec or more continuously.	• Line pressure solenoid valve • Control valve assembly

NOTE:

DC stands for "DRIVING CYCLE" and indicates a series of driving cycle of "Ignition switch OFF → ON → driving → OFF".

DTC CONFIRMATION PROCEDURE

CAUTION:

Be careful of the driving speed.

1. PREPARATION BEFORE WORK

If another "DTC CONFIRMATION PROCEDURE" occurs just before, turn ignition switch OFF and wait for at least 10 seconds, then perform the next test.

>> GO TO 2.

2. CHECK DTC DETECTION

1. Start the engine.
2. Drive the vehicle.
3. Maintain the following conditions for 10 seconds or more.

Selector lever	: "D" position
Accelerator pedal position	: 0.5/8 or more
Vehicle speed	: 40 km/h (25 MPH) or more

4. Stop the vehicle.
5. Check the first trip DTC.

Is "P0746" detected?

YES >> Go to [TM-123. "Diagnosis Procedure"](#).

P0746 PRESSURE CONTROL SOLENOID A

< DTC/CIRCUIT DIAGNOSIS >

[CVT: RE0F10J]

NO >> INSPECTION END

Diagnosis Procedure

INFOID:0000000011519545

1.CHECK INTERMITTENT INCIDENT

Refer to [GI-42, "Intermittent Incident"](#).

Is the inspection result normal?

YES >> Replace transaxle assembly. Refer to [TM-213, "Removal and Installation"](#).

NO >> Repair or replace the malfunction items.

A
B
C
E
F
G
H
I
J
K
L
M
N
O
P

TM

P0776 PRESSURE CONTROL SOLENOID B

< DTC/CIRCUIT DIAGNOSIS >

[CVT: RE0F10J]

P0776 PRESSURE CONTROL SOLENOID B

DTC Logic

INFOID:000000011519546

DTC DETECTION LOGIC

DTC	CONSULT screen terms (Trouble diagnosis content)	DTC detection condition	Possible cause
P0776	PC SOLENOID B (Pressure Control Solenoid "B" Performance/Stuck Off)	When any of 1 or 2 is satisfied and this state is maintained for 10 seconds: - When all of the following conditions are satisfied: - DTC other than the applicable DTC is not detected. - Engine speed: More than 625 rpm - Selector lever: Other than P/N position - CVT fluid temperature: More than -20°C (-4°F) - TCM power supply: More than 11 V - The difference between instruction pressure of secondary pressure and 10-msec-ago instruction secondary pressure is 0 MPa or more - Instruction pressure of secondary pressure: 0 MPa or more - Instruction pressure of secondary pressure - secondary pressure: More than 1.2 MPa - When all of the following conditions are satisfied and this state is maintained for 5.5 seconds: • DTC other than the applicable DTC is not detected. • CVT fluid temperature: More than -20°C (-4°F) • Selector lever: Other than P/N position • Secondary pressure - instruction pressure of secondary pressure: 1.2 MPa or more - When all of the following conditions are satisfied: - DTC other than the applicable DTC is not detected. - CVT fluid temperature: More than -20°C (-4°F) - Selector lever: Other than P/N position - TCM power supply: More than 11 V - When all of the following conditions are satisfied and this state is maintained for 5.5 seconds: • DTC other than the applicable DTC is not detected. • CVT fluid temperature: More than -20°C (-4°F) • Selector lever: Other than P/N position • Secondary pressure - instruction pressure of secondary pressure: 1.2 MPa or more - The difference between instruction pressure of secondary pressure and 10-msec-ago instruction secondary pressure is 0 MPa or more - Secondary pressure - instruction pressure of secondary pressure: More than 1.2 MPa	Secondary pressure solenoid valve

P0776 PRESSURE CONTROL SOLENOID B

< DTC/CIRCUIT DIAGNOSIS >

[CVT: RE0F10J]

DTC CONFIRMATION PROCEDURE

CAUTION:

Always drive vehicle at a safe speed.

1. PREPARATION BEFORE WORK

If another "DTC CONFIRMATION PROCEDURE" occurs just before, turn ignition switch OFF and wait for at least 10 seconds, then perform the next test.

>> GO TO 2.

2. CHECK DTC DETECTION

1. Start the engine.
2. Drive the vehicle.
3. Maintain the following condition for 20 seconds or more.

Selector lever	: "D" position
Vehicle speed	: 40 km/h (25 MPH) or more
Accelerator pedal position	: 1.0/8 or more

4. Stop the vehicle.
5. Check the first trip DTC.

Is "P0776" detected?

YES	>> Go to TM-125, "Diagnosis Procedure" .
NO	>> INSPECTION END

Diagnosis Procedure

INFOID:0000000011519547

1. CHECK INTERMITTENT INCIDENT

Refer to [GI-42, "Intermittent Incident"](#).

Is the inspection result normal?

YES	>> Replace transaxle assembly. Refer to TM-213, "Removal and Installation" .
NO	>> Repair or replace the malfunction items.

P0778 PRESSURE CONTROL SOLENOID B

< DTC/CIRCUIT DIAGNOSIS >

[CVT: RE0F10J]

P0778 PRESSURE CONTROL SOLENOID B

DTC Logic

INFOID:0000000011519548

DTC DETECTION LOGIC

DTC	CONSULT screen terms (Trouble diagnosis content)	DTC detection condition	Possible cause
P0778	PC SOLENOID B (Pressure Control Solenoid "B" Electrical)	When all of the following conditions are satisfied and this state is maintained for 0.48 seconds: • TCM power supply voltage: More than 11 V • TCM judges that solenoid valve circuit is short- ed to ground.	• Harness or connectors (Secondary pressure solenoid valve circuit is shorted to ground.) • Secondary pressure solenoid valve

DTC CONFIRMATION PROCEDURE

CAUTION:

Always drive vehicle at a safe speed.

1. PREPARATION BEFORE WORK

If another "DTC CONFIRMATION PROCEDURE" occurs just before, turn ignition switch OFF and wait for at least 10 seconds, then perform the next test.

>> GO TO 2.

2. CHECK DTC DETECTION

1. Start the engine and wait for 5 seconds or more.
2. Check the first trip DTC.

Is "P0778" detected?

YES >> Go to [TM-126, "Diagnosis Procedure"](#).
NO >> INSPECTION END

Diagnosis Procedure

INFOID:0000000011519549

1. CHECK CIRCUIT BETWEEN TCM AND CVT UNIT

1. Turn ignition switch OFF.
2. Disconnect TCM connector and CVT unit connector.
3. Check continuity between TCM harness connector terminal and ground.

TCM		—	Continuity
Connector	Terminal		
F23	39	Ground	Not existed

Is the inspection result normal?

YES >> GO TO 2.
NO >> Repair or replace damaged parts.

2. CHECK CIRCUIT BETWEEN CVT UNIT AND GROUND

Check continuity between CVT unit harness connector terminal and ground.

CVT unit		—	Condition	Resistance
Connector	Terminal			
F250	3	Ground	CVT fluid temperature: 20°C (68°F)	5.5 – 7.0 Ω
			CVT fluid temperature: 50°C (122°F)	6.0 – 8.0 Ω
			CVT fluid temperature: 80°C (176°F)	6.5 – 8.5 Ω

Is the inspection result normal?

YES >> Check intermittent incident. Refer to [GI-42, "Intermittent Incident"](#).

P0778 PRESSURE CONTROL SOLENOID B

< DTC/CIRCUIT DIAGNOSIS >

[CVT: RE0F10J]

NO >> GO TO 3.

3.CHECK CIRCUIT BETWEEN CVT UNIT AND CONTROL VALVE

1. Disconnect control valve connector. Refer to [TM-191, "Exploded View"](#).
2. Check continuity between CVT unit harness connector terminal and control valve harness connector terminal.

CVT unit		Control valve		Continuity
Connector	Terminal	Connector	Terminal	
F250	3	F251	2	Existed

Is the inspection result normal?

YES >> GO TO 4.

NO >> Replace terminal cord assembly. Refer to [TM-192, "Removal and Installation"](#).

4.CHECK CIRCUIT BETWEEN CONTROL VALVE AND GROUND

Check continuity between CVT unit harness connector terminal and ground.

Control valve	—	Condition	Resistance
Terminal			
2	Ground	CVT fluid temperature: 20°C (68°F)	5.5 – 7.0 Ω
		CVT fluid temperature: 50°C (122°F)	6.0 – 8.0 Ω
		CVT fluid temperature: 80°C (176°F)	6.5 – 8.5 Ω

Is the inspection result normal?

YES >> Check intermittent incident. Refer to [GI-42, "Intermittent Incident"](#).

NO >> There is malfunction of secondary pressure solenoid valve. Replace transaxle assembly. Refer to [TM-213, "Removal and Installation"](#).

P0779 PRESSURE CONTROL SOLENOID B

< DTC/CIRCUIT DIAGNOSIS >

[CVT: RE0F10J]

P0779 PRESSURE CONTROL SOLENOID B

DTC Logic

INFOID:0000000011519550

DTC DETECTION LOGIC

DTC	Trouble diagnosis name	DTC detection condition	Possible causes
P0779	Pressure control solenoid B Intermittent	When all of the following conditions are satisfied and this state is maintained for 0.2 seconds: • TCM power supply voltage: More than 11 V • P0778 is not detected • TCM judges that solenoid valve circuit is open or shorted to power supply.	• Harness or connector (Secondary pressure solenoid valve circuit open or shorted to power supply) • Secondary pressure solenoid valve

DTC CONFIRMATION PROCEDURE

1. PREPARATION BEFORE WORK

If another "DTC CONFIRMATION PROCEDURE" occurs just before, turn ignition switch OFF and wait for at least 10 seconds, then perform the next test.

>> GO TO 2.

2. CHECK DTC DETECTION

1. Start the engine.
2. Drive the vehicle.
3. Maintain the following conditions for 5 seconds or more.

Selector lever : "D" position
Vehicle speed : 40 km/h (25 MPH) or more

4. Stop the vehicle.
5. Check the first trip DTC.

Is "P0779" detected?

YES >> Go to [TM-128, "Diagnosis Procedure"](#).
NO >> INSPECTION END

Diagnosis Procedure

INFOID:0000000011519551

1. CHECK CIRCUIT BETWEEN TCM AND CVT UNIT

1. Turn ignition switch OFF.
2. Disconnect TCM connector and CVT unit connector.
3. Check continuity between TCM harness connector terminal and CVT unit harness connector terminal.

TCM		CVT unit		Continuity
Connector	Terminal	Connector	Terminal	
F23	39	F24	3	Existed

Is the inspection result normal?

YES >> GO TO 2.
NO >> Repair or replace damaged parts.

2. CHECK CIRCUIT BETWEEN CVT UNIT AND GROUND

Check continuity between CVT unit harness connector terminal and ground.

P0779 PRESSURE CONTROL SOLENOID B

< DTC/CIRCUIT DIAGNOSIS >

[CVT: RE0F10J]

CVT unit		—	Condition	Resistance
Connector	Terminal			
F250	3	Ground	CVT fluid temperature: 20°C (68°F)	5.5 – 7.0 Ω
			CVT fluid temperature: 50°C (122°F)	6.0 – 8.0 Ω
			CVT fluid temperature: 80°C (176°F)	6.5 – 8.5 Ω

Is the inspection result normal?

- YES >> Check intermittent incident. Refer to [GI-42, "Intermittent Incident"](#).
NO >> GO TO 3.

3. CHECK CIRCUIT BETWEEN CVT UNIT AND CONTROL VALVE

1. Disconnect control valve connector. Refer to [TM-191, "Exploded View"](#).
2. Check continuity between CVT unit harness connector terminal and control valve harness connector terminal.

CVT unit		Control valve		Continuity
Connector	Terminal	Connector	Terminal	
F250	3	F251	2	Existed

Is the inspection result normal?

- YES >> GO TO 4.
NO >> Replace terminal cord assembly. Refer to [TM-192, "Removal and Installation"](#).

4. CHECK CIRCUIT BETWEEN CONTROL VALVE AND GROUND

Check continuity between CVT unit harness connector terminal and ground.

Control valve	—	Condition	Resistance
Terminal			
2	Ground	CVT fluid temperature: 20°C (68°F)	5.5 – 7.0 Ω
		CVT fluid temperature: 50°C (122°F)	6.0 – 8.0 Ω
		CVT fluid temperature: 80°C (176°F)	6.5 – 8.5 Ω

Is the inspection result normal?

- YES >> Check intermittent incident. Refer to [GI-42, "Intermittent Incident"](#).
NO >> There is malfunction of secondary pressure solenoid valve. Replace transaxle assembly. Refer to [TM-213, "Removal and Installation"](#).

P0841 TRANSMISSION FLUID PRESSURE SEN/SW A

< DTC/CIRCUIT DIAGNOSIS >

[CVT: RE0F10J]

P0841 TRANSMISSION FLUID PRESSURE SEN/SW A

DTC Logic

INFOID:0000000011519552

DTC DETECTION LOGIC

DTC	CONSULT screen terms (Trouble diagnosis content)	DTC detection condition	Possible cause
P0841	FLUID PRESS SEN/SW A (Transmission Fluid Pressure Sensor/Switch "A" Circuit Range/Performance)	When all of the following conditions are satisfied and this state is maintained for 5 seconds: • TCM power supply voltage: More than 11 V • DTC other than the applicable DTC is not detected. • Primary pulley speed: 300 rpm or more • Secondary pulley speed: 250 rpm or more • Target speed for shifting: Less than 0.1 seconds • Primary pulley pressure is outside the specified value.	• Harness or connectors (Secondary pressure sensor circuit is open or shorted.) • Harness or connectors (Primary pressure sensor circuit is open or shorted.) • Secondary pressure sensor

DTC CONFIRMATION PROCEDURE

CAUTION:

Always drive vehicle at a safe speed.

1. PREPARATION BEFORE WORK

If another "DTC CONFIRMATION PROCEDURE" occurs just before, turn ignition switch OFF and wait for at least 10 seconds, then perform the next test.

>> GO TO 2.

2. CHECK DTC DETECTION

1. Start the engine.
2. Drive the vehicle.
3. Maintain the following condition for 10 seconds or more.

Selector lever : "D" position

Vehicle speed : Constant speed of 40 km/h (25 MPH)

CAUTION:

Also keep the accelerator pedal position constant.

4. Stop the vehicle.
5. Check the first trip DTC.

Is "P0841" detected?

YES >> Go to [TM-130, "Diagnosis Procedure"](#).

NO >> INSPECTION END

Diagnosis Procedure

INFOID:0000000011519553

1. CHECK INTERMITTENT INCIDENT

Refer to [GI-42, "Intermittent Incident"](#).

Is the inspection result normal?

YES >> Replace the transaxle assembly. Refer to [TM-213, "Removal and Installation"](#).

NO >> Repair or replace damaged parts.

P0847 TRANSMISSION FLUID PRESSURE SEN/SW B

< DTC/CIRCUIT DIAGNOSIS >

[CVT: RE0F10J]

P0847 TRANSMISSION FLUID PRESSURE SEN/SW B

DTC Logic

INFOID:0000000011519554

DTC DETECTION LOGIC

DTC	CONSULT screen terms (Trouble diagnosis content)	DTC detection condition	Possible causes
P0847	FLUID PRESS SEN/SW B (Transmission Fluid Pressure Sensor/Switch B Circuit Low)	When all of the following conditions are satisfied and this state is maintained for 5 seconds: • CVT fluid temperature: More than -20°C (-4°F) • TCM power supply voltage: 11 V or more • Secondary pressure sensor voltage: 0.09 V or less	• Harness or connector (Secondary pressure sensor circuit is open or shorted to ground) • Secondary pressure sensor • Control valve assembly

DTC CONFIRMATION PROCEDURE

1. PREPARATION BEFORE WORK

If another "DTC CONFIRMATION PROCEDURE" occurs just before, turn ignition switch OFF and wait for at least 10 seconds, then perform the next test.

>> GO TO 2.

2. CHECK DTC DETECTION

With CONSULT

1. Start the engine.
2. Select "Data Monitor" in "TRANSMISSION".
3. Select "FLUID TEMP".
4. Maintain the following conditions for 10 seconds or more.

FLUID TEMP : -20°C (-4°F)

5. Check the first trip DTC.

With GST

1. Start the engine and wait for at least 10 seconds.

CAUTION:

When the ambient temperature is less than -20°C (-4°F) and the engine is cold, warm up the engine for approximately 5 minutes.

2. Check the first trip DTC.

Is "P0847" detected?

YES >> Go to [TM-131, "Diagnosis Procedure"](#).

NO >> INSPECTION END

Diagnosis Procedure

INFOID:0000000011519555

1. CHECK TCM INPUT SIGNALS

1. Turn ignition switch OFF.
2. Start the engine.
3. Check voltage between TCM harness connector terminals.

+		–	Condition	Voltage
TCM				
Connector	Terminal			
F23	16	Ground	• After engine warm up • Selector lever: "N" position • At idle	1.7 – 1.8 V

Is the inspection result normal?

P0847 TRANSMISSION FLUID PRESSURE SEN/SW B

< DTC/CIRCUIT DIAGNOSIS >

[CVT: RE0F10J]

- YES >> Check intermittent incident. Refer to [GI-42, "Intermittent Incident"](#).
NO >> GO TO 2.

2.CHECK CIRCUIT BETWEEN TCM AND CVT UNIT (PART 1)

1. Turn ignition switch OFF.
2. Disconnect TCM connector and CVT unit connector.
3. Check continuity between TCM harness connector terminals and CVT unit harness connector terminals.

TCM		CVT unit		Continuity
Connector	Terminal	Connector	Terminal	
F23	11	F24	18	Existed
	16		14	
	26		22	

Is the inspection result normal?

- YES >> GO TO 3.
NO >> Repair or replace malfunctioning parts.

3.CHECK CIRCUIT BETWEEN TCM AND CVT UNIT (PART 2)

Check continuity between TCM harness connector terminals and ground.

TCM		—	Continuity
Connector	Terminal		
F23	16	Ground	Not existed
	26		

Is the inspection result normal?

- YES >> GO TO 4.
NO >> Repair or replace malfunctioning parts.

4.CHECK TERMINAL CORD ASSEMBLY (PART 1)

1. Remove terminal cord assembly. Refer to [TM-192, "Removal and Installation"](#).
2. Check continuity between CVT unit harness connector terminals and control valve harness connector terminals.

CVT unit		Control valve		Continuity
Connector	Terminal	Connector	Terminal	
F250	14	F251	12	Existed
	18		13	
	22		11	

Is the inspection result normal?

- YES >> GO TO 5.
NO >> Repair or replace malfunctioning parts.

5.CHECK TERMINAL CORD ASSEMBLY (PART 2)

Check damage of terminal cord assembly.

Is the inspection result normal?

- YES >> There is malfunction of secondary pressure sensor. Replace transaxle assembly. Refer to [TM-213, "Removal and Installation"](#).
NO >> Repair or replace malfunctioning parts.

P0848 TRANSMISSION FLUID PRESSURE SEN/SW B

< DTC/CIRCUIT DIAGNOSIS >

[CVT: RE0F10J]

P0848 TRANSMISSION FLUID PRESSURE SEN/SW B

DTC Logic

INFOID:0000000011519556

DTC DETECTION LOGIC

DTC	CONSULT screen terms (Trouble diagnosis content)	DTC detection condition	Possible causes
P0848	FLUID PRESS SEN/SW B (Transmission Fluid Pressure Sensor/Switch B Circuit Low)	When all of the following conditions are satisfied and this state is maintained for 5 seconds: • CVT fluid temperature: More than -20°C (-4°F) • TCM power supply voltage: More than 11 V • Instruction secondary pressure: 5.7 MPa or less • Secondary pressure sensor voltage: 4.7 V or more	• Harness or connector (Secondary pressure sensor circuit is shorted to power supply) • Secondary pressure sensor • Control valve assembly

DTC CONFIRMATION PROCEDURE

1. PREPARATION BEFORE WORK

If another "DTC CONFIRMATION PROCEDURE" occurs just before, the ignition switch OFF and wait for at least 10 seconds, then perform the next test.

>> GO TO 2.

2. CHECK DTC DETECTION

With CONSULT

1. Start the engine.
2. Select "Data Monitor" in "TRANSMISSION".
3. Select "FLUID TEMP".
4. Maintain the following conditions for 10 seconds or more.

FLUID TEMP : More than -20°C (-4°F)

5. Check the first trip DTC.

With GST

1. Start the engine and wait for at least 10 seconds.

CAUTION:

When the ambient temperature is less than -20°C (-4°F) and the engine is cold, warm up the engine for approximately 5 minutes.

2. Check the first trip DTC.

Is "P0848" detected?

YES >> Go to [TM-133, "Diagnosis Procedure"](#).

NO >> INSPECTION END

Diagnosis Procedure

INFOID:0000000011519557

1. CHECK TCM INPUT SIGNALS

1. Turn ignition switch OFF.
2. Start the engine.
3. Check voltage between TCM harness connector terminals.

P0848 TRANSMISSION FLUID PRESSURE SEN/SW B

< DTC/CIRCUIT DIAGNOSIS >

[CVT: RE0F10J]

+		–	Condition	Voltage
TCM				
Connector	Terminal			
F23	16	Ground	• After engine warm up • Selector lever: “N” position • At idle	1.7 – 1.8 V

Is the inspection result normal?

YES >> Check intermittent incident. Refer to [GI-42, "Intermittent Incident"](#).

NO >> GO TO 2.

2.CHECK SECONDARY PRESSURE SENSOR POWER CIRCUIT

1. Turn ignition switch OFF.
2. Connect TCM connector.
3. Turn ignition switch ON.
4. Disconnect CVT unit connector.
5. Check voltage between CVT unit harness connector terminal and ground.

+		–	Voltage
CVT unit			
Connector	Terminal		
F24	22	Ground	Approx. 5.0 V

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace malfunctioning parts.

3.CHECK SECONDARY PRESSURE SENSOR SIGNAL CIRCUIT

Check voltage between CVT unit harness connector terminal and ground.

+		–	Voltage
CVT unit			
Connector	Terminal		
F24	14	Ground	Approx. 0 V

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair or replace malfunctioning parts.

4.CHECK TERMINAL CORD ASSEMBLY

1. Turn ignition switch OFF.
2. Remove terminal cord assembly. Refer to [TM-192, "Removal and Installation"](#).
3. Check damage of terminal cord assembly.

Is the inspection result normal?

YES >> There is malfunction of secondary pressure sensor. Replace transaxle assembly. Refer to [TM-213, "Removal and Installation"](#).

NO >> Repair or replace malfunctioning parts.

P084C TRANSMISSION FLUID PRESSURE SEN/SW H

< DTC/CIRCUIT DIAGNOSIS >

[CVT: RE0F10J]

P084C TRANSMISSION FLUID PRESSURE SEN/SW H

DTC Logic

INFOID:0000000011519558

DTC DETECTION LOGIC

DTC	CONSULT screen terms (Trouble diagnosis content)	DTC detection condition	Possible causes
P084C	FLUID PRESS SEN/SW H (Transmission Fluid Pressure Sensor/Switch H Circuit Low)	When all of the following conditions are satisfied and this state is maintained for 5 seconds: • CVT fluid temperature: More than -20°C (-4°F) • TCM power supply voltage: More than 11 V • Primary pressure sensor voltage: 0.09 V or less	• Harness or connector (Primary pressure sensor circuit is open or shorted to ground) • Primary pressure sensor • Control valve assembly

DTC CONFIRMATION PROCEDURE

1. PREPARATION BEFORE WORK

If another "DTC CONFIRMATION PROCEDURE" occurs just before, turn ignition switch OFF and wait for at least 10 seconds, then perform the next test.

>> GO TO 2.

2. CHECK DTC DETECTION

With CONSULT

1. Start the engine.
2. Select "Data Monitor" in "TRANSMISSION".
3. Select "FLUID TEMP".
4. Maintain the following conditions for 10 seconds or more.

FLUID TEMP : More than -20°C (-4°F)

5. Check the first trip DTC.

With GST

1. Start the engine and wait for at least 10 seconds.

CAUTION:

When the ambient temperature is less than -20°C (-4°F) and the engine is cold, warm up the engine for approximately 5 minutes.

2. Check the first trip DTC.

Is "P084C" detected?

YES >> Go to [TM-135, "Diagnosis Procedure"](#).

NO >> INSPECTION END

Diagnosis Procedure

INFOID:0000000011519559

1. CHECK TCM INPUT SIGNALS

1. Turn ignition switch OFF.
2. Start the engine.
3. Check voltage between TCM harness connector terminals.

+		–	Condition	Voltage
TCM				
Connector	Terminal			
F23	17	Ground	• After engine warm up • Selector lever: “N” position • At idle	1.32 – 1.34 V

Is the inspection result normal?

P084C TRANSMISSION FLUID PRESSURE SEN/SW H

< DTC/CIRCUIT DIAGNOSIS >

[CVT: RE0F10J]

- YES >> Check intermittent incident. Refer to [GI-42, "Intermittent Incident"](#).
NO >> GO TO 2.

2.CHECK CIRCUIT BETWEEN TCM AND CVT UNIT (PART 1)

1. Turn ignition switch OFF.
2. Disconnect TCM connector and CVT unit connector.
3. Check continuity between TCM harness connector terminals and CVT unit harness connector terminals.

TCM		CVT unit		Continuity
Connector	Terminal	Connector	Terminal	
F23	11	F24	18	Existed
	17		13	
	26		22	

Is the inspection result normal?

- YES >> GO TO 3.
NO >> Repair or replace malfunctioning parts.

3.CHECK CIRCUIT BETWEEN TCM AND CVT UNIT (PART 2)

Check continuity between TCM harness connector terminals and ground.

TCM		—	Continuity
Connector	Terminal		
F23	17	Ground	Not existed
	26		

Is the inspection result normal?

- YES >> GO TO 4.
NO >> Repair or replace malfunctioning parts.

4.CHECK TERMINAL CORD ASSEMBLY (PART 1)

1. Remove terminal cord assembly. Refer to [TM-192, "Removal and Installation"](#).
2. Check continuity between CVT unit harness connector terminals and control valve harness connector terminals.

CVT unit		Control valve		Continuity
Connector	Terminal	Connector	Terminal	
F250	13	F251	10	Existed
	18		13	
	22		11	

Is the inspection result normal?

- YES >> GO TO 5.
NO >> Repair or replace malfunctioning parts.

5.CHECK TERMINAL CORD ASSEMBLY (PART 2)

Check damage of terminal cord assembly.

Is the inspection result normal?

- YES >> There is malfunction of primary pressure sensor. Replace transaxle assembly. Refer to [TM-213, "Removal and Installation"](#).
NO >> Repair or replace malfunctioning parts.

P084D TRANSMISSION FLUID PRESSURE SEN/SW H

< DTC/CIRCUIT DIAGNOSIS >

[CVT: RE0F10J]

P084D TRANSMISSION FLUID PRESSURE SEN/SW H

DTC Logic

INFOID:0000000011519560

DTC DETECTION LOGIC

DTC	CONSULT screen terms (Trouble diagnosis content)	DTC detection condition	Possible causes
P084D	FLUID PRESS SEN/SW H (Transmiision Fluid Pressure Sensor/Switch "H" Circuit High)	When all of the following conditions are satisfied and this state is maintained for 5 seconds: • CVT fluid temperature: More than -20°C (-4°F) • TCM power supply voltage: More than 11 V • Primary pressure sensor voltage: 4.7 V or more	• Harness or connector (Primary pressure sensor circuit is open or shorted to ground) • Primary pressure sensor • Control valve assembly

DTC CONFIRMATION PROCEDURE

1.PREPARATION BEFORE WORK

If another "DTC CONFIRMATION PROCEDURE" occurs just before, turn ignition switch OFF and wait for at least 10 seconds, then perform the next test.

>> GO TO 2.

2.CHECK DTC DETECTION

With CONSULT

1. Start the engine.
2. Select "Data Monitor" in "TRANSMISSION".
3. Select "FLUID TEMP".
4. Maintain the following conditions for 10 seconds or more.

FLUID TEMP : More than -20°C (-4°F)

5. Check the first trip DTC.

With GST

1. Start the engine and wait for at least 10 seconds.

CAUTION:

When the ambient temperature is less than -20°C (-4°F) and the engine is cold, warm up the engine for approximately 5 minutes.

2. Check the first trip DTC.

Is "P084D"detected?

YES >> Go to [TM-137, "Diagnosis Procedure"](#).

NO >> INSPECTION END

Diagnosis Procedure

INFOID:0000000011519561

1.CHECK TCM INPUT SIGNALS

1. Turn ignition switch OFF.
2. Start the engine.
3. Check voltage between TCM harness connector terminals.

+		–	Condition	Voltage
TCM				
Connector	Terminal			
F23	17	Ground	• After engine warm up • Selector lever: "N" position • At idle	1.32 – 1.34 V

Is the inspection result normal?

P084D TRANSMISSION FLUID PRESSURE SEN/SW H

< DTC/CIRCUIT DIAGNOSIS >

[CVT: RE0F10J]

- YES >> Check intermittent incident. Refer to [GI-42, "Intermittent Incident"](#).
NO >> GO TO 2.

2.CHECK PRIMARY PRESSURE SENSOR POWER CIRCUIT

1. Turn ignition switch OFF.
2. Connect TCM connector.
3. Turn ignition switch ON.
4. Disconnect CVT unit connector.
5. Check voltage between CVT unit harness connector terminal and ground.

+		–	Voltage
CVT unit			
Connector	Terminal		
F24	22	Ground	Approx. 5.0 V

Is the inspection result normal?

- YES >> GO TO 3.
NO >> Repair or replace malfunctioning parts.

3.CHECK PRIMARY PRESSURE SENSOR SIGNAL CIRCUIT

Check voltage between CVT unit harness connector terminal and ground.

+		–	Voltage
CVT unit			
Connector	Terminal		
F24	13	Ground	Approx. 0 V

Is the inspection result normal?

- YES >> GO TO 4.
NO >> Repair or replace malfunctioning parts.

4.CHECK TERMINAL CORD ASSEMBLY

1. Turn ignition switch OFF.
2. Remove terminal cord assembly. Refer to [TM-192, "Removal and Installation"](#).
3. Check damage of terminal cord assembly.

Is the inspection result normal?

- YES >> There is malfunction of primary pressure sensor. Replace transaxle assembly. Refer to [TM-213, "Removal and Installation"](#).
NO >> Repair or replace malfunctioning parts.

P0863 TCM COMMUNICATION

< DTC/CIRCUIT DIAGNOSIS >

[CVT: RE0F10J]

P0863 TCM COMMUNICATION

DTC Logic

INFOID:0000000011519562

DTC DETECTION LOGIC

DTC	CONSULT screen terms (Trouble diagnosis content)	DTC detection condition	Possible causes
P0863	CONTROL UNIT (CAN) (TCM Communication Circuit)	An error is detected at the initial CAN diagnosis of TCM.	TCM

DTC CONFIRMATION PROCEDURE

1. PREPARATION BEFORE WORK

If another "DTC CONFIRMATION PROCEDURE" occurs just before, turn ignition switch OFF and wait for at least 10 seconds, then perform the next test.

>> GO TO 2.

2. CHECK DTC DETECTION

1. Start the engine.
2. Check the DTC.

Is "P0863" detected?

YES >> Go to [TM-139, "Diagnosis Procedure"](#).
NO >> INSPECTION END

Diagnosis Procedure

INFOID:0000000011519563

1. CHECK INTERMITTENT INCIDENT

Refer to [GI-42, "Intermittent Incident"](#).

Is the inspection result normal?

YES >> Replace TCM. Refer to [TM-190, "Removal and Installation"](#).
NO >> Repair or replace malfunctioning parts.

P0890 TCM

DTC Logic

INFOID:000000011519564

DTC DETECTION LOGIC

DTC	CONSULT screen terms (Trouble diagnosis content)	DTC detection condition	Possible causes
P0890	TCM (Transmission Control Module Power Relay Sense Circuit Low)	When all of the following conditions are satisfied and this state is maintained for 0.2 seconds: • TCM power supply voltage: More than 11 V • Battery voltage: Less than 8.4 V	Harness or connector (TCM power supply (back-up) circuit is open or shorted.)

DTC CONFIRMATION PROCEDURE

1. PREPARATION BEFORE WORK

If another "DTC CONFIRMATION PROCEDURE" occurs just before, turn ignition switch OFF and wait for at least 10 seconds, then perform the next test.

>> GO TO 2.

2. CHECK DTC DETECTION

1. Start the engine and wait for 5 seconds or more.
2. Check the DTC.

Is "P0890" detected?

YES >> Go to [TM-140, "Diagnosis Procedure"](#).

NO >> INSPECTION END

Diagnosis Procedure

INFOID:000000011519565

1. CHECK TCM POWER SUPPLY (BACK-UP) CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect TCM connector.
3. Check voltage between TCM harness connector terminals and ground.

TCM		Ground	Voltage
Connector	Terminal		
F23	45	Ground	10 – 16 V
	46		

Is the inspection result normal?

YES >> Check intermittent incident. Refer to [GI-42, "Intermittent Incident"](#).

NO >> GO TO 2.

2. DETECT MALFUNCTIONING ITEMS

Check the following items:

- Open or short circuit of harness between battery positive terminal and TCM connectors terminals 45 and 46.
- 10A fuse (No.11, located in the fuse and fusible link block). Refer to [PG-94, "Fuse and Fusible Link Arrangement"](#).

Is the inspection result normal?

YES >> Check intermittent incident. Refer to [GI-42, "Intermittent Incident"](#).

NO >> Repair or replace malfunctioning parts.

P0962 PRESSURE CONTROL SOLENOID A

< DTC/CIRCUIT DIAGNOSIS >

[CVT: RE0F10J]

P0962 PRESSURE CONTROL SOLENOID A

DTC Logic

INFOID:0000000011519566

DTC DETECTION LOGIC

DTC	CONSULT screen terms (Trouble diagnosis content)	DTC detection condition	Possible causes
P0962	PC SOLENOID A (Pressure Control Solenoid A Control Circuit Low)	When all of the following conditions are satisfied and this state is maintained for 0.2 seconds: • TCM power supply voltage: More than 11 V • TCM judges that solenoid valve circuit is shorted to ground.	• Harness or connector (Line pressure solenoid valve circuit is shorted to ground) • Line pressure solenoid valve

DTC CONFIRMATION PROCEDURE

1. PREPARATION BEFORE WORK

If another "DTC CONFIRMATION PROCEDURE" occurs just before, turn ignition switch OFF and wait for at least 10 seconds, then perform the next test.

>> GO TO 2.

2. CHECK DTC DETECTION

1. Start the engine and wait for 5 seconds or more.
2. Check the first trip DTC.

Is "P0962" detected?

YES >> Go to [TM-141, "Diagnosis Procedure"](#).
NO >> INSPECTION END

Diagnosis Procedure

INFOID:0000000011519567

1. CHECK CIRCUIT BETWEEN TCM AND CVT UNIT

1. Turn ignition switch OFF.
2. Disconnect TCM connector and CVT unit connector.
3. Check continuity between TCM harness connector terminal and ground.

TCM		—	Continuity
Connector	Terminal		
F23	30	Ground	Not existed

Is the inspection result normal?

YES >> GO TO 2.
NO >> Repair or replace damaged parts.

2. CHECK CIRCUIT BETWEEN CVT UNIT AND GROUND

Check continuity between CVT unit harness connector terminal and ground.

CVT unit		—	Condition	Resistance
Connector	Terminal			
F250	1	Ground	CVT fluid temperature: 20°C (68°F)	5.5 – 7.0 Ω
			CVT fluid temperature: 50°C (122°F)	6.0 – 8.0 Ω
			CVT fluid temperature: 80°C (176°F)	6.5 – 8.5 Ω

Is the inspection result normal?

YES >> Check intermittent incident. Refer to [GI-42, "Intermittent Incident"](#).
NO >> GO TO 3.

P0962 PRESSURE CONTROL SOLENOID A

< DTC/CIRCUIT DIAGNOSIS >

[CVT: RE0F10J]

3. CHECK CIRCUIT BETWEEN CVT UNIT AND CONTROL VALVE

1. Disconnect control valve connector. Refer to [TM-191, "Exploded View"](#).
2. Check continuity between CVT unit harness connector terminal and control valve harness connector terminal.

CVT unit		Control valve		Continuity
Connector	Terminal	Connector	Terminal	
F250	1	F251	1	Existed

Is the inspection result normal?

YES >> GO TO 4.

NO >> Replace terminal cord assembly. Refer to [TM-192, "Removal and Installation"](#).

4. CHECK CIRCUIT BETWEEN CONTROL VALVE AND GROUND

Check continuity between CVT unit harness connector terminal and ground.

Control valve	—	Condition	Resistance
Terminal			
1	Ground	CVT fluid temperature: 20°C (68°F)	5.5 – 7.0 Ω
		CVT fluid temperature: 50°C (122°F)	6.0 – 8.0 Ω
		CVT fluid temperature: 80°C (176°F)	6.5 – 8.5 Ω

Is the inspection result normal?

YES >> Check intermittent incident. Refer to [GI-42, "Intermittent Incident"](#).

NO >> There is malfunction of line pressure solenoid valve. Replace transaxle assembly. Refer to [TM-213, "Removal and Installation"](#).

P0963 PRESSURE CONTROL SOLENOID A

< DTC/CIRCUIT DIAGNOSIS >

[CVT: RE0F10J]

P0963 PRESSURE CONTROL SOLENOID A

DTC Logic

INFOID:0000000011519568

DTC DETECTION LOGIC

DTC	CONSULT screen terms (Trouble diagnosis content)	DTC detection condition	Possible causes
P0963	PC SOLENOID A (Pressure Control Solenoid A Control Circuit High)	When all of the following conditions are satisfied and this state is maintained for 0.2 seconds: • TCM power supply voltage: More than 11 V • P0962 is not detected • TCM judges that solenoid valve circuit is open.	• Harness or connector (Line pressure solenoid valve circuit is open or shorted to power supply) • Line pressure solenoid valve

DTC CONFIRMATION PROCEDURE

1. PREPARATION BEFORE WORK

If another "DTC CONFIRMATION PROCEDURE" occurs just before, turn ignition switch OFF and wait for at least 10 seconds, then perform the next test.

>> GO TO 2.

2. CHECK DTC DETECTION

1. Start the engine and wait for 5 seconds or more.
2. Check the first trip DTC.

Is "P0963" detected?

YES >> Go to [TM-143, "Diagnosis Procedure"](#).
NO >> INSPECTION END

Diagnosis Procedure

INFOID:0000000011519569

1. CHECK CIRCUIT BETWEEN TCM AND CVT UNIT

1. Turn ignition switch OFF.
2. Disconnect TCM connector and CVT unit connector.
3. Check continuity between TCM harness connector terminal and ground.

TCM		CVT unit		Continuity
Connector	Terminal	Connector	Terminal	
F23	30	F24	1	Existed

Is the inspection result normal?

YES >> GO TO 2.
NO >> Repair or replace damaged parts.

2. CHECK CIRCUIT BETWEEN CVT UNIT AND GROUND

Check continuity between CVT unit harness connector terminal and ground.

CVT unit		—	Condition	Resistance
Connector	Terminal			
F250	1	Ground	CVT fluid temperature: 20°C (68°F)	5.5 – 7.0 Ω
			CVT fluid temperature: 50°C (122°F)	6.0 – 8.0 Ω
			CVT fluid temperature: 80°C (176°F)	6.5 – 8.5 Ω

Is the inspection result normal?

YES >> Check intermittent incident. Refer to [GI-42, "Intermittent Incident"](#).

P0963 PRESSURE CONTROL SOLENOID A

< DTC/CIRCUIT DIAGNOSIS >

[CVT: RE0F10J]

NO >> GO TO 3.

3. CHECK CIRCUIT BETWEEN CVT UNIT AND CONTROL VALVE

1. Disconnect control valve connector. Refer to [TM-191, "Exploded View"](#).
2. Check continuity between CVT unit harness connector terminal and control valve harness connector terminal.

CVT unit		Control valve		Continuity
Connector	Terminal	Connector	Terminal	
F250	1	F251	1	Existed

Is the inspection result normal?

YES >> GO TO 4.

NO >> Replace terminal cord assembly. Refer to [TM-192, "Removal and Installation"](#).

4. CHECK CIRCUIT BETWEEN CONTROL VALVE AND GROUND

Check continuity between CVT unit harness connector terminal and ground.

Control valve	—	Condition	Resistance
Terminal			
1	Ground	CVT fluid temperature: 20°C (68°F)	5.5 – 7.0 Ω
		CVT fluid temperature: 50°C (122°F)	6.0 – 8.0 Ω
		CVT fluid temperature: 80°C (176°F)	6.5 – 8.5 Ω

Is the inspection result normal?

YES >> Check intermittent incident. Refer to [GI-42, "Intermittent Incident"](#).

NO >> There is malfunction of line pressure solenoid valve. Replace transaxle assembly. Refer to [TM-213, "Removal and Installation"](#).

P0965 PRESSURE CONTROL SOLENOID B

< DTC/CIRCUIT DIAGNOSIS >

[CVT: RE0F10J]

P0965 PRESSURE CONTROL SOLENOID B

DTC Logic

INFOID:0000000011519570

DTC DETECTION LOGIC

DTC	CONSULT screen terms (Trouble diagnosis content)	DTC detection condition	Possible causes
P0965	PC SOLENOID B (Pressure Control Solenoid B Control Circuit Range Performance)	When any of 1 or 2 is satisfied and this state is maintained for 10 seconds: - When all of the following conditions are satisfied: - DTC other than the applicable DTC is not detected. - Engine speed: More than 625 rpm - Selector lever: Other than P/N position - CVT fluid temperature: More than -20°C (-4°F) - TCM power supply: More than 11 V - The difference between instruction pressure of primary pressure and 10-msec-ago instruction primary pressure is 0 MPa or more - Instruction pressure of primary pressure: 0.86 MPa or more - Instruction pressure of primary pressure - primary pressure: More than 1.2 MPa - When all of the following conditions are satisfied and this state is maintained for 1 second: - DTC other than the applicable DTC is not detected. - CVT fluid temperature: More than -20°C (-4°F) - Selector lever: Other than P/N position - Engine speed: More than 625 rpm - Instruction pressure of primary pressure: More than 2 MPa - Primary pressure: 0.4 MPa or less 2. When all of the following conditions are satisfied: - DTC other than the applicable DTC is not detected. - CVT fluid temperature: More than -20°C (-4°F) - Selector lever: Other than P/N position - TCM power supply: More than 11 V - When all of the following conditions are satisfied and this state is maintained for 5.5 seconds: - DTC other than the applicable DTC is not detected. - CVT fluid temperature: More than -20°C (-4°F) - Selector lever: Other than P/N position - Primary pressure - instruction pressure of primary pressure: 1.2 MPa or more - The difference between instruction pressure of primary pressure and 10-msec-ago instruction primary pressure is 0 MPa or more - Primary pressure - instruction pressure of primary pressure: More than 1.2 MPa	- Harness or connector (Primary pressure solenoid valve circuit is open or shorted.) - Primary pressure solenoid valve

DTC CONFIRMATION PROCEDURE

P0965 PRESSURE CONTROL SOLENOID B

< DTC/CIRCUIT DIAGNOSIS >

[CVT: RE0F10J]

1. PREPARATION BEFORE WORK

If another "DTC CONFIRMATION PROCEDURE" occurs just before, turn ignition switch OFF and wait for at least 10 seconds, then perform the next test.

>> GO TO 2.

2. CHECK DTC DETECTION

1. Start the engine.
2. Drive the vehicle.
3. Maintain the following conditions for 20 seconds or more.

Vehicle speed : 40 km/h (25 MPH) or more

4. Stop the vehicle.
5. Check the first trip DTC.

Is "P0965" detected?

- YES >> Go to [TM-146, "Diagnosis Procedure"](#).
NO >> INSPECTION END

Diagnosis Procedure

INFOID:0000000011519571

1. CHECK INTERMITTENT INCIDENT

Refer to [GI-42, "Intermittent Incident"](#).

Is the inspection result normal?

- YES >> Replace transaxle assembly. Refer to [TM-213, "Removal and Installation"](#).
NO >> Repair or replace malfunctioning parts.

P0966 PRESSURE CONTROL SOLENOID B

< DTC/CIRCUIT DIAGNOSIS >

[CVT: RE0F10J]

P0966 PRESSURE CONTROL SOLENOID B

DTC Logic

INFOID:0000000011519572

DTC DETECTION LOGIC

DTC	CONSULT screen terms (Trouble diagnosis content)	DTC detection condition	Possible causes
P0966	PC SOLENOID B (Pressure Control Solenoid B Control Circuit Low)	When all of the following conditions are satisfied and this state is maintained for 0.48 seconds: • TCM power supply voltage: More than 11 V • TCM judges that solenoid valve circuit is shorted to ground.	• Harness or connector (Primary pressure solenoid valve circuit shorted to ground) • Primary pressure solenoid valve

DTC CONFIRMATION PROCEDURE

1. PREPARATION BEFORE WORK

If another "DTC CONFIRMATION PROCEDURE" occurs just before, turn ignition switch OFF and wait for at least 10 seconds, then perform the next test.

>> GO TO 2.

2. CHECK DTC DETECTION

1. Start the engine and wait for 5 seconds or more.
2. Check the first trip DTC.

Is "P0966" detected?

YES >> Go to [TM-147, "Diagnosis Procedure"](#).
NO >> INSPECTION END

Diagnosis Procedure

INFOID:0000000011519573

1. CHECK CIRCUIT BETWEEN TCM AND CVT UNIT

1. Turn ignition switch OFF.
2. Disconnect TCM connector and CVT unit connector.
3. Check continuity between TCM harness connector terminal and ground.

TCM		—	Continuity
Connector	Terminal		
F23	40	Ground	Not existed

Is the inspection result normal?

YES >> GO TO 2.
NO >> Repair or replace damaged parts.

2. CHECK CIRCUIT BETWEEN CVT UNIT AND GROUND

Check continuity between CVT unit harness connector terminal and ground.

CVT unit		—	Condition	Resistance
Connector	Terminal			
F250	2	Ground	CVT fluid temperature: 20°C (68°F)	5.5 – 7.0 Ω
			CVT fluid temperature: 50°C (122°F)	6.0 – 8.0 Ω
			CVT fluid temperature: 80°C (176°F)	6.5 – 8.5 Ω

Is the inspection result normal?

YES >> Check intermittent incident. Refer to [GI-42, "Intermittent Incident"](#).
NO >> GO TO 3.

P0966 PRESSURE CONTROL SOLENOID B

< DTC/CIRCUIT DIAGNOSIS >

[CVT: RE0F10J]

3. CHECK CIRCUIT BETWEEN CVT UNIT AND CONTROL VALVE

1. Disconnect control valve connector. Refer to [TM-191, "Exploded View"](#).
2. Check continuity between CVT unit harness connector terminal and control valve harness connector terminal.

CVT unit		Control valve		Continuity
Connector	Terminal	Connector	Terminal	
F250	2	F251	9	Existed

Is the inspection result normal?

YES >> GO TO 4.

NO >> Replace terminal cord assembly. Refer to [TM-192, "Removal and Installation"](#).

4. CHECK CIRCUIT BETWEEN CONTROL VALVE AND GROUND

Check continuity between CVT unit harness connector terminal and ground.

Control valve	—	Condition	Resistance
Terminal			
9	Ground	CVT fluid temperature: 20°C (68°F)	5.5 – 7.0 Ω
		CVT fluid temperature: 50°C (122°F)	6.0 – 8.0 Ω
		CVT fluid temperature: 80°C (176°F)	6.5 – 8.5 Ω

Is the inspection result normal?

YES >> Check intermittent incident. Refer to [GI-42, "Intermittent Incident"](#).

NO >> There is malfunction of primary pressure solenoid valve. Replace transaxle assembly. Refer to [TM-213, "Removal and Installation"](#).

P0967 PRESSURE CONTROL SOLENOID B

< DTC/CIRCUIT DIAGNOSIS >

[CVT: RE0F10J]

P0967 PRESSURE CONTROL SOLENOID B

DTC Logic

INFOID:0000000011519574

DTC DETECTION LOGIC

DTC	CONSULT screen terms (Trouble diagnosis content)	DTC detection condition	Possible causes
P0967	PC SOLENOID B (Pressure Control Solenoid B Control Circuit High)	When all of the following conditions are satisfied and this state is maintained for 0.2 seconds: • TCM power supply voltage: More than 11 V • P0966 is not detected • TCM judges that solenoid valve circuit is open.	• Harness or connector (Primary pressure solenoid valve circuit open or shorted to power supply) • Primary pressure solenoid valve

DTC CONFIRMATION PROCEDURE

1. PREPARATION BEFORE WORK

If another "DTC CONFIRMATION PROCEDURE" occurs just before, turn ignition switch OFF and wait for at least 10 seconds, then perform the next test.

>> GO TO 2.

2. CHECK DTC DETECTION

1. Start the engine and wait for 5 seconds or more.
2. Check the first trip DTC.

Is "P0967" detected?

YES >> Go to [TM-149, "Diagnosis Procedure"](#).
NO >> INSPECTION END

Diagnosis Procedure

INFOID:0000000011519575

1. CHECK CIRCUIT BETWEEN TCM AND CVT UNIT

1. Turn ignition switch OFF.
2. Disconnect TCM connector and CVT unit connector.
3. Check continuity between TCM harness connector terminal and ground.

TCM		CVT unit		Continuity
Connector	Terminal	Connector	Terminal	
F23	40	F24	2	Existed

Is the inspection result normal?

YES >> GO TO 2.
NO >> Repair or replace damaged parts.

2. CHECK CIRCUIT BETWEEN CVT UNIT AND GROUND

Check continuity between CVT unit harness connector terminal and ground.

CVT unit		—	Condition	Resistance
Connector	Terminal			
F250	2	Ground	CVT fluid temperature: 20°C (68°F)	5.5 – 7.0 Ω
			CVT fluid temperature: 50°C (122°F)	6.0 – 8.0 Ω
			CVT fluid temperature: 80°C (176°F)	6.5 – 8.5 Ω

Is the inspection result normal?

YES >> Check intermittent incident. Refer to [GI-42, "Intermittent Incident"](#).

P0967 PRESSURE CONTROL SOLENOID B

< DTC/CIRCUIT DIAGNOSIS >

[CVT: RE0F10J]

NO >> GO TO 3.

3. CHECK CIRCUIT BETWEEN CVT UNIT AND CONTROL VALVE

1. Disconnect control valve connector. Refer to [TM-191, "Exploded View"](#).
2. Check continuity between CVT unit harness connector terminal and control valve harness connector terminal.

CVT unit		Control valve		Continuity
Connector	Terminal	Connector	Terminal	
F250	2	F251	9	Existed

Is the inspection result normal?

YES >> GO TO 4.

NO >> Replace terminal cord assembly. Refer to [TM-192, "Removal and Installation"](#).

4. CHECK CIRCUIT BETWEEN CONTROL VALVE AND GROUND

Check continuity between CVT unit harness connector terminal and ground.

Control valve	—	Condition	Resistance
Terminal			
9	Ground	CVT fluid temperature: 20°C (68°F)	5.5 – 7.0 Ω
		CVT fluid temperature: 50°C (122°F)	6.0 – 8.0 Ω
		CVT fluid temperature: 80°C (176°F)	6.5 – 8.5 Ω

Is the inspection result normal?

YES >> Check intermittent incident. Refer to [GI-42, "Intermittent Incident"](#).

NO >> There is malfunction of primary pressure solenoid valve. Replace transaxle assembly. Refer to [TM-213, "Removal and Installation"](#).

P1586 G SENSOR

< DTC/CIRCUIT DIAGNOSIS >

[CVT: RE0F10J]

P1586 G SENSOR

DTC Logic

INFOID:0000000011552033

DTC DETECTION LOGIC

DTC	Trouble diagnosis name	DTC detection condition	Possible causes
P1586	G Sensor Circuit Electrical	When 1 or 2 is satisfied and maintained for 5 seconds or more, and this state is satisfied two times within the same DC: 1. When all of the following conditions are satisfied: - G sensor detection voltage: 0.675 V or less - TCM power supply voltage: More than 11 V 2. When all of the following conditions are satisfied: - G sensor detection voltage: 3.13 V or more - TCM power supply voltage: More than 11 V	• Harness or connector (G sensor circuit) • G sensor

NOTE:

DC stands for "DRIVING CYCLE" and indicates a series of driving cycle of "Ignition switch OFF → ON → driving → OFF".

DTC CONFIRMATION PROCEDURE

CAUTION:

Be careful of the driving speed.

1. PREPARATION BEFORE WORK

If another "DTC CONFIRMATION PROCEDURE" occurs just before, turn ignition switch OFF and wait for at least 10 seconds, then perform the next test.

>> GO TO 2.

2. CHECK DTC DETECTION

④ With CONSULT

1. Start the engine.
2. Drive the vehicle for 5 seconds or more.
3. Stop the vehicle.

CAUTION:

Never stop the engine.

4. Repeat step 2 through 3.
5. Check the DTC.

"P1586" detected?

YES >> Go to [TM-151. "Diagnosis Procedure"](#).

NO >> INSPECTION END

Diagnosis Procedure

INFOID:0000000011552034

1. CHECK G SENSOR SIGNAL

④ With CONSULT

1. Park the vehicle on a level surface.
2. Turn ignition switch ON.
3. Select "Data Monitor" in "TRANSMISSION"
4. Select "G SEN SLOPE".
5. Swing the vehicle and check if value varies between -40.45% and 40.45%.

Monitor item	Condition	Standard
G SEN SLOPE	Flat road	0%
	Uphill	Positive value (Maximum 40.45%)
	Downhill	Negative value (Minimum -40.45%)

< DTC/CIRCUIT DIAGNOSIS >

Is the inspection result normal?

- YES >> GO TO 2.
NO >> GO TO 3.

2. G SENSOR CALIBRATION (PART 1)

Ⓐ With CONSULT

1. Select "Self Diagnostic Results" in "TRANSMISSION".
2. Touch "Erase".

>> Perform "G SENSOR CALIBRATION". Refer to [TM-78, "Work Procedure"](#).

3. CHECK SENSOR POWER SUPPLY

1. Turn ignition switch OFF.
2. Disconnect G sensor connector.
3. Turn ignition switch ON.
4. Check voltage between G sensor harness connector terminal and ground.

+		—	Voltage (Approx.)
G sensor			
Connector	Terminal		
B39	3	Ground	5.0 V

Is the inspection result normal?

- YES >> GO TO 4.
NO >> GO TO 8.

4. CHECK CIRCUIT BETWEEN TCM AND G SENSOR (PART 1)

1. Turn ignition switch OFF.
2. Disconnect TCM connector.
3. Check continuity between TCM harness connector terminals and G sensor harness connector terminals.

TCM		G sensor		Continuity
Connector	Terminal	Connector	Terminal	
F23	11	B39	2	Existed
	14		1	

Is the inspection result normal?

- YES >> GO TO 5.
NO >> Repair or replace malfunctioning parts.

5. CHECK CIRCUIT BETWEEN TCM AND G SENSOR (PART 2)

Check continuity between TCM harness connector terminals and ground.

TCM		—	Continuity
Connector	Terminal		
F23	11	Ground	Not existed
	14		

Is the inspection result normal?

- YES >> GO TO 6.
NO >> Repair or replace malfunctioning parts.

6. CHECK G SENSOR

1. Remove G sensor. Refer to [TM-197, "Removal and Installation"](#).
2. Connect the all connectors.
3. Turn ignition switch ON.

P1586 G SENSOR


< DTC/CIRCUIT DIAGNOSIS >

[CVT: RE0F10J]

- Check voltage between TCM harness connector terminal and ground.

← : Direction of gravitational force

+		—	Test condition	Voltage (Approx.)
TCM				
Connector	Terminal			
F23	14	Ground	Vertical (−1G) ㉠	1.17 V
			Horizontal ㉢	2.5 V
			Vertical (1G) ㉡	3.83 V



Is the inspection result normal?

YES >> GO TO 7.

NO >> Replace G sensor. Refer to [TM-197, "Removal and Installation"](#).

7. G SENSOR CALIBRATION (PART 2)

With CONSULT

- Install G sensor. Refer to [TM-197, "Removal and Installation"](#).
- Select "Self Diagnostic Results" in "TRANSMISSION".
- Touch "Erase".

>> Perform "G SENSOR CALIBRATION". Refer to [TM-78, "Work Procedure"](#).

8. CHECK SENSOR POWER SUPPLY CIRCUIT (PART 1)

- Turn ignition switch OFF.
- Disconnect TCM connector.
- Check continuity between TCM harness connector terminal and G sensor harness connector terminal.

TCM		G sensor		Continuity
Connector	Terminal	Connector	Terminal	
F23	26	B39	3	Existed

Is the inspection result normal?

YES >> GO TO 9.

NO >> Repair or replace malfunctioning parts.

9. CHECK SENSOR POWER SUPPLY CIRCUIT (PART 2)

Check continuity between TCM harness connector terminal and ground.

TCM		—	Continuity
Connector	Terminal		
F23	26	Ground	Not existed

Is the inspection result normal?

YES >> Check intermittent incident. Refer to [GI-42, "Intermittent Incident"](#).

NO >> Repair or replace malfunctioning parts.

P1588 G SENSOR

< DTC/CIRCUIT DIAGNOSIS >

[CVT: RE0F10J]

P1588 G SENSOR

DTC Logic

INFOID:0000000011552035

DTC DETECTION LOGIC

DTC	Trouble diagnosis name	DTC detection condition	Possible causes
P1588	G Sensor Circuit Range/Performance	When 1 is satisfied and 2 is satisfied two times within the same DC: 1. When all of the following conditions are satisfied and this state is maintained for 1 second: - TCM power supply voltage: More than 11 V - The difference between the current G sensor detection voltage and the previous G sensor detection voltage of 10 msec. before: ± 0.015 V or less 2. When all of the following conditions are satisfied and this state is maintained for 5 seconds: - The difference between the current acceleration and the previous acceleration of 1 second before: 0.2677m/s^2 (0.0273 G) - The difference between the current G sensor detection voltage and the previous G sensor detection voltage of 10 msec. before: ± 0.015 V or more	G Sensor

NOTE:

DC stands for "DRIVING CYCLE" and indicates a series of driving cycle of "Ignition switch OFF → ON → driving → OFF".

DTC CONFIRMATION PROCEDURE

CAUTION:

Be careful of the driving speed.

1. PREPARATION BEFORE WORK

If another "DTC CONFIRMATION PROCEDURE" occurs just before, turn ignition switch OFF and wait for at least 10 seconds, then perform the next test.

>> GO TO 2.

2. CHECK DTC DETECTION

With CONSULT

1. Start the engine.
2. Select "Data Monitor" in "TRANSMISSION".
3. Select "G SPEED".
4. Drive the vehicle.
5. Maintain the following conditions for 5 seconds or more.

Selector lever : "L" position

G SPEED : 0.05 G or more

6. Stop the vehicle.

CAUTION:

Never stop the engine.

7. Repeat step 4 through 6.
8. Check the DTC.

"P1588" detected?

- YES >> Go to [TM-155, "Diagnosis Procedure"](#).
NO >> INSPECTION END

Diagnosis Procedure

1.CHECK G SENSOR SIGNAL

④With CONSULT

1. Park the vehicle on a level surface.
2. Turn ignition switch ON.
3. Select "Data Monitor" in "TRANSMISSION"
4. Select "G SEN SLOPE".
5. Swing the vehicle and check if value varies between -40.45% and 40.45%.

Monitor item	Condition	Standard
G SEN SLOPE	Flat road	0%
	Uphill	Positive value (Maximum 40.45%)
	Downhill	Negative value (Minimum -40.45%)

Is the inspection result normal?

YES >> GO TO 2.

NO >> GO TO 3.

2.G SENSOR CALIBRATION (PART 1)

④With CONSULT

1. Select "Self Diagnostic Results" in "TRANSMISSION".
2. Touch "Erase".


>> Perform "G SENSOR CALIBRATION". Refer to [TM-78, "Work Procedure"](#).

3.CHECK G SENSOR

1. Remove G sensor. Refer to [TM-197, "Removal and Installation"](#).
2. Connect the all connectors.
3. Turn ignition switch ON.
4. Check voltage between TCM harness connector terminal and ground.

← : Direction of gravitational force

+		—	Test condition	Voltage (Approx.)
TCM				
Connector	Terminal			
F23	14	Ground	Vertical (−1G) ㉠	1.17 V
			Horizontal ㉢	2.5 V
			Vertical (1G) ㉡	3.83 V



Is the inspection result normal?

YES >> GO TO 4.

NO >> Replace G sensor. Refer to [TM-197, "Removal and Installation"](#).

4.G SENSOR CALIBRATION (PART 2)

④With CONSULT

1. Install G sensor. Refer to [TM-197, "Removal and Installation"](#).
2. Select "Self Diagnostic Results" in "TRANSMISSION".
3. Touch "Erase".

>> Perform "G SENSOR CALIBRATION". Refer to [TM-78, "Work Procedure"](#).

P2765 INPUT SPEED SENSOR B

< DTC/CIRCUIT DIAGNOSIS >

[CVT: RE0F10J]

P2765 INPUT SPEED SENSOR B

DTC Logic

INFOID:0000000011519576

DTC DETECTION LOGIC

DTC	CONSULT screen terms (Trouble diagnosis content)	DTC detection condition	Possible causes
P2765	INPUT SPEED SENSOR B (Input/Turbine Speed Sensor B Circuit)	When 1 is satisfied and any of 2, 3 or 4 is satisfied and this state is maintained for 5 seconds: - When all of the following conditions are satisfied: - TCM power supply voltage: More than 11 V - After range change completion, it spends 2 seconds or more. - When all of the following conditions are satisfied and this state is maintained for 5 seconds: - Secondary pulley speed: Less than 149 rpm - Primary pulley speed: 1,000 rpm or more - When all of the following conditions are satisfied and this state is maintained for 0.5 seconds: - 10-msec-ago secondary pulley speed: 1000 rpm or more - Now secondary pulley speed: 0 rpm - When all of the following conditions are satisfied and this state is maintained for 5 seconds: - Range: D or DS - Engine speed: 450 rpm or more - Primary pulley speed: 300 rpm or more - Secondary pulley speed: 300 rpm or more - Input speed: 300 rpm or more - The difference between engine speed and primary pulley speed is 1,000 rpm or less - The difference between engine speed and input speed is 1,000 rpm or less - The difference between primary pulley speed and input speed is 1,000 rpm or less - Lock-up command is being given (except for slip lock-up) - DTC other than the applicable DTC is not detected. - When any of following items are satisfied: • Primary pulley speed/secondary pulley speed: More than 2.9 • Primary pulley speed/secondary pulley speed: Less than 0.3	• Harness or connector (Output speed sensor circuit is open or shorted) • Output speed sensor

DTC CONFIRMATION PROCEDURE

CAUTION:

Be careful of the driving speed.

1. PREPARATION BEFORE WORK

If another "DTC CONFIRMATION PROCEDURE" occurs just before, turn ignition switch OFF and wait for at least 10 seconds, then perform the next test.

P2765 INPUT SPEED SENSOR B

< DTC/CIRCUIT DIAGNOSIS >

[CVT: RE0F10J]

>> GO TO 2.

2.CHECK DTC DETECTION

1. Start the engine.
2. Drive the vehicle.
3. Maintain the following conditions for 10 seconds or more.

Selector lever : "D" position
Engine speed : 1,200 rpm or more
Vehicle speed : 55 km/h (34 MPH) or more

4. Stop the vehicle.
5. Check the first trip DTC.

Is "P2765" detected?

YES >> Go to [TM-157, "Diagnosis Procedure"](#).
NO >> INSPECTION END

Diagnosis Procedure

INFOID:0000000011519577

1.CHECK OUTPUT SPEED SENSOR POWER CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect output speed sensor connector.
3. Turn ignition switch ON.
4. Check voltage between output speed sensor harness connector terminal and ground.

+		–	Voltage
Output speed sensor			
Connector	Terminal		
F19	3	Ground	10 – 16 V

Is the inspection result normal?

YES >> GO TO 2.
NO >> GO TO 6.

2.CHECK OUTPUT SPEED SENSOR GROUND CIRCUIT

Check continuity between output speed sensor harness connector terminal and ground.

Output speed sensor		—	Continuity
Connector	Terminal		
F19	1	Ground	Existed

Is the inspection result normal?

YES >> GO TO 3.
NO >> Repair or replace malfunctioning parts.

3.CHECK CIRCUIT BETWEEN OUTPUT SPEED SENSOR AND TCM (PART 1)

1. Turn ignition switch OFF.
2. Disconnect TCM connector.
3. Check continuity between output speed sensor harness connector terminal and TCM harness connector terminal.

Output speed sensor		TCM		Continuity
Connector	Terminal	Connector	Terminal	
F19	2	F23	34	Existed

Is the inspection result normal?

P2765 INPUT SPEED SENSOR B

[CVT: RE0F10J]

< DTC/CIRCUIT DIAGNOSIS >

- YES >> GO TO 4.
NO >> Repair or replace malfunctioning parts.

4.CHECK CIRCUIT BETWEEN OUTPUT SPEED SENSOR AND TCM (PART 2)

Check continuity between output speed sensor harness connector terminal and ground.

Output speed sensor		—	Continuity
Connector	Terminal		
F19	2	Ground	Not existed

Is the inspection result normal?

- YES >> GO TO 5.
NO >> Repair or replace malfunctioning parts.

5.CHECK TCM INPUT SIGNALS

1. Connect all of disconnected connectors.
2. Lift the vehicle.
3. Start the engine.
4. Check frequency of output speed sensor.

+		—	Condition	Standard
TCM				
Connector	Terminal			
F23	34	Ground	• Selector lever: “L” position • Vehicle speed: 20 km/h (12 MPH)	Approx. 200 Hz 2.5mSec/div  5V/div JSDIA1904GB

Is the inspection result normal?

- YES >> Check intermittent incident. Refer to [GI-42, "Intermittent Incident"](#).
NO >> Replace output speed sensor. Refer to [TM-201, "Removal and Installation"](#).

6.DETECT MALFUNCTIONING ITEMS

Check the following items:

- Harness open circuit or short circuit between ignition switch and IPDM E/R. Refer to [PG-56, "Wiring Diagram - IGNITION POWER SUPPLY -"](#).
- Harness open circuit or short circuit between output speed sensor and IPDM E/R.
- 10A fuse (No.43, located in the IPDM E/R). Refer to [PG-95, "Fuse, Connector and Terminal Arrangement"](#).
- IPDM E/R

Is the check result normal?

- YES >> Check intermittent incident. Refer to [GI-42, "Intermittent Incident"](#).
NO >> Repair or replace malfunctioning parts.

P2813 SELECT SOLENOID

< DTC/CIRCUIT DIAGNOSIS >

[CVT: RE0F10J]

P2813 SELECT SOLENOID

DTC Logic

INFOID:0000000011519578

DTC DETECTION LOGIC

DTC	CONSULT screen terms (Trouble diagnosis content)	DTC detection condition	Possible causes
P2813	SELECT SOLENOID (Select solenoid)	When any of 1, or 2 is satisfied: - When all the following conditions are established three times in 1DC - Precondition - DTC other than the applicable DTC is not detected. - Throttle position: More than 6.27 deg. - Vehicle speed: Less than 3 km/h (1 MPH) - CVT fluid temperature: More than 20°C (68°F) - Selector lever: Other than P, N - Turbine speed when performed N → D, N (P) → R: More than 500 rpm - TCM power supply voltage: More than 11 V - Detection time - N → D: 0.4 seconds - N → R: 0.3 seconds - P → R: 0.3 seconds - When all of the following conditions are satisfied and this state is maintained for 30 seconds: - The counting of time continues while all of the following conditions are satisfied and stops when the conditions become unsatisfied (the count is maintained). When accumulated time reaches 30 seconds (Clutch is judged as engaged and the count is reset.) - Selector lever: Other than P, N - Vehicle speed: Less than 3 km/h (1 MPH) - Differences between primary pulley speed and secondary speed speed: Less than 120 rpm - Clutch instructions pressure: 0.95 MPa or more - Differences between turbine speed and input speed speed: Less than 200 rpm - Turbine speed – speed: More than 450 rpm - DTC other than the applicable DTC is not detected. - TCM power supply voltage: More than 11 V	Select solenoid valve

NOTE:

DC stands for “DRIVING CYCLE” and indicates a series of driving cycle of “Ignition switch OFF → ON → driving → OFF”.

DTC CONFIRMATION PROCEDURE

CAUTION:

Be careful of the driving speed.

1. PREPARATION BEFORE WORK

P2813 SELECT SOLENOID

< DTC/CIRCUIT DIAGNOSIS >

[CVT: RE0F10J]

If another "DTC CONFIRMATION PROCEDURE" occurs just before, turn ignition switch OFF and wait for at least 10 seconds, then perform the next test.

>> GO TO 2.

2.CHECK DTC DETECTION 1

1. Start the engine.
2. Maintain the following conditions. (Keep 30seconds or more after the selector lever shifted.)

Selector lever : N→ D, N → R, P→ R

3. Check the first trip DTC.

Is "P2813"detected?

YES >> Go to [TM-160, "Diagnosis Procedure"](#).
NO >> INSPECTION END

Diagnosis Procedure

INFOID:0000000011519579

1.CHECK INTERMITTENT INCIDENT

Refer to [GI-42, "Intermittent Incident"](#).

Is the inspection result normal?

YES >> Replace transaxle assembly. Refer to [TM-213, "Removal and Installation"](#).
NO >> Repair or replace malfunctioning parts.

P2814 SELECT SOLENOID

< DTC/CIRCUIT DIAGNOSIS >

[CVT: RE0F10J]

P2814 SELECT SOLENOID

DTC Logic

INFOID:0000000011519580

DTC DETECTION LOGIC

DTC	CONSULT screen terms (Trouble diagnosis content)	DTC detection condition	Possible causes
P2814	SELECT SOLENOID (Select solenoid)	When all of the following conditions are satisfied and this state is maintained for 0.48 seconds: • TCM power supply voltage: 11 V or more • TCM judges that solenoid valve circuit is shorted to ground.	• Harness or connector (Select solenoid valve circuit shorted to ground) • Select solenoid valve

DTC CONFIRMATION PROCEDURE

CAUTION:

Be careful of the driving speed.

1. PREPARATION BEFORE WORK

If another "DTC CONFIRMATION PROCEDURE" occurs just before, turn ignition switch OFF and wait for at least 10 seconds, then perform the next test.

>> GO TO 2.

2. CHECK DTC DETECTION

1. Start the engine.
2. Maintain the following conditions. (Keep 5 seconds or more after the selector lever shifted.)

Selector lever N → D, N → R, P → R

3. Check the first trip DTC.

Is "P2814" detected?

- YES >> Go to [TM-161, "Diagnosis Procedure"](#).
NO >> INSPECTION END

Diagnosis Procedure

INFOID:0000000011519581

1. CHECK CIRCUIT BETWEEN TCM AND CVT UNIT

1. Turn ignition switch OFF.
2. Disconnect TCM connector and CVT unit connector.
3. Check continuity between TCM harness connector terminal and ground.

TCM		—	Continuity
Connector	Terminal		
F23	37	Ground	Not existed

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Repair or replace damaged parts.

2. CHECK CIRCUIT BETWEEN CVT UNIT AND GROUND

Check continuity between CVT unit harness connector terminal and ground.

P2814 SELECT SOLENOID

< DTC/CIRCUIT DIAGNOSIS >

[CVT: RE0F10J]

CVT unit		—	Condition	Resistance
Connector	Terminal			
F250	4	Ground	CVT fluid temperature: 20°C (68°F)	5.5 – 7.0 Ω
			CVT fluid temperature: 50°C (122°F)	6.0 – 8.0 Ω
			CVT fluid temperature: 80°C (176°F)	6.5 – 8.5 Ω

Is the inspection result normal?

YES >> Check intermittent incident. Refer to [GI-42, "Intermittent Incident"](#).

NO >> GO TO 3.

3. CHECK CIRCUIT BETWEEN CVT UNIT AND CONTROL VALVE

1. Disconnect control valve connector. Refer to [TM-191, "Exploded View"](#).
2. Check continuity between CVT unit harness connector terminal and control valve harness connector terminal.

CVT unit		Control valve		Continuity
Connector	Terminal	Connector	Terminal	
F250	4	F251	4	Existed

Is the inspection result normal?

YES >> GO TO 4.

NO >> Replace terminal cord assembly. Refer to [TM-192, "Removal and Installation"](#).

4. CHECK CIRCUIT BETWEEN CONTROL VALVE AND GROUND

Check continuity between CVT unit harness connector terminal and ground.

Control valve	—	Condition	Resistance
Terminal			
4	Ground	CVT fluid temperature: 20°C (68°F)	5.5 – 7.0 Ω
		CVT fluid temperature: 50°C (122°F)	6.0 – 8.0 Ω
		CVT fluid temperature: 80°C (176°F)	6.5 – 8.5 Ω

Is the inspection result normal?

YES >> Check intermittent incident. Refer to [GI-42, "Intermittent Incident"](#).

NO >> There is malfunction of select solenoid solenoid valve. Replace transaxle assembly. Refer to [TM-213, "Removal and Installation"](#).

P2815 SELECT SOLENOID

< DTC/CIRCUIT DIAGNOSIS >

[CVT: RE0F10J]

P2815 SELECT SOLENOID

DTC Logic

INFOID:0000000011519582

DTC DETECTION LOGIC

DTC	CONSULT screen terms (Trouble diagnosis content)	DTC detection condition	Possible causes
P2815	SELECT SOLENOID (Select solenoid)	When all of the following conditions are satisfied and this state is maintained for 0.2 seconds: • TCM power supply voltage: More than 11 V • TCM judges that solenoid valve circuit is open. • P2814 is not detected.	• Harness or connector (Select solenoid valve circuit open or shorted to power supply) • Select solenoid valve

DTC CONFIRMATION PROCEDURE

1.PREPARATION BEFORE WORK

If another "DTC CONFIRMATION PROCEDURE" occurs just before, turn ignition switch OFF and wait for at least 10 seconds, then perform the next test.

>> GO TO 2.

2.CHECK DTC DETECTION

1. Start the engine.
2. Maintain the following conditions. (Keep 5 seconds or more after the selector lever shifted.)

Selector lever N → D, N → R, P → R

3. Check the first trip DTC.

Is "P2815" detected?

YES >> Go to [TM-163. "Diagnosis Procedure"](#).
NO >> INSPECTION END

Diagnosis Procedure

INFOID:0000000011519583

1.CHECK CIRCUIT BETWEEN TCM AND CVT UNIT

1. Turn ignition switch OFF.
2. Disconnect TCM connector and CVT unit connector.
3. Check continuity between TCM harness connector terminal and ground.

TCM		CVT unit		Continuity
Connector	Terminal	Connector	Terminal	
F23	37	F24	4	Existed

Is the inspection result normal?

YES >> GO TO 2.
NO >> Repair or replace damaged parts.

2.CHECK CIRCUIT BETWEEN CVT UNIT AND GROUND

Check continuity between CVT unit harness connector terminal and ground.

P2815 SELECT SOLENOID

< DTC/CIRCUIT DIAGNOSIS >

[CVT: RE0F10J]

CVT unit		—	Condition	Resistance
Connector	Terminal			
F250	4	Ground	CVT fluid temperature: 20°C (68°F)	5.5 – 7.0 Ω
			CVT fluid temperature: 50°C (122°F)	6.0 – 8.0 Ω
			CVT fluid temperature: 80°C (176°F)	6.5 – 8.5 Ω

Is the inspection result normal?

YES >> Check intermittent incident. Refer to [GI-42, "Intermittent Incident"](#).

NO >> GO TO 3.

3. CHECK CIRCUIT BETWEEN CVT UNIT AND CONTROL VALVE

1. Disconnect control valve connector. Refer to [TM-191, "Exploded View"](#).
2. Check continuity between CVT unit harness connector terminal and control valve harness connector terminal.

CVT unit		Control valve		Continuity
Connector	Terminal	Connector	Terminal	
F250	4	F251	4	Existed

Is the inspection result normal?

YES >> GO TO 4.

NO >> Replace terminal cord assembly. Refer to [TM-192, "Removal and Installation"](#).

4. CHECK CIRCUIT BETWEEN CONTROL VALVE AND GROUND

Check continuity between CVT unit harness connector terminal and ground.

Control valve	—	Condition	Resistance
Terminal			
4	Ground	CVT fluid temperature: 20°C (68°F)	5.5 – 7.0 Ω
		CVT fluid temperature: 50°C (122°F)	6.0 – 8.0 Ω
		CVT fluid temperature: 80°C (176°F)	6.5 – 8.5 Ω

Is the inspection result normal?

YES >> Check intermittent incident. Refer to [GI-42, "Intermittent Incident"](#).

NO >> There is malfunction of select solenoid solenoid valve. Replace transaxle assembly. Refer to [TM-213, "Removal and Installation"](#).

MAIN POWER SUPPLY AND GROUND CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CVT: RE0F10J]

MAIN POWER SUPPLY AND GROUND CIRCUIT

Diagnosis Procedure

INFOID:0000000011519584

1.CHECK TCM POWER CIRCUIT (PART 1)

1. Turn ignition switch OFF.
2. Disconnect TCM connector.
3. Check voltage between TCM harness connector terminals and ground.

+		–	Voltage
TCM			
Connector	Terminal		
F23	45	Ground	10 – 16 V
	46		

Is the inspection result normal?

- YES >> GO TO 2.
NO >> GO TO 4.

2.CHECK TCM POWER CIRCUIT (PART 2)

Check voltage between TCM harness connector terminals and ground.

+		–	Condition	Voltage
TCM				
Connector	Terminal			
F23	47	Ground	Ignition switch ON	10 – 16 V
			Ignition switch OFF	Approx. 0 V
	48		Ignition switch ON	10 – 16 V
			Ignition switch OFF	Approx. 0 V

Is the inspection result normal?

- YES >> GO TO 3.
NO >> GO TO 5.

3.CHECK TCM GROUND CIRCUIT

Check continuity between TCM harness connector terminals and ground.

TCM		—	Continuity
Connector	Terminal		
F23	41	Ground	Existed
	42		

Is the inspection result normal?

- YES >> Check intermittent incident. Refer to [GI-42, "Intermittent Incident"](#).
NO >> Repair or replace malfunctioning parts.

4.DETECT MALFUNCTION ITEMS (PART 1)

Check the following items:

- Open or short circuit in harness between battery positive terminal and TCM connector terminal 45, and 46.
- 10A fuse (No.11, located in the fuse and fusible link block). Refer to [PG-94, "Fuse and Fusible Link Arrangement"](#).

Is the inspection result normal?

- YES >> Check intermittent incident. Refer to [GI-42, "Intermittent Incident"](#).
NO >> Repair or replace malfunctioning parts.

MAIN POWER SUPPLY AND GROUND CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CVT: RE0F10J]

5.CHECK CIRCUIT BETWEEN IPDM E/R AND TCM (PART 1)

1. Turn ignition switch OFF.
2. Disconnect IPDM E/R connector.
3. Check continuity between IPDM E/R harness connector terminal and TCM harness connector terminals.

IPDM E/R		TCM		Continuity
Connector	Terminal	Connector	Terminal	
F12	58	F23	47	Existed
			48	

Is the check result normal?

YES >> GO TO 6.

NO >> Repair or replace malfunctioning parts.

6.CHECK CIRCUIT BETWEEN IPDM E/R AND TCM (PART 2)

Check continuity between IPDM E/R harness connector terminal and ground.

IPDM E/R		—	Continuity
Connector	Terminal		
F12	58	Ground	Not existed

Is the check result normal?

YES >> GO TO 7.

NO >> Repair or replace malfunctioning parts.

7.DETECT MALFUNCTIONING ITEMS (PART 2)

Check the following items:

- Open or short circuit in harness between ignition switch and IPDM E/R. Refer to [PG-56, "Wiring Diagram - IGNITION POWER SUPPLY -"](#).
- 10A fuse (No.43, located in the IPDM E/R). Refer to [PG-95, "Fuse, Connector and Terminal Arrangement"](#).
- IPDM E/R

Is the check result normal?

YES >> Check intermittent incident. Refer to [GI-42, "Intermittent Incident"](#).

NO >> Repair or replace malfunctioning parts.

SHIFT POSITION INDICATOR CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CVT: RE0F10J]

SHIFT POSITION INDICATOR CIRCUIT

Component Function Check

INFOID:0000000011564841

1.CHECK SHIFT POSITION INDICATOR

1. Start the engine.
2. Check that correct selector lever position ("P", "R", "N", "D", "L") is displayed as selector lever is moved into each position.

Is the inspection result normal?

- YES >> INSPECTION END
NO >> Go to [TM-167, "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:0000000011564842

1.CHECK INPUT SIGNALS

 With CONSULT

1. Start the engine.
2. Select "Data Monitor" in "TRANSMISSION".
3. Select "RANGE".
4. Check that correct selector lever position ("P", "R", "N", "D", "L") is displayed as selector lever is moved into each position.

Is the inspection result normal?

- YES >> INSPECTION END
NO-1 (The actual gear position changes, but the shift position indicator is not indicated.)>>Perform "Self Diagnostic Results" in "TRANSMISSION".
NO-2 (The actual gear position and the indication on the shift position indicator do not coincide.)>>Perform "Self Diagnostic Results" in "TRANSMISSION".
NO-3 (Only a specific position or positions is/are not indicated on the shift position indicator.)>>Check the combination meter. Refer to [MWI-35, "CONSULT Function"](#).

OVERDRIVE CONTROL SWITCH

< DTC/CIRCUIT DIAGNOSIS >

[CVT: RE0F10J]

OVERDRIVE CONTROL SWITCH

Component Function Check

INFOID:0000000011564843

1.CHECK O/D OFF INDICATOR LAMP

When ignition switch is turned ON, check that O/D OFF indicator lamp in combination meter illuminates during 2 seconds approximately.

Is the inspection result normal?

YES >> GO TO 2.

NO >> Go to [TM-170, "Diagnosis Procedure"](#).

2.CHECK OVERDRIVE CONTROL SWITCH

- Shift the selector lever to "D" position.
- When overdrive control switch is operated, check that O/D OFF indicator lamp in combination meter illuminates/extinguishes.

Is the inspection result normal?

YES >> INSPECTION END.

NO >> Go to [TM-168, "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:0000000011564844

1.CHECK OVERDRIVE CONTROL SWITCH CIRCUIT

- Turn ignition switch OFF.
- Disconnect the CVT shift selector connector.
- Turn ignition switch ON.
- Check the voltage between CVT shift selector harness connector terminals.

CVT shift selector			Voltage (Approx.)
Connector	+	−	
	Terminal		
M57	1	4	12 V

Is the inspection result normal?

YES >> GO TO 2.

NO >> GO TO 4.

2.CHECK OVERDRIVE CONTROL SWITCH

Check the overdrive control switch. Refer to [TM-169, "Component Inspection \(Overdrive Control Switch\)"](#).

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace damaged parts.

3.CHECK CVT SHIFT SELECTOR HARNESS


Check the continuity between harness plate (A) and CVT shift selector (B).

Harness plate	CVT shift selector	Continuity
	Terminal	
C	1	Existed
D	4	

Is the inspection result normal?

YES >> Check intermittent incident. Refer to [GI-42, "Intermittent Incident"](#).

NO >> Replace the CVT shift selector assembly. Refer to [TM-185, "Removal and Installation"](#).



OVERDRIVE CONTROL SWITCH

< DTC/CIRCUIT DIAGNOSIS >

[CVT: RE0F10J]

4.CHECK GROUND CIRCUIT

Check the continuity between CVT shift selector harness connector terminal and ground.

CVT shift selector		—	Continuity
Connector	Terminal		
M57	4	Ground	Existed

Is the inspection result normal?

YES >> GO TO 5.

NO >> Repair or replace damaged parts.

5.CHECK HARNESS BETWEEN CVT SHIFT SELECTOR AND COMBINATION METER

1. Turn ignition switch OFF.
2. Disconnect the combination meter connector.
3. Check the continuity between CVT shift selector harness connector terminal and combination meter harness connector terminal.

CVT shift selector		Combination meter		Continuity
Connector	Terminal	Connector	Terminal	
M57	1	M34	32	Existed

4. Check continuity between CVT shift selector harness connector terminal and ground.

CVT shift selector		—	Continuity
Connector	Terminal		
M57	1	Ground	Not existed

Is the inspection result normal?

YES >> GO TO 6.

NO >> Repair or replace damaged parts.

6.CHECK COMBINATION METER INPUT SIGNAL

1. Connect all of the disconnected connectors.
2. Turn ignition switch ON.
3. Select "Data Monitor" in "METER/M&A".
4. Select "O/D OFF SW".
5. Check that "O/D OFF SW" turns ON/OFF when overdrive control switch is operated. Refer to [MWI-40, "Reference Value"](#).

Is the inspection result normal?

YES >> Check intermittent incident. Refer to [GI-42, "Intermittent Incident"](#).

NO >> Replace the combination meter. Refer to [MWI-90, "Removal and Installation"](#).

Component Inspection (Overdrive Control Switch)

INFOID:0000000011564845

1.CHECK OVERDRIVE CONTROL SWITCH


Check the continuity between wires of select lever knob (1).

Condition	Continuity
Overdrive control switch is depressed	Existed
Overdrive control switch is released	Not existed

Is the inspection result normal?

YES >> INSPECTION END

NO >> Replace the selector lever knob. Refer to [TM-185, "Removal and Installation"](#).



OD OFF INDICATOR LAMP

Component Function Check

INFOID:0000000011564846

1.CHECK O/D OF INDICATOR LAMP

When ignition switch is turned ON, check that O/D OFF indicator lamp in combination meter illuminates during 2 seconds approximately.

Is the inspection result normal?

YES >> INSPECTION END

NO >> Go to [TM-170. "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:0000000011564847

1.CHECK DTC (TCM)

Ⓔ With CONSULT

1. Turn ignition switch ON.
2. Check "Self Diagnostic Results" in "TRANSMISSION".

Is any DTC detected?

YES >> Check DTC detected item. Refer to [TM-58. "DTC Index"](#).

NO >> GO TO 2.

2.CHECK DTC (COMBINATION METER)

Ⓔ With CONSULT

Check "Self Diagnostic Results" in "METER/M&A".

Is any DTC detected?

YES >> Check DTC detected item. Refer to [MWI-48. "DTC Index"](#).

NO >> GO TO 3.

3.CHECK COMBINATION METER INPUT SIGNAL

Ⓔ With CONSULT

1. Shift the selector lever to "D" position.
2. Select "Data Monitor" in "METER/M&A".
3. Select "O/D OFF IND".
4. Check that "O/D OFF IND" turns ON/OFF when overdrive control switch is operated. Refer to [MWI-40. "Reference Value"](#).

Is the inspection result normal?

YES >> Replace the combination meter. Refer to [MWI-90. "Removal and Installation"](#).

NO >> GO TO 4.

4.CHECK TCM INPUT/OUTPUT SIGNAL

Ⓔ With CONSULT

1. Select "Data Monitor" in "TRANSMISSION".
2. Select "SPORT MODE SW".
3. Check that "SPORT MODE SW" turns ON/OFF when overdrive control switch is operated. Refer to [TM-47. "Reference Value"](#).

Is the inspection result normal?

YES >> Replace the combination meter. Refer to [MWI-90. "Removal and Installation"](#).

NO >> Check the overdrive control switch. Refer to [TM-168. "Diagnosis Procedure"](#).

SHIFT LOCK SYSTEM

< DTC/CIRCUIT DIAGNOSIS >

[CVT: RE0F10J]

SHIFT LOCK SYSTEM

Component Function Check

INFOID:0000000011564848

1. CHECK CVT SHIFT LOCK OPERATION

1. Turn ignition switch ON.
2. Move selector lever to "P" position.
3. Attempt to shift selector lever to any other position with brake pedal released.

Can selector lever be shifted to any other position?

- YES >> Go to [TM-171, "Diagnosis Procedure"](#).
NO >> GO TO 2.

2. CHECK CVT SHIFT LOCK OPERATION

Attempt to shift selector lever to any other position with brake pedal depressed.

Can the selector lever be shifted to any other position?

- YES >> INSPECTION END
NO >> Go to [TM-171, "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:0000000011564849

1. CHECK POWER SOURCE

1. Turn ignition switch OFF.
2. Disconnect the fuse block (J/B) connector.
3. Turn ignition switch ON.
4. Check the voltage between fuse block (J/B) connector terminal and ground.

+		-	Voltage (Approx.)
Fuse block (J/B)			
Connector	Terminal		
E100	4F	Ground	10 – 16 V

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Check the following.
 - 10A fuse [No. 3, located in fuse block (J/B)]
 - Ignition switch

2. CHECK HARNESS BETWEEN FUSE BLOCK (J/B) AND STOP LAMP SWITCH (PART 1)

1. Turn ignition switch OFF.
2. Disconnect the stop lamp switch connector.
3. Check continuity between fuse block (J/B) harness connector terminal and stop lamp switch harness connector terminal.

Fuse block (J/B)		Stop lamp switch		Continuity
Connector	Terminal	Connector	Terminal	
E100	4F	E115	3	Existed

Is the inspection result normal?

- YES >> GO TO 3.
NO >> Repair or replace damaged parts.

3. CHECK HARNESS BETWEEN FUSE BLOCK (J/B) AND STOP LAMP SWITCH (PART 2)

Check continuity between stop lamp switch harness connector terminal and ground.

SHIFT LOCK SYSTEM

< DTC/CIRCUIT DIAGNOSIS >

[CVT: RE0F10J]

Stop lamp switch		—	Continuity
Connector	Terminal		
E115	3	Ground	Not existed

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair or replace damaged parts.

4.CHECK STOP LAMP SWITCH

Check the stop lamp switch. Refer to [TM-173. "Component Inspection \(Stop Lamp Switch\)"](#).

Is the inspection result normal?

YES >> GO TO 5.

NO >> Replace stop lamp switch. Refer to [BR-20. "Removal and Installation"](#).

5.CHECK HARNESS BETWEEN STOP LAMP SWITCH AND CVT SHIFT SELECTOR (PART 1)

1. Disconnect the CVT shift selector connector.
2. Check the continuity between stop lamp switch harness connector terminal and CVT shift selector harness connector terminal.

Stop lamp switch		CVT shift selector		Continuity
Connector	Terminal	Connector	Terminal	
E115	4	M57	6	Existed

Is the inspection result normal?

YES >> GO TO 6.

NO >> Repair or replace damaged parts.

6.CHECK HARNESS BETWEEN STOP LAMP SWITCH AND CVT SHIFT SELECTOR (PART 2)

Check the continuity between control harness connector terminal and ground.

CVT shift selector		—	Continuity
Connector	Terminal		
M57	6	Ground	Not existed

Is the inspection result normal?

YES >> GO TO 7.

NO >> Repair or replace damaged parts.

7.CHECK GROUND CIRCUIT

Check the continuity between CVT shift selector harness connector terminal and ground.

CVT shift selector		—	Continuity
Connector	Terminal		
M57	7	Ground	Existed

Is the inspection result normal?

YES >> GO TO 8.

NO >> Repair or replace damaged parts.

8.CHECK CVT SHIFT SELECTOR

1. Shift selector lever to "P" position.
2. Check the continuity between CVT shift selector connector terminals.

CVT shift selector			Continuity
Connector	Terminal		
M57	6	7	Existed

Is the inspection result normal?

SHIFT LOCK SYSTEM

< DTC/CIRCUIT DIAGNOSIS >

[CVT: RE0F10J]

YES >> GO TO 9.

NO >> Replace CVT shift selector. Refer to [TM-185, "Removal and Installation"](#).

9.CHECK SHIFT LOCK SOLENOID

1. Remove the shift lock unit. Refer to [TM-186, "Disassembly and Assembly"](#).

2. Check the shift lock solenoid. Refer to [TM-173, "Component Inspection \(Shift Lock Solenoid\)"](#).

Is the inspection result normal?

YES >> INSPECTION END

NO >> Repair or replace damaged parts.

Component Inspection (Stop Lamp Switch)

INFOID:0000000011564850

1.CHECK STOP LAMP SWITCH

Check the continuity between stop lamp switch connector terminals.

Stop lamp switch		Condition	Continuity
Terminal			
3	4	Depressed brake pedal	Existed
		Released brake pedal	Not existed

Is the inspection result normal?

YES >> INSPECTION END

NO >> Replace the stop lamp switch. Refer to [BR-20, "Removal and Installation"](#).

Component Inspection (Shift Lock Solenoid)

INFOID:0000000011564851

1.CHECK SHIFT LOCK SOLENOID

Apply voltage to CVT shift selector connector terminals and then check that shift lock solenoid is activated.

CAUTION:

Connect the fuse between the terminals when applying the voltage.

+ (fuse)	-	Condition	Status
CVT shift selector connector			
Terminal			
6	7	• Park switch: ON • Apply 12 V direct current between terminals 6 and 7.	Shift lock solenoid operates

Is the inspection result normal?

YES >> INSPECTION END

NO >> Replace the shift lock unit. Refer to [TM-186, "Disassembly and Assembly"](#).

SYMPTOM DIAGNOSIS

CVT CONTROL SYSTEM

Symptom Table

INFOID:000000011519597

- The diagnosis item number indicates the order of check. Start checking in the order from 1.
- Perform diagnoses of symptom table 1 before symptom table 2.

Symptom Table 1

Symptom		Engine system											Stall test											CVT position											Power supply											Control valve											CVT fluid level and state											Ignition switch and starter																			
		EC-103											TM-58											TM-80											TM-81											TM-165											TM-213											TM-180											PG-56, STR-6								
Shift Shock	Large shock (N→ D position)	1	4	7				3				6		2		8	5																																																																						
	Large shock (N→ R position)	1	4	7				3				6		2		8	5																																																																						
	Shock is too large for lock-up.	2	3									6		1		5	4																																																																						
Slips/Will Not Engage	Vehicle cannot be started from D position.	8	3		5	6	7	9	10	11		4	2	12	13	1																																																																							
	Vehicle cannot be started from R position.	8	3		5	6	7	9	10	11		4	2	12	13	1																																																																							
	Does not lock-up.	2	6	8	3	4	10	9	11	12	5	7			13	1																																																																							
	Does not hold lock-up condition.	2	6	8	3	4	10	9	11	12	5	7			13	1																																																																							
	Lock-up is not released.	2	6		3	4					5	7			8	1																																																																							
	With selector lever in D position, acceleration is extremely poor.	3	4	5	7	8	9	12	10	11		2	6	13	14	1																																																																							
	With selector lever in R position, acceleration is extremely poor.	3	4	5	7	8	9	12	10	11		2	6	13	14	1																																																																							
	Slips at lock-up.	2	6	8	3	4	10	9	11	12	5	7			13	1																																																																							

CVT CONTROL SYSTEM

< SYMPTOM DIAGNOSIS >

[CVT: RE0F10J]

Symptom																
	Engine system	CAN communication line (U1000)	Transmission range switch (P0705, P0706)	Input speed sensor (P0717)	Primary speed sensor (P0715)	Output speed sensor (P2765)	CVT fluid temperature sensor (P0711, P0712, P0713)	Primary pressure sensor (P084C, P084D)	Secondary pressure sensor (P0841, P0847, P0848)	Torque converter clutch solenoid valve (P0740, P0743, P0744)	Stall test	CVT position	Power supply	Control valve	CVT fluid level and state	Ignition switch and starter
	EC-103	TM-58									TM-80	TM-81	TM-165	TM-213	TM-180	PG-56, STR-6
Other	No creep at all.	2	4	3	7	8	9	10	11	12		5	6	13	14	1
	Vehicle cannot run in any position.	8		2	5	6	7	9	10	11		3	4	12	13	1
	With selector lever in D position, driving is not possible.	8		2	5	6	7	9	10	11		3	4	12	13	1
	With selector lever in R position, driving is not possible.	8		2	5	6	7	9	10	11		3	4	12	13	1
	Judder occurs during lock-up.	2	6		3	4	5				7				8	1
	Strange noise in D position.	2	3												4	1
	Strange noise in R position.	2	3												4	1
	Strange noise in N position.	2	3												4	1
	Vehicle does not decelerate by engine brake.	7	3		4	5	6					2			8	1
	Maximum speed low.	2	3		5	6	7		8	9	11	4			10	1
	With selector lever in P position, vehicle does not enter parking condition or, with selector lever in another position, parking condition is not cancelled.			1									2			
	Vehicle runs with CVT in P position.			1								3			4	2
	Vehicle runs with CVT in N position.			1								3			4	2
	Engine stall.	2	6		3	4			8	9	5	7			10	1
	Engine stalls when selector lever shifted N → D or R.	2	6		3	4					5				7	1
	Engine speed does not return to idle.	2	4				3								5	1
	Engine does not start in N or P position.			3								2				1
	Engine starts in positions other than N or P.			3								2				1

A
B
C
TM
E
F
G
H
I
J
K
L
M
N
O
P

CVT CONTROL SYSTEM

< SYMPTOM DIAGNOSIS >

[CVT: RE0F10J]

Symptom Table 2

Symptom		Torque converter	Transmission range switch	Oil pump	Forward clutch	Reverse brake	Planetary gear	Bearings	Parking mechanism	Stop lamp switch	Shift lock solenoid	CVT shift selector
		<u>TM-217</u>	<u>TM-213</u>							<u>BR-21</u>	<u>TM-171</u>	<u>TM-185</u>
Shift Shock	Large shock (N→ D position)		2		1							
	Large shock (N→ R position)		2			1						
	Shock is too large for lock-up.	1										
Slips/Will Not Engage	Vehicle cannot be started from D position.		3	1	2							
	Vehicle cannot be started from R position.		4	1		2			3			
	Does not lock-up.	1	3	2								
	Does not hold lock-up condition.	1	3	2								
	Lock-up is not released.	1		2								
	With selector lever in D position, acceleration is extremely poor.	1	3		2							
	With selector lever in R position, acceleration is extremely poor.	1	4	2		3						
	Slips at lock-up.	1		2								

CVT CONTROL SYSTEM

< SYMPTOM DIAGNOSIS >

[CVT: RE0F10J]

Symptom	Torque converter	Transmission range switch	Oil pump	Forward clutch	Reverse brake	Planetary gear	Bearings	Parking mechanism	Stop lamp switch	Shift lock solenoid	CVT shift selector	
	TM-217	TM-213							BR-21	TM-171	TM-185	TM
Other	No creep at all.	1	6	2	4	5	3					A
	Vehicle cannot run in all positions.	1		2	4	5	3		6			B
	With selector lever in D position, driving is not possible.	1		2	4		3		5			C
	With selector lever in R position, driving is not possible.	1		2		4	3		5			
	Judder occurs during lock-up.	1										
	Strange noise in D position.	1		2	4		3	5				E
	Strange noise in R position.	1		2		4	3					F
	Strange noise in N position.	1		2			3					G
	Maximum speed low.	1	5	2	4		3					H
	With selector lever in P position, vehicle does not enter parking condition or, with selector lever in another position, parking condition is not cancelled.								1			I
	Vehicle runs with CVT in P position.						2		1			J
	Vehicle runs with CVT in N position.				2	3	1					K
	Engine stall.	1										
	Engine stalls when selector lever shifted N → D or R.	1										L
	When brake pedal is depressed with ignition switch ON, selector-lever cannot be shifted from P position to other position.								1	2	3	M
	When brake pedal is not depressed with ignition switch ON, selector lever can be shifted from P position to other position.								1	2	3	N
												O
												P

PERIODIC MAINTENANCE


CVT FLUID

Inspection

INFOID:000000011552539

FLUID LEAKAGE

- Check transaxle surrounding area (oil seal and plug etc.) for fluid leakage.
- If anything is found, repair or replace damaged parts and adjust CVT fluid level. Refer to [TM-180, "Adjustment"](#).



Replacement

INFOID:000000011552540

Recommended fluid and fluid capacity : Refer to [MA-10, "Fluids and Lubricants"](#).

CAUTION:

- Always use shop paper. Never use shop cloth.
- Replace a drain plug gasket with new ones at the final stage of the operation when installing.
- Use caution when looking into the drain hole as there is a risk of dripping fluid entering the eye.
- After replacement, always perform CVT fluid leakage check.

1. Select "Data Monitor" in "TRANSMISSION" using CONSULT.
2. Select "FLUID TEMP" and confirm that the CVT fluid temperature is 40°C (104°F) or less.
3. Check that the selector lever is in the "P" position, then completely engage the parking brake.
4. Lift up the vehicle.
5. Remove the drain plug and drain the CVT fluid from the oil pan. Refer to [TM-191, "Exploded View"](#).
6. Install the drain plug to oil pan.


CAUTION:

Drain plug gasket use the old one.

7. Remove the overflow plug (1) from converter housing.



: Vehicle front



CVT FLUID

< PERIODIC MAINTENANCE >

[CVT: RE0F10J]

8. Install the charging pipe set (KV311039S0) (A) into the overflow plug hole.

CAUTION:

Tighten the charging pipe by hand.

9. Install the ATF changer hose (B) to the charging pipe.

CAUTION:

Press the ATF changer hose all the way onto the charging pipe until it stops.

10. Fill approximately 3 liter (2-5/8 Imp qt) of the CVT fluid.

11. Remove the ATF changer hose and charging pipe, then install the overflow plug.

NOTE:

Perform this work quickly because CVT fluid leaks.

12. Lift down the vehicle.

13. Start the engine.

14. While depressing the brake pedal, shift the selector lever to the entire position from "P" to "L", and shift it to the "P" position.

NOTE:

Hold the lever at each position for 5 seconds.

15. Check that the CONSULT "Data Monitor" in "FLUID TEMP" is 35°C (95°F) to 45°C (113°F).

16. Stop the engine.

17. Lift up the vehicle.

18. Remove the drain plug, and then drain CVT fluid from oil pan.

19. Repeat steps 6 to 18 (one time).

20. Tighten the drain plug to the specified torque. Refer to [TM-191, "Exploded View"](#).

21. Remove the overflow plug.

22. Install the charging pipe set (KV311039S0) into the overflow plug hole.

CAUTION:

Tighten the charging pipe by hand.

23. Install the ATF changer hose to the charging pipe.

CAUTION:

Press the ATF changer hose all the way onto the charging pipe until it stops.

24. Fill approximately 3 liter (2-5/8 Imp qt) of the CVT fluid.

25. Remove the ATF changer hose and charging pipe, then install the overflow plug.

NOTE:

Perform this work quickly because CVT fluid leaks.

26. Lift down the vehicle.

27. Start the engine.

28. While depressing the brake pedal, shift the selector lever to the entire position from "P" to "L", and shift it to the "P" position.

NOTE:

Hold the lever at each position for 5 seconds.

29. Check that the CONSULT "Data Monitor" in "FLUID TEMP" is 35°C (95°F) to 45°C (113°F).

30. Lift up the vehicle.

31. Remove the overflow plug and confirm that the CVT fluid is drained from the overflow plug hole.

CAUTION:

Perform this work with the vehicle idling.

NOTE:


If the CVT fluid is not drained, refer to "Adjustment" and refill with the CVT fluid.

32. When the flow of CVT fluid slows to a drip, tighten the overflow plug to the specified torque. Refer to [TM-191, "Exploded View"](#).

CAUTION:

Never reuse O-ring.

33. Lift down the vehicle.



A

B

C

TM

E

F

G

H

I

J

K

L

M

N

O

P

34. Select "Data Monitor" in "TRANSMISSION" using CONSULT.
35. Select "CONFORM CVTF DETERIORATION".
36. Select "Erase".
37. Stop the engine.

Adjustment

INFOID:000000011552541

Recommended fluid and fluid capacity : Refer to [MA-10, "Fluids and Lubricants"](#).

CAUTION:

- During adjustment of the CVT fluid level, check CONSULT so that the oil temperature may be maintained from 35 to 45°C (95 to 113°F).
- Maintain specified engine idle speed during CVT fluid level adjustment. Refer to [EC-513, "Idle Speed"](#).
- Use caution when looking into the drain hole as there is a risk of dripping fluid entering the eye.

1. Check that the selector lever is in the "P" position, then completely engage the parking brake.
2. Start the engine.
3. Adjust the CVT fluid temperature to be approximately 40°C (104°F).

NOTE:

The CVT fluid is largely affected by temperature. Therefore be sure to use CONSULT and check the "FLUID TEMP" under "TRANSMISSION" in "Data Monitor" while adjusting.

4. While depressing the brake pedal, shift the selector lever to the entire position from "P" to "L", and shift it to the "P" position.


NOTE:

Hold the lever at each position for 5 seconds.

5. Lift up the vehicle.
6. Check that there is no CVT fluid leakage.
7. Remove the overflow plug (1) from converter housing.



: Vehicle front



8. Install the charging pipe set (KV311039S0) (A) into the overflow plug hole.

CAUTION:

Tighten the charging pipe by hand.

9. Install the ATF changer hose (B) to the charging pipe.

CAUTION:

Press the ATF changer hose all the way onto the charging pipe until it stops.

10. Fill approximately 0.5 liter (1/2 Imp qt) of the CVT fluid.
11. Remove the ATF changer hose from the charging pipe, and check that the CVT fluid drains out from the charging pipe. If it does not drain out, perform charging again.


CAUTION:

Perform this work with the vehicle idling.

12. When the flow of CVT fluid slows to a drip, remove the charging pipe from the converter housing.
13. Tighten the overflow plug to the specified torque. Refer to [TM-191, "Exploded View"](#).

CAUTION:

Never reuse O-ring.



- 14. Lift down the vehicle.
- 15. Stop the engine.

A

B

C

TM

E

F

G

H

I

J

K

L

M

N

O

P

CVT FLUID COOLER SYSTEM

Cleaning

INFOID:000000011322969

Whenever an automatic transaxle is repaired, overhauled, or replaced, the CVT fluid cooler mounted in the radiator must be inspected and cleaned.

Metal debris and friction material, if present, can be trapped or be deposited in the CVT fluid cooler. This debris can contaminate the newly serviced CVT or, in severe cases, can block or restrict the flow of CVT fluid. In either case, malfunction of the newly serviced CVT may occur.

Debris, if present, may deposit as CVT fluid enters the cooler inlet. It will be necessary to back flush the cooler through the cooler outlet in order to flush out any built up debris.


CVT FLUID COOLER CLEANING PROCEDURE

1. Position an oil pan under the transaxle's inlet and outlet cooler hoses.
2. Identify the inlet and outlet fluid cooler hoses.
3. Disconnect the fluid cooler inlet and outlet rubber hoses from the steel cooler tubes or bypass valve.

NOTE:

Replace the cooler hoses if rubber material from the hose remains on the tube fitting.

4. Allow any CVT fluid that remains in the cooler hoses to drain into the oil pan.




5. Insert the extension adapter hose of a can of Transmission Cooler Cleaner (Nissan P/N 999MP-AM006) into the cooler outlet hose.

CAUTION:

- **Wear safety glasses and rubber gloves when spraying the Transmission Cooler Cleaner.**
- **Spray Transmission Cooler Cleaner only with adequate ventilation.**
- **Avoid contact with eyes and skin.**
- **Do not breath vapors or spray mist.**

6. Hold the hose and can as high as possible and spray Transmission Cooler Cleaner in a continuous stream into the cooler outlet hose until CVT fluid flows out of the cooler inlet hose for 5 seconds.



7. Insert the tip of an air gun into the end of the cooler outlet hose.
8. Wrap a shop rag around the air gun tip and end of the cooler outlet hose.

9. Blow compressed air regulated to 5 to 9 kg/cm² (70 to 130 psi) through the cooler outlet hose for 10 seconds to force out any remaining CVT fluid.

10. Repeat steps 5 through 9 three additional times.

11. Position an oil pan under the banjo bolts that connect the CVT fluid cooler steel lines to the transaxle.


12. Remove the banjo bolts.

13. Flush each steel line from the cooler side back toward the transaxle by spraying Transmission Cooler Cleaner in a continuous stream for 5 seconds.

14. Blow compressed air regulated to 5 to 9 kg/cm² (70 to 130 psi) through each steel line from the cooler side back toward the transaxle for 10 seconds to force out any remaining CVT fluid.

15. Ensure all debris is removed from the steel cooler lines.

16. Ensure all debris is removed from the banjo bolts and fittings.



CVT FLUID COOLER SYSTEM

< PERIODIC MAINTENANCE >

[CVT: RE0F10J]

17. Perform "CVT FLUID COOLER DIAGNOSIS PROCEDURE".

CVT FLUID COOLER DIAGNOSIS PROCEDURE



NOTE:

Insufficient cleaning of the cooler inlet hose exterior may lead to inaccurate debris identification.


1. Position an oil pan under the transaxle's inlet and outlet cooler hoses.
2. Clean the exterior and tip of the cooler inlet hose.
3. Insert the extension adapter hose of a can of Transmission Cooler Cleaner (Nissan P/N 999MP-AM006) into the cooler outlet hose.

CAUTION:

- Wear safety glasses and rubber gloves when spraying the Transmission Cooler Cleaner.
 - Spray Transmission Cooler Cleaner only with adequate ventilation.
 - Avoid contact with eyes and skin.
 - Do not breath vapors or spray mist.
4. Hold the hose and can as high as possible and spray Transmission Cooler Cleaner in a continuous stream into the cooler outlet hose until CVT fluid flows out of the cooler inlet hose for 5 seconds.
 5. Tie a common white, basket-type coffee filter to the end of the cooler inlet hose.




6. Insert the tip of an air gun into the end of the cooler outlet hose.
7. Wrap a shop rag around the air gun tip and end of cooler outlet hose.
8. Blow compressed air regulated to 5 to 9 kg/cm² (70 to 130 psi) through the cooler outlet hose to force any remaining CVT fluid into the coffee filter.
9. Remove the coffee filter from the end of the cooler inlet hose.
10. Perform "CVT FLUID COOLER INSPECTION PROCEDURE".



CVT FLUID COOLER INSPECTION PROCEDURE

1. Inspect the coffee filter for debris.
- a. If small metal debris less than 1 mm (0.040 in) in size or metal powder is found in the coffee filter, this is normal. If normal debris is found, the CVT fluid cooler/radiator can be reused and the procedure is ended.




CVT FLUID COOLER SYSTEM

< PERIODIC MAINTENANCE >

[CVT: RE0F10J]

- b. If one or more pieces of debris are found that are over 1 mm (0.040 in) in size and/or peeled clutch facing material is found in the coffee filter, the fluid cooler is not serviceable. The radiator/ fluid cooler must be replaced and the inspection procedure is ended.



CVT FLUID COOLER FINAL INSPECTION

After performing all procedures, ensure that all remaining oil is cleaned from all components.

CVT SHIFT SELECTOR

< REMOVAL AND INSTALLATION >


[CVT: RE0F10J]

REMOVAL AND INSTALLATION

CVT SHIFT SELECTOR

Exploded View

INFOID:0000000011322970



- | | | |
|-----------------------|-----------------------|-------------------------------|
| ① Selector lever knob | ② Lock pin | ③ Knob cover |
| ④ Slide plate | ⑤ Shift lock solenoid | ⑥ CVT shift selector assembly |
| 🔧 : N·m (kg-m, in-lb) | | |

Removal and Installation

INFOID:0000000011322971

REMOVAL

CAUTION:

Always apply the parking brake before performing removal and installation.

1. Disconnect the battery cable from the negative terminal. Refer to [PG-118, "Removal and Installation"](#).
2. Move selector lever to "N" position.

CAUTION:


When pushing shift lock release button, wrap waste around the tip of flat screw driver to prevent damage.

CVT SHIFT SELECTOR

< REMOVAL AND INSTALLATION >

[CVT: RE0F10J]


3. Slide knob cover (1) below selector lever downward.
CAUTION:
Be careful not to damage knob cover.
4. Pull lock pin (2) out of selector lever knob (3).
5. Remove selector lever knob and knob cover.
6. Remove cluster lid C. Refer to [JP-14, "Removal and Installation"](#).
7. Disconnect CVT shift selector connector.



8. Remove control cable (1) from CVT shift selector assembly (2).

A : The ribbed


9. Remove CVT shift selector assembly.



INSTALLATION

Note the following, and install in the reverse order of removal.

- When installing control cable (1) to CVT shift selector assembly (2), check that control cable is fully pressed in with the ribbed (A) surface facing rearward.




- Refer to the followings when installing the selector lever knob to the CVT shift selector assembly.

1. Install the lock pin (2) to the selector lever knob (3).
2. Install the knob cover (1) to the selector lever knob.
3. Insert the selector lever knob into the CVT shift selector assembly until it clicks.

CAUTION:

- When pressing the selector lever knob onto the selector lever, never press the selector lever knob button.
- Never strike the selector lever knob to press it into place.

4. After installing the selector lever knob to the CVT shift selector assembly, check that the pulling on the selector lever knob does not disconnect it.



Disassembly and Assembly

INFOID:0000000011322972

Disassembly

1. Remove slide plate from cluster lid C.
2. Disconnect the shift lock solenoid connector.
3. Remove shift lock solenoid from CVT shift selector assembly.

CVT SHIFT SELECTOR

< REMOVAL AND INSTALLATION >

[CVT: RE0F10J]

Assembly

Assembly in the reverse order of disassembly.

Inspection and Adjustment

INFOID:0000000011322973

ADJUSTMENT AFTER INSTALLATION

Adjust the CVT positions after installing CVT shift selector assembly. Refer to [TM-81, "Inspection and Adjustment"](#).

INSPECTION AFTER INSTALLATION

Check the CVT positions after adjusting the CVT positions. Refer to [TM-81, "Inspection and Adjustment"](#).

A

B

C

TM

E

F

G

H

I

J

K

L

M

N

O

P

CONTROL CABLE


< REMOVAL AND INSTALLATION >

[CVT: RE0F10J]

CONTROL CABLE

Exploded View

INFOID:000000011322974



① CVT shift selector assembly

② Control cable

③ Lock plate

④ Bracket

⑤ Transaxle assembly

A Manual lever

B Retainer

: N·m (kg-m, ft-lb)

: N·m (kg-m, in-lb)

Removal and Installation


INFOID:000000011322975

REMOVAL

CAUTION:

Always apply the parking brake before performing removal and installation.

1. Disconnect the battery cable from the negative terminal. Refer to [PG-118, "Removal and Installation"](#).
2. Remove control cable from CVT shift selector assembly. Refer to [TM-185, "Removal and Installation"](#).
3. Remove air duct (inlet) and air cleaner case. Refer to [EM-27, "Removal and Installation"](#).
4. Remove the control cable nut () , using suitable tool.
5. Remove control cable (2) from manual lever (A).
6. Remove the lock plate (3) from control cable (2).
7. Remove control cable (2) from bracket (1).
8. Remove instrument lower cover center. Refer to [IP-14, "Removal and Installation"](#).




CONTROL CABLE

< REMOVAL AND INSTALLATION >

[CVT: RE0F10J]


9. Remove bolts (←) of retainer (A).
10. Remove the control cable from the vehicle.
11. Remove bracket from transaxle assembly.



INSTALLATION

Note the following, and install in the reverse order of removal.


- When installing control cable (1) to CVT shift selector assembly (2), check that control cable is fully pressed in with the ribbed (A) surface facing rearward.



- Install the socket (A) onto the CVT shift selector assembly.

CAUTION:

- Place the socket onto the CVT shift lever, then fasten it in place from above.
- Check that the pulling on the socket does not disconnect it.



Inspection and Adjustment

ADJUSTMENT AFTER INSTALLATION

Adjust the CVT positions after installing control cable. Refer to [TM-81. "Inspection and Adjustment"](#).

INSPECTION AFTER INSTALLATION


Check the CVT positions after adjusting the CVT positions. Refer to [TM-81. "Inspection and Adjustment"](#).

INFOID:0000000011322976

TCM

Exploded View

INFOID:000000011322977



① TCM

: N·m (kg-m, in-lb)

Removal and Installation

INFOID:000000011322978

REMOVAL

CAUTION:

- When replacing TCM, perform "ADDITIONAL SERVICE WHEN REPLACING TCM". Refer to [TM-72, "Work Procedure"](#).
 - When replacing TCM and transaxle assembly simultaneously, perform "ADDITIONAL SERVICE WHEN REPLACING TCM AND TRANSAXLE ASSEMBLY". Refer to [TM-74, "Work Procedure"](#).
 - When replacing TCM, note the "CVTF DETERIORATION DATE" value displayed on CONSULT "CONFORM CVTF DETERIORATION" in MAINTENANCE BOOKLET, before start the operation.
1. Disconnect the battery cable from the negative terminal. Refer to [PG-118, "Removal and Installation"](#).
 2. Remove air duct (inlet). Refer to [EM-27, "Removal and Installation"](#).
 3. Move battery harness to a place to keep the harness clear of working area.
 4. Disconnect TCM connector.
 5. Remove TCM.

INSTALLATION

Install in the reverse order of removal.

Adjustment

INFOID:000000011322979

ADJUSTMENT AFTER INSTALLATION

Perform "ADDITIONAL SERVICE WHEN REPLACING TCM". Refer to [TM-72, "Work Procedure"](#).

CONTROL VALVE

< REMOVAL AND INSTALLATION >


[CVT: RE0F10J]

CONTROL VALVE

Exploded View

INFOID:0000000011505789

COMPONENT PARTS LOCATION



- | | | |
|----------------------|--------------------------|-------------------------|
| ① Transaxle assembly | ② Terminal cord assembly | ③ Control valve |
| ④ Bracket | ⑤ O-ring | ⑥ Oil strainer assembly |
| ⑦ Oil pan gasket | ⑧ Oil pan | ⑨ Drain plug |
| ⑩ Drain plug gasket | ⑪ Magnet | ⑫ Spring washer |
| ⑬ Manual plate | ⑭ Lip seal | ⑮ Snap ring |
| ⑯ Overflow plug | ⑰ O-ring | |

⊗ : Always replace after every disassembly.

⊙ : N·m (kg-m, ft-lb)

⊙ : N·m (kg-m, in-lb)

 : Apply petroleum jelly


 : Apply CVT fluid

Removal and Installation


INFOID:000000011505790

REMOVAL


1. Disconnect battery negative terminal. Refer to [PG-118, "Removal and Installation"](#).
2. Remove drain plug from oil pan and then drain the CVT fluid.
3. Remove drain plug gasket.
CAUTION:
Do not reuse drain plug gasket.
4. Remove the front fender side protector (LH). Refer to [EXT-23, "Removal and Installation"](#).
5. Disconnect the CVT unit harness connector.
6. Remove the snap ring (1) from the CVT unit harness connector (A).



7. Press the CVT unit harness connector (A) into the transaxle case.
CAUTION:
Do not damage the CVT unit harness connector.
NOTE:
Clean around the harness connector to prevent foreign materials from entering into the transaxle case.



8. Remove the oil pan bolts, and then remove the oil pan and oil pan gasket.
CAUTION:
Do not reuse oil pan gasket.
9. Remove the magnets from the oil pan.
10. Remove the lock nut (1) and spring washer (2), and manual plate (3) from manual shaft (A).




 : Front

CONTROL VALVE


< REMOVAL AND INSTALLATION >

[CVT: RE0F10J]


11. Remove CVT fluid temperature sensor bracket (1).



12. Disconnect control valve harness connector (A).




13. Remove the oil strainer assembly bolts (A) and (B), and then remove the oil strainer assembly (1).





14. Remove O-ring from oil strainer assembly.


CAUTION:
Do not reuse O-ring.




15. Remove the bracket (1).




16. Remove the control valve bolts (A) and (B), and then remove the control valve from the transaxle case.



CAUTION:
Do not drop the control valve, ratio control valve and manual shaft.



17. Remove terminal cord assembly (1) from inside the transaxle case.



A
B
C
TM
E
F
G
H
I
J
K
L
M
N
O
P

CONTROL VALVE

< REMOVAL AND INSTALLATION >


[CVT: RE0F10J]

18. Remove the lip seal (1) from the transaxle case.

CAUTION:

Do not reuse lip seal.

⇐ : Front




INSTALLATION

1. Install the lip seal (1) to the transaxle case.

CAUTION:

Do not reuse lip seal.


⇐ : Front



2. Install terminal cord assembly (1) to the transaxle case.

CAUTION:

Connect the CVT unit connector with the stopper facing up, and then press in until it clicks.



3. Install the control valve to the transaxle case.


CAUTION:

- Do not pinch the harness between the control valve and the transaxle case.
- Do not drop the control valve, ratio control valve and manual shaft.

4. Secure the control valve using the control valve bolts (A) and (B).

⇐ : Front

Bolt	Bolt length (mm)	Number of bolts
A	54	8
B	44	1



CONTROL VALVE

< REMOVAL AND INSTALLATION >

[CVT: RE0F10J]

5. Connect the control valve harness connectors (A).

⇐ : Front

CAUTION:

- Do not pinch the harness between the control valve and the transaxle case.
- Securely insert the harness connector until it clicks and locks.

6. Install CVT fluid temperature sensor bracket (1).

⇐ : Bolt

7. Install the bracket (1).

⇐ : Bolt

⇐ : Front

8. Install O-ring to oil strainer assembly.

CAUTION:

- Do not reuse O-ring.
- Apply CVT fluid NS-3 to O-ring.

9. Install the oil strainer assembly (1) using the oil strainer assembly bolts (A) and (B).

⇐ : Front

Bolt	Bolt length (mm)	Number of bolts
A	12	2
B	44	1

NOTE:

Remove the bracket and adjust the position again if the bolt hole positions are not aligned.

10. Install the manual plate (1) while aligning with the groove (A) of the manual valve.





CAUTION:

Assemble the manual plate while aligning its end with the cutout (⇐) of the manual valve.

(A) : Manual shaft

⇐ : Front

11. Install the spring washer (2) and the lock-nut (3), and then tighten to the specified torque.



A

B

C

TM

E

F

G

H

I

J

K

L

M

N

O

P

CONTROL VALVE

< REMOVAL AND INSTALLATION >

[CVT: RE0F10J]

12. Install the snap ring (1) to the CVT unit harness connector (A).
13. Connect the CVT unit harness connector.
14. install fender protector side cover (LH).
15. Install the magnet while aligning it with the convex side of oil pan.

CAUTION:

Completely clean the iron powder from the magnet area of oil pan and the magnet.

16. Install the oil pan to the transaxle case with the following procedure.
 1. Install the oil pan gasket to the oil pan.

CAUTION:

- **Completely wipe out any moisture, oil, and old gasket from the oil pan gasket surface and bolt hole of oil pan and transaxle case.**
- **Do not reuse oil pan gasket.**

2. Install the oil pan assembly to the transaxle case, and then temporarily tighten the oil pan bolt.
3. Tighten the oil pan bolts in the order shown to the specified torque.



← : Front

4. Tighten the oil pan bolts again clockwise from (1) shown to the specified torque.
17. Install drain plug gasket to drain plug.

CAUTION:

Do not reuse drain plug gasket.

18. Install drain plug to oil pan.
19. Connect battery negative terminal. Refer to [PG-118, "Removal and Installation"](#).
20. Fill with CVT fluid to transaxle assembly. Refer to [TM-178, "Inspection"](#).



Inspection

INFOID:000000011505791

INSPECTION AFTER REMOVAL

Check oil pan for foreign material.

- If a large amount of worn material is found, clutch plate may be worn.
 - If iron powder is found, bearings, gears, or clutch plates may be worn.
 - If aluminum powder is found, bushing may be worn, or chips or burrs of aluminum casting parts may enter.
- Check points where wear is found in all cases.


INSPECTION AFTER INSTALLATION

Check the CVT fluid level and leakage. Refer to [TM-178, "Inspection"](#).

G SENSOR

Exploded View

INFOID:0000000011568867



1. G sensor

↔ : Vehicle front

Ⓒ : N·m (kg-m, in-lb)

Removal and Installation

INFOID:0000000011568868

CAUTION:

- Never drop or strike G sensor, because it has little tolerance for impact.
- Never use a power tool to avoid impact.

REMOVAL

1. Disconnect the battery cable from the negative terminal. Refer to [PG-118, "Exploded View"](#).
2. Remove center console. Refer to [IP-28, "Removal and Installation"](#).
3. Disconnect G sensor connector.
4. Remove G sensor.

INSTALLATION

Installation is the reverse order of removal.

Adjustment

INFOID:0000000011568869

ADJUSTMENT AFTER INSTALLATION

Perform "G SENSOR CALIBRATION". Refer to [TM-78, "Description"](#).

INPUT SPEED SENSOR


< REMOVAL AND INSTALLATION >

[CVT: RE0F10J]

INPUT SPEED SENSOR

Exploded View

INFOID:000000011505794




- ① Transaxle assembly ② Input speed sensor ③ O-ring
- ⊗ : Always replace after every disassembly.
- Ⓐ : N m (kg-m, in-lb)
- Ⓐ : Apply CVT fluid

Removal and Installation

INFOID:000000011505795

REMOVAL

1. Remove the starter motor. Refer to [STR-18, "Removal and Installation"](#).
2. Disconnect the harness connector from the input speed sensor (1).
3. Remove the input speed sensor bolt, then the input speed sensor (1).
4. Remove the O-ring (2) from the input speed sensor (1).
CAUTION:
Do not reuse O-ring.



INSTALLATION

Installation is in the reverse order of removal.

CAUTION:

- Do not reuse O-ring.
- Apply Genuine NISSAN CVT Fluid NS-3 to the O-ring.
- Perform "ADDITIONAL SERVICE WHEN REPLACING ECM". Refer to [EC-512, "Removal and Installation"](#)

Inspection and Adjustment

INFOID:000000011505796

INSPECTION AFTER INSTALLATION

Check for CVT fluid leakage. Refer to [TM-178, "Inspection"](#).

INPUT SPEED SENSOR

< REMOVAL AND INSTALLATION >

[CVT: RE0F10J]

ADJUSTMENT AFTER INSTALLATION

Adjust the CVT fluid level. Refer to [TM-180. "Adjustment"](#).

- A
- B
- C
- TM
- E
- F
- G
- H
- I
- J
- K
- L
- M
- N
- O
- P

PRIMARY SPEED SENSOR


< REMOVAL AND INSTALLATION >

[CVT: RE0F10J]

PRIMARY SPEED SENSOR

Exploded View

INFOID:000000011505797



- ① Transaxle assembly ② Primary speed sensor ③ O-ring
- ⊗ : Always replace after every disassembly.
- ⌘ : N m (kg-m, in-lb)
- 🔧 : Apply CVT Fluid


Removal and Installation

INFOID:000000011505798

REMOVAL

1. Remove the fender protector side cover (LH). Refer to [EXT-23, "Removal and Installation"](#).
2. Disconnect the harness connector from primary speed sensor (1).
3. Remove the primary speed sensor bolt, then the primary speed sensor (1).
4. Remove the O-ring (2) from the primary speed sensor (1).

CAUTION:
Do not reuse O-ring.



INSTALLATION

Installation is in the reverse order of removal.

CAUTION:

- Do not reuse O-ring.
- Apply Genuine NISSAN CVT Fluid NS-3 to the O-ring.

Inspection and Adjustment

INFOID:000000011505799

INSPECTION AFTER INSTALLATION

Check for CVT fluid leakage. Refer to [TM-178, "Inspection"](#).

ADJUSTMENT AFTER INSTALLATION

Adjust the CVT fluid level. Refer to [TM-180, "Adjustment"](#).

OUTPUT SPEED SENSOR


< REMOVAL AND INSTALLATION >

[CVT: RE0F10J]

OUTPUT SPEED SENSOR

Exploded View

INFOID:0000000011505800



① Transaxle assembly

② Output speed sensor

③ O-ring

⊗ : Always replace after every disassembly.

Ⓐ : N·m (kg-m, in-lb)

Ⓐ : Apply CVT Fluid


Removal and Installation

INFOID:0000000011505801

REMOVAL

1. Disconnect the harness connector from output speed sensor (1).
2. Remove the output speed sensor bolt, then the output speed sensor (1).
3. Remove the O-ring (2) from the output speed sensor (1).

CAUTION:
Do not reuse O-ring.



INSTALLATION

Installation is in the reverse order of removal.

CAUTION:

- Do not reuse O-ring.
- Apply Genuine NISSAN CVT Fluid NS-3 to the O-ring.

Inspection and Adjustment

INFOID:0000000011505802

INSPECTION AFTER INSTALLATION

Check for CVT fluid leakage. Refer to [TM-178, "Inspection"](#).

ADJUSTMENT AFTER INSTALLATION

Adjust the CVT fluid level. Refer to [TM-180, "Adjustment"](#).

AIR BREATHER HOSE


< REMOVAL AND INSTALLATION >

[CVT: RE0F10J]

AIR BREATHER HOSE

Exploded View

INFOID:000000011322980



① Air cleaner case

② Air breather hose

③ Transaxle assembly

④ Heater pipe

⇐ : Vehicle front

Removal and Installation

INFOID:000000011322981

REMOVAL

1. Disconnect the battery cable from the negative terminal. Refer to [PG-118, "Removal and Installation"](#).
2. Remove air duct (inlet). Refer to [EM-27, "Removal and Installation"](#).
3. Remove clip from air cleaner case.
4. Remove air cleaner case and air duct assembly. Refer to [EM-27, "Removal and Installation"](#).
5. Remove clip from heater pipe.
6. Remove air breather hose from transaxle assembly.

INSTALLATION

Note the following, and install in the reverse order of removal.


CAUTION:

AIR BREATHER HOSE

< REMOVAL AND INSTALLATION >

[CVT: RE0F10J]

- Insert air breather hose (2) to the bend (A) of air breather tube (1).
- Install air breather hose to air breather tube so that the paint mark is facing forward.
- Check that air breather hose is not collapsed or blocked due to folding or bending when installed.



A

B

C

TM

E

F

G

H

I

J

K

L

M

N

O

P

DIFFERENTIAL SIDE OIL SEAL


< REMOVAL AND INSTALLATION >

[CVT: RE0F10J]

DIFFERENTIAL SIDE OIL SEAL

Exploded View

INFOID:000000011515080



- ① Transaxle assembly ② Differential side oil seal (left side) ③ Differential side oil seal (right side)

⊗ : Always replace after every disassembly.

W : Apply CVT Fluid

Removal and Installation

INFOID:000000011515081

REMOVAL


NOTE:

When removing components such as hoses, tubes/lines, etc., cap or plug openings to prevent fluid from spilling.

1. Disconnect the battery cable from the negative terminal. Refer to [PG-118, "Removal and Installation"](#).
2. Remove exhaust front tube. Refer to [EX-6, "Removal and Installation"](#).
3. Remove front drive shaft. Refer to [FAX-18, "LEFT SIDE : Removal and Installation"](#) (LH) or [FAX-19, "RIGHT SIDE : Removal and Installation"](#) (RH).
4. Remove differential oil side seal (1) using suitable tool (A).

CAUTION:

Be careful not to scratch transaxle case and converter housing.



INSTALLATION

Installation is in the reverse order of removal.

CAUTION:

- Do not reuse differential side oil seal.
- Apply Genuine NISSAN CVT Fluid NS-3 to differential side oil seals.
- When inserting the drive shaft, be sure to use Tool.

Tool number : KV38107900

DIFFERENTIAL SIDE OIL SEAL


< REMOVAL AND INSTALLATION >

[CVT: RE0F10J]

Install each differential side oil seal evenly using Tool so that differential side oil seal protrudes by the dimension (C) and (D) respectively.

(A) : Differential side oil seal (LH)

(B) : Differential side oil seal (RH)



Dimension (C) :Height difference from case end surface is within 0 ± 0.5 mm (0.0 ± 0.020 in).

Dimension (D) :Height difference from case end surface is within 0 ± 0.5 mm (0.0 ± 0.020 in).

NOTE:

The reference is the installation direction of the differential side oil seal.

Drift to be used:

Location	Commercial Service Tools
Transaxle case side	Commercial service tool with outer dia. 56 mm (2.20 in) and inner dia. 50 mm (1.97 in)
Converter housing side	

Inspection and Adjustment

INFOID:0000000011515082

INSPECTION AFTER INSTALLATION

Check for CVT fluid leakage. Refer to [TM-178, "Inspection"](#).

ADJUSTMENT AFTER INSTALLATION

Adjust the CVT fluid level. Refer to [TM-180, "Adjustment"](#).

CVT OIL WARMER SYSTEM


< REMOVAL AND INSTALLATION >

[CVT: RE0F10J]

CVT OIL WARMER SYSTEM WATER HOSE

WATER HOSE : Exploded View

INFOID:000000011505818



- | | | |
|--------------------|---------------------|--------------------|
| ① Hose clamp | ② CVT water hose A | ③ CVT oil warmer |
| ④ CVT water hose B | ⑤ Heater thermostat | ⑥ CVT water hose C |

⑦ Transaxle assembly

A Water outlet

⊗ : Always replace after every disassembly.

Ⓒ : N·m (kg-m, ft-lb)

WATER HOSE : Removal and Installation

INFOID:000000011505819

REMOVAL

WARNING:

Do not remove the radiator cap when the engine is hot. Serious burns could occur from high pressure coolant escaping from the radiator. Wrap a thick cloth around the cap. Slowly turn it a quarter turn to allow built-up pressure to escape. Carefully remove the cap by turning it all the way.

CAUTION:

Perform when the engine is cold.

NOTE:

When removing components such as hoses, tubes/lines, etc., cap or plug openings to prevent fluid from spilling.

1. Remove engine room cover. Refer to [EM-25. "Removal and Installation"](#).

CVT OIL WARMER SYSTEM

< REMOVAL AND INSTALLATION >

[CVT: RE0F10J]


- Remove front air duct and air cleaner case assembly. Refer to [EM-27, "Removal and Installation"](#).
- Release clip (A) and release hose clamps and remove CVT water hose A from water outlet.

CAUTION:

Do not reuse hose clamps.



: Front



- Remove CVT heater thermostat bolt, release hose clamps then remove CVT heater thermostat and CVT water hose C from water outlet.

CAUTION:

Do not reuse hose clamps.

- Remove CVT water hose inlet and CVT water hose outlet from CVT oil warmer.

INSTALLATION


Note the following, and install in the reverse order of removal.

CAUTION:

Do not reuse hose clamps.

- Insert CVT water hose according to dimension (A) described below.


CVT water hose (1)	Insert side tube (2)	Dimension (A)
CVT water hose A	Water outlet	End reaches the spool portion (B)
	CVT oil warmer	
CVT water hose B	CVT oil warmer	
	Heater thermostat	
CVT water hose C	Heater thermostat	
	Water outlet	



- Install hose clamps (1) at the both ends of CVT water hose (2) with dimension (A) from the hose end.

Dimension (A) : 5 – 7 mm (0.20 – 0.28 in)

- Hose clamp should not interfere with the bulge.



CVT water hose	Hose end	Paint mark	Position of hose clamp
CVT water hose A	Water outlet side	Facing to the front of the vehicle	A
	CVT oil warmer side	Facing to the front of the vehicle	C
CVT water hose B	CVT oil warmer side	Facing to the front of the vehicle	B
	Heater thermostat side	N/A	A
CVT water hose C	Heater thermostat side	N/A	A
	Water outlet side	Facing upward	C


*: Refer to the illustrations for the specific position of each hose clamp tab.

CVT OIL WARMER SYSTEM

< REMOVAL AND INSTALLATION >

[CVT: RE0F10J]

- The illustrations indicate the view from the hose ends.
- When installing hose clamps the center line of each clamp tab should be positioned as shown.



ALDIA0557ZZ

WATER HOSE : Inspection

INFOID:0000000011505820

INSPECTION AFTER INSTALLATION


Start and warm up the engine. Visually check that there is no leakage of engine coolant and CVT fluid.

CVT FLUID COOLER HOSE

CVT FLUID COOLER HOSE : Exploded View

INFOID:0000000011505821

COMPONENT PARTS LOCATION



- ① CVT oil warmer
- ② Hose clamp
- ③ CVT fluid cooler hose A
- ④ CVT fluid cooler hose B
- ⑤ Transaxle assembly
- Ⓐ : To radiator
- ⓧ : Always replace after every disassembly.

CVT OIL WARMER SYSTEM

< REMOVAL AND INSTALLATION >

[CVT: RE0F10J]

CVT FLUID COOLER HOSE : Removal and Installation

INFOID:0000000011505822

REMOVAL

NOTE:

When removing components such as hoses, tubes/lines, etc., cap or plug openings to prevent fluid from spilling.

1. Remove engine room cover. Refer to [EM-25, "Removal and Installation"](#).
2. Remove the front air duct and air cleaner case assembly. Refer to [EM-27, "Removal and Installation"](#).
3. Release hose clamp, then remove CVT fluid cooler hose A and B from CVT oil warmer and radiator.

CAUTION:

Do not reuse hose clamps.

INSTALLATION


Installation is in the reverse order of removal.

CAUTION:

Do not reuse hose clamps.

- Insert CVT fluid cooler hoses according to dimension (A).


CVT fluid cooler hose (1)	Insert side tube (2)	Dimension (A)
CVT fluid cooler hose A	Radiator tube	End reaches the 2-stage bulge (B)
	CVT oil warmer	
CVT fluid cooler hose B	CVT oil warmer	
	Radiator tube	



- Install hose clamps (1) at both ends of CVT fluid cooler hoses (2) with dimension (A) from the hose end.

Dimension (A) : 5 – 7 mm (0.20 – 0.28 in)

- Hose clamp should not interfere with the bulge.



CVT fluid cooler hose	Hose end	Paint mark	Position of hose clamp
CVT fluid cooler hose A	Radiator tube side	Facing upward	B
	CVT oil warmer side	Facing to the right of the vehicle	B
CVT fluid cooler hose B	CVT oil warmer side	Facing downward	A
	Radiator tube side	Facing to the front of the vehicle	B


*: Refer to the illustrations for the specific position of each hose clamp tab.

CVT OIL WARMER SYSTEM

< REMOVAL AND INSTALLATION >

[CVT: RE0F10J]

- The illustrations indicate the view from the hose ends.
- When installing hose clamps the center line of each clamp tab should be positioned as shown.



CVT FLUID COOLER HOSE : Inspection

INFOID:000000011505823


INSPECTION AFTER INSTALLATION

Check for CVT fluid leakage and check CVT fluid level. Refer to [TM-178, "Inspection"](#).

CVT OIL WARMER

CVT OIL WARMER : Exploded View

INFOID:000000011505824



① Transaxle assembly

② CVT oil warmer

: N·m (kg-m, ft-lb)

CVT OIL WARMER : Removal and Installation

INFOID:000000011505825

REMOVAL

WARNING:

Do not remove the radiator cap when the engine is hot. Serious burns could occur from high pressure coolant escaping from the radiator. Wrap a thick cloth around the cap. Slowly turn it a quarter turn to allow built-up pressure to escape. Carefully remove the cap by turning it all the way.

CAUTION:

Perform when the engine is cold.

1. Remove CVT water hose inlet and CVT water hose outlet from CVT oil warmer. Refer to [TM-206, "WATER HOSE : Exploded View"](#).
2. Remove CVT fluid cooler hose inlet and CVT fluid cooler hose outlet from CVT oil warmer. Refer to [TM-208, "CVT FLUID COOLER HOSE : Exploded View"](#).
3. Remove CVT oil warmer bolts, then remove CVT oil warmer from vehicle.

CVT OIL WARMER SYSTEM

< REMOVAL AND INSTALLATION >

[CVT: RE0F10J]

INSTALLATION

Installation is in the reverse order of removal.

CVT OIL WARMER : Inspection

INFOID:0000000011505826

INSPECTION AFTER INSTALLATION

- Check for CVT fluid leakage and check CVT fluid level. Refer to [TM-178, "Inspection"](#).
- Start and warm up the engine. Visually check that there is no leakage of engine coolant and CVT fluid.

A
B
C
TM
E
F
G
H
I
J
K
L
M
N
O
P

PLUG

< REMOVAL AND INSTALLATION >

[CVT: RE0F10J]

PLUG


Description

INFOID:0000000011505827

Replace the O-ring if oil leakage or exudes from the plug.

Exploded View

INFOID:0000000011505828



① Transaxle assembly

② O-ring

③ Plug



: Always replace after every disassembly.



: N·m (kg-m, ft-lb)



: Apply CVT Fluid

Removal and Installation

INFOID:0000000011505829

REMOVAL

1. Remove fender protector side cover (LH). Refer to [EXT-23. "Removal and Installation"](#).
2. Remove the plug and O-ring.

INSTALLATION

Installation is in the reverse order of removal.

CAUTION:

- Do not reuse O-ring.
- Apply Genuine NISSAN CVT Fluid NS-3 to O-ring.

Inspection and Adjustment

INFOID:0000000011505830

INSPECTION AFTER INSTALLATION

Check for CVT fluid leakage. Refer to [TM-178. "Inspection"](#).

ADJUSTMENT AFTER INSTALLATION


Adjust the CVT fluid level. Refer to [TM-180. "Adjustment"](#).

UNIT REMOVAL AND INSTALLATION

TRANSAXLE ASSEMBLY

Exploded View

INFOID:000000011505837



- | | | |
|--|----------------------|-------------------------------|
| ① Gusset | ② Transaxle assembly | ③ O-ring |
| ④ CVT fluid charging pipe | ⑤ Water outlet | ⑥ CVT fluid charging pipe cap |
| A : For the tightening torque, refer to TM-213, "Removal and Installation" . | | |
| ⊗ : Always replace after every disassembly. | | |
| Ⓜ : N·m (kg·m, ft·lb) | | |
| Ⓜ : N·m (kg·m, in·lb) | | |
| Ⓜ : Apply petroleum jelly | | |

Removal and Installation

INFOID:000000011323003

REMOVAL

WARNING:

Never remove the reservoir tank cap when the engine is hot. Serious burns could occur from high-pressure engine coolant escaping from the reservoir tank.

CAUTION:

- Perform when the engine is cold.
- When replacing TCM and transaxle assembly, perform "ADDITIONAL SERVICE WHEN REPLACING TRANSAXLE ASSEMBLY". Refer to [TM-74, "Work Procedure"](#).
- When replacing TCM and transaxle assembly simultaneously, perform "ADDITIONAL SERVICE WHEN REPLACING TCM AND TRANSAXLE ASSEMBLY" before to [TM-76, "Work Procedure"](#).

NOTE:

When replacing TCM and transaxle assembly as a set, replace transaxle assembly first and then replace TCM. Refer to [TM-72, "Description"](#).

TRANSAXLE ASSEMBLY

< UNIT REMOVAL AND INSTALLATION >

[CVT: RE0F10J]


1. Remove the engine assembly, the transaxle assembly, and front suspension member as a set. Refer to [EM-58, "Removal and Installation"](#).
2. Disconnect the transaxle harness connectors.
3. Remove crankshaft position sensor (POS). Refer to [EM-39, "Removal and Installation"](#).
4. Remove air breather hose. Refer to [TM-202, "Removal and Installation"](#).
5. Remove CVT fluid charging pipe.
6. Remove O-ring from CVT fluid charging pipe.
7. Remove rear plate cover. Refer to [EM-39, "Removal and Installation"](#).
8. Turn crankshaft, and remove the tightening nuts for drive plate and torque converter.
CAUTION:
When turning crankshaft, turn it clockwise as viewed from the front of the engine.
9. Remove transaxle assembly fixing bolts with power tool.
10. Remove transmission bracket.
11. Remove transaxle assembly from engine assembly with a hoist.
CAUTION:
Secure torque converter to prevent it from dropping.
12. Remove CVT oil warmer. Refer to [TM-210, "CVT OIL WARMER : Removal and Installation"](#).

INSTALLATION

Note the following, and install in the reverse order of removal.
Installation is in the reverse order of removal.

NOTE:

Write down the serial number of the new transaxle assembly.



CAUTION:


- When replacing an engine or transaxle you must make sure any dowels are installed correctly during re-assembly
- Improper alignment caused by missing dowels may cause vibration, oil leaks or breakage of drive train components.
- Never reuse O-ring.
- Apply petroleum jelly to O-ring.

TRANSAXLE ASSEMBLY

< UNIT REMOVAL AND INSTALLATION >

[CVT: RE0F10J]

- Check fitting of dowel pins (↔) when installing transaxle assembly to engine assembly.




- Follow the procedure below and install transaxle to engine.
- 1. Rotate torque converter to align a torque converter stud bolt with the service hole.
- 2. Rotate drive plate to align a torque converter stud bolt insertion hole of drive plate with service hole.
- 3. Install transaxle to engine.

CAUTION:

Be careful not to strike the drive plate when inserting torque converter stud bolts to drive plate holes.

- 4. Tighten the fixing bolts in accordance with the following.

Bolt No.	1	2	3	4	5
Number of bolts	1	2	1	1	4
Bolt length "ℓ"mm (in)	55 (2.17)	39 (1.54)	35 (1.38)	50 (1.97)	45 (1.77)
Tightening torque N·m (kg·m, ft·lb)	74.5 (7.6, 55)				50.0 (5.1, 37)



- 5. After tighten the torque converter nuts temporarily, tighten the torque converter nuts to the specified torque.

CAUTION:

- When turning crankshaft, turn it clockwise as viewed from the crankshaft pulley side.
- When tightening the torque converter nuts after fixing the crankshaft pulley bolts, confirm the tightening torque of the crankshaft pulley mounting bolts. Refer to [EM-68, "Exploded View"](#).
- After converter is installed to drive plate, rotate crankshaft several turns to check that CVT rotates freely without binding.
- When installing the CVT to the engine, align the matching mark on the drive plate with the matching mark on the torque converter.
- When installing CVT assembly to the engine assembly, attach the bolts in accordance with the following standard.

Inspection and Adjustment


INFOID:0000000011323004

INSPECTION BEFORE INSTALLATION

After inserting a torque converter to transaxle assembly, check that dimension (A) is within the reference value limit.

- B : Scale
- C : Straightedge

Dimension A : Refer to [TM-220, "Torque Converter"](#).



TRANSAXLE ASSEMBLY

< UNIT REMOVAL AND INSTALLATION >

[CVT: RE0F10J]

INSPECTION AFTER INSTALLATION

Check the following.

- Check for CVT fluid leakage and check CVT fluid level. Refer to [TM-178, "Inspection"](#).
- Check CVT position. Refer to [TM-81, "Inspection and Adjustment"](#).
- Start and warm up the engine. Visually check that there is no leakage of engine coolant and CVT fluid.

ADJUSTMENT AFTER INSTALLATION


- Adjust the CVT fluid level. Refer to [TM-180, "Adjustment"](#).
- Perform "ADDITIONAL SERVICE WHEN REPLACE TRANSAXLE ASSEMBLY". Refer to [TM-74, "Work Procedure"](#).

UNIT DISASSEMBLY AND ASSEMBLY

TORQUE CONVERTER AND CONVERTER HOUSING OIL SEAL

Exploded View

INFOID:0000000011505838



① Transaxle assembly

② Torque converter

③ Converter housing oil seal

⊗ : Always replace after every disassembly.

🔧 : Apply CVT Fluid

Disassembly

INFOID:0000000011505839

1. Remove transaxle assembly. Refer to [TM-213. "Removal and Installation"](#).
2. Remove torque converter from transaxle assembly.
CAUTION:
Do not damage the bushing on the inside of torque converter sleeve when removing torque converter.
3. Remove converter housing oil seal using suitable tool.
CAUTION:
Be careful not to scratch converter housing.

Assembly

INFOID:0000000011505840

Assembly is in the reverse order of disassembly.

CAUTION:**Do not reuse converter housing oil seal.****NOTE:**

Lubricate converter housing oil seal prior to installation.

TORQUE CONVERTER AND CONVERTER HOUSING OIL SEAL

< UNIT DISASSEMBLY AND ASSEMBLY >


[CVT: RE0F10J]

- Drive converter housing oil seal ① evenly using a drift (A) (commercial service tool) so that converter housing oil seal protrudes by the dimension (B) respectively.

Unit: mm (in)

Commercial service tool: (A)	Outer diameter: 65 (2.56)
	Inner diameter: 60 (2.36)

② : Transaxle assembly




Unit: mm (in)

Dimension (B)	1.0 ± 0.5 (0.039 $\pm$ 0.020)
---------------	-----------------------------------

NOTE:


Converter housing oil seal pulling direction is used as the reference.



- Attach the pawl (A) of the torque converter to the drive sprocket hole (B) on the transaxle assembly side.

CAUTION:

- Rotate the torque converter for installing torque converter.
- Do not damage the bushing inside the torque converter sleeve when installing the converter housing oil seal.



Inspection

INFOID:0000000011505841

INSPECTION AFTER INSTALLATION

TORQUE CONVERTER AND CONVERTER HOUSING OIL SEAL


< UNIT DISASSEMBLY AND ASSEMBLY >

[CVT: RE0F10J]

- After inserting a torque converter to the CVT, check dimension (A) with in the reference value limit.

B : Scale
C : Straightedge

Dimension (A) : Refer to [TM-220, "Torque Converter"](#).



A

B

C

TM

E

F

G

H

I

J

K

L

M

N

O

P

SERVICE DATA AND SPECIFICATIONS (SDS)

< SERVICE DATA AND SPECIFICATIONS (SDS)

[CVT: RE0F10J]

SERVICE DATA AND SPECIFICATIONS (SDS)

SERVICE DATA AND SPECIFICATIONS (SDS)

General Specification

INFOID:0000000011551821

Applied model	Engine	VQ35DE
	Axle	2WD
Transaxle model		RE0F10J
Transaxle gear ratio	D position	2.436 – 0.384
	R position	1.815
	Final drive	4.602
Recommended fluid		Refer to MA-10, "Fluids and Lubricants" .
Fluid capacity liter (US qt, Imp qt)		

Shift Characteristics

INFOID:0000000011551822

Unit: rpm

Throttle position	Shift pattern	CVT input speed	
		At 40 km/h (25 MPH)	At 60 km/h (37 MPH)
2/8	"D" position	1,440 – 1,600	1,610 – 1,770
	"D" position (O/D OFF condition)	1,410 – 1,550	1,550 – 1,710
8/8	"D" position	3,830 – 4,230	4,840 – 5,350
	"D" position (O/D OFF condition)	3,830 – 4,230	4,840 – 5,350

NOTE:

- Lock-up is engaged at the vehicle speed of approximately 18 km/h (12 MPH) to 40 km/h (24 MPH).
- This is only reference value with constant operation.

Stall Speed

INFOID:0000000011551823

Unit: rpm

Stall speed	2,550 – 2,980
-------------	---------------

Torque Converter

INFOID:0000000011323013

Dimension between end of converter housing and torque converter	14.0 mm (0.55 in)
---	-------------------

Heater Thermostat

INFOID:0000000011323014

Standard

Valve opening temperature	71°C (159°F)
Maximum valve lift	5.0 mm / 85°C (0.197 in / 185°F)
Valve closing temperature	65°C (149°F)