

SECTION CHG

CHARGING SYSTEM

CONTENTS

PRECAUTION	3	DIAGNOSIS AND REPAIR WORKFLOW	13
PRECAUTIONS	3	Work Flow(With EXP-800 NI or GR8-1200 NI)	13
Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"	3	Work Flow(Without EXP-800 NI or GR8-1200 NI).....	17
Precaution for Procedure without Cowl Top Cover.....	3	CHARGING SYSTEM PRELIMINARY INSPECTION	20
Precaution for Power Generation Voltage Variable Control System	3	Inspection Procedure	20
Precautions for Removing Battery Terminal	4	POWER GENERATION VOLTAGE VARIABLE CONTROL SYSTEM OPERATION INSPECTION	21
PREPARATION	5	Inspection Procedure	21
PREPARATION	5	DTC/CIRCUIT DIAGNOSIS	23
Special Service Tools	5	B TERMINAL CIRCUIT	23
Commercial Service Tools	5	Description	23
SYSTEM DESCRIPTION	6	Diagnosis Procedure	23
COMPONENT PARTS	6	L TERMINAL CIRCUIT (OPEN)	24
Component Parts Location	6	Description	24
Component Description	6	Diagnosis Procedure	24
SYSTEM	7	L TERMINAL CIRCUIT (SHORT)	26
CHARGING SYSTEM	7	Description	26
CHARGING SYSTEM : System Diagram	7	Diagnosis Procedure	26
CHARGING SYSTEM : System Description	7	S TERMINAL CIRCUIT	27
POWER GENERATION VOLTAGE VARIABLE CONTROL SYSTEM	7	Description	27
POWER GENERATION VOLTAGE VARIABLE CONTROL SYSTEM : System Diagram	7	Diagnosis Procedure	27
POWER GENERATION VOLTAGE VARIABLE CONTROL SYSTEM : System Description	7	SYMPTOM DIAGNOSIS	28
WIRING DIAGRAM	9	CHARGING SYSTEM	28
CHARGING SYSTEM	9	Symptom Table	28
Wiring Diagram	9	REMOVAL AND INSTALLATION	29
BASIC INSPECTION	13	ALTERNATOR	29
		Exploded View	29
		Removal and Installation	30
		Inspection	32

A

B

C

D

E

F

G

H

I

J

K

L

CHG

N

O

P

SERVICE DATA AND SPECIFICATIONS		SERVICE DATA AND SPECIFICATIONS	
(SDS)	33	(SDS)	33
		Alternator	33

PRECAUTIONS

< PRECAUTION >

PRECAUTION

PRECAUTIONS

Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"

INFOID:0000000010260574

The Supplemental Restraint System such as "AIR BAG" and "SEAT BELT PRE-TENSIONER", used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. Information necessary to service the system safely is included in the "SRS AIR BAG" and "SEAT BELT" of this Service Manual.

WARNING:

Always observe the following items for preventing accidental activation.

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision that would result in air bag inflation, all maintenance must be performed by an authorized NISSAN/INFINITI dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see "SRS AIR BAG".
- Never use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harnesses or harness connectors.

PRECAUTIONS WHEN USING POWER TOOLS (AIR OR ELECTRIC) AND HAMMERS

WARNING:


Always observe the following items for preventing accidental activation.

- When working near the Air Bag Diagnosis Sensor Unit or other Air Bag System sensors with the ignition ON or engine running, never use air or electric power tools or strike near the sensor(s) with a hammer. Heavy vibration could activate the sensor(s) and deploy the air bag(s), possibly causing serious injury.
- When using air or electric power tools or hammers, always switch the ignition OFF, disconnect the battery, and wait at least 3 minutes before performing any service.

Precaution for Procedure without Cowl Top Cover

INFOID:0000000011508513

When performing the procedure after removing cowl top cover, cover the lower end of windshield with urethane, etc to prevent damage to windshield.



Precaution for Power Generation Voltage Variable Control System

INFOID:0000000010260575

CAUTION:

For this model, the battery current sensor that is installed to the battery cable at the negative terminal measures the charging/discharging current of the battery, and performs various controls. If the electrical component or the ground wire is connected directly to the battery terminal, the current other than that being measured with the battery current sensor is charging to or discharging from the battery. This condition causes the malfunction of the control, and then the battery discharge may occur. Do not connect the electrical component or the ground wire directly to the battery terminal.

PRECAUTIONS

< PRECAUTION >

Precautions for Removing Battery Terminal

INFOID:000000010260576

- When removing the 12V battery terminal, turn OFF the ignition switch and wait at least 30 seconds.

NOTE:

ECU may be active for several tens of seconds after the ignition switch is turned OFF. If the battery terminal is removed before ECU stops, then a DTC detection error or ECU data corruption may occur.

- For vehicles with the 2-batteries, be sure to connect the main battery and the sub battery before turning ON the ignition switch.


NOTE:

If the ignition switch is turned ON with any one of the terminals of main battery and sub battery disconnected, then DTC may be detected.

- After installing the 12V battery, always check "Self Diagnosis Result" of all ECUs and erase DTC.

NOTE:

The removal of 12V battery may cause a DTC detection error.



SEF289H

PREPARATION


< PREPARATION >

PREPARATION

PREPARATION

Special Service Tools

INFOID:000000010260577

Tool number (TechMate No.) Tool name	Description
— (—) Model GR8-1200 NI Multitasking battery and electrical diagnostic station  AWI1A1239ZZ	Tests batteries, starting and charging systems and charges batteries. For operating instructions, refer to diagnostic station instruction manual.
— (—) Model EXP-800 NI Battery and electrical diagnostic analyzer  JSMIA0806ZZ	Tests batteries and charging systems. For operating instructions, refer to diagnostic analyzer instruction manual.

Commercial Service Tools

INFOID:000000010260578

Tool name	Description
Power tool  PIIB1407E	Loosening bolts, nuts and screws

CHG

COMPONENT PARTS


< SYSTEM DESCRIPTION >

SYSTEM DESCRIPTION

COMPONENT PARTS

Component Parts Location

INFOID:0000000010260579



1. IPDM E/R
2. ECM
3. Battery current sensor
4. Alternator
5. Combination meter (charge warning lamp)
- A. Engine room RH

Component Description

INFOID:0000000010260580

Component part	Description
Alternator (IC voltage regulator)	IC voltage regulator controls the power generation voltage by the target power generation voltage based on the received power generation command signal. When there is no power generation command signal, the alternator performs the normal power generation according to the characteristic of the IC voltage regulator.
Battery current sensor	Battery current sensor is installed to the battery cable at the negative terminal, and it detects the charging/discharging current of the battery and sends the voltage signal to ECM according to the current value.
Combination meter (Charge warning lamp)	The IC voltage regulator warning function activates to illuminate the charge warning lamp, if any of the following symptoms occur while alternator is operating: - Excessive voltage is produced. - No voltage is produced.
ECM	Battery current sensor detects the charging/discharging current of the battery. ECM judges the battery condition based on this signal. ECM judges whether to perform the power generation voltage variable control according to the battery condition. When performing the power generation voltage variable control, ECM calculates the target power generation voltage according to the battery condition and sends the calculated value as the power generation command value to IPDM E/R.
IPDM E/R	IPDM E/R converts the received power generation command value into the power generation command signal (PWM signal) and sends it to the IC voltage regulator.

SYSTEM


< SYSTEM DESCRIPTION >

SYSTEM

CHARGING SYSTEM

CHARGING SYSTEM : System Diagram

INFOID:0000000010260581



CHARGING SYSTEM : System Description


INFOID:0000000010260582

The alternator provides DC voltage to operate the vehicle's electrical system and to keep the battery charged. The voltage output is controlled by the IC voltage regulator.

POWER GENERATION VOLTAGE VARIABLE CONTROL SYSTEM

POWER GENERATION VOLTAGE VARIABLE CONTROL SYSTEM : System Diagram

INFOID:0000000010260583



POWER GENERATION VOLTAGE VARIABLE CONTROL SYSTEM : System De-

SYSTEM

< SYSTEM DESCRIPTION >

scription

INFOID:0000000010260584

By performing the power generation voltage variable control, the engine load due to the power generation of the alternator is reduced and fuel consumption is decreased.

NOTE:

When any malfunction is detected in the power generation voltage variable control system, the power generation is performed according to the characteristic of the IC voltage regulator of the alternator.

CHARGING SYSTEM

< WIRING DIAGRAM >


WIRING DIAGRAM

CHARGING SYSTEM

Wiring Diagram

INFOID:0000000010260585

CHARGING SYSTEM



2014/07/11


JRMWG0982GB

CHARGING SYSTEM

< WIRING DIAGRAM >

CHARGING SYSTEM

Connector No.	E13
Connector Name	IPW L/R INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM
Connector Type	TH12FW-NH




Terminal No.	Color Of Wire	Signal Name [Specification]
23	GR/R	-
24	W/G	-
25	L/Y	-
26	P	-
27	L	-
28	V	-
30	R/W	-
32	LG	-
33	R	-
34	G	-

Connector No.	E61
Connector Name	WIRE TO WIRE
Connector Type	RH08MB



Terminal No.	Color Of Wire	Signal Name [Specification]
2	R	-
3	L/B	-
4	LG/R	-
5	W/G	-
7	V	-
8	B/R	-


Connector No.	E90
Connector Name	ECM
Connector Type	MAB5FB-MEB10-LH



Terminal No.	Color Of Wire	Signal Name [Specification]
111	R	FUEL INJECTOR DRIVER POWER SUPPLY
112	SB	FUEL INJECTOR DRIVER POWER SUPPLY
113	G	-
114	B	ECM GROUND
115	B	ECM GROUND
120	Y	EVAP CANISTER VENT CONTROL VALVE
122	BR/W	THROTTLE CONTROL MOTOR RELAY
123	V/R	THROTTLE CONTROL MOTOR RELAY
125	GR	FUEL PUMP CONTROL MODULE (FPCM)
126	O	ACCELERATOR PEDAL POSITION SENSOR 2
128	Y	ASC/D/CC STEERING SWITCH
129	P/L	SENSOR GROUND
130	R	SENSOR GROUND
131	L/W	SENSOR POWER SUPPLY
133	SB	SENSOR POWER SUPPLY
134	V/W	FUEL TEMPERATURE SENSOR
136	W/R	ACCELERATOR PEDAL POSITION SENSOR 1
137	W/G	SENSOR POWER SUPPLY
138	V	BATTERY CURRENT SENSOR
139	G	BATTERY TEMPERATURE SENSOR
140	R/Y	SENSOR GROUND
141	SB	IGNITION SWITCH
142	R/W	FUEL PUMP CONTROL MODULE (FPCM) CHECK
143	L/Y	EVAP CONTROL SYSTEM PRESSURE SENSOR
144	O/B	REFRIGERANT PRESSURE SENSOR
145	L	CAN COMMUNICATION LINE
146	G/Y	ASC/D/CC BRAKE SWITCH
150	R	SENSOR GROUND
151	P	CAN COMMUNICATION LINE
156	L	POWER SUPPLY FOR ECM (BACK-UP)
158	W/B	STOP LAMP SWITCH
161	R/W	ENG COMMUNICATION LINE
163	L/G	ECM RELAY (SELF SHUT-OFF)
165	GR/R	-
166	W	ENG COMMUNICATION LINE

169	G/B	ENGINE SPEED SIGNAL OUTPUT
171	W	POWER SUPPLY FOR ECM
172	W	POWER SUPPLY FOR ECM
173	O	THROTTLE CONTROL MOTOR POWER SUPPLY
174	B	ECM GROUND
175	B	ECM GROUND

Connector No.	E105
Connector Name	WIRE TO WIRE
Connector Type	TH80MH-CS16-TM4



Terminal No.	Color Of Wire	Signal Name [Specification]
1	L	-
2	L/W	-
3	R/B	-
4	L	-
5	Y	-
7	W/G	-
8	P/B	-
9	W/B	-
10	G	-
11	L	-
12	P	-
13	P/B	-
14	BR	-
15	L/B	-
16	SB	-
18	BR	-
19	Y/G	-
20	BR/Y	-
21	Y/V	-
22	L	-
23	Y	-
24	L/W	-
28	O	-
29	R/W	-
30	L/B	-
31	Y	-
32	GR/R	-

34	Y	-
35	R	-
36	B/R	-
37	G/Y	-
38	G	-
40	SB	-
41	W/R	-
42	R	-
43	V	-
54	GR/L	-
51	BR	-
52	L/W	-
54	Y/B	-
55	G/R	-
57	R	-
58	G/B	-
100	W/R	-

Connector No.	E201
Connector Name	BATTERY TERMINAL WITH FUSIBLE LINK
Connector Type	24340 79906



Terminal No.	Color Of Wire	Signal Name [Specification]
5	B/R	-

JRMWG0983GB

CHARGING SYSTEM

< WIRING DIAGRAM >

CHARGING SYSTEM

Connector No.	E203
Connector Name	ALTERNATOR
Connector Type	24340 EQ00A



Terminal No.	1
Color Of Wire	B/R
Signal Name [Specification]	-

Connector No.	E204
Connector Name	ALTERNATOR
Connector Type	E-BA506



Terminal No.	2
Color Of Wire	B
Signal Name [Specification]	-

Connector No.	E205
Connector Name	ALTERNATOR
Connector Type	NS03FB



Terminal No.	3
Color Of Wire	L/B
Signal Name [Specification]	-

Terminal No.	4
Color Of Wire	W
Signal Name [Specification]	-

Terminal No.	5
Color Of Wire	R
Signal Name [Specification]	-




Connector No.	E207
Connector Name	WIRE TO WIRE
Connector Type	RH03FB

Terminal No.	7A
Color Of Wire	LG
Signal Name [Specification]	-

Terminal No.	8A
Color Of Wire	W
Signal Name [Specification]	-

Connector No.	M24
Connector Name	COMBINATION METER
Connector Type	TH40FW-NH



Terminal No.	1
Color Of Wire	Y
Signal Name [Specification]	BATTERY POWER SUPPLY

Terminal No.	2
Color Of Wire	GR
Signal Name [Specification]	IGNITION SIGNAL

Terminal No.	3
Color Of Wire	B
Signal Name [Specification]	GROUND

Terminal No.	4
Color Of Wire	B
Signal Name [Specification]	ILL GND

Terminal No.	5
Color Of Wire	B
Signal Name [Specification]	ILL CONTROL OUTPUT

Terminal No.	6
Color Of Wire	GR
Signal Name [Specification]	LED HEADLAMP (RH) WARNING SIGNAL

Terminal No.	7
Color Of Wire	R
Signal Name [Specification]	TOW MODE SIGNAL

Terminal No.	8
Color Of Wire	P/L
Signal Name [Specification]	TRIP RESET SWITCH SIGNAL

Terminal No.	9
Color Of Wire	O
Signal Name [Specification]	LED HEADLAMP (LH) WARNING SIGNAL

Terminal No.	11
Color Of Wire	G
Signal Name [Specification]	ENTER SWITCH SIGNAL

Terminal No.	12
Color Of Wire	O
Signal Name [Specification]	SELECT SWITCH SIGNAL

Terminal No.	13
Color Of Wire	W/R
Signal Name [Specification]	ILLUMINATION CONTROL SWITCH SIGNAL (+)

Terminal No.	14
Color Of Wire	R
Signal Name [Specification]	ILLUMINATION CONTROL SWITCH SIGNAL (-)

Terminal No.	15
Color Of Wire	R/W
Signal Name [Specification]	AIR BAG SIGNAL

Terminal No.	18
Color Of Wire	W/R
Signal Name [Specification]	AMBIENT SENSOR SIGNAL

Terminal No.	19
Color Of Wire	V/W
Signal Name [Specification]	4-2 AUTO-AMP CONNECTION DETECTION SIGNAL

Terminal No.	20
Color Of Wire	B
Signal Name [Specification]	AMBIENT SENSOR GROUND

Terminal No.	21
Color Of Wire	L
Signal Name [Specification]	CAN-H

Terminal No.	22
Color Of Wire	P
Signal Name [Specification]	CAN-L

Terminal No.	23
Color Of Wire	P
Signal Name [Specification]	GROUND

Terminal No.	24
Color Of Wire	V
Signal Name [Specification]	FUEL LEVEL SENSOR GROUND

Terminal No.	25
Color Of Wire	O/L
Signal Name [Specification]	ALTERNATOR SIGNAL

Terminal No.	26
Color Of Wire	W
Signal Name [Specification]	PARKING BRAKE SWITCH SIGNAL

Terminal No.	28
Color Of Wire	GR/R
Signal Name [Specification]	SECURITY SIGNAL

Terminal No.	29
Color Of Wire	BR
Signal Name [Specification]	WASHER LEVEL SWITCH SIGNAL

Terminal No.	30
Color Of Wire	SB
Signal Name [Specification]	VEHICLE SPEED SIGNAL (2-PULSE)

Terminal No.	31
Color Of Wire	BR/W
Signal Name [Specification]	VEHICLE SPEED SIGNAL (3-PULSE)

Terminal No.	33
Color Of Wire	W
Signal Name [Specification]	SNOW MODE SIGNAL

Terminal No.	34
Color Of Wire	BR/Y
Signal Name [Specification]	FUEL LEVEL SENSOR SIGNAL

Terminal No.	35
Color Of Wire	O/B
Signal Name [Specification]	SEAT BELT BUCKLE SWITCH SIGNAL (DRIVER SIDE)

Terminal No.	36
Color Of Wire	G/Y
Signal Name [Specification]	PASSENGER SEAT BELT WARNING SIGNAL

Terminal No.	37
Color Of Wire	R/Y
Signal Name [Specification]	NON-MANUAL MODE SIGNAL

Terminal No.	38
Color Of Wire	G/Y
Signal Name [Specification]	-

Terminal No.	39
Color Of Wire	R
Signal Name [Specification]	-

Terminal No.	40
Color Of Wire	B/O
Signal Name [Specification]	-

Terminal No.	41
Color Of Wire	G/Y
Signal Name [Specification]	-

Terminal No.	42
Color Of Wire	G/Y
Signal Name [Specification]	-

Terminal No.	43
Color Of Wire	G/Y
Signal Name [Specification]	-

Terminal No.	44
Color Of Wire	G/Y
Signal Name [Specification]	-

Terminal No.	45
Color Of Wire	G/Y
Signal Name [Specification]	-

Terminal No.	46
Color Of Wire	G/Y
Signal Name [Specification]	-

Terminal No.	47
Color Of Wire	G/Y
Signal Name [Specification]	-

Terminal No.	48
Color Of Wire	G/Y
Signal Name [Specification]	-

Terminal No.	49
Color Of Wire	G/Y
Signal Name [Specification]	-

Terminal No.	50
Color Of Wire	G/Y
Signal Name [Specification]	-

Terminal No.	51
Color Of Wire	G/Y
Signal Name [Specification]	-

Terminal No.	52
Color Of Wire	G/Y
Signal Name [Specification]	-

Terminal No.	53
Color Of Wire	G/Y
Signal Name [Specification]	-

Terminal No.	54
Color Of Wire	G/Y
Signal Name [Specification]	-

Terminal No.	55
Color Of Wire	G/Y
Signal Name [Specification]	-

Terminal No.	56
Color Of Wire	G/Y
Signal Name [Specification]	-

Terminal No.	57
Color Of Wire	G/Y
Signal Name [Specification]	-

Terminal No.	58
Color Of Wire	G/Y
Signal Name [Specification]	-

Terminal No.	59
Color Of Wire	G/Y
Signal Name [Specification]	-

Terminal No.	60
Color Of Wire	G/Y
Signal Name [Specification]	-

Terminal No.	61
Color Of Wire	G/Y
Signal Name [Specification]	-

Terminal No.	62
Color Of Wire	G/Y
Signal Name [Specification]	-

Terminal No.	63
Color Of Wire	G/Y
Signal Name [Specification]	-

Terminal No.	64
Color Of Wire	G/Y
Signal Name [Specification]	-

Terminal No.	65
Color Of Wire	G/Y
Signal Name [Specification]	-

Terminal No.	66
Color Of Wire	G/Y
Signal Name [Specification]	-

Terminal No.	67
Color Of Wire	G/Y
Signal Name [Specification]	-

Terminal No.	68
Color Of Wire	G/Y
Signal Name [Specification]	-

Terminal No.	69
Color Of Wire	G/Y
Signal Name [Specification]	-

Terminal No.	70
Color Of Wire	G/Y
Signal Name [Specification]	-

Terminal No.	71
Color Of Wire	G/Y
Signal Name [Specification]	-

Terminal No.	72
Color Of Wire	G/Y
Signal Name [Specification]	-

Terminal No.	73
Color Of Wire	G/Y
Signal Name [Specification]	-

Terminal No.	74
Color Of Wire	G/Y
Signal Name [Specification]	-

Terminal No.	75
Color Of Wire	G/Y
Signal Name [Specification]	-

Terminal No.	76
Color Of Wire	G/Y
Signal Name [Specification]	-

Terminal No.	77
Color Of Wire	G/Y
Signal Name [Specification]	-

Terminal No.	78
Color Of Wire	G/Y
Signal Name [Specification]	-

Terminal No.	79
Color Of Wire	G/Y
Signal Name [Specification]	-

Terminal No.	80
Color Of Wire	G/Y
Signal Name [Specification]	-

Terminal No.	81
Color Of Wire	G/Y
Signal Name [Specification]	-

Terminal No.	82
Color Of Wire	G/Y
Signal Name [Specification]	-

Terminal No.	83
Color Of Wire	G/Y
Signal Name [Specification]	-

Terminal No.	84
Color Of Wire	G/Y
Signal Name [Specification]	-

Terminal No.	85
Color Of Wire	G/Y
Signal Name [Specification]	-

Terminal No.	86
Color Of Wire	G/Y
Signal Name [Specification]	-

Terminal No.	87
Color Of Wire	G/Y
Signal Name [Specification]	-

Terminal No.	88
Color Of Wire	G/Y
Signal Name [Specification]	-

Terminal No.	89
Color Of Wire	G/Y
Signal Name [Specification]	-

Terminal No.	90
Color Of Wire	G/Y
Signal Name [Specification]	-

Terminal No.	91
Color Of Wire	G/Y
Signal Name [Specification]	-

Terminal No.	92
Color Of Wire	G/Y
Signal Name [Specification]	-

Terminal No.	93
Color Of Wire	G/Y
Signal Name [Specification]	-

Terminal No.	94
Color Of Wire	G/Y
Signal Name [Specification]	-

Terminal No.	95
Color Of Wire	G/Y
Signal Name [Specification]	-

Terminal No.	96
Color Of Wire	G/Y
Signal Name [Specification]	-

Terminal No.	97
Color Of Wire	G/Y
Signal Name [Specification]	-

Terminal No.	98
Color Of Wire	G/Y
Signal Name [Specification]	-

Terminal No.	99
Color Of Wire	G/Y
Signal Name [Specification]	-

Terminal No.	100
Color Of Wire	G/Y
Signal Name [Specification]	-

Terminal No.	101
Color Of Wire	G/Y
Signal Name [Specification]	-

Terminal No.	102
Color Of Wire	G/Y
Signal Name [Specification]	-

Terminal No.	103
Color Of Wire	G/Y
Signal Name [Specification]	-

Terminal No.	104
Color Of Wire	G/Y
Signal Name [Specification]	-

Terminal No.	105
Color Of Wire	G/Y
Signal Name [Specification]	-

Terminal No.	106
Color Of Wire	G/Y
Signal Name [Specification]	-

< WIRING DIAGRAM >

CHARGING SYSTEM	
38	G
40	S8
41	W/R
42	R
43	V
54	GR/L
91	BR
92	L/W
94	Y/B
95	L/R
97	R
98	O/L
100	W/B
	-

JRMWG0985GB

DIAGNOSIS AND REPAIR WORKFLOW

< BASIC INSPECTION >

BASIC INSPECTION

DIAGNOSIS AND REPAIR WORKFLOW

Work Flow(With EXP-800 NI or GR8-1200 NI)

INFOID:0000000010260586

CHARGING SYSTEM DIAGNOSIS WITH EXP-800 NI OR GR8-1200 NI

To test the charging system, use the following special service tools:

- EXP-800 NI Battery and electrical diagnostic analyzer
- GR8-1200 NI Multitasking battery and electrical diagnostic station

NOTE:

Refer to the applicable Instruction Manual for proper charging system diagnosis procedures.

A

B

C

D

E

F

G

H

I

J

K

L

CHG

N


O

P

DIAGNOSIS AND REPAIR WORKFLOW

< BASIC INSPECTION >

OVERALL SEQUENCE



DETAILED FLOW

NOTE:

To ensure a complete and thorough diagnosis, the battery, starter and alternator test segments must be done as a set from start to finish.

1. PRELIMINARY INSPECTION

Perform the preliminary inspection. Refer to [CHG-20, "Inspection Procedure"](#).

DIAGNOSIS AND REPAIR WORKFLOW

< BASIC INSPECTION >

>> GO TO 2.

2. STOP POWER GENERATION VOLTAGE VARIABLE CONTROL SYSTEM

Stop the operation of the power generation voltage variable control in either of the following procedures.

- After selecting "ENGINE" of "SELECT SYSTEM" using CONSULT, set the DUTY value of "ALTERNATOR DUTY" to 0 % by selecting "ALTERNATOR DUTY" of "Active Test". Continue "Active Test" until the end of inspection. (When the DUTY value is 0 or 100 %, the normal power generation is performed according to the characteristic of the IC voltage regulator of the alternator.)
- Turn the ignition switch OFF, and disconnect the battery current sensor connector. [However, DTC (P1550 - P1554) of the engine might remain. After finishing the inspection, connect the battery current sensor connector and erase the self-diagnosis results history of the engine using CONSULT.]

>> GO TO 3.

3. DIAGNOSIS WITH EXP-800 NI OR GR8-1200 NI

Perform the charging system test using Multitasking battery and electrical diagnostic station GR8-1200 NI or Battery and electrical diagnostic analyzer EXP-800 NI. Refer to the applicable Instruction Manual for proper testing procedures.

Test result

NO PROBLEMS>>Charging system is normal and will also show "DIODE RIPPLE" test result.

NO VOLTAGE>>GO TO 4.

LOW VOLTAGE>>GO TO 12.

HIGH VOLTAGE>>GO TO 14.

EXCESSIVE RIPPLE, OPEN PHASE, OPEN DIODE or SHORTED DIODE>>Replace the alternator. Perform "DIODE RIPPLE" test again using Multitasking battery and electrical diagnostic station GR8-1200 NI or Battery and electrical diagnostic analyzer EXP-800 NI to confirm repair.

4. INSPECTION WITH CHARGE WARNING LAMP (IGNITION SWITCH IS ON)

Turn the ignition switch ON.

Does the charge warning lamp illuminate?

YES >> GO TO 6.

NO >> GO TO 5.

5. "L" TERMINAL CIRCUIT (OPEN) INSPECTION

Check "L" terminal circuit (open). Refer to [CHG-24, "Diagnosis Procedure"](#).

Is the "L" terminal circuit normal?

YES >> Replace alternator.

NO >> Repair as needed.

6. INSPECTION WITH CHARGE WARNING LAMP (IDLING)

Start the engine and run it at idle.

Does the charge warning lamp turn OFF?

YES >> GO TO 9.

NO >> GO TO 7.

7. "L" TERMINAL CIRCUIT (SHORT) INSPECTION

Check "L" terminal circuit (short). Refer to [CHG-26, "Diagnosis Procedure"](#).

Is the "L" terminal circuit normal?

YES >> GO TO 8.

NO >> Repair as needed.

8. "S" TERMINAL CIRCUIT INSPECTION

Check "S" terminal circuit. Refer to [CHG-27, "Diagnosis Procedure"](#).

Is the "S" terminal circuit normal?

YES >> GO TO 10.

NO >> Repair as needed.

DIAGNOSIS AND REPAIR WORKFLOW

< BASIC INSPECTION >

9. INSPECTION WITH CHARGE WARNING LAMP (ENGINE AT 3,000 RPM)

Increase and maintain the engine speed at 3,000 rpm.

Does the charge warning lamp remain off?

YES >> GO TO 11.

NO >> GO TO 10.

10. INSPECTION OF ALTERNATOR PULLEY

Check alternator pulley. Refer to [CHG-32, "Inspection"](#).

Is alternator pulley normal?

YES >> Replace alternator.

NO >> Repair as needed.

11. "B" TERMINAL CIRCUIT INSPECTION

Check "B" terminal circuit. Refer to [CHG-23, "Diagnosis Procedure"](#).

Is "B" terminal circuit normal?

YES >> Replace alternator.

NO >> Repair as needed.

12. "B" TERMINAL CIRCUIT INSPECTION

Check "B" terminal circuit. Refer to [CHG-23, "Diagnosis Procedure"](#).

Is "B" terminal circuit normal?

YES >> GO TO 13.

NO >> Repair as needed.

13. INSPECTION OF ALTERNATOR PULLEY

Check alternator pulley. Refer to [CHG-32, "Inspection"](#).

Is alternator pulley normal?

YES >> Replace alternator.

NO >> Repair as needed.

14. "S" TERMINAL CIRCUIT INSPECTION

Check "S" terminal circuit. Refer to [CHG-27, "Diagnosis Procedure"](#).

Is the "S" terminal circuit normal?

YES >> Replace alternator.

NO >> Repair as needed.


DIAGNOSIS AND REPAIR WORKFLOW

< BASIC INSPECTION >

Work Flow(Without EXP-800 NI or GR8-1200 NI)

INFOID:000000010260587

OVERALL SEQUENCE



DETAILED FLOW

1. PRELIMINARY INSPECTION

Perform the preliminary inspection. Refer to [CHG-20, "Inspection Procedure"](#).

DIAGNOSIS AND REPAIR WORKFLOW

< BASIC INSPECTION >

>> GO TO 2.

2. STOP POWER GENERATION VOLTAGE VARIABLE CONTROL SYSTEM

Stop the operation of the power generation voltage variable control in either of the following procedures.

- After selecting "ENGINE" of "SELECT SYSTEM" using CONSULT, set the DUTY value of "ALTERNATOR DUTY" to 0 % by selecting "ALTERNATOR DUTY" of "Active Test". Continue "Active Test" until the end of inspection. (When the DUTY value is 0 or 100 %, the normal power generation is performed according to the characteristic of the IC voltage regulator of the alternator.)
- Turn the ignition switch OFF, and disconnect the battery current sensor connector. [However, DTC (P1550 - P1554) of the engine might remain. After finishing the inspection, connect the battery current sensor connector and erase the self-diagnosis results history of the engine using CONSULT.]

>> GO TO 3.

3. INSPECTION WITH CHARGE WARNING LAMP (IGNITION SWITCH IS TURNED ON)

When ignition switch is turned ON

Does the charge warning lamp illuminate?

YES >> GO TO 4.

NO >> GO TO 10.

4. INSPECTION WITH CHARGE WARNING LAMP (IDLING)

Start the engine and run it at idle.

Does the charge warning lamp turn OFF?

YES >> GO TO 5.

NO >> GO TO 6.

5. INSPECTION WITH CHARGE WARNING LAMP (ENGINE AT 2,500 RPM)

Increase and maintain the engine speed at 2,500 rpm.

Does the charge warning lamp illuminate?

YES >> GO TO 8.

NO >> INSPECTION END

6. "L" TERMINAL CIRCUIT (SHORT) INSPECTION

Check "L" terminal circuit (short). Refer to [CHG-26, "Diagnosis Procedure"](#).

Is the inspection result normal?

YES >> GO TO 7.

NO >> Repair as needed.

7. "S" TERMINAL CIRCUIT INSPECTION

Check "S" terminal circuit. Refer to [CHG-27, "Diagnosis Procedure"](#).

Is the inspection result normal?

YES >> GO TO 8.

NO >> Repair as needed.

8. MEASURE "B" TERMINAL VOLTAGE

Start engine. With engine running at 2,500 rpm, measure "B" terminal voltage.

What voltage does the measurement result show?

Less than 13.0 V >> GO TO 9.

More than 16.0 V >> Replace alternator. Refer to [CHG-30, "Removal and Installation"](#).

9. "B" TERMINAL CIRCUIT INSPECTION

Check "B" terminal circuit. Refer to [CHG-23, "Diagnosis Procedure"](#).

Is the inspection result normal?

YES >> Replace alternator. Refer to [CHG-30, "Removal and Installation"](#).

NO >> Repair as needed.

10. INSPECTION WITH CHARGE WARNING LAMP (IGNITION SWITCH IS ON)

DIAGNOSIS AND REPAIR WORKFLOW

< BASIC INSPECTION >

1. Disconnect alternator connector and apply ground to "L" terminal.
2. Turn the ignition switch ON.

Does the charge warning lamp illuminate?

YES >> Replace alternator. Refer to [CHG-30. "Removal and Installation"](#).

NO >> GO TO 11.

11.CHECK "L" TERMINAL CIRCUIT (OPEN)

Check "L" terminal circuit (open). Refer to [CHG-24. "Diagnosis Procedure"](#).

>> Repair as needed.

A

B

C

D

E

F

G

H

I

J

K

L

CHG

N

O

P

CHARGING SYSTEM PRELIMINARY INSPECTION

< BASIC INSPECTION >

CHARGING SYSTEM PRELIMINARY INSPECTION

Inspection Procedure

INFOID:000000010260588

1.CHECK BATTERY TERMINALS CONNECTION

Check if battery terminals are clean and tight.

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair battery terminals connection.

2.CHECK FUSE

Check for blown fuse and fusible link.

Unit	Power source (Power supply terminals)	Fuse No.
Alternator	Battery ("S" terminal)	32
Combination meter	Ignition switch ON ("L" terminal)	3

Is the inspection result normal?

YES >> GO TO 3.

NO >> Replace the blown fuse after repairing the applicable circuit.

3.CHECK "E" TERMINAL CONNECTION

Check if "E" terminal (alternator ground harness) is clean and tight.

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair "E" terminal connection.

4.CHECK DRIVE BELT TENSION

Check drive belt tension. Refer to [EM-20, "Checking"](#).

Is the inspection result normal?

YES >> INSPECTION END

NO >> Repair as needed.

POWER GENERATION VOLTAGE VARIABLE CONTROL SYSTEM OPERATION INSPECTION

< BASIC INSPECTION >

POWER GENERATION VOLTAGE VARIABLE CONTROL SYSTEM OPERATION INSPECTION

Inspection Procedure

INFOID:000000010260589

CAUTION:

When performing this inspection, always use a charged battery that has completed the battery inspection. (When the charging rate of the battery is low, the response speed of the voltage change will become slow. This can cause an incorrect inspection.)

1.CHECK ECM (CONSULT)

Perform ECM self-diagnosis with CONSULT. Refer to [EC-71. "CONSULT Function"](#).

Self-diagnostic results content

No malfunction detected>> GO TO 2.

Malfunction detected>> Check applicable parts, and repair or replace corresponding parts.

2.CHECK OPERATION OF POWER GENERATION VOLTAGE VARIABLE CONTROL SYSTEM

1. Connect CONSULT and start the engine.
2. shift the selector lever to "P" or "N" position and turn off all of the electric loads and A/C, etc.
3. Select "ALTERNATOR DUTY" at "Active Test" of "ENGINE", and then check the value of "BATTERY VOLT" monitor when DUTY value of "ALTERNATOR DUTY" is set to 40.0 %.

"BATTERY VOLT"

2 seconds after setting the
DUTY value of "ALTERNATOR DUTY" to 40.0 % : 12 - 13.6 V

4. Check the value of "BATTERY VOLT" monitor when DUTY value of "ALTERNATOR DUTY" is set to 80.0%.

"BATTERY VOLT"

20 seconds after setting
the DUTY value of "ALTERNATOR DUTY" to 80.0 % : +0.5 V or more against
the value of "BATTERY VOLT" monitor when
DUTY value is 40.0 %

Is the measurement value within the specification?

YES >> INSPECTION END

NO >> GO TO 3.

3.CHECK IPDM E/R (CONSULT)

Perform IPDM E/R self-diagnosis with CONSULT. Refer to [PCS-12. "CONSULT Function \(IPDM E/R\)"](#).

Self-diagnostic results content

No malfunction detected>> GO TO 4.

Malfunction detected>> Check applicable parts, and repair or replace corresponding parts.

4.CHECK HARNESS BETWEEN ALTERNATOR AND IPDM E/R

1. Turn ignition switch OFF.
2. Disconnect alternator harness connector and IPDM E/R harness connector.
3. Check continuity between alternator harness connector and IPDM E/R harness connector.

Alternator		IPDM E/R		Continuity
Connector	Terminal	Connector	Terminal	
E205	5	E13	33	Existed

4. Check continuity between alternator harness connector and ground.

POWER GENERATION VOLTAGE VARIABLE CONTROL SYSTEM OPERATION INSPECTION

< BASIC INSPECTION >

Alternator		Ground	Continuity
Connector	Terminal		
E205	5		Not existed

Is the inspection result normal?

YES >> Replace IPDM E/R.

NO >> Repair harness or connector between IPDM E/R and alternator.

B TERMINAL CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

DTC/CIRCUIT DIAGNOSIS

B TERMINAL CIRCUIT

Description

INFOID:0000000010260590

"B" terminal circuit supplies power to charge the battery and to operate the vehicle's electrical system.

Diagnosis Procedure

INFOID:0000000010260591

1.CHECK "B" TERMINAL CONNECTION

1. Turn ignition switch OFF.
2. Check that "B" terminal is clean and tight.

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair "B" terminal connection. Confirm repair by performing complete Charging system test using EXP-800 NI or GR8-1200 NI (if available). Refer to the applicable Instruction Manual for proper testing procedures.

2.CHECK "B" TERMINAL CIRCUIT

Check voltage between alternator "B" terminal and ground.

(+)		(-)	Voltage
Alternator			
Connector	Terminal		
E203	1	Ground	Battery voltage

Is the inspection result normal?

YES >> GO TO 3.

NO >> Check harness for open between alternator and fusible link.

3.CHECK "B" TERMINAL CONNECTION (VOLTAGE DROP TEST)

1. Start engine, then engine running at idle and warm.
2. Check voltage between battery positive terminal and alternator "B" terminal.

(+)	(-)		Voltage (V) (Approx.)
	Alternator		
	Connector	Terminal	
Battery positive terminal	E203	1	Less than 0.2

Is the inspection result normal?

YES >> "B" terminal circuit is normal. Refer to [CHG-13, "Work Flow\(With EXP-800 NI or GR8-1200 NI\)"](#) or [CHG-17, "Work Flow\(Without EXP-800 NI or GR8-1200 NI\)"](#).

NO >> Check harness between battery and alternator for poor continuity.

CHG

L TERMINAL CIRCUIT (OPEN)

< DTC/CIRCUIT DIAGNOSIS >

L TERMINAL CIRCUIT (OPEN)

Description

INFOID:000000010260592

The "L" terminal circuit controls the charge warning lamp. The charge warning lamp illuminates when the ignition switch is set to ON or START. When the alternator is providing sufficient voltage with the engine running, the charge warning lamp will go off. If the charge warning lamp illuminates with the engine running, a malfunction is indicated.

Diagnosis Procedure

INFOID:000000010260593

1.CHECK "L" TERMINAL CONNECTION

1. Turn ignition switch OFF.
2. Check that "L" terminal is clean and tight.

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair "L" terminal connection. Confirm repair by performing complete Charging system test using EXP-800 NI or GR8-1200 NI (if available). Refer to the applicable Instruction Manual for proper testing procedures.

2.CHECK "L" TERMINAL CIRCUIT (OPEN)

1. Disconnect alternator connector.
2. Apply ground to alternator harness connector terminal.
3. Check condition of the charge warning lamp with the ignition switch in the ON position.

(+)		(-)	Condition	Charge warning lamp
Alternator				
Connector	Terminal			
E205	3	Ground	Ignition switch ON	ON

Does it illuminate?

YES >> "L" terminal circuit is normal. Refer to [CHG-13, "Work Flow\(With EXP-800 NI or GR8-1200 NI\)"](#) or [CHG-17, "Work Flow\(Without EXP-800 NI or GR8-1200 NI\)"](#).

NO >> GO TO 3.

3.CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the battery cable from the negative terminal.
2. Disconnect the combination meter connector.
3. Check continuity between alternator harness connector and combination meter harness connector.

Alternator		Combination meter		Continuity
Connector	Terminal	Connector	Terminal	
E205	3	M34	25	Existed

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair the harness or connector.

4.CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

Check continuity between combination meter harness connector and fuse block (J/B).

Combination meter		Fuse block (J/B)		Continuity
Connector	Terminal	Connector	Terminal	
M34	2	M1	2A	Existed

Is the inspection result normal?

YES >> GO TO 5.

NO >> Repair the harness or connector.

L TERMINAL CIRCUIT (OPEN)

< DTC/CIRCUIT DIAGNOSIS >

5.CHECK POWER SUPPLY CIRCUIT

- 1. Connect the battery cable to the negative terminal.
- 2. Check voltage between combination meter harness connector and ground.

(+)		(-)	Condition	Voltage
Combination meter				
Connector	Terminal			
M34	2	Ground	Ignition switch ON	Battery voltage

Is the inspection result normal?

- YES >> Replace combination meter.
- NO >> Inspect the power supply circuit. Refer to [PG-60, "Wiring Diagram - IGNITION POWER SUPPLY -](#)
[".](#)

CHG

L TERMINAL CIRCUIT (SHORT)

< DTC/CIRCUIT DIAGNOSIS >

L TERMINAL CIRCUIT (SHORT)

Description

INFOID:0000000010260594

The "L" terminal circuit controls the charge warning lamp. The charge warning lamp illuminates when the ignition switch is set to ON or START. When the alternator is providing sufficient voltage with the engine running, the charge warning lamp will go off. If the charge warning lamp illuminates with the engine running, a malfunction is indicated.

Diagnosis Procedure

INFOID:0000000010260595

1.CHECK "L" TERMINAL CIRCUIT (SHORT)

1. Turn ignition switch OFF.
2. Disconnect alternator connector.
3. Turn ignition switch ON.

Does charge warning lamp illuminate?

YES >> GO TO 2.

NO >> Refer to [CHG-13. "Work Flow\(With EXP-800 NI or GR8-1200 NI\)"](#) or [CHG-17. "Work Flow\(Without EXP-800 NI or GR8-1200 NI\)"](#).

2.CHECK HARNESS CONTINUITY (SHORT CIRCUIT)

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Disconnect combination meter connector.
4. Check continuity between combination meter harness connector and ground.

Combination meter		Ground	Continuity
Connector	Terminal		
M34	25		Not existed

Is the inspection result normal?

YES >> Replace combination meter.

NO >> Repair the harness or connector.

S TERMINAL CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

S TERMINAL CIRCUIT

Description

INFOID:0000000010260596

The output voltage of the alternator is controlled by the IC voltage regulator at the "S" terminal detecting the input voltage.

The "S" terminal circuit detects the battery voltage to adjust the alternator output voltage with the IC voltage regulator.

Diagnosis Procedure

INFOID:0000000010260597

1.CHECK "S" TERMINAL CONNECTION

1. Turn ignition switch OFF.
2. Check if "S" terminal is clean and tight.

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair "S" terminal connection. Confirm repair by performing complete Charging system test using EXP-800 NI or GR8-1200 NI (if available). Refer to the applicable Instruction Manual for proper testing procedures.

2.CHECK "S" TERMINAL CIRCUIT

Check voltage between alternator harness connector and ground.

(+) Alternator		(-)	Voltage
Connector	Terminal		
E205	4	Ground	Battery voltage

Is the inspection result normal?

YES >> Refer to [CHG-13. "Work Flow\(With EXP-800 NI or GR8-1200 NI\)"](#) or [CHG-17. "Work Flow\(Without EXP-800 NI or GR8-1200 NI\)"](#).

NO >> Check harness for open between alternator and fuse.

CHG

CHARGING SYSTEM

< SYMPTOM DIAGNOSIS >

SYMPTOM DIAGNOSIS

CHARGING SYSTEM

Symptom Table

INFOID:0000000010260598

Symptom	Reference
Discharged battery	Refer to CHG-13, "Work Flow(With EXP-800 NI or GR8-1200 NI)" or CHG-17, "Work Flow(Without EXP-800 NI or GR8-1200 NI)" .
The charge warning lamp does not illuminate when the ignition switch is set to ON.	
The charge warning lamp does not turn OFF after the engine starts.	
The charging warning lamp turns ON when increasing the engine speed.	

ALTERNATOR

< REMOVAL AND INSTALLATION >


REMOVAL AND INSTALLATION

ALTERNATOR

Exploded View

REMOVAL

INFOID:0000000010260599



- | | | |
|-----------------------|--------------------------------------|----------------------------------|
| 1. Alternator bracket | 2. Alternator bracket mounting bolt | 3. "B" terminal harness |
| 4. "B" terminal nut | 5. Alternator connector | 6. Alternator |
| 7. Alternator stay | 8. Alternator mounting bolt (lower) | 9. Alternator stay mounting bolt |
| 10. Ground harness | 11. Alternator mounting bolt (upper) | |

: N·m (kg-m, ft-lb)


DISASSEMBLY

CHG

ALTERNATOR

< REMOVAL AND INSTALLATION >

Type: A002TX1491



- | | | |
|--------------------|---------------------------|----------------------------------|
| 1. Rear bearing | 2. Rotor assembly | 3. Retainer |
| 4. Front bearing | 5. Front bracket assembly | 6. Pulley |
| 7. Pulley nut | 8. Stator assembly | 9. IC voltage regulator assembly |
| 10. Diode assembly | 11. Rear bracket assembly | 12. Terminal set |

⊗ : Always replace after every disassembly.

⌚ : N·m (kg-m, ft-lb)


⌚ : N·m (kg-m, in-lb)

Removal and Installation

INFOID:0000000010260600

REMOVAL


1. Disconnect the battery cable from the negative terminal. Refer to [PG-141, "Removal and Installation"](#).
2. Remove front under cover. Refer to [EXT-26, "Removal and Installation"](#).
3. Remove drive belt. Refer to [EM-20, "Removal and Installation"](#).
4. Disconnect engine oil pressure switch connector (A) and alternator connector (B).
5. Remove harness bracket bolt (C).
6. Remove "B" terminal nut (D) and disconnect "B" terminal harness.




ALTERNATOR

< REMOVAL AND INSTALLATION >


7. Remove ground harness mounting bolt.



8. Remove alternator mounting bolt (lower), and then alternator mounting bolt (upper).
9. Remove A/T fluid cooler tube (1) from fan shroud (2).



10. Move A/T fluid cooler tube (1) and secure work space.
11. Remove alternator assembly (2) from underneath the vehicle.




INSTALLATION

Note the following items, and then install in the reverse order of removal.

CAUTION:

- Be careful to tighten "B" terminal nut to the specified torque.
- Install alternator, and check tension of belt. Refer to [EM-20, "Checking"](#).
- For this model, the power generation voltage variable control system that controls the power generation voltage of the alternator has been adopted. Therefore, the power generation voltage variable control system operation inspection should be performed after replacing the alternator, and then make sure that the system operates normally. Refer to [CHG-21, "Inspection Procedure"](#).
- When installing alternator bracket, tighten mounting bolts in numerical order as shown in the figure.



A
B
C
D
E
F
G
H
I
J
K
L

CHG

N
O
P

ALTERNATOR

< REMOVAL AND INSTALLATION >

Inspection

INFOID:0000000010260601

ALTERNATOR PULLEY INSPECTION

Perform the following.

- Make sure that alternator pulley does not rattle.
- Make sure that alternator pulley nut is tight. Refer to [CHG-29. "Exploded View"](#).

SERVICE DATA AND SPECIFICATIONS (SDS)

< SERVICE DATA AND SPECIFICATIONS (SDS)

SERVICE DATA AND SPECIFICATIONS (SDS)

SERVICE DATA AND SPECIFICATIONS (SDS)

Alternator

INFOID:0000000010260602

Type		A002TX1491
		MITSUBISHI make
Nominal rating	[V - A]	12 -150
Ground polarity		Negative
Minimum revolution under no-load (When 13.5 V is applied)	[rpm]	Less than 1,300
Hot output current (When 13.5 V is applied)	[A/rpm]	More than 126/2,500 More than 152/5,000
Regulated output voltage	[V]	14.1 - 14.7*

*: Adjustment range of power generation voltage variable control is 11.4 - 15.6 V.

A

B

C

D

E

F

G

H

I

J

K

L

CHG

N

O

P