

SECTION DLN

DRIVELINE

A

B

C

DLN

CONTENTS

E

TRANSFER: ATX90A	ECU DIAGNOSIS INFORMATION	25	F
PRECAUTION	TRANSFER CONTROL UNIT	25	G
PRECAUTIONS	Reference Value	25	
Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"	Fail-Safe	29	
Precautions for Removing Battery Terminal	DTC Inspection Priority Chart	30	H
Service Notice or Precautions for Transfer	DTC Index	30	
PREPARATION	WIRING DIAGRAM	32	I
PREPARATION	4WD SYSTEM	32	
Special Service Tools	Wiring Diagram	32	J
Commercial Service Tools	BASIC INSPECTION	39	
SYSTEM DESCRIPTION	DIAGNOSIS AND REPAIR WORK FLOW	39	K
COMPONENT PARTS	Work Flow	39	
Component Parts Location	Diagnostic Work Sheet	40	L
Component Description	ADDITIONAL SERVICE WHEN REPLACING TRANSFER CONTROL UNIT	42	
Transfer Control Unit	Description	42	M
Transfer Control Actuator	Work Procedure	42	
Transfer Hi-Lo Position Sensor	ADDITIONAL SERVICE WHEN REPLACING TRANSFER ASSEMBLY	43	N
Transfer Rotary Position Sensor	Description	43	
Transfer Lock Position Sensor	Work Procedure	43	O
Transfer Fluid Temperature Sensor	TRANSFER LOCK POSITION SENSOR LEARNING	45	
STRUCTURE AND OPERATION	Description	45	P
Sectional View	Work Procedure	45	
Torque Split Mechanism	TRANSFER ROTARY POSITION SENSOR LEARNING	47	
SYSTEM	Description	47	
4WD SYSTEM	Work Procedure	47	
4WD SYSTEM : System Description	TRANSFER FLUID VISCOSITY LEARNING	48	
4WD SYSTEM : Fail-Safe	Description	48	
DIAGNOSIS SYSTEM (TRANSFER CONTROL UNIT)	Work Procedure	48	
CONSULT Function			

CONFIGURATION (TRANSFER CONTROL UNIT)	49	P181A TRANSFER MOTOR TEMPERATURE SENSOR	75
Description	49	DTC Logic	75
Work Procedure	49	Diagnosis Procedure	75
DTC/CIRCUIT DIAGNOSIS	52	Component Inspection	76
P1802, P1803, P1804, P1809 TRANSFER CONTROL UNIT	52	P181B INCOMPLETE SELF SHUT	77
DTC Logic	52	DTC Logic	77
Diagnosis Procedure	52	Diagnosis Procedure	77
P1807 OUT PUT SHAFT SPEED SENSOR	53	P181C TRANSFER MOTOR POWER SUPPLY	79
DTC Logic	53	Description	79
Diagnosis Procedure	53	DTC Logic	79
P1808 WHEEL SPEED SENSOR	54	Diagnosis Procedure	79
DTC Logic	54	P181E STEERING ANGLE SENSOR	81
Diagnosis Procedure	54	DTC Logic	81
P180C SENSOR POWER SUPPLY (5V)	55	Diagnosis Procedure	81
Description	55	P181F INCOMPLETE CALIBRATION	82
DTC Logic	55	DTC Logic	82
Diagnosis Procedure	55	Diagnosis Procedure	82
P180D TRANSFER ROTARY POSITION SENSOR	58	P1820 ENGINE SPEED SIGNAL	83
DTC Logic	58	DTC Logic	83
Diagnosis Procedure	58	Diagnosis Procedure	83
P180E SENSOR POWER SUPPLY (8V)	61	P1826 TRANSFER FLUID TEMPERATURE ...	84
Description	61	DTC Logic	84
DTC Logic	61	Diagnosis Procedure	84
Diagnosis Procedure	61	Component Inspection	85
P180F TRANSFER INTERNAL SPEED SENSOR	63	P1829 ACCELERATOR PEDAL POSITION SENSOR	86
DTC Logic	63	DTC Logic	86
Diagnosis Procedure	63	Diagnosis Procedure	86
P1811 POWER SUPPLY CIRCUIT FOR TRANSFER CONTROL UNIT	66	P182A TRANSFER HI-LO POSITION SENSOR	87
Description	66	DTC Logic	87
DTC Logic	66	Diagnosis Procedure	87
Diagnosis Procedure	66	P182B TRANSFER LOCK POSITION SENSOR	89
P1813 4WD MODE SWITCH	69	DTC Logic	89
DTC Logic	69	Diagnosis Procedure	89
Diagnosis Procedure	69	P1830 ABS OPERATION SIGNAL	92
Component Inspection	70	DTC Logic	92
P1816 PARKING/NEUTRAL POSITION SWITCH	72	Diagnosis Procedure	92
DTC Logic	72	P1831 VDC OPERATION SIGNAL	93
Diagnosis Procedure	72	DTC Logic	93
P1817 TRANSFER MOTOR	73	Diagnosis Procedure	93
DTC Logic	73	P1832 TCS OPERATION SIGNAL	94
Diagnosis Procedure	73	DTC Logic	94
Component Inspection	74	Diagnosis Procedure	94
		U1000 CAN COMM CIRCUIT	95

Description	95	TRANSFER CONTROL UNIT	112	
DTC Logic	95	Removal and Installation	112	A
Diagnosis Procedure	95			
U1010 CONTROL UNIT (CAN)	96	4WD MODE SWITCH	113	
Description	96	Removal and Installation	113	B
DTC Logic	96			
Diagnosis Procedure	96	FRONT OIL SEAL	114	
		Exploded View	114	
		Removal and Installation	114	C
POWER SUPPLY AND GROUND CIRCUIT	97			
Description	97	REAR OIL SEAL	116	
Diagnosis Procedure	97	Exploded View	116	
		Removal and Installation	116	DLN
		Adjustment	117	
4WD WARNING LAMP	101			
Component Function Check	101	TRANSFER CONTROL ACTUATOR	119	E
Diagnosis Procedure	101	Exploded View	119	
		Removal and Installation	119	
4WD INDICATOR LAMP	102	Inspection	119	F
Component Function Check	102			
Diagnosis Procedure	102	TRANSFER HI-LO POSITION SENSOR	121	
		Exploded View	121	
SYMPTOM DIAGNOSIS	103	Removal and Installation	121	G
		Inspection	121	
HEAVY TIGHT-CORNER BRAKING SYMP- TOM OCCURS	103			
Description	103	TRANSFER ROTARY POSITION SENSOR ...	122	H
Diagnosis Procedure	103	Exploded View	122	
		Removal and Installation	122	
4WD MODE DOES NOT CHANGE	104	Inspection	123	I
Description	104			
Diagnosis Procedure	104	TRANSFER LOCK POSITION SENSOR	124	
		Exploded View	124	
4WD MODE INDICATOR LAMP CONTINUES BLINKING	105	Removal and Installation	124	J
Description	105	Inspection	125	
Diagnosis Procedure	105			
4WD WARNING LAMP BLINKS QUICKLY	106	TRANSFER FLUID TEMPERATURE SEN- SOR	126	K
Description	106	Exploded View	126	
		Removal and Installation	126	
4WD WARNING LAMP BLINKS SLOWLY	107	Inspection	126	L
Description	107			
Diagnosis Procedure	107	UNIT REMOVAL AND INSTALLATION ...	127	
INFORMATION DISPLAY IS NOT DIS- PLAYED	108	TRANSFER ASSEMBLY	127	M
Description	108	Exploded View	127	
Diagnosis Procedure	108	Removal and Installation	127	
NOISE, VIBRATION AND HARSHNESS (NVH) TROUBLESHOOTING	109	INPUT OIL SEAL	130	N
NVH Troubleshooting Chart	109	Exploded View	130	
		Removal and Installation	130	
PERIODIC MAINTENANCE	110			O
		SERVICE DATA AND SPECIFICATIONS (SDS)	131	
TRANSFER FLUID	110			P
Inspection	110	SERVICE DATA AND SPECIFICATIONS (SDS)	131	
Draining	110	General Specifications	131	
Refilling	110	FRONT PROPELLER SHAFT: 2F P15		
REMOVAL AND INSTALLATION	112	PRECAUTION	132	
		PRECAUTIONS	132	

Precautions for Removing Battery Terminal	132
PREPARATION	133
PREPARATION	133
Commercial Service Tools	133
SYMPTOM DIAGNOSIS	134
NOISE, VIBRATION, AND HARSHNESS	
(NVH) TROUBLESHOOTING	134
NVH Troubleshooting Chart	134
PERIODIC MAINTENANCE	135
FRONT PROPELLER SHAFT	135
Inspection	135
REMOVAL AND INSTALLATION	136
FRONT PROPELLER SHAFT	136
Exploded View	136
Removal and Installation	137
Disassembly and Assembly	137
Inspection	139
SERVICE DATA AND SPECIFICATIONS	
(SDS)	141
SERVICE DATA AND SPECIFICATIONS	
(SDS)	141
General Specification	141
Propeller Shaft Runout	141
Journal Axial Play	141
REAR PROPELLER SHAFT: 2F P26	
PRECAUTION	142
PRECAUTIONS	142
Precautions for Removing Battery Terminal	142
SYMPTOM DIAGNOSIS	143
NOISE, VIBRATION, AND HARSHNESS	
(NVH) TROUBLESHOOTING	143
NVH Troubleshooting Chart	143
PERIODIC MAINTENANCE	144
REAR PROPELLER SHAFT	144
Inspection	144
REMOVAL AND INSTALLATION	145
REAR PROPELLER SHAFT	145
Exploded View	145
Removal and Installation	146
Disassembly and Assembly	146
Inspection	148
SERVICE DATA AND SPECIFICATIONS	
(SDS)	150

SERVICE DATA AND SPECIFICATIONS	
(SDS)	150
General Specification	150
Propeller Shaft Runout	150
Journal Axial Play	150
REAR PROPELLER SHAFT: 2S1410	
PRECAUTION	151
PRECAUTIONS	151
Precautions for Removing Battery Terminal	151
SYMPTOM DIAGNOSIS	152
NOISE, VIBRATION, AND HARSHNESS	
(NVH) TROUBLESHOOTING	152
NVH Troubleshooting Chart	152
PERIODIC MAINTENANCE	153
REAR PROPELLER SHAFT	153
Inspection	153
REMOVAL AND INSTALLATION	154
REAR PROPELLER SHAFT	154
Exploded View	154
Removal and Installation	155
Disassembly and Assembly	155
Inspection	157
SERVICE DATA AND SPECIFICATIONS	
(SDS)	159
SERVICE DATA AND SPECIFICATIONS	
(SDS)	159
General Specification	159
Propeller Shaft Runout	159
Journal Axial Play	159
FRONT FINAL DRIVE: R180A	
PRECAUTION	160
PRECAUTIONS	160
Precautions for Removing Battery Terminal	160
Precaution for Servicing Front Final Drive	160
PREPARATION	161
PREPARATION	161
Special Service Tool	161
Commercial Service Tool	163
SYSTEM DESCRIPTION	165
STRUCTURE AND OPERATION	165
Sectional View	165
SYMPTOM DIAGNOSIS	166
NOISE, VIBRATION AND HARSHNESS	
(NVH) TROUBLESHOOTING	166

NVH Troubleshooting Chart	166	
PERIODIC MAINTENANCE	167	
FRONT DIFFERENTIAL GEAR OIL	167	
Inspection	167	
Draining	167	
Refilling	167	
REMOVAL AND INSTALLATION	168	
FRONT OIL SEAL	168	
Exploded View	168	
Removal and Installation	168	
SIDE OIL SEAL	172	
Exploded View	172	
Removal and Installation	172	
UNIT REMOVAL AND INSTALLATION ...	174	
FRONT FINAL DRIVE ASSEMBLY	174	
Exploded View	174	
Removal and Installation	174	
UNIT DISASSEMBLY AND ASSEMBLY .	176	
SIDE SHAFT	176	
Exploded View	176	
Disassembly	177	
Assembly	178	
Inspection	178	
DIFFERENTIAL ASSEMBLY	179	
Exploded View	179	
Disassembly	180	
Assembly	181	
Adjustment	183	
Inspection	186	
DRIVE PINION	188	
Exploded View	188	
Disassembly	189	
Assembly	191	
Adjustment	193	
Inspection	196	
SERVICE DATA AND SPECIFICATIONS (SDS)	198	
SERVICE DATA AND SPECIFICATIONS (SDS)	198	
General Specifications	198	
Drive Gear Runout	198	
Preload Torque	198	
Backlash	198	
Companion Flange Runout	198	
REAR FINAL DRIVE: R230		
PRECAUTION	199	
PRECAUTIONS	199	
Precautions for Removing Battery Terminal	199	A
Service Notice or Precautions for Rear Final Drive	199	
PREPARATION	200	B
PREPARATION	200	
Special Service Tool	200	
Commercial Service Tool	202	C
SYSTEM DESCRIPTION	204	
STRUCTURE AND OPERATION	204	DLN
Sectional View	204	
SYMPTOM DIAGNOSIS	205	E
NOISE, VIBRATION AND HARSHNESS (NVH) TROUBLESHOOTING	205	
NVH Troubleshooting Chart	205	F
PERIODIC MAINTENANCE	206	
REAR DIFFERENTIAL GEAR OIL	206	G
Inspection	206	
Draining	206	
Refilling	206	H
REMOVAL AND INSTALLATION	207	
FRONT OIL SEAL	207	I
Exploded View	207	
Removal and Installation	207	J
SIDE OIL SEAL	212	
Exploded View	212	
Removal and Installation	212	K
UNIT REMOVAL AND INSTALLATION ...	214	
REAR FINAL DRIVE	214	L
Exploded View	214	
Removal and Installation	214	
UNIT DISASSEMBLY AND ASSEMBLY .	216	M
DIFFERENTIAL ASSEMBLY	216	
Exploded View	216	N
Disassembly	217	
Assembly	219	
Adjustment	223	O
Inspection	228	
DRIVE PINION	229	P
Exploded View	229	
Disassembly	230	
Assembly	231	
Adjustment	233	
Inspection	234	
SERVICE DATA AND SPECIFICATIONS (SDS)	235	

SERVICE DATA AND SPECIFICATIONS	
(SDS)	235
General Specification	235
Drive Gear Runout	235
Side Gear Clearance	235
Preload Torque	235
Backlash	235
Companion Flange Runout	235

PRECAUTION

PRECAUTIONS

Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"

INFOID:0000000010262176

The Supplemental Restraint System such as "AIR BAG" and "SEAT BELT PRE-TENSIONER", used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. Information necessary to service the system safely is included in the "SRS AIR BAG" and "SEAT BELT" of this Service Manual.

WARNING:

Always observe the following items for preventing accidental activation.

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision that would result in air bag inflation, all maintenance must be performed by an authorized NISSAN/INFINITI dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see "SRS AIR BAG".
- Never use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harnesses or harness connectors.

PRECAUTIONS WHEN USING POWER TOOLS (AIR OR ELECTRIC) AND HAMMERS

WARNING:

Always observe the following items for preventing accidental activation.

- When working near the Air Bag Diagnosis Sensor Unit or other Air Bag System sensors with the ignition ON or engine running, never use air or electric power tools or strike near the sensor(s) with a hammer. Heavy vibration could activate the sensor(s) and deploy the air bag(s), possibly causing serious injury.
- When using air or electric power tools or hammers, always switch the ignition OFF, disconnect the battery, and wait at least 3 minutes before performing any service.

Precautions for Removing Battery Terminal

INFOID:0000000010262177

- When removing the 12V battery terminal, turn OFF the ignition switch and wait at least 30 seconds.

NOTE:

ECU may be active for several tens of seconds after the ignition switch is turned OFF. If the battery terminal is removed before ECU stops, then a DTC detection error or ECU data corruption may occur.

- For vehicles with the 2-batteries, be sure to connect the main battery and the sub battery before turning ON the ignition switch.


NOTE:

If the ignition switch is turned ON with any one of the terminals of main battery and sub battery disconnected, then DTC may be detected.

- After installing the 12V battery, always check "Self Diagnosis Result" of all ECUs and erase DTC.

NOTE:

The removal of 12V battery may cause a DTC detection error.



SEF289H

Service Notice or Precautions for Transfer

INFOID:0000000010262178

CAUTION:

- Use Genuine NISSAN Transfer Fluid. Refer to [MA-15, "FOR NORTH AMERICA : Fluids and Lubricants"](#) (For NORTH AMERICA), [MA-16, "FOR MEXICO : Fluids and Lubricants"](#) (For MEXICO).
- Never reuse transfer fluid, once it has been drained.
- Check the fluid level or replace the fluid only with the vehicle parked on level ground.
- During removal or installation, keep inside of transfer clear of dust or dirt.

PRECAUTIONS

< PRECAUTION >

[TRANSFER: ATX90A]

- Replace all tires at the same time. Always use tires of the proper size and the same brand and pattern. Fitting improper size and unusually worn tires applies excessive force to vehicle mechanism and can cause longitudinal vibration.
- Disassembly should be done in a clean work area, it is preferable to work in dustproof area.
- Before proceeding with disassembly, thoroughly clean the transfer. It is important to prevent the internal parts from becoming contaminated by dirt or other foreign matter.
- All parts should be carefully cleaned with a general purpose, non-flammable solvent before inspection or reassembly.
- Check for the correct installation status prior to removal or disassembly. If matching marks are required, be certain they do not interfere with the function of the parts when applied.
- Check appearance of the disassembled parts for damage, deformation, and unusual wear. Replace them with a new ones if necessary.
- Gaskets, seals and O-rings should be replaced any time the transfer is disassembled.
- In principle, tighten bolts or nuts gradually in several steps working diagonally from inside to outside. If tightening sequence is specified, use it.
- Observe the specified torque when assembling.
- Clean and flush the parts sufficiently and blow-dry them.
- Be careful not to damage sliding surfaces and mating surfaces.
- Clean inner parts with lint-free cloth or towels. Do not use cotton work gloves and rags to prevent adhering fibers.

PREPARATION

< PREPARATION >

[TRANSFER: ATX90A]




PREPARATION

PREPARATION

Special Service Tools



INFOID:0000000010262179

The actual shapes of TechMate tools may differ from those of special service tools illustrated here.

Tool number (TechMate No.) Tool name		Description
ST30701000 (J-25742-2) Drift a: 61.5 mm (2.421 in) dia. b: 41 mm (1.61 in) dia.	 ZZA1000D	Removing dust shield from companion flange
KV40104710 (—) Drift a: 76.3 mm (3.004 in) dia. b: 67.9 mm (2.673 in) dia.	 ZZA1003D	- Installing rear oil seal - Installing input oil seal
KV10119400 (—) Splined socket	 ZZA1205D	- Installing transfer control actuator - Installing transfer rotary position sensor

Commercial Service Tools



INFOID:0000000010262180

Tool name		Description
Puller	 ZZA0119D	- Removing dust shield from shaft flange - Removing dust shield from companion flange
Replacer	 ZZA0700D	- Removing dust shield from shaft flange - Removing dust shield from companion flange

PREPARATION

< PREPARATION >

[TRANSFER: ATX90A]


Tool name	Description
Drift a: 63 mm (2.48 in) dia. b: 59 mm (2.32 in) dia.  ZZA1003D	Installing front oil seal
Power tool  PBIC0190E	Loosening bolts and nuts

SYSTEM DESCRIPTION

COMPONENT PARTS

Component Parts Location

INFOID:000000010262181



- | | | |
|---|--|--|
| 1. ECM
Refer to EC-23, "Component Parts Location" (For USA and Canada), EC-592, "Component Parts Location" (For Mexico). | 2. ABS actuator and electric unit (control unit)
Refer to BRC-9, "Component Parts Location" . | 3. Steering angle sensor
Refer to BRC-9, "Component Parts Location" . |
| 4. Control valve & TCM
Refer to TM-11, "A/T CONTROL SYSTEM : Component Parts Location" . | 5. Transfer control unit | 6. 4WD switch assembly |
| 7. Transfer lock position sensor | 8. Transfer Hi-Lo position sensor | 9. Transfer rotary position sensor |
| 10. Transfer control actuator | 11. Transfer fluid temperature sensor | |
| A. Back of glove box assembly | B. 4WD indicator lamp, 4WD warning lamp, ATP warning lamp (in combination meter) | C. Console assembly |
| D. Transfer assembly upper side | E. Transfer assembly under side | |

COMPONENT PARTS

< SYSTEM DESCRIPTION >

[TRANSFER: ATX90A]

Component Description

INFOID:0000000010262182

Component parts		Reference/Function
Transfer control unit		DLN-12, "Transfer Control Unit"
Transfer control actuator	Transfer motor	DLN-12, "Transfer Control Actuator"
	Transfer internal speed sensor	DLN-12, "Transfer Control Actuator"
	Transfer motor temperature sensor	DLN-12, "Transfer Control Actuator"
Transfer Hi-Lo position sensor		DLN-13, "Transfer Hi-Lo Position Sensor"
Transfer rotary position sensor		DLN-13, "Transfer Rotary Position Sensor"
Transfer lock position sensor		DLN-13, "Transfer Lock Position Sensor"
Transfer fluid temperature sensor		DLN-13, "Transfer Fluid Temperature Sensor"
4WD mode switch		DLN-19, "4WD SYSTEM : System Description"
4WD indicator lamp		DLN-19, "4WD SYSTEM : System Description"
4WD warning lamp		DLN-19, "4WD SYSTEM : System Description"
ATP warning lamp		DLN-19, "4WD SYSTEM : System Description"
ABS actuator and electric unit (control unit)		Transmits the following signals via CAN communication line to transfer control unit. • Vehicle speed signal (ABS) • Stop lamp switch signal (brake signal) • ABS operation signal/ABS malfunction signal • TCS operation signal/TCS malfunction signal • VDC operation signal/VDC malfunction signal
Steering angle sensor		Transmits the following signals via CAN communication line to transfer control unit. • Steering angle sensor signal/Steering angle sensor malfunction signal
ECM		Transmits the following signals via CAN communication line to transfer control unit. • Accelerator pedal position signal • Engine speed signal • Engine torque signal
TCM		Transmits the following signals via CAN communication line to transfer control unit. • Shift position signal • Gear position signal • Output shaft revolution signal

Transfer Control Unit

INFOID:0000000010262183

- Transfer control unit operates transfer control actuator, 4WD warning lamp and 4WD mode indicator lamp according to input signal from 4WD shift switch and each sensor and control unit.
- When 4WD system is malfunctioning, 4WD warning lamp turns ON and fail-safe status activates.
- When protection is necessary, 4WD warning lamp blinks and protection status activates.

Transfer Control Actuator

INFOID:0000000010262184

Transfer control actuator integrates transfer motor, transfer internal position sensor, and transfer motor temperature sensor, and switches 4WD mode (AUTO⇔4H⇔4L).

TRANSFER MOTOR

Transfer motor operates according to signal from transfer control unit and switches 4WD mode (AUTO⇔4H⇔4L). It also performs front and rear distribution of traction force during AUTO mode.

TRANSFER INTERNAL SPEED SENSOR

Transfer internal speed sensor detects rotation status of transfer motor and transmits signal to transfer control unit.

TRANSFER MOTOR TEMPERATURE SENSOR

- Transfer motor temperature sensor measures temperature of transfer motor.

COMPONENT PARTS

< SYSTEM DESCRIPTION >

[TRANSFER: ATX90A]

- This sensor uses a thermistor and its electrical resistance varies as the temperature varies. The electrical resistance decreases as the temperature increases.

A

Transfer Hi-Lo Position Sensor

INFOID:0000000010262185

Transfer Hi-Lo position sensor detects engagement status of Hi-Lo sleeve and transmits signal to transfer control unit.

B

Transfer Rotary Position Sensor

INFOID:0000000010262186

Transfer rotary position sensor detects rotation status of actuator shaft and transmits signal to transfer control unit.

C

Transfer Lock Position Sensor

INFOID:0000000010262187

Transfer lock position sensor detects engagement status of lock sleeve and transmits signal to transfer control unit.

DLN

E

Transfer Fluid Temperature Sensor

INFOID:0000000010262188

- Transfer fluid temperature sensor measures temperature of transfer fluid.
- This sensor uses a thermistor and its electrical resistance varies as the temperature varies. The electrical resistance decreases as the temperature increases.

F

G

H

I

J

K

L

M

N


O

P

STRUCTURE AND OPERATION

Sectional View

INFOID:000000010262189




JPDIE0277ZZ

- | | | |
|-------------------------------------|------------------------|-------------------------------|
| 1. Rear companion flange | 2. Main shaft | 3. Rear case |
| 4. Ball ramp lever | 5. Ball lamp lever | 6. Piston |
| 7. Clutch | 8. Sprocket | 9. Lock sleeve |
| 10. Hi-Lo sleeve | 11. Sun gear | 12. Front case |
| 13. Planetary carrier assembly | 14. Internal gear | 15. Shift fork |
| 16. Transfer rotary position sensor | 17. Front shaft flange | 18. Drive chain |
| 19. Actuator shaft | 20. Cam | 21. Transfer control actuator |

Torque Split Mechanism

INFOID:000000010262190

CONTROL DIAGRAM



DESCRIPTION

- Ball ramp lever operates in the direction of main shaft axis according to rotation of actuator shaft and presses piston. Pressure is applied to each clutch and torque is transmitted.
- Shift fork operates in the direction of main shaft axis according to rotation of actuator shaft and performs engagement and disengagement to Hi-Lo sleeve and lock sleeve of main shaft. Mode is switched between 4H⇔4L.

AUTO MODE

- The optimum torque distribution is electronically performed for front and rear wheels according to road conditions.
- Stable start without wheel spin is possible on slippery road conditions, such as on a snowy road.
- When road condition does not require 4WD driving, the status becomes close to rear wheel drive, which results in better fuel efficiency and provides FR-like steering characteristics.
- The vehicle cornering status is judged according to information from each sensor, and the optimum torque is distributed to front wheels for preventing tight-corner braking symptom.

NOTE:

When there is a difference of revolution speed between the front and rear wheel the shift occasionally changes to direct 4-wheel driving conditions automatically. This is not a malfunction.

4H MODE

- Torque distribution for front and rear wheels is fixed and stable start is achieved while driving on an rough, sandy or snowy road.

4L MODE


- Large traction force is obtained due to low gear. High running ability and escaping ability are achieved.
- Switching from 4H mode to 4L mode is not possible when the vehicle is running or A/T shift selector is shifted to any position other than neutral.

TORQUE DISTRIBUTION DIAGRAM

STRUCTURE AND OPERATION


< SYSTEM DESCRIPTION >

[TRANSFER: ATX90A]




- | | | |
|-------------------------------|-----------------------|----------------|
| 1. Main shaft | 2. Clutch | 3. Sprocket |
| 4. Lock sleeve | 5. Hi-Lo sleeve | 6. Sun gear |
| 7. Planetary carrier assembly | 8. Front shaft flange | 9. Drive chain |

TORQUE DISTRIBUTION FLOW



OPERATION PRINCIPLE

AUTO, 4H MODE




- | | | |
|---------------|--------------------|------------------------------|
| 1. Main shaft | 2. Ball ramp lever | 3. Piston |
| 4. Clutch | 5. Hi-Lo sleeve | 6. Sun gear |
| 7. Shift fork | 8. Actuator shaft | 9. Transfer control actuator |

- Transfer control unit supplies command current to transfer motor.
- Transfer motor operates and actuator shaft rotates clockwise.
- Shift fork operates according to rotation of actuator shaft. Sun gear and Hi-Lo sleeve are engaged.
- Ball ramp lever operates in axial direction via cam fixed on actuator shaft according to traction torque of transfer motor, presses piston, and thrusts multiple plate clutch.
- Torque is transmitted to front wheels according to thrusting pressure of multiple plate clutch.

NOTE:

Torque transmitted to the front wheel is determined according to the command current.

4L MODE



- | | | |
|-------------------------------|---------------|-------------------------------|
| 1. Main shaft | 2. Sprocket | 3. Lock sleeve |
| 4. Hi-Lo sleeve | 5. Sun gear | 6. Planetary carrier assembly |
| 7. Internal gear | 8. Shift fork | 9. Actuator shaft |
| 10. Transfer control actuator | | |

1. Transfer control unit supplies command current to transfer motor.
2. Transfer motor operates and actuator shaft rotates counterclockwise.
3. Shift fork operates according to rotation of actuator shaft. Planetary carrier assembly and Hi-Lo sleeve are engaged.

SYSTEM

4WD SYSTEM

4WD SYSTEM : System Description


INFOID:0000000010262191

- In AUTO mode, distribution of traction force is controlled from 2WD status (0:100) to 4WD status (50:50) according to signal from each sensor and switch.
- In accordance with fail-safe function, when system is malfunctioning, 4WD warning lamp on combination meter turns ON and 4WD control stops. For fail-safe function, refer to [DLN-21, "4WD SYSTEM : Fail-Safe"](#).
- When a high load status continues for transfer assembly (transfer control actuator or transfer fluid), 4WD control temporarily becomes 4H or 2WD status, according to protection function.

NOTE:

4WD system is not malfunctioning.

SYSTEM DIAGRAM



INPUT/OUTPUT SIGNAL

It transmits/receives each signal from the following transfer control unit via CAN communication line.

Component parts	Control signal
ABS actuator and electric unit (control unit)	Transmits the following signals via CAN communication line to transfer control unit. • Vehicle speed signal (ABS) • Stop lamp switch signal (brake signal) • ABS operation signal/ABS malfunction signal • TCS operation signal/TCS malfunction signal • VDC operation signal/VDC malfunction signal
ECM	Transmits the following signals via CAN communication line to transfer control unit. • Accelerator pedal position signal • Engine speed signal • Engine torque signal






SYSTEM

< SYSTEM DESCRIPTION >

[TRANSFER: ATX90A]

Component parts	Control signal
TCM	Transmits the following signals via CAN communication line to transfer control unit. • Shift position signal • Gear position signal • Output shaft revolution signal
Steering angle sensor	Transmits the following signals via CAN communication line to transfer control unit. • Steering angle sensor signal/Steering angle sensor malfunction signal
Combination meter	Receives the following signals via CAN communication line from transfer control unit. • 4WD warning lamp signal • ATP warning lamp signal • 4WD mode indicator signal

4WD SHIFT SWITCH AND 4WD SHIFT INDICATOR LAMP

4WD shift switch	4WD shift indicator lamp (in Information display)	4WD shift procedure
AUTO  JPDIE0230ZZ	 JPDIE0234ZZ	1. Start the engine. 2. Turn the 4WD shift switch. NOTE: Mode can be switched between AUTO⇔4H while driving straight.
4H  JPDIE0231ZZ	 JPDIE0235ZZ	
 JPDIE0231ZZ  JPDIE0233ZZ 4WD status: 4H⇔4L	 JPDIE0236ZZ (Blinking)^{*1*2}	1. Start the engine. 2. Never drive the vehicle. 3. Shift A/T shift selector to N position. 4. Press and rotate 4WD shift switch while depressing brake pedal. CAUTION: 4WD mode does not switch when 4WD shift switch is operated while the vehicle is running or A/T shift selector is shifted to any position other than neutral.
4L  JPDIE0233ZZ	 JPDIE0237ZZ	

*1: Blinking 2 times/1 second

*2: "4HI" and "4LO" blink alternately.

CONDITION FOR TURN ON THE WARNING LAMP

SYSTEM

< SYSTEM DESCRIPTION >

[TRANSFER: ATX90A]

4WD Warning Lamp

- Turns ON when there is a malfunction in 4WD system. 4WD warning lamp indicates the vehicle is in fail-safe mode.
- Also turns ON when ignition switch is turned ON, for the purpose of lamp check. Turns OFF approximately for 1 second after the engine starts if system is normal.

Condition	4WD warning lamp
Lamp check	Turns ON when ignition switch is turned ON. Turns OFF approx. 1 second after the engine start.
4WD system malfunction	ON
Protection function is activated due to heavy load to transfer assembly. (4WD system is not malfunctioning.)	Quick blinking: 2 times/second (Blinking in approx. 1 minute and then turning OFF)
Large difference in diameter of front/rear tires	Slow blinking: 1 time/2 seconds (Continuing to blink until turning ignition switch OFF)
Other than above (system normal)	OFF

ATP Warning Lamp

When the A/T shift selector is in P position, the vehicle may move if the transfer case is in neutral. ATP warning lamp is turned on to indicate this condition to the driver.

CONDITION FOR OPERATE WARNING BUZZER

For preventing an incorrect operation during 4H⇔4L switching, warning buzzer sounds from inside of transfer control unit and warns the driver, when certain conditions are satisfied.

Condition			Warning buzzer
4WD shift status	A/T shift selector	Engine speed	
4H⇔4L	N range	350 – 1,600 rpm	OFF
		Under 350 rpm or over 1,600 rpm	ON
	Except N range	Always	

4WD SYSTEM : Fail-Safe

INFOID:0000000010262192

- If any malfunction occurs in 4WD electrical system, and control unit detects the malfunction, 4WD warning lamp on combination meter turns ON to indicate system malfunction.
- When 4WD warning lamp is ON, vehicle changes to rear-wheel drive or shifts to 4-wheel drive (front-wheels still have some driving torque).

DIAGNOSIS SYSTEM (TRANSFER CONTROL UNIT)

< SYSTEM DESCRIPTION >

[TRANSFER: ATX90A]

DIAGNOSIS SYSTEM (TRANSFER CONTROL UNIT)

CONSULT Function

INFOID:000000010262193

FUNCTION

CONSULT can display each diagnostic item using the diagnostic test modes as follows.

Diagnostic test mode	Function
ECU Identification	Transfer control unit part number can be read.
Self Diagnostic Result	Self-diagnostic results can be read and erased quickly.*
Data Monitor	Input/Output data in the transfer control unit can be read.
Work Support	This mode enables a technician to adjust some devices faster and more accurately by following the indications on the CONSULT

*: The following diagnosis information is erased by erasing.

- DTC

ECU IDENTIFICATION

Transfer control unit part number can be read.

SELF DIAGNOSTIC RESULT

Refer to [DLN-30, "DTC Index"](#).

When "0" is displayed on self-diagnosis result.

- The system is presently malfunctioning.

When except "0" is displayed on self-diagnosis result.

- System malfunction in the past is detected, but the system is presently normal.

NOTE:

Each time when ignition switch is turned OFF to ON, numerical number increases in 1→2→3...110→111.

When the operation number of times exceeds 111, the number do not increase and "111" is displayed until self-diagnosis is erased*.

*: For "U1000" and "U1010", the maximum value is "39".

DATA MONITOR

NOTE:

The following table includes information (items) inapplicable to this vehicle. For information (items) applicable to this vehicle, refer to CONSULT display items.

X: Applicable

Monitor item (Unit)	SELECT MONITOR ITEM		Remarks
	ECU INPUT SIGNALS	MAIN SIGNALS	
4WD MODE [BOTNG/SWTNG/4L/4H/AUTO]		X	Control status of 4WD mode is displayed.
2WD SW [On/Off]	X		4WD shift switch (2WD) is not equipped, but it is displayed.
AUTO SW [On/Off]	X		4WD shift switch signal (AUTO) is displayed.
4H SW [On/Off]	X		4WD shift switch signal (4H) is displayed.
4L SW [On/Off]	X		4WD shift switch signal (4L) is displayed.
T/M RANGE [D/N/R/P]	X		A/T shift selector position via CAN communication line is displayed.
N RANGESW [On/Off]	X		A/T shift selector position (N) via CAN communication line is displayed.
R RANGE SW [On/Off]	X		A/T shift selector position (R) via CAN communication line is displayed.
ING SW [On/Off]	X		Ignition switch status is displayed.
TCS OPER [On/Off]	X		TCS operation status via CAN communication line is displayed.

DIAGNOSIS SYSTEM (TRANSFER CONTROL UNIT)

< SYSTEM DESCRIPTION >

[TRANSFER: ATX90A]

Monitor item (Unit)	SELECT MONITOR ITEM		Remarks
	ECU INPUT SIGNALS	MAIN SIGNALS	
VDC OPER [On/Off]	X		VDC operation status via CAN communication line is displayed.
ABS OPER [On/Off]	X		ABS operation status via CAN communication line is displayed.
SAND MODE IND [On/Off]			This indicator is not equipped, but it is displayed.
ROCK MODE IND [On/Off]			This indicator is not equipped, but it is displayed.
SNOW MODE IND [On/Off]			This indicator is not equipped, but it is displayed.
ONROAD MODE IND [On/Off]			This indicator is not equipped, but it is displayed.
SAND MODE SW [On/Off]	X		This switch is not equipped, but it is displayed.
ROCK MODE SW [On/Off]	X		This switch is not equipped, but it is displayed.
SNOW MODE SW [On/Off]	X		This switch is not equipped, but it is displayed.
ONROAD MODE SW [On/Off]	X		This switch is not equipped, but it is displayed.
HI/LO POSI SEN 3 [On/Off]	X		Transfer Hi-Lo position sensor (3) status is displayed.
HI/LO POSI SEN 1 [On/Off]	X		Transfer Hi-Lo position sensor (1) status is displayed.
LOCK POSI SEN [OPEN/LOCK/BAT/UNLEAN/HI TEMP/ERROR/GND]	X		Transfer lock position sensor signal is displayed.
ATP IND [On/Off]			Control status of ATP warning lamp is displayed.
4WD FAILLAMP [On/Off]		X	Control status of ATP warning lamp is displayed.
4WD MODE IND [4L/LOCK/AUTO]		X	Control status of 4WD mode indicator lamp is displayed. (LOCK means 4H of 4WD mode)
MOTOR DRIVE B [HI/LO/PWM]		X	Driving status of transfer motor is displayed. (Reverse side)
MOTOR DRIVE A [HI/LO/PWM]		X	Driving status of transfer motor is displayed. (Drive side)
FLUID TEMP SEN [V]	X		Temperature of transfer fluid is displayed.
MOTOR TEMP [V]	X		Temperature of transfer motor is displayed.
C/U POWER SUP [V]	X		Power supply voltage value of transfer control unit is displayed.
MOTOR POWER SUP [V]	X		Power supply voltage value of transfer motor unit is displayed.
ROTARY POSI SEN [%]	X		Transfer rotary position sensor signal is displayed.
THRTL POSI SEN [%]	X	X	Throttle opening status via CAN communication line is displayed.
AT R SPEED [km/h]	X		Output shaft revolution speed via CAN communication line is displayed.
T/M GEAR [0 - 7]	X		Current transmission gear via CAN communication line is displayed.
COMPR VHCL SPEED [km/h]		X	Vehicle speed calculated by transfer control unit is displayed.

A

B

C

DLN

E

F

G

H

I

J

K

L

M

N

O

P

DIAGNOSIS SYSTEM (TRANSFER CONTROL UNIT)

< SYSTEM DESCRIPTION >

[TRANSFER: ATX90A]

Monitor item (Unit)	SELECT MONITOR ITEM		Remarks
	ECU INPUT SIGNALS	MAIN SIGNALS	
VHCL/S SEN-FR [km/h]	X		Wheel speed (front) average calculated by transfer control.
VHCL/S SEN-RR [km/h]	X		Wheel speed (rear) average calculated by transfer control.
ENG SPEED [rpm]	X		Engine status via CAN communication line is displayed.
INTERNL SPEED SEN [count]	X		Transfer internal speed sensor status is displayed.
TRANSFER TORQUE [Nm]		X	Commanded transfer communication torque is displayed.
UNIT PARAMETER [A1 - A9, B1 - B9, C1 - C9, D1 - D9, E1 - E9, F1 - F9, G1 - G9, H1 - H9, J1 - J9]			Unit parameter of transfer recognized by transfer control unit is displayed.

WORK SUPPORT

Function	Description
UNIT CHARACTERISTIC WRITE	Writes the unit parameter of transfer to transfer control unit.
START CALIBRATION	Perform initial calibration of transfer control unit.
LOCK SLEEVE SENSOR* INITIALIZE	Format learning the transfer lock position sensor written to transfer control unit.
LOCK SLEEVE SENSOR* LEARNING	Perform learning the transfer lock position sensor.
OIL DETERIORATION INFO RESET	Format the transfer fluid viscosity written to transfer control unit.

*: "LOCK SLEEVE SENSOR" means transfer lock position sensor.

ECU DIAGNOSIS INFORMATION

TRANSFER CONTROL UNIT

Reference Value

INFOID:0000000010262194

VALUES ON THE DIAGNOSIS TOOL

NOTE:

The following table includes information (items) inapplicable to this vehicle. For information (items) applicable to this vehicle, refer to CONSULT display items.

Monitor item	Condition	Value/Status
4WD MODE	4WD is booting	BOTNG
	4WD mode is switching	SWTNG
	Ignition switch: ON 4WD mode: 4L	4L
	4WD mode: 4H	4H
	4WD mode: AUTO	AUTO
2WD SWITCH *1	Always	Off
AUTO SWITCH	4WD shift switch: AUTO	On
	4WD shift switch: 4H or 4L	Off
4H SWITCH	4WD shift switch: 4H	On
	4WD shift switch: AUTO or 4L	Off
4L SWITCH	4WD shift switch: 4L	On
	4WD shift switch: AUTO or 4H	Off
T/M RANGE	A/T shift selector: D	D
	A/T shift selector: N	N
	A/T shift selector: R	R
	A/T shift selector: P	P
N RANGE SW	A/T shift selector: N	On
	A/T shift selector: Except N	Off
R RANGE SW	A/T shift selector: R	On
	A/T shift selector: Except R	Off
IGN SW	Ignition switch: ON	On
	Ignition switch: OFF	Off
TCS OPER SW	TCS is operating	On
	TCS is not operating	Off
VDC OPER SW	VDC is operating	On
	VDC is not operating	Off
ABS OPER SW	ABS is operating	On
	ABS is not operating	Off
SAND MODE IND*2	Always	Off
ROCK MODE IND*2	Always	Off
SNOW MODE IND*2	Always	Off
ON ROAD MODE IND*2	Always	On
SAND MODE SW*3	Always	Off
ROCK MODE SW*3	Always	Off
SNOW MODE SW*3	Always	Off

TRANSFER CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >

[TRANSFER: ATX90A]

Monitor item	Condition		Value/Status
ON ROAD MODE SW*3	Always		On
HI-LO POSI SEN 3	4WD mode: AUTO or 4H		On
	4WD mode: Shifting		Off
	4WD mode: 4L		Off
HI-LO POSI SEN 1	4WD mode: AUTO or 4H		On
	4WD mode: Shifting		On
	4WD mode: 4L		Off
LOCK POSI SEN	When lock sleeve is opening		OPEN
	When lock sleeve locking		LOCK
	When transfer lock position sensor signal circuit is short. (Battery short)		BAT
	When transfer lock position sensor is unlearned.		UNLEAN
	When the temperature of transfer lock position sensor is high.		HI TMP
	When transfer lock position sensor is malfunctioning.		ERROR
	When transfer lock position sensor signal circuit is short. (Ground short)		GND
ATP IND	ATP warning lamp: ON		On
	ATP warning lamp: OFF		Off
4WD FAIL LAMP	4WD warning lamp: ON		On
	4WD warning lamp: OFF		Off
4WD MODE IND	4WD shift switch: AUTO		AUTO
	4WD shift switch: 4H		LOCK
	4WD shift switch: 4L		4L
MOTOR DRIVE B	When transfer motor is driving in reversal. (100% duty controlled)		HI
	When transfer motor is driving or stopping.		LO
	When transfer motor is driving in reversal. (PWM output)		PWM
MOTOR DRIVE A	When transfer motor is driving. (100% duty controlled)		HI
	When transfer motor is driving in reversal or stopping.		LO
	When transfer motor is driving. (PWM output)		PWM
FLUID TEMP SE	The temperature of transfer fluid is 20 – 80°C.		Approx. 1.1 – 0.3 V
MOTOR TEMP	The temperature of transfer motor is 20 – 80°C.		Approx. 1.1 – 0.3 V
C/U POWER SUP	Always		Battery voltage
MOTOR POWER SUP	Always		Battery voltage
ROTARY POSI SEN	4WD mode: AUTO A/T shift selector: D	Depress the accelerator pedal several times.	Value is changing
THRTL POS SEN	When depressing accelerator pedal (Value rises gradually in response to throttle position)		0 – 100 %
AT R SPEED	Vehicle stopped		0.00 km/h (0.00 mph)
	Vehicle driving (4WD mode: AUTO) CAUTION: Check air pressure of tire under standard condition.		Approx. equal to the indication on speedometer (inside of ±10 %)
T/M GEAR	A/T shift selector: D Vehicle driving		1 2 3 4 5 6 7

TRANSFER CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >

[TRANSFER: ATX90A]


Monitor item	Condition		Value/Status
COMPR VHCL SPEED	Vehicle stopped		0.00 km/h (0.00 mph)
	Vehicle driving CAUTION: Check air pressure of tire under standard condition.		Approx. equal to the indication on speedometer (inside of ±10 %)
VHCL/S SEN-FR	Vehicle stopped		0.00 km/h (0.00 mph)
	Vehicle driving CAUTION: Check air pressure of tire under standard condition.		Approx. equal to the indication on speedometer (inside of ±10 %)
VHCL/S SEN-RR	Vehicle stopped		0.00 km/h
	Vehicle driving CAUTION: Check air pressure of tire under standard condition.		Approx. equal to the indication on speedometer (inside of ±10 %)
ENGINE SPEED	Engine: Running		Approx. equal to the indication on tachometer (inside of ±10 %)
INTRNL SPEED SEN	4WD mode: AUTO A/T shift selector: D	Depress the accelerator pedal several times.	Value is changing
TRANSFER TORQUE	4WD shift switch: AUTO		0 - 2250 N·m
	4WD shift switch: 4H		0 - 2250 N·m
	4WD shift switch: 4L		0 Nm
UNIT PARAMETER	Always		A1 - A9 B1 - B9 C1 - C9 D1 - D9 E1 - E9 F1 - F9 G1 - G9 H1 - H9 J1 - J9

*1: 4WD shift switch (2WD) is not equipped, but it is displayed.

*2: This indicator is not equipped, but it is displayed.

*3: This switch is not equipped, but it is displayed.

TERMINAL LAYOUT





PHYSICAL VALUES

Terminal No. (Wire color)		Description		Condition	Value (Approx.)
+	-	Signal name	Input/ Output		
6 (BR)	Ground	Hi-Lo position sensor 1	Input/ Output	Engine: Running (Never drive the vehicle.) 4WD mode: AUTO or 4H	0 V
				4WD mode: Shifting	0 V
				4WD mode: 4L	5 V

TRANSFER CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >



[TRANSFER: ATX90A]

Terminal No. (Wire color)		Description		Condition		Value (Approx.)
+	-	Signal name	Input/ Output			
7 (Y)	Ground	Transfer fluid temperature sensor power supply	Input	Engine: Running		0 – 5 V
9 (G)	Ground	Transfer internal speed sensor (GND)	—	Always		0 V
10 (Y/G)	Ground	Transfer internal speed sensor (IMP)	Input	Ignition switch: ON	• 4WD mode: AUTO • A/T shift selector: N • Transfer motor: Driving	
11 (V)	Ground	4WD shift SW (4L)	Input	Ignition switch: ON	4WD shift switch: 4L	Battery voltage
					4WD shift switch: Except 4L	0 V
12 (L)	—	CAN-H	Input/ Output	—		—
13 (P)	—	CAN-L	Input/ Output	—		—
14 (W/R)	Ground	4WD shift SW (AUTO)	Input	Ignition switch: ON	4WD shift switch: AUTO	Battery voltage
					4WD shift switch: Except AUTO	0 V
15 (P/B)	Ground	Transfer rotary position sensor (PWM)	Input	Ignition switch: ON	• 4WD mode: AUTO • A/T shift selector: N	
16 (LG)	Ground	Transfer rotary position sensor (GND)	—	Always		0 V
17 (W/L)	Ground	Transfer lock position sensor power supply	Input	Ignition switch: ON		5 V
				10 seconds or more later after ignition switch turned OFF		0 V
18 (BR/Y)	Ground	Transfer rotary position sensor power supply	Input	Ignition switch: ON		5 V
				10 seconds or more later after ignition switch turned OFF		0 V
20 (GR)	Ground	Transfer control unit power supply	Input	Always		Battery voltage
25 (P/L)	Ground	Hi-Lo position sensor 3	Input/ Output	Engine: Running (Never drive the vehicle.)	4WD mode: AUTO or 4H	0 V
					4WD mode: Shifting	5 V
					4WD mode: 4L	5 V
28 (W)	Ground	Transfer motor temperature sensor power supply	Input	Ignition switch: ON		0 – 5 V
				Ignition switch: OFF		0 V

TRANSFER CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >

[TRANSFER: ATX90A]

Terminal No. (Wire color)		Description		Condition		Value (Approx.)
+	-	Signal name	Input/ Output			
29 (LG/R)	Ground	Hi-Lo position sensor 2	Input/ Output	Engine: Running (Never drive the vehicle.)	Always	0 V
30 (R/B)	Ground	Transfer lock position sensor (GND)	—	Always		0 V
31 (L/O)	Ground	Transfer internal speed sensor (DIR)	Input	Ignition switch: ON	4WD mode: AUTO - A/T shift selector: N - When changing the transfer motor rotation direction.	
32 (BR/R)	Ground	Ignition switch	Input	Ignition switch: ON		Battery voltage
				Ignition switch: OFF		0 V
35 (R)	Ground	4WD shift SW (4H)	Input	Ignition switch: ON	4WD shift switch: 4H	Battery voltage
					4WD shift switch: Except 4H	0 V
36 (L/R)	Ground	Transfer fluid tempera- ture sensor (GND)	—	Always		0 V
38 (G/O)	Ground	Transfer lock position sensor signal	Input	Ignition switch: ON	4WD mode: AUTO - A/T shift selector: N	
39 (R/W)	Ground	Transfer internal speed sensor power supply	Input	Ignition switch: ON		8 V
				Ignition switch: OFF		0 V
41 (W/R)	Ground	Transfer control actuator power supply	Input	Always		Battery voltage
43 (G/R)	Ground	Motor drive B	Input/ Output	Transfer motor: Driving		0 V - Battery voltage
44 (B)	Ground	GND	—	Always		0 V
45 (G/Y)	Ground	Motor drive A	Input/ Output	Transfer motor: Driving		0 V - Battery voltage
46 (B)	Ground	Transfer control actuator (GND)	—	Always		0 V

CAUTION:

When using circuit tester to measure voltage for inspection, be sure not to extend forcibly any connector terminals.

Fail-Safe

INFOID:0000000010262195

- If any malfunction occurs in 4WD electrical system, and control unit detects the malfunction, 4WD warning lamp on combination meter turns ON to indicate system malfunction.
- When 4WD warning lamp is ON, vehicle changes to rear-wheel drive or shifts to 4-wheel drive (front-wheels still have some driving torque).

TRANSFER CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >

[TRANSFER: ATX90A]

DTC Inspection Priority Chart

INFOID:000000010262196

If some DTCs are displayed at the same time, perform inspections one by one based on the following priority chart.

Priority	Detected items (DTC)
1	• U1000 CAN COMM CIRCUIT • U1010 CONTROL UNIT (CAN)
2	• P1802 CONTROL UNIT 1 • P1803 CONTROL UNIT 2 • P1804 CONTROL UNIT 3 • P1809 CONTROL UNIT 4 • P180C SEN POWER SUPPLY (5V) • P180E SEN POWER SUPPLY (8V) • P1811 BATTERY VOLTAGE • P181B INCOMP SELF SHUT • P181C MOTOR POWER SUPPLY • P181F INCOMP CALIBRATION
3	• P1807 VECL SPEED SEN-AT • P1808 VECL SPEED SEN-ABS • P1816 PNP SW/CIRC • P181E ST ANGLE SEN SIG • P1820 ENGINE SPEED SIG • P1829 THROTTLE POSI SEN • P1830 ABS OP SIG • P1831 VDC OP SIG • P1832 TCS OP SIG
4	• P180D ROTARY POSITION SEN • P1813 4WD MODE SW • P181A MOTOR TEMP SEN • P1826 OIL TEMP SEN • P182A HI-LO POSITION SEN • P182B LOCK POSITION SEN
5	• P180F MOTOR SYSTEM • P1817 SHIFT ACTUATOR

DTC Index

INFOID:000000010262197

DTC	Display Items	Reference
P1802	CONTROL UNIT 1	DLN-52, "DTC Logic"
P1803	CONTROL UNIT 2	DLN-52, "DTC Logic"
P1804	CONTROL UNIT 3	DLN-52, "DTC Logic"
P1807	VHCL SPEED SEN-AT	DLN-53, "DTC Logic"
P1808	VHCL SPEED SEN-ABS	DLN-54, "DTC Logic"
P1809	CONTROL UNIT 4	DLN-52, "DTC Logic"
P180C	SEN POWER SUPPLY (5V)	DLN-55, "DTC Logic"
P180D	ROTARY POSITION SEN	DLN-58, "DTC Logic"
P180E	SEN POWER SUPPLY (8V)	DLN-61, "DTC Logic"
P180F	MOTOR SYSTEM	DLN-63, "DTC Logic"
P1811	BATTERY VOLTAGE	DLN-66, "DTC Logic"
P1813	4WD MODE SW	DLN-69, "DTC Logic"
P1816	PNP SW/CIRC	DLN-72, "DTC Logic"
P1817	SHIFT ACTUATOR	DLN-73, "DTC Logic"
P181A	MOTOR TEMP SEN	DLN-75, "DTC Logic"
P181B	IMCOMP SELF SHUT	DLN-77, "DTC Logic"

TRANSFER CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >

[TRANSFER: ATX90A]

DTC	Display Items	Reference
P181C	MOTOR POWER SUPPLY	DLN-79, "DTC Logic"
P181E	ST ANGLE SEN SIG	DLN-81, "DTC Logic"
P181F	INCOMP CALIBRATION	DLN-82, "DTC Logic"
P1826	OIL TEMP SEN	DLN-84, "DTC Logic"
P1820	ENGINE SPEED SIG	DLN-83, "DTC Logic"
P1829	THROTTLE POSI SEN	DLN-86, "DTC Logic"
P182A	HI-LO POSITION SEN	DLN-87, "DTC Logic"
P182B	LOCK POSITION SEN	DLN-89, "DTC Logic"
P1830	ABS OP SIG	DLN-92, "DTC Logic"
P1831	VDC OP SIG	DLN-93, "DTC Logic"
P1832	TCS OP SIG	DLN-94, "DTC Logic"
U1000	CAN COMM CIRCUIT	DLN-95, "DTC Logic"
U1010	CONTROL UNIT (CAN)	DLN-96, "DTC Logic"

A

B

C

DLN

E

F

G

H

I

J

K

L

M

N

O


P

Wiring Diagram

★ : This connector is not shown in "Harness Layout".



JRDWC3690GB



A
B
C
DLN
E
F
G
H
I
J
K
L
M
N
O
P

4WD SYSTEM

< WIRING DIAGRAM >

[TRANSFER: ATX90A]

4WD SYSTEM

Connector No.	E7
Connector Name	WIRE TO WIRE
Connector Type	TH32MW-NH



1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16
17	18	19	20	21	22	23	24	25	26	27	28	29	30	31	32

Terminal No.	Color Of Wire	Signal Name [Specification]
1	W	-
2	G	-
3	L/O	-
4	LG	-
5	W/L	-
6	G/O	-
7	L/R	-
8	LG/R	-
14	R	-
16	SB	-
17	R/W	-
18	Y/G	-
19	BR/Y	-
20	P/B	-
21	R/B	-
22	Y	-
23	BR	-
24	P/L	-
29	P	-
30	BR	-
31	L	-
32	P	-

Connector No.	E13
Connector Name	IPWM E/R INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM
Connector Type	TH12FW-NH



28	27	26	25	24	23
34	33	32	31	30	29

Terminal No.	Color Of Wire	Signal Name [Specification]
23	GR/R	-
24	W/G	-
25	L/Y	-
26	P	-
27	L	-
28	V	-
30	R/W	-
32	LG	-
33	R	-
34	G	-

Connector No.	E15
Connector Name	IPWM E/R INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM
Connector Type	NS16FW-CS



32	31	30	29	28	27	26	25	24	23
49	48	47	46	45	44	43	42	41	40

Terminal No.	Color Of Wire	Signal Name [Specification]
48	BR	-
49	R	-
50	LG/B	-
51	BR/Y	-
52	W	-
55	O	-
56	L	-
57	V	-
58	BR/R	-

59	W/B	-
60	V/R	-
61	W	-
62	SB	-

Connector No.	E36
Connector Name	ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)
Connector Type	SAZ42FB-SZ74



48	47	46	45	44	43	42	41	40	39
38	37	36	35	34	33	32	31	30	29
28	27	26	25	24	23	22	21	20	19
18	17	16	15	14	13	12	11	10	9

Terminal No.	Color Of Wire	Signal Name [Specification]
1	G	BAT
2	B	GND
3	B	GND
4	W	MOTOR SUPPLY
9	R/B	YAW RATE / SIDE / DECEL G SENSOR COMMUNICATION-H
10	P/B	YAW RATE / SIDE / DECEL G SENSOR COMMUNICATION-L
13	GR	BRAKE FLUID LEVEL SW
17	L/R	STP2
18	W/B	IGN
19	O	DS FR
20	SB	DP FL
21	R/O	DS RR
22	V	DP RL
27	P	CAN-L
33	LG	DP FR
34	G	DS FL
35	BR	DP RR
36	P	DS RL
37	R	STP
39	L/W	VOC OFF SW
41	L	CAN-H
46	W	STOP LAMP SW ON

Connector No.	E46
Connector Name	WIRE TO WIRE
Connector Type	NS16MW-CS



1	2	3	4	5	6	7
8	9	10	11	12	13	14
15	16	17	18	19	20	21

Terminal No.	Color Of Wire	Signal Name [Specification]
1	B/Y	-
2	SHIELD	-
4	V	-
9	B/SB	-
10	L	-
11	W	-
14	SB	-
15	G	-

Connector No.	E59
Connector Name	TRANSFER CONTROL UNIT
Connector Type	TH40FW-NH



30	29	28	27	26	25	24	23	22	21
20	19	18	17	16	15	14	13	12	11
10	9	8	7	6	5	4	3	2	1

Terminal No.	Color Of Wire	Signal Name [Specification]
6	BR	H/L O POSITION SEN 1
7	Y	TRANSFER FLUID TEMP SEN PWR SUPPLY
9	G	INTERNAL SPEED SEN GND
10	Y/G	INTERNAL SPEED SEN IMP
11	V	4L SW
12	L	CAN-H
13	P	CAN-L
14	W/R	AUTO SW
15	P/B	ROTARY POSITION SEN PWM
16	LG	ROTARY POSITION SEN GND
17	W/L	LOCK POSITION SEN PWR SUPPLY

JRDWC3692GB

4WD SYSTEM

< WIRING DIAGRAM >

[TRANSFER: ATX90A]

4WD SYSTEM


18	BR/Y	ROTARY POSITION SEN PWR SUPPLY
20	GR	TRANSFER C/U PWR SUPPLY
25	P/L	HE-LO POSITION SEN 3
28	W	MOTOR TEMP SEN PWR SUPPLY
29	LG/R	HE-LO POSITION SEN 2
30	R/B	LOCK POSITION SEN GND
31	L/O	INTERNAL SPEED SEN DIR
32	BR/R	IGN
35	R	4H SW
36	L/R	TRANSFER FLUID TEMP SEN GND
38	G/O	LOCK POSITION SEN SIGNAL
39	R/W	INTERNAL SPEED SEN PWR SUPPLY

Connector No.	E60
Connector Name	TRANSFER CONTROL UNIT
Connector Type	M06FW-LC



Terminal No.	Color Of Wire	Signal Name [Specification]
41	W/R	MOTOR PWR SUPPLY
43	G/R	MOTOR DRIVE B
44	B	GND
45	G/Y	MOTOR DRIVE A
46	B	MOTOR GND

Connector No.	E80
Connector Name	ECM
Connector Type	MAB55FB-MEB10-LH




Terminal No.	Color Of Wire	Signal Name [Specification]
111	R	FUEL INJECTOR DRIVER POWER SUPPLY
112	SB	FUEL INJECTOR DRIVER POWER SUPPLY
113	G	-
114	B	ECM GROUND
115	B	EVAP CANISTER VENT CONTROL VALVE
120	Y	ECM GROUND
122	BR/W	THROTTLE CONTROL MOTOR RELAY
125	GR	FUEL PUMP CONTROL MODULE (PCM)
126	O	ACCELERATOR PEDAL POSITION SENSOR 2
128	Y	ASCD/IGC STEERING SWITCH
129	P/L	SENSOR GROUND
130	R	SENSOR GROUND
131	L/W	SENSOR POWER SUPPLY
133	SB	SENSOR POWER SUPPLY
134	V/W	FUEL TEMPERATURE SENSOR
136	W/R	ACCELERATOR PEDAL POSITION SENSOR 1
137	W/G	SENSOR POWER SUPPLY
138	V	BATTERY CURRENT SENSOR
139	G	BATTERY TEMPERATURE SENSOR
140	R/Y	SENSOR GROUND
141	SB	IGNITION SWITCH
142	R/W	FUEL PUMP CONTROL MODULE (PCM) CHECK
143	L/Y	EVAP CONTROL SYSTEM PRESSURE SENSOR
144	O/B	REFRIGERANT PRESSURE SENSOR
146	L	CAN COMMUNICATION LINE
147	G/Y	ASCD/IGC BRAKE SWITCH
150	R	SENSOR GROUND
151	P	CAN COMMUNICATION LINE
156	L	POWER SUPPLY FOR ECM (BACK-UP)
161	W/B	STOP LAMP SWITCH
163	L/G	ENG COMMUNICATION LINE
165	GR/R	ECM RELAY (SELF SHUT-OFF)
166	W	ENG COMMUNICATION LINE
168	C/B	ENGINE SPEED SIGNAL OUTPUT
171	W	POWER SUPPLY FOR ECM
172	W	POWER SUPPLY FOR ECM
173	O	THROTTLE CONTROL MOTOR POWER SUPPLY
174	B	ECM GROUND
175	B	ECM GROUND

Connector No.	E84
Connector Name	WIRE TO WIRE
Connector Type	M06MW-LC



Terminal No.	Color Of Wire	Signal Name [Specification]
1	G/Y	-
2	R	-
3	V	-
4	R	-
5	G/R	-
6	B/R	-


Connector No.	E105
Connector Name	WIRE TO WIRE
Connector Type	TH80MW-CS16-TM4



Terminal No.	Color Of Wire	Signal Name [Specification]
1	L	-
2	L/W	-
3	R/B	-
4	L	-
5	Y	-
7	W/G	-
8	P/B	-
9	W/B	-
10	G	-
11	L	-
12	P	-
13	P/B	-
14	BR	-
15	L/B	-

16	SB	-
18	BR	-
19	Y/G	-
20	BR/Y	-
21	V/V	-
22	L	-
23	Y	-
24	L/W	-
25	O	-
29	R/W	-
30	L/B	-
31	Y	-
32	GR/R	-
34	Y	-
35	R	-
36	B/R	-
37	G/Y	-
38	G	-
40	SB	-
41	W/R	-
42	R	-
43	V	-
54	GR/L	-
91	BR	-
92	L/W	-
94	Y/B	-
95	G/R	-
97	R	-
98	G/B	-
100	W/R	-

Connector No.	F1
Connector Name	WIRE TO WIRE
Connector Type	TH82FW-NH



Terminal No.	Color Of Wire	Signal Name [Specification]
1	W	-
2	G	-
3	L/O	-
4	LG	-

JRDWC3693GB

4WD SYSTEM

< WIRING DIAGRAM >

[TRANSFER: ATX90A]

4WD SYSTEM

5	W/L	-
6	G/O	-
7	L/R	-
8	LG/R	-
14	R	-
16	SB	-
17	R/W	-
18	Y/G	-
19	BR/Y	-
20	P/B	-
21	R/B	-
22	Y/L	-
23	BR/W	-
24	P/L	-
29	P	-
30	BR	-
31	L	-
32	P	-

Connector No.	F22
Connector Name	WIRE TO WIRE
Connector Type	NS16FW-CS



7	6	5	4		3	2	1	
16	15	14	13	12	11	10	9	8

Terminal No.	Color Of Wire	Signal Name [Specification]
1	B	-
2	SHIELD	-
4	V	-
9	B	-
10	L/W	-
11	W	-
14	SB	-
15	G	-

Connector No.	F37
Connector Name	TRANSFER FLUID TEMPERATURE SENSOR
Connector Type	E02FGY-RS



2	1
---	---

Terminal No.	Color Of Wire	Signal Name [Specification]
1	L/R	-
2	Y	-

Connector No.	F40
Connector Name	TRANSFER LOCK POSITION SENSOR
Connector Type	RH03FB



3	2	1
---	---	---

Terminal No.	Color Of Wire	Signal Name [Specification]
1	W/L	-
2	R/B	-
3	G/O	-

Connector No.	F41
Connector Name	TRANSFER ROTARY POSITION SENSOR
Connector Type	RH03FGY



3	2	1
---	---	---

Terminal No.	Color Of Wire	Signal Name [Specification]
1	BR/Y	-
2	LG	-
3	P/B	-

Connector No.	F42
Connector Name	TRANSFER HI-LO POSITION SENSOR
Connector Type	PE203FB



3	2	1
---	---	---

Terminal No.	Color Of Wire	Signal Name [Specification]
1	BR/W	-
2	P/L	-
3	LG/R	-

Connector No.	F51
Connector Name	A/T ASSEMBLY
Connector Type	RK10FG



5	4	3	2	1
10	9	8	7	6

Terminal No.	Color Of Wire	Signal Name [Specification]
1	V	IGNITION POWER SUPPLY
2	P	BATTERY POWER SUPPLY
3	L	CAN-H
4	SB	K-LINE
5	B	GROUND
6	V	IGNITION POWER SUPPLY
7	R	BACK-UP LAMP RELAY
8	P	CAN-L
9	BR	STARTER RELAY
10	B	GROUND

Connector No.	F52
Connector Name	TRANSFER CONTROL ACTUATOR
Connector Type	DH208FB



	6	7	8
1	2	3	4

Terminal No.	Color Of Wire	Signal Name [Specification]
1	G/R	-
2	Y/G	-
3	R/W	-
4	W	-
6	L/O	-
7	G	-
8	G/Y	-

JRDWC3694GB

4WD SYSTEM

< WIRING DIAGRAM >

[TRANSFER: ATX90A]

4WD SYSTEM

Connector No.	F103
Connector Name	WIRE TO WIRE
Connector Type	M08FW-LG



1	2	3	4
5	6	7	8

Connector No.	M3
Connector Name	FUSE BLOCK (J/B)
Connector Type	NS12FW-CS



1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24	25	26	27	28	29	30	31	32	33	34	35	36	37	38	39	40	41	42	43	44	45	46	47	48	49	50	51	52	53	54	55	56	57	58	59	60	61	62	63	64	65	66	67	68	69	70	71	72	73	74	75	76	77	78	79	80	81	82	83	84	85	86	87	88	89	90	91	92	93	94	95	96	97	98	99	100
---	---	---	---	---	---	---	---	---	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	-----

Terminal No.	Color	Wire	Signal Name [Specification]
1	G/Y	GR	-
2	R	R/L	-
3	V	GR/L	-
4	R	GR	-
5	G/R	B	-
6	B/R	W	-

Connector No.	F301
Connector Name	TCM
Connector Type	SPT0FG



1	2	3	4	5	6	7	8	9	10
---	---	---	---	---	---	---	---	---	----

Terminal No.	Color	Wire	Signal Name [Specification]
1	-	-	IGNITION POWER SUPPLY
2	-	-	BATTERY POWER SUPPLY
3	-	-	CAN-H
4	-	-	K-LINE
5	-	-	GROUND
6	-	-	IGNITION POWER SUPPLY
7	-	-	BACK-UP LAMP RELAY
8	-	-	CAN-L
9	-	-	STARTER RELAY
10	-	-	GROUND

Terminal No.	Color	Wire	Signal Name [Specification]
1	B	B	-
2	P	P	-
5	L	L	-

Connector No.	M34
Connector Name	COMBINATION METER
Connector Type	TH40FW-NH



1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24	25	26	27	28	29	30	31	32	33	34	35	36	37	38	39	40	41	42	43	44	45	46	47	48	49	50	51	52	53	54	55	56	57	58	59	60	61	62	63	64	65	66	67	68	69	70	71	72	73	74	75	76	77	78	79	80	81	82	83	84	85	86	87	88	89	90	91	92	93	94	95	96	97	98	99	100
---	---	---	---	---	---	---	---	---	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	-----

Connector No.	M30
Connector Name	STEERING ANGLE SENSOR
Connector Type	TH08FW-NH



1	2	3	4	5
---	---	---	---	---

Connector No.	M54
Connector Name	4WD SWITCH ASSEMBLY
Connector Type	TH24FW-NH



1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24	25	26	27	28	29	30	31	32	33	34	35	36	37	38	39	40	41	42	43	44	45	46	47	48	49	50	51	52	53	54	55	56	57	58	59	60	61	62	63	64	65	66	67	68	69	70	71	72	73	74	75	76	77	78	79	80	81	82	83	84	85	86	87	88	89	90	91	92	93	94	95	96	97	98	99	100
---	---	---	---	---	---	---	---	---	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	-----

Terminal No.	Color	Wire	Signal Name [Specification]
1	L/W	W	VDC OFF SW
9	W/R	R	AUTO SW
10	R	R	4L SW
11	V	V	4L SW
12	GR	GR	IGN
13	L/W	L	LIGHT SW
14	B/O	B	ILL CONT
20	B	B	GROUND
22	W	W	SNOW SW
23	R	R	TOW

Terminal No.	Color	Wire	Signal Name [Specification]
1	Y	Y	BATTERY POWER SUPPLY
2	GR	GR	IGNITION SIGNAL
3	B	B	GROUND
4	B	B	ILL CONT
5	B	B	ILL CONTROL OUTPUT
6	GR	GR	LED HEADLAMP L/R WARNING SIGNAL
7	R	R	TOW MODE SIGNAL
8	P/L	P	TRIP RESET SWITCH SIGNAL
9	O	O	LED HEADLAMP L/R WARNING SIGNAL
11	G	G	ENTER SWITCH SIGNAL
12	O	O	SELECT SWITCH SIGNAL
13	W/R	W	ILLUMINATION CONTROL SWITCH SIGNAL (+)
14	R	R	ILLUMINATION CONTROL SWITCH SIGNAL (-)
15	R/W	R	AIR BAG SIGNAL
18	W/R	W	AMBIENT SENSOR SIGNAL
19	V/W	V	A/C AUTO AMP CONNECTION RECOGNITION SIGNAL

Terminal No.	Color	Wire	Signal Name [Specification]
2	LG	LG	-
3	B	B	-
4	B	B	-
5	B	B	-
6	B	B	-
7	SB	SB	-
8	GR	GR	-
11	SB	SB	-
12	R	R	-
13	L	L	-
14	P	P	-
16	Y	Y	-

1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24	25	26	27	28	29	30	31	32	33	34	35	36	37	38	39	40	41	42	43	44	45	46	47	48	49	50	51	52	53	54	55	56	57	58	59	60	61	62	63	64	65	66	67	68	69	70	71	72	73	74	75	76	77	78	79	80	81	82	83	84	85	86	87	88	89	90	91	92	93	94	95	96	97	98	99	100
---	---	---	---	---	---	---	---	---	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	-----



Connector No.	M4
Connector Name	DATA LINK CONNECTOR
Connector Type	BD1EFW


A
B
C
DLN
E
F
G
H
I
J
K
L
M
N
O
P

JRDWC3695GB

4WD SYSTEM

Connector No.	M77
Connector Name	WIRE TO WIRE
Connector Type	TH80FW-CS16-TM4





54	GR/L	-
91	BR	-
92	L/W	-
94	Y/B	-
95	L/R	-
97	R	-
98	O/L	-
100	W/B	-

Terminal No.	Color Of Wire	Signal Name [Specification]
1	W	-
2	L/W	-
3	R/B	-
4	L	-
5	Y	-
7	W/G	-
8	P/B	-
9	W/B	-
10	G	-
11	L	-
12	P	-
13	P/B	-
14	BR	-
15	O/L	-
16	SB	-
18	BR	-
19	Y/G	-
20	BR/Y	-
21	V	-
22	L	-
23	Y	-
24	L/W	-
28	O	-
29	R/W	-
30	O/L	-
31	Y	-
32	GR/R	-
34	Y	-
35	R	-
36	B/O	-
37	G/Y	-
38	G	-
40	SB	-
41	W/R	-
42	R	-
43	V	-

JRDWC3696GB

BASIC INSPECTION

DIAGNOSIS AND REPAIR WORK FLOW

Work Flow

INFOID:0000000010262199

DETAILED FLOW

1.INTERVIEW FROM THE CUSTOMER

Clarify customer complaints before inspection. First of all, perform an interview utilizing [DLN-40, "Diagnostic Work Sheet"](#) and reproduce symptoms as well as fully understand it. Ask customer about his/her complaints carefully. Check symptoms by driving vehicle with customer, if necessary.

CAUTION:

Customers are not professional. Never guess easily like "maybe the customer means that..." or "maybe the customer mentions this symptom".

>> GO TO 2.

2.CHECK SYMPTOM

Reproduce the symptom that is indicated by the customer, based on the information from the customer obtained by interview. Also check that the symptom is not caused by fail-safe function. Refer to [DLN-29, "Fail-Safe"](#).

CAUTION:

When the symptom is caused by normal operation, fully inspect each portion and obtain the understanding of customer that the symptom is not caused by a malfunction.

>> GO TO 3.

3.PERFORM SELF-DIAGNOSIS

With CONSULT

Perform self-diagnosis for "ALL MODE AWD/4WD".

Is any DTC detected?

- YES >> Record or print self-diagnosis results. GO TO 4.
- NO >> GO TO 6.

4.RECHECK SYMPTOM

With CONSULT

1. Erase self-diagnostic results for "ALL MODE AWD/4WD".
2. Perform DTC confirmation procedures for the error detected system.

NOTE:

If some DTCs are detected at the same time, determine the order for performing the diagnosis based on [DLN-30, "DTC Inspection Priority Chart"](#).

Is any DTC detected?

- YES >> GO TO 5.
- NO >> Check harness and connectors based on the information obtained by interview. Refer to [GI-43, "Intermittent Incident"](#).

5.REPAIR OR REPLACE ERROR-DETECTED PARTS

- Repair or replace error-detected parts.
- Reconnect part or connector after repairing or replacing.
- When DTC is detected, erase self-diagnostic results for "ALL MODE AWD/4WD".

>> GO TO 7.

6.IDENTIFY ERROR-DETECTED SYSTEM BY SYMPTOM DIAGNOSIS

Estimate error-detected system based on symptom diagnosis and perform inspection.

Can the error-detected system be identified?

A

B

C

DLN

E

F

G

H

I

J

K

L

M

N

O

P

DIAGNOSIS AND REPAIR WORK FLOW

< BASIC INSPECTION >

[TRANSFER: ATX90A]

YES >> GO TO 7.

NO >> Check harness and connectors based on the information obtained by interview. Refer to [GI-43](#),
"Intermittent Incident".

7. FINAL CHECK

With CONSULT

1. Check the reference value for "ALL MODE AWD/4WD".

2. Recheck the symptom and check that symptom is not reproduced on the same conditions.

Is the symptom reproduced?

YES >> GO TO 3.

NO >> INSPECTION END

Diagnostic Work Sheet

INFOID:0000000010262200

Description

- In general, customers have their own criteria for a problem. Therefore, it is important to understand the symptom and status well enough by asking the customer about his/her concerns carefully. To systemize all the information for the diagnosis, prepare the interview sheet referring to the interview points.
- In some cases, multiple conditions that appear simultaneously may cause a DTC to be detected.

Interview sheet sample

Interview sheet					
Customer name	MR/MS	Registration number		Initial year registration	
		Vehicle type		VIN	
Storage date		Engine		Mileage	km (Mile)
Symptom		☐ Vehicle does not enter 4WD mode.			
		☐ 4WD warning lamp turns on.			
		☐ Heavy tight-corner braking symptom occurs			
		☐ Noise ☐ Vibration			
		☐ Others ()			
First occurrence		☐ Recently ☐ Others ()			
Frequency of occurrence		☐ Always ☐ Under a certain conditions of ☐ Sometimes (time(s)/day)			
Climate conditions		☐ Irrelevant			
	Weather	☐ Fine ☐ Cloud ☐ Rain ☐ Snow ☐ Others ()			
	Temperature	☐ Hot ☐ Warm ☐ Cool ☐ Cold ☐ Temperature [Approx. °C (°F)]			
	Relative humidity	☐ High ☐ Moderate ☐ Low			
Road conditions		☐ Urban area ☐ Suburb area ☐ High way ☐ Mounting road (uphill or down hill) ☐ Rough road			
Operation conditions, etc.		☐ Irrelevant ☐ When engine starts ☐ During idling ☐ During driving ☐ During acceleration ☐ At constant speed driving ☐ During deceleration ☐ During cornering (right curve or left curve)			

DIAGNOSIS AND REPAIR WORK FLOW

< BASIC INSPECTION >

[TRANSFER: ATX90A]

Interview sheet					
Customer name	MR/MS	Registration number		Initial year registration	
		Vehicle type		VIN	
Storage date		Engine		Mileage	km (Mile)
Other conditions					

Memo

A
B
C
DLN
E
F
G
H
I
J
K
L
M
N
O
P

ADDITIONAL SERVICE WHEN REPLACING TRANSFER CONTROL UNIT

< BASIC INSPECTION >

[TRANSFER: ATX90A]

ADDITIONAL SERVICE WHEN REPLACING TRANSFER CONTROL UNIT

Description

INFOID:000000010262201

Perform writing unit parameter and initial calibration after replacing transfer control unit. Refer to [DLN-42. "Work Procedure"](#).

Work Procedure

INFOID:000000010262202

NOTE:

In fail-safe mode, can not perform work support. (Except that DTC P181F is detected.)

1. WRITE UNIT PARAMETER

Perform writing unit parameter to control unit. Refer to [DLN-49. "Work Procedure"](#).

>> GO TO 2.

2. INITIAL CALIBRATION (1)

With CONSULT

1. Start the engine.

CAUTION:

Never drive the vehicle.

2. Check "4WD MODE", "T/M RANGE", "COMPR VHCL SPEED", "MOTOR POWER SUP" of CONSULT "DATA MONITOR" for "ALL MODE AWD/4WD".
3. Continue the following condition more than 10 seconds.

4WD MODE	: AUTO
T/M RANGE	: N
COMPR VHCL SPEED	: 0 km/h (Never drive the vehicle)
MOTOR POWER SUP	: More than 11 V

Does the transfer motor operate automatically?

- YES >> After the transfer motor operation stop (After approximately 10 seconds) GO TO 4.
NO >> GO TO 3.

3. INITIAL CALIBRATION (2)

With CONSULT

1. Select "START CALIBRATION" of CONSULT "WORK SUPPORT" for "ALL MODE AWD/4WD".
2. Wait until the motor operation stop. (After approximately 10 seconds)

>> GO TO 4.

4. PERFORM SELF-DIAGNOSIS

With CONSULT

1. Erase self-diagnosis result for "ALL MODE AWD/4WD".
2. Turn the ignition switch ON to OFF.
CAUTION:
Wait for 10 seconds after turning ignition switch OFF.
3. Start the engine.
CAUTION:
Never drive the vehicle.
4. Perform self-diagnosis for "ALL MODE AWD/4WD".

Is "DTC P181F" detected?

- YES >> GO TO 1.
NO >> WORK END

ADDITIONAL SERVICE WHEN REPLACING TRANSFER ASSEMBLY

< BASIC INSPECTION >

[TRANSFER: ATX90A]

ADDITIONAL SERVICE WHEN REPLACING TRANSFER ASSEMBLY

Description

INFOID:000000010262203

Perform writing unit parameter, transfer fluid viscosity learning and initial calibration after replacing transfer assembly. Refer to [DLN-43. "Work Procedure"](#).

Work Procedure

INFOID:000000010262204

NOTE:

In fail-safe mode, can not perform work support. (Except that DTC P181F is detected.)

1.WRITE UNIT PARAMETER

Perform writing unit parameter to control unit. Refer to [DLN-49. "Work Procedure"](#).

>> GO TO 2.

2.PREPARATION BEFORE WORK

With CONSULT

1. Start the engine.

CAUTION:

Never drive the vehicle.

2. Check "4WD MODE", "T/M RANGE", "COMPR VHCL SPEED", "MOTOR POWER SUP" of CONSULT "DATA MONITOR" for "ALL MODE AWD/4WD".
3. Continue the following condition more than 10 seconds.

4WD MODE	: AUTO
T/M RANGE	: N
COMPR VHCL SPEED	: 0 km/h (Never drive the vehicle)
MOTOR POWER SUP	: More than 11 V

>> GO TO 3.

3.PERFORM TRANSFER FLUID VISCOSITY LEARNING

With CONSULT

1. Select "OIL DETERIORATION INFO RESET" of CONSULT "WORK SUPPORT" for "ALL MODE AWD/4WD".
2. Select "Start".

>> GO TO 4.

4.INITIAL CALIBRATION

With CONSULT

1. Select "START CALIBRATION" of CONSULT "WORK SUPPORT" for "ALL MODE AWD/4WD".
2. Wait until the motor operation stop. (After approximately 10 seconds)

>> GO TO 5.

5.PERFORM SELF-DIAGNOSIS

With CONSULT

1. Erase self-diagnosis result for "ALL MODE AWD/4WD".
2. Turn the ignition switch ON to OFF.
CAUTION:
Wait for 10 seconds after turning ignition switch OFF.
3. Start the engine.
CAUTION:
Never drive the vehicle.
4. Perform self-diagnosis for "ALL MODE AWD/4WD".

ADDITIONAL SERVICE WHEN REPLACING TRANSFER ASSEMBLY

< BASIC INSPECTION >

[TRANSFER: ATX90A]

Is "DTC P181F" detected?

YES >> GO TO 1.

NO >> WORK END

TRANSFER LOCK POSITION SENSOR LEARNING

< BASIC INSPECTION >

[TRANSFER: ATX90A]

TRANSFER LOCK POSITION SENSOR LEARNING

Description

INFOID:0000000010262205

- Detect a stroke of transfer lock sleeve and learn operating area of transfer lock sleeve (Lock/Unlock)
- Perform the learning of transfer lock position sensor by "WORK SUPPORT" of CONSULT function. Refer to [DLN-45, "Work Procedure"](#).

CAUTION:

Before performing the learning of lock position sensor, must erase learning of transfer lock position sensor.

Function	Description
LOCK SLEEVE SENSOR* INITIALIZE	Format learning the transfer lock position sensor written to transfer control unit.
LOCK SLEEVE SENSOR* LEARNING	Perform learning the transfer lock position sensor.

*: "LOCK SLEEVE SENSOR" means transfer lock position sensor.

Work Procedure

INFOID:0000000010262206

NOTE:

In fail-safe mode, can not perform work support. (Except that DTC P181F or P182B is detected.)

1. PREPARATION BEFORE WORK

With CONSULT

1. Continue the following condition at vehicle.

Engine	: Running
Parking brake	: Apply
Brake pedal	: Release
Electrical system like air conditioner	: OFF

CAUTION:

Never drive the vehicle.

2. Check "4WD MODE", "T/M RANGE", "COMPR VHCL SPEED", "MOTOR POWER SUP" of CONSULT "DATA MONITOR" for "ALL MODE AWD/4WD".
3. Continue the following condition.

4WD MODE	: 4L
T/M RANGE	: N
COMPR VHCL SPEED	: 0 km/h (Never drive the vehicle)
MOTOR POWER SUP	: More than 11 V

>> GO TO 2.

2. PERFORM LOCK POSITION SENSOR LEARNING

With CONSULT

1. Select "LOCK SLEEVE SENSOR LEARNING" of CONSULT "WORK SUPPORT" for "ALL MODE AWD/4WD".
2. Select "Start".
3. Wait until the motor operation stop.

Is "Error" detected?

YES (within 5 times)>>GO TO 1.

YES (over 5 times)>>Transfer assembly is mechanical malfunction. Replace transfer assembly. Refer to [DLN-127, "Removal and Installation"](#).

NO >> GO TO 3.

3. PERFORM SELF-DIAGNOSIS

With CONSULT

TRANSFER LOCK POSITION SENSOR LEARNING

< BASIC INSPECTION >

[TRANSFER: ATX90A]

1. Erase self-diagnosis result for "ALL MODE AWD/4WD".
2. Turn the ignition switch ON to OFF.
CAUTION:
Wait for 10 seconds after turning ignition switch OFF.
3. Start the engine.
CAUTION:
Never drive the vehicle.
4. Perform self-diagnosis for "ALL MODE AWD/4WD".

Is "DTC P182B" detected?

YES >> GO TO 1.
NO >> WORK END

TRANSFER ROTARY POSITION SENSOR LEARNING

< BASIC INSPECTION >

[TRANSFER: ATX90A]

TRANSFER ROTARY POSITION SENSOR LEARNING

Description

INFOID:0000000110262207

Perform initial calibration after replacing transfer rotary position sensor. Refer to [DLN-47, "Work Procedure"](#).

Work Procedure

INFOID:0000000110262208

NOTE:

In fail-safe mode, can not perform work support. (Except that DTC P181F is detected.)

1. INITIAL CALIBRATION

With CONSULT

1. Start the engine.

CAUTION:

Never drive the vehicle.

2. Check "4WD MODE", "T/M RANGE", "COMPR VHCL SPEED", "MOTOR POWER SUP" of CONSULT "DATA MONITOR" for "ALL MODE AWD/4WD".
3. Continue the following condition.

4WD MODE	: AUTO
T/M RANGE	: N
COMPR VHCL SPEED	: 0 km/h (Never drive the vehicle)
MOTOR POWER SUP	: More than 11 V

4. Select "START CALIBRATION" of CONSULT "WORK SUPPORT" for "ALL MODE AWD/4WD".
5. Wait till the motor operates. (Approx. 10 seconds)

>> GO TO 2.

2. PERFORM SELF-DIAGNOSIS

With CONSULT

1. Erase self-diagnosis result for "ALL MODE AWD/4WD".
2. Turn the ignition switch ON to OFF.
CAUTION:
Wait for 10 seconds after turning ignition switch OFF.
3. Start the engine.
CAUTION:
Never drive the vehicle.
4. Perform self-diagnosis for "ALL MODE AWD/4WD".

Is "DTC P180D" detected?

- | | |
|-----|-------------|
| YES | >> GO TO 1. |
| NO | >> WORK END |

A

B

C

DLN

E

F

G

H

I

J

K

L

M

N

O

P

TRANSFER FLUID VISCOSITY LEARNING

Description

INFOID:0000000010262209

Perform transfer fluid viscosity learning and initial calibration after draining and refilling transfer fluid. Refer to [DLN-48, "Work Procedure"](#).

Work Procedure

INFOID:0000000010262210

NOTE:

In fail-safe mode, can not perform work support. (Except that DTC P181F is detected.)

1. PREPARATION BEFORE WORK

With CONSULT

1. Start the engine.

CAUTION:

Never drive the vehicle.

2. Check "4WD MODE", "T/M RANGE", "COMPR VHCL SPEED", "MOTOR POWER SUP" of CONSULT "DATA MONITOR" for "ALL MODE AWD/4WD".
3. Continue the following condition more than 10 seconds.

4WD MODE	: AUTO
T/M RANGE	: N
COMPR VHCL SPEED	: 0 km/h (Never drive the vehicle)
MOTOR POWER SUP	: More than 11 V

>> GO TO 2.

2. TRANSFER FLUID VISCOSITY LEARNING

With CONSULT

1. Select "OIL DETERIORATION INFO RESET" of CONSULT "WORK SUPPORT" for "ALL MODE AWD/4WD".
2. Select "Start".

>> GO TO 3.

3. INITIAL CALIBRATION

With CONSULT

1. Select "START CALIBRATION" of CONSULT "WORK SUPPORT" for "ALL MODE AWD/4WD".
2. Wait until the motor operation stop. (After approximately 10 seconds)

>> GO TO 4.

4. PERFORM SELF-DIAGNOSIS

With CONSULT

1. Erase self-diagnosis result for "ALL MODE AWD/4WD".
2. Turn the ignition switch ON to OFF.
CAUTION:
Wait for 10 seconds after turning ignition switch OFF.
3. Start the engine.
CAUTION:
Never drive the vehicle.
4. Perform self-diagnosis for "ALL MODE AWD/4WD".

Is "DTC P181F" detected?

- YES >> GO TO 1.
NO >> WORK END

CONFIGURATION (TRANSFER CONTROL UNIT)

< BASIC INSPECTION >

[TRANSFER: ATX90A]

CONFIGURATION (TRANSFER CONTROL UNIT)

Description

INFOID:000000010262211

Perform writing unit parameter after replacing transfer control unit, transfer assembly and transfer control actuator. Refer to [DLN-49, "Work Procedure"](#).

Work Procedure

INFOID:000000010262212

NOTE:

In fail-safe mode, can not perform work support. (Except that DTC P181F is detected.)

1.CONFIRM REPLACING PARTS

Confirm the replacing parts.

What is the replacing parts?

Transfer control unit>>GO TO 2.

Transfer control actuator>>GO TO 3.

Transfer assembly>>GO TO 4.

2.WRITE UNIT PARAMETER (1)


With CONSULT

1. Make the new unit parameter with the following procedure.

- Confirm the alphabet of unit parameter (A).

NOTE:


- This illustration is sample.
- For this illustration, the unit parameter is "G3" and the alphabet of unit parameter is "G".



- Confirm the alphabet of transfer control actuator parameter (B).

NOTE:

- Original transfer control actuator does not have marking of alphabet.
- Just in case that transfer control actuator has been replaced, it has marking of alphabet.
- This illustration is sample of replaced transfer control actuator.
- For this illustration, the alphabet of transfer control actuator parameter is "H".



- Make new alphabet of unit parameter as to the alphabets of unit parameter and the transfer control actuator parameter, using following chart.

When the alphabet of transfer control actuator parameter is no marking.

The alphabet of original unit parameter	A	B	C	D	E	F	G	H	J
↓	↓	↓	↓	↓	↓	↓	↓	↓	↓
The new alphabet of unit parameter	A	B	C	D	E	F	G	H	J

CONFIGURATION (TRANSFER CONTROL UNIT)

[TRANSFER: ATX90A]

< BASIC INSPECTION >

When the alphabet of transfer control actuator parameter is "C".

The alphabet of original unit parameter	A	B	C	D	E	F	G	H	J
↓	↓	↓	↓	↓	↓	↓	↓	↓	↓
The new alphabet of unit parameter	A	B	C	C	D	E	E	F	G

When the alphabet of transfer control actuator parameter is "H".

The alphabet of original unit parameter	A	B	C	D	E	F	G	H	J
↓	↓	↓	↓	↓	↓	↓	↓	↓	↓
The new alphabet of unit parameter	B	C	D	D	E	F	F	G	H

When the alphabet of transfer control actuator parameter is "N".

The alphabet of original unit parameter	A	B	C	D	E	F	G	H	J
↓	↓	↓	↓	↓	↓	↓	↓	↓	↓
The new alphabet of unit parameter	C	D	E	E	F	G	G	H	J

NOTE:

For the sample illustrations, the new alphabet of unit parameter is "F".

- Add the same number of unit parameter behind the new alphabet of unit parameter.

NOTE:

For the sample illustration, the number of unit parameter is "3" and new unit parameter is "F3".

2. Turn the ignition switch OFF to ON.
3. Select "UNIT CHARACTERISTICS WRITE" of CONSULT "WORK SUPPORT" for "ALL MODE AWD/ 4WD".
4. Input new unit parameter.
5. Select "Start".
6. Check that "UNIT CHARACTERISTICS WRITE COMPLETED" or "UNIT CHARACTERISTICS WRITE ALREADY WRITTEN" is displayed.

>> WORK END.


3.WRITE UNIT PARAMETER (2)

With CONSULT

1. Make the new unit parameter with the following procedure.
- Confirm the alphabet of unit parameter (A).

NOTE:


- This illustration is sample.
- For this illustration, the unit parameter is "G3" and the alphabet of unit parameter is "G".



- Confirm the alphabet of transfer control actuator parameter (B).

NOTE:

- Original transfer control actuator does not have marking of alphabet.
- Just in case that transfer control actuator has been replaced, it has marking of alphabet.
- This illustration is sample of replaced transfer control actuator.
- For this illustration, the alphabet of transfer control actuator parameter is "H".



CONFIGURATION (TRANSFER CONTROL UNIT)

< BASIC INSPECTION >

[TRANSFER: ATX90A]

- Make new alphabet of unit parameter as to the alphabets of unit parameter and the transfer control actuator parameter, using following chart.

When the alphabet of transfer control actuator parameter is "C".

The alphabet of original unit parameter	A	B	C	D	E	F	G	H	J
↓	↓	↓	↓	↓	↓	↓	↓	↓	↓
The new alphabet of unit parameter	A	B	C	C	D	E	E	F	G

When the alphabet of transfer control actuator parameter is "H".

The alphabet of original unit parameter	A	B	C	D	E	F	G	H	J
↓	↓	↓	↓	↓	↓	↓	↓	↓	↓
The new alphabet of unit parameter	B	C	D	D	E	F	F	G	H

When the alphabet of transfer control actuator parameter is "N".

The alphabet of original unit parameter	A	B	C	D	E	F	G	H	J
↓	↓	↓	↓	↓	↓	↓	↓	↓	↓
The new alphabet of unit parameter	C	D	E	E	F	G	G	H	J

NOTE:

For the sample illustrations, the new alphabet of unit parameter is "F".

- Add the same number of unit parameter behind the new alphabet of unit parameter.

NOTE:

For the sample illustration, the number of unit parameter is "3" and new unit parameter is "F3".

2. Turn the ignition switch OFF to ON.
3. Select "UNIT CHARACTERISTICS WRITE" of CONSULT "WORK SUPPORT" for "ALL MODE AWD/4WD".
4. Input new unit parameter.
5. Select "Start".
6. Check that "UNIT CHARACTERISTICS WRITE COMPLETED" or "UNIT CHARACTERISTICS WRITE ALREADY WRITTEN" is displayed.

>> WORK END.

4.WRITE UNIT PARAMETER (3)


With CONSULT

1. Confirm the unit parameter (A).

NOTE:

- This illustration is sample.
- For this illustration, the unit parameter is "G3".

2. Turn the ignition switch OFF to ON.
3. Select "UNIT CHARACTERISTICS WRITE" of CONSULT "WORK SUPPORT" for "ALL MODE AWD/4WD".
4. Input unit parameter.
5. Select "Start".
6. Check that "UNIT CHARACTERISTICS WRITE COMPLETED" or "UNIT CHARACTERISTICS WRITE ALREADY WRITTEN" is displayed.



>> WORK END.

P1802, P1803, P1804, P1809 TRANSFER CONTROL UNIT

< DTC/CIRCUIT DIAGNOSIS >

[TRANSFER: ATX90A]

DTC/CIRCUIT DIAGNOSIS

P1802, P1803, P1804, P1809 TRANSFER CONTROL UNIT

DTC Logic

INFOID:000000001026213

DTC DETECTION LOGIC

DTC	Display item	Malfunction detected condition	Possible cause
P1802	CONTROL UNIT 1	Malfunction is detected in the memory (RAM) system of transfer control unit.	Internal malfunction of transfer control unit.
P1803	CONTROL UNIT 2	Malfunction is detected in the memory (ROM) system of transfer control unit.	
P1804	CONTROL UNIT 3	Malfunction is detected in the memory (EEPROM) system of transfer control unit.	
P1809	CONTROL UNIT 4	AD converter system of transfer control unit is malfunctioning.	

DTC CONFIRMATION PROCEDURE

1. PRECONDITIONING

If "DTC CONFIRMATION PROCEDURE" has been previously conducted, always turn ignition switch OFF and wait at least 10 seconds before conducting the next test.

>> GO TO 2.

2. DTC REPRODUCTION PROCEDURE

With CONSULT

1. Turn the ignition switch OFF to ON.
2. Perform self-diagnosis for "ALL MODE AWD/4WD".

Are DTC's "P1802, P1803, P1804 or P1809" detected?

- YES >> Proceed to diagnosis procedure. Refer to [DLN-52, "Diagnosis Procedure"](#).
NO >> INSPECTION END

Diagnosis Procedure

INFOID:000000001026214

1. PERFORM SELF-DIAGNOSIS

With CONSULT

1. Erase self-diagnostic results for "ALL MODE AWD/4WD".
2. Turn the ignition switch OFF, and then wait 10 seconds and more.
3. Perform self-diagnosis for "ALL MODE AWD/4WD".

Are DTC's "P1802, P1803, P1804 or 1809" detected?

- YES >> Replace transfer control unit. Refer to [DLN-112, "Removal and Installation"](#).
NO >> Check transfer control unit pin terminals for damage or loose connection with harness connector.
If any items are damaged, repair or replace error-detected parts.

P1807 OUT PUT SHAFT SPEED SENSOR

< DTC/CIRCUIT DIAGNOSIS >

[TRANSFER: ATX90A]

P1807 OUT PUT SHAFT SPEED SENSOR

DTC Logic

INFOID:0000000010262215

DTC DETECTION LOGIC

DTC	Display item	Malfunction detected condition	Possible cause
P1807	VHCL SPEED SEN-AT	- Malfunction is detected in output speed signal that is output from TCM through CAN communication. - Improper signal is input while driving.	- Harness or connector (CAN communication line) - TCM - Internal malfunction of TCM - Output speed signal error

DTC CONFIRMATION PROCEDURE

1.PRECONDITIONING

If "DTC CONFIRMATION PROCEDURE" has been previously conducted, always turn ignition switch OFF and wait at least 10 seconds before conducting the next test.

>> GO TO 2.

2.DTC REPRODUCTION PROCEDURE

With CONSULT

- Start the engine and drive at 30 km/h (19 MPH) or more for approximately 1 minute.
- Perform self-diagnosis for "ALL MODE AWD/4WD".

Is DTC "P1807" detected?

- YES >> Proceed to diagnosis procedure. Refer to [DLN-53, "Diagnosis Procedure"](#).
NO >> INSPECTION END

Diagnosis Procedure

INFOID:0000000010262216

1.PERFORM TCM SELF-DIAGNOSIS

With CONSULT

Perform self-diagnosis for "TRANSMISSION".

Is any DTCs detected?

- YES >> Check the DTC. Refer to [TM-81, "DTC Index"](#).
NO >> GO TO 2.

2.CHECK TERMINALS AND HARNESS CONNECTORS

Check transfer control unit pin terminals for damage or loose connection with harness connector.

Is inspection result normal?

- YES >> After turning the ignition switch OFF, perform DTC confirmation procedure again. When DTC "P1807" is detected, Replace transfer control unit. Refer to [DLN-112, "Removal and Installation"](#).
NO >> Repair or replace error-detected parts.

P1808 WHEEL SPEED SENSOR

< DTC/CIRCUIT DIAGNOSIS >

[TRANSFER: ATX90A]

P1808 WHEEL SPEED SENSOR

DTC Logic

INFOID:0000000010262217

DTC DETECTION LOGIC

DTC	Display item	Malfunction detected condition	Possible cause
P1808	VHCL SPEED SEN-ABS	- Malfunction is detected in vehicle speed signal that is output from ABS actuator and electric unit (control unit) through CAN communication. - Improper signal is input while driving.	- Harness or connector (CAN communication line) - Malfunction of ABS actuator and electric unit (control unit) - Malfunction of ABS actuator and electric unit (control unit) circuit error - Vehicle speed signal error

DTC CONFIRMATION PROCEDURE

1. PRECONDITIONING

If "DTC CONFIRMATION PROCEDURE" has been previously conducted, always turn ignition switch OFF and wait at least 10 seconds before conducting the next test.

>> GO TO 2.

2. DTC REPRODUCTION PROCEDURE

With CONSULT

- Start the engine and drive at 30 km/h (19 MPH) or more for approximately 1 minute.
- Perform self-diagnosis for "ALL MODE AWD/4WD".

Is DTC "P1808" detected?

- YES >> Proceed to diagnosis procedure. Refer to [DLN-54, "Diagnosis Procedure"](#).
NO >> INSPECTION END

Diagnosis Procedure

INFOID:0000000010262218

1. PERFORM ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT) SELF-DIAGNOSIS

With CONSULT

Perform self-diagnosis for "ABS".

Is any DTCs detected?

- YES >> Check the DTC. Refer to [BRC-50, "DTC Index"](#).
NO >> GO TO 2.

2. CHECK TERMINALS AND HARNESS CONNECTORS

Check transfer control unit pin terminals for damage or loose connection with harness connector.

Is inspection result normal?

- YES >> After turning the ignition switch OFF, perform DTC confirmation procedure again. When DTC "P1808" is detected, Replace transfer control unit. Refer to [DLN-112, "Removal and Installation"](#).
NO >> Repair or replace error-detected parts.

P180C SENSOR POWER SUPPLY (5V)

< DTC/CIRCUIT DIAGNOSIS >

[TRANSFER: ATX90A]

P180C SENSOR POWER SUPPLY (5V)

Description

INFOID:0000000010262219

Supplies power (5V) to transfer lock position sensor and transfer rotary position sensor.

DTC Logic

INFOID:0000000010262220

DTC DETECTION LOGIC

DTC	Display item	Malfunction detected condition	Possible cause
P180C	SEN POWER SUPPLY (5V)	When the sensor power supply (5V) voltage is lower or higher than normal.	- Malfunction of transfer lock position sensor power supply circuit (open or short) - Malfunction of transfer rotary position sensor power supply circuit (open or short)

DLN

DTC CONFIRMATION PROCEDURE

1.PRECONDITIONING

If "DTC CONFIRMATION PROCEDURE" has been previously conducted, always turn ignition switch OFF and wait at least 10 seconds before conducting the next test.

>> GO TO 2.

2.DTC REPRODUCTION PROCEDURE

With CONSULT

- Turn the ignition switch OFF to ON.
- Perform self-diagnosis for "ALL MODE AWD/4WD".

Is DTC "P180C" detected?

YES >> Proceed to diagnosis procedure. Refer to [DLN-55, "Diagnosis Procedure"](#).
NO >> INSPECTION END

Diagnosis Procedure

INFOID:0000000010262221

1.CHECK TRANSFER LOCK POSITION SENSOR POWER SUPPLY (1)

- Turn the ignition switch OFF.
- Disconnect transfer lock position sensor harness connector and transfer rotary position sensor harness connector.
- Turn the ignition switch ON.
CAUTION:
Never start the engine.
- Check the voltage between transfer lock position sensor harness connector terminals.

+		-	Voltage
Transfer lock position sensor			
Connector	Terminal		
F40	1	2	Approx. 5 V

Is the inspection result normal?

YES >> GO TO 3.
NO >> GO TO 2.

2.CHECK TRANSFER LOCK POSITION SENSOR CIRCUIT

- Turn the ignition switch OFF.
- Disconnect transfer control unit harness connector.

P180C SENSOR POWER SUPPLY (5V)

< DTC/CIRCUIT DIAGNOSIS >

[TRANSFER: ATX90A]

3. Check the continuity between transfer control unit harness connector and transfer lock position sensor harness connector.

Transfer control unit		Transfer lock position sensor		Continuity
Connector	Terminal	Connector	Terminal	
E59	17	F40	1	Existed
	30		2	

4. Check the continuity between transfer lock position sensor harness connector and ground.

Transfer lock position sensor		—	Continuity
Connector	Terminal		
F40	1	Ground	Not existed

Is the inspection result normal?

- YES >> GO TO 4.
NO >> Repair or replace error-detected parts.

3.CHECK TRANSFER LOCK POSITION SENSOR POWER SUPPLY (2)

1. Turn the ignition switch OFF.
2. Connect transfer lock position sensor harness connector.
3. Turn the ignition switch ON.

CAUTION:

Never start the engine.

4. Check the voltage between transfer lock position sensor harness connector terminals.

+		-	Voltage
Transfer lock position sensor			
Connector	Terminal		
F40	1	2	Approx. 5 V

Is the inspection result normal?

- YES >> GO TO 6.
NO >> Replace transfer lock position sensor. Refer to [DLN-124, "Removal and Installation"](#).

4.CHECK TRANSFER ROTARY POSITION SENSOR POWER SUPPLY (1)

1. Turn the ignition switch OFF.
2. Connect transfer control unit harness connector.
3. Turn the ignition switch ON.

CAUTION:

Never start the engine.

4. Check the voltage between transfer rotary position sensor harness connector terminals.

+		-	Voltage
Transfer rotary position sensor			
Connector	Terminal		
F41	1	2	Approx. 5 V

Is the inspection result normal?

- YES >> GO TO 6.
NO >> GO TO 5.

5.CHECK TRANSFER ROTARY POSITION SENSOR CIRCUIT

1. Turn the ignition switch OFF.
2. Disconnect transfer control unit harness connector.
3. Check the continuity between transfer control unit harness connector and transfer rotary position sensor harness connector.

P180C SENSOR POWER SUPPLY (5V)

< DTC/CIRCUIT DIAGNOSIS >

[TRANSFER: ATX90A]

Transfer control unit		Transfer rotary position sensor		Continuity
Connector	Terminal	Connector	Terminal	
E59	18	F41	1	Existed
	16		2	

4. Check the continuity between transfer rotary position sensor harness connector and ground.

Transfer rotary position sensor		—	Continuity
Connector	Terminal		
F41	1	Ground	Not existed

Is the inspection result normal?

YES >> GO TO 7.

NO >> Repair or replace error-detected parts.

6.CHECK TRANSFER ROTARY POSITION SENSOR POWER SUPPLY (2)

1. Turn the ignition switch OFF.
2. Connect transfer lock position sensor harness connector.
3. Turn the ignition switch ON.

CAUTION:

Never start the engine.

4. Check the voltage between transfer rotary position sensor harness connector terminals.

+		-	Voltage
Transfer rotary position sensor			
Connector	Terminal		
F41	1	2	Approx. 5 V

Is the inspection result normal?

YES >> GO TO 7.

NO >> Replace transfer rotary position sensor. Refer to [DLN-122, "Removal and Installation"](#).

7.CHECK TERMINALS AND HARNESS CONNECTORS

Check the pin terminals for damage or loose connection with each harness connector.

Is the inspection result normal?

YES >> Replace transfer control unit. Refer to [DLN-112, "Removal and Installation"](#).

NO >> Repair or replace error-detected parts.

P180D TRANSFER ROTARY POSITION SENSOR

< DTC/CIRCUIT DIAGNOSIS >

[TRANSFER: ATX90A]

P180D TRANSFER ROTARY POSITION SENSOR

DTC Logic

INFOID:0000000010262222

DTC DETECTION LOGIC

DTC	Display item	Malfunction detected condition	Possible cause
P180D	ROTARY POSITION SEN	Malfunction is detected in transfer rotary position sensor.	Transfer rotary position sensor • Transfer rotary position sensor error • Transfer rotary position sensor circuit error

DTC CONFIRMATION PROCEDURE

1.PRECONDITIONING

If "DTC CONFIRMATION PROCEDURE" has been previously conducted, always turn ignition switch OFF and wait at least 10 seconds before conducting the next test.

>> GO TO 2.

2.DTC REPRODUCTION PROCEDURE

With CONSULT

1. Turn the ignition switch OFF to ON.
2. Turn the 4WD shift switch AUTO⇒4H⇒4L⇒4H⇒AUTO.
3. Perform self-diagnosis for "ALL MODE AWD/4WD".

Is DTC "P180D" detected?


- YES >> Proceed to diagnosis procedure. Refer to [DLN-58. "Diagnosis Procedure"](#).
NO >> INSPECTION END

Diagnosis Procedure

INFOID:0000000010262223

1.CHECK TRANSFER ROTARY POSITION SENSOR SIGNAL

1. Turn the ignition switch ON.
2. Check the voltage between transfer control unit harness connector and ground.

+		-	Voltage
Transfer control unit			
Connector	Terminal		
E59	15	Ground	400 μ Sec/div  2V/div JPDI E0268GB

Is the inspection result normal?

- YES >> GO TO 6.
NO >> GO TO 2.

2.CHECK TRANSFER ROTARY POSITION SENSOR POWER SUPPLY

1. Turn the ignition switch OFF.
2. Disconnect transfer rotary position sensor harness connector.
3. Turn the ignition switch ON.
CAUTION:
Never start the engine.
4. Check the voltage between transfer rotary position sensor harness connector terminals.

P180D TRANSFER ROTARY POSITION SENSOR

< DTC/CIRCUIT DIAGNOSIS >

[TRANSFER: ATX90A]

+		-	Voltage
Transfer rotary position sensor			
Connector	Terminal		
F41	1	2	Approx. 5 V

Is the inspection result normal?

YES >> GO TO 4.

NO >> GO TO 3.

3.CHECK TRANSFER ROTARY POSITION SENSOR CIRCUIT

1. Turn the ignition switch OFF.
2. Disconnect transfer control unit harness connector.
3. Check the continuity between transfer control unit harness connector and transfer rotary position sensor harness connector.

Transfer control unit		Transfer rotary position sensor		Continuity
Connector	Terminal	Connector	Terminal	
E59	18	F41	1	Existed
	16		2	

4. Check the continuity between transfer rotary position sensor harness connector and ground.

Transfer rotary position sensor		—	Continuity
Connector	Terminal		
F41	1	Ground	Not existed

Is the inspection result normal?

YES >> GO TO 5.

NO >> Repair or replace error-detected parts.

4.CHECK TRANSFER ROTARY POSITION SENSOR SIGNAL CIRCUIT

1. Turn the ignition switch OFF.
2. Disconnect transfer control unit harness connector.
3. Check the continuity between transfer control unit harness connector and transfer rotary position sensor harness connector.

Transfer control unit		Transfer rotary position sensor		Continuity
Connector	Terminal	Connector	Terminal	
E59	15	F41	3	Existed

4. Check the continuity between transfer rotary position sensor harness connector and ground.

Transfer rotary position sensor		—	Continuity
Connector	Terminal		
F41	3	Ground	Not existed

Is the inspection result normal?

YES >> GO TO 5.

NO >> Repair or replace error-detected parts.

5.REPLACE TRANSFER ROTARY POSITION SENSOR

1. Replace transfer rotary position sensor. Refer to [DLN-122, "Removal and Installation"](#).
2. Perform confirmation procedure again. Refer to [DLN-58, "DTC Logic"](#).

Is DTC "P180D" detected?

YES >> GO TO 6.

P180D TRANSFER ROTARY POSITION SENSOR

< DTC/CIRCUIT DIAGNOSIS >

[TRANSFER: ATX90A]

NO >> INSPECTION END

6. CHECK TERMINALS AND HARNESS CONNECTORS

Check the pin terminals for damage or loose connection with each harness connector.

Is the inspection result normal?

YES >> Replace transfer control unit. Refer to [DLN-112. "Removal and Installation"](#).

NO >> Repair or replace error-detected parts.

P180E SENSOR POWER SUPPLY (8V)

< DTC/CIRCUIT DIAGNOSIS >

[TRANSFER: ATX90A]

P180E SENSOR POWER SUPPLY (8V)

Description

INFOID:0000000010262224

Supplies power (8V) to transfer internal speed sensor.

DTC Logic

INFOID:0000000010262225

DTC DETECTION LOGIC

DTC	Display item	Malfunction detected condition	Possible cause
P180E	SEN POWER SUPPLY (8V)	When the sensor power supply (8V) voltage is lower or higher than normal.	Malfunction of transfer internal speed sensor power supply circuit (open or short)

A

B

C

DLN

E

DTC CONFIRMATION PROCEDURE

1. PRECONDITIONING

If "DTC CONFIRMATION PROCEDURE" has been previously conducted, always turn ignition switch OFF and wait at least 10 seconds before conducting the next test.

F

>> GO TO 2.

G

2. DTC REPRODUCTION PROCEDURE

With CONSULT

- Turn the ignition switch ON.
- Perform self-diagnosis for "ALL MODE AWD/4WD".

H

Is DTC "P180E" detected?

I

- YES >> Proceed to diagnosis procedure. Refer to [DLN-61, "Diagnosis Procedure"](#).
NO >> INSPECTION END

Diagnosis Procedure

INFOID:0000000010262226

J

1. CHECK TRANSFER INTERNAL SPEED SENSOR POWER SUPPLY (1)

- Turn the ignition switch OFF.
- Disconnect transfer control actuator harness connector.
- Turn the ignition switch ON.
CAUTION:
Never start the engine.
- Check the voltage between transfer control actuator harness connector terminals.

K

L

M

+		-	Voltage
Transfer control actuator			
Connector	Terminal		
F52	3	7	Approx. 8 V

N

Is the inspection result normal?

O

- YES >> GO TO 3.
NO >> GO TO 2.

2. CHECK TRANSFER INTERNAL SPEED SENSOR CIRCUIT

P

- Turn the ignition switch OFF.
- Disconnect transfer control unit harness connector.
- Check the continuity between transfer control unit harness connector and transfer control actuator harness connector.

P180E SENSOR POWER SUPPLY (8V)

< DTC/CIRCUIT DIAGNOSIS >

[TRANSFER: ATX90A]

Transfer control unit		Transfer control actuator		Continuity
Connector	Terminal	Connector	Terminal	
E59	39	F52	3	Existed
	9		7	

4. Check the continuity between transfer control actuator harness connector and ground.

Transfer control actuator		—	Continuity
Connector	Terminal		
F52	7	Ground	Not existed

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace error-detected parts.

3.CHECK TRANSFER INTERNAL SPEED SENSOR POWER SUPPLY (2)

1. Turn the ignition switch OFF.
2. Connect transfer control actuator harness connector.
3. Turn the ignition switch ON.

CAUTION:

Never start the engine.

4. Check the voltage between transfer control actuator harness connector terminals.

+		—	Voltage
Transfer control actuator			
Connector	Terminal		
F52	3	7	Approx. 8 V

Is the inspection result normal?

YES >> GO TO 4.

NO >> Transfer internal speed sensor is malfunctioning. Replace transfer control actuator. Refer to [DLN-119, "Removal and Installation"](#).

4.CHECK TERMINALS AND HARNESS CONNECTORS

Check the pin terminals for damage or loose connection with each harness connector.

Is the inspection result normal?

YES >> Replace transfer control unit. Refer to [DLN-112, "Removal and Installation"](#).

NO >> Repair or replace error-detected parts.

P180F TRANSFER INTERNAL SPEED SENSOR

< DTC/CIRCUIT DIAGNOSIS >

[TRANSFER: ATX90A]

P180F TRANSFER INTERNAL SPEED SENSOR

DTC Logic

INFOID:0000000010262227

DTC DETECTION LOGIC

DTC	Display item	Malfunction detected condition	Possible cause
P180F	MOTOR SYSTEM	- Malfunction is detected in transfer motor. - Malfunction is detected in transfer internal speed sensor.	- Transfer control actuator - Transfer motor error - Transfer internal speed sensor circuit error - Transfer assembly internal malfunction.

DTC CONFIRMATION PROCEDURE

1.PRECONDITIONING

If "DTC CONFIRMATION PROCEDURE" has been previously conducted, always turn ignition switch OFF and wait at least 10 seconds before conducting the next test.

>> GO TO 2.

2.DTC REPRODUCTION PROCEDURE

With CONSULT

- Turn the ignition switch OFF to ON.
- Turn the 4WD shift switch AUTO⇒4H⇒4L⇒4H⇒AUTO.
- Perform self-diagnosis for "ALL MODE AWD/4WD".

Is DTC "P180F" detected?

- YES >> Proceed to diagnosis procedure. Refer to [DLN-63, "Diagnosis Procedure"](#).
NO >> INSPECTION END

Diagnosis Procedure

INFOID:0000000010262228



1.CHECK TRANSFER INTERNAL SPEED SENSOR SIGNAL

- Turn the ignition switch ON.
- Check the voltage between transfer control unit harness connector and ground.

P180F TRANSFER INTERNAL SPEED SENSOR

< DTC/CIRCUIT DIAGNOSIS >

[TRANSFER: ATX90A]

+		—	Condition	Voltage
Transfer control unit				
Connector	Terminal			
E59	10	Ground	4WD mode: AUTO A/T shift selector: N Depress accelerator pedal several time	
	31	Ground		 NOTE: When changing the transfer motor rotation direction.

Is the inspection result normal?

YES >> GO TO 6.

NO >> GO TO 2.

2.CHECK TRANSFER INTERNAL SPEED SENSOR POWER SUPPLY

1. Turn the ignition switch OFF.
2. Disconnect transfer control actuator harness connector.
3. Turn the ignition switch ON.
4. Check the voltage between transfer control actuator harness connector terminals.

+		—	Voltage
Transfer control actuator			
Connector	Terminal		
F52	3	7	Approx. 8 V

Is the inspection result normal?

YES >> GO TO 4.

NO >> GO TO 3.

3.CHECK TRANSFER INTERNAL SPEED SENSOR POWER SUPPLY CIRCUIT

1. Turn the ignition switch OFF.
2. Disconnect transfer control unit harness connector.
3. Check the continuity between transfer control unit harness connector and transfer control actuator harness connector.

Transfer control unit		Transfer control actuator		Continuity
Connector	Terminal	Connector	Terminal	
E59	39	F52	3	Existed
	9		7	

4. Check the continuity between transfer control actuator harness connector and ground.

P180F TRANSFER INTERNAL SPEED SENSOR

< DTC/CIRCUIT DIAGNOSIS >

[TRANSFER: ATX90A]

Transfer control actuator		—	Continuity
Connector	Terminal		
F52	3	Ground	Not existed

Is the inspection result normal?

YES >> GO TO 6.

NO >> Repair or replace error-detected parts.

4.CHECK TRANSFER INTERNAL SPEED SENSOR SIGNAL CIRCUIT

1. Turn the ignition switch OFF.
2. Disconnect transfer control unit harness connector.
3. Check the continuity between transfer control unit harness connector and transfer control actuator harness connector.

Transfer control unit		Transfer control actuator		Continuity
Connector	Terminal	Connector	Terminal	
E59	10	F52	2	Existed
	31		6	

4. Check the continuity between transfer control actuator harness connector and ground.

Transfer control actuator		—	Continuity
Connector	Terminal		
F52	2	Ground	Not existed
	6		

Is the inspection result normal?

YES >> GO TO 5.

NO >> Repair or replace error-detected parts.

5.REPLACE TRANSFER CONTROL ACTUATOR

1. Replace transfer control actuator. Refer to [DLN-119, "Removal and Installation"](#).
2. Perform confirmation procedure again. Refer to [DLN-58, "DTC Logic"](#).

Is DTC "P180F" detected?

YES >> GO TO 6.

NO >> INSPECTION END

6.CHECK TRANSFER INTERNAL FUNCTION

With CONSULT

1. Remove transfer control actuator. Refer to [DLN-119, "Removal and Installation"](#).
2. Turn the actuator shaft. Refer to [DLN-119, "Inspection"](#).
3. Check "ROTARY POSI SEN" of CONSULT "DATA MONITOR" for "ALL MODE AWD/4WD".

Monitor item	Condition	Status
ROTARY POSI SEN	Turn the actuator shaft.	Value is changing

Is the inspection result normal?

YES >> GO TO 7.

NO >> Transfer assembly is mechanical malfunction. Replace transfer assembly. Refer to [DLN-127, "Removal and Installation"](#).

7.CHECK TERMINALS AND HARNESS CONNECTORS

Check the pin terminals for damage or loose connection with each harness connector.

Is the inspection result normal?

YES >> Replace transfer control unit. Refer to [DLN-112, "Removal and Installation"](#).

NO >> Repair or replace error-detected parts.

P1811 POWER SUPPLY CIRCUIT FOR TRANSFER CONTROL UNIT

< DTC/CIRCUIT DIAGNOSIS >

[TRANSFER: ATX90A]

P1811 POWER SUPPLY CIRCUIT FOR TRANSFER CONTROL UNIT

Description

INFOID:0000000010262229

Supplies power to transfer control unit.

DTC Logic

INFOID:0000000010262230

DTC DETECTION LOGIC

DTC	Display item	Malfunction detected condition	Possible cause
P1811	BATTERY VOLTAGE	When transfer control unit power supply is lower or higher than normal	Malfunction of transfer control unit power supply circuit (open or short)

DTC CONFIRMATION PROCEDURE

1.PRECONDITIONING

If "DTC CONFIRMATION PROCEDURE" has been previously conducted, always turn ignition switch OFF and wait at least 10 seconds before conducting the next test.

>> GO TO 2.

2.DTC REPRODUCTION PROCEDURE

With CONSULT

1. Turn the ignition switch OFF to ON.
2. Perform self-diagnosis for "ALL MODE AWD/4WD".

Is DTC "P1811" detected?

- YES >> Proceed to diagnosis procedure. Refer to [DLN-66, "Diagnosis Procedure"](#).
NO >> INSPECTION END

Diagnosis Procedure

INFOID:0000000010262231

1.CHECK TRANSFER CONTROL UNIT POWER SUPPLY (1)

1. Turn the ignition switch OFF.
2. Disconnect transfer control unit harness connector.
3. Check the voltage between transfer control unit harness connector and ground.

Transfer control unit		—	Voltage
Connector	Terminal		
E59	20	Ground	Battery voltage

4. Turn the ignition switch ON.
CAUTION:
Never start the engine.
5. Check the voltage between transfer control unit harness connector and ground.

Transfer control unit		—	Voltage
Connector	Terminal		
E59	20	Ground	Battery voltage

Is the inspection result normal?

- YES >> GO TO 3.
NO >> GO TO 2.

2.CHECK TRANSFER CONTROL UNIT POWER SUPPLY (2)

1. Turn the ignition switch OFF.
2. Check the 10A fuse (#34).

P1811 POWER SUPPLY CIRCUIT FOR TRANSFER CONTROL UNIT

[TRANSFER: ATX90A]

< DTC/CIRCUIT DIAGNOSIS >

3. Check the harness for open or short between transfer control unit harness connector No.20 terminal and 10A (#34).

Is the inspection result normal?

YES >> Perform the trouble diagnosis for power supply circuit. Refer to [PG-12, "Wiring Diagram - BATTERY POWER SUPPLY -"](#).

NO >> Repair or replace error-detected parts.

3.CHECK TRANSFER CONTROL UNIT POWER SUPPLY (3)

1. Turn the ignition switch OFF.
2. Check the voltage between transfer control unit harness connector and ground.

Transfer control unit		—	Voltage
Connector	Terminal		
E59	32	Ground	0 V

3. Turn the ignition switch ON.

CAUTION:

Never start the engine.

4. Check the voltage between transfer control unit harness connector and ground.

Transfer control unit		—	Voltage
Connector	Terminal		
E59	32	Ground	Battery voltage

Is the inspection result normal?

YES >> GO TO 5.

NO >> GO TO 4.

4.CHECK TRANSFER CONTROL UNIT POWER SUPPLY (4)

1. Turn the ignition switch OFF.
2. Check the 10A fuse (#56).
3. Disconnect IPDM E/R harness connector.
4. Check the continuity between transfer control unit harness connector and IPDM E/R harness connector.

IPDM E/R		Transfer control unit		Continuity
Connector	Terminal	Connector	Terminal	
E15	58	E59	32	Existed

5. Check the continuity between transfer control unit harness connector and the ground.

Transfer control unit		—	Continuity
Connector	Terminal		
E59	32	Ground	Not existed

Is the inspection result normal?

YES >> Perform the trouble diagnosis for ignition power supply circuit. Refer to [PG-60, "Wiring Diagram - IGNITION POWER SUPPLY -"](#).

NO >> Repair or replace error-detected parts.

5.CHECK TRANSFER CONTROL UNIT GROUND

1. Turn the ignition switch OFF.
2. Check the continuity between transfer control unit harness connector and ground.

P1811 POWER SUPPLY CIRCUIT FOR TRANSFER CONTROL UNIT

< DTC/CIRCUIT DIAGNOSIS >

[TRANSFER: ATX90A]

Transfer control unit		—	Continuity
Connector	Terminal		
E60	46	Ground	Existed
	44		

Is the inspection result normal?

YES >> GO TO 6.

NO >> Repair or replace error-detected parts.

6.CHECK TERMINALS AND HARNESS CONNECTORS

Check the transfer control unit pin terminals for damage or loose connection with harness connector.

Is the inspection result normal?

YES >> Replace transfer control unit. Refer to [DLN-112. "Removal and Installation"](#).

NO >> Repair or replace error-detected parts.

P1813 4WD MODE SWITCH

< DTC/CIRCUIT DIAGNOSIS >

[TRANSFER: ATX90A]

P1813 4WD MODE SWITCH

DTC Logic

INFOID:0000000010262232

DTC DETECTION LOGIC

DTC	Display item	Malfunction detected condition	Possible cause
P1813	4WD MODE SW	Multiple signals received from 4WD shift switch are detected.	• 4WD switch assembly - Internal malfunction of 4WD switch assembly - Malfunction of 4WD switch assembly circuit • Transfer control unit

DTC CONFIRMATION PROCEDURE

1.PRECONDITIONING

If "DTC CONFIRMATION PROCEDURE" has been previously conducted, always turn ignition switch OFF and wait at least 10 seconds before conducting the next test.

>> GO TO 2.

2.DTC REPRODUCTION PROCEDURE

With CONSULT

1. Turn the ignition switch OFF to ON.
2. Turn the 4WD shift switch AUTO⇒4H⇒4L⇒4H⇒AUTO.
3. Perform self-diagnosis for "ALL MODE AWD/4WD".

Is DTC "P1813" detected?

- YES >> Proceed to diagnosis procedure. Refer to [DLN-69, "Diagnosis Procedure"](#).
NO >> INSPECTION END

Diagnosis Procedure

INFOID:0000000010262233

1.CHECK TRANSFER SHIFT SWITCH

Check 4WD switch assembly. Refer to [DLN-70, "Component Inspection"](#).

Is the inspection result normal?

- YES >> GO TO 2.
NO >> 4WD shift switch is malfunctioning. Replace 4WD switch assembly. Refer to [DLN-113, "Removal and Installation"](#).

2.CHECK 4WD SHIFT SWITCH CIRCUIT (1)

1. Disconnect transfer control unit harness connector.
2. Check the continuity between transfer control unit harness connector and 4WD switch assembly harness connector.

P1813 4WD MODE SWITCH

< DTC/CIRCUIT DIAGNOSIS >

[TRANSFER: ATX90A]

Transfer control unit		4WD switch assembly		Continuity
Connector	Terminal	Connector	Terminal	
E59	11	M54	11	Existed
			10	Not existed
			9	Not existed
	35		11	Not existed
			10	Existed
			9	Not existed
	14		11	Not existed
			10	Not existed
			9	Existed

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace error-detected parts.

3.CHECK 4WD SHIFT SWITCH CIRCUIT (2)

Check the continuity between 4WD switch assembly harness connector and ground.

4WD switch assembly		—	Continuity
Connector	Terminal		
M54	11	Ground	Not existed
	10		
	9		

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair or replace error-detected parts.

4.CHECK TERMINALS AND HARNESS CONNECTORS

- Check transfer control unit pin terminals for damage or loose connection with harness connector.
- Check 4WD switch assembly pin terminals for damage or loose connection with harness connector.

Is the inspection result normal?

YES >> Replace transfer control unit. Refer to [DLN-112, "Removal and Installation"](#).

NO >> Repair or replace error-detected parts.

Component Inspection

INFOID:0000000010262234

1.CHECK 4WD SHIFT SWITCH

1. Turn the ignition switch OFF.
2. Remove 4WD switch assembly. Refer to [DLN-113, "Removal and Installation"](#).
3. Check the continuity between 4WD switch assembly harness connector terminals.

4WD switch assembly		Condition	Continuity
Terminal			
12	9	4WD shift switch: AUTO	Existed
		4WD shift switch: 4H or 4L	Not existed
12	10	4WD shift switch: 4H	Existed
		4WD shift switch: AUTO or 4L	Not existed
12	11	4WD shift switch: 4L	Existed
		4WD shift switch: AUTO or 4H	Not existed

P1813 4WD MODE SWITCH

< DTC/CIRCUIT DIAGNOSIS >

[TRANSFER: ATX90A]

Is the inspection result normal?

YES >> INSPECTION END

NO >> Replace 4WD switch assembly. Refer to [DLN-113. "Removal and Installation"](#).

A

B

C

DLN

E

F

G

H

I

J

K

L

M

N

O

P

P1816 PARKING/NEUTRAL POSITION SWITCH

< DTC/CIRCUIT DIAGNOSIS >

[TRANSFER: ATX90A]

P1816 PARKING/NEUTRAL POSITION SWITCH

DTC Logic

INFOID:0000000010262235

DTC DETECTION LOGIC

DTC	Display item	Malfunction detected condition	Possible cause
P1816	PNP SW/CIRC	Malfunction is detected in shift position signal that is output from TCM through CAN communication.	• Harness or connector (CAN communication line) • TCM - Internal malfunction of TCM - A/T shift selector error

DTC CONFIRMATION PROCEDURE

1.PRECONDITIONING

If "DTC CONFIRMATION PROCEDURE" has been previously conducted, always turn ignition switch OFF and wait at least 10 seconds before conducting the next test.

>> GO TO 2.

2.DTC REPRODUCTION PROCEDURE

With CONSULT

1. Turn the ignition switch OFF to ON.
2. Shift the A/T shift selector P position.
3. Perform self-diagnosis for "ALL MODE AWD/4WD".

Is DTC "P1816" detected?

- YES >> Proceed to diagnosis procedure. Refer to [DLN-72, "Diagnosis Procedure"](#).
NO >> INSPECTION END

Diagnosis Procedure

INFOID:0000000010262236

1.PERFORM TCM SELF-DIAGNOSIS

With CONSULT

Perform self-diagnosis for "TRANSMISSION".

Is any DTCs detected?

- YES >> Check the DTC. Refer to [TM-81, "DTC Index"](#).
NO >> GO TO 2.

2.CHECK TERMINALS AND HARNESS CONNECTORS

Check transfer control unit pin terminals for damage or loose connection with harness connector.

Is inspection result normal?

- YES >> After turning the ignition switch OFF, perform DTC confirmation procedure again. When DTC "P1816" is detected, Replace transfer control unit. Refer to [DLN-112, "Removal and Installation"](#).
NO >> Repair or replace error-detected parts.

P1817 TRANSFER MOTOR

< DTC/CIRCUIT DIAGNOSIS >

[TRANSFER: ATX90A]

P1817 TRANSFER MOTOR

DTC Logic

INFOID:0000000010262237

DTC DETECTION LOGIC

DTC	Display item	Malfunction detected condition	Possible cause
P1817	SHIFT ACTUATOR	Malfunction is detected in transfer motor.	Transfer control actuator • Transfer motor error • malfunction of transfer motor circuit

DTC CONFIRMATION PROCEDURE

1.PRECONDITIONING

If "DTC CONFIRMATION PROCEDURE" has been previously conducted, always turn ignition switch OFF and wait at least 10 seconds before conducting the next test.

>> GO TO 2.

2.DTC REPRODUCTION PROCEDURE

With CONSULT

1. Turn the ignition switch OFF to ON.
2. Turn the 4WD shift switch AUTO⇒4H⇒4L⇒4H⇒AUTO.
3. Perform self-diagnosis for "ALL MODE AWD/4WD".

Is DTC "P1817" detected?

- YES >> Proceed to diagnosis procedure. Refer to [DLN-73, "Diagnosis Procedure"](#).
NO >> INSPECTION END

Diagnosis Procedure

INFOID:0000000010262238

1.CHECK TRANSFER MOTOR CIRCUIT (1)

1. Turn the ignition switch OFF.
2. Disconnect transfer control unit harness connector.
3. Check the continuity between transfer control unit harness connector and transfer control actuator harness connector.

Transfer control unit		Transfer control actuator		Continuity
Connector	Terminal	Connector	Terminal	
E60	45	F52	8	Existed
	43		1	

4. Check the continuity between transfer control unit harness connector and ground.

Transfer control unit		—	Continuity
Connector	Terminal		
E60	45	Ground	Not existed
	43		

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Repair or replace error-detected parts.

2.CHECK TRANSFER MOTOR

Check the transfer control actuator. Refer to [DLN-74, "Component Inspection"](#).

Is the inspection result normal?

- YES >> GO TO 3.

P1817 TRANSFER MOTOR

< DTC/CIRCUIT DIAGNOSIS >

[TRANSFER: ATX90A]

NO >> Transfer motor is malfunctioning. Replace transfer control actuator. Refer to [DLN-119, "Removal and Installation"](#).

3.CHECK TRANSFER INTERNAL FUNCTION

With CONSULT

1. Remove transfer control actuator. Refer to [DLN-119, "Removal and Installation"](#).
2. Turn the actuator shaft. Refer to [DLN-119, "Inspection"](#).
3. Check "ROTARY POSI SEN" of CONSULT "DATA MONITOR" for "ALL MODE AWD/4WD".

Monitor item	Condition	Status
ROTARY POSI SEN	Turn the actuator shaft.	Value is changing

Is the inspection result normal?

YES >> GO TO 4.

NO >> Transfer assembly is mechanical malfunction. Replace transfer assembly. Refer to [DLN-127, "Removal and Installation"](#).

4.CHECK TERMINALS AND HARNESS CONNECTORS

Check the pin terminals for damage or loose connection with each harness connector.

Is the inspection result normal?

YES >> Replace transfer control unit. Refer to [DLN-112, "Removal and Installation"](#).

NO >> Repair or replace error-detected parts.

Component Inspection

INFOID:0000000010262239

1.CHECK TRANSFER MOTOR

1. Remove transfer control actuator. Refer to [DLN-119, "Removal and Installation"](#).
2. Apply 12 V to transfer control actuator connector No. 1 terminal and No. 8 terminal.

CAUTION:

- **Never make the terminals short.**
- **Connect the fuse between the terminals when applying the voltage.**

3. Check the operation of transfer control actuator.

Transfer control actuator		Condition	Operation
Terminal			
1	8	Apply the voltage between No. 1 (+) terminal and No. 8 (–) terminal.	Operate clockwise
		Apply the voltage between No. 1 (–) terminal and No. 8 (+) terminal.	Operate counter-clockwise

Is the inspection result normal?

YES >> INSPECTION END

NO >> Replace transfer control actuator. Refer to [DLN-119, "Removal and Installation"](#).

P181A TRANSFER MOTOR TEMPERATURE SENSOR

< DTC/CIRCUIT DIAGNOSIS >

[TRANSFER: ATX90A]

P181A TRANSFER MOTOR TEMPERATURE SENSOR

DTC Logic

INFOID:0000000010262240

DTC DETECTION LOGIC

DTC	Display item	Malfunction detected condition	Possible cause
P181A	MOTOR TEMP SEN	When vehicle speed is 40 km/h or more and transfer motor temperature is lower than normal	Transfer control actuator • Malfunction of transfer motor temperature sensor circuit. (open)
		When transfer motor temperature is higher than normal	Transfer control actuator • Malfunction of transfer motor temperature sensor circuit. (short)

DTC CONFIRMATION PROCEDURE

1. PRECONDITIONING

If "DTC CONFIRMATION PROCEDURE" has been previously conducted, always turn ignition switch OFF and wait at least 10 seconds before conducting the next test.

>> GO TO 2.

2. DTC REPRODUCTION PROCEDURE

With CONSULT

1. Start the engine and drive at 40 km/h (25 MPH) or more for approximately 1 minute.
2. Perform self-diagnosis for "ALL MODE AWD/4WD".

Is DTC "P181A" detected?

- YES >> Proceed to diagnosis procedure. Refer to [DLN-75, "Diagnosis Procedure"](#).
NO >> INSPECTION END

Diagnosis Procedure

INFOID:0000000010262241

1. CHECK TRANSFER MOTOR TEMPERATURE SENSOR POWER SUPPLY

1. Turn the ignition switch OFF.
2. Disconnect transfer control actuator harness connector.
3. Turn the ignition switch ON.
CAUTION:
Never start the engine.
4. Check the voltage between transfer control actuator harness connector terminals.

+		-	Voltage
Transfer control actuator			
Connector	Terminal		
F52	4	7	Approx. 5 V

Is the inspection result normal?

- YES >> GO TO 3.
NO >> GO TO 2.

2. CHECK TRANSFER MOTOR TEMPERATURE SENSOR CIRCUIT

1. Turn the ignition switch OFF.
2. Disconnect transfer control unit harness connector.
3. Check the continuity between transfer control unit harness connector and transfer control actuator harness connector.

P181A TRANSFER MOTOR TEMPERATURE SENSOR

< DTC/CIRCUIT DIAGNOSIS >

[TRANSFER: ATX90A]

Transfer control unit		Transfer control actuator		Continuity
Connector	Terminal	Connector	Terminal	
E59	28	F52	4	Existed
	9		7	

4. Check the continuity between transfer control actuator harness connector and ground.

Transfer control actuator		—	Continuity
Connector	Terminal		
F52	7	Ground	Not existed

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair or replace error-detected parts.

3.CHECK TRANSFER MOTOR TEMPERATURE SENSOR

Check the transfer control actuator. Refer to [DLN-76, "Component Inspection"](#).

Is the inspection result normal?

YES >> GO TO 4.

NO >> Transfer motor temperature sensor is malfunctioning. Replace transfer control actuator. Refer to [DLN-119, "Removal and Installation"](#).

4.CHECK TERMINALS AND HARNESS CONNECTORS

Check the pin terminals for damage or loose connection with each harness connector.

Is the inspection result normal?

YES >> Replace transfer control unit. Refer to [DLN-112, "Removal and Installation"](#).

NO >> Repair or replace error-detected parts.

Component Inspection

INFOID:0000000010262242

1.CHECK TRANSFER MOTOR TEMPERATURE SENSOR

1. Turn the ignition switch OFF.
2. Disconnect transfer control actuator harness connector.
3. Check the resistance between transfer control actuator harness connector terminals.

Transfer control actuator		Condition	Resistance
Terminal			
4	7	20°C (68°F)	Approx. 12.5 kΩ
		80°C (176°F)	Approx. 1.3 kΩ

Is the inspection result normal?

YES >> INSPECTION END

NO >> Transfer motor temperature sensor is malfunctioning. Replace transfer control actuator. Refer to [DLN-119, "Removal and Installation"](#).

P181B INCOMPLETE SELF SHUT

< DTC/CIRCUIT DIAGNOSIS >

[TRANSFER: ATX90A]

P181B INCOMPLETE SELF SHUT

DTC Logic

INFOID:0000000010262243

DTC DETECTION LOGIC

DTC	Display item	Malfunction detected condition	Possible cause
P181B	IMCOMP SELF SHUT	When ignition switch is OFF and transfer control unit power supply is lower or higher than normal	Self-shut is incomplete.

DTC CONFIRMATION PROCEDURE

1. PRECONDITIONING

If "DTC CONFIRMATION PROCEDURE" has been previously conducted, always turn ignition switch OFF and wait at least 10 seconds before conducting the next test.

>> GO TO 2.

2. DTC REPRODUCTION PROCEDURE

With CONSULT

- Turn the ignition switch OFF.
- Perform self-diagnosis for "ALL MODE AWD/4WD".

Is DTC "P181B" detected?

- YES >> Proceed to diagnosis procedure. Refer to [DLN-77, "Diagnosis Procedure"](#).
NO >> INSPECTION END

Diagnosis Procedure

INFOID:0000000010262244

1. CHECK TRANSFER CONTROL UNIT POWER SUPPLY (1)

- Turn the ignition switch OFF.
- Disconnect transfer control unit harness connector.
- Check the voltage between transfer control unit harness connector and ground.

Transfer control unit		—	Voltage
Connector	Terminal		
E59	20	Ground	Battery voltage

- Turn the ignition switch ON.
CAUTION:
Never start the engine.
- Check the voltage between transfer control unit harness connector and ground.

Transfer control unit		—	Voltage
Connector	Terminal		
E59	20	Ground	Battery voltage

Is the inspection result normal?

- YES >> GO TO 3.
NO >> GO TO 2.

2. CHECK TRANSFER CONTROL UNIT POWER SUPPLY (2)

- Turn the ignition switch OFF.
- Check the 10A fuse (#34).
- Check the harness for open or short between transfer control unit harness connector No.20 terminal and 10A (#34).

Is the inspection result normal?

P181B INCOMPLETE SELF SHUT

< DTC/CIRCUIT DIAGNOSIS >

[TRANSFER: ATX90A]

- YES >> Perform the trouble diagnosis for power supply circuit. Refer to [PG-12, "Wiring Diagram - BATTERY POWER SUPPLY -"](#).
- NO >> Repair or replace error-detected parts.

3. CHECK TRANSFER CONTROL UNIT GROUND

1. Turn the ignition switch OFF.
2. Check the continuity between transfer control unit harness connector and ground.

Transfer control unit		—	Continuity
Connector	Terminal		
E60	44	Ground	Existed
	46		

Is the inspection result normal?

- YES >> GO TO 4.
- NO >> Repair or replace error-detected parts.

4. CHECK TERMINALS AND HARNESS CONNECTORS

Check transfer control unit pin terminals for damage or loose connection with harness connector.

Is inspection result normal?

- YES >> After turning the ignition switch OFF, perform DTC confirmation procedure again. When DTC "P181B" is detected, Replace transfer control unit. Refer to [DLN-112, "Removal and Installation"](#).
- NO >> Repair or replace error-detected parts.

P181C TRANSFER MOTOR POWER SUPPLY

< DTC/CIRCUIT DIAGNOSIS >

[TRANSFER: ATX90A]

P181C TRANSFER MOTOR POWER SUPPLY

Description

INFOID:0000000010262245

Supplies power to transfer control actuator (transfer motor).

DTC Logic

INFOID:0000000010262246

DTC DETECTION LOGIC

DTC	Display item	Malfunction detected condition	Possible cause
P181C	MOTOR POWER SUPPLY	When transfer control actuator power supply is lower or higher than normal	Malfunction of transfer control actuator (transfer motor) power supply circuit

DLN

DTC CONFIRMATION PROCEDURE

1.PRECONDITIONING

If "DTC CONFIRMATION PROCEDURE" has been previously conducted, always turn ignition switch OFF and wait at least 10 seconds before conducting the next test.

>> GO TO 2.

2.DTC REPRODUCTION PROCEDURE

With CONSULT

- Turn the ignition switch OFF to ON.
- Perform self-diagnosis for "ALL MODE AWD/4WD".

Is DTC "P181C" detected?

- YES >> Proceed to diagnosis procedure. Refer to [DLN-79, "Diagnosis Procedure"](#).
NO >> INSPECTION END

Diagnosis Procedure

INFOID:0000000010262247

1.CHECK TRANSFER MOTOR POWER SUPPLY (2)

Check the voltage between transfer control unit harness connector and ground.

+		-	Voltage
Transfer control unit			
Connector	Terminal		
E60	41	46	Battery voltage

Is the inspection result normal?

- YES >> GO TO 3.
NO >> GO TO 2.

2.CHECK TRANSFER MOTOR POWER SUPPLY CIRCUIT (2)

- Turn the ignition switch OFF.
- Check the 30A fusible link (J).
- Check the harness for open or short between transfer control unit harness connector No.41 terminal and 30A fusible link (J).

Is the inspection result normal?

- YES >> Perform the trouble diagnosis for power supply circuit. Refer to [PG-12, "Wiring Diagram - BATTERY POWER SUPPLY -"](#).
NO >> Repair or replace error-detected parts.

3.CHECK TERMINALS AND HARNESS CONNECTORS

Check the pin terminals for damage or loose connection with each harness connector.

Is the inspection result normal?

P181C TRANSFER MOTOR POWER SUPPLY

< DTC/CIRCUIT DIAGNOSIS >

[TRANSFER: ATX90A]

-
- YES >> Replace transfer control unit. Refer to [DLN-112, "Removal and Installation"](#).
NO >> Repair or replace error-detected parts.

P181E STEERING ANGLE SENSOR

< DTC/CIRCUIT DIAGNOSIS >

[TRANSFER: ATX90A]

P181E STEERING ANGLE SENSOR

DTC Logic

INFOID:0000000010262248

DTC DETECTION LOGIC

DTC	Display item	Malfunction detected condition	Possible cause
P181E	ST ANGLE SEN SIG	Malfunction is detected in steering angle sensor signal through CAN communication.	• Harness or connector (CAN communication line) • Steering angle sensor - Steering angle sensor error - Malfunction of steering angle sensor circuit error

DTC CONFIRMATION PROCEDURE

1.PRECONDITIONING

If "DTC CONFIRMATION PROCEDURE" has been previously conducted, always turn ignition switch OFF and wait at least 10 seconds before conducting the next test.

>> GO TO 2.

2.DTC REPRODUCTION PROCEDURE

With CONSULT

1. Turn the ignition switch OFF to ON.
2. Perform self-diagnosis for "ALL MODE AWD/4WD".

Is DTC "P181E" detected?

- YES >> Proceed to diagnosis procedure. Refer to [DLN-81, "Diagnosis Procedure"](#).
NO >> INSPECTION END

Diagnosis Procedure

INFOID:0000000010262249

1.PERFORM ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT) SELF-DIAGNOSIS

With CONSULT

Perform self-diagnosis for "ABS".

Is DTC "C1143" detected?

- YES >> Proceed to diagnosis procedure. Refer to [BRC-104, "Diagnosis Procedure"](#).
NO >> GO TO 2.

2.CHECK TERMINALS AND HARNESS CONNECTORS

Check transfer control unit pin terminals for damage or loose connection with harness connector.

Is inspection result normal?

- YES >> After turning the ignition switch OFF, perform DTC confirmation procedure again. If DTC "P181E" is detected, replace transfer control unit. Refer to [DLN-112, "Removal and Installation"](#).
NO >> Repair or replace error-detected parts.

P181F INCOMPLETE CALIBRATION

< DTC/CIRCUIT DIAGNOSIS >

[TRANSFER: ATX90A]

P181F INCOMPLETE CALIBRATION

DTC Logic

INFOID:0000000010262250

DTC DETECTION LOGIC

DTC	Display item	Malfunction detected condition	Possible cause
P181F	INCOMP CALIBRATION	When incomplete calibration of transfer control unit is detected.	Initial calibration of transfer is incomplete

DTC CONFIRMATION PROCEDURE

1. PRECONDITIONING

If "DTC CONFIRMATION PROCEDURE" has been previously conducted, always turn ignition switch OFF and wait at least 10 seconds before conducting the next test.

>> GO TO 2.

2. DTC REPRODUCTION PROCEDURE

With CONSULT

1. Turn the ignition switch OFF to ON.
2. Perform self-diagnosis for "ALL MODE AWD/4WD".

Is DTC "P181F" detected?

- YES >> Proceed to diagnosis procedure. Refer to [DLN-82. "Diagnosis Procedure"](#).
NO >> INSPECTION END

Diagnosis Procedure

INFOID:0000000010262251

1. PERFORM INITIAL CALIBRATION

1. Erase self-diagnostic result for "ALL MODE AWD/4WD".
2. Perform initial calibration. Refer to [DLN-42. "Work Procedure"](#).
3. Perform self-diagnosis for "ALL MODE AWD/4WD".

Is any DTC except "P181F" detected?

- YES >> Check DTC.
NO >> GO TO 2.

2. PERFORM SELF-DIAGNOSIS

With CONSULT

1. Erase self-diagnostic result for "ALL MODE AWD/4WD".
2. Turn the ignition switch OFF, and then wait 10 seconds or more.
3. Perform self-diagnosis for "ALL MODE AWD/4WD".

Is DTC "P181F" detected?

- YES >> Replace transfer control unit. Refer to [DLN-112. "Removal and Installation"](#).
NO >> Check transfer control unit pin terminals for damage or loose connection with harness connector.
If any items are damaged, repair or replace the error-detected parts.

P1820 ENGINE SPEED SIGNAL

< DTC/CIRCUIT DIAGNOSIS >

[TRANSFER: ATX90A]

P1820 ENGINE SPEED SIGNAL

DTC Logic

INFOID:0000000010262252

DTC DETECTION LOGIC

DTC	Display item	Malfunction detected condition	Possible cause
P1820	ENGINE SPEED SIG	Malfunction is detected in engine speed signal that is output from ECM through CAN communication.	• Harness or connector (CAN communication line) • Internal malfunction of ECM

DTC CONFIRMATION PROCEDURE

1.PRECONDITIONING

If "DTC CONFIRMATION PROCEDURE" has been previously conducted, always turn ignition switch OFF and wait at least 10 seconds before conducting the next test.

>> GO TO 2.

2.DTC REPRODUCTION PROCEDURE

With CONSULT

1. Start the engine and drive at 20 km/h (12 MPH) or more.
2. Perform self-diagnosis for "ALL MODE AWD/4WD".

Is DTC "P1820" detected?

- YES >> Proceed to diagnosis procedure. Refer to [DLN-83, "Diagnosis Procedure"](#).
NO >> INSPECTION END

Diagnosis Procedure

INFOID:0000000010262253

1.PERFORM ECM SELF-DIAGNOSIS

With CONSULT

Perform self-diagnosis for "ENGINE".

Is any DTCs detected?

- YES >> Check the DTC.
 - For USA and Canada: Refer to [EC-108, "DTC Index"](#).
 - For Mexico: Refer to [EC-671, "DTC Index"](#).
NO >> GO TO 2.

2.CHECK TERMINALS AND HARNESS CONNECTORS

Check transfer control unit pin terminals for damage or loose connection with harness connector.

Is inspection result normal?

- YES >> After turning the ignition switch OFF, perform DTC confirmation procedure again. When DTC "P1820" is detected, Replace transfer control unit. Refer to [DLN-112, "Removal and Installation"](#).
NO >> Repair or replace error-detected parts.

P1826 TRANSFER FLUID TEMPERATURE

< DTC/CIRCUIT DIAGNOSIS >

[TRANSFER: ATX90A]

P1826 TRANSFER FLUID TEMPERATURE

DTC Logic

INFOID:000000010262254

DTC DETECTION LOGIC

DTC	Display item	Malfunction detected condition	Possible cause
P1826	OIL TEMP SEN	When vehicle speed is 40 km/h or more and transfer fluid temperature is lower than normal	Transfer fluid temperature Malfunction of transfer fluid temperature sensor circuit (open)
		When transfer fluid temperature is higher than normal	Transfer fluid temperature Malfunction of transfer fluid temperature sensor circuit (short)

DTC CONFIRMATION PROCEDURE

1. PRECONDITIONING

If "DTC CONFIRMATION PROCEDURE" has been previously conducted, always turn ignition switch OFF and wait at least 10 seconds before conducting the next test.

>> GO TO 2.

2. DTC REPRODUCTION PROCEDURE

With CONSULT

- Start the engine and drive at 40 km/h (25 MPH) or more for approximately 1 minute.
- Perform self-diagnosis for "ALL MODE AWD/4WD".

Is DTC "P1826" detected?

YES >> Proceed to diagnosis procedure. Refer to [DLN-84, "Diagnosis Procedure"](#).

NO >> INSPECTION END

Diagnosis Procedure

INFOID:000000010262255

1. CHECK TRANSFER FLUID TEMPERATURE SENSOR POWER SUPPLY

- Turn the ignition switch OFF.
- Disconnect transfer fluid temperature sensor harness connector.
- Turn the ignition switch ON.
CAUTION:
Never start the engine.
- Check the voltage between transfer fluid temperature sensor harness connector terminals.

+		-	Voltage
Transfer fluid temperature sensor			
Connector	Terminal		
F37	2	1	Approx. 5 V

Is the inspection result normal?

YES >> GO TO 3.

NO >> GO TO 2.

2. CHECK TRANSFER FLUID TEMPERATURE SENSOR CIRCUIT

- Turn the ignition switch OFF.
- Disconnect transfer control unit harness connector.
- Check the continuity between transfer control unit harness connector and transfer control actuator harness connector.

P1826 TRANSFER FLUID TEMPERATURE

< DTC/CIRCUIT DIAGNOSIS >

[TRANSFER: ATX90A]

Transfer control unit		Transfer fluid temperature sensor		Continuity
Connector	Terminal	Connector	Terminal	
E59	7	F37	2	Existed
	36		1	

4. Check the continuity between transfer fluid temperature sensor harness connector and ground.

Transfer fluid temperature sensor		—	Continuity
Connector	Terminal		
F37	2	Ground	Not existed

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair or replace error-detected parts.

3.CHECK TRANSFER FLUID TEMPERATURE SENSOR

Check the transfer fluid temperature sensor. Refer to [DLN-85, "Component Inspection"](#).

Is the inspection result normal?

YES >> GO TO 4.

NO >> Replace transfer fluid temperature sensor. Refer to [DLN-126, "Removal and Installation"](#).

4.CHECK TERMINALS AND HARNESS CONNECTORS

Check the pin terminals for damage or loose connection with each harness connector.

Is the inspection result normal?

YES >> Replace transfer control unit. Refer to [DLN-112, "Removal and Installation"](#).

NO >> Repair or replace error-detected parts.

Component Inspection

INFOID:0000000010262256

1.CHECK TRANSFER FLUID TEMPERATURE SENSOR

1. Turn the ignition switch OFF.
2. Disconnect transfer fluid temperature sensor harness connector.
3. Check the resistance between transfer control fluid temperature sensor connector terminals.

Transfer fluid temperature sensor		Condition	Resistance
Terminal			
2	1	20°C (68°F)	Approx. 2.5 kΩ
		80°C (176°F)	Approx. 0.3 kΩ

Is the inspection result normal?

YES >> INSPECTION END

NO >> Replace transfer fluid temperature sensor. Refer to [DLN-126, "Removal and Installation"](#).

P1829 ACCELERATOR PEDAL POSITION SENSOR

< DTC/CIRCUIT DIAGNOSIS >

[TRANSFER: ATX90A]

P1829 ACCELERATOR PEDAL POSITION SENSOR

DTC Logic

INFOID:0000000010262257

DTC DETECTION LOGIC

DTC	Display item	Malfunction detected condition	Possible cause
P1829	THROTTLE POSI SEN	Malfunction is detected in accelerator pedal position signal that is output from ECM through CAN communication.	• Harness or connector (CAN communication line) • Internal malfunction of ECM

DTC CONFIRMATION PROCEDURE

1.PRECONDITIONING

If "DTC CONFIRMATION PROCEDURE" has been previously conducted, always turn ignition switch OFF and wait at least 10 seconds before conducting the next test.

>> GO TO 2.

2.DTC REPRODUCTION PROCEDURE

With CONSULT

1. Start the engine and drive at 30 km/h (19 MPH) or more.
2. Perform self-diagnosis for "ALL MODE AWD/4WD".

Is DTC "P1829" detected?

- YES >> Proceed to diagnosis procedure. Refer to [DLN-86, "Diagnosis Procedure"](#).
NO >> INSPECTION END

Diagnosis Procedure

INFOID:0000000010262258

1.PERFORM ECM SELF-DIAGNOSIS

With CONSULT

Perform self-diagnosis for "ENGINE".

Is any DTCs detected?

- YES >> Check the DTC.
 - For USA and Canada: Refer to [EC-108, "DTC Index"](#).
 - For Mexico: Refer to [EC-671, "DTC Index"](#).
NO >> GO TO 2.

2.CHECK TERMINALS AND HARNESS CONNECTORS

Check transfer control unit pin terminals for damage or loose connection with harness connector.

Is inspection result normal?

- YES >> After turning the ignition switch OFF, perform DTC confirmation procedure again. When DTC "P1829" is detected, Replace transfer control unit. Refer to [DLN-112, "Removal and Installation"](#).
NO >> Repair or replace error-detected parts.

P182A TRANSFER HI-LO POSITION SENSOR

< DTC/CIRCUIT DIAGNOSIS >

[TRANSFER: ATX90A]

P182A TRANSFER HI-LO POSITION SENSOR

DTC Logic

INFOID:0000000010262259

DTC DETECTION LOGIC

DTC	Display item	Malfunction detected condition	Possible cause
P182A	HI-LO POSITION SEN	Malfunction related to transfer Hi-Lo position sensor has been detected.	Internal malfunction of transfer Hi-Lo position sensor

DTC CONFIRMATION PROCEDURE

1. PRECONDITIONING

If "DTC CONFIRMATION PROCEDURE" has been previously conducted, always turn ignition switch OFF and wait at least 10 seconds before conducting the next test.

>> GO TO 2.

2. DTC REPRODUCTION PROCEDURE

With CONSULT

1. Start the engine.

CAUTION:

Never drive the vehicle.

2. Turn the 4WD shift switch AUTO⇒4H⇒4L⇒4H⇒AUTO.
3. Drive at 20 km/h (12 MPH) or more for 1 minute or more.
4. Perform self-diagnosis for "ALL MODE AWD/4WD".

Is DTC "P182A" detected?

- YES >> Proceed to diagnosis procedure. Refer to [DLN-87, "Diagnosis Procedure"](#).
NO >> INSPECTION END

Diagnosis Procedure

INFOID:0000000010262260

1. CHECK TRANSFER HI-LO POSITION SENSOR SIGNAL

1. Turn the ignition switch ON.

CAUTION:

Never start the engine.

2. Check the voltage between transfer control unit harness connector and ground.

+		–	Condition	Voltage
Transfer control unit				
Connector	Terminal			
E59	6	Ground	4WD mode: AUTO or 4H	Approx. 0 V
			4WD mode: 4L	Approx. 5 V
	25		4WD mode: AUTO or 4H	Approx. 0 V
			4WD mode: 4L	Approx. 5 V

CAUTION:

After operating 4WD shift switch, move the vehicle back and forth to check voltage.

Is the inspection result normal?

- YES >> GO TO 5.
NO >> GO TO 2.

2. CHECK TRANSFER HI-LO POSITION SENSOR POWER SUPPLY

1. Turn the ignition switch OFF.
2. Disconnect transfer Hi-Lo position sensor harness connector.
3. Turn the ignition switch ON.

P182A TRANSFER HI-LO POSITION SENSOR

< DTC/CIRCUIT DIAGNOSIS >

[TRANSFER: ATX90A]

CAUTION:

Never start the engine.

4. Check the voltage between transfer Hi-Lo position sensor harness connector terminals.

+		-	Voltage
Transfer Hi-Lo position sensor			
Connector	Terminal	Ground	Approx. 5 V
F42	1		
	2		

Is the inspection result normal?

YES >> GO TO 4.

NO >> GO TO 3.

3.CHECK TRANSFER HI-LO POSITION SENSOR CIRCUIT

1. Turn the ignition switch OFF.
2. Disconnect transfer control unit harness connector.
3. Check the continuity between transfer control unit harness connector and transfer Hi-Lo position sensor harness connector.

Transfer control unit		Transfer Hi-Lo position sensor		Continuity
Connector	Terminal	Connector	Terminal	
E59	6	F42	1	Existed
	25		2	
	29		3	

4. Check the continuity between transfer Hi-Lo position sensor harness connector and ground.

Transfer Hi-Lo position sensor		—	Continuity
Connector	Terminal		
F42	1	Ground	Not existed
	2		
	3		

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair or replace error-detected parts.

4.REPLACE TRANSFER HI-LO POSITION SENSOR

1. Replace transfer Hi-Lo position sensor. Refer to [DLN-121, "Removal and Installation"](#).
2. Perform confirmation procedure again. Refer to [DLN-87, "DTC Logic"](#).

Is DTC "P182A" detected?

YES >> GO TO 5.

NO >> INSPECTION END

5.CHECK TERMINALS AND HARNESS CONNECTORS

Check the pin terminals for damage or loose connection with each harness connector.

Is the inspection result normal?

YES >> Replace transfer control unit. Refer to [DLN-112, "Removal and Installation"](#).

NO >> Repair or replace error-detected parts.

P182B TRANSFER LOCK POSITION SENSOR

< DTC/CIRCUIT DIAGNOSIS >

[TRANSFER: ATX90A]

P182B TRANSFER LOCK POSITION SENSOR

DTC Logic

INFOID:0000000010262261

DTC DETECTION LOGIC

DTC	Display item	Malfunction detected condition	Possible cause
P182B	Lock POSITION SEN	Malfunction related to transfer lock position sensor has been detected.	- Transfer lock position sensor - Transfer lock position sensor error - Malfunction of transfer lock position sensor circuit

A

B

C

DLN

DTC CONFIRMATION PROCEDURE

1.PRECONDITIONING

If "DTC CONFIRMATION PROCEDURE" has been previously conducted, always turn ignition switch OFF and wait at least 10 seconds before conducting the next test.

>> GO TO 2.

2.DTC REPRODUCTION PROCEDURE

With CONSULT

- Turn the ignition switch OFF to ON.
- Turn the 4WD shift switch AUTO⇒4H⇒4L⇒4H⇒AUTO.
- Perform self-diagnosis for "ALL MODE AWD/4WD".

Is DTC "P182B" detected?

- YES >> Proceed to diagnosis procedure. Refer to [DLN-89, "Diagnosis Procedure"](#).
NO >> INSPECTION END

Diagnosis Procedure

INFOID:0000000010262262

1.CHECK TRANSFER LOCK POSITION SENSOR

With CONSULT

- Start the engine.
- Turn the 4WD shift switch AUTO⇒4H⇒4L⇒4H⇒AUTO.
- Check "LOCK POSI SEN" of CONSULT "DATA MONITOR" for "ALL MODE AWD/4WD".

Monitor item	Condition	Status
LOCK POSI SEN	4WD shift switch: AUTO or 4H	OPEN
	4WD shift switch: 4L	LOCK
	When transfer lock position sensor is unlearned.	UNLEAN
	When the temperature of transfer lock position sensor is high.	HI TEMP
	When transfer lock position sensor is malfunctioning.	ERROR
	When transfer lock position sensor signal circuit is short. (Battery short)	BAT
	When transfer lock position sensor signal circuit is short. (Ground short)	GND

What is the item on "DATA MONITOR"?

- OPEN >> GO TO 7.
LOCK >> GO TO 7.
UNLEAN>>GO TO 6.
HI TEMP>>GO TO 5.
ERROR>>GO TO 5.
BAT >> GO TO 2.

E

F

G

H

I

J

K

L

M

N

O

P

P182B TRANSFER LOCK POSITION SENSOR

< DTC/CIRCUIT DIAGNOSIS >

[TRANSFER: ATX90A]

GND >> GO TO 2.

2.CHECK TRANSFER LOCK POSITION POWER SUPPLY

1. Turn the ignition switch OFF.
2. Disconnect transfer position sensor harness connector.
3. Turn the ignition switch ON.

CAUTION:

Never start the engine.

4. Check the voltage between transfer position sensor harness connector terminals.

+		-	Voltage
Transfer lock position sensor			
Connector	Terminal		
F40	1	2	Approx. 5 V

Is the inspection result normal?

YES >> GO TO 4.

NO >> GO TO 3.

3.CHECK TRANSFER LOCK POSITION SENSOR POWER SUPPLY CIRCUIT

1. Turn the ignition switch OFF.
2. Disconnect transfer control unit harness connector.
3. Check the continuity between transfer control unit harness connector and transfer lock position sensor harness connector.

Transfer control unit		Transfer lock position sensor		Continuity
Connector	Terminal	Connector	Terminal	
E59	17	F40	1	Existed
	30		2	

4. Check the continuity between transfer lock position harness connector and ground.

Transfer lock position sensor		-	Continuity
Connector	Terminal		
F40	1	Ground	Not existed

Is the inspection result normal?

YES >> GO TO 7.

NO >> Repair or replace error-detected parts.

4.CHECK TRANSFER LOCK POSITION SENSOR SIGNAL CIRCUIT

1. Turn the ignition switch OFF.
2. Disconnect transfer control unit harness connector.
3. Check the continuity between transfer control unit harness connector and transfer lock position sensor harness connector.

Transfer control unit		Transfer lock position sensor		Continuity
Connector	Terminal	Connector	Terminal	
E59	38	F40	3	Existed

4. Check the continuity between transfer lock position harness connector and ground.

Transfer lock position sensor		-	Continuity
Connector	Terminal		
F40	3	Ground	Not existed

Is the inspection result normal?

P182B TRANSFER LOCK POSITION SENSOR

< DTC/CIRCUIT DIAGNOSIS >

[TRANSFER: ATX90A]

- YES >> GO TO 5.
NO >> Repair or replace error-detected parts.

5.REPLACE TRANSFER LOCK POSITION SENSOR

1. Replace transfer lock position sensor. Refer to [DLN-124, "Removal and Installation"](#).
2. Perform confirmation procedure again. Refer to [DLN-89, "DTC Logic"](#).

Is the inspection result normal?

- YES >> INSPECTION END
NO >> GO TO 7.

6.PERFORM LEARNING OF TRANSFER LOCK POSITION SENSOR

Transfer lock position sensor. Refer to [DLN-45, "Work Procedure"](#).

>> GO TO 7.

7.CHECK TERMINALS AND HARNESS CONNECTORS

Check the pin terminals for damage or loose connection with each harness connector.

Is the inspection result normal?

- YES >> Replace transfer control unit. Refer to [DLN-112, "Removal and Installation"](#).
NO >> Repair or replace error-detected parts.

A
B
C
DLN
E
F
G
H
I
J
K
L
M
N
O
P

P1830 ABS OPERATION SIGNAL

< DTC/CIRCUIT DIAGNOSIS >

[TRANSFER: ATX90A]

P1830 ABS OPERATION SIGNAL

DTC Logic

INFOID:0000000010262263

DTC DETECTION LOGIC

DTC	Display item	Malfunction detected condition	Possible cause
P1830	ABS OP SIG	Malfunction is detected in ABS operation signal that is output from ABS actuator and electric unit (control unit) through CAN communication.	Malfunction of ABS system

DTC CONFIRMATION PROCEDURE

1. PRECONDITIONING

If "DTC CONFIRMATION PROCEDURE" has been previously conducted, always turn ignition switch OFF and wait at least 10 seconds before conducting the next test.

>> GO TO 2.

2. DTC REPRODUCTION PROCEDURE

With CONSULT

1. Start the engine and drive at 30 km/h (19 MPH) or more.
2. Perform self-diagnosis for "ALL MODE AWD/4WD".

Is DTC "P1830" detected?

- YES >> Proceed to diagnosis procedure. Refer to [DLN-92, "Diagnosis Procedure"](#).
NO >> INSPECTION END

Diagnosis Procedure

INFOID:0000000010262264

1. PERFORM ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT) SELF-DIAGNOSIS

With CONSULT

Perform self-diagnosis for "ABS".

Is any DTCs detected?

- YES >> Check the DTC. Refer to [BRC-50, "DTC Index"](#).
NO >> GO TO 2.

2. CHECK TERMINALS AND HARNESS CONNECTORS

Check transfer control unit pin terminals for damage or loose connection with harness connector.

Is inspection result normal?

- YES >> After turning the ignition switch OFF, perform DTC confirmation procedure again. When DTC "P1830" is detected, Replace transfer control unit. Refer to [DLN-112, "Removal and Installation"](#).
NO >> Repair or replace error-detected parts.

P1831 VDC OPERATION SIGNAL

< DTC/CIRCUIT DIAGNOSIS >

[TRANSFER: ATX90A]

P1831 VDC OPERATION SIGNAL

DTC Logic

INFOID:0000000010262265

DTC DETECTION LOGIC

DTC	Display item	Malfunction detected condition	Possible cause
P1831	VDC OP SIG	Malfunction is detected in VDC operation signal that is output from ABS actuator and electric unit (control unit) through CAN communication.	Malfunction of VDC system

DTC CONFIRMATION PROCEDURE

1. PRECONDITIONING

If "DTC CONFIRMATION PROCEDURE" has been previously conducted, always turn ignition switch OFF and wait at least 10 seconds before conducting the next test.

>> GO TO 2.

2. DTC REPRODUCTION PROCEDURE

With CONSULT

1. Start the engine and drive at 30 km/h (19 MPH) or more.
2. Perform self-diagnosis for "ALL MODE AWD/4WD".

Is DTC "P1831" detected?

- YES >> Proceed to diagnosis procedure. Refer to [DLN-93, "Diagnosis Procedure"](#).
NO >> INSPECTION END

Diagnosis Procedure

INFOID:0000000010262266

1. PERFORM ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT) SELF-DIAGNOSIS

With CONSULT

Perform self-diagnosis for "ABS".

Is any DTCs detected?

- YES >> Check the DTC. Refer to [BRC-50, "DTC Index"](#).
NO >> GO TO 2.

2. CHECK TERMINALS AND HARNESS CONNECTORS

Check transfer control unit pin terminals for damage or loose connection with harness connector.

Is inspection result normal?

- YES >> After turning the ignition switch OFF, perform DTC confirmation procedure again. When DTC "P1831" is detected, Replace transfer control unit. Refer to [DLN-112, "Removal and Installation"](#).
NO >> Repair or replace error-detected parts.

P1832 TCS OPERATION SIGNAL

< DTC/CIRCUIT DIAGNOSIS >

[TRANSFER: ATX90A]

P1832 TCS OPERATION SIGNAL

DTC Logic

INFOID:0000000010262267

DTC DETECTION LOGIC

DTC	Display item	Malfunction detected condition	Possible cause
P1832	TCS OP SIG	Malfunction is detected in TCS operation signal that is output from ABS actuator and electric unit (control unit) through CAN communication.	Malfunction of TCS system

DTC CONFIRMATION PROCEDURE

1. PRECONDITIONING

If "DTC CONFIRMATION PROCEDURE" has been previously conducted, always turn ignition switch OFF and wait at least 10 seconds before conducting the next test.

>> GO TO 2.

2. DTC REPRODUCTION PROCEDURE

With CONSULT

1. Start the engine and drive at 30 km/h (19 MPH) or more.
2. Perform self-diagnosis for "ALL MODE AWD/4WD".

Is DTC "P1832" detected?

- YES >> Proceed to diagnosis procedure. Refer to [DLN-94, "Diagnosis Procedure"](#).
NO >> INSPECTION END

Diagnosis Procedure

INFOID:0000000010262268

1. PERFORM ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT) SELF-DIAGNOSIS

With CONSULT

Perform self-diagnosis for "ABS".

Is any DTCs detected?

- YES >> Check the DTC. Refer to [BRC-50, "DTC Index"](#).
NO >> GO TO 2.

2. CHECK TERMINALS AND HARNESS CONNECTORS

Check transfer control unit pin terminals for damage or loose connection with harness connector.

Is inspection result normal?

- YES >> After turning the ignition switch OFF, perform DTC confirmation procedure again. When DTC "P1832" is detected, Replace transfer control unit. Refer to [DLN-112, "Removal and Installation"](#).
NO >> Repair or replace error-detected parts.

U1000 CAN COMM CIRCUIT

Description

INFOID:0000000010262269

CAN (Controller Area Network) is a serial communication line for real time application. It is an on-vehicle multiplex communication line with high data communication speed and excellent error detection ability. Many electronic control units are equipped onto a vehicle, and each control unit shares information and links with other control units during operation (not independent). In CAN communication, control units are connected with 2 communication lines (CAN-H line, CAN-L line) allowing a high rate of information transmission with less wiring. Each control unit communicate data but selectively reads required data only.

DTC Logic

INFOID:0000000010262270

DTC DETECTION LOGIC

DTC	Display item	Malfunction detected condition	Possible cause
U1000	CAN COMM CIRCUIT	Transfer control unit is not transmitting/receiving CAN communication signal for 2 seconds or more.	- CAN communication error - Malfunction of transfer control unit

DTC CONFIRMATION PROCEDURE

1. PRECONDITIONING

If "DTC CONFIRMATION PROCEDURE" has been previously conducted, always turn ignition switch OFF and wait at least 10 seconds before conducting the next test.

>> GO TO 2.

2. DTC REPRODUCTION PROCEDURE

With CONSULT

- Turn the ignition switch OFF to ON.
- Perform self-diagnosis for "ALL MODE AWD/4WD".

Is DTC "U1000" detected?

- YES >> Proceed to diagnosis procedure. Refer to [DLN-95, "Diagnosis Procedure"](#).
 NO >> INSPECTION END

Diagnosis Procedure

INFOID:0000000010262271

Proceed to [LAN-21, "Trouble Diagnosis Flow Chart"](#).

U1010 CONTROL UNIT (CAN)

Description

INFOID:0000000010262272

CAN (Controller Area Network) is a serial communication line for real time application. It is an on-vehicle multiplex communication line with high data communication speed and excellent error detection ability. Many electronic control units are equipped onto a vehicle, and each control unit shares information and links with other control units during operation (not independent). In CAN communication, control units are connected with 2 communication lines (CAN-H line, CAN-L line) allowing a high rate of information transmission with less wiring. Each control unit communicate data but selectively reads required data only.

DTC Logic

INFOID:0000000010262273

DTC DETECTION LOGIC

DTC	Display item	Malfunction detected condition	Possible cause
U1010	CONTROL UNIT (CAN)	Detecting error during the initial diagnosis of CAN controller of transfer control unit.	Malfunction of transfer control unit

DTC CONFIRMATION PROCEDURE

1. PRECONDITIONING

If "DTC CONFIRMATION PROCEDURE" has been previously conducted, always turn ignition switch OFF and wait at least 10 seconds before conducting the next test.

>> GO TO 2.

2. DTC REPRODUCTION PROCEDURE

With CONSULT

- Turn the ignition switch OFF to ON.
- Perform self-diagnosis for "ALL MODE AWD/4WD".

Is DTC "U1010" detected?

- YES >> Proceed to diagnosis procedure. Refer to [DLN-96, "Diagnosis Procedure"](#).
 NO >> INSPECTION END

Diagnosis Procedure

INFOID:0000000010262274

1. CHECK TRANSFER CONTROL UNIT

Check transfer control unit harness connector for disconnection and deformation.

Is the inspection result normal?

- YES >> Replace transfer control unit. Refer to [DLN-112, "Removal and Installation"](#).
 NO >> Repair or replace error-detected parts.

POWER SUPPLY AND GROUND CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[TRANSFER: ATX90A]

POWER SUPPLY AND GROUND CIRCUIT

Description

INFOID:0000000010262275

Supplies power to 4WD system.

Diagnosis Procedure

INFOID:0000000010262276

1.CHECK TRANSFER CONTROL UNIT POWER SUPPLY (1)

1. Turn the ignition switch OFF.
2. Disconnect transfer control unit harness connector.
3. Check the voltage between transfer control unit harness connector and ground.

Transfer control unit		—	Voltage
Connector	Terminal		
E59	20	Ground	Battery voltage

4. Turn the ignition switch ON.
CAUTION:
Never start the engine.
5. Check the voltage between transfer control unit harness connector and ground.

Transfer control unit		—	Voltage
Connector	Terminal		
E59	20	Ground	Battery voltage

Is the inspection result normal?

- YES >> GO TO 3.
NO >> GO TO 2.

2.CHECK TRANSFER CONTROL UNIT POWER SUPPLY (2)

1. Turn the ignition switch OFF.
2. Check the 10A fuse (#34).
3. Check the harness for open or short between transfer control unit harness connector No.20 terminal and 10A (#34).

Is the inspection result normal?

- YES >> Perform the trouble diagnosis for power supply circuit. Refer to [PG-12, "Wiring Diagram - BATTERY POWER SUPPLY -"](#).
- NO >> Repair or replace error-detected parts.

3.CHECK TRANSFER CONTROL UNIT POWER SUPPLY (3)

1. Turn the ignition switch OFF.
2. Check the voltage between transfer control unit harness connector and ground.

Transfer control unit		—	Voltage
Connector	Terminal		
E59	32	Ground	Approx. 0 V

3. Turn the ignition switch ON.
CAUTION:
Never start the engine.
4. Check the voltage between transfer control unit harness connector and ground.

Transfer control unit		—	Voltage
Connector	Terminal		
E59	32	Ground	Battery voltage

POWER SUPPLY AND GROUND CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[TRANSFER: ATX90A]

Is the inspection result normal?

- YES >> GO TO 5.
NO >> GO TO 4.

4.CHECK TRANSFER CONTROL UNIT POWER SUPPLY (4)

1. Turn the ignition switch OFF.
2. Check the 10A fuse (#56).
3. Disconnect IPDM E/R harness connector.
4. Check the continuity between transfer control unit harness connector and IPDM E/R harness connector.

IPDM E/R		Transfer control unit		Continuity
Connector	Terminal	Connector	Terminal	
E15	58	E59	32	Existed

5. Check the continuity between transfer control unit harness connector and the ground.

Transfer control unit		—	Continuity
Connector	Terminal		
E59	32	Ground	Not existed

Is the inspection result normal?

- YES >> Perform the trouble diagnosis for ignition power supply circuit. Refer to [PG-60, "Wiring Diagram - IGNITION POWER SUPPLY -"](#).
NO >> Repair or replace error-detected parts.

5.CHECK TRANSFER MOTOR POWER SUPPLY

1. Turn the ignition switch OFF.
2. Check the voltage between transfer control unit harness connector and ground.

Transfer control unit		—	Voltage
Connector	Terminal		
E60	41	Ground	Battery voltage

3. Turn the ignition switch ON.

CAUTION:

Never start the engine.

4. Check the voltage between transfer control unit harness connector and ground.

Transfer control unit		—	Voltage
Connector	Terminal		
E60	41	Ground	Battery voltage

Is the inspection result normal?

- YES >> GO TO 7.
NO >> GO TO 6.

6.CHECK TRANSFER MOTOR POWER SUPPLY CIRCUIT

1. Turn the ignition switch OFF.
2. Check the 30A fusible link (J).
3. Check the harness for open or short between transfer control unit harness connector No.41 terminal and 30A fusible link (J).

Is the inspection result normal?

- YES >> Perform the trouble diagnosis for power supply circuit. Refer to [PG-12, "Wiring Diagram - BATTERY POWER SUPPLY -"](#).
NO >> Repair or replace error-detected parts.

7.CHECK 4WD SWITCH ASSEMBLY POWER SUPPLY (1)

1. Turn the ignition switch OFF.

POWER SUPPLY AND GROUND CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[TRANSFER: ATX90A]

2. Disconnect 4WD switch assembly harness connector.
3. Check the voltage between 4WD switch assembly harness connector and ground.

4WD switch assembly		—	Voltage
Connector	Terminal		
M54	12	Ground	Approx. 0 V

4. Turn the ignition switch ON.

CAUTION:

Never start the engine.

5. Check the voltage between 4WD switch assembly harness connector and ground.

4WD switch assembly		—	Voltage
Connector	Terminal		
M54	12	Ground	Battery voltage

Is the inspection result normal?

YES >> GO TO 9.

NO >> GO TO 8.

8.CHECK 4WD SWITCH ASSEMBLY POWER SUPPLY (2)

1. Turn the ignition switch OFF.
2. Check the 10A fuse (#13).
3. Disconnect fuse block (J/B) harness connector.
4. Check the continuity between transfer control unit harness connector and IPDM E/R harness connector.

Fuse block (J/B)		4WD switch assembly		Continuity
Connector	Terminal	Connector	Terminal	
M3	10C	M54	12	Existed

5. Check the continuity between transfer control unit harness connector and the ground.

4WD switch assembly		—	Continuity
Connector	Terminal		
M54	12	Ground	Not existed

Is the inspection result normal?

YES >> Perform the trouble diagnosis for ignition power supply circuit. Refer to [PG-60, "Wiring Diagram - IGNITION POWER SUPPLY -"](#).

NO >> Repair or replace error-detected parts.

9.CHECK TRANSFER CONTROL UNIT GROUND

1. Turn the ignition switch OFF.
2. Check the voltage between transfer control unit harness connector and ground.

Transfer control unit		—	Voltage
Connector	Terminal		
E60	44	Ground	Approx. 0 V
	46		

3. Check the continuity between transfer control unit harness connector and ground.

Transfer control unit		—	Continuity
Connector	Terminal		
E60	44	Ground	Existed
	46		

POWER SUPPLY AND GROUND CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[TRANSFER: ATX90A]

Is the inspection result normal?

YES >> GO TO 10.

NO >> Repair or replace error-detected parts.

10.CHECK 4WD SWITCH ASSEMBLY GROUND

1. Turn the ignition switch OFF.
2. Check the voltage between transfer control unit harness connector and ground.

4WD switch assembly		—	Voltage
Connector	Terminal		
M54	20	Ground	Approx. 0 V

Is the inspection result normal?

YES >> INSPECTION END

NO >> Repair or replace error-detected parts.

4WD WARNING LAMP

Component Function Check

INFOID:0000000110262277

1.CHECK 4WD WARNING LAMP FUNCTION

1. Turn the ignition switch OFF to ON.
2. Check that 4WD warning lamp light up.

Is the inspection result normal?

- YES >> INSPECTION END
 NO >> Proceed diagnosis procedure. Refer to [DLN-101, "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:0000000110262278

1.CHECK POWER SUPPLY AND GROUND CIRCUIT

Perform the trouble diagnosis for power supply and ground circuit. Refer to [DLN-66, "Diagnosis Procedure"](#).

Is the inspection result normal?

- YES >> GO TO 2.
 NO >> Repair or replace the error-detected parts.

2.PERFORM SELF-DIAGNOSIS

With CONSULT

Perform self-diagnosis for "ALL MODE AWD/4WD".

Is any DTC detected?

- YES >> Check the DTC. Refer to [DLN-30, "DTC Index"](#).
 NO >> GO TO 3.

3.CHECK 4WD WARNING LAMP SIGNAL

With CONSULT

1. Turn the ignition switch ON.

CAUTION:

Never start the engine.

2. Check "4WD FAIL LAMP" of CONSULT "DATA MONITOR" for "ALL MODE AWD/4WD".

Does the item on "DATA MONITOR" indicate "On"?

- YES >> Check combination meter. Refer to [MWI-67, "COMBINATION METER : Diagnosis Procedure"](#).
 NO >> Replace transfer control unit. Refer to [DLN-112, "Removal and Installation"](#).

A

B

C

DLN

E

F

G

H

I

J

K

L

M

N

O

P

4WD INDICATOR LAMP

Component Function Check

INFOID:000000010262279

1.CHECK 4WD MODE INDICATOR LAMP FUNCTION

1. Start the engine

CAUTION:

Never drive the vehicle.

2. Turn the 4WD shift switch AUTO⇒4H⇒4L⇒4H⇒AUTO.
3. Check the 4WD shift switch position ("AUTO", "4H" and "4L") and the indication of the 4WD mode indicator lamp mutually coincide.

Is the inspection result normal?

YES >> INSPECTION END

NO >> Proceed to diagnosis procedure. Refer to [DLN-102, "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:000000010262280

1.CHECK POWER SUPPLY AND GROUND CIRCUIT

Perform the trouble diagnosis for power supply and ground circuit. Refer to [DLN-66, "Diagnosis Procedure"](#).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace the error-detected parts.

2.CHECK 4WD WARNING LAMP SIGNAL

With CONSULT

1. Start the engine.

CAUTION:

Never drive the vehicle.

2. Turn the 4WD shift switch AUTO⇒4H⇒4L⇒4H⇒AUTO.
3. Check "4WD MODE IND" of CONSULT "DATA MONITOR" for "ALL MODE AWD/4WD".

Monitor item	Condition	Status
4WD MODE IND	4WD shift switch: AUTO	AUTO
	4WD shift switch: 4H	4H
	4WD shift switch: 4L	4L

Is the inspection result normal?

YES >> Check combination meter. Refer to [MWI-67, "COMBINATION METER : Diagnosis Procedure"](#).

NO >> Replace transfer control unit. Refer to [DLN-112, "Removal and Installation"](#).

HEAVY TIGHT-CORNER BRAKING SYMPTOM OCCURS

< SYMPTOM DIAGNOSIS >

[TRANSFER: ATX90A]

SYMPTOM DIAGNOSIS

HEAVY TIGHT-CORNER BRAKING SYMPTOM OCCURS

Description

INFOID:0000000010262281

Heavy tight-corner braking symptom occurs when the vehicle is driven and the steering wheel is turned fully to either side after the engine is started.

NOTE:

Light tight-corner braking symptom may occur depending on driving conditions. This is not malfunction.

Diagnosis Procedure

INFOID:0000000010262282

1.PERFORM ECM SELF-DIAGNOSIS

With CONSULT

Perform self-diagnosis for "ECM".

Is any DTC detected?

YES >> Check the DTC.

- For USA and Canada: Refer to [EC-108, "DTC Index"](#).
- For Mexico: Refer to [EC-671, "DTC Index"](#).

NO >> GO TO 2.

2.PERFORM SELF-DIAGNOSIS

With CONSULT

Perform self-diagnosis for "ALL MODE AWD/4WD".

Is any DTC detected?

YES >> Check the DTC. Refer to [DLN-30, "DTC Index"](#).

NO >> GO TO 3.

3.CHECK TRANSFER INTERNAL FUNCTION

With CONSULT

1. Remove transfer control actuator. Refer to [DLN-119, "Removal and Installation"](#).
2. Turn the actuator shaft. Refer to [DLN-119, "Inspection"](#).
3. Check "ROTARY POSI SEN" of CONSULT "DATA MONITOR" for "ALL MODE AWD/4WD".

Monitor item	Condition	Status
ROTARY POSI SEN	Turn the actuator shaft.	Value is changing

Is the inspection result normal?

YES >> INSPECTION END

NO >> Transfer assembly is mechanical malfunction. Replace transfer assembly. Refer to [DLN-127, "Removal and Installation"](#).

4WD MODE DOES NOT CHANGE

< SYMPTOM DIAGNOSIS >

[TRANSFER: ATX90A]

4WD MODE DOES NOT CHANGE

Description

INFOID:0000000010262283

Vehicle does not enter 4-wheel drive mode even though 4WD warning lamp turned to OFF.

Diagnosis Procedure

INFOID:0000000010262284

1.PERFORM SELF-DIAGNOSIS

With CONSULT

Perform self-diagnosis for "ALL MODE AWD/4WD".

Is any DTC detected?

YES >> Check DTC. Refer to [DLN-30, "DTC Index"](#).

NO >> GO TO 2.

2.CHECK 4WD MODE INDICATOR LAMP

Check 4WD mode indicator lamp function. Refer to [DLN-102, "Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 3.

NO >> Proceed to diagnosis procedure. Refer to [DLN-102, "Diagnosis Procedure"](#).

3.CHECK 4WD SHIFT SWITCH

Perform rouble diagnosis of the 4WD shift switch. Refer to [DLN-69, "Diagnosis Procedure"](#).

Is the inspection result normal?

YES >> Transfer assembly is mechanical malfunction. Replace transfer assembly. Refer to [DLN-127, "Removal and Installation"](#).

NO >> Replace 4WD switch assembly. Refer to [DLN-113, "Removal and Installation"](#).

4WD MODE INDICATOR LAMP CONTINUES BLINKING

< SYMPTOM DIAGNOSIS >

[TRANSFER: ATX90A]

4WD MODE INDICATOR LAMP CONTINUES BLINKING

Description

INFOID:0000000110262285

After shift the 4WD mode 4H to 4L, 4WD mode indicator lamp continues to blink.

Diagnosis Procedure

INFOID:0000000110262286

1.MOVE THE VEHICLE

Move the vehicle back and forth.

Does the 4WD indicator lamp stop to blink?

- YES >> INSPECTION END
- NO >> GO TO 2.

2.CHECK 4WD MODE INDICATOR LAMP

Check 4WD mode indicator lamp function. Refer to [DLN-102. "Component Function Check"](#).

Is the inspection result normal?

- YES >> GO TO 3.
- NO >> Proceed to diagnosis procedure. Refer to [DLN-102. "Diagnosis Procedure"](#).

3.PERFORM SELF-DIAGNOSIS

With CONSULT

Perform self-diagnosis for "ALL MODE AWD/4WD".

Is any DTC detected?

- YES >> Check DTC. Refer to [DLN-30. "DTC Index"](#).
- NO >> Transfer assembly is mechanical malfunction. Replace transfer assembly. Refer to [DLN-127. "Removal and Installation"](#).

A
B
C
DLN
E
F
G
H
I
J
K
L
M
N
O
P

4WD WARNING LAMP BLINKS QUICKLY

< SYMPTOM DIAGNOSIS >

[TRANSFER: ATX90A]

4WD WARNING LAMP BLINKS QUICKLY

Description

INFOID:0000000010262287

While driving, 4WD warning lamp blinks 2 times in 1 second and it turns OFF after 1 minute.

- This symptom protects drivetrain parts when a heavy load is applied to the electric controlled coupling and multiple disc clutch temperature increases. Also, optional distribution of torque sometimes becomes rigid before lamp blinks quickly. Both cases are not malfunction.
- When this symptom occurs, stop vehicle and allow it to idle for some times. Blinking will stop and system will be restored.

4WD WARNING LAMP BLINKS SLOWLY

< SYMPTOM DIAGNOSIS >

[TRANSFER: ATX90A]

4WD WARNING LAMP BLINKS SLOWLY

Description

INFOID:0000000110262288

4WD warning lamp blinks at approximately 2 seconds intervals while driving.

Diagnosis Procedure

INFOID:0000000110262289

1.CHECK TIRE

Check the following.

- Tire pressure
- Wear condition
- Front and rear tire size (There is no difference between front and rear tires.)

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace error-detected parts. And then, drive the vehicle at speed of 20 km/h (12 MPH) or more for 5 seconds or more. Improper size information is initialized accordingly.

2.TERMINAL INSPECTION

Check 4WD control unit harness connector for disconnection.

Is the inspection result normal?

YES >> Replace transfer control unit. Refer to [DLN-112. "Removal and Installation"](#).

NO >> Repair or replace the error-detected parts.

A
B
C
DLN
E
F
G
H
I
J
K
L
M
N
O
P

INFORMATION DISPLAY IS NOT DISPLAYED

Description

INFOID:0000000010262290

Information display is not displayed.

NOTE:

When the combination meter receives 4WD shift switch signal, it displays a message on the information display and inform the driver of 4WD mode status. About indication contents, refer to [DLN-19, "4WD SYSTEM : System Description"](#) (4WD mode).

Diagnosis Procedure

INFOID:0000000010262291

1.CHECK 4WD SHIFT SWITCH

Perform trouble diagnosis for 4WD shift switch. Refer to [DLN-69, "Diagnosis Procedure"](#).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace error-detected parts.

2.CHECK 4WD MODE INDICATOR LAMP

Perform trouble diagnosis for 4WD mode indicator. Refer to [DLN-102, "Diagnosis Procedure"](#).

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace error-detected parts.

3.CHECK THE INFORMATION DISPLAY

Check that information except 4WD mode is displayed on information display.

Is the inspection result normal?

YES >> Replace transfer control unit. Refer to [DLN-112, "Removal and Installation"](#).

NO >> Check information display. Refer to [MWI-30, "On Board Diagnosis Function"](#).

NOISE, VIBRATION AND HARSHNESS (NVH) TROUBLESHOOTING

< SYMPTOM DIAGNOSIS >

[TRANSFER: ATX90A]

NOISE, VIBRATION AND HARSHNESS (NVH) TROUBLESHOOTING

NVH Troubleshooting Chart

INFOID:0000000110262292

Use the chart below to find the cause of the symptom. The numbers indicate the order of the inspection. If necessary, repair or replace these parts.

Reference		DLN-110. "Inspection"				Front oil seal: DLN-114. "Exploded View" Rear oil seal: DLN-116. "Exploded View"			
SUSPECTED PARTS (Possible cause)		TRANSFER FLUID (Level low)	TRANSFER FLUID (Wrong)	TRANSFER FLUID (Level too high)	LIQUID GASKET (Damaged)	OIL SEAL (Worn or damaged)	GEAR (Worn or damaged)	BEARING (Worn or damaged)	TRANSFER CASE (Damaged)
Symptom	Noise	1	2				3	3	3
	Transfer fluid leakage		4	1	2	2			3

PERIODIC MAINTENANCE

TRANSFER FLUID

Inspection

INFOID:0000000010262293

FLUID LEAKAGE

Check transfer surrounding area (oil seal, drain plug, and filler plug etc.) for fluid leakage.

FLUID LEVEL

1. Remove filler plug (1) and gasket. Then check that fluid is filled up from mounting hole for the filler plug.

CAUTION:


Never start engine while checking fluid level.

2. Set a new gasket onto filler plug, and install it on transfer and then tighten to the specified torque.

Specified torque : 48 N·m (4.9 kg-m, 35 ft-lb)

CAUTION:

Never reuse gasket.



JPDIE0295ZZ

Draining


INFOID:0000000010262294

1. Run the vehicle to warm up the transfer unit sufficiently.
2. Stop the engine.
3. Remove the drain plug (1) and drain transfer fluid.
4. Set a new gasket onto drain plug, and install it to transfer and tighten to the specified torque.

Specified torque : 48 N·m (4.9 kg-m, 35 ft-lb)

CAUTION:

Never reuse gasket.



JPDIE0245ZZ

Refilling

INFOID:0000000010262295

1. Remove filler plug (1). Fill up with new transfer fluid up to mounting hole for the filler plug.


Fluid grade and Viscosity : Refer to [MA-15, "FOR NORTH AMERICA : Fluids and Lubricants"](#) (for NORTH AMERICA), [MA-16, "FOR MEXICO : Fluids and Lubricants"](#) (for MEXICO).

Fluid capacity : Refer to [DLN-131, "General Specifications"](#).

CAUTION:

Carefully fill the fluid. (Fill up for approximately 3 minutes.)

2. Leave the vehicle for 3 minutes, and check the fluid level again.
3. Set a new gasket onto filler plug, and install it on transfer and tighten to the specified torque.



JPDIE0295ZZ

TRANSFER FLUID

< PERIODIC MAINTENANCE >

[TRANSFER: ATX90A]

Specified torque : 48 N·m (4.9 kg-m, 35 ft-lb)

CAUTION:
Never reuse gasket.

- 4. Perform learning of transfer fluid viscosity. Refer to [DLN-48, "Work Procedure"](#).

A
B
C
DLN
E
F
G
H
I
J
K
L
M
N
O
P

REMOVAL AND INSTALLATION

TRANSFER CONTROL UNIT

Removal and Installation

INFOID:0000000010262296

REMOVAL

1. Turn the ignition switch OFF.
2. Disconnect negative battery terminal.
CAUTION:
Wait for 5 seconds after turning ignition switch OFF.
3. Remove the glove box assembly. Refer to [JP-14, "Removal and Installation"](#).
4. Disconnect the transfer control unit connector.
5. Move instrument lower cover to backward. Refer to [JP-14, "Removal and Installation"](#).
6. Remove the transfer control unit.

INSTALLATION

Note the following, and install in the reverse order of removal.

- When replacing transfer control unit, perform writing unit parameter and initial calibration. Refer to [DLN-42, "Work Procedure"](#).

4WD MODE SWITCH

Removal and Installation

INFOID:0000000010262297

REMOVAL

NOTE:

4WD shift switch is integrated in 4WD switch assembly.

1. Remove console finisher assembly from center console assembly. Refer to [JP-25, "Removal and Installation"](#)
2. Disconnect 4WD switch assembly harness connector.
3. Press 4WD switch assembly fixing pawls, and remove 4WD switch assembly from console finisher assembly.

INSTALLATION

Install in the reverse order of removal.

A
B
C
DLN
E
F
G
H
I
J
K
L
M
N
O
P

FRONT OIL SEAL

< REMOVAL AND INSTALLATION >

[TRANSFER: ATX90A]

1. Install front oil seal with a drift (A) (commercial service tool) within the dimension (L) shown as follows.

When the dust shield is resin type:

L : 5.3 – 5.7 mm (0.209 – 0.224 in)

When the dust shield is metal type:

L : 4.8 – 5.2 mm (0.189 – 0.205 in)

CAUTION:

- **Never reuse front oil seal.**
- **Apply transfer fluid onto circumference of oil seal.**

2. Install the dust shield to the front shaft flange.
3. Install the front shaft flange.
4. Install the snap ring.

CAUTION:


Never reuse the snap ring.

5. Install the O-ring to plug.

CAUTION:

- **Never reuse the O-ring.**
- **Never damage the O-ring.**

6. Tighten the plug to specified torque.
7. Install front propeller shaft. Refer to [DLN-137, "Removal and Installation"](#).
8. Fill with new transfer fluid, check fluid level and for fluid leakage. Refer to [DLN-110, "Inspection"](#).



A

B

C

DLN

E

F

G

H

I

J

K

L

M

N


O

P

REAR OIL SEAL

Exploded View

INFOID:000000010262300



- | | | |
|--------------------------|-------------------|------------------|
| 1. Snap ring | 2. Adjusting shim | 3. O-ring |
| 4. Rear companion flange | 5. Dust shield | 6. Rear oil seal |
| 7. Transfer assembly | | |

↶: Vehicle front

Apply transfer fluid. Refer to [MA-15, "FOR NORTH AMERICA : Fluids and Lubricants"](#) (for NORTH AMERICA), [MA-16, "FOR MEXICO : Fluids and Lubricants"](#) (for MEXICO).


Refer to [GI-4, "Components"](#) for symbols not described above.

Removal and Installation

INFOID:000000010262301

REMOVAL

- Remove the rear propeller shaft. Refer to [DLN-146, "Removal and Installation"](#).
- Put matching marks (A) on the end of the main shaft and the rear companion flange.
- CAUTION:**
For matching mark, using paint. Never damage main shaft.
- Remove the snap ring.
- Remove the adjusting shim.
- Remove the rear companion flange, using a plastic hammer.




- Remove the dust shield from rear companion flange, using the drift, puller and replacer.

- | | |
|---|---------------------------------------|
| A | : Drift [SST: ST30701000 (J-25742-2)] |
| B | : Puller (commercial service tool) |
| C | : Replacer (commercial service tool) |

- Remove the o-ring from rear companion flange.
- Remove the rear oil seal from rear case.

CAUTION:
Never damage rear case and main shaft.



REAR OIL SEAL

< REMOVAL AND INSTALLATION >

[TRANSFER: ATX90A]

INSTALLATION


1. Install rear oil seal, with a drift (A) [SST: KV40104710 (—)] within the dimension (L) show as follows.

L : 2.8 – 3.2 (0.110 – 0.126 in)

CAUTION:

- Never reuse front oil seal.
- Apply transfer fluid onto circumference of oil seal.


2. Install the dust shield to the rear companion flange.




3. Install the rear companion flange to main shaft.

CAUTION:

- Align the matching marks (A) of main shaft and rear companion flange.



- Install bolt (A) (M12×1.75 mm) to main shaft, then install the rear companion flange by hammering while pulling the bolt.




4. Install the O-ring (3) to gap between rear companion flange (1) and main shaft (2).

CAUTION:

- Never reuse the O-ring.
- Never damage the O-ring.

5. Select adjusting shim. Refer to [DLN-117, "Adjustment"](#).
6. Install adjusting shim.
7. Install the snap ring.
8. Install the rear propeller shaft. Refer to [DLN-146, "Removal and Installation"](#).
9. Check fluid level and for fluid leakage. Refer to [DLN-110, "Inspection"](#).



Adjustment

INFOID:0000000010262302

ADJUSTING SHIM


1. Remove the snap ring.
2. Remove the adjusting shim.

REAR OIL SEAL

< REMOVAL AND INSTALLATION >

[TRANSFER: ATX90A]

3. Remove the O-ring.
4. Install the thinnest adjusting shim.
5. Install the snap ring to main shaft.
6. Install the bolt (A) (M12×1.75 mm) to main shaft, then hammer the rear companion flange while pulling the bolt.



7. Fit a dial indicator onto the end of main shaft.
8. Check the clearance between rear companion flange and main shaft during pushing the bolt (A) at ← direction.
9. Use the formula below to calculate adjusting shim thickness.


Shim selection equation:

$$T = T_0 + (C - 0.1)$$

T: Correct shim thickness

T₀: The thinnest shim thickness

C: Measured clearance between rear companion flange and main shaft



CAUTION:

Adjusting shim thickness is in step of 0.1 mm. When a calculation result includes the second decimal place, it must be rounded down.

Example:

$$T = 2.1 + (0.34 - 0.1) = 2.34$$

T₀: 2.1

C: 0.34

Calculated value... T = 2.34 mm

Used shim... T = 2.3 mm

10. Select the proper adjusting shim. For selecting adjusting shim, refer to the latest parts information.

TRANSFER CONTROL ACTUATOR


< REMOVAL AND INSTALLATION >

[TRANSFER: ATX90A]

TRANSFER CONTROL ACTUATOR

Exploded View

INFOID:0000000010262303



1. Transfer assembly

2. Transfer control actuator

⇐: Vehicle front

Refer to [GI-4, "Components"](#) for symbols not described above.

Removal and Installation

INFOID:0000000010262304

REMOVAL

CAUTION:

If DTC about transfer control actuator is detected, perform inspection after removal.

1. Turn the ignition switch OFF.
2. Disconnect negative battery terminal.
CAUTION:
Wait for 5 seconds after turning ignition switch OFF.
3. Disconnect the transfer control actuator connector.
4. Remove the bolts and detach the transfer control actuator.
5. Perform inspection after removal. Refer to [DLN-119, "Inspection"](#).

INSTALLATION

Note the following, and installing the reverse order of removal.

- Never damage oil seal of transfer motor.
- If transfer control actuator has been replaced, perform writing the unit parameter. Refer to [DLN-49, "Work Procedure"](#)
- Perform inspection after installation. Refer to [DLN-119, "Inspection"](#)

Inspection

INFOID:0000000010262305

INSPECTION AFTER REMOVAL

1. Check the oil seal assembled transfer control actuator for wear, crack and damage. Replace if there is malfunction.
2. Check the transfer assembly as follows.

TRANSFER CONTROL ACTUATOR

< REMOVAL AND INSTALLATION >


[TRANSFER: ATX90A]

- Install the spline socket (A) [SST: KV10119400 (—)] to transfer assembly in the figure.
- When turn the shaft in (B) direction, check returning to (C) direction by spring power.

CAUTION:

The maximum turning force shall be 30 N·m (3.1 kg-m, 22 ft-lb).

- When turn the shaft in (C) direction, check locking the shaft.



INSPECTION AFTER INSTALLATION

After driving, check the surface fitting transfer control actuator to transfer assembly for fluid leakage.

TRANSFER HI-LO POSITION SENSOR


< REMOVAL AND INSTALLATION >

[TRANSFER: ATX90A]

TRANSFER HI-LO POSITION SENSOR

Exploded View

INFOID:0000000010262306



1. Transfer Hi-Lo position sensor
2. Transfer assembly

⇐: Vehicle front

Refer to [GI-4, "Components"](#) for symbols not described above.

Removal and Installation

INFOID:0000000010262307

REMOVAL

1. Turn the ignition switch OFF.
2. Disconnect negative battery terminal.
CAUTION:
Wait for 5 seconds after turning ignition switch OFF.
3. Remove exhaust front tube (LH). Refer to [EX-5, "Removal and Installation"](#).
4. Support transfer assembly and transmission assembly with a jack.
5. Remove front suspension rear cross member with a power tool. Refer to [TM-217, "4WD : Removal and Installation"](#).
6. Remove rear engine mounting cross member with a power tool. Refer to [TM-217, "4WD : Removal and Installation"](#).
7. Remove heat insulator of exhaust front tube (LH).
8. Lower jack to the position where the transfer Hi-Lo position sensor can be removed.
9. Disconnect the transfer Hi-Lo position sensor connector.
10. Remove the transfer Hi-Lo position sensor.
11. Perform inspection after removal. Refer to [DLN-121, "Inspection"](#).

INSTALLATION

Note the following, and install in the reverse order of removal.

- Never damage O-ring of transfer Hi-Lo position sensor.
- Perform inspection after installation. Refer to [DLN-121, "Inspection"](#).

Inspection

INFOID:0000000010262308

INSPECTION AFTER REMOVAL

Check the O-ring assembled transfer Hi-Lo position sensor for wear, crack and damage. Replace the transfer Hi-Lo position sensor if there is malfunction.

INSPECTION AFTER INSTALLATION

After driving, check the surface fitting transfer Hi-Lo position sensor to transfer assembly for fluid leakage.

TRANSFER ROTARY POSITION SENSOR


< REMOVAL AND INSTALLATION >

[TRANSFER: ATX90A]

TRANSFER ROTARY POSITION SENSOR

Exploded View

INFOID:000000010262309



1. Transfer assembly
2. Transfer rotary position sensor

↔: Vehicle front

Refer to [GI-4, "Components"](#) for symbols not described above.

Removal and Installation

INFOID:000000010262310

REMOVAL


1. Turn the ignition switch OFF.
2. Disconnect negative battery terminal.
CAUTION:
Wait for 5 seconds after turning ignition switch OFF.
3. Support transfer assembly and transmission assembly with a jack.
4. Remove front suspension rear cross member with a power tool. Refer to [TM-217, "4WD : Removal and Installation"](#).
5. Remove rear engine mounting cross member with a power tool. Refer to [TM-217, "4WD : Removal and Installation"](#).
6. Disconnect the transfer rotary position sensor connector.
7. Remove the transfer rotary position sensor.
8. Perform inspection after removal. Refer to [DLN-123, "Inspection"](#).

INSTALLATION

1. Remove the transfer control actuator. Refer to [DLN-119, "Exploded View"](#)
2. Shift transfer assembly into AUTO as follows.
 - a. Install the spline socket (A) [SST: KV10119400 (—)] to transfer assembly in the figure.
 - b. Turn the shaft (B) direction and remove the spline socket at a position returning to (C) direction by spring power.

CAUTION:

The maximum turning force shall be 30 N·m (3.1 kg-m, 22 ft-lb).




TRANSFER ROTARY POSITION SENSOR

< REMOVAL AND INSTALLATION >

[TRANSFER: ATX90A]

- c. Check that the surface fitting transfer rotary position sensor to transfer assembly is in the figure.

↶: Vehicle front




3. Install the transfer rotary position sensor.

CAUTION:

- Check that part (A) of transfer rotary position sensor is in the position (B).
- Never damage O-ring of transfer rotary position sensor.

4. Connect transfer rotary position sensor connector.
5. Install the transfer control actuator. Refer to [DLN-119, "Exploded View"](#).
6. Perform inspection after installation. Refer to [DLN-123, "Inspection"](#).
7. When replacing the transfer rotary position sensor, perform learning of transfer rotary position sensor. Refer to [DLN-47, "Work Procedure"](#).



Inspection

INFOID:0000000010262311

INSPECTION AFTER REMOVAL

Check the O-ring assembled transfer rotary position sensor for wear, crack and damage. Replace the transfer rotary position sensor if there is malfunction.

INSPECTION AFTER INSTALLATION

After driving, check the surface fitting transfer rotary position sensor to transfer assembly for fluid leakage.

TRANSFER LOCK POSITION SENSOR


< REMOVAL AND INSTALLATION >

[TRANSFER: ATX90A]

TRANSFER LOCK POSITION SENSOR

Exploded View

INFOID:000000010262312



1. Transfer lock position sensor
2. Transfer assembly

⇐: Vehicle front

Refer to [GI-4, "Components"](#) for symbols not described above.

Removal and Installation

INFOID:000000010262313

REMOVAL

1. Shift the transmission to the neutral position, and release the parking brake.
2. Turn the ignition switch OFF.
3. Disconnect negative battery terminal.
CAUTION:
Wait for 5 seconds after turning ignition OFF.
4. Support transfer assembly and transmission assembly with a jack.
5. Remove the front propeller shaft assembly fixing bolts from transfer companion flange. Refer to [DLN-137, "Removal and Installation"](#).
CAUTION:
Put matching marks on front propeller shaft flange yoke and transfer companion flange.
NOTE:
It is not necessary to remove the propeller shaft fixing bolts from front final drive companion flange.
6. Remove the rear propeller shaft assembly fixing bolts from transfer companion flange. Refer to [DLN-146, "Removal and Installation"](#).
CAUTION:
Put matching marks on rear propeller shaft flange yoke and transfer companion flange.
NOTE:
It is not necessary to remove the propeller shaft fixing bolts from rear final drive companion flange.
7. Remove rear engine mounting cross member with a power tool. Refer to [TM-217, "4WD : Removal and Installation"](#).
8. Lower jack to the position where the transfer lock position sensor can be removed.
9. Disconnect the transfer lock position sensor connector.
10. Remove the transfer lock position sensor.
11. Perform inspection after removal. Refer to [DLN-125, "Inspection"](#).

INSTALLATION

Note the following, and install in the reverse order of removal.

- Never damage O-ring of transfer lock position sensor.

TRANSFER LOCK POSITION SENSOR

< REMOVAL AND INSTALLATION >

[TRANSFER: ATX90A]

- Perform inspection after installation. Refer to [DLN-125, "Inspection"](#).
- When replacing the transfer lock position sensor, perform learning of transfer lock position sensor. Refer to [DLN-45, "Work Procedure"](#).
- After learning of transfer lock position sensor, align matching mark to fix propeller shaft flange yoke and transfer companion flange. Refer to [DLN-137, "Removal and Installation"](#) (front propeller shaft), [DLN-146, "Removal and Installation"](#) (rear propeller shaft).

Inspection

INFOID:0000000010262314

INSPECTION AFTER REMOVAL

Check the O-ring assembled transfer lock position sensor for wear, crack and damage. Replace the transfer lock position sensor if there is malfunction.

INSPECTION AFTER INSTALLATION

After driving, check the surface fitting transfer lock position sensor to transfer assembly for fluid leakage.

A
B
C
DLN
E
F
G
H
I
J
K
L
M
N
O
P

TRANSFER FLUID TEMPERATURE SENSOR


< REMOVAL AND INSTALLATION >

[TRANSFER: ATX90A]

TRANSFER FLUID TEMPERATURE SENSOR

Exploded View

INFOID:0000000010262315



1. Transfer assembly

2. Transfer fluid temperature sensor

⇐: Vehicle front

Refer to [GI-4, "Components"](#) for symbols not described above.

Removal and Installation

INFOID:0000000010262316

REMOVAL

1. Drain transfer fluid. Refer to [DLN-110, "Draining"](#).
2. Disconnect the transfer fluid temperature sensor connector.
3. Remove the transfer fluid temperature sensor.
4. Perform inspection after removal. Refer to [DLN-126, "Inspection"](#).

INSTALLATION

Note the following, and install in the reverse order of removal.

- Perform inspection after installation. Refer to [DLN-126, "Inspection"](#).
- After refilling new transfer fluid, perform learning of transfer fluid viscosity. Refer to [DLN-48, "Work Procedure"](#).

Inspection

INFOID:0000000010262317

INSPECTION AFTER REMOVAL

Check the washer assembled transfer fluid temperature sensor for wear, crack and damage. Replace the transfer fluid temperature sensor if there is malfunction.

INSPECTION AFTER INSTALLATION


After driving, check the surface fitting transfer fluid temperature sensor to transfer assembly for fluid leakage.

UNIT REMOVAL AND INSTALLATION

TRANSFER ASSEMBLY

Exploded View

INFOID:0000000010262318



- | | | |
|------------------|-------------------|----------------------|
| 1. Bracket | 2. Bracket | 3. Breather hose |
| 4. Hose clip | 5. Hose connector | 6. Breather hose |
| 7. Breather hose | 8. Breather | 9. Transfer assembly |

⇐: Vehicle front

Refer to [GI-4, "Components"](#) for symbols not described above.

Removal and Installation

INFOID:0000000010262319

REMOVAL

1. Remove rear propeller shaft. Refer to [DLN-146, "Removal and Installation"](#).
2. Remove front propeller shaft. Refer to [DLN-137, "Removal and Installation"](#).
3. Disconnect transfer control actuator, transfer rotary position sensor, transfer lock position sensor, transfer Hi-Lo position sensor and transfer fluid temperature sensor harness connectors and separate harnesses from transfer assembly.
4. Remove transfer breather hose.
5. Remove exhaust front tube (LH) with a power tool. Refer to [EX-5, "Removal and Installation"](#).
6. Remove exhaust front tube (RH) with a power tool. Refer to [EX-5, "Removal and Installation"](#).
7. Remove main muffler with a power tool. Refer to [EX-5, "Removal and Installation"](#).
8. Support transfer assembly and transmission assembly with a jack.
9. Remove rear engine mounting member and engine mounting insulator with a power tool. Refer to [EM-105, "Removal and Installation"](#).
10. Lower jack to the position where the top transfer mounting bolts can be removed.
11. Remove transfer mounting bolts and separate transfer from transmission.

CAUTION:

Secure transfer assembly and transmission assembly to a jack.

CAUTION:

Secure transfer assembly and transmission assembly to a jack.

INSTALLATION

Note the following, and install in the reverse order of removal.

TRANSFER ASSEMBLY


< UNIT REMOVAL AND INSTALLATION >

[TRANSFER: ATX90A]

- When installing the transfer to the transmission, install the mounting bolts following the standard below, tighten bolts to the specified torque.


Bolt symbol	A	B
Insertion direction	Transfer to transmission	Transmission to transfer

➡ : Tightening the bolt with bracket




- When installing transfer breather hose assembly, check that there are no bend and twist on the transfer breather hose.
- Align paint marks (A) to connect breather hoses (1), (2), and (3) with breather connectors (4) in numerical order.
- Align arrow mark (B) of breather (5) with mark "C" of breather hose.

⇐ : Vehicle front



- Install hose clip (1) to the position where the distance from the breather side hose end is dimension "D."
- Install hose clip (2), (3), and (4) to the positions where the distance from breather hose joint (C) is dimension "E," "F," and "G," respectively, as shown in the figure.



Dimension

D: 26.3 mm (1.035 in)

E: 121.7 mm (4.791 in)

F: 25.0 mm (0.984 in)


G: 143.0 mm (5.630 in)

CAUTION:

- To install hose clips (1), (2), (3), and (4), observe the angle/ orientation shown in the figure.

Angle A: $45^\circ \pm 15^\circ$

- Never reuse hose clip
- After tightening band of clip, cut the extra part.




TRANSFER ASSEMBLY

< UNIT REMOVAL AND INSTALLATION >

[TRANSFER: ATX90A]

Transmission side hose end


- Install the transfer breather hose (1) with the paint mark (A) faced backward and the arrow mark (B) faced rightward.




Transfer side hose end

- Install the transfer breather hose (1) with the paint mark (A) faced upward, and insert breather hose to breather tube (2) until dimension (B) shown as follows.

B: 20 mm (0.79 in)




- Fix breather hose in (A) and (B) positions. For (A), face the paint mark upward.
- Check oil level and check for oil leakage after installation. Refer to [DLN-110, "Inspection"](#).
- If replacing transfer assembly, perform writing unit parameter, learning of fluid viscosity and initial calibration. Refer to [DLN-43, "Work Procedure"](#).



INPUT OIL SEAL

Exploded View

INFOID:000000010262320



1. Transfer assembly

2. Input oil seal

: Apply transfer fluid. Refer to [MA-15, "FOR NORTH AMERICA : Fluids and Lubricants"](#) (for NORTH AMERICA), [MA-16, "FOR MEXICO : Fluids and Lubricants"](#) (for MEXICO).

: Vehicle front

Refer to [GI-4, "Components"](#) for symbols not described above.

Removal and Installation

INFOID:000000010262321

REMOVAL

1. Remove transfer assembly from vehicle. Refer to [DLN-127, "Exploded View"](#).
2. Remove input oil seal from front case, using a suitable tool.

CAUTION:

Never damage the front case and input.


INSTALLATION

Note the following, and install in the reverse order of removal.

- Install input oil seal, with a drift (A) [SST: KV40104710 (—)] until it is flush with the end face of front case with the drift

CAUTION:

- **Never reuse input oil seal.**
- **Apply transfer fluid onto circumference of oil seal.**



SERVICE DATA AND SPECIFICATIONS (SDS)

< SERVICE DATA AND SPECIFICATIONS (SDS)

[TRANSFER: ATX90A]

SERVICE DATA AND SPECIFICATIONS (SDS)

SERVICE DATA AND SPECIFICATIONS (SDS)

General Specifications

INFOID:0000000010262322

Applied model	4WD	
	VK56VD	
	A/T	
Transfer model		ATX90A
Fluid capacity (Approx.)		ℓ (US pt, Imp pt) 1.5 (3-1/8, 2-5/8)
Gear ratio	4H	1.000
	4L	2.679

A

B

C

DLN

E

F

G

H

I

J

K

L

M

N

O

P

PRECAUTION

PRECAUTIONS

Precautions for Removing Battery Terminal

INFOID:0000000010262323

- When removing the 12V battery terminal, turn OFF the ignition switch and wait at least 30 seconds.

NOTE:

ECU may be active for several tens of seconds after the ignition switch is turned OFF. If the battery terminal is removed before ECU stops, then a DTC detection error or ECU data corruption may occur.

- For vehicles with the 2-batteries, be sure to connect the main battery and the sub battery before turning ON the ignition switch.


NOTE:

If the ignition switch is turned ON with any one of the terminals of main battery and sub battery disconnected, then DTC may be detected.

- After installing the 12V battery, always check "Self Diagnosis Result" of all ECUs and erase DTC.

NOTE:

The removal of 12V battery may cause a DTC detection error.



SEF289H

PREPARATION

< PREPARATION >


[FRONT PROPELLER SHAFT: 2F P15]

PREPARATION

PREPARATION

Commercial Service Tools

INFOID:0000000010262324

Tool name	Description
Power tool	Loosening bolts and nuts
	

A

B

C

DLN

E

F

G

H

I

J

K

L

M

N

O

P

NOISE, VIBRATION, AND HARSHNESS (NVH) TROUBLESHOOTING

< SYMPTOM DIAGNOSIS >

[FRONT PROPELLER SHAFT: 2F P15]

SYMPTOM DIAGNOSIS

NOISE, VIBRATION, AND HARSHNESS (NVH) TROUBLESHOOTING

NVH Troubleshooting Chart

INFOID:0000000010262325

Use the chart below to help you find the cause of the symptom. If necessary, repair or replace these parts.

Reference		DLN-135, "Inspection"	—	—	—	—	DLN-135, "Inspection"	DLN-135, "Inspection"	NVH of FRONT and REAR FINAL DRIVE in hits section.	NVH in FAX, RAX, FSU and RSU section.	NVH in WT section.	NVH in WT section.	NVH in FAX and RAX section.	NVH in BR section.	NVH in ST section.
Possible cause and SUSPECTED PARTS		Uneven rotating torque	Center bearing improper installation	Excessive center bearing axial end play	Center bearing mounting (insulator) cracks, damage or deterioration	Excessive joint angle	Rotation imbalance	Excessive runout	DIFFERENTIAL	AXLE AND SUSPENSION	TIRE	ROAD WHEEL	DRIVE SHAFT	BRAKE	STEERING
Symptom	Noise	×	×	×	×	×	×	×	×	×	×	×	×	×	×
	Shake		×			×				×	×	×	×	×	×
	Vibration	×	×	×	×	×	×	×		×	×		×		×

×: Applicable

PERIODIC MAINTENANCE

FRONT PROPELLER SHAFT

Inspection

INFOID:0000000010262326

APPEARANCE AND NOISE

Check the propeller shaft tube surface for dents or cracks. If damaged, replace propeller shaft assembly.


VIBRATION

If vibration is present at high speed, inspect propeller shaft runout first.

1. With a dial indicator, measure propeller shaft runout at runout measuring points by rotating final drive companion flange with hands.

↩: Vehicle front

Propeller shaft runout : Refer to [DLN-141, "Propeller Shaft Runout"](#).




- Propeller shaft runout measuring point (Point "Δ").

↩: Vehicle front

Dimension

- A** : 80 – 100 mm (3.15 – 3.94 in)
- B** : 100 – 120 mm (3.94 – 4.72 in)
- C** : 254.5 mm (10.02 in)



2. If runout still exceeds specifications, separate propeller shaft at final drive companion flange or transfer companion flange; then change the phase between companion flange and propeller shaft by the one bolt hole at a time and install propeller shaft.
3. If runout is more than the limit value, remove and check propeller shaft.
4. Check the vibration by driving vehicle.

FRONT PROPELLER SHAFT

< REMOVAL AND INSTALLATION >

[FRONT PROPELLER SHAFT: 2F P15]


REMOVAL AND INSTALLATION

FRONT PROPELLER SHAFT

Exploded View

INFOID:000000010262327

REMOVAL




1. Propeller shaft assembly

⇐: Vehicle front

Refer to [GI-4, "Components"](#) for symbols not described above.

DISASSEMBLY



- | | | |
|----------------|--------------------|-------------|
| 1. Flange yoke | 2. Snap ring* | 3. Bearing* |
| 4. Journal* | 5. Propeller shaft | |

*: Replace "2", "3" and "4" as a set.

⇐: Vehicle front

Refer to [GI-4, "Components"](#) for symbols not described above.

FRONT PROPELLER SHAFT

< REMOVAL AND INSTALLATION >


[FRONT PROPELLER SHAFT: 2F P15]

Removal and Installation

INFOID:000000010262328

REMOVAL


1. Shift the transmission to the neutral position, and then release the parking brake.
2. Remove protector A and B with power tool. Refer to [SCS-39, "PPMU, MIDDLE TUBE ASSEMBLY, PPMU PIPE : Removal and Installation"](#).
3. Remove front suspension rear cross member with a power tool. Refer to [TM-217, "4WD : Removal and Installation"](#).
4. Put matching mark (A) on front propeller shaft flange yoke and final drive companion flange.
CAUTION:
For matching mark, use paint. Never damage propeller shaft flange and final drive companion flange.
5. Put matching mark (A) on front propeller shaft flange yoke and transfer companion flange.
CAUTION:
For matching mark, use paint. Never damage propeller shaft flange and transfer companion flange.
6. Remove the propeller shaft assembly fixing bolts.
7. Remove propeller shaft assembly from the front final drive and transfer.
8. Perform inspection after removal. Refer to [DLN-139, "Inspection"](#).




INSTALLATION

Note the following, and install in the reverse order of removal.

- Align matching mark (A) to install propeller shaft flange yoke and transfer companion flange.
- Align matching mark (A) to install propeller shaft flange yoke and front final drive companion flange.
- Perform inspection after installation. Refer to [DLN-139, "Inspection"](#).



- If propeller shaft or final drive has been replaced, connect them as follows:
- Install the propeller shaft while aligning its matching mark (A) with the matching mark (B) on the joint as close as possible.



Disassembly and Assembly

INFOID:000000010262329

DISASSEMBLY

FRONT PROPELLER SHAFT


< REMOVAL AND INSTALLATION >

[FRONT PROPELLER SHAFT: 2F P15]

1. Put a matching mark (A) between propeller shaft and flange yoke and remove snap rings (1).

CAUTION:


For matching mark, use paint. Never damage the surface.



2. Lightly tap bottom of yoke using a copper hammer and remove journal bearing.

CAUTION:

Never damage the yoke.



ASSEMBLY

1. Install journal bearing to journal.


CAUTION:

- Never reuse journal or journal bearing.
- Always replace journal, journal bearing, and snap rings as a set.
- Apply multi-purpose grease to journal bearing.

2. Install bearing (1) using a vise.

CAUTION:


Never damage bearing or flange yoke.



3. Install journal to propeller shaft so that grease nipple (1) on journal portion is in the same direction.

CAUTION:

Never reuse journal.



4. Measure journal axial play. If necessary, select the appropriate snap ring.

FRONT PROPELLER SHAFT

< REMOVAL AND INSTALLATION >

[FRONT PROPELLER SHAFT: 2F P15]

- a. While pushing to 98 N·m (10 kg-m, 72 ft-lb), check the clearance between snap ring (1) and flange yoke (2).



Journal axial play : Refer to [DLN-141, "Journal Axial Play"](#)

- b. If journal axial play is outside the specification, use a thicker/thinner snap ring to adjust.

CAUTION:

- Never reuse snap ring.
- Select snap rings so that thickness difference between LH and RH is within 0.06 mm. For selecting snap ring, refer to the latest parts information.

5. Install selected snap ring as shown in the figure.



6. Check that joint moves smoothly.


Reference value (After adaptation)

Bending resistance : 1.96 N·m (0.20 kg-m, 17 in-lb) or less

NOTE:

The bending resistance [1.96 N·m (0.20 kg-m, 17 in-lb) or less] may not be satisfied soon after the installation.

7. Check the journal axial play. Refer to [DLN-139, "Inspection"](#).



INFOID:0000000010262330

Inspection

INSPECTION AFTER REMOVAL


Appearance

Check the propeller shaft for dents or cracks. If damage is detected, replace the propeller shaft assembly.

Propeller Shaft Runout

Check propeller shaft runout at measuring point with a dial indicator. If runout exceeds specifications, replace propeller shaft assembly.

Propeller shaft runout : Refer to [DLN-141, "Propeller Shaft Runout"](#)



FRONT PROPELLER SHAFT

< REMOVAL AND INSTALLATION >


[FRONT PROPELLER SHAFT: 2F P15]

- Propeller shaft runout measuring point (Point “△”).

↶: Vehicle front

Dimension


A	: 80 – 100 mm (3.15 – 3.94 in)
B	: 100 – 120 mm (3.94 – 4.72 in)
C	: 254.5 mm (10.02 in)



Journal Axial Play

As shown in the figure, while fixing yoke on one side, check axial play of joint. If axial play exceeds specifications, replace propeller shaft assembly.

Journal axial play : Refer to [DLN-141](#),
"Journal Axial Play"



INSPECTION AFTER INSTALLATION

After assembly, perform a driving test to check propeller shaft vibration. If vibration occurred, separate propeller shaft from final drive or transfer. Reinstall companion flange by changing the phase between companion flange and propeller shaft by the one bolt hole at a time. Then perform driving test and check propeller shaft vibration again at each point.

SERVICE DATA AND SPECIFICATIONS (SDS)

< SERVICE DATA AND SPECIFICATIONS (SDS)

[FRONT PROPELLER SHAFT: 2F P15]

SERVICE DATA AND SPECIFICATIONS (SDS)

SERVICE DATA AND SPECIFICATIONS (SDS)

General Specification

INFOID:0000000010262331

Applied model	4WD	
	VK56VD	
	A/T	
Propeller shaft model	2F P15	
Number of joints	2	
Type of journal bearings	1st joint	Shell type
	2nd joint	Shell type
Coupling method with transfer	Flange type	
Coupling method with rear final drive	Flange type	
Shaft length (Spider to spider)	729 mm (28.70 in)	
Shaft outer diameter	68.9 mm (2.713 in)	

Propeller Shaft Runout

INFOID:0000000010262332

Unit: mm (in)

Item	Limit
Propeller shaft runout	1.0 (0.04)

Journal Axial Play

INFOID:0000000010262333

Unit: mm (in)

Item	Standard
Journal axial play	0.06 (0.0024)

PRECAUTION

PRECAUTIONS

Precautions for Removing Battery Terminal

INFOID:0000000010262334

- When removing the 12V battery terminal, turn OFF the ignition switch and wait at least 30 seconds.

NOTE:

ECU may be active for several tens of seconds after the ignition switch is turned OFF. If the battery terminal is removed before ECU stops, then a DTC detection error or ECU data corruption may occur.

- For vehicles with the 2-batteries, be sure to connect the main battery and the sub battery before turning ON the ignition switch.


NOTE:

If the ignition switch is turned ON with any one of the terminals of main battery and sub battery disconnected, then DTC may be detected.

- After installing the 12V battery, always check "Self Diagnosis Result" of all ECUs and erase DTC.

NOTE:

The removal of 12V battery may cause a DTC detection error.



NOISE, VIBRATION, AND HARSHNESS (NVH) TROUBLESHOOTING

< SYMPTOM DIAGNOSIS >

[REAR PROPELLER SHAFT: 2F P26]

SYMPTOM DIAGNOSIS

NOISE, VIBRATION, AND HARSHNESS (NVH) TROUBLESHOOTING

NVH Troubleshooting Chart

INFOID:0000000010262335

Use the chart below to help you find the cause of the symptom. If necessary, repair or replace these parts.

Reference		DLN-144, "Inspection"	—	—	—	—	DLN-144, "Inspection"	DLN-144, "Inspection"	NVH of FRONT and REAR FINAL DRIVE in hits section.	NVH in FAX, RAX, FSU and RSU section.	NVH in WT section.	NVH in WT section.	NVH in FAX and RAX section.	NVH in BR section.	NVH in ST section.
Possible cause and SUSPECTED PARTS		Uneven rotating torque	Center bearing improper installation	Excessive center bearing axial end play	Center bearing mounting (insulator) cracks, damage or deterioration	Excessive joint angle	Rotation imbalance	Excessive runout	DIFFERENTIAL	AXLE AND SUSPENSION	TIRE	ROAD WHEEL	DRIVE SHAFT	BRAKE	STEERING
Symptom	Noise	x	x	x	x	x	x	x	x	x	x	x	x	x	x
	Shake		x			x				x	x	x	x	x	x
	Vibration	x	x	x	x	x	x	x		x	x		x		x

x: Applicable

A
B
C
DLN
E
F
G
H
I
J
K
L
M
N
O
P

PERIODIC MAINTENANCE

REAR PROPELLER SHAFT

Inspection

INFOID:000000010262336

APPEARANCE AND NOISE

Check the propeller shaft tube surface for dents or cracks. If damaged, replace propeller shaft assembly.


VIBRATION

If vibration is present at high speed, inspect propeller shaft runout first.

1. With a dial indicator, measure propeller shaft runout at runout measuring points by rotating final drive companion flange with hands.

↩: Vehicle front

Propeller shaft runout : Refer to [DLN-150, "Propeller Shaft Runout"](#).




- Propeller shaft runout measuring point (Point "△").

↩: Vehicle front

Dimension

- A** : 120 – 150 mm (4.72 – 5.91 in)
B : 150 – 180 mm (5.91 – 7.09 in)
C : 703.5 mm (27.70 in)



2. If runout still exceeds specifications, separate propeller shaft at final drive companion flange or transfer companion flange; then change the phase between companion flange and propeller shaft by the one bolt hole at a time and install propeller shaft.
3. If runout is more than the limit value, remove and check propeller shaft.
4. Check the vibration by driving vehicle.

REAR PROPELLER SHAFT

< REMOVAL AND INSTALLATION >

[REAR PROPELLER SHAFT: 2F P26]


REMOVAL AND INSTALLATION

REAR PROPELLER SHAFT

Exploded View

INFOID:0000000010262337

REMOVAL




1. Propeller shaft assembly

⇐: Vehicle front

Refer to [GI-4, "Components"](#) for symbols not described above.

DISASSEMBLY



- | | | |
|----------------|--------------------|-------------|
| 1. Flange yoke | 2. Snap ring* | 3. Bearing* |
| 4. Journal* | 5. Propeller shaft | |

*: Replace "2", "3" and "4" as a set.

⇐: Vehicle front

Refer to [GI-4, "Components"](#) for symbols not described above.

REAR PROPELLER SHAFT

< REMOVAL AND INSTALLATION >


[REAR PROPELLER SHAFT: 2F P26]

Removal and Installation

INFOID:000000010262338

REMOVAL



1. Shift the transmission to the neutral position, and then release the parking brake.
2. Put matching mark (A) on rear propeller shaft flange yoke and rear drive companion flange.
CAUTION:
For matching mark, use paint. Never damage propeller shaft flange and final drive companion flange.
3. Put matching mark (A) on rear propeller shaft flange yoke and transfer companion flange.
CAUTION:
For matching mark, use paint. Never damage propeller shaft flange and transfer companion flange.
4. Remove the propeller shaft assembly fixing bolts.
5. Remove propeller shaft assembly from the rear final drive and transfer.
6. Perform inspection after removal. Refer to [DLN-148. "Inspection"](#).



INSTALLATION

Note the following, and install in the reverse order of removal.

- Align matching mark (A) to install propeller shaft flange yoke and transfer companion flange.
 - Align matching mark (A) to install propeller shaft flange yoke and rear final drive companion flange.
 - Perform inspection after installation. Refer to [DLN-148. "Inspection"](#).
-
- If propeller shaft or final drive has been replaced, connect them as follows:
 - Install the propeller shaft while aligning its matching mark (A) with the matching mark (B) on the joint as close as possible.



Disassembly and Assembly

INFOID:000000010262339

DISASSEMBLY

REAR PROPELLER SHAFT


< REMOVAL AND INSTALLATION >

[REAR PROPELLER SHAFT: 2F P26]

1. Put a matching mark between propeller shaft and flange yoke and remove snap rings (1).

CAUTION:

For matching mark, use paint. Never damage the surface.




2. Lightly tap bottom of yoke using a copper hammer and remove journal bearing.

CAUTION:

Never damage the yoke.

3. Remove grease nipple.



ASSEMBLY

1. Install journal bearing to journal.


CAUTION:

- Never reuse journal or journal bearing.
- Always replace journal, journal bearing, and snap rings as a set.
- Apply multi-purpose grease to journal bearing.

2. Install bearing (1) using a vise.

CAUTION:


Never damage bearing or flange yoke.



3. Install journal to propeller shaft so that grease nipple (1) on journal portion is in the same direction.

CAUTION:

Never reuse journal.



A

B

C

DLN

E

F

G

H

I

J

K

L

M

N

O


P

REAR PROPELLER SHAFT

< REMOVAL AND INSTALLATION >

[REAR PROPELLER SHAFT: 2F P26]

4. Install snap ring (1).



5. Check that joint moves smoothly.


Reference value (After adaptation)

Bending resistance : 2.26 N·m (0.23 kg-m, 20 in-lb) or less

NOTE:

The bending resistance [2.26 N·m (0.23 kg-m, 20 in-lb) or less] may not be satisfied soon after the installation.

6. Check the journal axial play. Refer to [DLN-148. "Inspection"](#).



INFOID:0000000010262340

Inspection

INSPECTION AFTER REMOVAL


Appearance

Check the propeller shaft for dents or cracks. If damage is detected, replace the propeller shaft assembly.

Propeller Shaft Runout

Check propeller shaft runout at measuring point with a dial indicator. If runout exceeds specifications, replace propeller shaft assembly.

Propeller shaft runout : Refer to [DLN-150. "Propeller Shaft Runout"](#)




- Propeller shaft runout measuring point (Point "△").

⇐: Vehicle front

Dimension

A : 120 – 150 mm (4.72 – 5.91 in)
B : 150 – 180 mm (5.91 – 7.09 in)
C : 703.5 mm (27.70 in)



Journal Axial Play

REAR PROPELLER SHAFT


< REMOVAL AND INSTALLATION >

[REAR PROPELLER SHAFT: 2F P26]

As shown in the figure, while fixing yoke on one side, check axial play of joint. If axial play exceeds specifications, replace propeller shaft assembly.

Journal axial play

: Refer to [DLN-150](#),
["Journal Axial Play"](#)



INSPECTION AFTER INSTALLATION

After assembly, perform a driving test to check propeller shaft vibration. If vibration occurred, separate propeller shaft from final drive or transfer. Reinstall companion flange by changing the phase between companion flange and propeller shaft by the one bolt hole at a time. Then perform driving test and check propeller shaft vibration again at each point.

A

B

C

DLN

E

F

G

H

I

J

K

L

M

N

O

P

SERVICE DATA AND SPECIFICATIONS (SDS)

< SERVICE DATA AND SPECIFICATIONS (SDS)

[REAR PROPELLER SHAFT: 2F P26]

SERVICE DATA AND SPECIFICATIONS (SDS)

SERVICE DATA AND SPECIFICATIONS (SDS)

General Specification

INFOID:0000000010262341

Applied model	4WD	
	VK56VD	
	A/T	
Propeller shaft model	2F P26	
Number of joints	2	
Type of journal bearings	1st joint	Shell type
	2nd joint	Shell type
Coupling method with transfer	Flange type	
Coupling method with rear final drive	Flange type	
Shaft length (Spider to spider)	1168mm (45.98 in)	
Shaft outer diameter	101.6 mm (4.00 in)	

Propeller Shaft Runout

INFOID:0000000010262342

Unit: mm (in)

Item	Limit
Propeller shaft runout	1.0 (0.04)

Journal Axial Play

INFOID:0000000010262343

Unit: mm (in)

Item	Standard
Journal axial play	0 (0)

PRECAUTION

PRECAUTIONS

Precautions for Removing Battery Terminal

INFOID:0000000010262344

- When removing the 12V battery terminal, turn OFF the ignition switch and wait at least 30 seconds.

NOTE:

ECU may be active for several tens of seconds after the ignition switch is turned OFF. If the battery terminal is removed before ECU stops, then a DTC detection error or ECU data corruption may occur.

- For vehicles with the 2-batteries, be sure to connect the main battery and the sub battery before turning ON the ignition switch.


NOTE:

If the ignition switch is turned ON with any one of the terminals of main battery and sub battery disconnected, then DTC may be detected.

- After installing the 12V battery, always check "Self Diagnosis Result" of all ECUs and erase DTC.

NOTE:

The removal of 12V battery may cause a DTC detection error.



A

B

C

DLN

E

F

G

H

I

J

K

L

M

N

O

P

NOISE, VIBRATION, AND HARSHNESS (NVH) TROUBLESHOOTING

< SYMPTOM DIAGNOSIS >

[REAR PROPELLER SHAFT: 2S1410]

SYMPTOM DIAGNOSIS

NOISE, VIBRATION, AND HARSHNESS (NVH) TROUBLESHOOTING

NVH Troubleshooting Chart

INFOID:000000010262345

Use the chart below to help you find the cause of the symptom. If necessary, repair or replace these parts.

Reference		DLN-153, "Inspection"	—	—	—	—	DLN-153, "Inspection"	DLN-153, "Inspection"	NVH of REAR FINAL DRIVE in this section.	NVH in RAX and RSU section.	NVH in WT section.	NVH in WT section.	NVH in RAX section.	NVH in BR section.	NVH in ST section.
Possible cause and SUSPECTED PARTS		Uneven rotating torque	Center bearing improper installation	Excessive center bearing axial end play	Center bearing mounting (insulator) cracks, damage or deterioration	Excessive joint angle	Rotation imbalance	Excessive runout	DIFFERENTIAL	AXLE AND SUSPENSION	TIRE	ROAD WHEEL	DRIVE SHAFT	BRAKE	STEERING
Symptom	Noise	x	x	x	x	x	x	x	x	x	x	x	x	x	x
	Shake		x			x				x	x	x	x	x	x
	Vibration	x	x	x	x	x	x	x		x	x		x		x

x: Applicable

PERIODIC MAINTENANCE

REAR PROPELLER SHAFT

Inspection

INFOID:000000010262346

APPEARANCE AND NOISE

Check the propeller shaft tube surface for dents or cracks. If damaged, replace propeller shaft assembly.


VIBRATION

If vibration is present at high speed, inspect propeller shaft runout first.

1. With a dial indicator, measure propeller shaft runout at runout measuring points by rotating final drive companion flange with hands.

Propeller shaft runout


: Refer to [DLN-159, "Propeller Shaft Runout"](#).



- Propeller shaft runout measuring range.

↔: Vehicle front

2. If runout still exceeds specifications, separate propeller shaft at final drive companion flange; then change the phase between companion flange and propeller shaft by the one bolt hole at a time and install propeller shaft.
3. If runout is more than the limit value, remove and check propeller shaft.
4. Check the vibration by driving vehicle.



A
B
C
DLN
E
F
G
H
I
J
K
L
M
N
O
P

REAR PROPELLER SHAFT

< REMOVAL AND INSTALLATION >

[REAR PROPELLER SHAFT: 2S1410]


REMOVAL AND INSTALLATION

REAR PROPELLER SHAFT

Exploded View

INFOID:000000010262347

REMOVAL




1. Propeller shaft assembly

⇐: Vehicle front

Refer to [GI-4, "Components"](#) for symbols not described above.

DISASSEMBLY



- | | | |
|----------------|--------------------|----------------|
| 1. Flange yoke | 2. Snap ring | 3. Bearing |
| 4. Journal | 5. Propeller shaft | 6. Sleeve yoke |

⇐: Vehicle front

Refer to [GI-4, "Components"](#) for symbols not described above.

REAR PROPELLER SHAFT

< REMOVAL AND INSTALLATION >

[REAR PROPELLER SHAFT: 2S1410]

Removal and Installation

INFOID:000000010262348


REMOVAL

1. Shift the transmission to the neutral position, and then release the parking brake.
2. Put matching mark (A) on rear propeller shaft flange yoke and rear drive companion flange.

CAUTION:

For matching mark, use paint. Never damage propeller shaft flange and final drive companion flange.


3. Remove the propeller shaft assembly fixing bolts.
4. Remove propeller shaft assembly from the rear final drive and transfer.
5. Perform inspection after removal. Refer to [DLN-157. "Inspection"](#).




INSTALLATION

Note the following, and install in the reverse order of removal.

- Align matching mark (A) to install propeller shaft flange yoke and transfer companion flange.
- Align matching mark (A) to install propeller shaft flange yoke and rear final drive companion flange.
- Perform inspection after installation. Refer to [DLN-157. "Inspection"](#).



- If propeller shaft or final drive has been replaced, connect them as follows:
- Install the propeller shaft while aligning its matching mark (A) with the matching mark (B) on the joint as close as possible.



Disassembly and Assembly


INFOID:000000010262349

DISASSEMBLY

1. Put a matching mark between propeller shaft and flange yoke as shown.

CAUTION:

For matching mark, use paint. Never damage the surface.




REAR PROPELLER SHAFT

< REMOVAL AND INSTALLATION >

[REAR PROPELLER SHAFT: 2S1410]


2. Remove snap ring.



3. Lightly tap bottom of yoke using a copper hammer and remove journal bearing.

CAUTION:

Never damage the yoke.



ASSEMBLY

1. Install journal bearing to journal.


CAUTION:

- Never reuse journal or journal bearing.
- Always replace journal, journal bearing, and snap rings as a set.
- Apply multi-purpose grease to journal bearing.

2. Install bearing (1) using a vise.

CAUTION:

Never damage bearing or flange yoke.



3. Measure journal axial play. If necessary, select the appropriate snap ring.

- a. While pushing to 98 N·m (10 kg-m, 72 ft-lb), check the clearance between snap ring (1) and needle bearing (2).


Journal axial play

**: Refer to [DLN-159](#),
"Journal Axial Play"**

- b. If journal axial play is outside the specification, use a thicker/thinner snap ring to adjust.

CAUTION:

- Never reuse snap ring.
- Select snap rings so that thickness difference between LH and RH is within 0.02 mm (0.0008 in). For selecting snap ring, refer to the latest parts information.




REAR PROPELLER SHAFT

< REMOVAL AND INSTALLATION >

[REAR PROPELLER SHAFT: 2S1410]

4. Install snap ring (1).



5. Check that joint moves smoothly.


Reference value (After adaptation)

Bending resistance : 2.26 N·m (0.23 kg-m, 20 in-lb) or less

NOTE:

The bending resistance [2.26 N·m (0.23 kg-m, 20 in-lb) or less] may not be satisfied soon after the installation.

6. Check the journal axial play. Refer to [DLN-157, "Inspection"](#).



INFOID:0000000110262350

Inspection

INSPECTION AFTER REMOVAL


Appearance

Check the propeller shaft for dents or cracks. If damage is detected, replace the propeller shaft assembly.

Propeller Shaft Runout


Check propeller shaft runout at measuring point with a dial indicator. If runout exceeds specifications, replace propeller shaft assembly.

Propeller shaft runout : Refer to [DLN-159, "Propeller Shaft Runout"](#)



- Propeller shaft runout measuring range.

↔ Vehicle front



Journal Axial Play

REAR PROPELLER SHAFT


< REMOVAL AND INSTALLATION >

[REAR PROPELLER SHAFT: 2S1410]

As shown in the figure, while fixing yoke on one side, check axial play of joint. If axial play exceeds specifications, replace propeller shaft assembly.

Journal axial play

**: Refer to [DLN-159](#),
"Journal Axial Play"**



INSPECTION AFTER INSTALLATION

After assembly, perform a driving test to check propeller shaft vibration. If vibration occurred, separate propeller shaft from final drive. Reinstall companion flange by changing the phase between companion flange and propeller shaft by the one bolt hole at a time. Then perform driving test and check propeller shaft vibration again at each point.

SERVICE DATA AND SPECIFICATIONS (SDS)

< SERVICE DATA AND SPECIFICATIONS (SDS)

[REAR PROPELLER SHAFT: 2S1410]

SERVICE DATA AND SPECIFICATIONS (SDS)

SERVICE DATA AND SPECIFICATIONS (SDS)

General Specification

INFOID:0000000010262351

Applied model	2WD	
	VK56VD	
	A/T	
Propeller shaft model	2S1410	
Number of joints	2	
Type of journal bearings	1st joint	Shell type
	2nd joint	Shell type
Coupling method with transfer	Sleeve type	
Coupling method with rear final drive	Flange type	
Shaft length (Spider to spider)	1590.4 mm (62.61 in)	
Shaft outer diameter	127.6 mm (5.02 in)	

Propeller Shaft Runout

INFOID:0000000010262352

Unit: mm (in)

Item	Limit
Propeller shaft runout	1.02 (0.0402)

Journal Axial Play

INFOID:0000000010262353

Unit: mm (in)

Item	Standard
Journal axial play	0.02 (0.0008)

PRECAUTION

PRECAUTIONS

Precautions for Removing Battery Terminal

INFOID:0000000010262354

- When removing the 12V battery terminal, turn OFF the ignition switch and wait at least 30 seconds.

NOTE:

ECU may be active for several tens of seconds after the ignition switch is turned OFF. If the battery terminal is removed before ECU stops, then a DTC detection error or ECU data corruption may occur.

- For vehicles with the 2-batteries, be sure to connect the main battery and the sub battery before turning ON the ignition switch.


NOTE:

If the ignition switch is turned ON with any one of the terminals of main battery and sub battery disconnected, then DTC may be detected.

- After installing the 12V battery, always check "Self Diagnosis Result" of all ECUs and erase DTC.

NOTE:

The removal of 12V battery may cause a DTC detection error.



Precaution for Servicing Front Final Drive

INFOID:0000000010262355

- Before starting diagnosis of the vehicle, understand the symptoms well. Perform correct and systematic operations.
- Check for the correct installation status prior to removal or disassembly. When matching marks are required, be certain they do not interfere with the function of the parts they are applied to.
- Overhaul should be done in a clean work area, a dust proof area is recommended.
- Before disassembly, completely remove sand and mud from the exterior of the unit, preventing them from entering into the unit during disassembly or assembly.
- Always use shop paper for cleaning the inside of components.
- Avoid using cotton gloves or a shop cloth to prevent the entering of lint.
- Check appearance of the disassembled parts for damage, deformation, and abnormal wear. Replace them with new ones if necessary.
- Gaskets, seals and O-rings should be replaced any time the unit is disassembled.
- Clean and flush the parts sufficiently and blow them dry.
- Be careful not to damage sliding surfaces and mating surfaces.
- When applying sealant, remove the old sealant from the mating surface; then remove any moisture, oil, and foreign materials from the application and mating surfaces.
- In principle, tighten nuts or bolts gradually in several steps working diagonally from inside to outside. If a tightening sequence is specified, observe it.
- During assembly, observe the specified tightening torque.
- Add new differential gear oil, petroleum jelly, or multi-purpose grease, as specified.

PREPARATION

< PREPARATION >

[FRONT FINAL DRIVE: R180A]






PREPARATION

PREPARATION

Special Service Tool

INFOID:0000000010262356







The actual shapes of TechMate tools may differ from those of special service tools illustrated here.

Tool number (TechMate No.) Tool name	Description
ST3127S000 (J-25765-A) Preload gauge  ZZA0806D	Measuring pinion bearing preload and total preload
KV381054S0 (J-34286) Puller  ZZA0601D	Removing front oil seal
ST30720000 (J-25405) Drift a: 77 mm (3.03 in) dia. b: 55.5 mm (2.185 in) dia.  ZZA0811D	- Installing front oil seal - Installing side oil seal - Installing pinion front bearing outer race
ST27863000 (—) Drift a: 74.5 mm (2.933 in) dia. b: 62.5 mm (2.461 in) dia.  ZZA1003D	- Installing front oil seal - Installing side oil seal
KV10111100 (J-37228) Seal cutter  S-NT046	Removing carrier cover

PREPARATION

< PREPARATION >




[FRONT FINAL DRIVE: R180A]

Tool number (TechMate No.) Tool name	Description
ST3306S001 (J-22888-D) Differential side bearing puller set 1: ST33051001 (J-22888-20) Puller 2: ST33061000 (J-8107-2) Base a: 28.5 mm (1.122 in) dia. b: 38 mm (1.50 in) dia.	Removing and installing side bearing inner race  NT072
KV10112100 (BT-8653-A) Angle wrench	Tightening the drive gear mounting bolts  ZZA0120D
ST33230000 (J-35867) Drift a: 51 mm (2.01 in) dia. b: 41 mm (1.61 in) dia. c: 28 mm (1.10 in) dia.	Installing side bearing inner race  ZZA1046D
ST30611000 (J-25742-1) Drift bar	Installing pinion rear bearing outer race (Use with ST30613000)  S-NT090
ST30613000 (J-25742-3) Drift a: 72 mm (2.83 in) dia. b: 48 mm (1.89 in) dia.	Installing pinion rear bearing outer race  ZZA1000D
KV38100200 (J-26233) Drift a: 65 mm (2.56 in) dia. b: 49 mm (1.93 in) dia.	Installing pinion front bearing outer race  ZZA1143D

PREPARATION



< PREPARATION >

[FRONT FINAL DRIVE: R180A]

Tool number (TechMate No.) Tool name	Description	
ST30901000 (J-26010-01) Drift a: 79 mm (3.11 in) dia. b: 45 mm (1.77 in) dia. c: 35.2 mm (1.386 in) dia.	Installing drive pinion rear bearing inner race	A
 ZZA0978D		B
ST33200000 (J-26082) Drift a: 60 mm (2.36 in) dia. b: 44.5 mm (1.752 in) dia.	Installing drive pinion front bearing inner race	C
 ZZA1002D		DLN
— (J-34309) Differential shim selector tool	Adjusting bearing preload and pinion gear height	E
 NT134		F
— (J-25269-18) Side bearing disc (2 Req'd)	Selecting pinion height adjusting washer	G
 NT135		H

Commercial Service Tool




INFOID:0000000010262357

Tool name	Description	
Power tool	Loosening bolts and nuts	L
 PBIC0190E		M
Flange wrench	Removing and installing drive pinion lock nut	N
 NT035		O

PREPARATION

< PREPARATION >

[FRONT FINAL DRIVE: R180A]


Tool name		Description
Puller	 ZZA0119D	Removing companion flange
Drift a: 63 mm (2.48 in) dia. or less b: 49 mm (1.93 in) dia. or more	 ZZA0811D	Removing and Installing bushing
Sliding hammer	 NT125	Removing differential case assembly
Replacer	 ZZA0700D	Removing pinion rear bearing inner race

SYSTEM DESCRIPTION

STRUCTURE AND OPERATION

Sectional View

INFOID:0000000010262358



- | | | |
|-------------------------|-----------------------|--------------------------|
| 1. Side shaft | 2. Side shaft bearing | 3. Side gear |
| 4. Drive gear | 5. Pinion mate shaft | 6. Differential case |
| 7. Side bearing | 8. Pinion mate gear | 9. Drive pinion |
| 10. Collapsible spacer | 11. Companion flange | 12. Pinion front bearing |
| 13. Pinion rear bearing | 14. Housing spacer | |

NOISE, VIBRATION AND HARSHNESS (NVH) TROUBLESHOOTING

< SYMPTOM DIAGNOSIS >

[FRONT FINAL DRIVE: R180A]

SYMPTOM DIAGNOSIS

NOISE, VIBRATION AND HARSHNESS (NVH) TROUBLESHOOTING

NVH Troubleshooting Chart

INFOID:0000000010262359

Use the chart below to help you find the cause of the symptom. If necessary, repair or replace these parts.

Symptom		Possible cause and SUSPECTED PARTS												Reference	
Noise	x	Gear tooth rough												DLN-186, "Inspection"	
		Gear contact improper												DLN-183, "Adjustment"	
		Tooth surfaces worn												DLN-186, "Inspection"	
		Backlash incorrect												DLN-183, "Adjustment"	
		Companion flange excessive runout												DLN-183, "Adjustment"	
		Gear oil improper												DLN-167, "Inspection"	
		PROPELLER SHAFT												NVH of FRONT PROPELLER SHAFT in this section. NVH of REAR PROPELLER SHAFT in this section.	
		AXLE AND SUSPENSION												NVH in FAX, RAX, FSU and RSU sections.	
		TIRE												NVH in WT section.	
		ROAD WHEEL												NVH in WT section.	
		DRIVE SHAFT												NVH in FAX and RAX section.	
		BRAKE												NVH in BR section.	
		STEERING												NVH in ST section.	

x: Applicable

PERIODIC MAINTENANCE

FRONT DIFFERENTIAL GEAR OIL

Inspection

INFOID:0000000010262360

OIL LEAKAGE

Check that oil is not leaking from the front final drive assembly or around it.

OIL LEVEL

- Remove filler plug (1) and check oil level from filler plug mounting hole as shown in the figure.


CAUTION:

Never start engine while checking oil level.

- Set a gasket on filler plug and install it on final drive assembly. Refer to [DLN-179, "Exploded View"](#).

CAUTION:

Never reuse gasket.



JPDID0312ZZ


INFOID:0000000010262361

Draining

- Stop engine.
- Remove drain plug (1) and drain gear oil.
- Set a gasket on drain plug and install it to final drive assembly and tighten to the specified torque. Refer to [DLN-179, "Exploded View"](#).

CAUTION:

Never reuse gasket.



JPDID0313ZZ

INFOID:0000000010262362

Refilling


- Remove filler plug (1). Fill with new gear oil until oil level reaches the specified level near filler plug mounting hole.

Oil grade and Viscosity

: Refer to [MA-15, "FOR NORTH AMERICA : Fluids and Lubricants"](#) (for NORTH AMERICA), [MA-16, "FOR MEXICO : Fluids and Lubricants"](#) (for MEXICO).

Oil capacity

: Refer to [DLN-198, "General Specifications"](#).



JPDID0312ZZ

- After refilling oil, check oil level. Set a gasket to filler plug, then install it to final drive assembly. Refer to [DLN-179, "Exploded View"](#).

CAUTION:


Never reuse gasket.

REMOVAL AND INSTALLATION

FRONT OIL SEAL

Exploded View

INFOID:0000000010262363



1. Front final drive assembly
2. Front oil seal
3. Companion flange
4. Drive pinon lock nut
- A. Oil seal lip

: Apply multi-purpose grease.

*: Apply anti-corrosion oil.

Refer to [GI-4, "Components"](#) for symbols not described on the above.

Removal and Installation

INFOID:0000000010262364

REMOVAL

CAUTION:

Verify identification stamp of replacement frequency put in the lower part of gear carrier to determine replacement for collapsible spacer when replacing front oil seal. Refer to "Identification stamp of replacement frequency of front oil seal". If collapsible spacer replacement is necessary, remove final drive assembly and disassemble it to replace front oil seal and collapsible spacer. Refer to [DLN-174, "Removal and Installation"](#) and [DLN-180, "Disassembly"](#).

NOTE:


The reuse of collapsible spacer is prohibited in principle. However, it is reusable on a one-time basis only in cases when replacing front oil seal.

Identification Stamp of Replacement Frequency of Front Oil Seal

- The diagonally shaded area in the figure shows stamping point for replacement frequency of front oil seal.
- The following table shows if collapsible spacer replacement is needed before replacing front oil seal.

When collapsible spacer replacement is required, disassemble final drive assembly to replace collapsible spacer and front oil seal. Refer to [DLN-180, "Disassembly"](#).

Stamp	collapsible spacer replacement
No stamp	Not required
"0" or "0" on the far right of stamp	Required
"01" or "1" on the far right of stamp	Not required



FRONT OIL SEAL

< REMOVAL AND INSTALLATION >

[FRONT FINAL DRIVE: R180A]

CAUTION:

Make a stamping after replacing front oil seal.

- After replacing front oil seal, make a stamping on the stamping point in accordance with the table below in order to identify replacement frequency.

CAUTION:


Make a stamping from left to right.

Stamp before stamping	Stamping on the far right	Stamping
No stamp	0	0
"0" (Front oil seal was replaced once.)	1	01
"01" (Collapsible spacer and front oil seal were replaced last time.)	0	010
"0" is on the far right. (Only front oil seal was replaced last time.)	1	...01
"1" is on the far right. (Collapsible spacer and front oil seal were replaced last time.)	0	...010

- Make a judgement if a collapsible spacer replace is required.
- Drain gear oil. Refer to [DLN-167, "Draining"](#).
- Remove the drive shafts from the front final drive assembly. Refer to [FAX-21, "Removal and Installation"](#).
- Remove the front propeller shaft from the front final drive assembly. Refer to [DLN-137, "Removal and Installation"](#).
- Measure the total preload torque using preload gauge (A) [SST: ST3127S000 (J-25765-A)].

NOTE:


Record the total preload torque measurement.




- Put matching mark (B) on the end of drive pinion. The matching mark should be in line with the matching mark (A) on companion flange (1).

CAUTION:

For matching, marks use paint. Never damage companion flange and drive pinion.



- Remove the drive pinion lock nut using flange wrench (commercial service tool).




FRONT OIL SEAL


< REMOVAL AND INSTALLATION >

[FRONT FINAL DRIVE: R180A]

8. Remove the companion flange using puller (commercial service tool).



9. Remove front oil seal using the puller [SST: KV381054S0 (J-34286)].



INSTALLATION


1. Drive the front oil seal in evenly until it becomes flush with the gear carrier using drifts (A and B).

A: Drift [SST: ST30720000 (J-25405)]

B: Drift [SST: ST27863000 (—)]

CAUTION:


- Never reuse oil seal.
- Never incline oil seal when installing.
- Apply multi-purpose grease to the lips and differential gear oil to the circumference of oil seal.



2. Install companion flange.

NOTE:

When reusing drive pinion, align the matching mark (B) of drive pinion with the matching mark (A) of companion flange, and then install companion flange (1).



FRONT OIL SEAL

< REMOVAL AND INSTALLATION >

[FRONT FINAL DRIVE: R180A]

3. Apply anti-corrosion oil to the thread and seat of new drive pinion lock nut, and temporarily tighten drive pinion lock nut to drive pinion, using flange wrench (commercial service tool).

A: Preload gauge [SST: ST3127S000 (J-25765-A)]

CAUTION:


Never reuse drive pinion lock nut.

4. Tighten drive pinion lock nut within the limits of specified torque so as to keep the pinion bearing preload within a standard values, using preload gauge [SST: ST3127S000 (J-25765-A)].

Total preload torque: A value that add 0.1 – 0.4 N·m (0.01 – 0.04 kg·m, 1 – 3 in·lb) to the measured value when removing.

CAUTION:


- Adjust to the lower limit of the drive pinion lock nut tightening torque first.
- If the preload torque exceeds the specified value, replace collapsible spacer and tighten it again to adjust. Never loosen drive pinion lock nut to adjust the preload torque.



5. Fit a dial indicator onto the companion flange face (inner side of the propeller shaft mounting bolt holes).
6. Rotate the companion flange to check for runout.

Companion flange runout : Refer to [DLN-198, "Companion Flange Runout"](#).

7. Fit a test indicator to the inner side of the companion flange (socket diameter).
8. Rotate the companion flange to check for runout.



Companion flange runout : Refer to [DLN-198, "Companion Flange Runout"](#).

9. If the runout value is outside the repair limit, follow the procedure below to adjust.
 - a. Check for runout while changing the phase between companion flange and drive pinion gear by 90° step, and search for the position where the runout is the minimum.
 - b. If the runout value is still outside of the limit after the phase has been changed, possible causes are be an assembly malfunction of drive pinion and pinion bearing and malfunction of pinion bearing. Check for these items and repair if necessary.
 - c. If the runout value is still outside of the limit after the check and repair, replace companion flange.
10. Install front propeller shaft. Refer to [DLN-137, "Removal and Installation"](#).
11. Install drive shaft. Refer to [FAX-21, "Removal and Installation"](#).
12. Refill gear oil to the final drive and check oil level. Refer to [DLN-167, "Refilling"](#).
13. Check the final drive for oil leakage. Refer to [DLN-167, "Inspection"](#).

SIDE OIL SEAL


< REMOVAL AND INSTALLATION >

[FRONT FINAL DRIVE: R180A]

SIDE OIL SEAL

Exploded View

INFOID:000000010262365



1. Front final drive assembly
2. Side oil seal
- A. Oil seal lip



Apply gear oil.



Apply multi-purpose grease.

Refer to [GI-4, "Components"](#) for symbols not described on the above.


Removal and Installation

INFOID:000000010262366

REMOVAL

1. Drain gear oil. Refer to [DLN-167, "Draining"](#).
2. Remove the drive shafts from the front final drive assembly. Refer to [FAX-21, "Removal and Installation"](#).
3. Remove the side oil seal using suitable tool.

CAUTION:
Never damage gear carrier.



INSTALLATION


1. Drive the new side oil seal in evenly until it becomes flush with the gear carrier using drifts (A and B).

A: Drift [SST: ST30720000 (J-25405)]

B: Drift [SST: ST27863000 (—)]

CAUTION:

- Never reuse side oil seal.
- Never incline the new side oil seal when installing.
- Apply multi-purpose grease to the lips and differential gear oil to the circumference of the new side oil seal.



SIDE OIL SEAL

< REMOVAL AND INSTALLATION >

[FRONT FINAL DRIVE: R180A]

2. Install drive shaft. Refer to [FAX-21, "Removal and Installation"](#).
3. Refill gear oil to the final drive and check oil level. Refer to [DLN-167, "Refilling"](#).
4. Check the final drive for oil leakage. Refer to [DLN-167, "Inspection"](#).

A

B

C

DLN

E

F

G

H

I

J

K

L

M

N

O


P

UNIT REMOVAL AND INSTALLATION

FRONT FINAL DRIVE ASSEMBLY

Exploded View

INFOID:000000010262367



1. Front final drive assembly

Refer to [GI-4. "Components"](#) for symbols in figure.

Removal and Installation

INFOID:000000010262368

REMOVAL

1. Drain the differential gear oil. Refer to [DLN-167. "Draining"](#).
2. Remove the drive shafts. Refer to [FAX-21. "Removal and Installation"](#).
3. Remove the front propeller shaft from the front final drive assembly. Refer to [DLN-137. "Removal and Installation"](#).
4. Disconnect the breather hose from the front final drive assembly.
5. Support the front final drive assembly using a suitable jack.
6. Remove the front final drive assembly bolts, then remove the front final drive assembly with a power tool.

CAUTION:

Secure the front final drive assembly to a suitable jack while removing it.

INSTALLATION

Note the following, and installation is in the reverse order of removal.

CAUTION:

Check that there are no pinched or restricted areas on the breather hose caused by bending or winding when installing it.

FRONT FINAL DRIVE ASSEMBLY

< UNIT REMOVAL AND INSTALLATION >

[FRONT FINAL DRIVE: R180A]

- Install the breather hose (1) as shown in the figure.

↖: Vehicle front

- Install the breather hose (1) of final side with the paint mark (A) facing vehicle front, and insert the breather hose until dimension (B) shown as follows.


B: 20 mm (0.79 in)

CAUTION:

- **Never reuse hose clamp.**
- **Install the hose clamp with the tab facing vehicle front.**
- Be sure to fix the breather hose in (C) position.
- If remove the bracket (2), align stopper part (D) to part (E) of suspension mounting bracket (3), and tighten the mounting bolt (4) to specified torque.

Specified torque: 8.3 N·m (0.85 kg-m, 73 in-lb)

- When oil leaks while removing final drive assembly, check oil level after the installation. Refer to [DLN-167, "Inspection"](#).



A

B

C

DLN

E

F

G

H

I

J

K

L

M

N

O

P

SIDE SHAFT

< UNIT DISASSEMBLY AND ASSEMBLY >


[FRONT FINAL DRIVE: R180A]

UNIT DISASSEMBLY AND ASSEMBLY

SIDE SHAFT

Exploded View

INFOID:000000010262369



- | | | |
|----------------------------------|--------------------------------|---|
| 1. Bushing | 2. Bearing cap | 3. Side bearing |
| 4. Side bearing adjusting washer | 5. Drive pinion | 6. Pinion height adjusting washer |
| 7. Pinion rear bearing | 8. Collapsible spacer | 9. Gasket |
| 10. Drain plug | 11. Side oil seal (left side) | 12. Pinion front bearing |
| 13. Front oil seal | 14. Companion flange | 15. Drive pinion lock nut |
| 16. Gear carrier | 17. Side shaft | 18. Side shaft bearing |
| 19. Snap ring | 20. Snap ring | 21. Side oil seal (right side) |
| 22. Drive gear | 23. Differential case assembly | 24. Housing spacer |
| 25. Filler plug | 26. Carrier cover | |
| A: Oil seal lip | B: Screw hole | C: Comply with the assembly procedure when tightening. Refer to DLN-181, "Assembly" . |

: Apply gear oil.

*: Apply anti-corrosion oil.

: Apply multi-purpose grease.

: Apply Genuine Silicone RTV or equivalent. Refer to [GI-22, "Recommended Chemical Products and Sealants"](#).

: Apply Genuine High Strength Thread Locking Sealant or equivalent. Refer to [GI-22, "Recommended Chemical Products and Sealants"](#).

Refer to [GI-4, "Components"](#) for symbols not described above.


Disassembly

INFOID:0000000010262370

1. Drain the differential gear oil if necessary.
2. Remove the carrier cover bolts
3. Remove carrier cover to insert the seal cutter (A) [SST: KV10111100 (J-37228)] between gear carrier and carrier cover.

CAUTION:


- Never damage the mating surface.
- Never insert flat-bladed screwdriver, this will damage the mating surface.




4. Remove side oil seal (right side) with a suitable tool.

CAUTION:

Never damage gear carrier.



5. Remove snap ring (hole side) with a suitable tool.




6. Remove differential side shaft assembly out of gear carrier with a suitable tool.

NOTE:

Tap on differential side shaft assembly from side gear side.

7. Remove snap ring (differential side shaft side).



A

B

C

DLN

E

F

G

H

I

J

K

L

M

N

O


P

SIDE SHAFT

< UNIT DISASSEMBLY AND ASSEMBLY >

[FRONT FINAL DRIVE: R180A]


- Press differential side shaft out of differential side shaft bearing.
CAUTION:
Never drop differential side shaft.
- Perform inspection after disassembly. Refer to [DLN-178](#), "[Inspection](#)".



INFOID:000000010262371

Assembly

- Press differential side shaft bearing to differential side shaft.
CAUTION:
Never reuse differential side shaft bearing.
- Install snap ring (differential side shaft side).
- Install differential side shaft assembly into gear carrier.
- Install snap ring (hole side).




- Install side oil seal (right side) until it becomes flush with the gear carrier, with the drifts (A and B).

A: Drift [SST: ST30720000 (J-25405)]

B: Drift [SST: ST27863000 (—)]

CAUTION:

- **Never reuse side oil seal.**
- **When installing, never incline oil seal.**
- **Apply multi-purpose grease onto oil seal lips and gear oil onto the circumference of oil seal.**



INFOID:000000010262372

Inspection

INSPECTION AFTER DISASSEMBLY

Side Shaft

- If it is chipped (by friction), cracked, damaged, or unusually worn, replace.

Bearing

- Clean up the disassembled parts.
- If any chipped (by friction), pitted, worn, rusted or scratched marks, or unusual noise from the bearing is observed, replace as a bearing assembly (as a new set).

Oil Seal

- Whenever disassembled, replace.
- If wear, deterioration of adherence (sealing force lips), or damage is detected on the lips, replace them.

DIFFERENTIAL ASSEMBLY


< UNIT DISASSEMBLY AND ASSEMBLY >

[FRONT FINAL DRIVE: R180A]

DIFFERENTIAL ASSEMBLY

Exploded View

INFOID:0000000110262373



- | | | |
|----------------------------------|--------------------------------|---|
| 1. Bushing | 2. Bearing cap | 3. Side bearing |
| 4. Side bearing adjusting washer | 5. Drive pinion | 6. Pinion height adjusting washer |
| 7. Pinion rear bearing | 8. Collapsible spacer | 9. Gasket |
| 10. Drain plug | 11. Side oil seal (left side) | 12. Pinion front bearing |
| 13. Front oil seal | 14. Companion flange | 15. Drive pinion lock nut |
| 16. Gear carrier | 17. Side shaft | 18. Side shaft bearing |
| 19. Snap ring | 20. Snap ring | 21. Side oil seal (right side) |
| 22. Drive gear | 23. Differential case assembly | 24. Housing spacer |
| 25. Filler plug | 26. Carrier cover | |
| A: Oil seal lip | B: Screw hole | C: Comply with the assembly procedure when tightening. Refer to DLN-181, "Assembly" . |

: Apply gear oil.

: Apply anti-corrosion oil.

: Apply multi-purpose grease.

DIFFERENTIAL ASSEMBLY

< UNIT DISASSEMBLY AND ASSEMBLY >

[FRONT FINAL DRIVE: R180A]

: Apply Genuine Silicone RTV or equivalent. Refer to [GI-22, "Recommended Chemical Products and Sealants"](#).

: Apply Genuine High Strength Thread Locking Sealant or equivalent. Refer to [GI-22, "Recommended Chemical Products and Sealants"](#).

Refer to [GI-4, "Components"](#) for symbols not described above.


Disassembly

INFOID:000000010262374


1. Remove bushing with drift (commercial service tool).
2. Remove differential side shaft assembly. Refer to [DLN-177, "Disassembly"](#).
3. Remove side oil seal (left side) from gear carrier with a suitable tool.
4. For proper reinstallation, paint matching marks on one side of the side bearing cap and gear carrier.

CAUTION:


- For matching marks, use paint. Never damage side bearing cap and gear carrier.
- Bearing caps are manufactured as integral molding. Use the matching marks to them in their original positions.



5. Remove the side bearing caps.




6. Lift the differential case assembly out of the gear carrier with sliding hammer (commercial service tool).



7. Remove the differential case assembly with the side bearing outer race and side bearing adjusting washer.

CAUTION:

- Keep side bearing outer races together with side bearing inner races. Do not mix them up.
- Keep side bearing adjusting washers together with side bearings.



DIFFERENTIAL ASSEMBLY

< UNIT DISASSEMBLY AND ASSEMBLY >

[FRONT FINAL DRIVE: R180A]


8. Remove housing spacer.
9. Remove side bearing inner race with the puller (A) and base (B).

A: Puller [SST: ST33051001 (J-22888-20)]

B: Base [SST: ST33061000 (J-8107-2)]

CAUTION:

- To prevent damage to the side bearing and drive gear, place copper plates between these parts and vise.
- It is necessary to remove side bearing inner race except when it is replaced.



10. For proper reinstallation, paint matching marks on the differential case and drive gear.

CAUTION:


For matching marks, use paint. Never damage differential case and drive gear.

11. Remove the drive mounting gear bolts.
12. Tap the drive gear off the differential case using suitable tool.

CAUTION:

Tap evenly all around to keep drive gear from bending.

13. Perform inspection after disassembly. Refer to [DLN-186, "Inspection"](#).



Assembly

INFOID:0000000010262375

1. Apply thread locking sealant into the threaded holes of the drive gear and install the new drive gear bolts.
 - Use Genuine High Strength Thread Locking Sealant or equivalent. Refer to [GI-22, "Recommended Chemical Products and Sealants"](#).


CAUTION:

Clean degrees drive gear back and threaded holes sufficiently.

2. Install the drive gear to differential case assembly.

CAUTION:

Align the matching marks of differential case assembly and drive gear



3. Tighten the drive gear mounting bolts with the following procedure.

CAUTION:

Apply anti-corrosion oil to the thread and seat of mounting bolts.

- a. Tighten the bolts in a crisscross fashion to the specified torque.


Drive gear mounting bolts tightening torque : 58.8 N·m (6.0 kg-m, 43 ft-lb)

- b. Tighten the bolts additionally at the specified angle.

Drive gear mounting bolts tightening angle : 34 to 39 degree

CAUTION:

Check the tightening angle using the angle wrench (A) [SST: KV10112100 (BT-8653-A)]. Never make judgment by visual inspection.



DIFFERENTIAL ASSEMBLY

< UNIT DISASSEMBLY AND ASSEMBLY >

[FRONT FINAL DRIVE: R180A]

4. Press side bearing inner races to the differential case with the drift (A) and the base (B).


A: Drift [SST: ST33230000 (J-35867)]

B: Base [SST: ST33061000 (J-8107-2)]

CAUTION:

Never reuse side bearing inner races.


5. Install housing spacer.




6. Install the differential case assembly with the side bearing outer races into the gear carrier.

CAUTION:

- **Never reuse side bearing outer race when replacing side bearing inner race (replace as a set).**
- **Apply differential gear oil to the side bearings.**




7. Insert left and right original side bearing adjusting washers in place between side bearings and gear carrier.



8. Install the side bearing caps with the matching marks aligned and tighten the side bearing cap bolts to the specified torque.

CAUTION:

Align matching marks on bearing cap with that on gear carrier.




9. Install side oil seal (left side) until it becomes flush with the gear carrier with the drift (A and B).

A: Drift [SST: ST30720000 (J-25405)]

B: Drift [SST: ST27863000 (—)]

CAUTION:

- **Never reuse side oil seal.**
- **When installing, never incline oil seal.**
- **Apply multi-purpose grease onto oil seal lips, and gear oil onto the circumference of oil seal.**




DIFFERENTIAL ASSEMBLY

< UNIT DISASSEMBLY AND ASSEMBLY >

[FRONT FINAL DRIVE: R180A]

10. Check and adjust drive gear runout, tooth contact, backlash, and total preload torque. Refer to [DLN-183, "Adjustment"](#).
Recheck above items. Readjust the above description, if necessary.
11. Apply sealant to match surface of carrier cover.
 - Use Genuine Silicone RTV or equivalent. Refer to [GI-22, "Recommended Chemical Products and Sealants"](#).**CAUTION:**
Remove any old sealant adhering to the mating surfaces. Also remove any moisture, oil, or foreign material adhering to the application and mating surfaces.
12. Install the carrier cover to the gear carrier. Tighten the bolts to the specified torque.
13. Install side shaft. Refer to [DLN-178, "Assembly"](#).
14. Install bushing with drift (commercial service tool).



INFOID:0000000010262376

Adjustment


TOTAL PRELOAD TORQUE

1. Install the differential side shaft. Refer to [DLN-178, "Assembly"](#).
2. Rotate the drive pinion back and forth 2 to 3 times to check for unusual noise and rotation malfunction.
3. Rotate the drive pinion at least 20 times to check for smooth operation of the bearings.
4. Measure total preload torque with the preload gauge [SST: ST3127S000 (J-25765-A)].

Total preload torque : Refer to [DLN-198, "Preload Torque"](#).

NOTE:

Total preload torque = Drive pinion bearing preload torque + Side bearing preload torque



- If the measured value is out of the specification, check and adjust each part. Adjust the drive pinion bearing preload torque first, then adjust the side bearing preload torque.

When the preload torque is large

On drive pinion bearings: Decrease the drive pinion bearing adjusting washer and drive pinion adjusting washer thickness. For selecting adjusting washer, refer to the latest parts information.

On side bearings: Increase the side bearing adjusting washer thickness. For selecting adjusting washer, refer to the latest parts information.

When the preload torque is small

On drive pinion bearings: Increase the drive pinion bearing adjusting washer and drive pinion adjusting washer thickness. For selecting adjusting washer, refer to the latest parts information.

On side bearings: Decrease the side bearing adjusting washer thickness. For selecting adjusting washer, refer to the latest parts information.

DRIVE GEAR RUNOUT

1. Remove carrier cover. Refer to [DLN-180, "Disassembly"](#).

DIFFERENTIAL ASSEMBLY

< UNIT DISASSEMBLY AND ASSEMBLY >

[FRONT FINAL DRIVE: R180A]


2. Fit a dial indicator to the drive gear back face.
3. Rotate the drive gear to measure runout.

Drive gear runout : Refer to [DLN-198, "Drive Gear Runout"](#).

- If the runout is outside of the repair limit, check drive gear assembly condition; foreign material may be caught between the drive gear and differential case, or differential case or drive gear may be deformed.

CAUTION:

Replace drive gear and drive pinion as a set.




TOOTH CONTACT

1. Remove carrier cover. Refer to [DLN-180, "Disassembly"](#).
2. Apply red lead to the drive gear.

CAUTION:


Apply red lead to both the faces of 3 to 4 gears at 4 locations evenly spaced on the drive gear.



3. Rotate the drive gear back and forth several times. Then check for correct drive pinion to drive gear tooth contact as shown.

CAUTION:








Check tooth contact on drive side and reverse side.



DIFFERENTIAL ASSEMBLY


< UNIT DISASSEMBLY AND ASSEMBLY >

[FRONT FINAL DRIVE: R180A]


Tooth contact condition		Drive pinion adjusting shim selection value [mm (in)]	Adjustment (Yes/No)	Possible cause
Drive side	Back side			
Heel side 	Toe side 	Thicker ↑	Yes	Occurrence of noise and scoring sound in all speed ranges.
				Occurrence of noise when accelerating.
				
		0	No	—
				
				
		Thinner ↓	Yes	Occurrence of noise at constant speed and decreasing speed.
				Occurrence of noise and scoring sound in all speed ranges.
				

SDIA2549E

4. If the tooth contact is improperly adjusted, adjust the drive pinion height (dimension X).



- If the tooth contact is near the face (face contact), or near the heel (heel contact), use a thicker drive pinion height adjusting washer to move drive pinion closer to the drive gear. For selecting adjusting washer, refer to the latest parts information.




DIFFERENTIAL ASSEMBLY

< UNIT DISASSEMBLY AND ASSEMBLY >

[FRONT FINAL DRIVE: R180A]

- If the tooth contact is near the flank (flank contact), or near the toe (toe contact), use a thinner drive pinion height adjusting washer to move the drive pinion farther from the drive gear. For selecting adjusting washer, refer to the latest parts information.



BACKLASH

1. Remove carrier cover. Refer to [DLN-180, "Disassembly"](#).
2. Fit a dial indicator to the drive gear face to measure the backlash.

Backlash

: Refer to [DLN-198, "Backlash"](#).


- If the backlash is outside of the specification, change the thickness of the side bearing adjusting washers.

When the backlash is large:

Make drive gear back side adjusting washer thicker, and drive tooth side adjusting washer thinner by the same amount. For selecting adjusting washer, refer to the latest parts information.

If the backlash is less than specification:

Make drive gear back side adjusting washer thinner, and drive tooth side adjusting washer thicker by the same amount. For selecting adjusting washer, refer to the latest parts information.



CAUTION:

Never change the total amount of washers as it changes the preload torque.

Inspection

INFOID:0000000010262377

INSPECTION AFTER DISASSEMBLY

Drive Gear and Drive Pinion

- Clean up the disassembled parts.
- If the gear teeth never mesh or line-up correctly, determine the cause and adjust or replace as necessary.
- If the gears are worn, cracked, damaged, pitted or chipped (by friction) noticeably, replace with new drive gear and drive pinion as a set.

Bearing

- Clean up the disassembled parts.
- If any chipped (by friction), pitted, worn, rusted or scratched marks, or unusual noise from the bearing is observed, replace as a bearing assembly (as a new set).

Side Gear and Pinion Mate Gear

- Clean up the disassembled parts.
- If any cracks or damage on the surface of the tooth is found, replace.
- If any worn or chipped mark on the contact sides of the thrust washer is found, replace.

Side Gear Thrust Washer and Pinion Mate Thrust Washer

- Clean up the disassembled parts.
- If it is chipped (by friction), damaged, or unusually worn, replace.

Oil Seal

DIFFERENTIAL ASSEMBLY

< UNIT DISASSEMBLY AND ASSEMBLY >

[FRONT FINAL DRIVE: R180A]

- Whenever disassembled, replace.
- If wear, deterioration of adherence (sealing force lips), or damage is detected on the lips, replace them.

Differential Case

- Clean up the disassembled parts.
- If any wear or crack on the contact sides of the differential case is found, replace.

A

B

C

DLN

E

F

G

H

I

J

K

L

M

N

O

P

DRIVE PINION


< UNIT DISASSEMBLY AND ASSEMBLY >

[FRONT FINAL DRIVE: R180A]

DRIVE PINION

Exploded View

INFOID:000000010262378



- | | | |
|----------------------------------|--------------------------------|---|
| 1. Bushing | 2. Bearing cap | 3. Side bearing |
| 4. Side bearing adjusting washer | 5. Drive pinion | 6. Pinion height adjusting washer |
| 7. Pinion rear bearing | 8. Collapsible spacer | 9. Gasket |
| 10. Drain plug | 11. Side oil seal (left side) | 12. Pinion front bearing |
| 13. Front oil seal | 14. Companion flange | 15. Drive pinion lock nut |
| 16. Gear carrier | 17. Side shaft | 18. Side shaft bearing |
| 19. Snap ring | 20. Snap ring | 21. Side oil seal (right side) |
| 22. Drive gear | 23. Differential case assembly | 24. Housing spacer |
| 25. Filler plug | 26. Carrier cover | |
| A: Oil seal lip | B: Screw hole | C. Comply with the assembly procedure when tightening. Refer to DLN-181, "Assembly" . |

: Apply gear oil.

*: Apply anti-corrosion oil.

: Apply multi-purpose grease.

DRIVE PINION

< UNIT DISASSEMBLY AND ASSEMBLY >

[FRONT FINAL DRIVE: R180A]

: Apply Genuine Silicone RTV or equivalent. Refer to [GI-22, "Recommended Chemical Products and Sealants"](#).


: Apply Genuine High Strength Thread Locking Sealant or equivalent. Refer to [GI-22, "Recommended Chemical Products and Sealants"](#).

Refer to [GI-4, "Components"](#) for symbols not described above.

Disassembly

INFOID:0000000110262379


1. Remove the side shaft. Refer to [DLN-177, "Disassembly"](#).
2. Remove the differential assembly. Refer to [DLN-180, "Disassembly"](#).
3. Remove the drive pinion lock nut with a flange wrench (commercial service tool).




4. Put matching mark (B) on the end of drive pinion. The matching mark should be in line with the matching mark (A) on companion flange (1).

CAUTION:

For matching, marks use paint. Never damage companion flange and drive pinion.




5. Remove the companion flange with the puller (commercial service tool).



6. Press the drive pinion assembly.

CAUTION:

Never drop drive pinion assembly.



A
B
C
DLN
E
F
G
H
I
J
K
L
M
N
O
P

DRIVE PINION

< UNIT DISASSEMBLY AND ASSEMBLY >


[FRONT FINAL DRIVE: R180A]

7. Remove the front oil seal with a suitable tool.


CAUTION:

Never damage gear carrier.

8. Remove the drive pinion front bearing inner race.
9. Remove the collapsible spacer.



10. Remove the drive pinion rear bearing inner race and drive pinion height adjusting washer with the replacer (commercial service tool).




11. Remove the drive pinion front and rear bearing outer races by tapping them uniformly with a suitable tool.

CAUTION:

Never damage gear carrier.

12. Perform inspection after disassembly. Refer to [DLN-196](#), "[Inspection](#)".



DRIVE PINION

< UNIT DISASSEMBLY AND ASSEMBLY >

[FRONT FINAL DRIVE: R180A]

INFOID:000000010262380

Assembly

1. Install drive pinion rear bearing outer race and drive pinion front bearing outer race using drifts (A, B, and C).

A: Drift bar [SST: ST30611000 (J-25742-1)]


B: Drift [SST: ST30313000 (J-25742-3)]

C: Drift [SST: KV38100200 (J-26233)]

CAUTION:

- First tap the drive pinion bearing outer race until it becomes flush with the gear carrier.
- Never reuse drive pinion front and rear bearing outer race.


2. Select pinion height adjusting washer. Refer to [DLN-193](#), "Adjustment".



3. Install selected drive pinion height adjusting washer (2) to drive pinion. Press pinion rear bearing inner race (1) to it, using drift (A) [SST: ST30901000 (J-26010-01)].

CAUTION:

- Be careful of the direction of pinion height adjusting washer. (Assemble as shown in the figure.)
- Never reuse pinion rear bearing inner race.



4. Assemble collapsible spacer.

CAUTION:

Never reuse collapsible spacer.

5. Assemble drive pinion into gear carrier.


CAUTION:

Apply gear oil to pinion rear bearing.

6. Assemble pinion front bearing inner race to drive pinion assembly.

CAUTION:

- Never reuse pinion front bearing inner race.
- Apply gear oil to pinion front bearing.




DRIVE PINION

< UNIT DISASSEMBLY AND ASSEMBLY >

[FRONT FINAL DRIVE: R180A]

7. Using drift [SST: ST33200000 (J-26082)], press the pinion front bearing inner race to drive pinion as far as drive pinion nut can be tightened.




8. Install front oil seal as shown in figure with the drifts (A and B).

A: Drift [SST: ST30720000 (J-25405)]

B: Drift [SST: ST27863000 (—)]

CAUTION:


- **Never reuse oil seal.**
- **When installing, never incline oil seal.**
- **Apply multi-purpose grease onto oil seal lips, and gear oil onto the circumference of oil seal.**



9. Install companion flange.

NOTE:

When reusing drive pinion, align the matching mark (B) of drive pinion with the matching mark (A) of companion flange, and then install companion flange (1).



DRIVE PINION

< UNIT DISASSEMBLY AND ASSEMBLY >

[FRONT FINAL DRIVE: R180A]

10. Temporarily tighten drive pinion lock nut to drive pinion, using flange wrench (A).

A: Flange wrench (commercial service tool)

B: Preload gauge [SST: ST3127S000 (J-25765-A)]

CAUTION:

- Apply anti-corrosion oil to the thread and seat of the drive pinion lock nut
- Never reuse drive pinion lock nut.

11. Tighten to drive pinion lock nut using flange wrench (commercial service tool), while adjusting pinion bearing preload torque using preload gauge [SST: ST3127S000 (J-25765-A)].

Pinion bearing preload : Refer to [DLN-198, "Pre-load Torque"](#).

CAUTION:

- Adjust to the lower limit of the drive pinion lock nut tightening torque first.
- After adjustment, rotate drive pinion back and forth 2 to 3 times to check for unusual noise, rotation malfunction, and other malfunctions.

12. Install differential case assembly. Refer to [DLN-181, "Assembly"](#).

CAUTION:

Never install carrier cover yet.



13. Check and adjust drive gear runout, tooth contact, drive gear to drive pinion backlash. Refer to [DLN-183, "Adjustment"](#).
14. Install side shaft. Refer to [DLN-178, "Assembly"](#).
15. Check and adjust companion flange runout. Refer to [DLN-193, "Adjustment"](#).
16. Check total preload torque. Refer to [DLN-183, "Adjustment"](#).
17. Install carrier cover. Refer to [DLN-181, "Assembly"](#).

Adjustment

INFOID:0000000010262381

PINION GEAR HEIGHT

1. Make sure all parts are clean and that the bearings are well lubricated.
2. Assemble the pinion gear bearings into the differential shim selector tool [SST: — (J-34309)].





A
B
C
DLN
E
F
G
H
I
J
K
L
M
N
O
P

DRIVE PINION


< UNIT DISASSEMBLY AND ASSEMBLY >

[FRONT FINAL DRIVE: R180A]


- **Pinion front bearing;** make sure the J-34309-3 pinion front bearing seat is secured tightly against the J-34309-2 gauge anvil. Then turn the pinion front bearing pilot, J-34309-7, to secure the bearing in its proper position.
 - **Pinion rear bearing;** the pinion rear bearing pilot, J-34309-8, is used to center the pinion rear bearing only. The pinion rear bearing locking seat, J-34309-4, is used to lock the bearing to the assembly.
 - **Installation of J-34309-9 and J-34309-16;** place a suitable 2.5 mm (0.098 in) thick plain washer between J-34309-9 and J-34309-16. Both surfaces of J-34309-9 and J-34309-16 must be parallel with a clearance of 2.5 mm (0.098 in).
3. Install the pinion rear bearing inner race into gear carrier. Then place the pinion preload shim selector tool, J-34309-1, gauge screw assembly.



4. Assemble the pinion front bearing inner race and the J-34309-2 gauge anvil. Assemble them together with the J-34309-1 gauge screw in gear carrier. Make sure that the pinion height gauge plate, J-34309-16, turns a full 360 degrees. Tighten the two sections together by hand.




5. Turn the assembly several times to seat the bearings.



6. Measure the turning torque at the end of the J-34309-2 gauge anvil using preload gauge [SST: ST3127S000 (J-25765-A)].

Turning torque specification : 1.08 – 1.66 N·m (0.11 – 0.16 kg-m, 10 – 14 in-lb)



DRIVE PINION


< UNIT DISASSEMBLY AND ASSEMBLY >

[FRONT FINAL DRIVE: R180A]


- Place the J-34309-10 "R180A" pinion height adapter onto the gauge plate and tighten it by hand.

CAUTION:


Make sure all machined surfaces are clean.




- Position the side bearing discs, J-25269-18, and arbor firmly into the side bearing bores. Install the bearing caps and tighten bearing cap mounting bolts to the specified torque. Refer to [DLN-188, "Exploded View"](#).



- Select the correct standard pinion height adjusting washer thickness. Select by using a standard gauge of 3 mm (0.12 in) and J-34309-101 feeler gauge. Measure the distance between the J-34309-11 pinion height adapter including the standard gauge and the arbor.




- Write down exact measurement (the value of feeler gauge).



- Correct the pinion height washer size by referring to the "pinion head number".

There are two numbers painted on the drive pinion. The first one refers to the drive pinion and drive gear as a matched set. This number should be the same as the number on the drive gear. The second number is the "pinion head height number". It refers to the ideal pinion height from standard for quietest operation. Use the following chart to determine the correct pinion height washer.




DRIVE PINION

< UNIT DISASSEMBLY AND ASSEMBLY >

[FRONT FINAL DRIVE: R180A]

Pinion head height number	Add or remove from the standard pinion height adjusting washer thickness measurement
-6	Add 0.06 mm (0.0024 in)
-5	Add 0.05 mm (0.0020 in)
-4	Add 0.04 mm (0.0016 in)
-3	Add 0.03 mm (0.0012 in)
-2	Add 0.02 mm (0.0008 in)
-1	Add 0.01 mm (0.0004 in)
0	Use the selected washer thickness
+1	Subtract 0.01 mm (0.0004 in)
+2	Subtract 0.02 mm (0.0008 in)
+3	Subtract 0.03 mm (0.0012 in)
+4	Subtract 0.04 mm (0.0016 in)
+5	Subtract 0.05 mm (0.0020 in)
+6	Subtract 0.06 mm (0.0024 in)

12. Select the correct pinion height adjusting washer. For selecting adjusting washer, refer to the latest parts information.
13. Remove the J-34309 differential shim selector tool from the final drive housing. Then disassemble to retrieve the pinion bearings.




COMPANION FLANGE RUNOUT

1. Fit a dial indicator onto the companion flange face (inner side of the propeller shaft mounting bolt holes).
2. Rotate companion flange to check for runout.

Companion flange runout : Refer to [DLN-198, "Companion Flange Runout"](#).

3. Fit a test indicator to the inner side of companion flange (socket diameter).
4. Rotate companion flange to check for runout.



Companion flange runout : Refer to [DLN-198, "Companion Flange Runout"](#).

5. If the runout value is outside the runout limit, follow the procedure below to adjust.
 - a. Check for runout while changing the phase between companion flange and drive pinion by 90° step, and search for the position where the runout is the minimum.
 - b. If the runout value is still outside of the limit after the phase has been changed, possible cause will be an assembly malfunction of drive pinion and pinion bearing and malfunction of pinion bearing. Check for these items and repair if necessary.
 - c. If the runout value is still outside of the limit after the check and repair, replace companion flange.

Inspection

INFOID:0000000010262382

INSPECTION AFTER DISASSEMBLY

Drive Gear and Drive Pinion

- Clean up the disassembled parts.
- If the gear teeth never mesh or line-up correctly, determine the cause and adjust or replace as necessary.

DRIVE PINION

< UNIT DISASSEMBLY AND ASSEMBLY >

[FRONT FINAL DRIVE: R180A]

- If the gears are worn, cracked, damaged, pitted or chipped (by friction) noticeably, replace with new drive gear and drive pinion as a set.

A

Bearing

- Clean up the disassembled parts.
- If any chipped (by friction), pitted, worn, rusted or scratched marks, or unusual noise from the bearing is observed, replace as a bearing assembly (as a new set).

B

Oil Seal

- Whenever disassembled, replace.
- If wear, deterioration of adherence (sealing force lips), or damage is detected on the lips, replace them.

C

Companion Flange

- Clean up the disassembled parts.
- If any chipped mark [about 0.1 mm, (0.004 in)] or other damage on the contact sides of the lips of the companion flange is found, replace.

DLN

E

F

G

H

I

J

K

L

M

N

O

P

SERVICE DATA AND SPECIFICATIONS (SDS)

< SERVICE DATA AND SPECIFICATIONS (SDS)

[FRONT FINAL DRIVE: R180A]

SERVICE DATA AND SPECIFICATIONS (SDS)

SERVICE DATA AND SPECIFICATIONS (SDS)

General Specifications

INFOID:0000000010262383

Applied model	4WD
	VK56VD
	A/T
Final drive model	R180A
Gear ratio	2.937
Number of teeth (Drive gear/Drive pinion)	47/16
Oil capacity (Approx.) ℓ (US pt, Imp pt)	0.75 (1-5/8, 1-3/8)
Number of pinion gears	4
Drive pinion adjustment spacer type	Collapsible

Drive Gear Runout

INFOID:0000000010262384

Unit: mm (in)

Item	Limit
Drive gear back face runout	0.05 (0.0020)

Preload Torque

INFOID:0000000010262385

Unit: N·m (kg-m, in-lb)

Item	Standard
Pinion bearing (P1)	1.08 – 1.66 (0.11 – 0.16, 10 – 14)
Side bearing (P2)	0.59 – 1.08 (0.06 – 0.11, 6 – 9)
Side bearing to pinion bearing (Total preload) (Total preload = P1 + P2)	1.67 – 2.74 (0.17 – 0.27, 15 – 24)

Backlash

INFOID:0000000010262386

Unit: mm (in)

Item	Standard
Drive gear to drive pinion gear	0.10 – 0.15 (0.0039 – 0.0059)

Companion Flange Runout

INFOID:0000000010262387

Unit: mm (in)

Item	Limit
Companion flange face	0.10 (0.004)
Inner side of the companion flange	0.10 (0.004)

PRECAUTION

PRECAUTIONS

Precautions for Removing Battery Terminal

INFOID:000000010262388

- When removing the 12V battery terminal, turn OFF the ignition switch and wait at least 30 seconds.

NOTE:

ECU may be active for several tens of seconds after the ignition switch is turned OFF. If the battery terminal is removed before ECU stops, then a DTC detection error or ECU data corruption may occur.

- For vehicles with the 2-batteries, be sure to connect the main battery and the sub battery before turning ON the ignition switch.


NOTE:

If the ignition switch is turned ON with any one of the terminals of main battery and sub battery disconnected, then DTC may be detected.

- After installing the 12V battery, always check "Self Diagnosis Result" of all ECUs and erase DTC.

NOTE:

The removal of 12V battery may cause a DTC detection error.



Service Notice or Precautions for Rear Final Drive

INFOID:000000010262389

- Check for the correct installation status prior to removal or disassembly. If matching marks are required, be certain they never interfere with the function of the parts when applied.
- Overhaul should be done in a clean work area, it is preferable to work in dustproof area.
- Before disassembly, using steam or white gasoline, completely remove sand and mud from the exterior of the unit, preventing them from entering into the unit during disassembly or assembly.
- Check appearance of the disassembled parts for damage, deformation, and unusual wear. Replace them with new ones, if necessary.
- Gaskets, seals and O-rings should be replaced any time when the unit is disassembled.
- In principle, tighten bolts or nuts gradually in several steps working diagonally from inside to outside. If tightening sequence is specified, observe it.
- Clean and flush the parts sufficiently and blow-dry them.
- Be careful not to damage sliding surfaces and mating surfaces.
- When applying sealant, remove the old sealant from the mounting surface; then remove any moisture, oil, and foreign materials from the application and mounting surfaces.
- Always use shop paper for cleaning the inside of components.
- Never use cotton gloves or shop rags to prevent entering of lint.
- During assembly, observe the specified tightening torque, and apply new gear oil, petroleum jelly, or multi-purpose grease as specified for each vehicle, if necessary.

PREPARATION

< PREPARATION >

[REAR FINAL DRIVE: R230]







PREPARATION

PREPARATION

Special Service Tool

INFOID:0000000010262390








The actual shapes of TechMate tools may differ from those of special service tools illustrated here.

Tool number (TechMate No.) Tool name		Description
KV40104100 (—) Attachment	 ZZA0804D	Removing side flange
ST36230000 (J-25840-A) Sliding hammer	 ZZA0803D	Removing side flange
ST3127S000 (J-25765-A) Preload gauge	 ZZA0806D	Measuring pinion bearing preload and total preload
KV381054S0 (J-34286) Puller	 ZZA0601D	Removing front oil seal
ST15310000 (J-25640-B) Drift a: 96 mm (3.78 in) dia. b: 84 mm (3.31 in) dia.	 S-NT673	Installing front oil seal
KV38108000 (—) Protector	 S-NT129	Installing side flange

PREPARATION

< PREPARATION >






[REAR FINAL DRIVE: R230]

Tool number (TechMate No.) Tool name	Description	A
ST35271000 (J26091) Drift a: 72 mm (2.83 in) dia. b: 63 mm (2.48 in) dia.  ZZA1143D	Installing side oil seal	B
KV10111100 (J-37228) Seal cutter  S-NT046	Removing carrier cover	C
KV38100800 (J-25604-01) Attachment A: 541 mm (21.30 in) B: 200 mm (7.87 in)  SDIA0267E	Securing unit assembly	DLN
ST33051001 (J-22888-20) Puller  PDIA0747J	Removing side bearing inner race	E
KV40104730 (—) Drift a: 53.7 mm (2.11 in) dia. b: 47 mm (1.85 in) dia.  S-NT108	Removing and installing side bearing inner race	F
KV10112100 (BT-8653-A) Angle wrench  ZZA0120D	Tightening the drive gear mounting bolt	G
ST01550002 (—) Drift a: 65 mm (2.56 in) dia. b: 56 mm (2.20 in) dia. c: 40 mm (1.57 in) dia.  ZZA1046D	Installing side bearing inner race	H

PREPARATION

< PREPARATION >

[REAR FINAL DRIVE: R230]

Tool number (TechMate No.) Tool name	Description
— (J-8129) Spring gauge  NT127	Measuring turning torque
KV38103300 (—) Drift a: 99 mm (3.90 in) dia.  PDIA0933E	Installing drive pinion rear bearing outer race
ST30611000 (J-25742-1) Drift bar  S-NT090	Installing drive pinion front bearing outer race
ST30621000 (J-25742-5) Drift a: 79 mm (3.11 in) dia. b: 59 mm (2.32 in) dia.  ZZA1000D	Installing drive pinion front bearing outer race
ST30022000 (—) Drift a: 110 mm (4.33 in) dia. b: 56 mm (2.20 in) dia. c: 46 mm (1.81 in) dia.  ZZA0978D	Installing pinion rear bearing inner race






Commercial Service Tool

INFOID:0000000010262391

PREPARATION

< PREPARATION >

[REAR FINAL DRIVE: R230]

Tool name	Description
Flange wrench	Removing and installing drive pinion lock nut
 NT035	
Puller	Removing companion flange
 ZZA0119D	
Sliding hammer	Removing differential case assembly
 NT125	
Puller	Removing drive pinion rear bearing inner race
 ZZA0700D	
Spacer a: 60 mm (2.36 in) dia. b: 36 mm (1.42 in) dia. c: 30 mm (1.18 in)	Installing drive pinion front bearing inner race
 ZZA1133D	
Power tool	Loosing nuts and bolts
 PBIC0190E	

A
B
C
DLN
E
F
G
H
I
J
K
L
M
N
O
P


SYSTEM DESCRIPTION

STRUCTURE AND OPERATION

Sectional View

INFOID:000000010262392

CROSS-SECTIONAL VIEW



PDIA0923E

- | | | |
|------------------------|-------------------------|---------------------|
| 1. Side flange | 2. Pinion mate gear | 3. Drive gear |
| 4. Pinion mate shaft | 5. Differential case | 6. Side bearing |
| 7. Drive pinion | 8. Pinion front bearing | 9. Companion flange |
| 10. Collapsible spacer | 11. Pinion rear bearing | 12. Side gear |

NOISE, VIBRATION AND HARSHNESS (NVH) TROUBLESHOOTING

< SYMPTOM DIAGNOSIS >

[REAR FINAL DRIVE: R230]

SYMPTOM DIAGNOSIS

NOISE, VIBRATION AND HARSHNESS (NVH) TROUBLESHOOTING

NVH Troubleshooting Chart

INFOID:0000000010262393

Use the chart below to find the cause of the symptom. If necessary, repair or replace these parts.

Reference page		DLN-228, "Inspection"	DLN-223, "Adjustment"	DLN-228, "Inspection"	DLN-223, "Adjustment"	DLN-223, "Adjustment"	DLN-206, "Inspection"	NVH of FRONT PROPELLER SHAFT in this section. NVH of REAR PROPELLER SHAFT in this section.	NVH in FAX, RAX, and RSU sections.	NVH in WT section.	NVH in WT section.	NVH in RAX section.	NVH in BR section.	NVH in ST section.
Possible cause and SUSPECTED PARTS		Gear tooth rough	Gear contact improper	Tooth surfaces worn	Backlash incorrect	Companion flange excessive runout	Gear oil improper	PROPELLER SHAFT	AXLE AND SUSPENSION	TIRES	ROAD WHEEL	DRIVE SHAFT	BRAKES	STEERING
Symptom	Noise	x	x	x	x	x	x	x	x	x	x	x	x	x

x: Applicable

A
B
C
DLN
E
F
G
H
I
J
K
L
M
N
O
P

PERIODIC MAINTENANCE

REAR DIFFERENTIAL GEAR OIL

Inspection

INFOID:0000000010262394

OIL LEAKAGE

Check that differential gear oil is not leaking from the rear final drive assembly or around it.

OIL LEVEL

- Remove filler plug (1) and check oil level from filler plug mounting hole as shown in the figure.


CAUTION:

Never start engine while checking oil level.

- Set a gasket on filler plug and install it on final drive assembly. Refer to [DLN-216, "Exploded View"](#).

CAUTION:

Never reuse gasket.




Draining

INFOID:0000000010262395

- Stop the engine.
- Remove drain plug (1) and drain gear oil.
- Set a gasket on drain plug and install it to final drive assembly and tighten to the specified torque. Refer to [DLN-216, "Exploded View"](#).

CAUTION:

Never reuse gasket.




Refilling

INFOID:0000000010262396

- Remove filler plug (1). Fill with new gear oil until oil level reaches the specified level near filler plug mounting hole.

Oil grade and viscosity : Refer to [MA-15, "FOR NORTH AMERICA : Fluids and Lubricants"](#) (for NORTH AMERICA), [MA-16, "FOR MEXICO : Fluids and Lubricants"](#) (for MEXICO).

Oil capacity : Refer to [DLN-235, "General Specification"](#).



- After refilling oil, check oil level. Set a gasket to filler plug, then install it to final drive assembly. Refer to [DLN-216, "Exploded View"](#).

CAUTION:


Never reuse gasket.

REMOVAL AND INSTALLATION

FRONT OIL SEAL

Exploded View

INFOID:0000000010262397



1. Final drive assembly
2. Front oil seal
3. Companion flange
4. Drive pinion lock nut
A. Oil seal lip

⇐: Vehicle front

: Apply gear oil.

*: Apply anti-corrosion oil.

Refer to [GI-4, "Components"](#) for symbols not described above.

Removal and Installation

INFOID:0000000010262398

REMOVAL

CAUTION:

Verify identification stamp of replacement frequency put in the lower part of gear carrier to determine replacement for collapsible spacer when replacing front oil seal. Refer to "Identification stamp of replacement frequency of front oil seal". If collapsible spacer replacement is necessary, remove final drive assembly and disassemble it to replace front oil seal and collapsible spacer.


NOTE:

The reuse of collapsible spacer is prohibited in principle. However, it is reusable on a one-time basis only in cases when replacing front oil seal.

Identification Stamp of Replacement Frequency of Front Oil Seal

- The diagonally shaded area in the figure shows stamping point for replacement frequency of front oil seal.
 - The following table shows if collapsible spacer replacement is needed before replacing front oil seal.
- When collapsible spacer replacement is required, disassemble final drive assembly to replace collapsible spacer and front oil seal. Refer to [DLN-230, "Disassembly"](#).

Stamp	collapsible spacer replacement
No stamp	Not required



FRONT OIL SEAL

< REMOVAL AND INSTALLATION >

[REAR FINAL DRIVE: R230]

Stamp	collapsible spacer replacement
"0" or "0" on the far right of stamp	Required
"01" or "1" on the far right of stamp	Not required

CAUTION:

Make a stamping after replacing front oil seal.

- After replacing front oil seal, make a stamping on the stamping point in accordance with the table below in order to identify replacement frequency.

CAUTION:

Make a stamping from left to right.

Stamp before stamping	Stamping on the far right	Stamping
No stamp	0	0
"0" (Front oil seal was replaced once.)	1	01
"01" (Collapsible spacer and front oil seal were replaced last time.)	0	010
"0" is on the far right. (Only front oil seal was replaced last time.)	1	...01
"1" is on the far right. (Collapsible spacer and front oil seal were replaced last time.)	0	...010

- Make a judgment if a collapsible spacer replacement is required.
- Drain gear oil. Refer to [DLN-206, "Draining"](#).
- Remove the drive shafts from final drive. Then suspend it by wire, etc. Refer to [RAX-10, "Removal and Installation"](#).
- Remove the side flange using attachment (A) and sliding hammer (B).


A : Attachment [SST: KV40104100 (—)]

B : Sliding hammer [SST: ST36230000 (J-25840-A)]

NOTE:

Circular clip installation position: Side flange


- Remove the rear propeller shaft. Refer to [DLN-155, "Removal and Installation"](#) (2WD), [DLN-146, "Removal and Installation"](#) (4WD).



- Measure the total preload torque with the preload gauge (A) [SST: ST3127S000 (J-25765-A)].

NOTE:

Record the total preload torque measurement.



FRONT OIL SEAL


< REMOVAL AND INSTALLATION >

[REAR FINAL DRIVE: R230]


7. Put matching mark (B) on the end of the drive pinion. The matching mark (A) on companion flange (1).

CAUTION:


For matching mark, use paint. Never damage companion flange and drive pinion.




8. Remove the drive pinion lock nut using a flange wrench (commercial service tool).



9. Remove the companion flange using a puller (commercial service tool).



10. Remove the front oil seal using the puller (A) [SST: KV381054S0 (J-34286)].



INSTALLATION

A
B
C
DLN
E
F
G
H
I
J
K
L
M
N
O
P

FRONT OIL SEAL


< REMOVAL AND INSTALLATION >

[REAR FINAL DRIVE: R230]


1. Apply multi-purpose grease to the lips of the new front oil seal. Then drive the new front oil seal in evenly until it becomes flush with the gear carrier using the drift (A) [SST: ST15310000 (J-25640-B)].

CAUTION:

- Never reuse front oil seal.
- Never incline the new front oil seal when installing.



2. Align the matching mark (B) of drive pinion with the matching mark (A) of companion flange (1), and then install the companion flange.



3. Apply anti-corrosion oil to the thread and seat of new drive pinion lock nut, and temporarily tighten drive pinion lock nut to drive pinion, using a flange wrench (commercial service tool).

A : Preload gauge [SST: ST3127S000 (J-25765-A)]

CAUTION:


Never reuse drive pinion lock nut.

4. Tighten drive pinion lock nut within the limits of specified torque so as to keep the pinion bearing preload within a standard values, using the preload gauge [SST: ST3127S000 (J-25765-A)].

Total preload torque : A value that add 0.1 – 0.4 N·m (0.01 – 0.04 kg-m, 0.9 – 3.5 in-lb) to the measured value before removing.

CAUTION:


- Adjust to the lower limit of the drive pinion lock nut tightening torque first.
- If the preload torque exceeds the specified value, replace collapsible spacer and tighten it again to adjust. Never loosen drive pinion lock nut to adjust the preload torque.



5. Fit a test indicator to the inner side of companion flange (socket diameter).
6. Rotate companion flange to check for runout.

Companion flange runout : Refer to [DLN-235, "Companion Flange Runout"](#).

- If the runout value is outside the runout limit, follow the procedure below to adjust.
- Check for runout while changing the phase between companion flange and drive pinion by 90° step, and search for the position where the runout is the minimum.



FRONT OIL SEAL

< REMOVAL AND INSTALLATION >

[REAR FINAL DRIVE: R230]

- If the runout value is still outside of the limit after the phase has been changed, possible cause will be an assembly malfunction of drive pinion and pinion bearing and malfunction of pinion bearing. Check for these items and repair if necessary.
 - If the runout value is still outside of the limit after the check and repair, replace companion flange.
7. Make a stamping for identification of front oil seal replacement frequency. Refer to "Identification stamp of replacement frequency of front oil seal".

CAUTION:

Make a stamping after replacing front oil seal.

8. Install rear propeller shaft. Refer to [DLN-155, "Removal and Installation"](#) (2WD), [DLN-146, "Removal and Installation"](#) (4WD).

9. Install side flange with the following procedure.

- a. Attach the protector [SST: KV38108000 (—)] to side oil seal.
- b. After the side flange is inserted and the serrated part of side gear has engaged the serrated part of flange, remove the protector.
- c. Put a suitable drift on the center of side flange, then drive it until sound changes.

NOTE:



When installation is completed, driving sound of the side flange turns into a sound that seems to affect the whole final drive.

- d. Confirm that the dimension of the side flanges (1) installation measurement (A) in the figure comes into the following.

Standard

A : 342.2 mm (13.47 in)

10. Install drive shaft. Refer to [RAX-10, "Removal and Installation"](#).
11. Refill gear oil to the final drive and check oil level. Refer to [DLN-206, "Refilling"](#).
12. Check the final drive for oil leakage. Refer to [DLN-206, "Inspection"](#).



A

B

C

DLN

E

F

G

H

I

J

K

L

M

N

O

P

SIDE OIL SEAL


< REMOVAL AND INSTALLATION >

[REAR FINAL DRIVE: R230]

SIDE OIL SEAL

Exploded View

INFOID:000000010262399



1. Final drive assembly 2. Side oil seal 3. Side flange
A. Oil seal lip

⇐: Apply anti-corrosion oil.



: Apply gear oil.

Refer to [GI-4, "Components"](#) for symbols not described above.

Removal and Installation

INFOID:000000010262400

REMOVAL

1. Drain gear oil. Refer to [DLN-206, "Draining"](#).
2. Remove the drive shaft from the rear final drive assembly. Refer to [RAX-10, "Removal and Installation"](#).
3. Remove the side flange using attachment (A) and sliding hammer (B).

A : Attachment [SST: KV40104100 (—)]

B : Sliding hammer [SST: ST36230000 (J-25840-A)]


NOTE:

Circular clip installation position: Side flange side

4. Remove the side oil seal using a suitable tool.

CAUTION:

Never damage gear carrier.



INSTALLATION

SIDE OIL SEAL


< REMOVAL AND INSTALLATION >

[REAR FINAL DRIVE: R230]

1. Install side oil seal until it becomes flush with the case end, using the drift (A) [SST: ST35271000 (J-26091)].

CAUTION:


- Never reuse side oil seal.
- Never incline the new side oil seal when installing.
- Apply multi-purpose grease to the lips of the new side oil seal.



2. Install the side flange with the following procedure.
 - a. Install the protector [SST: KV38108000 (—)] to the side oil seal as shown.
 - b. Insert the side flange until the serrated part of the side flange has engaged the serrated part of the side gear and remove the Tool.
 - c. Drive in the side flange using suitable tool.

NOTE:


Installation is completed when the driving sound of the side flange turns into a sound which seems to affect the whole rear final drive assembly.



- d. Confirm that the dimension of the side flanges (1) installation measurement (A) in the figure comes into the following.

A : 342.2 mm (13.47 in)

3. Install drive shaft. Refer to [RAX-10, "Removal and Installation"](#).
4. Refill gear oil to final drive and check oil level. Refer to [DLN-206, "Refilling"](#).
5. When oil leaks while removing, check oil level after the installation. Refer to [DLN-206, "Inspection"](#).




A
B
C
DLN
E
F
G
H
I
J
K
L
M
N
O
P

UNIT REMOVAL AND INSTALLATION

REAR FINAL DRIVE

Exploded View

INFOID:0000000010262401



- | | | |
|------------------------------|------------------|------------------|
| 1. Rear final drive assembly | 2. Upper stopper | 3. Lower stopper |
| 4. Washer | | |

↩: Vehicle front


Refer to [GI-4, "Components"](#) for symbols in the figure.

Removal and Installation

INFOID:0000000010262402

REMOVAL

1. Remove spare tire.
2. Remove rear propeller shaft from the final drive. Refer to [DLN-155, "Removal and Installation"](#) (2WD), [DLN-146, "Removal and Installation"](#) (4WD).
3. Remove drive shaft from final drive with power tool. Then suspend it by wire, etc. Refer to [RAX-10, "Removal and Installation"](#).
4. Remove breather hose from the final drive.




REAR FINAL DRIVE

< UNIT REMOVAL AND INSTALLATION >

[REAR FINAL DRIVE: R230]

5. Set a suitable jack to rear final drive assembly.
CAUTION:
Never place a jack under the rear cover (aluminum case).
6. Remove the mounting bolts and nuts connecting to the suspension member with power tool. And then, remove rear final drive assembly.
CAUTION:
Secure rear final drive assembly to a suitable jack while removing it.



INSTALLATION

Note the following, and installation is in the reverse order of removal.

CAUTION:

Check that there are no pinched or restricted areas on the breather hose caused by bending or winding when installing it.

- In (A) position, install the breather hose (1) until dimension (D) shown as follows.

↖: Vehicle front

D : 20 mm (0.79 in)

CAUTION:

- **Never reuse hose clamp.**
- **Install the hose clamp, with the tab facing downward.**
- In (B) position, install the breather hose (2) until hose reaches the plane tube surface connector.

CAUTION:

- **Never reuse hose clamp.**
- **Install the hose clamp, with the tab facing rightward and upward direction of the vehicle at 45°.**
- In (C) position, install the breather hose (2) until dimension (E) shown as follows.

E : 20 mm (0.79 in)

- Install breather hose (1) and (2), breather tube (3) and metal connector (4) as shown in the figure.

↖: Vehicle front

- Fix breather hose (2) with clip in (A) position

CAUTION:



Never reuse clip.

- Install metal connector (4) to rear cover with a part to insert breather hose with facing vehicle left.

CAUTION:

Never reuse metal connector.

- Fix a point with paint mark (B) of breather tube (3) in (C) position.
- Fix breather tube (3) in (D) position.
- When oil leaks while removing final drive assembly, check oil level after the installation. Refer to [DLN-206, "Inspection"](#).



DIFFERENTIAL ASSEMBLY

< UNIT DISASSEMBLY AND ASSEMBLY >


[REAR FINAL DRIVE: R230]

UNIT DISASSEMBLY AND ASSEMBLY

DIFFERENTIAL ASSEMBLY

Exploded View

INFOID:000000010262403



- | | | |
|-----------------------------------|------------------------------|---|
| 1. Rear cover | 2. Bearing cap | 3. Side gear thrust washer |
| 4. Side gear | 5. Pinion mate thrust washer | 6. Pinion mate gear |
| 7. Pinion mate shaft | 8. Lock pin | 9. Side bearing |
| 10. Side bearing adjusting washer | 11. Drive pinion | 12. Pinion height adjusting washer |
| 13. Pinion rear bearing | 14. Collapsible spacer | 15. Side flange |
| 16. Circlip | 17. Side oil seal | 18. Gear carrier |
| 19. Pinion front bearing | 20. Front oil seal | 21. Companion flange |
| 22. Drive pinion lock nut | 23. Drive gear | 24. Differential case |
| 25. Gasket | 26. Drain plug | 27. Filler plug |
| A. Oil seal lip | B. Screw hole | C. Comply with the assembly procedure when tightening. Refer to DLN-219, "Assembly" . |

Apply gear oil.

*: Apply anti-corrosion oil.

DIFFERENTIAL ASSEMBLY

< UNIT DISASSEMBLY AND ASSEMBLY >

[REAR FINAL DRIVE: R230]

: Apply Genuine Silicone RTV or equivalent. Refer to [GI-22, "Recommended Chemical Products and Sealants"](#).

: Apply Genuine High Strength Thread Locking Sealant or equivalent. Refer to [GI-22, "Recommended Chemical Products and Sealants"](#).

Refer to [GI-4, "Components"](#) for symbols not described above.


Disassembly

INFOID:0000000010262404


1. Drain gear oil, if necessary.
2. Remove side flanges.
3. Remove rear cover mounting bolts.
4. Remove rear cover to insert the seal cutter [SST: KV10111100 (J-37228)] between gear carrier and rear cover.

CAUTION:

- Never damage the mating surface.
- Never insert flat-bladed screwdriver, this may damage the mating surface.




5. Using spacers, mount carrier on the attachment (A) [SST: KV38100800 (J-25604-01)].




6. For proper reinstallation, paint matching marks on one side of the bearing cap.

CAUTION:

- For matching marks, use paint. Never damage bearing caps and gear carrier.
- Bearing caps are manufactured as integral molding. Use the matching marks to them in their original positions.



7. Remove bearing caps.



A

B

C

DLN

E

F

G

H

I

J

K

L

M

N

O


P

DIFFERENTIAL ASSEMBLY


< UNIT DISASSEMBLY AND ASSEMBLY >

[REAR FINAL DRIVE: R230]

8. Lift differential case assembly out with a sliding hammer (commercial service tool).



- Keep side bearing outer races together with inner race. Never mix them up.
Also, keep side bearing adjusting washers together with bearings.




9. Remove side bearing inner race with puller (A) and base (B). To prevent damage to bearing, engage puller jaws in groove (←).

A : Puller [SST: ST33051001 (J-22888-20)]

B : Base [SST: KV40104730 (—)]

CAUTION:

- To prevent damage to the side bearing and drive gear, place copper plates between these parts and vise.
- It is not necessary to remove side bearing inner race except when it is replaced.



10. For proper reinstallation, paint matching marks on one differential case assembly.


CAUTION:

For matching marks, use paint. Never damage differential case and drive gear.

11. Remove drive gear mounting bolts.
12. Tap drive gear off differential case assembly with a soft hammer.

CAUTION:

Tap evenly all around to keep drive gear from bending.




DIFFERENTIAL ASSEMBLY


< UNIT DISASSEMBLY AND ASSEMBLY >

[REAR FINAL DRIVE: R230]

13. Remove lock pin of pinion mate shaft with a punch from drive gear side.




14. Remove pinion mate shaft.



15. Turn pinion mate gear, then remove pinion mate gear, pinion mate thrust washer, side gear and side gear thrust washer from differential case.


16. Perform inspection after disassembly. Refer to [DLN-228](#), "[Inspection](#)".



INFOID:0000000010262405

Assembly

1. Install side gear thrust washers with the same thickness as the ones installed prior to disassembly or reinstall the old ones on the side gears.



DIFFERENTIAL ASSEMBLY

< UNIT DISASSEMBLY AND ASSEMBLY >


[REAR FINAL DRIVE: R230]

2. Install side gears and thrust washers into differential case.


CAUTION:

Make sure that the circular clip is installed to side gears.

3. Align 2 pinion mate gears in diagonally opposite positions, then rotate and install them into differential case after installing thrust washer to pinion mate gear.




4. Align the lock pin holes on differential case with shaft, and install pinion mate shaft.



5. Measure side gear end play. If necessary, select the appropriate side gear thrust washers.

- a. Place differential case straight up so that side gear to be measured comes upward.



DIFFERENTIAL ASSEMBLY

< UNIT DISASSEMBLY AND ASSEMBLY >

[REAR FINAL DRIVE: R230]

- b. Using feeler gauge, measure the clearance between side gear back and differential case at 3 different points, while rotating side gear. Average the 3 readings, and then measure the clearance of the other side as well.

Standard

Side gear back clearance : Refer to [DLN-235, "Side Gear Clearance"](#).

CAUTION:

To prevent side gear from tilting, insert feeler gauges with the same thickness from both sides.

- c. If the back clearance is outside the specification, use a thicker/thinner side gear thrust washer to adjust. For selecting thrust washer, refer to the latest parts information.

When the back clearance is large: Use a thicker thrust washer.

When the back clearance is small: Use a thinner thrust washer.

CAUTION:

Select a side gear thrust washer for right and left individually.

6. Drive a lock pin into pinion mate shaft, using a punch. Make sure lock pin is flush with differential case.

CAUTION:

Never reuse lock pin.

7. Apply thread locking sealant into the thread hole of drive gear.
- Use Genuine High Strength Thread Locking Sealant or equivalent. Refer to [GI-22, "Recommended Chemical Products and Sealants"](#).

CAUTION:

Clean and degrease drive gear back and threaded holes sufficiently.

8. Install drive gear to differential case.

CAUTION:

Align the matching marks of differential case and drive gear.

9. Tighten the mounting bolts with the following procedure.





CAUTION:

Apply anti-corrosion oil to the thread and seat of mounting bolts.

- a. Tighten the bolts in a crisscross fashion to the specified torque.

Drive gear mounting bolts tightening torque : 78.5 N·m (8.0 kg-m, 58 ft-lb)

- b. Tighten the bolts additionally to the specified angle.



DIFFERENTIAL ASSEMBLY

< UNIT DISASSEMBLY AND ASSEMBLY >

[REAR FINAL DRIVE: R230]

Drive gear mounting bolts tightening angle : 31 to 36 degree

CAUTION:

Check the tightening angle using the angle wrench [SST: KV10112100 (BT-8653-A)]. Never make judgment by visual inspection.


10. Press side bearing inner races to differential case, using the drifts (A and B).

A : Drift [SST: ST01550002 (—)]


B : Drift [SST: KV40104730 (—)]

CAUTION:


Never reuse side bearing inner race.




11. Install differential case assembly with side bearing outer races into gear carrier.
12. Measure side bearing preload. If necessary, select the appropriate side bearing adjusting washers. Refer to [DLN-223, "Adjustment"](#).



13. Insert selected left and right side bearing adjusting washers in place between side bearings and gear carrier. Refer to [DLN-223, "Adjustment"](#).



14. Align matching marks on bearing cap with that on gear carrier.
15. Install bearing caps and tighten bearing cap mounting bolts.



DIFFERENTIAL ASSEMBLY

< UNIT DISASSEMBLY AND ASSEMBLY >

[REAR FINAL DRIVE: R230]

16. Using the drift [SST: ST35271000 (J-26091)], drive side oil seals until it becomes flush with the case end.

CAUTION:

- Never reuse oil seal.
- When installing, never incline oil seal.
- Apply multi-purpose grease onto oil seal lips, and gear oil onto the circumference of oil seal.



17. Check and adjust drive gear runout, tooth contact, drive gear to drive pinion backlash, and total preload torque. Refer to [DLN-223. "Adjustment"](#).
Recheck above items. Readjust the above description, if necessary.

18. Apply sealant to mating surface of rear cover.
- Use Genuine Silicone RTV or equivalent. Refer to [GI-22. "Recommended Chemical Products and Sealants"](#).

CAUTION:

Remove old sealant adhering to mounting surfaces. Also remove any moisture, oil, or foreign material adhering to application and mounting surfaces.

19. Install rear cover on gear carrier and tighten mounting bolts.




20. Install side flange with the following procedure.

- Attach the protector [SST: KV38108000 (—)] to side oil seal.
- After the side flange is inserted and the serrated part of side gear has engaged the serrated part of flange, remove the protector.
- Insert the side flange until the serrated part of the side flange has engaged the serrated part of the side gear and remove the protector.

NOTE:


When installation is completed, driving sound of the side flange turns into a sound that seems to affect the whole final drive.



- Confirm that the dimension of the side flanges (1) installation measurement (A) in the figure comes into the following.

Standard

A : 342.2 mm (13.47 in)



INFOID:0000000010262406

Adjustment

TOTAL PRELOAD TORQUE

Before inspection and adjustment, drain gear oil.

- Secure final drive assembly onto an attachment [SST: KV38100800 (—)].
- Remove side flanges.
- Rotate drive pinion back and forth 2 to 3 times to check for unusual noise and rotation malfunction.
- Rotate drive pinion at least 20 times to check for smooth operation of the bearing.

DIFFERENTIAL ASSEMBLY

< UNIT DISASSEMBLY AND ASSEMBLY >

[REAR FINAL DRIVE: R230]


5. Measure total preload with the preload gauge (A) [SST: ST3127S000 (J-25765-A)].

Total preload torque : Refer to [DLN-235, "Pre-load Torque"](#).

NOTE:

Total preload torque = Pinion bearing preload torque + Side bearing preload torque

- If measured value is out of the specification, disassemble it to check and adjust each part. Adjust the pinion bearing preload and side bearing preload.
Adjust the pinion bearing preload first, then adjust the side bearing preload.



When the preload torque is large

On pinion bearings: Replace the collapsible spacer.

On side bearings: Use thinner side bearing adjusting washers by the same amount to each side. For selecting adjusting washer, refer to the latest parts information.

When the preload is small


On pinion bearings: Tighten the drive pinion lock nut.

On side bearings: Use thicker side bearing adjusting washers by the same amount to each side. For selecting adjusting washer, refer to the latest parts information.


SIDE BEARING PRELOAD

Before inspection and adjustment, drain gear oil.

1. Remove rear cover. Refer to [DLN-217, "Disassembly"](#).
2. Make sure all parts are clean. Also, make sure the bearings are well lubricated with gear oil.
3. Place the differential case, with side bearings and bearing races installed, into gear carrier.



4. Insert left and right original side bearing adjusting washers in place between side bearings and gear carrier.




DIFFERENTIAL ASSEMBLY

< UNIT DISASSEMBLY AND ASSEMBLY >


[REAR FINAL DRIVE: R230]

5. Install bearing caps in their correct locations and tighten bearing cap mounting bolts.
6. Turn the carrier several times to seat the bearings.




7. Measure the turning torque of the carrier at the drive gear mounting bolts with a spring gauge [SST: — (J-8129)].

Specification : 34.2 – 39.2 N (3.5 – 4.0 kg, 7.7 – 8.8 lb) of pulling force at the drive gear bolt



8. If the turning torque is outside the specification, use a thicker/thinner side bearing adjusting washer to adjust. For selecting adjusting washer, refer to the latest parts information.

If the turning torque is less than the specified range: Use a thicker thrust washer.
If the turning torque is greater than the specification: Use a thinner thrust washer.



CAUTION:

Select a side bearing adjusting washer for right and left individually.

9. Record the total amount of washer thickness required for the correct carrier side bearing preload.

DRIVE GEAR RUNOUT


1. Remove rear cover. Refer to [DLN-217, "Disassembly"](#).
2. Fit a dial indicator to the drive gear back face.
3. Rotate the drive gear to measure runout.

Drive gear runout : Refer to [DLN-235, "Drive Gear Runout"](#).

- If the runout is outside of the repair limit, check drive gear assembly condition; foreign material may be caught between drive gear and differential case, or differential case or drive gear may be deformed, etc.

CAUTION:

Replace drive gear and drive pinion gear as a set.



TOOTH CONTACT

Before inspection and adjustment, drain gear oil.

1. Remove rear cover. Refer to [DLN-217, "Disassembly"](#).

DIFFERENTIAL ASSEMBLY


< UNIT DISASSEMBLY AND ASSEMBLY >

[REAR FINAL DRIVE: R230]

2. Apply red lead to drive gear.

CAUTION:


Apply red lead to both the faces of 3 to 4 gears at 4 locations evenly spaced on drive gear.



3. Rotate drive gear back and forth several times, check drive pinion gear to drive gear tooth contact.

CAUTION:

Check tooth contact on drive side and reverse side.



Tooth contact condition		Pinion height adjusting washer selection value [mm (in)]		Adjustment (Yes/No)	Possible cause
Drive side	Back side				
Heel side Toe side	Toe side Heel side	Thicker ↑	+0.06 (+0.0024)	Yes	Occurrence of noise and scoring sound in all speed ranges.
			+0.04 (+0.0016)		Occurrence of noise when accelerating.
			+0.02 (+0.0008)	No	—
		Thinner ↓	0		
			-0.02 (-0.0008)		
			-0.04 (-0.0016)	Yes	Occurrence of noise at constant speed and decreasing speed.
			-0.06 (-0.0024)		Occurrence of noise and scoring sound in all speed ranges.


JPDID0398GB

DIFFERENTIAL ASSEMBLY


< UNIT DISASSEMBLY AND ASSEMBLY >

[REAR FINAL DRIVE: R230]


4. If tooth contact is improperly adjusted, follow the procedure below to adjust the pinion height [dimension (X)].



- If the tooth contact is near the face (face contact), or near the heel (heel contact), thicken pinion height adjusting washers to move drive pinion closer to drive gear. For selecting adjusting washer, refer to the latest parts information.



- If the tooth contact is near the flank (flank contact), or near the toe (toe contact), thin pinion height adjusting washers to move drive pinion farther from drive gear. For selecting adjusting washer, refer to the latest parts information.



BACKLASH

Before inspection and adjustment, drain gear oil.

1. Remove rear cover. Refer to [DLN-217, "Disassembly"](#).
2. Fit a dial indicator to the drive gear face to measure the backlash.


Backlash

: Refer to [DLN-235, "Backlash"](#).

- If the backlash is outside of the specified value, change the thickness of side bearing adjusting washer.

When the backlash is large:

Make drive gear back side adjusting washer thicker, and drive gear tooth side adjusting washer thinner by the same amount. For selecting adjusting washer, refer to the latest parts information.



When the backlash is small:

Make drive gear back side adjusting washer thinner, and drive gear tooth side adjusting washer thicker by the same amount. For selecting adjusting washer, refer to the latest parts information.

CAUTION:

Never change the total amount of washers as it changes the bearing preload.

Inspection

INFOID:0000000010262407

INSPECTION AFTER DISASSEMBLY

Drive Gear and Drive Pinion

- Clean up the disassembled parts.
- If the gear teeth never mesh or line-up correctly, determine the cause and adjust or replace as necessary.
- If the gears are worn, cracked, damaged, pitted or chipped (by friction) noticeably, replace with new drive gear and drive pinion as a set.

Bearing

- Clean up the disassembled parts.
- If any chipped (by friction), pitted, worn, rusted or scratched marks, or unusual noise from the bearing is observed, replace as a bearing assembly (as a new set).

Side Gear and Pinion Mate Gear

- Clean up the disassembled parts.
- If any cracks or damage on the surface of the tooth is found, replace.
- If any worn or chipped mark on the contact sides of the thrust washer is found, replace.

Side Gear Thrust Washer and Pinion Mate Thrust Washer

- Clean up the disassembled parts.
- If it is chipped (by friction), damaged, or unusually worn, replace.

Oil Seal

- Whenever disassembled, replace.
- If wear, deterioration of adherence (sealing force lips), or damage is detected on the lips, replace them.

Differential case

- Clean up the disassembled parts.
- If any wear or crack on the contact sides of the differential case is found, replace.

DRIVE PINION


< UNIT DISASSEMBLY AND ASSEMBLY >

[REAR FINAL DRIVE: R230]

DRIVE PINION

Exploded View

INFOID:0000000110262408



- | | | |
|-----------------------------------|------------------------------|---|
| 1. Rear cover | 2. Bearing cap | 3. Side gear thrust washer |
| 4. Side gear | 5. Pinion mate thrust washer | 6. Pinion mate gear |
| 7. Pinion mate shaft | 8. Lock pin | 9. Side bearing |
| 10. Side bearing adjusting washer | 11. Drive pinion | 12. Pinion height adjusting washer |
| 13. Pinion rear bearing | 14. Collapsible spacer | 15. Side flange |
| 16. Circlip | 17. Side oil seal | 18. Gear carrier |
| 19. Pinion front bearing | 20. Front oil seal | 21. Companion flange |
| 22. Drive pinion lock nut | 23. Drive gear | 24. Differential case |
| 25. Gasket | 26. Drain plug | 27. Filler plug |
| A. Oil seal lip | B. Screw hole | C. Comply with the assembly procedure when tightening. Refer to DLN-219, "Assembly" . |

: Apply gear oil.

: Apply anti-corrosion oil.

: Apply Genuine Silicone RTV or equivalent. Refer to [GI-22, "Recommended Chemical Products and Sealants"](#).

DRIVE PINION

< UNIT DISASSEMBLY AND ASSEMBLY >

[REAR FINAL DRIVE: R230]


: Apply Genuine High Strength Thread Locking Sealant or equivalent. Refer to [GI-22, "Recommended Chemical Products and Sealants"](#).

Refer to [GI-4, "Components"](#) for symbols not described above.

Disassembly

INFOID:0000000010262409

1. Remove differential case assembly. Refer to [DLN-217, "Disassembly"](#).
2. Remove drive pinion lock nut with the flange wrench (commercial service tool).



3. Put matching mark (B) on the end of drive pinion. The matching mark should be in line with the matching mark (A) on companion flange (1).


CAUTION:

For matching mark, use paint. Never damage companion flange and drive pinion.


NOTE:

The matching mark on the final drive companion flange indicates the maximum vertical runout position.

When replacing companion flange, matching mark is not necessary.



4. Remove companion flange using the suitable puller (commercial service tool).




5. Press drive pinion assembly out of gear carrier.

CAUTION:

Never drop drive pinion assembly.

6. Remove front oil seal.
7. Remove side oil seal.
8. Remove pinion front bearing inner race.
9. Remove collapsible spacer.




DRIVE PINION

< UNIT DISASSEMBLY AND ASSEMBLY >

[REAR FINAL DRIVE: R230]

10. Remove pinion rear bearing inner race and pinion height adjusting washer with the replacer (A) (commercial service tool).




11. Tap pinion front/rear bearing outer races uniformly using a brass rod or equivalent to remove them.

CAUTION:

Never damage gear carrier.

12. Perform inspection after disassembly. Refer to [DLN-234](#), "[Inspection](#)".



Assembly

INFOID:0000000010262410

1. Install front bearing outer race and rear bearing outer race using drifts (A and B) and drift bar (C).

A : Drift [SST: KV38103300 (—)]


B : Drift [SST: ST30611000 (J-25742-1)]

C : Drift bar [SST: ST30621000 (J-25742-5)]

CAUTION:

- At first, using a hammer, tap bearing outer race until it becomes flat to gear carrier.
- Never reuse pinion front and rear bearing outer race.

2. Select drive pinion height adjusting washer. For selecting adjusting washer, refer to the latest parts information.



DRIVE PINION


< UNIT DISASSEMBLY AND ASSEMBLY >

[REAR FINAL DRIVE: R230]

3. Install selected drive pinion height adjusting washer (2) to drive pinion. Press pinion rear bearing inner race (1) to it, using drift (A) [SST: ST30022000 (—)].

CAUTION:

- Be careful of the direction of pinion height adjusting washer. (Assemble as shown in the figure.)
- Never reuse pinion rear bearing inner race.



4. Assemble collapsible spacer to drive pinion.


CAUTION:

Never reuse collapsible spacer.


5. Apply gear oil to pinion rear bearing, and assemble drive pinion into gear carrier.
6. Apply gear oil to pinion front bearing, and assemble pinion front bearing inner race to drive pinion assembly.

CAUTION:

Never reuse pinion front bearing inner race.




7. Using suitable spacer (A) (commercial service tool), press the pinion front bearing inner race to drive pinion as far as drive pinion nut can be tightened.



8. Using the drift (A) [SST: ST15310000 (J-25640-B)], install front oil seal in evenly until it becomes flush with the gear carrier.

CAUTION:

- Never reuse oil seal.
- When installing, never incline oil seal.
- Apply multi-purpose grease onto oil seal lips, and gear oil onto the circumference of oil seal.



9. Install companion flange.


NOTE:

DRIVE PINION

< UNIT DISASSEMBLY AND ASSEMBLY >

[REAR FINAL DRIVE: R230]

When reusing drive pinion, align the matching mark (B) of drive pinion with the matching mark (A) of companion flange, and then install companion flange (1).



10. Apply anti-corrosion oil to the thread and seat of drive pinion lock nut, and temporarily tighten drive pinion lock nut to drive pinion, using flange wrench (commercial service tool).

A : Preload gauge [SST: ST3127S000 (J-25765-A)]

CAUTION:

Never reuse drive pinion lock nut.

11. Adjust to the drive pinion lock nut tightening torque and pinion bearing preload torque, using preload gauge [SST: ST3127S000 (J-25765-A)].

Pinion bearing preload : Refer to [DLN-235, "Pre-load Torque"](#).

CAUTION:

- Adjust to the lower limit of the drive pinion lock nut tightening torque first.
- If the preload torque exceeds the specified value, replace collapsible spacer and tighten it again to adjust. Never loosen drive pinion lock nut to adjust the preload torque.
- After adjustment, rotate drive pinion back and forth 2 to 3 times to check for unusual noise, rotation malfunction, and other malfunctions.

12. Install differential case assembly. Refer to [DLN-219, "Assembly"](#).

CAUTION:

Never install rear cover at this timing.

13. Check and adjust drive gear runout, tooth contact, drive gear to drive pinion backlash, and companion flange runout. Refer to [DLN-223, "Adjustment"](#) and [DLN-233, "Adjustment"](#).
Recheck above items. Readjust the above description, if necessary.
14. Check total preload torque. Refer to [DLN-223, "Adjustment"](#).
15. Install rear cover. Refer to [DLN-219, "Assembly"](#).

Adjustment


INFOID:0000000010262411

COMPANION FLANGE RUNOUT

1. Fit a test indicator to the inner side of the companion flange (socket diameter).
2. Rotate companion flange to check for runout.

Inner side of companion flange runout : Refer to [DLN-235, "Companion Flange Runout"](#).

3. If the runout value is outside the runout limit, follow the procedure below to adjust.



DRIVE PINION

< UNIT DISASSEMBLY AND ASSEMBLY >

[REAR FINAL DRIVE: R230]

- a. Check for runout while changing the phase between companion flange and drive pinion by 90° step, and search for the position where the runout is the minimum.
- b. If the runout value is still outside of the limit after the phase has been changed, possible cause will be an assembly malfunction of drive pinion and pinion bearing and malfunction of pinion bearing. Check for these items and repair if necessary.
- c. If the runout value is still outside of the limit after the check and repair, replace companion flange.

Inspection

INFOID:0000000010262412

INSPECTION AFTER DISASSEMBLY

Drive Gear and Drive Pinion

- Clean up the disassembled parts.
- If the gear teeth never mesh or line-up correctly, determine the cause and adjust or replace as necessary.
- If the gears are worn, cracked, damaged, pitted or chipped (by friction) noticeably, replace with new drive gear and drive pinion as a set.

Bearing

- Clean up the disassembled parts.
- If any chipped (by friction), pitted, worn, rusted or scratched marks, or unusual noise from the bearing is observed, replace as a bearing assembly (as a new set).

Oil Seal

- Whenever disassembled, replace.
- If wear, deterioration of adherence (sealing force lips), or damage is detected on the lips, replace them.

Companion Flange

- Clean up the disassembled parts.
- If any chipped mark [about 0.1 mm, (0.004 in)] or other damage on the contact sides of the lips of the companion flange is found, replace.

SERVICE DATA AND SPECIFICATIONS (SDS)

< SERVICE DATA AND SPECIFICATIONS (SDS)

[REAR FINAL DRIVE: R230]

SERVICE DATA AND SPECIFICATIONS (SDS)

SERVICE DATA AND SPECIFICATIONS (SDS)

General Specification

INFOID:0000000010262413

Applied model	2WD	4WD
	VK56VD	
	A/T	
Final drive model	R230	
Gear ratio	2.937	
Number of teeth (Drive gear/Drive pinion)	47/16	
Oil capacity (Approx.) ℓ (US pt, Imp pt)	1.75 (3-3/4, 3-1/8)	
Number of pinion gears	2	
Drive pinion adjustment spacer type	Collapsible	

Drive Gear Runout

INFOID:0000000010262414

Unit: mm (in)

Item	Runout limit
Drive gear back face	0.05 (0.0020) or less

Side Gear Clearance

INFOID:0000000010262415

Unit: mm (in)

Item	Specification
Side gear back clearance (Clearance limit between side gear and differential case for adjusting side gear backlash)	0.20 (0.0079) or less (Each gear should rotate smoothly without excessive resistance during differential motion.)

Preload Torque

INFOID:0000000010262416

Item	Specification
Drive pinion bearing preload torque	1.76 – 2.65 N·m (0.18 – 0.27 kg-m, 16 – 23 in-lb)
Side bearing preload torque (reference value determined by drive gear bolt pulling force)	0.29 – 1.47 N·m (0.03 – 0.14 kg-m, 3 – 13 in-lb)
Total preload torque (Total preload torque = drive pinion bearing preload torque + Side bearing preload torque)	2.06 – 4.12 N·m (0.21 – 0.42 kg-m, 19 – 36 in-lb)

Backlash

INFOID:0000000010262417

Unit: mm (in)

Item	Specification
Drive gear to drive pinion gear	0.13 – 0.18 (0.0051 – 0.0070)

Companion Flange Runout

INFOID:0000000010262418

Unit: mm (in)

Item	Runout limit
Inner side of the companion flange	0.08 (0.0031) or less