

ELECTRICAL SYSTEM

SECTION **EL**



When you read wiring diagrams

- Read GI section, "HOW TO READ WIRING DIAGRAMS".

CONTENTS

HARNESS CONNECTOR	EL- 2
STANDARDIZED RELAY	EL- 3
POWER SUPPLY ROUTING	EL- 5
BATTERY	EL- 9
STARTING SYSTEM	EL- 17
STARTING SYSTEM — Starter —	EL- 18
CHARGING SYSTEM ...	EL- 23
CHARGING SYSTEM — Alternator — ..	EL- 26
COMBINATION SWITCH	EL- 32
INSTRUMENT SWITCH	EL- 34
HEADLAMP ...	EL- 35
EXTERIOR LAMP	EL- 54
INTERIOR LAMP	EL- 59
METER AND GAUGES — Digital type combination meter	EL- 65
METER AND GAUGES — Needle type combination meter	EL- 83
METER AND GAUGES — Needle type combination gauge	EL- 86
WARNING LAMPS AND CHIME	EL- 90
TIME CONTROL SYSTEM	EL- 98
WIPER AND WASHER ...	EL-107
HORN, CIGARETTE LIGHTER, CLOCK	EL-111
REAR WINDOW DEFOGGER	EL-112
AUDIO AND POWER ANTENNA	EL-115
AUTOMATIC SPEED CONTROL DEVICE (A S.C.D)	EL-118
STEERING WHEEL SWITCH SYSTEM ...	EL-126
THEFT WARNING SYSTEM.	EL-148
LOCATION OF ELECTRICAL UNITS.	EL-179
HARNESS LAYOUT	EL-181
SPECIAL SERVICE TOOL	EL-197

WIRING DIAGRAM REFERENCE CHART

E C C S	EF & EC SECTION	POWER WINDOW, DOOR LOCK AND
LOCK-UP CONTROL SYSTEM	AT SECTION	MIRROR
ADJUSTABLE SHOCK ABSORBER . .	FA SECTION	HEATER AND AIR CONDITIONER . .
		BF SECTION
		HA SECTION

EL

HARNESS CONNECTOR

Description


HARNESS CONNECTOR

- All harness connectors are designed so that they do not become loose or disconnected accidentally.
- The connector can be disconnected by pushing or lifting the locking section.

CAUTION:

Do not pull the harness when disconnecting the connector.

[Example]



SEL769D

STANDARDIZED RELAY

Normal Open, Normal Closed and Mixed Type Relays

Relays can mainly be divided into three types normal open, normal closed and mixed type relays

	NORMAL OPEN RELAY	NORMAL CLOSED RELAY	MIXED TYPE RELAY
SW 1 "OFF"			
SW 1 "ON"			

SEL881H













Type of Standardized Relays

1M 1 Make 2M 2 Make
1T 1 Transfer 1M 1B 1 Make 1 Break

1M	2M
1T	1M 1B

SEL882H

STANDARDIZED RELAY


Type	Outer view	Circuit	Connector symbol and connection	Case color
1T				BLACK
1M				BLUE
2M				BROWN
1M 1B				GRAY

SEL883H

POWER SUPPLY ROUTING

Wiring Diagram

TURBO MODELS



SEL078J

Wiring Diagram (Cont'd)

BATTERY

FUSIBLE LINK BOX

STARTING SYSTEM

ECCS system

Charging system

(Engine room harness)

IGNITION RELAY

CIRCUIT BREAKER

ACCESSORY RELAY

BLOWER RELAY

IGNITION SWITCH

	OFF	ACC	ON	ST
B				
A				
IG				
S				

Power window

Power seat

Air conditioner

161M BODY GROUND (Back side)

UP

FUSE BLOCK


- G/W → Ignition coil ECCS system
- L/W → Fuel pump ECCS system
- G → Meter Gauge Time control unit Hold relay O₂ sensor amp Bulb check relay
- R/G → Rear defogger
- LG → Turn signal Back up lamp, A S C D Direction amp Power steering switch Boost sensor, Injector cooling fan timer
- BR → Kickdown solenoid Seat belt tension reducer, O D switch Lock-up control unit Shock absorber control system
- R → Theft warning control unit
- GY → Door lock system
- Y/G → Radio Radio amp Clock Time control unit Remote control mirror Door mirror defogger, Theft warning control unit
- GY → Rear wiper and washer Meter (Digital) Gauge (Digital) Headlamp washer
- P → Wiper and washer
- PU → Cigarette lighter
- SB → Air conditioner
- B/R → Air conditioner
- B/R → Air conditioner
- L/OR → Stop lamp, Injector cooling fan timer
- L/Y → Horn, Time control unit
- L/B → Hazard
- OR → Auxiliary driving lamp
- L/R → Lamp (Interior, Spot Step Luggage), Clock Radio, Antenna timer, Meter (Digital), Steering lock switch O₂ sensor amp
- R/L → Lamp (Clearance Tail License, Illumination), Headlamp system
- R/G → Headlamp motor L H
- R/Y → Headlamp motor R H
- R/B → Headlamp L H
- P/W → Headlamp R H

© GL and GLL models

SE L079J

POWER SUPPLY ROUTING

Fuse




SEL276

- a. If fuse is blown, be sure to eliminate cause of problem before installing new fuse.
- b. Use fuse of specified rating. Never use fuse of more than specified rating.
- c. Do not install fuse in oblique direction, always insert it into fuse holder properly.
- d. Remove fuse for clock if vehicle is not used for a long period of time.

Fusible Link

A melted fusible link can be detected either by visual inspection or by feeling with finger tip. If its condition is questionable, use circuit tester or test lamp



SEL641D

CAUTION.

- a. If fusible link should melt, it is possible that critical circuit (power supply or large current carrying circuit) is shorted. In such a case, carefully check and eliminate cause of problem.
- b. Never wrap periphery of fusible link with vinyl tape. Extreme care should be taken with this link to ensure that it does not come into contact with any other wiring harness or vinyl or rubber parts.

POWER SUPPLY ROUTING

Note

BATTERY

CAUTION:


- If it becomes necessary to start the engine with a booster battery and jumper cables, use a 12-volt booster battery.
- After connecting battery cables, ensure that they are tightly clamped to battery terminals for good contact
- Never add distilled water through the hole used to check specific gravity

How to Handle Battery

METHODS OF PREVENTING OVER-DISCHARGE

The following precautions must be taken to prevent over-discharging a battery


- The battery surface (particularly its top) should always be kept clean and dry



SEL711E


If the top surface of a battery is wet with electrolyte or water, leakage current will cause the battery to discharge. Always keep the battery clean and dry.

- When the vehicle is not going to be used over a long period of time, disconnect the negative battery terminal. (If the vehicle has an extended storage switch, turn it off.)



SEL712E

- Check the charge condition of the battery



Periodically check the specific gravity of the electrolyte. Keep a close check on charge condition to prevent over-discharge.

CHECKING ELECTROLYTE LEVEL

WARNING

Do not allow battery fluid to come in contact with skin, eyes, fabrics, or painted surfaces. After touching a battery, do not touch or rub your eyes until you have thoroughly washed your hands. If the acid contacts the eyes, skin or clothing, immediately flush with water for 15 minutes and seek medical attention.


Normally the battery does not require additional water. However, when the battery is used under severe conditions, adding distilled water may be necessary during the battery life.

To maintain serviceability, a perforated line has been added to the battery caution label.

BATTERY

How to Handle Battery (Cont'd)


- Remove the cell plug using a suitable tool
- Add distilled water up to the MAX level



SULPHATION

When a battery has been left unattended for a long period of time and has a specific gravity of less than 1 100, it will be completely discharged, resulting in sulphation on the cell plates

Compared with a battery discharged under normal conditions, the current flow in a "sulphated" battery is not as smooth although its voltage is high during the initial stage of charging, as shown in the following figure




BATTERY

Specific Gravity Check

SPECIFIC GRAVITY CHECK


- 1 Read hydrometer and thermal gauge indications at eye level

Read top level with scale.



SEL442D

- When electrolyte level is too low, tilt battery case to raise it for easy measurement




SEL710E

- 2 Convert into specific gravity at 20°C (68°F)

Example

- When electrolyte temperature is 35°C (95°F) and specific gravity of electrolyte is 1 230, converted specific gravity at 20°C (68°F) is 1 240
- When electrolyte temperature is 0°C (32°F) and specific gravity of electrolyte is 1 210, converted specific gravity at 20°C (68°F) is 1 196




SEL042D

BATTERY

M.F. Battery Test and Charging Chart

Chart I




• "STANDARD CHARGE" is recommended in case that the vehicle is in storage after charging

BATTERY

M.F. Battery Test and Charging Chart (Cont'd)


Chart II



- Check battery type and determine the specified current using the following table

Fig 1 DISCHARGING CURRENT (Load tester)

Type	Current (A)
28B19R(L)-MF	90
34B19R(L)-MF	99
46B24R(L) MF	135
55B24R(L)-MF	135
50D23R(L)-MF	150
55D23R(L)-MF	180
65D26R(L)-MF	195
80D26R(L) MF	195
75D31R(L)-MF	210
95D31R(L)-MF	240



SEL697B

BATTERY

M.F. Battery Test and Charging Chart (Cont'd)



A SLOW CHARGE

Fig 2 INITIAL CHARGING CURRENT SETTING (Slow charge)

BATTERY TYPE CON VERTED SPECIFIC GRAVITY	28B19R(L)-MF 34B19R(L)-MF	46B24R(L)-MF 55B24R(L)-MF	50D23R(L)-MF 55D23R(L)-MF	65D26R(L)-MF 80D26R(L)-MF	75D31R(L)-MF	95D31R(L)-MF
Below 1 100	4 0 (A)	5 0 (A)	7 0 (A)	8 0 (A)	9 0 (A)	10 0 (A)

- Check battery type and determine the specified current using the table shown above
- After starting charging, adjustment of charging current is not necessary

Fig 3 ADDITIONAL CHARGE (Slow charge)



CAUTION:

- Set charging current to value specified in Fig. 2. If charger is not capable of producing specified current value, set its charging current as close to that value as possible.
- Keep battery away from open flame while it is being charged.
- When connecting charger, connect leads first, then turn on charger. Do not turn on charger first, as this may cause a spark.
- If battery temperature rises above 60°C (140°F), stop charging. Always charge battery when its temperature is below 60°C (140°F).

BATTERY

M.F. Battery Test and Charging Chart (Cont'd)

B STANDARD CHARGE





Fig 4 INITIAL CHARGING CURRENT SETTING (Standard charge)

CON VERTED SPECIFIC GRAVITY	BATTERY TYPE	28B19R(L)-MF	34B19R(L)-MF	46B24R(L)-MF	55B24R(L)-MF	50D23R(L)-MF	55D23R(L)-MF	65D26R(L)-MF	80D26R(L)-MF	75D31R(L)-MF	95D31R(L)-MF
		28B19R(L)-MF	34B19R(L)-MF	46B24R(L)-MF	55B24R(L)-MF	50D23R(L)-MF	55D23R(L)-MF	65D26R(L)-MF	80D26R(L)-MF	75D31R(L)-MF	95D31R(L)-MF
1 100	1 130	4 0 (A)	5 0 (A)	6 0 (A)	7 0 (A)	8 0 (A)	9 0 (A)				
1 130	1 160	3 0 (A)	4 0 (A)	5 0 (A)	6 0 (A)	7 0 (A)	8 0 (A)				
1 160	1 190	2 0 (A)	3 0 (A)	4 0 (A)	5 0 (A)	6 0 (A)	7 0 (A)				
1 190	1 220	2 0 (A)	2 0 (A)	3 0 (A)	4 0 (A)	5 0 (A)	5 0 (A)				

- Check battery type and determine the specified current using the table shown above
- After starting charging, adjustment of charging current is not necessary

Fig 5 ADDITIONAL CHARGE (Standard charge)



CAUTION:

- Do not use standard charge method on a battery whose specific gravity is less than 1.100.
- Set charging current to value specified in Fig. 4. If charger is not capable of producing specified current value, set its charging current as close to that value as possible.
- Keep battery away from open flame while it is being charged.
- When connecting charger, connect leads first, then turn on charger. Do not turn on charger first, as this may cause a spark.
- If battery temperature rises above 60°C (140°F), stop charging. Always charge battery when its temperature is below 60°C (140°F).

BATTERY

M.F. Battery Test and Charging Chart (Cont'd)

C QUICK CHARGE




Fig 6 INITIAL CHARGING CURRENT SETTING AND CHARGING TIME (Quick charge)

CON VERTED SPECIFIC GRAVITY	BATTERY TYPE CUR RENT [A]	28B19R(L)-MF 34B19R(L)-MF	46B24R(L)-MF 55B24R(L)-MF 50D23R(L)-MF	55D23R(L)-MF 65D26R(L)-MF 80D26R(L)-MF	75D31R(L)-MF 95D31R(L)-MF
		10 (A)	15 (A)	20 (A)	30 (A)
1 100 - 1 130		2 5 hours			
1 130 - 1 160		2 0 hours			
1 160 - 1 190		1 5 hours			
1 190 - 1 220		1 0 hours			
Above 1 220		0 75 hours (45 min)			

- Check battery type and determine the specified current using the table shown above
- After starting charging, adjustment of charging current is not necessary

CAUTION:

- Do not use quick charge method on a battery whose specific gravity is less than 1.100.
- Set initial charging current to value specified in Fig 6. If charger is not capable of producing specified current value, set its charging current as close to that value as possible.
- Keep battery away from open flame while it is being charged.
- When connecting charger, connect leads first, then turn on charger. Do not turn on charger first, as this may cause a spark.
- Be careful of a rise in battery temperature because a large current flow is required during quick-charge operation.
If battery temperature rises above 60°C (140°F), stop charging. Always charge battery when its temperature is below 60°C (140°F)
- Do not exceed the charging time specified in Fig. 6, because charging battery over the charging time can cause deterioration of the battery


Service Data and Specifications (S.D.S.)

Applied model	U S A	U S A option and Canada
Type	55D23R-MF	75D31R-MF
Capacity	V-AH	12-60
		12-70

STARTING SYSTEM


Wiring Diagram

M/T MODEL



SEL080J

A/T MODEL




SEL081J

STARTING SYSTEM —Starter—

Construction

S114-457



Unit: mm (in)
 . N-m (kg-m, ft-lb)
 High-temperature grease point

Unit mm (in)

N-m (kg-m, ft-lb)

High-temperature grease point

SEL623D


STARTING SYSTEM —Starter—

Magnetic Switch Check

- Before starting to check, disconnect battery ground cable.
- Disconnect "M" terminal of starter motor.


1 Continuity test (between "S" terminal and switch body)

- No continuity ... Replace.



2. Continuity test (between "S" terminal and "M" terminal)


- No continuity ... Replace.




Pinion/Clutch Check

1 Check to see if clutch assembly locks in one direction and rotates smoothly in the opposite direction.

- If it does not lock (or locks) in either direction or unusual resistance is evident ... Replace.




2. Check pinion movement.



3. Check ball bearing.

Spin outer race of ball bearing to ensure that it turns smoothly without binding.



- Abnormal resistance Replace.

STARTING SYSTEM —Starter—


Brush Check

- 4 Inspection pinion teeth
 - Replace pinion if teeth are worn or damaged. (Also check condition of ring gear teeth)
- 5 Inspect reduction gear teeth
 - Replace reduction gear if teeth are worn or damaged (Also check condition of armature shaft gear teeth)

BRUSH

Check wear of brush

Wear limit length: 11 mm (0.43 in)




SEL626B

- Excessive wear Replace

BRUSH HOLDER

- 1 Perform insulation test between brush holder (positive side) and its base (negative side)




SEL568B


- Continuity exists Replace
- 2 Check brush holder to see if it moves smoothly
 - If brush holder is bent, replace it, if sliding surface is dirty, clean

Field Coil Check

- 1 Continuity test (between field coil positive terminal and positive brushes)



- No continuity . Replace field coil
- 2 Insulation test (between field coil positive terminal and yoke)




- Continuity exists ... Replace field coil

STARTING SYSTEM —Starter—

Armature Check


- 1 Continuity test (between two segments side by side)



SEL625B

- No continuity Replace.

- 2 Insulation test (between each commutator bar and shaft)




SEL104E

- Continuity exists . Replace

- 3 Check commutator surface

- Rough Sand lightly with No 500 - 600 sandpaper




SEL624B

- 4 Check diameter of commutator

Commutator minimum diameter
29 mm (1.14 in)

- Less than specified value Replace




SEL418A

- 5 Check depth of insulating mica from commutator surface.


- Less than 0.2 mm (0.008 in) Undercut to 0.5 - 0.8 mm (0.020 - 0.031 in)

Undercut procedures




0.5 - 0.8 mm
(0.020 - 0.031 in)

Round



Correct



File

Commutator

Segment

Mica



Incorrect

EE021

STARTING SYSTEM —Starter—

Assembly

Carefully observe the following instructions.


a. Apply grease to:

- Rear cover metal
- Gear case metal
- Frictional surface of pinion
- Moving portion of shift lever
- Plunger of magnetic switch

Compare difference "g" in height of pinion when it is pushed out with magnetic switch energized and when it is pulled out by hand until it touches stopper


Difference "g":

0.3 - 1.5 mm (0.012 - 0.059 in)



SEL497D

- Not in the specified value ... Adjust by dust cover (Adjusting plate).



SEL573B

Service Data and Specifications


(S.D.S.)

Applied model		All
Type		S114-457
System voltage	V	12
No load		
Terminal voltage	V	11
Current	A	Less than 100
Revolution	rpm	More than 3,900
Outer diameter of commutator	mm (in)	More than 29 (1 1/4)
Minimum length of brush	mm (in)	11 (0.43)
Brush spring tension	N (kg, lb)	15.7 - 19.6 (1.6 - 2.0, 3.5 - 4.4)
Difference "g" in height of pinion assembly	mm (in)	0.3 - 1.5 (0.012 - 0.059)

CHARGING SYSTEM

Wiring Diagram

TURBO MODEL




SEL082J

CHARGING SYSTEM

Wiring Diagram (Cont'd)

NON-TURBO MODEL



SEL083J


CHARGING SYSTEM

Trouble-shooting

Before conducting an alternator test, make sure that the battery is fully charged. A 30-volt voltmeter and suitable test probes are necessary for the test. The alternator can be checked easily by referring to the Inspection Table.

Before starting trouble-shooting, inspect the fusible link.


WITH IC REGULATOR



CHARGING SYSTEM —Alternator—

Construction

A2T48195 (MITSUBISHI make)



*Rear bearing


CAUTION:

Rear cover may be hard to remove because a ring is used to lock outer race of rear bearing. Be careful not to lose this ring during removal.

CHARGING SYSTEM —Alternator—

Removal


- Remove bolts from alternator
- Remove bolts for front stabilizer.
- Manually move stabilizer down and remove alternator.



Disassembly


CAUTION:

Rear cover may be hard to remove because a ring is used to lock outer race of rear bearing. To facilitate removal of rear cover, heat only the bearing box section with a 200-watt soldering iron. Do not use a heat gun, as it can damage diode assembly.




Rotor Slip Ring Check

1. Continuity test



- No continuity ... Replace rotor.

2. Insulator test



- Continuity exists ... Replace rotor.

3. Check slip ring for wear

Slip ring minimum outer diameter:


21.6 mm (0.850 in) [HITACHI make]

22.4 mm (0.882 in) [MITSUBISHI make]

CHARGING SYSTEM —Alternator—

Brush Check

1. Check for smooth movement of brush
 - Not smooth ... Check brush holder and clean.
2. Check brush for wear.




SEL631D

- Replace brush if it is worn down to the limit line
3. Check brush pig tail for damage.
 - Damaged ... Replace.
 4. Check brush spring pressure.
Measure brush spring pressure with brush projected approximately 2 mm (0.08 in) from brush holder.

Spring pressure:

- 1.471 - 3.531 N (150 - 360 g,
5.29 - 12.70 oz) [HITACHI make]
- 3.040 - 4.217 N (310 - 430 g,
10.93 - 15.17 oz) [MITSUBISHI make]



EE049


- Not in the specified value .. Replace

Stator Check

To test the stator or diode, you must separate them by unsoldering the connecting wires.


CAUTION

Used only as much heat as required to melt solder.
Diodes will be damaged if excessive heat is applied.



SEL054D


1 Continuity test



SEL108E

- No continuity Replace stator

2 Ground test



SEL109E

- Continuity exists .. Replace stator


CHARGING SYSTEM —Alternator—

Diode Check

DIODE


- Use an ohmmeter to check condition of diodes as indicated in chart below
- If any of the test results is not satisfactory, replace diode assembly

	Ohmmeter probes		Continuity
	Positive $\oplus$	Negative $\ominus$	
Diodes check (Positive side)	Positive diode plate	Diode terminals	Yes
	Diode terminals	Positive diode plate	No
Diodes check (Negative side)	Negative diode plate	Diode terminals	No
	Diode terminals	Negative diode plate	Yes



Sub-diode

- Attach ohmmeters' probe to each end of diode and check for continuity.




- Continuity is N.G. . . Replace diode assembly

CHARGING SYSTEM —Alternator—

Assembly


Carefully observe the following instructions.

1. When soldering each stator coil lead wire to diode assembly terminal, perform the operation as fast as possible.
2. When soldering brush lead wire, observe the following.
 - Position brush so that its wear limit line protrudes 2 mm (0.08 in) beyond end face of brush holder.




SEL632D

3. Fit ring into groove in rear bearing so that it is as close to the adjacent area as possible.




SEL633D

4. Before installing front cover with pulley and rotor to rear cover, push brush up with fingers and retain brush by inserting brush lift into brush lift hole from outside. After installing, remove wire for brush lift.



EE540



EE541

5. After installing front and rear covers of alternator, pull brush lift by pushing toward center. Do not pull brush lift by pushing toward outside of cover as it will damage slip ring sliding surface.



CHARGING SYSTEM —Alternator—

— Service Data and Specifications (S.D.S.)

Type	A2T48195
Applied model	All
Nominal rating V-A	12-70
Ground polarity	Negative
Minimum revolution under no-load (when 14 volts is applied) rpm	Less than 1,100
Hot output current A/rpm	More than 21/1,300 More than 50/2,500
Regulated output voltage V	14.1 - 14.7
Minimum length of brush mm (in)	More than 8 (0.31)
Brush spring pressure N (g, oz)	3.040 - 4.217 (310 - 430, 10.93 - 15.17)
Slip ring outer diameter mm (in)	More than 22.4 (0.882)

COMBINATION SWITCH

Check




LIGHTING SWITCH

	OFF			1ST			2ND		
	A	B	C	A	B	C	A	B	C
5									
6									
7									
8									
9									
10									
11									
12									
26									
27									


WIPER SWITCH

	OFF	INT	LO	HI	WASH
13					
14					
15					
16					
17					
18					

INTERMITTENT WIPER VOLUME



HORN SWITCH



ASC D SWITCH

	CANSEL	RESUME	ACCEL	SET COAST
21				
22				
23				
24				
25				

	R	N	L
1			
2			
3			


TURN SIGNAL SWITCH

SEL642D

COMBINATION SWITCH



Replacement

Lighting switch wiper & washer switch and A.S.C.D switch can be replaced without removing combination switch base



SEL643D

To remove combination switch base, remove base attaching screw and turn after pushing on it.




SEL644D

INSTRUMENT SWITCH

Check

INSTRUMENT SWITCH L.H.



RETRACT SWITCH

	UP	DOWN
9		
10		
11		
12		
27		
28		
13		
14		

HAZARD SWITCH


	OFF	ON
2		
1		
7		
3		
4		
5		

A S C D MAIN SWITCH


	OFF	N	ON
17			
18			
19			

ILLUMINATION CONTROL SWITCH

	BRIGHT	DARK
15		
16		
14		



INSTRUMENT SWITCH R.H.



REAR DEFOGGER SWITCH

	OFF	TIME	N
18			
19			
20			
21			
22			
23			

REAR WIPER & WASHER SWITCH

	WIPE WASH	OFF	WIPE	WIPE WASH
5				
6				
7				
8				

AUXILIARY DRIVING LAMP SWITCH

	OFF	ON
10		
11		
12		




- For removal, refer to "INSTRUMENT" in BF section

SEL497F

HEADLAMP

Schematic




SEL084J

HEADLAMP


Wiring Diagram

WITHOUT HEADLAMP SENSOR



HEADLAMP

Wiring Diagram (Cont'd)




SEL085J

HEADLAMP


Wiring Diagram (Cont'd)

WITH HEADLAMP SENSOR



HEADLAMP

Wiring Diagram (Cont'd)




SEL086J

HEADLAMP

Operation

- The following chart depicts the operational modes of relays and headlamp motors in relation to the positions of the lighting switch and retract switch.



SEL743D


HEADLAMP

Description

CIRCUIT OPERATION

[A] When lighting switch is switched from "1ST" → "2ND"

A-1· While operating the headlamp motor to open position




SEL240J

HEADLAMP

Description (Cont'd)

A-2: After the headlamp motor reaches fully open position




SEL241J

HEADLAMP

Description (Cont'd)


- [B] When lighting switch is switched from "2ND" → "1ST"
(Headlamp goes out and keeps up by headlamp timer and headlamp relay.)



HEADLAMP

Description (Cont'd)

- [C] When lighting switch is switched from "1ST" → "OFF"
(While operating the headlamp motor to closed position)




SEL243J

HEADLAMP

Description (Cont'd)

[D]


D-1: When lighting switch is switched to "PASSING"



SEL244J

Description (Cont'd)


Closing operation is the same as [C] when lighting switch is switched from "1ST" → "OFF"



HEADLAMP

Description (Cont'd)

- [E] When retractor switch is turned ON
(While operating the headlamp motor to open position)




SEL246J

HEADLAMP

Description (Cont'd)


- [F] When retractor switch is turned OFF
(While operating the headlamp motor to closed position)



SEL247J


HEADLAMP

Trouble-shooting



HEADLAMP



Removal



HEADLAMP

Installation


- 1 Set the headlamp motor to "DOWN" position
- Connect harness to headlamp motor and set retract switch to "DOWN". Headlamp motor can now be set to "DOWN" with retract switch.
- 2 Install the headlamp link assembly and headlamp motor in the body.
3. Install the connecting link
- When installing the link to the motor, make sure the motor link is installed as shown below.



SEL649D


Adjustment

- After installing connecting link, always adjust it as follows:
 - 1) Set the headlamp to "DOWN" position
 - 2) Adjust connecting link so that the lid is properly aligned with hood and fender.



SEL650D

- 3) Set the headlamp to "UP" position.
- 4) Adjust stopper screw.



SEL651D

HEADLAMP



Headlamp Motor Check

- Use an ohmmeter to check for continuity in headlamp motor circuit while rotating motor with manual knob

CAUTION:

Prior to performing continuity test, disconnect ground cable from battery.

Headlamp	Ohmmeter probe		Continuity
	(+)	(-)	
DOWN	⑤	①	Yes
	①	⑤	No
	⑦	①	Yes
	①	⑦	No
UP	⑤	②	Yes
	②	⑤	No
	⑦	②	Yes
	②	⑦	No

**SEL652D**

Aiming Adjustment



When performing headlamp aiming adjustment, use an aiming machine, aiming wall screen or headlamp tester. For operating instructions of any aimer, it should be in good repair, calibrated and used according to respective operation manuals supplied with the unit.

If aimer is not available, aiming adjustment can be done as follows

For details, refer to the regulations in your own country

CAUTION:

- a. **Keep all tires inflated to correct pressures**
- b. **Place vehicle and tester on the same flat surface.**
- c. **Ensure that there is no load in vehicle (coolant, engine oil filled up to correct level and full fuel tank) other than the driver (or equivalent weight placed in driver's position).**

$$W_L = 1,120 \text{ (44 09)}$$


SEL914D


- Adjust headlamps so that upper edge and left edge of high intensity zone are within the acceptable range as shown in the figure above.
- Dotted lines in illustration show center of headlamp

HEADLAMP

Aiming Adjustment (Cont'd)

LOW BEAM



- 1 Turn headlamp low beam on
 - 2 Use adjusting screws to perform aiming adjustment
- Before adjusting headlamps, remove covers.
 - First tighten the adjust screw all the way and then make adjustment by loosening the screw.



SEL138J

When using a mechanical aimer, adjust it to the data stamped on the headlamps

Example.




SEL139J

Bulb Replacement

The headlamp is a semi-sealed beam type which uses a replaceable halogen bulb. A bulb can be replaced from the engine compartment side without removing the headlamp body.

- Grasp only its plastic base when handling the bulb. Never touch the glass envelope.
- 1 Disconnect the battery cable
 - 2 Turn the bulb retaining ring counterclockwise until it is free from the headlight reflector, and then remove it
 3. Disconnect the harness connector from the rear end of the bulb
 - 4 Remove the headlamp bulb carefully. Do not shake or rotate the bulb when removing it.



SEL348F

- 5 Installation is in the reverse order of removal


CAUTION:

- Do not leave the bulb out of the headlamp reflector for a long period of time as dust, moisture, smoke, etc. may enter the headlamp body and affect the performance of the headlamp. Thus, the headlamp bulb should not be removed from the headlamp reflector until just before a replacement bulb is to be installed.

EXTERIOR LAMP

Clearance, License, Tail and Stop Lamps/Wiring Diagram


WITHOUT STOP & TAIL LAMP SENSOR



SEL087J

EXTERIOR LAMP


Clearance, License, Tail and Stop Lamps/Wiring Diagram (Cont'd)
WITH STOP & TAIL LAMP SENSOR




SEL088J

EXTERIOR LAMP

Auxiliary Driving Lamp/Wiring Diagram




Back-up Lamp/Wiring Diagram



EXTERIOR LAMP

Turn Signal and Hazard Warning Lamps/Wiring Diagram



EXTERIOR LAMP

_Stop and Tail Lamp Sensor Check


Bulb Specifications

- Before checking, ensure that bulbs meet specifications.

STOP LAMP

Start engine

Stop lamp switch on (Depress brake pedal)



All stop lamps in good order:

Approx. 5V (Digital type combination meter)

Approx. 12V (Needle type combination meter)

At least one of stop lamps is moved:


Less than 3V (Digital type combination meter)

Approx. 1V (Needle type combination meter)

TAIL LAMP

Start engine.

Lighting switch on



All tail lamps in good order:

Approx. 5V (Digital type combination meter)

Approx. 12V (Needle type combination meter)

At least one of tail lamps is moved:

Less than 3V (Digital type combination meter)

Approx. 1V (Needle type combination meter)


Item	Wattage (W)	Bulb No
Headlamp	65/45	9004
Auxiliary driving lamp	55	—
Front combination lamp	27/8	1157
Front side marker lamp	3 4	158
Rear side marker lamp	3 4	158
Rear combination lamp		
Turn signal	27	1073
Stop/Tail	27/8	1157
Back-up	27	1073
License plate lamp	3 8	—
High-mounted stop lamp	7 3*	—
Interior lamp	10	—
Spot lamp	8	—
Rear (luggage) compartment lamp	3 4	—
Door step lamp	5	—
Leg room lamp	2	—

- Light emission diode

INTERIOR LAMP

Illumination/Wiring Diagram

NEEDLE TYPE COMBINATION METER EQUIPPED MODEL




SEL092J

INTERIOR LAMP

Illumination/Wiring Diagram (Cont'd)

DIGITAL TYPE COMBINATION METER EQUIPPED MODEL (GLL)




SEL093J

INTERIOR LAMP

Interior, Luggage and Step Lamps/Wiring Diagram

SF MODEL




SEL094J

INTERIOR LAMP

Interior, Luggage and Step Lamps/Wiring Diagram (Cont'd)

GL MODEL




SE L095J

INTERIOR LAMP

Interior, Luggage and Step Lamps/Wiring Diagram (Cont'd)


GLL MODEL



SE L096J

INTERIOR LAMP

Illuminated Entry System and Door Key Illumination/Wiring Diagram




SEL097J

METER AND GAUGES — Digital Type Combination Meter

Combination Meter

CAUTION:


Electrical terminal should not be touched with bare hands.



SEL140J

METER AND GAUGES — Digital Type Combination Meter


Combination Meter (Cont'd)



SEL141J

METER AND GAUGES — Digital Type Combination Meter


Schematic



SEL099J


METER AND GAUGES — Digital Type Combination Meter

Wiring Diagram



METER AND GAUGES — Digital Type Combination Meter

Wiring Diagram (Cont'd)



METER AND GAUGES — Digital Type Combination Meter

Self-check


Digital type combination meter consists of three units: a control unit, power unit, and display unit. In order to judge if there is a defect in the meter and which unit is malfunctioning, trouble-shooting should be performed by using the following two types of self-check functions built into the meter.

For details, refer to "Trouble-shooting".

DISPLAY CHECK

This is used to check for an open circuit in each segment of the display and a short circuit between segments.

- (1) While pushing trip reset switch A, turn ignition switch from "OFF" to "ON". Trip reset switch A should remain pushed in until self-check operation starts.
- (2) Meter starts to automatically perform self-check. Segments for meters and gauges should illuminate one after another.
- (3) If any particular segment remains off, combination meter itself is faulty.




A display check will be cancelled and the normal display restarted in the following cases:

- If the vehicle has operated during the display check.
- If a series of display check items have been completed.



PRE-PROGRAMED SIGNAL CHECK

This is used to check for a defect in the meter.

- (1) Remove power unit.
- (2) Remove nuts which secure instrument switches.
- (3) Remove instrument switches.
- (4) Remove cluster lid A.




- (5) Remove combination meter.
- (6) Disconnect connectors from instrument harness.
- (7) Connect a self-checking tool (Diagnostic sub-harness) to meter.




METER AND GAUGES — Digital Type Combination Meter

Self-check (Cont'd)



(8) Turn the ignition switch to "ON"

(9) If a display such as the following figure appears on meter, the results of the pre-programmed signal check are satisfactory.



SEL148J

METER AND GAUGES — Digital Type Combination Meter

Trouble-shooting —Quick Reference Table—


The following Quick Reference Table lists various combination meter troubles and self-checks and voltage or resistance checks to be made.

For trouble-shooting procedures, refer to the pertinent flow charts on the pages that follow this Table

Reference flow chart number		Trouble condition	Check item			
			Self-check		Volt/ohm check	
			Display unit check	Pre-programmed signal check	Meter side	Vehicle harness side
Speedometer	1	Always indicates zero ("0")		○	○	○
	2	Indication error is noted		○		○
	3	Indicated value changes irregularly		○		○
	4	All segments become illuminated	○			
	5	All segments fail to illuminate	○			
	6	Sometimes indicates zero ("0")		○		○
Tacho & torque meter	7	Tachometer does not operate	○	○	○	○
	8	Torque meter does not operate	○	○		○
Gauges	9	Water temp gauge does not function	○	○		○
	10	Fuel gauge does not function	○	○		○
	11	Fuel gauge does not reach "Full"	○	○		○
Drive information	12	"DIST TO EMPTY" does not operate	○	○		○
	13	"AVE SPEED" does not operate	○	○		
	14	"AVE MPG" does not operate	○	○		○
Others	15	Trip meter does not function	○			
	16	Odometer does not function.		○	○	
	17	Warning display does not operate	○	○		○
	18	Segments do not operate normally	○			

METER AND GAUGES — Digital Type Combination Meter

Trouble-shooting Flow Chart



METER AND GAUGES — Digital Type Combination Meter

Trouble-shooting Flow Chart (Cont'd)

5 Speedometer all segments fail to illuminate

Go to "Power Unit Check" to check power unit output voltage for speedometer

OK

NG

Replace power unit

Make display unit check (Refer to "Self-Check")

OK

NG

Replace control unit

Replace display unit

6 Speedometer sometimes indicates zero ("0")

While making pre-programmed signal check, lightly tap on control unit and display unit with screw-driver to see if display changes

OK

NG

Replace control unit

- Speed sensor is broken.
- Damaged speed sensor circuit

7 Tachometer does not operate

Make pre-programmed signal check (Refer to "Self-Check")

OK

Check tachometer input signal circuit.

OK

NG

- Malfunctioning ignition circuit

Replace control unit

NG

Make display unit check (Refer to "Self-Check")


OK

NG

Replace control unit

Replace display unit


- 1 Turn ignition switch to "ON"
2. Connect voltmeter between ① and ⑭ .





METER AND GAUGES — Digital Type Combination Meter

Trouble-shooting Flow Chart (Cont'd)


8 Torque meter does not operate




1. Disconnect meter harness connector (Black)
2. Connect vacuum pump gauge to boost sensor vacuum hose
3. Turn the ignition switch to "ON"
4. Apply vacuum pressure to boost sensor by vacuum pump gauge and measure voltage across ① and ②



9 Water temp gauge does not function



1. Disconnect meter harness connector (Black)
2. Turn ignition switch to "OFF".
3. Measure resistance between ② and ①



Ignition switch → OFF

Engine coolant temperature	Resistance
60°C or less	70Ω or more
60°C or more	Approx 10 - 70Ω

SEL156J

METER AND GAUGES — Digital Type Combination Meter

Trouble-shooting Flow Chart (Cont'd)

10 Fuel gauge does not function

Make pre-programmed signal check
(Refer to "Self-Check")

OK

NG

Check fuel tank
gauge circuit

OK

NG

Replace
control unit

Go to "Fuel Tank
Gauge unit Check"

OK

NG

• Damaged fuel
tank gauge unit
circuit

Replace fuel
tank gauge unit

Make display unit check (Refer to
"Self-Check")

Replace control
unit

Replace display
unit

11 Fuel gauge does not reach "Full"

Make pre-programmed signal check
(Refer to "Self-Check")

OK

NG

Check fuel tank
gauge circuit

OK

NG

Replace
control unit

Go to "Fuel Tank
Gauge Unit Check"

OK

NG

• Damaged fuel
tank gauge unit
circuit


Replace fuel
tank gauge unit

Make display unit check (Refer
to "Self-Check")

Replace control
unit

Replace display
unit

- 1 Disconnect meter harness connector (Black)
2. Turn ignition switch to "OFF".
- 3 Measure resistance between ②9 and ②1



METER AND GAUGES — Digital Type Combination Meter

Trouble-shooting Flow Chart (Cont'd)

12 "DIST TO EMPTY" does not operate

Is speedometer normal?

YES

NO

Go to "Trouble-shooting 1-6"

Is fuel gauge normal?

YES

NO

Go to "Trouble-shooting 10-11"

Make pre-programmed signal check
(Refer to "Self-Check")

OK

N.G.

Check injection pulse circuit

N G

Replace control unit

OK

- Malfunctioning E C C S control unit
- Damaged injection pulse circuit

Make display unit check (Refer to "Self-Check")

OK

Replace control unit

N G

Replace drive information unit

FUEL INJECTION PULSE CIRCUIT CHECK

1. Turn ignition switch to "ON"
2. Connect voltmeter between ③③ and ②①

13 "AVE SPEED" does not operate

Make display unit check (Refer to "Self-Check")

OK

Replace control unit

N G

Replace drive information unit

14 "AVE MPG" does not operate

Is speedometer normal?

YES

NO

Go to "Trouble-shooting 1-6"

Make pre-programmed signal check
(Refer to "Self-Check")

OK

N G

Check injection pulse circuit

N G

Replace control unit

OK

- Malfunctioning E C C S control unit
- Damaged injection pulse circuit


Make display unit check (Refer to "Self-Check")

OK

Replace control unit

N G

Replace drive information unit.




SEL158J


METER AND GAUGES — Digital Type Combination Meter

Trouble-shooting Flow Chart (Cont'd)


15 Trip meter does not function.




17 Warning display does not operate



16 Odometer does not function




18 Segments do not operate normally



METER AND GAUGES — Digital Type Combination Meter

Power Unit Check

- Remove power unit with harness connected.
- Perform voltage and continuity tests Refer to chart below



SEL159J

- Turn ignition switch to "ON"

Voltmeter terminal		Voltage [V]	Remarks
+	-		
②	⑨	Approx 12	Check when no display appears
③		Approx 0	
⑤		Approx 22	
⑥		Approx 26	
⑨	⑦	Approx 23	For speedometer, fuel, information, tachometer
	⑬	Approx. 14	
	⑭		For temp , trip
	⑮	Approx 19	
	⑯		

- Turn ignition switch to "OFF".

Ohmmeter		Continuity	Remarks
(+)	(-)		
⑨	Body ground	Yes	Check when no display appears

If specified voltage or continuity is not produced, replace power unit


Boost Sensor Check

- Connect vacuum pump gauge to boost sensor vacuum hose.
- Disconnect harness connector from boost sensor and connect battery and voltmeter as shown
- Apply vacuum pressure to boost sensor by vacuum pump gauge and measure voltages

Approx. 2.2V at 0 kPa (0 mmHg, 0 inHg)
(Atmospheric pressure)

Approx. 1.3V

at -53.3 kPa (-400 mmHg, -15.75 inHg)



SEL674D

METER AND GAUGES — Digital Type Combination Meter


Speed Sensor Signal Check

SPEED SENSOR OUTPUT CHECK

When speedometer is functioning properly, this test is not necessary. Go to "Meter Output check".


- 1 Remove cluster lid A
- 2 Connect a voltmeter between ⑪ and ① on combination meter side. Combination meter harness connector should remain connected to instrument harness.
- 3 Turn ignition switch from "OFF" to "ON". Voltmeter should indicate approximately 5 volts when switch is "ON".

If voltmeter indicates no voltage, go to "Power Unit Check".



SEL160J


4. Turn ignition switch to "OFF".
5. Disconnect speedometer cable from speed sensor and remove speed sensor with harness connected.
6. Disconnect combination meter harness from instrument harness as shown below, and connect a voltmeter across ⑫ and ①.



SEL161J

7. Turn ignition switch "OFF" → "ON".
8. Slowly turn speed sensor rotor shaft with a suitable screwdriver to make sure voltmeter pointer deflects.

Do not turn rotor shaft quickly as voltmeter deflects 24 times per revolution of rotor shaft.



SEL162J


If voltmeter pointer does not deflect, replace speed sensor.

METER AND GAUGES — Digital Type Combination Meter

Speed Sensor Signal Check (Cont'd)

METER OUTPUT CHECK


- Combination meter emits speed sensor signal to control E.C.C.S. control unit, A S.C.D. control unit, voice warning unit and A/T control unit
1. Disconnect speedometer cable from speed sensor and remove speed sensor with harness connected
 2. Remove cluster lid A.
 3. Connect a voltmeter between ⑮ and ① from meter harness side.



SEL163J

4. Turn ignition switch "OFF" → "ON"
5. Slowly turn speed sensor rotor shaft with a suitable screwdriver to make sure ohmmeter pointer deflects.

Ohmmeter pointer should deflect twice for each rotation or rotor shaft



SEL164J

If ohmmeter pointer does not deflect, go to "Speed Sensor Output Check". (Refer to back page)


METER AND GAUGES — Digital Type Combination Meter

Fuel Tank Gauge Check

- For removal, refer to FE section


Ohmmeter terminal		Float position	Resistance value
(+)	(-)		
②	①	Full	Approx 10 - 20Ω
		Empty	Approx 480 - 520Ω
		1/2	Approx 100 - 110Ω
③	①	A	Approx 4Ω or below
		B	Approx 870 - 930Ω
④	①	B	0Ω

Main gauge



SEL675D


Sub gauge



SEL676D

Water Temp Sensor Check


Cylinder head R H side



SEL677D

METER AND GAUGES —Needle Type Combination Meter


Combination Meter



SEL103J

METER AND GAUGES — Needle Type Combination Meter

Tachometer, Fuel and Water Temperature Gauges/Wiring Diagram



© GL and GLL models

SEL104J


METER AND GAUGES —Needle Type Combination Meter

Fuel Tank Gauge Check

- For removal, refer to FE section


Ohmmeter terminal		Float position	Resistance value
(+)	(-)		
②	①	Full Empty 1/2	Approx 6Ω Approx 80Ω Approx 30 - 35Ω
③	①	A B	More than 60Ω Less than 6Ω

Main gauge



SEL675D


Sub gauge



SEL676D

Speed Sensor Signal Check.


- 1 Remove speed sensor from transmission
Location Refer to "Location of Electrical units"
- 2 Turn speedometer pinion quickly and measure voltage across ① and ②



Speed Sensor Installation.

When you install the speed sensor, be careful of the following

1. Connect pinion shaft and thrusting key as shown below



- 2 Install speed sensor to speedometer pinion by hand, and then tighten speed sensor nut to the specified torque


Tightening torque of speed sensor nut:

29 - 49 N·m

(3.0 - 5.0 kg-m, 22 - 36 ft-lb)

METER AND GAUGES — Needle Type Combination Gauge

Combination Gauge




SEL693D

METER AND GAUGES — Needle Type Combination Gauge


Oil Temp. Sensor Check

1. Warm up engine.
2. Stop engine and turn ignition switch OFF
3. Check resistance of oil temp. sensor



SEL695D

Oil Pressure Sensor Check




SEL678D

Ohmmeter terminal		With engine stopped	With engine running (idling)
(+)	(-)		
①	Engine ground	0Ω	∞
②		More than 74Ω	Less than 60Ω

Boost Gauge Trimmer Adjustment

- When boost gauge does not give proper reading, adjust 0 kPa (0 mmHg, 0 inHg) point with the trimmer located on interior upper wall of glove box.
- Use a screwdriver to adjust trimmer




SEL273B

- For checking boost sensor, refer to page EL-79.

METER AND GAUGES — Needle Type Combination Gauge

Oil Temp, Oil Pressure, Boost and Volt Gauges/Wiring Diagram


DIGITAL METER TYPE MODEL



METER AND GAUGES — Needle Type Combination Gauge

— Oil Temp, Oil Pressure, Boost and Volt Gauges/Wiring Diagram (Cont'd) —


NEEDLE METER TYPE MODEL



SEL105J

WARNING LAMPS AND CHIME


Schematic



SEL106J

WARNING LAMPS AND CHIME


— Warning Lamps/Wiring Diagram— For Digital Type Combination Meter —



WARNING LAMPS AND CHIME

— Warning Lamps/Wiring Diagram — For Needle Type Combination Meter —

GLL MODEL



SEL109J

Warning Lamps/Wiring Diagram
—For Needle Type Combination Meter (Cont'd)—

This is a comprehensive wiring diagram for a vehicle's electrical system. It illustrates the connections between various components and the power source (battery/alternator). Key components and their connections include:

- Ignition System:** The Ignition Switch (ON or START) is connected to the Fuse Block (10A, 20A, 30A) and the Ignition Coil (10A).
- Lighting:** The Head Lamp Sensor is connected to the Head Lamp Switch (ON or START) and the Head Lamp (10A). The Stop & Tail Lamp Sensor is connected to the Stop & Tail Lamp Switch (ON or START) and the Stop & Tail Lamp (10A).
- Door and Belt:** The Door Switch (ON or START) is connected to the Door Switch (ON or START) and the Door Switch (ON or START). The Seat Belt Switch is connected to the Seat Belt Switch (ON or START) and the Seat Belt Switch (ON or START).
- Gauges and Sensors:** The Fuel Gauge, Oil Pressure Sensor, and Coolant Level Switch are connected to their respective sensors and the Gauge Cluster (10A).
- Wiring Harness:** The diagram shows the routing of wires through the engine compartment, under the dashboard, and into the passenger compartment.
- Wire Color Codes:** Various wire colors are used to identify different circuits, such as BR/W (Brown/White), W/L (White/Light Blue), G/Y (Green/Yellow), and G/B (Green/Black).
- Terminal Numbers:** Numerous terminal numbers are provided for each component, indicating the specific connection points.

AT	A/T model
MT	M/T model
R	2 + 2 seater
T	2 seater
CA	Canada model
US	U.S.A. model


SEL110J

WARNING LAMPS AND CHIME

Warning Lamps/Wiring Diagram

— For Needle Type Combination Meter (Cont'd) —

SF MODEL



SEL111J

Warning Chime/Wiring Diagram.

GL AND SF MODELS

GL AND SF MODELS

Legend:
SF model (Solid line)
GL model (Dashed line)

Wiring Diagram Components and Connections:

- Battery:** Connected to the Ignition Switch (ON or START) and the Fuse Block.
- Ignition Switch (ON or START):** Controls the main power distribution to the Fuse Block.
- Fuse Block:** Contains fuses for various circuits: 10A, 15A, and 20A.
- Headlamp Motor (LH and RH):** Controls the headlamps. The LH motor is connected to the Headlamp Relay, which is controlled by the Headlamp Switch.
- Headlamp Relay:** Controls the power to the Headlamp Motor (LH).
- Uphold Relay:** Controls the power to the Uphold Motor.
- Time Control Unit:** Controls the power to the Time Control Motor.
- Diode:** Connected to the Time Control Unit.
- Warning Chime:** Connected to the main power line.
- Steering Lock Switch:** Controls the power to the Steering Lock Motor.
- Lighting Switch:** Controls the power to the Lighting Motor.
- Retract Switch:** Controls the power to the Retract Motor.
- Seat Belt Switch:** Controls the power to the Seat Belt Motor.
- Door Switch (LH):** Controls the power to the Door Motor.
- Seat Switch:** Controls the power to the Seat Motor.

Wire Color Legend:
BR (Brown)
G (Green)
L (Light Blue)
R (Red)
Y (Yellow)
W (White)
B (Black)

Wire Gauge Legend:
16M, 17M, 18M, 19M, 20M, 21M, 22M, 23M, 24M, 25M, 26M, 27M, 28M, 29M, 30M, 31M, 32M, 33M, 34M, 35M, 36M, 37M, 38M, 39M, 40M, 41M, 42M, 43M, 44M, 45M, 46M, 47M, 48M, 49M, 50M, 51M, 52M, 53M, 54M, 55M, 56M, 57M, 58M, 59M, 60M, 61M, 62M, 63M, 64M, 65M, 66M, 67M, 68M, 69M, 70M, 71M, 72M, 73M, 74M, 75M, 76M, 77M, 78M, 79M, 80M, 81M, 82M, 83M, 84M, 85M, 86M, 87M, 88M, 89M, 90M, 91M, 92M, 93M, 94M, 95M, 96M, 97M, 98M, 99M, 100M

Warning Chime/Wiring Diagram (Cont'd)

GLL MODEL

GLL MODEL

Wiring Diagram Components and Connections:

- Battery:** Connected to the **IGNITION SWITCH ON or START** and **SEAT BELT SWITCH L H**.
- Ignition Switch:** Controls the **HEADLAMP MOTOR R H** and **HEADLAMP MOTOR L H**.
- Seat Belt Switch:** Controls the **HEADLAMP MOTOR R H** and **HEADLAMP MOTOR L H**.
- Headlamp Motors:** **HEADLAMP MOTOR R H** and **HEADLAMP MOTOR L H** are connected to the **UP** and **DOWN** switches.
- Uphold Relay:** Controls the **HEADLAMP MOTOR R H** and **HEADLAMP MOTOR L H**.
- Fuse Block:** Contains fuses for **10A**, **15A**, and **10A**.
- Lighting Switch:** Controls the **HEADLAMP MOTOR R H** and **HEADLAMP MOTOR L H**.
- Steering Lock Switch:** Controls the **HEADLAMP MOTOR R H** and **HEADLAMP MOTOR L H**.
- Retract Switch:** Controls the **HEADLAMP MOTOR R H** and **HEADLAMP MOTOR L H**.
- Warning Chime:** Controls the **HEADLAMP MOTOR R H** and **HEADLAMP MOTOR L H**.
- Door Switch:** Controls the **HEADLAMP MOTOR R H** and **HEADLAMP MOTOR L H**.
- Diode:** Controls the **HEADLAMP MOTOR R H** and **HEADLAMP MOTOR L H**.
- Time Control Unit:** Controls the **HEADLAMP MOTOR R H** and **HEADLAMP MOTOR L H**.
- Body Ground:** Connected to the **HEADLAMP MOTOR R H** and **HEADLAMP MOTOR L H**.

Wiring Diagram Labels:


- UP** (Up)
- DOWN** (Down)
- R** (Right)
- L** (Left)
- R/L** (Right/Left)
- L/R** (Left/Right)
- G/W** (Green/White)
- BR/W** (Brown/White)
- BR** (Brown)
- R/Y** (Red/Yellow)
- R/L** (Red/Left)
- L/R** (Left/Right)
- G/B** (Green/Blue)
- L/Y** (Left/Yellow)
- R/G** (Right/Green)
- L/B** (Left/Blue)
- G** (Green)
- B** (Blue)
- W** (White)
- Y** (Yellow)
- BR** (Brown)
- R** (Red)
- L** (Left)
- R/L** (Right/Left)
- L/R** (Left/Right)
- G/W** (Green/White)
- BR/W** (Brown/White)
- BR** (Brown)
- R/Y** (Red/Yellow)
- R/L** (Red/Left)
- L/R** (Left/Right)
- G/B** (Green/Blue)
- L/Y** (Left/Yellow)
- R/G** (Right/Green)
- L/B** (Left/Blue)
- G** (Green)
- B** (Blue)
- W** (White)
- Y** (Yellow)
- BR** (Brown)
- R** (Red)
- L** (Left)
- R/L** (Right/Left)
- L/R** (Left/Right)
- G/W** (Green/White)
- BR/W** (Brown/White)
- BR** (Brown)
- R/Y** (Red/Yellow)
- R/L** (Red/Left)
- L/R** (Left/Right)
- G/B** (Green/Blue)
- L/Y** (Left/Yellow)
- R/G** (Right/Green)
- L/B** (Left/Blue)
- G** (Green)
- B** (Blue)
- W** (White)
- Y** (Yellow)
- BR** (Brown)
- R** (Red)
- L** (Left)
- R/L** (Right/Left)
- L/R** (Left/Right)
- G/W** (Green/White)
- BR/W** (Brown/White)
- BR** (Brown)
- R/Y** (Red/Yellow)
- R/L** (Red/Left)
- L/R** (Left/Right)
- G/B** (Green/Blue)
- L/Y** (Left/Yellow)
- R/G** (Right/Green)
- L/B** (Left/Blue)
- G** (Green)
- B** (Blue)
- W** (White)
- Y** (Yellow)
- BR** (Brown)
- R** (Red)
- L** (Left)
- R/L** (Right/Left)
- L/R** (Left/Right)
- G/W** (Green/White)
- BR/W** (Brown/White)
- BR** (Brown)
- R/Y** (Red/Yellow)
- R/L** (Red/Left)
- L/R** (Left/Right)
- G/B** (Green/Blue)
- L/Y** (Left/Yellow)
- R/G** (Right/Green)
- L/B** (Left/Blue)
- G** (Green)
- B** (Blue)
- W** (White)
- Y** (Yellow)
- BR** (Brown)
- R** (Red)
- L** (Left)
- R/L** (Right/Left)
- L/R** (Left/Right)
- G/W** (Green/White)
- BR/W** (Brown/White)
- BR** (Brown)
- R/Y** (Red/Yellow)
- R/L** (Red/Left)
- L/R** (Left/Right)
- G/B** (Green/Blue)
- L/Y** (Left/Yellow)
- R/G** (Right/Green)
- L/B** (Left/Blue)
- G** (Green)
- B** (Blue)
- W** (White)
- Y** (Yellow)
- BR** (Brown)
- R** (Red)
- L** (Left)
- R/L** (Right/Left)
- L/R** (Left/Right)
- G/W** (Green/White)
- BR/W** (Brown/White)
- BR** (Brown)
- R/Y** (Red/Yellow)
- R/L** (Red/Left)
- L/R** (Left/Right)
- G/B** (Green/Blue)
- L/Y** (Left/Yellow)
- R/G** (Right/Green)
- L/B** (Left/Blue)
- G** (Green)
- B** (Blue)
- W** (White)
- Y** (Yellow)
- BR** (Brown)
- R** (Red)
- L** (Left)
- R/L** (Right/Left)
- L/R** (Left/Right)
- G/W** (Green/White)
- BR/W** (Brown/White)
- BR** (Brown)
- R/Y** (Red/Yellow)
- R/L** (Red/Left)
- L/R** (Left/Right)
- G/B** (Green/Blue)
- L/Y** (Left/Yellow)
- R/G** (Right/Green)
- L/B** (Left/Blue)
- G** (Green)
- B** (Blue)
- W** (White)
- Y** (Yellow)
- BR** (Brown)
- R** (Red)
- L** (Left)
- R/L** (Right/Left)
- L/R** (Left/Right)
- G/W** (Green/White)
- BR/W** (Brown/White)
- BR** (Brown)
- R/Y** (Red/Yellow)
- R/L** (Red/Left)
- L/R** (Left/Right)
- G/B** (Green/Blue)
- L/Y** (Left/Yellow)
- R/G** (Right/Green)
- L/B** (Left/Blue)
- G** (Green)
- B** (Blue)
- W** (White)
- Y** (Yellow)
- BR** (Brown)
- R** (Red)
- L** (Left)
- R/L** (Right/Left)
- L/R** (Left/Right)
- G/W** (Green/White)
- BR/W** (Brown/White)
- BR** (Brown)
- R/Y** (Red/Yellow)
- R/L** (Red/Left)
- L/R** (Left/Right)
- G/B** (Green/Blue)
- L/Y** (Left/Yellow)
- R/G** (Right/Green)
- L/B** (Left/Blue)
- G** (Green)
- B** (Blue)
- W** (White)
- Y** (Yellow)
- BR** (Brown)
- R** (Red)
- L** (Left)
- R/L** (Right/Left)
- L/R** (Left/Right)
- G/W** (Green/White)
- BR/W** (Brown/White)
- BR** (Brown)
- R/Y** (Red/Yellow)
- R/L** (Red/Left)
- L/R** (Left/Right)
- G/B** (Green/Blue)
- L/Y** (Left/Yellow)
- R/G** (Right/Green)
- L/B** (Left/Blue)
- G** (Green)
- B** (Blue)
- W** (White)
- Y** (Yellow)
- BR** (Brown)
- <

SEL113J

WARNING LAMPS AND CHIME

Diode Check

- Check continuity using an ohmmeter
- Diode is functioning properly if test results are as shown below.



SEL700D


DIGITAL TYPE COMBINATION METER

- Diodes for warning lamps are located on the panel where warning bulbs are fitted.

NEEDLE TYPE COMBINATION METER

- Diodes for warning lamps are built into the combination meter printed circuit

Warning Chime Check



SEL875D

TIME CONTROL SYSTEM


Schematic

CAUTION.

Never touch the terminals of time control unit with bare hands.

• Time control unit has the following functions.

- 1) Intermittent wiper control timer
- 2) Interior lamp timer
- 3) Door key hole illumination timer
- 4) Illumination control timer
- 5) Light warning timer
- 6) Key warning timer
- 7) Seat belt warning timer
- 8) Rear defogger timer




SEL114J

TIME CONTROL SYSTEM

Wiring Diagram

GL AND SF MODELS



SEL115J

Wiring Diagram (Cont'd)


[illegible]

SEL116J

TIME CONTROL SYSTEM


— Preparation for Trouble-shooting —

1. Remove R H dash side cover and remove blower motor
2. Remove time control unit with harness connected.
3. Connect main harness to instrument harness (if disconnected)




— Power Supply Circuit Check —

Voltmeter terminals		Ignition switch position		
(+)	(-)	OFF	ACC	ON
①	②	Approx 12V	Approx 12V	Approx 12V
②①	②	0V	0V	Approx 12V
②⑥	②	0V	Approx 12V	Approx 12V
Ohmmeter terminals		Continuity		
(+)	(-)			
②	Body ground	Yes		




— Trouble-shooting —




WIPER RELAY CIRCUIT CHECK

1. Turn wiper switch to "INT"
2. Turn ignition switch to "ACC".
3. Measure voltage across ①⑤ and ②



WIPER SWITCH CIRCUIT CHECK

1. Turn wiper switch to "INT"
2. Turn ignition switch to "OFF"
3. Check continuity between ①② and ②.



TIME CONTROL SYSTEM

Trouble-shooting (Cont'd)

Intermittent time of wiper cannot be adjusted

Check intermittent wiper volume circuit

OK

Replace T C U.

NG

Check intermittent wiper volume

OK


Check harness between T C U and intermittent wiper volume

NG

Replace wiper switch

1. Turn ignition switch to "OFF".
2. Measure resistance between ①⑥ and ② while turning intermittent wiper volume

Check from harness side



SEL710D

Wiper and washer activate individually but not in combination

Check washer switch circuit

OK


Replace T C U

NG

Check harness between T C U and washer switch

1. Turn ignition switch to "OFF"
2. Turn washer switch to "ON".
3. Check continuity between ①④ and ②.


Check from harness side



SEL711D




TIME CONTROL SYSTEM

Trouble-shooting (Cont'd)




TIME CONTROL SYSTEM


Trouble-shooting (Cont'd)



LIGHT SWITCH CIRCUIT CHECK




ILLUMINATION CIRCUIT CHECK



ILLUMINATION CONTROL CIRCUIT CHECK

Check from harness side




Ohmmeter (+)	Ohmmeter (-)	Illumination control switch	
		DARK	BRIGHT
23	2	0 Ω	Except 0 Ω
24	2	Except 0 Ω	0 Ω

SEL717D

TIME CONTROL SYSTEM

Trouble-shooting (Cont'd)



TIME CONTROL SYSTEM

Trouble-shooting (Cont'd)

Seat belt warning lamp does not go off nor come on

Go to "Power Supply Circuit Check"

OK

Check harness for T C U
power supply circuit

Check belt warning circuit

NG


Replace T C U

OK
Check warning lamp

BELT WARNING CIRCUIT CHECK

1. Unfasten seat belt
2. Measure voltage across ① and ② when ignition switch is "ON".

Check from harness side



Voltmeter needle keeps swinging
(approx 0 ↔ 12V) for about 7
seconds after ignition switch is
turned ON

SEL720D

Rear defogger does not activate, or does not go off
automatically

Go to "Power Supply Circuit Check".

OK

Check harness for T C U
power supply circuit

Check rear defogger circuit

NG

Check rear defogger relay,
and harness between T C U
and rear defogger relay

Check defogger switch circuit

OK


Replace T C U

NG
Check defogger switch,
and harness between T C U
and defogger switch


REAR DEFOGGER CIRCUIT CHECK

1. Turn ignition switch to "ON"
2. Measure voltage across ① and ② while operating rear defogger switch.

Check from harness side



Ignition switch ON




Approx
12 V when rear defogger switch is OFF
0 V when rear defogger switch is ON

Voltmeter

SEL722D

DEFOGGER SWITCH CIRCUIT CHECK

Check from harness side



Ignition switch OFF


- 0Ω when rear defogger switch is ON
- Except 0Ω when rear defogger switch is OFF

Ohmmeter

SEL723D

WIPER AND WASHER

Windshield Wiper and Washer/Wiring Diagram



SEL117J


Windshield Wiper and Washer/Installation

WIPER ARM

- 1 Prior to wiper arm installation, set wiper switch to "LOW" to operate wiper motor and then turn it "OFF" (Auto Stop).
- 2 Adjust wiper blades within clearance "C"
- 3 Tighten windshield wiper arm nuts to specified torque.
13 - 18 N·m (13 - 1.8 kg·m, 9 - 13 ft·lb)
- 4 Eject washer fluid Set wiper switch to "LOW" to operate wiper motor and then turn it "OFF"

- 5 Ensure that wiper blades stop within clearance "C".


Clearance "C" 15 - 25 mm (0.59 - 0.98 in)



SEL355E

WIPER AND WASHER

Rear Wiper and Washer/Wiring Diagram




SEL118J

WIPER AND WASHER

Washer Nozzle Adjustment


Front washer



*1	370 (14 57)
*2	220 (8 66)
*3	360 (14 17)
*4	240 (9 45)
*5	140 (5 51)
*6	430 (16 93)

Unit mm (in)
SEL152J

Rear washer




*1	600 (23 62)
*2	122 (4 80)
*3	240 (9 45)

Unit mm (in)
SEL153J

WIPER AND WASHER


Headlamp Washer/Wiring Diagram

WITHOUT HEADLAMP SENSOR



SEL119J

WITH HEADLAMP SENSOR




GL and GLL models

SEL120J

HORN, CIGARETTE LIGHTER, CLOCK

Wiring Diagram




SEL121J

REAR WINDOW DEFOGGER


Wiring Diagram

SF AND GL MODELS



SEL122J

GLL MODEL




SEL123J

REAR WINDOW DEFOGGER

Filament Check


- 1 Attach probe circuit tester (in volt range) to middle portion of each filament



6 volts (normal filament)


SEL263

2. If a filament is burned out, circuit tester registers 0 or 12 volts.



12 volts


SEL264



0 volts

SEL265

- 3 To locate burned out point, move probe to left and right along filament to determine point where tester needle swings abruptly.



SEL266

Filament Repair

REPAIR EQUIPMENT

- 1 Conductive silver composition (Dupont No 4817 or equivalent)
- 2 Ruler, 30 cm (11 8 in) long
- 3 Drawing pen
- 4 Heat gun
- 5 Alcohol
6. Cloth

REPAIRING PROCEDURE


1. Wipe broken heat wire and its surrounding area clean with a cloth dampened in alcohol
- 2 Apply a small amount of conductive silver composition to tip of drawing pen

Shake silver composition container before use.

REAR WINDOW DEFOGGER

Filament Repair (Cont'd)


- 3 Place ruler on glass along broken line. Deposit conductive silver composition on break with drawing pen. Slightly overlap existing heat wire on both sides [preferably 5 mm (0.20 in)] of the break



BE540


- 4 After repair has been completed, check repaired wire for continuity. This check should be conducted 10 minutes after silver composition is deposited

Do not touch repaired area while test is being conducted.



SEL012D

5. Apply a constant stream of hot air directly to the repaired area for approximately 20 minutes with a heat gun. A minimum distance of 3 cm (1.2 in) should be kept between repaired area and hot air outlet. If a heat gun is not available, let the repaired area dry for 24 hours




SEL013D

AUDIO AND POWER ANTENNA

Wiring Diagram

SF AND GL MODELS




SEL124J

AUDIO AND POWER ANTENNA

Wiring Diagram (Cont'd)


GLL MODEL



SEL125J

AUDIO AND POWER ANTENNA


Power Antenna Motor Check



SEL732D

Radio Fuse Check

- 1 Disconnect, at connector, harness between power antenna unit and antenna timer.
 2. Apply 12-volt battery voltage across ① and ② to make sure antenna rod extends and retracts
 - 3 Connect a voltmeter across terminal ③ and ground terminal of battery.
 - 4 Check to determine if voltmeter varies between 0 and 12 volts (approx) in relation to movement of antenna rod when 12-volt battery voltage is applied across ① and ②
- If above test results are not satisfactory, replace antenna motor.



SEL733D

Schematic

Wiring Diagram for ASCD System

Components and Connections:

- BATTERY:** Connected to the system via a FUSE.
- IGNITION SWITCH (ON or START):** Controls the main power flow.
- ASCD MAIN SWITCH:** Controls the ASCD system.
- ASCD RELAY:** Controls the ASCD system.
- STOP LAMP SWITCH:** Controls the STOP LAMP.
- CLUTCH SWITCH (M/T):** Controls the CLUTCH.
- STOP SWITCH:** Controls the STOP function.
- THEFT WARNING RELAY:** Controls the THEFT WARNING.
- INHIBITOR RELAY (A/T):** Controls the INHIBITOR.
- VACUUM PUMP RELAY:** Controls the VACUUM PUMP.
- ASCD CONTROL UNIT:** The central control unit with terminals 1 through 15.
- COMBINATION METER:** Includes the CRUISE control and SPEED SENSOR.
- LOCK-UP CONTROL UNIT (A/T):** Controls the LOCK-UP.
- OD CANCEL SOLENOID:** Controls the OD CANCEL.
- ACTUATOR:** Controls the VACUUM VALVE and RELEASE VALVE.
- VACUUM VALVE:** Controls the VACUUM PUMP.
- RELEASE VALVE:** Controls the RELEASE.
- THROTTLE LEVER:** Controls the ACTUATOR.


Note: For digital type combination meter equipped model, refer to schematic for STEERING WHEEL SWITCH SYSTEM.

Note For digital type combination meter equipped model, refer to schematic for STEERING WHEEL SWITCH SYSTEM

AUTOMATIC SPEED CONTROL DEVICE (A.S.C.D.)

Wiring Diagram

GL MODEL (For Canada)



SEL239J

AUTOMATIC SPEED CONTROL DEVICE (A.S.C.D.)

Wiring Diagram (Cont'd)


GLL MODEL

Refer to wiring diagram for STEERING WHEEL SWITCH SYSTEM

AUTOMATIC SPEED CONTROL DEVICE (A.S.C.D.)

—Preparation for Trouble-shooting ————— Trouble-shooting —————


- Remove A.S.C.D. control unit with harness connected



SEL520F

POWER SUPPLY CIRCUIT CHECK


- Release brake and clutch pedals.
- Turn ignition switch to "ON".
- Turn A.S.C.D. main switch to "ON".
- Check voltage between ⑬ and ⑤



SEL610D

SET SWITCH CIRCUIT CHECK

- Turn ignition switch to "OFF".
- Push A.S.C.D. set switch.
- Check continuity between ① and ⑭



SEL611D

A.S.C.D. control unit cannot be set properly

Turn A.S.C.D. main switch "OFF" and then "ON" to make sure indicator (located above combination meter) illuminates

Yes

No

Check for loose vacuum hose

Check A.S.C.D. main switch and A.S.C.D. relay

OK

Check power supply circuit for A.S.C.D. control unit

OK

NG

Check stop switch, clutch switch (M/T model), inhibitor relay and inhibitor switch (A/T model)

OK

Check harness between A.S.C.D. power supply circuit

Check set switch circuit for A.S.C.D. control unit

OK

NG

Check set switch, and harness between control unit and set switch

Go to "A.S.C.D. Actuator Check"

OK


NG

(Next page)

Replace actuator


AUTOMATIC SPEED CONTROL DEVICE (A.S.C.D.)

Trouble-shooting (Cont'd)




1. Turn ignition switch to "OFF".
 2. Disconnect speedometer cable from transmission.
 3. Connect an ohmmeter between ⑩ and ⑤
 4. Turn ignition switch to "ON"
 5. Slowly turn speedometer cable pinion by hand to make sure ohmmeter pointer deflects
- Ohmmeter pointer should deflect twice per rotation of pinion.

Check from harness side




AUTOMATIC SPEED CONTROL DEVICE (A.S.C.D.)

Trouble-shooting (Cont'd)




RESUME SWITCH CIRCUIT CHECK

1. Turn ignition switch to "OFF".
2. Turn resume switch to "ON"
3. Check continuity between ② and ⑭.




SEL612D




ACCELERATE SWITCH CIRCUIT CHECK


1. Turn ignition switch to "OFF"
2. Turn accelerate switch to "ON"
3. Check continuity between ③ and ⑭.



SEL613D



Large difference between set vehicle speed and actual speed.



AUTOMATIC SPEED CONTROL DEVICE (A.S.C.D.)

Trouble-shooting (Cont'd)

A/T model only

- When A S C D is set while vehicle is operating in "O D" range, O D will be cancelled and shifting to O D cannot be made thereafter
- While vehicle is being driven using A S.C.D in "O D" range, O D will not be cancelled even if actual car speed is 6 km/h (4 MPH) lower than set speed (Set speed cannot be maintained)

Check O D cancel circuit for A S C D control unit

OK

Replace A S C D control unit


NG

- **Electronic-controlled A/T**
Check harness between lock-up control unit and A S C D control unit
- **Conventional A/T**
Check harness between O D cancel solenoid, O D cancel switch and A S C D control unit

ELECTRONIC-CONTROLLED A/T EQUIPPED MODEL (E4N71B)

- Turn ignition switch to "OFF"
- Check continuity between ⑧ and ⑤

Check from harness side




SEL737D

CONVENTIONAL A/T EQUIPPED MODEL (4N71B)

- Turn ignition switch to "ON"
- Turn O D cancel switch to "OFF".
- Check voltage ⑧ - ⑤ and ⑩ - ⑤.

Check from harness side




SEL741D

A.S.C.D. Actuator Check

- 1 Check continuity between terminal ① and terminals ②, ③ and ④

Continuity exist ... O.K.



SEL738D

CAUTION:


Do not attempt to remove valves from actuator.

- 2 Connect battery (approx 12V) to harness connector of actuator as shown below, and apply vacuum to actuator.

If diaphragm moves smoothly, actuator is O.K

CAUTION.


When checking actuator by applying vacuum, do not apply engine vacuum directly as it is too strong to check actuator properly.



SEL739D

AUTOMATIC SPEED CONTROL DEVICE (A.S.C.D.)

A.S.C.D. Wire Adjustment



SEL740D

CAUTION:

- Be careful not to twist wire when removing it.
- Be careful not to pinch vacuum hose when installing actuator.
- Do not tighten wire excessively during adjustment.


Without depressing the accelerator pedal, adjust wire tension with adjusting nut

Wire free play (at throttle lever):
0 - 0.5 mm (0 - 0.020 in)

- For A.S.C.D. stop switch and clutch switch adjustment, refer to BR and CL sections.
- For vacuum pump and tank check, refer to HA section.

STEERING WHEEL SWITCH SYSTEM

Description




SEL647E

The steering wheel switch system transmits the on-off signal of the switch on the steering wheel to the receiver optically and operates A.S.C.D. and audio.

HOW TO TRANSMIT SWITCH SIGNAL OPTICALLY

- (1) The on-off signal of the switch on the steering wheel is converted into an L.E.D. on-off signal by the transmitter.
- (2) This L.E.D. signal (optical signal) is transmitted to the photo-transistor through the optical ring.
- (3) The optical signal is re-converted into electrical signal by the photo-transistor and transmitted to the receiver. Receiver controls A.S.C.D. and radio.

By the three steps mentioned above, the on-off signal of the switch on the steering wheel is optically transmitted.



SEL648E

L.E.D. (Light Emitting Diode):

A diode which emits light when voltage is applied.


Photo-transistor:

A transistor which allows current to flow when light is applied.

STEERING WHEEL SWITCH SYSTEM

Description (Cont'd)


STEERING WHEEL SWITCH



- If two or more audio switches or A S C D switches are pressed simultaneously, all the pressed switches will be cancelled
- If one switch is pressed while pressing another, the second one pressed will be cancelled



	Switch		Function
For Audio	①	SW	Power ON/OFF
	②	PLAY	Tape deck play
	③	AM/FM	AM/FM band selection
	④	SCAN	SCAN tuning (for radio) Auto program search (for tape deck)
	⑤	VOL	Volume
For A S C D	⑥	RESUME	Deceleration and resuming
	⑦	ACCEL	Acceleration
	⑧	SET	Cruising speed setting

TRANSMITTER



The transmitter is a device which converts the signal from the steering wheel switch into intermittent current in order to flash the L E D

OPTICAL RING




STEERING WHEEL SWITCH SYSTEM

Description (Cont'd)

- The steering wheel switch system uses an acrylic optical ring, and this optical ring functions in the same way as optical fiber. The optical ring is built in the slip ring.

The slip ring must not be disassembled.


Light transmission path:



SEL649E


- As the LED embedded in the optical ring lights, its light moves forward while repeating reflection on the side wall of the ring. It eventually will reach the photo-transistor placed on the outer periphery of the ring.

L.E.D. and photo-transistor:



- The L.E.D. and optical ring are mounted on the steering wheel side of the slip ring and rotate with the steering wheel.
- The photo-transistor is mounted on the vehicle side of the slip ring and it does not rotate.

SLIP RING




SEL650E

- Power for the transmitter is fed from the vehicle side through the slip ring.
- The horn switch circuit is connected to the vehicle side through the slip ring.

The slip ring must not be disassembled.

HEAD AMPLIFIER



SEL651E


The photo-transistor allows a minimal amount of current to flow as it receives light. The head amplifier amplifies this current and sends it to the receiver.

STEERING WHEEL SWITCH SYSTEM


Description (Cont'd)

RECEIVER

2 seater model




2+2 seater model



The receiver activates the radio or A S C D. drive circuit corresponding to the steering wheel switch signal sent from the head amplifier

AUDIO VOLUME CONTROL




SEL652E

- The volume control on the steering wheel switch is connected in series with the volume control on the radio
- When the volume control on the radio is set to a minimum, no sound will be heard from the loudspeaker even if the steering wheel switch volume control is adjusted
- Sound level from the loudspeaker will be at the maximum when the steering wheel switch volume control is set to the maximum with the volume control on the radio also set to the maximum

STEERING WHEEL SWITCH SYSTEM

Steering Wheel Switch Removal and Installation




SEL653E

STEERING WHEEL REMOVAL AND INSTALLATION


To prevent the steering wheel switch from being damaged, be sure to observe the following procedure:

- When removing the steering wheel.
1. Remove the horn pad and both sections of the steering shell cover.



SEL521F

2. Disconnect the connector ① first and then loosen the steering nut and remove steering wheel.




SEL522F

STEERING WHEEL SWITCH SYSTEM


Steering Wheel Switch Removal and Installation (Cont'd)

- When installing the steering wheel:
First determine the slip ring position so that the projected portion ② of the slip ring will fit in the recessed portion ③ of the combination switch. Then install the steering wheel.




STEERING WHEEL REAR COVER REMOVAL

- Remove the rear cover with the projected portion of the slip ring fitted into the cutout portion of the rear cover.



SLIP RING REMOVAL

- Remove the connector joining the slip ring and transmitter after removing the transmitter mounting screws. Then remove the transmitter.




SEL656E

STEERING WHEEL SWITCH SYSTEM

Steering Wheel Switch Removal and Installation (Cont'd)

TRANSMITTER AND SLIP RING INSTALLATION

- When installing the transmitter and slip ring, arrange and secure the harnesses and connectors as shown in the following figure




SEL657E

STEERING WHEEL SWITCH SYSTEM

Schematic

GLL MODEL




SEL126J


STEERING WHEEL SWITCH SYSTEM

Wiring Diagram

GLL MODEL




Wiring Diagram (Cont'd)




STEERING WHEEL SWITCH SYSTEM

Trouble-shooting




STEERING WHEEL SWITCH SYSTEM

Trouble-shooting (Cont'd)




STEERING WHEEL SWITCH SYSTEM

Trouble-shooting (Cont'd)




STEERING WHEEL SWITCH SYSTEM

Trouble-shooting (Cont'd)



STEERING WHEEL SWITCH SYSTEM

Trouble-shooting (Cont'd)



STEERING WHEEL SWITCH SYSTEM

Trouble-shooting (Cont'd)

Radio volume decrease when the steering is turned rapidly under extremely low temperature conditions

This results from a poor ground connection inside the steering column bearing. To correct the incident, apply low temperature grease to the steering column bearing as follows.


TROUBLE-SHOOTING PROCEDURE

- 1 Disconnect the battery ground cable
 - 2 Remove the horn pad, horn cover, and both sections of the steering shell cover
 - 3 Disconnect the steering switch transmitter harness connector from the rear of the combination switch.
 - 4 Remove the steering wheel, using the tool and procedure described in the ST section.
 - 5 Apply the low temperature grease to the steering column shaft bearing as follows.
 - 1) Place the turn signal switch in neutral position to prevent grease from getting on the turn signal cancel cam.
 - 2) Carefully apply approximately 1 ml (0.03 US fl oz, 0.04 Imp fl oz) of grease to the steering column bearing
- To facilitate application of the grease, a cone of paper or vinyl film is suggested.**
- 3) Temporarily install the steering wheel. Insure that the projected portion of the slip ring fits in the recessed portion of the combination switch. Turn the steering wheel fully to the left and right a couple of times, taking care to prevent damage to the projected portion of the slip ring.
 - 4) Remove the steering wheel
 - 5) Repeat steps b, c, and d
 - 6) Make sure that grease is applied to the entire bearing
 - 6 Install the steering wheel on the shaft in a straight ahead position. Be sure that the projected portion of the slip ring fits in the recessed portion of the combination switch
 7. Connect steering switch transmitter harness connector to combination switch
 8. Install horn cover, horn pad and both sections of the combination switch housing
 - 9 Connect battery ground cable

STEERING WHEEL SWITCH SYSTEM

Receiver Check

- 1 Remove luggage box.
- 2 Remove receiver with harness connected.
- 3 Turn ignition switch to ON.
- 4 Check voltage between terminals referring to the chart below




SEL660E

Check item	Voltmeter terminal		Switch condition	Specified voltage [V]
	(+)	(-)		
Power source input	IG ①	④	—	Approx 12
	ACC ②	④		
Power source output for head amplifier and slip ring	③	④	—	Approx 12
Output for A S C D relay	⑤	④	A S C D main switch ON	0
			OFF	Approx 5
Output for A S C D control unit	⑦	④	SET switch ON	Approx 12
	⑧	④	RESUME switch ON	Approx 12
	⑨	④	ACCEL switch ON	Approx 12
Output for audio system (Check voltage while operating the SW, PLAY, SCAN or FM/AM on the steering wheel switch)	⑩	④	SW switch ON	0
			OFF	Approx 5
	⑪	④	PLAY switch ON	0
			OFF	Approx 5
	⑫	④	SCAN switch ON	0
			OFF	Approx 5
	⑬	④	AM/FM switch ON	0
			OFF	Approx 5

STEERING WHEEL SWITCH SYSTEM

Head Amplifier Check

- 1 Remove steering column cover.
- 2 Turn ignition switch to ON.
- 3 Check voltage between terminals at harness connector for head amplifier referring to chart below.
(Leave the harness connector for head amplifier to be connected)



SEL661E


Check item	Voltmeter terminals		Specified voltage [V]
	(+)	(-)	
Power supply input	⑤①	⑤②	Approx 12
Output for receiver	⑤③	⑤④	Approx 2 - 4

Slip Ring Check

POWER SUPPLY VOLTAGE CHECK

1. Remove steering column cover.
2. Disconnect harness connector for slip ring at the back of combination switch
- 3 Remove steering wheel
4. Remove combination switch with harness connected.
- 5 Check voltage between terminals ⑤⑦ and ⑥① when the ignition switch is turned to ON.

Specified voltage: Approx. 12V




SEL662E

CONTINUITY CHECK

1. Remove slip ring from steering wheel
2. Check continuity between terminals ⑤⑦ and ③①.

Continuity exists .. O.K.



SEL663E


STEERING WHEEL SWITCH SYSTEM

Transmitter Check

POWER SUPPLY VOLTAGE CHECK

- 1 Connect the harness connector for slip ring at the back of combination switch
- 2 Install steering wheel on the column shaft.
3. Connect the voltmeter probe to
(+) terminal . ③①
(-) terminal . Steering column shaft
- 4 Check voltage when the ignition switch is turned to ON.

Specified voltage: Approx. 12V




SEL664E

OUTPUT SIGNAL CHECK

- 1 Disconnect harness connector between transmitter and slip ring
2. Connect terminals ③① and ③④ with a suitable wire
3. Check voltage between terminals ③③ and ③④ when the ignition switch is turned to ON

Specified voltage: Approx. 2 - 4V



SEL665E

STEERING WHEEL SWITCH SYSTEM


Steering Wheel Switch Check

1. Disconnect harness connector for slip ring at the back of combination switch
2. Remove steering wheel
3. Remove steering wheel rear cover
4. Disconnect harness connector between steering wheel switch and transmitter
5. Remove steering wheel switches

A.S.C.D. SWITCH CHECK

- Check continuity while pressing each switch
Below 300Ω . O.K.

	OFF	SET	ACCEL	RESUME
③⑤		○		
③⑥		●	○	
③⑦		●	●	○
③⑧		○	○	○




SEL666E

AUDIO SWITCH CHECK

- Check continuity while pressing each switch
Below 300Ω ... O.K.



	OFF	SW (Power)	PLAY	SCAN	AM/FM
③⑨		○			
④①		○	○		
④②		○	○	○	
④④		○	○	○	○



SEL667E

VOLUME CHECK

- Measure resistance between terminals ④③ and ④④ while operating the volume




SEL668E

STEERING WHEEL SWITCH SYSTEM

A.S.C.D. Control Unit Check

- 1 Remove A S C D control unit with harness connected.
- 2 Check terminal voltage referring to chart below.



SEL736D


Check item	Voltmeter terminals		Switch condition	Specified voltage [V]
	(+)	(-)		
Power source input	⑭	⑤	A S C D main switch ON	Approx 12
Input signal	①	⑤	SET switch ON	Approx 12
	②	⑤	RESUME switch ON	Approx 12
	③	⑤	ACCEL switch ON	Approx 12

Radio Check

- 1 Remove radio with harness connected
- 2 Disconnect DIN cable for steering wheel switch receiver from radio.
3. Remove luggage box
4. Remove "short-plug" from steering wheel switch receiver
5. Connect the "short-plug" to radio
- 6 Check the sound when the radio is turned on

The radio is normal if there is sound.

- 7 After finishing this check, be sure to re-install the "short-plug" on the steering wheel switch receiver.



SEL669E


STEERING WHEEL SWITCH SYSTEM

Note

THEFT WARNING SYSTEM


Location of Electrical Units

- When adjusting hood, front door, back door or removing & installing them or switches, check theft warning system operation.




Operation of Switches and Sensors


Hood switch (Fig 1)




Theft warning main control unit & sub control unit (Fig 2)



Door switch (Fig 3)




Door lock switch, unlock switch and key cylinder tamper switch (Fig 4)




THEFT WARNING SYSTEM

Operation of Switches and Sensors (Cont'd)


Power door lock switch (Fig 5)




Power door lock actuator (Fig 6)



Back door switch (Fig. 7)




Back door unlock & key cylinder tamper switch (Fig 8)




THEFT WARNING SYSTEM

Schematic




Schematic (Cont'd)




THEFT WARNING SYSTEM

Wiring Diagram



Wiring Diagram (Cont'd)



SEL129J


THEFT WARNING SYSTEM

Trouble-shooting

- During trouble-shooting, if "checks ① – ④, ⑥" are indicated, be sure to refer to "checks ① – ④, ⑥" in the "Terminal check" (Refer to pages EL-170 - EL-172)
- During trouble-shooting, if the cause of trouble is found to be due to "Faulty sub-control unit, Faulty main control unit or Faulty adapter harness", be sure to refer to "Control Unit Inspection".

Contents

No	INCIDENT The theft warning system responds in one of these ways		Refer to TROUBLE-SHOOTING PROCEDURE
1	Indicator lamp	does not blink (Remains out)	IND ①
2		remains blinking	IND ②
3		does not come on (1)	IND ③
4		does not come on (2)	IND ④
5		remains lit	IND ⑤
6		does not go out (Comes on)	IND ⑥
7		does not go out (Remains lit)	IND ⑦
8	Armed	is set even if ignition switch is in ACC or ON position	ARM ①
9		is set even if at least one of doors is unlocked	ARM ②
10		is set even if at least one of doors is open	ARM ③
11		is not set (Armed phase)	ARM ④
12	Alarm	is given without any cause	ALR ①
13		does not operate (Alarm phase)	ALR ②
14		does not stop (Alarm continues for over 4 minutes)	ALR ③
15		does not stop even if stop signal is given	ALR ④
16		stops too soon	ALR ⑤
17		continues (Alarm is not intermittent)	ALR ⑥
18	Starter motor	cannot operate (Except alarm phase)	ST ①
19		can operate (Starter killed phase)	ST ②

• Symbol  Action  Judgment  Probable cause

- "Armed phase" means that approx 30 seconds have passed (Indicator lamp goes out) since locking and closing all doors.
- "Alarm phase" means that the horn sounds and the headlamps blink intermittently
- "Starter killed phase" means that the starter does not work until one door is unlocked with the key after the alarm has sounded.


THEFT WARNING SYSTEM

Trouble-shooting (Cont'd)

CUSTOMER COMPLAINT

- 1 Indicator lamp does not blink (Remains out)
 - Ignition switch OFF
 - At least one of the doors, hood, or back door is open

TROUBLE-SHOOTING PROCEDURE IND ①




THEFT WARNING SYSTEM

Trouble-shooting (Cont'd)

2 Indicator lamp remains blinking

- Ignition switch OFF
- Doors, hood and back door are closed.

TROUBLE-SHOOTING PROCEDURE IND ②




THEFT WARNING SYSTEM

Trouble-shooting (Cont'd)

3 Indicator lamp does not come on (1)

- Ignition switch OFF
- Doors, hood and back door are closed.
- After closing all doors, doors are locked with key

TROUBLE-SHOOTING PROCEDURE IND ③




THEFT WARNING SYSTEM

Trouble-shooting (Cont'd)

4. Indicator lamp does not come on (2)

- Ignition switch OFF
- After closing hood and back door, lock and close all doors without key. Or after locking and closing all doors, close hood and back door.

TROUBLE-SHOOTING PROCEDURE IND ④



THEFT WARNING SYSTEM

Trouble-shooting (Cont'd)


5 Indicator lamp remains lit.

- Ignition switch OFF
- At least one of the door is open or unlocked.

or

- Reset the armed phase

TROUBLE-SHOOTING PROCEDURE IND ⑤




THEFT WARNING SYSTEM

Trouble-shooting (Cont'd)

6 Indicator lamp does not go out (Comes on)

- Ignition switch OFF
- Doors close and at least one of the doors unlocks


TROUBLE-SHOOTING PROCEDURE IND ⑥



7 Indicator lamp does not go out (Remains lit)

- Ignition switch OFF
- More than 30 seconds have passed after closing and locking all doors

TROUBLE-SHOOTING PROCEDURE IND ⑦




THEFT WARNING SYSTEM

Trouble-shooting (Cont'd)


8 Armed is set, even if ignition switch is in ACC or ON position

TROUBLE-SHOOTING PROCEDURE ARM ①



9 Armed is set, even if at least one of the doors is unlocked

TROUBLE-SHOOTING PROCEDURE ARM ②




THEFT WARNING SYSTEM

Trouble-shooting (Cont'd)


10 Armed is set, even if at least one of the doors is open

TROUBLE-SHOOTING PROCEDURE ARM ③



11 Armed is not set, even if ignition switch is in OFF position and all doors are closed and locked

TROUBLE-SHOOTING PROCEDURE ARM ④




THEFT WARNING SYSTEM

Trouble-shooting (Cont'd)

12 Alarm is given without any cause

- Ignition switch OFF
- Doors locked and closed

TROUBLE-SHOOTING PROCEDURE ALR ①




THEFT WARNING SYSTEM

Trouble-shooting (Cont'd)

13 Alarm does not operate, even if any door is opened without key or any key cylinder is drawn out

TROUBLE-SHOOTING PROCEDURE ALR ②




THEFT WARNING SYSTEM

Trouble-shooting (Cont'd)

14 Alarm does not stop (Alarm continues for over 4 minutes)


- Ignition switch OFF
- Alarm phase

TROUBLE-SHOOTING PROCEDURE ALR ③



15. Alarm does not stop, even if any door or back door is unlocked with key or code number of keyless entry system is put in

TROUBLE-SHOOTING PROCEDURE ALR ④




THEFT WARNING SYSTEM

Trouble-shooting (Cont'd)

16 Alarm stops too soon (Alarm does not continue for 2 to 4 minutes)

- Ignition switch OFF
- Alarm phase


TROUBLE-SHOOTING PROCEDURE ALR ⑤



17 Alarm continues (Alarm is not intermittent)

- Ignition switch OFF
- Alarm phase

TROUBLE-SHOOTING PROCEDURE ALR ⑥




THEFT WARNING SYSTEM

Trouble-shooting (Cont'd)

18 Starter motor does not operate (Except alarm phase)

- Ignition switch ST


TROUBLE-SHOOTING PROCEDURE ST ①



19 Starter motor operates (Starter killed phase)


- Ignition switch ST

TROUBLE-SHOOTING PROCEDURE ST ②



THEFT WARNING SYSTEM

Terminal Check



Terminal arrangement of connector for theft warning sub-control unit (View from harness side)

Check table of connector terminals for sub-control unit (Disconnect connector at sub-control unit)

Terminal	Function	From	Normal operation	If N G , check
A	System source	Fuse box	Battery voltage should come between [A] and body ground	10A fuse, Harness
B	Security lamp operating control	Fuse box (Through security lamp)	Ground [B] , security lamp should come on	10A fuse, Harness, Bulb of security lamp
C	System cancel signal	Fuse box	Battery voltage should come between [C] and body ground when key is in A cc or ON	10A fuse, Harness
D	Starter kill	Fuse box (Through theft warning relay-2)	Ground [D] starter should not operate	Theft warning relay-2, Harness, Inhibitor relay (A/T), Inhibitor switch (A/T)
E	Door switch trigger and tamper switch trigger for passenger's side	Passenger's door switch and tamper switch	Battery voltage should come between [E] and body ground when passenger's door is closed Zero voltage between [E] and body ground when passenger's door is open Battery voltage between [E] and body ground when passenger's tamper switch is installed to key cylinder when passenger's door is closed	Door switch, Tamper switch, Harness
F	Door switch trigger and tamper switch trigger of driver's side Tamper switch trigger of back door	Driver's door switch and tamper switch Back door tamper switch	Battery voltage should come between [F] and body ground when driver's door is closed Zero voltage between [F] and body ground when driver's door is open Battery voltage should come between [F] and body ground when driver's and back door tamper switches are installed to key cylinders (when driver's door is closed)	Door switch, Tamper switch, Harness
G	Arm signal	Door lock switches	Continuity exists between [G] and body ground when key stops between neutral and full stroke of lock	Door lock switch, Harness

THEFT WARNING SYSTEM

Terminal Check (Cont'd)

Terminal	Function	From	Normal operation	If N G , check
H	Power door lock trigger	Power door lock switch	Battery voltage should come between [H] and body ground when driver's door is locked Zero voltage between [H] and body ground when driver's door is unlocked	Power door lock actuator, Power door lock switch
I	Passenger's door unlock sensor signal	Power door lock actuator	Continuity exists between [I] and body ground when passenger's door is unlocked No continuity between [I] and body ground when passenger's door is locked	Power door lock actuator
J	Disarm signal Back door	Back door unlock switch	Continuity exists between [J] and body ground when key stops between neutral and full stroke of unlock	Unlock switch, Harness
K	Disarm signal (Driver's and passenger's doors)	Door unlock switches	Continuity exists between [K] and body ground when key stops between neutral and full stroke of unlock	Unlock switch, Harness
L	Alarm signal	Fuse box (Through horn relay) Fuse box (Through theft warning relay-1)	Ground [L] , horn should sound and headlamp should come on	Horn relay, Theft warning relay-1, 15A, 10A fuse, Harness
N	Back door switch trigger	Back door switch	Battery voltage should come between [N] and body ground when back door is closed Zero voltage between [N] and body ground when back door is open	Back door switch, Harness
O	Hood switch trigger	Hood switch	No continuity between [O] and body ground when hood is closed Continuity exists between [O] and body ground when hood is open	Hood switch, Harness
P	System ground	Body ground	Continuity exists between [P] and body ground	Body ground terminal, Harness

Connect connector to sub-control unit

Terminal	Function	From	Normal operation	If N G , check
L (Check ②)	Alarm signal	Fuse box (Through horn relay) Fuse box (Through theft warning relay-1)	Pointer deflection should come intermittently under alarm phase	Sub-control unit, Main control unit, Adapter harness



THEFT WARNING SYSTEM

Terminal Check (Cont'd)


Preparation for check

- Disconnect body harness connector at sub-control unit (Except check ②)


Terminal arrangement for check (View from harness side)




CHECK ① System source check




CHECK ③ System cancel signal check



CHECK ② ... Security lamp circuit check




CHECK ④ ... Starter kill signal check




THEFT WARNING SYSTEM

Terminal Check (Cont'd)


CHECK ⑤ Door switch trigger and tamper switch trigger for passenger's side




CHECK ⑥ Door switch trigger and tamper switch trigger for driver's side & tamper switch trigger for back door




CHECK ⑦ Arm signal check




CHECK ⑧ Power door lock trigger



CHECK ⑨ Passenger's door unlock sensor signal



CHECK ⑩ Disarm signal of back door unlock switch check




THEFT WARNING SYSTEM

Terminal Check (Cont'd)

CHECK (K) . Disarm signal of door unlock switch check

Check for continuity between terminals (K) and (P)


• Stop key between neutral and full stroke of unlock



SEL544F

CHECK (O) Hood switch trigger check


Check for continuity between terminals (O) and (P)



SEL547F

CHECK (L) . Alarm check


Connect terminals (L) and (P) with jumper cable



SEL545F

CHECK (P) Body ground circuit check


Check for continuity between terminals (P) and body



SEL548F

CHECK (N) .. Back door switch trigger check


Measure voltage across terminals (N) and (P)



SEL546F

CHECK (Z) ... Alarm signal check

- 1 Connect connector to theft warning sub-control unit
- 2 Connect between terminals (A) and (L)



SEL549F

THEFT WARNING SYSTEM

Control Unit Check

CONTROL UNIT INSPECTION


- This inspection is available only when the cause of trouble in "Trouble-shooting" is due to a "faulty sub-control unit" or "faulty main control unit" or "faulty adapter harness"
- This inspection should be carried out with adapter harness disconnected at main control unit. When disconnecting adapter harness, first disconnect battery ground cable. Be sure to reconnect battery ground cable afterwards.

TROUBLE-SHOOTING PROCEDURE

1. **OK** in following checks indicates "Replace main control unit" and **NG** indicates "Replace sub-control unit or "Replace adapter harness"
2. In case of **NG**, check adapter harness referring to "Adapter harness check"
3. If theft warning does not operate normally even after replacing sub-control unit, replace main control unit

Preparation for check

Disconnect adapter harness at main control unit



THEFT WARNING SYSTEM

Control Unit Check (Cont'd)


Check (a) . Ground circuit check

Check for continuity between terminals sub-control unit (P) and body

N G

Faulty ground circuit

O K



Check for continuity terminals (a) and sub-control unit (P)

N G


(N G)

Replace sub-control unit or adapter harness (Refer to "Adapter harness check")

O K

(O K)

Replace main control unit



Check (b) .. Door unlock signal check

Measure voltage across terminals (b) and (a)

N G


(N G)

Replace sub-control unit or adapter harness (Refer to "Adapter harness check")

O K

(O K)



Replace main control unit





THEFT WARNING SYSTEM

Control Unit Check (Cont'd)



Check ③ . Hood signal check



Check ④ Indicator lamp circuit check



Check ⑤ ... Starter kill signal check



THEFT WARNING SYSTEM

Control Unit Check (Cont'd)

Check ① ... Alarm check

Connect ① and ② with jumper cable


Does horn sound and headlamp come on?

YES

OK Replace main control unit

NO

NG Replace sub-control unit or adapter harness (Refer to "Adapter harness check")



SEL315F

Check ③ .. Arm signal check


Connect between terminals ③ and ②

OK

OK Replace main control unit


NG

NG Replace sub-control unit or adapter harness (Refer to "Adapter harness check")



- All doors (including hood, and back door) are closed
- Turn key from neutral to lock

[Example]
Driver's side



Pointer deflection exists
OK

SEL316F

THEFT WARNING SYSTEM

Control Unit Check (Cont'd)

Check ⑧ . Unlock signal check

Measure voltage across terminals ⑧ and ⑨


OK

OK Replace main control unit

NG

NG

Replace sub-control unit or adapter harness (Refer to "Adapter harness check")



Check ⑩ Door switch signal check

Measure voltage across terminals ⑩ and ⑪


OK

OK Replace main control unit

NG

NG

Replace sub-control unit or adapter harness (Refer to "Adapter harness check")



Check ⑪ ... System cancel signal check

Measure voltage across terminals ⑪ and ⑫


OK

OK Replace main control unit

NG

NG

Replace sub-control unit or adapter harness (Refer to "Adapter harness check")



THEFT WARNING SYSTEM

Control Unit Check (Cont'd)

Check ③ . . . System source check


Measure voltage across terminals ③ and ④

OK

OK Replace main control unit

NG

NG Replace sub-control unit or adapter harness (Refer to "Adapter harness check")



Adapter Harness Check

- This inspection is available only when the cause of trouble in "Control Unit Check" is due to a "Replace sub-control unit or adapter harness"


Check for continuity between same letter of sub-control unit and main control unit

OK

Replace sub-control unit.


NG

Replace adapter harness




- If theft warning does not operate normally even after replacing adapter harness, replace sub-control unit.
- If theft warning does not operate normally even after replacing sub-control unit, replace adapter harness

LOCATION OF ELECTRICAL UNITS



SEL249J

LOCATION OF ELECTRICAL UNITS




SEL753D

HARNESS LAYOUT

Note

HARNESS LAYOUT


Outline



SEL496F


HARNESS LAYOUT

Main Harness



SEL130J


. Main Harness (Cont'd)



HARNESS LAYOUT


Main Harness (Cont'd)

Diode (81M)



(For E C C S system)

Diode (84M)




(For A S C D system E C C S system, headlamp system & time control system)

SEL131J

HARNESS LAYOUT

Main Harness (Cont'd)




SEL 132J

HARNESS LAYOUT

Note:


HARNESS LAYOUT

Main Harness (Cont'd)




HARNESS LAYOUT


Main Harness (Cont'd)




(For interior lamp system & time control system)




(For interior lamp system & time control system)




(For interior lamp system)




(For time control system)




(For interior lamp system & illumination control system)




(For interior lamp system & illumination control system)



(For interior lamp system)



(For headlamp system)




(For interior lamp system)

2. Main Harness (Cont'd)


HARNESS LAYOUT

Engine Room Harness



HARNESS LAYOUT


E.F.I. Harness



SEL135J

HARNESS LAYOUT


Instrument Harness



11	To 68E (White)	171	Chime
21	To 45M (Blue) (GL and GLL models)	181	Instrument switch R H
31	To 46M (White)	191	Instrument switch R H
41	Joint } (For Exhaust gas sensor warning lamp)	201	Combination gauge (Digital type meter model)
51	Joint }	211	Combination gauge (Needle type meter model)
61	Combination meter (White)	221	Joint (Needle type meter model)
	Needle type meter (Canada model)	231	Joint (Needle type meter model)
71	Illumination control switch	241	Glove box lamp switch
81	Instrument switch L H	251	Glove box lamp
91	Instrument switch L H	261	Hold relay (For U S A)
101	Combination meter (Black)	281	To 45M (Black)
111	Combination meter (White)	291	To 3E (White)
121	Combination meter (White)	301	Joint (Needle type meter model)
131	Combination meter (White)	311	Joint (Needle type meter model)
141	Combination meter (White)	321	Joint (Needle type meter model)
151	Combination meter (White)	331	Joint (Needle type meter model)
161	Combination meter (Blue)	341	Joint (Needle type meter model)
	Digital type meter	351	Joint (Needle type meter model)

HARNESS LAYOUT


Console Harness



SEL137J

HARNESS LAYOUT


Air Conditioner Harness



SEL944G


HARNESS LAYOUT

Back Door Harness



SEL138J

SPECIAL SERVICE TOOL

Tool number	Tool name
KV999U0060	Diagnostic sub-harness (For digital type combination meter)  SEL145J

NISSAN FACTORY SERVICE MANUAL CDROM END-USER LICENSE AGREEMENT

NOTICE TO USER: THIS IS A CONTRACT. BY PURCHASING AND USING THE SERVICE MANUAL ON CDROM, YOU ACCEPT ALL THE TERMS AND CONDITIONS OF THIS AGREEMENT.

This End User License Agreement accompanies the Service Manual on CDROM product and related explanatory materials. Please read this Agreement carefully. By purchasing and using the Service Manual on CDROM, you are implying that you have carefully read, agree with, and will adhere to the conditions set forth in this agreement. If you do not wish to accept the terms of this End User Agreement please do not use the Service Manual on CDROM. You will not be permitted to use the Service Manual on CDROM without consenting to this end user agreement.

Upon your acceptance of this Agreement, Courtesy Nissan grants to you a nonexclusive license to use the Service Manual on CDROM, provided that you agree to the following:

USE OF SOFTWARE

You may install the contents of the CD on a hard disk or other storage device for personal use only. Each Service Manual on CDROM comes with a single user license. Under no circumstances should the contents of the Service Manual CDROM be placed on a server for purposes of distributing or allowing access to the material over a network.

COPYRIGHT AND TRADEMARK RIGHTS

The Service Manual CDROM is owned by Courtesy Nissan and its structure and organization, all graphics and coding are considered intellectual property of Courtesy Nissan. The Service Manual on CDROM is also protected by United States Copyright Law and International Treaty provisions. This Agreement does not grant you any intellectual property or resale rights to the Service Manual CDROM.

RESTRICTIONS

You agree not to modify, adapt, translate, reverse engineer, decompile or disassemble the PDF file on the Service Manual CDROM. The Service Manual on CDROM is licensed and distributed by Courtesy Nissan for single user utilization of its contents only. Licensed users will be permitted to use the contents of the Service Manual CDROM for multimedia presentation to an audience from a single machine using a large display or projection device but the Service Manual CDROM may not otherwise be distributed, sold to or made accessible to multiple users.

NO WARRANTY

The software is being delivered to you AS IS and Courtesy Nissan makes no warranty as to its use or performance. COURTESY NISSAN DOES NOT AND CANNOT WARRANT THE PERFORMANCE OR RESULTS YOU MAY OBTAIN BY USING THE SERVICE MANUAL CDROM OR DOCUMENTATION, NOR MAKES ANY WARRANTIES, EXPRESS OR IMPLIED, AS TO NONINFRINGEMENT OF THIRD-PARTY RIGHTS, MERCHANTABILITY, OR FITNESS FOR ANY PARTICULAR PURPOSE. IN NO EVENT WILL COURTESY NISSAN BE LIABLE TO YOU FOR ANY CONSEQUENTIAL, INCIDENTAL, OR SPECIAL DAMAGES FOR ANY REASON.

Courtesy Nissan
1777 North Central Expressway
Richardson, TX 75080
(800)527-1909

GOVERNING LAW AND GENERAL PROVISIONS

This Agreement will be governed by the laws of the State of Texas, USA, excluding the application of its conflicts of law rules. This Agreement will not be governed by the United Nations Convention on Contracts for the International Sale of Goods, the application of which is expressly excluded. If any part of this Agreement is found void and unenforceable, it will not affect the validity of the balance of the Agreement, which shall remain valid and enforceable according to its terms. You agree that the Service Manual on CDROM will not be shipped, transferred or exported into any country or used in any manner prohibited by the United States Export Administration act or any other export laws, restrictions or regulations. This Agreement shall automatically terminate upon failure by you to comply with its terms. This Agreement may only be modified in writing signed by and authorized officer for Courtesy Nissan.

Courtesy Nissan
1777 North Central Expressway
Richardson, TX 75080
USA

YOUR ACCEPTANCE OF THE FOREGOING AGREEMENT IS IMPLIED UPON PURCHASING AND USING THE SERVICE MANUAL CDROM.