

HEATER & AIR CONDITIONER

SECTION HA

CONTENTS


GENERAL DESCRIPTION	HA- 2
AIR FLOW AND COMPONENT LAYOUT (Manual)	HA- 3
LOCATION OF VACUUM COMPONENTS (Manual)	HA- 5
CONTROL	HA- 6
HEATER ELECTRICAL CIRCUIT	HA- 7
DESCRIPTION — Air Conditioner (Manual)	HA- 9
DISCHARGING, EVACUATING, CHARGING AND CHECKING	HA- 10
A/C PERFORMANCE TEST (Manual)	HA- 16
PRECAUTIONS FOR REFRIGERANT CONNECTION	HA- 18
PIPING, COMPRESSOR MOUNTING AND F.I.C.D.	HA- 19
COMPRESSOR OIL — For DKS-16H (DIESEL-KIKI make)	HA- 21
COMPRESSOR — Model DKS-16H (DIESEL-KIKI make)	HA- 23
A/C ELECTRICAL CIRCUIT (Manual)	HA- 31
A/C ELECTRICAL COMPONENTS (Manual)	HA- 33
LOCATION OF A/C ELECTRICAL COMPONENTS (Manual)	HA- 35
TROUBLE DIAGNOSES (Manual)	HA- 36
DESCRIPTION — Air Conditioner (Auto)	HA- 68
AIR FLOW AND COMPONENT LAYOUT (Auto)	HA- 88
LOCATION OF VACUUM COMPONENTS (Auto)	HA- 90
A/C PERFORMANCE TEST (Auto)	HA- 91
A/C PERFORMANCE TEST (Auto)/PIPING (Auto)	HA- 92
A/C ELECTRICAL CIRCUIT (Auto)	HA- 93
A/C ELECTRICAL COMPONENTS (Auto)	HA- 96
LOCATION OF A/C ELECTRICAL COMPONENTS (Auto)	HA- 97
SELF-DIAGNOSING SYSTEM OF TROUBLE (Auto)	HA-100
TROUBLE DIAGNOSES (Auto)	HA-104
SERVICE DATA AND SPECIFICATIONS (S.D.S.)	HA-133
SPECIAL SERVICE TOOLS	HA-136

HA

GENERAL DESCRIPTION

Continuously Variable Air Flow Control


The fan control amplifier, which utilizes transistor circuits, continuously controls the air flow blown out by the blower, allowing for selection of the desired air flowrate. The fan control amplifier is housed in the blower motor unit. The heat-radiating plate of the amplifier is placed in the stream of the air flow to effectively cool the transistors.



SHA255B

Device for Distributing Cool Air to the Feet during "FACE MODE"


A vacuum actuator is used in the cool-air distribution device to remove the hot air directed to the floor area and distribute the optimum air temperature to the driver's compartment. When the vacuum switch is turned "ON", part of the outside air (or: part of the cool air on models equipped with air conditioning systems) taken in the vehicle is bypassed to the shower duct on the driver's side through the operation of the actuator.



SHA23

AIR FLOW AND COMPONENT LAYOUT (Manual)

Air Flow



Ⓙ Turbocharged model with A.S.C.D.

FLOOR VENTILATOR SWITCH		
DOOR	PULL UP	PRESS DOWN
FLOOR VENT		

INTAKE CONTROL		
RECIRC	RECIRC	OUTSIDE
INTAKE DOOR		
OPERATION OF SOLENOID VALVE	S/V 1	S/V 2
	OP	CL


AIR MIX DOOR CONTROL		
HOT	HOLD	COLD
VALVE		
OPERATION OF SOLENOID VALVE	S/V 6	S/V 7
	OP	CL

OUTLET CONTROL						
MODE	FACE	B/L	ROOT	DEMIST	DEF	
DEF DOOR 1	b	b	b	a	a	
VENT. DOOR	b	b	b	a	a	
FLOOR DOOR	a	a	a	b	b	
DEF DOOR 2	a	a	a	b	b	
S/V 3	CL	OP	OP	OP	OP	CL
S/V 4	OP	OP	OP	CL	CL	CL
S/V 5	OP	OP	OP	CL	CL	CL

SHA231B


AIR FLOW AND COMPONENT LAYOUT (Manual)

Component Layout



SHA79


LOCATION OF VACUUM COMPONENTS (Manual)



SHA9808

CONTROL


Heater and Air Conditioner Control Removal



★ : Heater and air conditioner control assembly mounting bolts


HEATER ELECTRICAL CIRCUIT

Schematic



SHA417B

Wiring Diagram



DESCRIPTION—Air Conditioner (Manual)

Refrigeration Cycle

REFRIGERANT FLOW


The refrigerant flows in the standard pattern, that is, through the compressor, the condenser, the receiver drier, through the evaporator, and back to the compressor.

The refrigerant evaporation through the evaporator coil is controlled by an externally equalized expansion valve, located inside the evaporator case.

FREEZE PROTECTION — Compressor control

The compressor cycles on and off to maintain the evaporator temperature within a specified range. When the evaporator coil temperature falls below a specified point, the thermo control amplifier interrupts the compressor operation. When the evaporator coil temperature rises above the specification, the thermo control amplifier allows compressor operation.

The refrigerant system is protected against excessively high pressure by a pressure relief valve located between the receiver drier and the condenser. Protection against excessively low pressure (interruption of compressor operation) is provided by a low pressure switch, located on the receiver drier.




SHA9268

DISCHARGING, EVACUATING, CHARGING AND CHECKING

Precautions

WARNING:

- Always be careful that refrigerant does not come in contact with your skin.
- Always wear eye protection when working around the system.
- Keep refrigerant containers stored below 50° C (122° F) and never drop from high places.
- Work in well-ventilated area because refrigerant gas evaporates quickly and breathing may become difficult due to the lack of oxygen.
- Keep refrigerant away from open flames because poisonous gas will be produced if it burns.
- Do not use steam to clean surface of condenser or evaporator. Be sure to use cold water or compressed air.
- Compressed air must never be used to clean a dirty line. Clean with refrigerant gas.
- Do not use manifold gauge whose press point shape is different. Otherwise, insufficient evacuating may occur.




SHA919A

- Do not over-tighten service valve cap.
- Do not allow refrigerant to rush out. Otherwise, compressor oil will be discharged along with refrigerant.

Discharging

Slowly open the valves to discharge only refrigerant. If they are opened quickly, compressor oil will also be discharged.




SHA24

DISCHARGING, EVACUATING, CHARGING AND CHECKING

—Evacuating the System—Step one—

1. Start pump, then open both valves and run pump for about 5 minutes.



2. When low gauge has reached approx. 101.3 kPa (760 mmHg, 29.92 inHg), completely close both valves of gauge and stop vacuum pump. Let it stand for 5 to 10 minutes in this state and confirm that the reading does not rise.

- a. The low-pressure gauge reads lower by 3.3 kPa (25 mmHg, 0.98 inHg) per 300 m (1,000 ft) elevation. Perform evacuation according to the following table.

Elevation m (ft)	Vacuum of system* kPa (mmHg, inHg)
0 (0)	101.3 (760, 29.92)
300 (1,000)	98.0 (735, 28.94)
600 (2,000)	94.6 (710, 27.95)
900 (3,000)	91.3 (685, 26.97)

*: Values show reading of the low-pressure gauge.


- b. The rate of ascension of the low-pressure gauge should be less than 3.3 kPa (25 mmHg, 0.98 inHg) in five minutes.

—Charging—Step one—

1. Evacuate refrigerant system.

Refer to "Evacuating the System—Step One".

2. Close manifold gauge valves securely and disconnect charging hose from vacuum pump.
3. Purge air from center charging hose.
 - 1) Connect center charging hose to refrigerant can through can top.
 - 2) Break seal of refrigerant can and purge air.




4. Charge refrigerant into system.

WARNING:

Ensure that engine is off.

- 1) Open high-pressure valve of manifold gauge and charge refrigerant into system.




DISCHARGING, EVACUATING, CHARGING AND CHECKING

Charging—Step one (Cont'd)

CAUTION:

If charging liquefied refrigerant into the system with the can turned upside down to reduce charging time, charge refrigerant only through high-pressure (discharge) service valve. After charging, the compressor should always be turned several times manually.




SHA244B

- When low-pressure gauge reading is 98 kPa (1.0 kg/cm², 14 psi), completely close high-pressure valve of manifold gauge and stop charging.

Evacuating the System—Step two

- Close manifold gauge valve securely and disconnect charging hose from refrigerant can.
- Connect center charging hose to vacuum pump.
- Start pump, then open both valves and run pump for about 20 minutes.




SHA241B

Charging—Step two

Refer to "Charging—step one" of Nos. 2 through 4.

- When refrigerant charging speed slows down, close high-pressure valve of manifold gauge and open low-pressure valve of manifold gauge and charge it while running the compressor for ease of charging.



SHA245B

- Start Engine — Air conditioning system ON, maximum temperature set, maximum blower speed. Open low-pressure valve on gauge set, with can in upright position, and monitor sight glass. Charge is complete when sight glass is clear.

Cycling clutch systems will produce bubbles in sight glass when clutch engages. Therefore, allow 5 seconds after clutch engages to determine if bubbles continue, and, if so, add refrigerant to clear sight glass.

WARNING:

Never charge refrigerant through high-pressure side (discharge side) of system since this will force refrigerant back into refrigerant can and can may explode.

DISCHARGING, EVACUATING, CHARGING AND CHECKING

Charging—Step two (Cont'd)

6. Charge refrigerant while controlling low-pressure gauge reading at 275 kPa (2.8 kg/cm², 40 psi) or less by turning in or out low-pressure valve of manifold gauge.

- Be sure to purge air from charging hose when replacing can with a new one.


In low ambient conditions in order to reduce charging time, warming of the refrigerant can will increase internal pressure.

CAUTION:

Do not increase can temperature beyond 40°C (104°F).

WARNING:


Do not heat can directly. There is danger of it exploding.



7. Charge the specified amount of refrigerant into system by weighing charged refrigerant with scale. Overcharging will cause discharge pressure to rise.

Refrigerant amount:

0.9 - 1.1 kg (2.0 - 2.4 lb)



The state of the bubbles in sight glass should only be used for checking whether the amount of charged refrigerant is small or not. The amount of charged refrigerant can be correctly judged by means of discharge pressure.

8. After charging, be sure to install valve cap on service valve.
 9. Confirm that there are no leaks in system by checking with a leak detector.
- When refrigerant charging is performed with a charging cylinder, charging station, or automatic charging equipment, engine off, charge only through high side, after specified refrigerant amount has entered the system, close high pressure valve on gauge set. Start engine return to idle speed, operate A/C at maximum temperature setting, high blower. Observe sight glass to confirm complete charge.

Overcharging will result in increased high pressures, and reduced performance.




DISCHARGING, EVACUATING, CHARGING AND CHECKING

Checking Refrigerant Level

CONDITION

- Door window: Open
- A/C switch: ON

- TEMP. lever position: Max. COLD
- FAN lever position: 4
- Check sight glass after a lapse of about five minutes.

Amount of refrigerant	Almost no refrigerant	Insufficient	Suitable	Too much refrigerant
Check item				
Temperature of high pressure and low pressure lines.	Almost no difference between high pressure and low pressure side temperature.	High pressure side is warm and low pressure side is fairly cold.	High pressure side is hot and low pressure side is cold.	High pressure side is abnormally hot.
State in sight glass.	Bubbles flow continuously. Bubbles will disappear and something like mist will flow when refrigerant is nearly gone.	The bubbles are seen at intervals of 1 - 2 seconds.	Almost transparent. Bubbles may appear when engine speed is raised and lowered. No clear difference exists between these two conditions.	No bubbles can be seen.
	 AC256	 AC257	 AC258	
Pressure of system.	High pressure side is abnormally low.	Both pressure on high and low pressure sides are slightly low.	Both pressures on high and low pressure sides are normal.	Both pressures on high and low pressure sides are abnormally high.
Repair	Stop compressor immediately and conduct an overall check.	Check for gas leakage, repair as required, replenish and charge system.		Discharge refrigerant from service valve of low pressure side.

a. The bubbles seen through the sight glass are influenced by the ambient temperature. Since the bubbles are hard to show up in comparatively low temperatures below 20°C (68°F), it is possible that a slightly larger amount of refrigerant would be filled, if supplied according to the sight glass. Be sure to recheck the amount when it exceeds 20°C (68°F). In

higher temperature the bubbles are easy to show up.

b. When the screen in the receiver drier is clogged, the bubbles will appear even if the amount of refrigerant is normal. In this case, the outlet side pipe of the receiver drier becomes considerably cold.

DISCHARGING, EVACUATING, CHARGING AND CHECKING


Checking Refrigerant Leaks

ELECTRIC LEAK-DETECTOR

The leak detector is a delicate device that detects small amounts of halogen.

In order to use the device properly, read the manufacturer's manuals and perform the specified maintenance and inspections.

Nominal sensitivity:
15 - 25 g (0.53 - 0.88 oz)/year



SHA733A

GENERAL PRECAUTIONS FOR HANDLING LEAK DETECTOR

Place the probe on connection fitting and wait for 5 seconds or more.

As to check cooling unit, wait for 10 seconds or more.


WARNING:

As detector's meter moves even slightly, keep the probe as still as possible for one more minute.

NOTICE:


When fixing single bolt flange, place the probe on opposite side of the fitting.

UNION TYPE



RHA279

PLATE TYPE



RHA280

MEASUREMENT STANDARD

If any reaction is noted using a detector having a nominal sensitivity of 15 to 25 g (0.53 to 0.88 oz)/year, that portion found leaking must be repaired.

- The nominal sensitivity of the detector is determined under the assumption that all the leaking gas is collected by the detector. Accordingly, the quantity of gas actually leaking can amount to five to ten times the indicated value. Generally speaking, leakage of 150 to 200 g (5.29 to 7.05 oz) of refrigerant can cause insufficient cooling.
- Oil deposited during assembling must be wiped off before inspection. Refrigerant easily dissolves in oil, and the presence of oil can cause an error in measurement. This precaution is important when checking a used vehicle for refrigerant leakage.
- If any trace of oil is noted at and around connection fittings, it is a sure indication that refrigerant is leaking.

A/C PERFORMANCE TEST (Manual)

Performance Chart

TEST CONDITION

Testing must be performed as follows:

Vehicle location:	Indoors or in the shade (in a well ventilated place)
Doors:	Closed
Door window:	Open
Hood:	Open
TEMP. lever position:	Max, COLD
Mode switch position:	 (Face)
Recirculation switch position:	RECIRC. ON
FAN speed:	MAX, HI
Engine speed:	1,500 rpm
Time required before starting testing after air conditioner starts operating:	More than 10 minutes

TEST READING

Recirculating-to-discharge air temperature table

Inside air (Recirculating air) at blower assembly inlet		Discharge air temperature at center ventilator °C (°F)
Relative humidity %	At temperature °C (°F)	
50 - 60	20 (68)	4.5 - 5.0 (40 - 41)
	25 (77)	8.6 - 9.5 (47 - 49)
	30 (86)	12.7 - 14.1 (55 - 57)
	35 (95)	16.7 - 18.6 (62 - 65)
	40 (104)	20.8 - 23.1 (69 - 74)
60 - 70	20 (68)	5.0 - 5.5 (41 - 42)
	25 (77)	9.5 - 10.5 (49 - 51)
	30 (86)	14.1 - 15.5 (57 - 60)
	35 (95)	18.6 - 20.5 (65 - 69)
	40 (104)	23.1 - 25.4 (74 - 78)

A/C PERFORMANCE TEST (Manual)

Performance Chart (Cont'd)

Ambient air temperature to compressor pressure table

Ambient air		High pressure (Discharge side) kPa (kg/cm ² , psi)	Low pressure (Suction side) kPa (kg/cm ² , psi)
Relative humidity %	Air temperature °C (°F)		
50 - 70	20 (68)	853 - 1,049 (8.7 - 10.7, 124 - 152)	59 - 78 (0.6 - 0.8, 9 - 11)
	25 (77)	1,040 - 1,275 (10.6 - 13.0, 151 - 185)	88 - 108 (0.9 - 1.1, 13 - 16)
	30 (86)	1,216 - 1,491 (12.4 - 15.2, 176 - 216)	108 - 137 (1.1 - 1.4, 16 - 20)
	35 (95)	1,393 - 1,706 (14.2 - 17.4, 202 - 247)	137 - 167 (1.4 - 1.7, 20 - 24)
	40 (104)	1,579 - 1,932 (16.1 - 19.7, 229 - 280)	157 - 196 (1.6 - 2.0, 23 - 28)

a. The pressure will change in the following manner with changes in conditions:

- When blower speed is low, discharge pressure will drop.
- When the relative humidity of intake air is low, discharge pressure will drop.

b. The temperature will change in the following manner with changes in conditions:

When the ambient air temperature is low, the outlet air temperature will become low.


PRECAUTIONS FOR REFRIGERANT CONNECTION

WARNING:

Gradually loosen discharge side hose fitting, and remove it after remaining pressure has been released.


When replacing or cleaning refrigerant cycle components, observe the following.

- Do not leave compressor on its side or upside down for more than 10 minutes, as compressor oil will enter low pressure chamber.
- When connecting tubes, be sure to use a torque wrench.




SHA896A

- After disconnecting tubes, plug all openings immediately to prevent entrance of dirt and moisture.




SHA058

- Do not reuse used O-ring.
- When connecting tube, apply compressor oil to portions shown in illustration. Be careful not to apply oil to threaded portion.
- O-ring must be closely attached to inflated portion of tube.



SHA896B

- After inserting tube into union until O-ring is no more visible, tighten nut to specified torque.




SHA896C


- After connecting line, conduct leak test and make sure that there is no leak from connections. When the gas leaking point is found, disconnect that line and replace the O-ring. Check fit for further use and then tighten connection to seal seat for the specified torque.

PIPING, COMPRESSOR MOUNTING AND F.I.C.D.

Refrigerant Lines



Compressor Mounting




PIPING, COMPRESSOR MOUNTING AND F.I.C.D.

Idle Speed Adjusting and Checking

FAST IDLE CONTROL DEVICE (F.I.C.D.)


1. Run engine until it reaches operating temperature.
2. With air conditioning system OFF (when compressor is not operating), make sure that engine is at correct idle speed.
3. With air conditioning system ON (Recirculation switch at "RECIRC" position, fan control lever at "HI" position), make sure that compressor and F.I.C.D. solenoid valve are functioning properly.
4. For non-turbocharged model, set idle speed at the specified value.
For turbocharged model, make sure that idle speed is at the specified value. (Non-adjustable)

Non-turbocharged model



SHA223B

Turbocharged model



SHA248B

ENGINE IDLING SPEED

Transmission		Non-turbocharged model	Turbocharged model
When A/C is OFF			
Refer to MA section.			
When A/C is ON			
M/T	rpm	750 - 850	750 - 850
A/T	rpm	750 - 850 at "D" range	750 - 850 at "D" range

COMPRESSOR OIL—For DKS-16H (DIESEL-KIKI make)

Checking and Adjusting

The oil used to lubricate the compressor is circulating with the refrigerant.

Whenever replacing any component of the system or a large amount of gas leakage occurs, add oil to maintain the original amount of oil.

OIL CAPACITY

Unit: mL (US fl oz, Imp fl oz)

Applied model	All models
Capacity	
Total in system	200 (6.8, 7.0)
Amount of oil which can be drained	130 (4.4, 4.6)*
Compressor (Service parts) charging amount	200 (6.8, 7.0)

*: All oil cannot be drained from system.

OIL RETURN OPERATION

Before checking and adjusting oil level, operate compressor at engine idling speed, with controls set for maximum cooling and high blower speed, for 20 to 30 minutes in order to return oil to compressor.

CHECKING AND ADJUSTING FOR USED COMPRESSOR

1. After oil return operation, stop the engine and discharge refrigerant and then remove compressor from the vehicle.

2. Remove oil drain plug, drain compressor oil from compressor oil sump and measure the amount.

Oil is sometimes hard to extract when compressor is cooled. Remove oil while compressor is warm [maintained to 40 to 50°C (104 to 122°F)].

3. If the amount is less than 130 mL (4.4 US fl oz, 4.6 Imp fl oz), some refrigerant may have leaked out. Conduct leak tests on connections of each system, and if necessary, repair or replace faulty parts.

4. Check the purity of the oil and then adjust oil level following the procedure below.

(a) When oil is clean:

Unit: mL (US fl oz, Imp fl oz)

Amount of oil drained	Adjusting procedure
Above 130 (4.4, 4.6)*	Oil level is right. Pour in same amount of oil as was drained out.
Below 130 (4.4, 4.6)	Oil level may be low. Pour in 130 mL (4.4 US fl oz, 4.6 Imp fl oz) of oil.

*: If amount of oil drained is much greater than under normal circumstances, flush air conditioner system with refrigerant. Then pour in 200 mL (6.8 US fl oz, 7.0 Imp fl oz) of oil into air conditioner system.

- (b) When oil contains chips or foreign material;
After air conditioner system has been flushed with refrigerant, replace receiver drier. Then pour in 200 mL (6.8 US fl oz, 7.0 Imp fl oz) of oil into air conditioner system.

CHECKING AND ADJUSTING FOR COMPRESSOR REPLACEMENT

200 mL (6.8 US fl oz, 7.0 Imp fl oz) of oil is charged in compressor (service parts). So it is necessary to drain the proper amount of oil from new compressor. Follow the procedure below.

1. After oil return operation, drain compressor oil from used compressor and measure the amount.

(It is the same procedure as CHECKING AND ADJUSTING FOR USED COMPRESSOR.)

COMPRESSOR OIL—For DKS-16H (DIESEL-KIKI make)

Checking and Adjusting (Cont'd)

2. Check the purity of the oil and then adjust oil level following the procedure below.

(a) Oil is clean;

Unit: mL (US fl oz, Imp fl oz)

Amount of oil drained from used compressor	Draining amount of oil from new compressor
Above 130 (4.4, 4.6)*	200 (6.8, 7.0) – [Amount of oil drained + 25 (0.8, 0.9)]
Below 130 (4.4, 4.6)	130 (4.4, 4.6)

*: If amount of oil drained is much greater than under normal circumstances, flush air conditioner system with refrigerant. Then install new compressor. [200 mL (6.8 US fl oz, 7.0 Imp fl oz) of oil is changed compressor service parts.]

Example:

Unit: mL (US fl oz, Imp fl oz)


Amount of oil drained from used compressor	Draining amount of oil from new compressor
145 (4.9, 5.1)	30 (1.0, 1.1)
95 (3.2, 3.3)	130 (4.4, 4.6)

- (b) When oil contains chips or foreign material;
After air conditioner system has been flushed with refrigerant, replace receiver drier. Then install new compressor. [200 mL (6.8 US fl oz, 7.0 Imp fl oz) of oil is charged in compressor service parts.]

COMPRESSOR—Model DKS-16H (DIESEL-KIKI make)

- Plug all openings to prevent moisture and foreign matter from entering.
- Do not leave compressor on its side or upside down for more than 10 minutes.
- When replacing or repairing compressor, check compressor oil level in system.
- When replacing with a new compressor, drain specified oil from new compressor. Refer to COMPRESSOR OIL.
- Be sure there is no oil or dirt on frictional surface of clutch disc and pulley.
- When replacing compressor clutch, be careful not to scratch shaft or bend pulley.
- When replacing compressor clutch assembly, do not forget BREAK-IN OPERATION.
- When storing a compressor, be sure to fill it with refrigerant to prevent rust formation. Add refrigerant at the low-pressure side and purge air at the high-pressure side, while rotating shaft by hand.
- Replace shaft seal, seal seat, oil seal and O-ring as a set.
- When installing shaft seal, seal seat, oil seal, O-ring and gaskets, apply compressor oil sparingly to the contact surface. Do not reuse them.
- After replacement or repairs, conduct a Leak Test.

COMPRESSOR—Model DKS-16H (DIESEL-KIKI make)




Ⓜ : N·m (kg-m, ft-lb)

COMPRESSOR—Model DKS-16H (DIESEL-KIKI make)

Compressor Clutch


REMOVAL

- When removing shaft nut, hold clutch disc with clutch disc wrench.




SHA899B

- Using clutch disc puller, clutch disc can be removed easily.




RHA474A

- Bend down pawl of lock washer.
- When removing pulley, remove lock nut with nut wrench.



SHA900B

- Remove the pulley by hand. If difficult, use pulley pilot.



SHA700B

INSPECTION

Clutch disc


If the contact surface shows signs of damage due to excessive heat, the drive plate and pulley should be replaced.

Pulley

Check the appearance of the pulley assembly. If the contact surface of the pulley shows signs of excessive grooving due to slippage, both the pulley and drive plate should be replaced. The contact surfaces of the pulley assembly should be cleaned with a suitable solvent before re-installation.

Coil

Check coil for loose connection or cracked insulation.




SHA703B

COMPRESSOR—Model DKS-16H (DIESEL-KIKI make)

Compressor Clutch (Cont'd)


INSTALLATION

- Install the key in the keyway on the compressor drive shaft.
- Install the coil to compressor (lead wire up) and tighten the mounting screws.
- Install the load wire with its holder into the hold.



SHA704B

- Install lock washer and nut with nut wrench.
- Bend one pawl of the lock washer up against the nut to prevent the nut from loosening.




SHA705B

- Check to ensure that the clutch clearance between 0.3 to 0.6 mm (0.012 to 0.024 in). Adjust the clearance using shim(s) as necessary.

BREAKE-IN OPERATION

When replacing compressor clutch assembly, not forget break-in operation, accomplished by engaging and disengaging the clutch about thirty times.

Break-in operation raises the level of transmitting torque.



SHA706B


COMPRESSOR—Model DKS-16H (DIESEL-KIKI make)

Shaft Seal Assembly

The shaft seal assembly is a precision-part, with it's critical parts finished to extremely close tolerances and, as such, must be handled with great care. Its slip face demands particularly careful handling.


REMOVAL

- Remove the magnetic clutch assembly, as outlined in "REMOVAL" of Compressor Clutch.
- Using Internal Snap Ring Pliers, remove the seal seat/compressor snap ring.
- Remove and discard seal seat.
- Using a suitable piece of wire, remove the O-ring from the inside groove of the shaft seal housing. Discard the O-ring.



SHA710B


- Remove the shaft seal as follows: Turning clockwise, engage the remover hook with the shaft seal hook, and slowly draw out the seal. Discard the shaft seal.
- Check the shaft and inside of the compressor neck for dirt or foreign material and ensure these areas are perfectly clean before installing new shaft seal.



SHA712B

INSPECTION

- Shaft seal assembly should not be reused. Always use a new shaft seal kit on reassembling the compressor. Be extremely careful to ensure that the face of the shaft of the shaft seal to be installed is not scratched or damaged in any way. Make sure the seal seat and shaft seal are free of lint and dirt that could damage the shaft seal surface.



SHA713B


COMPRESSOR—Model DKS-16H (DIESEL-KIKI make)

Shaft Seal Assembly (Cont'd)

INSTALLATION

Clean the sealed section of the compressor. Apply clean compressor oil to the new shaft seal and the drive shaft. If the slip faces are dirty, clean them with thinners and after drying the cleaned faces, apply clean compressor oil.



Fit the new O-ring with clean compressor oil to the groove inside the compressor neck. Apply clean compressor oil to the seal seat.



Cylinder Heads (Front & rear)

DISASSEMBLY


- Remove the compressor clutch assembly, outlined in "REMOVAL" of Compressor Clutch.
- Remove the oil filler plug and drain plug, and then draw out the oil.
- Remove the shaft seal assembly, as outlined in "REMOVAL" of Shaft Seal Assembly.
- Remove the felt, stopper and six through bolts securing the head, using a wrench.
- Alternately tap four projections on the circumference of the front head with a screwdriver and a plastic mallet, and remove the front cylinder head.



COMPRESSOR—Model DKS-16H (DIESEL-KIKI make)


Cylinder Heads (Front & rear) (Cont'd)

- Remove and discard the O-ring from the front cylinder head.
- Remove all gasket material from the front cylinder head and front valve plate.




SHA726B

- Alternately tap four projections on the circumference of the rear head with a screwdriver and a plastic mallet, and remove the rear cylinder head.



SHA719B


- Remove the gear pump from the rear cylinder head or drive shaft end.
Remove all gasket material from the rear cylinder head and rear valve plate.
Remove and discard the O-ring from the rear side of the cylinder shaft assembly.



SHA725B

INSPECTION

Check the front and rear valve plates for scratched, bent or otherwise damaged parts. Inspect both cylinder heads and both valve plate assemblies for nicks or burrs on the sealing surfaces. Clean, or replace if badly damaged. Make sure that all passages in the valve plate are unobstructed. If either the cylinder head or valve plate is cracked, it must be replaced.



SHA721B


INSTALLATION

- Installation is the reverse of removal.
- Tighten bolts or plugs to specified torques.

COMPRESSOR—Model DKS-16H (DIESEL-KIKI make)

Leak Test


- Charge refrigerant from suction side and evacuate air from discharge side. Then conduct leak test.



SHA873A

A/C ELECTRICAL CIRCUIT (Manual)


Schematic



SHA9918

A/C ELECTRICAL CIRCUIT (Manual)


Wiring Diagram



A/C ELECTRICAL COMPONENTS (Manual)

Inspection


VACUUM TANK



-  : Magnet valve
 : Check valve (One way ↓)

SHA253B

Solenoid valve check for water cock




SHA254B

1. Disconnect vacuum hose ①.
2. Disconnect vacuum hose ② and connect hose ③ instead. Suck in through hose ③ to confirm that air does not flow through the hose and that check valve is closed.
3. While sucking vacuum hose ③, change voltage to solenoid to check for open-close operation of solenoid valve.

Applied voltage to solenoid (V)	Operation of solenoid valve
0	Close
12	Open

Pressure switch check for turbocharged model



Pressure	Resistance (Ω)
Atmospheric pressure	0
Vacuum pressure more than 46.7 kPa (350 mmHg, 13.78 inHg)	∞

SHA255B

1. Disconnect vacuum hose ④ from the terminal and connect a vacuum handy pump with the same terminal.
2. Check pressure switch using a vacuum handy pump.

A/C ELECTRICAL COMPONENTS (Manual)

Inspection (Cont'd)


VACUUM PUMP MOTOR

1. Turn ignition switch "OFF". Disconnect vacuum hose ④ (Refer to "Pressure Switch Check") from vacuum tank and connect it again.
2. Make sure air conditioner switch is "OFF".
3. Turn ignition switch "ON" (Do not start the engine).
4. Push cruise control main switch to make sure vacuum pump starts. (A sound should be heard from the pump.)
5. The vacuum pump is operating properly if it stops within 20 seconds after it has started.
6. If it fails to stop within 20 seconds, and vacuum hoses are in good order, it is malfunctioning.

SOLENOID VALVE

Perform operational check, referring to the "Table of operation of solenoid valve in Air Flow (page HA-3) and Wiring Diagram (page HA-8 or HA-32).

LOCATION OF A/C ELECTRICAL COMPONENTS (Manual)




SHA997B

TROUBLE DIAGNOSES (Manual)

CONTENTS

Circuit for Trouble Diagnoses	HA
Preliminary Check	HA
1) Insufficient cooling (Mode switch position: "FACE")	HA
2) Insufficient heating	HA
3) Insufficient air flow (Blower motor does not rotate.)	HA
4) Abnormal sound	HA
Trouble Diagnoses from Abnormal Conditions	HA
(A) Blower motor does not rotate.	HA
(B) Air flow cannot be changed between HI and LO.	HA
(C) Blower motor continues to rotate when fan switch is turned off.	HA
(D) "FACE" mode cannot be set.	HA
(E) "B/L" mode cannot be set.	HA
(F) "FOOT" mode cannot be set.	HA
(G) "DEMIST" mode cannot be set.	HA
(H) "DEF" mode cannot be set.	HA
(I) Outlet air will not become warm.	HA
(J) Outlet air will not become cool.	HA
(K) Outlet air temperature cannot be changed with temp. control lever.	HA
(L) Malfunction of water cock operation	HA
(M) Outlet air temperature fluctuates.	HA
(N) Recirculation mode cannot be set when "REC" switch is pressed.	HA
(P) Outside air is not drawn into compartment when "REC" switch is turned off.	HA
(Q) Compressor clutch is not engaged.	HA
(R) Malfunction of F.I.C.D.	HA
(S) Blower motor rotates intermittently.	HA

Circuit for Trouble Diagnoses




TROUBLE DIAGNOSES (Manual)

Preliminary Check

Before starting to diagnose the trouble, check the items below in order to completely understand the trouble symptom.


1) INSUFFICIENT COOLING (Mode switch position: "FACE")



DIAGNOSES (Manual)

Preliminary Check (Cont'd)


2) INSUFFICIENT HEATING



TROUBLE DIAGNOSES (Manual)

Preliminary Check (Cont'd)


3) INSUFFICIENT AIR FLOW (Blower motor does not rotate.)



TROUBLE DIAGNOSES (Manual)

Preliminary Check (Cont'd)



4) ABNORMAL SOUND




TROUBLE DIAGNOSES (Manual)

Trouble Diagnoses from Abnormal Conditions

(A) BLOWER MOTOR DOES NOT ROTATE. (Ignition switch on position)




Applied voltage of motor check.




SHA45

SHA50



SHA50


Fuse check
(Ignition switch: OFF position)



Blower relay check (Fan switch: ON position)

Remove relay bracket and check the relay operation from the back side of the electrical connector.

- ① Terminal voltage check (Correct voltage: Approx. 12V)
- ② If item ① is N.G., check applied voltage of relay coil (Correct voltage: Approx. 12V)




SHA39

TROUBLE DIAGNOSES (Manual)

Trouble Diagnoses from Abnormal Conditions (Cont'd)


(B) AIR FLOW CANNOT BE CHANGED BETWEEN HI AND LO.



TROUBLE DIAGNOSES (Manual)

Trouble Diagnoses from Abnormal Conditions (Cont'd)

(C) BLOWER MOTOR CONTINUES TO ROTATE WHEN FAN SWITCH IS TURNED OFF.



TROUBLE DIAGNOSES (Manual)


Trouble Diagnoses from Abnormal Conditions (Cont'd)

(D) "FACE" MODE CANNOT BE SET.

Depress FACE switch to "ON".

Remove under cover.

Check voltage at connector solenoid box.
Measure voltage with connector in place.
S/V4 and S/V5: Approx. 12 volts
S/V3: 0 volts



SHA526B

Yes

No

Verify if vacuum exists
at solenoid box.

Yes

No

Check vacuum at outlet of
S/V4 and S/V5 and also check
S/V3 output port. This should
be open to the atmosphere.

Malfunction of
vacuum hose at
the source side.
Replace the hose.

Yes

No

Check vacuum hose between
S/V3, 4 and 5.


Faulty solenoid
valve.

O.K.

N.G.

Faulty vacuum
actuator or linkage.

Replace vacuum
hose.




SHA400B

A

TROUBLE DIAGNOSES (Manual)


Trouble Diagnoses from Abnormal Conditions (Cont'd)



TROUBLE DIAGNOSES (Manual)




Trouble Diagnoses from Abnormal Conditions (Cont'd)

(E) "B/L" MODE CANNOT BE SET.



TROUBLE DIAGNOSES (Manual)

Trouble Diagnoses from Abnormal Conditions (Cont'd)



TROUBLE DIAGNOSES (Manual)

Trouble Diagnoses from Abnormal Conditions (Cont'd)


(F) "FOOT" MODE CANNOT BE SET.

Depress FOOT switch to "ON".

Remove under-cover.

Check voltage at connector solenoid box. Measure voltage with connector in place.

- S/V3 and S/V5: Approx. 12 volts
- S/V4: Approx. 0 volts



SHA509B

Yes

No

Check vacuum at the inlet of the solenoid box.

Yes

No

Check vacuum at the outlets of S/V3 and 5. Check S/V4—this should be opened to atmosphere.

Faulty vacuum hose at source side.

Yes

No

Check vacuum hose between solenoid valves and vacuum actuator.


Faulty solenoid valve.

O.K.

N.G.

Faulty vacuum actuator or linkage.

Replace vacuum hose.





SHA400B


A

TROUBLE DIAGNOSES (Manual)

Trouble Diagnoses from Abnormal Conditions (Cont'd)



SHA51





SHA51


TROUBLE DIAGNOSES (Manual)

Trouble Diagnoses from Abnormal Conditions (Cont'd)

(G) "DEMIST" MODE CANNOT BE SET.



SHA509B






SHA400B

A

TROUBLE DIAGNOSES (Manual)


Trouble Diagnoses from Abnormal Conditions (Cont'd)



TROUBLE DIAGNOSES (Manual)

Trouble Diagnoses from Abnormal Conditions (Cont'd)


(H) "DEF" MODE CANNOT BE SET.



TROUBLE DIAGNOSES (Manual)


Trouble Diagnoses from Abnormal Conditions (Cont'd)

(I) OUTLET AIR WILL NOT BECOME WARM.



TROUBLE DIAGNOSES (Manual)


Trouble Diagnoses from Abnormal Conditions (Cont'd)



TROUBLE DIAGNOSES (Manual)


Trouble Diagnoses from Abnormal Conditions (Cont'd)

(J) OUTLET AIR WILL NOT BECOME COOL.





TROUBLE DIAGNOSES (Manual)

Trouble Diagnoses from Abnormal Conditions (Cont'd)



TROUBLE DIAGNOSES (Manual)

Trouble Diagnoses from Abnormal Conditions (Cont'd)




TROUBLE DIAGNOSES (Manual)

Trouble Diagnoses from Abnormal Conditions (Cont'd)

(K) OUTLET AIR TEMPERATURE CANNOT BE CHANGED WITH TEMP. CONTROL LEVER.
Refer to item (I) or (J) above to check and correct.


(L) MALFUNCTION OF WATER COCK OPERATION.



TROUBLE DIAGNOSES (Manual)


Trouble Diagnoses from Abnormal Conditions (Cont'd)

(M) OUTLET AIR TEMPERATURE FLUCTUATES.



TROUBLE DIAGNOSES (Manual)


Trouble Diagnoses from Abnormal Conditions (Cont'd)




TROUBLE DIAGNOSES (Manual)

Trouble Diagnoses from Abnormal Conditions (Cont'd)

(N) RECIRCULATION MODE CANNOT BE SET WHEN "REC" SWITCH IS PRESSED.




(P) OUTSIDE AIR IS NOT DRAWN INTO COMPARTMENT WHEN "REC" SWITCH IS TURNED OFF.



TROUBLE DIAGNOSES (Manual)


Trouble Diagnoses from Abnormal Conditions (Cont'd)

(Q) COMPRESSOR CLUTCH IS NOT ENGAGED.




TROUBLE DIAGNOSES (Manual)

Trouble Diagnoses from Abnormal Conditions (Cont'd)



TROUBLE DIAGNOSES (Manual)


Trouble Diagnoses from Abnormal Conditions (Cont'd)



TROUBLE DIAGNOSES (Manual)

Trouble Diagnoses from Abnormal Conditions (Cont'd)


(R) MALFUNCTION OF F.I.C.D.



TROUBLE DIAGNOSES (Manual)

Trouble Diagnoses from Abnormal Conditions (Cont'd)


(S) BLOWER MOTOR ROTATES INTERMITTENTLY.



DESCRIPTION — Air Conditioner (Auto)

Features

- The vehicle sensors are installed at head level and foot level, in order to maintain the temperatures of both positions at the optimum levels.
- When starting the engine in cold weather, the system immediately operates in the defroster mode until the coolant temperature rises, thereby preventing fogging of the windshield.
- As the coolant temperature rises high enough to use the heater, the outlet door is automatically switched to the foot level for starting the heating operation. The system begins to control the air flow automatically as the outlet air temperature reaches the optimum level.
- When the DEF switch is ON, the air flow is automatically set to the "HI" position. However, the air flow can also be switched to "LO" by setting the manual switch to "LO" position.
- The objective temperature fine control switch (Set temp. adjuster) has been adopted. This switch permits adjustment of the upper objective temperature and the lower objective temperature within the range of $\pm 2^{\circ}\text{C}$ ($\pm 3.6^{\circ}\text{F}$).
- The control unit display section (digital display and air flow indicator) is utilized for self-diagnosing each sensor and actuator.
- The proportional integral control system newly adopted in the temperature control system provides quick and accurate response without generation of steady-state error during stabilized operation.



DESCRIPTION — Air Conditioner (Auto)

Refrigeration Cycle

REFRIGERANT FLOW


The refrigerant flows in the standard pattern, that is, through the compressor, the condenser, the receiver drier, through the evaporator, and back to the compressor.

The refrigerant evaporation through the evaporator coil is controlled by an externally equalized expansion valve, located inside the evaporator case.

FREEZE PROTECTION — Compressor control


When the A/C is switched on, the compressor runs continuously, and the evaporator pressure is controlled by a suction throttling valve (S.T.V.) to prevent freeze up.

The refrigerant system is protected against excessively high pressure by a pressure relief valve located between the receiver drier and the condenser. Protection against excessively low pressure (interruption of compressor operation) is provided by a low pressure switch, located on the receiver drier.



DESCRIPTION — Air Conditioner (Auto)

Function of the Switches on Control Unit



DESCRIPTION — Air Conditioner (Auto)


Basic Control Function and Control Switches

(3) SWITCHES AND THEIR CONTROL FUNCTIONS

Switch	Item to be controlled	Air flow	A/M door	Compressor	Water cock (W/C)	Intake air	Air outlet	Control When starting	Remarks
OFF		OFF	Auto	OFF	Auto	Outside air	Auto		Display (SET)/(AM/B) is ON with ignition switch set to ACC. A/M door and W/C control air temperature obtained by ram pressure.
AUTO SW	A/C	Auto	Auto	ON [OFF below 0°C (32°F) amb. temp.]	Auto	Auto	Auto	Operated	A/C — ECON momentary switch (A/C has priority over ECON.)
	ECON	Auto	Auto	OFF	Auto	Outside air	Auto	Operated	
 SW	DEMIST	Auto	Auto	ON [OFF below 0°C (32°F) amb. temp.]	Auto	Auto	DEF and foot	Operated	DEF — DEMIST momentary switch (DEF has priority over DEMIST.)
	DEF	HI	Full-Hot	ON [OFF below 0°C (32°F) amb. temp.]	Open	Outside air	DEF	Not operated	
Manual fan SW	Lo	Lo	—	—	—	—	—		Only air flow in Lo mode. All others are as determined by AUTO and "H" switches. When manual switch is pushed again, control function is cancelled.
	HI	HI	—	—	—	—	—		Only air flow in HI mode. All others are as determined by AUTO and "H" switches. When manual switch is pushed again, control function is cancelled.
REC		—	—	—	—	Inside air recirculation	—		REC function is activated by AUTO switch (A/C position) and OFF. REC switch is provided with timer which cancels REC function 10 minutes after it has turned on.
SET TEMP ADJUSTER		—	—	—	—	—	—	—	Air temperatures at head and foot levels are adjustable to ±2°C (±3.6°F), regardless of operation of any other switch.

DESCRIPTION — Air Conditioner (Auto)

Display of the Air Flow Indicator



SHA79

Display of Temperature Setting


Digital display	Analog display	Digital display
°C		°F
40		90
36		85
34		84
33		83
32		82
31		81
30	H	80
29		79
28		78
27		77
26		76
25		75
24		74
23		73
22		72
21		71
20	C	70
19		69
18		68
17		67
16		66
15		65
10		60

SHA523B


DESCRIPTION — Air Conditioner (Auto)

Control System

SENSOR & SWITCH LOCATION



SHA925B



SHA799B

DESCRIPTION — Air Conditioner (Auto)

System Operation (Air mix door control)

AIR MIX DOOR CONTROL (Automatic temperature control)

1. Component parts

Air mix door control system consists of the parts shown below.


- 1) Automatic amplifier (with microcomputer)
- 2) Temperature setting switch
- 3) Two in vehicle sensors (head/foot)
- 4) Ambient temperature sensor
- 5) Three duct temperature sensors (defroster duct, ventilator duct, floor duct)
- 6) Sunload sensor
- 7) Power servo 1 and Power servo 2
- 8) PBR1 and PBR2
(P.B.R.: Potentio Balance Resistor)
- 9) D.S.V.V. 1 and D.S.V.V. 2
(D.S.V.V.: Double Solenoid Vacuum Valve)

• Automatic amplifier

This amplifier has a built-in microcomputer enabling it to deal with data and to provide precise control, which is necessary for driving the auto air conditioner system. In addition to the auto air conditioner mode, this microcomputer has a self-diagnosis mode program.

* For functioning of system for self-diagnosis of trouble, refer to "SELF-DIAGNOSING SYSTEM OF TROUBLE".

• Temperature setting switch




SHA984B

This switch is used for setting the in-vehicle temperature. Temperature set by the temperature setting switch is electrically memorized by the microcomputer in the automatic amplifier.


• In-vehicle sensor (Head, foot)

The in-vehicle sensor converts the temperature value of the inside air, which is drawn through (by low pressure) the aspirator fan, into a resistance value, which is then input into the auto amplifier.

The sensor placed at head level detects the typical temperature at the upper half body level. The sensor placed at foot level detects the foot level temperature.



SHA318B




SHA609B

DESCRIPTION — Air Conditioner (Auto)

System Operation (Air mix door control) (Cont'd)

In-vehicle sensor specification



- **Ambient temperature sensor**

This sensor transforms the value of ambient temperature into a resistance value, which is put into the automatic amplifier.

(The specification of this sensor is the same as for the in-vehicle sensor.)

- **Defroster duct temp. sensor, ventilator duct temp. sensor, floor duct temp. sensor**


Each sensor transforms the value of outlet air temperature from each duct into a resistance value, which is put into automatic amplifier.

(The specification of these sensors is the same as for in-vehicle sensor.)

* For the location of these sensors, refer to AIR FLOW AND COMPONENT LAYOUT — Auto A/C (Component Layout).


- **Sunload sensor (Photo diode)**

This sensor transforms sunload into current value, which is put into the automatic amplifier. This sensor is located in the defroster grille.



- **Power servo 1 & 2, P.B.R. 1 & 2**
(P.B.R.: Potentio Balance Resistor)


The power servo varies its stroke depending on the vacuum or atmospheric pressure led through the D.S.V.V. for controlling the air mix door. The P.B.R. is a variable resistor interlinked to the power servo, and the air mix door position (opening) information is input into the auto amplifier in terms of resistance value.



DESCRIPTION — Air Conditioner (Auto)


System Operation (Air mix door control) (Cont'd)

P.B.R. 1




SHA610B

P.B.R. 2




SHA301B



SHA611B


• D.S.V.V. (Double Solenoid Vacuum Valve)

D.S.V.V. can drive the power servo, because it transforms the electric signal from automatic amplifier into vacuum pressure or atmospheric pressure.



SHA986


Inner structure of D.S.V.V.



SHA289

DESCRIPTION — Air Conditioner (Auto)

System Operation (Air mix door control) (Cont'd)



SHA288B

The objective air mix door opening calculated in the auto amplifier and the actual door opening input from P.B.R. are compared in the auto amplifier. A signal, as shown in the list is sent to D.S.V.V. according to the results of comparison.


CL: Solenoid valve is closed
OP: Solenoid valve is open

AIR MIX DOOR CONTROL					
			HOT side	HOLD	COLD side
Air mix door 1	Operation of solenoid valve	S/V8	CL	CL	OP
		S/V9	OP	CL	OP
Air mix door 2		S/V4	CL	CL	OP
		S/V5	OP	CL	OP

DESCRIPTION — Air Conditioner (Auto)

System Operation (Air mix door control) (Cont'd)

2. System operation of air mix door control



SHA2908

The temperature setting switch in this control system inputs the setting temperature signal to the auto amplifier.

The in-vehicle sensor, sunload sensor, ambient air temperature sensor, and duct temperature sensor also input the resistance value signals respectively to the auto amplifier corresponding to their conditions.

Receiving these input signals, the auto amplifier calculates the desirable air mix door position and causes the air mix door to move to the calculated position from its actual position detected by P.B.R. 1.

This movement of the air mix door is done by the power servo activated by the signal sent from the auto amplifier to the atmosphere side or vacuum side of the D.S.V.V.

The position of the air mix door is confirmed by the P.B.R. when converting the stroke of the power servo into voltage signal, and then by inputting the signal to the auto amplifier. The D.S.V.V. then continues operation until the air mix door position detected in this way coincides with the position determined by the control unit. The D.S.V.V. and the power servo stops operation once coincidence is attained.

DESCRIPTION — Air Conditioner (Auto)


System Operation (Intake door control)

INTAKE DOOR CONTROL

1. Component parts


The next parts are added to the component parts of air mix door control system.

• Intake door actuator



SHA318B


• Solenoid valve (Air valve type)



SW	Vacuum source	Actuator side	Atmosphere side
ON	○	○	○
OFF	○	○	○

SHA302B

2. System operation of intake door control




	S/V3	S/V2
Inside air	OPEN	OPEN
Partial outside air	OPEN	CLOSED
Outside air	CLOSED	CLOSED

SHA303B

DESCRIPTION — Air Conditioner (Auto)


System Operation (Intake door control) (Cont'd)

The intake door is switched in order to introduce the inside air, partial outside air, or outside air at the positions already memorized in the auto amplifier corresponding to the angle (opening) of the air mix door 1 which is automatically temperature controlled. The relationship between the angle (opening) of the air mix door and the intake door position is as shown below.




SHA304B

Condition 1: Outside temperature is 10°C (18°F) higher than set temperature



A/M door 1 angle (Opening angle): setting value

Condition 2: Except for Condition 1



A/M door 1 angle (Opening angle): setting value.

SHA304C

System Operation (Outlet door control)


OUTLET DOOR CONTROL

1. Component parts

Outlet door control system consists of the parts shown below.


- 1) Defroster door actuator
- 2) Ventilator door actuator
- 3) Defroster and floor door actuator
- 4) Solenoid valve 6, 7
- 5) Sunload sensor
- 6) Ambient temperature sensor
- 7) Automatic amplifier

• Actuators



SHA304D

• Solenoid valve 6, 7




SHA304E

DESCRIPTION — Air Conditioner (Auto)

System Operation (Outlet door control) (Cont'd)


2. System operation of outlet door control



SHA291B

The outlet door is switched to HEAT, B/L, or VENT at the positions already memorized in the auto amplifier, corresponding to the ambient air temperature and sunload.

Condition: Very fine in midsummer
 (Sunload: Approximately 0.768 kW
 (860 kcal/h, 2,619 BTU/h)/m²
 [0.0713 kW (61.3 kcal/h, 243.2 BTU/h)/sq ft])




SHA800B

The relationship between the ambient air temperature and outlet door is as shown below.

If the sunload increases, points ① and ② are moved in parallel direction to the arrow by the distance corresponding to the increase in sunload.

Condition: No sunload



SHA801B

DESCRIPTION — Air Conditioner (Auto)

System Operation (Air flow volume control)


AIR FLOW VOLUME CONTROL

1. Component parts

Power transistor is added to the component parts of air mix door control system.

- Power transistor

Power transistor varies blower speed automatically according to the signal from automatic amplifier.





SHA3188

2. System operation of air flow volume control

The auto amplifier computes signals from the setting temperature switch and sensors that compose the air mix door control, and sends the control signal voltage (V_{IN} : 0.6 to 4 V) to the power transistor.

The power transistor amplifies this control signal voltage to change the voltage (V_M) fed to the motor terminals. Accordingly, the air flow is controlled automatically. With the manual fan switch the voltage is fixed at 5.0V (VENT) or 5.5V (Except for VENT) for LO, and at 12V for HI position.



SHA802

DESCRIPTION — Air Conditioner (Auto)

System Operation (Air flow volume control) (Cont'd)


3. Specification of air flow volume control (Automatic control)

- When "AUTO" switch is ON:

VENT mode

The air flow volume control voltage is determined according to the difference between the objective temperature at head level and the actual room temperature at head level. This voltage varies within the range of 5.5V to 12V.

The V_M max is determined according to the difference between the ambient temperature and objective temperature, and this voltage varies within the range of from 9V to 12V.




SHA310B

B/L, HEAT mode

The air flow volume control voltage is determined according to the difference between the average room temperature and the objective temperature. This voltage varies within the range of 6V to 12V. The V_M max varies within the range of 9V to 12V, just like in the case of VENT.

When the DEMIST switch on the DEF switch is ON, the V_M min voltage is fixed at 8V. Accordingly, the control voltage varies within the range of 8V to 12V.



SHA311B

4. Compensation of air flow volume when sunload exists

In order to compensate for a change in room temperature depending on whether or not the sunload exists, the air flow volume is corrected according to the following diagram.


In VENT V_M min: 5.5 to 7 V

Except VENT V_M min: 6 to 7 V

(In both cases, the upper limit of compensation is 7V.)

V_M max is the same as when no sunload exists.

If the DEMIST switch is ON, compensation of air flow volume by sunload does not occur.



SHA292B

DESCRIPTION — Air Conditioner (Auto)


System Operation (Control at starting)

CONTROL AT STARTING

1. Component parts


Water temperature switch is added to the component parts of air mix door control system.

• Water temperature switch



SHA312B

Specification




SHA293B

2. System operation of control at starting

- Curve ① means that the coolant temperature is below 40°C (104°F) and the room temperature at head level is lower than the objective temperature by more than 5°C (9°F). (Example: When sunload does not exist in winter)
- Curve ② means that the coolant temperature is below 40°C (104°F) and the room temperature at foot level is only lower than the objective temperature. (Example: When sunload exists in winter)
- Curve ③ means that the room temperature at head level is higher than the objective temperature by more than 5°C (9°F) and the room temperature at foot level is also higher than the objective temperature. (The outlet door is controlled by the outlet door control signal.)
- Curve ④ means that the difference between the objective temperature and actual room temperature is less than 8°C (14°F).

In cases ① and ② when the voltage is higher than 6V, the outlet door is determined by the outlet door control signal.



SHA313B


DESCRIPTION — Air Conditioner (Auto)

System Operation (Compressor, water cock control and compensation for ambient temperature)

COMPRESSOR CONTROL



- "ECON" mode: OFF
- Except for "ECON" mode:

Ambient temperature	Control
More than 0°C (32°F)	ON
Less than 0°C (32°F)	OFF



WATER COCK CONTROL

When the ambient temperature is lower than the objective temperature, the water cock is kept open. In other cases, the water cock is opened or closed at the position already memorized in the auto amplifier corresponding to the opening angle of the air mix door 1.




COMPENSATION FOR AMBIENT TEMPERATURE

In the temperature control system, the head-level and foot-level objective temperatures are compensated for a change in the ambient temperature.

For example, when the setting temperature is 25°C (77°F), and if the ambient temperature is 0°C (32°F), the foot-level objective temperature is compensated to 30.5°C (87°F) and the head-level objective temperature to 26.5°C (80°F). If the ambient temperature is higher than 20°C (68°F), the objective temperature at both levels is 26.5°C (80°F).

Specification of objective temperature
[When the setting temperature is 25°C (77°F)]




DESCRIPTION — Air Conditioner (Auto)


System Operation (Function of set TEMP. adjuster)

FUNCTION OF SET TEMP. ADJUSTER

TEMP. SET ADJUSTER changes the value of the objective controlling temperature shown above, according to the ambient temperature, to the next value shown below.



SHAB04B



SHA805B

DESCRIPTION — Air Conditioner (Auto)

Function of Self-diagnosis of Trouble


The self-diagnosis program is used to locate trouble and is composed of the following two steps:

Step 1 Inspection of input system

Step 2 Inspection of output system

Diagnosing test connector


To change the system to the diagnosis mode, short the terminals of test connector located under the right side of the instrument panel.



SHA126C

STEP 1 INSPECTION OF INPUT SYSTEM

The number of the part being checked and the value detected by that part (whether that part is disconnected or shorted) is displayed on the temperature display section by the setting temperature switch.



SHA998B


Display No	Item of input signal	Parts to be checked
0	Temperature of inside air temperature sensor (foot)	In-vehicle sensor (foot)
1	Temperature of in-vehicle sensor (head)	In-vehicle sensor (head)
2	Temperature of floor outlet	Floor duct temperature sensor
3	Temperature of ventilator outlet	Ventilator duct temperature sensor
4	Temperature of defroster outlet	Defroster duct temperature sensor
5	Water temperature-SW, display ON-OFF	Water temperature SW.
6	Sunload	Sunload sensor
7	Width of objective temperature	Set temp, adjuster
8	Position of A/M door 2	P.B.R. 2
9	Position of A/M door 1	P.B.R. 1
10~ 15	No meaning	No meaning

STEP 2 INSPECTION OF OUTPUT SYSTEM

- Whether the parts of the output system are operating normally according to the predetermined pattern can be checked by applying a hand to the outlet door, observing the air flow indicator, listening to the operating noise, or by measuring the applied voltage.
- Once the step 2 program starts, the following six parts begin their operation sequentially, moving between stroke ends or changing all positions.
- Operating parts
 - Air mix door 1 and air mix door 2 (same motion)
 - Outlet doors (All mode)
 - Intake door
 - Water cock
 - Compressor magnet clutch
 - Blower motor

AIR FLOW AND COMPONENT LAYOUT (Auto)

Air Flow



Ⓙ : Turbocharged model


INTAKE CONTROL			
INTAKE AIR	RECIRC	PARTIAL OUTSIDE	OUTSIDE
INTAKE DOOR POSITION	c	b	a
OPERATION OF SOLENOID VALVE	OP	CL	CL
S/V 7	OP	CL	CL
S/V 8	OP	CL	CL
S/V 9	OP	CL	CL

AIR MIX DOOR CONTROL			
AIR MIX DOOR POSITION	HOT side		COLD side
	CL	OP	CL
Air mix door 1	CL	OP	CL
Air mix door 2	CL	OP	CL

OUTLET CONTROL			
MODE	VENT	B/L	HEAT/DEHUMID
DEF. DOOR 1	b	b	a
VENT. DOOR	b	b	a
FLOOR DOOR	a	b	a
DEF. DOOR 2	a	b	a
S/V 6	OP	CL	CL
S/V 7	CL	OP	CL


AIR FLOW AND COMPONENT LAYOUT (Auto)

Component Layout



SH4988B

LOCATION OF VACUUM COMPONENTS (Auto)



A/C PERFORMANCE TEST (Auto)

Performance Chart

TEST CONDITION

Testing must be performed as follows:

Vehicle location:	Indoors or in the shade (in a well ventilated place)
Ambient temperature	More than 14°C (57°F)
Doors:	Closed
Door window:	Open
Hood:	Open
SET TEMP. switch position:	Max. COLD
Auto switch position:	A/C (Ventilation mode)
Recirculation switch position:	RECIRC. ON
FAN switch position	Hi. ON
Engine speed:	1,500 rpm
Time required before starting testing after air conditioner starts operating:	More than 10 minutes

*Connect 895 (L/B) and 866 (BR/W) terminals of check connector with jumper wire.

TEST READING

Recirculating-to-discharge air temperature table

Inside air (Recirculating air) at blower assembly inlet		Discharge air temperature at center ventilator °C (°F)
Relative humidity %	At temperature °C (°F)	
50 - 70	20 (68)	3.0 - 5.0 (37 - 41)
	25 (77)	5.5 - 8.5 (42 - 47)
	30 (86)	10.0 - 13.5 (50 - 56)
	35 (95)	14.7 - 18.4 (58 - 65)
	40 (104)	19.5 - 23.2 (67 - 74)
70 - 90	20 (68)	5.0 - 7.0 (41 - 45)
	25 (77)	8.5 - 11.5 (47 - 53)
	30 (86)	13.5 - 17.0 (56 - 63)
	35 (95)	18.4 - 21.8 (65 - 71)
	40 (104)	23.2 - 26.8 (74 - 80)

A/C PERFORMANCE TEST (Auto)/PIPING (Auto)

Performance Chart

Ambient air temperature to compressor pressure table


Ambient air		Low pressure (Suction side) kPa (kg/cm ² , psi)	High pressure (Discharge side) kPa (kg/cm ² , psi)
Relative humidity %	Air temperature °C (°F)		
50 - 70	20 (68)	59 - 98 (0.6 - 1.0, 9 - 14)	755 - 892 (7.7 - 9.1, 109 - 129)
	25 (77)	78 - 127 (0.8 - 1.3, 11 - 18)	883 - 1,030 (9.0 - 10.5, 128 - 149)
	30 (86)	98 - 157 (1.0 - 1.6, 14 - 23)	1,010 - 1,187 (10.3 - 12.1, 146 - 171)
	35 (95)	118 - 186 (1.2 - 1.9, 17 - 27)	1,138 - 1,334 (11.6 - 13.6, 165 - 191)
	40 (104)	137 - 216 (1.4 - 2.2, 20 - 31)	1,295 - 1,510 (13.2 - 15.4, 188 - 216)
70 - 90	20 (68)	98 - 137 (1.0 - 1.4, 14 - 20)	883 - 1,020 (9.0 - 10.4, 128 - 148)
	25 (77)	127 - 177 (1.3 - 1.8, 18 - 26)	1,030 - 1,177 (10.5 - 12.0, 149 - 171)
	30 (86)	157 - 216 (1.6 - 2.2, 23 - 31)	1,187 - 1,344 (12.1 - 13.7, 172 - 191)
	35 (95)	186 - 255 (1.9 - 2.6, 27 - 37)	1,334 - 1,530 (13.6 - 15.6, 193 - 221)
	40 (104)	216 - 304 (2.2 - 3.1, 31 - 44)	1,510 - 1,736 (15.4 - 17.7, 219 - 251)

- a. The pressure will change in the following manner with changes in conditions:
- When blower speed is low, discharge pressure will drop.
 - When the relative humidity of intake air is low, discharge pressure will drop.

- b. The temperature will change in the following manner with changes in conditions:
- When the ambient air temperature is low, outlet air temperature will become low.

Refrigerant Lines—Cooling Unit


- Refrigerant lines for auto A/C are the same as for manual A/C.



SHA

A/C ELECTRICAL CIRCUIT (Auto)


Schematic




SHA993B

A/C ELECTRICAL CIRCUIT (Auto)

Wiring Diagram



Wiring Diagram (Cont'd)



A/C ELECTRICAL COMPONENTS (Auto)

Inspection

IN-VEHICLE SENSOR AT HEAD OR FOOT (with aspirator fan)

- For aspirator fan, check the air flow when applying voltage.
- For thermistor detecting temperature, refer to "SELF - DIAGNOSING SYSTEM OF TROUBLE" and "DESCRIPTION - AUTO A/C" [System Operation (Air mix door control)].

WATER TEMPERATURE SWITCH

1. Disconnect vacuum hose and two heater hoses and harness connector.
2. Dip the water cock assembly in a container filled with cold water and increase the temperature of the water. The switch should turn "ON".

Refer to DESCRIPTION - AUTO "A/C"
[System operation (Control at starting)].


NOTICE

- Do not separate the switch from the water cock assembly.

SUNLOAD SENSOR

- Check the operation of the pointer of the micro-ammeter when pointing the flashlight toward the sensor and turning it off and on.
Refer to DESCRIPTION - AUTO "A/C"
[System operation (Air mix door control)].

LOCATION OF A/C ELECTRICAL COMPONENTS (Auto)



SHA995B

LOCATION OF A/C ELECTRICAL COMPONENTS (Auto)

Diagnostic Procedure

Listen carefully to the customer's complaint to correctly understand the problem. Then start the engine, sit in the seat, and operate the control panel to check system operation on the following items (A) to (D). In this case, check whether the air outlet grille is oriented correctly; if necessary, correct its orientation before starting inspection.

A.T.C. normal operating condition	Trouble diagnosis
(A) Ignition key ON (a) SET and AMB temperatures are indicated on digital meters. (Air flow indicator is not lighted.) (b) With blower OFF, automatic temperature control operates in ram pressure temperature control mode.	(1) Check if the power supply is connected to the control amplifier. (2) Check if the body ground terminal of the control amplifier is connected to ground. If items (1) and (2) above are all normal but item (a) at left is not normal, the control unit is faulty. When the ram pressure temperature control or mode control is faulty with A/C switch OFF, use the self-diagnosis program.
(B) Mode SW (AUTO, DEF) ON (a) The outlet mode is determined according to the ambient air temperature and sunload. * If the engine cooling water temperature is low when starting the engine, the system is set temporarily in the start control mode. Example ○ Low Tu and Low Tw → Start in DEF mode ○ High Tu, Low TL and Low Tw → Start in VENT mode Tu Head level temperature TL Foot level temperature Tw Engine cooling water temperature (b) If ambient air temperature is above 0°C (32°F) in A/C mode, COMP is ON. (1) In economy mode, comp is OFF. (2) DEF SW ON (a) In DEMIST mode, air comes out of FLOOR and DEF. Lo: 8V Automatic temperature control and REC switch are refused. (b) In DEF mode, air comes out only from DEF. Manual Lo is operable.	(1) Items to be checked when mode control is abnormal. (a) Ambient temperature sensor (b) Sunload sensor ... Perform self-diagnosis of input system. (c) Air valve, actuator ... Perform self-diagnosis of input & output system. (d) Check harness connectors. (2) Checking procedure when start control is faulty (a) Water temperature sensor (b) TdL sensor (c) Tu, TL sensors Perform self-diagnosis of input system. (d) Air valve, actuator ... Perform self-diagnosis of input & output system. (e) Check wiring and harness connectors (a) Ambient temperature sensor ... Perform self-diagnosis of AMB temperature indication and input & output system. (b) Harness wiring and connectors (a) Air valve and actuator (b) COMP Magnet clutch Perform self-diagnosis of input & output system. (a) Air valve, actuator (b) Blower speed Perform self-diagnosis of input & output system. (a) Perform self-diagnosis of input & output system.

LOCATION OF A/C ELECTRICAL COMPONENTS (Auto)

Diagnostic Procedure (Cont'd)

A.T.C. normal operating condition	Trouble diagnosis
(C) TEMP SW change (1) Air outlet temperature varies with a change in set temperature. (2) Blower speed varies with the set temperature. (3) W/C operation and intake mode vary with the set temperature.	(a) $T_L, T_u, T_dL, T_{du}, T_{dd}, T_w, Z_c, T_a$... Self-diagnosis of input system (b) P_L, P_u ... Self-diagnosis of input & output system (c) Air valve, actuator ... Self-diagnosis of input & output system (d) Check wiring and connectors. (a) T_L, T_u (b) Fan control system Perform self-diagnosis of input & output system. (a) Air valve and actuator (For control of intake door) (For control of water cock) Perform self-diagnosis of output system.
(D) manual SW operation (1) Blower speed is set at Hi or Lo by blower Hi-Lo switch. (2) Air intake mode is changed to REC mode by "REC SW."	(1) Fan control system Perform self-diagnosis of input & output system. (2) Air valve and actuator (For control of intake door) Perform self-diagnosis of input & output system.

Note: T_dL Floor duct temperature
 T_{du} Vent duct temperature
 T_{dd} Def. duct temperature

Z_c Sun load
 T_a Ambient temperature
 P_L Position of Feedback potentiometer (floor side)
 P_u Position of Feedback potentiometer (vent side)

(1) Diagnosing functions

The diagnostic program facilitates detection of failed points, and permits diagnosis in the following two modes:

- (a) Input system inspection Inspection of sensor and potentiometer (Step 1)
- (b) Input-output system inspection Inspection of actuator, W/C, COMP, and blower motor simultaneously with inspection of item (a) (Step 2)

Shown below are examples of efficient use of this diagnostic function.


- * "Input system inspection" permits inspection of the temperature of all sensors, power servo stroke and other functions while operating the A.T.C. system normally. Hence, this can be utilized to determine whether or not a device is normal according to the data obtained.
- * In "Input & output system inspection", the specified control voltage is applied from the control unit to the blower control amplifier to control the blower motor speed when inspecting blower speed. Accordingly, whether the control unit and the blower control amplifier are normal or not can be determined by checking whether the control voltage is normal.
- * In the simultaneous inspection of the input & output system in item (b) above, the air-mix door is forcibly actuated by the specified stroke during inspection of the output system. By reading the potentiometer during inspection of the input system as mentioned in (a), it is possible to determine whether the temperature control system is operating normally.

SELF-DIAGNOSING SYSTEM OF TROUBLE (Auto)

Inspection of Input System


CHECKING PROCEDURES FOR INPUT SIGNALS

1. To perform the input system inspection, connect pins 888 (Y) and 895 (L/B) of the test connector (7A), as shown. The connector is located under the right side of the instrument panel.



SHA124C

2. Turn the ignition to "ACC" position and press the "ECON/AC" button once.
3. Set data number by pushing set temp. button. Read figures indicated on "AMB" indicator.



SHA999B

Step No.	Unit to be checked	"Set"	Results (Ambient section)	
			Correct	Incorrect
0	In-vehicle sensor (foot level) (TL)	0	Indicates the approximate temperature at the location of the sensor.	All other figures: -17 (2) indicates open circuit. 83 (181) indicates short circuit. Proceed to Step (B2), Page HA-110.
1	In-vehicle sensor (head level) (Tu)	1		
2	Floor duct sensor (Tdl)	2		
3	Vent duct sensor (Tdu)	3		
4	Defrost duct sensor (Tdd)	4		
5	Water temperature switch (Tu)	5	Water temp. under 40°C (104°F) = -17 (2) Water temp. over 40°C (104°F) = 83 (181)	All others: Refer to Step (B3), Page HA-110.
6	Sunload sensor (Tc)	6	0 (32) no sunload 40 (104) high sunload (Note 1)	No change: Refer to Step (B4), Page HA-110.
7	Objective temperature adjusting switch	7	Set temperature adjuster setting equal to approx. temp. difference	Varies from actual temp. difference. Refer to Step No. 4, Page HA-122.
8	Potential balance resistor (Air mix door No. 2)	8	Varies in the range of approx. 40 to approx. 20 (approx. 104 to approx. 68). (Must perform output system diagnosis to read variation)	No variation: Improper variation: Refer to Step (C0), Page HA-112.
9	Potential balance resistor (Air mix door No. 1)	9		

NOTE 1: Values change gradually while simulating sensor with incandescent lamp.

NOTE 2: Values in () indicate °F.

$$0 - 64 (32 - 147) \quad 0 (32) - \text{Set Temp. Adjuster} + 64 (147) \\ 32 (90)$$

Set Temp. Adjuster

SELF-DIAGNOSING SYSTEM OF TROUBLE (Auto)

Inspection of Ambient Temperature Sensor

1. Turn the ignition to "ACC" position.
2. Read figures indicated on "AMB" indicator.
3. How to judge

Terminal No. 864 (L/W)

The letter in () indicates lead color.

OK — Reasonable ambient temperature

—49 [—56] * : Open sensor

83 [181] : Shorted sensor

*Figures in [] indicate degrees Fahrenheit.
(U.S.A. model)


2. Start the engine and press the "ECON/AC" button.

3. Check that output parts operate smoothly using the following chart. (Refer to pages HA-102, 103.)

- The way to make sure of the operation of actuators.

- 1) By digital indicator

When checking air mix door, set indicated number at 8 or 9 in SET section by pushing SET TEMP. button as shown below and read the displayed value in AMB section.




SHA001C

Inspection of Output System


CHECKING PROCEDURES FOR OPERATION OF ACTUATORS

1. To perform the output system inspection, connect pins 889 (L/Y), 888 (Y) and 895 (L/B) of the test connector (7A), as shown. The connector is located under the right side of the instrument panel.




SHA125C

- 2) By air flow indicator.



SHA002C



Checking items are displayed in the indicator during inspecting.

- 3) By feeling. (air velocity or temperature at ventilator grilles.)

SELF-DIAGNOSING SYSTEM OF TROUBLE (Auto)

Inspection of Output System (Cont'd)

The following 4 steps can be selected by pushing the OFF Switch.

Step number increases by pushing the switch. Each single push advances to next Step.

(1st push → 2, 2nd push → 3, 3rd push → 4, 4th push → 1)

Checking Item		Procedures of confirming operation	Step No.					Terminal
				1	2	3	4	
O-1	Air mix door 1 (Upper) P.B.R. 1	• Position of air mix door 1	Full Hot					882 (W/R) 883 (W/Y)
		Item No. 9 Objective display value 	Full Cool					
	Air mix door 2 (Lower) P.B.R. 2	• Position of air mix door 2	Full Hot					884 (W/B) 885 (W/L)
		Item No. 8 Objective display value 	Full Cool					
O-2	Outlet	• Air flow indicator • Check each outlet by hand.	DEF VENT B/L DEMIST					DEF/VENT Changeover 887 (R/Y) FOOT Opens/ Closes 886 (R)
O-3	Intake door	• Air flow indicator • Look at the intake door spring	REC. Partial REC Fresh air					880 (R/L) 881 (R/G)
O-4	Water cock	• Air flow indicator • Look at the water cock position and check temperature by hand.	ON OFF					564 (GY)
O-5	Compressor clutch	• Air flow indicator • Check operation of the magnet clutch.	ON OFF					567 (Y/G)
Display								


- Note:
- Value marked * is for U.S.A. model.
 - The letter in () indicates lead wire color.
 - If approx. ± 7 difference exists between indicated value and the value in test chart, this is normal.
 - Location of components is shown on page HA-90, HA-97.

SELF-DIAGNOSING SYSTEM OF TROUBLE (Auto)

—Inspection of Output System (Cont'd)—

Blower motor can be checked by the following procedure.


4 steps can be selected by pushing the Lo Switch. Step No. increases by pushing the switch.

Checking item		Procedures of confirming operation	Step No.					Terminal No.
				1	2	3	4	
Q-6	Blower motor	• Air conditioner operation indicator • Touch with each outlet by hand. • Measure the applied voltage of motor.						Blower relay 571 (G) Signal for amount of air 568 (G/W)

Note: The letter in () indicates lead wire color.

SHA820B

Measurement of blower motor applied voltage



SHA004C

TROUBLE DIAGNOSES (Auto)


CONTENTS

Circuit for trouble diagnoses	HA-106
Auto A/C system diagnosis	HA-108
(A0) Check to see if SET AMB. temperature is displayed when ignition switch is set to ACC, or when engine is running	HA-108
Input system diagnosis	HA-110
(B0) Inoperative input system	HA-110
Output system diagnosis	HA-112
1) Inoperative air mix door	HA-112
(C0) Input & output system: Check O-1 for proper operation	HA-112
2) Doors, water cock and compressor diagnosis	HA-114
(D0) Check if 12 volts are present at terminal 867 (SB) with connector ⑨ in place	HA-114
(E0) Check if 12 volts are present at terminal 561 (SB) when connector ⑤ is connected	HA-115
(F0) Check if 12 volts are present at lead wire (OR) of air valve located on vacuum tank	HA-116
(G0) Check if 12 volts are present at lead wire (L side) of air conditioner relay located in engine compartment	HA-117
3) Blower motor diagnosis	HA-118
(H0) Conduct self-diagnostic checks on input & output system	HA-118
Automatic amplifier diagnosis	HA-120
1) LCD (Liquid Crystal Display) or LED (Light Emitting Diode) does not glow	HA-120
(I0) Do LCD's or LED's glow?	HA-120
2) Operating (Buzzing) sound is not emitted.	HA-121
(J0) Disconnect buzzer connector from control subassembly and apply 12 volts across buzzer terminals (red ⊕ and black ⊖) to see if buzzer sounds	HA-121
3) Switches on switch panel assembly do not operate.	HA-121
(K0) Is SET AMB. temperature displayed when ignition switch is set to ACC?	HA-121
4) Erroneous display during inspection of the input system	HA-122
(L0) Are all numbers except Step No. 7 correct?	HA-122
5) Erroneous operation during inspection of the output system	HA-122
(M0) Does air flow indication change properly?	HA-122
6) Escutcheon lamp does not come on	HA-122
Replacement of control subassembly and switch panel assembly	HA-123
Blower continues to rotate in HI mode	HA-124
Blower rotates only in LO mode	HA-124
Blower motor does not rotate	HA-125
Blower speed changes variably	HA-125
No air is discharged from vent outlets	HA-126
No air is discharged from floor outlets	HA-126
No air is discharged from defroster outlets	HA-127
Hot air is not discharged or outlet air temperature does not change	HA-127
No cool air is discharged	HA-128
Cool air at foot level will not stop or is discharged intermittently	HA-129
Outside air is not drawn into compartment	HA-129
Discharged air is too cool	HA-130
Discharged air is not cool	HA-130
Compartment is too hot	HA-131

TROUBLE DIAGNOSES (Auto)


Compartment will not become warm	HA-131
• Temperature of air discharged from floor outlets fluctuates	HA-132
• In-vehicle temperature fluctuates	HA-132
• Temperature of air discharged from def. outlets on instrument panel fluctuates	HA-132

TROUBLE DIAGNOSES GUIDE



TROUBLE DIAGNOSES (Auto)


Circuit for Trouble Diagnoses



★ Perform voltage and continuity test with control unit connected to harness.


TC : Turbocarged models
NT : Non-turbocarged models

TROUBLE DIAGNOSES (Auto)




TROUBLE DIAGNOSES (Auto)

AUTO A/C SYSTEM DIAGNOSIS




TROUBLE DIAGNOSES (Auto)



(B)

Inspection procedure:
Refer to Connector arrangement diagrams ① to ⑩ shown in HA-107.

1. Inspection of connectors ⑦ and ⑧, located near the cooling unit, to heater unit connecting section.
 - (1) Disconnect the connector and check the voltage at terminals 563, 565 and 787 on the cooling unit side. (Voltage must be greater than 9 volts.)



- (2) Check the voltage of terminal 954. (Voltage must be 0 volt.)
2.
 - (1) If the result of inspection 1 above is no good, check the fuse of 10A (ACC) and 10A (VB) in the fuse box.
 - (2) If the result of inspection 1 above is O.K., connect connectors ⑦ and ⑧ and disconnect connector ④ on the rear side of the control unit.

565		563
787	954	955

Check the voltage of terminals 563 (OR), 565 (SB), 787 (L/B), 954 (B) and 955 (B).

If it is difficult to check with connectors ⑦

and ⑧ connected, this inspection may be substituted with the continuity check between connectors ⑦ and ⑧ and connector ④.


3.
 - (1) If the result of inspection 2 above is no good, continuity of the harness between connectors ⑦ and ⑧ and connector ④ is faulty.
 - (2) If the result of inspection is O.K., the control unit is faulty.

TROUBLE DIAGNOSES (Auto)

INPUT SYSTEM DIAGNOSIS (Page HA-100)

★ Numbers displayed on indicators.
When the indicator at Step No. 0
thru 4 shows only -17 [2], check
line 861 (sensor ground = 0V).

Number: Canada model
[U.S.A. model]



INSPECTION PROCEDURE

Conduct inspection referring to connector arrangement diagram on page HA-107.

Procedure 1

- (1) If ambient display on the control panel is faulty, disconnect the ambient sensor connector at the front bumper. If the display is -49°C (-56°F) when disconnected and 83°C (181°F) when the voltage side is shorted to ground, the auto amplifier and harness are O.K. Check the ambient sensor for temperature-resistance characteristics. (See page HA-75.)
- (2) If the display does not change from -49°C (-56°F) even when shorted, check terminal 864 for approx. 5.0 volts with the sensor disconnected. No = faulty auto amplifier. Yes = proceed to step 3.
- (3) Check circuit 864 through to sensor.

TROUBLE DIAGNOSES (Auto)

Procedure 2


- (A) If display Nos. 0, 1, 2, 3, or 4 are faulty, disconnect harness connector at the sensor location. If the display is -17°C (2°F) with the connector disconnected, and 83°C (181°F) when the voltage side is shorted to ground, the auto amplifier and harness are O.K. Check the sensor temperature-resistance characteristics.
- (B) If the display does not change from -17°C (2°F) even when shorted, check for approx. 5.0 volts at the appropriate terminal of the auto amplifier harness.
No = Faulty auto amplifier Yes = Proceed to (C).
- (C) Check faulty circuit from auto amplifier through to sensor.

Procedure 3

- (A) Disconnect harness connector at the sensor. If the display is -17°C (2°F) with the harness disconnected, and 83°C (181°F) when the voltage side is shorted to ground, replace water temperature switch.
- (B) If the display does not change from -17°C (2°F) even when shorted, check for approx. 5.0 volts at terminal 862 (L/R) of auto amplifier harness.
No = Faulty auto amplifier Yes = Proceed to (C).
- (C) Check circuit from connector No. 5 through to connector (34F).

Procedure 4

- (A) If 0 (32) is displayed with connector No. 17 removed, move vehicle into the sun and check for a change in current value between male terminals 855 (BR) and 890 (L/B). No change = Replace sensor.
- * Under high sunload condition: If the output is on the order of 0.05 to 2.0 mA and it drops to 0 mA when the sunload sensor is covered, the display is normal.



*2) Check connectors (4), (5) and (6) with the control unit pulled out as far as the gear shift lever.

STEP NO.	SENSOR	TERMINAL
0	TL	857 (BR/Y)
1	Tu	863 (BR/W)
2	TdL	858 (Y/W)
3	Tdu	860 (Y/R)
4	Tdd	859 (Y/B)


SHA008C

TROUBLE DIAGNOSES (Auto)

OUTPUT SYSTEM DIAGNOSIS (Page HA-101 to HA-103)

1) Inoperative air mix door


INSPECTION PROCEDURE – Air Mix Door




INSPECTION PROCEDURE

Use layout of connectors ① through ⑳ on page HA-107 as an inspection guide.

- (Note 1) Check with engine running while diagnosing input and output system.
- (Note 2) Same as Note 1 above. Faulty input vacuum line can be determined by fixed DEF mode.
- (Note 3) After disconnecting vacuum hose from air valve No. 5 or No. 9, connect vacuum hose (on hand) to the hose. Suck air from and blow air into hose orally or by using a vacuum pump and check if potentiometer reading varies with changes in air temperature. If potentiometer reading does not change, link may be jammed, power servo may not be installed properly (loose screws, etc.) or power servo may be faulty.
- (Note 4) In a manner similar to Note 3 above, disconnect vacuum hose from air valve No. 5 or No. 9 and connect vacuum hose (on hand) to the hose. Suck air from and blow air into hose orally or by using a vacuum pump. If air temperature does not change regardless of control operation of photo amplifier for power servo, link may be jammed, power servo may be installed improperly (loose screws, etc.) or power servo is not functioning.
- Other If air valves constantly repeat ON-OFF operation when ATC and input & output system function properly, air valve(s) may be leaking.
- ★ Performance characteristics of PL and PU-potentiometer voltages and input indications (#8 and 9)



SHA618B



SHA009C

POTENTIOMETER ADJUSTMENT PROCEDURE

With the heater assembly removed from the vehicle, check to be sure that there is no binding of either the air mix doors or linkage. With both air mix doors in the full heat position, (no vacuum applied), adjust the resistance between terminals No. 1 (B/W) and No. 3 (G/Y) of the P.B.R. harness to 2.8k. Adjust the resistance between terminal No. 1 (B/W) and No. 4 (G/R) to 3.0k.

TROUBLE DIAGNOSES (Auto)

2) Doors, water cock and compressor diagnosis

While checking input, output system, check solenoid valves, relays, vacuum pressure, etc., using following tables as a guide.

Normal solenoid valve and relay operation

Positive (+) side: Approx. 12 V (Constant)

Negative (−) side: OFF (approx. 12 V)
ON (0 volts)

INSPECTION PROCEDURE – Doors, Water Cock and Compressor

Check operation of air valves and relays while operating input and output system SELF DIAGNOSIS FUNCTION.


Air valves and relays

Positive (+) side: Approximately 12 volts (constant)

Negative (−) side: Approximately 0 volts (OFF)


(Downstream of coil): Approximately 0 volts (ON)

★ Be careful not to short-circuit positive and negative sides of coil.
Otherwise, transistor(s) inside control unit may be damaged.



SHA

2-1 Inspection Procedure – Air Outlets



NOTE 1: Check with engine running while operating Input and Output System Test.

TROUBLE DIAGNOSES (Auto)

Mode Door Operation

Air valve actuator Mode		Air valve		Actuator		
		No. 6	No. 7	DEF door	VENT door	FLOOR door
Air outlet	DEF	OFF	OFF	Atmospheric pressure		
	VENT	ON	OFF	Vacuum pressure		Atmospheric pressure
	B/L	ON	ON	Vacuum pressure		
	HEAT	OFF	ON	Atmospheric pressure		Vacuum pressure

2-2 Inspection Procedure – Intake Doors

(E0)

Check if 12 volts are present at terminal 561 (SB) when connector ⑬ is connected.

O.K.

N.G.

(E1)

Disconnect connector ⑬. Check if resistance between male terminals 561 (OR) and 880 (R/L) and between 561 (OR) and 881 (R/G) connecting to connector ⑬ is approximately 140 ohms.

(E7)

Check if continuity exists between terminals 561 (SB) of connector ⑬ and male terminal 562 (SB) of connector ④A (connecting to connector ②). Check if continuity exists between male terminal 952 (B) connecting to connector ⑬ and 952 (B/Y) of connector ③.

O.K.

O.K.

N.G.

(E2)

Note 1

Connect connector ⑬. Check if 12 and 0 volts are alternately present at terminals 880 (R/L) and 881 (R/G).

(E3)

Faulty air valve assembly

(E8)

Poor harness connection

O.K.

N.G.

(E4)

Check if vacuum pressure is produced at actuator connections from air valves No. 2 and 3.

(E9)

Check if continuity exists in lines 880 (R/L) and 881 (R/G) between connectors ⑬ and ⑥.

(E5)

Faulty link or actuator

(E6)

Faulty air valve

(E10)

Faulty control unit

(E11)

Poor harness connection


NOTE 1: Check with engine running while operating Input and Output System Test.

TROUBLE DIAGNOSES (Auto)

Intake Door Operation

Mode \ Air valve actuator		Air valve No. 3	Air valve No. 2	Double-action actuator (intake door closed)
Air inlet	Inside air	ON	ON	Vacuum pressure (at 1st and 2nd positions)
	Inside-outside air	ON	OFF	Vacuum pressure (at 1st position)
	Outside air	OFF	OFF	Atmospheric pressure

2-3 Inspection Procedure — Water Cock




NOTE 1: Check with engine running while operating Input and Output System Test.

Water cock operation

Water cock \ Air valve actuator	Air valve	Water cock actuator
Open	OFF	Atmospheric pressure
Close	ON	Vacuum pressure

TROUBLE DIAGNOSES (Auto)

2-4 Inspection Procedure — Compressor



Compressor operation


	Relay
Compressor ON	ON
Compressor OFF	OFF

NOTE 1: Check with engine running while operating Input and Output System Test.

TROUBLE DIAGNOSES (Auto)

3) Blower motor diagnosis


INSPECTION PROCEDURE — Blower & Motor




NOTE: Check with engine running while performing Input and Output System Test.

TROUBLE DIAGNOSES (Auto)

- (Note 1) When ignition switch is set to ACC, current flows through blower relay coil. With ignition switch held there, activating switches "AUTO" and "DEF" on control unit causes downstream side of relay coil to be grounded so that blower relay activates. If blower motor does not activate due to problems in its power supply, it will be due to one of the following causes:
- (a) Lead wire (W) between fusible link and relay is broken,
 - (b) The line between lead wire (W/G) of relay and terminal 560 of connector (3) (including two 15-A fuses) is broken,
 - (c) The line between lead wire (S/B) of relay and fuse (ACC) is broken, or
 - (d) The line between lead wire (G) of relay and terminal 571 of connector (6) is broken.



- (Note 2) Output performance characteristics of fan control is shown below:





SHA620B

TROUBLE DIAGNOSES (Auto)

AUTOMATIC AMPLIFIER DIAGNOSIS


- 1) LCD (Liquid Crystal Display) or LED (Light Emitting Diode) does not glow.




*: Refer to REPLACEMENT OF CONTROL SUBASSEMBLY AND SWITCH PANEL ASSEMBLY. (Page HA-123)

TROUBLE DIAGNOSES (Auto)

2) Operating (Buzzing) Sound is not Emitted.




3) Switches on Switch Panel Assembly do not Operate.




*: Refer to REPLACEMENT OF CONTROL SUBASSEMBLY AND SWITCH PANEL ASSEMBLY. (Page HA-123)

TROUBLE DIAGNOSES (Auto)

4) Erroneous Display during Inspection of the Input System



5) Erroneous Operation during Inspection of the Output System



6) Escutcheon lamp does not come on.


Check for burned-out lamp located at rear of switch panel assembly ④.*

*: Refer to REPLACEMENT OF CONTROL SUBASSEMBLY AND SWITCH PANEL ASSEMBLY. (Page HA-123)

TROUBLE DIAGNOSES (Auto)


REPLACEMENT OF CONTROL SUBASSEMBLY AND SWITCH PANEL ASSEMBLY

- Before performing various operational checks of the automatic amplifier, check to make sure the four switch panel assembly-to-control subassembly connectors and buzzer connector are secure and tight and are free from damage.
- On the rear of the control panel assembly are five light bulbs that can be serviced as required.



SHA011C

TROUBLE DIAGNOSES (Auto)




[CHECK POINTS]

- (1) Open or shorted sensor (Tu, Tdu, or Tdd)
- (2) Aspirator motor does not rotate and "Tu" value is close to "TA" value.

TU: In-vehicle sensor (Head)

TA: Ambient temp. sensor



[CHECK POINTS]

Harnesses, connectors and sensors in relation to TL, Tu, TdL, Tdu, Tdd

TL: In-vehicle sensor (Foot)


Tu: In-vehicle sensor (Head)

TdL: Floor duct temp. sensor

Tdu: Vent duct temp. sensor

Tdd: Defroster nozzle temp. sensor



TROUBLE DIAGNOSES (Auto)



[CHECK POINTS]

- (1) Poor or faulty connection of In-vehicle sensor (Foot), In-vehicle sensor (Head), Floor duct temp. sensor, Vent duct temp. sensor, Defroster nozzle duct temp. sensor, Ambient temp. sensor, Sunload sensor, Potentio Balance Resistor (AM1), Potentio Balance Resistor (AM2).
- (2) Start-stop operation of aspirator motor and voltage measurements at sensors (Remove sensor assembly to gain access to sensors.)

TROUBLE DIAGNOSES (Auto)



TROUBLE DIAGNOSES (Auto)

NO AIR IS DISCHARGED FROM DEFROSTER OUTLETS.

↓

Check (D0, E0, F0, G0) under OUTPUT SYSTEM DIAGNOSIS
(Use self-diagnosing functions).

[CHECK POINTS]

- (1) Harness (line 8B7) and solenoid valve 6
- (2) Damaged hose/link between solenoid valve 6 and actuator Ad (DEF. door Actuator)

HOT AIR IS NOT DISCHARGED OR OUTLET
AIR TEMPERATURE DOES NOT CHANGE.

↓

Check input system using self-diagnosing functions.

N.G.

↓


Check (B2) and (B3) under INPUT
SYSTEM DIAGNOSIS.

O.K.


↓

Check OUTPUT SYSTEM DIAGNOSIS:
Air mix door (C0)
Water cock (F0)


TROUBLE DIAGNOSES (Auto)





TROUBLE DIAGNOSES (Auto)




TROUBLE DIAGNOSES (Auto)



TROUBLE DIAGNOSES (Auto)



TROUBLE DIAGNOSES (Auto)



[CHECK POINTS]

Poor connection of connector harness under vibrating conditions, such as when vehicle is being driven.

If outlet discharged air temperature fluctuates (sometimes becomes warm), check continuity between terminals corresponding to each symptom using following table.

Portions to be inspected			Outlet from which discharged air temperature is fluctuating			Remarks
Terminal (harness line) No. See HA-106 & 107.	Connector No. See HA-107.	Circuit connection	VENT	FLOOR	DEF.	
864 (L/W)	① ⑤ ⑦	AMBIENT TEMP. SENSOR		⊙	⊙	Refer to step (B1) Page HA-110.
857 (BR/Y)	⑤ ⑦ ⑩	IN-VEHICLE SENSOR (FOOT)		⊙		Refer to step (B2) Page HA-110.
863 (BR/W)	① ⑤ ⑧	IN-VEHICLE SENSOR (HEAD)	⊙		○	
858 (Y/W)	⑤ ⑦ ⑨ ⑪	FLOOR DUCT TEMP. SENSOR		⊙		
860 (Y/R)	⑤ ⑦ ⑨ ⑩	VENT DUCT TEMP. SENSOR	⊙			
859 (Y/B)	⑤ ⑦ ⑪	DEFROSTER DUCT TEMP. SENSOR			⊙	
868 (B/W)	⑤ ⑦ ⑨	P.B.R. 1 & 2	⊙	⊙	○	—
882 (W/R)	⑥ ⑧ ⑨	S/V 4		⊙		For air mix door 2
883 (W/Y)	⑥ ⑧ ⑨	S/V 5		⊙		
884 (W/B)	⑥ ⑧ ⑨	S/V 8	⊙		○	For air mix door 1
885 (W/L)	⑥ ⑧ ⑨	S/V 9	⊙		○	
567 (Y/L)	② ⑥ ⑧	COMPRESSOR RELAY	⊙	⊙		—

- This table indicates the portions to be inspected for each type of symptom. It is necessary for each symptom to check circuit connections marked "⊙" or "○".
- Prior to portions marked "○", check portions marked "⊙".

SERVICE DATA AND SPECIFICATIONS (S.D.S.)

General Specifications

COMPRESSOR

Model	DIESEL-KIKI make DKS-16H
Type	Swash plate
Displacement cm ³ (cu in)/Rev.	167 (10.19)
Cylinder bore x stroke mm (in)	37.0 x 25.8 (1.457 x 1.016)
Direction of rotation	Clockwise (viewed from drive end)
Drive belt	Poly V

LUBRICATION OIL

Model	DIESEL-KIKI make DKS-16H
Type	SUNISO 506
Capacity ml (US fl oz, Imp fl oz) Total in system	200 (6.8, 7.0)
Amount of oil which can be drained	130 (4.4, 4.6)
Compressor (Service parts) charging amount	200 (6.8, 7.0)

REFRIGERANT

Type	R-12
Capacity kg (lb)	0.9 - 1.1 (2.0 - 2.4)

ENGINE IDLING SPEED

Transmission		Non- turbocharged model	Turbocharged model
When A/C is OFF		Refer to MA section.	
When A/C is ON	M/T rpm	750 - 850	750 - 850
	A/T rpm	750 - 850 at "D" range	750 - 850 at "D" range

Inspection and Adjustment

COMPRESSOR

Model	DKS-16H
Clutch disc-pulley clearance mm (in)	0.3 - 0.6 (0.012 - 0.024)

SERVICE DATA AND SPECIFICATIONS (S.D.S.)

Tightening Torque


COMPRESSOR INSTALLATION

	N·m	kg·m	ft·lb
Compressor bracket to cylinder block	36 - 49	3.7 - 5.0	27 - 36
Compressor to compressor bracket	36 - 49	3.7 - 5.0	27 - 36
Compressor shaft nut	14 - 16	1.4 - 1.6	10 - 12
Compressor lock nut	34 - 39	3.5 - 4.0	25 - 29

REFRIGERANT LINE

When connecting lines made of different material, basically use the lower tightening torque of the two.


Union type (pipe to pipe)



SHA669A

Pipe O.D. mm (in)	Material					
	Steel or copper			Aluminum		
	N·m	kg·m	ft·lb	N·m	kg·m	ft·lb
6 (1/4)	10 - 20	1.0 - 2.0	7 - 14	—	—	—
8 (5/16)	15 - 25	1.5 - 2.5	11 - 18	10 - 20	1.0 - 2.0	7 - 14
10 (3/8)	15 - 25	1.5 - 2.5	11 - 18	10 - 20	1.0 - 2.0	7 - 14
12 (1/2)	20 - 29	2.0 - 3.0	14 - 22	15 - 25	1.5 - 2.5	11 - 18
16 (5/8)	25 - 34	2.5 - 3.5	18 - 25	20 - 29	2.0 - 3.0	14 - 22
19 (3/4)	25 - 34	2.5 - 3.5	18 - 25	20 - 29	2.0 - 3.0	14 - 22

Union type (hose to hose)




SHA670A

Pipe O.D. mm (in)	Material					
	Steel or copper			Aluminum		
	N·m	kg·m	ft·lb	N·m	kg·m	ft·lb
6 (1/4)	10 - 20	1.0 - 2.0	7 - 14	—	—	—
8 (5/16)	15 - 25	1.5 - 2.5	11 - 18	10 - 20	1.0 - 2.0	7 - 14
10 (3/8)	15 - 25	1.5 - 2.5	11 - 18	10 - 20	1.0 - 2.0	7 - 14
12 (1/2)	25 - 34	2.5 - 3.5	18 - 25	20 - 29	2.0 - 3.0	14 - 22
16 (5/8)	25 - 34	2.5 - 3.5	18 - 25	20 - 29	2.0 - 3.0	14 - 22

SERVICE DATA AND SPECIFICATIONS (S.D.S.)

Tightening Torque (Cont'd)


Union type (hose to pipe)



SHA671A

- Use tightening torque for flexible hose.

Plate type









SHA672A


		Bolt type		Tightening torque		
Grade	Nominal size	Bolt diameter mm	Pitch mm	N·m	kg·m	ft·lb
	M6	6.0	1.0	3 - 4	0.3 - 0.4	2.2 - 2.9
4T	M8	8.0	1.25	8 - 11	0.8 - 1.1	5.8 - 8.0
	M10	10.0	1.5	16 - 22	1.6 - 2.2	12 - 16

In case of 7T Bolt has been installed in vehicle,
Tightening torque is as same as 4T bolt.

SPECIAL SERVICE TOOLS

Tool number (Kent-Moore No.) Tool name	Description
KV99232022 (J26571-A) Clutch disc puller	 Removing clutch disc
KV99235140 (J37876) Shaft seal remover and installer	 Removing and installing shaft seal.
KV99241420 (J37881) Blind cover set ① KV99241400 (-) ② KV99211100 (-) ③ KV99211300 (-)	 Blind cover
KV994C1552 (J37880) Charge nozzle	 Using charge refrigerant
KV99231010 (J37877) Clutch disc wrench	 Removing shaft nut and clutch disc
KV99233040 (J26720-A) Puller pilot	 Removing pulley
KV99234160 (J37879) Pulley installer	 Installing pulley

CE TOOLS

Tool number (Kent-Moore No.) Tool name	Description
KV99267420 (J37878) Shaft seal guide	 Installing shaft seal
KV99235160 (J37882) Nut wrench	 Removing lock nut