


1. General Description

A: SPECIFICATION

Refer to FS section for rear suspension specifications. <Ref. to FS-2, SPECIFICATION, General Description.>

NOTE:

- Front and rear toe-in and front camber can be adjusted. If the toe-in or camber tolerance exceeds specifications, adjust toe-in and camber to the middle value of the specification.
- Other items indicated in the specifications table cannot be adjusted. If other items exceed specifications, check suspension parts and connections for deformation, and replace with new parts as required.




(1) Front

A – B = Positive: Toe-in, Negative: Toe-out

α_1, α_2 : Toe angles

B: COMPONENT

1. REAR SUSPENSION



RS-00205

(1) Stabilizer	(15) Trailing link front bushing	(28) Flange nut
(2) Stabilizer bracket	(16) Trailing link bracket	
(3) Stabilizer bushing	(17) Cap (Protection)	
(4) Clamp	(18) Washer	
(5) Floating bushing	(19) Rear crossmember	
(6) Stopper	(20) Strut mount cap	
(7) Stabilizer link	(21) Strut mount	
(8) Rear lateral link	(22) Self-locking nut	
(9) Bushing	(23) Dust cover	
(10) Bushing	(24) Coil spring	
(11) Front lateral link	(25) Helper	
(12) Bushing	(26) Rubber seat lower	
(13) Trailing link rear bushing	(27) Damper strut	
(14) Trailing link		

Tightening torque: N·m (kgf·m, ft·lb)

T1: 20 (2.0, 14.5)
T2: 25 (2.5, 18.1)
T3: 45 (4.6, 33.2)
T4: 60 (6.1, 44)
T5: 90 (9.2, 66)
T6: 100 (10.2, 74)
T7: 115 (11.7, 85)
T8: 130 (13.3, 96)
T9: 140 (14.3, 103)
T10: 200 (20.4, 148)

General Description




REAR SUSPENSION

C: CAUTION

- Wear work clothing, including a cap, protective goggles and protective shoes during operation.
- Before disposing of shock absorbers, be sure to bleed the gas out completely. Also, do not expose to flames or fire.
- Before removal, installation or disassembly, be sure to clarify the failure. Avoid unnecessary removal, installation, disassembly and replacement.
- Use SUBARU genuine grease etc. or equivalent. Do not mix grease with another grade or from other manufacturers.
- Be sure to tighten fasteners including bolts and nuts to the specified torque.
- Place shop jacks or rigid racks at the specified points.
- Before securing a part on a vise, place cushioning material such as wood blocks, aluminum plate, or shop cloth between the part and the vise.




D: PREPARATION TOOL

1. SPECIAL TOOL

ILLUSTRATION	TOOL NUMBER	DESCRIPTION	REMARKS
 ST-927720000	927720000	INSTALLER & REMOVER	Used for replacing the front bushing.
 ST-927730000	927730000	INSTALLER & REMOVER	Used for replacing the rear bushing.
 ST-927700000	927700000	INSTALLER & REMOVER	Used for replacing the lateral link bushing.

General Description

REAR SUSPENSION

ILLUSTRATION	TOOL NUMBER	DESCRIPTION	REMARKS
	927690000	INSTALLER & REMOVER	Used for replacing the lateral link bushing.
	28099PA090	OIL SEAL PROTECTOR	<ul style="list-style-type: none"> Used for installing the rear drive shaft into the rear differential. For oil seal protection
	28099PA100	REMOVER	Used for removing the rear drive shaft from the rear differential.

2. GENERAL TOOL

TOOL NAME	REMARKS
Alignment gauge	Used for measuring wheel alignment.
Alignment gauge adapter	Used for measuring wheel alignment.
Turning radius gauge	Used for measuring wheel alignment.
Toe-in gauge	Used for toe-in measurement.
Transmission jack	Used for removing and installing the suspension.
Bearing puller	Used for removing bushings.
Coil spring compressor	Used for strut assembly/disassembly.