

CLUTCH 2-10


	Page
S SPECIFICATIONS AND SERVICE DATA	2
1. Specifications	2
C COMPONENT PARTS	3
1. Clutch System	3
W SERVICE PROCEDURE	4
1. General	4
2. On-Car Service	4
3. Release Bearing and Lever	5
4. Clutch Disc and Cover	7
K DIAGNOSTICS	11
1. Clutch Trouble in General	11

1. Specifications

		1800 cc	2200 cc
Clutch cover	Diaphragm set load kg (lb)	450 (992)	
Clutch disc	Facing material	Woven	
	O.D. x I.D. x thickness mm (in)	225 x 150 x 3.5 (8.86 x 5.91 x 0.138)	
	Spline O.D. (No. of teeth) mm (in)	25.2 (0.992) (24)	
	Depth of rivet head mm (in)	Standard	1.3 — 1.9 (0.051 — 0.075)
		Limit of sinking	0.3 (0.012)
	Limit for runout mm (in)	1.0 (0.039) at R = 107 (4.21)	
Clutch release lever ratio		3.0	
Release lever	Stroke mm (in)	24 — 26 (0.94 — 1.02)	
	Play at release lever center mm (in)	3 — 4 (0.12 — 0.16)	
Release bearing		Grease-packed self-aligning	
Clutch pedal	Full stroke mm (in)	140 — 145 (5.51 — 5.71)	

O.D.; Outer Diameter I.D.; Inner Diameter

1. Clutch System



H2M1562A

- ① Clutch cable bracket
- ② Clutch release lever sealing
- ③ Pivot
- ④ Retainer spring
- ⑤ Clutch release lever
- ⑥ Clip
- ⑦ Clutch release bearing
- ⑧ Clutch cover
- ⑨ Clutch disc

- ⑩ Flywheel
- ⑪ Return spring
- ⑫ Clutch return spring bracket

Tightening torque: N·m (kg·m, ft·lb)
T: 15.7±1.5 (1.6±0.15, 11.6±1.1)


1. General

A: PRECAUTION

1. MECHANICAL APPLICATION TYPE

When servicing clutch system, pay attention to the following items.

- 1) Check the routing of clutch cable for smoothness.
- 2) Excessive tightness or looseness of clutch cable have a bad influence upon the cable durability.
- 3) Apply grease sufficiently to the connecting portion of clutch pedal.
- 4) Apply grease sufficiently to the release lever portion.
- 5) Position clutch cable through the center of toe board hole and route it smoothly. Adjustment is done by moving the outer cable.
- 6) Make sure not to let the clutch chatter when starting forward or rearward. If clutch chattering occurs, readjust so that the bend of clutch outer cable becomes flatter.



2. On-Car Service

A: ADJUSTMENT

1. MECHANICAL APPLICATION TYPE


- 1) Remove release lever return spring from lever.
- 2) Adjust spherical nut so that the play is within the specified value at the lever end (center of spherical nut).

CAUTION:

Take care not to twist the cable during adjustment

Play: 3 — 4 mm (0.12 — 0.16 in)


Full stroke: 24 — 26 mm (0.94 — 1.02 in)




- 3) Upon completion of adjustment, securely lock spherical nut with lock nut.
Install return spring on lever.

NOTE:

Hook the long hook side of the return spring with the lever.



4) Depress clutch pedal to assure there is no abnormality in the clutch system.



3. Release Bearing and Lever

A: REMOVAL


1. MECHANICAL APPLICATION TYPE

- 1) Remove release lever return spring ①.
- 2) Remove the two clips ② from clutch release lever ③ and remove release bearing ⑥.


CAUTION:

Be careful not to deform clips.

- 3) Remove release lever seal ④.



- 4) Remove release lever retainer spring from release lever pivot with a screwdriver by accessing it through clutch housing release lever hole. Then remove release lever.



B: INSPECTION

1. RELEASE BEARING

CAUTION:


Since this bearing is grease sealed and is of a nonlubrication type, do not wash with gasoline or any solvent when servicing the clutch.

1) Check the bearing for smooth movement by applying force in the radial direction.

Radial direction stroke:


Approx.

1.4 mm (0.055 in)



2) Check the bearing for smooth rotation by applying pressure in the thrust direction.

3) Check wear and damage of bearing case surface contacting with lever.



2. RELEASE LEVER

Check lever pivot portion and the point of contact with release bearing case for wear.


C: INSTALLATION

1. MECHANICAL APPLICATION TYPE

CAUTION:

Before or during assembling, lubricate the following points with a light coat of grease.

- Inner groove of release bearing
- Contact surface of lever and pivot
- Contact surface of lever and bearing
- Transmission main shaft spline (Use grease containing molybdenum disulphide.)




1) While pushing release lever ③ to pivot and twisting it to both sides, fit retainer spring ⑤ onto the constricted portion of pivot.

NOTE:

Confirm that retainer spring is securely fitted by observing it through the main case hole.

- 2) Install release bearing ⑥ and fasten it with two clips ②.
- 3) Install release lever seal ④.



4) After remounting engine and transmission on body, make adjustment of the clutch release lever end play.


CAUTION:

Take care not to twist the cable during adjustment.

5) Install release lever return spring.

NOTE:

Hook up the return spring to right side hole of the release lever.



4. Clutch Disc and Cover

A: REMOVAL

1) Install ST on flywheel.


ST 498497100 CRANKSHAFT STOPPER


2) Remove clutch cover and clutch disc.

CAUTION:

- Take care not to allow oil on the clutch disc facing.
- Do not disassemble either clutch cover or clutch disc.

3) Remove flywheel.



**B: INSPECTION****1. CLUTCH DISC****1) Facing wear**

Measure the depth of rivet head from the surface of facing. Replace if facings are worn locally or worn down to less than the specified value.

Depth of rivet head:**Standard value**


1.3 — 1.9 mm (0.051 — 0.075 in)

Limit of sinking

0.3 mm (0.012 in)

CAUTION:


Do not wash clutch disc with any cleaning fluid.

**2) Hardened facing**

Correct by using emery paper or replace.

3) Oil soakage on facing


Replace clutch disc and inspect transmission front oil seal, transmission case mating surface, engine rear oil seal and other points for oil leakage.

**4) Deflection on facing**


If deflection exceeds the specified value at the outer circumference of facing, repair or replace.

Limit for deflection:

1.0 mm (0.039 in) at R = 107 mm (4.21 in)

**5) Worn spline, loose rivets and torsion spring failure**


Replace defective parts.



2. CLUTCH COVER


Visually check for the following items without disassembling, and replace or repair if defective.

- 1) Loose thrust rivet.
- 2) Damaged or worn bearing contact area at center of diaphragm spring.



- 3) Damaged or worn disc contact surface of pressure plate.

- 4) Loose strap plate setting bolt.
- 5) Worn diaphragm sliding surface.




3. FLYWHEEL

CAUTION:

Since this bearing is grease sealed and is of a nonlubrication type, do not wash with gasoline or any solvent.

- 1) Damage of facing and ring gear
If defective, replace flywheel.




- 2) Smoothness of rotation

Rotate ball bearing applying pressure in thrust direction.

If noise or excessive play is noted, replace ball bearing as follows:

- (1) Drive out ball bearing from flywheel.
- (2) Press bearing into flywheel until bearing end surface is flush with clutch disc contact surface of flywheel.
Do not press inner race.

ST 899754112 SNAP RING PRESS

**C: INSTALLATION**

- 1) Install flywheel.
- 2) Install ST, and tighten the flywheel attaching bolts to the specified torque.



ST 498497100 CRANKSHAFT STOPPER

Tightening torque:

$72 \pm 3 \text{ N}\cdot\text{m}$ ($7.3 \pm 0.3 \text{ kg}\cdot\text{m}$, $52.8 \pm 2.2 \text{ ft}\cdot\text{lb}$)


NOTE:

Tighten flywheel installing bolts gradually. Each bolt should be tightened to the specified torque in a crisscross fashion.



- 3) Insert ST into the clutch disc and install them on the flywheel by inserting the ST end into the pilot bearing.

ST 499747100 CLUTCH DISC GUIDE



- 4) Install clutch cover on flywheel and tighten bolts to the specified torque.

NOTE:

- When installing the clutch cover on the flywheel, position the clutch cover so that there is a gap of 120° or more between "0" marks on the flywheel and clutch cover. ("0" marks indicate the directions of residual unbalance.)
- Note the front and rear of the clutch disc when installing.
- Tighten clutch cover installing bolts gradually. Each bolt should be tightened to the specified torque in a crisscross fashion.

Tightening torque:

$15.7 \pm 1.5 \text{ N}\cdot\text{m}$ ($1.6 \pm 0.15 \text{ kg}\cdot\text{m}$, $11.6 \pm 1.1 \text{ ft}\cdot\text{lb}$)

- 5) Remove ST.

ST 499747100 CLUTCH DISC GUIDE


1. Clutch Trouble in General

Condition	Possible cause and testing	Corrective action
1. Clutch slip-page	It is hard to perceive clutch slippage in the early stage, but pay attention to the following symptoms.	
	(a) Engine revs up when shifting. (b) High speed driving is impossible; especially rapid acceleration impossible and vehicle speed does not increase in proportion to an increase in engine speed. (c) Power falls, particularly when ascending a slope, and there is a smell of burning of the clutch facing. ● Method of testing: Put the vehicle in stationary condition with parking brake fully applied. Disengage the clutch and shift the transmission gear into the first. Gradually allow the clutch to engage while gradually increasing the engine speed. The clutch function is satisfactory if the engine stalls. However, the clutch is slipping if the vehicle does not start off and the engine does not stall.	
2. Clutch drags.	(a) No clutch pedal play	Readjust.
	(b) No release lever end play	Readjust.
	(c) Clutch facing smeared by oil	Replace.
	(d) Worn clutch facing	Replace.
	(e) Deteriorated diaphragm spring	Replace.
	(f) Distorted pressure plate or flywheel	Correct or replace.
	(g) Defective release bearing holder	Correct or replace.
	(h) Defective pedal and cable system	Correct or replace.
2. Clutch drags.	As a symptom of this trouble, a harsh scratching noise develops and control becomes quite difficult when shifting gears. The symptom becomes more apparent when shifting into the first gear. However, because much trouble of this sort is due to defective synchronization mechanism, carry out the test as described after.	
	● Method of testing: Refer to DIAGNOSTIC DIAGRAM on page after.	
	It may be judged as insufficient disengagement of clutch if any noise occurs during this test.	
	(a) Excessive clutch pedal play	Readjust.
	(b) Excessive clutch release lever play	Readjust.
	(c) Worn or rusty clutch disc hub spline	Replace clutch disc.
	(d) Excessive deflection of clutch disc facing	Correct or replace.
	(e) Seized crankshaft pilot needle bearing	Replace.
	(f) Malfunction of pedal and cable system	Correct or replace.
	(g) Cracked clutch disc facing	Replace.
	(h) Sticked clutch disc (smeared by oil or water)	Replace.
3. Clutch chatters.	Clutch chattering is an unpleasant vibration to the whole body when the vehicle is just started with clutch partially engaged.	
	(a) Improper clutch cable routing	Correct.
	(b) Adhesion of oil on the facing	Replace clutch disc.
	(c) Weak or broken torsion spring	Replace clutch disc.
	(d) Defective facing contact or excessive disc	Replace clutch disc defection.
	(e) Warped pressure plate or flywheel	Correct or replace.
	(f) Loose disc rivets	Replace clutch disc.
	(g) Loose engine mounting	Retighten or replace mounting.
	(h) Improper adjustment of pitching stopper	Adjustment.

1. Clutch Trouble in General

Condition	Possible cause and testing	Corrective action
4. Noisy clutch	Examine whether the noise is generated when the clutch is disengaged, engaged, or partially engaged.	
	(a) Broken, worn or unlubricated release bearing	Replace release bearing.
	(b) Insufficient lubrication of pilot bearing	Apply grease.
	(c) Loose clutch disc hub	Replace clutch disc.
	(d) Loose torsion spring retainer	Replace clutch disc.
	(e) Deteriorated or broken torsion spring	Replace clutch disc.
5. Clutch grabs.	When starting the vehicle with the clutch partially engaged, the clutch engages suddenly and the vehicle jumps instead of making a smooth start.	
	(a) Grease or oil on facing	Replace clutch disc.
	(b) Deteriorated cushioning spring	Replace clutch disc.
	(c) Worn or rusted spline of clutch disc or main	Take off rust, apply grease or replace clutch shaft disc or mainshaft.
	(d) Deteriorated or broken torsion spring	Replace clutch disc.
	(e) Loose engine mounting	Retighten or replace mounting.
	(f) Deteriorated diaphragm spring	Replace.

A: DIAGNOSTIC DIAGRAM OF CLUTCH DRAG




EMISSION CONTROL SYSTEM AND VACUUM FITTING

2-1

	Page
W SERVICE PROCEDURE	2
1. Front Catalytic Converter	2
2. Rear Catalytic Converter	5
3. Canister	8
4. Purge Control Solenoid Valve	9
5. EGR Valve [AT Vehicles]	9
6. Back-Pressure Transducer (BPT) [AT Vehicles]	10
7. EGR Solenoid Valve [AT Vehicles]	10
8. Fuel Temperature Sensor	10
9. Fuel Tank Pressure Sensor	14
10. Pressure Control Solenoid Valve	16
11. Vent Control Solenoid Valve	16
12. Fuel Level Sensor	18
13. Air Filter	22


1. Front Catalytic Converter



1. Front Catalytic Converter

A: REMOVAL

1) Remove air intake duct. <Ref. to 2-7 [W1A0].>




2) Disconnect front oxygen sensor connector.

3) Lift-up the vehicle.

4) Apply SUBARU CRC or its equivalent to threaded portion of front oxygen sensor, and leave it for one minute or more.


SUBARU CRC (Part No. 004301003)




5) Remove front oxygen sensor.

CAUTION:


When removing oxygen sensor, do not force oxygen sensor especially when exhaust pipe is cold, otherwise it will damage exhaust pipe.




6) Disconnect rear oxygen sensor connector.



7) Separate center exhaust pipe from rear exhaust pipe.




8) Remove bolts which hold front exhaust pipe onto cylinder heads.




9) Remove front exhaust pipe and center exhaust pipe from hanger bracket.

CAUTION:

Be careful not to pull down front exhaust pipe and center exhaust pipe.



10) Separate front catalytic converter from front exhaust pipe and center exhaust pipe.



B: INSTALLATION

CAUTION:


Replace gaskets with new ones.

1) Install front catalytic converter to front exhaust pipe and center exhaust pipe.


Tightening torque:

30 ± 5 N·m (3.1 ± 0.5 kg·m, 22.4 ± 3.6 ft·lb)

1. Front Catalytic Converter




- 2) Install front exhaust pipe and center exhaust pipe. And temporarily tighten bolt which installs center exhaust pipe to hanger bracket.



- 3) Tighten bolts which hold front exhaust pipe onto cylinder heads.

Tightening torque:


30 ± 5 N·m (3.1 ± 0.5 kg·m, 22.4 ± 3.6 ft·lb)



- 4) Install center exhaust pipe to rear exhaust pipe.

Tightening torque:


18 ± 5 N·m (1.8 ± 0.5 kg·m, 13.0 ± 3.6 ft·lb)




- 5) Tighten bolt which holds center exhaust pipe to hanger bracket.

Tightening torque:

35 ± 5 N·m (3.6 ± 0.5 kg·m, 26.0 ± 3.6 ft·lb)



- 6) Connect rear oxygen sensor connector.




7) Before installing front oxygen sensor, apply anti-seize compound only to threaded portion of front oxygen sensor to make the next removal easier.

Anti-seize compound:

SS-30 by JET LUBE

CAUTION:


Never apply anti-seize compound to protector of front oxygen sensor.



8) Install front oxygen sensor.


Tightening torque:

21±3 N·m (2.1±0.3 kg-m, 15.2±2.2 ft-lb)




9) Lower the vehicle.

10) Connect front oxygen sensor connector.



11) Install air intake duct.



2. Rear Catalytic Converter


A: REMOVAL

1) Lift-up the vehicle.

2) Disconnect rear oxygen sensor connector.

3) Apply SUBARU CRC or its equivalent to threaded portion of rear oxygen sensor, and leave it for one minute or more.


SUBARU CRC (Part No. 004301003)




4) Remove rear oxygen sensor.

CAUTION:


When removing rear oxygen sensor, do not force rear oxygen sensor especially when exhaust pipe is cold, otherwise it will damage exhaust pipe.



5) Separate center exhaust pipe and rear catalytic converter assembly from rear exhaust pipe.




6) Separate center exhaust pipe and rear catalytic converter assembly from front catalytic converter.



7) Remove center exhaust pipe and rear catalytic converter assembly from hanger bracket.

CAUTION:


- Be careful not to pull down center exhaust pipe.
- After removing center exhaust pipe, do not apply excessive pulling force on front catalytic converter and front exhaust pipe.

**B: INSTALLATION****CAUTION:**

Replace gaskets with new ones.

1) Install center exhaust pipe and rear catalytic converter assembly.


Temporarily tighten bolt which installs center exhaust pipe to hanger bracket.



2) Install center exhaust pipe to front catalytic converter.

Tightening torque:


35 ± 5 N·m (3.6 ± 0.5 kg·m, 26.0 ± 3.6 ft·lb)



3) Install center exhaust pipe to rear exhaust pipe.

Tightening torque:


18 ± 5 N·m (1.8 ± 0.5 kg·m, 13.0 ± 3.6 ft·lb)



4) Tighten bolt which holds center exhaust pipe to hanger bracket.

Tightening torque:

35 ± 5 N·m (3.6 ± 0.5 kg·m, 26.0 ± 3.6 ft·lb)




5) Before installing rear oxygen sensor, apply anti-seize compound only to threaded portion of rear oxygen sensor to make the next removal easier.

Anti-seize compound:

SS-30 by JET LUBE

CAUTION:


Never apply anti-seize compound to protector of rear oxygen sensor.



6) Install rear oxygen sensor.


Tightening torque:

$21 \pm 3 \text{ N}\cdot\text{m}$ ($2.1 \pm 0.3 \text{ kg}\cdot\text{m}$, $15.2 \pm 2.2 \text{ ft}\cdot\text{lb}$)



7) Connect rear oxygen sensor connector.

8) Lower the vehicle.




3. Canister


A: REMOVAL AND INSTALLATION

1) Lift-up the vehicle.

2) Disconnect evaporation hoses from canister.



3) Remove canister from body.




4) Installation is in the reverse order of removal.

Tightening torque:

$T1: 22.5 \pm 7 \text{ N}\cdot\text{m}$ ($2.3 \pm 0.7 \text{ kg}\cdot\text{m}$, $16.6 \pm 5.1 \text{ ft}\cdot\text{lb}$)

$T2: 24.5 \pm 7 \text{ N}\cdot\text{m}$ ($2.5 \pm 0.7 \text{ kg}\cdot\text{m}$, $18.1 \pm 5.1 \text{ ft}\cdot\text{lb}$)




4. Purge Control Solenoid Valve

A: REMOVAL AND INSTALLATION

1. 1800 cc MODEL

- 1) Disconnect connector from FICD solenoid valve.
- 2) Remove bolts which install FICD solenoid valve to intake manifold.



- 3) Disconnect connector from purge control solenoid valve.
- 4) Disconnect vacuum hoses from purge control solenoid valve.
- 5) Remove bolt which installs purge control solenoid valve to intake manifold.
- 6) Take out purge control solenoid valve.
- 7) Installation is in the reverse order of removal.

Tightening torque:



$16 \pm 1.5 \text{ N} \cdot \text{m}$ ($1.6 \pm 0.15 \text{ kg} \cdot \text{m}$, $11.6 \pm 1.1 \text{ ft} \cdot \text{lb}$)

2. 2200 cc MODEL

- 1) Disconnect connector from purge control solenoid valve.
- 2) Disconnect vacuum hoses from purge control solenoid valve.
- 3) Remove bolt which installs purge control solenoid valve to intake manifold.
- 4) Take out purge control solenoid valve.
- 5) Installation is in the reverse order of removal.

Tightening torque:

$16 \pm 1.5 \text{ N} \cdot \text{m}$ ($1.6 \pm 0.15 \text{ kg} \cdot \text{m}$, $11.6 \pm 1.1 \text{ ft} \cdot \text{lb}$)



5. EGR Valve [AT Vehicles]

A: REMOVAL AND INSTALLATION

- 1) Disconnect vacuum hose from EGR valve.
- 2) Remove bolts which install EGR valve onto intake manifold.


3) Installation is in the reverse order of removal.

CAUTION:

Replace gasket with a new one.

Tightening torque:


19 ± 1 N·m (1.9 ± 0.1 kg-m, 13.7 ± 0.7 ft-lb)



6. Back-Pressure Transducer (BPT) [AT Vehicles]

A: REMOVAL AND INSTALLATION

- 1) Disconnect vacuum hoses from BPT.
- 2) Remove BPT from bracket.
- 3) Installation is in the reverse order of removal.




7. EGR Solenoid Valve [AT Vehicles]

A: REMOVAL AND INSTALLATION

- 1) Disconnect connector from EGR solenoid valve.
- 2) Disconnect vacuum hoses from EGR solenoid valve.
- 3) Remove bolt which installs EGR solenoid valve.
- 4) Take out EGR solenoid valve.
- 5) Installation is in the reverse order of removal.

Tightening torque:

16 ± 1.5 N·m (1.6 ± 0.15 kg-m, 11.6 ± 1.1 ft-lb)




8. Fuel Temperature Sensor

A: REMOVAL


1. 1800 cc MODEL

- 1) Disconnect battery ground cable.




2) Release fuel pressure. <Ref. to 2-8 [W1B0].>


- 3) Disconnect fuel delivery hose ① and return hose ②.




4) Remove nuts which install fuel pump assembly onto fuel tank.




5) Take off fuel pump from fuel tank.




6) Remove two screws fixing terminals on fuel pump assembly.




7) Disconnect connector from fuel pump.



8) Remove fuel temperature sensor from fuel pump assembly.


**2. 2200 cc MODEL**

1) Disconnect battery ground cable.




2) Release fuel pressure. <Ref. to 2-8 [W1B0].>


3) Disconnect fuel delivery hose ①, return hose ② and jet pump hose ③.




4) Remove nuts which install fuel pump assembly onto fuel tank.




5) Take off fuel pump from fuel tank.




6) Remove two screws fixing terminals on fuel pump assembly.



7) Disconnect connector from fuel pump.



8) Remove fuel temperature sensor from fuel pump assembly.



B: INSTALLATION

1. 1800 cc MODEL

CAUTION:


Leave fuel filler cap open when tightening nuts, to prevent fuel from flowing out through fuel delivery and return pipes. Close fuel filler cap after tightening nuts.

Installation is in the reverse order of removal. Do the following:

- Always use new gaskets.
- Ensure sealing portion is free from fuel or foreign particles before installation.
- Tighten nuts in alphabetical sequence shown in Figure to specified torque.

Tightening torque:

$4.4 \pm 1.5 \text{ N}\cdot\text{m}$ ($0.45 \pm 0.15 \text{ kg}\cdot\text{m}$, $3.3 \pm 1.1 \text{ ft}\cdot\text{lb}$)



2. 2200 cc MODEL

CAUTION:


Leave fuel filler cap open when tightening nuts, to prevent fuel from flowing out through fuel delivery and return pipes. Close fuel filler cap after tightening nuts.

Installation is in the reverse order of removal. Do the following:

- Always use new gaskets.
- Ensure sealing portion is free from fuel or foreign particles before installation.
- Tighten nuts in alphabetical sequence shown in Figure to specified torque.

Tightening torque:


$4.4 \pm 1.5 \text{ N} \cdot \text{m}$ ($0.45 \pm 0.15 \text{ kg} \cdot \text{m}$, $3.3 \pm 1.1 \text{ ft} \cdot \text{lb}$)



9. Fuel Tank Pressure Sensor

A: REMOVAL AND INSTALLATION


1) Disconnect battery ground cable.



2) Remove trims.


- 4 door model:

Remove right trunk side trim.




- Wagon model:

Remove right rear quarter lower trim. <Ref. to 5-3 [W5A4].>




3) Remove bolts which install fuel tank pressure sensor bracket on body.

4) Disconnect hose from connection pipe.




5) Disconnect connector from fuel tank pressure sensor.

6) Remove fuel tank pressure sensor assembly from bracket.




7) Remove fuel tank pressure sensor from bracket.



8) Installation is in the reverse order of removal.


Tightening torque:

$7.35 \pm 1.96 \text{ N} \cdot \text{m}$ ($0.75 \pm 0.20 \text{ kg} \cdot \text{m}$, $5.4 \pm 1.4 \text{ ft} \cdot \text{lb}$)



Tightening torque:


$7.35 \pm 1.96 \text{ N} \cdot \text{m}$ ($0.75 \pm 0.20 \text{ kg} \cdot \text{m}$, $5.4 \pm 1.4 \text{ ft} \cdot \text{lb}$)




10. Pressure Control Solenoid Valve

A: REMOVAL AND INSTALLATION


- 1) Disconnect battery ground cable.
- 2) Lift-up the vehicle.




- 3) Disconnect evaporation hoses from pressure control valve.
- 4) Disconnect connector from pressure control valve.



- 5) Remove pressure control valve with bracket.




- 6) Remove pressure control valve from bracket.
- 7) Installation is in the reverse order of removal.




11. Vent Control Solenoid Valve

A: REMOVAL


- 1) Disconnect battery ground cable.




- 2) Lift-up the vehicle.
- 3) Remove canister. <Ref. to 2-1 [W3A0].>
- 4) Disconnect connector from vent control solenoid valve.




- 5) Remove one bolt fixing bracket on the body.



- 6) Remove one vacuum hose from vent control solenoid valve.




- 7) Remove one bolt fixing vent control solenoid valve on bracket.
- 8) Remove vent control solenoid valve.




B: INSTALLATION

- 1) Install the bolt fixing vent control solenoid valve on bracket.




2) Install the vacuum hose to vent control solenoid valve.



3) Install the bolt fixing bracket on the body.

Tightening torque:


25 ± 7 N·m (2.5 ± 0.7 kg·m, 18.1 ± 5.1 ft·lb)




4) Connect connector to vent control solenoid valve.

5) Install canister. <Ref. to 2-1 [W3A0].>

6) Lower the vehicle.



7) Connect battery ground cable.




12. Fuel Level Sensor


A: REMOVAL

1. 1800 cc MODEL


1) Disconnect battery ground cable.




- 2) Release fuel pressure. <Ref. to 2-8 [W1B0].>
- 3) Disconnect fuel delivery hose (A) and return hose (B).




- 4) Remove nuts which install fuel pump assembly onto fuel tank.




- 5) Take off fuel pump from fuel tank.




- 6) Disconnect connector from fuel pump.



- 7) Remove two screws fixing bracket on fuel pump assembly.




- 8) Remove one screw fixing fuel level sensor on bracket.
- 9) Remove fuel level sensor from fuel pump assembly.




2. 2200 cc MODEL


- 1) Disconnect battery ground cable.




- 2) Release fuel pressure. <Ref. to 2-8 [W1B0].>
- 3) Disconnect fuel delivery hose (A) and return hose (B).




- 4) Remove nuts which install fuel pump assembly onto fuel tank.




- 5) Take off fuel pump from fuel tank.



6) Disconnect connector from fuel pump.




7) Remove two screws fixing bracket on fuel pump assembly.



8) Remove one screw fixing fuel level sensor on bracket.

9) Remove fuel level sensor from fuel pump assembly.



B: INSTALLATION

1. 1800 cc MODEL

CAUTION:


Leave fuel filler cap open when tightening nuts, to prevent fuel from flowing out through fuel delivery and return pipes. Close fuel filler cap after tightening nuts.

Installation is in the reverse order of removal. Do the following:

- Always use new gaskets.
- Ensure sealing portion is free from fuel or foreign particles before installation.
- Tighten nuts in alphabetical sequence shown in Figure to specified torque.

Tightening torque:

$4.4 \pm 1.5 \text{ N}\cdot\text{m}$ ($0.45 \pm 0.15 \text{ kg}\cdot\text{m}$, $3.3 \pm 1.1 \text{ ft}\cdot\text{lb}$)



2. 2200 cc MODEL

CAUTION:


Leave fuel filler cap open when tightening nuts, to prevent fuel from flowing out through fuel delivery and return pipes. Close fuel filler cap after tightening nuts.

Installation is in the reverse order of removal. Do the following:

- Always use new gaskets.
- Ensure sealing portion is free from fuel or foreign particles before installation.
- Tighten nuts in alphabetical sequence shown in Figure to specified torque.

Tightening torque:


$4.4 \pm 1.5 \text{ N}\cdot\text{m}$ ($0.45 \pm 0.15 \text{ kg}\cdot\text{m}$, $3.3 \pm 1.1 \text{ ft}\cdot\text{lb}$)



13. Air Filter

A: REMOVAL AND INSTALLATION

- 1) Remove canister. <Ref. to 2-1 [W3A0].>
- 2) Remove two hoses from air filter.




- 3) Remove flange nut from bracket.
- 4) Installation is in the reverse order of removal.

ENGINE AND TRANSMISSION MOUNTING SYSTEM

2-11

	Page
C COMPONENT PARTS	2
1. Engine Mounting	2
2. Transmission Mounting	3
W SERVICE PROCEDURE	5
1. Engine	5
2. Transmission	25

1. Engine Mounting



G2M0258

- ① Front cushion rubber
- ② Front engine mounting bracket

Tightening torque: N·m (kg·m, ft·lb)


T1: 26±7 (2.7±0.7, 19.5±5.1)

T2: 41±10 (4.2±1.0, 30±7)

T3: 69±15 (7.0±1.5, 51±11)

2. Transmission Mounting

A: MT MODEL



- ① Pitching stopper
- ② Rear cushion rubber
- ③ Rear crossmember
- ④ Stopper

Tightening torque: N·m (kg·m, ft·lb)

T1: 33±5 (3.4±0.5, 24.6±3.6)


T2: 37±10 (3.8±1.0, 27±7)

T3: 49±5 (5.0±0.5, 36.2±3.6)

T4: 57±10 (5.8±1.0, 42±7)

T5: 69±15 (7.0±1.5, 51±11)

B: AT MODEL



- ① Pitching stopper
- ② Rear cushion rubber
- ③ Stopper
- ④ Crossmember

Tightening torque: N·m (kg·m, ft·lb)**T1: 25±7 (2.5±0.7, 18.1±5.1)****T2: 37±10 (3.8±1.0, 27±7)****T3: 49±5 (5.0±0.5, 36.2±3.6)****T4: 57±10 (5.8±1.0, 42±7)****T5: 69±15 (7.0±1.5, 51±11)**

1. Engine

A: GENERAL PRECAUTION

- 1) Remove or install engine in an area where chain hoists, lifting devices, etc. are available for ready use.
- 2) Be sure not to damage coated surfaces of body panels with tools or stain seats and windows with coolant or oil. Place a cover over fenders, as required, for protection.
- 3) Prior to starting work, prepare the following:
Service tools, clean cloth, containers to catch coolant and oil, wire ropes, chain hoist, transmission jacks, etc.
- 4) Lift-up or lower the vehicle when necessary. Make sure to support the correct positions. <Ref. to 1-3 [0700].>

B: REMOVAL

1. Set the vehicle on lift arms.
2. Open front hood and support with a stay.



3. Release fuel pressure.
4. Disconnect battery cable and remove battery from vehicle.
5. Drain coolant.



6. Remove cooling system.

**A/C equipped model**

7. Collect refrigerant, and remove pressure hose.



8. Remove air intake system.



9. Remove canister and bracket. (2200 cc)



10. Disconnect connectors, cables and hoses.



11. Remove power steering pump from bracket.



12. Remove front exhaust pipe and center exhaust pipe.



13. Remove nuts which hold lower side of transmission to engine.
14. Remove nuts which install front cushion rubber onto front crossmember.

**AT model**

15. Separate torque converter from drive plate.



16. Remove pitching stopper and bracket.



17. Disconnect fuel delivery hose, return hose and evaporation hose.



18. Support engine with a lifting device and wire ropes.
19. Support transmission with a garage jack.




20. Remove bolts which hold upper side of transmission to engine.




21. Remove engine from vehicle.

- 1) Set the vehicle on lift arms.
- 2) Open front hood fully and support with stay.




- 3) Release fuel pressure.
 - (1) Disconnect fuel pump connector.
 - (2) Start the engine, and run until it stalls.
 - (3) After the engine stalls, crank it for five seconds more.
 - (4) Turn ignition switch to "OFF".


<Ref. to 2-8 [W1B0].>




- 4) Disconnect battery cables and remove battery from vehicle.




- 5) Drain coolant.
Set container under the vehicle, and remove drain cock from radiator.




- 6) Remove cooling system.
 - (1) Disconnect radiator fan motor connector.




- (2) Disconnect radiator outlet hose from thermostat cover.
- (3) Disconnect ATF cooler hoses from pipes. (AT model)



- (4) Remove V-belt cover.




- (5) Disconnect radiator inlet hose from radiator.




- (6) Remove radiator upper bracket, and remove radiator assembly from vehicle.

7) Collect refrigerant, and remove pressure hoses. (With A/C)

- (1) Place and connect the attachment hose to the refrigerant recycle system.
- (2) Collect refrigerant from A/C system.




(3) Disconnect A/C pressure hoses from A/C compressor.




8) Remove air intake system.

- (1) Disconnect connector from mass air flow sensor.
- (2) Remove air intake duct with air cleaner upper cover, and remove air cleaner element.




9) Remove canister and bracket. (2200 cc model)


- 10) Disconnect connectors, cables and hoses.
- (1) Disconnect the following connectors.
- ① FICD solenoid valve (With A/C 1800 cc)
 - ② Front oxygen sensor connector
 - ③ Engine harness connectors
 - ④ Engine ground terminal stay
 - ⑤ Alternator connector and terminal
 - ⑥ A/C compressor connectors (With A/C)




H2M1550A




G2M0275




H2M1553A



H2M1551A






H2M1554A



H2M1552A




SUBARU.


- (2) Disconnect the following cables.
- ① Clutch release spring (MT model)
 - ② Clutch cable (MT model)
 - ③ Accelerator cable
 - ④ Cruise control cable (With cruise control)




(3) Disconnect the following hoses.

- ① Brake booster vacuum hose
- ② Heater inlet and outlet hoses







- 11) Remove power steering pump from bracket.
(1) Loosen lock bolt and slider bolt, and remove front side V-belt.




- (2) Remove pipe with bracket from intake manifold.




- (3) Remove bolts which install power steering pump from bracket.




- (4) Place power steering pump on the right side wheel apron.




- 12) Remove front exhaust pipe and center exhaust pipe.
(1) Lift-up the vehicle.
(2) Remove nuts which install front exhaust pipe onto engine.



(3) Disconnect connector from rear oxygen sensor.



(4) Separate center exhaust pipe from rear exhaust pipe.




(5) Remove bolt which installs center exhaust pipe on hunger bracket.


(6) Take off front and center exhaust pipes.

CAUTION:


Exhaust pipe will drop when all bolts are removed. So, hold it when removing the last bolt.



13) Remove nuts which hold lower side of transmission to engine.




14) Remove nuts which install front cushion rubber onto front crossmember.




- 15) Separate torque converter from drive plate. (AT model)
- (1) Lower the vehicle.
 - (2) Remove service hole plug.
 - (3) Remove bolts which hold torque converter to drive plate.
 - (4) Remove other bolts while rotating the engine using ST.

ST 499977000 CRANK PULLEY WRENCH




- 16) Remove pitching stopper.




- 17) Disconnect fuel delivery hose, return hose and evaporation hose.

CAUTION:

- Disconnect hose with its end wrapped with cloth to prevent fuel from splashing.
- Catch fuel from hose into container.




- 18) Support engine with a lifting device and wire ropes.




- 19) Support transmission with a garage jack.

CAUTION:

Before moving engine away from transmission, check to be sure no work has been overlooked. Doing this is very important in order to facilitate re-installation and because transmission lowers under its own weight.



20) Remove bolts which holds upper side of transmission to engine.





21) Remove engine from vehicle.

- (1) Slightly raise engine.
- (2) Raise transmission with garage jack.
- (3) Move engine horizontally until mainshaft is withdrawn from clutch cover.
- (4) Slowly move engine away from engine compartment.

CAUTION:

Be careful not to damage adjacent parts or body panels with crank pulley, oil pressure gauge, etc.

C: INSTALLATION




- 1) Install engine onto transmission.
 - (1) Position engine in engine compartment and align it with transmission.

CAUTION:

Be careful not to damage adjacent parts or body panels with crank pulley, oil pressure gauge, etc.


- (2) Apply a small amount of grease to splines of mainshaft.




- 2) Tighten bolts which hold upper side of transmission to engine.

Tightening torque:

$50 \pm 4 \text{ N}\cdot\text{m}$ ($5.1 \pm 0.4 \text{ kg}\cdot\text{m}$, $36.9 \pm 2.9 \text{ ft}\cdot\text{lb}$)



- 3) Remove lifting device and wire ropes.
- 4) Remove garage jack.




5) Install pitching stopper.

Tightening torque:

T1: 49 ± 5 N·m (5.0 ± 0.5 kg-m, 36.2 ± 3.6 ft-lb)

T2: 57 ± 10 N·m (5.8 ± 1.0 kg-m, 42 ± 7 ft-lb)



6) Install torque converter onto drive plate. (AT model)

(1) Tighten bolts which hold torque converter to drive plate.

(2) Tighten other bolts while rotating the engine by using ST.

ST 499977000 CRANK PULLEY WRENCH


CAUTION:

Be careful not to drop bolts into torque converter housing.


Tightening torque:

25 ± 2 N·m (2.5 ± 0.2 kg-m, 18.1 ± 1.4 ft-lb)

(3) Clog plug onto service hole.



7) Install canister and bracket. (2200 cc model)




8) Install power steering pump on bracket.


(1) Install power steering pump on bracket, and tighten bolts.

Tightening torque:


39 ± 10 N·m (4.0 ± 1.0 kg-m, 29 ± 7 ft-lb)



(2) Install power steering pipe bracket on right side intake manifold, and install spark plug codes.




(3) Install front side V-belt, and adjust it.
<Ref. to 1-5 [0200].>



9) Tighten nuts which hold lower side of transmission to engine.

Tightening torque:

$50 \pm 4 \text{ N}\cdot\text{m}$ ($5.1 \pm 0.4 \text{ kg}\cdot\text{m}$, $36.9 \pm 2.9 \text{ ft}\cdot\text{lb}$)



10) Tighten nuts which install front cushion rubber onto crossmember.

Tightening torque:

$69 \pm 15 \text{ N}\cdot\text{m}$ ($7.0 \pm 1.5 \text{ kg}\cdot\text{m}$, $51 \pm 11 \text{ ft}\cdot\text{lb}$)


CAUTION:

Be sure to tighten front cushion rubber mounting bolts in the innermost elliptical hole in the front crossmember.


- 11) Install front exhaust pipe and center exhaust pipe.
- 12) Connect hoses, connectors and cables.
 - (1) Connect the following hoses.
 - Fuel delivery hose, return hose and evaporation hose
 - Heater inlet and outlet hoses
 - Brake booster vacuum hose
 - Canister hoses (2200 cc)
 - (2) Connect the following connectors.
 - Engine ground terminal
 - Engine harness connectors
 - Front and rear oxygen sensor connector
 - Cam angle sensor connector
 - Crank angle sensor connector
 - Alternator connector and terminal
 - A/C compressor connectors (With A/C)
 - (3) Connect the following cables.
 - Accelerator cable
 - Cruise control cables (With cruise control)
 - Clutch cable
 - Clutch release spring

CAUTION:


After connecting each cable, adjust them.



- 13) Install air intake system.
 - (1) Install air cleaner element.
 - (2) Install air intake duct with air cleaner upper cover.




- (3) Connect connector to mass air flow sensor.



14) Install A/C flexible hoses. (With A/C)
<Ref. to 4-7 [W16A0].>


CAUTION:
Use new O-rings.

Tightening torque:
 $25 \pm 7 \text{ N}\cdot\text{m}$ ($2.5 \pm 0.7 \text{ kg}\cdot\text{m}$, $18.1 \pm 5.1 \text{ ft}\cdot\text{lb}$)




15) Install cooling system.


(1) Attach radiator mounting cushions to pins on lower side of radiator.




(2) Fit cushions on lower side of radiator, into holes on body side and install radiator.




(3) Install radiator brackets and tighten bolts.
Tightening torque:
 $13.7 \pm 1.5 \text{ N}\cdot\text{m}$ ($1.4 \pm 0.15 \text{ kg}\cdot\text{m}$, $10.1 \pm 1.1 \text{ ft}\cdot\text{lb}$)



(4) Connect radiator fan motor connector.




(5) Connect radiator inlet hose.



(6) Connect radiator outlet hose.

(7) Connect ATF cooler hoses. (AT model)



(8) Install V-belt cover.

16) Install battery in the vehicle, and connect cables.

17) Fill coolant.

<Ref. to 1-5 [0600].>

18) Check ATF level and correct if necessary. (AT model)

<Ref. to 3-2 [W1B1].>

19) Charge A/C system with refrigerant.

<Ref. to 4-7 [W700].>

20) Remove front hood stay, and close front hood.

21) Remove the vehicle from lift arms.

2. Transmission

A: GENERAL PRECAUTION

- 1) Remove or install transmission in an area where chain hoists, lifting devices, etc. are available for ready use.
- 2) Be sure not to damage coated surfaces of body panels with tools or stain seats and windows with coolant or oil. Place a cover over fenders, as required, for protection.
- 3) Prior to starting work, prepare the following:
Service tools, clean cloth, containers to catch coolant and oil, wire ropes, chain hoist, transmission jacks, etc.
- 4) Lift-up or lower the vehicle when necessary. Make sure to support the correct positions. <Ref. to 1-3 [0700].>

B: REMOVAL

1. Open front hood fully, and support it with stay.
2. Disconnect battery ground terminal.



3. Remove air intake duct and chamber.



4. Disconnect connectors and cables.



5. Remove starter.



6. Remove pitching stopper and bracket.

**AT model**

7. Separate torque converter from drive plate.
8. Remove ATF level gauge.



9. Remove transmission connector bracket.



10. Set special tools.



11. Remove bolt which holds right upper side of transmission to engine.



12. Remove exhaust system.

- Front exhaust pipe
- Center exhaust pipe
- Rear exhaust pipe
- Heat shield cover

**AT model**


13. Drain ATF to remove drain plug.
14. Disconnect ATF cooler hose from pipe on transmission side, and remove ATF supply pipe.




15. Remove propeller shaft.




Ⓐ




- 1) Open front hood fully, and support with stay.
- 2) Disconnect battery ground terminal.




- 3) Remove air intake duct and chamber.




- 4) Disconnect connectors and cables.
 - (1) Disconnect the following connectors.
 - Front oxygen sensor connector




- Transmission harness connector
- Transmission ground terminal




- (2) Disconnect the following cables.
 - Clutch release spring
 - Clutch cable
 - Hill holder cable




- Speedometer cable



- 5) Remove starter.
 - (1) Disconnect connectors and terminal from starter.
 - (2) Remove bolt which installs upper side of starter.
 - (3) Remove nut which installs lower side of starter, and remove starter from transmission.




- 6) Remove pitching stopper.



- 7) Separate torque converter from drive plate. (AT model)
 - (1) Remove service hole plug.
 - (2) Remove bolts which hold torque converter to drive plate.
 - (3) While rotating the engine, remove other bolts using ST.


ST 499977000 CRANK PULLEY WRENCH

CAUTION:
Be careful not to drop bolts into torque converter housing.




- 8) Remove ATF level gauge. (AT model)

CAUTION:
Plug opening to prevent entry of foreign particles into transmission fluid.



9) Remove transmission connector holder bracket.




10) Set special tool.


ST 41099AA000 ENGINE SUPPORT ASSY

NOTE:

Also available is Part No. 927670000.




11) Remove bolt which holds right upper side of transmission to engine.




12) Remove exhaust system.

(1) Lift-up the vehicle.


(2) Remove nuts which install front exhaust pipe onto engine.




(3) Disconnect connector from rear oxygen sensor.



(4) Separate center exhaust pipe from rear exhaust pipe.




(5) Remove bolt which installs center exhaust pipe to hanger bracket then take off front and center exhaust pipes.




(6) Remove rear exhaust pipe.

CAUTION:


When removing exhaust pipes, be careful each exhaust pipe does not drop out.



(7) Remove heat shield cover of rear exhaust pipe.




(8) Remove hanger bracket from right side of transmission.




13) Drain ATF to remove drain plug. (AT model)

- ① Front differential oil drain plug
- ② ATF drain plug




14) Disconnect ATF cooler hoses from pipes of transmission side and remove ATF level gauge guide. (AT model)



15) Remove propeller shaft.


- (1) Remove front cover of rear differential mount.
- (2) Separate propeller shaft from rear differential.



(3) Remove bolts which hold center bearing onto body.

CAUTION:


Be careful not to drop propeller shaft.



(4) Remove propeller shaft from transmission.


CAUTION:

- Be sure to use an empty container to catch oil flowing out when removing propeller shaft.
- Be sure not to damage oil seals and the frictional surface of sleeve yoke.
- Be sure to plug the opening in transmission after removal of propeller shaft.




16) Remove gear shift rod and stay from transmission. (MT model)

- (1) Remove spring.
- (2) Disconnect stay from transmission.
- (3) Disconnect rod from transmission.




17) Remove shift selector cable. (AT model)

- (1) Disconnect shift selector cable from selector lever.
- (2) Remove cable bracket from selector lever assembly.




18) Remove bolts which install stabilizer clamp onto crossmember.



19) Remove front drive shaft from transmission.


- (1) Remove transverse link from housing.
- (2) Lower transverse link.




(3) Remove spring pin and separate front drive shaft from each side of the transmission.

CAUTION:

Discard removing spring pin. Replace with a new one.




20) Remove nuts which hold lower side of transmission to engine.



21) Place transmission jack under transmission.


CAUTION:

- Always support transmission case with a transmission jack.
- On AT model, make sure that the support plates of transmission jack do not touch the oil pan.




22) Remove transmission rear crossmember.

- MT model




- AT model





23) Remove transmission.

CAUTION:

- Move transmission jack toward rear until mainshaft is withdrawn from clutch cover. (MT model)
- Move transmission and torque converter as a unit away from engine. (AT model)

C: INSTALLATION






- 1) Install transmission onto engine.
 - (1) Gradually raise transmission with transmission jack.
 - (2) Engage them at splines.

CAUTION:

Be careful not to strike mainshaft against clutch cover. (MT model)



- 2) Install transmission rear crossmember.


● MT model

Tightening torque:

T1: $24.5 \pm 1.5 \text{ N}\cdot\text{m}$ ($2.50 \pm 0.153 \text{ kg}\cdot\text{m}$, $18.07 \pm 1.11 \text{ ft}\cdot\text{lb}$)

T2: $37 \pm 10 \text{ N}\cdot\text{m}$ ($3.8 \pm 1.0 \text{ kg}\cdot\text{m}$, $27 \pm 7 \text{ ft}\cdot\text{lb}$)

T3: $69 \pm 15 \text{ N}\cdot\text{m}$ ($7.0 \pm 1.5 \text{ kg}\cdot\text{m}$, $51 \pm 11 \text{ ft}\cdot\text{lb}$)




● AT model

Tightening torque:

T1: $37 \pm 10 \text{ N}\cdot\text{m}$ ($3.8 \pm 1.0 \text{ kg}\cdot\text{m}$, $27 \pm 7 \text{ ft}\cdot\text{lb}$)


T2: $69 \pm 15 \text{ N}\cdot\text{m}$ ($7.0 \pm 1.5 \text{ kg}\cdot\text{m}$, $51 \pm 11 \text{ ft}\cdot\text{lb}$)



- 3) Take off transmission jack.
- 4) Tighten nuts which hold lower side of transmission to engine.

Tightening torque:

$50 \pm 4 \text{ N}\cdot\text{m}$ ($5.1 \pm 0.4 \text{ kg}\cdot\text{m}$, $36.9 \pm 2.9 \text{ ft}\cdot\text{lb}$)



- 5) Tighten bolt which holds right upper side of transmission to engine.

Tightening torque:

$50 \pm 4 \text{ N}\cdot\text{m}$ ($5.1 \pm 0.4 \text{ kg}\cdot\text{m}$, $36.9 \pm 2.9 \text{ ft}\cdot\text{lb}$)



- 6) Install torque converter to drive plate. (AT model)
- (1) Tighten bolts which hold torque converter to drive plate.
 - (2) Tighten other bolts while rotating the engine by using ST.

ST 499977000 CRANK PULLEY WRENCH


CAUTION:

Be careful not to drop bolts into torque converter housing.


Tightening torque:

$25 \pm 2 \text{ N}\cdot\text{m}$ ($2.5 \pm 0.2 \text{ kg}\cdot\text{m}$, $18.1 \pm 1.4 \text{ ft}\cdot\text{lb}$)


- (3) Clog plug onto service hole.



- (4) Install V-belt cover.



- 7) Remove special tool.




- 8) Install pitching stopper.

Tightening torque:

T1: $49 \pm 5 \text{ N}\cdot\text{m}$ ($5.0 \pm 0.5 \text{ kg}\cdot\text{m}$, $36.2 \pm 3.6 \text{ ft}\cdot\text{lb}$)


T2: $57 \pm 10 \text{ N}\cdot\text{m}$ ($5.8 \pm 1.0 \text{ kg}\cdot\text{m}$, $42 \pm 7 \text{ ft}\cdot\text{lb}$)



- 9) Install front drive shafts into transmission.
 - (1) Lift-up the vehicle.
 - (2) Install front drive shaft into transmission.
 - (3) Drive spring pin into chamfered hole of drive shaft.

CAUTION:


Always use a new spring pin.



- (4) Install ball joints of lower arm into knuckle arm of housing, and tighten installing bolt.

Tightening torque:


$49 \pm 10 \text{ N}\cdot\text{m}$ ($5.0 \pm 1.0 \text{ kg}\cdot\text{m}$, $36 \pm 7 \text{ ft}\cdot\text{lb}$)



- 10) Install stabilizer clamp onto front crossmember.


Tightening torque:

$25 \pm 4 \text{ N}\cdot\text{m}$ ($2.5 \pm 0.4 \text{ kg}\cdot\text{m}$, $18.1 \pm 2.9 \text{ ft}\cdot\text{lb}$)



- 11) Install gear shift rod and stay. (MT model)

- (1) Install gear shift rod onto transmission.
- (2) Install stay onto transmission.
- (3) Install spring.



- 12) Install shift selector cable onto selector cable. (AT model)


- (1) Install selector cable into selector lever.
- (2) Install cable bracket onto body.

Tightening torque:


$18 \pm 5 \text{ N}\cdot\text{m}$ ($1.84 \pm 0.51 \text{ kg}\cdot\text{m}$, $13.3 \pm 3.7 \text{ ft}\cdot\text{lb}$)

NOTE:

Tighten selector cable adjusting and lock nut after checking selector lever operation. <Ref. to 3-3 [W2E0].>



13) Install ATF level gauge guide, and ATF cooler hoses onto pipe. (AT model)




14) Install propeller shaft.

- (1) Install propeller shaft into transmission.
- (2) Tighten bolts which install propeller shaft onto companion flange of rear differential.

Tightening torque:


$31 \pm 8 \text{ N} \cdot \text{m}$ ($3.2 \pm 0.8 \text{ kg} \cdot \text{m}$, $23.1 \pm 5.8 \text{ ft} \cdot \text{lb}$)



(3) Install center bearing bracket on body.


Tightening torque:

$52 \pm 5 \text{ N} \cdot \text{m}$ ($5.3 \pm 0.5 \text{ kg} \cdot \text{m}$, $38.3 \pm 3.6 \text{ ft} \cdot \text{lb}$)



15) Install exhaust system.


- (1) Install heat shield cover.




(2) Install rear exhaust pipe to muffler.

Tightening torque:

$48 \pm 9 \text{ N} \cdot \text{m}$ ($4.9 \pm 0.9 \text{ kg} \cdot \text{m}$, $35.4 \pm 6.5 \text{ ft} \cdot \text{lb}$)




(3) Install hanger bracket on right side of transmission.



(4) Install front exhaust pipe onto engine.

Tightening torque:


30 ± 5 N·m (3.1 ± 0.5 kg-m, 22.4 ± 3.6 ft-lb)



(5) Install center exhaust pipe to rear exhaust pipe.

Tightening torque:


18 ± 5 N·m (1.8 ± 0.5 kg-m, 13.0 ± 3.6 ft-lb)




(6) Tighten bolt which installs center exhaust pipe to hanger bracket.

Tightening torque:


30 ± 5 N·m (3.1 ± 0.5 kg-m, 22.4 ± 3.6 ft-lb)



(7) Connect connector to rear oxygen sensor.




16) Install transmission connector holder bracket.



17) Install ATF level gauge. (AT model)

18) Connect connectors and cables.

- (1) Connect the following connectors.
 - Transmission harness connectors
 - Transmission ground terminal
 - Front oxygen sensor connector
- (2) Connect the following cables.
 - Cruise control cable
(With cruise control model)
 - Clutch cable
 - Speedometer cable




19) Install starter.

- (1) Install starter onto transmission case, and connect connectors and terminals.
- (2) Tighten bolt and nut which install starter onto transmission.

Tightening torque:

40±4 N·m (4.1±0.4 kg-m, 29.7±2.9 ft-lb)



20) Install air intake duct and chamber then connect connector to mass air flow sensor.

- 21) Connect battery ground cable.
- 22) Fill ATF. (AT model)
<Ref. to 3-2 [W1B1].>
- 23) Check selector lever operation. (AT model)
<Ref. to 3-3 [W2E0].>
- 24) Take off vehicle from lift arms.
- 25) Check the vehicle on road tester. (AT model)
<Ref. to 3-2 [W7A0].>

ENGINE COOLING SYSTEM **2-5**

	Page
S SPECIFICATIONS AND SERVICE DATA	2
1. Specifications	2
2. Service Data	2
C COMPONENT PARTS	3
1. Water Pump	3
2. Radiator and Radiator Fan	4
3. Water Pipe	5
W SERVICE PROCEDURE	6
1. On-Car Service	6
2. Water Pump	7
3. Thermostat	10
4. Radiator	11
5. Radiator Cap	14
6. Radiator Fan and Fan Motor	14
7. Water Pipe	15
K DIAGNOSTICS	18
1. Engine Cooling System Trouble in General	18


1. Specifications

Cooling system			Electric fan + Forced engine coolant circulation system
Total engine coolant capacity ℓ (US qt, Imp qt)		1800 cc	6.2 (6.6, 5.5)
		2200 cc	5.8 (6.1, 5.1)
Water pump	Type		Centrifugal impeller type
	Discharge performance I	Discharge	20 ℓ (5.3 US gal, 4.4 Imp gal)/min.
		Pump speed—total engine coolant head	760 rpm — 0.3 mAq (1.0 ftAq)
		Engine coolant temperature	85°C (185°F)
	Discharge performance II	Discharge	100 ℓ (26.4 US gal, 22.0 Imp gal)/min.
		Pump speed—total engine coolant head	3,000 rpm — 5.0 mAq (16.4 ftAq)
		Engine coolant temperature	85°C (185°F)
	Discharge performance III	Discharge	200 ℓ (52.8 US gal, 44.0 Imp gal)/min.
		Pump speed—total engine coolant head	6,000 rpm — 23.0 mAq (75.5 ftAq)
		Engine coolant temperature	85°C (185°F)
	Impeller diameter		76 mm (2.99 in)
	Number of impeller vanes		8
	Pump pulley diameter		60 mm (2.36 in)
Thermostat	Type		Wax pellet type
	Starts to open		76 — 80°C (169 — 176°F)
	Fully opened		91°C (196°F)
	Valve lift		9.0 mm (0.354 in) or more
	Valve bore		35 mm (1.38 in)
Radiator fan	Motor		90 W
	Fan diameter x Blade		320 mm (12.60 in) x 5
Radiator	Type		Down flow, pressure type
	Core dimensions		691 x 340 x 16 mm (27.20 x 13.39 x 0.63 in)
	Pressure range in which cap valve is open		Above: 88±10 kPa (0.9±0.1 kg/cm ² , 12.8±1.4 psi) Below: -4.9 to -9.8 kPa (-0.05 to -0.1 kg/cm ² , -0.7 to -1.4 psi)
	Fins		Corrugated fin type
Reservoir tank	Capacity		0.5 ℓ (0.5 US qt, 0.4 Imp qt)

2. Service Data

Water pump	Clearance between impeller and case	Standard Limit	0.5 — 0.7 mm (0.020 — 0.028 in) 1.0 mm (0.039 in)
	"Thrust" runout of impeller end		0.5 mm (0.020 in)


1. Water Pump



- ① Water pump ASSY
- ② Gasket
- ③ Heater hose
- ④ Thermostat
- ⑤ Gasket
- ⑥ Thermostat case

Tightening torque: N·m (kg·m, ft·lb)
T1: First 10^{+4}_0 ($1.0^{+0.4}_0$, $7.2^{+2.9}_0$)
Second 10^{+4}_0 ($1.0^{+0.4}_0$, $7.2^{+2.9}_0$)
T2: 6.4±0.5 ($0.65±0.05$, $4.7±0.4$)

2. Radiator and Radiator Fan




- ① Radiator lower cushion
- ② Radiator
- ③ Radiator cap
- ④ Radiator upper cushion
- ⑤ Radiator upper bracket
- ⑥ Clamp
- ⑦ Radiator inlet hose
- ⑧ Over flow hose
- ⑨ Air vent hose
- ⑩ Engine coolant reservoir tank cap
- ⑪ Engine coolant reservoir tank
- ⑫ Clip
- ⑬ Washer
- ⑭ Radiator main fan motor ASSY
- ⑮ Radiator main fan
- ⑯ Radiator drain plug

- ⑰ Radiator outlet hose
- ⑱ ATF hose clamp
- ⑲ ATF inlet hose A
- ⑳ ATF outlet hose A
- ㉑ ATF pipe
- ㉒ ATF outlet hose B
- ㉓ ATF inlet hose B

Tightening torque: N·m (kg·m, ft·lb)**T1: 2.0±0.5 (0.2±0.05, 1.4±0.4)****T2: 3.4±0.5 (0.35±0.05, 2.5±0.4)****T3: 3.9±1.0 (0.4±0.1, 2.9±0.7)****T4: 7.4±2.0 (0.75±0.2, 5.4±1.4)****T5: 18±5 (1.8±0.5, 13.0±3.6)**


3. Water Pipe



G2M0203

- ① Engine coolant temperature sensor
- ② Engine coolant temperature gauge
- ③ Water pipe
- ④ O-ring
- ⑤ By-pass hose

Tightening torque: N·m (kg·m, ft·lb)
T: 6.4±0.5 (0.65±0.05, 4.7±0.4)




1. On-Car Service

A: DRAINING OF ENGINE COOLANT

- 1) Lift-up the vehicle.
- 2) Loosen drain cock to drain engine coolant into container.


NOTE:

Remove radiator cap so that engine coolant will drain faster.




B: FILLING OF ENGINE COOLANT

- 1) Fill engine coolant into radiator up to filler neck position.



- 2) Fill engine coolant into reservoir tank up to upper level.

- 3) Attach radiator cap and reservoir tank cap properly.
- 4) Warm-up engine completely for more than five minutes at 2,000 to 3,000 rpm.
- 5) Stop engine and wait until temperature drops to a safe level.
- 6) If engine coolant level drops in radiator, add engine coolant to filler neck position.
- 7) If engine coolant level drops from upper level of reservoir tank, add engine coolant to upper level.
- 8) Attach radiator cap and reservoir tank cap properly.




C: CHECKING OF COOLING SYSTEM

- 1) Remove radiator cap, top off radiator, and attach tester to radiator in place of cap.
- 2) Apply a pressure of 157 kPa (1.6 kg/cm², 23 psi) to radiator to check if:

- (1) Engine coolant leaks at/around radiator.
- (2) Engine coolant leaks at/around hoses or connections.

CAUTION:


- Engine should be off.
- Wipe engine coolant from check points in advance.
- Be careful to prevent engine coolant from spurting out when removing tester.
- Be careful also not to deform filler neck of radiator when installing or removing tester.



2. Water Pump

A: REMOVAL AND INSTALLATION


- 1) Open front hood.
- 2) Disconnect ground cable from the battery.




- 3) Drain engine coolant completely.

NOTE:


Set container under the vehicle, and remove drain cock from radiator.




- 4) Disconnect radiator outlet hose from water pump.




5) Remove radiator fan motor assembly.
<Ref. to 2-5 [W6A0].>




6) Remove V-belt(s).
<Ref. to 1-5 [02B0].>




7) Remove timing belt.
<Ref. to 1-5 [03A0].>




8) Remove belt tension adjuster.




9) Remove camshaft position sensor.




- 10) Remove left-hand camshaft sprocket by using ST.
ST 499207100 CAMSHAFT SPROCKET WRENCH



- 11) Remove left-hand belt cover No. 2.



- 12) Remove tensioner bracket.
- 13) Disconnect heater hose from water pump.
- 14) Remove water pump.



- 15) Installation is in the reverse order of removal.

CAUTION:


- Replace gasket with a new one.
- When installing water pump, tighten bolts in two stages in numerical sequence as shown in figure.

Tightening torque:

10_0^{+4} N·m ($1.0_0^{+0.4}$ kg·m, $7.2_0^{+2.9}$ ft·lb)


B: INSPECTION

- 1) Check water pump bearing for smooth rotation.
- 2) Check water pump pulley for abnormalities.



3) Using a dial gauge, measure impeller runout in thrust direction while rotating the pulley.

"Thrust" runout limit:
0.5 mm (0.020 in)



4) Check clearance between impeller and pump case.

Clearance between impeller and pump case:


Standard

0.5 — 0.7 mm (0.020 — 0.028 in)

Limit

1.0 mm (0.039 in)

5) After water pump installation, check pulley shaft for engine coolant leaks. If leaks are noted, replace water pump assembly.



3. Thermostat


A: REMOVAL AND INSTALLATION

1) Drain engine coolant:

Set container under the vehicle, and remove drain cock from radiator.

2) Disconnect radiator outlet hose from thermostat cover.


3) Remove thermostat cover and gasket, and pull out the thermostat.



4) Install the thermostat in the intake manifold, and install the thermostat cover together with a gasket.

CAUTION:

- When reinstalling the thermostat, use a new gasket.
- The thermostat must be installed with the jiggle pin upward.
- In this time, set the jiggle pin of thermostat for front side.

**B: INSPECTION**

Replace the thermostat if the valve does not close completely at an ambient temperature or if the following test shows unsatisfactory results.


Immerse the thermostat and a thermometer in water. Raise water temperature gradually, and measure the temperature and valve lift when the valve begins to open and when the valve is fully opened. During the test, agitate the water for even temperature distribution. The measurement should be to the specification.

Starts to open:

76.0 — 80.0°C (169 — 176°F)

Fully opens:


91°C (196°F)

**4. Radiator****A: REMOVAL**

1) Disconnect battery cables and remove battery from body.


2) Drain engine coolant:

Set container under the vehicle, and remove drain cock from radiator.




3) Disconnect radiator outlet hose from thermostat cover.


4) Disconnect ATF cooler hoses from radiator. (AT model)




5) Remove V-belt cover.



6) Disconnect inlet hose from radiator.



7) Disconnect connectors of radiator main fan and sub fan motor.




8) Remove radiator upper brackets.


NOTE:

Place left upper radiator bracket between grille and body.


9) While slightly lifting radiator, slide it to left.




10) Lift radiator up and away from vehicle.

**B: INSTALLATION**

1) Attach radiator mounting cushions to pins on the lower side of radiator.




2) Fit cushions on lower side of radiator, into holes on body side and install radiator.




3) Install radiator brackets and tighten bolts.

4) Connect radiator main fan motor and sub fan motor connectors.




5) Connect radiator inlet and outlet hoses.


6) Connect ATF cooler hoses. (AT model)



7) Install V-belt cover.



8) Connect ground cable to battery terminal.



5. Radiator Cap

A: INSPECTION

- 1) Attach radiator cap to tester.
- 2) Increase pressure until tester gauge pointer stops. Radiator cap is functioning properly if it holds the service limit pressure for five to six seconds.

Standard pressure:


78 — 98 kPa (0.8 — 1.0 kg/cm², 11 — 14 psi)

Service limit pressure:

69 kPa (0.7 kg/cm², 10 psi)

CAUTION:


Be sure to remove foreign matter and rust from the cap in advance; otherwise, results of pressure test will be incorrect.




6. Radiator Fan and Fan Motor

A: REMOVAL AND INSTALLATION


- 1) Disconnect ground cable from battery terminal.
- 2) Disconnect connector of fan motor.



3) Remove reservoir tank.



4) Remove two bolts holding shroud to radiator upper side.




5) Remove radiator fan motor assembly.

6) Remove fan motor from shroud.

7) Installation is in the reverse order of removal procedures.

NOTE:

- Before installing radiator fan motor, apply a coat of sealant to threads and tighten nuts.
- Make sure radiator fan does not come into contact with shroud when installed.
- After installation, make sure there is no unusual noise or vibration when fan is rotated.




7. Water Pipe

A: REMOVAL

1) Release fuel pressure.


<Ref. to 2-8 [W1B0].>

2) Disconnect ground cable from the battery.




3) Drain engine coolant completely.


<Ref. to 2-5 [W1A0].>




- 4) Remove intake manifold.
<Ref. to 2-7 [W4A0].>




- 5) Disconnect heater inlet hose.



- 6) Disconnect radiator inlet hose from water pipe.



- 7) Remove bolts which install water pipe on cylinder block.



B: INSTALLATION


- 1) Install water pipe on cylinder block.

Tightening torque:


$6.4 \pm 0.5 \text{ N} \cdot \text{m}$ ($0.65 \pm 0.05 \text{ kg} \cdot \text{m}$, $4.7 \pm 0.4 \text{ ft} \cdot \text{lb}$)

CAUTION:


Use a new O-ring.




2) Connect radiator inlet hose.



3) Connect heater inlet hose.



4) Install intake manifold.
<Ref. to 2-7 [W4D0].>



5) Connect ground cable to battery terminal.

1. Engine Cooling System Trouble in General

Trouble	Possible cause	Corrective action
Over-heating	a. Insufficient engine coolant	Replenish engine coolant, inspect for leakage, and repair.
	b. Loose timing belt	Repair or replace timing belt tensioner.
	c. Oil on drive belt	Replace.
	d. Malfunction of thermostat	Replace.
	e. Malfunction of water pump	Replace.
	f. Clogged engine coolant passage	Clean.
	g. Improper ignition timing	Inspect and repair ignition control system. <Ref. to 2-7 [T8D0].>
	h. Clogged or leaking radiator	Clean or repair, or replace.
	i. Improper engine oil in engine coolant	Replace engine coolant.
	j. Air/fuel mixture ratio too lean	Inspect and repair fuel injection system. <Ref. to 2-7 [T1000].>
	k. Excessive back pressure in exhaust system	Clean or replace.
	l. Insufficient clearance between piston and cylinder	Adjust or replace.
	m. Slipping clutch	Repair or replace.
	n. Dragging brake	Adjust.
	o. Improper transmission oil	Replace.
	p. Defective thermostat	Replace.
	q. Malfunction of electric fan	Inspect radiator fan relay, engine coolant temperature sensor or radiator motor and replace there.
Over-cooling	a. Atmospheric temperature extremely low	Partly cover radiator front area.
	b. Defective thermostat	Replace.
Engine coolant leaks.	a. Loosened or damaged connecting units on hoses	Repair or replace.
	b. Leakage from water pump	Replace.
	c. Leakage from water pipe	Repair or replace.
	d. Leakage around cylinder head gasket	Retighten cylinder head bolts or replace gasket.
	e. Damaged or cracked cylinder head and crankcase	Repair or replace.
	f. Damaged or cracked thermostat case	Repair or replace.
	g. Leakage from radiator	Repair or replace.
Noise	a. Defective drive belt	Replace.
	b. Defective radiator fan	Replace.
	c. Defective water pump bearing	Replace water pump.
	d. Defective water pump mechanical seal	Replace water pump.


ENGINE LUBRICATION SYSTEM **2-4**

	Page
S SPECIFICATIONS AND SERVICE DATA	2
1. Specifications	2
C COMPONENT PARTS	3
1. Lubrication System	3
W SERVICE PROCEDURE	4
1. Oil Pump	4
2. Oil Pan and Oil Strainer.....	8
3. Oil Pressure Switch	13
K DIAGNOSTICS	16
1. Engine Lubrication System Trouble in General.....	16

1. Specifications

Lubrication method					Forced lubrication	
Oil pump	Pump type				Trochoid type	
	Number of teeth		Inner rotor		9	
			Outer rotor		10	
	Outer rotor diameter x thickness				78 x 9 mm (3.07 x 0.35 in)	
	Tip clearance between inner and outer rotor			STANDARD	0.04 — 0.14 mm (0.0016 — 0.0055 in)	
				LIMIT	0.18 mm (0.0071 in)	
	Side clearance between inner rotor and pump case			STANDARD	0.02 — 0.07 mm (0.0008 — 0.0028 in)	
				LIMIT	0.15 mm (0.0059 in)	
	Case clearance between outer rotor and pump case			STANDARD	0.10 — 0.175 mm (0.0039 — 0.0069 in)	
				LIMIT	0.20 mm (0.0079 in)	
	Capacity at 80°C (176°F)	600 rpm	Discharge	- pressure	98 kPa (1.0 kg/cm ² , 14 psi) or more	
				- quantity	4.2 ℓ (4.4 US qt, 3.7 Imp qt)/min.	
		5,000 rpm	Discharge	- pressure	294 kPa (3.0 kg/cm ² , 43 psi) or more	
				- quantity	42.0 ℓ (11.10 US gal, 9.24 Imp gal)/min.	
Relief valve operation pressure					490 kPa (5.0 kg/cm ² , 71 psi)	
Oil filter	Type				Full-flow filter type	
	Filtration area				1,000 cm ² (155 sq in)	
	By-pass valve opening pressure				156 kPa (1.6 kg/cm ² , 23 psi)	
	Outer diameter x width				80 x 70 mm (3.15 x 2.76 in)	
	Oil filter to engine thread size				M 20 x 1.5	
Relief valve (on rocker shaft) operation pressure					69 kPa (0.7 kg/cm ² , 10 psi)	
Oil pressure switch	Type				Immersed contact point type	
	Working voltage — wattage				12 V — 3.4 W or less	
	Warning light activation pressure				14.7 kPa (0.15 kg/cm ² , 2.1 psi)	
	Proof pressure				More than 981 kPa (10 kg/cm ² , 142 psi)	
Oil capacity (at replacement)					4.0 ℓ (4.2 US qt, 3.5 Imp qt)	

1. Lubrication System



H2M1728A

- ① Plug
- ② Washer
- ③ Relief valve spring
- ④ Relief valve
- ⑤ Oil seal
- ⑥ Oil pump case
- ⑦ Inner rotor
- ⑧ Outer rotor
- ⑨ Oil pump cover
- ⑩ Oil filter
- ⑪ O-ring
- ⑫ Oil pump ASSY
- ⑬ Oil pressure switch
- ⑭ Oil filler duct

- ⑮ Baffle plate
- ⑯ Oil strainer stay
- ⑰ O-ring
- ⑱ Oil strainer
- ⑲ Oil level gauge guide
- ⑳ Oil pan
- ㉑ Oil level gauge

Tightening torque: N·m (kg·m, ft·lb)


T1: 5 (0.5, 3.6)

T2: 5 — 6 (0.5 — 0.6, 3.6 — 4.3)

T3: 6.4 (0.65, 4.7)

T4: 9.8 (1.0, 7.0)

T5: 40.7 — 47.6 (4.15 — 4.85, 30.0 — 35.1)




1. Oil Pump

A: REMOVAL


1) Drain engine oil.

Set container under the vehicle, and remove drain plug from oil pan.




2) Drain coolant.


Set container under the vehicle, and remove drain cock from radiator.



3) Remove belt covers, timing belt and related parts.
<Ref. to 1-5 [W2A0].>




4) Remove belt tensioner bracket.



5) Remove left-hand camshaft sprocket and left-hand belt cover No. 2.


6) Remove water pump.



7) Remove oil pump by using flat-bladed screwdriver.

CAUTION:

Be careful not to scratch mating surfaces of cylinder block and oil pump.



B: DISASSEMBLY


Remove screws which secure oil pump cover and disassemble oil pump.

Inscribe alignment marks on inner and outer rotors so that they can be replaced in their original positions during reassembly.

CAUTION:

Before removing relief valve, loosen plug when removing oil pump from cylinder block.

- ① Oil seal
- ② Pump case
- ③ Inner rotor
- ④ Outer rotor
- ⑤ Pump cover
- ⑥ Relief valve
- ⑦ Relief spring
- ⑧ Plug
- ⑨ Washer



C: INSPECTION

1. TIP CLEARANCE

Measure the tip clearance of rotors. If the clearance exceeds the limit, replace rotors as a matched set.


Tip clearance:

Standard

0.04 — 0.14 mm (0.0016 — 0.0055 in)

Limit

0.18 mm (0.0071 in)



2. CASE CLEARANCE

Measure the clearance between the outer rotor and the cylinder block rotor housing. If the clearance exceeds the limit, replace the rotor.


Case clearance:

Standard

0.10 — 0.175 mm (0.0039 — 0.0069 in)

Limit

0.20 mm (0.0079 in)



3. SIDE CLEARANCE

Measure clearance between oil pump inner rotor and pump cover. If the clearance exceeds the limit, replace rotor or pump body.

Side clearance:

Standard

0.02 — 0.07 mm (0.0008 — 0.0028 in)

Limit

0.15 mm (0.0059 in)

4. OIL RELIEF VALVE

Check the valve for fitting condition and damage, and the relief valve spring for damage and deterioration. Replace the parts if defective.

Relief valve spring:

Free length; 71.8 mm (2.827 in)

Installed length; 54.7 mm (2.154 in)


Load when installed; 77.08 N (7.86 kg, 17.33 lb)

5. OIL PUMP CASE

Check the oil pump case for worn shaft hole, clogged oil passage, worn rotor chamber, cracks, and other faults.

6. OIL SEAL

Check the oil seal lips for deformation, hardening, wear, etc. and replace if defective.




D: ASSEMBLY

1) Install front oil seal by using ST.

ST 499587100 OIL SEAL INSTALLER

CAUTION:

Use a new oil seal.




- 2) Install inner and outer rotors in their original positions.
- 3) Install oil relief valve and relief spring.
- 4) Install oil pump cover.

Tightening torque:

T1: 5 — 6 N·m (0.5 — 0.6 kg-m, 3.6 — 4.3 ft-lb)

T2: 40.7 — 47.6 N·m

(4.15 — 4.85 kg-m, 30.0 — 35.1 ft-lb)

**E: INSTALLATION**

Installation is in the reverse order of removal.

Observe the following:

- 1) Apply fluid packing to matching surfaces of oil pump.

Fluid packing:

THREE BOND 1215 or equivalent

- 2) Replace O-ring with a new one.


- 3) Be careful not to scratch oil seal when installing oil pump on cylinder block.

CAUTION:

Apply fluid packing to oil pressure switch threads before installation.

Fluid packing:


THREE BOND 1215 or equivalent




2. Oil Pan and Oil Strainer

A: REMOVAL


- 1) Remove front wheels.
- 2) Remove air intake duct and air intake chamber.
- 3) Disconnect connector from front oxygen sensor.



- 4) Remove pitching stopper.




- 5) Remove radiator upper brackets.



- 6) Support engine with a lifting device and wire ropes.
- 7) Lift-up the vehicle.


CAUTION:

At this time, raise up wire ropes.




- 8) Drain engine oil.

Set container under the vehicle, and remove drain plug from oil pan.




9) Disconnect connector from rear oxygen sensor.




10) Remove front exhaust pipe.

- (1) Separate front catalytic converter from center exhaust pipe.
- (2) Remove front exhaust pipe from engine.
- (3) Remove bolt which installs front exhaust pipe on bracket.



11) Remove nuts which install front cushion rubber onto front crossmember.




12) Remove bolts which install oil pan on cylinder block while raising up engine.


13) Insert oil pan cutter blade between cylinder block-to-oil pan clearance.

CAUTION:


Do not use a screwdriver or similar tool in place of oil pan cutter.



14) Separate oil strainer from oil strainer stay.




15) Remove oil strainer.



16) Remove baffle plate and oil strainer stay.

B: INSPECTION

By visual check make sure oil pan, oil strainer, oil strainer stay and baffle plate are not damaged.



C: INSTALLATION


CAUTION:

Before installing oil pan, clean sealant from oil and engine block.

1) Install baffle plate and oil strainer stay.

Tightening torque:

6.4 N·m (0.65 kg-m, 4.7 ft-lb)




2) Install oil strainer onto baffle plate.

CAUTION:

Replace O-ring with a new one.

Tightening torque:


9.8 N·m (1.0 kg-m, 7 ft-lb)



3) Hold oil strainer to oil strainer stay.

Tightening torque:


9.8 N·m (1.0 kg-m, 7 ft-lb)



4) Apply fluid packing to mating surfaces and install oil pan.

Fluid packing:


THREE BOND 1215 or equivalent



5) Tighten bolts which install oil pan onto engine block.

Tightening torque:

5 N·m (0.5 kg-m, 3.6 ft-lb)




6) Lower engine onto front crossmember.

7) Tighten nuts which install front cushion rubber onto front crossmember.

Tightening torque:

69±15 N·m (7.0±1.5 kg-m, 51±11 ft-lb)



8) Install front exhaust pipe.

CAUTION:


Always use the new gaskets.

(1) Place front exhaust pipe on bracket.

(2) Tighten nuts which install front exhaust pipe on engine.

Tightening torque:


30±5 N·m (3.1±0.5 kg-m, 22.4±3.6 ft-lb)



(3) Tighten nuts which install front catalytic converter to center exhaust pipe.

Tightening torque:


35 ± 5 N·m (3.6 ± 0.5 kg-m, 26.0 ± 3.6 ft-lb)




(4) Tighten bolt which installs front exhaust pipe on bracket.

Tightening torque:

24 ± 3 N·m (2.4 ± 0.3 kg-m, 17.4 ± 2.2 ft-lb)



9) Connect connector to rear oxygen sensor.




10) Lower the vehicle.


CAUTION:

At this time, lower lifting device and release steel cables.

11) Remove lifting device and steel cables.



12) Connect connector to front oxygen sensor.




13) Install pitching stopper.

Tightening torque:

T1: 49 ± 5 N·m (5.0 ± 0.5 kg-m, 36.2 ± 3.6 ft-lb)


T2: 57 ± 10 N·m (5.8 ± 1.0 kg-m, 42 ± 7 ft-lb)




14) Install radiator upper brackets.

Tightening torque:

18 ± 5 N·m (1.8 ± 0.5 kg-m, 13 ± 4 ft-lb)



15) Install air intake duct and air intake chamber.




3. Oil Pressure Switch

A: REMOVAL


1) Remove alternator from bracket.

(1) Disconnect connector and terminal from generator.




(2) Remove V-belt cover.


(3) Loosen lock bolt and slider bolt, and remove front side V-belt.



(4) Remove bolts which install generator on bracket.



- 2) Disconnect terminal from oil pressure switch.
- 3) Remove oil pressure switch.




B: INSTALLATION

- 1) Install oil pressure switch onto engine block.


Tightening torque:

$25 \pm 3 \text{ N}\cdot\text{m}$ ($2.5 \pm 0.3 \text{ kg}\cdot\text{m}$, $18.1 \pm 2.2 \text{ ft}\cdot\text{lb}$)


- 2) Connect terminal of oil pressure switch.



- 3) Install generator on bracket and temporary tighten installing bolts.



- 4) Install front side V-belt and adjust it.
<Ref. to 1-5 [01B0].>
- 5) Install V-belt cover.



6) Connect connector and terminal to generator.

1. Engine Lubrication System Trouble in General

Before troubleshooting, make sure that the engine oil level is correct and no oil leakage exists.

Trouble	Possible cause		Corrective action
1. Warning light remains on.	1) Oil pressure switch failure	Cracked diaphragm or oil leakage within switch	Replace.
		Broken spring or seized contacts	Replace.
	2) Low oil pressure	Clogged oil filter	Replace.
		Malfunction of oil by-pass valve of oil filter	Clean or replace.
		Malfunction of oil relief valve of oil pump	Clean or replace.
		Clogged oil passage	Clean.
		Excessive tip clearance and side clearance of oil pump rotor and gear	Replace.
		Clogged oil strainer or broken pipe	Clean or replace.
	3) No oil pressure	Insufficient engine oil	Replenish.
		Broken pipe of oil strainer	Replace.
		Stuck oil pump rotor	Replace.
2. Warning light does not go on.	1) Burn-out bulb		Replace.
	2) Poor contact of switch contact points		Replace.
	3) Disconnection of wiring		Repair.
3. Warning light flickers momentarily.	1) Poor contact at terminals		Repair.
	2) Defective wiring harness		Repair.
	3) Low oil pressure		Check for the same possible causes as listed in 1.—2)

ENGINE 2-3

	Page
S SPECIFICATIONS AND SERVICE DATA	2
1. Specifications	2
2. Service Data	3
C COMPONENT PARTS	7
1. Timing Belt	7
2. Cylinder Head and Camshaft	8
3. Cylinder Head and Valve Assembly	9
4. Cylinder Block.....	10
5. Crankshaft and Piston.....	11
6. Timing Belt (Equipped New Automatic Belt Tension Adjuster).....	12
W SERVICE PROCEDURE	13
1. General Precautions	13
2. Timing Belt	14
3. Valve Rocker Assembly	26
4. Camshaft.....	31
5. Cylinder Head	37
6. Cylinder Block.....	50
7. Timing Belt (Equipped New Automatic Belt Tension Adjuster).....	77
K DIAGNOSTICS	92
1. Engine Trouble in General.....	92
2. Engine Noise.....	97

1. Specifications

Model			1800 cc		2200 cc		
ENGINE	Type		Horizontally opposed, liquid cooled, 4-cylinder, 4-stroke gaso- line engine				
	Valve arrangement		Belt driven, single over-head camshaft, 4-valve/cylinder				
	Bore x Stroke		mm (in)		87.9 x 75.0 (3.461 x 2.953)	96.9 x 75.0 (3.815 x 2.953)	
	Piston displacement		cm ³ (cu in)		1,820 (111.06)	2,212 (135.0)	
	Compression ratio		9.7				
	Compression pressure (at 200 — 300 rpm)		kPa (kg/cm ² , psi)		1,079 — 1,275 (11.0 — 13.0, 156 — 185)		
	Number of piston rings		Pressure ring: 2, Oil ring: 1				
	Intake valve timing	Opening		2° BTDC		4° BTDC	
		Closing		54° ABDC		52° ABDC	
	Exhaust valve timing	Opening		48° BBDC		48° BBDC	
		Closing		8° ATDC		12° ATDC	
	Valve clearance	Intake	mm (in)	0.20±0.02 (0.0079±0.0008)			
		Exhaust	mm (in)	0.25±0.02 (0.0098±0.0008)			
	Idling speed [At neutral position on MT, or “P” or “N” position on AT]		rpm	700±100 (No load) 800±50 (A/C switch ON)		700±100 (No load) 850±50 (A/C switch ON)	
	Firing order		1 → 3 → 2 → 4				
	Ignition timing		BTDC/rpm	MT: 20°±2°/700		AT: 20°±8°/700 MT: 14°±8°/700	

2. Service Data

Belt tensioner adjuster	Protrusion of adjuster rod				15.4 — 16.4 mm	(0.606 — 0.646 in)	
Belt tensioner	Spacer O.D.				16 mm	(0.63 in)	
	Tensioner bush I.D.				16.16 mm	(0.6362 in)	
	Clearance between spacer and bush			STD	0.117 — 0.180 mm	(0.0046 — 0.0071 in)	
				Limit	0.230 mm	(0.0091 in)	
	Side clearance of spacer			STD	0.37 — 0.54 mm	(0.0146 — 0.0213 in)	
Limit				0.8 mm	(0.031 in)		
Valve rocker arm	Clearance between shaft and arm			STD	0.020 — 0.054 mm	(0.0008 — 0.0021 in)	
				Limit	0.10 mm	(0.0039 in)	
Camshaft	Bend limit				0.025 mm	(0.0010 in)	
	Thrust clearance			STD	0.030 — 0.260 mm	(0.0012 — 0.0102 in)	
				Limit	0.35 mm	(0.0138 in)	
	Cam lobe height		Intake	STD	32.244 — 32.344 mm	(1.2694 — 1.2734 in)	
				Limit	32.094 mm	(1.2635 in)	
			Exhaust	STD	31.964 — 32.064 mm	(1.2584 — 1.2624 in)	
				Limit	31.814 mm	(1.2525 in)	
	Camshaft journal O.D.	RH	Front	LH	Rear	31.935 — 31.950 mm	(1.2573 — 1.2579 in)
			Center		Center	37.435 — 37.450 mm	(1.4738 — 1.4744 in)
			Rear		Front	37.935 — 37.950 mm	(1.4935 — 1.4941 in)
	Camshaft journal hole I.D.	RH	Front	LH	Rear	32.005 — 32.025 mm	(1.2600 — 1.2608 in)
			Center		Center	37.505 — 37.525 mm	(1.4766 — 1.4774 in)
			Rear		Front	38.005 — 38.025 mm	(1.4963 — 1.4970 in)
	Oil clearance			STD	0.055 — 0.090 mm	(0.0022 — 0.0035 in)	
Limit				0.10 mm	(0.0039 in)		
Cylinder head	Surface warpage limit				0.05 mm	(0.0020 in)	
	Surface grinding limit				0.1 mm	(0.004 in)	
	Standard height				98.3 mm	(3.870 in)	
Valve set	Refacing angle				90°		
	Contacting width			Intake	STD	0.7 mm	(0.028 in)
					Limit	1.4 mm	(0.055 in)
				Exhaust	STD	1.4 mm	(0.055 in)
Limit					1.8 mm	(0.071 in)	
Valve guide	Inner diameter				6.000 — 6.012 mm	(0.2362 — 0.2367 in)	
	Protrusion above head				17.5 — 18.0 mm	(0.689 — 0.709 in)	
Valve	Head edge thickness			Intake	STD	1.0 mm	(0.039 in)
					Limit	0.8 mm	(0.031 in)
				Exhaust	STD	1.2 mm	(0.047 in)
					Limit	0.8 mm	(0.031 in)
	Stem diameter			Intake	5.950 — 5.965 mm	(0.2343 — 0.2348 in)	
				Exhaust	5.945 — 5.960 mm	(0.2341 — 0.2346 in)	
	Stem oil clearance			STD	Intake	0.035 — 0.062 mm	(0.0014 — 0.0024 in)
					Exhaust	0.040 — 0.067 mm	(0.0016 — 0.0026 in)
				Limit	—	0.15 mm	(0.0059 in)
Overall length			Intake	101.0 mm	(3.976 in)		
			Exhaust	101.2 mm	(3.984 in)		

STD: Standard I.D.: Inner Diameter O.D.: Outer Diameter

Valve spring	Free length				44.05 mm (1.7342 in)	
	Squareness				2.5°, 1.9 mm (0.075 in)	
	Tension/spring height				174.6 — 200.1 N (17.8 — 20.4 kg, 39.2 — 45.0 lb)/36.0 mm (1.417 in) 405.0 — 458.0 N (41.3 — 46.7 kg, 91.1 — 103.0 lb)/28.2 mm (1.110 in)	
Cylinder block	Surface warpage limit (mating with cylinder head)				0.05 mm (0.0020 in)	
	Surface grinding limit				0.1 mm (0.004 in)	
	Cylinder bore	1800 cc	STD	A	87.905 — 87.915 mm (3.4608 — 3.4612 in)	
				B	87.895 — 87.905 mm (3.4604 — 3.4608 in)	
		2200 cc	STD	A	96.905 — 96.915 mm (3.8151 — 3.8155 in)	
				B	96.895 — 96.905 mm (3.8148 — 3.8151 in)	
	Taper			STD	0.015 mm (0.0006 in)	
				Limit	0.050 mm (0.0020 in)	
	Out-of-roundness			STD	0.010 mm (0.0004 in)	
				Limit	0.050 mm (0.0020 in)	
	Piston clearance			STD	0.010 — 0.030 mm (0.0004 — 0.0012 in)	
				Limit	0.050 mm (0.0020 in)	
Enlarging (boring) limit				0.5 mm (0.020 in)		
Piston	Outer diameter	1800 cc	STD	A	87.885 — 87.895 mm (3.4600 — 3.4604 in)	
				B	87.875 — 87.885 mm (3.4596 — 3.4600 in)	
			0.25 mm (0.0098 in) OS		88.125 — 88.135 mm (3.4695 — 3.4699 in)	
			0.50 mm (0.0197 in) OS		88.375 — 88.385 mm (3.4793 — 3.4797 in)	
		2200 cc	STD	A	96.885 — 96.895 mm (3.8144 — 3.8148 in)	
				B	96.875 — 96.885 mm (3.8140 — 3.8144 in)	
			0.25 mm (0.0098 in) OS		97.115 — 97.145 mm (3.8234 — 3.8246 in)	
			0.50 mm (0.0197 in) OS		97.365 — 97.395 mm (3.8333 — 3.8344 in)	
Piston pin	Standard clearance between piston pin and hole in piston			STD	0.004 — 0.010 mm (0.0002 — 0.0004 in)	
				Limit	0.020 mm (0.0008 in)	
	Degree of fit				Piston pin must be fitted into position with thumb at 20°C (68°F).	
Piston ring	Piston ring gap	Top ring	STD	0.20 — 0.35 mm (0.0079 — 0.0138 in)		
			Limit	1.0 mm (0.039 in)		
		Second ring	STD	0.20 — 0.50 mm (0.0079 — 0.0197 in)		
			Limit	1.0 mm (0.039 in)		
		Oil ring	STD	0.20 — 0.70 mm (0.0079 — 0.0276 in)		
			Limit	1.5 mm (0.059 in)		
	Clearance between piston ring and piston ring groove	Top ring	STD	0.040 — 0.080 mm (0.0016 — 0.0031 in)		
			Limit	0.15 mm (0.0059 in)		
Second ring		STD	0.030 — 0.070 mm (0.0012 — 0.0028 in)			
		Limit	0.15 mm (0.0059 in)			


Connect- ing rod	Bend twist per 100 mm (3.94 in) in length	Limit	0.10 mm	(0.0039 in)
	Side clearance	STD	0.070 — 0.330 mm	(0.0028 — 0.0130 in)
		Limit	0.4 mm	(0.016 in)
Connect- ing rod bearing	Oil clearance	STD	0.015 — 0.045 mm	(0.0006 — 0.0018 in)
		Limit	0.05 mm	(0.0020 in)
		STD	1.492 — 1.501 mm	(0.0587 — 0.0591 in)
	Thickness at center portion	0.03 mm (0.0012 in) US	1.510 — 1.513 mm	(0.0594 — 0.0596 in)
		0.05 mm (0.0020 in) US	1.520 — 1.523 mm	(0.0598 — 0.0600 in)
		0.25 mm (0.0098 in) US	1.620 — 1.623 mm	(0.0638 — 0.0639 in)
Connect- ing rod bushing	Clearance between piston pin and bushing	STD	0 — 0.022 mm	(0 — 0.0009 in)
		Limit	0.030 mm	(0.0012 in)

STD: Standard OS: Oversize US: Undersize

Crankshaft	Bend limit			0.035 mm	(0.0014 in)	
	Crankpin and crank journal	Out-of-roundness		0.030 mm (0.0012 in) or less		
		Grinding limit		0.250 mm	(0.0098 in)	
	Crankpin outer diameter		STD	51.984 — 52.000 mm	(2.0466 — 2.0472 in)	
			0.03 mm (0.0012 in) US	51.954 — 51.970 mm	(2.0454 — 2.0461 in)	
			0.05 mm (0.0020 in) US	51.934 — 51.950 mm	(2.0446 — 2.0453 in)	
			0.25 mm (0.0098 in) US	51.734 — 51.750 mm	(2.0368 — 2.0374 in)	
	Crank journal outer diameter		#1, #5	STD	59.992 — 60.008 mm	(2.3619 — 2.3625 in)
				0.03 mm (0.0012 in) US	59.962 — 59.978 mm	(2.3607— 2.3613 in)
				0.05 mm (0.0020 in) US	59.934 — 59.950 mm	(2.3596 — 2.3602 in)
				0.25 mm (0.0098 in) US	59.742 — 59.758 mm	(2.3520 — 2.3527 in)
			#2, #3, #4	STD	59.992 — 60.008 mm	(2.3619 — 2.3625 in)
				0.03 mm (0.0012 in) US	59.954 — 59.970 mm	(2.3604 — 2.3610 in)
				0.05 mm (0.0020 in) US	59.934 — 59.950 mm	(2.3596 — 2.3602 in)
				0.25 mm (0.0098 in) US	59.734 — 59.750 mm	(2.3517 — 2.3524 in)
	Thrust clearance		STD	0.030 — 0.115 mm	(0.0012 — 0.0045 in)	
			Limit	0.25 mm	(0.0098 in)	
	Oil clearance		#1, #5	STD	0.003 — 0.030 mm	(0.0001 — 0.0012 in)
			#2, #3, #4	STD	0.010 — 0.033 mm	(0.0004 — 0.0013 in)
			#1, #3, #5	Limit	0.040 mm	(0.0016 in)
			#2, #4	Limit	0.035 mm	(0.0014 in)
Crankshaft bearing	Crankshaft bearing thickness		#1, #5	STD	1.998 — 2.011 mm	(0.0787 — 0.0792 in)
				0.03 mm (0.0012 in) US	2.017 — 2.020 mm	(0.0794 — 0.0795 in)
				0.05 mm (0.0020 in) US	2.027 — 2.030 mm	(0.0798 — 0.0799 in)
				0.25 mm (0.0098 in) US	2.127 — 2.130 mm	(0.0837 — 0.0839 in)
			#2, #3, #4	STD	2.000 — 2.013 mm	(0.0787 — 0.0793 in)
				0.03 mm (0.0012 in) US	2.019 — 2.022 mm	(0.0795 — 0.0796 in)
				0.05 mm (0.0020 in) US	2.029 — 2.032 mm	(0.0799 — 0.0800 in)
				0.25 mm (0.0098 in) US	2.129 — 2.132 mm	(0.0838 — 0.0839 in)

STD: Standard US: Undersize

1. Timing Belt




B2M0102A

- ① Crankshaft sprocket
- ② Belt cover No. 2 (RH)
- ③ Belt cover No. 2 (LH)
- ④ Camshaft sprocket No. 1
- ⑤ Belt idler (No. 1)
- ⑥ Tensioner bracket
- ⑦ Belt idler (No. 2)
- ⑧ Belt tensioner
- ⑨ Belt tensioner adjuster
- ⑩ Belt idler No. 2
- ⑪ Camshaft sprocket No. 2
- ⑫ Timing belt

- ⑬ Belt cover (RH)
- ⑭ Front belt cover
- ⑮ Belt cover (LH)
- ⑯ Crankshaft pulley

Tightening torque: N·m (kg·m, ft·lb)**T1: 5±1 (0.5±0.1, 3.6±0.7)****T2: 25±2 (2.5±0.2, 18.1±1.4)****T3: 39±4 (4.0±0.4, 28.9±2.9)****T4: 78±5 (8.0±0.5, 57.9±3.6)****T5: 127±10 (13.0±1.0, 94±7)**

2. Cylinder Head and Camshaft




- ① Rocker cover (RH)
- ② Rocker cover gasket
- ③ Camshaft support (RH)
- ④ O-ring
- ⑤ Camshaft (RH)
- ⑥ Intake valve guide
- ⑦ Exhaust valve guide
- ⑧ Oil seal
- ⑨ Cylinder head (RH)
- ⑩ Cylinder head gasket
- ⑪ Cylinder head (LH)
- ⑫ Plug
- ⑬ Camshaft (LH)
- ⑭ O-ring
- ⑮ Camshaft support (LH)

- ⑯ Oil seal
- ⑰ Oil filler cap
- ⑱ Gasket
- ⑲ Oil filler pipe
- ⑳ O-ring
- ㉑ Rocker gasket
- ㉒ Rocker cover (LH)

Tightening torque: N·m (kg-m, ft-lb)**T1: <Ref. to 2-3 [W5E1].>****T2: 5±1 (0.5±0.1, 3.7±0.7)****T3: 10 (1.0, 7)****T4: 16 (1.6, 12)**

3. Cylinder Head and Valve Assembly



B2M1001B

- ① Exhaust valve
- ② Intake valve
- ③ Intake valve oil seal
- ④ Valve spring
- ⑤ Retainer
- ⑥ Retainer key
- ⑦ Exhaust valve oil seal
- ⑧ Rocker shaft support
- ⑨ Rocker shaft support
- ⑩ Rocker shaft support
- ⑪ Rocker shaft
- ⑫ Valve rocker adjust screw

- ⑬ Valve rocker nut
- ⑭ Intake valve rocker arm
- ⑮ Exhaust valve rocker arm
- ⑯ Spring
- ⑰ Plate


Tightening torque: N·m (kg·m, ft·lb)

T1: 5±1 (0.5±0.1, 3.6±0.7)

T2: 10±1 (1.0±0.1, 7.2±0.7)

T3: 12±1 (1.2±0.1, 8.7±0.7)

4. Cylinder Block




H2M1729A

- ① Oil pressure switch
- ② Cylinder block (RH)
- ③ Service hole plug
- ④ Gasket
- ⑤ Oil separator cover
- ⑥ Water by-pass pipe
- ⑦ Oil pump
- ⑧ Front oil seal
- ⑨ Rear oil seal
- ⑩ O-ring
- ⑪ Service hole cover
- ⑫ Cylinder block (LH)
- ⑬ Water pump
- ⑭ Baffle plate
- ⑮ Oil strainer stay
- ⑯ Oil strainer

- ⑰ Gasket
- ⑱ Oil pan
- ⑲ Oil drain plug
- ⑳ Gasket
- ㉑ Oil filler pipe

Tightening torque: N·m (kg·m, ft·lb)**T1: 5 (0.5, 3.6)****T2: 6.4 (0.65, 4.7)****T3: 10 (1.0, 7)****T4: 25±2 (2.5±0.2, 18.1±1.4)****T5: 47±3 (4.8±0.3, 34.7±2.2)****T6: 69±7 (7.0±0.7, 50.6±5.1)****T7: First 12±2 (1.2±0.2, 8.7±1.4)****Second 12±2 (1.2±0.2, 8.7±1.4)**

5. Crankshaft and Piston



B2M1317A

- ① Flywheel (MT vehicles)
- ② Bell bearing (MT vehicles)
- ③ Drive plate (AT vehicles)
- ④ Reinforcement (AT vehicles)
- ⑤ Top ring
- ⑥ Second ring
- ⑦ Oil ring
- ⑧ Piston
- ⑨ Piston pin
- ⑩ Circlip
- ⑪ Connecting rod bolt
- ⑫ Connecting rod


- ⑬ Connecting rod bearing
- ⑭ Connecting rod cap
- ⑮ Crankshaft
- ⑯ Woodruff key
- ⑰ Crankshaft bearing #1, #5
- ⑱ Crankshaft bearing #2, #4
- ⑲ Crankshaft bearing #3

Tightening torque: N·m (kg·m, ft·lb)

T1: 44±2 (4.5±0.2, 32.5±1.4)

T2: 72±3 (7.3±0.3, 52.8±2.2)

6. Timing Belt (Equipped New Automatic Belt Tension Adjuster)



B2M1695A

- ① Crankshaft sprocket
- ② Belt cover No. 2 (RH)
- ③ Belt cover No. 2 (LH)
- ④ Camshaft sprocket No. 1
- ⑤ Belt idler (No. 1)
- ⑥ Tensioner bracket
- ⑦ Belt idler (No. 2)
- ⑧ Automatic belt tension adjuster ASSY
- ⑨ Belt idler No. 2
- ⑩ Camshaft sprocket No. 2
- ⑪ Timing belt
- ⑫ Belt cover (RH)

- ⑬ Front belt cover
- ⑭ Belt cover (LH)
- ⑮ Crankshaft pulley

Tightening torque: N·m (kg·m, ft·lb)


T1: 5±1 (0.5±0.1, 3.6±0.7)

T2: 25±3 (2.5±0.3, 18.1±2.2)

T3: 39±4 (4.0±0.4, 28.9±2.9)

T4: 78±5 (8.0±0.5, 57.9±3.6)

T5: 127±10 (13.0±1.0, 94±7)



1. General Precautions

1) Before disassembling engine, place it on ST3.

ST1	498457000	ENGINE STAND ADAPTER RH
ST2	498457100	ENGINE STAND ADAPTER LH
ST3	499817000	ENGINE STAND

2) All parts should be thoroughly cleaned, paying special attention to the engine oil passages, pistons and bearings.

3) Rotating parts and sliding parts such as piston, bearing and gear should be coated with oil prior to assembly.

4) Be careful not to let oil, grease or coolant contact the timing belt, clutch disc and flywheel.

5) All removed parts, if to be reused, should be reinstalled in the original positions and directions.

6) Gaskets and lock washers must be replaced with new ones. Liquid gasket should be used where specified to prevent leakage.


7) Bolts, nuts and washers should be replaced with new ones as required.

8) Even if necessary inspections have been made in advance, proceed with assembly work while making rechecks.

2. Timing Belt


A: REMOVAL

1. CRANKSHAFT PULLEY AND BELT COVER



- ① V-belt
- ② Crankshaft pulley bolt
- ③ Crankshaft pulley

- ④ Belt cover (LH)
- ⑤ Belt cover (RH)
- ⑥ Front belt cover




- 1) Remove V-belt and A/C belt tensioner.
- 2) Remove crankshaft pulley bolt. To lock crankshaft use ST.

ST 499977000 CRANKSHAFT PULLEY WRENCH

- 3) Remove crankshaft pulley.
- 4) Remove belt cover (LH).
- 5) Remove belt cover (RH).
- 6) Remove front belt cover.


2. TIMING BELT



H2M1564A


- (a) Alignment mark
(1) Belt idler (No. 2)

- (2) Belt idler No. 2
(3) Timing belt



G2M0110


1) If alignment mark (2) and/or arrow mark (which indicates rotation direction) on timing belt fade away, put new marks before removing timing belt as follows:



B2M0064A

(1) Turn crankshaft, and align alignment marks (2) on crankshaft sprocket, and left and right camshaft sprockets with notches (1) of belt cover and cylinder block.


ST 499987500 CRANKSHAFT SOCKET



(2) Using white paint, put alignment and/or arrow marks on timing belts in relation to the sprockets.

Z_1 : 44 tooth length

Z_2 : 40.5 tooth length




2) Loosen belt tensioner adjuster mounting bolts.

3) Remove belt idler (No. 2).

4) Remove belt idler No. 2.

5) Remove timing belt.

3. BELT TENSIONER AND IDLER




- ① Belt idler (No. 1)
- ② Belt tensioner ASSY

- ③ Belt tensioner adjuster

- 1) Remove belt idler (No. 1).
- 2) Remove belt tensioner assembly.
- 3) Remove belt tensioner adjuster.


4. SPROCKET



B2M0416A

- ① Camshaft sprocket No. 2
- ② Camshaft sprocket No. 1
- ③ Crankshaft sprocket

- ④ Belt cover No. 2 (LH)
- ⑤ Belt cover No. 2 (RH)
- ⑥ Tensioner bracket



G2M0114

- 1) Remove camshaft sprocket No. 2.
 - 2) Remove camshaft sprocket No. 1. To lock camshaft use ST.
- ST 499207100 CAMSHAFT SPROCKET WRENCH

- 3) Remove crankshaft sprocket.
- 4) Remove belt cover No. 2 (LH).
- 5) Remove belt cover No. 2 (RH).

CAUTION:

Do not damage or lose the seal rubber when removing belt covers.


- 6) Remove tensioner bracket.

B: INSPECTION**1. TIMING BELT**

- 1) Check timing belt teeth for breaks, cracks, and wear. If any fault is found, replace belt.
- 2) Check the condition of back side of belt; if any crack is found, replace belt.

CAUTION:

- Be careful not to let oil, grease or coolant contact the belt. Remove quickly and thoroughly if this happens.



- Do not bend the belt sharply.

Bending radius: h
60 mm (2.36 in) or more

2. BELT TENSIONER ADJUSTER


- 1) Visually check oil seals for leaks, and rod ends for abnormal wear or scratches. If necessary, replace belt tensioner adjuster.

CAUTION:

Slight traces of oil at rod' oil seal does not indicate a problem.

- 2) While holding belt tensioner adjuster with both hands, push the rod section against floor or wall ensuring the rod section will react as follows:

- (1) When applying a force of 147 N (15 kg, 33 lb), the rod section should not sink.
- (2) When applying a force of 147 to 490 N (15 to 50 kg, 33 to 110 lb), the rod section should maintain a projectionally acting force and should not sink within 8.5 seconds.



3) Measure the extension of rod beyond the body. If it is not within specifications, replace with a new one.

Rod extension: H

15.4 — 16.4 mm (0.606 — 0.646 in)

3. BELT TENSIONER


- 1) Check mating surfaces of timing belt and contact point of belt tensioner adjuster rod for abnormal wear or scratches. Replace belt tensioner if faulty.
- 2) Check spacer and tensioner bushing for wear.
- 3) Check belt tensioner for smooth rotation. Replace if noise or excessive play is noted.
- 4) Check belt tensioner for grease leakage.

4. BELT IDLER

- 1) Check belt idler for smooth rotation. Replace if noise or excessive play is noted.
- 2) Check outer contacting surfaces of belt idler for abnormal wear and scratches.
- 3) Check belt idler for grease leakage.


5. CAMSHAFT AND CRANKSHAFT SPROCKET

- 1) Check sprocket teeth for abnormal wear and scratches.
- 2) Make sure there is no free play between sprocket and key.
- 3) Check crankshaft sprocket notch for sensor for damage and contamination of foreign matter.

C: INSTALLATION**1. CAMSHAFT AND CRANKSHAFT SPROCKET**

B2M0416E

- | | |
|-------------------------|---------------------------|
| ① Belt cover No. 2 (RH) | ④ Crankshaft pulley |
| ② Tensioner bracket | ⑤ Camshaft sprocket No. 1 |
| ③ Belt cover No. 2 (LH) | ⑥ Camshaft sprocket No. 2 |


Tightening torque: N·m (kg·m, ft·lb)**T1: 5±1 (0.5±0.1, 3.6±0.7)****T2: 25±2 (2.5±0.2, 18.1±1.4)****T3: 78±5 (8.0±0.5, 57.9±3.6)**

- 1) Install belt cover No. 2 (RH).
- 2) Install tensioner bracket.
- 3) Install belt cover No. 2 (LH).
- 4) Install crankshaft sprocket.
- 5) Install camshaft sprocket No. 1 and camshaft sprocket No. 2. To lock camshaft use ST.

ST 499207100 CAMSHAFT SPROCKET WRENCH**CAUTION:**

Do not confuse left and right side camshaft sprockets during installation. The camshaft sprocket No. 2 is identified by a projection used to monitor camshaft position sensor.

2. BELT TENSIONER AND IDLER




G2M0118

- ① Belt tensioner adjuster
- ② Belt tensioner ASSY
- ③ Belt idler (No. 1)

Tightening torque: N·m (kg·m, ft·lb)

T1: 25±2 (2.5±0.2, 18.1±1.4)

T2: 39±4 (4.0±0.4, 28.9±2.9)



G2M0119

1) Installation of belt tensioner adjuster


(1) Insert stopper pin 1.5 mm (0.059 in) diameter into place while pushing adjuster rod into body using a press.

CAUTION:

- Do not allow press pressure to exceed 9,807 N (1,000 kg, 2,205 lb).
- Do not release press pressure until stopper pin is completely inserted.
- Push belt tensioner adjuster rod vertically.
- Press-in the push adjuster rod gradually taking three minutes or more.


(2) Install belt tensioner adjuster to tensioner bracket.

- 2) Install belt tensioner assembly.
- 3) Install belt idler (No. 1).




- 4) Temporarily tighten bolts while belt tensioner adjuster is pushed all the way to the right.

3. TIMING BELT



- Ⓐ Alignment mark
- ① Timing belt
- ② Belt idler No. 2
- ③ Belt idler (No. 2)


Tightening torque: N·m (kg-m, ft-lb)
T1: 25±2 (2.5±0.2, 18.1±1.4)
T2: 39±4 (4.0±0.4, 28.9±2.9)



1) Installation of timing belt.

(1) Using ST, turn left and right camshaft sprockets so that their alignment marks come to top positions.

ST 499207100 CAMSHAFT SPROCKET WRENCH




(2) While aligning alignment mark on timing belt with marks on sprockets, position timing belt properly.

CAUTION:


Ensure belt's rotating direction is correct.

2) Install belt idler No. 2.

3) Install belt idler (No. 2).




4) Loosen belt tensioner adjuster attaching bolts and move adjuster all the way to the left. Tighten the bolts.



5) After ensuring that the marks on timing belt and camshaft sprockets are aligned, remove stopper pin from belt tensioner adjuster.

4. CRANKSHAFT PULLEY AND BELT COVER




- ① Front belt cover
- ② Belt cover (RH)
- ③ Belt cover (LH)
- ④ Crankshaft pulley
- ⑤ Crankshaft pulley bolt
- ⑥ V-belt

Tightening torque: N·m (kg·m, ft·lb)

T1: 5 ± 1 (0.5 ± 0.1 , 3.6 ± 0.7)

T2: 127 ± 10 (13.0 ± 1.0 , 94 ± 7)


- 1) Install front belt cover.
- 2) Install belt cover (RH).
- 3) Install belt cover (LH).
- 4) Install crankshaft pulley.



- 5) Install pulley bolt.
To lock crankshaft, use ST.
ST 499977000 CRANKSHAFT PULLEY WRENCH
- 6) Install V-belt.

3. Valve Rocker Assembly


A: REMOVAL



B2M1206C

- ① Rocker cover
- ② Rocker cover gasket

- ③ Valve rocker ASSY
- ④ Knock pin



B2M1207C

1) Disconnect PCV hose and remove rocker cover.

2) Removal of valve rocker assembly


(1) Remove bolts ① through ④ in alphabetical sequence.

CAUTION:

Leave two or three threads of bolt ① engaged to retain valve rocker assembly.

(2) Equally loosen bolts ⑤ through ⑧ all the way, being careful that knock pin is not gouged.

(3) Remove valve rocker assembly.

B: DISASSEMBLY

B2M1264C

- ① Bolt
- ② Rocker shaft
- ③ Rocker shaft support
- ④ Intake valve rocker arm
- ⑤ Plate

- ⑥ Exhaust valve rocker arm
- ⑦ Spring
- ⑧ Valve rocker nut
- ⑨ Valve rocker adjust screw

- 1) Remove bolts which secure rocker shaft.
- 2) Extract rocker shaft. Remove valve rocker arms, plates, springs and shaft supports from rocker shaft.



CAUTION:

Arrange all removed parts in order so that they can be installed in their original positions.

- 3) Loosen valve rocker nut, and then remove valve rocker adjust screw and nut from valve rocker arm.

CAUTION:

Do not remove valve rocker adjust screw and valve rocker nut unless necessary.



C: INSPECTION

1. VALVE ROCKER ARM

1) Measure inside diameter of valve rocker arm and outside diameter of valve rocker shaft, and determine the difference between the two (= oil clearance).

Clearance between arm and shaft:

Standard

0.020 — 0.054 mm (0.0008 — 0.0021 in)

Limit

0.10 mm (0.0039 in)

If oil clearance exceeds specifications, replace valve rocker arm or shaft.

NOTE:

Replace valve rocker arm or shaft, whichever shows greater amount of wear.

Rocker arm inside diameter:

22.020 — 22.041 mm (0.8669 — 0.8678 in)

Rocker shaft diameter:

21.987 — 22.000 mm (0.8656 — 0.8661 in)

2) Measure inside diameter of rocker shaft support and outside diameter of valve rocker shaft, and determine the difference between the two (= oil clearance).

Clearance between support and shaft:

Standard

0.005 — 0.039 mm (0.0002 — 0.0015 in)

Limit

0.05 mm (0.0020 in)

If oil clearance exceeds specifications, replace rocker shaft support or shaft.

NOTE:

Replace rocker shaft support or shaft, whichever shows greater amount of wear.

Rocker shaft support inside diameter:

22.005 — 22.026 mm (0.8663 — 0.8672 in)

Rocker shaft diameter:

21.987 — 22.000 mm (0.8656 — 0.8661 in)

3) If cam or valve contact surface of valve rocker arm is worn or dented excessively, replace valve rocker arm.

4) Check that valve rocker arm roller rotates smoothly. If not, replace valve rocker arm.

2. VALVE ROCKER SHAFT


Visually check oil relief valve of shaft end for any of the following abnormalities.

- Breaks in check ball body
- Foreign particles caught in valve spring
- Oil leaks at check ball

CAUTION:

Repair or replace valve rocker shaft as necessary.

D: ASSEMBLY



B2M1264D

- ① Valve rocker adjust screw
- ② Valve rocker nut
- ③ Intake valve rocker arm
- ④ Exhaust valve rocker arm
- ⑤ Spring
- ⑥ Plate
- ⑦ Rocker shaft

- ⑧ Rocker shaft support
- ⑨ Bolt
- A Oil hole
- B Lock hole

Tightening torque: N·m (kg·m, ft·lb)
T: 5±1 (0.5±0.1, 3.6±0.7)

1) Install valve rocker adjust screw and valve rocker nut to valve rocker arm, and loosely tighten nut.


2) Arrange valve rocker arms, plates, springs and rocker shaft supports in assembly order and insert valve rocker shaft. Ensure that cutout portion of rocker shaft faces oil holes (A) in rocker shaft supports.

CAUTION:

Valve rocker arms, rocker shaft and rocker shaft supports have identification marks. Ensure parts with same markings are properly assembled.

3) Install valve rocker shaft securing bolts while aligning shaft "lock" holes (B) with bolts.

E: INSTALLATION




- ① Valve rocker ASSY
- ② Knock pin
- ③ Rocker cover gasket
- ④ Rocker cover

Tightening torque: N·m (kg-m, ft-lb)

T1: 5 ± 1 (0.5 ± 0.1 , 3.6 ± 0.7)

T2: 12 ± 1 (1.2 ± 0.1 , 8.7 ± 0.7)



1) Installation of valve rocker assembly

- (1) Temporarily tighten bolts ① through ④ equally as shown in Figure.

CAUTION:

Do not allow valve rocker assembly to gouge knock pins.

- (2) Tighten bolts ⑤ through ⑧ to specified torque.
 (3) Tighten bolts ① through ④ to specified torque.

Tightening torque:

12 ± 1 N·m (1.2 ± 0.1 kg-m, 8.7 ± 0.7 ft-lb)

- 2) Adjust the valve clearances. <Ref. to 2-2 [07B0].>
 3) Install rocker cover and connect PCV hose.

4. Camshaft

A: REMOVAL

1. RELATED PARTS


1) Remove timing belt, camshaft sprockets and related parts.

<Ref. to 2-3 [W2A0].>

2) Remove valve rocker assembly.

<Ref. to 2-3 [W3A0].>

2. CAMSHAFT (LH)



- ① Camshaft position sensor
- ② Bolt
- ③ Camshaft support (LH)

- ④ O-ring
- ⑤ Camshaft (LH)
- ⑥ Oil seal

1) Remove camshaft position sensor.

CAUTION:

Do not damage the camshaft position sensor.

2) Remove oil level gauge guide attaching bolt.

3) Remove camshaft support (LH).

4) Remove O-ring.


5) Remove camshaft (LH).

6) Remove oil seal.

CAUTION:

- Do not remove oil seal unless necessary.
- Do not scratch journal surface when removing oil seal.

3. CAMSHAFT (RH)




- ① Camshaft support (RH)
- ② O-ring

- ③ Camshaft (RH)
- ④ Oil seal

- 1) Remove camshaft support (RH).
- 2) Remove O-ring.
- 3) Remove camshaft (RH).
- 4) Remove oil seal.

CAUTION:

- Do not remove oil seal unless necessary.
- Do not scratch journal surface when removing oil seal.

**B: INSPECTION****1. CAMSHAFT**

1) Measure the bend, and repair or replace if necessary.


Limit:

0.025 mm (0.0010 in)

2) Check journal for damage and wear. Replace if faulty.

3) Measure outside diameter of camshaft journal and inside diameter of cylinder head journal, and determine the difference between the two (= oil clearance). If oil clearance exceeds specifications, replace camshaft or cylinder head as necessary.

Unit: mm (in)				
Item	Right-hand camshaft	Front	Center	Rear
	Left-hand camshaft	Rear	Center	Front
Clearance at journal	Standard	0.055 — 0.090 (0.0022 — 0.0035)		
	Limit	0.10 (0.0039)		
Camshaft journal O.D.		31.935 — 31.950 (1.2573 — 1.2579)	37.435 — 37.450 (1.4738 — 1.4744)	37.935 — 37.950 (1.4935 — 1.4941)
Journal hole I.D.		32.005 — 32.025 (1.2600 — 1.2608)	37.505 — 37.525 (1.4766 — 1.4774)	38.005 — 38.025 (1.4963 — 1.4970)



4) Check cam face condition; remove minor faults by grinding with oil stone. Measure the cam height H; replace if the limit has been exceeded.

Cam height: H

Standard

IN: 32.244 — 32.344 mm (1.2694 — 1.2734 in)

EX: 31.964 — 32.064 mm (1.2584 — 1.2624 in)

Limit


IN: 32.094 mm (1.2635 in)

EX: 31.814 mm (1.2525 in)

Cam base circle diameter A:

IN: 27.5 mm (1.083 in)

EX: 27.0 mm (1.063 in)



2. CAMSHAFT SUPPORT


Measure the thrust clearance of camshaft with dial gauge. If the clearance exceeds the limit, replace camshaft support.

Standard:

0.030 — 0.260 mm (0.0012 — 0.0102 in)

Limit:

0.35 mm (0.0138 in)

C: INSTALLATION**1. CAMSHAFT (LH)**

- ① Camshaft (LH)
- ② O-ring
- ③ Camshaft support (LH)

- ④ Oil seal
- ⑤ Bolt
- ⑥ Camshaft position sensor
- ★: Replacement part

Tightening torque: N·m (kg-m, ft-lb)

T1: 5 (0.5, 3.6)

T2: 10 (1.0, 7)

T3: 16 (1.6, 12)

1) Apply a coat of engine oil to camshaft journals and install camshaft (LH).


2) Apply a coat of engine oil or grease to O-ring.

3) Install O-ring to camshaft support (LH).

CAUTION:

Use a new O-ring.

4) Install camshaft support (LH).



5) Apply a coat of grease to oil seal lips and install oil seal on camshaft support (LH) by using ST1 and ST2.

CAUTION:

Use a new oil seal.


ST1 499597000 OIL SEAL GUIDE

ST2 499587100 OIL SEAL INSTALLER

6) Install oil level gauge guide bolt.

7) Install camshaft position sensor.

2. CAMSHAFT (RH)



- ① Camshaft (RH)
- ② O-ring
- ③ Camshaft support (RH)

- ④ Oil seal
- ★: Replacement part


Tightening torque: N·m (kg·m, ft·lb)
T: 16 (1.6, 1.2)

- 1) Apply a coat of engine oil to camshaft journals and install camshaft (RH).
- 2) Apply a coat of engine oil or grease to O-ring.
- 3) Install O-ring to camshaft support (RH).

CAUTION:

Use a new O-ring.

- 4) Install camshaft support (RH).



- 5) Install oil seal by using ST1 and ST2.

CAUTION:

Use a new oil seal.

ST1 499597000 OIL SEAL GUIDE
 ST2 499587100 OIL SEAL INSTALLER


3. RELATED PARTS

- 1) Install valve rocker assembly.
<Ref. to 2-3 [W3E0].>
- 2) Install timing belt, camshaft sprockets and related parts.
<Ref. to 2-3 [W2C0].>

5. Cylinder Head**A: REMOVAL****1. RELATED PARTS**

- 1) Release fuel pressure. <Ref. to 2-8 [W1B0].>
- 2) Drain engine coolant. <Ref. to 2-5 [W1A0].>
- 3) Remove V-belt.
- 4) Remove alternator and bracket.
- 5) Disconnect spark plug cords.
- 6) Remove connector bracket attaching bolt.
- 7) Remove crankshaft position sensor and camshaft position sensor.
- 8) Disconnect oil pressure switch connector.
- 9) Disconnect blow-by hose.
- 10) Remove EGR pipe. (AT vehicles only)
- 11) Remove intake manifold and gasket. <Ref. to 2-7 [W4A0].>
- 12) Remove water pipe.

2. CYLINDER HEAD



B2M0119E


- ① Cylinder head bolt
- ② Cylinder head

- ③ Cylinder head gasket

1) Remove timing belt, camshaft sprocket and related parts.

<Ref. to 2-3 [W2A0].>

2) Remove oil level gauge guide attaching bolt (left hand only) and oil level gauge guide.



3) Remove cylinder head bolts in alphabetical sequence shown in Figure.

CAUTION:

Leave bolts (A) and (C) engaged by three or four threads to prevent cylinder head from falling.

4) While tapping cylinder head with a plastic hammer, separate it from cylinder block.

5) Remove bolts (A) and (C) to remove cylinder head.


6) Remove cylinder head gasket.

CAUTION:

Do not scratch the mating surface of cylinder head and cylinder block.

7) Similarly, remove right side cylinder head.

B: DISASSEMBLY




H2M1541A

- ① Rocker cover
- ② Valve rocker ASSY
- ③ Camshaft support

- ④ Camshaft
- ⑤ Oil seal

- 1) Remove rocker cover.
- 2) Remove valve rocker assembly.
<Ref. to 2-3 [W3A0].>
- 3) Remove camshaft and support.
<Ref. to 2-3 [W4A0].>
- 4) Place cylinder head on ST.
ST 498267200 CYLINDER HEAD TABLE



5) Set ST on valve spring. Compress valve spring and remove the valve spring retainer key. Remove each valve and valve spring.

ST 499718000 VALVE SPRING REMOVER

CAUTION:

- Mark each valve to prevent confusion.
- Use extreme care not to damage the lips of the intake valve oil seals and exhaust valve oil seals.

6) Removal of plug (cylinder head LH).

CAUTION:

Do not remove plug unless necessary.

C: INSPECTION


1. CYLINDER HEAD

1) Make sure that no crack or other damage exists. In addition to visual inspection, inspect important areas by means of red lead check.

Also make sure that gasket installing surface shows no trace of gas and water leaks.

2) Place cylinder head on ST.

ST 498267200 CYLINDER HEAD TABLE



3) Measure the warping of the cylinder head surface that mates with crankcase by using a straight edge and thickness gauge.

If the warping exceeds 0.05 mm (0.0020 in), regrind the surface with a surface grinder.

Warping limit:

0.05 mm (0.0020 in)

Grinding limit:






0.1 mm (0.004 in)

Standard height of cylinder head:

98.3 mm (3.870 in)

CAUTION:

Uneven torque for the cylinder head bolts can cause warping. When reassembling, pay special attention to the torque so as to tighten evenly.



2. VALVE SEAT

Inspect intake and exhaust valve seats, and correct the contact surfaces with valve seat cutter if they are defective or when valve guides are replaced.

Valve seat width: *W*

Intake

Standard

0.7 mm (0.028 in)

Limit

1.4 mm (0.055 in)

Exhaust

Standard

1.4 mm (0.055 in)

Limit

1.8 mm (0.071 in)

3. VALVE GUIDE

1) Check the clearance between valve guide and stem. The clearance can be checked by measuring the outside diameter of valve stem and the inside diameter of valve guide with outside and inside micrometers respectively.

Clearance between the valve guide and valve stem:

Standard

Intake

0.035 — 0.062 mm (0.0014 — 0.0024 in)

Exhaust

0.040 — 0.067 mm (0.0016 — 0.0026 in)

Limit

0.15 mm (0.0059 in)

Valve guide inner diameters:

6.000 — 6.012 mm (0.2362 — 0.2367 in)

Valve stem outer diameter:

Intake

5.950 — 5.965 mm (0.2343 — 0.2348 in)

Exhaust


5.945 — 5.960 mm (0.2341 — 0.2346 in)

2) If the clearance between valve guide and stem exceeds the specification, replace guide as follows:

(1) Place cylinder head on ST1 with the combustion chamber upward so that valve guides enter the holes in ST1.


(2) Insert ST2 into valve guide and press it down to remove valve guide.

ST1 498267200 CYLINDER HEAD TABLE
ST2 499767200 VALVE GUIDE REMOVER



(3) Turn cylinder head upside down and place ST as shown in the Figure.

ST 499767000 VALVE GUIDE ADJUSTER




(4) Before installing new oversize valve guide, make sure that neither scratches nor damages exist on the inside surface of the valve guide holes in cylinder head.

(5) Put new valve guide, coated with sufficient oil, in cylinder, and insert ST1 into valve guide. Press in until the valve guide upper end is flush with the upper surface of ST2.

ST1 499767200 VALVE GUIDE REMOVER


ST2 499767000 VALVE GUIDE ADJUSTER



(6) Check the valve guide protrusion.

Valve guide protrusion: L

17.5 — 18.0 mm (0.689 — 0.709 in)




(7) Ream the inside of valve guide with ST. Gently rotate the reamer clockwise while pressing it lightly into valve guide, and return it also rotating clockwise. After reaming, clean valve guide to remove chips.

ST 499767400 VALVE GUIDE REAMER

CAUTION:

- Apply engine oil to the reamer when reaming.
- If the inner surface of the valve guide is torn, the edge of the reamer should be slightly ground with an oil stone.
- If the inner surface of the valve guide becomes lustrous and the reamer does not chips, use a new reamer or remedy the reamer.

- (8) Recheck the contact condition between valve and valve seat after replacing valve guide.



4. INTAKE AND EXHAUST VALVE

- 1) Inspect the flange and stem of valve, and replace if damaged, worn, or deformed, or if "H" is less than the specified limit.

H:

Intake

Standard

1.0 mm (0.039 in)

Limit

0.8 mm (0.031 in)

Exhaust

Standard

1.2 mm (0.047 in)

Limit

0.8 mm (0.031 in)

Valve overall length:


Intake

101.0 mm (3.976 in)

Exhaust

101.2 mm (3.984 in)

- 2) Put a small amount of grinding compound on the seat surface and lap the valve and seat surface. Also refer to "2. VALVE SEAT" at this time <Ref. to 2-3 [W5C2].>. Install a new intake valve oil seal after lapping.




5. VALVE SPRINGS

1) Check valve springs for damage, free length, and tension. Replace valve spring if it is not to the specifications presented below.

2) To measure the squareness of the valve spring, stand the spring on a surface plate and measure its deflection at the top using a try square.

Free length	44.05 mm (1.7342 in)
Squareness	2.5°, 1.9 mm (0.075 in)
Tension/spring height	174.6 — 200.1 N (17.8 — 20.4 kg, 39.2 — 45.0 lb)/ 36.0 mm (1.417 in)
	405.0 — 458.0 N (41.3 — 46.7 kg, 91.1 — 103.0 lb)/ 28.2 mm (1.110 in)



6. INTAKE AND EXHAUST VALVE OIL SEAL

Replace oil seal with new one, if lip is damaged or spring out of place, or when the surfaces of intake valve and valve seat are reconditioned or intake valve guide is replaced.

1) Place cylinder head on ST1.

2) Press in oil seal to the specified dimension indicated in the Figure by using ST2.

ST1 498267200 CYLINDER HEAD TABLE

ST2 498857100 VALVE OIL SEAL GUIDE

CAUTION:

- Apply engine oil to oil seal before force-fitting.
- When press-fitting oil seal, do not use a hammer or strike into position.
- Differentiate between intake valve oil seal and exhaust valve oil seal by noting their difference in color.

Color of rubber part:

Intake [Black]


Exhaust [Brown]

Color of spring part:

Intake [Silver]

Exhaust [Silver]

D: ASSEMBLY



- ① Oil seal
- ② Camshaft
- ③ Camshaft support

- ④ Valve rocker ASSY
- ⑤ Rocker cover
- ★: Replacement part

Tightening torque: N·m (kg·m, ft·lb)
T1: 5±1 (0.5±0.1, 3.6±0.7)
T2: 10 (1.0, 7)
T3: 12±1 (1.2±0.1, 8.7±0.7)
T4: 16 (1.6, 12)

1) Install plug (cylinder head LH) by using ST.

ST 499587100 OIL SEAL INSTALLER

2) Installation of valve spring and valve


(1) Place cylinder head on ST.

ST 498267200 CYLINDER HEAD TABLE

(2) Coat stem of each valve with engine oil and insert valve into valve guide.

CAUTION:

When inserting valve into valve guide, use special care not to damage the oil seal lip.



(3) Install valve spring and retainer.


CAUTION:

Be sure to install the valve springs with their painted facing towards the valve spring retainer.

(4) Set ST on valve spring.

ST 499718000 VALVE SPRING REMOVER

(5) Compress valve spring and fit valve spring retainer key.



(6) After installing, tap valve spring retainers lightly with wooden hammer for better seating.


3) Install camshaft and support.

<Ref. to 2-3 [W4C0].>

4) Install valve rocker assembly.

<Ref. to 2-3 [W3E0].>

5) Install rocker cover.

E: INSTALLATION**1. CYLINDER HEAD**

B2M0119F


- ① Cylinder head gasket
- ② Cylinder head

- ③ Cylinder head bolt

1) Install cylinder head and gaskets on cylinder block.

CAUTION:

Use new cylinder head gaskets.



B2M0120F

2) Tighten cylinder head bolts.

(1) Apply a coat of engine oil to washers and bolt threads.

(2) Tighten all bolts to 29 N·m (3.0 kg-m, 22 ft-lb) in alphabetical sequence.

Then tighten all bolts to 69 N·m (7.0 kg-m, 51 ft-lb) in alphabetical sequence.

(3) Back off all bolts by 180° first; back them off by 180° again.

(4) Tighten bolts ① and ② to 34 N·m (3.5 kg-m, 25 ft-lb).

(5) Tighten bolts ③, ④, ⑤ and ⑥ to 15 N·m (1.5 kg-m, 11 ft-lb).

(6) Tighten all bolts by 80 to 90° in alphabetical sequence.

CAUTION:

Do not tighten bolts more than 90°.

(7) Further tighten all bolts by 80 to 90° in alphabetical sequence.

CAUTION:

Ensure that the total “re-tightening angle” [in the former two steps] does not exceed 180°.

3) Install oil level gauge guide attaching bolt (left hand only).

4) Install timing belt, camshaft sprocket and related parts.
<Ref. to 2-3 [W2C0].>

2. RELATED PARTS

CAUTION:

Use dry compressed air to remove foreign particles before installing each solenoid valve and sensor.

- 1) Install water pipe.
- 2) Install intake manifold. <Ref. to 2-7 [W4D0].>
- 3) Connect blow-by hose.
- 4) Install EGR pipe. (AT vehicles only)
- 5) Connect oil pressure switch connector.
- 6) Install crankshaft position sensor and camshaft position sensor.
- 7) Install connector bracket attaching bolt.
- 8) Connect spark plug cords.
- 9) Install alternator and bracket.
- 10) Install V-belt.
- 11) Remove engine stand.

6. Cylinder Block


A: REMOVAL

1. RELATED PARTS

1) Remove timing belt, camshaft sprocket and related parts.
<Ref. to 2-3 [W2A0].>

2) Remove intake manifold and cylinder head.
<Ref. to 2-3 [W5A0].>

2. OIL PUMP AND WATER PUMP




B2M0124E

- ① Clutch housing cover (MT vehicles)
- ② Oil separator cover
- ③ Water by-pass pipe
- ④ Water pump
- ⑤ Oil pump

- ⑥ Oil pan
- ⑦ Oil strainer stay
- ⑧ Oil strainer
- ⑨ Baffle plate
- ⑩ Oil filter


- 1) Remove clutch housing cover. (MT vehicles only)



- 2) Remove flywheel or drive plate.
To lock crankshaft use ST.

ST 498497100 CRANKSHAFT STOPPER


- 3) Remove oil separator cover.
- 4) Remove water pipe and water by-pass pipe.
- 5) Remove water pump.



- 6) Remove oil pump from cylinder block.
Use a flat-bladed screwdriver as shown in Figure when removing oil pump.

CAUTION:

Be careful not to scratch the mating surface of cylinder block and oil pump.




7) Removal of oil pan.

- (1) Turn cylinder block with #2 and #4 piston sides facing upward.
- (2) Remove bolts which secure oil pan to cylinder block.
- (3) Insert a oil pan cutter blade between cylinder block-to-oil pan clearance and remove oil pan.

CAUTION:

Do not use a screwdriver or similar tool in place of oil-pan cutter blade.


- 8) Remove oil strainer stay.
- 9) Remove oil strainer.
- 10) Remove baffle plate.
- 11) Remove oil filter.

B: DISASSEMBLY**1. PISTON PIN AND CYLINDER BLOCK
CONNECTING BOLT**


- ① Service hole plug
- ② Service hole cover
- ③ Gasket

- ④ Circlip
- ⑤ Piston pin

1) Remove service hole cover and service hole plugs using hexagon wrench (14 mm).



2) Rotate crankshaft to bring #1 and #2 pistons to BDC position, then remove piston circlip through service hole of #1 and #2 cylinders.



- 3) Draw out piston pin from #1 and #2 pistons by using ST.
ST 499097500 PISTON PIN REMOVER

CAUTION:

Be careful not to confuse original combination of piston, piston pin and cylinder.


- 4) Similarly remove piston pins from #3 and #4 pistons by using ST.

ST 499097500 PISTON PIN REMOVER

- 5) Remove bolts which connect cylinder block on the side of #2 and #4 cylinders.

- 6) Back off bolts which connect cylinder block on the side of #1 and #3 cylinders two or three turns.

2. CYLINDER BLOCK



B2M1319B

- ① Bolt
- ② Cylinder block (RH)
- ③ Cylinder block (LH)
- ④ Rear oil seal

- ⑤ Crankshaft
- ⑥ Connecting rod
- ⑦ Crankshaft bearing
- ⑧ Piston

1) Set up cylinder block so that #1 and #3 cylinders are on the upper side, then remove cylinder block connecting bolts.

2) Separate left-hand and right-hand cylinder blocks.

CAUTION:

When separating cylinder block, do not allow the connecting rod to fall and damage the cylinder block.

3) Remove rear oil seal.

4) Remove crankshaft together with connecting rod.

5) Remove crankshaft bearings from cylinder block using hammer handle.

CAUTION:


Do not confuse combination of crankshaft bearings. Press bearing at the end opposite to locking lip.

6) Draw out each piston from cylinder block using wooden bar or hammer handle.

CAUTION:

Do not confuse combination of piston and cylinder.

3. CRANKSHAFT AND PISTON



- ① Connecting rod cap
- ② Connecting rod bearing
- ③ Top ring

- ④ Second ring
- ⑤ Oil ring
- ⑥ Circlip

- 1) Remove connecting rod cap.
- 2) Remove connecting rod bearing.

CAUTION:

Arrange removed connecting rod, connecting rod cap and bearing in order to prevent confusion.

- 3) Remove piston top and second rings using the piston ring expander.
- 4) Remove the oil ring by hand.


CAUTION:

Arrange the removed piston rings in good order to prevent confusion.

- 5) Remove circlip.

C: INSPECTION**1. CYLINDER BLOCK**

- 1) Check for cracks and damage visually. Especially, inspect important parts by means of red lead check.
- 2) Check the oil passages for clogging.
- 3) Inspect crankcase surface that mates with cylinder head for warping by using a straight edge, and correct by grinding if necessary.



Warping limit:**0.05 mm (0.0020 in)****Grinding limit:****0.1 mm (0.004 in)****Standard height of cylinder block:****201.0 mm (7.91 in)****2. CYLINDER AND PISTON**

- 1) The cylinder bore size is stamped on the cylinder block's front upper surface.

NOTE:

Standard sized pistons are classified into two grades, "A" and "B". These grades should be used as a guideline in selecting a standard piston.

Standard diameter:**1800 cc:****A: 87.905 — 87.915 mm (3.4608 — 3.4612 in)****B: 87.895 — 87.905 mm (3.4604 — 3.4608 in)****2200 cc:****A: 96.905 — 96.915 mm (3.8151 — 3.8155 in)****B: 96.895 — 96.905 mm (3.8148 — 3.8151 in)**



2) How to measure the inner diameter of each cylinder
Measure the inner diameter of each cylinder in both the thrust and piston pin directions at the heights shown in the Figure, using a cylinder bore gauge.

CAUTION:

Measurement should be performed at a temperature 20°C (68°F).

● **Taper:****Standard**

0.015 mm (0.0006 in)

Limit

0.050 mm (0.0020 in)

● **Out-of-roundness:****Standard**

0.010 mm (0.0004 in)

Limit

0.050 mm (0.0020 in)

3) When piston is to be replaced due to general or cylinder wear, determine a suitable sized piston by measuring the piston clearance.

4) How to measure the outer diameter of each piston
Measure the outer diameter of each piston at the height shown in the Figure. (Thrust direction)

CAUTION:

Measurement should be performed at a temperature of 20°C (68°F).

● **Piston grade point H:**

40.0 mm (1.575 in)

● **Piston outer diameter:**● **1800 cc:****Standard**

A: 87.885 — 87.895 mm (3.4600 — 3.4604 in)

B: 87.875 — 87.885 mm (3.4596 — 3.4600 in)

0.25 mm (0.0098 in) oversize

88.125 — 88.135 mm (3.4695 — 3.4699 in)

0.50 mm (0.0197 in) oversize

88.375 — 88.385 mm (3.4793 — 3.4797 in)

● **2200 cc:****Standard**

A: 96.885 — 96.895 mm (3.8144 — 3.8148 in)

B: 96.875 — 96.885 mm (3.8140 — 3.8144 in)

0.25 mm (0.0098 in) oversize

97.115 — 97.145 mm (3.8234 — 3.8246 in)

0.50 mm (0.0197 in) oversize

97.365 — 97.395 mm (3.8333 — 3.8344 in)

5) Calculate the clearance between cylinder and piston.

CAUTION:

Measurement should be performed at a temperature of 20°C (68°F).

Cylinder to piston clearance at 20°C (68°F):

Standard

0.010 — 0.030 mm (0.0004 — 0.0012 in)

Limit

0.050 mm (0.0020 in)

6) Boring and honing

(1) If the value of taper, out-of-roundness, or cylinder-to-piston clearance measured exceeds the specified limit or if there is any damage on the cylinder wall, rebore it to use an oversize piston.

CAUTION:

When any of the cylinders needs reboring, all other cylinders must be bored at the same time, and use oversize pistons. Do not perform boring on one cylinder only, nor use an oversize piston for one cylinder only.

(2) If the cylinder inner diameter exceeds the limit after boring and honing, replace the crankcase.

CAUTION:

Immediately after reboring, the cylinder diameter may differ from its real diameter due to temperature rise. Thus, pay attention to this when measuring the cylinder diameter.


Limit of cylinder enlarging (boring):

0.5 mm (0.020 in)

3. PISTON AND PISTON PIN

1) Check pistons and piston pins for damage, cracks, and wear and the piston ring grooves for wear and damage. Replace if defective.

2) Measure the piston-to-cylinder clearance at each cylinder as instructed in "2. CYLINDER AND PISTON". <Ref. to 2-3 [W6C2].> If any of the clearances is not to specification, replace the piston or bore the cylinder to use an oversize piston.



3) Make sure that piston pin can be inserted into the piston pin hole with a thumb at 20°C (68°F). Replace if defective.



Standard clearance between piston pin and hole in piston:

Standard

0.004 — 0.010 mm (0.0002 — 0.0004 in)


Limit

0.020 mm (0.0008 in)



4) Check circlip installation groove on the piston for burr. If necessary, remove burr from the groove so that piston pin can lightly move.

5) Check piston pin circlip for distortion, cracks and wear.




4. PISTON RING


1) If piston ring is broken, damaged, or worn, or if its tension is insufficient, or when the piston is replaced, replace piston ring with a new one of the same size as the piston.

CAUTION:

● "R" is marked on the end of the top and second rings. When installing the rings to the piston, face this mark upward.




- The oil ring is a combined ring consisting of two rails and a spacer in between. When installing, be careful to assemble correctly.



- 2) Squarely place piston ring and oil ring in cylinder, and measure the piston ring gap with a thickness gauge.

Item		Unit: mm (in)	
		Standard	Limit
Piston ring gap	Top ring	0.20 — 0.35 (0.0079 — 0.0138)	1.0 (0.039)
	Second ring	0.20 — 0.50 (0.0079 — 0.0197)	1.0 (0.039)
	Oil ring rail	0.20 — 0.70 (0.0079 — 0.0276)	1.5 (0.059)



- 3) Measure the clearance between piston ring and piston ring groove with a thickness gauge.


CAUTION:

Before measuring the clearance, clean the piston ring groove and piston ring.

Item		Unit: mm (in)	
		Standard	Limit
Clearance between piston ring and piston ring groove	Top ring	0.040 — 0.080 (0.0016 — 0.0031)	0.15 (0.0059)
	Second ring	0.030 — 0.070 (0.0012 — 0.0028)	0.15 (0.0059)


5. CONNECTING ROD

- 1) Replace connecting rod, if the large or small end thrust surface is damaged.



2) Check for bend or twist using a connecting rod aligner. Replace connecting rod if the bend or twist exceeds the limit.

**Limit of bend or twist per 100 mm (3.94 in) in length:
0.10 mm (0.0039 in)**



3) Install connecting rod fitted with bearing to crankshaft and measure the side clearance (thrust clearance). Replace connecting rod if the side clearance exceeds the specified limit.

Connecting rod side clearance:

Standard

0.070 — 0.330 mm (0.0028 — 0.0130 in)

Limit

0.4 mm (0.016 in)

4) Inspect connecting rod bearing for scar, peeling, seizure, melting, wear, etc.

5) Measure the oil clearance on individual connecting rod bearings by means of plastigauge. If any oil clearance is not within specification, replace the defective bearing with a new one of standard size or undersize as necessary.

Connecting rod oil clearance:


Standard

0.015 — 0.045 mm (0.0006 — 0.0018 in)

Limit

0.05 mm (0.0020 in)

Unit: mm (in)		
Bearing	Bearing size (Thickness at center)	Outer diameter of crank pin
Standard	1.492 — 1.501 (0.0587 — 0.0591)	51.984 — 52.000 (2.0466 — 2.0472)
0.03 (0.0012) undersize	1.510 — 1.513 (0.0594 — 0.0596)	51.954 — 51.970 (2.0454 — 2.0461)
0.05 (0.0020) undersize	1.520 — 1.523 (0.0598 — 0.0600)	51.934 — 51.950 (2.0446 — 2.0453)
0.25 (0.0098) undersize	1.620 — 1.623 (0.0638 — 0.0639)	51.734 — 51.750 (2.0368 — 2.0374)



6) Inspect bushing at connecting rod small end, and replace if worn or damaged. Also measure the piston pin clearance at the connecting rod small end.



Clearance between piston pin and bushing:

Standard

0 — 0.022 mm (0 — 0.0009 in)

Limit

0.030 mm (0.0012 in)



7) Replacement procedure is as follows.

- (1) Remove bushing from connecting rod with ST and press.
- (2) Press bushing with ST after applying oil on the periphery of bushing.


ST 499037100 CONNECTING ROD BUSHING
REMOVER AND INSTALLER

- (3) Make two 3 mm (0.12 in) holes in bushing. Ream the inside of bushing.

(4) After completion of reaming, clean bushing to remove chips.

6. CRANKSHAFT AND CRANKSHAFT BEARING

1) Clean crankshaft completely and check for cracks by means of red lead check etc., and replace if defective.




2) Measure the crankshaft bend, and correct or replace if it exceeds the limit.

CAUTION:

If a suitable V-block is not available, install #1 and #5 crankshaft bearing on cylinder block, position crankshaft on these bearings and measure crankshaft bend using a dial gauge.

Crankshaft bend limit:
0.035 mm (0.0014 in)



3) Inspect the crank journal and crank pin for wear. If not to specifications, replace bearing with an undersize one, and replace or recondition crankshaft as necessary. When grinding crank journal or crank pin, finish them to the specified dimensions according to the undersize bearing to be used.

Crank pin and crank journal:

Out-of-roundness

0.030 mm (0.0012 in) or less

Taper limit


0.07 mm (0.0028 in)

Grinding limit

0.25 mm (0.0098 in)

Unit: mm (in)				
		Crank journal diameter		Crank pin diameter
		#1, #5	#2, #3, #4	
Standard	Journal O.D.	59.992 — 60.008 (2.3619 — 2.3625)	59.992 — 60.008 (2.3619 — 2.3625)	51.984 — 52.000 (2.0466 — 2.0472)
	Bearing size (Thickness at center)	1.998 — 2.011 (0.0787 — 0.0792)	2.000 — 2.013 (0.0787 — 0.0793)	1.492 — 1.501 (0.0587 — 0.0591)
0.03 (0.0012) undersize	Journal O.D.	59.962 — 59.978 (2.3607 — 2.3613)	59.954 — 59.970 (2.3604 — 2.3610)	51.954 — 51.970 (2.0454 — 2.0461)
	Bearing size (Thickness at center)	2.017 — 2.020 (0.0794 — 0.0795)	2.019 — 2.022 (0.0795 — 0.0796)	1.510 — 1.513 (0.0594 — 0.0596)
0.05 (0.0020) undersize	Journal O.D.	59.934 — 59.950 (2.3596 — 2.3602)	59.934 — 59.950 (2.3596 — 2.3602)	51.934 — 51.950 (2.0446 — 2.0453)
	Bearing size (Thickness at center)	2.027 — 2.030 (0.0798 — 0.0799)	2.029 — 2.032 (0.0799 — 0.0800)	1.520 — 1.523 (0.0598 — 0.0600)
0.25 (0.0098) undersize	Journal O.D.	59.742 — 59.758 (2.3520 — 2.3527)	59.734 — 59.750 (2.3517 — 2.3524)	51.734 — 51.750 (2.0368 — 2.0374)
	Bearing size (Thickness at center)	2.127 — 2.130 (0.0837 — 0.0839)	2.129 — 2.132 (0.0838 — 0.0839)	1.620 — 1.623 (0.0638 — 0.0639)

O.D. ... Outer Diameter



4) Measure the thrust clearance of crankshaft at center bearing. If the clearance exceeds the limit, replace bearing.

Crankshaft thrust clearance:

Standard

0.030 — 0.115 mm (0.0012 — 0.0045 in)


Limit

0.25 mm (0.0098 in)

5) Inspect individual crankshaft bearings for signs of flaking, seizure, melting, and wear.

6) Measure the oil clearance on each crankshaft bearing by means of plastigauge. If the measurement is not within the specification, replace defective bearing with an under-size one, and replace or recondition crankshaft as necessary.

Unit: mm (in)		
Crankshaft oil clearance		
Standard	#1, #5	0.003 — 0.030 (0.0001 — 0.0012)
	#2, #3, #4	0.010 — 0.033 (0.0004 — 0.0013)
Limit	#1, #3, #5	0.040 (0.0016)
	#2, #4	0.035 (0.0014)

D: ASSEMBLY**1. CRANKSHAFT AND PISTON**

- ① Connecting rod bearing
- ② Connecting rod
- ③ Connecting rod cap
- ④ Oil ring
- ⑤ Second ring

- ⑥ Top ring
- ⑦ Circlip
- ★: Replacement part

Tightening torque: N·m (kg·m, ft·lb)
T: 44±2 (4.5±0.2, 32.5±1.4)

1) Install connecting rod bearings on connecting rods and connecting rod caps.

CAUTION:

Apply oil to the surfaces of the connecting rod bearings.

2) Install connecting rod on crankshaft.

CAUTION:

Position each connecting rod with the side marked facing forward.






3) Install connecting rod cap with connecting rod nut.

Ensure the arrow on connecting rod cap faces the front during installation.

CAUTION:

- Each connecting rod has its own mating cap. Make sure that they are assembled correctly by checking their matching number.

- When tightening the connecting rod nuts, apply oil on the threads.



4) Installation of piston rings and oil ring

(1) Install oil ring spacer, upper rail and lower rail in this order by hand. Then install second ring and top ring with a piston ring expander.

(2) Position the top ring gap at A or B in the Figure.

(3) Position the second ring gap at 180° on the reverse side for the top ring gap.

(4) Position the upper rail gap at C or D in the Figure.

(5) Position the expander gap at 180° of the reverse side for the upper rail gap.

(6) Position the lower rail gap at E or F in the Figure.

CAUTION:

- Ensure ring gaps do not face the same direction.
- Ensure ring gaps are not within the piston skirt area.

5) Install circlip.

Install circlips in piston holes located opposite service holes in cylinder block, when positioning all pistons in the corresponding cylinders.


CAUTION:

Use new circlips.

NOTE:

Piston front mark "○" facer toward front of engine.

2. CYLINDER BLOCK



B2M1321B

- ① Crankshaft bearing
- ② Crankshaft ASSY
- ③ Cylinder block (LH)
- ④ Cylinder block (RH)

- ⑤ Bolt
- ⑥ Bolt
- ⑦ Rear oil seal

Tightening torque: N·m (kg-m, ft-lb)

T1: 25±2 (2.5±0.2, 18.1±1.4)

T2: 47±3 (4.8±0.3, 34.7±2.2)


1) Install ST to cylinder block, then install crankshaft bearings.

ST 499817000 ENGINE STAND

CAUTION:

Remove oil the mating surface of bearing and cylinder block before installation. Also apply a coat of engine oil to crankshaft pins.

2) Position crankshaft on the cylinder block (LH).




3) Apply fluid packing to the mating surface of #1 and #3 cylinder block, and position it on #2 and #4 cylinder block.

Fluid packing:

THREE BOND 1215 or equivalent

CAUTION:

Do not allow fluid packing to jut into O-ring grooves, oil passages, bearing grooves, etc.




4) Temporarily tighten 10 mm cylinder block connecting bolts in alphabetical order shown in Figure.

5) Tighten 10 mm cylinder block connecting bolts in alphabetical order.

Tightening torque:

$47 \pm 3 \text{ N}\cdot\text{m}$ ($4.8 \pm 0.3 \text{ kg}\cdot\text{m}$, $34.7 \pm 2.2 \text{ ft}\cdot\text{lb}$)




6) Tighten 8 mm and 6 mm cylinder block connecting bolts in alphabetical order shown in Figure.

Tightening torque:

Ⓐ — Ⓒ : **$25 \pm 2 \text{ N}\cdot\text{m}$**

$(2.5 \pm 0.2 \text{ kg}\cdot\text{m}, 18.1 \pm 1.4 \text{ ft}\cdot\text{lb})$

Ⓗ : **$6.4 \text{ N}\cdot\text{m}$ ($0.65 \text{ kg}\cdot\text{m}$, $4.7 \text{ ft}\cdot\text{lb}$)**




7) Install rear oil seal by using ST1 and ST2.

ST1 499597100 OIL SEAL GUIDE

ST2 499587200 OIL SEAL INSTALLER


3. PISTON AND PISTON PIN (#1 AND #2)



- ① Piston
- ② Piston pin
- ③ Circlip

- ④ Gasket
- ⑤ Service hole plug
- ★ Replacement part

Tightening torque: N·m (kg·m, ft·lb)
T: 69±7 (7.0±0.7, 50.6±5.1)




- 1) Installing piston
 - (1) Turn cylinder block so that #1 and #2 cylinders face upward.
 - (2) Using ST1, turn crankshaft so that #1 and #2 connecting rods are set at bottom dead center.

ST1 499987500 CRANKSHAFT SOCKET

- (3) Apply a coat of engine oil to pistons and cylinders and insert pistons in their cylinders by using ST2.

ST2 498747000 PISTON GUIDE (1800 cc)

498747100 PISTON GUIDE (2200 cc)



- 2) Installing piston pin


- (1) Insert ST3 into service hole to align piston pin hole with connecting rod small end.

CAUTION:

Apply a coat of engine oil to ST3 before insertion.

ST3 499017100 PISTON PIN GUIDE

(2) Apply a coat of engine oil to piston pin and insert piston pin into piston and connecting rod through service hole.



(3) Install circlip.


CAUTION:
Use new circlips.

(4) Install service hole plug and gasket.

CAUTION:
Use a new gasket and apply a coat of fluid packing to it before installation.

Fluid packing:
THREE BOND 1215 or equivalent

4. PISTON AND PISTON PIN (#3 AND #4)



- ① Piston
- ② Piston pin
- ③ Circlip
- ④ Gasket
- ⑤ Service hole plug

- ⑥ Service hole cover
★: Replacement part

Tightening torque: N·m (kg-m, ft-lb)


T1: 6.4 (0.65, 4.7)

T2: 69±7 (7.0±0.7, 50.6±5.1)

Turn cylinder block so that #3 and #4 cylinders face upward. Using the same procedures as used for #1 and #2 cylinders, install pistons and piston pins.

E: INSTALLATION

1. OIL PUMP AND WATER PUMP



- ① Baffle plate
- ② Oil strainer
- ③ Oil strainer stay
- ④ Oil pan
- ⑤ Oil separator cover
- ⑥ Flywheel (MT vehicles)/
Drive plate (AT vehicles)
- ⑦ Clutch housing (MT vehicles)
- ⑧ Oil pump

- ⑨ Water pump
- ⑩ Water by-pass pipe
- ⑪ Oil filter

Tightening torque: N·m (kg-m, ft-lb)

T1: 5 (0.5, 3.6)


T2: 6.4 (0.65, 4.7)

T3: 10 (1.0, 7)

T4: 72±3 (7.3±0.3, 52.8±2.2)


T5: First **12±2 (1.2±0.2, 8.7±1.4)**

Second 12 ± 2 (1.2 ± 0.2 , 8.7 ± 1.4)




- 1) Install baffle plate.
- 2) Install oil strainer and O-ring
- 3) Install oil strainer stay.
- 4) Apply fluid packing to matching surfaces and install oil pan.

Fluid packing:
THREE BOND 1215 or equivalent




- 5) Apply fluid packing to matching surfaces and install oil separator cover.


Fluid packing:
THREE BOND 1215 or equivalent



- 6) Install flywheel or drive plate.
 To lock crankshaft, use ST.
 ST 498497100 CRANKSHAFT STOPPER
- 7) Install housing cover.



- 8) Installation of oil pump.
 (1) Discard front oil seal after removal. Replace with a new one by using ST.
 ST 499587100 OIL SEAL INSTALLER



(2) Apply fluid packing to matching surface of oil pump.


Fluid packing:

THREE BOND 1215 or equivalent

(3) Install oil pump on cylinder block. Be careful not to damage oil seal during installation.

CAUTION:

- Do not forget to install O-ring and seal when installing oil pump.
- Align flat surface of oil pump's inner rotor with crankshaft before installation.



9) Install water pump and gasket.

CAUTION:

- Be sure to use a new gasket.
- When installing water pump, tighten bolts in two stages in alphabetical sequence as shown in Figure.

10) Install water pipe.

11) Install oil filter.

2. RELATED PARTS

1) Install cylinder head and intake manifold.

<Ref. to 2-3 [W5E0].>


2) Install timing belt, camshaft sprocket and related parts.

<Ref. to 2-3 [W2C0].>

7. Timing Belt (Equipped New Automatic Belt Tension Adjuster)


A: REMOVAL

1. CRANKSHAFT PULLEY AND BELT COVER




- ① V-belt
- ② Crankshaft pulley bolt
- ③ Crankshaft pulley

- ④ Belt cover (LH)
- ⑤ Belt cover (RH)
- ⑥ Front belt cover




1) Remove V-belt.



2) Remove crankshaft pulley bolt. To lock crankshaft use ST.


ST 499977000 CRANKSHAFT PULLEY WRENCH

3) Remove crankshaft pulley.




- 4) Remove belt cover (LH).
- 5) Remove belt cover (RH).
- 6) Remove front belt cover.

2. TIMING BELT




- Ⓐ Alignment mark
- ① Belt idler (No. 2)

- ② Belt idler No. 2
- ③ Timing belt




1) If alignment mark Ⓐ and/or arrow mark (which indicates rotation direction) on timing belt fade away, put new marks before removing timing belt as follows:



(1) Turn crankshaft, and align alignment marks ① on crankshaft sprocket, and left and right camshaft sprockets with notches of belt cover and cylinder block.



ST 499987500 CRANKSHAFT SOCKET



(2) Using white paint, put alignment and/or arrow marks on timing belts in relation to the sprockets.


Z_1 : 44 tooth length

Z_2 : 40.5 tooth length




2) Remove belt idler (No. 2).

3) Remove belt idler No. 2.




4) Remove timing belt.

3. AUTOMATIC BELT TENSION ADJUSTER ASSEMBLY AND BELT IDLER




① Belt idler (No. 1)

② Automatic belt tension adjuster ASSY




1) Remove belt idler (No. 1).




2) Remove automatic belt tension adjuster assembly.

4. SPROCKET




- ① Camshaft sprocket No. 2
- ② Camshaft sprocket No. 1
- ③ Crankshaft sprocket

- ④ Belt cover No. 2 (LH)
- ⑤ Belt cover No. 2 (RH)
- ⑥ Tensioner bracket




1) Remove camshaft sprocket No. 1 and No. 2.
To lock camshaft use ST.

ST 499207100 CAMSHAFT SPROCKET WRENCH




2) Remove crankshaft sprocket.



3) Remove belt cover No. 2 (LH).
4) Remove belt cover No. 2 (RH).

CAUTION:

Do not damage or lose the seal rubber when removing belt covers.



5) Remove tensioner bracket.

B: INSPECTION


1. TIMING BELT

- 1) Check timing belt teeth for breaks, cracks, and wear. If any fault is found, replace belt.
- 2) Check the condition of back side of belt; if any crack is found, replace belt.

CAUTION:

- Be careful not to let oil, grease or coolant contact the belt. Remove quickly and thoroughly if this happens.
- Do not bend the belt sharply.

**Bending radius: h
60 mm (2.36 in) or more**



2. AUTOMATIC BELT TENSION ADJUSTER

- 1) Visually check oil seals for leaks, and rod ends for abnormal wear or scratches. If necessary, replace faulty parts.

CAUTION:


Slight traces of oil at rod's oil seal does not indicate a problem.

- 2) Check that the adjuster rod does not move when a pressure of 294 N (30 kg, 66 lb) is applied to it. This is to check adjuster rod stiffness.
- 3) If the adjuster rod is not stiff and moves freely when applying 294 N (30 kg, 66 lb), check it using the following procedures:

- (1) Slowly press the adjuster rod down to the end surface of the cylinder. Repeat this motion 2 or 3 times.
- (2) With the adjuster rod moved all the way up, apply a pressure of 294 N (30 kg, 66 lb) to it. Check adjuster rod stiffness.
- (3) If the adjuster rod is not stiff and moves down, replace the automatic belt tension adjuster assembly with a new one.

CAUTION:

- Always use a vertical type pressing tool to move the adjuster rod down.
- Do not use a lateral type vise.
- Push adjuster rod vertically.
- Press-in the push adjuster rod gradually taking more than three minutes.
- Do not allow press pressure to exceed 9,807 N (1,000 kg, 2,205 lb).
- Press the adjuster rod as far as the end surface of the cylinder. Do not press the adjuster rod into the cylinder. Doing so may damage the cylinder.



- 4) Measure the extension of rod beyond the body. If it is not within specifications, replace with a new one.

Rod extension: *H* **$6.0 \pm 0.5 \text{ mm } (0.236 \pm 0.020 \text{ in})$** **3. BELT TENSION PULLEY**


- 1) Check mating surfaces of timing belt and contact point of adjuster rod for abnormal wear or scratches. Replace belt tension pulley if faulty.
- 2) Check belt tension pulley for smooth rotation. Replace if noise or excessive play is noted.
- 3) Check belt tension pulley for grease leakage.

4. BELT IDLER

- 1) Check belt idler for smooth rotation. Replace if noise or excessive play is noted.
- 2) Check outer contacting surfaces of idler pulley for abnormal wear and scratches.
- 3) Check belt idler for grease leakage.


5. CAMSHAFT AND CRANKSHAFT SPROCKET

- 1) Check sprocket teeth for abnormal wear and scratches.
- 2) Make sure there is no free play between sprocket and key.
- 3) Check crankshaft sprocket notch for sensor for damage and contamination of foreign matter.

C: INSTALLATION**1. CAMSHAFT AND CRANKSHAFT SPROCKET**


H2M2376D

- | | |
|-------------------------|---------------------------|
| ① Tensioner bracket | ④ Crankshaft sprocket |
| ② Belt cover No. 2 (RH) | ⑤ Camshaft sprocket No. 1 |
| ③ Belt cover No. 2 (LH) | ⑥ Camshaft sprocket No. 2 |


Tightening torque: N·m (kg·m, ft·lb)**T1: 5±1 (0.5±0.1, 3.6±0.7)****T2: 25±3 (2.5±0.3, 18.1±2.2)****T3: 78±5 (8.0±0.5, 57.9±3.6)**

H2M2380


- 1) Install tensioner bracket.



- 2) Install belt cover No. 2 (RH).
- 3) Install belt cover No. 2 (LH).



- 4) Install crankshaft sprocket.




- 5) Install camshaft sprocket No. 1 and camshaft sprocket No. 2. To lock camshaft use ST.

ST 499207100 CAMSHAFT SPROCKET WRENCH

CAUTION:

Do not confuse left and right side camshaft sprockets during installation. The camshaft sprocket No. 2 is identified by a projection used to monitor camshaft position sensor.



2. BELT TENSIONER AND IDLER



H2M2373C

- ① Automatic belt tensioner ASSY
 ② Belt idler (No. 1)

Tightening torque: N·m (kg·m, ft·lb)
T: 39±4 (4.0±0.4, 28.9±2.9)




1) Preparation for installation of automatic belt tensioner adjuster assembly;

CAUTION:


- Always use a vertical type pressing tool to move the adjuster rod down.
- Do not use a lateral type vise.
- Push adjuster rod vertically.
- Be sure to slowly move the adjuster rod down applying a pressure of 294 N (30 kg, 66 lb).
- Press-in the push adjuster rod gradually taking more than three minutes.
- Do not allow press pressure to exceed 9,807 N (1,000 kg, 2,205 lb).
- Press the adjuster rod as far as the end surface of the cylinder. Do not press the adjuster rod into the cylinder. Doing so may damage the cylinder.
- Do not release press pressure until stopper pin is completely inserted.

(1) Attach the automatic belt tensioner assembly to the vertical pressing tool.

- (2) Slowly move the adjuster rod down with a pressure of 294 N (30 kg, 66 lb) until the adjuster rod is aligned with the stopper pin hole in the cylinder.
- (3) With a 2 mm (0.08 in) dia. stopper pin or a 2 mm (0.08 in) (nominal) dia. hex bar wrench inserted into the stopper pin hole in the cylinder, secure the adjuster rod.




- 2) Install automatic belt tension adjuster assembly.




- 3) Install belt idler (No. 1).

3. TIMING BELT



- (A) Alignment mark
- (1) Timing belt
- (2) Belt idler No. 2
- (3) Belt idler (No. 2)


Tightening torque: N·m (kg·m, ft·lb)
T: 39±4 (4.0±0.4, 28.9±2.9)



1) Installation of timing belt.


(1) Using ST, turn left and right camshaft sprockets so that their alignment marks come to top positions.

ST 499207100 CAMSHAFT SPROCKET WRENCH




(2) While aligning alignment mark (A) on timing belt with marks on sprockets, position timing belt properly.

CAUTION:
Ensure belt's rotating direction is correct.




- 2) Install belt idler No. 2.
- 3) Install belt idler (No. 2).




- 4) After ensuring that the marks on timing belt and camshaft sprockets are aligned, remove stopper pin from automatic belt tension adjuster.

4. CRANKSHAFT PULLEY AND BELT COVER




- | | |
|--------------------|--------------------------|
| ① Front belt cover | ④ Crankshaft pulley |
| ② Belt cover (RH) | ⑤ Crankshaft pulley bolt |
| ③ Belt cover (LH) | ⑥ V-belt |


Tightening torque: N·m (kg·m, ft·lb)
T1: 5±1 (0.5±0.1, 3.6±0.7)
T2: 127±10 (13.0±1.0, 94±7)



- 1) Install front belt cover.
- 2) Install belt cover (RH).
- 3) Install belt cover (LH).



- 4) Install crankshaft pulley.
 - 5) Install pulley bolt.
- To lock crankshaft, use ST.
 ST 499977000 CRANKSHAFT PULLEY WRENCH



6) Install V-belt.

1. Engine Trouble in General

TROUBLE	PROBLEM PARTS, ETC.	POSSIBLE CAUSE	RANK
1. Engine will not start.			
1) Starter does not turn.	● Starter	● Defective battery-to-starter harness	B
		● Defective starter switch	C
		● Defective inhibitor switch or neutral switch	C
		● Defective starter	B
	● Battery	● Poor terminal connection	A
		● Run-down battery	A
		● Defective charging system	B
	● Friction	● Seizure of crankshaft and connecting rod bearing	C
		● Seized camshaft	C
		● Seized or stuck piston and cylinder	C
2) Initial combustion does not occur.	● Starter	● Defective starter	C
	● Fuel injection system (Ref. to 2-7 On-Board Diagnostics II System)		A
	● Fuel line	● Defective fuel pump and relay	A
		● Lack of or insufficient fuel	B
	● Belt	● Defective	B
		● Defective timing	B
	● Compression	● Incorrect valve clearance	C
		● Loosened spark plugs or defective gasket	C
		● Loosened cylinder head bolts or defective gasket	C
		● Improper valve seating	C
		● Defective valve stem	C
		● Worn or broken valve spring	B
		● Worn or stuck piston rings, cylinder and piston	C
		● Incorrect valve timing	B
		● Improper engine oil (low viscosity)	B
3) Initial combustion occurs.	● Fuel injection system (Ref. to 2-7 On-Board Diagnostics II System)		A
	● Intake system	● Defective intake manifold gasket	B
		● Defective throttle body gasket	B
	● Fuel line	● Defective fuel pump and relay	C
		● Clogged fuel line	C
		● Lack of/or insufficient fuel	B
	● Belt	● Defective	B
		● Defective timing	B
	● Compression	● Incorrect valve clearance	C
		● Loosened spark plugs or defective gasket	C
		● Loosened cylinder head bolts or defective gasket	C
		● Improper valve seating	C
		● Defective valve stem	C
		● Worn or broken valve spring	B
		● Worn or stuck piston rings, cylinder and piston	C
		● Incorrect valve timing	B
		● Improper engine oil (low viscosity)	B

TROUBLE	PROBLEM PARTS, ETC.	POSSIBLE CAUSE	RANK
4) Engine stalls after initial combustion.	● Fuel injection system (Ref. to 2-7 On-Board Diagnostics II System)		A
	● Intake system	● Loosened or cracked intake duct	B
		● Loosened or cracked PCV hose	C
		● Loosened or cracked vacuum hose	C
		● Defective intake manifold gasket	B
		● Defective throttle body gasket	B
		● Dirty air cleaner element	C
	● Fuel line	● Clogged fuel line	C
		● Lack of or insufficient fuel	B
	● Belt	● Defective	B
		● Defective timing	B
	● Compression	● Incorrect valve clearance	C
		● Loosened spark plugs or defective gasket	C
		● Loosened cylinder head bolts or defective gasket	C
		● Improper valve seating	C
		● Defective valve stem	C
		● Worn or broken valve spring	B
		● Worn or stuck piston rings, cylinder and piston	C
		● Incorrect valve timing	B
		● Improper engine oil (low viscosity)	B
2. Rough idle and engine stall	● Fuel injection system (Ref. to 2-7 On-Board Diagnostics II System)		A
	● Intake system	● Loosened or cracked intake duct	A
		● Loosened or cracked PCV hose	A
		● Loosened or cracked vacuum hose	A
		● Defective intake manifold gasket	B
		● Defective throttle body gasket	B
		● Defective PCV valve	C
		● Loosened oil filler cap	B
		● Dirty air cleaner element	C
	● Fuel line	● Defective fuel pump and relay	C
		● Clogged fuel line	C
		● Lack of/or insufficient fuel	B
	● Belt	● Defective timing	C
	● Compression	● Incorrect valve clearance	B
		● Loosened spark plugs or defective gasket	B
		● Loosened cylinder head bolts or defective gasket	B
		● Improper valve seating	B
		● Defective valve stem	C
		● Worn or broken valve spring	B
		● Worn or stuck piston rings, cylinder and piston	B
		● Incorrect valve timing	A
		● Improper engine oil (low viscosity)	B
	● Lubrication system	● Incorrect oil pressure	B
		● Defective rocker cover gasket	C
	● Cooling system	● Overheating	C
	● Others	● Malfunction of evaporative emission control system	A
		● Stuck or damaged throttle valve	B
		● Accelerator cable out of adjustment	C

TROUBLE	PROBLEM PARTS, ETC.	POSSIBLE CAUSE	RANK
3. Low output, hesitation and poor acceleration	● Fuel injection system (Ref. to 2-7 On-Board Diagnostics II System)		A
	● Intake system	● Loosened or cracked intake duct	A
		● Loosened or cracked PCV hose	A
		● Loosened or cracked vacuum hose	B
		● Defective intake manifold gasket	B
		● Defective throttle body gasket	B
		● Defective PCV valve	B
		● Loosened oil filler cap	B
		● Dirty air cleaner element	A
	● Fuel line	● Defective fuel pump and relay	B
		● Clogged fuel line	B
		● Lack of/or insufficient fuel	C
	● Belt	● Defective timing	B
	● Compression	● Incorrect valve clearance	B
		● Loosened spark plugs or defective gasket	B
		● Loosened cylinder head bolts or defective gasket	B
		● Improper valve seating	B
		● Defective valve stem	C
		● Worn or broken valve spring	B
		● Worn or stuck piston rings, cylinder and piston	C
		● Incorrect valve timing	A
		● Improper engine oil (low viscosity)	B
	● Lubrication system	● Incorrect oil pressure	B
	● Cooling system	● Overheating	C
		● Over cooling	C
	● Others	● Malfunction of evaporative emission control system	A

TROUBLE	PROBLEM PARTS, ETC.	POSSIBLE CAUSE	RANK
4. Surging	● Fuel injection system (Ref. to 2-7 On-Board Diagnostics II System)		A
	● Intake system	● Loosened or cracked intake duct	A
		● Loosened or cracked PCV hose	A
		● Loosened or cracked vacuum hose	A
		● Defective intake manifold gasket	B
		● Defective throttle body gasket	B
		● Defective PCV valve	B
		● Loosened oil filler cap	B
		● Dirty air cleaner element	B
	● Fuel line	● Defective fuel pump and relay	B
		● Clogged fuel line	B
		● Lack of/or insufficient fuel	C
	● Belt	● Defective timing	B
	● Compression	● Incorrect valve clearance	B
		● Loosened spark plugs or defective gasket	C
		● Loosened cylinder head bolts or defective gasket	C
		● Improper valve seating	C
		● Defective valve stem	C
		● Worn or broken valve spring	C
		● Worn or stuck piston rings, cylinder and piston	C
		● Incorrect valve timing	A
		● Improper engine oil (low viscosity)	B
	● Cooling system	● Overheating	B
	● Others	● Malfunction of evaporative emission control system	C
5. Engine does not return to idle.	● Fuel injection system (Ref. to 2-7 On-Board Diagnostics II System)		A
	● Intake system	● Loosened or cracked vacuum hose	A
	● Others	● Stuck or damaged throttle valve	A
		● Accelerator cable out of adjustment	B
6. Dieseling (Run-on)	● Fuel injection system (Ref. to 2-7 On-Board Diagnostics II System)		A
	● Cooling system	● Overheating	B
	● Others	● Accelerator cable out of adjustment	B

TROUBLE	PROBLEM PARTS, ETC.	POSSIBLE CAUSE	RANK
7. After burning in exhaust system	● Fuel injection system (Ref. to 2-7 On-Board Diagnostics II System)		A
	● Intake system	● Loosened or cracked intake duct	C
		● Loosened or cracked PCV hose	C
		● Loosened or cracked vacuum hose	B
		● Defective PCV valve	B
		● Loosened oil filler cap	C
	● Belt	● Defective timing	B
	● Compression	● Incorrect valve clearance	B
		● Loosened spark plugs or defective gasket	C
		● Loosened cylinder head bolts or defective gasket	C
		● Improper valve seating	B
		● Defective valve stem	C
		● Worn or broken valve spring	C
		● Worn or stuck piston rings, cylinder and piston	C
		● Incorrect valve timing	A
	● Lubrication system	● Incorrect oil pressure	C
	● Cooling system	● Over cooling	C
	● Others	● Malfunction of evaporative emission control system	C
8. Knocking	● Fuel injection system (Ref. to 2-7 On-Board Diagnostics II System)		A
	● Intake system	● Loosened oil filler cap	B
	● Belt	● Defective timing	B
	● Compression	● Incorrect valve clearance	C
		● Incorrect valve timing	B
	● Cooling system	● Overheating	A
9. Excessive engine oil consumption	● Intake system	● Loosened or cracked PCV hose	A
		● Defective PCV valve	B
		● Loosened oil filler cap	C
	● Compression	● Defective valve stem	A
		● Worn or stuck piston rings, cylinder and piston	A
	● Lubrication system	● Loosened oil pump attaching bolts and defective gasket	B
		● Defective oil filter seal	B
		● defective crankshaft oil seal	B
		● Defective rocker cover gasket	B
		● Loosened oil drain plug or defective gasket	B
		● Loosened oil pan fitting bolts or defective oil pan	B
10. Excessive fuel consumption	● Fuel injection system (Ref. to 2-7 On-Board Diagnostics II System)		A
	● Intake system	● Dirty air cleaner element	A
	● Belt	● Defective timing	B
	● Compression	● Incorrect valve clearance	B
		● Loosened spark plugs or defective gasket	C
		● Loosened cylinder head bolts or defective gasket	C
		● Improper valve seating	B
		● Defective valve stem	C
		● Worn or broken spring	C
		● Worn or stuck piston rings, cylinder and piston	B
		● Incorrect valve timing	B
	● Lubrication system	● Incorrect oil pressure	C
	● Cooling system	● Over cooling	C
	● Others	● Accelerator cable out of adjustment	B

2. Engine Noise

Type of sound	Condition	Possible cause
Regular clicking sound	Sound increases as engine speed increases.	- Valve mechanism is defective. - Incorrect valve clearance - Worn valve rocker - Worn camshaft - Broken valve spring
Heavy and dull clank	Oil pressure is low.	- Worn crankshaft main bearing - Worn connecting rod bearing (big end)
	Oil pressure is normal.	- Loose flywheel mounting bolts - Damaged engine mounting
High-pitched clank (Spark knock)	Sound is noticeable when accelerating with an overload.	- Ignition timing advanced - Accumulation of carbon inside combustion chamber - Wrong spark plug - Improper gasoline
Clank when engine speed is medium (1,000 to 2,000 rpm).	Sound is reduced when fuel injector connector of noisy cylinder is disconnected. (NOTE*)	- Worn crankshaft main bearing - Worn bearing at crankshaft end of connecting rod
Knocking sound when engine is operating under idling speed and engine is warm.	Sound is reduced when fuel injector connector of noisy cylinder is disconnected. (NOTE*)	- Worn cylinder liner and piston ring - Broken or stuck piston ring - Worn piston pin and hole at piston end of connecting rod
	Sound is not reduced if each fuel injector connector is disconnected in turn. (NOTE*)	Worn camshaft journal bore in crankcase
Squeaky sound	—	Insufficient generator lubrication
Rubbing sound	—	Defective generator brush and rotor contact
Gear scream when starting engine	—	- Defective ignition starter switch - Worn gear and starter pinion
Sound like polishing glass with a dry cloth	—	- Loose drive belt - Defective water pump shaft
Hissing sound	—	- Loss of compression - Air leakage in air intake system, hoses, connections or manifolds
Timing belt noise	—	- Loose timing belt - Belt contacting case/adjacent part
Valve tappet noise	—	Incorrect valve clearance


NOTE*:

- When disconnecting fuel injector connector, Malfunction Indicator Light (CHECK ENGINE light) illuminates and trouble code is stored in ECM memory.
- Therefore, carry out the CLEAR MEMORY MODE <Ref. to 2-7 [T3D0]> and INSPECTION MODE <Ref. to 2-7 [T3E0]> after connecting fuel injector connector.

EXHAUST SYSTEM 2-9

	Page
C COMPONENT PARTS	2
1. Exhaust System	2
W SERVICE PROCEDURE	3
1. Front Exhaust Pipe and Center Exhaust Pipe	3
2. Rear Exhaust Pipe	5
3. Muffler	6

1. Exhaust System




H2M1543A

- ① Upper front exhaust pipe cover CTR
- ② Lower front exhaust pipe cover CTR
- ③ Band RH
- ④ Band LH
- ⑤ Upper front exhaust pipe cover LH
- ⑥ Lower front exhaust pipe cover LH
- ⑦ Center exhaust pipe
- ⑧ Lower front exhaust pipe cover RH
- ⑨ Upper front exhaust pipe cover RH
- ⑩ Gasket
- ⑪ Spring
- ⑫ Rear exhaust pipe
- ⑬ Self-locking nut

- ⑭ Gasket
- ⑮ Muffler
- ⑯ Cushion rubber
- ⑰ Clamp
- ⑱ Upper center exhaust pipe cover
- ⑲ Rear catalytic converter
- ⑳ Clamp B
- ㉑ Upper rear catalytic converter cover
- ㉒ Lower rear catalytic converter cover
- ㉓ Gasket
- ㉔ Front oxygen sensor
- ㉕ Rear oxygen sensor
- ㉖ Front catalytic converter

- ㉗ Lower front catalytic converter cover
- ㉘ Upper front catalytic converter cover
- ㉙ Front exhaust pipe (2200 cc)
- ㉚ Front exhaust pipe (1800 cc)


Tightening torque: N·m (kg·m, ft·lb)**T1: 13±3 (1.3±0.3, 9.4±2.2)****T2: 18±5 (1.8±0.5, 13.0±3.6)****T3: 30±5 (3.1±0.5, 22.4±3.6)****T4: 35±5 (3.6±0.5, 26.0±3.6)****T5: 48±5 (4.9±0.5, 35.4±3.6)**



1. Front Exhaust Pipe and Center Exhaust Pipe


A: REMOVAL

1) Disconnect front oxygen sensor connector.




2) Lift-up the vehicle.


3) Disconnect rear oxygen sensor connector.



4) Separate center exhaust pipe from rear exhaust pipe.



5) Remove bolts which hold front exhaust pipe onto cylinder heads.




6) Remove front exhaust pipe and center exhaust pipe from hanger bracket.

CAUTION:

Be careful not to pull down front exhaust pipe and center exhaust pipe.

1. Front Exhaust Pipe and Center Exhaust Pipe



7) Separate front exhaust pipe from front catalytic converter.


B: INSTALLATION**CAUTION:**

Replace gaskets with new ones.


1) Install front catalytic converter to front exhaust pipe.

Tightening torque:

$30 \pm 5 \text{ N}\cdot\text{m}$ ($3.1 \pm 0.5 \text{ kg}\cdot\text{m}$, $22.4 \pm 3.6 \text{ ft}\cdot\text{lb}$)




2) Install front exhaust pipe and center exhaust pipe. And temporarily tighten bolt which installs center exhaust pipe to hanger bracket.



3) Tighten bolts which hold front exhaust pipe onto cylinder heads.

Tightening torque:


$30 \pm 5 \text{ N}\cdot\text{m}$ ($3.1 \pm 0.5 \text{ kg}\cdot\text{m}$, $22.4 \pm 3.6 \text{ ft}\cdot\text{lb}$)




4) Install center exhaust pipe to rear exhaust pipe.

Tightening torque:

$18 \pm 5 \text{ N}\cdot\text{m}$ ($1.8 \pm 0.5 \text{ kg}\cdot\text{m}$, $13.0 \pm 3.6 \text{ ft}\cdot\text{lb}$)







5) Tighten bolt which holds center exhaust pipe to hanger bracket.

Tightening torque:

35 ± 5 N·m (3.6 ± 0.5 kg-m, 26.0 ± 3.6 ft-lb)




6) Connect rear oxygen sensor connector.



7) Lower the vehicle.


8) Connect front oxygen sensor connector.



2. Rear Exhaust Pipe

A: REMOVAL


1) Separate rear exhaust pipe from front catalytic converter.



2) Separate rear exhaust pipe from muffler.

CAUTION:

Be careful not to pull down front exhaust pipe and front catalytic converter.




3) Remove rear exhaust pipe bracket from rubber cushion.

NOTE:

To facilitate removal, apply a coat of SUBARU CRC to pipe bracket in advance.

SUBARU CRC (Part No. 004301003)



B: INSTALLATION

CAUTION:


Replace gaskets with new ones.

1) Install rear exhaust pipe bracket to rubber cushion.

NOTE:

To facilitate installation, apply a coat of SUBARU CRC to mating area of rubber cushion in advance.


SUBARU CRC (Part No. 004301003)



2) Install rear exhaust pipe to muffler.

Tightening torque:


48±5 N·m (4.9±0.5 kg-m, 35.4±3.6 ft-lb)



3) Install rear exhaust pipe to front catalytic converter.

Tightening torque:


18±5 N·m (1.8±0.5 kg-m, 13.0±3.6 ft-lb)



3. Muffler

A: REMOVAL AND INSTALLATION

1) Separate muffler from rear exhaust pipe.



2) Remove left and right rubber cushions.


CAUTION:

Be careful not to pull down front exhaust pipe and front catalytic converter.

NOTE:

To facilitate removal, apply a coat of SUBARU CRC to mating area of rubber cushions in advance.

SUBARU CRC (Part No. 004301003)




3) Remove front rubber cushion, and detach muffler assembly.

NOTE:

To facilitate removal, apply a coat of SUBARU CRC to mating area of rubber cushion in advance.

SUBARU CRC (Part No. 004301003)



4) Installation is in the reverse order of removal.

CAUTION:

Replace gasket with a new one.


Tightening torque:

$48 \pm 5 \text{ N} \cdot \text{m}$ ($4.9 \pm 0.5 \text{ kg} \cdot \text{m}$, $35.4 \pm 3.6 \text{ ft} \cdot \text{lb}$)

	Page
C COMPONENT PARTS	2
1. Intake Manifold.....	2
2. Air Intake System.....	6
3. Air Cleaner	8
W SERVICE PROCEDURE	9
1. Air Cleaner and Air Intake Duct.....	9
2. Mass Air Flow Sensor	10
3. Throttle Body.....	11
4. Intake Manifold.....	13
5. Engine Coolant Temperature Sensor	37
6. Crankshaft Position Sensor	38
7. Front Oxygen Sensor.....	38
8. Rear Oxygen Sensor	40
9. Throttle Position Sensor	41
10. Camshaft Position Sensor	42
11. Pressure Sensor	42
12. Idle Air Control Solenoid Valve	43
13. Pressure Sources Switching Solenoid Valve.....	46
14. Fuel Injector	46
15. Engine Control Module	47
16. Main Relay	49
17. Fuel Pump Relay	50
18. Air Intake Chamber.....	51

1. Intake Manifold

A: 1800 cc MODEL



H2M1576A

- ① Intake manifold gasket LH
- ② Intake manifold gasket RH
- ③ Fuel injector pipe insulator
- ④ Fuel injector pipe
- ⑤ O-ring A
- ⑥ O-ring B
- ⑦ Fuel injector
- ⑧ Insulator
- ⑨ Fuel injector cap
- ⑩ Plug
- ⑪ PCV valve
- ⑫ Purge control solenoid valve
- ⑬ Nipple
- ⑭ FICD solenoid valve hose A (With A/C model)
- ⑮ FICD solenoid valve (With A/C model)
- ⑯ FICD solenoid valve hose B (With A/C model)
- ⑰ Pressure sensor

- ⑱ Pressure sources switching solenoid valve
- ⑲ Vacuum hose A
- ⑳ Vacuum hose B
- ㉑ Vacuum hose C
- ㉒ Bracket (Except Canada spec. vehicles)
- ㉓ Bracket (For Canada spec. vehicles)
- ㉔ Intake manifold

Tightening torque: N·m (kg-m, ft-lb)

T1: 3.4±0.5 (0.35±0.05, 2.5±0.4)

T2: 4.9±0.5 (0.5±0.05, 3.6±0.4)

T3: 7.4±2.0 (0.75±0.2, 5.4±1.4)


T4: 16±1.5 (1.6±0.15, 11.6±1.1)

T5: 19±2 (1.9±0.2, 13.7±1.4)

T6: 23±3 (2.3±0.3, 16.6±2.2)

T7: 25±2 (2.5±0.2, 18.1±1.4)

B: 2200 cc MODEL



H2M1575A

- ① Intake manifold gasket LH
- ② Intake manifold gasket RH
- ③ Fuel injector pipe insulator
- ④ Fuel injector pipe
- ⑤ O-ring A
- ⑥ O-ring B
- ⑦ Fuel injector
- ⑧ Insulator
- ⑨ Fuel injector cap
- ⑩ Plate
- ⑪ Sealing
- ⑫ Gasket
- ⑬ Engine coolant hose B
- ⑭ Air by-pass hose
- ⑮ Idle air control solenoid valve
- ⑯ Engine coolant hose A
- ⑰ Nipple (AT vehicles)
- ⑱ Plug
- ⑲ PCV valve
- ⑳ Purge control solenoid valve
- ㉑ Nipple
- ㉒ BPT (AT vehicles)
- ㉓ BPT holder bracket (AT vehicles)
- ㉔ Back pressure hose (AT vehicles)
- ㉕ EGR vacuum hose A (AT vehicles)

- ㉖ EGR vacuum hose B (AT vehicles)
- ㉗ EGR valve (AT vehicles)
- ㉘ Gasket (AT vehicles)
- ㉙ EGR solenoid valve (AT vehicles)
- ㉚ EGR pipe (AT vehicles)
- ㉛ Pressure sensor
- ㉜ Pressure sources switching solenoid valve
- ㉝ Vacuum hose A
- ㉞ Vacuum hose B
- ㉟ Vacuum hose C
- ㊱ Bracket (Except Canada spec. vehicles)
- ㊲ Bracket (For Canada spec. vehicles)
- ㊳ Intake manifold

Tightening torque: N·m (kg·m, ft·lb)

T1: 3.4±0.5 (0.35±0.05, 2.5±0.4)

T2: 4.9±0.5 (0.5±0.05, 3.6±0.4)

T3: 6.4±0.5 (0.65±0.05, 4.7±0.4)

T4: 16±1.5 (1.6±0.15, 11.6±1.1)

T5: 19±1.5 (1.9±0.15, 13.7±1.1)

T6: 19±2 (1.9±0.2, 13.7±1.4)


T7: 23±3 (2.3±0.3, 16.6±2.2)

T8: 25±2 (2.5±0.2, 18.1±1.4)

T9: 34±2 (3.5±0.2, 25.3±1.4)

2. Air Intake System

A: 1800 cc MODEL




H2M1545A

- | | |
|-----------------------------------|------------------------|
| ① Gasket | ⑨ By-pass hose |
| ② Throttle position sensor | ⑩ Air intake chamber |
| ③ O-ring | ⑪ Stay A |
| ④ Gasket | ⑫ Stay C (MT vehicles) |
| ⑤ Idle air control solenoid valve | ⑬ Stay D (MT vehicles) |
| ⑥ Throttle body | ⑭ Spacer |
| ⑦ Clamp | ⑮ Bush |
| ⑧ Air intake duct | |

Tightening torque: N·m (kg-m, ft-lb)
T1: 2.2±0.2 (0.22±0.02, 1.6±0.1)
T2: 4.9±0.5 (0.5±0.05, 3.6±0.4)
T3: 6.0±0.8 (0.61±0.08, 4.4±0.6)
T4: 22±2 (2.2±0.2, 15.9±1.4)

B: 2200 cc MODEL




B2M1166A

- | | |
|----------------------------|---------------------|
| ① Gasket | ⑧ Stay A |
| ② Throttle position sensor | ⑨ Stay B (AT model) |
| ③ Throttle body | ⑩ Stay C (MT model) |
| ④ Clamp | ⑪ Stay D (MT model) |
| ⑤ Air intake duct | ⑫ Spacer |
| ⑥ By-pass hose | ⑬ Bush |
| ⑦ Air intake chamber | |


Tightening torque: N·m (kg-m, ft-lb)
T1: 2.2±0.2 (0.22±0.02, 1.6±0.1)
T2: 4.9±0.5 (0.5±0.05, 3.6±0.4)
T3: 22±2 (2.2±0.2, 15.9±1.4)

3. Air Cleaner



- | | |
|--------------------------------|--------------------------|
| ① Mass air flow sensor bracket | ⑦ Clip |
| ② Mass air flow sensor ASSY | ⑧ Air cleaner case |
| ③ Air cleaner upper cover | ⑨ Cushion rubber |
| ④ Air cleaner element | ⑩ Air intake duct |
| ⑤ Spacer | ⑪ Resonator chamber ASSY |
| ⑥ Bush | ⑫ Clip |


Tightening torque: N·m (kg·m, ft·lb)
T1: 7.4±2.0 (0.75±0.2, 5.4±1.4)
T2: 33±10 (3.4±1.0, 25±7)



1. Air Cleaner and Air Intake Duct

A: REMOVAL AND INSTALLATION


1) Disconnect connector from mass air flow sensor.



2) Loosen clamp which connects air intake duct to air intake chamber.


3) Remove two clips of air cleaner upper cover.

4) Disconnect blow-by hose from air intake duct.




5) Remove air intake duct and air cleaner upper cover as a unit.

6) Remove air cleaner element.




7) Remove air cleaner lower case.



8) Installation is in the reverse order of removal.

CAUTION:


Before installing air cleaner upper cover, align holes with protruding portions of air cleaner lower case, then secure upper cover to lower case.




2. Mass Air Flow Sensor

A: REMOVAL AND INSTALLATION


- 1) Loosen clamps which connect air intake duct to air intake chamber and mass air flow sensor.
- 2) Disconnect blow-by hose from air intake duct.
- 3) Remove air intake duct.



- 4) Disconnect connector from mass air flow sensor.



- 5) Remove two clips, then remove air cleaner upper cover.



- 6) Remove mass air flow sensor from air cleaner upper cover.


- 7) Installation is in the reverse order of removal.

Tightening torque:

$7.4 \pm 2.0 \text{ N}\cdot\text{m}$ ($0.75 \pm 0.2 \text{ kg}\cdot\text{m}$, $5.4 \pm 1.4 \text{ ft}\cdot\text{lb}$)

CAUTION:

Before installing air cleaner upper cover, align holes with protruding portions of air cleaner lower case, then secure upper cover to lower case.




3. Throttle Body


A: REMOVAL AND INSTALLATION

1. 1800 cc MODEL


- 1) Loosen clamps which connect air intake duct to air intake chamber and mass air flow sensor.
- 2) Disconnect blow-by hose from air intake duct.
- 3) Remove air intake duct.




- 4) Loosen clamp which connects air intake chamber to throttle body.
- 5) Disconnect air hoses, and remove air intake chamber.



- 6) Disconnect accelerator cable (A).
- 7) Disconnect cruise control cable (B). (With cruise control model)




- 8) Disconnect connectors from idle air control solenoid valve and throttle position sensor.



- 9) Disconnect water hoses from throttle body.

3. Throttle Body



10) Remove bolts which install throttle body to intake manifold.

11) Installation is in the reverse order of removal.

CAUTION:


- Always use a new gasket.
- Before installing air cleaner upper cover, align holes with protruding portions of air cleaner lower case, then secure upper cover to lower case.

Tightening torque:**Throttle body:**


$22 \pm 2 \text{ N} \cdot \text{m}$ ($2.2 \pm 0.2 \text{ kg} \cdot \text{m}$, $15.9 \pm 1.4 \text{ ft} \cdot \text{lb}$)

Air intake chamber:

$4.9 \pm 0.5 \text{ N} \cdot \text{m}$ ($0.5 \pm 0.05 \text{ kg} \cdot \text{m}$, $3.6 \pm 0.4 \text{ ft} \cdot \text{lb}$)


**2. 2200 cc MODEL**

- 1) Loosen clamps which connect air intake duct to air intake chamber and mass air flow sensor.
- 2) Disconnect blow-by hose from air intake duct.
- 3) Remove air intake duct.




4) Loosen clamp which connects air intake chamber to throttle body.

5) Disconnect air hoses, and remove air intake chamber.




6) Disconnect accelerator cable (A).


7) Disconnect cruise control cable (B). (With cruise control model)



8) Disconnect connector from throttle position sensor.



9) Disconnect engine coolant hoses from throttle body.



10) Remove bolts which install throttle body to intake manifold.

11) Installation is in the reverse order of removal.

CAUTION:

- Always use a new gasket.
- Before installing air cleaner upper cover, align holes with protruding portions of air cleaner lower case, then secure upper cover to lower case.


Tightening torque:

Throttle body:

22 ± 2 N·m (2.2 ± 0.2 kg-m, 15.9 ± 1.4 ft-lb)

Air intake chamber:

4.9 ± 0.5 N·m (0.5 ± 0.05 kg-m, 3.6 ± 0.4 ft-lb)




4. Intake Manifold

A: REMOVAL


1. 1800 cc MODEL

- 1) Release fuel pressure. <Ref. to 2-8 [W1B0].>
- 2) Disconnect connector from mass air flow sensor.


4. Intake Manifold




- 3) Loosen clamp which connects air intake duct to air intake chamber.
- 4) Remove two clips of air cleaner upper cover.
- 5) Disconnect blow-by hose from air intake duct.




- 6) Remove air intake duct and air cleaner upper cover as a unit.
- 7) Remove air cleaner element.




- 8) Loosen clamp which connects air intake chamber to throttle body.
- 9) Disconnect air hoses, and remove air intake chamber.



- 10) Disconnect accelerator cable (A).
- 11) Disconnect cruise control cable (B). (With cruise control model)




- 12) Disconnect vacuum hoses from pressure sources switching solenoid valve.




13) Remove power steering pump from bracket.

(1) Remove V-belt cover.




(2) Loosen lock bolt and slider bolt, and remove power steering pump drive V-belt.




(3) Remove bolts which secure power steering pipe brackets to intake manifold.

NOTE:


Do not disconnect power steering hose.




(4) Remove bolts which install power steering pump to bracket.




(5) Place power steering pump on the right side wheel apron.




- 14) Disconnect spark plug cords from ignition coil.
- 15) Disconnect connector from ignition coil.




- 16) Disconnect water hose from throttle body.




- 17) Disconnect brake booster hose (A).
- 18) Disconnect cruise control vacuum hose (B). (With cruise control)




- 19) Disconnect air by-pass hose from FICD solenoid valve. (With A/C)
- 20) Disconnect emission hose from PCV valve.




- 21) Disconnect engine harness connectors from bulkhead harness connectors, and remove engine harness connectors from bracket.




22) Disconnect connectors from engine coolant temperature sensor (A) and thermometer (B).




23) Disconnect knock sensor connector.



24) Disconnect connector from camshaft position sensor.




25) Disconnect connector from crankshaft position sensor.



26) Disconnect connector from oil pressure switch.


4. Intake Manifold




27) Disconnect fuel hoses from fuel pipes.

WARNING:


Catch fuel from hoses in a container.




28) Remove bolts which hold intake manifold onto cylinder heads.




29) Remove intake manifold.

**2. 2200 cc MODEL**


- 1) Release fuel pressure. <Ref. to 2-8 [W1B0].>
- 2) Disconnect connector from mass air flow sensor.




- 3) Loosen clamp which connects air intake duct to air intake chamber.
- 4) Remove two clips of air cleaner upper cover.
- 5) Disconnect blow-by hose from air intake duct.




- 6) Remove air intake duct and air cleaner upper cover as a unit.
- 7) Remove air cleaner element.




- 8) Loosen clamp which connects air intake chamber to throttle body.
- 9) Disconnect air hoses, and remove air intake chamber.




- 10) Disconnect accelerator cable (A).
- 11) Disconnect cruise control cable (B). (With cruise control model)




- 12) Disconnect vacuum hoses from pressure sources switching solenoid valve.



- 13) Remove power steering pump from bracket.
 - (1) Remove V-belt cover.




(2) Loosen lock bolt and slider bolt, and remove power steering pump drive V-belt.




(3) Remove bolts which secure power steering pipe brackets to intake manifold.

NOTE:


Do not disconnect power steering hose.




(4) Remove bolts which install power steering pump to bracket.




(5) Place power steering pump on the right side wheel apron.




14) Disconnect spark plug cords from ignition coil.



15) Disconnect PCV hose from intake manifold.




16) Disconnect engine coolant hose from throttle body.




17) Disconnect engine coolant hose (A) from idle air control solenoid valve.


18) Disconnect air by-pass hose (B) from idle air control solenoid valve.




19) Disconnect brake booster hose.




20) Remove EGR pipe. (AT vehicles)




21) Disconnect canister hoses from pipes.




22) Disconnect engine harness connectors from bulkhead harness connectors, and remove engine harness connectors from bracket.




23) Disconnect connectors from engine coolant temperature sensor (A) and thermometer (B).




24) Disconnect knock sensor connector.




25) Disconnect connector from camshaft position sensor.



26) Disconnect connector from crankshaft position sensor.




27) Disconnect connector from oil pressure switch.




28) Disconnect fuel hoses from fuel pipes.


WARNING:
Catch fuel from hoses in a container.




29) Remove bolts which hold intake manifold onto cylinder heads.



30) Remove intake manifold.


**B: DISASSEMBLY****1. 1800 cc MODEL**

1) Disconnect engine ground terminal from intake manifold.




2) Disconnect connectors from throttle position sensor, ignition coil, fuel injectors, idle air control solenoid valve, purge control solenoid valve and FICD solenoid valve.


3) Remove engine harness from intake manifold.




4) Remove throttle body from intake manifold.




5) Remove fuel pipes, etc. from intake manifold.

**2. 2200 cc MODEL**


1) Disconnect engine ground terminal from intake manifold.




- 2) Disconnect EGR vacuum hose from EGR valve. (AT vehicles)
- 3) Disconnect back pressure hose from pipe. (AT vehicles)
- 4) Disconnect BPT hoses from EGR solenoid valve and intake manifold. (AT vehicles)
- 5) Remove BPT with BTP holder bracket. (AT vehicles)
- 6) Remove EGR valve. (AT vehicles)




- 7) Disconnect connectors from throttle position sensor, ignition coil, fuel injectors, idle air control solenoid valve, purge control solenoid valve and EGR solenoid valve. (AT vehicles)
- 8) Remove engine harness from intake manifold.




- 9) Remove idle air control solenoid valve from intake manifold.




- 10) Remove throttle body from intake manifold.



- 11) Remove fuel pipes, etc. from intake manifold.
- 12) Remove EGR solenoid valve (AT vehicles) and purge control solenoid valve.

**C: ASSEMBLY****1. 1800 cc MODEL**

- 1) Install EGR solenoid valve (AT vehicles) and purge control solenoid valve.
- 2) Assemble fuel pipes, etc. to intake manifold.




- 3) Assemble throttle body to intake manifold.

CAUTION:


Replace gasket with a new one.

Tightening torque:

22 ± 2 N·m (2.2 ± 0.2 kg-m, 15.9 ± 1.4 ft-lb)




- 4) Install engine harness onto intake manifold.
- 5) Connect connectors to throttle position sensor, ignition coil, fuel injectors, idle air control solenoid valve, purge control solenoid valve and solenoid valve.




- 6) Connect engine ground terminal to intake manifold.

Tightening torque:

19 ± 1.5 N·m (1.9 ± 0.15 kg-m, 13.7 ± 1.1 ft-lb)

**2. 2200 cc MODEL**

- 1) Install EGR solenoid valve (AT vehicles) and purge control solenoid valve.
- 2) Assemble fuel pipes, etc. to intake manifold.




3) Assemble throttle body to intake manifold.

CAUTION:

Replace gasket with a new one.

Tightening torque:

$22 \pm 2 \text{ N}\cdot\text{m}$ ($2.2 \pm 0.2 \text{ kg}\cdot\text{m}$, $15.9 \pm 1.4 \text{ ft}\cdot\text{lb}$)




4) Install idle air control solenoid valve to intake manifold.

CAUTION:

Replace gasket with a new one.


Tightening torque:

$6.4 \pm 0.5 \text{ N}\cdot\text{m}$ ($0.65 \pm 0.05 \text{ kg}\cdot\text{m}$, $4.7 \pm 0.4 \text{ ft}\cdot\text{lb}$)



5) Install engine harness onto intake manifold.

6) Connect connectors to throttle position sensor, ignition coil, fuel injectors, idle air control solenoid valve, purge control solenoid valve and EGR solenoid valve. (AT vehicles)



7) Install EGR valve. (AT vehicles)

CAUTION:

Replace gasket with a new one.

Tightening torque:


$19 \pm 1.5 \text{ N}\cdot\text{m}$ ($1.9 \pm 0.15 \text{ kg}\cdot\text{m}$, $13.7 \pm 1.1 \text{ ft}\cdot\text{lb}$)

8) Install BPT with BPT holder bracket. (AT vehicles)

9) Connect BPT hoses from EGR solenoid valve and intake manifold. (AT vehicles)

10) Connect back pressure hose from pipe. (AT vehicles)


11) Connect EGR vacuum hose from EGR valve. (AT vehicles)



12) Connect engine ground terminal to intake manifold.

Tightening torque:

$19 \pm 1.5 \text{ N}\cdot\text{m}$ ($1.9 \pm 0.15 \text{ kg}\cdot\text{m}$, $13.7 \pm 1.1 \text{ ft}\cdot\text{lb}$)



D: INSTALLATION

1. 1800 cc MODEL


1) Install intake manifold onto cylinder heads.

CAUTION:


Always use new gaskets.

Tightening torque:


$25 \pm 2 \text{ N}\cdot\text{m}$ ($2.5 \pm 0.2 \text{ kg}\cdot\text{m}$, $18.1 \pm 1.4 \text{ ft}\cdot\text{lb}$)




2) Connect fuel hoses.




3) Connect connector to oil pressure switch.




4) Connect connector to crankshaft position sensor.




5) Connect connector to camshaft position sensor.




6) Connect connector to knock sensor.




7) Connect connectors to engine coolant temperature sensor (A) and thermometer (B).




8) Connect engine harness connector to bulkhead harness connectors.




9) Connect cruise control vacuum hose (B). (With cruise control)
10) Connect brake booster vacuum hose (A).




- 11) Connect air by-pass hose to FICD solenoid valve. (With A/C)
- 12) Connect emission hose to PCV valve.



- 13) Connect engine coolant hoses to throttle body.




- 14) Connect spark plug cords to ignition coil.
- 15) Connect connector to ignition coil.




- 16) Install power steering pump on bracket.
 - (1) Install power steering pump on bracket, and tighten bolts.

Tightening torque:


$20.1 \pm 2.5 \text{ N} \cdot \text{m}$ ($2.05 \pm 0.25 \text{ kg} \cdot \text{m}$, $14.8 \pm 1.8 \text{ ft} \cdot \text{lb}$)




- (2) Install power steering pipe brackets on right side intake manifold.




- (3) Install power steering pump drive V-belt.
- (4) Adjust V-belt. <Ref. to 1-5 [01A0].>




- (5) Install V-belt cover.



- 17) Connect vacuum hoses to pressure sources switching solenoid valve.




- 18) Connect accelerator cable (A).
- 19) Connect cruise control cable (B). (With cruise control model)



- 20) Install air intake chamber and connect air hoses.

Tightening torque:


4.9±0.5 N·m (0.5±0.05 kg-m, 3.6±0.4 ft-lb)




- 21) Install air cleaner element.
- 22) Install air cleaner upper cover and air intake duct as a unit.

CAUTION:

Before installing air cleaner upper cover, align holes with protruding portions of air cleaner lower case, then secure upper cover to lower case.



- 23) Connect connector to mass air flow sensor.

**2. 2200 cc MODEL**


- 1) Install intake manifold onto cylinder heads.

CAUTION:


Always use new gaskets.

Tightening torque:


25 ± 2 N·m (2.5 ± 0.2 kg-m, 18.1 ± 1.4 ft-lb)




- 2) Connect fuel hoses.




- 3) Connect connector to oil pressure switch.




4) Connect connector to crankshaft position sensor.




5) Connect connector to camshaft position sensor.




6) Connect knock sensor connector.




7) Connect connectors to engine coolant temperature sensor (A) and thermometer (B).



8) Install engine harness connectors to bracket, and connect engine harness connectors to bulkhead connectors.




9) Connect canister hoses.




10) Install EGR pipe. (AT vehicles)

Tightening torque:

34 ± 2 N·m (3.5 ± 0.2 kg·m, 25.3 ± 1.4 ft·lb)




11) Connect brake booster hose.




12) Connect engine coolant hose (A) to idle air control solenoid valve.


13) Connect air by-pass hose (B) to idle air control solenoid valve.




14) Connect engine coolant hose to throttle body.



15) Connect PCV hose to intake manifold.



16) Connect spark plug cords to ignition coil.




17) Install power steering pump on bracket.


(1) Install power steering pump on bracket, and tighten bolts.

Tightening torque:

$20.1 \pm 2.5 \text{ N} \cdot \text{m}$ ($2.05 \pm 0.25 \text{ kg} \cdot \text{m}$, $14.8 \pm 1.8 \text{ ft} \cdot \text{lb}$)




(2) Install power steering pipe brackets on right side intake manifold.




(3) Install power steering pump drive V-belt.


(4) Adjust V-belt. <Ref. to 1-5 [01A0].>



(5) Install V-belt cover.




18) Connect vacuum hoses to pressure sources switching solenoid valve.



19) Connect accelerator cable (A).


20) Connect cruise control cable (B). (With cruise control model)



21) Install air intake chamber and connect air hoses.

Tightening torque:

$4.9 \pm 0.5 \text{ N} \cdot \text{m}$ ($0.5 \pm 0.05 \text{ kg} \cdot \text{m}$, $3.6 \pm 0.4 \text{ ft} \cdot \text{lb}$)




22) Install air cleaner element.


23) Install air cleaner upper cover and air intake duct as a unit.

CAUTION:

Before installing air cleaner upper cover, align holes with protruding portions of air cleaner lower case, then secure upper cover to lower case.




24) Connect connector to mass air flow sensor.




5. Engine Coolant Temperature Sensor

A: REMOVAL AND INSTALLATION


- 1) Loosen clamps which connect air intake duct to air intake chamber and mass air flow sensor.
- 2) Disconnect blow-by hose from air intake duct.
- 3) Remove air intake duct.



- 4) Loosen clamp which connects air intake chamber to throttle body.
- 5) Disconnect air hoses, and remove air intake chamber.




- 6) Disconnect connector from engine coolant temperature sensor.
- 7) Remove engine coolant temperature sensor.



- 8) Installation is in the reverse order of removal.

Tightening torque:


$25 \pm 3 \text{ N-m}$ ($2.5 \pm 0.3 \text{ kg-m}$, $18.1 \pm 2.2 \text{ ft-lb}$)




6. Crankshaft Position Sensor

A: REMOVAL AND INSTALLATION

1) Remove bolt which install crankshaft position sensor to cylinder block.




2) Remove crankshaft position sensor, and disconnect connector from it.



3) Installation is in the reverse order of removal.

Tightening torque:

$6.4 \pm 0.5 \text{ N} \cdot \text{m}$ ($0.65 \pm 0.05 \text{ kg} \cdot \text{m}$, $4.7 \pm 0.4 \text{ ft} \cdot \text{lb}$)




7. Front Oxygen Sensor

A: REMOVAL

1) Loosen clamps which connect air intake duct to air intake chamber and mass air flow sensor.

2) Disconnect blow-by hose from air intake duct.


3) Remove air intake duct.



4) Disconnect connector from front oxygen sensor.

- 5) Lift-up the vehicle.
- 6) Apply SUBARU CRC or its equivalent to threaded portion of front oxygen sensor, and leave it for one minute or more.


SUBARU CRC (Part No. 004301003)



- 7) Remove front oxygen sensor.

CAUTION:

When removing oxygen sensor, do not force oxygen sensor especially when exhaust pipe is cold, otherwise it will damage exhaust pipe.



B: INSTALLATION


- 1) Before installing front oxygen sensor, apply anti-seize compound only to threaded portion of front oxygen sensor to make the next removal easier.

Anti-seize compound:

SS-30 by JET LUBE

CAUTION:

Never apply anti-seize compound to protector of front oxygen sensor.




- 2) Install front oxygen sensor.

Tightening torque:

21 ± 3 N·m (2.1 ± 0.3 kg-m, 15.2 ± 2.2 ft-lb)

- 3) Lower the vehicle.
- 4) Connect connector of front oxygen sensor.
- 5) Install air intake duct.




8. Rear Oxygen Sensor

A: REMOVAL

- 1) Lift-up the vehicle.
- 2) Disconnect connector from rear oxygen sensor.

3) Apply SUBARU CRC or its equivalent to threaded portion of rear oxygen sensor, and leave it for one minute or more.


SUBARU CRC (Part No. 004301003)



- 4) Remove rear oxygen sensor.

CAUTION:

When removing rear oxygen sensor, do not force rear oxygen sensor especially when exhaust pipe is cold, otherwise it will damage exhaust pipe.



B: INSTALLATION


- 1) Before installing rear oxygen sensor, apply anti-seize compound only to threaded portion of rear oxygen sensor to make the next removal easier.

Anti-seize compound:

SS-30 by JET LUBE

CAUTION:

Never apply anti-seize compound to protector of rear oxygen sensor.




- 2) Install rear oxygen sensor.

Tightening torque:

21±3 N·m (2.1±0.3 kg-m, 15.2±2.2 ft-lb)


- 3) Connect connector of rear oxygen sensor.
- 4) Lower the vehicle.

1800 cc model




H2M1586A

2200 cc model




H2M1587A

1800 cc model




H2M1588A

2200 cc model



H2M1589A



G2M0415

9. Throttle Position Sensor

A: REMOVAL AND INSTALLATION

- 1) Disconnect connector from throttle position sensor.
- 2) Remove throttle position sensor holding screws, and remove it.
- 3) Installation is in the reverse order of removal.

Tightening torque:

$2.2 \pm 0.2 \text{ N} \cdot \text{m}$ ($0.22 \pm 0.02 \text{ kg} \cdot \text{m}$, $1.6 \pm 0.1 \text{ ft} \cdot \text{lb}$)

CAUTION:

When installing throttle position sensor, adjust to the specified data.

B: ADJUSTMENT

- 1) Turn ignition switch to OFF.
- 2) Loosen throttle position sensor holding screws.

- 3) When using voltage meter;


- (1) Take out ECM.
- (2) Turn ignition switch to ON.
- (3) Adjust throttle position sensor to specified voltage between ECM connector terminal.

Connector & terminal / Specified voltage

(B84) No. 6 — No. 20 / 0.45 — 0.55 V

[Fully closed.]

- (4) Tighten throttle position sensor holding screws.




- 4) When using the Select Monitor;
 - (1) Attach Select Monitor.
 - (2) Turn ignition switch to ON.
 - (3) Select mode "F07".
 - (4) Adjust throttle position sensor to specified data.

Condition / Specified data

Throttle fully closed. / 0.50 V


- (5) Tighten throttle position sensor holding screws.



10. Camshaft Position Sensor

A: REMOVAL AND INSTALLATION

- 1) Disconnect connector from camshaft position sensor.




- 2) Remove camshaft position sensor from camshaft support LH.

- 3) Installation is in the reverse order of removal.

Tightening torque:


6.4±0.5 N·m (0.65±0.05 kg-m, 4.7±0.4 ft-lb)



11. Pressure Sensor


A: REMOVAL AND INSTALLATION

- 1) Disconnect battery ground cable.



- 2) Disconnect connector from pressure sensor.


- 3) Disconnect hose from pressure sensor.



- 4) Remove pressure sensor from bracket.
- 5) Installation is in the reverse order of removal.

Tightening torque:

$6.4 \pm 0.5 \text{ N}\cdot\text{m}$ ($0.65 \pm 0.05 \text{ kg}\cdot\text{m}$, $4.7 \pm 0.4 \text{ ft}\cdot\text{lb}$)




12. Idle Air Control Solenoid Valve


A: REMOVAL AND INSTALLATION

1. 1800 cc MODEL

- 1) Disconnect connector from idle air control solenoid valve.



- 2) Remove idle air control solenoid valve from throttle body.




- 3) Installation is in the reverse order of removal.

CAUTION:

Replace gasket with a new one.


Tightening torque:

$6.0 \pm 0.8 \text{ N}\cdot\text{m}$ ($0.61 \pm 0.08 \text{ kg}\cdot\text{m}$, $4.4 \pm 0.6 \text{ ft}\cdot\text{lb}$)




2. 2200 cc MODEL

- 1) Disconnect connector from idle air control solenoid valve.



- 2) Disconnect engine coolant hoses (A) from idle air control solenoid valve.
- 3) Disconnect air by-pass hose (B) from idle air control solenoid valve.



- 4) Remove idle air control solenoid valve from throttle body.


- 5) Installation is in the reverse order of removal.

CAUTION:


Replace gasket with a new one.

Tightening torque:


$6.4 \pm 0.5 \text{ N} \cdot \text{m}$ ($0.65 \pm 0.05 \text{ kg} \cdot \text{m}$, $4.7 \pm 0.4 \text{ ft} \cdot \text{lb}$)

**B: CLEANING (2200 cc MODEL)**

- 1) Start and warm-up the engine until radiator fan operates.
- 2) Hold throttle valve so that engine speed is at 2,000 rpm.



- 3) Disconnect by-pass hose from idle air control solenoid valve.



4) Slowly pour one can (16 oz) of cleaner into by-pass air hole.

Cleaner:


- **Part No. 1050002 GM Top Engine Cleaner**
- **Part No. X66-A AC Delco Carburetor Tune-up Conditioner**

5) Leave the engine running for five minutes.

NOTE:


White smoke comes out of the muffler until the cleaner is used up.

6) Stop the engine.



7) Release the throttle valve.


8) Connect by-pass hose to idle air control solenoid valve.



9) Check duty ratio of idle air control solenoid valve with Subaru Select Monitor.

- (1) Connect Subaru Select Monitor to the data link connector.
- (2) Start the engine and turn Subaru Select Monitor switch to ON.
- (3) Select mode "F12".
- (4) Make sure duty ratio on radiator fan and electric load is OFF.


Specified data: 25 — 40%



13. Pressure Sources Switching Solenoid Valve


A: REMOVAL AND INSTALLATION

1) Disconnect battery ground cable.



2) Disconnect connector from pressure sources switching solenoid valve.

3) Disconnect hoses from pressure sources switching solenoid valve.




4) Remove pressure sources switching solenoid valve from bracket.

5) Installation is in the reverse order of removal.

Tightening torque:

$6.4 \pm 0.5 \text{ N} \cdot \text{m}$ ($0.65 \pm 0.05 \text{ kg} \cdot \text{m}$, $4.7 \pm 0.4 \text{ ft} \cdot \text{lb}$)




14. Fuel Injector

A: REMOVAL AND INSTALLATION


1) Release fuel pressure.

<Ref. to 2-8 [W1B0].>

2) Disconnect connector from fuel injector.



3) Remove fuel injector from fuel pipe assembly.



4) Installation is in the reverse order of removal.


CAUTION:

Replace O-rings and insulator.

Tightening torque:

T: 3.4 ± 0.5 N·m (0.35 ± 0.05 kg-m, 2.5 ± 0.4 ft-lb)


- ① O-ring B
- ② O-ring A
- ③ Fuel injector
- ④ Insulator
- ⑤ Fuel injector cup
- ★: Replacement part




15. Engine Control Module

A: REMOVAL AND INSTALLATION


1) Disconnect battery ground cable.




2) Remove front pillar lower trim.




3) Detach floor mat of front passenger seat.




4) Remove protect cover.




5) Remove vinyl cover and nuts which attach ECM to bracket.




6) Detach clip from bracket.




7) Remove connector cover.



8) Disconnect ECM connector.




- 9) Take out ECM.
- 10) Installation is in the reverse order of removal.




16. Main Relay

A: REMOVAL AND INSTALLATION


- 1) Disconnect battery ground cable.




- 2) Remove lower cover and then disconnect connectors.
- 3) Remove the front pillar lower trim.



- 4) Remove fuse and relay box from bracket.
- 5) Disconnect connector from horn relay.
- 6) Remove all relays with bracket from body.
- 7) Remove fuse box mounting nuts.
- 8) Lower fuse box.
- 9) Remove fuse box mounting bracket.




- 10) Remove bolt which retains bracket of main relay ① and fuel pump relay ②.
- 11) Disconnect connector from main relay.
- 12) Installation is in the reverse order of removal.



17. Fuel Pump Relay


A: REMOVAL AND INSTALLATION

1) Disconnect battery ground cable.



2) Remove lower cover and then disconnect connectors.

3) Remove the front pillar lower trim.



4) Remove fuse and relay box from bracket.


5) Disconnect connector from horn relay.

6) Remove all relays with bracket from body.

7) Remove fuse box mounting nuts.

8) Lower fuse box.


9) Remove fuse box mounting bracket.



10) Remove fuel pump relay from main relay and fuel pump relay mounting bracket.

11) Disconnect connector from fuel pump relay.

12) Installation is in the reverse order of removal.



18. Air Intake Chamber

A: REMOVAL AND INSTALLATION

- 1) Loosen clamps which connect air intake chamber to throttle body and air intake duct.
- 2) Disconnect air hoses from air intake chamber.
- 3) Remove bolts which secure air intake chamber to stays.
- 4) Remove air intake chamber.
- 5) Installation is in the reverse order of removal.

Tightening torque:


4.9±0.5 N·m (0.5±0.05 kg-m, 3.6±0.4 ft-lb)

FUEL SYSTEM 2-8

	Page
S SPECIFICATIONS AND SERVICE DATA	2
1. Specifications	2
C COMPONENT PARTS	3
1. Fuel Tank	3
2. Fuel Line	7
W SERVICE PROCEDURE	11
1. On-Car Services.....	11
2. Fuel Tank	13
3. Fuel Filler Pipe.....	17
4. Fuel Filter	19
5. Fuel Pump.....	20
6. Fuel Meter Unit	21
7. Fuel Delivery, Return and Evaporation Lines.....	22
8. Roll Over Valve	23
9. Fuel Cut Valve	24
K DIAGNOSTICS	25
1. Fuel System Trouble in General.....	25

1. Specifications

Model		1800 cc	2200 cc
Fuel tank	Capacity	50 ℓ (13.2 US gal, 11.0 Imp gal)	60 ℓ (15.9 US gal, 13.2 Imp gal)
	Location	Under rear seat	
Fuel pump	Type	Impeller	
	Discharge pressure	250.1 kPa (2.55 kg/cm ² , 36.3 psi)	
	Discharge flow	More than 80 ℓ (21.1 US gal, 17.6 Imp gal)/h [12 V at 250.1 kPa (2.55 kg/cm ² , 36.3 psi)]	
Fuel filter		Cartridge type	

1. Fuel Tank**A: 1800 cc MODEL**

H2M1542A


1. Fuel Tank

- ① Heat sealed cover
- ② Evaporation hose E
- ③ Fuel tank band
- ④ Protector
- ⑤ Fuel tank
- ⑥ Pressure control solenoid valve bracket
- ⑦ Pressure control solenoid valve
- ⑧ Clip
- ⑨ Evaporation hose G
- ⑩ Evaporation pipe A
- ⑪ Fuel pump gasket
- ⑫ Fuel pump ASSY
- ⑬ Evaporation hose F
- ⑭ Joint pipe
- ⑮ Evaporation hose B
- ⑯ Evaporation hose A
- ⑰ Evaporation pipe ASSY

- ⑱ Evaporation hose D
- ⑲ Fuel cut valve
- ⑳ Fuel cut valve gasket
- ㉑ Evaporation hose C
- ㉒ Clamp
- ㉓ Fuel delivery hose A
- ㉔ Fuel return hose A
- ㉕ Fuel pipe ASSY
- ㉖ Fuel delivery hose B
- ㉗ Fuel return hose B

Tightening torque: N·m (kg-m, ft-lb)**T1: 4.4±1.5 (0.45±0.15, 3.3±1.1)****T2: 7.4±2.0 (0.75±0.2, 5.4±1.4)****T3: 33±10 (3.4±1.0, 25±7)**

B: 2200 cc MODEL



H2M2313A

1. Fuel Tank


- ① Heat sealed cover
- ② Evaporation hose E
- ③ Fuel tank band
- ④ Protector
- ⑤ Fuel tank
- ⑥ Pressure control solenoid valve bracket
- ⑦ Pressure control solenoid valve
- ⑧ Clip
- ⑨ Evaporation hose G
- ⑩ Evaporation pipe A
- ⑪ Fuel pump gasket
- ⑫ Fuel pump ASSY
- ⑬ Evaporation hose F
- ⑭ Joint pipe
- ⑮ Evaporation hose B
- ⑯ Evaporation hose A
- ⑰ Evaporation pipe ASSY
- ⑱ Evaporation hose D
- ⑲ Fuel cut valve
- ⑳ Fuel cut valve gasket

- ㉑ Evaporation hose C
- ㉒ Clamp
- ㉓ Fuel delivery hose A
- ㉔ Fuel return hose A
- ㉕ Fuel pipe ASSY
- ㉖ Fuel delivery hose B
- ㉗ Fuel return hose B
- ㉘ Jet pump hose A
- ㉙ Jet pump hose B
- ㉚ Evaporation hose E
- ㉛ Fuel sub meter unit
- ㉜ Jet pump filter
- ㉝ Gasket

Tightening torque: N·m (kg·m, ft·lb)
T1: 4.4±1.5 (0.45±0.15, 3.3±1.1)
T2: 7.4±2.0 (0.75±0.2, 5.4±1.4)
T3: 33±10 (3.4±1.0, 25±7)

2. Fuel Line

A: 1800 cc MODEL



H2M1476A

2. Fuel Line

- ① Clamp

② Fuel delivery hose A

③ Fuel filter bracket

④ Fuel filter holder

⑤ Fuel filter cup

⑥ Fuel filter

⑦ Evaporation hose

⑧ Clip

⑨ Fuel delivery hose B

⑩ Fuel return hose

⑪ Roll over valve

⑫ Roll over valve bracket

⑬ Evaporation hose H

⑭ Evaporation hose I

⑮ Evaporation pipe B

⑯ Canister hose A

⑰ Canister hose B

⑱ Canister holder

⑲ Canister upper bracket

⑳ Cushion rubber

㉑ Canister lower bracket

㉒ Canister

㉓ Fuel pipe ASSY

㉔ Fuel filler valve

㉕ Fuel filler pipe

㉖ Packing
- ㉗ Ring A

㉘ Ring B

㉙ Fuel filler cap

㉚ Fuel filler pipe protector

㉛ Fuel tank pressure sensor

㉜ Fuel tank pressure sensor hose A

㉝ Fuel tank pressure sensor bracket

㉞ Grommet

㉟ Fuel tank pressure sensor hose B

㊱ Air ventilator hose A

㊲ Air ventilator pipe A

㊳ Air ventilator hose B

㊴ Air ventilator pipe B

㊵ Air ventilator pipe protector

㊶ Vent control solenoid valve

㊷ Vent control solenoid valve hose

㊸ Air filter hose A


㊹ Air filter hose B

㊺ Air filter

㊻ Tapping screw

Tightening torque: N·m (kg·m, ft·lb)
T1: 23±7 (2.3±0.7, 17±5.1)
T2: 25±7 (2.5±0.7, 18±5.1)

B: 2200 cc MODEL



H2M2314A

2. Fuel Line

- ① Clamp

② Fuel delivery hose A

③ Fuel filter bracket

④ Fuel filter holder

⑤ Fuel filter cup

⑥ Fuel filter

⑦ Evaporation hose

⑧ Clip

⑨ Fuel delivery hose B

⑩ Fuel return hose

⑪ Roll over valve

⑫ Roll over valve bracket

⑬ Evaporation hose H

⑭ Evaporation hose I

⑮ Evaporation pipe B

⑯ Canister hose A

⑰ Canister hose B

⑱ Canister holder

⑲ Canister upper bracket

⑳ Cushion rubber

㉑ Canister lower bracket

㉒ Canister

㉓ Fuel pipe ASSY

㉔ Fuel filler valve

㉕ Fuel filler pipe

㉖ Packing
- ㉗ Ring A

㉘ Ring B

㉙ Fuel filler cap

㉚ Fuel filler pipe protector

㉛ Fuel tank pressure sensor

㉜ Fuel tank pressure sensor hose A

㉝ Fuel tank pressure sensor bracket

㉞ Grommet

㉟ Fuel tank pressure sensor hose B

㊱ Air ventilator hose A

㊲ Air ventilator pipe A

㊳ Air ventilator hose B

㊴ Air ventilator pipe B

㊵ Air ventilator pipe protector

㊶ Vent control solenoid valve

㊷ Vent control solenoid valve hose

㊸ Air filter hose A

㊹ Air filter hose B

㊺ Air filter

㊻ Tapping screw


Tightening torque: N·m (kg·m, ft·lb)
T1: 23±7 (2.3±0.7, 17±5.1)
T2: 25±7 (2.5±0.7, 18±5.1)

1. On-Car Services

A: PRECAUTIONS


WARNING:

- Place “No fire” signs near the working area.
- Disconnect ground terminal from battery.
- Be careful not to spill fuel on the floor.




B: RELEASING OF FUEL PRESSURE

- 1) Remove rear seat, and turn up floor mat.
- 2) Disconnect connector from fuel tank.
- 3) Start the engine, and run it until it stalls.
- 4) After the engine stalls, crank it for five more seconds.
- 5) Turn ignition switch OFF.




C: DRAINING OF FUEL


- 1) Remove rear seat and seat back.
- 2) Remove access hole lid.
- 3) Disconnect connector from fuel pump.
- 4) Release fuel pressure. <Ref. to 2-8 [W1B0].>




- 5) Disconnect fuel delivery hose ① and return hose ②.



- 6) Remove nuts which install fuel pump assembly onto fuel tank.




7) Take off fuel pump from fuel tank.



8) Drain fuel from fuel tank by using a hand pump.

WARNING:

Do not use a motor pump when draining fuel.




9) After draining fuel, reinstall fuel pump.

Tighten nuts in numerical sequence shown in Figure to specified torque.

Tightening torque:


$4.4 \pm 1.5 \text{ N} \cdot \text{m}$ ($0.45 \pm 0.15 \text{ kg} \cdot \text{m}$, $3.3 \pm 1.1 \text{ ft} \cdot \text{lb}$)




D: MEASUREMENT OF FUEL PRESSURE

1) Release fuel pressure. <Ref. to 2-8 [W1B0].>

2) Connect connector to fuel tank.



3) Disconnect fuel delivery hose from fuel filter, and connect fuel pressure gauge.



- 4) Start the engine.
- 5) Measure fuel pressure while disconnecting pressure regulator vacuum hose from collector chamber.

Fuel pressure:

235 — 265 kPa (2.4 — 2.7 kg/cm², 34 — 38 psi)

- 6) After connecting pressure regulator vacuum hose, measure fuel pressure.

Fuel pressure:


177 — 206 kPa (1.8 — 2.1 kg/cm², 26 — 30 psi)

WARNING:

Before removing fuel pressure gauge, release fuel pressure.

NOTE:


If out of specification as measured at step 6), check or replace pressure regulator and pressure regulator vacuum hose.



2. Fuel Tank

A: REMOVAL

- 1) Release fuel pressure. <Ref. to 2-8 [W1B0].>
- 2) Drain fuel from fuel tank. <Ref. to 2-8 [W1C0].>




- 3) Remove rear exhaust pipe.

- (1) Lift-up the vehicle.
- (2) Separate rear exhaust pipe from front catalyst converter.
- (3) Separate rear exhaust pipe from muffler.
- (4) Remove hook from rubber cushion, and remove exhaust pipe.

NOTE:

To facilitate the removal of parts, apply a coat of SUBARU CRC5-56 (004301003)

<Ref. to 2-9 [W2A0].>




4) Remove muffler assembly.

NOTE:

To facilitate the removal of parts, apply a coat of SUBARU CRC5-56 (004301003)

<Ref. to 2-9 [W3A0].>



5) Remove rear differential assembly.

(1) Remove rear axle shafts from rear differential assembly.

(2) Remove rear differential front cover.


(3) Remove propeller shaft.

(4) Remove lower differential bracket.

(5) Set transmission jack under rear differential.


(6) Remove bolts which install rear differential onto transmission jack.

<Ref. to 3-4 [W2B0], [W3B0].>



6) Remove rear crossmember.

<Ref. to 4-1 [W10A0].>




7) Loosen clamp, and disconnect fuel filler hose from pipe.


8) Loosen clamp, and disconnect air vent hose from air vent pipe.

① Fuel filler hose

② Air vent hose



9) Loosen clip and clamps, and disconnect fuel delivery hose ①, return hose ② and evaporation hose ③.



10) While holding fuel tank, remove bolts from bands and dismount fuel tank.


WARNING:

A helper is required to perform step 10).

B: INSTALLATION

Installation is in the reverse order of removal. Observe the following:

- 1) When installing fuel tank, have a helper hold fuel tank while installing bands.
- 2) Before tightening band mounting bolts, connect fuel system hoses.



3) Install hose and hold down clips at positions indicated in Figure.

Tightening torque:

$12.5 \pm 2.5 \text{ N} \cdot \text{m}$ ($1.27 \pm 0.25 \text{ kg} \cdot \text{m}$, $9.2 \pm 1.8 \text{ ft} \cdot \text{lb}$)

Type A: When fitting length is specified.

Type B: When fitting length is not specified.


① Fitting

② Clamp

③ Hose

$l : 2.5 \pm 1.5 \text{ mm}$ ($0.098 \pm 0.059 \text{ in}$)

$L : 22.5 \pm 2.5 \text{ mm}$ ($0.886 \pm 0.059 \text{ in}$)



① Hose

② Clip


③ Pipe

Fuel return hose:

$L = 22.5 \pm 2.5 \text{ mm}$ ($0.098 \pm 0.059 \text{ in}$)

Evaporation hose:


$L = 17.5 \pm 2.5 \text{ mm}$ ($0.689 \pm 0.098 \text{ in}$)




4) Tighten band mounting bolts.

Tightening torque:


$23.5 \pm 0.5 \text{ N}\cdot\text{m}$ ($2.40 \pm 0.05 \text{ kg}\cdot\text{m}$, $17.4 \pm 0.4 \text{ ft}\cdot\text{lb}$)




5) Install rear crossmember. <Ref. to 4-1 [W10C0].>



6) Install rear differential assembly. <Ref. to 3-4 [W2F0], [W3F0].>




7) Install muffler assembly.




8) Install heat sealed cover.

9) Install rear exhaust pipe.




- 10) Lower the vehicle, and connect connector to fuel pump.
- 11) Install access hole lid.
- 12) Install rear seat back and rear seat.




3. Fuel Filler Pipe

A: REMOVAL


- 1) Release fuel pressure. <Ref. to 2-8 [W1B0].>
- 2) Drain fuel from fuel tank. <Ref. to 2-8 [W1C0].>




- 3) Remove right rear wheel.
- 4) Open fuel filler flap and remove filler cap.
- 5) Remove screws holding packing in place.



- 6) Lift-up the vehicle.
- 7) Remove fuel filler pipe protector.




- 8) Remove clip, and separate air vent hose from pipe.
- 9) Loosen clamp, and separate fuel filler hose from pipe.
- ① Fuel filler hose
- ② Air vent hose
- 10) Remove fuel filler pipe to under side of the vehicle.

**B: INSTALLATION**

- 1) Hold fuel filler flap open.
- 2) Set fuel saucer ① with rubber packing ③, and insert fuel filler pipe into hole from the inner side of apron.
- 3) Align holes in fuel filler pipe neck and set cup ②, and tighten screws.

NOTE:

If edges of rubber packing are folded toward the inside, straighten it with a screwdriver.




- 4) Insert fuel filler hose approximately 25 to 30 mm (0.98 to 1.18 in) over the lower end of fuel filler pipe and tighten clamp.

- ① Fuel filler hose
- ② Air vent hose

CAUTION:


Do not allow clips to touch air vent hose and rear suspension crossmember.



- 5) Insert air vent hose approximately 25 to 30 mm (0.98 to 1.18 in) into the lower end of air vent pipe and hold clip.

- ① Hose
- ② Clip
- ③ Pipe

$$L = 27.5 \pm 2.5 \text{ mm } (1.083 \pm 0.098 \text{ in})$$




- 6) Install fuel filler pipe protector.
- 7) Install right rear wheel.

4. Fuel Filter

A: REMOVAL

1) Release fuel pressure. <Ref. to 2-8 [W1B0].>



- 2) Disconnect fuel hoses from fuel filter.
3) Remove filter from holder.


B: INSPECTION

- 1) Check the inside of fuel filter for dirt and water sediment.
2) If it is clogged, or if replacement interval has been reached, replace it.
3) If water is found in it, shake and expel the water from inlet port.

C: INSTALLATION

CAUTION:


- If fuel hoses are damaged at the connecting portion, replace it with a new one.
- If clamps are badly damaged, replace with new ones.



- 1) Installation is in the reverse order of removal.
2) Tighten hose clamp screws.

Tightening torque:


$12.5 \pm 2.5 \text{ N} \cdot \text{m}$ ($1.27 \pm 0.25 \text{ kg} \cdot \text{m}$, $9.2 \pm 1.8 \text{ ft} \cdot \text{lb}$)




5. Fuel Pump

A: REMOVAL


- 1) Release fuel pressure. <Ref. to 2-8 [W1B0].>
- 2) Disconnect fuel delivery hose ① and return hose ②.



- 3) Remove nuts which install fuel pump onto fuel tank.



- 4) Take off fuel pump from fuel tank.




B: INSPECTION

Connect lead harness to connector terminal of fuel pump, and apply a 12 V power supply to check whether the pump operate.

WARNING:

- Wipe off the fuel completely.
- Keep battery as far apart from fuel pump as possible.
- Be sure to turn the 12 V supply ON and OFF on the battery side.
- Do not run fuel pump for a long time under non-load condition.



C: INSTALLATION

Installation is in the reverse order of removal. Observe the following:

- (1) Always use new gaskets.
- (2) Ensure sealing portion is free from fuel or foreign particles before installation.
- (3) Tighten nuts in numerical sequence shown in Figure to specified torque.

Tightening torque:

$4.4 \pm 1.5 \text{ N}\cdot\text{m}$ ($0.45 \pm 0.15 \text{ kg}\cdot\text{m}$, $3.3 \pm 1.1 \text{ ft}\cdot\text{lb}$)



6. Fuel Meter Unit

A: REMOVAL

NOTE:

Fuel meter unit is built in fuel pump assembly.

- 1) Release fuel pressure. <Ref. to 2-8 [W1B0].>
- 2) Disconnect fuel delivery hose ① and return hose ②.



- 3) Remove nuts which install fuel pump onto fuel tank.
- 4) Take off fuel pump assembly.


B: INSTALLATION

Installation is in the reverse order of removal. <Ref. to 2-8 [W5C0].>

Tighten nuts in numerical sequence shown in Figure to specified torque.

Tightening torque:



$4.4 \pm 1.5 \text{ N}\cdot\text{m}$ ($0.45 \pm 0.15 \text{ kg}\cdot\text{m}$, $3.3 \pm 1.1 \text{ ft}\cdot\text{lb}$)




7. Fuel Delivery, Return and Evaporation Lines

A: REMOVAL

- 1) Release fuel pressure. <Ref. to 2-8 [W1B0].>
- 2) Remove inner trim, insulator and rear seat. <Ref. to 5-3 [W2A0].>
- 3) Remove fuel delivery pipes and hoses, fuel return pipes and hoses, and evaporation pipes and hoses.



- 4) In engine compartment, detach fuel delivery hose return hoses and evaporation hose.



B: INSTALLATION

Installation is in the reverse order of removal.

1) Connect fuel delivery hose to pipe with an overlap of 20 to 25 mm (0.79 to 0.98 in).

Type A: When fitting length is specified.

Type B: When fitting length is not specified.


① Fitting

② Clamp

③ Hose

ℓ : 2.5 ± 1.5 mm (0.098 ± 0.059 in)

L : 22.5 ± 2.5 mm (0.886 ± 0.098 in)



2) Connect evaporation hose to pipe by approx. 15 mm (0.59 in) from hose end.

① Hose


② Clip

③ Pipe

L = 17.5 ± 2.5 mm (0.689 ± 0.098 in)

CAUTION:

Be sure to inspect hoses and their connections for any leakage of fuel.




8. Roll Over Valve

A: REMOVAL

1) Lift-up the vehicle.

2) Remove roll over valve from bracket.

3) Disconnect hoses from roll over valve.




B: INSPECTION

1) Connect hoses to roll over valve as shown in Figure.

2) While blowing through open end of hose, tilt valve at least 90° left and right from normal position.

3) Ensure that there is no air flow when hose is tilted greater than 90°.




C: INSTALLATION

Installation is in the reverse order of removal.

CAUTION:

- Do not install top side of valve down.
- Before installing bracket on body, securely fit concave part of bracket to hole in body.




9. Fuel Cut Valve

A: REMOVAL AND INSTALLATION

- 1) Remove fuel tank. <Ref. to 2-8 [W2A0].>
- 2) Disconnect evaporation hose from fuel cut valve.
- 3) Remove fuel cut valve.
- 4) Installation is in the reverse order of removal procedure.

Tightening torque:

$4.4 \pm 1.5 \text{ N}\cdot\text{m}$ ($0.45 \pm 0.15 \text{ kg}\cdot\text{m}$, $3.3 \pm 1.1 \text{ ft}\cdot\text{lb}$)



1. Fuel System Trouble in General

Trouble and possible cause		Corrective action
1. Insufficient fuel supply to the injector		
1)	Fuel pump will not operate.	
	○ Defective terminal contact.	Inspect connections, especially ground, and tighten securely.
	○ Trouble in electromagnetic or electronic circuit parts.	Replace fuel pump.
2)	Lowering of fuel pump function.	Replace fuel pump.
3)	Clogged dust or water in the fuel filter.	Replace fuel filter, clean or replace fuel tank.
4)	Clogged or bent fuel pipe or hose.	Clean, correct or replace fuel pipe or hose.
5)	Air is mixed in the fuel system.	Inspect or retighten each connection part.
6)	Clogged or bent breather tube or pipe.	Clean, correct or replace air breather tube or pipe.
7)	Damaged diaphragm of pressure regulator.	Replace.
2. Leakage or blow out fuel		
1)	Loosened joints of the fuel pipe.	Retightening.
2)	Cracked fuel pipe, hose and fuel tank.	Replace.
3)	Defective welding part on the fuel tank.	Replace.
4)	Defective drain packing of the fuel tank.	Replace.
5)	Clogged or bent air breather tube or air vent tube.	Clean, correct or replace air breather tube or air vent tube.
3. Gasoline smell inside of compartment		
1)	Loose joints at air breather tube, air vent tube and fuel filler pipe.	Retightening.
2)	Defective packing air tightness on the fuel saucer.	Correct or replace packing.
3)	Cracked fuel separator.	Replace separator.
4)	Inoperable fuel pump modulator or circuit.	Replace.
4. Defective fuel meter indicator		
1)	Defective operation of fuel meter unit.	Replace.
2)	Defective operation of fuel meter.	Replace.
5. Noise		
1)	Large operation noise or vibration of fuel pump.	Replace.

NOTE:

● When the vehicle is left unattended for an extended period of time, water may accumulate in the fuel tank. To prevent water condensation:

- 1) Top off the fuel tank or drain the fuel completely.
- 2) Drain water condensation from the fuel filter.

● Refilling the fuel tank.

- 1) Refill the fuel tank while there is still some fuel left in the tank.

● Protecting the fuel system against freezing and water condensation.

- 1) Cold areas

In snow-covered areas, mountainous areas, skiing areas, etc. where ambient temperatures drop below 0°C (32°F) throughout the winter season, use an anti-freeze solution in the cooling system.

Refueling will also complement the effect of anti-freeze solution each time the fuel level drops to about one-half.

After the winter season, drain water which may have accumulated in the fuel filter and fuel tank in the manner same as that described under Affected areas below.

- 2) Affected areas

When water condensation is notched in the fuel filter, drain water from both the fuel filter and fuel tank or use a water removing agent (or anti-freeze solution) in the fuel tank.

● Observe the instructions, notes, etc., indicated on the label affixed to the anti-freeze solution (water removing agent) container before use.

ON-CAR SERVICES **2-2**

	Page
1. Foreword.....	2
2. Ignition Timing.....	2
3. Engine Idle Speed	3
4. Engine Compression	4
5. Intake Manifold Vacuum	5
6. Engine Oil Pressure.....	6
7. Valve Clearance.....	8

1. Foreword

This chapter describes major inspection and service procedures for the engine mounted on the body. For procedures not found in this chapter, refer to the service procedure section in the applicable chapter.


2. Ignition Timing

A: MEASUREMENT

CAUTION:

After warming-up, engine becomes very hot. Be careful not to burn yourself during measurement.

1) Warm-up the engine.



2) To check the ignition timing, connect a timing light to #1 cylinder spark plug cord, and illuminate the timing mark with the timing light.

3) Start the engine at idle speed and check the ignition timing.

If the timing is not correct, check the ignition control system. <Ref. to 2-7 [T8D0].>

Ignition timing [BTDC/rpm]:

$16^{\circ} \pm 8^{\circ} / 700$ (1800 cc MT vehicles)

$14^{\circ} \pm 8^{\circ} / 700$ (2200 cc MT vehicles)

$20^{\circ} \pm 8^{\circ} / 700$ (2200 cc AT vehicles)

NOTE:

To improve stability, ignition timing while engine is idling is also controlled. For this reason specified ignition timing range is increased somewhat, to $\pm 8^{\circ}$.

3. Engine Idle Speed

A: MEASUREMENT

1) Before checking idle speed, check the following:

- (1) Ensure that air cleaner element is free from clogging, ignition timing is correct, spark plugs are in good condition, and that hoses are connected properly.
- (2) Ensure that malfunction indicator lamp (CHECK ENGINE light) does not illuminate.

2) Warm-up the engine.

3) Connect Subaru Select Monitor or the OBD-II general scan tool to data link connector.



CAUTION:

When connecting Subaru Select Monitor, turn ignition switch to OFF.

4) Start the engine and measure engine speed.

NOTE:

Engine speed is indicated on Subaru Select Monitor by selecting "MODE F04".



NOTE:

- When using the OBD-II general scan tool, carefully read its operation manual.
- When Subaru Select Monitor is not used, attach the pickup sensor on tachometer (Secondary pickup type) to #1 spark plug cord.
- This ignition system provides simultaneous ignition for #1 and #2 plugs. It must be noted that some tachometers may register twice that of actual engine speed.

5) Check idle speed when unloaded (with headlights, heater fan, rear defroster, radiator fan, air conditioning, etc. OFF).

Idle speed [No load and gears in neutral (MT) or N or P (AT) position]:

700±100 rpm

6) Check idle speed when loaded. (Turn air conditioning switch to "ON" and operate compressor for at least one minute before measurement.)

Idle speed [A/C switch "ON", no load and gears in neutral (MT) or N or P (AT) position]:

850±100 rpm

CAUTION:

Never rotate idle adjusting screw, if idle speed is outside specifications, refer to General On-board Diagnosis Table under "2-7 On-Board Diagnostics II System".

4. Engine Compression


A: MEASUREMENT

- 1) After warming-up the engine, turn ignition switch to OFF.
- 2) Make sure that the battery is fully charged.
- 3) Remove all the spark plugs.
- 4) Disconnect connectors from fuel injectors.
- 5) Fully open throttle valve.
- 6) Check the starter motor for satisfactory performance and operation.
- 7) Hold the compression gauge tight against the spark plug hole.

CAUTION:

When using a screw-in type compression gauge, the screw (put into cylinder head spark plug hole) should be less than 18 mm (0.71 in) long.

- 8) Crank the engine by means of the starter motor, and read the maximum value on the gauge when the pointer is steady.



- 9) Perform at least two measurements per cylinder, and make sure that the values are correct.

Compression (200 — 300 rpm and fully open throttle):

Standard: 1,079 — 1,275 kPa

(11.0 — 13.0 kg/cm², 156 — 185 psi)


Limit: 883 kPa (9.0 kg/cm², 128 psi)

Difference between cylinders: 196 kPa (2.0 kg/cm², 28 psi)

5. Intake Manifold Vacuum

A: MEASUREMENT

- 1) Warm-up the engine.
- 2) Disconnect the vacuum hose and install the vacuum gauge to the hose fitting on the manifold.



- 3) Keep the engine at the idle speed and read the vacuum gauge indication.

By observing the gauge needle movement, the internal condition of the engine can be diagnosed as described below.

Vacuum pressure (at idling, A/C "OFF"):

1800 cc:

Less than -66.7 kPa


(-500 mmHg, -19.69 inHg)

2200 cc:

Less than -60.0 kPa

(-450 mmHg, -17.72 inHg)


Diagnosis of engine condition by measurement of manifold vacuum	
Vacuum gauge indication	Possible engine condition
1. Needle is steady but lower than normal position. This tendency becomes more evident as engine temperature rises.	Leakage around intake manifold gasket/throttle chamber gasket or disconnection/damaged vacuum hose
2. When engine speed is reduced slowly from higher speed, needle stops temporarily when it is lowering or becomes steady above normal position.	Back pressure too high, or exhaust system clogged
3. Needle intermittently drops to position lower than normal position.	Leakage around cylinder
4. Needle drops suddenly and intermittently from normal position.	Sticky valves
5. When engine speed is gradually increased, needle begins to vibrate rapidly at certain speed, and then vibration increases as engine speed increases.	Weak or broken valve springs
6. Needle vibrates above and below normal position in narrow range.	Defective ignition system or throttle chamber idle adjustment




6. Engine Oil Pressure

A: MEASUREMENT


- 1) Remove generator from bracket.
 - (1) Disconnect connector and terminal from generator.




- (2) Remove V-belt cover.
 - (3) Loosen lock bolt and slider bolt, and remove front side V-belt.



- (4) Remove lock bolt.
 - (5) Remove bolts which install generator on bracket.



- (2) Disconnect connector from oil pressure switch.
 - (3) Remove oil pressure switch from engine block.



- 4) Connect oil pressure gauge hose.
- 5) Start the engine, and measure oil pressure.

Oil pressure:

98 kPa (1.0 kg/cm², 14 psi) or more at 600 rpm

294 kPa (3.0 kg/cm², 43 psi) or more at 5,000 rpm

CAUTION:

- If oil pressure is out of specification, check oil pump, oil filter and lubrication line.

<Ref. to 2-4 [W1A0].>

- If oil pressure warning light is turned ON and oil pressure is in specification, replace oil pressure switch.

<Ref. to 2-4 [W3A0].>

NOTE:

The specified data is based on an engine oil temperature of 80°C (176°F).

- 6) After measuring oil pressure, install oil pressure switch.

Tightening torque:

25±3 N·m (2.5±0.3 kg-m, 18.1±2.2 ft-lb)

- 7) Install generator and V-belt in the reverse order of removal, and adjust the V-belt deflection.


7. Valve Clearance

A: INSPECTION


CAUTION:

Inspection and adjustment of valve clearance should be performed while engine is cold.

- 1) Set the vehicle onto the lift.
- 2) Disconnect battery ground cable.
- 3) Remove timing belt cover (RH).



- 4) Remove rocker cover.
 - When inspecting #1 and #3 cylinders;
 - (1) Disconnect connector from mass air flow sensor.




- (2) Loosen clamp which connects air intake duct to air intake chamber.
- (3) Remove the two clips from air cleaner upper cover.

CAUTION:


Before installing air cleaner upper cover, align hole(s) with protruding portions of air cleaner lower case, then secure upper cover.

- (4) Disconnect blow-by hose from air intake duct.



- (5) Remove air intake duct and air cleaner upper cover as a unit.
- (6) Remove air cleaner element.
- (7) Disconnect spark plug cords from spark plugs (#1 and #3 cylinders).
- (8) Remove under cover (RH).
- (9) Place suitable container under the vehicle.
- (10) Disconnect PCV hose from rocker cover (RH).
- (11) Remove bolts, then remove rocker cover (RH).


- When inspecting #2 and #4 cylinders;
 - (1) Disconnect battery cables, and then remove battery and battery carrier.
 - (2) Disconnect washer motor connectors.
 - (3) Disconnect rear window glass washer hose from washer motor, then plug connection with a suitable cap.
 - (4) Remove the two bolts which holds washer tank, then secure the tank away from working area.
 - (5) Disconnect spark plug cords from spark plugs (#2 and #4 cylinders).
 - (6) Remove under cover (LH).
 - (7) Place suitable container under the vehicle.
 - (8) Disconnect PCV hose from rocker cover (LH).
 - (9) Remove bolts, then remove rocker cover (LH).



- 5) Set #1 cylinder piston to top dead center of compression stroke by rotating crankshaft pulley clockwise.

NOTE:

When arrow mark on camshaft sprocket (RH) comes exactly to the top, #1 cylinder piston is brought to the top dead center of compression stroke.



- 6) Measure #1 cylinder valve clearance by using thickness gauge.

CAUTION:


- Insert the thickness gauge in as horizontal a direction as possible with respect to the valve stem end face.
- Measure exhaust valve clearances while lifting-up the vehicle.

Valve clearance:

Intake: 0.20 ± 0.02 mm (0.0079 ± 0.0008 in)

Exhaust: 0.25 ± 0.02 mm (0.0098 ± 0.0008 in)

- 7) If necessary, adjust the valve clearance. <Ref. to 2-2 [07B0].>




8) Similar to measurement procedures used for #1 cylinder, measure #2, #3 and #4 cylinder valve clearances.

NOTE:

- Be sure to set cylinder pistons to their respective top dead centers on compression stroke before measuring valve clearances.

- To set #3, #2 and #4 cylinder pistons to their top dead centers on compression stroke, turn crankshaft pulley clockwise 90° at a time starting with arrow mark on right-hand camshaft sprocket facing up.

9) After inspection, install the related parts in the reverse order of removal.



B: ADJUSTMENT

CAUTION:

Adjustment of valve clearance should be performed while engine is cold.

1) Set #1 cylinder piston to top dead center of compression stroke by rotating crankshaft pulley clockwise.

NOTE:

When arrow mark on camshaft sprocket (RH) comes exactly to the top, #1 cylinder piston is brought to the top dead center of compression stroke.

2) Adjust the #1 cylinder valve clearance.

(1) Loosen the valve rocker nut and screw.

(2) Place suitable thickness gauge.

(3) While noting valve clearance, tighten valve rocker adjust screw.

(4) When specified valve clearance is obtained, tighten valve rocker nut.

Tightening torque:

$10 \pm 1 \text{ N} \cdot \text{m}$ ($1.0 \pm 0.1 \text{ kg} \cdot \text{m}$, $7.2 \pm 0.7 \text{ ft} \cdot \text{lb}$)

CAUTION:

- Insert the thickness gauge in as horizontal a direction as possible with respect to the valve stem end face.


- Adjust exhaust valve clearances while lifting-up the vehicle.

Valve clearance:

Intake: $0.20 \pm 0.02 \text{ mm}$ ($0.0079 \pm 0.0008 \text{ in}$)

Exhaust: $0.25 \pm 0.02 \text{ mm}$ ($0.0098 \pm 0.0008 \text{ in}$)

3) Ensure that valve clearances are within specifications.



- 4) Turn crankshaft two complete rotations until #1 cylinder piston is again set to top dead center on compression stroke.
- 5) Ensure that valve clearances are within specifications. If necessary, re-adjust valve clearances.