


21. Dropping Resistor

A: REMOVAL

NOTE:


Dropping resistor is installed on non-turbo models only.

- 1) Disconnect the ground cable from battery.



- 2) Remove the air intake duct. <Ref. to IN(H4SO)-6, REMOVAL, Air Cleaner Case.>
- 3) Disconnect the connector from dropping resistor.

- 4) Remove the dropping resistor.




(A) Dropping resistor

B: INSTALLATION

- 1) Install in the reverse order of removal.

Tightening torque:

7.5 N·m (0.76 kgf-m, 5.5 ft-lb)



(A) Dropping resistor

C: INSPECTION

Step	Check	Yes	No
1 CHECK RESISTOR. 1) Turn ignition switch to OFF. 2) Disconnect the connector from dropping resistor. 3) Measure the resistance between dropping resistor terminals. Terminal No. 1 — No. 2: Is the measured value within the specified range?	9 — 15 Ω	Go to step 2.	Replace the dropping resistor. <Ref. to AT-72, Dropping Resistor.>
2 CHECK RESISTOR. Measure the resistance between dropping resistor terminals. Terminal No. 3 — No. 4: Is the measured value within the specified range?	9 — 15 Ω	Dropping resistor is normal.	Replace the dropping resistor. <Ref. to AT-72, Dropping Resistor.>