

Brought to you by Eris Studios  
NOT FOR RESALE

# **AIRBAG SYSTEM (DIAGNOSTICS)**

# BASIC DIAGNOSTIC PROCEDURE

AIRBAG SYSTEM (DIAGNOSTICS)

## 1. Basic Diagnostic Procedure

### A: PROCEDURE

	Step	Check	Yes	No
1	<b>READ DTC.</b> <Ref. to AB-24, Read Diagnostic Trouble Code (DTC).>	Is the normal code being detected?	Finish the diagnosis.	Go to step 2.
2	<b>READ DTC.</b> <Ref. to AB-24, Read Diagnostic Trouble Code (DTC).>	Is the DTC being detected?	Go to step 3.	Go to "Airbag Warning Light Failure". <Ref. to AB-27, Airbag Warning Light Failure.>
3	<b>PERFORM THE DIAGNOSIS.</b> 1) Judge the possible cause from "List of Diagnostic Trouble Code (DTC)". <Ref. to AB-32, List of Diagnostic Trouble Code (DTC).> 2) Inspect using "Diagnostic Chart with Diagnostic Trouble Code (DTC)". 3) Repair the cause of the trouble. 4) Perform the clear memory mode. <Ref. to AB-26, Clear Memory Mode.> 5) Perform the inspection mode. <Ref. to AB-25, Inspection Mode.> 6) Read any DTC again.	Is the DTC being detected?	Perform the procedure 1) to 5) in step 3.	Finish the diagnosis.

# CHECK LIST FOR INTERVIEW

AIRBAG SYSTEM (DIAGNOSTICS)

## 2. Check List for Interview


### A: CHECK

Customer's Name		Inspector's Name	
Date Vehicle Brought In	/ /	Registration No.	
Odometer Reading	km Miles	VIN	
Date Problem Occurred	/ /	Registration Year	/ /
Weather	<input type="checkbox"/> Fine <input type="checkbox"/> Cloudy <input type="checkbox"/> Rainy <input type="checkbox"/> Snowy <input type="checkbox"/> Other:		
Temperature	°C (°F)		
Road Condition	<input type="checkbox"/> Level road <input type="checkbox"/> Uphill <input type="checkbox"/> Downhill <input type="checkbox"/> Rough road <input type="checkbox"/> Others:		
Vehicle Operation	<input type="checkbox"/> Driving ( <input type="checkbox"/> Constant Speed <input type="checkbox"/> Acceleration <input type="checkbox"/> Deceleration ) <input type="checkbox"/> Starting <input type="checkbox"/> Idling <input type="checkbox"/> Steering wheel turn <input type="checkbox"/> Other:		
Details of Problem			
Check Airbag Warning Light	<input type="checkbox"/> Remains ON <input type="checkbox"/> Remains OFF		
Check DTC	<input type="checkbox"/> Normal Code <input type="checkbox"/> DTC: (Code: )		


### 3. General Description

#### A: CAUTION


- When servicing a vehicle, be sure to turn the ignition switch to OFF, disconnect the ground cable from battery, and wait for more than 20 seconds before starting work.
- The airbag system is fitted with a backup power source. If the airbag system is serviced within 20 seconds after the ground cable is disconnected, it may inflate.




- If sensors, airbag module, airbag control module, pretensioner, and harness are deformed or damaged, replace them with new genuine parts.



- Do not use the airbag system and pretensioners on other vehicles. When replacing parts, be sure to replace them with new parts.
- When checking the airbag system, be sure to use a digital circuit tester. Use of an analog circuit tester may cause the airbag to activate erroneously.




- When checking, use a test harness. Do not directly apply the tester probe to any connector terminal of the airbag.



(1) Test harness


- Do not drop the airbag modulator parts, subject them to high temperature over 93°C (199°F), or let water, oil, or grease get on them; otherwise, the internal parts may be damaged and may be reliability greatly lowered.




# GENERAL DESCRIPTION

## AIRBAG SYSTEM (DIAGNOSTICS)


- If any damage, opening, or rust is found on the airbag system wire harness, do not attempt to repair using soldering equipment. Be sure to replace the faulty harness with a new genuine part.



- Install the wire harness securely with the specified clips to avoid interference or tangled up with other parts.




- Do not allow water or oil to come in contact with the connector terminals. Do not touch the connector terminals.




- Either of the airbag modules for driver, passenger or side, or pretensioner must not be disassembled.


- The airbag module cannot be used again if once inflated.



- After removal, keep the airbag module with the pad facing upward on a dry, clean, and flat surface away from heat and light sources, and moisture and dust.




- Do not check continuity of either of the airbag modules for driver, passenger or side, or pretensioner.



## GENERAL DESCRIPTION


### AIRBAG SYSTEM (DIAGNOSTICS)

- The removed front seat with the airbag module must be kept at least 200 mm (8 in) away from walls and other objects.



(1) More than 200 mm (8 in)

- When painting or performing sheet metal work on the front part of the vehicle, including the front wheel apron, front fender, and front side frame, remove the front sub sensors and wire harness of the airbag system.
- When painting or performing sheet metal work on the side of the vehicle, including the side sill, center pillar, and front and rear doors, remove the side airbag sensors and wire harness of the airbag system.










- Do not discard undeployed airbag modules. They could easily cause a serious accident if accidentally deployed.

# GENERAL DESCRIPTION






## AIRBAG SYSTEM (DIAGNOSTICS)

- When storing a removed airbag module, do not place any objects on it or pile airbag modules on top of each other. If the airbag inflates for some reason when it is placed with its pad side facing downward or under any object, a serious accident may result.

(1)



(2)



AB-00130

(1) Driver side airbag module

(2) Passenger side airbag module

# GENERAL DESCRIPTION

AIRBAG SYSTEM (DIAGNOSTICS)

## B: INSPECTION

Before diagnosing, check the following items that might be related to the engine problem:

### 1. BATTERY

Measure the battery voltage and specific gravity of electrolyte.


**Standard voltage: 12 V**


**Specific gravity: Above 1.260**

## C: PREPARATION TOOL

### 1. SPECIAL TOOLS

- TEST HARNESS M

ILLUSTRATION	TOOL NUMBER	DESCRIPTION	REMARKS
 <p style="text-align: center;">ST98299FE020</p>	98299FE020	TEST HARNESS M	<ul style="list-style-type: none"> <li>• Used when measuring voltage, resistance of airbag system.</li> <li>• Used with test harness T (98299SA060).</li> </ul>







# GENERAL DESCRIPTION

AIRBAG SYSTEM (DIAGNOSTICS)

## • TEST HARNESS F


ILLUSTRATION	TOOL NUMBER	DESCRIPTION	REMARKS
 <p data-bbox="326 594 467 615">ST98299FC010</p>	98299FC010	TEST HARNESS F	Used when measuring voltage, resistance of air-bag module harness.




# GENERAL DESCRIPTION

## AIRBAG SYSTEM (DIAGNOSTICS)

### • TEST HARNESS G


ILLUSTRATION	TOOL NUMBER	DESCRIPTION	REMARKS
 <p style="text-align: center;">ST98299FC020</p>	98299FC020	TEST HARNESS G	Used when measuring voltage, resistance of side airbag sensor.




# GENERAL DESCRIPTION

AIRBAG SYSTEM (DIAGNOSTICS)

## • TEST HARNESS H

ILLUSTRATION	TOOL NUMBER	DESCRIPTION	REMARKS
 <p>ST98299FA030</p>	98299FA030	TEST HARNESS H	Used when measuring voltage, resistance of front sub-sensor.





AB-00429

# GENERAL DESCRIPTION

AIRBAG SYSTEM (DIAGNOSTICS)

## • TEST HARNESS L


ILLUSTRATION	TOOL NUMBER	DESCRIPTION	REMARKS
 <p style="text-align: center;">ST98299FE000</p>	98299FE000	TEST HARNESS L	Used when measuring voltage, resistance of seat belt pretensioner.




# GENERAL DESCRIPTION

AIRBAG SYSTEM (DIAGNOSTICS)

## • TEST HARNESS R

ILLUSTRATION	TOOL NUMBER	DESCRIPTION	REMARKS
 <p>ST98299FE030</p>	98299FE030	TEST HARNESS R	Used when measuring voltage, resistance of air-bag control module.





AB-00606

# GENERAL DESCRIPTION

## AIRBAG SYSTEM (DIAGNOSTICS)

### • TEST HARNESS N


ILLUSTRATION	TOOL NUMBER	DESCRIPTION	REMARKS
 <p style="text-align: center;">ST98299SA000</p>	98299SA000	TEST HARNESS N	Used when measuring voltage, resistance of driver's airbag module and seat belt pretensioner.




# GENERAL DESCRIPTION

AIRBAG SYSTEM (DIAGNOSTICS)

## • TEST HARNESS T


ILLUSTRATION	TOOL NUMBER	DESCRIPTION	REMARKS
 <p data-bbox="324 590 467 611">ST98299SA060</p>	98299SA060	TEST HARNESS T	<ul style="list-style-type: none"> <li>• Used when measuring voltage, resistance of airbag system.</li> <li>• Used with test harness M (98299FE020).</li> </ul>




# GENERAL DESCRIPTION

## AIRBAG SYSTEM (DIAGNOSTICS)

### • AIRBAG RESISTOR

ILLUSTRATION	TOOL NUMBER	DESCRIPTION	REMARKS
 <p style="text-align: center;">ST98299PA040</p>	98299PA040	AIRBAG RESISTOR	Used in replacement of airbag module which resistance value is same as airbag module.






# ELECTRICAL COMPONENTS LOCATION

AIRBAG SYSTEM (DIAGNOSTICS)

## 4. Electrical Components Location

### A: LOCATION



AB-00494

- |  |                               |                                    |
|--|-------------------------------|------------------------------------|
| (1) Front sub sensor (LH)  | (7) Roll connector            | (14) Side airbag inflator (LH)     |
| (2) Front sub sensor (RH)  | (8) Airbag main harness       | (15) Side airbag inflator (RH)     |
| (3) Front sub sensor harness (LH)                                  | (9) Driver's airbag inflator  | (a) To body harness                |
| (4) Front sub sensor harness (RH)                                  | (10) Side airbag harness (LH) | (b) To seat belt pretensioner (LH) |
| (5) Airbag control module with built-in safety and electric sensor | (11) Side airbag harness (RH) | (c) To seat belt pretensioner (RH) |
| (6) Passenger's airbag inflator                                    | (12) Side airbag sensor (LH)  |                                    |
|  | (13) Side airbag sensor (RH)  |                                    |



Connector No.	(AB1)	(AB2)	(AB3)	(AB4)	(AB7)	(AB8)	(AB9)	(AB10)	(AB11)	(AB12)	(AB13)	(AB14)
Pole	6	2	28	4	12	12	2	4	2	4	2	2
Color	Yellow	Black	Yellow	Yellow	Yellow	Yellow	Yellow	Yellow	Yellow	Yellow	Yellow	Yellow
Male/Female	Male	Female	Female	Female	Female	Female	Female	Female	Female	Female	Female	Male
Connector No.	(AB15)	(AB18)	(AB19)	(AB20)	(AB21)	(AB26)	(AB27)	(AB28)	(AB29)			
Pole	2	2	2	2	2	2	2	2	2			
Color	Yellow	Yellow	Black	Black	Yellow	Yellow	Yellow	Yellow	Yellow			
Male/Female	Female	Female	Female	Female	Female	Male	Male	Male	Male			

# AIRBAG CONTROL MODULE I/O SIGNAL

AIRBAG SYSTEM (DIAGNOSTICS)

## 5. Airbag Control Module I/O Signal





### A: SCHEMATIC



AB-00600

# AIRBAG CONTROL MODULE I/O SIGNAL


AIRBAG SYSTEM (DIAGNOSTICS)



AB-00614

# AIRBAG CONTROL MODULE I/O SIGNAL

AIRBAG SYSTEM (DIAGNOSTICS)



AB9 (YELLOW)

AB10 (YELLOW)





AB7 (YELLOW)

AB8 (YELLOW)

AB19

AB11 (YELLOW)

AB12 (YELLOW)



AB-00615


### 6. Airbag Connector

#### A: OPERATION

##### 1. POWER SUPPLY

1) How to disconnect:


- (1) Move the slide lock (A) in the direction of the arrow.
- (2) Pull the female connector in the direction of the arrow with slide lock (A) moved.



**CAUTION:**  
When pulling, be sure to hold onto the connector and not the wire.

2) How to connect:

Holding the connector (A), and push it in carefully until a connecting sound is heard.




**CAUTION:**  
Be sure to insert the connector in until it locks. Then pull on it gently to make sure that it is locked.

##### 2. DRIVER'S AIRBAG (BETWEEN AIRBAG MAIN HARNESS AND ROLL CONNECTOR), PASSENGER'S AIRBAG AND SIDE AIRBAG

1) How to disconnect:


- (1) Push the lock arm (A).

- (2) With the lock arm (A) pushed in, move the slide lock (B) in the direction of the arrow.



- (3) With the slide lock (B) pulled, remove the lock arm (A) to its original position, and then pull in the direction of the arrow and separate the connector.


**CAUTION:**  
When pulling, be sure to hold onto the connector and not the wire.



2) How to connect:

Holding the connector, and push it in carefully until a connecting sound is heard.

**CAUTION:**  
Be sure to insert the connector in until it locks. Then pull on it gently to make sure that it is locked.




# AIRBAG CONNECTOR

## AIRBAG SYSTEM (DIAGNOSTICS)


### 3. DRIVER'S AIRBAG MODULE AND PRE-TENSIONER

1) How to disconnect:

(1) Using a flat tip screwdriver, pry the push lock upward to unlock.



(2) Pull the connector to disconnect from driver's side airbag module assembly or retractor assembly.




2) How to connect:

Connect the connector in reverse order of disconnecting. At this time, be sure to insert the connector in until connecting sound is heard.

**CAUTION:**

- Be sure to insert the connector in until it locks. Then pull on it gently to make sure that it is locked.
- Be sure to push the push lock in securely.




### 4. FRONT SUB-SENSOR AND SIDE AIRBAG SENSOR

1) How to disconnect:

Holding outer part (A), pull it in the direction of the arrow.

**CAUTION:**

When pulling, be sure to hold onto the connector and not the wire.




2) How to connect:

Holding the connector, and push it in carefully until a connecting sound is heard.

**CAUTION:**

- Outer (A) moves back, and so do not put your hand on the outer part.
- Be sure to insert the connector in until it locks. Then pull on it gently to make sure that it is locked.




# AIRBAG WARNING LIGHT ILLUMINATION PATTERN

AIRBAG SYSTEM (DIAGNOSTICS)

## 7. Airbag Warning Light Illumination Pattern

### A: INSPECTION

Keep the ignition switch to ON, and confirm that the airbag warning light remains off after being turned on for approx. 6 seconds.



- (1) Airbag warning light
- (2) Approx. 6 seconds
- (3) Ignition switch ON


# READ DIAGNOSTIC TROUBLE CODE (DTC)

## AIRBAG SYSTEM (DIAGNOSTICS)

### 8. Read Diagnostic Trouble Code (DTC)

#### A: OPERATION

- 1) Turn the ignition switch to ON.
- 2) Connect the ground terminal to diagnosis connector terminal No. 1 in the instrument panel lower cover area.



- (1) Diagnosis connector  
(2) Ground terminal


3) Read the DTC by identifying the way airbag warning light flashes.

The airbag warning light flashes a code corresponding to the faulty parts.

The long segment (1.2 sec on) indicates a "ten", and the short segment (0.3 sec on) indicates a "one".

#### NOTE:

- "List of Diagnostic Trouble Code (DTC)" <Ref. to AB-32, List of Diagnostic Trouble Code (DTC).>
- "Airbag Warning Light Failure" <Ref. to AB-27, Airbag Warning Light Failure.>



- (1) Example  
(2) Flashing code 12:  
(3) Flashing code 21:  
(4) Flashing normal code:  
(5) Sec.

4) Turn the ignition switch to OFF, and disconnect the ground terminal from the diagnosis connector terminal No. 1.

5) Wind tape around the ground terminal and return it to its original position.



## 9. Inspection Mode

### A: OPERATION

Recreate the circumstance by referring to the conditions described in the checklist.


## CLEAR MEMORY MODE

AIRBAG SYSTEM (DIAGNOSTICS)

### 10. Clear Memory Mode

#### A: OPERATION

- 1) Turn the ignition switch to ON.
- 2) Connect the ground terminal (ground terminal "A") to diagnosis connector terminal No. 1 in the instrument panel lower cover area.



- (1) Diagnosis connector
- (2) Ground terminal "B"
- (3) Ground terminal "A"

- 3) While the warning light flashes, connect another diagnosis terminal (ground terminal "B") to diagnosis connector terminal No. 2.
- 4) Once the memory is erased, the warning light returns to the normal flash rate (0.6 sec on). The failure to recover the normal flash rate indicates that trouble parts still remain. Having repaired such parts, erase the memory again and confirm that the normal flash rate has returned.
- 5) When the memory has been cleared, disconnect the ground terminal from the diagnosis connector.
- 6) Wind tape around the ground terminal and return it to its original position.

## Airbag Warning Light Failure

### A: AIRBAG WARNING LIGHT REMAINS ON.


#### DIAGNOSIS:

- Airbag warning light unit is faulty.
- Airbag control module to airbag warning light circuit is shorted or open.
- Grounding circuit is faulty.
- Airbag control module is faulty.
- (AB1) and (B31) are not connected properly.
- (AB3) is not connected properly to the airbag control module.

#### CAUTION:

- Before diagnosing the airbag system, be sure to turn the ignition switch to OFF, disconnect the ground cable from battery, and wait more than 20 seconds before starting to work.
- Before replacing the airbag module, seat belt pretensioner roll connector, control module, and sensor, reconnect each part and confirm that the warning light operates properly.
- When inspecting the airbag main harness, disconnect the airbag module connector of the driver and passenger seats for safety reasons.

#### WIRING DIAGRAM:



# AIRBAG WARNING LIGHT FAILURE

## AIRBAG SYSTEM (DIAGNOSTICS)

Step	Check	Yes	No
<b>1 CHECK POOR CONTACT IN CONNECTORS (AB1) AND (B31).</b> 1) Turn the ignition switch to OFF, disconnect the battery ground cable, and wait more than 20 seconds. 2) Remove the side sill cover. (Driver's side) 3) Confirm that firm contact is secured between connectors (AB1) and (B31).	Is the poor contact in connectors (AB1) and (B31)?	Repair the body harness or replace the body harness with airbag main harness.	Go to step 2.
<b>2 CHECK AIRBAG WARNING LIGHT.</b> 1) Turn the ignition switch to OFF, disconnect the battery ground cable, and wait more than 20 seconds. 2) Connect the connector (1T) in test harness T to the body harness connector (B31). 3) Connect the connector (1M) in test harness M to the connector (2T) in test harness T. 4) Connect the battery ground cable and turn the ignition switch to ON. 5) Connect two connectors, (3M) and (4M) in test harness M.	Is the airbag warning light turned off?	Go to step 4.	Go to step 3.
<b>3 CHECK BODY HARNESS.</b> Check the body harness.  NOTE: After problem has been eliminated, disconnect the connectors (3M) and (4M).	Is there anything unusual to body harness?	Repair the body harness.	Replace the combination meter printed circuit. <Ref. to IDI-10, Combination Meter Assembly.>
<b>4 CHECK POOR CONTACT.</b> Confirm that firm contact is secured between the airbag control module and the connector (AB3). <Ref. to AB-16, Airbag Control Module.>	Is the poor contact in connector (AB3)?	Replace the body harness with airbag main harness or replace the airbag control module. <Ref. to AB-16, Airbag Control Module.>	Go to step 5.
<b>5 CHECK AIRBAG MAIN HARNESS.</b> 1) Turn the ignition switch to OFF, disconnect the battery ground cable, and wait more than 20 seconds. 2) Connect the connector (AB1) to (B31). 3) Disconnect the connectors (AB26) and (AB21). 4) Remove the glove box and disconnect the connectors (AB27) and (AB4). 5) Disconnect the connector (AB3) from the airbag control module, and connect the connector (1R) in test harness R. <Ref. to AB-16, Airbag Control Module.> 6) Connect the battery ground cable and turn the ignition switch to ON. 7) Connect the connectors (5R) and (6R) in test harness R.  NOTE: After problem has been eliminated, disconnect the connectors (5R) and (6R).	Is the airbag warning light turned off?	Go to step 6.	Replace the body harness with airbag main harness.

# AIRBAG WARNING LIGHT FAILURE

AIRBAG SYSTEM (DIAGNOSTICS)

Step	Check	Yes	No
<b>6</b> <b>CHECK GROUNDING CIRCUIT.</b> 1) Turn the ignition switch to OFF, disconnect the battery ground cable, and wait more than 20 seconds. 2) Disconnect the connector (AB3) from the airbag control module. 3) Connect the connector (1R) in test harness R to body harness connector (AB3). 4) Measure the resistance between connector (2R) in test harness R and the chassis ground. <b>Connector &amp; terminal</b> <b>(2R) No. 10 — Chassis ground:</b> <b>(2R) No. 11 — Chassis ground:</b>	Is the resistance less than 10 $\Omega$ ?	Replace the airbag control module. <Ref. to AB-16, Airbag Control Module.>	Repair the body-grounding circuit.

# AIRBAG WARNING LIGHT FAILURE

AIRBAG SYSTEM (DIAGNOSTICS)

## B: AIRBAG WARNING LIGHT REMAINS OFF.






### DIAGNOSIS:

- Fuse No. 13 (in fuse box) is blown.
- Body harness circuit is open.
- Airbag warning light is faulty.
- Airbag main harness is faulty.
- Airbag control module is faulty.

### CAUTION:

- Before diagnosing the airbag system, be sure to turn the ignition switch to OFF, disconnect the ground cable from battery, and wait more than 20 seconds before starting to work.
- Before replacing the airbag module, seat belt pretensioner roll connector, control module, and sensor, reconnect each part and confirm that the warning light operates properly.
- When inspecting the airbag main harness, disconnect the airbag module connector of the driver and passenger seats for safety reasons.

### WIRING DIAGRAM:



AB-00601

# AIRBAG WARNING LIGHT FAILURE

AIRBAG SYSTEM (DIAGNOSTICS)

Step	Check	Yes	No
<b>1 CHECK COMBINATION METER.</b> Turn the ignition switch to ON, and confirm that warning lights equipped in the combination meter are turned on.	Do the warning lights not for airbag turn on?	Go to step 2.	Repair the combination meter power supply. <Ref. to IDI-3, Combination Meter System.>
<b>2 CHECK FUSE NO. 13 (IN MAIN FUSE BOX).</b> Remove the fuse No. 13 and perform visual inspection.	Is the fuse No. 13 (in main fuse box) blown out?	Replace the fuse No. 13. If fuse No. 13 is blown out again, go to step 3.	Go to step 3.
<b>3 CHECK AIRBAG WARNING LIGHT CIRCUIT (IN COMBINATION METER).</b> 1) Turn the ignition switch to OFF, disconnect the battery ground cable, and wait more than 20 seconds. 2) Disconnect the connector (AB1) from (B31). 3) Connect the battery ground cable and turn the ignition switch to ON.	Is the airbag warning light turned on?	Go to step 4.	Replace the airbag warning light bulb or combination meter printed circuit. <Ref. to IDI-10, Combination Meter Assembly.>
<b>4 CHECK AIRBAG MAIN HARNESS.</b> 1) Turn the ignition switch to OFF, disconnect the battery ground cable, and wait more than 20 seconds. 2) Connect the connector (AB1) to (B31). 3) Disconnect the connector (AB3) from the airbag control module. <Ref. to AB-16, Airbag Control Module.> 4) Connect the battery ground cable and turn the ignition switch to ON.	Is the airbag warning light turned on?	Replace the airbag control module. <Ref. to AB-16, Airbag Control Module.>	Replace the body harness with airbag main harness.

# LIST OF DIAGNOSTIC TROUBLE CODE (DTC)

AIRBAG SYSTEM (DIAGNOSTICS)

## 12. List of Diagnostic Trouble Code (DTC)

### A: LIST

DTC	Memory function	Contents of diagnosis	Index No.
11	Provided.	<ul style="list-style-type: none"> <li>• Airbag main harness circuit is open, shorted or shorted to ground.</li> <li>• Airbag module harness (driver) circuit is open, shorted or shorted to ground.</li> <li>• Roll connector circuit is open, shorted or shorted to ground.</li> <li>• Airbag control module is faulty.</li> <li>• Driver's airbag module is faulty.</li> </ul>	<Ref. to AB-35, DTC 11, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
12	Provided.	<ul style="list-style-type: none"> <li>• Airbag main harness circuit is open, shorted or shorted to ground.</li> <li>• Airbag module harness (passenger) circuit is open, shorted or shorted to ground.</li> <li>• Airbag control module is faulty.</li> <li>• Passenger's airbag module is faulty.</li> </ul>	<Ref. to AB-37, DTC 12, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
15	Provided.	<ul style="list-style-type: none"> <li>• Airbag main harness circuit (driver) is shorted to power supply.</li> <li>• Airbag module harness (driver) is shorted to power supply.</li> <li>• Roll connector is shorted to power supply.</li> <li>• Airbag control module is faulty.</li> <li>• Driver's airbag module is faulty.</li> </ul>	<Ref. to AB-39, DTC 15, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
16	Provided.	<ul style="list-style-type: none"> <li>• Airbag main harness circuit (passenger) is shorted to power supply.</li> <li>• Airbag module harness (passenger) is shorted to power supply.</li> <li>• Airbag control module is faulty.</li> <li>• Passenger's airbag module is faulty.</li> </ul>	<Ref. to AB-41, DTC 16, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
21	Provided.	Airbag control module is faulty.	<Ref. to AB-42, DTC 21, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
22	Provided.	Front airbag module and seat belt pretensioner (LH/RH) are inflated.	<Ref. to AB-43, DTC 22, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
23	Not provided.	(AB3), (AB7) and (AB8) are not connected properly to airbag control module.	<Ref. to AB-44, DTC 23, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
24	Not provided.	<ul style="list-style-type: none"> <li>• Airbag control module is faulty.</li> <li>• Airbag main harness circuit is open.</li> <li>• Fuse No. 11 (in joint box) is blown.</li> <li>• Body harness circuit is open.</li> </ul>	<Ref. to AB-45, DTC 24, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
25	Provided.	<ul style="list-style-type: none"> <li>• Airbag control module is faulty.</li> <li>• Airbag main harness circuit is open.</li> <li>• Fuse No. 6 (in joint box) is blown.</li> <li>• Body harness circuit is open.</li> </ul>	<Ref. to AB-47, DTC 25, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
31	Provided.	<ul style="list-style-type: none"> <li>• Front sub-sensor harness (RH) circuit is shorted.</li> <li>• Front sub-sensor harness (RH) circuit is open.</li> <li>• Front sub-sensor (RH) is faulty.</li> <li>• Airbag control module is faulty.</li> </ul>	<Ref. to AB-49, DTC 31, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>



# LIST OF DIAGNOSTIC TROUBLE CODE (DTC)

## AIRBAG SYSTEM (DIAGNOSTICS)

DTC	Memory function	Contents of diagnosis	Index No.
32	Provided.	<ul style="list-style-type: none"> <li>• Front sub-sensor harness (LH) circuit is shorted.</li> <li>• Front sub-sensor harness (LH) circuit is open.</li> <li>• Front sub-sensor (LH) is faulty.</li> <li>• Airbag control module is faulty.</li> </ul>	<Ref. to AB-51, DTC 32, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
41	Provided.	<ul style="list-style-type: none"> <li>• Side airbag harness (RH) is faulty.</li> <li>• Side airbag module (RH) is faulty.</li> <li>• Airbag control module is faulty.</li> </ul>	<Ref. to AB-54, DTC 41, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
42	Provided.	<ul style="list-style-type: none"> <li>• Side airbag harness (LH) is faulty.</li> <li>• Side airbag module (LH) is faulty.</li> <li>• Airbag control module is faulty.</li> </ul>	<Ref. to AB-56, DTC 42, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
45	Provided.	<ul style="list-style-type: none"> <li>• Side airbag harness (RH) is shorted to power supply.</li> <li>• Airbag control module is faulty.</li> </ul>	<Ref. to AB-58, DTC 45, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
46	Provided.	<ul style="list-style-type: none"> <li>• Side airbag harness (LH) is shorted to power supply.</li> <li>• Airbag control module is faulty.</li> </ul>	<Ref. to AB-60, DTC 46, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
51	Provided.	<ul style="list-style-type: none"> <li>• Side airbag sensor (RH) is faulty.</li> <li>• Side airbag harness (RH) is faulty.</li> <li>• Airbag control module is faulty.</li> </ul>	<Ref. to AB-62, DTC 51, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
52	Provided.	<ul style="list-style-type: none"> <li>• Side airbag sensor (LH) is faulty.</li> <li>• Side airbag harness (LH) is faulty.</li> <li>• Airbag control module is faulty.</li> </ul>	<Ref. to AB-64, DTC 52, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
53	Provided.	Side airbag sensor (RH) is faulty.	<Ref. to AB-66, DTC 53, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
54	Provided.	Side airbag sensor (LH) is faulty.	<Ref. to AB-66, DTC 54, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
55	Provided.	Side airbag module is inflated.	<Ref. to AB-66, DTC 55, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
61	Provided.	<ul style="list-style-type: none"> <li>• Seat belt pretensioner (RH) circuit is open, shorted or shorted to ground.</li> <li>• Airbag control module is faulty.</li> <li>• Pretensioner is faulty.</li> <li>• Pretensioner harness is faulty.</li> </ul>	<Ref. to AB-67, DTC 61, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
62	Provided.	<ul style="list-style-type: none"> <li>• Seat belt pretensioner (LH) circuit is open, shorted or shorted to ground.</li> <li>• Airbag control module is faulty.</li> <li>• Pretensioner is faulty.</li> <li>• Pretensioner harness is faulty.</li> </ul>	<Ref. to AB-69, DTC 62, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>

# LIST OF DIAGNOSTIC TROUBLE CODE (DTC)

## AIRBAG SYSTEM (DIAGNOSTICS)

DTC	Memory function	Contents of diagnosis	Index No.
65	Provided.	<ul style="list-style-type: none"><li>• Seat belt pretensioner (RH) circuit is shorted to power supply.</li><li>• Pretensioner is faulty.</li><li>• Pretensioner harness is faulty.</li><li>• Airbag control module is faulty.</li></ul>	<Ref. to AB-71, DTC 65, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
66	Provided.	<p>Seat belt pretensioner (LH) circuit is shorted to power supply.</p> <ul style="list-style-type: none"><li>• Pretensioner is faulty.</li><li>• Pretensioner harness is faulty.</li><li>• Airbag control module is faulty.</li></ul>	<Ref. to AB-73, DTC 66, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>

### 13. Diagnostic Procedure with Diagnostic Trouble Code (DTC)

#### A: DTC 11


##### DIAGNOSIS:

- Airbag main harness circuit is open, shorted or shorted to ground.
- Airbag module harness (Driver) circuit is open, shorted or shorted to ground.
- Roll connector circuit is open, shorted or shorted to ground.
- Driver's airbag module is faulty.
- Airbag control module is faulty.

##### CAUTION:

- Before diagnosing the airbag system, be sure to turn the ignition switch to OFF, disconnect the ground cable from battery, and wait more than 20 seconds before starting to work.
- Before replacing the airbag module, seat belt pretensioner roll connector, control module, and sensor, reconnect each part and confirm that the warning light operates properly.
- When inspecting the airbag main harness, disconnect the driver's airbag module and passenger's airbag module connectors for safety reasons.

##### WIRING DIAGRAM:



# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

## AIRBAG SYSTEM (DIAGNOSTICS)

Step	Check	Yes	No
<b>1 CHECK DRIVER'S AIRBAG MODULE.</b> 1) Turn the ignition switch to OFF, disconnect the battery ground cable, and wait more than 20 seconds. 2) Remove the driver's airbag module. <Ref. to AB-12, Driver's Airbag Module.> 3) Connect the connector (1N) in test harness N to connector (AB2). 4) Connect the airbag resistor to connector (2N) in test harness N. 5) Connect the battery ground cable and turn the ignition switch to ON.	Does the airbag warning light operate properly?	Replace the driver's airbag module. <Ref. to AB-12, Driver's Airbag Module.>	Go to step 2.
<b>2 CHECK ROLL CONNECTOR.</b> 1) Turn the ignition switch to OFF, disconnect the battery ground cable, and wait more than 20 second. 2) Disconnect the test harness N from the connector (AB2). 3) Remove the instrument panel lower cover, disconnect the connector (AB26) from (AB21) and connect the connector (1F) in test harness F to connector (AB21). 4) Connect the airbag resistor to connector (3F) in test harness F. 5) Connect the battery ground cable and turn the ignition switch to ON.	Does the airbag warning light operate properly?	Replace the roll connector. <Ref. to AB-18, Roll Connector.>	Go to step 3.
<b>3 CHECK AIRBAG MAIN HARNESS.</b> 1) Turn the ignition switch to OFF, disconnect the ground cable, and wait more than 20 seconds. 2) Disconnect the airbag resistor from the connector (3F) in test harness F. 3) Remove the glove box, <Ref. to AB-13, Passenger's Airbag Module.> and disconnect connectors (AB27) and (AB4). 4) Disconnect the connector (AB3) from the airbag control module, and connect the connector (1R) in test harness R. <Ref. to AB-16, Airbag Control Module.> 5) Measure the resistance between connector (2R) in test harness R and the connector (3F) in test harness F. <b>Connector &amp; terminal</b> <b>(2R) No. 2 — (3F) No. 3:</b> <b>(2R) No. 4 — (3F) No. 4:</b>	Is the resistance less than 10 Ω?	Go to step 4.	Replace the body harness with airbag main harness.
<b>4 CHECK AIRBAG MAIN HARNESS.</b> Measure the resistance of the connector (2R) in test harness R. <b>Connector &amp; terminal</b> <b>(2R) No. 2 — (2R) No. 4:</b> <b>(2R) No. 4 — Chassis ground:</b> <b>(2R) No. 2 — Chassis ground:</b>	Is the resistance more than 1 MΩ?	Replace the airbag control module. <Ref. to AB-16, Airbag Control Module.>	Replace the body harness with airbag main harness.

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

AIRBAG SYSTEM (DIAGNOSTICS)

## B: DTC 12


### DIAGNOSIS:

- Airbag main harness circuit is open, shorted or shorted to ground.
- Airbag module harness (Passenger) circuit is open, shorted or shorted to ground.
- Passenger's airbag module is faulty.
- Airbag control module is faulty.

### CAUTION:

- Before diagnosing the airbag system, be sure to turn the ignition switch to OFF, disconnect the ground cable from battery, and wait more than 20 seconds before starting to work.
- Before replacing the airbag module, seat belt pretensioner roll connector, control module, and sensor, reconnect each part and confirm that the warning light operates properly.
- When inspecting the airbag main harness, disconnect the airbag module connector of the driver and passenger seats for safety reasons.

### WIRING DIAGRAM:



# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

## AIRBAG SYSTEM (DIAGNOSTICS)

Step	Check	Yes	No
<b>1 CHECK PASSENGER'S AIRBAG MODULE.</b> 1) Turn the ignition switch to OFF, disconnect the battery ground cable, and wait more than 20 seconds. 2) Remove the glove box. 3) Disconnect the connector (AB27) from (AB4). 4) Connect the connector (1F) in test harness F to connector (AB4). 5) Connect the airbag resistor to connector (3F) in test harness F. 6) Connect the battery ground cable and turn the ignition switch to ON.	Does the airbag warning light operate properly?	Replace the passenger airbag module. <Ref. to AB-13, Passenger's Airbag Module.>	Go to step 2.
<b>2 CHECK AIRBAG MAIN HARNESS.</b> 1) Turn the ignition switch to OFF, disconnect the battery ground cable, and wait more than 20 seconds. 2) Disconnect the airbag resistor from the connector (3F) in test harness F. 3) Remove the instrument panel lower cover and disconnect the connector (AB26) from (AB21). 4) Disconnect the connector (AB3) from the airbag control module, and connect the connector (1R) in test harness R. <Ref. to AB-16, Airbag Control Module.> 5) Measure the resistance between connector (2R) in test harness R and the connector (3F) in test harness F. <b>Connector &amp; terminal</b> <b>(2R) No. 3 — (3F) No. 4:</b> <b>(2R) No. 5 — (3F) No. 3:</b>	Is the resistance less than 10 Ω?	Go to step 3.	Replace the body harness with airbag main harness.
<b>3 CHECK AIRBAG MAIN HARNESS.</b> Measure the resistance of the connector (2R) in test harness R. <b>Connector &amp; terminal</b> <b>(2R) No. 3 — (2R) No. 5:</b> <b>(2R) No. 3 — Chassis ground:</b> <b>(2R) No. 5 — Chassis ground:</b>	Is the resistance more than 1 MΩ?	Replace the airbag control module. <Ref. to AB-16, Airbag Control Module.>	Replace the body harness with airbag main harness.

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

AIRBAG SYSTEM (DIAGNOSTICS)

## C: DTC 15


### DIAGNOSIS:

- Airbag main harness circuit (Driver) is shorted to the power supply.
- Airbag module harness (Driver) is shorted to the power supply.
- Roll connector is shorted to the power supply.
- Driver's airbag module is faulty.
- Airbag control module is faulty.

### CAUTION:

- Before diagnosing the airbag system, be sure to turn the ignition switch to OFF, disconnect the ground cable from battery, and wait more than 20 seconds before starting to work.
- Before replacing the airbag module, seat belt pretensioner roll connector, control module, and sensor, reconnect each part and confirm that the warning light operates properly.
- When inspecting the airbag main harness, disconnect the driver's airbag module and passenger's airbag module connectors for safety reasons.

### WIRING DIAGRAM:



# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

## AIRBAG SYSTEM (DIAGNOSTICS)

	Step	Check	Yes	No
<b>1</b> <b>CHECK DRIVER'S AIRBAG MODULE.</b> 1) Turn the ignition switch to OFF, disconnect the battery ground cable, and wait more than 20 seconds. 2) Remove the driver's airbag module. <Ref. to AB-12, Driver's Airbag Module.> 3) Connect the connector (AB2) to connector (1N) in test harness N. 4) Connect the airbag resistor to connector (2N) in test harness N. 5) Connect the battery ground cable and turn the ignition switch to ON.	Does the airbag warning light operate properly?	Replace the driver's airbag module. <Ref. to AB-12, Driver's Airbag Module.>	Go to step 2.	
<b>2</b> <b>CHECK ROLL CONNECTOR.</b> 1) Turn the ignition switch to OFF, disconnect the battery ground cable, and wait more than 20 seconds. 2) Disconnect the test harness N from the connector (AB2). 3) Remove the instrument panel lower cover panel and disconnect the connector (AB26) from (AB21). 4) Connect the connector (1F) in test harness F to connector (AB21). 5) Connect the airbag resistor to connector (3F) in test harness F. 6) Connect the battery ground cable and turn the ignition switch to ON.	Does the airbag warning light operate properly?	Replace the roll connector. <Ref. to AB-18, Roll Connector.>	Go to step 3.	
<b>3</b> <b>CHECK AIRBAG MAIN HARNESS.</b> 1) Turn the ignition switch to OFF, disconnect the battery ground cable, and wait more than 20 seconds. 2) Disconnect the airbag resistor from the connector (3F) in test harness F. 3) Remove the glove box, and disconnect the connectors (AB27) and (AB4). 4) Disconnect the connector (AB3) from the airbag control module, and connect the connector (1R) in test harness R. <Ref. to AB-16, Airbag Control Module.> 5) Connect the battery ground cable and turn the ignition switch to ON. (engine OFF) 6) Measure the voltage between connector (2R) in test harness R and the chassis ground. <b>Connector &amp; terminal</b> (2R) No. 4 (+) — Chassis ground (-): (2R) No. 2 (+) — Chassis ground (-):	Is the voltage less than 1 V?	Replace the airbag control module. <Ref. to AB-16, Airbag Control Module.>	Replace the body harness with airbag main harness.	



# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

AIRBAG SYSTEM (DIAGNOSTICS)

## D: DTC 16


### DIAGNOSIS:

- Airbag main harness circuit (Passenger) is shorted to the power supply.
- Airbag module harness (Passenger) is shorted to the power supply.
- Passenger's airbag module is faulty.
- Airbag control module is faulty.

### CAUTION:

- Before diagnosing the airbag system, be sure to turn the ignition switch to OFF, disconnect the ground cable from battery, and wait more than 20 seconds before starting to work.
- Before replacing the airbag module, seat belt pretensioner roll connector, control module, and sensor, reconnect each part and confirm that the warning light operates properly.
- When inspecting the airbag main harness, disconnect the airbag module connector of the driver and passenger seats for safety reasons.

### WIRING DIAGRAM:



AB-00538

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

## AIRBAG SYSTEM (DIAGNOSTICS)

Step	Check	Yes	No
<b>1 CHECK PASSENGER'S AIRBAG MODULE.</b> 1) Turn the ignition switch to OFF, disconnect the battery ground cable, and wait more than 20 seconds. 2) Remove the glove box. 3) Disconnect the connector (AB27) from (AB4) 4) Connect the connector (1F) in test harness F to connector (AB4). 5) Connect the airbag resistor to connector (3F) in test harness F. 6) Connect the battery ground cable and turn the ignition switch to ON.	Does the airbag warning light operate properly?	Replace the passenger airbag module. <Ref. to AB-13, Passenger's Airbag Module.>	Go to step 2.
<b>2 CHECK AIRBAG MAIN HARNESS.</b> 1) Turn the ignition switch to OFF, disconnect the battery ground cable, and wait more than 20 seconds. 2) Disconnect the airbag resistor from the connector (3F) in test harness F. 3) Remove the instrument panel lower cover and disconnect the connector (AB26) from (AB21). 4) Disconnect the connector (AB3) from the airbag control module, and connect the connector (1R) in test harness R. <Ref. to AB-16, Airbag Control Module.> 5) Measure the voltage between connector (2R) in test harness R and the chassis ground. <b>Connector &amp; terminal</b> (2R) No. 3 (+) — Chassis ground (-): (2R) No. 5 (+) — Chassis ground (-):	Is the voltage less than 1 V?	Replace the airbag control module. <Ref. to AB-16, Airbag Control Module.>	Replace the body harness with airbag main harness.

### E: DTC 21

#### DIAGNOSIS:

- Airbag control module is faulty.

#### CAUTION:

- Before diagnosing the airbag system, be sure to turn the ignition switch to OFF, disconnect the ground cable from battery, and wait more than 20 seconds before starting to work.
- Before replacing the airbag module, seat belt pretensioner roll connector, control module, and sensor, reconnect each part and confirm that the warning light operates properly.


Step	Check	Yes	No
<b>1 CHECK IF DTC 21 IS INDICATED.</b> Read the DTC. <Ref. to AB-24, Read Diagnostic Trouble Code (DTC).>	Is the airbag warning light DTC 21 indicated?	Replace the airbag control module. <Ref. to AB-16, Airbag Control Module.>	Perform clear memory. <Ref. to AB-26, Clear Memory Mode.>

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

AIRBAG SYSTEM (DIAGNOSTICS)

## F: DTC 22

### WIRING DIAGRAM:



AB-00542

This code is indicated when the front airbag and the pretensioner are in operation.

Once this code is indicated, memory is not erasable; therefore replace the following parts.

- Airbag control module. <Ref. to AB-16, Airbag Control Module.>
- Driver's airbag module. <Ref. to AB-12, Driver's Airbag Module.>
- Passenger's airbag module. <Ref. to AB-13, Passenger's Airbag Module.>
- Front sub-sensor of both sides. <Ref. to AB-19, Front Sub Sensor.>
- Front seat belt outer with pretensioner of both sides. <Ref. to SB-8, Front Seat Belt.>

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

AIRBAG SYSTEM (DIAGNOSTICS)

## G: DTC 23

### DIAGNOSIS:

(AB3), (AB7) and (AB8) are not connected properly to airbag control module.

### CAUTION:

**Before diagnosing the airbag system, be sure to turn the ignition switch to OFF, disconnect the ground cable from battery, and wait more than 20 seconds before starting to work.**

	Step	Check	Yes	No
1	<b>CHECK POOR CONTACT IN CONECTORS (AB3), (AB7) AND (AB8).</b> 1) Turn the ignition switch to OFF, disconnect the battery ground cable, and wait more than 20 seconds. 2) Disconnect the connectors (AB3), (AB7) and (AB8) from the airbag control module. <Ref. to AB-16, Airbag Control Module.>	Check if rust or damage appear on the harness connector and the control module connector.	Replace the airbag control module. <Ref. to AB-16, Airbag Control Module.> Replace the body harness with airbag main harness. Replace the body harness with side airbag harness.	Go to step 2.
2	<b>CHECK POOR CONTACT IN CONECTORS (AB3), (AB7) AND (AB8).</b> 1) Ensure that connectors are firmly reconnected. 2) Connect the battery ground cable and turn the ignition switch to ON.	Does the airbag warning light operate properly?	Finish the diagnosis.	Replace the airbag control module. <Ref. to AB-16, Airbag Control Module.>

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

AIRBAG SYSTEM (DIAGNOSTICS)

## H: DTC 24


### DIAGNOSIS:

- Airbag control module is faulty.
- Airbag main harness circuit is open.
- Fuse No, 11 (in joint box) is blown.
- Body harness circuit is open.

### CAUTION:

- Before diagnosing the airbag system, be sure to turn the ignition switch to OFF, disconnect the ground cable from battery, and wait more than 20 seconds before starting to work.
- Before replacing the airbag module, seat belt pretensioner roll connector, control module, and sensor, reconnect each part and confirm that the warning light operates properly.
- When inspecting the airbag main harness, disconnect the driver's airbag module and passenger's airbag module connectors for safety reasons.

### WIRING DIAGRAM:



AB-00602

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

## AIRBAG SYSTEM (DIAGNOSTICS)

Step	Check	Yes	No
<b>1 CHECK AIRBAG CONTROL MODULE.</b> 1) Turn the ignition switch to OFF, disconnect the battery ground cable, and wait more than 20 seconds. 2) Disconnect the connector (AB3) from the airbag control module. <Ref. to AB-16, Airbag Control Module.> 3) Connect the connector (1R) in test harness R to connector (AB3). 4) Connect the battery ground cable and turn the ignition switch to ON. 5) Measure the voltage between connector (2R) in test harness R and chassis ground. <b>Connector &amp; terminal</b> <b>(2R) No. 1 (+) — Chassis ground (-):</b>	Is the voltage more than 10 V?	Replace the airbag control module. <Ref. to AB-16, Airbag Control Module.>	Go to step 2.
<b>2 CHECK AIRBAG MAIN HARNESS.</b> 1) While checking control module, turn the ignition switch to OFF and disconnect the battery ground cable. Wait more than 20 seconds before operation. 2) Disconnect the airbag connector (AB1) from the body harness (B31). 3) Connect the connector (2M) in test harness M to connector (AB1). 4) Measure the resistance between connector (5M) in test harness M and the connector (2R) in test harness R. <b>Connector &amp; terminal</b> <b>(5M) No. 2 — (2R) No. 1:</b>	Is the resistance less than 10 Ω?	Go to step 3.	Replace the body harness with airbag main harness.
<b>3 CHECK AIRBAG MAIN HARNESS.</b> Measure the following resistance with the above-mentioned condition maintained. <b>Connector &amp; terminal</b> <b>(5M) No. 2 — Chassis ground:</b> <b>(2R) No. 1 — Chassis ground:</b>	Is the resistance more than 1 MΩ?	Go to step 4.	Replace the body harness with airbag main harness.
<b>4 CHECK FUSE NO. 11 (IN JOINT BOX).</b> 1) Confirm that the ignition switch is turned OFF. 2) Remove the fuse No. 11 (in joint box) and perform visual inspection.	Is the fuse No. 11 blown out?	Replace the fuse No. 11. If fuse No. 11 is blown out again, repair the body harness.	Repair the body harness.

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

AIRBAG SYSTEM (DIAGNOSTICS)

## I: DTC 25


### DIAGNOSIS:

- Airbag control module is faulty.
- Airbag main harness circuit is open.
- Fuse No. 6 (in joint box) is blown.
- Body harness circuit is open.

### CAUTION:

- Before diagnosing the airbag system, be sure to turn the ignition switch to OFF, disconnect the ground cable from battery, and wait more than 20 seconds before starting to work.
- Before replacing the airbag module, seat belt pretensioner roll connector, control module, and sensor, reconnect each part and confirm that the warning light operates properly.
- When inspecting the airbag main harness, disconnect the driver's airbag module and passenger's airbag module connectors for safety reasons.

### WIRING DIAGRAM:



AB-00603

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

## AIRBAG SYSTEM (DIAGNOSTICS)

Step	Check	Yes	No
<b>1 CHECK AIRBAG CONTROL MODULE.</b> 1) Turn the ignition switch to OFF, disconnect the battery ground cable, and wait more than 20 seconds. 2) Disconnect the connector (AB3) from airbag control module. <Ref. to AB-16, Airbag Control Module.> 3) Connect the connector (1R) in test harness R to connector (AB3). 4) Connect the battery ground cable, and turn the ignition switch to ON. 5) Measure the voltage between the connector (2R) in test harness R and the chassis ground. <b>Connector &amp; terminal</b> <b>(2R) No. 6 (+) — Chassis ground (-):</b>	Is the voltage more than 10 V?	Replace the airbag control module. <Ref. to AB-16, Airbag Control Module.>	Go to step 2.
<b>2 CHECK AIRBAG MAIN HARNESS.</b> 1) While checking control module, turn the ignition switch to OFF and disconnect the battery ground cable. Wait more than 20 seconds before operation. 2) Disconnect the airbag connector (AB1) from the body harness (B31). 3) Connect the connector (2M) in test harness M to the airbag connector (AB1). 4) Measure the resistance between the connector (5M) in test harness M and the connector (2R) in test harness R. <b>Connector &amp; terminal</b> <b>(5M) No. 4 — (2R) No. 6:</b>	Is the resistance less than 10 Ω?	Go to step 3.	Replace the body harness with airbag main harness.
<b>3 CHECK AIRBAG MAIN HARNESS.</b> Measure the following resistance with the above-mentioned condition maintained. <b>Connector &amp; terminal</b> <b>(5M) No. 4 — Chassis ground:</b> <b>(2R) No. 6 — Chassis ground:</b>	Is the resistance more than 1 MΩ?	Go to step 4.	Replace the body harness with airbag main harness.
<b>4 CHECK FUSE NO. 6 (IN JOINT BOX).</b> 1) Confirm that the ignition switch is turned OFF. 2) Remove the No. 6 fuse (in joint box) and perform visual inspection.	Is the fuse No. 6 blown out?	Replace the fuse No. 6. If fuse No. 6 is blown out again, repair the body harness.	Repair the body harness.



# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

AIRBAG SYSTEM (DIAGNOSTICS)

## J: DTC 31


### DIAGNOSIS:

- Front sub-sensor harness (RH) circuit is shorted.
- Front sub-sensor harness (RH) circuit is open.
- Front sub-sensor (RH) is faulty.
- Airbag control module is faulty.

### CAUTION:

- Before diagnosing the airbag system, be sure to turn the ignition switch to OFF, disconnect the ground cable from battery, and wait more than 20 seconds before starting to work.
- Before replacing the airbag module, seat belt pretensioner roll connector, control module, and sensor, reconnect each part and confirm that the warning light operates properly.
- When inspecting the airbag main harness, disconnect the driver's airbag module and passenger's airbag module connectors for safety reasons.

### WIRING DIAGRAM:



AB-00604

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

## AIRBAG SYSTEM (DIAGNOSTICS)

Step	Check	Yes	No
<b>1 CHECK FRONT SUB-SENSOR (RH) AND FRONT SUB-SENSOR HARNESS (RH).</b> 1) Turn the ignition switch to OFF, disconnect the battery ground cable, and wait more than 20 seconds. 2) Disconnect the connector (AB3) from the airbag control module, and connect the connector (1R) in test harness R. <Ref. to AB-16, Airbag Control Module.> 3) Measure the resistance of the connector (3R) in test harness R. <b>Connector &amp; terminal</b> <b>(3R) No. 7 — (3R) No. 9:</b>	Is the resistance 750 $\Omega$ — 1 k $\Omega$ ?	Replace the airbag control module. <Ref. to AB-16, Airbag Control Module.>	Go to step 2.
<b>2 CHECK FRONT SUB-SENSOR (RH) AND FRONT SUB-SENSOR HARNESS (RH).</b> Measure the resistance between connector (3R) in test harness R and the chassis ground. <b>Connector &amp; terminal</b> <b>(3R) No. 7 — Chassis ground:</b> <b>(3R) No. 9 — Chassis ground:</b>	Is the resistance more than 1 M $\Omega$ ?	Replace the airbag control module. <Ref. to AB-16, Airbag Control Module.>	Go to step 3.
<b>3 CHECK AIRBAG MAIN HARNESS AND FRONT SUB-SENSOR HARNESS (RH).</b> 1) Disconnect the connector (AB15) from the front sub-sensor. <Ref. to AB-19, Front Sub Sensor.> 2) Connect the connector (1H) in test harness H to connector (AB15). 3) Measure the resistance between connector (3R) in test harness R and connector (3H) in test harness H. <b>Connector &amp; terminal</b> <b>(3R) No. 7 — (3H) No. 6:</b> <b>(3R) No. 9 — (3H) No. 5:</b>	Is the resistance less than 10 $\Omega$ ?	Go to step 4.	Replace the body harness with airbag main harness.
<b>4 CHECK AIRBAG MAIN HARNESS AND FRONT SUB-SENSOR HARNESS (RH).</b> Measure the resistance between connector (3R) in test harness R and the chassis ground. <b>Connector &amp; terminal</b> <b>(3R) No. 7 — Chassis ground:</b> <b>(3R) No. 9 — Chassis ground:</b>	Is the resistance more than 1 M $\Omega$ ?	Finish the diagnosis.	Replace the front sub-sensor (RH). <Ref. to AB-19, Front Sub Sensor.>

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

AIRBAG SYSTEM (DIAGNOSTICS)

## K: DTC 32


### DIAGNOSIS:

- Front sub-sensor harness (LH) circuit is shorted.
- Front sub-sensor harness (LH) circuit is open.
- Front sub-sensor (LH) is faulty.
- Airbag control module is faulty.

### CAUTION:

- Before diagnosing the airbag system, be sure to turn the ignition switch to OFF, disconnect the ground cable from battery, and wait more than 20 seconds before starting to work.
- Before replacing the airbag module, seat belt pretensioner roll connector, control module, and sensor, reconnect each part and confirm that the warning light operates properly.
- When inspecting the airbag main harness, disconnect the driver's airbag module and passenger's airbag module connectors for safety reasons.

### WIRING DIAGRAM:



AB-00605

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

## AIRBAG SYSTEM (DIAGNOSTICS)

Step	Check	Yes	No
<b>1 CHECK FRONT SUB-SENSOR (LH) AND FRONT SUB-SENSOR HARNESS (LH).</b> 1) Turn the ignition switch to OFF, disconnect the battery ground cable, and wait more than 20 seconds. 2) Disconnect the connector (AB3) from the airbag control module, and connect connector (1R) in the test harness R to connector (AB3). <Ref. to AB-16, Airbag Control Module.> 3) Measure the resistance of the connector (3R) in the test harness R. <b>Connector &amp; terminal</b> <b>(3R) No. 8 — (3R) No. 6:</b>	Is the resistance 750 Ω — 1 kΩ?	Replace the airbag control module. <Ref. to AB-16, Airbag Control Module.>	Go to step 2.
<b>2 CHECK FRONT SUB-SENSOR (LH) AND FRONT SUB-SENSOR HARNESS (LH).</b> Measure the resistance between connector (3R) in test harness R and the chassis ground. <b>Connector &amp; terminal</b> <b>(3R) No. 8 — Chassis ground:</b> <b>(3R) No. 6 — Chassis ground:</b>	Is the resistance more than 1 MΩ?	Replace the airbag control module. <Ref. to AB-16, Airbag Control Module.>	Go to step 3.
<b>3 CHECK AIRBAG MAIN HARNESS AND FRONT SUB-SENSOR HARNESS (LH).</b> 1) Disconnect the connector (AB18) from the front sub-sensor. <Ref. to AB-19, Front Sub Sensor.> 2) Connect the connector (1H) in test harness H to connector (AB18). 3) Measure the resistance between connector (3R) in test harness R and connector (3H) in test harness H. <b>Connector &amp; terminal</b> <b>(3R) No. 6 — (3H) No. 5:</b> <b>(3R) No. 8 — (3H) No. 6:</b>	Is the resistance less than 10 Ω?	Go to step 4.	Go to step 5.
<b>4 CHECK AIRBAG MAIN HARNESS AND FRONT SUB-SENSOR HARNESS (LH).</b> Measure the resistance between connector (3R) in test harness R and the chassis ground. <b>Connector &amp; terminal</b> <b>(3R) No. 6 — Chassis ground:</b> <b>(3R) No. 8 — Chassis ground:</b>	Is the resistance more than 1 MΩ?	Go to step 9.	Go to step 5.
<b>5 CHECK AIRBAG MAIN HARNESS.</b> 1) Disconnect the connector (AB13) from (AB14), and connect the connector (1F) in test harness F to (AB13). 2) Measure the resistance between connector (3R) in test harness R and connector (3F) in test harness F. <b>Connector &amp; terminal</b> <b>(3R) No. 6 — (3F) No. 3:</b> <b>(3R) No. 8 — (3F) No. 4:</b>	Is the resistance less than 10 Ω?	Go to step 6.	Replace the body harness with airbag main harness.
<b>6 CHECK AIRBAG MAIN HARNESS.</b> Measure the resistance between connector (3R) in the test harness R and the chassis ground. <b>Connector &amp; terminal</b> <b>(3R) No. 6 — Chassis ground:</b> <b>(3R) No. 8 — Chassis ground:</b>	Is the resistance more than 1 MΩ?	Go to step 7.	Replace the body harness with airbag main harness.

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

AIRBAG SYSTEM (DIAGNOSTICS)

Step	Check	Yes	No
<b>7</b> <b>CHECK FRONT SUB-SENSOR HARNESS (LH).</b> 1)Connect the connector (2F) in test harness F to connector (AB14). 2)Measure the resistance between connector (3H) in test harness H and connector (3F) in test harness F. <i>Connector &amp; terminal</i> <i>(3F) No. 5 — (3H) No. 5:</i> <i>(3F) No. 6 — (3H) No. 6:</i>	Is the resistance less than 10 $\Omega$ ?	Go to step <b>8</b> .	Replace the body harness with front sub-sensor harness (LH).
<b>8</b> <b>CHECK FRONT SUB-SENSOR HARNESS (LH).</b> Measure the resistance between connector (3F) in test harness F and the chassis ground. <i>Connector &amp; terminal</i> <i>(3F) No. 5 — Chassis ground:</i> <i>(3F) No. 6 — Chassis ground:</i>	Is the resistance more than 1 M $\Omega$ ?	Go to step <b>9</b> .	Replace the body harness with front sub-sensor harness (LH).
<b>9</b> <b>CHECK FRONT SUB-SENSOR (LH).</b> 1)Connect the connector (2H) in test harness H to front sub-sensor (LH). 2)Measure the resistance of the connector (3H) in test harness H. <i>Connector &amp; terminal</i> <i>(3H) No. 3 — (3H) No. 4:</i>	Is the resistance 750 $\Omega$ — 1 k $\Omega$ ?	Go to step <b>10</b> .	Replace the front sub-sensor (LH). <Ref. to AB-19, Front Sub Sensor.>
<b>10</b> <b>CHECK FRONT SUB-SENSOR (LH).</b> Measure the resistance between connector (3H) in test harness H and the chassis ground. <i>Connector &amp; terminal</i> <i>(3H) No. 3 — Chassis ground:</i> <i>(3H) No. 4 — Chassis ground:</i>	Is the resistance more than 1 M $\Omega$ ?	Finish the diagnosis.	Replace the front sub-sensor (LH). <Ref. to AB-19, Front Sub Sensor.>

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

## AIRBAG SYSTEM (DIAGNOSTICS)

### L: DTC 41


#### DIAGNOSIS:

- Side airbag harness (RH) is faulty.
- Side airbag module (RH) is faulty.
- Airbag control module is faulty.

#### CAUTION:

- Before diagnosing the airbag system, be sure to turn the ignition switch to OFF, disconnect the ground cable from battery, and wait more than 20 seconds before starting to work.
- Before replacing the airbag module, seat belt pretensioner roll connector, control module, and sensor, reconnect each part and confirm that the warning light operates properly.
- When inspecting the airbag main harness, disconnect the driver's airbag module and passenger's airbag module connectors for safety reasons.
- When inspecting the side airbag harness, disconnect the side airbag module connector and seat belt pretensioner connector for the safety reasons.

#### WIRING DIAGRAM:



AB-00562

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

## AIRBAG SYSTEM (DIAGNOSTICS)

Step	Check	Yes	No
<b>1 CHECK SIDE AIRBAG MODULE.</b> 1) Turn the ignition switch to OFF, disconnect the battery ground cable, and wait more than 20 seconds. 2) Disconnect the connector (AB20) from the seat belt pretensioner (RH). <Ref. to SB-8, Front Seat Belt.> 3) Disconnect the connector (AB28) from (AB11), and connect the connector (1F) in test harness F to (AB11). 4) Connect the airbag resistor to connector (3F) in test harness F. 5) Connect the battery ground cable, and turn the ignition switch to ON.	Does the airbag warning light operate properly?	Replace the front seat with side airbag module (RH). <Ref. to SE-6, Front Seat.>	Go to step 2.
<b>2 CHECK SIDE AIRBAG HARNESS (RH).</b> 1) Turn the ignition switch to OFF, disconnect the battery ground cable, and wait more than 20 seconds. 2) Disconnect the airbag resistor from test harness F. 3) Disconnect the connector (AB8) from air bag control module. <Ref. to AB-16, Airbag Control Module.> 4) Connect the connector (1R) in test harness R to connector (AB8). 5) Measure the resistance between connector (3R) in test harness R and connector (3F) in test harness F. <i>Connector &amp; terminal</i> <i>(3R) No. 20 — (3F) No. 4:</i> <i>(3R) No. 18 — (3F) No. 3:</i>	Is the resistance less than 10 $\Omega$ ?	Go to step 3.	Replace the body harness with side airbag harness.
<b>3 CHECK SIDE AIRBAG HARNESS (RH).</b> Measure the resistance of the connector (3R) in test harness R. <i>Connector &amp; terminal</i> <i>(3R) No. 20 — (3R) No. 18:</i>	Is the resistance more than 1 M $\Omega$ ?	Go to step 4.	Replace the body harness with side airbag harness.
<b>4 CHECK SIDE AIRBAG HARNESS (RH).</b> Measure the resistance of the connector (3F) in test harness F. <i>Connector &amp; terminal</i> <i>(3F) No. 3 — (3F) No. 4:</i>	Is the resistance more than 1 M $\Omega$ ?	Go to step 5.	Replace the body harness with side airbag harness.
<b>5 CHECK SIDE AIRBAG HARNESS (RH).</b> Measure the resistance between connector (3F) in test harness F and the chassis ground. <i>Connector &amp; terminal</i> <i>(3F) No. 3 — Chassis ground:</i> <i>(3F) No. 4 — Chassis ground:</i>	Is the resistance more than 1 M $\Omega$ ?	Go to step 6.	Replace the body harness with side airbag harness.
<b>6 CHECK SIDE AIRBAG HARNESS (RH).</b> Measure the resistance between connector (3R) in test harness R and the chassis ground. <i>Connector &amp; terminal</i> <i>(3R) No. 20 — Chassis ground:</i> <i>(3R) No. 18 — Chassis ground:</i>	Is the resistance more than 1 M $\Omega$ ?	Replace the airbag control module. <Ref. to AB-16, Airbag Control Module.>	Replace the body harness with side airbag harness.

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

## AIRBAG SYSTEM (DIAGNOSTICS)

### M: DTC 42


#### DIAGNOSIS:

- Side airbag harness (LH) is faulty.
- Side airbag module (LH) is faulty.
- Airbag control module is faulty.

#### CAUTION:

- Before diagnosing the airbag system, be sure to turn the ignition switch to OFF, disconnect the ground cable from battery, and wait more than 20 seconds before starting to work.
- Before replacing the airbag module, seat belt pretensioner roll connector, control module, and sensor, reconnect each part and confirm that the warning light operates properly.
- When inspecting the airbag main harness, disconnect the driver's airbag module and passenger's airbag module connectors for safety reasons.
- When inspecting the side airbag harness, disconnect the side airbag module connector and seat belt pretensioner connector for the safety reasons.

#### WIRING DIAGRAM:



AB-00566



# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

## AIRBAG SYSTEM (DIAGNOSTICS)

Step	Check	Yes	No
<b>1 CHECK SIDE AIRBAG MODULE.</b> 1) Turn the ignition switch to OFF, disconnect the battery ground cable, and wait more than 20 seconds. 2) Disconnect the connector (AB19) from the seat belt pretensioner (LH). <Ref. to SB-8, Front Seat Belt.> 3) Disconnect the connector (AB29) from (AB9), and connect the connector (1F) in test harness F to (AB9). 4) Connect the airbag resistor to connector (3F) in test harness F. 5) Connect the battery ground cable, and turn the ignition switch to ON.	Does the airbag warning light operate properly?	Replace the front seat with side airbag module (LH). <Ref. to SE-6, Front Seat.>	Go to step 2.
<b>2 CHECK SIDE AIRBAG HARNESS (LH).</b> 1) Turn ignition switch to OFF, disconnect the battery ground cable, and wait more than 20 seconds. 2) Disconnect the airbag resistor from the test harness. 3) Disconnect the connector (AB7) from the airbag control module. <Ref. to AB-16, Airbag Control Module.> 4) Connect the connector (1R) in test harness R to connector (AB7). 5) Measure the resistance between connector (3R) in test harness R and connector (3F) in test harness F. <b>Connector &amp; terminal</b> <b>(3R) No. 12 — (3F) No. 3:</b> <b>(3R) No. 10 — (3F) No. 4:</b>	Is the resistance less than 10 Ω?	Go to step 3.	Replace the body harness with side airbag harness.
<b>3 CHECK SIDE AIRBAG HARNESS (LH).</b> Measure the resistance of the connector (3R) in test harness R. <b>Connector &amp; terminal</b> <b>(3R) No. 12 — (3R) No. 10:</b>	Is the resistance more than 1 MΩ?	Go to step 4.	Replace the body harness with side airbag harness.
<b>4 CHECK SIDE AIRBAG HARNESS (LH).</b> Measure the resistance of the connector (3F) in test harness F. <b>Connector &amp; terminal</b> <b>(3F) No. 3 — (3F) No. 4:</b>	Is the resistance more than 1 MΩ?	Go to step 5.	Replace the body harness with side airbag harness.
<b>5 CHECK SIDE AIRBAG HARNESS (LH).</b> Measure the resistance between connector (3F) in test harness F and the chassis ground. <b>Connector &amp; terminal</b> <b>(3F) No. 3 — Chassis ground:</b> <b>(3F) No. 4 — Chassis ground:</b>	Is the resistance more than 1 MΩ?	Go to step 6.	Replace the body harness with side airbag harness.
<b>6 CHECK SIDE AIRBAG HARNESS (LH).</b> Measure the resistance between connector (3R) in test harness R and the chassis ground. <b>Connector &amp; terminal</b> <b>(3R) No. 12 — Chassis ground:</b> <b>(3R) No. 10 — Chassis ground:</b>	Is the resistance more than 1 MΩ?	Replace the airbag control module. <Ref. to AB-16, Airbag Control Module.>	Replace the body harness with side airbag harness.

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

AIRBAG SYSTEM (DIAGNOSTICS)

## N: DTC 45


### DIAGNOSIS:

- Side airbag harness (RH) is shorted to power supply.
- Airbag control module is faulty.

### CAUTION:

- Before diagnosing the airbag system, be sure to turn the ignition switch to OFF, disconnect the ground cable from battery, and wait more than 20 seconds before starting to work.
- Before replacing the airbag module, seat belt pretensioner roll connector, control module, and sensor, reconnect each part and confirm that the warning light operates properly.
- When inspecting the airbag main harness, disconnect the driver's airbag module and passenger's airbag module connectors for safety reasons.
- When inspecting the side airbag harness, disconnect the side airbag module connector and seat belt pretensioner connector for the safety reasons.

### WIRING DIAGRAM:



AB-00562

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

## AIRBAG SYSTEM (DIAGNOSTICS)

	Step	Check	Yes	No
<b>1</b> <b>CHECK SIDE AIRBAG MODULE.</b> 1) Turn the ignition switch to OFF, disconnect the battery ground cable, and wait more than 20 seconds. 2) Disconnect the connector (AB20) from the seat belt pretensioner (RH). <Ref. to SB-8, Front Seat Belt.> 3) Disconnect the connector (AB28) from (AB11), and connect the connector (1F) in test harness F to (AB11). 4) Connect the airbag resistor to connector (3F) in test harness F. 5) Connect the battery ground cable, and turn the ignition switch to ON.	Does the airbag warning light operate properly?	Replace the front seat with side airbag module (RH). <Ref. to SE-6, Front Seat.>	Go to step 2.	
<b>2</b> <b>CHECK SIDE AIRBAG HARNESS (RH).</b> 1) Turn the ignition switch to OFF, disconnect the battery ground cable, and wait more than 20 seconds. 2) Disconnect the airbag resistor from the test harness. 3) Disconnect the connector (AB8) from the airbag control module. <Ref. to AB-16, Airbag Control Module.> 4) Connect the connector (1R) in test harness R to connector (AB8). 5) Connect the battery ground cable, and turn the ignition switch to ON. 6) Measure the voltage between connector (3R) in test harness R and the chassis ground. <b>Connector &amp; terminal</b> <i>(3R) No. 20 (+) — Chassis ground (-):</i> <i>(3R) No. 18 (+) — Chassis ground (-):</i>	Is the voltage less than 1 V?	Replace the airbag control module. <Ref. to AB-16, Airbag Control Module.>	Replace the body harness with side airbag harness.	

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

AIRBAG SYSTEM (DIAGNOSTICS)

## O: DTC 46


### DIAGNOSIS:

- Side airbag harness (LH) is shorted to power supply.
- Airbag control module is faulty.

### CAUTION:

- Before diagnosing the airbag system, be sure to turn the ignition switch to OFF, disconnect the ground cable from battery, and wait more than 20 seconds before starting to work.
- Before replacing the airbag module, seat belt pretensioner roll connector, control module, and sensor, reconnect each part and confirm that the warning light operates properly.
- When inspecting the airbag main harness, disconnect the driver's airbag module and passenger's airbag module connectors for safety reasons.
- When inspecting the side airbag harness, disconnect the side airbag module connector and seat belt pretensioner connector for the safety reasons.

### WIRING DIAGRAM:



AB-00566

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

## AIRBAG SYSTEM (DIAGNOSTICS)

	Step	Check	Yes	No
<b>1</b> <b>CHECK SIDE AIRBAG MODULE.</b> 1) Turn the ignition switch to OFF, disconnect the battery ground cable, and wait more than 20 seconds. 2) Disconnect the connector (AB19) from the seat belt pretensioner (LH). <Ref. to SB-8, Front Seat Belt.> 3) Disconnect the connector (AB29) from (AB9), and connect the connector (1F) in test harness F to (AB9). 4) Connect the airbag resistor to connector (3F) in test harness F. 5) Connect the battery ground cable and turn the ignition switch to ON.	Does the airbag warning light operate properly?	Replace the front seat with side airbag module (LH). <Ref. to SE-6, Front Seat.>	Go to step 2.	
<b>2</b> <b>CHECK SIDE AIRBAG HARNESS (LH).</b> 1) Turn the ignition switch to OFF, disconnect the battery ground cable, and wait more than 20 seconds. 2) Disconnect the airbag resistor from the test harness. 3) Disconnect the connector (AB7) from the airbag control module. <Ref. to AB-16, Airbag Control Module.> 4) Connect the connector (1R) in test harness R to connector (AB7). 5) Connect the battery ground cable, and turn the ignition switch to ON. 6) Measure the voltage between connector (3R) in test harness R and the chassis ground. <b>Connector &amp; terminal</b> <b>(3R) No. 12 (+) — Chassis ground (-):</b> <b>(3R) No. 10 (+) — Chassis ground (-):</b>	Is the voltage less than 1 V?	Replace the airbag control module. <Ref. to AB-16, Airbag Control Module.>	Replace the body harness with side airbag harness.	

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

## AIRBAG SYSTEM (DIAGNOSTICS)

### P: DTC 51


#### DIAGNOSIS:

- Side airbag sensor (RH) is faulty.
- Side airbag harness (RH) is faulty.
- Airbag control module is faulty.

#### CAUTION:

- Before diagnosing the airbag system, be sure to turn the ignition switch to OFF, disconnect the ground cable from battery, and wait more than 20 seconds before starting to work.
- Before replacing the airbag module, seat belt pretensioner roll connector, control module, and sensor, reconnect each part and confirm that the warning light operates properly.
- When inspecting the airbag main harness, disconnect the driver's airbag module and passenger's airbag module connectors for safety reasons.
- When inspecting the side airbag harness, disconnect the side airbag module connector and seat belt pretensioner connector for the safety reasons.

#### WIRING DIAGRAM:



AB-00562

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

## AIRBAG SYSTEM (DIAGNOSTICS)

	Step	Check	Yes	No
1	<p><b>CHECK SIDE AIRBAG HARNESS (RH).</b></p> <p>1) Turn the ignition switch to OFF, disconnect the battery ground cable, and wait more than 20 seconds.</p> <p>2) Disconnect the connector (AB20) from the seat belt pretensioner (RH). &lt;Ref. to SB-8, Front Seat Belt.&gt;</p> <p>3) Disconnect the connector (AB28) from (AB11).</p> <p>4) Disconnect the connector (AB8) from the airbag control module. &lt;Ref. to AB-16, Airbag Control Module.&gt;</p> <p>5) Connect the connector (1R) in test harness R to the connector (AB8).</p> <p>6) Disconnect the connector (AB12) from the side airbag sensor (RH), and connect the connector (1G) in test harness G to connector (AB12).</p> <p>7) Measure the resistance between connector (4R) in test harness R and connector (3G) in test harness G.</p> <p><b>Connector &amp; terminal</b></p> <p><b>(4R) No. 5 — (3G) No. 2:</b></p> <p><b>(4R) No. 7 — (3G) No. 1:</b></p> <p><b>(4R) No. 8 — (3G) No. 5:</b></p> <p><b>(4R) No. 6 — (3G) No. 4:</b></p>	Is the resistance less than 10 Ω?	Go to step 2.	Replace the body harness with side airbag harness.
2	<p><b>CHECK SIDE AIRBAG HARNESS (RH).</b></p> <p>Measure the resistance between connector (4R) in test harness R and the chassis ground.</p> <p><b>Connector &amp; terminal</b></p> <p><b>(4R) No. 5 — Chassis ground:</b></p> <p><b>(4R) No. 7 — Chassis ground:</b></p> <p><b>(4R) No. 8 — Chassis ground:</b></p> <p><b>(4R) No. 6 — Chassis ground:</b></p>	Is the resistance more than 1 MΩ?	Replace the side airbag sensor (RH). <Ref. to AB-17, Side Airbag Sensor.> When sensor replacement is not OK, replace the airbag control module. <Ref. to AB-16, Airbag Control Module.>	Replace the body harness with side airbag harness.

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

## AIRBAG SYSTEM (DIAGNOSTICS)

### Q: DTC 52


#### DIAGNOSIS:

- Side airbag sensor (LH) is faulty.
- Side airbag harness (LH) is faulty.
- Airbag control module is faulty.

#### CAUTION:

- Before diagnosing the airbag system, be sure to turn the ignition switch to OFF, disconnect the ground cable from battery, and wait more than 20 seconds before starting to work.
- Before replacing the airbag module, seat belt pretensioner roll connector, control module, and sensor, reconnect each part and confirm that the warning light operates properly.
- When inspecting the airbag main harness, disconnect the driver's airbag module and passenger's airbag module connectors for safety reasons.
- When inspecting the side airbag harness, disconnect the side airbag module connector and seat belt pretensioner connector for the safety reasons.

#### WIRING DIAGRAM:



AB-00566



# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

## AIRBAG SYSTEM (DIAGNOSTICS)

Step	Check	Yes	No
<p><b>1</b></p> <p><b>CHECK SIDE AIRBAG HARNESS (LH).</b></p> <p>1) Turn the ignition switch to OFF, disconnect the battery ground cable, and wait more than 20 seconds.</p> <p>2) Disconnect the connector (AB19) from the seat belt pretensioner (LH). &lt;Ref. to SB-8, Front Seat Belt.&gt;</p> <p>3) Disconnect the connector (AB29) from (AB9).</p> <p>4) Disconnect the connector (AB7) from the airbag control module. &lt;Ref. to AB-16, Airbag Control Module.&gt;</p> <p>5) Connect the connector (1R) in test harness R to connector (AB7).</p> <p>6) Disconnect the connector (AB10) from the side airbag sensor (LH), and connect the connector (1G) in test harness G to connector (AB10).</p> <p>7) Measure the resistance between connector (4R) in test harness R and connector (3G) in test harness G.</p> <p><b>Connector &amp; terminal</b></p> <p><b>(4R) No. 3 — (3G) No. 4:</b></p> <p><b>(4R) No. 1 — (3G) No. 5:</b></p> <p><b>(4R) No. 2 — (3G) No. 1:</b></p> <p><b>(4R) No. 4 — (3G) No. 2:</b></p>	<p>Is the resistance less than 10 Ω?</p>	<p>Go to step 2.</p>	<p>Replace the body harness with side airbag harness.</p>
<p><b>2</b></p> <p><b>CHECK SIDE AIRBAG HARNESS (RH).</b></p> <p>Measure the resistance between connector (4R) in test harness R and the chassis ground.</p> <p><b>Connector &amp; terminal</b></p> <p><b>(4R) No. 3 — Chassis ground:</b></p> <p><b>(4R) No. 1 — Chassis ground:</b></p> <p><b>(4R) No. 2 — Chassis ground:</b></p> <p><b>(4R) No. 4 — Chassis ground:</b></p>	<p>Is the resistance more than 1 MΩ?</p>	<p>Replace the side airbag sensor (LH). &lt;Ref. to AB-17, Side Airbag Sensor.&gt; When sensor replacement is not OK, replace the airbag control module. &lt;Ref. to AB-16, Airbag Control Module.&gt;</p>	<p>Replace the body harness with side airbag harness.</p>

## DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

### AIRBAG SYSTEM (DIAGNOSTICS)

---

#### **R: DTC 53**

##### **DIAGNOSIS:**

- Side airbag sensor (RH) is faulty.

When Code 53 is displayed, the circuit within the side airbag sensor (RH) is faulty. Replace the side airbag sensor (RH).

<Ref. to AB-17, Side Airbag Sensor.>

#### **S: DTC 54**

##### **DIAGNOSIS:**

- Side airbag sensor (LH) is faulty.

When Code 53 is displayed, the circuit within the side airbag sensor (LH) is faulty. Replace the side airbag sensor (LH).

<Ref. to AB-17, Side Airbag Sensor.>

#### **T: DTC 55**

This code is displayed when the side airbag is deployed.

When this code is displayed, the memory cannot be erased. Replace the following parts.

- Airbag control module. <Ref. to AB-16, Airbag Control Module.>
- Front seat with side airbag module. (Operating side) <Ref. to SE-6, Front Seat.>
- Side airbag sensor. (Operating side) <Ref. to AB-17, Side Airbag Sensor.>

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

AIRBAG SYSTEM (DIAGNOSTICS)

## U: DTC 61


### DIAGNOSIS:

- Seat belt pretensioner (RH) circuit is open, shorted or shorted to ground.
- Airbag control module is faulty.
- Pretensioner is faulty.
- Pretensioner harness is faulty.

### CAUTION:

- Before diagnosing the airbag system, be sure to turn the ignition switch to OFF, disconnect the ground cable from battery, and wait more than 20 seconds before starting to work.
- Before replacing the airbag module, seat belt pretensioner roll connector, control module, and sensor, reconnect each part and confirm that the warning light operates properly.
- When inspecting the side airbag harness, disconnect the side airbag module connector and seat belt pretensioner connector for the safety reasons.

### WIRING DIAGRAM:



AB-00570

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

## AIRBAG SYSTEM (DIAGNOSTICS)

Step	Check	Yes	No
<b>1 CHECK SEAT BELT PRETENSIONER.</b> 1) Turn the ignition switch to OFF, disconnect the battery ground cable, and wait more than 20 seconds. 2) Disconnect the connector (AB20) from the seat belt pretensioner (RH). <Ref. to SB-8, Front Seat Belt.> 3) Connect the connector (1N) in test harness N to (AB20). 4) Connect the airbag resistor to connector (2N) in test harness N. 5) Connect the battery ground cable and turn the ignition switch to ON.	Does the airbag warning light operate properly?	Replace the seat belt pretensioner (RH). <Ref. to SB-8, Front Seat Belt.>	Go to step 2.
<b>2 CHECK SIDE AIRBAG HARNESS (RH).</b> 1) Turn the ignition switch to OFF, disconnect the battery ground cable, and wait more than 20 seconds. 2) Disconnect the airbag resistor from the test harness. 3) Disconnect the connector (AB28) from (AB11). 4) Disconnect the connectors (AB7) and (AB8) from the airbag control module. <Ref. to AB-16, Airbag Control Module.> 5) Connect the connector (1R) in test harness R to connector (AB8). 6) Measure the resistance between connector (3R) in test harness R and connector (2N) in test harness N. <b>Connector &amp; terminal</b> <b>(3R) No. 19 — (2N) No. 1:</b> <b>(3R) No. 17 — (2N) No. 2:</b>	Is the resistance less than 10 Ω?	Go to step 3.	Replace the body harness with side airbag harness.
<b>3 CHECK SIDE AIRBAG HARNESS (RH).</b> Measure the resistance of the connector (3R) in test harness R. <b>Connector &amp; terminal</b> <b>(3R) No. 17 — (3R) No. 19:</b>	Is the resistance more than 1 MΩ?	Go to step 4.	Replace the body harness with side airbag harness.
<b>4 CHECK SIDE AIRBAG HARNESS (RH).</b> Measure the resistance between connector (3R) in test harness R and the chassis ground. <b>Connector &amp; terminal</b> <b>(3R) No. 17 — Chassis ground:</b> <b>(3R) No. 19 — Chassis ground:</b>	Is the resistance more than 1 MΩ?	Replace the airbag control module. <Ref. to AB-16, Airbag Control Module.>	Replace the body harness with side airbag harness.

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

AIRBAG SYSTEM (DIAGNOSTICS)

## V: DTC 62


### DIAGNOSIS:

- Seat belt pretensioner (LH) circuit is open, shorted or shorted to ground.
- Airbag control module is faulty.
- Pretensioner is faulty.
- Pretensioner harness is faulty.

### CAUTION:

- Before diagnosing the airbag system, be sure to turn the ignition switch to OFF, disconnect the ground cable from battery, and wait more than 20 seconds before starting to work.
- Before replacing the airbag module, seat belt pretensioner roll connector, control module, and sensor, reconnect each part and confirm that the warning light operates properly.
- When inspecting the side airbag harness, disconnect the side airbag module connector and seat belt pretensioner connector for the safety reasons.

### WIRING DIAGRAM:



AB-00574

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

## AIRBAG SYSTEM (DIAGNOSTICS)

Step	Check	Yes	No
<b>1 CHECK SEAT BELT PRETENSIONER.</b> 1) Turn the ignition switch to OFF, disconnect the battery ground cable, and wait more than 20 seconds. 2) Disconnect the connector (AB19) from the seat belt pretensioner (LH). <Ref. to SB-8, Front Seat Belt.> 3) Connect the connector (1N) in test harness N to (AB19). 4) Connect the airbag resistor to the connector (2N) in test harness N. 5) Connect the battery ground cable and turn the ignition switch to ON.	Does the airbag warning light operate properly?	Replace the seat belt pretensioner (LH). <Ref. to SB-8, Front Seat Belt.>	Go to step 2.
<b>2 CHECK SIDE AIRBAG HARNESS (LH).</b> 1) Turn the ignition switch to OFF, disconnect the battery ground cable, and wait more than 20 seconds. 2) Disconnect the airbag resistor from the test harness. 3) Disconnect the connector (AB29) from (AB9). 4) Disconnect the connectors (AB7) and (AB8) from the airbag control module. <Ref. to AB-16, Airbag Control Module.> 5) Connect the connector (1R) in test harness R to the connector (AB7). 6) Measure the resistance between connector (3R) in test harness R and the connector (2N) in test harness N. <b>Connector &amp; terminal</b> <b>(3R) No. 11 — (2N) No. 2:</b> <b>(3R) No. 13 — (2N) No. 1:</b>	Is the resistance less than 10 $\Omega$ ?	Go to step 3.	Replace the body harness with side airbag harness.
<b>3 CHECK SIDE AIRBAG HARNESS (LH).</b> Measure the resistance of the connector (3R) in test harness R. <b>Connector &amp; terminal</b> <b>(3R) No. 11 — (3R) No. 13:</b>	Is the resistance more than 1 M $\Omega$ ?	Go to step 4.	Replace the body harness with side airbag harness.
<b>4 CHECK SIDE AIRBAG HARNESS (LH).</b> Measure the resistance between the connector (3R) in test harness R and the chassis ground. <b>Connector &amp; terminal</b> <b>(3R) No. 11 — Chassis ground:</b> <b>(3R) No. 13 — Chassis ground:</b>	Is the resistance more than 1 M $\Omega$ ?	Replace the airbag control module. <Ref. to AB-16, Airbag Control Module.>	Replace the body harness with side airbag harness.

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

AIRBAG SYSTEM (DIAGNOSTICS)

## W: DTC 65


### DIAGNOSIS:

- Seat belt pretensioner (RH) circuit is shorted to the power supply.
- Pretensioner is faulty.
- Pretensioner harness is faulty.
- Airbag control module is faulty.

### CAUTION:

- Before diagnosing the airbag system, be sure to turn the ignition switch to OFF, disconnect the ground cable from battery, and wait more than 20 seconds before starting to work.
- Before replacing the airbag module, seat belt pretensioner roll connector, control module, and sensor, reconnect each part and confirm that the warning light operates properly.
- When inspecting the side airbag harness, disconnect the side airbag module connector and seat belt pretensioner connector for the safety reasons.

### WIRING DIAGRAM:



# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

## AIRBAG SYSTEM (DIAGNOSTICS)

Step	Check	Yes	No
<p><b>1 CHECK SEAT BELT PRETENSIONER.</b></p> <p>1) Turn the ignition switch to OFF, disconnect the battery ground cable, and wait more than 20 seconds.</p> <p>2) Disconnect the connector (AB20) from the seat belt pretensioner (RH). &lt;Ref. to SB-8, Front Seat Belt.&gt;</p> <p>3) Connect the connector (1N) in test harness N to (AB20).</p> <p>4) Connect the airbag resistor to connector (2N) in test harness N.</p> <p>5) Connect the battery ground cable, and turn the ignition switch to ON.</p>	<p>Does the airbag warning light operate properly?</p>	<p>Replace the seat belt pretensioner (RH). &lt;Ref. to SB-8, Front Seat Belt.&gt;</p>	<p>Go to step 2.</p>
<p><b>2 CHECK SIDE AIRBAG HARNESS (RH).</b></p> <p>1) Turn the ignition switch to OFF, disconnect the battery ground cable, and wait more than 20 seconds.</p> <p>2) Disconnect the airbag resistor from the test harness.</p> <p>3) Disconnect the connector (AB28) from (AB11).</p> <p>4) Disconnect the connectors (AB7) and (AB8) from the airbag control module. &lt;Ref. to AB-16, Airbag Control Module.&gt;</p> <p>5) Connect the connector (1R) in test harness R to the connector (AB8).</p> <p>6) Connect the battery ground cable and turn the ignition switch to ON.</p> <p>7) Measure the voltage between connector (3R) in test harness R and the chassis ground.</p> <p><b>Connector &amp; terminal</b></p> <p><b>(3R) No. 17 (+) — Chassis ground (-):</b></p> <p><b>(3R) No. 19 (+) — Chassis ground (-):</b></p>	<p>Is the voltage less than 1 V?</p>	<p>Replace the airbag control module. &lt;Ref. to AB-16, Airbag Control Module.&gt;</p>	<p>Replace the body harness with side airbag harness.</p>



# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

AIRBAG SYSTEM (DIAGNOSTICS)

## X: DTC 66


### DIAGNOSIS:

- Seat belt pretensioner (LH) circuit is shorted to the power supply.
- Pretensioner is faulty.
- Pretensioner harness is faulty.
- Airbag control module is faulty.

### CAUTION:

- Before diagnosing the airbag system, be sure to turn the ignition switch to OFF, disconnect the ground cable from battery, and wait more than 20 seconds before starting to work.
- Before replacing the airbag module, seat belt pretensioner roll connector, control module and the sensor, reconnect each part and confirm that the warning light operates properly.
- When inspecting the side airbag harness, disconnect the side airbag module connector and seat belt pretensioner connector for the safety reasons.

### WIRING DIAGRAM:



AB-00574

# DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

## AIRBAG SYSTEM (DIAGNOSTICS)

Step	Check	Yes	No
<p><b>1 CHECK SEAT BELT PRETENSIONER.</b></p> <p>1) Turn the ignition switch to OFF, disconnect the battery ground cable, and wait more than 20 seconds.</p> <p>2) Disconnect the connector (AB19) from the seat belt pretensioner (LH). &lt;Ref. to SB-8, Front Seat Belt.&gt;</p> <p>3) Connect the connector (1N) in test harness N to (AB19).</p> <p>4) Connect the airbag resistor to the connector (2N) in test harness N.</p> <p>5) Connect the battery ground cable and turn the ignition switch to ON.</p>	<p>Does the airbag warning light operate properly?</p>	<p>Replace the seat belt pretensioner (LH). &lt;Ref. to SB-8, Front Seat Belt.&gt;</p>	<p>Go to step 2.</p>
<p><b>2 CHECK SIDE AIRBAG HARNESS (LH).</b></p> <p>1) Turn the ignition switch to OFF, disconnect the battery ground cable, and wait more than 20 seconds.</p> <p>2) Disconnect the airbag resistor from the test harness.</p> <p>3) Disconnect the connector (AB29) from (AB9).</p> <p>4) Disconnect the connectors (AB7) and (AB8) from the airbag control module. &lt;Ref. to AB-16, Airbag Control Module.&gt;</p> <p>5) Connect the connector (1R) in test harness R to the connector (AB7).</p> <p>6) Connect the battery ground cable and turn the ignition switch to ON.</p> <p>7) Measure the voltage between connector (3R) in test harness R and the chassis ground.</p> <p><b>Connector &amp; terminal</b></p> <p><b>(3R) No. 11 (+) — Chassis ground (-):</b></p> <p><b>(3R) No. 13 (+) — Chassis ground (-):</b></p>	<p>Is the voltage less than 1 V?</p>	<p>Replace the airbag control module. &lt;Ref. to AB-16, Airbag Control Module.&gt;</p>	<p>Replace the body harness with side airbag harness.</p>