

Brought to you by Eris Studios
NOT FOR RESALE

ENGINE (DIAGNOSTICS)

Basic Diagnostic Procedure

ENGINE (DIAGNOSTICS)

1. Basic Diagnostic Procedure

A: PROCEDURE

1. ENGINE

| Step | Check | Yes | No |
|---|--|---|--|
| 1 CHECK ENGINE START FAILURE. 1) Ask the customer when and how trouble occurred using the interview check list. <Ref. to EN(H4DOTC)(diag)-4, CHECK, Check List for Interview.> 2) Start the engine. | Does the engine start? | Go to step 2. | Inspection using "Diagnostics for Engine Start Failure". <Ref. to EN(H4DOTC)(diag)-58, Diagnostics for Engine Starting Failure.> |
| 2 CHECK ILLUMINATION OF MALFUNCTION INDICATOR LIGHT. | Does the malfunction indicator light illuminate? | Go to step 3. | Inspection using "General Diagnostics Table". <Ref. to EN(H4DOTC)(diag)-340, General Diagnostic Table.> |
| 3 CHECK INDICATION OF DTC ON DISPLAY. 1) Turn the ignition switch to OFF. 2) Connect the Subaru Select Monitor or OBD-II general scan tool to data link connector. 3) Turn the ignition switch to ON and the Subaru Select Monitor or OBD-II general scan tool switch to ON. 4) Read the DTC on Subaru Select Monitor or OBD-II general scan tool. | Does the Subaru Select Monitor or OBD-II general scan tool indicate DTC? | Record the DTC code. Repair the trouble cause. <Ref. to EN(H4DOTC)(diag)-71, List of Diagnostic Trouble Code (DTC).> Go to step 4. | Repair the related parts. NOTE: If a DTC is not shown on display although malfunction indicator light illuminates, perform diagnostics of malfunction indicator light circuit or combination meter. <Ref. to EN(H4DOTC)(diag)-49, Malfunction Indicator Light.> |
| 4 PERFORM THE DIAGNOSIS. 1) Perform the clear memory mode. <Ref. to EN(H4DOTC)(diag)-46, Clear Memory Mode.> 2) Perform the inspection mode. <Ref. to EN(H4DOTC)(diag)-39, Inspection Mode.> | Does the Subaru Select Monitor or OBD-II general scan tool indicate DTC? | Inspect using "Diagnostics Procedure with Diagnostic Trouble Code (DTC)". <Ref. to EN(H4DOTC)(diag)-78, Diagnostic Procedure with Diagnostic Trouble Code (DTC).> | Complete the diagnosis. |

2. AUTOMATIC TRANSMISSION

When DTC about automatic transmission is shown on display, carry out the following basic check. After that, carry out the replacement or repair work.

- 1) ATF level check <Ref. to 4AT-30, Automatic Transmission Fluid.>
- 2) Differential gear oil level check <Ref. to 4AT-31, Differential Gear Oil.>
- 3) ATF leak check <Ref. to 4AT-30, Automatic Transmission Fluid.>
- 4) Differential gear oil leak check <Ref. to 4AT-31, Differential Gear Oil.>
- 5) Stall test <Ref. to 4AT-33, Stall Test.>
- 6) Line pressure test <Ref. to 4AT-35, Line Pressure Test.>
- 7) Transfer clutch pressure test <Ref. to 4AT-36, Transfer Clutch Pressure Test.>
- 8) Time lag test <Ref. to 4AT-34, Time Lag Test.>
- 9) Road test <Ref. to 4AT-32, Road Test.>
- 10) Shift characteristics <Ref. to 4AT-36, Transfer Clutch Pressure Test.>

Check List for Interview

ENGINE (DIAGNOSTICS)

2. Check List for Interview

A: CHECK

1. CHECK LIST No. 1

Check the following items when problem has occurred.

NOTE:

Use copies of this page for interviewing customers.

| | | | |
|---------------------|---|------------------|--|
| Customer's name | | Engine No. | |
| Date of sale | | Fuel brand | |
| Date of repair | | Odometer reading | km |
| VIN | | | miles |
| Weather | <input type="checkbox"/> Fine <input type="checkbox"/> Cloudy <input type="checkbox"/> Rainy <input type="checkbox"/> Snowy <input type="checkbox"/> Various/Others: | | |
| Outdoor temperature | °C (°F) | | |
| | <input type="checkbox"/> Hot <input type="checkbox"/> Warm <input type="checkbox"/> Cool <input type="checkbox"/> Cold | | |
| Place | <input type="checkbox"/> Highway <input type="checkbox"/> Suburbs <input type="checkbox"/> Inner city <input type="checkbox"/> Uphill <input type="checkbox"/> Downhill <input type="checkbox"/> Rough road <input type="checkbox"/> Others: | | |
| Engine temperature | <input type="checkbox"/> Cold <input type="checkbox"/> Warming-up <input type="checkbox"/> After warming-up <input type="checkbox"/> Any temperature <input type="checkbox"/> Others: | | |
| Engine speed | rpm | | |
| Vehicle speed | MPH | | |
| Driving conditions | <input type="checkbox"/> Not affected <input type="checkbox"/> At starting <input type="checkbox"/> While idling <input type="checkbox"/> At racing <input type="checkbox"/> While accelerating <input type="checkbox"/> While cruising <input type="checkbox"/> While decelerating <input type="checkbox"/> While turning (RH/LH) | | |
| Headlight | <input type="checkbox"/> ON / <input type="checkbox"/> OFF | Rear defogger | <input type="checkbox"/> ON / <input type="checkbox"/> OFF |
| Blower | <input type="checkbox"/> ON / <input type="checkbox"/> OFF | Radio | <input type="checkbox"/> ON / <input type="checkbox"/> OFF |
| A/C compressor | <input type="checkbox"/> ON / <input type="checkbox"/> OFF | CD/Cassette | <input type="checkbox"/> ON / <input type="checkbox"/> OFF |
| Cooling fan | <input type="checkbox"/> ON / <input type="checkbox"/> OFF | Car phone | <input type="checkbox"/> ON / <input type="checkbox"/> OFF |
| Front wiper | <input type="checkbox"/> ON / <input type="checkbox"/> OFF | CB | <input type="checkbox"/> ON / <input type="checkbox"/> OFF |
| Rear wiper | <input type="checkbox"/> ON / <input type="checkbox"/> OFF | | |

Check List for Interview

ENGINE (DIAGNOSTICS)

2. CHECK LIST No. 2

Check the following items about the vehicle's state when malfunction indicator light turns on.

NOTE:

Use copies of this page for interviewing customers.

| |
|--|
| a) Other warning lights or indicators turn on. <input type="checkbox"/> Yes / <input type="checkbox"/> No |
| <input type="checkbox"/> Low fuel warning light <input type="checkbox"/> Charge indicator light <input type="checkbox"/> AT diagnostics indicator light <input type="checkbox"/> ABS warning light <input type="checkbox"/> Engine oil pressure warning light |
| b) Fuel level |
| <ul style="list-style-type: none">• Lack of gasoline: <input type="checkbox"/> Yes / <input type="checkbox"/> No• Indicator position of fuel gauge: |
| c) Intentional connecting or disconnecting of harness connectors or spark plug cords: <input type="checkbox"/> Yes / <input type="checkbox"/> No |
| <ul style="list-style-type: none">• What: |
| d) Intentional connecting or disconnecting of hoses: <input type="checkbox"/> Yes / <input type="checkbox"/> No |
| <ul style="list-style-type: none">• What: |
| e) Installing of parts other than genuine parts: <input type="checkbox"/> Yes / <input type="checkbox"/> No |
| <ul style="list-style-type: none">• What:• Where: |
| f) Occurrence of noise: <input type="checkbox"/> Yes / <input type="checkbox"/> No |
| <ul style="list-style-type: none">• From where:• What kind: |
| g) Occurrence of smell: <input type="checkbox"/> Yes / <input type="checkbox"/> No |
| <ul style="list-style-type: none">• From where:• What kind: |
| h) Intrusion of water into engine compartment or passenger compartment: <input type="checkbox"/> Yes / <input type="checkbox"/> No |
| i) Troubles occurred |
| <input type="checkbox"/> Engine does not start. <input type="checkbox"/> Engine stalls during idling. <input type="checkbox"/> Engine stalls while driving. <input type="checkbox"/> Engine speed decreases. <input type="checkbox"/> Engine speed does not decrease. <input type="checkbox"/> Rough idling <input type="checkbox"/> Poor acceleration <input type="checkbox"/> Back fire <input type="checkbox"/> After fire <input type="checkbox"/> No shift <input type="checkbox"/> Excessive shift shock |

3. General Description

A: CAUTION

1) Airbag system wiring harness is routed near the ECM, main relay and fuel pump relay.

CAUTION:

- All airbag system wiring harness and connectors are colored yellow. Do not use the electrical test equipment on these circuit.
- Be careful not to damage the airbag system wiring harness when servicing the ECM, TCM, main relay and fuel pump relay.

2) Never connect the battery in reverse polarity.

- The ECM will be destroyed instantly.
- The fuel injector and other part will be damaged in just a few minutes more.

3) Do not disconnect the battery cables while the engine is running.

A large counter electromotive force will be generated in the alternator, and this voltage may damage electronic parts such as ECM, etc.

4) Before disconnecting the connectors of each sensor and the ECM, be sure to turn the ignition switch to OFF.

5) Poor contact has been identified as a primary cause of this problem. To measure the voltage and/or resistance of individual sensors or all electrical control modules at the harness side connector, use a tapered pin with a diameter of less than 0.64 mm (0.025 in). Do not insert the pin more than 5 mm (0.20 in) into the part.

6) Before removing the ECM from located position, disconnect two cables on battery.


Otherwise, the ECM may be damaged.

CAUTION:

When replacing the ECM, be careful not to use the wrong spec. ECM to avoid any damage on the fuel injection system.


7) The connectors to each sensor in the engine compartment and the harness connectors on the engine side and body side are all designed to be waterproof. However, it is still necessary to take care not to allow water to get into the connectors when washing the vehicle, or when servicing the vehicle on a rainy day.

8) Use the ECM mounting stud bolt at the body head grounding points when measuring voltage and resistance inside the passenger compartment.




(A) Stud bolt

9) Use the engine grounding terminal or engine proper as the grounding point to the body, when measuring voltage and resistance in the engine compartment.



10) Use the TCM mounting stud bolts at the grounding point, when measuring voltage and resistance inside the passenger compartment.



(A) Stud bolt

11) Every MFI-related part is a precision part. Do not drop them.

12) Observe the following cautions when installing a radio in MFI equipped models.

CAUTION:

- The antenna must be kept as far apart as possible from the control unit. (The ECM is located under the steering column, inside of the instrument panel lower trim panel.)
- The antenna feeder must be placed as far as possible from ECM and MFI harness.
- Carefully adjust the antenna for correct matching.
- When mounting a large power type radio, pay special attention to the three items above mentioned.
- Incorrect installation of the radio may affect the operation of ECM.

13) Before disconnecting the fuel hose, disconnect the fuel pump connector and crank the engine for more than 5 seconds to release pressure in the fuel system. If the engine starts during this operation, run it until it stops.

14) Problems in the electronic-controlled automatic transmission may be caused by failure of the engine, the electronic control system, the transmission proper, or by a combination of these. These three causes must be distinguished clearly when performing diagnostics.

15) Diagnostics should be conducted by rotating with simple, easy operations and proceeding to complicated, difficult operations. The most important thing in diagnostics is to understand the customer's complaint, and distinguish between the three causes.

16) On model with ABS, when performing driving test in jacked-up or lifted-up position, sometimes the warning light may be lit, but this is not a malfunction of the system. The reason for this is the speed difference between front and rear wheels. After diagnosis of engine control system, perform the ABS memory clearance procedure of self-diagnosis system.

B: INSPECTION

Before performing diagnostics, check the following items which might affect engine problems:

1. BATTERY

1) Measure the battery voltage and specific gravity of electrolyte.


Standard voltage: 12 V

Specific gravity: Above 1.260

2) Check the condition of main and other fuses, and harnesses and connectors. Also check for proper grounding.

2. ENGINE GROUNDING

Make sure the engine grounding terminal is properly connected to engine.



C: NOTE

1. DESCRIPTION

- The on-board diagnostics (OBD) system detects and indicates a fault in various inputs and outputs of complex electronic control. Malfunction indicator light in combination meter indicates occurrence of a fault or trouble.
- Further, against such a failure or sensors as may disable the drive, the fail-safe function is provided to ensure the minimal driveability.
- The OBD system incorporated with the vehicles within this engine family complies with Section 1968.1, California Code of Regulations (OBD-II regulation). The OBD system monitors the components and the system malfunction listed in Engine Section which affects on emissions.
- When the system decides that a malfunction occurs, malfunction indicator light illuminates. At the same time of malfunction indicator light illumination or blinking, a DTC and a freeze frame engine conditions are stored into on-board computer.
- The OBD system stores freeze frame engine condition data (engine load, engine coolant temperature, fuel trim, engine speed and vehicle speed, etc.) into on-board computer when it detects a malfunction first.
- If the OBD system detects the various malfunctions including the fault of fuel trim or misfire, the OBD system first stores freeze frame engine conditions about the fuel trim or misfire.
- When the malfunction does not occur again for three consecutive driving cycles, malfunction indicator light is turned off, but DTC remains at on-board computer.
- The OBD-II system is capable of communication with a general scan tool (OBD-II general scan tool) formed by ISO 9141 CARB.

General Description

ENGINE (DIAGNOSTICS)

- The OBD-II diagnostics procedure is different from usual diagnostics procedure. When troubleshooting model with OBD-II, connect the Subaru Select Monitor or the OBD-II general scan tool to the vehicle.

2. ENGINE AND EMISSION CONTROL SYSTEM

- The Multipoint Fuel Injection (MFI) system is a system that supplies the optimum air-fuel mixture to the engine for all the various operating conditions through the use of the latest electronic technology.



With this system fuel, which is pressurized at a constant pressure, is injected into the intake air passage of the cylinder head. The injection quantity of fuel is controlled by an intermittent injection system where the electro-magnetic injection valve (fuel injector) opens only for a short period of time, depending on the quantity of air required for one cycle of operation. In actual operation, the injection quantity is determined by the duration of an electric pulse applied to the fuel injector and this permits simple, yet highly precise metering of the fuel.

- Further, all the operating conditions of the engine are converted into electric signals, and this results in additional features of the system, such as large improved adaptability, easier addition of compensating element, etc.

The MFI system also has the following features:

- Reduced emission of harmful exhaust gases.
- Reduced in fuel consumption.
- Increased engine output.
- Superior acceleration and deceleration.
- Superior startability and warm-up performance in cold weather since compensation is made for coolant and intake air temperature.

D: PREPARATION TOOL


| ILLUSTRATION | TOOL NUMBER | DESCRIPTION | REMARKS |
|---|-------------|---------------------------|---|
|  <p style="text-align: center;">ST24082AA230</p> | 24082AA230 | CARTRIDGE | Troubleshooting for electrical systems. |
|  <p style="text-align: center;">ST22771AA030</p> | 22771AA030 | SUBARU SELECT MONITOR KIT | Troubleshooting for electrical systems. |

4. Electrical Components Location

A: LOCATION


1. ENGINE

- Module




EN-01202


- (1) Engine control module (ECM)
- (2) Malfunction indicator light
- (3) Data link connector
- (4) Test mode connector




EN-00156



EN-01601



EN-01204




EN-01205

Electrical Components Location

ENGINE (DIAGNOSTICS)









• Sensor



- | | | |
|---------------------------------------|---|--|
| (1) Manifold absolute pressure sensor | (5) Camshaft position sensor | (8) Tumble generator valve position sensor |
| (2) Engine coolant temperature sensor | (6) Crankshaft position sensor | |
| (3) Throttle position sensor | (7) Mass air flow and intake air temperature sensor | |
| (4) Knock sensor | | |

Electrical Components Location


ENGINE (DIAGNOSTICS)







Electrical Components Location

ENGINE (DIAGNOSTICS)

Brought to you by Eris Studios
NOT FOR RESALE





- | | | |
|-------------------------------|--------------------------------|------------------------------|
| (1) Front oxygen (A/F) sensor | (3) Exhaust temperature sensor | (5) Rear oxygen sensor |
| (2) Precatalytic converter | (4) Front catalytic converter | (6) Rear catalytic converter |





Electrical Components Location

ENGINE (DIAGNOSTICS)

Brought to you by Eris Studios
NOT FOR RESALE




- (1) Fuel level sensor
- (2) Fuel temperature sensor
- (3) Fuel tank pressure sensor
- (4) Fuel sub level sensor



Electrical Components Location


ENGINE (DIAGNOSTICS)

Brought to you by Eris Studios
NOT FOR RESALE



SUBARU.


• Solenoid Valve, Actuator, Emission Control System Parts and Ignition System Parts




- | | | |
|--------------------------------------|----------------------------------|-------------------------------------|
| (1) Wastegate control solenoid valve | (3) Purge control solenoid valve | (5) Tumble generator valve actuator |
| (2) Idle air control solenoid valve | (4) Ignition coil | |

Electrical Components Location


ENGINE (DIAGNOSTICS)




EN-00313




EN-00314



EN-00315



EN-00316




EN-00317

SUBARU.

Electrical Components Location

ENGINE (DIAGNOSTICS)





Brought to you by Eris Studios
NOT FOR RESALE



(1) Pressure control solenoid valve
(2) Canister


(3) Drain valve
(4) Drain filter

(5) Fuel tank sensor control valve




Electrical Components Location

ENGINE (DIAGNOSTICS)




EN-01602


- | | | |
|----------------------|-------------------------------|------------------------------|
| (1) Fuel pump | (5) Fuel pump control unit | (9) Radiator sub fan relay 2 |
| (2) Inhibitor switch | (6) Radiator main fan relay 1 | (10) Starter |
| (3) Main relay | (7) Radiator main fan relay 2 | |
| (4) Fuel pump relay | (8) Radiator sub fan relay 1 | |




EN-01217



EN-00321





EN-01281



EN-01282


Electrical Components Location

ENGINE (DIAGNOSTICS)





2. TRANSMISSION

• Module




(1) Transmission control module (TCM) (for AT model)

(2) AT diagnostic indicator light (for AT model)



• Sensor



(1) Rear vehicle speed sensor (for AT model)

(2) Front vehicle speed sensor (for MT model)

(3) Front vehicle speed sensor (for AT model)

(4) Torque converter turbine speed sensor (for AT model)


(5) ATF temperature sensor (for AT model)

(6) Brake light switch

Electrical Components Location


ENGINE (DIAGNOSTICS)

• Solenoid Valve and Switch (AT model)



- | | | |
|----------------------------|---------------------------------|--------------------------------------|
| (1) Inhibitor switch | (4) Line pressure duty solenoid | (7) 2-4 brake duty solenoid |
| (2) Shift solenoid valve 1 | (5) Lock-up duty solenoid | (8) Low clutch timing solenoid valve |
| (3) Shift solenoid valve 2 | (6) Transfer duty solenoid | (9) 2-4 brake timing solenoid valve |


• Solenoid Valve and Switch (MT model)



- (1) Neutral position switch

5. Engine Control Module (ECM) I/O Signal

A: ELECTRICAL SPECIFICATION



EN-01286

| Content | | Con- nector No. | Termi- nal No. | Signal (V) | | Note |
|---|-------------------|-----------------------|-------------------|--|--------------------|---|
| | | | | Ignition SW ON (Engine OFF) | Engine ON (Idling) | |
| Crank- shaft posi- tion sensor | Signal (+) | B135 | 2 | 0 | -7 — +7 | Sensor output waveform |
| | Signal (-) | B135 | 11 | 0 | 0 | — |
| | Shield | B135 | 21 | 0 | 0 | — |
| Camshaft position sensor | Signal (+) | B135 | 1 | 0 | -7 — +7 | Sensor output waveform |
| | Signal (-) | B135 | 10 | 0 | 0 | — |
| | Shield | B135 | 21 | 0 | 0 | — |
| Throttle position sensor | Signal | B135 | 7 | Fully closed: 0.2 — 1.0 Fully opened: 4.2 — 4.7 | | — |
| | Power supply | B135 | 9 | 5 | 5 | — |
| | GND (sen- sor) | B135 | 19 | 0 | 0 | — |
| Rear oxy- gen sen- sor | Signal | B135 | 17 | 0 | 0 — 0.9 | — |
| | Shield | B135 | 26 | 0 | 0 | — |
| | GND (sen- sor) | B135 | 19 | 0 | 0 | — |
| Front oxy- gen (A/F) sensor heater | Signal 1 | B84 | 5 | 0 — 1.0 | 0 — 1.0 | — |
| | Signal 2 | B84 | 4 | 0 — 1.0 | 0 — 1.0 | — |
| Rear oxygen sensor heater signal | | B137 | 13 | 0 — 1.0 | 0 — 1.0 | — |
| Engine coolant tempera- ture sen- sor | Signal | B135 | 18 | 1.0 — 1.4 | 1.0 — 1.4 | After warm-up the engine. |
| | GND (sen- sor) | B135 | 19 | 0 | 0 | After warm-up the engine. |
| Vehicle speed signal | | B134 | 1 | 0 or 5 | 0 or 5 | “5” and “0” are repeatedly dis- played when vehicle is driven. |

Engine Control Module (ECM) I/O Signal

ENGINE (DIAGNOSTICS)

| Content | | Connector No. | Terminal No. | Signal (V) | | Note |
|---|--------------|---------------|--------------|--|-----------------------|--------------------------------|
| | | | | Ignition SW ON (Engine OFF) | Engine ON (Idling) | |
| Mass air flow sensor | Signal | B136 | 13 | — | 0.3 — 4.5 | — |
| | Shield | B136 | 8 | 0 | 0 | — |
| | GND | B136 | 7 | 0 | 0 | — |
| Intake air temperature sensor signal | | B135 | 27 | — | — | — |
| Exhaust gas temperature sensor | Signal | B135 | 16 | — | — | — |
| | GND (sensor) | B135 | 19 | 0 | 0 | — |
| Tumble generator valve position sensor RH | Signal | B135 | 23 | Fully closed: 0.2 — 1.0 Fully opened: 4.2 — 4.7 | | — |
| | Power supply | B135 | 9 | 5 | 5 | — |
| | GND (sensor) | B135 | 19 | 0 | 0 | — |
| Tumble generator valve position sensor LH | Signal | B135 | 13 | Fully closed: 0.2 — 1.0 Fully opened: 4.2 — 4.7 | | — |
| | Power supply | B135 | 9 | 5 | 5 | — |
| | GND (sensor) | B135 | 19 | 0 | 0 | — |
| Tumble generator valve RH (open) | | B136 | 4 | 0 or 10 — 13 | 0 or 13 — 14 | — |
| Tumble generator valve RH (close) | | B136 | 5 | 0 or 10 — 13 | 0 or 13 — 14 | — |
| Tumble generator valve LH (open) | | B136 | 10 | 0 or 10 — 13 | 0 or 13 — 14 | — |
| Tumble generator valve LH (close) | | B136 | 11 | 0 or 10 — 13 | 0 or 13 — 14 | — |
| Wastegate control solenoid valve | | B84 | 24 | 10 — 13 | 13 — 14 | — |
| Starter switch | | B134 | 16 | 0 | 0 | Cranking: 8 — 14 |
| A/C switch | | B134 | 2 | ON: 10 — 13 OFF: 0 | ON: 13 — 14 OFF: 0 | — |
| Ignition switch | | B134 | 5 | 10 — 13 | 13 — 14 | — |
| Neutral position switch (MT model) | | B134 | 8 | ON: 10 — 13 OFF: 0 | ON: 13 — 14 OFF: 0 | — |
| Neutral position switch (AT model) | | B134 | 8 | ON: 0 OFF: 10 — 13 | ON: 0 OFF: 13 — 14 | — |
| Test mode connector | | B134 | 14 | 5 | 5 | When connected: 0 |
| Knock sensor | Signal | B135 | 4 | 2.8 | 2.8 | — |
| | Shield | B135 | 22 | 0 | 0 | — |
| Back-up power supply | | B84 | 10 | 10 — 13 | 13 — 14 | Ignition switch "OFF": 10 — 13 |
| Control unit power supply | B84 | 2 | 10 — 13 | 13 — 14 | — | |
| | B84 | 3 | 10 — 13 | 13 — 14 | — | |
| Sensor power supply | | B135 | 9 | 5 | 5 | — |
| Line end check 1 | | B134 | 10 | 0 | 0 | — |
| Ignition control | #1 | B137 | 24 | 0 | 13 — 14 | Waveform |
| | #2 | B137 | 23 | 0 | 13 — 14 | Waveform |
| | #3 | B137 | 22 | 0 | 13 — 14 | Waveform |
| | #4 | B137 | 21 | 0 | 13 — 14 | Waveform |

Engine Control Module (ECM) I/O Signal

ENGINE (DIAGNOSTICS)

| Content | | Connector No. | Terminal No. | Signal (V) | | Note |
|--------------------------------------|--------------|---------------|--------------|---------------------------------|---------------------------------|---|
| | | | | Ignition SW ON (Engine OFF) | Engine ON (Idling) | |
| Fuel injector | #1 | B84 | 1 | 10 — 13 | 1 — 14 | Waveform |
| | #2 | B137 | 6 | 10 — 13 | 1 — 14 | Waveform |
| | #3 | B137 | 5 | 10 — 13 | 1 — 14 | Waveform |
| | #4 | B137 | 4 | 10 — 13 | 1 — 14 | Waveform |
| Idle air control solenoid valve | Signal | B137 | 10 | 0 or 13 — 14 | 0 or 13 — 14 | Waveform |
| Fuel pump control unit | Signal 1 | B134 | 13 | — | — | — |
| | Signal 2 | B137 | 15 | — | — | — |
| A/C relay control | | B84 | 27 | ON: 0.5 or less OFF: 10 — 13 | ON: 0.5 or less OFF: 13 — 14 | — |
| Radiator fan relay 1 control | | B84 | 17 | ON: 0.5 or less OFF: 10 — 13 | ON: 0.5 or less OFF: 13 — 14 | — |
| Radiator fan relay 2 control | | B84 | 28 | ON: 0.5 or less OFF: 10 — 13 | ON: 0.5 or less OFF: 13 — 14 | Model with A/C only |
| Malfunction indicator lamp | | B84 | 15 | — | — | Light "ON": 1 or less Light "OFF": 10 — 14 |
| Engine speed output | | B137 | 9 | — | 0 — 13, or more | Waveform |
| Purge control solenoid valve | | B84 | 16 | ON: 1 or less OFF: 10 — 13 | ON: 1 or less OFF: 13 — 14 | — |
| Manifold absolute pressure sensor | Signal | B135 | 8 | 1.7 — 2.4 | 1.1 — 1.6 | — |
| | Power supply | B135 | 9 | 5 | 5 | |
| | GND (sensor) | B135 | 19 | 0 | 0 | |
| Fuel tank pressure sensor | Signal | B135 | 15 | 2.3 — 2.7 | 2.3 — 2.7 | The valve operates when fuel filler cap is removed and reinstalled. |
| | GND (sensor) | B135 | 19 | 0 | 0 | — |
| Pressure control solenoid valve | | B84 | 22 | ON: 1 or less OFF: 10 — 13 | ON: 1 or less OFF: 13 — 14 | — |
| Drain valve | | B84 | 11 | ON: 1 or less OFF: 10 — 13 | ON: 1 or less OFF: 13 — 14 | — |
| Fuel tank sensor control valve | | B84 | 23 | ON: 1 or less OFF: 10 — 13 | ON: 1 or less OFF: 13 — 14 | — |
| Fuel level sensor | | B135 | 25 | 0.12 — 4.75 | 0.12 — 4.75 | — |
| Fuel temperature sensor signal | | B135 | 6 | 2.5 — 3.8 | 2.5 — 3.8 | Ambient temperature: 25°C (75°F) |
| Blow-by leak diagnosis signal | | B137 | 2 | 5 | 5 | — |
| Small light switch | | B134 | 17 | ON: 0 OFF: 10 — 13 | ON: 0 OFF: 13 — 14 | — |
| Blower fan switch | | B134 | 9 | ON: 0 OFF: 10 — 13 | ON: 0 OFF: 13 — 14 | — |
| Rear defogger switch | | B134 | 3 | ON: 0 OFF: 10 — 13 | ON: 0 OFF: 13 — 14 | — |
| Power steering oil pressure switch | | B135 | 24 | 10 — 13 | ON: 0 OFF: 13 — 14 | — |
| Front oxygen (A/F) sensor signal (+) | | B84 | 29 | 2.8 — 3.2 | 2.8 — 3.2 | — |

Engine Control Module (ECM) I/O Signal

ENGINE (DIAGNOSTICS)

| Content | Connector No. | Terminal No. | Signal (V) | | Note |
|--|---------------|--------------|-----------------------------|----------------------------|----------|
| | | | Ignition SW ON (Engine OFF) | Engine ON (Idling) | |
| Front oxygen (A/F) sensor signal (-) | B84 | 19 | 2.4 — 2.7 | 2.4 — 2.7 | — |
| Front oxygen (A/F) sensor shield | B84 | 18 | 0 | 0 | — |
| SSM/GST communication line | B134 | 21 | Less than 1 ←→ More than 4 | Less than 1 ←→ More than 4 | — |
| Torque control 1 signal | B134 | 19 | More than 4 | More than 4 | — |
| Torque control 2 signal | B134 | 18 | More than 4 | More than 4 | — |
| Torque control cut signal | B137 | 14 | 8 | 8 | — |
| AT diagnosis input signal | B135 | 20 | Less than 1 ←→ More than 4 | Less than 1 ←→ More than 4 | Waveform |
| AT load signal | B135 | 28 | 4.3 — 4.4 | 0.9 — 1.4 | — |
| GND (sensors) | B135 | 19 | 0 | 0 | — |
| GND (injectors) | B137 | 8 | 0 | 0 | — |
| GND (ignition system) | B137 | 18 | 0 | 0 | — |
| GND (power supply) | B137 | 17 | 0 | 0 | — |
| | B134 | 22 | 0 | 0 | — |
| GND (control systems) | B134 | 7 | 0 | 0 | — |
| | B134 | 15 | 0 | 0 | — |
| GND (front oxygen (A/F) sensor heater 1) | B84 | 9 | 0 | 0 | — |
| GND (front oxygen (A/F) sensor heater 2) | B84 | 8 | 0 | 0 | — |

6. Engine Condition Data

A: ELECTRICAL SPECIFICATION

| Content | Specified data |
|-------------|----------------------------------|
| Engine load | 1.6 — 2.9 (%): Idling |
| | 6.4 — 12.8 (%): 2,500 rpm racing |

Measuring condition:

- After warm-up the engine.
- Gear position is in neutral position.
- A/C is turned to OFF.
- All accessory switches are turned to OFF.

Transmission Control Module (TCM) I/O Signal

ENGINE (DIAGNOSTICS)

7. Transmission Control Module (TCM) I/O Signal

A: ELECTRICAL SPECIFICATION

<Ref. to 4AT(diag)-11, Transmission Control Module (TCM) I/O Signal.>


8. Data Link Connector

A: NOTE

This connector is used both for the OBD-II general scan tools and Subaru Select Monitor.

CAUTION:

Do not connect any scan tools other than the OBD-II general scan tools and Subaru Select Monitor, because the circuit for Subaru Select Monitor may be damaged.




| Terminal No. | Contents | Terminal No. | Contents |
|--------------|-------------------------|--------------|---|
| 1 | Power supply | 9 | Blank |
| 2 | Blank | 10 | Subaru Select Monitor/OBD-II general scan tool signal |
| 3 | Blank | 11 | Blank |
| 4 | Blank | 12 | Ground |
| 5 | Blank | 13 | Ground |
| 6 | Line end check signal 1 | 14 | Blank |
| 7 | Blank | 15 | Blank |
| 8 | Line end check signal 2 | 16 | Blank |

9. OBD-II General Scan Tool

A: OPERATION

1. HOW TO USE OBD-II GENERAL SCAN TOOL

- 1) Prepare a general scan tool (OBD-II general scan tool) required by SAE J1978.
- 2) Open the cover and connect the OBD-II general scan tool to data link connector located in the lower portion of instrument panel (on the driver's side).



- 3) Using the OBD-II general scan tool, call up DTC and freeze frame data.

2. MODE \$01 (CURRENT POWERTRAIN DIAGNOSTIC DATA)

Refers to data denoting the current operating condition of analog input/output, digital input/output and/or the powertrain system.

A list of the support data and PID (Parameter Identification) codes are shown in the following table.

| PID | Data | Unit of measure |
|-----|--|-----------------|
| 01 | Number of emission-related powertrain DTC and malfunction indicator light status and diagnosis support information | — |
| 03 | Fuel system control status | — |
| 04 | Calculated engine load value | % |
| 05 | Engine coolant temperature | °C |
| 06 | Short term fuel trim | % |
| 07 | Long term fuel trim | % |
| 0B | Intake manifold absolute pressure | kPa |
| 0C | Engine revolution | rpm |
| 0D | Vehicle speed | km/h |
| 0E | Ignition timing advance | ° |
| 0F | Intake air temperature | °C |
| 10 | Air flow rate from mass air flow sensor | g/sec |
| 11 | Throttle valve absolute opening angle | % |
| 13 | Check whether oxygen sensor is installed. | — |
| 15 | Oxygen sensor output voltage and short term fuel trim associated with oxygen sensor | V and % |
| 1C | Supporting OBD system | — |
| 24 | A/F value and A/F sensor output voltage | — and V |

NOTE:

Refer to OBD-II general scan tool manufacturer's instruction manual to access generic OBD-II PIDs (MODE \$01).

- OBD-II general scan tool functions consist of:
- (1) MODE \$01: Current powertrain diagnostic data
 - (2) MODE \$02: Powertrain freeze frame data
 - (3) MODE \$03: Emission-related powertrain DTC
 - (4) MODE \$04: Clear/Reset emission-related diagnostic information
 - (5) MODE \$06: Request on-board monitoring test results for non-continuously monitored systems
 - (6) MODE \$07: Request on-board monitoring test results for continuously monitored systems
 - (7) MODE \$09: Request vehicle information

Read out the data according to repair procedures. (For detailed operation procedures, refer to the OBD-II General Scan Tool Operation Manual.)

NOTE:

For details concerning DTC, refer to the List of Diagnostic Trouble Code (DTC). <Ref. to EN(H4DOTC)(diag)-71, List of Diagnostic Trouble Code (DTC).>

3. MODE \$02 (POWERTRAIN FREEZE FRAME DATA)

Refers to data denoting the operating condition when trouble is sensed by the on-board diagnosis system. A list of the support data and PID (Parameter Identification) codes are shown in the following table.

| PID | Data | Unit of measure |
|-----|---|-----------------|
| 02 | DTC that caused CARB required freeze frame data storage | — |
| 03 | Fuel system control status | — |
| 04 | Calculated engine load value | % |
| 05 | Engine coolant temperature | °C |
| 06 | Short term fuel trim | % |
| 07 | Long term fuel trim | % |
| 0B | Intake manifold absolute pressure | kPa |
| 0C | Engine revolution | rpm |
| 0D | Vehicle speed | km/h |
| 0E | Ignition timing advance | ° |
| 0F | Intake air temperature | °C |
| 10 | Air flow rate from mass air flow sensor | g/sec |
| 11 | Throttle valve opening angle | % |

NOTE:

Refer to OBD-II general scan tool manufacturer's instruction manual to access freeze frame data (MODE \$02).

4. MODE \$03 (EMISSION-RELATED POWERTRAIN DIAGNOSTIC TROUBLE CODE (DTC))

Refer to Read Diagnostic Trouble Code (DTC) for information about data denoting emission-related powertrain DTC. <Ref. to EN(H4DOTC)(diag)-38, Read Diagnostic Trouble Code (DTC).>

5. MODE \$04 (CLEAR/RESET EMISSION-RELATED DIAGNOSTIC INFORMATION)

Refers to the mode used to clear or reset emission-related diagnostic information (OBD-II trouble diagnostic information).

NOTE:

Refer to OBD-II general scan tool manufacturer's instruction manual to clear or reset emission-related diagnostic information (MODE \$04).

6. MODE \$06

Refer to test value of troubleshooting and data of test limit on support data bit sequence table. List of support data is shown in the following table.

| TID | CID | Test value & Test limit | Unit |
|------|------|--|-------|
| \$01 | \$01 | Catalyst system efficiency below threshold | ----- |
| \$03 | \$01 | Evaporative emission control system large leak | mmHg |
| | \$02 | Evaporative emission control system small leak | mmHg |
| | \$03 | Evaporative emission control system very small leak | mmHg |
| \$05 | \$01 | O ₂ sensor circuit slow response (Bank 1 Sensor 1) | ----- |
| \$06 | \$81 | O ₂ sensor circuit (Bank 1 Sensor 2) | V |
| | \$02 | | |
| \$07 | \$01 | O ₂ sensor circuit slow response (Bank 1 Sensor 2) | Sec. |
| \$0C | \$01 | Coolant thermostat (Coolant temperature below thermostat regulating temperature) | °C |
| \$0F | \$01 | Drain valve range/performance | mmHg |
| | \$82 | | |

7. MODE \$07

Refer to data of DTC (pending code) for troubleshooting result about emission in first time.

8. MODE \$09

Refer to data of vehicle specification (VIN, calibration ID, etc.).

Brought to you by Eris Studios
NOT FOR RESALE

10. Subaru Select Monitor

A: OPERATION


1. HOW TO USE SUBARU SELECT MONITOR

1) Prepare the Subaru Select Monitor kit. <Ref. to EN(H4DOTC)(diag)-8, PREPARATION TOOL, General Description.>




2) Connect the diagnosis cable to Subaru Select Monitor.

3) Insert the cartridge into Subaru Select Monitor. <Ref. to EN(H4DOTC)(diag)-8, PREPARATION TOOL, General Description.>



4) Connect the Subaru Select Monitor to data link connector.

(1) Data link connector is located in the lower portion of instrument panel (on the driver's side).




(2) Connect the diagnosis cable to data link connector.

CAUTION:

Do not connect the scan tools except for Subaru Select Monitor and OBD-II general scan tool.

5) Turn the ignition switch to ON (engine OFF) and Subaru Select Monitor switch to ON.



(A) Power switch

6) Using the Subaru Select Monitor, call up the DTC and various data, and then record them.

2. READ DIAGNOSTIC TROUBLE CODE (DTC) FOR ENGINE. (NORMAL MODE)

Refer to Read Diagnostic Trouble Code (DTC) for information about how to indicate DTC. <Ref. to EN(H4DOTC)(diag)-38, Read Diagnostic Trouble Code (DTC).>

3. READ DIAGNOSTIC TROUBLE CODE (DTC) FOR ENGINE. (OBD MODE)

Refer to Read Diagnostic Trouble Code (DTC) for information about how to indicate DTC. <Ref. to EN(H4DOTC)(diag)-38, Read Diagnostic Trouble Code (DTC).>

Subaru Select Monitor

ENGINE (DIAGNOSTICS)

4. READ CURRENT DATA FOR ENGINE. (NORMAL MODE)

- 1) On the «Main Menu» display screen, select the {Each System Check} and press the [YES] key.
- 2) On the «System Selection Menu» display screen, select the {Engine Control System} and press the [YES] key.
- 3) Press the [YES] key after the information of engine type is displayed.
- 4) On the «Engine Diagnosis» display screen, select the {Current Data Display & Save} and press the [YES] key.
- 5) On the «Data Display Menu» display screen, select the {Data Display} and press the [YES] key.
- 6) Using the scroll key, move the display screen up or down until desired data is shown.
 - A list of the support data is shown in the following table.

| Contents | Display | Unit of measure |
|---|------------------------------------|----------------------------|
| Battery voltage | Battery Voltage | V |
| Vehicle speed signal | Vehicle Speed | km/h or MPH |
| Engine speed signal | Engine Speed | rpm |
| Engine coolant temperature signal | Coolant Temp. | °C or °F |
| Ignition timing signal | Ignition Timing | deg |
| Throttle position signal | Throttle Opening Angle | % |
| Throttle position signal | Throttle Sensor Voltage | V |
| Injection pulse width | Fuel Injection #1 Pulse | ms |
| Idle air control signal | ISC Valve Duty Ratio | % |
| Fuel pump duty control signal | Fuel Pump Duty | % |
| A/F sensor current | A/F Sensor #1 Current | mA |
| A/F sensor resistance | A/F Sensor #1 Resistance | Ω |
| Front oxygen (A/F) sensor output signal | A/F Sensor #1 | — |
| Rear oxygen sensor output signal | Rear O ₂ Sensor | V |
| Short term fuel trim | A/F Correction #1 | % |
| Knock sensor signal | Knocking Correction | deg |
| Atmospheric absolute pressure signal | Atmosphere Pressure | mmHg or kPa or inHg or psi |
| Intake manifold relative pressure signal | Mani. Relative Pressure | mmHg or kPa or inHg or psi |
| Intake manifold absolute pressure signal | Mani. Absolute Pressure | mmHg or kPa or inHg or psi |
| A/F correction (short term fuel trim) by rear oxygen sensor | A/F Correction #3 | % |
| Long term whole fuel trim | A/F Learning #1 | % |
| Front oxygen (A/F) sensor heater current | A/F Heater Current 1 | A |
| Rear oxygen sensor heater voltage | Rear O ₂ Heater Voltage | V |
| Canister purge control solenoid valve duty ratio | CPC Valve Duty Ratio | % |
| Primary supercharged pressure control signal | Primary Control | % |
| Tumble generator valve position sensor signal (right side) | TGV Position Sensor R | V |
| Tumble generator valve position sensor signal (left side) | TGV Position Sensor L | V |
| Tumble generator valve drive signal | TGV Drive | OPEN or CLOSE |
| Fuel level signal | Fuel Level | V |
| Intake air temperature signal | Intake Air Temp. | °C or °F |
| Mass air flow sensor signal | Mass Air Flow | g/s |
| Mass air flow sensor signal | Air Flow Sensor Voltage | V |
| Fuel tank pressure signal | Fuel Tank Pressure | mmHg or kPa or inHg or psi |
| Fuel temperature signal | Fuel Temp. | °C or °F |
| Exhaust gas temperature signal | Exhaust Gas Temperature | °C or °F |
| AT/MT identification signal | AT Vehicle ID Signal | AT or MT |
| Fuel pressure control signal | Solenoid Valve | ON or OFF |

Subaru Select Monitor

ENGINE (DIAGNOSTICS)

| Contents | Display | Unit of measure |
|---|---------------------------------|-----------------|
| Drain valve signal | Vent. Solenoid Valve | ON or OFF |
| Tank sensor control solenoid valve signal | Tank Sensor Cntl Valve | ON or OFF |
| Ignition switch signal | Ignition Switch | ON or OFF |
| Test mode signal | Test Mode Signal | ON or OFF |
| Neutral position switch signal | Neutral Position Switch | ON or OFF |
| Air conditioning switch signal | A/C Switch | ON or OFF |
| Air conditioning signal | A/C Compressor Signal | ON or OFF |
| Radiator main fan relay signal | Radiator Fan Relay #1 | ON or OFF |
| Blow-by leak diagnosis SW | Blow-by Leak Connector | ON or OFF |
| Knocking signal | Knocking Signal | ON or OFF |
| Radiator sub fan relay signal | Radiator Fan Relay #2 | ON or OFF |
| Power steering switch signal | P/S Switch | ON or OFF |
| Engine torque control signal #1 | Torque Control Signal #1 | ON or OFF |
| Engine torque control signal #2 | Torque Control Signal #2 | ON or OFF |
| Engine torque control permission signal | Torque Permission Signal | ON or OFF |
| Rear oxygen sensor rich signal | Rear O ₂ Rich Signal | ON or OFF |
| Starter switch signal | Starter Switch | ON or OFF |
| Idle switch signal | Idle Switch | ON or OFF |
| Crankshaft position sensor signal | Crankshaft Position Sig. | ON or OFF |
| Camshaft position sensor signal | Camshaft Position Sig. | ON or OFF |
| Rear defogger switch signal | Rear Defogger SW | ON or OFF |
| Blower fan switch signal | Blower Fan SW | ON or OFF |
| Small light switch signal | Light Switch | ON or OFF |
| Tumble generator valve output signal | TGV Output | ON or OFF |

NOTE:

For detailed operation procedure, refer to the SUBARU SELECT MONITOR OPERATION MANUAL.

Subaru Select Monitor

ENGINE (DIAGNOSTICS)

5. READ CURRENT DATA FOR ENGINE. (OBD MODE)

- 1) On the «Main Menu» display screen, select the {Each System Check} and press the [YES] key.
 - 2) On the «System Selection Menu» display screen, select the {Engine Control System} and press the [YES] key.
 - 3) Press the [YES] key after the information of engine type is displayed.
 - 4) On the «Engine Diagnosis» display screen, select the {OBD System} and press the [YES] key.
 - 5) On the «OBD Menu» display screen, select the {Current Data Display & Save} and press the [YES] key.
 - 6) On the «Data Display Menu» display screen, select the {Data Display} and press the [YES] key.
 - 7) Using the scroll key, move the display screen up or down until desired data is shown.
- A list of the support data is shown in the following table.

| Contents | Display | Unit of measure |
|---|---------------------------------|----------------------------|
| Number of DTC | Number of DTC | — |
| Malfunction indicator light status | MI (MIL) | ON or OFF |
| Monitoring test of misfire | Misfire monitoring | Complete or incomplete |
| Monitoring test of fuel system | Fuel system monitoring | Complete or incomplete |
| Monitoring test of comprehensive component | Component monitoring | Complete or incomplete |
| Test of catalyst | Catalyst Diagnosis | Complete or incomplete |
| Test of heated catalyst | Heated catalyst | No support |
| Test of evaporative emission purge control system | Evaporative purge system | Complete or incomplete |
| Test of secondary air system | Secondary air system | No support |
| Test of air conditioning system refrigerant | A/C system refrigerant | No support |
| Test of oxygen sensor | Oxygen sensor | Complete or incomplete |
| Test of oxygen sensor heater | O ₂ Heater Diagnosis | Complete or incomplete |
| Test of EGR system | EGR system | No support |
| Air fuel ratio control system for bank 1 | Fuel System for Bank 1 | — |
| Engine load data | Calculated load value | % |
| Engine coolant temperature signal | Coolant Temp. | °C or °F |
| Short term fuel trim by front oxygen (A/F) sensor | Short term fuel trim B1 | % |
| Long term fuel trim by front oxygen (A/F) sensor | Long term fuel trim B1 | % |
| Intake manifold absolute pressure signal | Mani. Absolute Pressure | mmHg or kPa or inHg or psi |
| Engine speed signal | Engine Speed | rpm |
| Vehicle speed signal | Vehicle Speed | km/h or MPH |
| Ignition timing advance for #1 cylinder | Ignition timing adv. #1 | ° |
| Intake air temperature signal | Intake Air Temp. | °C or °F |
| Intake air amount | Mass Air Flow | g/s |
| Throttle position signal | Throttle Opening Angle | % |
| Oxygen sensor #11 | Oxygen Sensor #11 | — |
| Oxygen sensor #12 | Oxygen Sensor #12 | — |
| Rear oxygen sensor output signal | Oxygen Sensor #12 | V |
| Air fuel ratio correction by rear oxygen sensor | Short term fuel trim #12 | % |
| On-board diagnostic system | OBD System | CARB-OBD2 |
| A/F sensor output signal | A/F sensor #11 | V |
| A/F lambda signal | A/F sensor #11 | — |

NOTE:

For detailed operation procedure, refer to the SUBARU SELECT MONITOR OPERATION MANUAL.

6. READ FREEZE FRAME DATA FOR ENGINE. (OBD MODE)

- 1) On the «Main Menu» display screen, select the {Each System Check} and press the [YES] key.
 - 2) On the «System Selection Menu» display screen, select the {Engine Control System} and press the [YES] key.
 - 3) Press the [YES] key after the information of engine type is displayed.
 - 4) On the «Engine Diagnosis» display screen, select the {OBD System} and press the [YES] key.
 - 5) On the «OBD Menu» display screen, select the {Freeze Frame Data} and press the [YES] key.
- A list of the support data is shown in the following table.

| Contents | Display | Unit of measure |
|---|-------------------------|--------------------------|
| DTC for freeze frame data | Freeze frame data | DTC |
| Air fuel ratio control system for bank 1 | Fuel system for Bank1 | Closed loop or Open loop |
| Engine load data | Calculated load value | % |
| Engine coolant temperature signal | Coolant Temp. | °C or °F |
| Short term fuel trim by front oxygen (A/F) sensor | Short term fuel trim B1 | % |
| Long term fuel trim by front oxygen (A/F) sensor | Long term fuel trim B1 | % |
| Intake manifold absolute pressure signal | Mani. Absolute Pressure | mmHg, kPa, inHg or psi |
| Engine speed signal | Engine Speed | rpm |
| Vehicle speed signal | Vehicle Speed | km/h or MPH |

NOTE:

For detailed operation procedure, refer to the SUBARU SELECT MONITOR OPERATION MANUAL.

Subaru Select Monitor

ENGINE (DIAGNOSTICS)

7. LED OPERATION MODE FOR ENGINE

- 1) On the «Main Menu» display screen, select the {Each System Check} and press the [YES] key.
- 2) On the «System Selection Menu» display screen, select the {Engine Control System} and press the [YES] key.
- 3) Press the [YES] key after the information of engine type is displayed.
- 4) On the «Engine Diagnosis» display screen, select the {Current Data Display & Save} and press the [YES] key.
- 5) On the «Data Display Menu» display screen, select the {Data & LED Display} and press the [YES] key.
- 6) Using the scroll key, move the display screen up or down until the desired data is shown.
 - A list of the support data is shown in the following table.

| Contents | Display | Message | LED "ON" requirements |
|--|---------------------------------|---------------|---|
| Ignition switch signal | Ignition Switch | ON or OFF | When ignition switch is turned to ON. |
| Test mode signal | Test Mode Signal | ON or OFF | When test mode connector is connected. |
| Neutral position switch signal | Neutral Position Switch | ON or OFF | When neutral position signal is entered. |
| Air conditioning switch signal | A/C Switch | ON or OFF | When air conditioning switch is turned ON. |
| Air conditioning relay signal | A/C Compressor Signal | ON or OFF | When air conditioning relay is in function. |
| Radiator main fan relay signal | Radiator Fan Relay #1 | ON or OFF | When radiator main fan relay is in function. |
| Knocking signal | Knocking Signal | ON or OFF | When knocking signal is entered. |
| Radiator sub fan relay signal | Radiator Fan Relay #2 | ON or OFF | When radiator sub fan relay is in function. |
| Engine torque control signal #1 | Torque Control Signal #1 | ON or OFF | When engine torque control signal 1 is entered. |
| Engine torque control signal #2 | Torque Control Signal #2 | ON or OFF | When engine torque control signal 2 is entered. |
| Engine torque control permission signal | Torque Control Permission | ON or OFF | When engine torque control permission signal is entered. |
| Rear oxygen sensor rich signal | Rear O ₂ Rich Signal | ON or OFF | When rear oxygen sensor mixture ratio is rich. |
| Starter switch signal | Starter Switch Signal | ON or OFF | When starter switch signal is entered. |
| Idle switch signal | Idle Switch Signal | ON or OFF | When idle switch signal is entered. |
| Crankshaft position sensor signal | Crankshaft Position Signal | ON or OFF | When crankshaft position sensor signal is entered. |
| Camshaft position sensor signal | Camshaft Position Signal | ON or OFF | When camshaft position sensor signal is entered. |
| Power steering switch signal | P/S Switch | ON or OFF | When power steering switch is entered. |
| Rear defogger switch signal | Rear Defogger Switch | ON or OFF | When rear defogger switch is turned ON. |
| Blower fan switch signal | Blower Fan Switch | ON or OFF | When blower fan switch is turned ON. |
| Small light switch signal | Light Switch | ON or OFF | When small light switch is turned ON. |
| Tumble generator valve actuator signal | TGV Output | ON or OFF | When TGV actuator signal is entered. |
| Tumble generator valve drive signal | TGV Drive | Close or Open | When TGV moves and valve opens. |
| Fuel pressure control solenoid | PCV Solenoid Valve | ON or OFF | When fuel pressure control solenoid valve is in function. |
| Drain valve signal | Vent. Solenoid Valve | ON or OFF | When drain valve is in function. |
| AT/MT identification signal | AT Vehicle ID Signal | ON or OFF | When AT vehicle is checked. |
| Fuel tank sensor control solenoid valve signal | Fuel Tank Sensor Ctrl Valve | ON or OFF | When tank sensor control solenoid valve is in function. |
| Blow-by leak diagnosis SW | Blow-by Leak Connector | ON or OFF | When connected. |

NOTE:

For detailed operation procedure, refer to the SUBARU SELECT MONITOR OPERATION MANUAL.

8. READ CURRENT DATA FOR AT

- 1) On the «Main Menu» display screen, select the {Each System Check} and press the [YES] key.
- 2) On the «System Selection Menu» display screen, select the {Transmission Control System} and press the [YES] key.
- 3) Press the [YES] key after the information of transmission type is displayed.
- 4) On the «Transmission Diagnosis» display screen, select the {Current Data Display & Save} and press the [YES] key.
- 5) On the «Data Display Menu» display screen, select the {Data Display} and press the [YES] key.
- 6) Using the scroll key, move the display screen up or down until desired data is shown.
 - A list of the support data is shown in the following table.

| Contents | Display | Unit of measure |
|---|--------------------------|-----------------|
| Battery voltage | Battery Voltage | V |
| Rear vehicle speed sensor signal | Rear Wheel Speed | km/h or MPH |
| Front vehicle speed sensor signal | Front Wheel Speed | km/h or MPH |
| Engine speed signal | Engine Speed | rpm |
| Automatic transmission fluid temperature signal | ATF Temp. | °C or °F |
| Mass air flow sensor signal | Air Flow Sensor Voltage | V |
| Throttle position signal | Throttle Sensor Voltage | V |
| Gear position | Gear Position | — |
| Line pressure control duty ratio | Line Pressure Duty Ratio | % |
| Lock up clutch control duty ratio | Lock Up Duty Ratio | % |
| Transfer clutch control duty ratio | Transfer Duty Ratio | % |
| Power supply for throttle position sensor | Throttle Sensor Power | V |
| Torque converter turbine speed signal | Turbine Revolution Speed | rpm |
| 2-4 brake timing pressure control duty ratio | Brake Clutch Duty Ratio | % |
| Stop lamp switch signal | Stop Light Switch | ON or OFF |
| Anti lock brake system signal | ABS Signal | ON or OFF |
| Cruise control system signal | Cruise Control Signal | ON or OFF |
| Neutral/Parking range signal | N/P Range Signal | ON or OFF |
| Reverse range signal | R Range Signal | ON or OFF |
| Drive range signal | D Range Signal | ON or OFF |
| 3rd range signal | 3rd Range Signal | ON or OFF |
| 2nd range signal | 2nd Range Signal | ON or OFF |
| 1st range signal | 1st Range Signal | ON or OFF |
| Shift control solenoid A | Shift Solenoid #1 | ON or OFF |
| Shift control solenoid B | Shift Solenoid #2 | ON or OFF |
| Torque control output signal #1 | Torque Control Signal #1 | ON or OFF |
| Torque control output signal #2 | Torque Control Signal #2 | ON or OFF |
| Torque control cut signal | Torque Control Cut Sig. | ON or OFF |
| 2-4 brake timing control solenoid valve | 2-4 Brake Timing Sol. | ON or OFF |
| Low clutch timing control solenoid valve | Low Clutch Timing Sol. | ON or OFF |
| Automatic transmission diagnosis indicator lamp | Diagnosis Lamp | ON or OFF |

NOTE:

For detailed operation procedure, refer to the SUBARU SELECT MONITOR OPERATION MANUAL.

11. Read Diagnostic Trouble Code (DTC)

A: OPERATION

1. SUBARU SELECT MONITOR (NORMAL MODE)

- 1) On the «Main Menu» display screen, select the {Each System Check} and press the [YES] key.
- 2) On the «System Selection Menu» display screen, select the {Engine Control System} and press the [YES] key.
- 3) Press the [YES] key after the information of engine type is displayed.
- 4) On the «Engine Diagnosis» display screen, select the {DTC Display} and press the [YES] key.
- 5) On the «DTC Display» display screen, select the {Current DTC} or {History DTC} and press the [YES] key.

NOTE:

- For detailed operation procedure, refer to the SUBARU SELECT MONITOR OPERATION MANUAL.
- For detailed concerning DTC, refer to the List of Diagnostic Trouble Code (DTC). <Ref. to EN(H4DOTC)(diag)-71, List of Diagnostic Trouble Code (DTC).>

2. SUBARU SELECT MONITOR (OBD MODE)

- 1) On the «Main Menu» display screen, select the {2. Each System Check} and press the [YES] key.
- 2) On the «System Selection Menu» display screen, select the {Engine Control System} and press the [YES] key.
- 3) Press the [YES] key after the information of engine type is displayed.
- 4) On the «Engine Diagnosis» display screen, select the {OBD System} and press the [YES] key.
- 5) On the «OBD Menu» display screen, select the {DTC Display} and press the [YES] key.
- 6) Make sure that a DTC is shown on the display screen.

NOTE:

- For detailed operation procedure, refer to the SUBARU SELECT MONITOR OPERATION MANUAL.
- For detailed concerning DTC, refer to the List of Diagnostic Trouble Code (DTC). <Ref. to EN(H4DOTC)(diag)-71, List of Diagnostic Trouble Code (DTC).>

3. OBD-II GENERAL SCAN TOOL

Refers to data denoting emission-related powertrain DTC.

For details concerning DTC, refer to the List of Diagnostic Trouble Code (DTC). <Ref. to EN(H4DOTC)(diag)-71, List of Diagnostic Trouble Code (DTC).>

NOTE:

Refer to OBD-II general scan tool manufacturer's instruction manual to access emission-related powertrain DTC (MODE \$03).

12. Inspection Mode

A: PROCEDURE

Carry out trouble diagnosis shown in the following DTC table.

When performing trouble diagnosis which is not shown in the DTC table, refer to the next item Drive cycle.

<Ref. to EN(H4DOTC)(diag)-44, Drive Cycle.>

| DTC | Item | Condition |
|-------|--|-----------|
| P0030 | HO2S Heater Control Circuit (Bank 1 Sensor 1) | — |
| P0031 | HO2S Heater Control Circuit Low (Bank 1 Sensor 1) | — |
| P0032 | HO2S Heater Control Circuit High (Bank 1 Sensor 1) | — |
| P0037 | HO2S Heater Control Circuit Low (Bank 1 Sensor 2) | — |
| P0038 | HO2S Heater Control Circuit High (Bank 1 Sensor 2) | — |
| P0102 | Mass or Volume Air Flow Circuit Low Input | — |
| P0103 | Mass or Volume Air Flow Circuit High Input | — |
| P0107 | Manifold Absolute Pressure/Barometric Pressure Circuit Low Input | — |
| P0108 | Manifold Absolute Pressure/Barometric Pressure Circuit High Input | — |
| P0112 | Intake Air Temperature Circuit Low Input | — |
| P0113 | Intake Air Temperature Circuit High Input | — |
| P0117 | Engine Coolant Temperature Circuit Low Input | — |
| P0118 | Engine Coolant Temperature Circuit High Input | — |
| P0122 | Throttle/Pedal Position Sensor/Switch "A" Circuit Low Input | — |
| P0123 | Throttle/Pedal Position Sensor/Switch "A" Circuit High Input | — |
| P0129 | Atmospheric Pressure Sensor Circuit Range/Performance | — |
| P0130 | O ₂ Sensor Circuit (Bank 1 Sensor 1) | — |
| P0134 | O ₂ Sensor Circuit No Activity Detected (Bank 1 Sensor 1) | — |
| P0137 | O ₂ Sensor Circuit Low Voltage (Bank 1 Sensor 2) | — |
| P0138 | O ₂ Sensor Circuit High Voltage (Bank 1 Sensor 2) | — |
| P0182 | Fuel Temperature Sensor "A" Circuit Low Input | — |
| P0183 | Fuel Temperature Sensor "A" Circuit High Input | — |
| P0230 | Fuel Pump Primary Circuit | — |
| P0245 | Turbo/Super Charger Wastegate Solenoid "A" Low | — |
| P0327 | Knock Sensor 1 Circuit Low Input (Bank 1 or Single Sensor) | — |
| P0328 | Knock Sensor 1 Circuit High Input (Bank 1 or Single Sensor) | — |
| P0335 | Crankshaft Position Sensor "A" Circuit | — |
| P0336 | Crankshaft Position Sensor "A" Circuit Range/Performance | — |
| P0340 | Camshaft Position Sensor "A" Circuit (Bank 1 or Single Sensor) | — |
| P0341 | Camshaft Position Sensor "A" Circuit Range/Performance (Bank 1 or Single Sensor) | — |
| P0447 | Evaporative Emission Control System Vent Control Circuit Open | — |
| P0448 | Evaporative Emission Control System Vent Control Circuit Shorted | — |
| P0452 | Evaporative Emission Control System Pressure Sensor Low Input | — |
| P0453 | Evaporative Emission Control System Pressure Sensor High Input | — |
| P0458 | Evaporative Emission Control System Purge Control Valve Circuit Low | — |
| P0462 | Fuel Level Sensor Circuit Low Input | — |
| P0463 | Fuel Level Sensor Circuit High Input | — |
| P0502 | Vehicle Speed Sensor Circuit Low Input | — |
| P0503 | Vehicle Speed Sensor Intermittent/Erratic/High | — |
| P0508 | Idle Control System Circuit Low | — |
| P0509 | Idle Control System Circuit High | — |
| P0512 | Starter Request Circuit | — |
| P0519 | Idle Control System Malfunction (Fail-Safe) | — |

Inspection Mode

ENGINE (DIAGNOSTICS)

| DTC | Item | Condition |
|-------|--|-----------|
| P0545 | Exhaust Gas Temperature Sensor Circuit Low - Bank 1 | — |
| P0565 | Cruise Control On Signal | — |
| P0604 | Internal Control Module Random Access Memory (RAM) Error | — |
| P0691 | Cooling Fan 1 Control Circuit Low | — |
| P0703 | Torque Converter/Brake Switch "B" Circuit | — |
| P0705 | Transmission Range Sensor Circuit (PRNDL Input) | — |
| P0710 | Transmission Fluid Temperature Sensor Circuit | — |
| P0716 | Torque Converter Turbine Speed Sensor | — |
| P0720 | Output Speed Sensor Circuit | — |
| P0726 | Engine Speed Input Circuit Range/Performance | — |
| P0731 | Gear 1 Incorrect Ratio | — |
| P0732 | Gear 2 Incorrect Ratio | — |
| P0733 | Gear 3 Incorrect Ratio | — |
| P0734 | Gear 4 Incorrect Ratio | — |
| P0741 | Torque Converter Clutch Circuit Performance or Stuck Off | — |
| P0743 | Torque Converter Clutch Circuit Electrical | — |
| P0748 | Pressure Control Solenoid "A" Electrical | — |
| P0753 | Shift Solenoid "A" Electrical | — |
| P0758 | Shift Solenoid "B" Electrical | — |
| P0771 | Low Clutch Timing Solenoid | — |
| P0778 | Pressure Control Solenoid "B" Electrical | — |
| P0785 | Shift/Timing Solenoid | — |
| P0851 | Neutral Switch Input Circuit Low | — |
| P0852 | Neutral Switch Input Circuit High | — |
| P0864 | TCM Communication Circuit Range/Performance | — |
| P0865 | TCM Communication Circuit Low | — |
| P0866 | TCM Communication Circuit High | — |
| P1086 | Tumble Generated Valve Position Sensor 2 Circuit Low | — |
| P1087 | Tumble Generated Valve Position Sensor 2 Circuit High | — |
| P1088 | Tumble Generated Valve Position Sensor 1 Circuit Low | — |
| P1089 | Tumble Generated Valve Position Sensor 1 Circuit High | — |
| P1091 | Tumble Generated Valve System 1 (Valve Close) | — |
| P1093 | Tumble Generated Valve System 2 (Valve Close) | — |
| P1094 | Tumble Generated Valve Signal 1 Circuit Malfunction (Open) | — |
| P1095 | Tumble Generated Valve Signal 1 Circuit Malfunction (Short) | — |
| P1096 | Tumble Generated Valve Signal 2 Circuit Malfunction (Open) | — |
| P1097 | Tumble Generated Valve Signal 2 Circuit Malfunction (Short) | — |
| P1110 | Atmospheric Pressure sensor circuit malfunction (Low input) | — |
| P1111 | Atmospheric Pressure sensor circuit malfunction (High input) | — |
| P1134 | A/F Sensor Micro-Computer Problem | — |
| P1152 | O ₂ Sensor Circuit Range/Performance (Low) (Bank1 Sensor1) | — |
| P1153 | O ₂ Sensor Circuit Range/Performance (High) (Bank1 Sensor1) | — |
| P1400 | Fuel Tank Pressure Control Solenoid Valve Circuit Low | — |
| P1420 | Fuel Tank Pressure Control Sol. Valve Circuit High | — |
| P1446 | Fuel Tank Sensor Control Valve Circuit Low | — |
| P1447 | Fuel Tank Sensor Control Valve Circuit High | — |
| P1491 | Positive Crankcase Ventilation (Blow-by) Function Problem | — |
| P1518 | Starter Switch Circuit Low Input | — |
| P1544 | Exhaust Gas Temperature Too High | — |
| P1560 | Back-up Voltage Circuit Malfunction | — |
| P1700 | Throttle Position Sensor | — |


| DTC | Item | Condition |
|-------|--|-----------|
| P1711 | Engine Torque Control Signal 1 Circuit Malfunction | — |
| P1712 | Engine Torque Control Signal 2 Circuit Malfunction | — |

1. PREPARATION FOR THE INSPECTION MODE

- 1) Make sure that the fuel remains approx. half amount [20 — 40 ℓ (5.3 — 10.6 US gal, 4.4 — 8.8 Imp gal)] and the battery voltage is 12 V or more.
- 2) Raise the vehicle using a garage jack and place on safety stands or drive the vehicle onto free rollers.

WARNING:


- Before raising the vehicle, ensure the parking brake is applied.
- Do not use a pantograph jack in place of a safety stand.
- Secure a rope or wire to the front and rear towing or tie-down hooks to prevent the lateral runout of front wheels.
- Do not abruptly depress/release the clutch pedal or accelerator pedal during works even when engine is operating at low speeds since this may cause vehicle to jump off free rollers.
- In order to prevent the vehicle from slipping due to vibration, do not place any wooden blocks or similar items between the safety stands and the vehicle.
- Since the rear wheels will also rotate, do not place anything near them. Also, make sure that nobody goes in front of the vehicle.




- (A) Safety stand
(B) Free rollers

2. SUBARU SELECT MONITOR


- 1) Warm up the engine.
- 2) Prepare the Subaru Select Monitor kit. <Ref. to EN(H4DOTC)(diag)-8, PREPARATION TOOL, General Description.>



- 3) Connect the diagnosis cable to Subaru Select Monitor.
- 4) Insert the cartridge into Subaru Select Monitor. <Ref. to EN(H4DOTC)(diag)-8, PREPARATION TOOL, General Description.>



- 5) Connect the test mode connector (A) at the lower portion of instrument panel (on the driver's side).




(A) Test mode connector

Inspection Mode

ENGINE (DIAGNOSTICS)


6) Connect the Subaru Select Monitor to data link connector located in the lower portion of the instrument panel (on the driver's side).



CAUTION:

Do not connect the scan tools except for Subaru Select Monitor and OBD-II general scan tool.

7) Turn the ignition switch to ON (engine OFF) and Subaru Select Monitor switch to ON.



(A) Power switch

8) On the «Main Menu» display screen, select the {2. Each System Check} and press the [YES] key.

9) On the «System Selection Menu» display screen, select the {Engine Control System} and press the [YES] key.

10) Press the [YES] key after the information of engine type is displayed.

11) On the «Engine Diagnosis» display screen, select the {Dealer Check Mode Procedure} and press the [YES] key.

12) When the "Perform Inspection (Dealer Check Mode)?" is shown on the display screen, press the [YES] key.

13) Perform subsequent procedures as instructed on the display screen.

- If trouble still remains in the memory, the corresponding DTC appears on the display screen.

NOTE:

- For detailed operation procedure, refer to the SUBARU SELECT MONITOR OPERATION MANUAL.

- For detailed concerning the DTC, refer to the List of Diagnostic Trouble Code (DTC).

<Ref. to EN(H4DOTC)(diag)-71, List of Diagnostic Trouble Code (DTC).>


- Release the parking brake.

- The speed difference between front and rear wheels may light either the ABS warning light, but this indicates no malfunctions. When the engine control diagnosis is finished, perform the ABS memory clearance procedure of self-diagnosis system.

3. OBD-II GENERAL SCAN TOOL

1) Warm up the engine.


2) Connect the test mode connector (A) at the lower side of instrument panel (on the driver's side).



3) Connect the OBD-II general scan tool to its data link connector in the lower portion of instrument panel (on the driver's side).

CAUTION:

Do not connect the scan tools except for Subaru Select Monitor and OBD-II general scan tool.



4) Start the engine.

NOTE:

- Ensure the select lever is placed in "P" range before starting. (AT model)

- Depress the clutch pedal when starting engine. (MT model)

5) Using the select lever or shift lever, turn the "P" position switch and "N" position switch to ON.

6) Depress the brake pedal to turn brake switch ON. (AT model)

7) Keep the engine speed in 2,500 — 3,000 rpm range for 40 seconds.

8) Place the select lever or shift lever in “D” range (AT model) or “1st” gear (MT model) and drive the vehicle at 5 to 10 km/h (3 to 6 MPH).

NOTE:

- On AWD model, release the parking brake.
- The speed difference between front and rear wheels may light ABS warning light, but this indicates no malfunctions. When the engine control diagnosis is finished, perform the ABS memory clearance procedure of self-diagnosis system.

9) Using the OBD-II general scan tool, check for DTC and record the result(s).

NOTE:

- For detailed operation procedures, refer to the OBD-II General Scan Tool Instruction Manual.
- For detailed concerning DTC, refer to the List of Diagnostic Trouble Code (DTC).

<Ref. to EN(H4DOTC)(diag)-71, List of Diagnostic Trouble Code (DTC).>

Brought to you by Eris Studios
NOT FOR RESALE

13. Drive Cycle

A: PROCEDURE

There are three drive patterns for the trouble diagnosis. Driving in the specified pattern allows to diagnose malfunctioning items listed below. After the malfunctioning items listed below are repaired, always check whether they correctly resume their functions by driving in the required drive pattern.

1. PREPARATION FOR THE DRIVE CYCLE

- 1) Make sure that the fuel remains approx. half amount [20 — 40 ℓ (5.3 — 10.6 US gal, 4.4 — 8.8 Imp gal)], and battery voltage is 12 V or more.
- 2) Separate the test mode connector.

NOTE:

- Except for the engine coolant temperature specified items at starting, the diagnosis is carried out after engine warm up.
- Carry out the diagnosis which is marked* on DTC twice, then, after finishing first diagnosis, stop the engine and do second time at the same condition.

2. AFTER RUNNING 20 MINUTES AT 80 KM/H (50 MPH), IDLE ENGINE FOR 1 MINUTE.

| DTC | Item | Condition |
|--------|--|---|
| *P0125 | Insufficient Coolant Temperature for Closed Loop Fuel Control | Engine coolant temperature is less than 20°C (68°F) at engine start. |
| *P0128 | Coolant Thermostat | Engine coolant temperature is less than 55°C (131°F) at engine start. |
| *P0133 | O ₂ Sensor Circuit Slow Response (Bank 1 Sensor 1) | — |
| *P0181 | Fuel Temperature Sensor A Performance Problem | — |
| *P0420 | Catalyst System Efficiency Below Threshold (Bank 1) | — |
| *P0442 | Evaporative Emission Control System Leak Detected (small leak) | — |
| *P0451 | Evaporative Emission Control System Pressure Sensor Range/Performance | — |
| *P0456 | Evaporative Emission Control System Leak Detected (very small leak) | — |
| *P0457 | Evaporative Emission Control System Leak Detected (fuel cap loose/off) | — |
| P0459 | Evaporative Emission Control System Purge Control Valve Circuit High | — |
| P0461 | Fuel Level Sensor Circuit Range/Performance | — |
| P0692 | Cooling Fan 1 Control Circuit High | — |
| P1312 | Exhaust Gas Temperature Sensor Malfunction | Engine coolant temperature is less than 40°C (104°F) at engine start. |
| P1443 | Vent Control Solenoid Valve Function Problem | — |
| *P1448 | Fuel Tank Sensor Control Valve Range/Performance | — |
| *P2096 | Post Catalyst Fuel Trim System Too Lean Bank 1 | — |
| *P2097 | Post Catalyst Fuel Trim System Too Rich Bank 1 | — |


3. IDLE FOR 10 MINUTES

NOTE:

Before the diagnosis, drive the vehicle at 10 km/h (6 MPH) or more.

| DTC | Item | Condition |
|--------|---|--|
| *P0111 | Intake Air Temperature Sensor Range/Performance Problem | Engine coolant temperature is less than 30°C (86°F) at engine start. |
| P0171 | System too Lean (Bank 1) | — |
| P0172 | System too Rich (Bank 1) | — |
| *P0464 | Fuel Level Sensor Circuit Intermittent | — |
| *P0483 | Cooling Fan Rationality Check | — |
| *P0506 | Idle Control System RPM Lower Than Expected | — |
| *P0507 | Idle Control System RPM Higher Than Expected | — |
| P0546 | Exhaust Gas Temperature Sensor Circuit High-Bank 1 | — |

4. DRIVE ACCORDING TO THE FOLLOWING DRIVE PATTERN



- | | | |
|---|--|--|
| (A) Idle engine for 10 seconds or more. | (D) Decelerate with fully closed throttle to 64 km/h (40 MPH). | (G) Stop vehicle with throttle fully closed. |
| (B) Accelerate to 97 km/h (60 MPH) within 20 seconds. | (E) Drive vehicle at 64 km/h (40 MPH) for 20 seconds. | |
| (C) Drive vehicle at 97 km/h (60 MPH) for 20 seconds. | (F) Accelerate to 97 km/h (60 MPH) within 10 seconds. | |

| DTC | Item | Condition |
|--------|--|--|
| P0068 | Manifold Absolute Pressure/Barometric Pressure Circuit Range/Performance | — |
| *P0101 | Mass or Volume Air Flow Circuit Range/Performance | — |
| *P0121 | Throttle/Pedal Position Sensor/Switch "A" Circuit Range/Performance | — |
| *P0139 | O ₂ Sensor Circuit Slow Response (Bank 1 Sensor 2) | — |
| P0244 | Turbo/Supercharger Wastegate Solenoid "A" Range/Performance | — |
| P0246 | Turbo/Supercharger Wastegate Solenoid "A" High | — |
| *P0301 | Cylinder 1 Misfire Detected | In some cases, diagnosis may complete at once. |
| *P0302 | Cylinder 2 Misfire Detected | In some cases, diagnosis may complete at once. |
| *P0303 | Cylinder 3 Misfire Detected | In some cases, diagnosis may complete at once. |
| *P0304 | Cylinder 4 Misfire Detected | In some cases, diagnosis may complete at once. |
| P1090 | Tumble Generated Valve System 1 (Valve Open) | — |
| P1092 | Tumble Generated Valve System 2 (Valve Open) | — |
| P1301 | Misfire Detected (High Temperature Exhaust Gas) | — |

14. Clear Memory Mode

A: OPERATION

1. SUBARU SELECT MONITOR (NORMAL MODE)

- 1) On the «Main Menu» display screen, select the {2. Each System Check} and press the [YES] key.
- 2) On the «System Selection Menu» display screen, select the {Engine Control System} and press the [YES] key.
- 3) Press the [YES] key after the information of engine type is displayed.
- 4) On the «Engine Diagnosis» display screen, select the {Clear Memory} and press the [YES] key.
- 5) When the 'Done' and 'Turn Ignition Switch OFF' are shown on the display screen, turn the ignition switch to OFF, and then turn the Subaru Select Monitor to OFF.

NOTE:

For detailed operation procedure, refer to the SUBARU SELECT MONITOR OPERATION MANUAL.

2. SUBARU SELECT MONITOR (OBD MODE)

- 1) On the «Main Menu» display screen, select the {2. Each System Check} and press the [YES] key.
- 2) On the «System Selection Menu» display screen, select the {Engine Control System} and press the [YES] key.
- 3) Press the [YES] key after the information of engine type is displayed.
- 4) On the «Engine Diagnosis» display screen, select the {OBD System} and press the [YES] key.
- 5) On the «OBD Menu» display screen, select the {4. Diagnosis Code(s) Cleared} and press the [YES] key.
- 6) When the 'Clear Diagnostic Code?' is shown on the display screen, press the [YES] key.
- 7) Turn the ignition switch to OFF, and then turn the Subaru Select Monitor to OFF.

NOTE:

For detailed operation procedure, refer to the SUBARU SELECT MONITOR OPERATION MANUAL.


3. OBD-II GENERAL SCAN TOOL

For clear memory procedures using the OBD-II general scan tool, refer to the OBD-II General Scan Tool Instruction Manual.

15. Compulsory Valve Operation Check Mode


A: OPERATION

1) Prepare the Subaru Select Monitor kit. <Ref. to EN(H4DOTC)(diag)-8, PREPARATION TOOL, General Description.>




2) Connect the diagnosis cable to Subaru Select Monitor.


3) Insert the cartridge into Subaru Select Monitor. <Ref. to EN(H4DOTC)(diag)-8, PREPARATION TOOL, General Description.>



4) Connect the test mode connector (A) at the lower portion of instrument panel (on the driver's side).




5) Connect the Subaru Select Monitor to data link connector located in the lower portion of instrument panel (on the driver's side).



CAUTION:

Do not connect scan tools except for the Subaru Select Monitor and OBD-II general scan tool.

6) Turn the ignition switch to ON (engine OFF) and Subaru Select Monitor switch to ON.



(A) Power switch

7) On the «Main Menu» display screen, select the {2. Each System Check} and press the [YES] key.

8) On the «System Selection Menu» display screen, select the {Engine Control System} and press the [YES] key.

9) Press the [YES] key after the information of engine type is displayed.

10) On the «Engine Diagnosis» display screen, select the {System Operation Check Mode} and press the [YES] key.

11) On the «System Operation Check Mode» display screen, select the {Actuator ON/OFF Operation} and press the [YES] key.

12) Select the desired compulsory actuator on the «Actuator ON/OFF Operation» display screen and press the [YES] key.

13) Pressing the [NO] key completes the compulsory operation check mode. The display will then return to the «Actuator ON/OFF Operation» screen.

Compulsory Valve Operation Check Mode

ENGINE (DIAGNOSTICS)

- A list of support data is shown in the following table.

| Contents | Display |
|--|--------------------------------|
| Compulsory fuel pump relay operation check | Fuel Pump Relay |
| Compulsory radiator fan relay operation check | Radiator Fan Relay |
| Compulsory air conditioning relay operation check | A/C Compressor Relay |
| Compulsory purge control solenoid valve operation check | CPC Solenoid Valve |
| Compulsory pressure control solenoid valve operation check | PCV Solenoid Valve |
| Compulsory drain valve operation check | Vent. Control Solenoid Valve |
| Compulsory fuel tank sensor control valve operation check | Fuel Tank Sensor Control Valve |

NOTE:

- The following parts will be displayed but not functional because they are not installed on the vehicle.

| Display |
|---------------------------------|
| EGR Solenoid Valve |
| ASV Solenoid Valve |
| FICD Solenoid |
| Pressure Switching Sol. 1 |
| Pressure Switching Sol. 2 |
| AAI Solenoid Valve |
| Turbocharger Wastegate Solenoid |

- For detailed operation procedure, refer to the SUBARU SELECT MONITOR OPERATION MANUAL.

16. Malfunction Indicator Light

A: PROCEDURE

| |
|--|
| 1. Activation of check malfunction indicator light. <Ref. to EN(H4DOTC)(diag)-50, ACTIVATION OF MALFUNCTION INDICATOR LIGHT, Malfunction Indicator Light.> |
| ↓ |
| 2. Check that the malfunction indicator light does not come on. <Ref. to EN(H4DOTC)(diag)-51, MALFUNCTION INDICATOR LIGHT DOES NOT COME ON., Malfunction Indicator Light.> |
| ↓ |
| 3. Check that the malfunction indicator light does not go off. <Ref. to EN(H4DOTC)(diag)-53, MALFUNCTION INDICATOR LIGHT DOES NOT GO OFF., Malfunction Indicator Light.> |
| ↓ |
| 4. Check that the malfunction indicator light does not blink at a cycle of 3 Hz. <Ref. to EN(H4DOTC)(diag)-54, MALFUNCTION INDICATOR LIGHT DOES NOT BLINK AT A CYCLE OF 3 HZ., Malfunction Indicator Light.> |
| ↓ |
| 5. Check that the malfunction indicator light remains blinking at a cycle of 3 Hz. <Ref. to EN(H4DOTC)(diag)-56, MALFUNCTION INDICATOR LIGHT REMAINS BLINKING AT A CYCLE OF 3 HZ., Malfunction Indicator Light.> |

Malfunction Indicator Light


ENGINE (DIAGNOSTICS)

B: ACTIVATION OF MALFUNCTION INDICATOR LIGHT

1) When the ignition switch is turned to ON (engine off), the malfunction indicator light in the combination meter illuminates.


NOTE:

If the malfunction indicator light does not illuminate, perform diagnostics of the malfunction indicator light circuit or the combination meter circuit. <Ref. to EN(H4DOTC)(diag)-51, MALFUNCTION INDICATOR LIGHT DOES NOT COME ON., Malfunction Indicator Light.>



EN-01604


2) After starting the engine, the malfunction indicator light goes out. If it does not, either the engine or the emission control system is malfunctioning.



EN-01679

- (1) No trouble
- (2) Trouble occurs
- (3) ON
- (4) OFF
- (5) Ignition switch ON
- (6) Engine start


3) If the diagnosis system senses a misfire which could damage the catalyzer, the malfunction indicator light will blink at a cycle of 1 Hz.



EN-01680

- (1) ON
- (2) OFF
- (3) Ignition switch ON
- (4) Engine start
- (5) Misfire start
- (6) 1 second

4) When the ignition switch is turned to ON (engine off) or to START with the test mode connector connected, the malfunction indicator light blinks at a cycle of 3 Hz.



EN-01681

- (1) ON
- (2) OFF
- (3) Ignition switch ON
- (4) 1 second

Malfunction Indicator Light

ENGINE (DIAGNOSTICS)

C: MALFUNCTION INDICATOR LIGHT DOES NOT COME ON.


DIAGNOSIS:

The malfunction indicator light circuit is shorted.

TROUBLE SYMPTOM:

When the ignition switch is turned to ON (engine OFF), malfunction indicator light does not come on.

WIRING DIAGRAM:



| Step | Check | Yes | No | |
|------|--|---|---------------|---------------|
| 1 | CHECK OUTPUT SIGNAL FROM ECM. 1) Turn the ignition switch to ON. 2) Measure the voltage between ECM connector and chassis ground. Connector & terminal (B84) No. 15 (+) — Chassis ground (-): | Is the voltage less than 1 V? | Go to step 4. | Go to step 2. |
| 2 | CHECK POOR CONTACT. Does the malfunction indicator light come on when shaking or pulling ECM connector and harness? | Repair the poor contact in ECM connector. | Go to step 3. | |

Malfunction Indicator Light

ENGINE (DIAGNOSTICS)

| Step | Check | Yes | No |
|---|---|--|---|
| 3 CHECK ECM CONNECTOR. | Is the ECM connector correctly connected? | Replace the ECM. <Ref. to FU(H4DOTC)-48, Engine Control Module (ECM).> | Repair the connection of ECM connector. |
| 4 CHECK HARNESS BETWEEN COMBINATION METER AND ECM CONNECTOR. 1) Turn the ignition switch to OFF. 2) Remove the combination meter. <Ref. to IDI-10, Combination Meter Assembly.> 3) Disconnect the connector from ECM and combination meter. 4) Measure the resistance of harness between ECM and combination meter connector. <i>Connector & terminal</i> <i>(B84) No. 15 — (i11) No. 6:</i> | Is the resistance less than 1 Ω ? | Go to step 5. | Repair the harness and connector. NOTE: In this case, repair the following: <ul style="list-style-type: none"> • Open circuit in harness between ECM and combination meter connector • Poor contact in coupling connector |
| 5 CHECK POOR CONTACT. Check poor contact in combination meter connector. | Is there poor contact in combination meter connector? | Repair the poor contact in combination meter connector. | Go to step 6. |
| 6 CHECK HARNESS BETWEEN COMBINATION METER AND IGNITION SWITCH CONNECTOR. 1) Turn the ignition switch to ON. 2) Measure the voltage between combination meter connector and chassis ground. <i>Connector & terminal</i> <i>(i12) No. 7 (+) — Chassis ground (-):</i> | Is the voltage more than 10 V? | Replace the combination meter circuit board. <Ref. to IDI-10, Combination Meter Assembly.> | Check the following and repair if necessary. NOTE: <ul style="list-style-type: none"> • Blown out fuse (No. 13) • Open or short circuit in harness between fuse (No. 13) and battery terminal • Poor contact in ignition switch connector |

Malfunction Indicator Light

ENGINE (DIAGNOSTICS)

E: MALFUNCTION INDICATOR LIGHT DOES NOT BLINK AT A CYCLE OF 3 Hz.


DIAGNOSIS:

- The malfunction indicator light circuit is open or shorted.
- Test mode connector circuit is open.

TROUBLE SYMPTOM:

During inspection mode, malfunction indicator light does not blink at a cycle of 3 Hz.

WIRING DIAGRAM:



EN-01606

Malfunction Indicator Light

ENGINE (DIAGNOSTICS)

| Step | Check | Yes | No |
|---|---|---|---|
| 1 CHECK STATUS OF MALFUNCTION INDICATOR LIGHT. 1) Turn the ignition switch to OFF. 2) Disconnect the test mode connector. 3) Turn the ignition switch to ON. (engine OFF) | Does the malfunction indicator light come on? | Go to step 2. | Repair the malfunction indicator light circuit. <Ref. to EN(H4DOTC)(diag)-51, MALFUNCTION INDICATOR LIGHT DOES NOT COME ON., Malfunction Indicator Light.> |
| 2 CHECK HARNESS BETWEEN COMBINATION METER AND ECM CONNECTOR. 1) Turn the ignition switch to OFF. 2) Disconnect the connector from ECM. 3) Turn the ignition switch to ON. | Does the malfunction indicator light come on? | Repair the ground short circuit in harness between combination meter and ECM connector. | Go to step 3. |
| 3 CHECK HARNESS BETWEEN TEST MODE CONNECTOR AND CHASSIS GROUND. 1) Turn the ignition switch to OFF. 2) Disconnect the connector from ECM. 3) Measure the resistance of harness between test mode connector and chassis ground. <i>Connector & terminal (B76) No. 1 — Chassis ground:</i> | Is the resistance less than 1 Ω ? | Go to step 4. | Repair the harness and connector. NOTE: In this case, repair the following: • Open circuit in harness between test mode connector and chassis ground |
| 4 CHECK POOR CONTACT. Check poor contact in ECM connector. | Is there poor contact in ECM connector? | Repair the poor contact in ECM connector. | Go to step 5. |
| 5 CHECK HARNESS BETWEEN ECM AND TEST MODE CONNECTOR. 1) Connect the test mode connector. 2) Measure the resistance of harness between ECM and chassis ground. <i>Connector & terminal (B134) No. 14 — Chassis ground:</i> | Is the resistance less than 1 Ω ? | Go to step 6. | Repair the open circuit in harness between ECM and test mode connector. |
| 6 CHECK POOR CONTACT. Check poor contact in ECM connector. | Is there poor contact in ECM connector? | Repair the poor contact in ECM connector. | Replace the ECM. <Ref. to FU(H4DOTC)-48, Engine Control Module (ECM).> |

Malfunction Indicator Light

ENGINE (DIAGNOSTICS)

F: MALFUNCTION INDICATOR LIGHT REMAINS BLINKING AT A CYCLE OF 3 Hz.


DIAGNOSIS:

Test mode connector circuit is shorted.

TROUBLE SYMPTOM:

Malfunction indicator light blinks at a cycle of 3 Hz when ignition switch is turned to ON.

WIRING DIAGRAM:



EN-01606

| Step | Check | Yes | No | |
|------|---|---|---------------|---|
| 1 | <p>CHECK TEST MODE CONNECTOR.</p> <p>1) Disconnect the test mode connector. 2) Turn the ignition switch to ON.</p> | Does the malfunction indicator light blink? | Go to step 2. | <p>System is in good order.</p> <p>NOTE: Malfunction indicator light blinks at a cycle of 3 Hz when test mode connector is connected.</p> |

Malfunction Indicator Light

ENGINE (DIAGNOSTICS)

| Step | Check | Yes | No |
|--|--|--|---|
| 2 CHECK HARNESS BETWEEN ECM CONNECTOR AND ENGINE GROUNDING TERMINAL. 1) Turn the ignition switch to OFF. 2) Disconnect the connector from ECM. 3) Measure the resistance of harness between ECM connector and chassis ground. Connector & terminal (B134) No. 14 — Chassis ground: | Is the resistance less than 5 Ω ? | Repair the short circuit in harness between ECM and test mode connector. | Replace the ECM. <Ref. to FU(H4DOTC)-48, Engine Control Module (ECM).> |

Diagnostics for Engine Starting Failure

ENGINE (DIAGNOSTICS)

17. Diagnostics for Engine Starting Failure

A: PROCEDURE

| |
|---|
| 1. Inspection of starter motor circuit. <Ref. to EN(H4DOTC)(diag)-59, STARTER MOTOR CIRCUIT, Diagnostics for Engine Starting Failure.> |
| ↓ |
| 2. Inspection of ECM power supply and ground line. <Ref. to EN(H4DOTC)(diag)-62, CONTROL MODULE POWER SUPPLY AND GROUND LINE, Diagnostics for Engine Starting Failure.> |
| ↓ |
| 3. Inspection of ignition control system. <Ref. to EN(H4DOTC)(diag)-65, IGNITION CONTROL SYSTEM, Diagnostics for Engine Starting Failure.> |
| ↓ |
| 4. Inspection of fuel pump circuit. <Ref. to EN(H4DOTC)(diag)-68, FUEL PUMP CIRCUIT, Diagnostics for Engine Starting Failure.> |
| ↓ |
| 5. Inspection of fuel injector circuit. <Ref. to EN(H4DOTC)(diag)-69, FUEL INJECTOR CIRCUIT, Diagnostics for Engine Starting Failure.> |

Diagnostics for Engine Starting Failure

ENGINE (DIAGNOSTICS)

| Step | Check | Yes | No | |
|----------|--|---|---|---|
| 1 | CHECK OPERATION OF STARTER MOTOR. | Does the starter motor operate? | Go to step 2. | Go to step 3. |
| 2 | CHECK DTC. | Is the DTC displayed? <Ref. to EN(H4DOTC)(diag)-38, OPERATION, Read Diagnostic Trouble Code (DTC).> | Using the List of Diagnostic Trouble Code (DTC), check the appropriate DTC. <Ref. to EN(H4DOTC)(diag)-71, List of Diagnostic Trouble Code (DTC).> | Repair the poor contact in ECM connector. |
| 3 | CHECK INPUT SIGNAL FOR STARTER MOTOR. 1) Turn the ignition switch to OFF. 2) Disconnect the connector from starter motor. 3) Turn the ignition switch to START. 4) Measure the power supply voltage between starter motor connector terminal and engine ground. Connector & terminal (B14) No. 1 (+) — Engine ground (-): NOTE: • On AT model, move the select lever to “P” or “N” range. • On MT model, depress the clutch pedal. | Is the voltage more than 10 V? | Go to step 4. | Go to step 5. |
| 4 | CHECK GROUND CIRCUIT OF STARTER MOTOR. 1) Turn the ignition switch to OFF. 2) Disconnect the terminal from starter motor. 3) Measure the resistance of ground cable between ground cable terminal and engine ground. | Is the resistance less than 5 Ω? | Check the starter motor. <Ref. to SC(H4SO)-7, Starter.> | Repair the open circuit of ground cable. |
| 5 | CHECK HARNESS BETWEEN BATTERY AND IGNITION SWITCH CONNECTOR. 1) Disconnect the connector from ignition switch. 2) Measure the power supply voltage between ignition switch connector and chassis ground. Connector & terminal (B72) No. 1 (+) — Chassis ground (-): | Is the voltage more than 10 V? | Go to step 6. | Check the following, repair if necessary. • Fuse is blown out. • Open circuit in harness between ignition switch and battery. |
| 6 | CHECK IGNITION SWITCH. 1) Disconnect the connector from ignition switch. 2) Measure the resistance between ignition switch terminals while turning ignition switch to START. Terminals No. 1 — No. 3: | Is the resistance less than 5 Ω? | Go to step 7. | Replace the ignition switch. |
| 7 | CHECK TRANSMISSION TYPE. | Is the transmission AT? | Go to step 8. | Go to step 10. |

Diagnostics for Engine Starting Failure

ENGINE (DIAGNOSTICS)

| Step | Check | Yes | No |
|--|--|---|---|
| <p>8 CHECK INPUT VOLTAGE OF INHIBITOR SWITCH. 1) Turn ignition switch to OFF. 2) Disconnect the connector from inhibitor switch. 3) Connect the connector to ignition switch. 4) Measure the input voltage between inhibitor switch connector terminal and engine ground while turning ignition switch to START. Connector & terminal (B12) No. 12 (+) — Engine ground (-):</p> | Is the voltage more than 10 V? | Go to step 9. | Repair open or short circuit to ground in harness between inhibitor switch and ignition switch. NOTE: Check security system (if equipped). <Ref. to SL-20, Security System.> |
| <p>9 CHECK INHIBITOR SWITCH. 1) Move the selector lever to "P" or "N" range. 2) Measure the resistance between inhibitor switch terminals. Connector & terminal (T3) No. 11 — No. 12:</p> | Is the resistance less than 1 Ω ? | Repair open or short circuit to ground in harness between inhibitor switch and starter motor. | Replace the inhibitor switch. <Ref. to 4AT-46, Inhibitor Switch.> |
| <p>10 CHECK INPUT VOLTAGE OF STARTER INTERLOCK RELAY. 1) Turn ignition switch to OFF. 2) Disconnect the connector from starter interlock relay. 3) Connect the connector to ignition switch. 4) Measure the input voltage between starter interlock relay connector and chassis ground while turning ignition switch to START. Connector & terminal (B104) No. 27 (+) — Chassis ground (-): (B104) No. 24 (+) — Chassis ground (-):</p> | Is the voltage more than 10 V? | Go to step 11. | Repair open or short circuit to ground in harness between starter interlock relay and ignition switch. NOTE: Check security system (if equipped). <Ref. to SL-20, Security System.> |
| <p>11 CHECK STARTER INTERLOCK RELAY. 1) Connect the battery to starter interlock relay terminals No. 26 and No. 24. 2) Measure the resistance between starter interlock relay terminals. Terminals No. 27 — No. 28:</p> | Is the resistance less than 1 Ω ? | Go to step 12. | Replace the starter interlock relay. |
| <p>12 CHECK GROUND CIRCUIT OF CLUTCH SWITCH. 1) Disconnect the connector from clutch switch. 2) Measure the resistance between clutch switch connector and chassis ground. Connector & terminal (B106) No. 1 — Chassis ground:</p> | Is the resistance less than 5 Ω ? | Go to step 13. | Repair open circuit of ground cable. |
| <p>13 CHECK CLUTCH SWITCH. Measure the resistance between clutch switch terminals while depressing the clutch pedal. Terminals No. 1 — No. 2:</p> | Is the resistance less than 1 Ω ? | Go to step 12. | Replace the clutch switch. <Ref. to CL-28, Clutch Switch.> |
| <p>14 CHECK CLUTCH SWITCH CIRCUIT. 1) Connect the connector to clutch switch. 2) Measure the resistance between starter interlock relay connector and chassis ground while depressing the clutch pedal. Connector & terminal (B104) No. 26 — Chassis ground:</p> | Is the resistance less than 1 Ω ? | Repair short circuit to ground in harness between starter interlock relay and starter motor. | Repair open circuit in harness between starter interlock relay and clutch switch. |

Diagnostics for Engine Starting Failure



ENGINE (DIAGNOSTICS)

C: CONTROL MODULE POWER SUPPLY AND GROUND LINE

CAUTION:

After repair or replacement of faulty parts, conduct Clear Memory Mode <Ref. to EN(H4DOTC)(diag)-46, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(H4DOTC)(diag)-39, PROCEDURE, Inspection Mode.>.

WIRING DIAGRAM:



EN-01608

Diagnostics for Engine Starting Failure

ENGINE (DIAGNOSTICS)

| Step | Check | Yes | No |
|---|--|---------------|--|
| <p>1 CHECK MAIN RELAY. 1) Turn the ignition switch to OFF. 2) Remove the main relay. 3) Connect the battery to main relay terminals No. 1 and No. 2. 4) Measure the resistance between main relay terminals.</p> <p>Terminals No. 3 — No. 5: No. 4 — No. 6:</p> | Is the resistance less than 10 Ω ? | Go to step 2. | Replace the main relay. |
| <p>2 CHECK GROUND CIRCUIT OF ECM. 1) Disconnect the connector from ECM. 2) Measure the resistance of harness between ECM and chassis ground.</p> <p>Connector & terminal (B134) No. 7 — Chassis ground: (B134) No. 15 — Chassis ground: (B134) No. 22 — Chassis ground: (B136) No. 1 — Chassis ground: (B137) No. 8 — Chassis ground: (B137) No. 17 — Chassis ground: (B137) No. 18 — Chassis ground: (B84) No. 8 — Chassis ground: (B84) No. 9 — Chassis ground:</p> | Is the resistance less than 5 Ω ? | Go to step 3. | Repair the open circuit in harness between ECM connector and engine grounding terminal. |
| <p>3 CHECK INPUT VOLTAGE OF ECM. Measure the voltage between ECM connector and chassis ground.</p> <p>Connector & terminal (B84) No. 10 (+) — Chassis ground (-): (B134) No. 5 (+) — Chassis ground (-):</p> | Is the voltage more than 10 V? | Go to step 4. | Repair the open or ground short circuit of power supply circuit. |
| <p>4 CHECK HARNESS BETWEEN ECM AND MAIN RELAY CONNECTOR. 1) Turn the ignition switch to OFF. 2) Measure the resistance between ECM and chassis ground.</p> <p>Connector & terminal (B134) No. 6 — Chassis ground:</p> | Is the resistance more than 1 M Ω ? | Go to step 5. | Repair the ground short circuit in harness between ECM connector and main relay connector, and then replace ECM. |
| <p>5 CHECK OUTPUT VOLTAGE FROM ECM. 1) Connect the connector to ECM. 2) Turn the ignition switch to ON. 3) Measure the voltage between ECM connector and chassis ground.</p> <p>Connector & terminal (B134) No. 6 (+) — Chassis ground (-):</p> | Is the voltage more than 10 V? | Go to step 6. | Replace the ECM. <Ref. to FU(H4DOTC)-48, Engine Control Module (ECM).> |
| <p>6 CHECK INPUT VOLTAGE OF MAIN RELAY. Check the voltage between main relay connector and chassis ground.</p> <p>Connector & terminal (B47) No. 2 (+) — Chassis ground (-):</p> | Is the voltage more than 10 V? | Go to step 7. | Repair the open circuit in harness between ECM connector and main relay connector. |
| <p>7 CHECK GROUND CIRCUIT OF MAIN RELAY. 1) Turn the ignition switch to OFF. 2) Measure the resistance between main relay connector and chassis ground.</p> <p>Connector & terminal (B47) No. 1 — Chassis ground:</p> | Is the resistance less than 5 Ω ? | Go to step 8. | Repair the open circuit between main relay and chassis ground. |

Diagnostics for Engine Starting Failure

ENGINE (DIAGNOSTICS)


| Step | Check | Yes | No |
|--|--------------------------------|--|--|
| 8 CHECK INPUT VOLTAGE OF MAIN RELAY. Measure the voltage between main relay connector and chassis ground. <i>Connector & terminal</i> <i>(B47) No. 5 (+) — Chassis ground (-):</i> <i>(B47) No. 6 (+) — Chassis ground (-):</i> | Is the voltage more than 10 V? | Go to step 9 . | Repair the open or ground short circuit in harness of power supply circuit. |
| 9 CHECK INPUT VOLTAGE OF ECM. 1) Connect the main relay connector. 2) Turn the ignition switch to ON. 3) Measure the voltage between ECM connector and chassis ground. <i>Connector & terminal</i> <i>(B84) No. 2 (+) — Chassis ground (-):</i> <i>(B84) No. 3 (+) — Chassis ground (-):</i> | Is the voltage more than 10 V? | Check the ignition control system. <Ref. to EN(H4DOTC)(diag)-65, IGNITION CONTROL SYSTEM, Diagnostics for Engine Starting Failure.> | Repair the open or ground short circuit in harness between ECM connector and main relay connector. |

D: IGNITION CONTROL SYSTEM

CAUTION:

After repair or replacement of faulty parts, conduct Clear Memory Mode <Ref. to EN(H4DOTC)(diag)-46, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(H4DOTC)(diag)-39, PROCEDURE, Inspection Mode.>.

WIRING DIAGRAM:



Diagnostics for Engine Starting Failure

ENGINE (DIAGNOSTICS)

| Step | Check | Yes | No |
|--|--|--|--|
| 1 CHECK SPARK PLUG CONDITION. 1) Remove the spark plug. <Ref. to IG(H4DOTC)-5, INSTALLATION, Spark Plug.> 2) Check the spark plug condition. <Ref. to IG(H4DOTC)-5, INSPECTION, Spark Plug.> | Is the spark plug's status OK? | Go to step 2. | Replace the spark plug. |
| 2 CHECK IGNITION SYSTEM FOR SPARKS. 1) Connect the spark plug to ignition coil. 2) Release the fuel pressure. <Ref. to FU(H4DOTC)-52, RELEASING OF FUEL PRESSURE, PROCEDURE, Fuel.> 3) Contact the spark plug's thread portion on engine. 4) While opening the throttle valve fully, crank engine to check that spark occurs at each cylinder. | Does spark occur at each cylinder? | Check the fuel pump system. <Ref. to EN(H4DOTC)(diag)-68, FUEL PUMP CIRCUIT, Diagnostics for Engine Starting Failure.> | Go to step 3. |
| 3 CHECK POWER SUPPLY CIRCUIT FOR IGNITION COIL & IGNITOR ASSEMBLY. 1) Turn the ignition switch to OFF. 2) Disconnect the connector from ignition coil & ignitor assembly. 3) Turn the ignition switch to ON. 4) Measure the power supply voltage between ignition coil & ignitor assembly connector and engine ground. <i>Connector & terminal</i> (E31) No. 3 (+) — Engine ground (-): (E32) No. 3 (+) — Engine ground (-): (E33) No. 3 (+) — Engine ground (-): (E34) No. 3 (+) — Engine ground (-): | Is the voltage more than 10 V? | Go to step 4. | Repair the harness and connector. NOTE: In this case, repair the following: <ul style="list-style-type: none"> • Open circuit in harness between ignition coil & ignitor assembly, and ignition switch connector • Poor contact in coupling connectors |
| 4 CHECK HARNESS OF IGNITION COIL & IGNITOR ASSEMBLY GROUND CIRCUIT. 1) Turn the ignition switch to OFF. 2) Measure the resistance between ignition coil & ignitor assembly connector and engine ground. <i>Connector & terminal</i> (E31) No. 2 — Engine ground: (E32) No. 2 — Engine ground: (E33) No. 2 — Engine ground: (E34) No. 2 — Engine ground: | Is the resistance less than 5 Ω ? | Go to step 5. | Repair the harness and connector. NOTE: In this case, repair the following: <ul style="list-style-type: none"> • Open circuit in harness between ignition coil & ignitor assembly connector and engine grounding terminal |
| 5 CHECK HARNESS BETWEEN ECM AND IGNITION COIL & IGNITOR ASSEMBLY CONNECTOR. 1) Turn the ignition switch to OFF. 2) Disconnect the connector from ECM. 3) Disconnect the connector from ignition coil & ignitor assembly. 4) Measure the resistance of harness between ECM and ignition coil & ignitor assembly connector. <i>Connector & terminal</i> (B137) No. 21 — (E34) No. 1: (B137) No. 22 — (E33) No. 1: (B137) No. 23 — (E32) No. 1: (B137) No. 24 — (E31) No. 1: | Is the resistance less than 1 Ω ? | Go to step 6. | Repair the harness and connector. NOTE: In this case, repair the following: <ul style="list-style-type: none"> • Open circuit in harness between ECM and ignition coil & ignitor assembly connector • Poor contact in coupling connector |

Diagnostics for Engine Starting Failure

ENGINE (DIAGNOSTICS)

| Step | Check | Yes | No |
|---|--|--|---|
| <p>6</p> <p>CHECK HARNESS BETWEEN ECM AND IGNITION COIL & IGNITOR ASSEMBLY CONNECTOR. Measure the resistance of harness between ECM and engine ground. <i>Connector & terminal:</i> (B137) No. 21 — Engine ground: (B137) No. 22 — Engine ground: (B137) No. 23 — Engine ground: (B137) No. 24 — Engine ground:</p> | <p>Is the resistance more than 1 MΩ?</p> | <p>Go to step 7.</p> | <p>Repair the ground short circuit in harness between ECM and ignition coil & ignitor assembly connector.</p> |
| <p>7</p> <p>CHECK POOR CONTACT. Check poor contact in ECM connector.</p> | <p>Is there poor contact in ECM connector?</p> | <p>Repair the poor contact in ECM connector.</p> | <p>Replace the ignition coil and ignitor assembly.</p> |

Diagnostics for Engine Starting Failure


ENGINE (DIAGNOSTICS)

E: FUEL PUMP CIRCUIT

CAUTION:

After repair or replacement of faulty parts, conduct Clear Memory Mode <Ref. to EN(H4DOTC)(diag)-46, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(H4DOTC)(diag)-39, PROCEDURE, Inspection Mode.>.

WIRING DIAGRAM:



EN-01609








| Step | Check | Yes | No |
|--|--|---|--|
| <p>1 CHECK OPERATING SOUND OF FUEL PUMP. Make sure that the fuel pump is in operation for 2 seconds when turning ignition switch to ON. NOTE: Fuel pump operation check can also be executed using the Subaru Select Monitor. For the procedure, refer to "Compulsory Valve Operation Check Mode". <Ref. to EN(H4DOTC)(diag)-47, Compulsory Valve Operation Check Mode.></p> | <p>Does the fuel pump produce "operating" sound?</p> | <p>Check the fuel injector circuit. <Ref. to EN(H4DOTC)(diag)-69, FUEL INJECTOR CIRCUIT, Diagnostics for Engine Starting Failure.></p> | <p>Display the DTC. <Ref. to EN(H4DOTC)(diag)-38, OPERATION, Read Diagnostic Trouble Code (DTC).></p> |

F: FUEL INJECTOR CIRCUIT

CAUTION:

After repair or replacement of faulty parts, conduct Clear Memory Mode <Ref. to EN(H4DOTC)(diag)-46, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(H4DOTC)(diag)-39, PROCEDURE, Inspection Mode.>.

WIRING DIAGRAM:



Diagnostics for Engine Starting Failure

ENGINE (DIAGNOSTICS)

| Step | Check | Yes | No |
|--|--|---|--|
| 1 CHECK OPERATION OF EACH FUEL INJECTOR. While cranking the engine, check that each fuel injector emits "operating" sound. Use a sound scope or attach a screwdriver to injector for this check. | Does the fuel injector emit "operating" sound? | Check the fuel pressure. <Ref. to ME(H4DOTC)-27, INSPECTION, Fuel Pressure.> | Go to step 2. |
| 2 CHECK POWER SUPPLY TO EACH FUEL INJECTOR. 1) Turn the ignition switch to OFF. 2) Disconnect the connector from fuel injector. 3) Turn the ignition switch to ON. 4) Measure the power supply voltage between the fuel injector terminal and engine ground. Connector & terminal <i>#1 (E5) No. 2 (+) — Engine ground (-):</i> <i>#2 (E16) No. 2 (+) — Engine ground (-):</i> <i>#3 (E6) No. 2 (+) — Engine ground (-):</i> <i>#4 (E17) No. 2 (+) — Engine ground (-):</i> | Is the voltage more than 10 V? | Go to step 3. | Repair the harness and connector. NOTE: In this case, repair the following: • Open circuit in harness between main relay and fuel injector connector • Poor contact in main relay connector • Poor contact in coupling connector • Poor contact in fuel injector connector |
| 3 CHECK HARNESS BETWEEN ECM AND FUEL INJECTOR CONNECTOR. 1) Disconnect the connector from ECM. 2) Measure the resistance of harness between ECM and fuel injector connector. Connector & terminal <i>(B84) No. 1 — (E5) No. 1:</i> <i>(B137) No. 6 — (E16) No. 1:</i> <i>(B137) No. 5 — (E6) No. 1:</i> <i>(B137) No. 4 — (E6) No. 1:</i> | Is the resistance less than 1 Ω ? | Go to step 4. | Repair the harness and connector. NOTE: In this case, repair the following: • Open circuit in harness between ECM and fuel injector connector • Poor contact in coupling connector |
| 4 CHECK HARNESS BETWEEN ECM AND FUEL INJECTOR CONNECTOR. Measure the resistance of harness between ECM and fuel injector connector. Connector & terminal <i>(B84) No. 1 — Chassis ground:</i> <i>(B137) No. 6 — Chassis ground:</i> <i>(B137) No. 5 — Chassis ground:</i> <i>(B137) No. 4 — Chassis ground:</i> | Is the resistance less than 1 Ω ? | Repair the ground short circuit in harness between ECM and fuel injector connector. | Go to step 5. |
| 5 CHECK EACH FUEL INJECTOR. 1) Turn the ignition switch to OFF. 2) Measure the resistance between each fuel injector terminals. Terminals <i>No. 1 — No. 2:</i> | Is the resistance 5 — 20 Ω ? | Go to step 6. | Replace the faulty fuel injector. |
| 6 CHECK POOR CONTACT. Check poor contact in ECM connector. | Is there poor contact in ECM connector? | Repair the poor contact in ECM connector. | Inspection using "General Diagnostic Table". <Ref. to EN(H4DOTC)(diag)-340, INSPECTION, General Diagnostic Table.> |

List of Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

18. List of Diagnostic Trouble Code (DTC)

A: LIST

| DTC | Item | Index |
|-------|--|---|
| P0030 | HO2S Heater Control Circuit (Bank 1 Sensor 1) | <Ref. to EN(H4DOTC)(diag)-78, DTC P0030 HO2S HEATER CONTROL CIRCUIT (BANK 1 SENSOR 1), Diagnostic Procedure with Diagnostic Trouble Code (DTC).> |
| P0031 | HO2S Heater Control Circuit Low (Bank 1 Sensor 1) | <Ref. to EN(H4DOTC)(diag)-80, DTC P0031 HO2S HEATER CONTROL CIRCUIT LOW (BANK 1 SENSOR 1), Diagnostic Procedure with Diagnostic Trouble Code (DTC).> |
| P0032 | HO2S Heater Control Circuit High (Bank 1 Sensor 1) | <Ref. to EN(H4DOTC)(diag)-83, DTC P0032 HO2S HEATER CONTROL CIRCUIT HIGH (BANK 1 SENSOR 1), Diagnostic Procedure with Diagnostic Trouble Code (DTC).> |
| P0037 | HO2S Heater Control Circuit Low (Bank 1 Sensor 2) | <Ref. to EN(H4DOTC)(diag)-85, DTC P0037 HO2S HEATER CONTROL CIRCUIT LOW (BANK 1 SENSOR 2), Diagnostic Procedure with Diagnostic Trouble Code (DTC).> |
| P0038 | HO2S Heater Control Circuit High (Bank 1 Sensor 2) | <Ref. to EN(H4DOTC)(diag)-88, DTC P0038 HO2S HEATER CONTROL CIRCUIT HIGH (BANK 1 SENSOR 2), Diagnostic Procedure with Diagnostic Trouble Code (DTC).> |
| P0068 | Manifold Absolute Pressure/Barometric Pressure Circuit Range/Performance | <Ref. to EN(H4DOTC)(diag)-90, DTC P0068 MANIFOLD ABSOLUTE PRESSURE/BAROMETRIC PRESSURE CIRCUIT RANGE/PERFORMANCE, Diagnostic Procedure with Diagnostic Trouble Code (DTC).> |
| P0101 | Mass or Volume Air Flow Circuit Range/Performance | <Ref. to EN(H4DOTC)(diag)-92, DTC P0101 MASS OR VOLUME AIR FLOW CIRCUIT RANGE/PERFORMANCE, Diagnostic Procedure with Diagnostic Trouble Code (DTC).> |
| P0102 | Mass or Volume Air Flow Circuit Low Input | <Ref. to EN(H4DOTC)(diag)-94, DTC P0102 MASS OR VOLUME AIR FLOW CIRCUIT LOW INPUT, Diagnostic Procedure with Diagnostic Trouble Code (DTC).> |
| P0103 | Mass or Volume Air Flow Circuit High Input | <Ref. to EN(H4DOTC)(diag)-97, DTC P0103 MASS OR VOLUME AIR FLOW CIRCUIT HIGH INPUT, Diagnostic Procedure with Diagnostic Trouble Code (DTC).> |
| P0107 | Manifold Absolute Pressure/Barometric Pressure Circuit Low Input | <Ref. to EN(H4DOTC)(diag)-99, DTC P0107 MANIFOLD ABSOLUTE PRESSURE/BAROMETRIC PRESSURE CIRCUIT LOW INPUT, Diagnostic Procedure with Diagnostic Trouble Code (DTC).> |
| P0108 | Manifold Absolute Pressure/Barometric Pressure Circuit High Input | <Ref. to EN(H4DOTC)(diag)-101, DTC P0108 MANIFOLD ABSOLUTE PRESSURE/BAROMETRIC PRESSURE CIRCUIT HIGH INPUT, Diagnostic Procedure with Diagnostic Trouble Code (DTC).> |
| P0111 | Intake Air Temperature Circuit Range/Performance | <Ref. to EN(H4DOTC)(diag)-103, DTC P0111 INTAKE AIR TEMPERATURE CIRCUIT RANGE/PERFORMANCE, Diagnostic Procedure with Diagnostic Trouble Code (DTC).> |
| P0112 | Intake Air Temperature Circuit Low Input | <Ref. to EN(H4DOTC)(diag)-105, DTC P0112 INTAKE AIR TEMPERATURE CIRCUIT LOW INPUT, Diagnostic Procedure with Diagnostic Trouble Code (DTC).> |
| P0113 | Intake Air Temperature Circuit High Input | <Ref. to EN(H4DOTC)(diag)-107, DTC P0113 INTAKE AIR TEMPERATURE CIRCUIT HIGH INPUT, Diagnostic Procedure with Diagnostic Trouble Code (DTC).> |
| P0117 | Engine Coolant Temperature Circuit Low Input | <Ref. to EN(H4DOTC)(diag)-110, DTC P0117 ENGINE COOLANT TEMPERATURE CIRCUIT LOW INPUT, Diagnostic Procedure with Diagnostic Trouble Code (DTC).> |
| P0118 | Engine Coolant Temperature Circuit High Input | <Ref. to EN(H4DOTC)(diag)-112, DTC P0118 ENGINE COOLANT TEMPERATURE CIRCUIT HIGH INPUT, Diagnostic Procedure with Diagnostic Trouble Code (DTC).> |
| P0121 | Throttle/Pedal Position Sensor/Switch "A" Circuit Range/Performance | <Ref. to EN(H4DOTC)(diag)-115, DTC P0121 THROTTLE/PEDAL POSITION SENSOR/SWITCH "A" CIRCUIT RANGE/PERFORMANCE, Diagnostic Procedure with Diagnostic Trouble Code (DTC).> |
| P0122 | Throttle/Pedal Position Sensor/Switch "A" Circuit Low Input | <Ref. to EN(H4DOTC)(diag)-117, DTC P0122 THROTTLE/PEDAL POSITION SENSOR/SWITCH "A" CIRCUIT LOW INPUT, Diagnostic Procedure with Diagnostic Trouble Code (DTC).> |

List of Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

| DTC | Item | Index |
|-------|--|--|
| P0123 | Throttle/Pedal Position Sensor/Switch "A" Circuit High Input | <Ref. to EN(H4DOTC)(diag)-120, DTC P0123 THROTTLE/PEDAL POSITION SENSOR/SWITCH "A" CIRCUIT HIGH INPUT, Diagnostic Procedure with Diagnostic Trouble Code (DTC).> |
| P0125 | Insufficient Coolant Temperature for Closed Loop Fuel Control | <Ref. to EN(H4DOTC)(diag)-122, DTC P0125 INSUFFICIENT COOLANT TEMPERATURE FOR CLOSED LOOP FUEL CONTROL, Diagnostic Procedure with Diagnostic Trouble Code (DTC).> |
| P0128 | Coolant Thermostat (Coolant Temperature Below Thermostat Regulating Temperature) | <Ref. to EN(H4DOTC)(diag)-124, DTC P0128 COOLANT THERMOSTAT (COOLANT TEMPERATURE BELOW THERMOSTAT REGULATING TEMPERATURE), Diagnostic Procedure with Diagnostic Trouble Code (DTC).> |
| P0129 | Atmospheric Pressure Sensor Circuit Range/Performance | <Ref. to EN(H4DOTC)(diag)-125, DTC P0129 ATMOSPHERIC PRESSURE SENSOR CIRCUIT RANGE/PERFORMANCE, Diagnostic Procedure with Diagnostic Trouble Code (DTC).> |
| P0130 | O ₂ Sensor Circuit (Bank 1 Sensor 1) | <Ref. to EN(H4DOTC)(diag)-126, DTC P0130 O ₂ SENSOR CIRCUIT (BANK 1 SENSOR 1), Diagnostic Procedure with Diagnostic Trouble Code (DTC).> |
| P0133 | O ₂ Sensor Circuit Slow Response (Bank 1 Sensor 1) | <Ref. to EN(H4DOTC)(diag)-128, DTC P0133 O ₂ SENSOR CIRCUIT SLOW RESPONSE (BANK 1 SENSOR 1), Diagnostic Procedure with Diagnostic Trouble Code (DTC).> |
| P0134 | O ₂ Sensor Circuit No Activity Detected (Bank 1 Sensor 1) | <Ref. to EN(H4DOTC)(diag)-129, DTC P0134 O ₂ SENSOR CIRCUIT NO ACTIVITY DETECTED (BANK 1 SENSOR 1), Diagnostic Procedure with Diagnostic Trouble Code (DTC).> |
| P0137 | O ₂ Sensor Circuit Low Voltage (Bank 1 Sensor 2) | <Ref. to EN(H4DOTC)(diag)-130, DTC P0137 O ₂ SENSOR CIRCUIT LOW VOLTAGE (BANK 1 SENSOR 2), Diagnostic Procedure with Diagnostic Trouble Code (DTC).> |
| P0138 | O ₂ Sensor Circuit High Voltage (Bank 1 Sensor 2) | <Ref. to EN(H4DOTC)(diag)-133, DTC P0138 O ₂ SENSOR CIRCUIT HIGH VOLTAGE (BANK 1 SENSOR 2), Diagnostic Procedure with Diagnostic Trouble Code (DTC).> |
| P0139 | O ₂ Sensor Circuit Slow Response (Bank 1 Sensor 2) | <Ref. to EN(H4DOTC)(diag)-136, DTC P0139 O ₂ SENSOR CIRCUIT SLOW RESPONSE (BANK 1 SENSOR 2), Diagnostic Procedure with Diagnostic Trouble Code (DTC).> |
| P0171 | System too Lean (Bank 1) | <Ref. to EN(H4DOTC)(diag)-137, DTC P0171 SYSTEM TOO LEAN (BANK 1), Diagnostic Procedure with Diagnostic Trouble Code (DTC).> |
| P0172 | System too Rich (Bank 1) | <Ref. to EN(H4DOTC)(diag)-138, DTC P0172 SYSTEM TOO RICH (BANK 1), Diagnostic Procedure with Diagnostic Trouble Code (DTC).> |
| P0181 | Fuel Temperature Sensor "A" Circuit Range/Performance | <Ref. to EN(H4DOTC)(diag)-141, DTC P0181 FUEL TEMPERATURE SENSOR "A" CIRCUIT RANGE/PERFORMANCE, Diagnostic Procedure with Diagnostic Trouble Code (DTC).> |
| P0182 | Fuel Temperature Sensor "A" Circuit Low Input | <Ref. to EN(H4DOTC)(diag)-143, DTC P0182 FUEL TEMPERATURE SENSOR "A" CIRCUIT LOW INPUT, Diagnostic Procedure with Diagnostic Trouble Code (DTC).> |
| P0183 | Fuel Temperature Sensor "A" Circuit High Input | <Ref. to EN(H4DOTC)(diag)-145, DTC P0183 FUEL TEMPERATURE SENSOR "A" CIRCUIT HIGH INPUT, Diagnostic Procedure with Diagnostic Trouble Code (DTC).> |
| P0230 | Fuel Pump Primary Circuit | <Ref. to EN(H4DOTC)(diag)-148, DTC P0230 FUEL PUMP PRIMARY CIRCUIT, Diagnostic Procedure with Diagnostic Trouble Code (DTC).> |
| P0244 | Turbo/Super Charger Wastegate Solenoid "A" Range/Performance | <Ref. to EN(H4DOTC)(diag)-151, DTC P0244 TURBO/SUPER CHARGER WASTEGATE SOLENOID "A" RANGE/PERFORMANCE, Diagnostic Procedure with Diagnostic Trouble Code (DTC).> |
| P0245 | Turbo/Super Charger Wastegate Solenoid "A" Low | <Ref. to EN(H4DOTC)(diag)-153, DTC P0245 TURBO/SUPER CHARGER WASTEGATE SOLENOID "A" LOW, Diagnostic Procedure with Diagnostic Trouble Code (DTC).> |
| P0246 | Turbo/Super Charger Wastegate Solenoid "A" High | <Ref. to EN(H4DOTC)(diag)-155, DTC P0246 TURBO/SUPER CHARGER WASTEGATE SOLENOID "A" HIGH, Diagnostic Procedure with Diagnostic Trouble Code (DTC).> |
| P0301 | Cylinder 1 misfire detected | <Ref. to EN(H4DOTC)(diag)-157, DTC P0301 CYLINDER 1 MISFIRE DETECTED, Diagnostic Procedure with Diagnostic Trouble Code (DTC).> |

List of Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

| DTC | Item | Index |
|-------|--|--|
| P0302 | Cylinder 2 misfire detected | <Ref. to EN(H4DOTC)(diag)-157, DTC P0302 CYLINDER 2 MISFIRE DETECTED, Diagnostic Procedure with Diagnostic Trouble Code (DTC).> |
| P0303 | Cylinder 3 misfire detected | <Ref. to EN(H4DOTC)(diag)-157, DTC P0303 CYLINDER 3 MISFIRE DETECTED, Diagnostic Procedure with Diagnostic Trouble Code (DTC).> |
| P0304 | Cylinder 4 misfire detected | <Ref. to EN(H4DOTC)(diag)-157, DTC P0304 CYLINDER 4 MISFIRE DETECTED, Diagnostic Procedure with Diagnostic Trouble Code (DTC).> |
| P0327 | Knock Sensor 1 Circuit Low Input (Bank 1 or Single Sensor) | <Ref. to EN(H4DOTC)(diag)-162, DTC P0327 KNOCK SENSOR 1 CIRCUIT LOW INPUT (BANK 1 OR SINGLE SENSOR), Diagnostic Procedure with Diagnostic Trouble Code (DTC).> |
| P0328 | Knock Sensor 1 Circuit High Input (Bank 1 or Single Sensor) | <Ref. to EN(H4DOTC)(diag)-164, DTC P0328 KNOCK SENSOR 1 CIRCUIT HIGH INPUT (BANK 1 OR SINGLE SENSOR), Diagnostic Procedure with Diagnostic Trouble Code (DTC).> |
| P0335 | Crankshaft Position Sensor "A" Circuit | <Ref. to EN(H4DOTC)(diag)-166, DTC P0335 CRANKSHAFT POSITION SENSOR "A" CIRCUIT, Diagnostic Procedure with Diagnostic Trouble Code (DTC).> |
| P0336 | Crankshaft Position Sensor "A" Circuit Range/Performance | <Ref. to EN(H4DOTC)(diag)-168, DTC P0336 CRANKSHAFT POSITION SENSOR "A" CIRCUIT RANGE/PERFORMANCE, Diagnostic Procedure with Diagnostic Trouble Code (DTC).> |
| P0340 | Camshaft Position Sensor "A" Circuit (Bank 1 or Single Sensor) | <Ref. to EN(H4DOTC)(diag)-170, DTC P0340 CAMSHAFT POSITION SENSOR "A" CIRCUIT (BANK 1 OR SINGLE SENSOR), Diagnostic Procedure with Diagnostic Trouble Code (DTC).> |
| P0341 | Camshaft Position Sensor "A" Circuit Range/Performance (Bank 1 or Single Sensor) | <Ref. to EN(H4DOTC)(diag)-172, DTC P0341 CAMSHAFT POSITION SENSOR "A" CIRCUIT RANGE/PERFORMANCE (BANK 1 OR SINGLE SENSOR), Diagnostic Procedure with Diagnostic Trouble Code (DTC).> |
| P0420 | Catalyst System Efficiency Below Threshold (Bank 1) | <Ref. to EN(H4DOTC)(diag)-175, DTC P0420 CATALYST SYSTEM EFFICIENCY BELOW THRESHOLD (BANK 1), Diagnostic Procedure with Diagnostic Trouble Code (DTC).> |
| P0442 | Evaporative Emission Control System Leak Detected (small leak) | <Ref. to EN(H4DOTC)(diag)-177, DTC P0442 EVAPORATIVE EMISSION CONTROL SYSTEM LEAK DETECTED (SMALL LEAK), Diagnostic Procedure with Diagnostic Trouble Code (DTC).> |
| P0447 | Evaporative Emission Control System Vent Control Circuit Open | <Ref. to EN(H4DOTC)(diag)-181, DTC P0447 EVAPORATIVE EMISSION CONTROL SYSTEM VENT CONTROL CIRCUIT OPEN, Diagnostic Procedure with Diagnostic Trouble Code (DTC).> |
| P0448 | Evaporative Emission Control System Vent Control Circuit Shorted | <Ref. to EN(H4DOTC)(diag)-184, DTC P0448 EVAPORATIVE EMISSION CONTROL SYSTEM VENT CONTROL CIRCUIT SHORTED, Diagnostic Procedure with Diagnostic Trouble Code (DTC).> |
| P0451 | Evaporative Emission Control System Pressure Sensor Range/Performance | <Ref. to EN(H4DOTC)(diag)-186, DTC P0451 EVAPORATIVE EMISSION CONTROL SYSTEM PRESSURE SENSOR RANGE/PERFORMANCE, Diagnostic Procedure with Diagnostic Trouble Code (DTC).> |
| P0452 | Evaporative Emission Control System Pressure Sensor Low Input | <Ref. to EN(H4DOTC)(diag)-188, DTC P0452 EVAPORATIVE EMISSION CONTROL SYSTEM PRESSURE SENSOR LOW INPUT, Diagnostic Procedure with Diagnostic Trouble Code (DTC).> |
| P0453 | Evaporative Emission Control System Pressure Sensor High Input | <Ref. to EN(H4DOTC)(diag)-191, DTC P0453 EVAPORATIVE EMISSION CONTROL SYSTEM PRESSURE SENSOR HIGH INPUT, Diagnostic Procedure with Diagnostic Trouble Code (DTC).> |
| P0456 | Evaporative Emission Control System Leak Detected (very small leak) | <Ref. to EN(H4DOTC)(diag)-194, DTC P0456 EVAPORATIVE EMISSION CONTROL SYSTEM LEAK DETECTED (VERY SMALL LEAK), Diagnostic Procedure with Diagnostic Trouble Code (DTC).> |
| P0457 | Evaporative Emission Control System Leak Detected (fuel cap loose/off) | <Ref. to EN(H4DOTC)(diag)-198, DTC P0457 EVAPORATIVE EMISSION CONTROL SYSTEM LEAK DETECTED (FUEL CAP LOOSE/OFF), Diagnostic Procedure with Diagnostic Trouble Code (DTC).> |
| P0458 | Evaporative Emission Control System Purge Control Valve Circuit Low | <Ref. to EN(H4DOTC)(diag)-202, DTC P0458 EVAPORATIVE EMISSION CONTROL SYSTEM PURGE CONTROL VALVE CIRCUIT LOW, Diagnostic Procedure with Diagnostic Trouble Code (DTC).> |
| P0459 | Evaporative Emission Control System Purge Control Valve Circuit High | <Ref. to EN(H4DOTC)(diag)-204, DTC P0459 EVAPORATIVE EMISSION CONTROL SYSTEM PURGE CONTROL VALVE CIRCUIT HIGH, Diagnostic Procedure with Diagnostic Trouble Code (DTC).> |

List of Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

| DTC | Item | Index |
|-------|--|--|
| P0461 | Fuel Level Sensor Circuit Range/Performance | <Ref. to EN(H4DOTC)(diag)-206, DTC P0461 FUEL LEVEL SENSOR CIRCUIT RANGE/PERFORMANCE, Diagnostic Procedure with Diagnostic Trouble Code (DTC).> |
| P0462 | Fuel Level Sensor Circuit Low Input | <Ref. to EN(H4DOTC)(diag)-208, DTC P0462 FUEL LEVEL SENSOR CIRCUIT LOW INPUT, Diagnostic Procedure with Diagnostic Trouble Code (DTC).> |
| P0463 | Fuel Level Sensor Circuit High Input | <Ref. to EN(H4DOTC)(diag)-212, DTC P0463 FUEL LEVEL SENSOR CIRCUIT HIGH INPUT, Diagnostic Procedure with Diagnostic Trouble Code (DTC).> |
| P0464 | Fuel Level Sensor Circuit Intermittent | <Ref. to EN(H4DOTC)(diag)-215, DTC P0464 FUEL LEVEL SENSOR CIRCUIT INTERMITTENT, Diagnostic Procedure with Diagnostic Trouble Code (DTC).> |
| P0483 | Cooling Fan Rationality Check | <Ref. to EN(H4DOTC)(diag)-218, DTC P0483 COOLING FAN RATIONALITY CHECK, Diagnostic Procedure with Diagnostic Trouble Code (DTC).> |
| P0502 | Vehicle Speed Sensor Circuit Low Input | <Ref. to EN(H4DOTC)(diag)-221, DTC P0502 VEHICLE SPEED SENSOR CIRCUIT LOW INPUT, Diagnostic Procedure with Diagnostic Trouble Code (DTC).> |
| P0503 | Vehicle Speed Sensor Intermittent/Erratic/High | <Ref. to EN(H4DOTC)(diag)-223, DTC P0503 VEHICLE SPEED SENSOR INTERMITTENT/ERRATIC/HIGH, Diagnostic Procedure with Diagnostic Trouble Code (DTC).> |
| P0506 | Idle Control System RPM Lower Than Expected | <Ref. to EN(H4DOTC)(diag)-225, DTC P0506 IDLE CONTROL SYSTEM RPM LOWER THAN EXPECTED, Diagnostic Procedure with Diagnostic Trouble Code (DTC).> |
| P0507 | Idle Control System RPM Higher Than Expected | <Ref. to EN(H4DOTC)(diag)-227, DTC P0507 IDLE CONTROL SYSTEM RPM HIGHER THAN EXPECTED, Diagnostic Procedure with Diagnostic Trouble Code (DTC).> |
| P0508 | Idle Control System Circuit Low | <Ref. to EN(H4DOTC)(diag)-229, DTC P0508 IDLE CONTROL SYSTEM CIRCUIT LOW, Diagnostic Procedure with Diagnostic Trouble Code (DTC).> |
| P0509 | Idle Control System Circuit High | <Ref. to EN(H4DOTC)(diag)-231, DTC P0509 IDLE CONTROL SYSTEM CIRCUIT HIGH, Diagnostic Procedure with Diagnostic Trouble Code (DTC).> |
| P0512 | Starter Request Circuit | <Ref. to EN(H4DOTC)(diag)-232, DTC P0512 STARTER REQUEST CIRCUIT, Diagnostic Procedure with Diagnostic Trouble Code (DTC).> |
| P0519 | Idle Control System Malfunction (Fail-Safe) | <Ref. to EN(H4DOTC)(diag)-235, DTC P0519 IDLE CONTROL SYSTEM MALFUNCTION (FAIL-SAFE), Diagnostic Procedure with Diagnostic Trouble Code (DTC).> |
| P0545 | Exhaust Gas Temperature Sensor Circuit Low-Bank 1 | <Ref. to EN(H4DOTC)(diag)-237, DTC P0545 EXHAUST GAS TEMPERATURE SENSOR CIRCUIT LOW-BANK 1, Diagnostic Procedure with Diagnostic Trouble Code (DTC).> |
| P0546 | Exhaust Gas Temperature Sensor Circuit High-Bank 1 | <Ref. to EN(H4DOTC)(diag)-239, DTC P0546 EXHAUST GAS TEMPERATURE SENSOR CIRCUIT HIGH-BANK 1, Diagnostic Procedure with Diagnostic Trouble Code (DTC).> |
| P0565 | Cruise Control On Signal | <Ref. to EN(H4DOTC)(diag)-242, DTC P0565 CRUISE CONTROL ON SIGNAL, Diagnostic Procedure with Diagnostic Trouble Code (DTC).> |
| P0604 | Internal Control Module Random Access Memory (RAM) Error | <Ref. to EN(H4DOTC)(diag)-244, DTC P0604 INTERNAL CONTROL MODULE RANDOM ACCESS MEMORY (RAM) ERROR, Diagnostic Procedure with Diagnostic Trouble Code (DTC).> |
| P0691 | Cooling Fan 1 Control Circuit Low | <Ref. to EN(H4DOTC)(diag)-246, DTC P0691 COOLING FAN 1 CONTROL CIRCUIT LOW, Diagnostic Procedure with Diagnostic Trouble Code (DTC).> |
| P0692 | Cooling Fan 1 Control Circuit High | <Ref. to EN(H4DOTC)(diag)-249, DTC P0692 COOLING FAN 1 CONTROL CIRCUIT HIGH, Diagnostic Procedure with Diagnostic Trouble Code (DTC).> |
| P0703 | Torque Converter/Brake Switch "B" Circuit | <Ref. to EN(H4DOTC)(diag)-252, DTC P0703 TORQUE CONVERTER/BRAKE SWITCH "B" CIRCUIT, Diagnostic Procedure with Diagnostic Trouble Code (DTC).> |

List of Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

| DTC | Item | Index |
|-------|--|--|
| P0705 | Transmission Range Sensor Circuit (PRNDL Input) | <Ref. to EN(H4DOTC)(diag)-254, DTC P0705 TRANSMISSION RANGE SENSOR CIRCUIT (PRNDL INPUT), Diagnostic Procedure with Diagnostic Trouble Code (DTC).> |
| P0710 | Transmission Fluid Temperature Sensor Circuit | <Ref. to EN(H4DOTC)(diag)-254, DTC P0710 TRANSMISSION FLUID TEMPERATURE SENSOR CIRCUIT, Diagnostic Procedure with Diagnostic Trouble Code (DTC).> |
| P0716 | Torque Converter Turbine Speed Sensor | <Ref. to EN(H4DOTC)(diag)-254, DTC P0716 TORQUE CONVERTER TURBINE SPEED SENSOR, Diagnostic Procedure with Diagnostic Trouble Code (DTC).> |
| P0720 | Output Speed Sensor Circuit | <Ref. to EN(H4DOTC)(diag)-254, DTC P0720 OUTPUT SPEED SENSOR CIRCUIT, Diagnostic Procedure with Diagnostic Trouble Code (DTC).> |
| P0726 | Engine Speed Input Circuit Range/Performance | <Ref. to EN(H4DOTC)(diag)-254, DTC P0726 ENGINE SPEED INPUT CIRCUIT RANGE/PERFORMANCE, Diagnostic Procedure with Diagnostic Trouble Code (DTC).> |
| P0731 | Gear 1 Incorrect Ratio | <Ref. to EN(H4DOTC)(diag)-254, DTC P0731 GEAR 1 INCORRECT RATIO, Diagnostic Procedure with Diagnostic Trouble Code (DTC).> |
| P0732 | Gear 2 Incorrect Ratio | <Ref. to EN(H4DOTC)(diag)-254, DTC P0732 GEAR 2 INCORRECT RATIO, Diagnostic Procedure with Diagnostic Trouble Code (DTC).> |
| P0733 | Gear 3 Incorrect Ratio | <Ref. to EN(H4DOTC)(diag)-254, DTC P0733 GEAR 3 INCORRECT RATIO, Diagnostic Procedure with Diagnostic Trouble Code (DTC).> |
| P0734 | Gear 4 Incorrect Ratio | <Ref. to EN(H4DOTC)(diag)-255, DTC P0734 GEAR 4 INCORRECT RATIO, Diagnostic Procedure with Diagnostic Trouble Code (DTC).> |
| P0741 | Torque Converter Clutch Circuit Performance or Stuck Off | <Ref. to EN(H4DOTC)(diag)-256, DTC P0741 TORQUE CONVERTER CLUTCH CIRCUIT PERFORMANCE OR STUCK OFF, Diagnostic Procedure with Diagnostic Trouble Code (DTC).> |
| P0743 | Torque Converter Clutch Circuit Electrical | <Ref. to EN(H4DOTC)(diag)-258, DTC P0743 TORQUE CONVERTER CLUTCH CIRCUIT ELECTRICAL, Diagnostic Procedure with Diagnostic Trouble Code (DTC).> |
| P0748 | Pressure Control Solenoid "A" Electrical | <Ref. to EN(H4DOTC)(diag)-258, DTC P0748 PRESSURE CONTROL SOLENOID "A" ELECTRICAL, Diagnostic Procedure with Diagnostic Trouble Code (DTC).> |
| P0753 | Shift Solenoid "A" Electrical | <Ref. to EN(H4DOTC)(diag)-258, DTC P0753 SHIFT SOLENOID "A" ELECTRICAL, Diagnostic Procedure with Diagnostic Trouble Code (DTC).> |
| P0758 | Shift Solenoid "B" Electrical | <Ref. to EN(H4DOTC)(diag)-258, DTC P0758 SHIFT SOLENOID "B" ELECTRICAL, Diagnostic Procedure with Diagnostic Trouble Code (DTC).> |
| P0771 | Low Clutch Timing Solenoid | <Ref. to EN(H4DOTC)(diag)-258, DTC P0771 LOW CLUTCH TIMING SOLENOID, Diagnostic Procedure with Diagnostic Trouble Code (DTC).> |
| P0778 | Pressure Control Solenoid "B" Electrical | <Ref. to EN(H4DOTC)(diag)-258, DTC P0778 PRESSURECONTROL SOLENOID "B" ELECTRICAL, Diagnostic Procedure with Diagnostic Trouble Code (DTC).> |
| P0785 | Shift/Timing Solenoid | <Ref. to EN(H4DOTC)(diag)-258, DTC P0785 SHIFT/TIMING SOLENOID, Diagnostic Procedure with Diagnostic Trouble Code (DTC).> |
| P0851 | Neutral Switch Input Circuit Low | <Ref. to EN(H4DOTC)(diag)-259, DTC P0851 NEUTRAL SWITCH INPUT CIRCUIT LOW (AT MODEL), Diagnostic Procedure with Diagnostic Trouble Code (DTC).> or <Ref. to EN(H4DOTC)(diag)-261, DTC P0851 NEUTRAL SWITCH INPUT CIRCUIT LOW (MT MODEL), Diagnostic Procedure with Diagnostic Trouble Code (DTC).> |
| P0852 | Neutral Switch Input Circuit High | <Ref. to EN(H4DOTC)(diag)-263, DTC P0852 NEUTRAL SWITCH INPUT CIRCUIT HIGH (AT MODEL), Diagnostic Procedure with Diagnostic Trouble Code (DTC).> or <Ref. to EN(H4DOTC)(diag)-266, DTC P0852 NEUTRAL SWITCH INPUT CIRCUIT HIGH (MT MODEL), Diagnostic Procedure with Diagnostic Trouble Code (DTC).> |
| P0864 | TCM Communication Circuit Range/Performance | <Ref. to EN(H4DOTC)(diag)-268, DTC P0864 TCM COMMUNICATION CIRCUIT RANGE/PERFORMANCE, Diagnostic Procedure with Diagnostic Trouble Code (DTC).> |
| P0865 | TCM Communication Circuit Low | <Ref. to EN(H4DOTC)(diag)-270, DTC P0865 TCM COMMUNICATION CIRCUIT LOW, Diagnostic Procedure with Diagnostic Trouble Code (DTC).> |

List of Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

| DTC | Item | Index |
|-------|--|--|
| P0866 | TCM Communication Circuit High | <Ref. to EN(H4DOTC)(diag)-272, DTC P0866 TCM COMMUNICATION CIRCUIT HIGH, Diagnostic Procedure with Diagnostic Trouble Code (DTC).> |
| P1086 | Tumble Generated Valve Position Sensor 2 Circuit Low | <Ref. to EN(H4DOTC)(diag)-274, DTC P1086 TUMBLE GENERATED VALVE POSITION SENSOR 2 CIRCUIT LOW, Diagnostic Procedure with Diagnostic Trouble Code (DTC).> |
| P1087 | Tumble Generated Valve Position Sensor 2 Circuit High | <Ref. to EN(H4DOTC)(diag)-277, DTC P1087 TUMBLE GENERATED VALVE POSITION SENSOR 2 CIRCUIT HIGH, Diagnostic Procedure with Diagnostic Trouble Code (DTC).> |
| P1088 | Tumble Generated Valve Position Sensor 1 Circuit Low | <Ref. to EN(H4DOTC)(diag)-279, DTC P1088 TUMBLE GENERATED VALVE POSITION SENSOR 1 CIRCUIT LOW, Diagnostic Procedure with Diagnostic Trouble Code (DTC).> |
| P1089 | Tumble Generated Valve Position Sensor 1 Circuit High | <Ref. to EN(H4DOTC)(diag)-282, DTC P1089 TUMBLE GENERATED VALVE POSITION SENSOR 1 CIRCUIT HIGH, Diagnostic Procedure with Diagnostic Trouble Code (DTC).> |
| P1090 | Tumble Generated Valve System 1 (Valve Open) | <Ref. to EN(H4DOTC)(diag)-284, DTC P1090 TUMBLE GENERATED VALVE SYSTEM 1 (VALVE OPEN), Diagnostic Procedure with Diagnostic Trouble Code (DTC).> |
| P1091 | Tumble Generated Valve System 1 (Valve Close) | <Ref. to EN(H4DOTC)(diag)-285, DTC P1091 TUMBLE GENERATED VALVE SYSTEM 1 (VALVE CLOSE), Diagnostic Procedure with Diagnostic Trouble Code (DTC).> |
| P1092 | Tumble Generated Valve System 2 (Valve Open) | <Ref. to EN(H4DOTC)(diag)-286, DTC P1092 TUMBLE GENERATED VALVE SYSTEM 2 (VALVE OPEN), Diagnostic Procedure with Diagnostic Trouble Code (DTC).> |
| P1093 | Tumble Generated Valve System 2 (Valve Close) | <Ref. to EN(H4DOTC)(diag)-287, DTC P1093 TUMBLE GENERATED VALVE SYSTEM 2 (VALVE CLOSE), Diagnostic Procedure with Diagnostic Trouble Code (DTC).> |
| P1094 | Tumble Generated Valve Signal 1 Circuit Malfunction (Open) | <Ref. to EN(H4DOTC)(diag)-288, DTC P1094 TUMBLE GENERATED VALVE SIGNAL 1 CIRCUIT MALFUNCTION (OPEN), Diagnostic Procedure with Diagnostic Trouble Code (DTC).> |
| P1095 | Tumble Generated Valve Signal 1 Circuit Malfunction (Short) | <Ref. to EN(H4DOTC)(diag)-290, DTC P1095 TUMBLE GENERATED VALVE SIGNAL 1 CIRCUIT MALFUNCTION (SHORT), Diagnostic Procedure with Diagnostic Trouble Code (DTC).> |
| P1096 | Tumble Generated Valve Signal 2 Circuit Malfunction (Open) | <Ref. to EN(H4DOTC)(diag)-292, DTC P1096 TUMBLE GENERATED VALVE SIGNAL 2 CIRCUIT MALFUNCTION (OPEN), Diagnostic Procedure with Diagnostic Trouble Code (DTC).> |
| P1097 | Tumble Generated Valve Signal 2 Circuit Malfunction (Short) | <Ref. to EN(H4DOTC)(diag)-294, DTC P1097 TUMBLE GENERATED VALVE SIGNAL 2 CIRCUIT MALFUNCTION (SHORT), Diagnostic Procedure with Diagnostic Trouble Code (DTC).> |
| P1110 | Atmospheric Pressure Sensor Circuit Malfunction (Low Input) | <Ref. to EN(H4DOTC)(diag)-295, DTC P1110 ATMOSPHERIC PRESSURE SENSOR CIRCUIT MALFUNCTION (LOW INPUT), Diagnostic Procedure with Diagnostic Trouble Code (DTC).> |
| P1111 | Atmospheric Pressure Sensor Circuit Malfunction (High Input) | <Ref. to EN(H4DOTC)(diag)-296, DTC P1111 ATMOSPHERIC PRESSURE SENSOR CIRCUIT MALFUNCTION (HIGH INPUT), Diagnostic Procedure with Diagnostic Trouble Code (DTC).> |
| P1134 | A/F Sensor Micro-Computer Problem | <Ref. to EN(H4DOTC)(diag)-297, DTC P1134 A/F SENSOR MICRO-COMPUTER PROBLEM, Diagnostic Procedure with Diagnostic Trouble Code (DTC).> |
| P1152 | O ₂ Sensor Circuit Range/Performance (Low) (Bank1 Sensor1) | <Ref. to EN(H4DOTC)(diag)-298, DTC P1152 O ₂ SENSOR CIRCUIT RANGE/PERFORMANCE (LOW) (BANK1 SENSOR1), Diagnostic Procedure with Diagnostic Trouble Code (DTC).> |
| P1153 | O ₂ Sensor Circuit Range/Performance (High) (Bank1 Sensor1) | <Ref. to EN(H4DOTC)(diag)-300, DTC P1153 O ₂ SENSOR CIRCUIT RANGE/PERFORMANCE (HIGH) (BANK1 SENSOR1), Diagnostic Procedure with Diagnostic Trouble Code (DTC).> |
| P1301 | Misfire Detected (High Temperature Exhaust Gas) | <Ref. to EN(H4DOTC)(diag)-302, DTC P1301 MISFIRE DETECTED (HIGH TEMPERATURE EXHAUST GAS), Diagnostic Procedure with Diagnostic Trouble Code (DTC).> |

List of Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

| DTC | Item | Index |
|-------|---|---|
| P1312 | Exhaust Gas Temperature Sensor Malfunction | <Ref. to EN(H4DOTC)(diag)-304, DTC P1312 EXHAUST GAS TEMPERATURE SENSOR MALFUNCTION, Diagnostic Procedure with Diagnostic Trouble Code (DTC).> |
| P1400 | Fuel Tank Pressure Control Solenoid Valve Circuit Low | <Ref. to EN(H4DOTC)(diag)-306, DTC P1400 FUEL TANK PRESSURE CONTROL SOLENOID VALVE CIRCUIT LOW, Diagnostic Procedure with Diagnostic Trouble Code (DTC).> |
| P1420 | Fuel Tank Pressure Control Sol. Valve Circuit High | <Ref. to EN(H4DOTC)(diag)-309, DTC P1420 FUEL TANK PRESSURE CONTROL SOL. VALVE CIRCUIT HIGH, Diagnostic Procedure with Diagnostic Trouble Code (DTC).> |
| P1443 | Vent Control Solenoid Valve Function Problem | <Ref. to EN(H4DOTC)(diag)-311, DTC P1443 VENT CONTROL SOLENOID VALVE FUNCTION PROBLEM, Diagnostic Procedure with Diagnostic Trouble Code (DTC).> |
| P1446 | Fuel Tank Sensor Control Valve Circuit Low | <Ref. to EN(H4DOTC)(diag)-313, DTC P1446 FUEL TANK SENSOR CONTROL VALVE CIRCUIT LOW, Diagnostic Procedure with Diagnostic Trouble Code (DTC).> |
| P1447 | Fuel Tank Sensor Control Valve Circuit High | <Ref. to EN(H4DOTC)(diag)-316, DTC P1447 FUEL TANK SENSOR CONTROL VALVE CIRCUIT HIGH, Diagnostic Procedure with Diagnostic Trouble Code (DTC).> |
| P1448 | Fuel Tank Sensor Control Valve Range/Performance | <Ref. to EN(H4DOTC)(diag)-318, DTC P1448 FUEL TANK SENSOR CONTROL VALVE RANGE/PERFORMANCE, Diagnostic Procedure with Diagnostic Trouble Code (DTC).> |
| P1491 | Positive Crankcase Ventilation (Blow-by) Function Problem | <Ref. to EN(H4DOTC)(diag)-320, DTC P1491 POSITIVE CRANKCASE VENTILATION (BLOW-BY) FUNCTION PROBLEM, Diagnostic Procedure with Diagnostic Trouble Code (DTC).> |
| P1518 | Starter Switch Circuit Low Input | <Ref. to EN(H4DOTC)(diag)-321, DTC P1518 STARTER SWITCH CIRCUIT LOW INPUT, Diagnostic Procedure with Diagnostic Trouble Code (DTC).> |
| P1544 | Exhaust Gas Temperature Too High | <Ref. to EN(H4DOTC)(diag)-324, DTC P1544 EXHAUST GAS TEMPERATURE TOO HIGH, Diagnostic Procedure with Diagnostic Trouble Code (DTC).> |
| P1560 | Back-Up Voltage Circuit Malfunction | <Ref. to EN(H4DOTC)(diag)-325, DTC P1560 BACK-UP VOLTAGE CIRCUIT MALFUNCTION, Diagnostic Procedure with Diagnostic Trouble Code (DTC).> |
| P1700 | Throttle Position Sensor | <Ref. to EN(H4DOTC)(diag)-327, DTC P1700 THROTTLE POSITION SENSOR, Diagnostic Procedure with Diagnostic Trouble Code (DTC).> |
| P1711 | Engine Torque Control Signal 1 Circuit Malfunction | <Ref. to EN(H4DOTC)(diag)-328, DTC P1711 ENGINE TORQUE CONTROL SIGNAL 1 CIRCUIT MALFUNCTION, Diagnostic Procedure with Diagnostic Trouble Code (DTC).> |
| P1712 | Engine Torque Control Signal 2 Circuit Malfunction | <Ref. to EN(H4DOTC)(diag)-330, DTC P1712 ENGINE TORQUE CONTROL SIGNAL 2 CIRCUIT MALFUNCTION, Diagnostic Procedure with Diagnostic Trouble Code (DTC).> |
| P2096 | Post Catalyst Fuel Trim System Too Lean Bank 1 | <Ref. to EN(H4DOTC)(diag)-332, DTC P2096 POST CATALYST FUEL TRIM SYSTEM TOO LEAN BANK 1, Diagnostic Procedure with Diagnostic Trouble Code (DTC).> |
| P2097 | Post Catalyst Fuel Trim System Too Rich Bank 1 | <Ref. to EN(H4DOTC)(diag)-336, DTC P2097 POST CATALYST FUEL TRIM SYSTEM TOO RICH BANK 1, Diagnostic Procedure with Diagnostic Trouble Code (DTC).> |

Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

19. Diagnostic Procedure with Diagnostic Trouble Code (DTC)

A: DTC P0030 HO2S HEATER CONTROL CIRCUIT (BANK 1 SENSOR 1)


DTC DETECTING CONDITION:

- Two consecutive driving cycles with fault
- GENERAL DESCRIPTION <Ref. to GD(H4DOTC)-9, DTC P0030 HO2S HEATER CONTROL CIRCUIT (BANK 1 SENSOR 1), Diagnostic Trouble Code (DTC) Detecting Criteria.>

CAUTION:

After repair or replacement of faulty parts, conduct Clear Memory Mode <Ref. to EN(H4DOTC)(diag)-46, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(H4DOTC)(diag)-39, PROCEDURE, Inspection Mode.>.

WIRING DIAGRAM:



EN-01610

Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

| Step | Check | Yes | No |
|---|--|--|--|
| 1 CHECK HARNESS BETWEEN ECM AND FRONT OXYGEN (A/F) SENSOR CONNECTOR. 1) Start the engine and warm-up engine. 2) Turn the ignition switch to OFF. 3) Disconnect the connectors from ECM and front oxygen (A/F) sensor. 4) Measure the resistance of harness between ECM and front oxygen (A/F) sensor connector. <i>Connector & terminal</i> (B84) No. 5 — (B18) No. 1: (B84) No. 4 — (B18) No. 1: | Is the resistance less than 1 Ω ? | Go to step 2. | Repair the open circuit in harness between ECM and front oxygen (A/F) sensor connector. |
| 2 CHECK HARNESS BETWEEN ECM AND FRONT OXYGEN (A/F) SENSOR CONNECTOR. Measure the resistance of harness between ECM and front oxygen (A/F) sensor connector. <i>Connector & terminal</i> (B84) No. 19 — (B18) No. 4: (B84) No. 29 — (B18) No. 3: | Is the resistance less than 1 Ω ? | Go to step 3. | Repair the open circuit in harness between ECM and front oxygen (A/F) sensor connector. |
| 3 CHECK HARNESS BETWEEN ECM AND FRONT OXYGEN (A/F) SENSOR CONNECTOR. Measure the resistance of harness between main relay and front oxygen (A/F) sensor connector. <i>Connector & terminal</i> (B47) No. 4 — (B18) No. 2: | Is the resistance less than 1 Ω ? | Go to step 4. | Repair the open circuit in harness between ECM and front oxygen (A/F) sensor connector. |
| 4 CHECK FRONT OXYGEN (A/F) SENSOR. Measure the resistance between front oxygen (A/F) sensor connector terminals. <i>Terminals</i> No. 2 — No. 1: | Is the resistance less than 5 Ω ? | Go to step 5. | Replace the front oxygen (A/F) sensor. <Ref. to FU(H4DOTC)-43, Front Oxygen (A/F) Sensor.> |
| 5 CHECK POOR CONTACT. Check the poor contact in ECM and front oxygen (A/F) sensor connector. | Is there poor contact in ECM or front oxygen (A/F) sensor connector? | Repair the poor contact in ECM or front oxygen (A/F) sensor connector. | Replace the front oxygen (A/F) sensor. <Ref. to FU(H4DOTC)-43, Front Oxygen (A/F) Sensor.> |

Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

B: DTC P0031 HO2S HEATER CONTROL CIRCUIT LOW (BANK 1 SENSOR 1)


DTC DETECTING CONDITION:

- Immediately at fault recognition
- GENERAL DESCRIPTION <Ref. to GD(H4DOTC)-11, DTC P0031 HO2S HEATER CONTROL CIRCUIT LOW (BANK 1 SENSOR 1), Diagnostic Trouble Code (DTC) Detecting Criteria.>

CAUTION:

After repair or replacement of faulty parts, conduct Clear Memory Mode <Ref. to EN(H4DOTC)(diag)-46, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(H4DOTC)(diag)-39, PROCEDURE, Inspection Mode.>.

WIRING DIAGRAM:



EN-01610

Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

| Step | Check | Yes | No |
|--|--|--|---|
| <p>1 CHECK POWER SUPPLY TO FRONT OXYGEN (A/F) SENSOR. 1) Turn the ignition switch to OFF. 2) Disconnect the connector from front oxygen (A/F) sensor. 3) Turn the ignition switch to ON. 4) Measure the voltage between front oxygen (A/F) sensor connector and engine ground. Connector & terminal (B18) No. 2 (+) — Engine ground (-):</p> | Is the voltage more than 10 V? | Go to step 2. | Repair the power supply line. NOTE: In this case, repair the following: <ul style="list-style-type: none"> • Open circuit in harness between main relay and front oxygen (A/F) sensor connector • Poor contact in front oxygen (A/F) sensor connector • Poor contact in main relay connector |
| <p>2 CHECK GROUND CIRCUIT OF ECM. Measure the resistance of harness between ECM connector and chassis ground. Connector & terminal (B84) No. 8 — Chassis ground: (B84) No. 9 — Chassis ground:</p> | Is the resistance less than 5 Ω? | Go to step 3. | Repair the harness and connector. NOTE: In this case, repair the following: <ul style="list-style-type: none"> • Open circuit in harness between ECM and engine ground cable • Poor contact in ECM connector • Poor contact in coupling connector |
| <p>3 CHECK CURRENT DATA. 1) Start the engine. 2) Read the data of front oxygen (A/F) sensor heater current using Subaru Select Monitor or OBD-II general scan tool. NOTE: • Subaru Select Monitor For detailed operation procedure, refer to the "READ CURRENT DATA FOR ENGINE". <Ref. to EN(H4DOTC)(diag)-31, Subaru Select Monitor.> • OBD-II scan tool For detailed operation procedures, refer to the OBD-II General Scan Tool Instruction Manual.</p> | Is the current more than 0.2 A? | Repair the poor contact in connector. NOTE: In this case, repair the following: <ul style="list-style-type: none"> • Poor contact in front oxygen (A/F) sensor connector • Poor contact in ECM connector | Go to step 4. |
| <p>4 CHECK OUTPUT SIGNAL FROM ECM. 1) Start and idle the engine. 2) Measure the voltage between ECM connector and chassis ground. Connector & terminal (B84) No. 4 (+) — Chassis ground (-): (B84) No. 5 (+) — Chassis ground (-):</p> | Is the voltage less than 1 V? | Go to step 6. | Go to step 5. |
| <p>5 CHECK OUTPUT SIGNAL FROM ECM. Measure the voltage between ECM connector and chassis ground. Connector & terminal (B84) No. 4 (+) — Chassis ground (-): (B84) No. 5 (+) — Chassis ground (-):</p> | Shake the ECM harness and connector, while monitoring value of voltage meter. Does the voltage change? | Repair the poor contact in ECM connector. | Go to step 6. |

Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

| Step | Check | Yes | No |
|--|--|---|---|
| <p>6 CHECK FRONT OXYGEN (A/F) SENSOR. 1) Turn the ignition switch to OFF. 2) Measure the resistance between front oxygen (A/F) sensor connector terminals. Terminals No. 2 — No. 1:</p> | <p>Is the resistance less than 10 Ω?</p> | <p>Repair the harness and connector. NOTE: In this case, repair the following:</p> <ul style="list-style-type: none">• Open or ground short circuit in harness between front oxygen (A/F) sensor and ECM connector• Poor contact in front oxygen (A/F) sensor connector• Poor contact in ECM connector | <p>Replace the front oxygen (A/F) sensor. <Ref. to FU(H4DOTC)-43, Front Oxygen (A/F) Sensor.></p> |

Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

C: DTC P0032 HO2S HEATER CONTROL CIRCUIT HIGH (BANK 1 SENSOR 1)


DTC DETECTING CONDITION:

- Immediately at fault recognition
- GENERAL DESCRIPTION <Ref. to GD(H4DOTC)-13, DTC P0032 HO2S HEATER CONTROL CIRCUIT HIGH (BANK 1 SENSOR 1), Diagnostic Trouble Code (DTC) Detecting Criteria.>

CAUTION:

After repair or replacement of faulty parts, conduct Clear Memory Mode <Ref. to EN(H4DOTC)(diag)-46, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(H4DOTC)(diag)-39, PROCEDURE, Inspection Mode.>.

WIRING DIAGRAM:



EN-01610

Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

| Step | Check | Yes | No |
|---|--|--|---------------|
| 1 CHECK OUTPUT SIGNAL FROM ECM. 1) Turn the ignition switch to ON. 2) Measure the voltage between ECM connector and chassis ground. Connector & terminal <i>(B84) No. 4 (+) — Chassis ground (-):</i> <i>(B84) No. 5 (+) — Chassis ground (-):</i> | Is the voltage more than 8 V? | Go to step 3. | Go to step 2. |
| 2 CHECK FRONT OXYGEN (A/F) SENSOR HEATER CURRENT. 1) Turn the ignition switch to OFF. 2) Repair the battery short circuit in harness between ECM and front oxygen (A/F) sensor connector. 3) Turn the ignition switch to ON. 4) Read the data of front oxygen (A/F) sensor heater current using Subaru Select Monitor or the OBD-II general scan tool. NOTE: <ul style="list-style-type: none"> • Subaru Select Monitor For detailed operation procedure, refer to the "READ CURRENT DATA FOR ENGINE". <Ref. to EN(H4DOTC)(diag)-31, Subaru Select Monitor.> <ul style="list-style-type: none"> • OBD-II general scan tool For detailed operation procedure, refer to the OBD-II General Scan Tool Instruction Manual. | Is the current more than 2.3 A? | Replace the ECM. <Ref. to FU(H4DOTC)-48, Engine Control Module (ECM).> | END |
| 3 CHECK OUTPUT SIGNAL FROM ECM. Measure the voltage between ECM connector and chassis ground. Connector & terminal <i>(B84) No. 4 (+) — Chassis ground (-):</i> <i>(B84) No. 5 (+) — Chassis ground (-):</i> | Shake the ECM harness and connector, while monitoring value of voltage meter. Does the voltage change? | Repair the battery short circuit in harness between ECM and front oxygen (A/F) sensor connector. | END |

Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

D: DTC P0037 HO2S HEATER CONTROL CIRCUIT LOW (BANK 1 SENSOR 2)


DTC DETECTING CONDITION:

- Immediately at fault recognition
- GENERAL DESCRIPTION <Ref. to GD(H4DOTC)-15, DTC P0037 HO2S HEATER CONTROL CIRCUIT LOW (BANK 1 SENSOR 2), Diagnostic Trouble Code (DTC) Detecting Criteria.>

CAUTION:

After repair or replacement of faulty parts, conduct Clear Memory Mode <Ref. to EN(H4DOTC)(diag)-46, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(H4DOTC)(diag)-39, PROCEDURE, Inspection Mode.>.

WIRING DIAGRAM:



EN-01611

Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

| Step | Check | Yes | No |
|--|--|---|---|
| 1 CHECK GROUND CIRCUIT OF ECM. 1) Turn the ignition switch to OFF. 2) Disconnect the connector from ECM. 3) Measure the resistance of harness between ECM connector and chassis ground. Connector & terminal (B84) No. 8 — Chassis ground: (B84) No. 9 — Chassis ground: | Is the resistance less than 5 Ω ? | Go to step 2. | Repair the harness and connector. NOTE: In this case, repair the following: <ul style="list-style-type: none"> • Open circuit in harness between ECM and engine ground cable • Poor contact in ECM connector • Poor contact in coupling connector |
| 2 CHECK CURRENT DATA. 1) Start the engine. 2) Read the data of rear oxygen sensor heater current using Subaru Select Monitor or OBD-II general scan tool. NOTE: <ul style="list-style-type: none"> • Subaru Select Monitor For detailed operation procedure, refer to the "READ CURRENT DATA FOR ENGINE". <Ref. to EN(H4DOTC)(diag)-31, Subaru Select Monitor.> <ul style="list-style-type: none"> • OBD-II scan tool For detailed operation procedures, refer to the OBD-II General Scan Tool Instruction Manual. | Is the current more than 0.2 A? | Repair the connector. NOTE: In this case, repair the following: <ul style="list-style-type: none"> • Poor contact in rear oxygen sensor connector • Poor contact in rear oxygen sensor connecting harness connector • Poor contact in ECM connector | Go to step 3. |
| 3 CHECK OUTPUT SIGNAL FROM ECM. 1) Start and idle the engine. 2) Measure the voltage between ECM connector and chassis ground. Connector & terminal (B137) No. 13 (+) — Chassis ground (-): | Is the voltage less than 1 V? | Go to step 6. | Go to step 4. |
| 4 CHECK OUTPUT SIGNAL FROM ECM. Measure the voltage between ECM connector and chassis ground. Connector & terminal (B137) No. 13 (+) — Chassis ground (-): | Shake the ECM harness and connector, while monitoring value of voltage meter. Does the voltage change? | Repair the poor contact in ECM connector. | Go to step 5. |
| 5 CHECK OUTPUT SIGNAL FROM ECM. 1) Turn the ignition switch to OFF. 2) Disconnect the connector from rear oxygen sensor. 3) Measure the voltage between ECM connector and chassis ground. Connector & terminal (B137) No. 13 (+) — Chassis ground (-): | Is the voltage less than 1 V? | Replace the ECM. <Ref. to FU(H4DOTC)-48, Engine Control Module (ECM).> | Repair the battery short circuit in harness between ECM and rear oxygen sensor connector. After repair, replace the ECM. <Ref. to FU(H4DOTC)-48, Engine Control Module (ECM).> |

Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

| Step | Check | Yes | No |
|---|--|---|---|
| <p>6</p> <p>CHECK POWER SUPPLY TO REAR OXYGEN SENSOR.</p> <p>1) Turn the ignition switch to OFF. 2) Disconnect the connector from rear oxygen sensor. 3) Turn the ignition switch to ON. 4) Measure the voltage between rear oxygen sensor connector and engine ground or chassis ground.</p> <p>Connector & terminal (B19) No. 2 (+) — Chassis ground (-):</p> | <p>Is the voltage more than 10 V?</p> | <p>Go to step 7.</p> | <p>Repair the power supply line.</p> <p>NOTE: In this case, repair the following:</p> <ul style="list-style-type: none"> • Open circuit in harness between main relay and rear oxygen sensor connector • Poor contact in rear oxygen sensor connector • Poor contact in coupling connector |
| <p>7</p> <p>CHECK REAR OXYGEN SENSOR.</p> <p>1) Turn the ignition switch to OFF. 2) Measure the resistance between rear oxygen sensor connector terminals.</p> <p>Terminals No. 1 — No. 2:</p> | <p>Is the resistance less than 30 Ω?</p> | <p>Repair the harness and connector.</p> <p>NOTE: In this case, repair the following:</p> <ul style="list-style-type: none"> • Open circuit in harness between rear oxygen sensor and ECM connector • Poor contact in rear oxygen sensor connector • Poor contact in ECM connector • Poor contact in coupling connector | <p>Replace the rear oxygen sensor. <Ref. to FU(H4DOTC)-45, Rear Oxygen Sensor.></p> |

Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

E: DTC P0038 HO2S HEATER CONTROL CIRCUIT HIGH (BANK 1 SENSOR 2)


DTC DETECTING CONDITION:

- Immediately at fault recognition
- GENERAL DESCRIPTION <Ref. to GD(H4DOTC)-17, DTC P0038 HO2S HEATER CONTROL CIRCUIT HIGH (BANK 1 SENSOR 2), Diagnostic Trouble Code (DTC) Detecting Criteria.>

CAUTION:

After repair or replacement of faulty parts, conduct Clear Memory Mode <Ref. to EN(H4DOTC)(diag)-46, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(H4DOTC)(diag)-39, PROCEDURE, Inspection Mode.>.

WIRING DIAGRAM:



EN-01611

Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

| Step | Check | Yes | No |
|--|---|---|---------------|
| 1 CHECK INPUT SIGNAL FOR ECM. 1) Turn the ignition switch to OFF. 2) Measure the voltage between ECM connector and chassis ground. Connector & terminal (B137) No. 13 (+) — Chassis ground (-): | Is the voltage more than 8 V? | Go to step 2. | Go to step 3. |
| 2 CHECK CURRENT DATA. 1) Repair the battery short circuit in harness between ECM and rear oxygen sensor connector. 2) Turn the ignition switch to ON. 3) Read the data of rear oxygen sensor heater current using Subaru Select Monitor or the OBD-II general scan tool. NOTE: • Subaru Select Monitor For detailed operation procedure, refer to the "READ CURRENT DATA FOR ENGINE". <Ref. to EN(H4DOTC)(diag)-31, Subaru Select Monitor.> • OBD-II general scan tool For detailed operation procedure, refer to the OBD-II General Scan Tool Instruction Manual. | Is the current more than 7 A? | Replace the ECM. <Ref. to FU(H4DOTC)-48, Engine Control Module (ECM).> | END |
| 3 CHECK POOR CONTACT. Check poor contact in ECM connector. | Is there poor contact in ECM connector? | Repair the poor contact in ECM connector. | END |

Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

F: DTC P0068 MANIFOLD ABSOLUTE PRESSURE/BAROMETRIC PRESSURE CIRCUIT RANGE/PERFORMANCE

DTC DETECTING CONDITION:

- Two consecutive driving cycles with fault
- GENERAL DESCRIPTION <Ref. to GD(H4DOTC)-19, DTC P0068 MANIFOLD PRESSURE SENSOR RANGE/PERFORMANCE, Diagnostic Trouble Code (DTC) Detecting Criteria.>






TROUBLE SYMPTOM:

Failure of engine to start

CAUTION:

After repair or replacement of faulty parts, conduct Clear Memory Mode <Ref. to EN(H4DOTC)(diag)-46, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(H4DOTC)(diag)-39, PROCEDURE, Inspection Mode.>.

WIRING DIAGRAM:



EN-01612

Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

| Step | Check | Yes | No |
|---|--|---|--|
| 1 CHECK IDLE SWITCH SIGNAL. 1) Turn the ignition switch to ON. 2) Operate the LED operation mode for engine using Subaru Select Monitor. NOTE: • Subaru Select Monitor For detailed operation procedure, refer to the "LED OPERATION MODE FOR ENGINE". <Ref. to EN(H4DOTC)(diag)-31, Subaru Select Monitor.> | Does the LED of {Idle Switch Signal} come on? | Go to step 2. | Check the throttle position sensor circuit. <Ref. to EN(H4DOTC)(diag)-115, DTC P0121 THROTTLE/ PEDAL POSITION SENSOR/ SWITCH "A" CIRCUIT RANGE/ PERFORMANCE, Diagnostic Procedure with Diagnostic Trouble Code (DTC).> NOTE: In this case, it is not necessary to inspect DTC P0106. |
| 2 CHECK ANY OTHER DTC ON DISPLAY. | Is any other DTC displayed? | Inspect the relevant DTC. "List of Diagnostic Trouble Code (DTC)". <Ref. to EN(H4DOTC)(diag)-71, List of Diagnostic Trouble Code (DTC).> NOTE: In this case, it is not necessary to inspect DTC P0106. | Go to step 3. |
| 3 CHECK CONDITION OF MANIFOLD ABSOLUTE PRESSURE SENSOR. | Is the manifold absolute pressure sensor installation bolt tightened securely? | Go to step 4. | Tighten the manifold absolute pressure sensor installation bolt securely. |
| 4 CHECK CONDITION OF THROTTLE BODY. | Is the throttle body installation bolt tightened securely? | Replace the manifold absolute pressure sensor. <Ref. to FU(H4DOTC)-33, Manifold Absolute Pressure Sensor.> | Tighten the throttle body installation bolt securely. |

Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

G: DTC P0101 MASS OR VOLUME AIR FLOW CIRCUIT RANGE/PERFORMANCE

DTC DETECTING CONDITION:

- Two consecutive driving cycles with fault
- GENERAL DESCRIPTION <Ref. to GD(H4DOTC)-21, DTC P0101 MASS OR VOLUME AIR FLOW CIRCUIT RANGE/PERFORMANCE, Diagnostic Trouble Code (DTC) Detecting Criteria.>


TROUBLE SYMPTOM:

- Erroneous idling
- Engine stalls.
- Poor driving performance

CAUTION:

After repair or replacement of faulty parts, conduct Clear Memory Mode <Ref. to EN(H4DOTC)(diag)-46, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(H4DOTC)(diag)-39, PROCEDURE, Inspection Mode.>.

WIRING DIAGRAM:



EN-01613

Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

| Step | Check | Yes | No |
|---|-----------------------------|---|--|
| 1 CHECK ANY OTHER DTC ON DISPLAY. | Is any other DTC displayed? | Inspect the relevant DTC using "List of Diagnostic Trouble Code (DTC)". <Ref. to EN(H4DOTC)(diag)-71, List of Diagnostic Trouble Code (DTC).> NOTE: In this case, it is not necessary to inspect DTC P0101. | Replace the mass air flow and intake air temperature sensor. <Ref. to FU(H4DOTC)-32, Mass Air Flow and Intake Air Temperature Sensor.> |

Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

H: DTC P0102 MASS OR VOLUME AIR FLOW CIRCUIT LOW INPUT

DTC DETECTING CONDITION:

- Immediately at fault recognition
- GENERAL DESCRIPTION <Ref. to GD(H4DOTC)-23, DTC P0102 MASS OR VOLUME AIR FLOW CIRCUIT LOW INPUT, Diagnostic Trouble Code (DTC) Detecting Criteria.>


TROUBLE SYMPTOM:

- Erroneous idling
- Engine stalls.
- Poor driving performance

CAUTION:

After repair or replacement of faulty parts, conduct Clear Memory Mode <Ref. to EN(H4DOTC)(diag)-46, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(H4DOTC)(diag)-39, PROCEDURE, Inspection Mode.>.

WIRING DIAGRAM:



EN-01613

Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

| Step | Check | Yes | No |
|---|---|---|--|
| <p>1 CONNECT SUBARU SELECT MONITOR OR THE OBD-II GENERAL SCAN TOOL, AND READ DATA.</p> <p>1) Turn the ignition switch to OFF. 2) Connect the Subaru Select Monitor or OBD-II general scan tool to data link connector. 3) Turn the ignition switch to ON and Subaru Select Monitor or the OBD-II general scan tool switch to ON. 4) Start the engine. 5) Read the mass air flow sensor voltage using Subaru Select Monitor or OBD-II general scan tool.</p> <p>NOTE:</p> <ul style="list-style-type: none"> Subaru Select Monitor <p>For detailed operation procedure, refer to the "READ CURRENT DATA FOR ENGINE". <Ref. to EN(H4DOTC)(diag)-31, Subaru Select Monitor.></p> <ul style="list-style-type: none"> OBD-II general scan tool <p>For detailed operation procedures, refer to the OBD-II General Scan Tool Instruction Manual.</p> | <p>Is the voltage 0.2 — 4.7 V?</p> | <p>Even if malfunction indicator light lights up, the circuit has returned to a normal condition at this time. A temporary poor contact of the connector or harness may be the cause. Repair the harness or connector in the mass air flow sensor.</p> <p>NOTE: In this case, repair the following:</p> <ul style="list-style-type: none"> Open or ground short circuit in harness between mass air flow sensor and ECM connector Poor contact in mass air flow sensor or ECM connector | <p>Go to step 2.</p> |
| <p>2 CHECK INPUT SIGNAL FOR ECM.</p> <p>Measure the voltage between ECM connector and chassis ground while engine is idling.</p> <p>Connector & terminal (B136) No. 13 (+) — Chassis ground (-):</p> | <p>Is the voltage less than 0.2 V?</p> | <p>Go to step 4.</p> | <p>Go to step 3.</p> |
| <p>3 CHECK INPUT SIGNAL FOR ECM (USING SUBARU SELECT MONITOR).</p> <p>Measure the voltage between ECM connector and chassis ground while engine is idling.</p> | <p>Shake the ECM harness and connector, while monitoring value of Subaru Select Monitor. Does the voltage change?</p> | <p>Repair the poor contact in ECM connector.</p> | <p>Contact your SOA Service Center.</p> <p>NOTE: Inspection by DTM is required, because probable cause is deterioration of multiple parts.</p> |
| <p>4 CHECK POWER SUPPLY TO MASS AIR FLOW SENSOR.</p> <p>1) Turn the ignition switch to OFF. 2) Disconnect the connector from mass air flow sensor. 3) Turn the ignition switch to ON. 4) Measure the voltage between mass air flow sensor connector and chassis ground.</p> <p>Connector & terminal (B3) No. 1 (+) — Chassis ground (-):</p> | <p>Is the voltage more than 5 V?</p> | <p>Go to step 5.</p> | <p>Repair the open circuit between mass air flow sensor and main relay.</p> |

Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

| Step | Check | Yes | No |
|---|--|--|--|
| 5 CHECK HARNESS BETWEEN ECM AND MASS AIR FLOW SENSOR CONNECTOR. 1) Turn the ignition switch to OFF. 2) Disconnect the connector from ECM. 3) Measure the resistance of harness between ECM and mass air flow sensor connector. <i>Connector & terminal</i> (B136) No. 13 — (B3) No. 3: (B136) No. 7 — (B3) No. 2: (B135) No. 19 — (B3) No. 5: | Is the resistance less than 1 Ω ? | Go to step 6. | Repair the open circuit between ECM and mass air flow sensor connector. |
| 6 CHECK HARNESS BETWEEN ECM AND MASS AIR FLOW SENSOR CONNECTOR Measure the resistance of harness between ECM and chassis ground. <i>Connector & terminal</i> (B136) No. 13 — Chassis ground: (B136) No. 7 — Chassis ground: (B135) No. 19 — Chassis ground: | Is the resistance more than 1 M Ω ? | Go to step 7. | Repair the ground short circuit between ECM and mass air flow sensor connector. |
| 7 CHECK POOR CONTACT Check poor contact in mass air flow sensor connector. | Is there poor contact in mass air flow sensor connector? | Repair the poor contact in mass air flow sensor connector. | Replace the mass air flow and intake air temperature sensor. <Ref. to FU(H4DOTC)-32, Mass Air Flow and Intake Air Temperature Sensor.> |

Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

I: DTC P0103 MASS OR VOLUME AIR FLOW CIRCUIT HIGH INPUT

DTC DETECTING CONDITION:

- Immediately at fault recognition
- GENERAL DESCRIPTION <Ref. to GD(H4DOTC)-25, DTC P0103 MASS OR VOLUME AIR FLOW CIRCUIT HIGH INPUT, Diagnostic Trouble Code (DTC) Detecting Criteria.>


TROUBLE SYMPTOM:

- Erroneous idling
- Engine stalls.
- Poor driving performance

CAUTION:

After repair or replacement of faulty parts, conduct Clear Memory Mode <Ref. to EN(H4DOTC)(diag)-46, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(H4DOTC)(diag)-39, PROCEDURE, Inspection Mode.>.

WIRING DIAGRAM:



EN-01613

Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

| Step | Check | Yes | No |
|---|---|---|--|
| <p>1 CONNECT SUBARU SELECT MONITOR OR THE OBD-II GENERAL SCAN TOOL, AND READ DATA.</p> <p>1) Turn the ignition switch to OFF. 2) Connect the Subaru Select Monitor or OBD-II general scan tool to data link connector. 3) Turn the ignition switch to ON and Subaru Select Monitor or OBD-II general scan tool switch to ON. 4) Start the engine. 5) Read the mass air flow sensor voltage using Subaru Select Monitor or OBD-II general scan tool.</p> <p>NOTE:</p> <ul style="list-style-type: none"> • Subaru Select Monitor <p>For detailed operation procedure, refer to the "READ CURRENT DATA FOR ENGINE". <Ref. to EN(H4DOTC)(diag)-31, Subaru Select Monitor.></p> <ul style="list-style-type: none"> • OBD-II general scan tool <p>For detailed operation procedures, refer to the OBD-II General Scan Tool Instruction Manual.</p> | <p>Is the voltage 0.2 — 4.7 V?</p> | <p>Even if malfunction indicator light lights up, the circuit has returned to a normal condition at this time.</p> | <p>Go to step 2.</p> |
| <p>2 CHECK HARNESS BETWEEN ECM AND MASS AIR FLOW SENSOR CONNECTOR.</p> <p>1) Turn the ignition switch to OFF. 2) Disconnect the connector from mass air flow sensor. 3) Turn the ignition switch to ON. 4) Measure the voltage between mass air flow sensor connector and chassis ground.</p> <p>Connector & terminal (B3) No. 3 (+) — Chassis ground (-):</p> | <p>Is the voltage more than 5 V?</p> | <p>Repair the battery short of harness between mass air flow sensor connector and ECM connector.</p> | <p>Go to step 3.</p> |
| <p>3 CHECK HARNESS BETWEEN ECM AND MASS AIR FLOW SENSOR CONNECTOR.</p> <p>1) Turn the ignition switch to OFF. 2) Disconnect the connector from ECM. 3) Measure the resistance between ECM connector and mass air flow sensor connector.</p> <p>Connector & terminal (B3) No. 2 — (B136) No. 7:</p> | <p>Is the resistance less than 1 Ω?</p> | <p>Replace the mass air flow sensor. <Ref. to FU(H4DOTC)-32, Mass Air Flow and Intake Air Temperature Sensor.></p> | <p>Repair the open harness between mass air flow sensor connector and ECM connector.</p> |

Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

J: DTC P0107 MANIFOLD ABSOLUTE PRESSURE/BAROMETRIC PRESSURE CIRCUIT LOW INPUT


DTC DETECTING CONDITION:

- Immediately at fault recognition
- GENERAL DESCRIPTION <Ref. to GD(H4DOTC)-27, DTC P0107 MANIFOLD ABSOLUTE PRESSURE/BAROMETRIC PRESSURE CIRCUIT LOW INPUT, Diagnostic Trouble Code (DTC) Detecting Criteria.>

CAUTION:

After repair or replacement of faulty parts, conduct Clear Memory Mode <Ref. to EN(H4DOTC)(diag)-46, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(H4DOTC)(diag)-39, PROCEDURE, Inspection Mode.>.

WIRING DIAGRAM:



EN-01612

Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

| Step | Check | Yes | No |
|--|--|---|---|
| 1 CHECK INPUT SIGNAL FOR ECM. Measure the voltage between ECM connector and chassis ground. <i>Connector & terminal</i> <i>(B135) No. 9 (+) — Chassis ground (-):</i> | Is the voltage more than 4.5 V? | Go to step 3. | Go to step 2. |
| 2 CHECK INPUT SIGNAL FOR ECM. Measure the voltage between ECM connector and chassis ground. <i>Connector & terminal</i> <i>(B135) No. 9 (+) — Chassis ground (-):</i> | Shake the ECM harness and connector, while monitoring value of voltage meter. Does the voltage change? | Repair the poor contact in ECM connector. | Contact your SOA Service Center. NOTE: Inspection by DTM is required, because probable cause is deterioration of multiple parts. |
| 3 CHECK INPUT SIGNAL FOR ECM. Measure the voltage between ECM and chassis ground. <i>Connector & terminal</i> <i>(B135) No. 8 (+) — Chassis ground (-):</i> | Is the voltage less than 0.7 V? | Go to step 4. | Contact your SOA Service Center. NOTE: Inspection by DTM is required, because probable cause is deterioration of multiple parts. |
| 4 CHECK HARNESS BETWEEN ECM AND MANIFOLD ABSOLUTE PRESSURE SENSOR CONNECTOR. 1) Turn the ignition switch to OFF. 2) Disconnect the connector from manifold absolute pressure sensor. 3) Turn the ignition switch to ON. 4) Measure the voltage between manifold absolute pressure sensor connector and engine ground. <i>Connector & terminal</i> <i>(E21) No. 3 (+) — Engine ground (-):</i> | Is the voltage more than 4.5 V? | Go to step 5. | Repair the open circuit in harness between ECM and manifold absolute pressure sensor connector. |
| 5 CHECK HARNESS BETWEEN ECM AND MANIFOLD ABSOLUTE PRESSURE SENSOR CONNECTOR. 1) Turn the ignition switch to OFF. 2) Disconnect the connector from ECM. 3) Measure the resistance of harness between ECM and manifold absolute pressure sensor connector. <i>Connector & terminal</i> <i>(B135) No. 19 — (E21) No. 2:</i> | Is the resistance less than 1 Ω ? | Go to step 6. | Repair the open circuit in harness between ECM and manifold absolute pressure sensor connector. |
| 6 CHECK HARNESS BETWEEN ECM AND MANIFOLD ABSOLUTE PRESSURE SENSOR CONNECTOR. Measure the resistance of harness between manifold absolute pressure sensor connector and engine ground. <i>Connector & terminal</i> <i>(E21) No. 1 — Engine ground:</i> | Is the resistance more than 1 M Ω ? | Go to step 7. | Repair the ground short circuit in harness between ECM and manifold absolute pressure sensor connector. |
| 7 CHECK POOR CONTACT. Check poor contact in manifold absolute pressure sensor connector. | Is there poor contact in manifold absolute pressure sensor connector? | Repair the poor contact in manifold absolute pressure sensor connector. | Replace the manifold absolute pressure sensor. <Ref. to FU(H4DOTC)-33, Manifold Absolute Pressure Sensor.> |

Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

K: DTC P0108 MANIFOLD ABSOLUTE PRESSURE/BAROMETRIC PRESSURE CIRCUIT HIGH INPUT


DTC DETECTING CONDITION:

- Immediately at fault recognition
- GENERAL DESCRIPTION <Ref. to GD(H4DOTC)-29, DTC P0108 MANIFOLD ABSOLUTE PRESSURE/BAROMETRIC PRESSURE CIRCUIT HIGH INPUT, Diagnostic Trouble Code (DTC) Detecting Criteria.>

CAUTION:

After repair or replacement of faulty parts, conduct Clear Memory Mode <Ref. to EN(H4DOTC)(diag)-46, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(H4DOTC)(diag)-39, PROCEDURE, Inspection Mode.>.

WIRING DIAGRAM:



EN-01612

Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

| Step | Check | Yes | No |
|--|--|---|---|
| 1 CHECK INPUT SIGNAL FOR ECM. Measure the voltage between ECM connector and chassis ground. <i>Connector & terminal</i> <i>(B135) No. 9 (+) — Chassis ground (-):</i> | Is the voltage more than 4.5 V? | Go to step 3. | Go to step 2. |
| 2 CHECK INPUT SIGNAL FOR ECM. Measure the voltage between ECM connector and chassis ground. <i>Connector & terminal</i> <i>(B135) No. 9 (+) — Chassis ground (-):</i> | Shake the ECM harness and connector, while monitoring value of voltage meter. Does the voltage change? | Repair the poor contact in ECM connector. | Contact your SOA Service Center. NOTE: Inspection by DTM is required, because probable cause is deterioration of multiple parts. |
| 3 CHECK INPUT SIGNAL FOR ECM. Measure the voltage between ECM connector and chassis ground. <i>Connector & terminal</i> <i>(B135) No. 8 (+) — Chassis ground (-):</i> | Is the voltage more than 4.5 V? | Go to step 4. | Contact your SOA Service Center. NOTE: Inspection by DTM is required, because probable cause is deterioration of multiple parts. |
| 4 CHECK HARNESS BETWEEN ECM AND MANIFOLD ABSOLUTE PRESSURE SENSOR CONNECTOR. 1) Turn the ignition switch to OFF. 2) Disconnect the connector from manifold absolute pressure sensor. 3) Turn the ignition switch to ON. 4) Measure the voltage between manifold absolute pressure sensor connector and engine ground. <i>Connector & terminal</i> <i>(E21) No. 3 (+) — Engine ground (-):</i> | Is the voltage more than 4.5 V? | Go to step 5. | Repair the open circuit in harness between ECM and manifold absolute pressure sensor connector. |
| 5 CHECK HARNESS BETWEEN ECM AND MANIFOLD ABSOLUTE PRESSURE SENSOR CONNECTOR. 1) Turn the ignition switch to OFF. 2) Disconnect the connector from ECM. 3) Measure the resistance of harness between ECM and manifold absolute pressure sensor connector. <i>Connector & terminal</i> <i>(B135) No. 8 — (E21) No. 1:</i> | Is the resistance less than 1 Ω ? | Go to step 6. | Repair the open circuit in harness between ECM and manifold absolute pressure sensor connector. |
| 6 CHECK HARNESS BETWEEN ECM AND MANIFOLD ABSOLUTE PRESSURE SENSOR CONNECTOR. Measure the resistance of harness between ECM and manifold absolute pressure sensor connector. <i>Connector & terminal</i> <i>(B135) No. 19 — (E21) No. 2:</i> | Is the resistance less than 1 Ω ? | Go to step 7. | Repair the open circuit in harness between ECM and manifold absolute pressure sensor connector. |
| 7 CHECK POOR CONTACT. Check poor contact in manifold absolute pressure sensor connector. | Is there poor contact in manifold absolute pressure sensor connector? | Repair the poor contact in manifold absolute pressure sensor connector. | Replace the manifold absolute pressure sensor. <Ref. to FU(H4DOTC)-33, Manifold Absolute Pressure Sensor.> |

Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

L: DTC P0111 INTAKE AIR TEMPERATURE CIRCUIT RANGE/PERFORMANCE

DTC DETECTING CONDITION:

- Two consecutive driving cycles with fault
- GENERAL DESCRIPTION <Ref. to GD(H4DOTC)-31, DTC P0111 INTAKE AIR TEMPERATURE CIRCUIT RANGE/PERFORMANCE, Diagnostic Trouble Code (DTC) Detecting Criteria.>


TROUBLE SYMPTOM:

- Erroneous idling
- Poor driving performance

CAUTION:

After repair or replacement of faulty parts, conduct Clear Memory Mode <Ref. to EN(H4DOTC)(diag)-46, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(H4DOTC)(diag)-39, PROCEDURE, Inspection Mode.>.

WIRING DIAGRAM:



EN-01613

Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

| Step | Check | Yes | No |
|--|--|---|--|
| 1 CHECK ANY OTHER DTC ON DISPLAY. | Is any other DTC displayed? | Inspect the relevant DTC using "List of Diagnostic Trouble Code (DTC)". <Ref. to EN(H4DOTC)(diag)-71, List of Diagnostic Trouble Code (DTC).> NOTE: In this case, it is not necessary to inspect DTC P0111. | Go to step 2. |
| 2 CHECK ENGINE COOLANT TEMPERATURE. 1) Start the engine and warm it up completely. 2) Measure the engine coolant temperature using Subaru Select Monitor or OBD-II general scan tool. NOTE: • Subaru Select Monitor For detailed operation procedure, refer to the "READ CURRENT DATA FOR ENGINE". <Ref. to EN(H4DOTC)(diag)-31, Subaru Select Monitor.> • OBD-II general scan tool For detailed operation procedures, refer to the OBD-II General Scan Tool Instruction Manual. | Is the engine coolant temperature 75°C (167°F) — 95°C (203°F)? | Replace the mass air flow and intake air temperature sensor. <Ref. to FU(H4DOTC)-32, Mass Air Flow and Intake Air Temperature Sensor.> | Inspect the DTC P0125 using "List of Diagnostic Trouble Code (DTC)". <Ref. to EN(H4DOTC)(diag)-71, List of Diagnostic Trouble Code (DTC).> |

Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

M: DTC P0112 INTAKE AIR TEMPERATURE CIRCUIT LOW INPUT

DTC DETECTING CONDITION:

- Immediately at fault recognition
- GENERAL DESCRIPTION <Ref. to GD(H4DOTC)-33, DTC P0112 INTAKE AIR TEMPERATURE CIRCUIT LOW INPUT, Diagnostic Trouble Code (DTC) Detecting Criteria.>


TROUBLE SYMPTOM:

- Erroneous idling
- Poor driving performance

CAUTION:

After repair or replacement of faulty parts, conduct Clear Memory Mode <Ref. to EN(H4DOTC)(diag)-46, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(H4DOTC)(diag)-39, PROCEDURE, Inspection Mode.>.

WIRING DIAGRAM:



EN-01613

Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

| Step | Check | Yes | No |
|--|---|---|--|
| <p>1</p> <p>CHECK CURRENT DATA.</p> <p>1) Start the engine.</p> <p>2) Read the data of intake air temperature sensor signal using Subaru Select Monitor or the OBD-II general scan tool.</p> <p>NOTE:</p> <ul style="list-style-type: none"> • Subaru Select Monitor <p>For detailed operation procedure, refer to the "READ CURRENT DATA FOR ENGINE". <Ref. to EN(H4DOTC)(diag)-31, Subaru Select Monitor.></p> <ul style="list-style-type: none"> • OBD-II general scan tool <p>For detailed operation procedure, refer to the OBD-II General Scan Tool Instruction Manual.</p> | <p>Is the temperature more than 55°C (131°F)?</p> | <p>Go to step 2.</p> | <p>Repair the poor contact.</p> <p>NOTE:</p> <p>In this case, repair the following:</p> <ul style="list-style-type: none"> • Poor contact mass air flow and intake air temperature sensor • Poor contact in ECM • Poor contact in joint connector |
| <p>2</p> <p>CHECK HARNESS BETWEEN MASS AIR FLOW AND INTAKE AIR TEMPERATURE SENSOR AND ECM CONNECTOR.</p> <p>1) Turn the ignition switch to OFF.</p> <p>2) Disconnect the connector from mass air flow and intake air temperature sensor.</p> <p>3) Turn the ignition switch to ON.</p> <p>4) Read the data of intake air temperature sensor signal using Subaru Select Monitor or the OBD-II general scan tool.</p> <p>NOTE:</p> <ul style="list-style-type: none"> • Subaru Select Monitor <p>For detailed operation procedure, refer to the "READ CURRENT DATA FOR ENGINE". <Ref. to EN(H4DOTC)(diag)-31, Subaru Select Monitor.></p> <ul style="list-style-type: none"> • OBD-II general scan tool <p>For detailed operation procedure, refer to the OBD-II General Scan Tool Instruction Manual.</p> | <p>Is the temperature less than – 36°C (–33°F)?</p> | <p>Replace the mass air flow and intake air temperature sensor. <Ref. to FU(H4DOTC)-32, Mass Air Flow and Intake Air Temperature Sensor.></p> | <p>Repair the ground short circuit in harness between mass air flow and intake air temperature sensor and ECM connector.</p> |

Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

N: DTC P0113 INTAKE AIR TEMPERATURE CIRCUIT HIGH INPUT

DTC DETECTING CONDITION:

- Immediately at fault recognition
- GENERAL DESCRIPTION <Ref. to GD(H4DOTC)-35, DTC P0113 INTAKE AIR TEMPERATURE CIRCUIT HIGH INPUT, Diagnostic Trouble Code (DTC) Detecting Criteria.>


TROUBLE SYMPTOM:

- Erroneous idling
- Poor driving performance

CAUTION:

After repair or replacement of faulty parts, conduct Clear Memory Mode <Ref. to EN(H4DOTC)(diag)-46, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(H4DOTC)(diag)-39, PROCEDURE, Inspection Mode.>.

WIRING DIAGRAM:



EN-01613

Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

| Step | Check | Yes | No |
|---|---|---|---|
| <p>1 CHECK CURRENT DATA.</p> <p>1) Start the engine.</p> <p>2) Read the data of intake air temperature sensor signal using Subaru Select Monitor or the OBD-II general scan tool.</p> <p>NOTE:</p> <ul style="list-style-type: none"> • Subaru Select Monitor <p>For detailed operation procedure, refer to the "READ CURRENT DATA FOR ENGINE". <Ref. to EN(H4DOTC)(diag)-31, Subaru Select Monitor.></p> <ul style="list-style-type: none"> • OBD-II general scan tool <p>For detailed operation procedure, refer to the OBD-II General Scan Tool Instruction Manual.</p> | <p>Is the temperature less than – 36°C (–33°F)?</p> | <p>Go to step 2.</p> | <p>Repair the poor contact.</p> <p>NOTE:</p> <p>In this case, repair the following:</p> <ul style="list-style-type: none"> • Poor contact in mass air flow and intake air temperature sensor • Poor contact in ECM • Poor contact in joint connector |
| <p>2 CHECK HARNESS BETWEEN MASS AIR FLOW AND INTAKE AIR TEMPERATURE SENSOR AND ECM CONNECTOR.</p> <p>1) Turn the ignition switch to OFF.</p> <p>2) Disconnect the connector from mass air flow and intake air temperature sensor.</p> <p>3) Measure the voltage between mass air flow and intake air temperature sensor connector and engine ground.</p> <p>Connector & terminal (B3) No. 4 (+) — Engine ground (-):</p> | <p>Is the voltage more than 10 V?</p> | <p>Repair the battery short circuit in harness between mass air flow and intake air temperature sensor and ECM connector.</p> | <p>Go to step 3.</p> |
| <p>3 CHECK HARNESS BETWEEN MASS AIR FLOW AND INTAKE AIR TEMPERATURE SENSOR AND ECM CONNECTOR.</p> <p>1) Turn the ignition switch to ON.</p> <p>2) Measure the voltage between mass air flow and intake air temperature sensor connector and engine ground.</p> <p>Connector & terminal (B3) No. 4 (+) — Engine ground (-):</p> | <p>Is the voltage more than 10 V?</p> | <p>Repair the battery short circuit in harness between mass air flow and intake air temperature sensor and ECM connector.</p> | <p>Go to step 4.</p> |
| <p>4 CHECK HARNESS BETWEEN MASS AIR FLOW AND INTAKE AIR TEMPERATURE SENSOR AND ECM CONNECTOR.</p> <p>Measure the voltage between mass air flow and intake air temperature sensor and manifold absolute pressure sensor connector and engine ground.</p> <p>Connector & terminal (B3) No. 4 (+) — Engine ground (-):</p> | <p>Is the voltage more than 4 V?</p> | <p>Go to step 5.</p> | <p>Repair the harness and connector.</p> <p>NOTE:</p> <p>In this case, repair the following:</p> <ul style="list-style-type: none"> • Open circuit in harness between mass air flow and intake air temperature sensor and ECM connector • Poor contact in mass air flow and intake air temperature sensor • Poor contact in ECM • Poor contact in joint connector |

Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

| Step | Check | Yes | No |
|--|---|---|---|
| <p>5</p> <p>CHECK HARNESS BETWEEN MASS AIR FLOW AND INTAKE AIR TEMPERATURE SENSOR AND ECM CONNECTOR.</p> <p>1) Turn the ignition switch to OFF.</p> <p>2) Measure the resistance of harness between mass air flow and intake air temperature sensor and engine ground.</p> <p>Connector & terminal (B3) No. 5 — Engine ground:</p> | <p>Is the resistance less than 5 Ω?</p> | <p>Replace the mass air flow and intake air temperature sensor. <Ref. to FU(H4DOTC)-32, Mass Air Flow and Intake Air Temperature Sensor.></p> | <p>Repair the harness and connector.</p> <p>NOTE: In this case, repair the following:</p> <ul style="list-style-type: none"> • Open circuit in harness between mass air flow and intake air temperature sensor and ECM connector • Poor contact in mass air flow and intake air temperature sensor • Poor contact in ECM • Poor contact in joint connector |

Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

O: DTC P0117 ENGINE COOLANT TEMPERATURE CIRCUIT LOW INPUT

DTC DETECTING CONDITION:

- Immediately at fault recognition
- GENERAL DESCRIPTION <Ref. to GD(H4DOTC)-37, DTC P0117 ENGINE COOLANT TEMPERATURE CIRCUIT LOW INPUT, Diagnostic Trouble Code (DTC) Detecting Criteria.>


TROUBLE SYMPTOM:

- Hard to start
- Erroneous idling
- Poor driving performance

CAUTION:

After repair or replacement of faulty parts, conduct Clear Memory Mode <Ref. to EN(H4DOTC)(diag)-46, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(H4DOTC)(diag)-39, PROCEDURE, Inspection Mode.>.

WIRING DIAGRAM:



EN-01614

Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

| Step | Check | Yes | No |
|---|--|---|---|
| <p>1</p> <p>CHECK CURRENT DATA.</p> <p>1) Start the engine.</p> <p>2) Read the data of engine coolant temperature sensor signal using Subaru Select Monitor or OBD-II general scan tool.</p> <p>NOTE:</p> <ul style="list-style-type: none"> • Subaru Select Monitor <p>For detailed operation procedure, refer to the "READ CURRENT DATA FOR ENGINE". <Ref. to EN(H4DOTC)(diag)-31, Subaru Select Monitor.></p> <ul style="list-style-type: none"> • OBD-II general scan tool <p>For detailed operation procedures, refer to the OBD-II General Scan Tool Instruction Manual.</p> | <p>Is the temperature more than 120°C (248°F)?</p> | <p>Go to step 2.</p> | <p>Repair the poor contact.</p> <p>NOTE:</p> <p>In this case, repair the following:</p> <ul style="list-style-type: none"> • Poor contact in engine coolant temperature sensor • Poor contact in ECM • Poor contact in coupling connector • Poor contact in joint connector |
| <p>2</p> <p>CHECK HARNESS BETWEEN ENGINE COOLANT TEMPERATURE SENSOR AND ECM CONNECTOR.</p> <p>1) Turn the ignition switch to OFF.</p> <p>2) Disconnect the connector from engine coolant temperature sensor.</p> <p>3) Turn the ignition switch to ON.</p> <p>4) Read the data of engine coolant temperature sensor signal using Subaru Select Monitor or OBD-II general scan tool.</p> <p>NOTE:</p> <ul style="list-style-type: none"> • Subaru Select Monitor <p>For detailed operation procedure, refer to the "READ CURRENT DATA FOR ENGINE". <Ref. to EN(H4DOTC)(diag)-31, Subaru Select Monitor.></p> <ul style="list-style-type: none"> • OBD-II general scan tool <p>For detailed operation procedures, refer to the OBD-II General Scan Tool Instruction Manual.</p> | <p>Is the temperature less than –40°C (–40°F)?</p> | <p>Replace the engine coolant temperature sensor. <Ref. to FU(H4DOTC)-27, Engine Coolant Temperature Sensor.></p> | <p>Repair the ground short circuit in harness between engine coolant temperature sensor and ECM connector.</p> |

Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

P: DTC P0118 ENGINE COOLANT TEMPERATURE CIRCUIT HIGH INPUT

DTC DETECTING CONDITION:

- Immediately at fault recognition
- GENERAL DESCRIPTION <Ref. to GD(H4DOTC)-39, DTC P0118 ENGINE COOLANT TEMPERATURE CIRCUIT HIGH INPUT, Diagnostic Trouble Code (DTC) Detecting Criteria.>


TROUBLE SYMPTOM:

- Hard to start
- Erroneous idling
- Poor driving performance

CAUTION:

After repair or replacement of faulty parts, conduct Clear Memory Mode <Ref. to EN(H4DOTC)(diag)-46, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(H4DOTC)(diag)-39, PROCEDURE, Inspection Mode.>.

WIRING DIAGRAM:



EN-01614

Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

| Step | Check | Yes | No |
|--|--|---|---|
| <p>1</p> <p>CHECK CURRENT DATA.</p> <p>1) Start the engine.</p> <p>2) Read the data of engine coolant temperature sensor signal using Subaru Select Monitor or OBD-II general scan tool.</p> <p>NOTE:</p> <ul style="list-style-type: none"> Subaru Select Monitor <p>For detailed operation procedure, refer to the "READ CURRENT DATA FOR ENGINE". <Ref. to EN(H4DOTC)(diag)-31, Subaru Select Monitor.></p> <ul style="list-style-type: none"> OBD-II general scan tool <p>For detailed operation procedures, refer to the OBD-II General Scan Tool Instruction Manual.</p> | <p>Is the temperature less than -40°C (-40°F)?</p> | <p>Go to step 2.</p> | <p>Repair the poor contact.</p> <p>NOTE:</p> <p>In this case, repair the following:</p> <ul style="list-style-type: none"> Poor contact in engine coolant temperature sensor Poor contact in ECM Poor contact in coupling connector Poor contact in joint connector |
| <p>2</p> <p>CHECK HARNESS BETWEEN ENGINE COOLANT TEMPERATURE SENSOR AND ECM CONNECTOR.</p> <p>1) Turn the ignition switch to OFF.</p> <p>2) Disconnect the connector from engine coolant temperature sensor.</p> <p>3) Measure the voltage between engine coolant temperature sensor connector and engine ground.</p> <p>Connector & terminal (E8) No. 2 (+) — Engine ground (-):</p> | <p>Is the voltage more than 10 V?</p> | <p>Repair the battery short circuit in harness between ECM and engine coolant temperature sensor connector.</p> | <p>Go to step 3.</p> |
| <p>3</p> <p>CHECK HARNESS BETWEEN ENGINE COOLANT TEMPERATURE SENSOR AND ECM CONNECTOR.</p> <p>1) Turn the ignition switch to ON.</p> <p>2) Measure the voltage between engine coolant temperature sensor connector and engine ground.</p> <p>Connector & terminal (E8) No. 2 (+) — Engine ground (-):</p> | <p>Is the voltage more than 10 V?</p> | <p>Repair the battery short circuit in harness between ECM and engine coolant temperature sensor connector.</p> | <p>Go to step 4.</p> |
| <p>4</p> <p>CHECK HARNESS BETWEEN ENGINE COOLANT TEMPERATURE SENSOR AND ECM CONNECTOR.</p> <p>Measure the voltage between engine coolant temperature sensor connector and engine ground.</p> <p>Connector & terminal (E8) No. 2 (+) — Engine ground (-):</p> | <p>Is the voltage more than 4 V?</p> | <p>Go to step 5.</p> | <p>Repair the harness and connector.</p> <p>NOTE:</p> <p>In this case, repair the following:</p> <ul style="list-style-type: none"> Open circuit in harness between ECM and engine coolant temperature sensor connector Poor contact in engine coolant temperature sensor connector Poor contact in ECM connector Poor contact in coupling connector Poor contact in joint connector |

Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

| Step | Check | Yes | No |
|--|---|---|---|
| <p>5</p> <p>CHECK HARNESS BETWEEN ENGINE COOLANT TEMPERATURE SENSOR AND ECM CONNECTOR.</p> <p>1) Turn the ignition switch to OFF.</p> <p>2) Measure the resistance of harness between engine coolant temperature sensor connector and engine ground.</p> <p>Connector & terminal (E8) No. 1 — Engine ground:</p> | <p>Is the resistance less than 5 Ω?</p> | <p>Replace the engine coolant temperature sensor. <Ref. to FU(H4DOTC)-27, Engine Coolant Temperature Sensor.></p> | <p>Repair the harness and connector.</p> <p>NOTE: In this case, repair the following:</p> <ul style="list-style-type: none"> • Open circuit in harness between ECM and engine coolant temperature sensor connector • Poor contact in engine coolant temperature sensor connector • Poor contact in ECM connector • Poor contact in coupling connector • Poor contact in joint connector |

Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

Q: DTC P0121 THROTTLE/PEDAL POSITION SENSOR/SWITCH "A" CIRCUIT RANGE/PERFORMANCE

DTC DETECTING CONDITION:

- Two consecutive driving cycles with fault
- GENERAL DESCRIPTION <Ref. to GD(H4DOTC)-41, DTC P0121 THROTTLE/PEDAL POSITION SENSOR/SWITCH "A" CIRCUIT RANGE/PERFORMANCE, Diagnostic Trouble Code (DTC) Detecting Criteria.>


TROUBLE SYMPTOM:

- Erroneous idling
- Engine stalls.
- Poor driving performance
- Fuel is cut.

CAUTION:

After repair or replacement of faulty parts, conduct Clear Memory Mode <Ref. to EN(H4DOTC)(diag)-46, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(H4DOTC)(diag)-39, PROCEDURE, Inspection Mode.>.

WIRING DIAGRAM:



EN-01615

Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

| Step | Check | Yes | No |
|---|-----------------------------|---|--|
| 1 CHECK ANY OTHER DTC ON DISPLAY. | Is any other DTC displayed? | Inspect the relevant DTC using "List of Diagnostic Trouble Code (DTC)". <Ref. to EN(H4DOTC)(diag)-71, List of Diagnostic Trouble Code (DTC).> NOTE: In this case, it is not necessary to inspect DTC P0121. | Replace the throttle position sensor. <Ref. to FU(H4DOTC)-31, Throttle Position Sensor.> |

Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

R: DTC P0122 THROTTLE/PEDAL POSITION SENSOR/SWITCH "A" CIRCUIT LOW INPUT

DTC DETECTING CONDITION:

- Immediately at fault recognition
- GENERAL DESCRIPTION <Ref. to GD(H4DOTC)-44, DTC P0122 THROTTLE/PEDAL POSITION SENSOR/SWITCH "A" CIRCUIT LOW INPUT, Diagnostic Trouble Code (DTC) Detecting Criteria.>


TROUBLE SYMPTOM:

- Erroneous idling
- Engine stalls.
- Poor driving performance

CAUTION:

After repair or replacement of faulty parts, conduct Clear Memory Mode <Ref. to EN(H4DOTC)(diag)-46, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(H4DOTC)(diag)-39, PROCEDURE, Inspection Mode.>.

WIRING DIAGRAM:



EN-01615

Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

| Step | Check | Yes | No |
|---|--|---|---|
| 1 CHECK CURRENT DATA. 1) Start the engine. 2) Read the data of throttle position sensor signal using Subaru Select Monitor or OBD-II general scan tool. NOTE: • Subaru Select Monitor For detailed operation procedure, refer to the "READ CURRENT DATA FOR ENGINE". <Ref. to EN(H4DOTC)(diag)-31, Subaru Select Monitor.> • OBD-II general scan tool For detailed operation procedures, refer to the OBD-II General Scan Tool Instruction Manual. | Is the voltage less than 0.15 V? | Go to step 2. | Even if malfunction indicator light lights up, the circuit has returned to a normal condition at this time. A temporary poor contact of the connector may be the cause. NOTE: In this case, repair the following: • Poor contact in throttle position sensor connector • Poor contact in ECM connector • Poor contact in coupling connector |
| 2 CHECK INPUT SIGNAL FOR ECM. Measure the voltage between ECM connector and chassis ground while throttle valve is fully closed. Connector & terminal (B135) No. 9 (+) — Chassis ground (-): | Is the voltage more than 4.5 V? | Go to step 4. | Go to step 3. |
| 3 CHECK INPUT SIGNAL FOR ECM. Measure the voltage between ECM connector and chassis ground. Connector & terminal (B135) No. 9 (+) — Chassis ground (-): | Shake the ECM harness and connector, while monitoring value of voltage meter. Does the voltage change? | Repair the poor contact in ECM connector. | Contact your SOA Service Center. NOTE: Inspection by DTM is required, because probable cause is deterioration of multiple parts. |
| 4 CHECK INPUT SIGNAL FOR ECM. Measure the voltage between ECM connector and chassis ground. Connector & terminal (B135) No. 7 (+) — Chassis ground (-): | Is the voltage less than 0.15 V? | Go to step 6. | Go to step 5. |
| 5 CHECK INPUT SIGNAL FOR ECM. (USING SUBARU SELECT MONITOR) Measure the voltage between ECM connector and chassis ground. | Shake the ECM harness and connector, while monitoring value of Subaru Select Monitor. Does the voltage change? | Repair the poor contact in ECM connector. | Go to step 6. |

Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

| Step | Check | Yes | No |
|---|---|---|--|
| <p>6</p> <p>CHECK HARNESS BETWEEN ECM AND THROTTLE POSITION SENSOR CONNECTOR.</p> <p>1) Turn the ignition switch to OFF. 2) Disconnect the connectors from throttle position sensor. 3) Turn the ignition switch to ON. 4) Measure the voltage between throttle position sensor connector and engine ground.</p> <p>Connector & terminal (E13) No. 1 (+) — Engine ground (-):</p> | <p>Is the voltage more than 4.5 V?</p> | <p>Go to step 7.</p> | <p>Repair the harness and connector.</p> <p>NOTE: In this case, repair the following:</p> <ul style="list-style-type: none"> • Open circuit in harness between throttle position sensor and ECM connector • Poor contact in throttle position sensor connector • Poor contact in ECM connector • Poor contact in coupling connector • Poor contact in joint connector |
| <p>7</p> <p>CHECK HARNESS BETWEEN ECM AND THROTTLE POSITION SENSOR CONNECTOR.</p> <p>1) Turn the ignition switch to OFF. 2) Measure the resistance of harness between ECM connector and throttle position sensor connector.</p> <p>Connector & terminal (B135) No. 7 — (E13) No. 3:</p> | <p>Is the resistance less than 1 Ω?</p> | <p>Go to step 8.</p> | <p>Repair the harness and connector.</p> <p>NOTE: In this case, repair the following:</p> <ul style="list-style-type: none"> • Open circuit in harness between throttle position sensor and ECM connector • Poor contact in ECM connector • Poor contact in throttle position sensor connector • Poor contact in coupling connector |
| <p>8</p> <p>CHECK HARNESS BETWEEN ECM AND THROTTLE POSITION SENSOR CONNECTOR.</p> <p>Measure the resistance of harness between throttle position sensor connector and engine ground.</p> <p>Connector & terminal (E13) No. 3 — Engine ground:</p> | <p>Is the resistance more than 1 MΩ?</p> | <p>Go to step 9.</p> | <p>Repair the ground short circuit in harness between throttle position sensor and ECM connector.</p> |
| <p>9</p> <p>CHECK POOR CONTACT.</p> <p>Check poor contact in throttle position sensor connector.</p> | <p>Is there poor contact in throttle position sensor connector?</p> | <p>Repair the poor contact in throttle position sensor connector.</p> | <p>Replace the throttle position sensor. <Ref. to FU(H4DOTC)-31, Throttle Position Sensor.></p> |

Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

S: DTC P0123 THROTTLE/PEDAL POSITION SENSOR/SWITCH "A" CIRCUIT HIGH INPUT

DTC DETECTING CONDITION:

- Immediately at fault recognition
- GENERAL DESCRIPTION <Ref. to GD(H4DOTC)-46, DTC P0123 THROTTLE/PEDAL POSITION SENSOR/SWITCH "A" CIRCUIT HIGH INPUT, Diagnostic Trouble Code (DTC) Detecting Criteria.>


TROUBLE SYMPTOM:

- Erroneous idling
- Engine stalls.
- Poor driving performance

CAUTION:

After repair or replacement of faulty parts, conduct Clear Memory Mode <Ref. to EN(H4DOTC)(diag)-46, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(H4DOTC)(diag)-39, PROCEDURE, Inspection Mode.>.

WIRING DIAGRAM:



EN-01615

Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

| Step | Check | Yes | No |
|---|---|---|--|
| <p>1</p> <p>CHECK CURRENT DATA.</p> <p>1) Start the engine.</p> <p>2) Read the data of throttle position sensor signal using Subaru Select Monitor or OBD-II general scan tool.</p> <p>NOTE:</p> <ul style="list-style-type: none"> Subaru Select Monitor <p>For detailed operation procedure, refer to the "READ CURRENT DATA FOR ENGINE". <Ref. to EN(H4DOTC)(diag)-31, Subaru Select Monitor.></p> <ul style="list-style-type: none"> OBD-II general scan tool <p>For detailed operation procedures, refer to the OBD-II General Scan Tool Instruction Manual.</p> | <p>Is the voltage more than 4.7 V?</p> | <p>Go to step 2.</p> | <p>Even if malfunction indicator light lights up, the circuit has returned to a normal condition at this time. A temporary poor contact of the connector may be the cause.</p> <p>NOTE:</p> <p>In this case, repair the following:</p> <ul style="list-style-type: none"> Poor contact in throttle position sensor connector Poor contact in ECM connector Poor contact in coupling connector |
| <p>2</p> <p>CHECK HARNESS BETWEEN THROTTLE POSITION SENSOR AND ECM CONNECTOR.</p> <p>1) Turn the ignition switch to OFF.</p> <p>2) Disconnect the connector from throttle position sensor.</p> <p>3) Measure the resistance of harness between throttle position sensor connector and engine ground.</p> <p>Connector & terminal (E13) No. 2 — Engine ground:</p> | <p>Is the resistance less than 5 Ω?</p> | <p>Go to step 3.</p> | <p>Repair the harness and connector.</p> <p>NOTE:</p> <p>In this case, repair the following:</p> <ul style="list-style-type: none"> Open circuit in harness between throttle position sensor and ECM connector Poor contact in coupling connector Poor contact in joint connector |
| <p>3</p> <p>CHECK HARNESS BETWEEN THROTTLE POSITION SENSOR AND ECM CONNECTOR.</p> <p>1) Turn the ignition switch to ON.</p> <p>2) Measure the voltage between throttle position sensor connector and engine ground.</p> <p>Connector & terminal (E13) No. 3 (+) — Engine ground (-):</p> | <p>Is the voltage more than 4.7 V?</p> | <p>Repair the battery short circuit in harness between throttle position sensor and ECM connector. After repair, replace the ECM. <Ref. to FU(H4DOTC)-48, Engine Control Module (ECM).></p> | <p>Replace the throttle position sensor. <Ref. to FU(H4DOTC)-31, Throttle Position Sensor.></p> |

Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

T: DTC P0125 INSUFFICIENT COOLANT TEMPERATURE FOR CLOSED LOOP FUEL CONTROL

DTC DETECTING CONDITION:

- Two consecutive driving cycles with fault
- GENERAL DESCRIPTION <Ref. to GD(H4DOTC)-48, DTC P0125 INSUFFICIENT COOLANT TEMPERATURE FOR CLOSED LOOP FUEL CONTROL, Diagnostic Trouble Code (DTC) Detecting Criteria.>


TROUBLE SYMPTOM:

Engine will not return to idling.

CAUTION:

After repair or replacement of faulty parts, conduct Clear Memory Mode <Ref. to EN(H4DOTC)(diag)-46, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(H4DOTC)(diag)-39, PROCEDURE, Inspection Mode.>.

WIRING DIAGRAM:



EN-01614

Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

| Step | Check | Yes | No |
|---|--|---|--|
| 1 CHECK ANY OTHER DTC ON DISPLAY. | Is any other DTC displayed? | Inspect the relevant DTC using "List of Diagnostic Trouble Code (DTC)". <Ref. to EN(H4DOTC)(diag)-71, List of Diagnostic Trouble Code (DTC).> NOTE: In this case, it is not necessary to inspect DTC P0125. | Go to step 2. |
| 2 CHECK ENGINE COOLING SYSTEM. NOTE: Check the following items. <ul style="list-style-type: none">• Thermostat open stuck• Coolant level• Coolant freeze• Tire diameter | Is there a fault in engine cooling system? | Replace the thermostat. <Ref. to CO(H4SO)-17, Thermostat.> | Replace the engine coolant temperature sensor. <Ref. to FU(H4DOTC)-27, Engine Coolant Temperature Sensor.> |

Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

U: DTC P0128 COOLANT THERMOSTAT (COOLANT TEMPERATURE BELOW THERMOSTAT REGULATING TEMPERATURE)

DTC DETECTING CONDITION:

- Two consecutive driving cycles with fault
- GENERAL DESCRIPTION <Ref. to GD(H4DOTC)-50, DTC P0128 COOLANT THERMOSTAT (COOLANT TEMPERATURE BELOW THERMOSTAT REGULATING TEMPERATURE), Diagnostic Trouble Code (DTC) Detecting Criteria.>

TROUBLE SYMPTOM:

Thermostat remains open.

CAUTION:

After repair or replacement of faulty parts, conduct Clear Memory Mode <Ref. to EN(H4DOTC)(diag)-46, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(H4DOTC)(diag)-39, PROCEDURE, Inspection Mode.>.

| Step | Check | Yes | No | |
|------|--|---|---|---|
| 1 | CHECK VEHICLE CONDITION. | Was the vehicle driven or idled with the engine partially submerged under water? | In this case, it is not necessary to inspect DTC P0128. | Go to step 2. |
| 2 | CHECK FOR OTHER DTC ON DISPLAY. | Is any other DTC displayed? | Inspect the relevant DTC using "List of Diagnostic Trouble Codes (DTC)". <Ref. to EN(H4DOTC)(diag)-71, List of Diagnostic Trouble Code (DTC).> | Go to step 3. |
| 3 | CHECK ENGINE COOLANT. | Are coolant level and mixture ratio of cooling water to anti-freeze solution correct? | Go to step 4. | Replace the engine coolant. <Ref. to CO(H4SO)-12, REPLACEMENT, Engine Coolant.> |
| 4 | CHECK RADIATOR FAN. 1) Start the engine. 2) Check radiator fan operation. | Does the radiator fan continuously rotate for more than 3 minutes during idling? | Repair radiator fan circuit. <Ref. to CO(H4SO)-22, Radiator Main Fan and Fan Motor.> and <Ref. to CO(H4SO)-23, Radiator Sub Fan and Fan Motor.> | Replace the thermostat. <Ref. to CO(H4SO)-17, Thermostat.> |

Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

V: DTC P0129 ATMOSPHERIC PRESSURE SENSOR CIRCUIT RANGE/PERFORMANCE

DTC DETECTING CONDITION:

- Two consecutive driving cycles with fault
- GENERAL DESCRIPTION <Ref. to GD(H4DOTC)-52, DTC P0129 BAROMETRIC PRESSURE TOO LOW, Diagnostic Trouble Code (DTC) Detecting Criteria.>

CAUTION:

After repair or replacement of faulty parts, conduct Clear Memory Mode <Ref. to EN(H4DOTC)(diag)-46, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(H4DOTC)(diag)-39, PROCEDURE, Inspection Mode.>.

| Step | Check | Yes | No |
|--------------------------------------|-----------------------------|---|--|
| 1 CHECK ANY OTHER DTC ON DISPLAY. | Is any other DTC displayed? | Replace the ECM. <Ref. to FU(H4DOTC)-48, Engine Control Module (ECM).> NOTE: Atmospheric pres- sure sensor is built into ECM. | NOTE: It is not necessary to inspect DTC P0129. |

Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

W: DTC P0130 O₂ SENSOR CIRCUIT (BANK 1 SENSOR 1)


DTC DETECTING CONDITION:

- Immediately at fault recognition
- GENERAL DESCRIPTION <Ref. to GD(H4DOTC)-53, DTC P0130 O₂ SENSOR CIRCUIT (BANK 1 SENSOR 1), Diagnostic Trouble Code (DTC) Detecting Criteria.>

CAUTION:

After repair or replacement of faulty parts, conduct Clear Memory Mode <Ref. to EN(H4DOTC)(diag)-46, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(H4DOTC)(diag)-39, PROCEDURE, Inspection Mode.>.

WIRING DIAGRAM:



EN-01610

Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

| Step | Check | Yes | No |
|--|--|---|--|
| 1 CHECK ANY OTHER DTC ON DISPLAY. | Is any other DTC displayed? | Inspect the relevant DTC using "List of Diagnostic Trouble Code (DTC)". <Ref. to EN(H4DOTC)(diag)-71, List of Diagnostic Trouble Code (DTC).> | Go to step 2. |
| 2 CHECK FRONT (A/F) OXYGEN SENSOR DATA. 1) Start the engine. 2) While observing the Subaru Select Monitor or OBD-II general scan tool screen, warm-up the engine until coolant temperature is above 70°C (158°F). If the engine is already warmed-up, operate at idle speed for at least 1 minute. 3) Read the data of front oxygen (A/F) sensor signal using Subaru Select Monitor or OBD-II general scan tool. NOTE: • Subaru Select Monitor For detailed operation procedure, refer to the "READ CURRENT DATA FOR ENGINE". <Ref. to EN(H4DOTC)(diag)-31, Subaru Select Monitor.> • OBD-II general scan tool For detailed operation procedures, refer to the OBD-II General Scan Tool Instruction Manual. | Is the measured value 0.85 — 1.15 (in idling)? | Go to step 3. | Go to step 4. |
| 3 CHECK REAR OXYGEN SENSOR SIGNAL. 1) Race the engine at speeds from idling to 5,000 rpm for a total of 5 cycles. NOTE: To increase the engine speed to 5,000 rpm, slowly depress accelerator pedal, taking approx. 5 seconds, and quickly release accelerator pedal to decrease engine speed. 2) Operate the LED operation mode for engine. NOTE: • Subaru Select Monitor For detailed operation procedure, refer to the "LED OPERATION MODE FOR ENGINE". <Ref. to EN(H4DOTC)(diag)-31, Subaru Select Monitor.> | Does the LED of {Rear O ₂ Rich Signal} blink? | Repair the poor contact in front oxygen (A/F) sensor and rear oxygen sensor connector. | Check the rear oxygen sensor circuit. <Ref. to FU(H4DOTC)-45, Rear Oxygen Sensor.> |
| 4 CHECK EXHAUST SYSTEM. Check the exhaust system parts. NOTE: Check the following items. <ul style="list-style-type: none"> • Loose installation of portions • Damage (crack, hole etc.) of parts • Looseness of front oxygen (A/F) sensor • Looseness and ill fitting of parts between front oxygen (A/F) sensor and rear oxygen sensor | Is there a fault in exhaust system? | Repair or replace the faulty parts. | Replace the front oxygen (A/F) sensor. <Ref. to FU(H4DOTC)-43, Front Oxygen (A/F) Sensor.> |

Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

X: DTC P0133 O₂ SENSOR CIRCUIT SLOW RESPONSE (BANK 1 SENSOR 1)


DTC DETECTING CONDITION:

- Two consecutive driving cycles with fault
- GENERAL DESCRIPTION <Ref. to GD(H4DOTC)-55, DTC P0133 O₂ SENSOR CIRCUIT SLOW RESPONSE (BANK 1 SENSOR 1), Diagnostic Trouble Code (DTC) Detecting Criteria.>

CAUTION:

After repair or replacement of faulty parts, conduct Clear Memory Mode <Ref. to EN(H4DOTC)(diag)-46, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(H4DOTC)(diag)-39, PROCEDURE, Inspection Mode.>.

WIRING DIAGRAM:



EN-01610

Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

| | Step | Check | Yes | No |
|---|---|-------------------------------------|--|--|
| 1 | CHECK ANY OTHER DTC ON DISPLAY. | Is any other DTC displayed? | Inspect the relevant DTC using "List of Diagnostic Trouble Code (DTC)". <Ref. to EN(H4DOTC)(diag)-71, List of Diagnostic Trouble Code (DTC).> NOTE: In this case, it is not necessary to inspect DTC P0133. | Go to step 2. |
| 2 | CHECK EXHAUST SYSTEM. NOTE: Check the following items. <ul style="list-style-type: none">• Loose installation of front portion of exhaust pipe onto cylinder heads• Loose connection between front exhaust pipe and front catalytic converter• Damage of exhaust pipe resulting in a hole | Is there a fault in exhaust system? | Repair the exhaust system. | Replace the front oxygen (A/F) sensor. <Ref. to FU(H4DOTC)-43, Front Oxygen (A/F) Sensor.> |

Y: DTC P0134 O₂ SENSOR CIRCUIT NO ACTIVITY DETECTED (BANK 1 SENSOR 1)

NOTE:

For the diagnostic procedure, refer to DTC P0130. <Ref. to EN(H4DOTC)(diag)-126, DTC P0130 O₂ SENSOR CIRCUIT (BANK 1 SENSOR 1), Diagnostic Procedure with Diagnostic Trouble Code (DTC).>

Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

Z: DTC P0137 O₂ SENSOR CIRCUIT LOW VOLTAGE (BANK 1 SENSOR 2)


DTC DETECTING CONDITION:

- Two consecutive driving cycles with fault
- GENERAL DESCRIPTION <Ref. to GD(H4DOTC)-60, DTC P0137 O₂ SENSOR CIRCUIT LOW VOLTAGE (BANK 1 SENSOR 2), Diagnostic Trouble Code (DTC) Detecting Criteria.>

CAUTION:

After repair or replacement of faulty parts, conduct Clear Memory Mode <Ref. to EN(H4DOTC)(diag)-46, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(H4DOTC)(diag)-39, PROCEDURE, Inspection Mode.>.

WIRING DIAGRAM:



EN-01611

Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

| Step | Check | Yes | No |
|------|---|----------------------------------|---|
| 1 | CHECK ANY OTHER DTC ON DISPLAY. | Is any other DTC displayed? | Using the List of Diagnostic Trouble Code (DTC), check the appropriate DTC. <Ref. to EN(H4DOTC)(diag)-71, List of Diagnostic Trouble Code (DTC).> |
| 2 | CHECK REAR OXYGEN SENSOR DATA. 1) Warm-up the engine until engine coolant temperature is above 70°C (158°F), and keep the engine speed at 2,000 rpm to 3,000 rpm for 2 minutes. 2) Read the data of rear oxygen sensor signal using Subaru Select Monitor or OBD-II general scan tool. NOTE: • Subaru Select Monitor For detailed operation procedure, refer to the "READ CURRENT DATA SHOWN ON DISPLAY FOR ENGINE". <Ref. to EN(H4DOTC)(diag)-31, Subaru Select Monitor.> • OBD-II general scan tool For detailed operation procedures, refer to the OBD-II General Scan Tool Instruction Manual. | Does the value fluctuate? | Go to step 6. |
| 3 | CHECK REAR OXYGEN SENSOR DATA. Read the data of rear oxygen sensor signal using Subaru Select Monitor or OBD-II general scan tool. | Is the voltage 0.2 — 0.4 V? | Go to step 4. |
| 4 | CHECK HARNESS BETWEEN ECM AND REAR OXYGEN SENSOR CONNECTOR. 1) Turn the ignition switch to OFF. 2) Disconnect the connectors from ECM and rear oxygen sensor. 3) Measure the resistance of harness between ECM and rear oxygen sensor connector. Connector & terminal (B135) No. 17 — (B19) No. 3: | Is the resistance more than 3 Ω? | Repair the open circuit in harness between ECM and rear oxygen sensor connector. |
| 5 | CHECK HARNESS BETWEEN REAR OXYGEN SENSOR AND ECM CONNECTOR. 1) Turn the ignition switch to OFF. 2) Disconnect the connector from rear oxygen sensor. 3) Turn the ignition switch to ON. 4) Measure the voltage between rear oxygen sensor harness connector and engine ground or chassis ground. Connector & terminal (B19) No. 3 (+) — Engine ground (-): | Is the voltage more than 0.2 V? | Replace the rear oxygen sensor. <Ref. to FU(H4DOTC)-45, Rear Oxygen Sensor.> Repair the harness and connector. NOTE: In this case, repair the following: • Open circuit in harness between rear oxygen sensor and ECM connector • Poor contact in rear oxygen sensor connector • Poor contact in ECM connector |

Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

| | Step | Check | Yes | No |
|---|---|-------------------------------------|-------------------------------------|---|
| 6 | CHECK EXHAUST SYSTEM. Check the exhaust system parts. NOTE: Check the following items. <ul style="list-style-type: none">• Loose installation of portions• Damage (crack, hole etc.) of parts• Looseness and ill fitting of parts between front oxygen (A/F) sensor and rear oxygen sensor | Is there a fault in exhaust system? | Repair or replace the faulty parts. | Replace the rear oxygen sensor. <Ref. to FU(H4DOTC)-45, Rear Oxygen Sensor.> |

Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

AA:DTC P0138 O₂ SENSOR CIRCUIT HIGH VOLTAGE (BANK 1 SENSOR 2)


DTC DETECTING CONDITION:

- Two consecutive driving cycles with fault
- GENERAL DESCRIPTION <Ref. to GD(H4DOTC)-62, DTC P0138 O₂ SENSOR CIRCUIT HIGH VOLTAGE (BANK 1 SENSOR 2), Diagnostic Trouble Code (DTC) Detecting Criteria.>

CAUTION:

After repair or replacement of faulty parts, conduct Clear Memory Mode <Ref. to EN(H4DOTC)(diag)-46, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(H4DOTC)(diag)-39, PROCEDURE, Inspection Mode.>.

WIRING DIAGRAM:



Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

| Step | Check | Yes | No |
|---|----------------------------------|---|---|
| 1 CHECK ANY OTHER DTC ON DISPLAY. | Is any other DTC displayed? | Using the List of Diagnostic Trouble Code (DTC), check the appropriate DTC. <Ref. to EN(H4DOTC)(diag)-71, List of Diagnostic Trouble Code (DTC).> | Go to step 2. |
| 2 CHECK REAR OXYGEN SENSOR DATA. 1) Warm-up the engine until engine coolant temperature is above 70°C (158°F), and keep the engine speed at 2,000 rpm to 3,000 rpm for 2 minutes. 2) Read the data of rear oxygen sensor signal using Subaru Select Monitor or OBD-II general scan tool. NOTE: • Subaru Select Monitor For detailed operation procedure, refer to the "READ CURRENT DATA SHOWN ON DISPLAY FOR ENGINE". <Ref. to EN(H4DOTC)(diag)-31, Subaru Select Monitor.> • OBD-II general scan tool For detailed operation procedures, refer to the OBD-II General Scan Tool Instruction Manual. | Does the value fluctuate? | Go to step 6. | Go to step 3. |
| 3 CHECK REAR OXYGEN SENSOR DATA. Read the data of rear oxygen sensor signal using Subaru Select Monitor or OBD-II general scan tool. | Is the voltage 0.2 — 0.4 V? | Go to step 4. | Replace the rear oxygen sensor. <Ref. to FU(H4DOTC)-45, Rear Oxygen Sensor.> |
| 4 CHECK HARNESS BETWEEN ECM AND REAR OXYGEN SENSOR CONNECTOR. 1) Turn the ignition switch to OFF. 2) Disconnect the connectors from ECM and rear oxygen sensor. 3) Measure the resistance of harness between ECM and rear oxygen sensor connector. Connector & terminal (B135) No. 17 — (B19) No. 3: | Is the resistance more than 3 Ω? | Repair the open circuit in harness between ECM and rear oxygen sensor connector. | Go to step 5. |
| 5 CHECK HARNESS BETWEEN REAR OXYGEN SENSOR AND ECM CONNECTOR. 1) Turn the ignition switch to OFF. 2) Disconnect the connector from rear oxygen sensor. 3) Turn the ignition switch to ON. 4) Measure the voltage between rear oxygen sensor harness connector and engine ground or chassis ground. Connector & terminal (B19) No. 3 (+) — Engine ground (-): | Is the voltage more than 0.2 V? | Replace the rear oxygen sensor. <Ref. to FU(H4DOTC)-45, Rear Oxygen Sensor.> | Repair the harness and connector. NOTE: In this case, repair the following: • Open circuit in harness between rear oxygen sensor and ECM connector • Poor contact in rear oxygen sensor connector • Poor contact in ECM connector |

Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

| Step | Check | Yes | No |
|---|-------------------------------------|-------------------------------------|---|
| 6 CHECK EXHAUST SYSTEM. Check the exhaust system parts. NOTE: Check the following items. <ul style="list-style-type: none">• Loose installation of portions• Damage (crack, hole etc.) of parts• Looseness and ill fitting of parts between front oxygen (A/F) sensor and rear oxygen sensor | Is there a fault in exhaust system? | Repair or replace the faulty parts. | Replace the rear oxygen sensor. <Ref. to FU(H4DOTC)-45, Rear Oxygen Sensor.> |

Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

AB:DTC P0139 O₂ SENSOR CIRCUIT SLOW RESPONSE (BANK 1 SENSOR 2)


DTC DETECTING CONDITION:

- Two consecutive driving cycles with fault
- GENERAL DESCRIPTION <Ref. to GD(H4DOTC)-64, DTC P0139 O₂ SENSOR CIRCUIT SLOW RESPONSE (BANK 1 SENSOR 2), Diagnostic Trouble Code (DTC) Detecting Criteria.>

CAUTION:

After repair or replacement of faulty parts, conduct Clear Memory Mode <Ref. to EN(H4DOTC)(diag)-46, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(H4DOTC)(diag)-39, PROCEDURE, Inspection Mode.>.

WIRING DIAGRAM:



EN-01611

Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

| Step | Check | Yes | No |
|---|-----------------------------|---|---|
| 1 CHECK ANY OTHER DTC ON DISPLAY. | Is any other DTC displayed? | Inspect the relevant DTC using "List of Diagnostic Trouble Code (DTC)". <Ref. to EN(H4DOTC)(diag)-71, List of Diagnostic Trouble Code (DTC).> NOTE: In this case, it is not necessary to inspect DTC P0139. | Replace the rear oxygen sensor. <Ref. to FU(H4DOTC)-45, Rear Oxygen Sensor.> |

AC:DTC P0171 SYSTEM TOO LEAN (BANK 1)

NOTE:

For the diagnostic procedure, refer to DTC P0172. <Ref. to EN(H4DOTC)(diag)-138, DTC P0172 SYSTEM TOO RICH (BANK 1), Diagnostic Procedure with Diagnostic Trouble Code (DTC).>

Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

AD:DTC P0172 SYSTEM TOO RICH (BANK 1)

DTC DETECTING CONDITION:

- Two consecutive driving cycles with fault
- GENERAL DESCRIPTION <Ref. to GD(H4DOTC)-70, DTC P0172 SYSTEM TOO RICH (BANK 1), Diagnostic Trouble Code (DTC) Detecting Criteria.>

TROUBLE SYMPTOM:

- Erroneous idling
- Engine stalls.
- Poor driving performance

CAUTION:

After repair or replacement of faulty parts, conduct Clear Memory Mode <Ref. to EN(H4DOTC)(diag)-46, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(H4DOTC)(diag)-39, PROCEDURE, Inspection Mode.>.

| Step | Check | Yes | No | |
|------|--|---|--|--|
| 1 | CHECK EXHAUST SYSTEM. | Are there holes or loose bolts on exhaust system? | Repair the exhaust system. Go to step 2. | |
| 2 | CHECK AIR INTAKE SYSTEM. | Are there holes, loose bolts or disconnection of hose on air intake system? | Repair the air intake system. Go to step 3. | |
| 3 | CHECK FUEL PRESSURE. Warning: <ul style="list-style-type: none"> • Place “NO FIRE” signs near the working area. • Be careful not to spill fuel on the floor. <ol style="list-style-type: none"> 1) Release the fuel pressure. <ol style="list-style-type: none"> (1) Disconnect the connector from fuel pump relay. (2) Start the engine and run it until it stalls. (3) After the engine stalls, crank it for 5 more seconds. (4) Turn the ignition switch to OFF. 2) Connect the connector to fuel pump relay. 3) Disconnect the fuel delivery hose from fuel filter, and connect fuel pressure gauge. 4) Install the fuel filler cap. 5) Start the engine and idle while gear position is neutral. 6) Measure the fuel pressure while disconnecting pressure regulator vacuum hose from intake manifold. Warning: Before removing the fuel pressure gauge, release fuel pressure. NOTE: If the fuel pressure does not increase, squeeze fuel return hose 2 to 3 times, then measure fuel pressure again. | Is the measured value 284 — 314 kPa (2.9 — 3.2 kg/cm ² , 41 — 46 psi)? | Go to step 4. | Repair the following items. Fuel pressure too high: <ul style="list-style-type: none"> • Clogged fuel return line or bent hose Fuel pressure too low: <ul style="list-style-type: none"> • Improper fuel pump discharge • Clogged fuel supply line |

Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

| Step | Check | Yes | No |
|--|--|----------------------|--|
| <p>4</p> <p>CHECK FUEL PRESSURE. After connecting the pressure regulator vacuum hose, measure fuel pressure.</p> <p>Warning: Before removing the fuel pressure gauge, release fuel pressure.</p> <p>NOTE:</p> <ul style="list-style-type: none"> • If the fuel pressure does not increase, squeeze fuel return hose 2 to 3 times, then measure fuel pressure again. • If out of specification as measured at this step, check or replace the pressure regulator and pressure regulator vacuum hose. | <p>Is the measured value 206 — 235 kPa (2.1 — 2.4 kg/cm², 30 — 34 psi)?</p> | <p>Go to step 5.</p> | <p>Repair the following items.</p> <p>Fuel pressure too high:</p> <ul style="list-style-type: none"> • Faulty pressure regulator • Clogged fuel return line or bent hose <p>Fuel pressure too low:</p> <ul style="list-style-type: none"> • Faulty pressure regulator • Improper fuel pump discharge • Clogged fuel supply line |
| <p>5</p> <p>CHECK ENGINE COOLANT TEMPERATURE SENSOR.</p> <ol style="list-style-type: none"> 1) Start the engine and warm-up completely. 2) Read the data of engine coolant temperature sensor signal using Subaru Select Monitor or OBD-II general scan tool. <p>NOTE:</p> <ul style="list-style-type: none"> • Subaru Select Monitor <p>For detailed operation procedure, refer to the "READ CURRENT DATA FOR ENGINE". <Ref. to EN(H4DOTC)(diag)-31, Subaru Select Monitor.></p> <ul style="list-style-type: none"> • OBD-II general scan tool <p>For detailed operation procedures, refer to the OBD-II General Scan Tool Instruction Manual.</p> | <p>Is the temperature more than 60°C (140°F)?</p> | <p>Go to step 6.</p> | <p>Replace the engine coolant temperature sensor. <Ref. to FU(H4DOTC)-27, Engine Coolant Temperature Sensor.></p> |
| <p>6</p> <p>CHECK MASS AIR FLOW AND INTAKE AIR TEMPERATURE.</p> <ol style="list-style-type: none"> 1) Start the engine and warm-up engine until coolant temperature is greater than 60°C (140°F). 2) Place the shift lever in neutral position. 3) Turn the A/C switch to OFF. 4) Turn all accessory switches to OFF. 5) Read the data of mass air flow and intake air temperature sensor signal using Subaru Select Monitor or OBD-II general scan tool. <p>NOTE:</p> <ul style="list-style-type: none"> • Subaru Select Monitor <p>For detailed operation procedure, refer to the "READ CURRENT DATA FOR ENGINE". <Ref. to EN(H4DOTC)(diag)-31, Subaru Select Monitor.></p> <ul style="list-style-type: none"> • OBD-II general scan tool <p>For detailed operation procedure, refer to the OBD-II General Scan Tool Instruction Manual.</p> | <p>Is the measured value within the followings? Ignition ON: 73.3 — 106.6 kPa (550 — 800 mmHg, 21.65 — 31.50 inHg) Idling: 24.0 — 41.3 kPa (180 — 310 mmHg, 7.09 — 12.20 inHg)</p> | <p>Go to step 7.</p> | <p>Replace the mass air flow and intake air temperature sensor. <Ref. to FU(H4DOTC)-32, Mass Air Flow and Intake Air Temperature Sensor.></p> |

Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

| Step | Check | Yes | No |
|---|---|---|---|
| <p>7</p> <p>CHECK MASS AIR FLOW AND INTAKE AIR TEMPERATURE SENSOR.</p> <p>1) Start the engine and warm-up engine until coolant temperature is greater than 60°C (140°F).</p> <p>2) Place the shift lever in neutral position.</p> <p>3) Turn the A/C switch to OFF.</p> <p>4) Turn all accessory switches to OFF.</p> <p>5) Open the front hood.</p> <p>6) Measure the ambient temperature.</p> <p>7) Read the data of mass air flow and intake air temperature sensor signal using Subaru Select Monitor or OBD-II general scan tool.</p> <p>NOTE:</p> <ul style="list-style-type: none"> • Subaru Select Monitor For detailed operation procedure, refer to the "READ CURRENT DATA FOR ENGINE". <Ref. to EN(H4DOTC)(diag)-31, Subaru Select Monitor.> • OBD-II general scan tool For detailed operation procedure, refer to the OBD-II General Scan Tool Instruction Manual. | <p>Subtract ambient temperature from intake air temperature. Is the obtained value -10°C — 50°C (14°F — 122°F)?</p> | <p>Contact your SOA Service Center.</p> <p>NOTE: Inspection by DTM is required, because probable cause is deterioration of multiple parts.</p> | <p>Check the mass air flow and intake air temperature sensor. <Ref. to FU(H4DOTC)-32, Mass Air Flow and Intake Air Temperature Sensor.></p> |

AE:DTC P0181 FUEL TEMPERATURE SENSOR "A" CIRCUIT RANGE/PERFORMANCE


DTC DETECTING CONDITION:

- Two consecutive driving cycles with fault
- GENERAL DESCRIPTION <Ref. to GD(H4DOTC)-73, DTC P0181 FUEL TEMPERATURE SENSOR "A" CIRCUIT RANGE/PERFORMANCE, Diagnostic Trouble Code (DTC) Detecting Criteria.>

CAUTION:

After repair or replacement of faulty parts, conduct Clear Memory Mode <Ref. to EN(H4DOTC)(diag)-46, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(H4DOTC)(diag)-39, PROCEDURE, Inspection Mode.>.

WIRING DIAGRAM:



EN-01616

Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

| Step | Check | Yes | No |
|---|-----------------------------|--|---|
| 1 CHECK FOR OTHER DTC ON DISPLAY. | Is any other DTC displayed? | Inspect the relevant DTC using "List of Diagnostic Trouble Codes (DTC)". <Ref. to EN(H4DOTC)(diag)-71, List of Diagnostic Trouble Code (DTC).> NOTE: In this case, it is not necessary to inspect DTC P0181. | Replace the fuel temperature sensor. <Ref. to EC(H4DOTC)-9, Fuel Temperature Sensor.> |

Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

| Step | Check | Yes | No |
|--|---|---|--|
| 1 CHECK CURRENT DATA. 1) Start the engine. 2) Read the data of fuel temperature sensor signal using Subaru Select Monitor or OBD-II general scan tool. NOTE: • Subaru Select Monitor For detailed operation procedures, refer to "READ CURRENT DATA FOR ENGINE". <Ref. to EN(H4DOTC)(diag)-31, Subaru Select Monitor.> • OBD-II general scan tool For detailed operation procedures, refer to the OBD-II General Scan Tool Instruction Manual. | Is the temperature more than 150°C (302°F)? | Go to step 2. | The malfunction indicator light may light up, however, the circuit is returned to the normal status at the moment. |
| 2 CHECK CURRENT DATA. 1) Turn ignition switch to OFF. 2) Remove the access hole lid. 3) Disconnect the connector from fuel pump. 4) Turn ignition switch to ON. 5) Read the data of fuel temperature sensor signal using Subaru Select Monitor or OBD-II general scan tool. NOTE: • Subaru Select Monitor For detailed operation procedures, refer to "READ CURRENT DATA FOR ENGINE". <Ref. to EN(H4DOTC)(diag)-31, Subaru Select Monitor.> • OBD-II general scan tool For detailed operation procedures, refer to the OBD-II General Scan Tool Instruction Manual. | Is the temperature less than –40°C (–40°F)? | Replace the fuel temperature sensor. <Ref. to EC(H4DOTC)-9, Fuel Temperature Sensor.> | Repair short circuit to ground in harness between fuel pump and ECM connector. |

Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

AG:DTC P0183 FUEL TEMPERATURE SENSOR "A" CIRCUIT HIGH INPUT


DTC DETECTING CONDITION:

- Immediately at fault recognition
- GENERAL DESCRIPTION <Ref. to GD(H4DOTC)-78, DTC P0183 FUEL TEMPERATURE SENSOR "A" CIRCUIT HIGH INPUT, Diagnostic Trouble Code (DTC) Detecting Criteria.>

CAUTION:

After repair or replacement of faulty parts, conduct Clear Memory Mode <Ref. to EN(H4DOTC)(diag)-46, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(H4DOTC)(diag)-39, PROCEDURE, Inspection Mode.>.

WIRING DIAGRAM:



EN-01616

Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

| Step | Check | Yes | No |
|---|---|---|---|
| 1 CHECK CURRENT DATA. 1) Start the engine. 2) Read the data of fuel temperature sensor signal using Subaru Select Monitor or OBD-II general scan tool. NOTE: • Subaru Select Monitor For detailed operation procedures, refer to "READ CURRENT DATA FOR ENGINE". <Ref. to EN(H4DOTC)(diag)-31, Subaru Select Monitor.> • OBD-II general scan tool For detailed operation procedures, refer to the OBD-II General Scan Tool Instruction Manual. | Is the temperature less than -40°C (-40°F)? | Go to step 2. | Repair poor contact. NOTE: In this case, repair the following: • Poor contact in fuel pump connector • Poor contact in ECM connector • Poor contact in coupling connector • Poor contact in joint connector |
| 2 CHECK HARNESS BETWEEN FUEL TEMPERATURE SENSOR AND ECM CONNECTOR. 1) Turn ignition switch to OFF. 2) Remove the access hole lid. 3) Disconnect the connector from fuel pump. 4) Measure the voltage between fuel pump connector and chassis ground. Connector & terminal (R58) No. 6 (+) — Chassis ground (-): | Is the voltage more than 10 V? | Repair short circuit to battery in harness between ECM and fuel pump connector. | Go to step 3. |
| 3 CHECK HARNESS BETWEEN FUEL TEMPERATURE SENSOR AND ECM CONNECTOR. 1) Turn ignition switch to ON. 2) Measure the voltage between fuel pump connector and chassis ground. Connector & terminal (R58) No. 6 (+) — Chassis ground (-): | Is the voltage more than 10 V? | Repair short circuit to battery in harness between ECM and fuel pump connector. | Go to step 4. |
| 4 CHECK HARNESS BETWEEN FUEL TEMPERATURE SENSOR AND ECM CONNECTOR. Measure the voltage between fuel pump connector and chassis ground. Connector & terminal (R58) No. 6 (+) — Chassis ground (-): | Is the voltage more than 4 V? | Go to step 5. | Repair harness and connector. NOTE: In this case, repair the following: • Open circuit in harness between ECM and fuel pump connector • Poor contact in fuel pump connector • Poor contact in ECM connector • Poor contact in coupling connector |

Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

| Step | Check | Yes | No |
|---|---|--|--|
| <p>5</p> <p>CHECK HARNESS BETWEEN FUEL TEMPERATURE SENSOR AND ECM CONNECTOR.</p> <p>1) Turn ignition switch to OFF. 2) Disconnect the connector from ECM. 3) Measure the resistance of harness between fuel pump connector and ECM.</p> <p>Connector & terminal (R58) No. 5 — (B135) No. 19:</p> | <p>Is the resistance less than 1 Ω?</p> | <p>Replace the fuel temperature sensor. <Ref. to EC(H4DOTC)-9, Fuel Temperature Sensor.></p> | <p>Repair harness and connector.</p> <p>NOTE: In this case, repair the following:</p> <ul style="list-style-type: none"> • Open circuit in harness between ECM and fuel pump connector • Poor contact in fuel pump connector • Poor contact in ECM connector • Poor contact in coupling connector • Poor contact in joint connector |

Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

AH:DTC P0230 FUEL PUMP PRIMARY CIRCUIT


DTC DETECTING CONDITION:

- Immediately at fault recognition
- GENERAL DESCRIPTION <Ref. to GD(H4DOTC)-81, ECM OPERATING AT DTC SETTING, DTC P0230 FUEL PUMP PRIMARY CIRCUIT, Diagnostic Trouble Code (DTC) Detecting Criteria.>

CAUTION:

After repair or replacement of faulty parts, conduct Clear Memory Mode <Ref. to EN(H4DOTC)(diag)-46, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(H4DOTC)(diag)-39, PROCEDURE, Inspection Mode.>.

WIRING DIAGRAM:



EN-01609

Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

| Step | Check | Yes | No |
|--|--|----------------------|---|
| <p>1</p> <p>CHECK POWER SUPPLY CIRCUIT TO FUEL PUMP CONTROL UNIT.</p> <p>1) Turn the ignition switch to OFF. 2) Disconnect the connector from fuel pump control unit. 3) Turn the ignition switch to ON. 4) Measure the voltage between fuel pump control unit and chassis ground.</p> <p>Connector & terminal (R122) No. 10 (+) — Chassis ground (-):</p> | <p>Is the voltage more than 10 V?</p> | <p>Go to step 2.</p> | <p>Repair the power supply circuit.</p> <p>NOTE: In this case repair the following:</p> <ul style="list-style-type: none"> • Open or ground short circuit in harness between fuel pump relay and fuel pump control unit • Poor contact in fuel pump control unit connector • Poor contact in fuel pump relay connector |
| <p>2</p> <p>CHECK GROUND CIRCUIT OF FUEL PUMP CONTROL UNIT.</p> <p>1) Turn the ignition switch to OFF. 2) Measure the resistance of harness between fuel pump control unit and chassis ground.</p> <p>Connector & terminal (R122) No. 5 — Chassis ground:</p> | <p>Is the resistance less than 5 Ω?</p> | <p>Go to step 3.</p> | <p>Repair the harness and connector.</p> <p>NOTE: In this case, repair the following:</p> <ul style="list-style-type: none"> • Open circuit between fuel pump control unit and chassis ground • Poor contact in fuel pump control unit connector |
| <p>3</p> <p>CHECK HARNESS BETWEEN FUEL PUMP CONTROL UNIT AND FUEL PUMP CONNECTOR.</p> <p>1) Disconnect the connector from fuel pump. 2) Measure the resistance of harness between fuel pump control unit and fuel pump connector.</p> <p>Connector & terminal (R122) No. 7 — (R58) No. 1: (R122) No. 6 — (R58) No. 4:</p> | <p>Is the resistance less than 1 Ω?</p> | <p>Go to step 4.</p> | <p>Repair the open circuit between fuel pump control unit and fuel pump.</p> |
| <p>4</p> <p>CHECK HARNESS BETWEEN FUEL PUMP CONTROL UNIT AND FUEL PUMP CONNECTOR.</p> <p>Measure the resistance of harness between fuel pump control unit and chassis ground.</p> <p>Connector & terminal (R122) No. 7 — Chassis ground: (R122) No. 6 — Chassis ground:</p> | <p>Is the resistance more than 1 $M\Omega$?</p> | <p>Go to step 5.</p> | <p>Repair the ground short circuit between fuel pump control unit and fuel pump.</p> |

Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

| Step | Check | Yes | No |
|---|--|--|---|
| 5 CHECK HARNESS BETWEEN FUEL PUMP CONTROL UNIT AND ECM CONNECTOR. 1) Turn the ignition switch to OFF. 2) Disconnect the connector from ECM. 3) Measure the resistance of harness between fuel pump control unit and ECM connector. <i>Connector & terminal</i> <i>(R122) No. 9 — (B134) No. 13:</i> <i>(R122) No. 8 — (B137) No. 15:</i> | Is the resistance less than 1 Ω ? | Go to step 6. | Repair the harness and connector. NOTE: In this case, repair the following: <ul style="list-style-type: none"> • Open circuit between fuel pump control unit and ECM • Poor contact in fuel pump control unit and ECM connector |
| 6 CHECK HARNESS BETWEEN FUEL PUMP CONTROL UNIT AND ECM CONNECTOR. Measure the resistance of harness between fuel pump control unit and chassis ground. <i>Connector & terminal</i> <i>(R122) No. 9 — Chassis ground:</i> <i>(R122) No. 8 — Chassis ground:</i> | Is the resistance more than 1 $M\Omega$? | Go to step 7. | Repair the ground short circuit between fuel pump control unit and ECM. |
| 7 CHECK POOR CONTACT. Check poor contact in ECM and fuel pump control unit connector. | Is there poor contact in ECM and fuel pump control unit connector? | Repair the poor contact in ECM and fuel pump control unit. | Replace the fuel pump control unit. <Ref. to FU(H4DOTC)-51, Fuel Pump Control Unit.> |

Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

AI: DTC P0244 TURBO/SUPER CHARGER WASTEGATE SOLENOID "A" RANGE/PERFORMANCE

DTC DETECTING CONDITION:

- Immediately at fault recognition
- GENERAL DESCRIPTION <Ref. to GD(H4DOTC)-82, DTC P0244 TURBO/SUPER CHARGER WASTEGATE SOLENOID "A" RANGE/PERFORMANCE, Diagnostic Trouble Code (DTC) Detecting Criteria.>


TROUBLE SYMPTOM:

- Erroneous idling
- Engine stalls.
- Poor driving performance

CAUTION:

After repair or replacement of faulty parts, conduct Clear Memory Mode <Ref. to EN(H4DOTC)(diag)-46, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(H4DOTC)(diag)-39, PROCEDURE, Inspection Mode.>.

WIRING DIAGRAM:



EN-01617

Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

| Step | Check | Yes | No |
|---|-----------------------------|---|---|
| 1 CHECK ANY OTHER DTC ON DISPLAY. | Is any other DTC displayed? | Inspect the relevant DTC using "List of Diagnostic Trouble Code (DTC)". <Ref. to EN(H4DOTC)(diag)-71, List of Diagnostic Trouble Code (DTC).> NOTE: In this case, it is not necessary to inspect DTC P0244. | Replace the wastegate control solenoid valve. <Ref. to FU(H4DOTC)-42, Wastegate Control Solenoid Valve.> |

Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

AJ:DTC P0245 TURBO/SUPER CHARGER WASTEGATE SOLENOID "A" LOW

DTC DETECTING CONDITION:

- Immediately at fault recognition
- GENERAL DESCRIPTION <Ref. to GD(H4DOTC)-84, DTC P0245 TURBO/SUPER CHARGER WASTEGATE SOLENOID "A" LOW, Diagnostic Trouble Code (DTC) Detecting Criteria.>


TROUBLE SYMPTOM:

Erroneous idling

CAUTION:

After repair or replacement of faulty parts, conduct Clear Memory Mode <Ref. to EN(H4DOTC)(diag)-46, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(H4DOTC)(diag)-39, PROCEDURE, Inspection Mode.>.

WIRING DIAGRAM:



EN-01617

Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

| Step | Check | Yes | No |
|---|--|---|--|
| 1 CHECK OUTPUT SIGNAL FROM ECM. 1) Turn the ignition switch to ON. 2) Measure the voltage between ECM and chassis ground. <i>Connector & terminal</i> <i>(B84) No. 24 (+) — Chassis ground (-):</i> | Is the voltage more than 10 V? | Even if malfunction indicator light lights up, the circuit has returned to a normal condition at this time. | Go to step 2. |
| 2 CHECK HARNESS BETWEEN WASTEGATE CONTROL SOLENOID VALVE AND ECM CONNECTOR. 1) Turn the ignition switch to OFF. 2) Disconnect the connectors from wastegate control solenoid valve and ECM. 3) Measure the resistance of harness between wastegate control solenoid valve connector and engine ground. <i>Connector & terminal</i> <i>(B127) No. 1 — Engine ground:</i> | Is the resistance less than 10 Ω ? | Repair the ground short circuit in harness between ECM and wastegate control solenoid valve connector. | Go to step 3. |
| 3 CHECK HARNESS BETWEEN WASTEGATE CONTROL SOLENOID VALVE AND ECM CONNECTOR. Measure the resistance of harness between ECM and wastegate control solenoid valve of harness connector. <i>Connector & terminal</i> <i>(B84) No. 24 — (B127) No. 1:</i> | Is the resistance less than 1 Ω ? | Go to step 4. | Repair the open circuit in harness between ECM and wastegate control solenoid valve connector. NOTE: In this case, repair the following: • Open circuit in harness between ECM and wastegate control solenoid valve connector |
| 4 CHECK WASTEGATE CONTROL SOLENOID VALVE. 1) Remove the wastegate control solenoid valve. 2) Measure the resistance between wastegate control solenoid valve terminals. <i>Terminals</i> <i>No. 1 — No. 2:</i> | Is the resistance 30 — 40 Ω ? | Go to step 5. | Replace the wastegate control solenoid valve. <Ref. to FU(H4DOTC)-42, Wastegate Control Solenoid Valve.> |
| 5 CHECK POWER SUPPLY TO WASTEGATE CONTROL SOLENOID VALVE. 1) Turn the ignition switch to ON. 2) Measure the voltage between wastegate control solenoid valve and engine ground. <i>Connector & terminal</i> <i>(B127) No. 2 (+) — Engine ground (-):</i> | Is the voltage more than 10 V? | Go to step 6. | Repair the open circuit in harness between main relay and wastegate control solenoid valve connector. |
| 6 CHECK POOR CONTACT. Check poor contact in wastegate control solenoid valve connector. | Is there poor contact in wastegate control solenoid valve connector? | Repair the poor contact in wastegate control solenoid valve connector. | Contact your SOA Service Center. NOTE: Inspection by DTM is required, because probable cause is deterioration of multiple parts. |

Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

AK:DTC P0246 TURBO/SUPER CHARGER WASTEGATE SOLENOID "A" HIGH DTC DETECTING CONDITION:

- Immediately at fault recognition
- GENERAL DESCRIPTION <Ref. to GD(H4DOTC)-86, DTC P0246 TURBO/SUPER CHARGER WASTEGATE SOLENOID "A" HIGH, Diagnostic Trouble Code (DTC) Detecting Criteria.>


TROUBLE SYMPTOM:

Erroneous idling

CAUTION:

After repair or replacement of faulty parts, conduct Clear Memory Mode <Ref. to EN(H4DOTC)(diag)-46, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(H4DOTC)(diag)-39, PROCEDURE, Inspection Mode.>.

WIRING DIAGRAM:



Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

| Step | Check | Yes | No |
|---|--|--|--|
| 1 CHECK OUTPUT SIGNAL FROM ECM. 1) Turn the ignition switch to ON. 2) Measure the voltage between ECM and chassis ground. Connector & terminal (B84) No. 24 (+) — Chassis ground (-): | Is the voltage more than 10 V? | Go to step 3. | Go to step 2. |
| 2 CHECK POOR CONTACT. Check poor contact in ECM connector. | Is there poor contact in ECM connector? | Repair the poor contact in ECM connector. | Replace the ECM. <Ref. to FU(H4DOTC)-48, Engine Control Module (ECM).> |
| 3 CHECK HARNESS BETWEEN WASTEGATE CONTROL SOLENOID VALVE AND ECM CONNECTOR. 1) Turn the ignition switch to OFF. 2) Disconnect the connector from wastegate control solenoid valve. 3) Turn the ignition switch to ON. 4) Measure the voltage between ECM and chassis ground. Connector & terminal (B84) No. 24 (+) — Chassis ground (-): | Is the voltage more than 10 V? | Repair the battery short circuit in harness between ECM and wastegate control solenoid valve connector. After repair, replace the ECM. <Ref. to FU(H4DOTC)-48, Engine Control Module (ECM).> | Go to step 4. |
| 4 CHECK WASTEGATE CONTROL SOLENOID VALVE. 1) Turn the ignition switch to OFF. 2) Measure the resistance between wastegate control solenoid valve terminals. Terminals No. 1 — No. 2: | Is the resistance less than 1 Ω ? | Replace the wastegate control solenoid valve <Ref. to FU(H4DOTC)-42, Wastegate Control Solenoid Valve.> and ECM <Ref. to FU(H4DOTC)-48, Engine Control Module (ECM).> | Go to step 5. |
| 5 CHECK POOR CONTACT. Check poor contact in ECM connector. | Is there poor contact in ECM connector? | Repair the poor contact in ECM connector. | Replace the ECM. <Ref. to FU(H4DOTC)-48, Engine Control Module (ECM).> |

Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

AL:DTC P0301 CYLINDER 1 MISFIRE DETECTED

NOTE:

For the diagnostic procedure, refer to DTC P0304. <Ref. to EN(H4DOTC)(diag)-157, DTC P0304 CYLINDER 4 MISFIRE DETECTED, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>

AM:DTC P0302 CYLINDER 2 MISFIRE DETECTED

NOTE:

For the diagnostic procedure, refer to DTC P0304. <Ref. to EN(H4DOTC)(diag)-157, DTC P0304 CYLINDER 4 MISFIRE DETECTED, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>

AN:DTC P0303 CYLINDER 3 MISFIRE DETECTED

NOTE:

For the diagnostic procedure, refer to DTC P0304. <Ref. to EN(H4DOTC)(diag)-157, DTC P0304 CYLINDER 4 MISFIRE DETECTED, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>

AO:DTC P0304 CYLINDER 4 MISFIRE DETECTED

DTC DETECTING CONDITION:

- Two consecutive driving cycles with fault
- Immediately at fault recognition (A misfire which could damage catalyst occurs.)
- GENERAL DESCRIPTION <Ref. to GD(H4DOTC)-94, DTC P0304 CYLINDER 4 MISFIRE DETECTED, Diagnostic Trouble Code (DTC) Detecting Criteria.>

TROUBLE SYMPTOM:

- Engine stalls.
- Erroneous idling
- Rough driving








CAUTION:

After repair or replacement of faulty parts, conduct Clear Memory Mode <Ref. to EN(H4DOTC)(diag)-46, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(H4DOTC)(diag)-39, PROCEDURE, Inspection Mode.>.

Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

WIRING DIAGRAM:



EN-01297

Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

| Step | Check | Yes | No |
|---|-----------------------------------|---|--|
| 1 CHECK ANY OTHER DTC ON DISPLAY. | Is any other DTC displayed? | Inspect the relevant DTC using "List of Diagnostic Trouble Code (DTC)". <Ref. to EN(H4DOTC)(diag)-71, List of Diagnostic Trouble Code (DTC).> | Go to step 2. |
| 2 CHECK OUTPUT SIGNAL FROM ECM. 1) Turn the ignition switch to ON. 2) Measure the voltage between ECM connector and chassis ground on faulty cylinders. Connector & terminal <i>#1 (B84) No. 1 (+) — Chassis ground (-):</i> <i>#2 (B137) No. 6 (+) — Chassis ground (-):</i> <i>#3 (B137) No. 5 (+) — Chassis ground (-):</i> <i>#4 (B137) No. 4 (+) — Chassis ground (-):</i> | Is the voltage more than 10 V? | Go to step 7. | Go to step 3. |
| 3 CHECK HARNESS BETWEEN FUEL INJECTOR AND ECM CONNECTOR. 1) Turn the ignition switch to OFF. 2) Disconnect the connector from fuel injector on faulty cylinders. 3) Disconnect the connector from ECM. 4) Measure the resistance between ECM connector and engine ground on faulty cylinders. Connector & terminal <i>#1 (E5) No. 1 — Engine ground:</i> <i>#2 (E16) No. 1 — Engine ground:</i> <i>#3 (E6) No. 1 — Engine ground:</i> <i>#4 (E17) No. 1 — Engine ground:</i> | Is the resistance more than 1 MΩ? | Go to step 4. | Repair the ground short circuit in harness between fuel injector and ECM connector. |
| 4 CHECK HARNESS BETWEEN FUEL INJECTOR AND ECM CONNECTOR. Measure the resistance of harness connector between ECM connector and fuel injector on faulty cylinders. Connector & terminal <i>#1 (B84) No. 1 — (E5) No. 1:</i> <i>#2 (B137) No. 6 — (E16) No. 1:</i> <i>#3 (B137) No. 5 — (E6) No. 1:</i> <i>#4 (B137) No. 4 — (E17) No. 1:</i> | Is the resistance less than 1 Ω? | Go to step 5. | Repair the harness and connector. NOTE: In this case, repair the following: • Open circuit in harness between ECM and fuel injector connector • Poor contact in coupling connector |
| 5 CHECK FUEL INJECTOR. Measure the resistance between fuel injector terminals on faulty cylinder. Terminals <i>No. 1 — No. 2:</i> | Is the resistance 5 — 20 Ω? | Go to step 6. | Replace the faulty fuel injector. <Ref. to FU(H4DOTC)-35, Fuel Injector.> |

Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

| Step | Check | Yes | No |
|---|---|--|---|
| <p>6</p> <p>CHECK POWER SUPPLY LINE. 1) Turn the ignition switch to ON. 2) Measure the voltage between fuel injector and engine ground on faulty cylinders. Connector & terminal <i>#1 (E5) No. 2 (+) — Engine ground (-):</i> <i>#2 (E16) No. 2 (+) — Engine ground (-):</i> <i>#3 (E6) No. 2 (+) — Engine ground (-):</i> <i>#4 (E17) No. 2 (+) — Engine ground (-):</i></p> | <p>Is the voltage more than 10 V?</p> | <p>Repair the poor contact in all connectors in fuel injector circuit.</p> | <p>Repair the harness and connector. NOTE: In this case, repair the following:</p> <ul style="list-style-type: none"> • Open circuit in harness between main relay and fuel injector connector on faulty cylinders • Poor contact in coupling connector • Poor contact in main relay connector • Poor contact in fuel injector connector on faulty cylinders |
| <p>7</p> <p>CHECK HARNESS BETWEEN FUEL INJECTOR AND ECM CONNECTOR. 1) Turn the ignition switch to OFF. 2) Disconnect the connector from fuel injector on faulty cylinder. 3) Turn the ignition switch to ON. 4) Measure the voltage between ECM connector and chassis ground on faulty cylinders. Connector & terminal <i>#1 (B84) No. 1 (+) — Chassis ground (-):</i> <i>#2 (B137) No. 6 (+) — Chassis ground (-):</i> <i>#3 (B137) No. 5 (+) — Chassis ground (-):</i> <i>#4 (B137) No. 4 (+) — Chassis ground (-):</i></p> | <p>Is the voltage more than 10 V?</p> | <p>Repair the battery short circuit in harness between ECM and fuel injector. After repair, replace the ECM. <Ref. to FU(H4DOTC)-48, Engine Control Module (ECM).></p> | <p>Go to step 8.</p> |
| <p>8</p> <p>CHECK FUEL INJECTOR. 1) Turn the ignition switch to OFF. 2) Measure the resistance between fuel injector terminals on faulty cylinder. Terminals <i>No. 1 — No. 2:</i></p> | <p>Is the resistance less than 1 Ω?</p> | <p>Replace the faulty fuel injector <Ref. to FU(H4DOTC)-35, Fuel Injector.> and ECM <Ref. to FU(H4DOTC)-48, Engine Control Module (ECM).></p> | <p>Go to step 9.</p> |
| <p>9</p> <p>CHECK INSTALLATION OF CAMSHAFT POSITION SENSOR/CRANKSHAFT POSITION SENSOR.</p> | <p>Is the camshaft position sensor or crankshaft position sensor loosely installed?</p> | <p>Tighten the camshaft position sensor or crankshaft position sensor.</p> | <p>Go to step 10.</p> |
| <p>10</p> <p>CHECK CRANKSHAFT SPROCKET. Remove the timing belt cover.</p> | <p>Is the crankshaft sprocket rusted or does it have broken teeth?</p> | <p>Replace the crankshaft sprocket. <Ref. to ME(H4DOTC)-55, Crankshaft Sprocket.></p> | <p>Go to step 11.</p> |
| <p>11</p> <p>CHECK INSTALLATION CONDITION OF TIMING BELT. Turn the crankshaft, and align alignment mark on crankshaft sprocket with alignment mark on cylinder block.</p> | <p>Is the timing belt dislocated from its proper position?</p> | <p>Repair the installation condition of timing belt. <Ref. to ME(H4DOTC)-46, Timing Belt Assembly.></p> | <p>Go to step 12.</p> |

Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

| Step | Check | Yes | No |
|---|--|--|--|
| 12 CHECK FUEL LEVEL. | Is the fuel meter indication higher than the "Lower" level? | Go to step 13 . | Replenish the fuel so fuel meter indication is higher than the "Lower" level. After replenishing fuel; Go to step 13 . |
| 13 CHECK STATUS OF MALFUNCTION INDICATOR LIGHT. 1) Clear the memory using Subaru Select Monitor. <Ref. to EN(H4DOTC)(diag)-46, Clear Memory Mode.> 2) Start the engine, and drive the vehicle more than 10 minutes. | Is the malfunction indicator light coming on or blinking? | Go to step 15 . | Go to step 14 . |
| 14 CHECK CAUSE OF MISFIRE DIAGNOSED. | Was the cause of misfire diagnosed when the engine is running? | Finish the diagnostics operation, if the engine has no abnormality. | Repair the poor contact. NOTE: In this case, repair the following: <ul style="list-style-type: none"> • Poor contact in ignition coil connector • Poor contact in fuel injector connector on faulty cylinders • Poor contact in ECM connector • Poor contact in coupling connector |
| 15 CHECK AIR INTAKE SYSTEM. | Is there a fault in air intake system? | Repair the air intake system. NOTE: Check the following items: <ul style="list-style-type: none"> • Are there air leaks or air suction caused by loose or dislocated nuts and bolts? • Are there cracks or any disconnection of hoses? | Go to step 16 . |
| 16 CHECK CYLINDER. | Is there a fault in that cylinder? | Repair or replace the faulty parts. NOTE: Check the following items. <ul style="list-style-type: none"> • Spark plug • Fuel injector • Compression pressure | Go to DTC P0171 and P0172. <Ref. to EN(H4DOTC)(diag)-137, DTC P0171 SYSTEM TOO LEAN (BANK 1), Diagnostic Procedure with Diagnostic Trouble Code (DTC).> |

Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

AP:DTC P0327 KNOCK SENSOR 1 CIRCUIT LOW INPUT (BANK 1 OR SINGLE SENSOR)

DTC DETECTING CONDITION:

- Immediately at fault recognition
- GENERAL DESCRIPTION <Ref. to GD(H4DOTC)-95, DTC P0327 KNOCK SENSOR 1 CIRCUIT LOW INPUT (BANK 1 OR SINGLE SENSOR), Diagnostic Trouble Code (DTC) Detecting Criteria.>


TROUBLE SYMPTOM:

- Poor driving performance
- Knocking occurs.

CAUTION:

After repair or replacement of faulty parts, conduct Clear Memory Mode <Ref. to EN(H4DOTC)(diag)-46, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(H4DOTC)(diag)-39, PROCEDURE, Inspection Mode.>.

WIRING DIAGRAM:



EN-01240

Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

| Step | Check | Yes | No |
|---|--|---|---|
| <p>1</p> <p>CHECK HARNESS BETWEEN KNOCK SENSOR AND ECM CONNECTOR.</p> <p>1) Turn the ignition switch to OFF. 2) Disconnect the connector from ECM. 3) Measure the resistance between ECM harness connector and chassis ground.</p> <p>Connector & terminal (B135) No. 4 — Chassis ground:</p> | <p>Is the resistance more than 700 kΩ?</p> | <p>Go to step 2.</p> | <p>Repair the harness and connector.</p> <p>NOTE: In this case, repair the following:</p> <ul style="list-style-type: none"> • Open circuit in harness between knock sensor and ECM connector • Poor contact in knock sensor connector • Poor contact in coupling connector |
| <p>2</p> <p>CHECK KNOCK SENSOR.</p> <p>1) Disconnect the connector from knock sensor. 2) Measure the resistance between knock sensor connector terminal and engine ground.</p> <p>Terminals No. 2 — Engine ground:</p> | <p>Is the resistance more than 700 kΩ?</p> | <p>Go to step 3.</p> | <p>Repair the harness and connector.</p> <p>NOTE: In this case, repair the following:</p> <ul style="list-style-type: none"> • Poor contact in knock sensor connector • Poor contact in coupling connector |
| <p>3</p> <p>CHECK CONDITION OF KNOCK SENSOR INSTALLATION.</p> | <p>Is the knock sensor installation bolt tightened securely?</p> | <p>Replace the knock sensor. <Ref. to FU(H4DOTC)-30, Knock Sensor.></p> | <p>Tighten the knock sensor installation bolt securely.</p> |

Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

AQ:DTC P0328 KNOCK SENSOR 1 CIRCUIT HIGH INPUT (BANK 1 OR SINGLE SENSOR)

DTC DETECTING CONDITION:

- Immediately at fault recognition
- GENERAL DESCRIPTION <Ref. to GD(H4DOTC)-97, DTC P0328 KNOCK SENSOR 1 CIRCUIT HIGH INPUT (BANK 1 OR SINGLE SENSOR), Diagnostic Trouble Code (DTC) Detecting Criteria.>


TROUBLE SYMPTOM:

- Poor driving performance
- Knocking occurs.

CAUTION:

After repair or replacement of faulty parts, conduct Clear Memory Mode <Ref. to EN(H4DOTC)(diag)-46, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(H4DOTC)(diag)-39, PROCEDURE, Inspection Mode.>.

WIRING DIAGRAM:



EN-01240

Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

| Step | Check | Yes | No |
|--|--|---|---|
| <p>1</p> <p>CHECK HARNESS BETWEEN KNOCK SENSOR AND ECM CONNECTOR. Measure the resistance of harness between ECM connector and chassis ground. Connector & terminal (B135) No. 4 — Chassis ground:</p> | <p>Is the resistance less than 400 kΩ?</p> | <p>Go to step 2.</p> | <p>Go to step 3.</p> |
| <p>2</p> <p>CHECK KNOCK SENSOR. 1) Disconnect the connector from knock sensor. 2) Measure the resistance between knock sensor connector terminal and engine ground. Terminals No. 2 — Engine ground:</p> | <p>Is the resistance less than 400 kΩ?</p> | <p>Replace the knock sensor. <Ref. to FU(H4DOTC)-30, Knock Sensor.></p> | <p>Repair the ground short circuit in harness between knock sensor connector and ECM connector. NOTE: The harness between both connectors is shielded. Repair the short circuit of harness together with shield.</p> |
| <p>3</p> <p>CHECK INPUT SIGNAL FOR ECM. 1) Connect the connectors to ECM and knock sensor. 2) Turn the ignition switch to ON. 3) Measure the voltage between ECM and chassis ground. Connector & terminal (B135) No. 4 (+) — Chassis ground (-):</p> | <p>Is the voltage more than 2 V?</p> | <p>Even if malfunction indicator light lights up, the circuit has returned to a normal condition at this time. (However, the possibility of poor contact still remains.) NOTE: In this case, repair the following:</p> <ul style="list-style-type: none"> • Poor contact in knock sensor connector • Poor contact in ECM connector • Poor contact in coupling connector | <p>Repair the poor contact in ECM connector.</p> |

Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

AR:DTC P0335 CRANKSHAFT POSITION SENSOR "A" CIRCUIT

DTC DETECTING CONDITION:

- Immediately at fault recognition
- GENERAL DESCRIPTION <Ref. to GD(H4DOTC)-99, DTC P0335 CRANKSHAFT POSITION SENSOR "A" CIRCUIT, Diagnostic Trouble Code (DTC) Detecting Criteria.>


TROUBLE SYMPTOM:

- Engine stalls.
- Failure of engine to start

CAUTION:

After repair or replacement of faulty parts, conduct Clear Memory Mode <Ref. to EN(H4DOTC)(diag)-46, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(H4DOTC)(diag)-39, PROCEDURE, Inspection Mode.>.

WIRING DIAGRAM:



EN-01241

Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

| Step | Check | Yes | No |
|---|--|--|--|
| <p>1 CHECK HARNESS BETWEEN CRANKSHAFT POSITION SENSOR AND ECM CONNECTOR.</p> <p>1) Turn the ignition switch to OFF. 2) Disconnect the connector from crankshaft position sensor. 3) Measure the resistance of harness between crankshaft position sensor connector and engine ground.</p> <p>Connector & terminal (E10) No. 1 — Engine ground:</p> | <p>Is the resistance more than 100 kΩ?</p> | <p>Repair the harness and connector.</p> <p>NOTE: In this case, repair the following:</p> <ul style="list-style-type: none"> • Open circuit in harness between crankshaft position sensor and ECM connector • Poor contact in ECM connector • Poor contact in coupling connector | <p>Go to step 2.</p> |
| <p>2 CHECK HARNESS BETWEEN CRANKSHAFT POSITION SENSOR AND ECM CONNECTOR.</p> <p>Measure the resistance of harness between crankshaft position sensor connector and engine ground.</p> <p>Connector & terminal (E10) No. 1 — Engine ground:</p> | <p>Is the resistance more than 1 MΩ?</p> | <p>Go to step 3.</p> | <p>Repair the ground short circuit in harness between crankshaft position sensor and ECM connector.</p> <p>NOTE: The harness between both connectors are shielded. Repair ground short circuit in harness together with shield.</p> |
| <p>3 CHECK HARNESS BETWEEN CRANKSHAFT POSITION SENSOR AND ECM CONNECTOR.</p> <p>Measure the resistance of harness between crankshaft position sensor connector and engine ground.</p> <p>Connector & terminal (E10) No. 2 — Engine ground:</p> | <p>Is the resistance less than 5 Ω?</p> | <p>Go to step 4.</p> | <p>Repair the harness and connector.</p> <p>NOTE: In this case, repair the following:</p> <ul style="list-style-type: none"> • Open circuit in harness between crankshaft position sensor and ECM connector • Poor contact in ECM connector • Poor contact in coupling connector |
| <p>4 CHECK CONDITION OF CRANKSHAFT POSITION SENSOR.</p> | <p>Is the crankshaft position sensor installation bolt tightened securely?</p> | <p>Go to step 5.</p> | <p>Tighten the crankshaft position sensor installation bolt securely.</p> |
| <p>5 CHECK CRANKSHAFT POSITION SENSOR.</p> <p>1) Remove the crankshaft position sensor. 2) Measure the resistance between connector terminals of crankshaft position sensor.</p> <p>Terminals No. 1 — No. 2:</p> | <p>Is the resistance 1 — 4 kΩ?</p> | <p>Repair the poor contact in crankshaft position sensor connector.</p> | <p>Replace the crankshaft position sensor. <Ref. to FU(H4DOTC)-28, Crankshaft Position Sensor.></p> |

Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

AS:DTC P0336 CRANKSHAFT POSITION SENSOR "A" CIRCUIT RANGE/PERFORMANCE

DTC DETECTING CONDITION:

- Two consecutive driving cycles with fault
- GENERAL DESCRIPTION <Ref. to GD(H4DOTC)-101, DTC P0336 CRANKSHAFT POSITION SENSOR "A" CIRCUIT RANGE/PERFORMANCE, Diagnostic Trouble Code (DTC) Detecting Criteria.>


TROUBLE SYMPTOM:

- Engine stalls.
- Failure of engine to start

CAUTION:

After repair or replacement of faulty parts, conduct Clear Memory Mode <Ref. to EN(H4DOTC)(diag)-46, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(H4DOTC)(diag)-39, PROCEDURE, Inspection Mode.>.

WIRING DIAGRAM:



EN-01241

Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

| | Step | Check | Yes | No |
|---|--|---|---|--|
| 1 | CHECK ANY OTHER DTC ON DISPLAY. | Is any other DTC displayed? | Inspect the relevant DTC using "List of Diagnostic Trouble Code (DTC)". <Ref. to EN(H4DOTC)(diag)-71, List of Diagnostic Trouble Code (DTC).> | Go to step 2. |
| 2 | CHECK CONDITION OF CRANKSHAFT POSITION SENSOR. Turn the ignition switch to OFF. | Is the crankshaft position sensor installation bolt tightened securely? | Go to step 3. | Tighten the crankshaft position sensor installation bolt securely. |
| 3 | CHECK CRANKSHAFT SPROCKET. Remove the front belt cover. | Are the crankshaft sprocket teeth cracked or damaged? | Replace the crankshaft sprocket. <Ref. to FU(H4DOTC)-28, Crankshaft Position Sensor.> | Go to step 4. |
| 4 | CHECK INSTALLATION CONDITION OF TIMING BELT. Turn the crankshaft, and align alignment mark on crankshaft sprocket with alignment mark on cylinder block. | Is the timing belt dislocated from its proper position? | Repair the installation condition of timing belt. <Ref. to ME(H4DOTC)-46, Timing Belt Assembly.> | Replace the crankshaft position sensor. <Ref. to FU(H4DOTC)-28, Crankshaft Position Sensor.> |

Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

AT:DTC P0340 CAMSHAFT POSITION SENSOR "A" CIRCUIT (BANK 1 OR SINGLE SENSOR)

DTC DETECTING CONDITION:

- Immediately at fault recognition
- GENERAL DESCRIPTION <Ref. to GD(H4DOTC)-103, DTC P0340 CAMSHAFT POSITION SENSOR "A" CIRCUIT (BANK 1 OR SINGLE SENSOR), Diagnostic Trouble Code (DTC) Detecting Criteria.>


TROUBLE SYMPTOM:

- Engine stalls.
- Failure of engine to start

CAUTION:

After repair or replacement of faulty parts, conduct Clear Memory Mode <Ref. to EN(H4DOTC)(diag)-46, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(H4DOTC)(diag)-39, PROCEDURE, Inspection Mode.>.

WIRING DIAGRAM:



EN-01242

Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

| Step | Check | Yes | No |
|---|--|--|--|
| <p>1</p> <p>CHECK HARNESS BETWEEN CAMSHAFT POSITION SENSOR AND ECM CONNECTOR.</p> <p>1) Turn the ignition switch to OFF. 2) Disconnect the connector from camshaft position sensor. 3) Measure the resistance of harness between camshaft position sensor connector and engine ground.</p> <p>Connector & terminal (E15) No. 1 — Engine ground:</p> | <p>Is the resistance more than 100 kΩ?</p> | <p>Repair the harness and connector.</p> <p>NOTE: In this case, repair the following:</p> <ul style="list-style-type: none"> • Open circuit in harness between camshaft position sensor and ECM connector • Poor contact in ECM connector • Poor contact in coupling connector | <p>Go to step 2.</p> |
| <p>2</p> <p>CHECK HARNESS BETWEEN CAMSHAFT POSITION SENSOR AND ECM CONNECTOR.</p> <p>Measure the resistance of harness between camshaft position sensor connector and engine ground.</p> <p>Connector & terminal (E15) No. 1 — Engine ground:</p> | <p>Is the resistance less than 10 Ω?</p> | <p>Go to step 3.</p> | <p>Repair the ground short circuit in harness between camshaft position sensor and ECM connector.</p> <p>NOTE: The harness between both connectors are shielded. Repair the ground short circuit in harness together with shield.</p> |
| <p>3</p> <p>CHECK HARNESS BETWEEN CAMSHAFT POSITION SENSOR AND ECM CONNECTOR.</p> <p>Measure the resistance of harness between camshaft position sensor connector and engine ground.</p> <p>Connector & terminal (E15) No. 2 — Engine ground:</p> | <p>Is the resistance less than 5 Ω?</p> | <p>Go to step 4.</p> | <p>Repair the harness and connector.</p> <p>NOTE: In this case, repair the following:</p> <ul style="list-style-type: none"> • Open circuit in harness between camshaft position sensor and ECM connector • Poor contact in ECM connector • Poor contact in coupling connector |
| <p>4</p> <p>CHECK CONDITION OF CAMSHAFT POSITION SENSOR.</p> | <p>Is the camshaft position sensor installation bolt tightened securely?</p> | <p>Go to step 5.</p> | <p>Tighten the camshaft position sensor installation bolt securely.</p> |
| <p>5</p> <p>CHECK CAMSHAFT POSITION SENSOR.</p> <p>1) Remove the camshaft position sensor. 2) Measure the resistance between connector terminals of camshaft position sensor.</p> <p>Terminals No. 1 — No. 2:</p> | <p>Is the resistance 1 — 4 kΩ?</p> | <p>Repair the poor contact in camshaft position sensor connector.</p> | <p>Replace the camshaft position sensor. <Ref. to FU(H4DOTC)-29, Camshaft Position Sensor.></p> |

Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

AU:DTC P0341 CAMSHAFT POSITION SENSOR "A" CIRCUIT RANGE/PERFORMANCE (BANK 1 OR SINGLE SENSOR)

DTC DETECTING CONDITION:

- Two consecutive driving cycles with fault
- GENERAL DESCRIPTION <Ref. to GD(H4DOTC)-108, ECM OPERATING AT DTC SETTING, DTC P0341 CAMSHAFT POSITION SENSOR "A" CIRCUIT RANGE/PERFORMANCE (BANK 1 OR SINGLE SENSOR), Diagnostic Trouble Code (DTC) Detecting Criteria.>


TROUBLE SYMPTOM:

- Engine stalls.
- Failure of engine to start

CAUTION:

After repair or replacement of faulty parts, conduct Clear Memory Mode <Ref. to EN(H4DOTC)(diag)-46, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(H4DOTC)(diag)-39, PROCEDURE, Inspection Mode.>.

WIRING DIAGRAM:



EN-01242

Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

| Step | Check | Yes | No | |
|------|---|---|---|---|
| 1 | CHECK ANY OTHER DTC ON DISPLAY. | Is any other DTC displayed? | Inspect the relevant DTC using "List of Diagnostic Trouble Code (DTC)". <Ref. to EN(H4DOTC)(diag)-71, List of Diagnostic Trouble Code (DTC).> | Go to step 2. |
| 2 | CHECK HARNESS BETWEEN CAMSHAFT POSITION SENSOR AND ECM CONNECTOR. 1) Turn the ignition switch to OFF. 2) Disconnect the connector from camshaft position sensor. 3) Measure the resistance of harness between camshaft position sensor connector and engine ground. Connector & terminal (E15) No. 1 — Engine ground: | Is the resistance more than 100 k Ω ? | Repair the harness and connector. NOTE: In this case, repair the following: • Open circuit in harness between camshaft position sensor and ECM connector • Poor contact in ECM connector • Poor contact in coupling connector | Go to step 3. |
| 3 | CHECK HARNESS BETWEEN CAMSHAFT POSITION SENSOR AND ECM CONNECTOR. Measure the resistance of harness between camshaft position sensor connector and engine ground. Connector & terminal (E15) No. 1 — Engine ground: | Is the resistance less than 10 Ω ? | Go to step 4. | Repair the ground short circuit in harness between camshaft position sensor and ECM connector. NOTE: The harness between both connectors are shielded. Repair ground short circuit in harness together with shield. |
| 4 | CHECK HARNESS BETWEEN CAMSHAFT POSITION SENSOR AND ECM CONNECTOR. Measure the resistance of harness between camshaft position sensor connector and engine ground. Connector & terminal (E15) No. 2 — Engine ground: | Is the resistance less than 5 Ω ? | Go to step 5. | Repair the harness and connector. NOTE: In this case, repair the following: • Open circuit in harness between camshaft position sensor and ECM connector • Poor contact in ECM connector • Poor contact in coupling connector |
| 5 | CHECK CONDITION OF CAMSHAFT POSITION SENSOR. | Is the camshaft position sensor installation bolt tightened securely? | Go to step 6. | Tighten the camshaft position sensor installation bolt securely. |

Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

| Step | Check | Yes | No |
|--|---|--|--|
| 6 CHECK CAMSHAFT POSITION SENSOR. 1) Remove the camshaft position sensor. 2) Measure the resistance between connector terminals of camshaft position sensor. Terminals No. 1 — No. 2: | Is the resistance 1 — 4 k Ω ? | Go to step 7. | Replace the camshaft position sensor. <Ref. to FU(H4DOTC)-29, Camshaft Position Sensor.> |
| 7 CHECK CONDITION OF CAMSHAFT POSITION SENSOR. Turn the ignition switch to OFF. | Is the camshaft position sensor installation bolt tightened securely? | Go to step 8. | Tighten the camshaft position sensor installation bolt securely. |
| 8 CHECK CAMSHAFT SPROCKET. Remove the front belt cover. <Ref. to ME(H4DOTC)-45, Timing Belt Cover.> | Are the camshaft sprocket teeth cracked or damaged? | Replace the camshaft sprocket. <Ref. to ME(H4DOTC)-54, Camshaft Sprocket.> | Go to step 9. |
| 9 CHECK INSTALLATION CONDITION OF TIMING BELT. Turn the camshaft, and align alignment mark on camshaft sprocket with alignment mark on timing belt cover LH. | Is the timing belt dislocated from its proper position? | Repair the installation condition of timing belt. <Ref. to ME(H4DOTC)-46, Timing Belt Assembly.> | Replace the camshaft position sensor. <Ref. to FU(H4DOTC)-29, Camshaft Position Sensor.> |

Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

AV:DTC P0420 CATALYST SYSTEM EFFICIENCY BELOW THRESHOLD (BANK 1)

DTC DETECTING CONDITION:

- Two consecutive driving cycles with fault
- GENERAL DESCRIPTION <Ref. to GD(H4DOTC)-109, DTC P0420 CATALYST SYSTEM EFFICIENCY BELOW THRESHOLD (BANK 1), Diagnostic Trouble Code (DTC) Detecting Criteria.>


TROUBLE SYMPTOM:

- Engine stalls.
- Idle mixture is out of specifications.

CAUTION:

After repair or replacement of faulty parts, conduct Clear Memory Mode <Ref. to EN(H4DOTC)(diag)-46, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(H4DOTC)(diag)-39, PROCEDURE, Inspection Mode.>.

WIRING DIAGRAM:



EN-01618

Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

| | Step | Check | Yes | No |
|---|--|---|---|--|
| 1 | CHECK ANY OTHER DTC ON DISPLAY. | Is any other DTC displayed? | Inspect the relevant DTC using "List of Diagnostic Trouble Code (DTC)". <Ref. to EN(H4DOTC)(diag)-71, List of Diagnostic Trouble Code (DTC).> NOTE: In this case, it is not necessary to inspect DTC P0420. | Go to step 2. |
| 2 | CHECK EXHAUST SYSTEM. Check for gas leaks or air suction caused by loose or dislocated nuts and bolts, and open hole at exhaust pipes. NOTE: Check the following positions. <ul style="list-style-type: none"> • Between cylinder head and front exhaust pipe • Between front exhaust pipe and front catalytic converter • Between front catalytic converter and rear catalytic converter | Is there a fault in exhaust system? | Repair or replace the exhaust system. <Ref. to EX(H4DOTC)-2, General Description.> | Go to step 3. |
| 3 | CHECK REAR CATALYTIC CONVERTER. Separate the rear catalytic converter from rear exhaust pipe. | Is there damage at rear face of rear catalyst? | Replace the front catalytic converter. <Ref. to EC(H4DOTC)-3, Front Catalytic Converter.> and rear catalytic converter <Ref. to EC(H4DOTC)-4, Rear Catalytic Converter.> | Go to step 4. |
| 4 | CHECK FRONT CATALYTIC CONVERTER. Remove the front catalytic converter. | Is there damage at rear face or front face of front catalyst? | Replace the front catalytic converter. <Ref. to EC(H4DOTC)-3, Front Catalytic Converter.> | Contact your SOA Service Center. NOTE: Inspection by DTM is required, because probable cause is deterioration of multiple parts. |

Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

AW:DTC P0442 EVAPORATIVE EMISSION CONTROL SYSTEM LEAK DETECTED (SMALL LEAK)

DTC DETECTING CONDITION:

- Two consecutive driving cycles with fault
- GENERAL DESCRIPTION <Ref. to GD(H4DOTC)-112, DTC P0442 EVAPORATIVE EMISSION CONTROL SYSTEM LEAK DETECTED (SMALL LEAK), Diagnostic Trouble Code (DTC) Detecting Criteria.>

TROUBLE SYMPTOM:

- Fuel odor
- There is a hole of more than 1.0 mm (0.04 in) dia. in evaporation system or fuel tank.








CAUTION:

After repair or replacement of faulty parts, conduct Clear Memory Mode <Ref. to EN(H4DOTC)(diag)-46, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(H4DOTC)(diag)-39, PROCEDURE, Inspection Mode.>.

Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

WIRING DIAGRAM:



EN-01619

Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

| Step | Check | Yes | No |
|------|--|---|---|
| 1 | CHECK FOR OTHER DTC ON DISPLAY. | Is any other DTC displayed? | Inspect the relevant DTC using "List of Diagnostic Trouble Code (DTC)". <Ref. to EN(H4DOTC)(diag)-71, List of Diagnostic Trouble Code (DTC).> |
| 2 | CHECK FUEL FILLER CAP. 1) Turn ignition switch to OFF. 2) Check the fuel filler cap. NOTE: The DTC is stored in memory if fuel filler cap is or was loose or if the cap chain was caught while tightening. | Is the fuel filler cap tightened securely? | Go to step 3. Tighten fuel filler cap securely. |
| 3 | CHECK FUEL FILLER CAP. | Is the fuel filler cap SUBARU genuine? | Go to step 4. Replace with a SUBARU genuine fuel filler cap. |
| 4 | CHECK FUEL FILLER PIPE PACKING. | Is there any damage to the seal between fuel filler cap and fuel filler pipe? | Repair or replace the fuel filler cap and fuel filler pipe. <Ref. to FU(H4DOTC)-56, Fuel Filler Pipe.> |
| 5 | CHECK DRAIN VALVE. 1) Connect the test mode connector. 2) Turn ignition switch to ON. 3) Operate the drain valve. NOTE: Drain valve operation can also be executed using Subaru Select Monitor. For the procedure, refer to "Compulsory Valve Operation Check Mode". <Ref. to EN(H4DOTC)(diag)-47, Compulsory Valve Operation Check Mode.> | Does the drain valve operate? | Go to step 6. Replace the drain valve. <Ref. to EC(H4DOTC)-19, Drain Valve.> |
| 6 | CHECK PURGE CONTROL SOLENOID VALVE. Operate the purge control solenoid valve. NOTE: Purge control solenoid valve operation can also be executed using Subaru Select Monitor. For the procedure, refer to "Compulsory Valve Operation Check Mode". <Ref. to EN(H4DOTC)(diag)-47, Compulsory Valve Operation Check Mode.> | Does the purge control solenoid valve operate? | Go to step 7. Replace the purge control solenoid valve. <Ref. to EC(H4DOTC)-7, Purge Control Solenoid Valve.> |
| 7 | CHECK PRESSURE CONTROL SOLENOID VALVE. Operate the pressure control solenoid valve. NOTE: Pressure control solenoid valve operation can also be executed using Subaru Select Monitor. For the procedure, refer to "Compulsory Valve Operation Check Mode". <Ref. to EN(H4DOTC)(diag)-47, Compulsory Valve Operation Check Mode.> | Does the pressure control solenoid valve operate? | Go to step 8. Replace the pressure control solenoid valve. <Ref. to EC(H4DOTC)-13, Pressure Control Solenoid Valve.> |

Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

| Step | Check | Yes | No | |
|-----------|--|--|---|--|
| 8 | CHECK EVAPORATIVE EMISSION CONTROL SYSTEM LINE. Turn ignition switch to OFF. | Is there a hole of more than 1.0 mm (0.04 in) dia. on evaporation line? | Repair or replace the evaporation line. <Ref. to FU(H4DOTC)-69, Fuel Delivery, Return and Evaporation Lines.> | Go to step 9. |
| 9 | CHECK CANISTER. | Is the canister damaged or is there a hole of more than 1.0 mm (0.04 in) dia. in it? | Repair or replace the canister. <Ref. to EC(H4DOTC)-6, Canister.> | Go to step 10. |
| 10 | CHECK FUEL TANK. Remove the fuel tank. <Ref. to FU(H4DOTC)-53, Fuel Tank.> | Is the fuel tank damaged or is there a hole of more than 1.0 mm (0.04 in) dia. in it? | Repair or replace the fuel tank. <Ref. to FU(H4DOTC)-53, Fuel Tank.> | Go to step 11. |
| 11 | CHECK ANY OTHER MECHANICAL TROUBLE IN EVAPORATIVE EMISSION CONTROL SYSTEM. | Are there holes of more than 1.0 mm (0.04 in) dia., cracks, clogging, or disconnections, bend, misconnection of hoses or pipes in evaporative emission control system? | Repair or replace the hoses or pipes. | Contact with SOA Service Center. NOTE: Inspection by DTM is required, because probable cause is deterioration of multiple parts. |

Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

| Step | Check | Yes | No |
|---|--|---------------------------------------|---|
| 1 CHECK OUTPUT SIGNAL FROM ECM. 1) Turn ignition switch to ON. 2) Measure the voltage between ECM and chassis ground. Connector & terminal (B84) No. 11 (+) — Chassis ground (-): | Is the voltage more than 10 V? | Go to step 2. | Go to step 3. |
| 2 CHECK FOR POOR CONTACT. Check for poor contact in ECM connector. | Is there poor contact in ECM connector? | Repair poor contact in ECM connector. | The malfunction indicator light may light up, however, the circuit is returned to the normal status at the moment. (However, the possibility of poor contact still remains.) NOTE: In this case, repair the following: <ul style="list-style-type: none"> • Poor contact in drain valve connector • Poor contact in ECM connector • Poor contact in coupling connector |
| 3 CHECK HARNESS BETWEEN DRAIN VALVE AND ECM CONNECTOR. 1) Turn ignition switch to OFF. 2) Disconnect the connectors from drain valve and ECM. 3) Measure the resistance of harness between drain valve connector and chassis ground. Connector & terminal (R69) No. 2 — Chassis ground: | Is the resistance more than 1 M Ω ? | Go to step 4. | Repair short circuit to ground in harness between ECM and drain valve connector. |
| 4 CHECK HARNESS BETWEEN DRAIN VALVE AND ECM CONNECTOR. Measure the resistance of harness between ECM and drain valve connector. Connector & terminal (B84) No. 11 — (R69) No. 2: | Is the resistance less than 1 Ω ? | Go to step 5. | Repair harness and connector. NOTE: In this case, repair the following: <ul style="list-style-type: none"> • Open circuit in harness between ECM and drain valve connector • Poor contact in coupling connector |
| 5 CHECK DRAIN VALVE. Measure the resistance between drain valve terminals. Terminals No. 1 — No. 2: | Is the resistance 10 — 100 Ω ? | Go to step 6. | Replace the drain valve. <Ref. to EC(H4DOTC)-19, Drain Valve.> |

Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

| Step | Check | Yes | No |
|---|--|--|---|
| <p>6 CHECK POWER SUPPLY TO DRAIN VALVE. 1) Turn ignition switch to ON. 2) Measure the voltage between drain valve and chassis ground. Connector & terminal (R69) No. 1 (+) — Chassis ground (-):</p> | <p>Is the voltage more than 10 V?</p> | <p>Go to step 7.</p> | <p>Repair harness and connector. NOTE: In this case, repair the following: • Open circuit in harness between main relay and drain valve • Poor contact in coupling connector • Poor contact in main relay connector</p> |
| <p>7 CHECK FOR POOR CONTACT. Check for poor contact in drain valve connector.</p> | <p>Is there poor contact in drain valve connector?</p> | <p>Repair poor contact in drain valve connector.</p> | <p>Contact with SOA Service Center. NOTE: Inspection by DTM is required, because probable cause is deterioration of multiple parts.</p> |

Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

AY:DTC P0448 EVAPORATIVE EMISSION CONTROL SYSTEM VENT CONTROL CIRCUIT SHORTED


DTC DETECTING CONDITION:

- Two consecutive driving cycles with fault
- GENERAL DESCRIPTION <Ref. to GD(H4DOTC)-137, DTC P0448 EVAPORATIVE EMISSION CONTROL SYSTEM VENT CONTROL CIRCUIT SHORTED, Diagnostic Trouble Code (DTC) Detecting Criteria.>

CAUTION:

After repair or replacement of faulty parts, conduct Clear Memory Mode <Ref. to EN(H4DOTC)(diag)-46, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(H4DOTC)(diag)-39, PROCEDURE, Inspection Mode.>.

WIRING DIAGRAM:



EN-01620

Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

| Step | Check | Yes | No |
|--|---|--|--|
| 1 CHECK INPUT SIGNAL FOR ECM. 1) Turn ignition switch to OFF. 2) Connect the test mode connector at the lower portion of instrument panel (on the driver's side). 3) Turn ignition switch to ON. 4) While operating the drain valve, measure voltage between ECM and chassis ground. NOTE: Drain valve operation can be executed using Subaru Select Monitor. For the procedure, refer to "Compulsory Valve Operation Check Mode". <Ref. to EN(H4DOTC)(diag)-47, Compulsory Valve Operation Check Mode.> Connector & terminal (B84) No. 11 (+) — Chassis ground (-): | Does the resistance change within 0 — 10 V? | Go to step 2. | The malfunction indicator light may light up, however, the circuit is returned to the normal status at the moment. In this case, repair poor contact in ECM connector. |
| 2 CHECK INPUT SIGNAL FOR ECM. 1) Turn ignition switch to ON. 2) Measure the voltage between ECM and chassis ground. Connector & terminal (B84) No. 11 (+) — Chassis ground (-): | Is the voltage more than 10 V? | Go to step 4. | Go to step 3. |
| 3 CHECK FOR POOR CONTACT. Check for poor contact in ECM connector. | Is there poor contact in ECM connector? | Repair poor contact in ECM connector. | Replace the ECM. <Ref. to FU(H4DOTC)-48, Engine Control Module (ECM).> |
| 4 CHECK HARNESS BETWEEN DRAIN VALVE AND ECM CONNECTOR. 1) Turn ignition switch to OFF. 2) Disconnect the connector from drain valve. 3) Turn ignition switch to ON. 4) Measure the voltage between ECM and chassis ground. Connector & terminal (B84) No. 11 (+) — Chassis ground (-): | Is the voltage more than 10 V? | Repair short circuit to battery in harness between ECM and drain valve connector. After repair, replace the ECM. <Ref. to FU(H4DOTC)-48, Engine Control Module (ECM).> | Go to step 5. |
| 5 CHECK DRAIN VALVE. 1) Turn ignition switch to OFF. 2) Measure the resistance between drain valve terminals. Terminals No. 1 — No. 2: | Is the resistance less than 1 Ω ? | Replace the drain valve <Ref. to EC(H4DOTC)-19, Drain Valve.> and ECM <Ref. to FU(H4DOTC)-48, Engine Control Module (ECM).>. | Go to step 6. |
| 6 CHECK FOR POOR CONTACT. Check for poor contact in ECM connector. | Is there poor contact in ECM connector? | Repair poor contact in ECM connector. | Replace the ECM. <Ref. to FU(H4DOTC)-48, Engine Control Module (ECM).> |

Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

AZ:DTC P0451 EVAPORATIVE EMISSION CONTROL SYSTEM PRESSURE SENSOR RANGE/PERFORMANCE


DTC DETECTING CONDITION:

- Two consecutive driving cycles with fault
- GENERAL DESCRIPTION <Ref. to GD(H4DOTC)-139, DTC P0451 EVAPORATIVE EMISSION CONTROL SYSTEM PRESSURE SENSOR RANGE/PERFORMANCE, Diagnostic Trouble Code (DTC) Detecting Criteria.>

CAUTION:

After repair or replacement of faulty parts, conduct Clear Memory Mode <Ref. to EN(H4DOTC)(diag)-46, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(H4DOTC)(diag)-39, PROCEDURE, Inspection Mode.>.

WIRING DIAGRAM:



EN-01621

Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

| | Step | Check | Yes | No |
|---|--|--|---|--|
| 1 | CHECK FOR OTHER DTC ON DISPLAY. | Is any other DTC displayed? | Inspect the relevant DTC using "List of Diagnostic Trouble Code (DTC)". <Ref. to EN(H4DOTC)(diag)-71, List of Diagnostic Trouble Code (DTC).> | Go to step 2. |
| 2 | CHECK FUEL FILLER CAP. 1) Turn ignition switch to OFF. 2) Open the fuel flap. | Is the fuel filler cap tightened securely? | Go to step 3. | Tighten fuel filler cap securely. |
| 3 | CHECK PRESSURE/VACUUM LINE. NOTE: Check the following items. <ul style="list-style-type: none"> • Disconnection, leakage and clogging of the vacuum hoses and pipes between fuel tank pressure sensor and fuel tank • Disconnection, leakage and clogging of air ventilation hoses and pipes between fuel filler pipe and fuel tank | Is there a fault in pressure/vacuum line? | Repair or replace the hoses and pipes. | Replace the fuel tank pressure sensor. <Ref. to EC(H4DOTC)-11, Fuel Tank Pressure Sensor.> |

Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

BA:DTC P0452 EVAPORATIVE EMISSION CONTROL SYSTEM PRESSURE SENSOR LOW INPUT


DTC DETECTING CONDITION:

- Two consecutive driving cycles with fault
- GENERAL DESCRIPTION <Ref. to GD(H4DOTC)-141, DTC P0452 EVAPORATIVE EMISSION CONTROL SYSTEM PRESSURE SENSOR LOW INPUT, Diagnostic Trouble Code (DTC) Detecting Criteria.>

CAUTION:

After repair or replacement of faulty parts, conduct Clear Memory Mode <Ref. to EN(H4DOTC)(diag)-46, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(H4DOTC)(diag)-39, PROCEDURE, Inspection Mode.>.

WIRING DIAGRAM:



EN-01621

Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

| Step | Check | Yes | No |
|--|---|--|---|
| <p>1</p> <p>CHECK CURRENT DATA.</p> <ol style="list-style-type: none"> 1) Turn ignition switch to OFF. 2) Remove the fuel filler cap. 3) Install the fuel filler cap. 4) Turn ignition switch to ON. 5) Read the data of fuel tank pressure sensor signal using Subaru Select Monitor or the OBD-II general scan tool. <p>NOTE:</p> <ul style="list-style-type: none"> • Subaru Select Monitor <p>For detailed operation procedures, refer to "READ CURRENT DATA FOR ENGINE". <Ref. to EN(H4DOTC)(diag)-31, Subaru Select Monitor.></p> <ul style="list-style-type: none"> • OBD-II general scan tool <p>For detailed operation procedures, refer to the OBD-II General Scan Tool Instruction Manual.</p> | <p>Is the measured value less than -2.8 kPa (-21.0 mmHg, -0.827 inHg)?</p> | <p>Go to step 2.</p> | <p>The malfunction indicator light may light up, however, the circuit is returned to the normal status at the moment.</p> |
| <p>2</p> <p>CHECK POWER SUPPLY TO FUEL TANK PRESSURE SENSOR.</p> <p>Measure the voltage between ECM connector and chassis ground.</p> <p>Connector & terminal (B135) No. 9 (+) — Chassis ground (-):</p> | <p>Is the voltage more than 4.5 V?</p> | <p>Go to step 4.</p> | <p>Go to step 3.</p> |
| <p>3</p> <p>CHECK POWER SUPPLY TO FUEL TANK PRESSURE SENSOR.</p> <p>Measure the voltage between ECM connector and chassis ground.</p> <p>Connector & terminal (B135) No. 9 (+) — Chassis ground (-):</p> | <p>Is the voltage more than 4.5 V?</p> | <p>Repair poor contact in ECM connector.</p> | <p>Contact with SOA Service Center.</p> <p>NOTE: Inspection by DTM is required, because probable cause is deterioration of multiple parts.</p> |
| <p>4</p> <p>CHECK INPUT SIGNAL FOR ECM.</p> <p>Measure the voltage between ECM and chassis ground.</p> <p>Connector & terminal (B135) No. 15 (+) — Chassis ground (-):</p> | <p>Is the voltage less than 0.2 V?</p> | <p>Go to step 6.</p> | <p>Go to step 5.</p> |
| <p>5</p> <p>CHECK INPUT SIGNAL FOR ECM. (USING SUBARU SELECT MONITOR.)</p> <p>Read the data of fuel tank pressure sensor signal using Subaru Select Monitor.</p> <p>NOTE:</p> <ul style="list-style-type: none"> • Subaru Select Monitor <p>For detailed operation procedures, refer to "READ CURRENT DATA FOR ENGINE". <Ref. to EN(H4DOTC)(diag)-31, Subaru Select Monitor.></p> | <p>Does the measured value exceed the specified value by shaking the ECM harness and connector?</p> | <p>Repair poor contact in ECM connector.</p> | <p>Go to step 6.</p> |
| <p>6</p> <p>CHECK HARNESS BETWEEN ECM AND COUPLING CONNECTOR IN REAR WIRING HARNESS.</p> <ol style="list-style-type: none"> 1) Turn ignition switch to OFF. 2) Remove the rear seat cushion. 3) Separate rear wiring harness and fuel tank cord. 4) Turn ignition switch to ON. 5) Measure the voltage between rear wiring harness connector and chassis ground. <p>Connector & terminal (R15) No. 12 (+) — Chassis ground (-):</p> | <p>Is the voltage more than 4.5 V?</p> | <p>Go to step 7.</p> | <p>Repair harness and connector.</p> <p>NOTE: In this case, repair the following:</p> <ul style="list-style-type: none"> • Open circuit in harness between ECM and rear wiring harness connector • Poor contact in coupling connector |

Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

| Step | Check | Yes | No |
|--|--|--|--|
| <p>7</p> <p>CHECK HARNESS BETWEEN ECM AND COUPLING CONNECTOR IN REAR WIRING HARNESS. 1) Turn ignition switch to OFF. 2) Disconnect the connector from ECM. 3) Measure the resistance of harness between ECM and rear wiring harness connector.</p> <p>Connector & terminal (B135) No. 19 — (R15) No. 14:</p> | <p>Is the resistance less than 1 Ω?</p> | <p>Go to step 8.</p> | <p>Repair harness and connector.</p> <p>NOTE: In this case, repair the following:</p> <ul style="list-style-type: none"> • Open circuit in harness between ECM and rear wiring harness connector • Poor contact in coupling connector • Poor contact in joint connector |
| <p>8</p> <p>CHECK HARNESS BETWEEN ECM AND COUPLING CONNECTOR IN REAR WIRING HARNESS. Measure the resistance of harness between rear wiring harness connector and chassis ground.</p> <p>Connector & terminal (R15) No. 14 — Chassis ground:</p> | <p>Is the resistance more than 1 $M\Omega$?</p> | <p>Go to step 9.</p> | <p>Repair short circuit to ground in harness between ECM and rear wiring harness connector.</p> |
| <p>9</p> <p>CHECK FUEL TANK CORD. 1) Disconnect the connector from fuel tank pressure sensor. 2) Measure the resistance of fuel tank cord.</p> <p>Connector & terminal (R57) No. 12 — (R47) No. 3:</p> | <p>Is the resistance less than 1 Ω?</p> | <p>Go to step 10.</p> | <p>Repair open circuit in fuel tank cord.</p> |
| <p>10</p> <p>CHECK FUEL TANK CORD. Measure the resistance of fuel tank cord.</p> <p>Connector & terminal (R57) No. 14 — (R47) No. 2:</p> | <p>Is the resistance less than 1 Ω?</p> | <p>Go to step 11.</p> | <p>Repair open circuit in fuel tank cord.</p> |
| <p>11</p> <p>CHECK FUEL TANK CORD. Measure the resistance of harness between fuel tank pressure sensor connector and engine ground.</p> <p>Connector & terminal (R47) No. 1 — Chassis ground:</p> | <p>Is the resistance more than 1 $M\Omega$?</p> | <p>Go to step 12.</p> | <p>Repair short circuit to ground in fuel tank cord.</p> |
| <p>12</p> <p>CHECK FOR POOR CONTACT. Check for poor contact in fuel tank pressure sensor connector.</p> | <p>Is there poor contact in fuel tank pressure sensor connector?</p> | <p>Repair poor contact in fuel tank pressure sensor connector.</p> | <p>Replace the fuel tank pressure sensor. <Ref. to EC(H4DOTC)-11, Fuel Tank Pressure Sensor.></p> |

BB:DTC P0453 EVAPORATIVE EMISSION CONTROL SYSTEM PRESSURE SENSOR HIGH INPUT


DTC DETECTING CONDITION:

- Two consecutive driving cycles with fault
- GENERAL DESCRIPTION <Ref. to GD(H4DOTC)-143, DTC P0453 EVAPORATIVE EMISSION CONTROL SYSTEM PRESSURE SENSOR HIGH INPUT, Diagnostic Trouble Code (DTC) Detecting Criteria.>

CAUTION:

After repair or replacement of faulty parts, conduct Clear Memory Mode <Ref. to EN(H4DOTC)(diag)-46, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(H4DOTC)(diag)-39, PROCEDURE, Inspection Mode.>.

WIRING DIAGRAM:



EN-01621

Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

| Step | Check | Yes | No |
|--|---|---------------------------------------|--|
| 1 CHECK CURRENT DATA. 1) Turn ignition switch to OFF. 2) Remove the fuel filler cap. 3) Install the fuel filler cap. 4) Turn ignition switch to ON. 5) Read the data of fuel tank pressure sensor signal using Subaru Select Monitor or the OBD-II general scan tool. NOTE: • Subaru Select Monitor For detailed operation procedures, refer to "READ CURRENT DATA FOR ENGINE". <Ref. to EN(H4DOTC)(diag)-31, Subaru Select Monitor.> • OBD-II general scan tool For detailed operation procedures, refer to the OBD-II General Scan Tool Instruction Manual. | Is the measured value more than 2.8 kPa (21.0 mmHg, 0.827 inHg) | Go to step 11. | Go to step 2. |
| 2 CHECK POWER SUPPLY TO FUEL TANK PRESSURE SENSOR. Measure the voltage between ECM connector and chassis ground. <i>Connector & terminal</i> <i>(B135) No. 9 (+) — Chassis ground (-):</i> | Is the voltage more than 4.5 V? | Go to step 4. | Go to step 3. |
| 3 CHECK POWER SUPPLY TO FUEL TANK PRESSURE SENSOR. Measure the voltage between ECM connector and chassis ground. <i>Connector & terminal</i> <i>(B135) No. 9 (+) — Chassis ground (-):</i> | Does the measured value exceed the specified value by shaking the ECM harness and connector? | Repair poor contact in ECM connector. | Replace the ECM. <Ref. to FU(H4DOTC)-48, Engine Control Module (ECM).> |
| 4 CHECK INPUT SIGNAL FOR ECM. Measure the voltage between ECM and chassis ground. <i>Connector & terminal</i> <i>(B135) No. 15 (+) — Chassis ground (-):</i> | Is the voltage less than 0.2 V? | Go to step 6. | Go to step 5. |
| 5 CHECK INPUT SIGNAL FOR ECM. (USING SUBARU SELECT MONITOR.) Read the data of fuel tank pressure sensor signal using Subaru Select Monitor. NOTE: • Subaru Select Monitor For detailed operation procedures, refer to "READ CURRENT DATA FOR ENGINE". <Ref. to EN(H4DOTC)(diag)-31, Subaru Select Monitor.> | Does the measured value exceed -2.8 kPa (-21.0 mmHg, -0.827 inHg) by shaking the ECM harness and connector? | Repair poor contact in ECM connector. | Go to step 6. |
| 6 CHECK HARNESS BETWEEN ECM AND COUPLING CONNECTOR IN REAR WIRING HARNESS. 1) Turn ignition switch to OFF. 2) Remove the rear seat cushion. 3) Separate rear wiring harness and fuel tank cord. 4) Turn ignition switch to ON. 5) Measure the voltage between rear wiring harness connector and chassis ground. <i>Connector & terminal</i> <i>(R15) No. 12 (+) — Chassis ground (-):</i> | Is the voltage more than 4.5 V? | Go to step 7. | Repair harness and connector. NOTE: In this case, repair the following: • Open circuit in harness between ECM and rear wiring harness connector • Poor contact in coupling connector |

Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

| Step | Check | Yes | No |
|---|---|--|---|
| <p>7 CHECK HARNESS BETWEEN ECM AND COUPLING CONNECTOR IN REAR WIRING HARNESS.</p> <p>1) Turn ignition switch to OFF. 2) Disconnect the connector from ECM. 3) Measure the resistance of harness between ECM and rear wiring harness connector.</p> <p>Connector & terminal (B135) No. 15 — (R15) No. 13: (B135) No. 19 — (R15) No. 14:</p> | <p>Is the resistance less than 1 Ω?</p> | <p>Go to step 8.</p> | <p>Repair harness and connector.</p> <p>NOTE: In this case, repair the following:</p> <ul style="list-style-type: none"> • Open circuit in harness between ECM and rear wiring harness connector • Poor contact in coupling connector |
| <p>8 CHECK FUEL TANK CORD.</p> <p>1) Disconnect the connector from fuel tank pressure sensor. 2) Measure the resistance of fuel tank cord.</p> <p>Connector & terminal (R57) No. 13 — (R47) No. 1:</p> | <p>Is the resistance less than 1 Ω?</p> | <p>Go to step 9.</p> | <p>Repair open circuit in fuel tank cord.</p> |
| <p>9 CHECK FUEL TANK CORD.</p> <p>Measure the resistance of fuel tank cord.</p> <p>Connector & terminal (R57) No. 14 — (R47) No. 2:</p> | <p>Is the resistance less than 1 Ω?</p> | <p>Go to step 10.</p> | <p>Repair open circuit in fuel tank cord.</p> |
| <p>10 CHECK FOR POOR CONTACT.</p> <p>Check for poor contact in fuel tank pressure sensor connector.</p> | <p>Is there poor contact in fuel tank pressure sensor connector?</p> | <p>Repair poor contact in fuel tank pressure sensor connector.</p> | <p>Replace the fuel tank pressure sensor. <Ref. to EC(H4DOTC)-11, Fuel Tank Pressure Sensor.></p> |
| <p>11 CHECK HARNESS BETWEEN ECM AND FUEL TANK PRESSURE SENSOR CONNECTOR.</p> <p>1) Turn ignition switch to OFF. 2) Disconnect the connector from fuel tank pressure sensor. 3) Turn ignition switch to ON. 4) Read the data of fuel tank pressure sensor signal using Subaru Select Monitor or the OBD-II general scan tool.</p> <p>NOTE:</p> <ul style="list-style-type: none"> • Subaru Select Monitor For detailed operation procedures, refer to "READ CURRENT DATA FOR ENGINE". <Ref. to EN(H4DOTC)(diag)-31, Subaru Select Monitor.> • OBD-II general scan tool For detailed operation procedures, refer to the OBD-II General Scan Tool Instruction Manual. | <p>Is the measured value more than 2.8 kPa (21.0 mmHg, 0.827 inHg)?</p> | <p>Repair short circuit to battery in harness between ECM and fuel tank pressure sensor connector.</p> | <p>Replace the fuel tank pressure sensor. <Ref. to EC(H4DOTC)-11, Fuel Tank Pressure Sensor.></p> |

Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

BC:DTC P0456 EVAPORATIVE EMISSION CONTROL SYSTEM LEAK DETECTED (VERY SMALL LEAK)

DTC DETECTING CONDITION:

- Two consecutive driving cycles with fault
- GENERAL DESCRIPTION <Ref. to GD(H4DOTC)-144, DTC P0456 EVAPORATIVE EMISSION CONTROL SYSTEM LEAK DETECTED (VERY SMALL LEAK), Diagnostic Trouble Code (DTC) Detecting Criteria.>

TROUBLE SYMPTOM:

- Fuel odor
- There is a hole of more than 0.5 mm (0.020 in) dia. in evaporation system or fuel tank.









CAUTION:

After repair or replacement of faulty parts, conduct Clear Memory Mode <Ref. to EN(H4DOTC)(diag)-46, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(H4DOTC)(diag)-39, PROCEDURE, Inspection Mode.>.

Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

WIRING DIAGRAM:



EN-01619

Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

| Step | Check | Yes | No |
|----------|---|---|---|
| 1 | CHECK FOR OTHER DTC ON DISPLAY. | Is any other DTC displayed? | Inspect the relevant DTC using "List of Diagnostic Trouble Code (DTC)". <Ref. to EN(H4DOTC)(diag)-71, List of Diagnostic Trouble Code (DTC).> |
| 2 | CHECK FUEL FILLER CAP. 1) Turn ignition switch to OFF. 2) Check the fuel filler cap. NOTE: The DTC is stored in memory if fuel filler cap is or was loose or if the cap chain was caught while tightening. | Is the fuel filler cap tightened securely? | Go to step 3. Tighten fuel filler cap securely. |
| 3 | CHECK FUEL FILLER CAP. | Is the fuel filler cap SUBARU genuine? | Go to step 4. Replace with a SUBARU genuine fuel filler cap. |
| 4 | CHECK FUEL FILLER PIPE PACKING. | Is there any damage to the seal between fuel filler cap and fuel filler pipe? | Repair or replace the fuel filler cap and fuel filler pipe. <Ref. to FU(H4DOTC)-56, Fuel Filler Pipe.> |
| 5 | CHECK DRAIN VALVE. 1) Connect the test mode connector. 2) Turn ignition switch to ON. 3) Operate the drain valve. NOTE: Drain valve operation can also be executed using Subaru Select Monitor. For the procedure, refer to "Compulsory Valve Operation Check Mode". <Ref. to EN(H4DOTC)(diag)-47, Compulsory Valve Operation Check Mode.> | Does the drain valve operate? | Go to step 6. Replace the drain valve. <Ref. to EC(H4DOTC)-19, Drain Valve.> |
| 6 | CHECK PURGE CONTROL SOLENOID VALVE. Operate the purge control solenoid valve. NOTE: Purge control solenoid valve operation can also be executed using Subaru Select Monitor. For the procedure, refer to "Compulsory Valve Operation Check Mode". <Ref. to EN(H4DOTC)(diag)-47, Compulsory Valve Operation Check Mode.> | Does the purge control solenoid valve operate? | Go to step 7. Replace the purge control solenoid valve. <Ref. to EC(H4DOTC)-7, Purge Control Solenoid Valve.> |
| 7 | CHECK PRESSURE CONTROL SOLENOID VALVE. Operate the pressure control solenoid valve. NOTE: Pressure control solenoid valve operation can also be executed using Subaru Select Monitor. For the procedure, refer to "Compulsory Valve Operation Check Mode". <Ref. to EN(H4DOTC)(diag)-47, Compulsory Valve Operation Check Mode.> | Does the pressure control solenoid valve operate? | Go to step 8. Replace the pressure control solenoid valve. <Ref. to EC(H4DOTC)-7, Purge Control Solenoid Valve.> |

Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

| Step | Check | Yes | No |
|--|---|---|--|
| 8 CHECK EVAPORATIVE EMISSION CONTROL SYSTEM LINE. Turn ignition switch to OFF. | Is there a hole of more than 0.5 mm (0.020 in) dia. on evaporation line? | Repair or replace the evaporation line. <Ref. to FU(H4DOTC)-69, Fuel Delivery, Return and Evaporation Lines.> | Go to step 9. |
| 9 CHECK CANISTER. | Is the canister damaged or is there a hole of more than 0.5 mm (0.020 in) dia. in it? | Repair or replace the canister. <Ref. to EC(H4DOTC)-6, Canister.> | Go to step 10. |
| 10 CHECK FUEL TANK. Remove the fuel tank. <Ref. to FU(H4DOTC)-53, Fuel Tank.> | Is the fuel tank damaged or is there a hole of more than 0.5 mm (0.020 in) dia. in it? | Repair or replace the fuel tank. <Ref. to FU(H4DOTC)-53, Fuel Tank.> | Go to step 11. |
| 11 CHECK ANY OTHER MECHANICAL TROUBLE IN EVAPORATIVE EMISSION CONTROL SYSTEM. | Are there holes of more than 0.5 mm (0.020 in) dia., cracks, clogging, or disconnections, bend, misconnection of hoses or pipes in evaporative emission control system? | Repair or replace the hoses or pipes. | Contact with SOA Service Center. NOTE: Inspection by DTM is required, because probable cause is deterioration of multiple parts. |

Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

BD:DTC P0457 EVAPORATIVE EMISSION CONTROL SYSTEM LEAK DETECTED (FUEL CAP LOOSE/OFF)

DTC DETECTING CONDITION:

- Two consecutive driving cycles with fault
- GENERAL DESCRIPTION <Ref. to GD(H4DOTC)-144, DTC P0457 EVAPORATIVE EMISSION CONTROL SYSTEM LEAK DETECTED (FUEL CAP LOOSE/OFF), Diagnostic Trouble Code (DTC) Detecting Criteria.>

TROUBLE SYMPTOM:

- Fuel odor
- Fuel filler cap is loose or not installed.










CAUTION:

After repair or replacement of faulty parts, conduct Clear Memory Mode <Ref. to EN(H4DOTC)(diag)-46, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(H4DOTC)(diag)-39, PROCEDURE, Inspection Mode.>.

Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

WIRING DIAGRAM:



EN-01619

Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

| Step | Check | Yes | No |
|----------|--|---|---|
| 1 | CHECK FOR OTHER DTC ON DISPLAY. | Is any other DTC displayed? | Inspect the relevant DTC using "List of Diagnostic Trouble Code (DTC)". <Ref. to EN(H4DOTC)(diag)-71, List of Diagnostic Trouble Code (DTC).> |
| 2 | CHECK FUEL FILLER CAP. 1) Turn ignition switch to OFF. 2) Check the fuel filler cap. NOTE: The DTC is stored in memory if fuel filler cap is or was loose or if the cap chain was caught while tightening. | Is the fuel filler cap tightened securely? | Go to step 3. Tighten fuel filler cap securely. |
| 3 | CHECK FUEL FILLER CAP. | Is the fuel filler cap SUBARU genuine? | Go to step 4. Replace with a SUBARU genuine fuel filler cap. |
| 4 | CHECK FUEL FILLER PIPE PACKING. | Is there any damage to the seal between fuel filler cap and fuel filler pipe? | Repair or replace the fuel filler cap and fuel filler pipe. <Ref. to FU(H4DOTC)-56, Fuel Filler Pipe.> |
| 5 | CHECK DRAIN VALVE. 1) Connect the test mode connector. 2) Turn ignition switch to ON. 3) Operate the drain valve. NOTE: Drain valve operation can also be executed using Subaru Select Monitor. For the procedure, refer to "Compulsory Valve Operation Check Mode". <Ref. to EN(H4DOTC)(diag)-47, Compulsory Valve Operation Check Mode.> | Does the drain valve operate? | Go to step 6. Replace the drain valve. <Ref. to EC(H4DOTC)-19, Drain Valve.> |
| 6 | CHECK PURGE CONTROL SOLENOID VALVE. Operate the purge control solenoid valve. NOTE: Purge control solenoid valve operation can also be executed using Subaru Select Monitor. For the procedure, refer to "Compulsory Valve Operation Check Mode". <Ref. to EN(H4DOTC)(diag)-71, List of Diagnostic Trouble Code (DTC).> | Does the purge control solenoid valve operate? | Go to step 7. Replace the purge control solenoid valve. <Ref. to EC(H4DOTC)-7, Purge Control Solenoid Valve.> |
| 7 | CHECK PRESSURE CONTROL SOLENOID VALVE. Operate the pressure control solenoid valve. NOTE: Pressure control solenoid valve operation can also be executed using Subaru Select Monitor. For the procedure, refer to "Compulsory Valve Operation Check Mode". <Ref. to EN(H4DOTC)(diag)-47, Compulsory Valve Operation Check Mode.> | Does the pressure control solenoid valve operate? | Go to step 8. Replace the pressure control solenoid valve. <Ref. to EC(H4DOTC)-7, Purge Control Solenoid Valve.> |
| 8 | CHECK CANISTER. | Is the canister damaged? | Repair or replace the canister. <Ref. to EC(H4DOTC)-6, Canister.> |

Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

| Step | Check | Yes | No |
|--|---|--|---|
| 9 CHECK FUEL TANK. Remove the fuel tank. <Ref. to FU(H4DOTC)-53, Fuel Tank.> | Is the fuel tank damaged? | Repair or replace the fuel tank. <Ref. to FU(H4DOTC)-53, Fuel Tank.> | Go to step 10 . |
| 10 CHECK ANY OTHER MECHANICAL TROUBLE IN EVAPORATIVE EMISSION CONTROL SYSTEM. | Are there holes of more than 0.5 mm (0.020 in) dia., cracks, clogging, or disconnections, misconnection of hoses or pipes in evaporative emission control system? | Repair or replace the hoses or pipes. | Contact with SOA Service Center. NOTE: Inspection by DTM is required, because probable cause is deterioration of multiple parts. |

Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

BE:DTC P0458 EVAPORATIVE EMISSION CONTROL SYSTEM PURGE CONTROL VALVE CIRCUIT LOW

DTC DETECTING CONDITION:

- Two consecutive driving cycles with fault
- GENERAL DESCRIPTION <Ref. to GD(H4DOTC)-145, DTC P0458 EVAPORATIVE EMISSION CONTROL SYSTEM PURGE CONTROL VALVE CIRCUIT LOW, Diagnostic Trouble Code (DTC) Detecting Criteria.>


TROUBLE SYMPTOM:

Erroneous idling

CAUTION:

After repair or replacement of faulty parts, conduct Clear Memory Mode <Ref. to EN(H4DOTC)(diag)-46, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(H4DOTC)(diag)-39, PROCEDURE, Inspection Mode.>.

WIRING DIAGRAM:



Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

| Step | Check | Yes | No |
|--|--|---|--|
| <p>1</p> <p>CHECK OUTPUT SIGNAL FROM ECM. 1) Turn the ignition switch to ON. 2) Measure the voltage between ECM and chassis ground. <i>Connector & terminal</i> <i>(B84) No. 16 (+) — Chassis ground (-):</i></p> | Is the voltage more than 10 V? | Even if malfunction indicator light lights up, the circuit has returned to a normal condition at this time. | Go to step 2. |
| <p>2</p> <p>CHECK HARNESS BETWEEN PURGE CONTROL SOLENOID VALVE AND ECM CONNECTOR. 1) Turn the ignition switch to OFF. 2) Disconnect the connectors from purge control solenoid valve and ECM. 3) Measure the resistance of harness between purge control solenoid valve connector and engine ground. <i>Connector & terminal</i> <i>(E4) No. 2 — Engine ground:</i></p> | Is the resistance more than 1 M Ω ? | Go to step 3. | Repair the ground short circuit in harness between ECM and purge control solenoid valve connector. |
| <p>3</p> <p>CHECK HARNESS BETWEEN PURGE CONTROL SOLENOID VALVE AND ECM CONNECTOR. Measure the resistance of harness between ECM and purge control solenoid valve of harness connector. <i>Connector & terminal</i> <i>(B84) No. 16 — (E4) No. 2:</i></p> | Is the resistance less than 1 Ω ? | Go to step 4. | Repair the open circuit in harness between ECM and purge control solenoid valve connector. NOTE: In this case, repair the following: • Open circuit in harness between ECM and purge control solenoid valve connector • Poor contact in coupling connector |
| <p>4</p> <p>CHECK PURGE CONTROL SOLENOID VALVE. 1) Remove the purge control solenoid valve. 2) Measure the resistance between purge control solenoid valve terminals. <i>Terminals</i> <i>No. 1 — No. 2:</i></p> | Is the resistance 10 — 100 Ω ? | Go to step 5. | Replace the purge control solenoid valve. <Ref. to EC(H4DOTC)-7, Purge Control Solenoid Valve.> |
| <p>5</p> <p>CHECK POWER SUPPLY TO PURGE CONTROL SOLENOID VALVE. 1) Turn the ignition switch to ON. 2) Measure the voltage between purge control solenoid valve and engine ground. <i>Connector & terminal</i> <i>(E4) No. 1 (+) — Engine ground (-):</i></p> | Is the voltage more than 10 V? | Go to step 6. | Repair the open circuit in harness between main relay and purge control solenoid valve connector. |
| <p>6</p> <p>CHECK POOR CONTACT. Check poor contact in purge control solenoid valve connector.</p> | Is there poor contact in purge control solenoid valve connector? | Repair the poor contact in purge control solenoid valve connector. | Contact your SOA Service Center. NOTE: Inspection by DTM is required, because probable cause is deterioration of multiple parts. |

Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

BF:DTC P0459 EVAPORATIVE EMISSION CONTROL SYSTEM PURGE CONTROL VALVE CIRCUIT HIGH

DTC DETECTING CONDITION:

- Two consecutive driving cycles with fault
- GENERAL DESCRIPTION <Ref. to GD(H4DOTC)-147, DTC P0459 EVAPORATIVE EMISSION CONTROL SYSTEM PURGE CONTROL VALVE CIRCUIT HIGH, Diagnostic Trouble Code (DTC) Detecting Criteria.>


TROUBLE SYMPTOM:

Erroneous idling

CAUTION:

After repair or replacement of faulty parts, conduct Clear Memory Mode <Ref. to EN(H4DOTC)(diag)-46, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(H4DOTC)(diag)-39, PROCEDURE, Inspection Mode.>.

WIRING DIAGRAM:



EN-01623

Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

| Step | Check | Yes | No |
|---|--|--|---|
| <p>1 CHECK OUTPUT SIGNAL FROM ECM. 1) Turn the ignition switch to OFF. 2) Connect the test mode connector at the lower portion of instrument panel (on the driver's side). 3) Turn the ignition switch to ON. 4) While operating the purge control solenoid valve, measure the voltage between ECM and chassis ground.</p> <p>NOTE: Purge control solenoid valve operation can be executed using the Subaru Select Monitor. For procedure, refer to "Compulsory Valve Operation Check Mode". <Ref. to EN(H4DOTC)(diag)-47, Compulsory Valve Operation Check Mode.></p> <p>Connector & terminal (B84) No. 16 (+) — Chassis ground (-):</p> | Is the voltage 0 — 13 V? | Go to step 2. | Even if malfunction indicator light lights up, the circuit has returned to a normal condition at this time. In this case, repair the poor contact in ECM connector. |
| <p>2 CHECK OUTPUT SIGNAL FROM ECM. 1) Turn the ignition switch to ON. 2) Measure the voltage between ECM and chassis ground.</p> <p>Connector & terminal (B84) No. 16 (+) — Chassis ground (-):</p> | Is the voltage more than 10 V? | Go to step 4. | Go to step 3. |
| <p>3 CHECK POOR CONTACT. Check the poor contact in ECM connector.</p> | Is there poor contact in ECM connector? | Repair the poor contact in ECM connector. | Replace the ECM. <Ref. to FU(H4DOTC)-48, Engine Control Module (ECM).> |
| <p>4 CHECK HARNESS BETWEEN PURGE CONTROL SOLENOID VALVE AND ECM CONNECTOR. 1) Turn the ignition switch to OFF. 2) Disconnect the connector from purge control solenoid valve. 3) Turn the ignition switch to ON. 4) Measure the voltage between ECM and chassis ground.</p> <p>Connector & terminal (B84) No. 16 (+) — Chassis ground (-):</p> | Is the voltage more than 10 V? | Repair the battery short circuit in harness between ECM and purge control solenoid valve connector. After repair, replace the ECM. <Ref. to FU(H4DOTC)-48, Engine Control Module (ECM).> | Go to step 5. |
| <p>5 CHECK PURGE CONTROL SOLENOID VALVE. 1) Turn the ignition switch to OFF. 2) Measure the resistance between purge control solenoid valve terminals.</p> <p>Terminals No. 1 — No. 2:</p> | Is the resistance less than 1 Ω ? | Replace the purge control solenoid valve <Ref. to EC(H4DOTC)-7, Purge Control Solenoid Valve.> and ECM <Ref. to FU(H4DOTC)-48, Engine Control Module (ECM).> | Go to step 6. |
| <p>6 CHECK POOR CONTACT. Check poor contact in ECM connector.</p> | Is there poor contact in ECM connector? | Repair the poor contact in ECM connector. | Replace the ECM. <Ref. to FU(H4DOTC)-48, Engine Control Module (ECM).> |

Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

BG:DTC P0461 FUEL LEVEL SENSOR CIRCUIT RANGE/PERFORMANCE

DTC DETECTING CONDITION:

- Two consecutive driving cycles with fault
- GENERAL DESCRIPTION <Ref. to GD(H4DOTC)-149, DTC P0461 FUEL LEVEL SENSOR CIRCUIT RANGE/PERFORMANCE, Diagnostic Trouble Code (DTC) Detecting Criteria.>









CAUTION:

After repair or replacement of faulty parts, conduct Clear Memory Mode <Ref. to EN(H4DOTC)(diag)-46, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(H4DOTC)(diag)-39, PROCEDURE, Inspection Mode.>.

Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

WIRING DIAGRAM:



EN-01624

Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

| Step | Check | Yes | No |
|---|-----------------------------|---|--|
| 1 CHECK ANY OTHER DTC ON DISPLAY. | Is any other DTC displayed? | Inspect the relevant DTC using "List of Diagnostic Trouble Code (DTC)". <Ref. to EN(H4DOTC)(diag)-71, List of Diagnostic Trouble Code (DTC).> NOTE: In this case, it is not necessary to inspect DTC P0461. | Replace the fuel level sensor. <Ref. to FU(H4DOTC)-63, Fuel Level Sensor.> and fuel sub level sensor <Ref. to FU(H4DOTC)-64, Fuel Sub Level Sensor.> |

BH:DTC P0462 FUEL LEVEL SENSOR CIRCUIT LOW INPUT

DTC DETECTING CONDITION:

- Two consecutive driving cycles with fault
- GENERAL DESCRIPTION <Ref. to GD(H4DOTC)-151, DTC P0462 FUEL LEVEL SENSOR CIRCUIT LOW INPUT, Diagnostic Trouble Code (DTC) Detecting Criteria.>









CAUTION:

After repair or replacement of faulty parts, conduct Clear Memory Mode <Ref. to EN(H4DOTC)(diag)-46, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(H4DOTC)(diag)-39, PROCEDURE, Inspection Mode.>.

Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

WIRING DIAGRAM:



EN-01624

Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

| Step | Check | Yes | No |
|--|---|---|--|
| 1 CHECK SPEEDOMETER AND TACHOMETER OPERATION IN COMBINATION METER. | Does the speedometer and tachometer operate normally? | Go to step 2. | Repair or replace the combination meter. <Ref. to IDI-3, Combination Meter System.> |
| 2 CHECK INPUT SIGNAL FOR ECM. 1) Turn the ignition switch to ON. (engine OFF) 2) Measure the voltage between ECM connector and chassis ground. Connector & terminal (B135) No. 25 (+) — Chassis ground (-): | Is the voltage less than 0.12 V? | Go to step 4. | Go to step 3. |
| 3 CHECK INPUT SIGNAL FOR ECM. (USING SUBARU SELECT MONITOR) Read the data of fuel level sensor signal using Subaru Select Monitor. NOTE: • Subaru Select Monitor For detailed operation procedure, refer to the "READ CURRENT DATA FOR ENGINE". <Ref. to EN(H4DOTC)(diag)-31, Subaru Select Monitor.> | Does the voltage change, while shaking the ECM harness and connector? | Repair the poor contact in ECM connector. | Even if malfunction indicator light lights up, the circuit has returned to a normal condition at this time. A temporary poor contact of the connector may be the cause. NOTE: In this case, repair the following: • Poor contact in combination meter connector • Poor contact in ECM connector • Poor contact in coupling connectors |
| 4 CHECK INPUT VOLTAGE OF ECM. 1) Turn the ignition switch to OFF. 2) Separate the fuel tank cord connector (R57) and rear wiring harness connector (R15). 3) Turn the ignition switch to ON. 4) Measure the voltage of harness between ECM connector and chassis ground. Connector & terminal (B135) No. 25 (+) — Chassis ground (-): | Is the voltage more than 0.12 V? | Go to step 5. | Go to step 6. |
| 5 CHECK HARNESS BETWEEN ECM AND COMBINATION METER. 1) Turn the ignition switch to OFF. 2) Disconnect the connector from connector (i11), (i12) and ECM connector. 3) Measure the resistance between ECM and chassis ground. Connector & terminal (B135) No. 25 — Chassis ground: | Is the resistance more than 1 MΩ? | Go to step 7. | Repair the ground short circuit in harness between ECM and combination meter connector. |

Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

| Step | Check | Yes | No |
|---|--|---|--|
| 6 CHECK HARNESS BETWEEN ECM AND COMBINATION METER. Measure the resistance between ECM and combination meter connector. <i>Connector & terminal</i> <i>(B135) No. 25 — (i12) No. 2:</i> | Is the resistance less than 10 Ω ? | Repair or replace the combination meter. <Ref. to IDI-3, Combination Meter System.> | Repair the open circuit between ECM and combination meter connector. NOTE: In this case, repair the following: Poor contact in coupling connector |
| 7 CHECK FUEL TANK CORD. 1) Turn the ignition switch to OFF. 2) Disconnect the connector from fuel sub level sensor. 3) Measure the resistance between fuel sub level sensor and chassis ground. <i>Connector & terminal</i> <i>(R59) No. 1 — Chassis ground:</i> | Is the resistance more than 1 M Ω ? | Go to step 8. | Repair the ground short circuit in fuel tank cord. |
| 8 CHECK FUEL TANK CORD. 1) Disconnect the connector from fuel pump assembly. 2) Measure the resistance between fuel pump assembly and chassis ground. <i>Connector & terminal</i> <i>(R59) No. 2 — Chassis ground:</i> | Is the resistance more than 1 M Ω ? | Go to step 9. | Repair the ground short circuit in fuel tank cord. |
| 9 CHECK FUEL LEVEL SENSOR. 1) Remove the fuel pump assembly. <Ref. to FU(H4DOTC)-61, Fuel Pump.> 2) Measure the resistance between fuel level sensor and terminals with its float set to the full position. <i>Terminals</i> <i>No. 2 — No. 3:</i> | Is the resistance 0.5 — 2.5 Ω ? | Go to step 10. | Replace the fuel level sensor. |
| 10 CHECK FUEL SUB LEVEL SENSOR. 1) Remove the fuel sub level sensor. <Ref. to FU(H4DOTC)-64, Fuel Sub Level Sensor.> 2) Measure the resistance between fuel sub level sensor and terminals with its float set to the full position. <i>Terminals</i> <i>No. 1 — No. 2:</i> | Is the resistance 0.5 — 2.5 Ω ? | Repair the poor contact in harness between ECM and combination meter connector. | Replace the fuel sub level sensor. |

Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

BI: DTC P0463 FUEL LEVEL SENSOR CIRCUIT HIGH INPUT

DTC DETECTING CONDITION:

- Two consecutive driving cycles with fault
- GENERAL DESCRIPTION <Ref. to GD(H4DOTC)-153, DTC P0463 FUEL LEVEL SENSOR CIRCUIT HIGH INPUT, Diagnostic Trouble Code (DTC) Detecting Criteria.>



CAUTION:

After repair or replacement of faulty parts, conduct Clear Memory Mode <Ref. to EN(H4DOTC)(diag)-46, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(H4DOTC)(diag)-39, PROCEDURE, Inspection Mode.>.

Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

WIRING DIAGRAM:



EN-01624

Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

| Step | Check | Yes | No |
|------|---|---------------|---|
| 1 | CHECK SPEEDOMETER AND TACHOMETER OPERATION IN COMBINATION METER. | Go to step 2. | Repair or replace the combination meter. <Ref. to IDI-3, Combination Meter System.> |
| 2 | CHECK INPUT SIGNAL FOR ECM. 1) Turn the ignition switch to ON. (engine OFF) 2) Measure the voltage between ECM connector and chassis ground. Connector & terminal (B135) No. 25 (+) — Chassis ground (-): | Go to step 3. | Even if malfunction indicator light lights up, the circuit has returned to a normal condition at this time. A temporary poor contact of the connector may be the cause. NOTE: In this case, repair the following: <ul style="list-style-type: none"> • Poor contact in fuel pump connector • Poor contact in coupling connector |
| 3 | CHECK INPUT VOLTAGE OF ECM. 1) Turn the ignition switch to OFF. 2) Disconnect the combination meter connector (i11) and ECM connector. 3) Turn the ignition switch to ON. 4) Measure the voltage of harness between ECM and chassis ground. Connector & terminal (B135) No. 25 (+) — Chassis ground (-): | Go to step 4. | Repair the battery short circuit between ECM and combination meter connector. |
| 4 | CHECK HARNESS BETWEEN ECM AND FUEL TANK CORD. 1) Turn the ignition switch to OFF. 2) Separate the fuel tank cord connector (R57) and rear wiring harness connector (R15). 3) Measure the resistance between ECM and fuel tank cord. Connector & terminal (B135) No. 25 — (R15) No. 7: | Go to step 5. | Repair the open circuit between ECM and fuel tank cord. |
| 5 | CHECK HARNESS BETWEEN FUEL TANK CORD AND CHASSIS GROUND. Measure the resistance between fuel tank cord and chassis ground. Connector & terminal (R15) No. 11 — Chassis ground: | Go to step 6. | Repair the open circuit between fuel tank cord and chassis ground. NOTE: In this case, repair the following: Poor contact in coupling connectors |
| 6 | CHECK FUEL TANK CORD. 1) Disconnect the connector from fuel level sensor. 2) Measure the resistance between fuel level sensor and coupling connector. Connector & terminal (R57) No. 11 — (R58) No. 2: | Go to step 7. | Repair the open circuit between coupling connector and fuel level sensor. |

Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

| Step | Check | Yes | No |
|---|---|--|---|
| 7 CHECK FUEL TANK CORD. 1) Disconnect the connector from fuel sub level sensor. 2) Measure the resistance between fuel level sensor and fuel sub level sensor. <i>Connector & terminal</i> <i>(R58) No. 3 — (R59) No. 2:</i> | Is the resistance less than 10 Ω | Go to step 8. | Repair the open circuit between fuel level sensor and fuel sub level sensor. |
| 8 CHECK FUEL TANK CORD. Measure the resistance between fuel sub level sensor and coupling connector. <i>Connector & terminal</i> <i>(R57) No. 7 — (R59) No. 1:</i> | Is the resistance less than 10 Ω ? | Go to step 9. | Repair the open circuit between coupling connector and fuel sub level sensor. |
| 9 CHECK FUEL LEVEL SENSOR. 1) Remove the fuel pump assembly. <Ref. to FU(H4DOTC)-61, Fuel Pump.> 2) While moving the fuel level sensor float up and down, measure the resistance between fuel level sensor terminals. <i>Terminals</i> <i>No. 2 — No. 3:</i> | Is the resistance more than 53 Ω ? | Replace the fuel level sensor. <Ref. to FU(H4DOTC)-63, Fuel Level Sensor.> | Go to step 10. |
| 10 CHECK FUEL SUB LEVEL SENSOR. 1) Remove the fuel sub level sensor. <Ref. to FU(H4DOTC)-64, Fuel Sub Level Sensor.> 2) While moving the fuel sub level sensor float up and down, measure the resistance between fuel sub level sensor terminals. <i>Terminals</i> <i>No. 1 — No. 2:</i> | Is the resistance more than 45 Ω ? | Replace the fuel sub level sensor. <Ref. to FU(H4DOTC)-64, Fuel Sub Level Sensor.> | Replace the combination meter. <Ref. to IDI-10, Combination Meter Assembly.> |

BJ:DTC P0464 FUEL LEVEL SENSOR CIRCUIT INTERMITTENT

DTC DETECTING CONDITION:

- Two consecutive driving cycles with fault
- GENERAL DESCRIPTION <Ref. to GD(H4DOTC)-155, DTC P0464 FUEL LEVEL SENSOR CIRCUIT INTERMITTENT, Diagnostic Trouble Code (DTC) Detecting Criteria.>









CAUTION:

After repair or replacement of faulty parts, conduct Clear Memory Mode <Ref. to EN(H4DOTC)(diag)-46, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(H4DOTC)(diag)-39, PROCEDURE, Inspection Mode.>.

Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

WIRING DIAGRAM:



EN-01624

Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

| Step | Check | Yes | No |
|--|--------------------------------------|---|--|
| 1 CHECK ANY OTHER DTC ON DISPLAY. | Is any other DTC displayed? | Inspect the relevant DTC using "List of Diagnostic Trouble Code (DTC)". <Ref. to EN(H4DOTC)(diag)-71, List of Diagnostic Trouble Code (DTC).> | Go to step 2. |
| 2 CHECK FUEL LEVEL SENSOR. 1) Remove the fuel pump assembly. <Ref. to FU(H4DOTC)-61, Fuel Pump.> 2) While moving the fuel level sensor float up and down, make sure that the resistance between fuel level sensor terminals changes smoothly. <i>Terminals</i> No. 3 — No. 2: | Does the resistance change smoothly? | Go to step 3. | Replace the fuel level sensor. <Ref. to FU(H4DOTC)-63, Fuel Level Sensor.> |
| 3 CHECK FUEL SUB LEVEL SENSOR. 1) Remove the fuel sub level sensor. <Ref. to FU(H4DOTC)-64, Fuel Sub Level Sensor.> 2) While moving the fuel sub level sensor float up and down, make sure that the resistance between fuel level sensor terminals changes smoothly. <i>Terminals</i> No. 1 — No. 2: | Does the resistance change smoothly? | Repair the poor contact in ECM, combination meter and coupling connectors. | Replace the fuel sub level sensor. <Ref. to FU(H4DOTC)-64, Fuel Sub Level Sensor.> |

Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

BK:DTC P0483 COOLING FAN RATIONALITY CHECK

DTC DETECTING CONDITION:

- Two consecutive driving cycles with fault
- GENERAL DESCRIPTION <Ref. to GD(H4DOTC)-158, DTC P0483 COOLING FAN RATIONALITY CHECK, Diagnostic Trouble Code (DTC) Detecting Criteria.>

TROUBLE SYMPTOM:

- Occurrence of noise
- Overheating

CAUTION:

After repair or replacement of faulty parts, conduct Clear Memory Mode <Ref. to EN(H4DOTC)(diag)-46, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(H4DOTC)(diag)-39, PROCEDURE, Inspection Mode.>.


NOTE:

If the vehicle, with the engine idling, is placed very close to a wall or another vehicle, preventing normal cooling function, the OBD system may detect malfunction.

Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

WIRING DIAGRAM:



(B72)

| | |
|---|---|
| 1 | 2 |
| 3 | 4 |

(F27)

| | | | | | | | | | | | | | | |
|---|---|---|----|----|----|----|----|----|----|----|----|----|----|----|
| 1 | 2 | 5 | 6 | 7 | 10 | 15 | 16 | 17 | 20 | 25 | 26 | 27 | 30 | 35 |
| 3 | 4 | 8 | 11 | 18 | 21 | 28 | 31 | 36 | | | | | | |
| | | 9 | 12 | 13 | 14 | 19 | 22 | 23 | 24 | 29 | 32 | 33 | 34 | |

(B84)

| | | | | | | | | | | | |
|----|----|----|----|----|----|----|----|----|----|----|----|
| 1 | 2 | 3 | 4 | 5 | 6 | 7 | 8 | 9 | | | |
| 10 | 11 | 12 | 13 | 14 | 15 | 16 | 17 | 18 | 19 | 20 | 21 |
| 22 | 23 | 24 | 25 | 26 | 27 | 28 | 29 | 30 | 31 | | |

(F45)

| | | | | | | | | | | | | |
|----|----|----|----|----|----|----|----|----|----|----|----|----|
| 1 | 2 | 3 | 4 | 5 | 6 | 7 | 8 | 9 | 10 | 11 | | |
| 12 | 13 | 14 | 15 | 16 | 17 | 18 | 19 | 20 | 21 | 22 | 23 | 24 |

(F16)

| | |
|---|---|
| 1 | 2 |
| 3 | 4 |

EN-01625

Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

| | Step | Check | Yes | No |
|---|--|-----------------------------|---|--|
| 1 | CHECK ANY OTHER DTC ON DISPLAY. | Is any other DTC displayed? | Inspect the relevant DTC using "List of Diagnostic Trouble Code (DTC)". <Ref. to EN(H4DOTC)(diag)-71, List of Diagnostic Trouble Code (DTC).> | Check the radiator fan, fan motor and thermostat. <Ref. to CO(H4SO)-22, Radiator Main Fan and Fan Motor.> and <Ref. to CO(H4SO)-23, Radiator Sub Fan and Fan Motor.> If thermostat is stuck, replace thermostat. |

Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

BL:DTC P0502 VEHICLE SPEED SENSOR CIRCUIT LOW INPUT


DTC DETECTING CONDITION:

- Immediately at fault recognition
- GENERAL DESCRIPTION <Ref. to GD(H4DOTC)-160, DTC P0502 VEHICLE SPEED SENSOR CIRCUIT LOW INPUT, Diagnostic Trouble Code (DTC) Detecting Criteria.>

CAUTION:

After repair or replacement of faulty parts, conduct Clear Memory Mode <Ref. to EN(H4DOTC)(diag)-46, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(H4DOTC)(diag)-39, PROCEDURE, Inspection Mode.>.

WIRING DIAGRAM:



EN-01626

Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

| | Step | Check | Yes | No |
|---|--|--|--|--|
| 1 | CHECK TRANSMISSION TYPE. | Is the transmission type AT? | Go to step 2. | Go to step 4. |
| 2 | CHECK HARNESS BETWEEN ECM AND TCM CONNECTOR. 1) Turn the ignition switch to OFF. 2) Disconnect the connectors from ECM and TCM. 3) Measure the resistance of harness between TCM connector and chassis ground. Connector & terminal (B56) No. 17 — Chassis ground: | Is the resistance more than 1 MΩ? | Go to step 3. | Repair the ground short circuit in harness between ECM and TCM connector. |
| 3 | CHECK POOR CONTACT. Check poor contact in TCM connector. | Is there poor contact in TCM connector? | Repair poor contact in TCM connector. | Contact your SOA Service Center. |
| 4 | CHECK HARNESS BETWEEN VEHICLE SPEED SENSOR AND ECM CONNECTOR. 1) Turn the ignition switch to OFF. 2) Disconnect the connectors from vehicle speed sensor and ECM. 3) Measure the resistance of harness between vehicle speed sensor connector and chassis ground. Connector & terminal (B17) No. 1 — Chassis ground: | Is the resistance more than 1 MΩ? | Go to step 5. | Repair the ground short circuit in harness between vehicle speed sensor and ECM connector. |
| 5 | CHECK POOR CONTACT. Check poor contact in the vehicle speed sensor connector. | Is there poor contact in the vehicle speed sensor connector? | Repair poor contact in the vehicle speed sensor connector. | Replace the vehicle speed sensor. <Ref. to 5MT-38, Vehicle Speed Sensor.> |

Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

BM:DTC P0503 VEHICLE SPEED SENSOR INTERMITTENT/ERRATIC/HIGH


DTC DETECTING CONDITION:

- Immediately at fault recognition
- GENERAL DESCRIPTION <Ref. to GD(H4DOTC)-161, DTC P0503 VEHICLE SPEED SENSOR INTERMITTENT/ERRATIC/HIGH, Diagnostic Trouble Code (DTC) Detecting Criteria.>

CAUTION:

After repair or replacement of faulty parts, conduct Clear Memory Mode <Ref. to EN(H4DOTC)(diag)-46, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(H4DOTC)(diag)-39, PROCEDURE, Inspection Mode.>.

WIRING DIAGRAM:



EN-01626

Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

| Step | Check | Yes | No |
|----------|--|--|--|
| 1 | CHECK TRANSMISSION TYPE. | Is the transmission type AT? | Go to step 2. |
| 2 | CHECK DTC P0720 ON DISPLAY. | Go to step 3. | Go to step 3. |
| 3 | CHECK SPEEDOMETER OPERATION IN COMBINATION METER. | Does the Subaru Select Monitor or OBD-II general scan tool indicate DTC P0720? | Check the front vehicle speed sensor signal circuit. <Ref. to 4AT(diag)-52, DTC 33 FRONT VEHICLE SPEED SENSOR, Diagnostic Procedure with Diagnostic Trouble Code (DTC).> |
| 4 | CHECK SPEEDOMETER OPERATION IN COMBINATION METER. | Does the speedometer operate normally? | Go to step 4. |
| 4 | CHECK HARNESS BETWEEN ECM AND COMBINATION METER CONNECTOR. 1) Turn the ignition switch to OFF. 2) Disconnect the connector from combination meter. 3) Measure the resistance between ECM and combination meter. Connector & terminal (B134) No. 1 — (i11) No. 2: | Is the resistance less than 10 Ω? | Repair the poor contact in ECM connector. Repair the harness and connector. NOTE: In this case, repair the following: • Open circuit in harness between ECM and combination meter connector • Poor contact in ECM connector • Poor contact in combination meter connector • Poor contact in coupling connector |

Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

BN:DTC P0506 IDLE CONTROL SYSTEM RPM LOWER THAN EXPECTED

DTC DETECTING CONDITION:

- Two consecutive driving cycles with fault
- GENERAL DESCRIPTION <Ref. to GD(H4DOTC)-162, DTC P0506 IDLE CONTROL SYSTEM RPM LOWER THAN EXPECTED, Diagnostic Trouble Code (DTC) Detecting Criteria.>


TROUBLE SYMPTOM:

- Engine is difficult to start.
- Engine does not start.
- Erroneous idling
- Engine stalls.

CAUTION:

After repair or replacement of faulty parts, conduct Clear Memory Mode <Ref. to EN(H4DOTC)(diag)-46, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(H4DOTC)(diag)-39, PROCEDURE, Inspection Mode.>.

WIRING DIAGRAM:



Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

| Step | Check | Yes | No |
|--|----------------------------------|---|--|
| 1 CHECK ANY OTHER DTC ON DISPLAY. | Is any other DTC displayed? | Inspect the relevant DTC using "List of Diagnostic Trouble Code (DTC)". <Ref. to EN(H4DOTC)(diag)-71, List of Diagnostic Trouble Code (DTC).> NOTE: In this case, it is not necessary to inspect DTC P0506. | Go to step 2. |
| 2 CHECK IDLE AIR CONTROL SOLENOID VALVE. 1) Turn the ignition switch to OFF. 2) Remove the idle air control solenoid valve from throttle body. <Ref. to FU(H4DOTC)-34, REMOVAL, Idle Air Control Solenoid Valve.> 3) Using an air gun, force air into the idle air control solenoid valve by-pass air inlet. Confirm that forced air subsequently escapes from both main air passage and assist air passage. | Does air flow out? | Go to step 4. | Replace the idle air control solenoid valve. <Ref. to FU(H4DOTC)-34, Idle Air Control Solenoid Valve.> After replace, Go to step 3. |
| 3 CHECK IDLE AIR CONTROL SOLENOID VALVE DUTY RATIO. 1) Turn the ignition switch to ON. 2) Start the engine, and warm-up the engine. 3) Turn all accessory switches to OFF. 4) Read the data of idle air control solenoid valve duty ratio using Subaru Select Monitor or OBD-II general scan tool. NOTE: • Subaru Select Monitor For detailed operation procedures, refer to the "READ CURRENT DATA FOR ENGINE". <Ref. to EN(H4DOTC)(diag)-31, Subaru Select Monitor.> • OBD-II general scan tool For detailed operation procedures, refer to the OBD-II General Scan Tool Instruction Manual. | Is the duty ratio more than 60%? | Go to step 4. | END. |
| 4 CHECK BY-PASS AIR LINE. 1) Turn the ignition switch to OFF. 2) Remove the idle air control solenoid valve from throttle body. <Ref. to FU(H4DOTC)-34, REMOVAL, Idle Air Control Solenoid Valve.> 3) Remove the throttle body to intake manifold. <Ref. to FU(H4DOTC)-13, REMOVAL, Throttle Body.> 4) Using an air gun, force air into the solenoid valve installation area and throttle valve interior. Confirm that forced air subsequently escapes from both these areas. | Does air flow out? | Replace the idle air control solenoid valve. <Ref. to FU(H4DOTC)-34, Idle Air Control Solenoid Valve.> | Replace the throttle body. <Ref. to FU(H4DOTC)-13, Throttle Body.> |

Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

BO:DTC P0507 IDLE CONTROL SYSTEM RPM HIGHER THAN EXPECTED

DTC DETECTING CONDITION:

- Two consecutive driving cycles with fault
- GENERAL DESCRIPTION <Ref. to GD(H4DOTC)-164, DTC P0507 IDLE CONTROL SYSTEM RPM HIGHER THAN EXPECTED, Diagnostic Trouble Code (DTC) Detecting Criteria.>


TROUBLE SYMPTOM:

Engine keeps running at higher revolution than specified idling revolution.

CAUTION:

After repair or replacement of faulty parts, conduct Clear Memory Mode <Ref. to EN(H4DOTC)(diag)-46, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(H4DOTC)(diag)-39, PROCEDURE, Inspection Mode.>.

WIRING DIAGRAM:



EN-01627

Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

| Step | Check | Yes | No |
|---|---|---|--|
| 1 CHECK ANY OTHER DTC ON DISPLAY. | Is any other DTC displayed? | Inspect the relevant DTC using "List of Diagnostic Trouble Code (DTC)". <Ref. to EN(H4DOTC)(diag)-71, List of Diagnostic Trouble Code (DTC).> NOTE: In this case, it is not necessary to inspect DTC P0507. | Go to step 2. |
| 2 CHECK THROTTLE CABLE. | Does the throttle cable have play for adjustment? | Go to step 3. | Adjust the throttle cable. <Ref. to SP(H4SO)-6, INSTALLATION, Accelerator Control Cable.> |
| 3 CHECK AIR INTAKE SYSTEM. 1) Turn the ignition switch to ON. 2) Start the engine, and idle it. 3) Check the following items. <ul style="list-style-type: none"> • Loose installation of intake manifold, idle air control solenoid valve and throttle body • Cracks of intake manifold gasket, idle air control solenoid valve gasket and throttle body gasket • Disconnections of vacuum hoses | Is there a fault in air intake system? | Repair the air suction and leaks. | Replace the idle air control solenoid valve. <Ref. to FU(H4DOTC)-34, Idle Air Control Solenoid Valve.> |

Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

BP:DTC P0508 IDLE CONTROL SYSTEM CIRCUIT LOW

DTC DETECTING CONDITION:

- Immediately at fault recognition
- GENERAL DESCRIPTION <Ref. to GD(H4DOTC)-166, DTC P0508 IDLE CONTROL SYSTEM CIRCUIT LOW, Diagnostic Trouble Code (DTC) Detecting Criteria.>


TROUBLE SYMPTOM:

- Erroneous idling
- Engine stalls.
- Engine breathing

CAUTION:

After repair or replacement of faulty parts, conduct Clear Memory Mode <Ref. to EN(H4DOTC)(diag)-46, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(H4DOTC)(diag)-39, PROCEDURE, Inspection Mode.>.

WIRING DIAGRAM:



EN-01627

Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

| Step | Check | Yes | No |
|---|--|--|--|
| 1 CHECK OUTPUT SIGNAL FROM ECM. 1) Turn the ignition switch to ON. 2) Measure the voltage between ECM and chassis ground. <i>Connector & terminal</i> <i>(B137) No. 10 (+) — Chassis ground (-):</i> | Is the voltage more than 3 V? | Repair the poor contact in ECM connector. | Go to step 2. |
| 2 CHECK POWER SUPPLY TO IDLE AIR CONTROL SOLENOID VALVE. 1) Turn the ignition switch to OFF. 2) Disconnect the connector from idle air control solenoid valve. 3) Turn the ignition switch to ON. 4) Measure the voltage between idle air control solenoid valve and engine ground. <i>Connector & terminal</i> <i>(E7) No. 2 (+) — Engine ground (-):</i> | Is the voltage more than 10 V? | Go to step 3. | Repair the harness and connector. NOTE: In this case, repair the following: <ul style="list-style-type: none"> • Open circuit in harness between idle air control solenoid valve and main relay connector • Poor contact in coupling connector |
| 3 CHECK HARNESS BETWEEN ECM AND IDLE AIR CONTROL SOLENOID VALVE CONNECTOR. 1) Turn the ignition switch to OFF. 2) Disconnect the connector from ECM. 3) Measure the resistance of harness between ECM and idle air control solenoid valve connector. <i>Connector & terminal</i> <i>(B137) No. 10 — (E7) No. 1:</i> | Is the resistance less than 1 Ω ? | Go to step 4. | Repair the harness and connector. NOTE: In this case, repair the following: <ul style="list-style-type: none"> • Open circuit in harness between ECM and idle air control solenoid valve connector • Poor contact in coupling connector |
| 4 CHECK HARNESS BETWEEN ECM AND IDLE AIR CONTROL SOLENOID VALVE CONNECTOR. Measure the resistance of harness between ECM and chassis ground. <i>Connector & terminal</i> <i>(B137) No. 10 — Chassis ground:</i> | Is the resistance more than 1 M Ω ? | Go to step 5. | Repair the ground short circuit in harness between ECM and idle air control solenoid valve connector. |
| 5 CHECK GROUND CIRCUIT OF IDLE AIR CONTROL SOLENOID VALVE. Measure the resistance of harness between idle air control solenoid valve connector and engine ground. <i>Connector & terminal</i> <i>(E7) No. 3 — Engine ground:</i> | Is the resistance less than 5 Ω ? | Go to step 6. | Repair the open circuit in harness between idle air control solenoid valve connector and engine ground cable. |
| 6 CHECK POOR CONTACT. Check poor contact in ECM and idle air control solenoid valve connectors. | Is there poor contact in ECM and idle air control solenoid valve connectors? | Repair the poor contact in ECM and idle air control solenoid valve connectors. | Replace the idle air control solenoid valve. <Ref. to FU(H4DOTC)-34, Idle Air Control Solenoid Valve.> |

Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

BQ:DTC P0509 IDLE CONTROL SYSTEM CIRCUIT HIGH

DTC DETECTING CONDITION:

- Immediately at fault recognition
- GENERAL DESCRIPTION <Ref. to GD(H4DOTC)-168, DTC P0509 IDLE CONTROL SYSTEM CIRCUIT HIGH, Diagnostic Trouble Code (DTC) Detecting Criteria.>


TROUBLE SYMPTOM:

- Erroneous idling
- Engine stalls.
- Engine breathing

CAUTION:

After repair or replacement of faulty parts, conduct Clear Memory Mode <Ref. to EN(H4DOTC)(diag)-46, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(H4DOTC)(diag)-39, PROCEDURE, Inspection Mode.>.

WIRING DIAGRAM:



Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

| Step | Check | Yes | No |
|---|--|---|--|
| 1 CHECK THROTTLE CABLE. | Does the throttle cable have play for adjustment? | Go to step 2. | Adjust the throttle cable. <Ref. to SP(H4SO)-6, INSTALLATION, Accelerator Control Cable.> |
| 2 CHECK OUTPUT SIGNAL FROM ECM. 1) Turn the ignition switch to ON. 2) Measure the voltage between ECM and chassis ground. Connector & terminal (B137) No. 10 (+) — Chassis ground (-): | Is the voltage more than 10 V? | Go to step 3. | Go to step 4. |
| 3 CHECK OUTPUT SIGNAL FROM ECM. 1) Turn the ignition switch to OFF. 2) Disconnect the connector from idle air control solenoid valve. 3) Turn the ignition switch to ON. 4) Measure the voltage between ECM and chassis ground. Connector & terminal (B137) No. 10 (+) — Chassis ground (-): | Is the voltage more than 10 V? | Repair the battery short circuit in harness between ECM and idle air control solenoid valve connector. After repair, replace the ECM. <Ref. to FU(H4DOTC)-48, Engine Control Module (ECM).> | Replace the idle air control solenoid valve. <Ref. to FU(H4DOTC)-34, Idle Air Control Solenoid Valve.> and ECM <Ref. to FU(H4DOTC)-48, Engine Control Module (ECM).> |
| 4 CHECK OUTPUT SIGNAL FROM ECM. Measure the voltage between ECM and chassis ground. Connector & terminal (B137) No. 10 (+) — Chassis ground (-): | Shake the ECM harness and connector, while monitoring value of voltage meter. Does the voltage change? | Repair the battery short circuit in harness between ECM and idle air control solenoid valve connector. After repair, replace the ECM. <Ref. to FU(H4DOTC)-48, Engine Control Module (ECM).> | Contact your SOA Service Center. NOTE: Inspection by DTM is required, because probable cause is deterioration of multiple parts. |

BR:DTC P0512 STARTER REQUEST CIRCUIT

DTC DETECTING CONDITION:

- Immediately at fault recognition
- GENERAL DESCRIPTION <Ref. to GD(H4DOTC)-170, DTC P0512 STARTER REQUEST CIRCUIT, Diagnostic Trouble Code (DTC) Detecting Criteria.>

TROUBLE SYMPTOM:

Failure of engine to start



CAUTION:

After repair or replacement of faulty parts, conduct Clear Memory Mode <Ref. to EN(H4DOTC)(diag)-46, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(H4DOTC)(diag)-39, PROCEDURE, Inspection Mode.>.

Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

WIRING DIAGRAM:



EN-01607

Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

| Step | Check | Yes | No |
|---|--|---|---|
| 1 CHECK OPERATION OF STARTER MOTOR. | Does the starter motor operate when ignition switch is turned to ON? | Repair the battery short circuit in starter motor circuit. After repair, replace the ECM. <Ref. to FU(H4DOTC)-48, Engine Control Module (ECM).> | Check the starter motor circuit. <Ref. to EN(H4DOTC)(diag)-59, STARTER MOTOR CIRCUIT, Diagnostics for Engine Starting Failure.> |

Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

BS:DTC P0519 IDLE CONTROL SYSTEM MALFUNCTION (FAIL-SAFE)

DTC DETECTING CONDITION:

- Immediately at fault recognition
- GENERAL DESCRIPTION <Ref. to GD(H4DOTC)-171, DTC P0519 IDLE CONTROL SYSTEM MALFUNCTION (FAIL-SAFE), Diagnostic Trouble Code (DTC) Detecting Criteria.>


TROUBLE SYMPTOM:

- Engine keeps running at higher revolution than specified idling revolution.
- Fuel is cut according to fail-safe function.

CAUTION:

After repair or replacement of faulty parts, conduct Clear Memory Mode <Ref. to EN(H4DOTC)(diag)-46, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(H4DOTC)(diag)-39, PROCEDURE, Inspection Mode.>.

WIRING DIAGRAM:



EN-01627

Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

| Step | Check | Yes | No |
|---|---|---|--|
| 1 CHECK ANY OTHER DTC ON DISPLAY. | Is any other DTC displayed? | Inspect the relevant DTC using "List of Diagnostic Trouble Code (DTC)". <Ref. to EN(H4DOTC)(diag)-71, List of Diagnostic Trouble Code (DTC).> NOTE: In this case, it is not necessary to inspect DTC P0519. | Go to step 2. |
| 2 CHECK AIR INTAKE SYSTEM. 1) Turn the ignition switch to ON. 2) Start the engine, and idle it. 3) Check the following items. <ul style="list-style-type: none"> • Loose installation of intake manifold, idle air control solenoid valve and throttle body • Cracks of intake manifold gasket, idle air control solenoid valve gasket and throttle body gasket • Disconnections of vacuum hoses | Is there a fault in air intake system? | Repair the air suction and leaks. | Go to step 3. |
| 3 CHECK THROTTLE CABLE. | Does the throttle cable have play for adjustment? | Go to step 4. | Adjust the throttle cable. <Ref. to SP(H4SO)-6, INSTALLATION, Accelerator Control Cable.> |
| 4 CHECK AIR BY-PASS LINE. 1) Turn the ignition switch to OFF. 2) Remove the idle air control solenoid valve from throttle body. <Ref. to FU(H4DOTC)-34, Idle Air Control Solenoid Valve.> 3) Confirm that there are no foreign particles in by-pass air line. | Are foreign particles in by-pass air line? | Remove the foreign particles from by-pass air line. | Replace the idle air control solenoid valve. <Ref. to FU(H4DOTC)-34, Idle Air Control Solenoid Valve.> |

Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

BT:DTC P0545 EXHAUST GAS TEMPERATURE SENSOR CIRCUIT LOW-BANK

1

DTC DETECTING CONDITION:

- Immediately at fault recognition
- GENERAL DESCRIPTION <Ref. to GD(H4DOTC)-173, DTC P0545 EXHAUST GAS TEMPERATURE SENSOR CIRCUIT LOW-BANK 1, Diagnostic Trouble Code (DTC) Detecting Criteria.>


TROUBLE SYMPTOM:

- Hard to start
- Erroneous idling
- Poor driving performance

CAUTION:

After repair or replacement of faulty parts, conduct Clear Memory Mode <Ref. to EN(H4DOTC)(diag)-46, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(H4DOTC)(diag)-39, PROCEDURE, Inspection Mode.>.

WIRING DIAGRAM:



EN-01628

Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

| Step | Check | Yes | No |
|--|--|---|--|
| <p>1</p> <p>CHECK CURRENT DATA.</p> <p>1) Start the engine.</p> <p>2) Read the data of exhaust gas temperature sensor signal using Subaru Select Monitor or OBD-II general scan tool.</p> <p>NOTE:</p> <ul style="list-style-type: none"> • Subaru Select Monitor <p>For detailed operation procedure, refer to the "READ CURRENT DATA FOR ENGINE". <Ref. to EN(H4DOTC)(diag)-31, Subaru Select Monitor.></p> <ul style="list-style-type: none"> • OBD-II general scan tool <p>For detailed operation procedures, refer to the OBD-II General Scan Tool Instruction Manual.</p> | <p>Is the temperature more than 1200°C (2192°F)?</p> | <p>Go to step 2.</p> | <p>Repair the poor contact.</p> <p>NOTE:</p> <p>In this case, repair the following:</p> <ul style="list-style-type: none"> • Poor contact in exhaust gas temperature sensor • Poor contact in ECM • Poor contact in joint connector |
| <p>2</p> <p>CHECK HARNESS BETWEEN EXHAUST GAS TEMPERATURE SENSOR AND ECM CONNECTOR.</p> <p>1) Turn the ignition switch to OFF.</p> <p>2) Disconnect the connector from exhaust gas temperature sensor.</p> <p>3) Turn the ignition switch to ON.</p> <p>4) Read the data of exhaust gas temperature sensor signal using Subaru Select Monitor or OBD-II general scan tool.</p> <p>NOTE:</p> <ul style="list-style-type: none"> • Subaru Select Monitor <p>For detailed operation procedure, refer to the "READ CURRENT DATA FOR ENGINE". <Ref. to EN(H4DOTC)(diag)-31, Subaru Select Monitor.></p> <ul style="list-style-type: none"> • OBD-II general scan tool <p>For detailed operation procedures, refer to the OBD-II General Scan Tool Instruction Manual.</p> | <p>Is the temperature less than 372°C (702°F)?</p> | <p>Replace the exhaust gas temperature sensor. <Ref. to FU(H4DOTC)-47, Exhaust Temperature Sensor.></p> | <p>Repair the ground short circuit in harness between exhaust gas temperature sensor and ECM connector.</p> |

Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

BU:DTC P0546 EXHAUST GAS TEMPERATURE SENSOR CIRCUIT HIGH-BANK

1

DTC DETECTING CONDITION:

- Immediately at fault recognition
- GENERAL DESCRIPTION <Ref. to GD(H4DOTC)-175, DTC P0546 EXHAUST GAS TEMPERATURE SENSOR CIRCUIT HIGH-BANK 1, Diagnostic Trouble Code (DTC) Detecting Criteria.>


TROUBLE SYMPTOM:

- Hard to start
- Erroneous idling
- Poor driving performance

CAUTION:

After repair or replacement of faulty parts, conduct Clear Memory Mode <Ref. to EN(H4DOTC)(diag)-46, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(H4DOTC)(diag)-39, PROCEDURE, Inspection Mode.>.

WIRING DIAGRAM:



EN-01628

Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

| Step | Check | Yes | No |
|---|--|--|---|
| <p>1 CHECK CURRENT DATA.</p> <p>1) Start the engine.</p> <p>2) Read the data of exhaust gas temperature sensor signal using Subaru Select Monitor or OBD-II general scan tool.</p> <p>NOTE:</p> <ul style="list-style-type: none"> • Subaru Select Monitor <p>For detailed operation procedure, refer to the "READ CURRENT DATA FOR ENGINE". <Ref. to EN(H4DOTC)(diag)-31, Subaru Select Monitor.></p> <ul style="list-style-type: none"> • OBD-II general scan tool <p>For detailed operation procedures, refer to the OBD-II General Scan Tool Instruction Manual.</p> | <p>Is the temperature less than 372°C (702°F)?</p> | <p>Go to step 2.</p> | <p>Repair the poor contact.</p> <p>NOTE:</p> <p>In this case, repair the following:</p> <ul style="list-style-type: none"> • Poor contact in exhaust gas temperature sensor • Poor contact in ECM • Poor contact in joint connector |
| <p>2 CHECK HARNESS BETWEEN EXHAUST GAS TEMPERATURE SENSOR AND ECM CONNECTOR.</p> <p>1) Turn the ignition switch to OFF.</p> <p>2) Disconnect the connector from exhaust gas temperature sensor.</p> <p>3) Measure the voltage between exhaust gas temperature sensor connector and engine ground.</p> <p>Connector & terminal (B279) No. 1 (+) — Engine ground (-):</p> | <p>Is the voltage more than 10 V?</p> | <p>Repair the battery short circuit in harness between ECM and exhaust gas temperature sensor connector.</p> | <p>Go to step 3.</p> |
| <p>3 CHECK HARNESS BETWEEN EXHAUST GAS TEMPERATURE SENSOR AND ECM CONNECTOR.</p> <p>1) Turn the ignition switch to ON.</p> <p>2) Measure the voltage between exhaust gas temperature sensor connector and engine ground.</p> <p>Connector & terminal (B279) No. 1 (+) — Engine ground (-):</p> | <p>Is the voltage more than 10 V?</p> | <p>Repair the battery short circuit in harness between ECM and exhaust gas temperature sensor connector.</p> | <p>Go to step 4.</p> |
| <p>4 CHECK HARNESS BETWEEN EXHAUST GAS TEMPERATURE SENSOR AND ECM CONNECTOR.</p> <p>Measure the voltage between exhaust gas temperature sensor connector and engine ground.</p> <p>Connector & terminal (B279) No. 1 (+) — Engine ground (-):</p> | <p>Is the voltage more than 4 V?</p> | <p>Go to step 5.</p> | <p>Repair the harness and connector.</p> <p>NOTE:</p> <p>In this case, repair the following:</p> <ul style="list-style-type: none"> • Open circuit in harness between ECM and exhaust gas temperature sensor connector • Poor contact in exhaust gas temperature sensor connector • Poor contact in ECM connector • Poor contact in joint connector |

Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

| Step | Check | Yes | No |
|--|---|---|---|
| <p>5</p> <p>CHECK HARNESS BETWEEN EXHAUST GAS TEMPERATURE SENSOR AND ECM CONNECTOR.</p> <p>1) Turn the ignition switch to OFF.</p> <p>2) Measure the resistance of harness between exhaust gas temperature sensor connector and engine ground.</p> <p>Connector & terminal (B279) No. 2 — Engine ground:</p> | <p>Is the resistance less than 5 Ω?</p> | <p>Replace the exhaust gas temperature sensor. <Ref. to FU(H4DOTC)-47, Exhaust Temperature Sensor.></p> | <p>Repair the harness and connector.</p> <p>NOTE: In this case, repair the following:</p> <ul style="list-style-type: none"> • Open circuit in harness between ECM and exhaust gas temperature sensor connector • Poor contact in exhaust gas temperature sensor connector • Poor contact in ECM connector • Poor contact in joint connector |

Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

BV:DTC P0565 CRUISE CONTROL ON SIGNAL


DTC DETECTING CONDITION:

- Two consecutive driving cycles with fault
- GENERAL DESCRIPTION <Ref. to GD(H4DOTC)-177, DTC P0565 CRUISE CONTROL ON SIGNAL, Diagnostic Trouble Code (DTC) Detecting Criteria.>

CAUTION:

After repair or replacement of faulty parts, conduct Clear Memory Mode <Ref. to EN(H4DOTC)(diag)-46, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(H4DOTC)(diag)-39, PROCEDURE, Inspection Mode.>.

WIRING DIAGRAM:



EN-00377

Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

| Step | Check | Yes | No |
|--|--|---|--|
| 1 CHECK HARNESS BETWEEN TCM AND CCM CONNECTOR. 1) Turn the ignition switch to OFF. 2) Disconnect the connectors from TCM and CCM. 3) Measure the resistance of harness between TCM and CCM connector. Connector & terminal (B55) No. 22 — (B94) No. 3: | Is the resistance less than 1 Ω ? | Go to step 2. | Repair the open circuit in harness between TCM and CCM connector. |
| 2 CHECK HARNESS BETWEEN TCM AND CCM CONNECTOR. Measure the resistance of harness between TCM and chassis ground. Connector & terminal (B55) No. 22 — Chassis ground: | Is the resistance more than 1 M Ω ? | Go to step 3. | Repair the short circuit in harness between TCM and CCM connector. |
| 3 CHECK INPUT SIGNAL FOR TCM. 1) Connect the connector to TCM and CCM. 2) Lift-up the vehicle or set the vehicle on free rollers. CAUTION: On AWD models, raise all wheels off ground. 3) Start the engine. 4) Turn the cruise control main switch to ON. 5) Move the select lever to "D" range and slowly increase vehicle speed to 50 km/h (31 MPH). 6) Turn the cruise control command switch to ON. 7) Measure the voltage between TCM and chassis ground. Connector & terminal (B55) No. 22 (+) — Chassis ground (-): | Is the voltage less than 1 V? | Go to step 4. | Check the cruise control command switch circuit. <Ref. to CC-7, INSPECTION, Cruise Control Command Switch.> |
| 4 CHECK POOR CONTACT. Check poor contact in TCM connector. | Is there poor contact in TCM connector? | Repair the poor contact in TCM connector. | Replace the TCM. <Ref. to 4AT-67, Transmission Control Module (TCM).> |

Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

BW:DTC P0604 INTERNAL CONTROL MODULE RANDOM ACCESS MEMORY (RAM) ERROR

DTC DETECTING CONDITION:

- Immediately at fault recognition
- GENERAL DESCRIPTION <Ref. to GD(H4DOTC)-178, DTC P0604 INTERNAL CONTROL MODULE RANDOM ACCESS MEMORY (RAM) ERROR, Diagnostic Trouble Code (DTC) Detecting Criteria.>

TROUBLE SYMPTOM:

- Engine does not start.
- Engine stalls.



CAUTION:

After repair or replacement of faulty parts, conduct Clear Memory Mode <Ref. to EN(H4DOTC)(diag)-46, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(H4DOTC)(diag)-39, PROCEDURE, Inspection Mode.>.

Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

WIRING DIAGRAM:



EN-01608

| Step | Check | Yes | No |
|------|--|---|---------------------------|
| 1 | CHECK ANY OTHER DTC ON DISPLAY. Does the Subaru Select Monitor or OBD-II general scan tool indicate DTC P0604? | Replace the ECM. <Ref. to FU(H4DOTC)-48, Engine Control Module (ECM).> | A temporary poor contact. |

Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

BX:DTC P0691 COOLING FAN 1 CONTROL CIRCUIT LOW

DTC DETECTING CONDITION:

- Two consecutive driving cycles with fault
- GENERAL DESCRIPTION <Ref. to GD(H4DOTC)-179, DTC P0691 COOLING FAN 1 CONTROL CIRCUIT LOW, Diagnostic Trouble Code (DTC) Detecting Criteria.>

TROUBLE SYMPTOM:

- Radiator fan does not operate properly.
- Overheating


CAUTION:

After repair or replacement of faulty parts, conduct Clear Memory Mode <Ref. to EN(H4DOTC)(diag)-46, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(H4DOTC)(diag)-39, PROCEDURE, Inspection Mode.>.

Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

WIRING DIAGRAM:



(B72)

| | |
|---|---|
| 1 | 2 |
| 3 | 4 |

(F27)

| | | | | | | | | | | | | | | |
|---|----|----|----|----|----|----|----|----|----|----|----|----|----|----|
| 1 | 2 | 5 | 6 | 7 | 10 | 15 | 16 | 17 | 20 | 25 | 26 | 27 | 30 | 35 |
| 3 | 4 | 8 | 11 | 18 | 21 | 28 | 31 | 36 | | | | | | |
| 9 | 12 | 13 | 14 | 19 | 22 | 23 | 24 | 29 | 32 | 33 | 34 | 36 | | |

(B84)

| | | | | | | | | | | | |
|----|----|----|----|----|----|----|----|----|----|----|----|
| 1 | 2 | 3 | 4 | 5 | 6 | 7 | 8 | 9 | | | |
| 10 | 11 | 12 | 13 | 14 | 15 | 16 | 17 | 18 | 19 | 20 | 21 |
| 22 | 23 | 24 | 25 | 26 | 27 | 28 | 29 | 30 | 31 | | |

(F45)

| | | | | | | | | | | | | |
|----|----|----|----|----|----|----|----|----|----|----|----|----|
| 1 | 2 | 3 | 4 | 5 | 6 | 7 | 8 | 9 | 10 | 11 | | |
| 12 | 13 | 14 | 15 | 16 | 17 | 18 | 19 | 20 | 21 | 22 | 23 | 24 |

(F16)

| | |
|---|---|
| 1 | 2 |
| 3 | 4 |

EN-01625

Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

| Step | Check | Yes | No |
|---|--|--|--|
| 1 CHECK OUTPUT SIGNAL FROM ECM. 1) Turn the ignition switch to OFF. 2) Connect the test mode connector. 3) Turn the ignition switch to ON. 4) While operating the radiator fan relay, measure voltage between ECM terminal and ground. NOTE: Radiator fan relay operation can be executed using Subaru Select Monitor. For procedure, refer to "Compulsory Valve Operation Check Mode". <Ref. to EN(H4DOTC)(diag)-31, Subaru Select Monitor.> Connector & terminal (B84) No. 17 (+) — Chassis ground (-): (B84) No. 28 (+) — Chassis ground (-): | Does the voltage change 0 — 10 V? | Repair poor contact in ECM connector. | Go to step 2. |
| 2 CHECK GROUND SHORT CIRCUIT IN RADIATOR FAN RELAY CONTROL CIRCUIT. 1) Turn the ignition switch to OFF. 2) Disconnect the connectors from ECM. 3) Measure the resistance of harness between ECM connector and chassis ground. Connector & terminal (B84) No. 17 — Chassis ground: (B84) No. 28 — Chassis ground: | Is the resistance more than 1 M Ω ? | Go to step 3. | Repair ground short circuit in radiator fan relay control circuit. |
| 3 CHECK POWER SUPPLY FOR RELAY. 1) Remove the main fan relay 1 and main fan relay 2 from A/C relay holder. 2) Turn the ignition switch to ON. 3) Measure the voltage between fuse and relay box (F/B) connector and chassis ground. Connector & terminal (F27) No. 27 (+) — Chassis ground (-): (F27) No. 32 (+) — Chassis ground (-): | Is the voltage more than 10 V? | Go to step 4. | Repair open circuit in harness between ignition switch and fuse and relay box (F/B) connector. |
| 4 CHECK MAIN FAN RELAY. 1) Turn the ignition switch to OFF. 2) Measure the resistance between main fan relay terminals. Terminals No. 32 — No. 34: (Main fan relay 1) No. 25 — No. 27: (Main fan relay 2) | Is the resistance 87 — 107 Ω ? | Go to step 5. | Replace the main fan relay. |
| 5 CHECK OPEN CIRCUIT IN MAIN FAN RELAY CONTROL CIRCUIT. Measure the resistance of harness between ECM and fan relay connector. Connector & terminal (B84) No. 17 — (F27) No. 32: (B84) No. 28 — (F27) No. 27: | Is the resistance less than 1 Ω ? | Go to step 6. | Repair harness and connector. NOTE: In this case, repair the following: • Open circuit in harness between ECM and fan relay connector • Poor contact in coupling connector |
| 6 CHECK POOR CONTACT. Check poor contact in ECM or fan relay connector. | Is there poor contact in ECM or fan relay connector? | Repair poor contact in ECM or fan relay connector. | Contact your SOA Service Center. |

Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

BY:DTC P0692 COOLING FAN 1 CONTROL CIRCUIT HIGH

DTC DETECTING CONDITION:

- Two consecutive driving cycles with fault
- GENERAL DESCRIPTION <Ref. to GD(H4DOTC)-180, DTC P0692 COOLING FAN 1 CONTROL CIRCUIT HIGH, Diagnostic Trouble Code (DTC) Detecting Criteria.>

TROUBLE SYMPTOM:

- Radiator fan does not operate properly.
- Overheating


CAUTION:

After repair or replacement of faulty parts, conduct Clear Memory Mode <Ref. to EN(H4DOTC)(diag)-46, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(H4DOTC)(diag)-39, PROCEDURE, Inspection Mode.>.

Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

WIRING DIAGRAM:



(B72)

| | |
|---|---|
| 1 | 2 |
| 3 | 4 |

(F27)

| | | | | | | | | | | | | | | |
|---|---|---|----|----|----|----|----|----|----|----|----|----|----|----|
| 1 | 2 | 5 | 6 | 7 | 10 | 15 | 16 | 17 | 20 | 25 | 26 | 27 | 30 | 35 |
| 3 | 4 | 8 | 11 | 18 | 21 | 28 | 31 | 36 | | | | | | |
| | | 9 | 12 | 13 | 14 | 19 | 22 | 23 | 24 | 29 | 32 | 33 | 34 | 36 |

(B84)

| | | | | | | | | | | | |
|----|----|----|----|----|----|----|----|----|----|----|----|
| 1 | 2 | 3 | 4 | 5 | 6 | 7 | 8 | 9 | | | |
| 10 | 11 | 12 | 13 | 14 | 15 | 16 | 17 | 18 | 19 | 20 | 21 |
| 22 | 23 | 24 | 25 | 26 | 27 | 28 | 29 | 30 | 31 | | |

(F45)

| | | | | | | | | | | | | |
|----|----|----|----|----|----|----|----|----|----|----|----|----|
| 1 | 2 | 3 | 4 | 5 | 6 | 7 | 8 | 9 | 10 | 11 | | |
| 12 | 13 | 14 | 15 | 16 | 17 | 18 | 19 | 20 | 21 | 22 | 23 | 24 |

(F16)

| | |
|---|---|
| 1 | 2 |
| 3 | 4 |

EN-01625

Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

| Step | Check | Yes | No |
|---|---|--|---|
| <p>1 CHECK OUTPUT SIGNAL FROM ECM.</p> <ol style="list-style-type: none"> 1) Turn the ignition switch to OFF. 2) Connect the test mode connector. 3) Turn the ignition switch to ON. 4) While operating the radiator fan relay, measure the voltage between ECM and chassis ground. <p>NOTE: Radiator fan relay operation can be executed using the Subaru Select Monitor. For procedure, refer to "Compulsory Valve Operation Check Mode". <Ref. to EN(H4DOTC)(diag)-47, Compulsory Valve Operation Check Mode.></p> <p>Connector & terminal (B84) No. 17 (+) — Chassis ground (-): (B84) No. 28 (+) — Chassis ground (-):</p> | <p>Does the voltage change 0 — 10 V?</p> | <p>Even if malfunction indicator light lights up, the circuit has returned to a normal condition at this time. In this case, repair the poor contact in ECM connector.</p> | <p>Go to step 2.</p> |
| <p>2 CHECK SHORT CIRCUIT IN RADIATOR FAN RELAY CONTROL CIRCUIT.</p> <ol style="list-style-type: none"> 1) Turn the ignition switch to OFF. 2) Remove the fan relay 1, fan relay 2 and fan mode relay. 3) Disconnect the test mode connector. 4) Turn the ignition switch to ON. 5) Measure the voltage between ECM and chassis ground. <p>Connector & terminal (B84) No. 17 (+) — Chassis ground (-): (B84) No. 28 (+) — Chassis ground (-):</p> | <p>Is the voltage more than 10 V?</p> | <p>Repair the battery short circuit in radiator fan relay control circuit. After repair, replace the ECM. <Ref. to FU(H4DOTC)-48, Engine Control Module (ECM).></p> | <p>Go to step 3.</p> |
| <p>3 CHECK MAIN FAN RELAY.</p> <ol style="list-style-type: none"> 1) Turn the ignition switch to OFF. 2) Remove the main fan relay. 3) Measure the resistance between main fan relay terminals. <p>Terminals No. 30 — No. 31: (Main fan relay 1) No. 28 — No. 29: (Main fan relay 2)</p> | <p>Is the resistance less than 1 Ω?</p> | <p>Replace the main fan relay and ECM. <Ref. to FU(H4DOTC)-48, Engine Control Module (ECM).></p> | <p>Go to step 4.</p> |
| <p>4 CHECK SUB FAN RELAY.</p> <ol style="list-style-type: none"> 1) Remove the sub fan relay. 2) Measure the resistance between sub fan relay terminals. <p>Terminals No. 8 — No. 9: (Sub fan relay 1) No. 20 — No. 21: (Sub fan relay 2)</p> | <p>Is the resistance less than 1 Ω?</p> | <p>Replace the sub fan relay and ECM. <Ref. to FU(H4DOTC)-48, Engine Control Module (ECM).></p> | <p>Go to step 5.</p> |
| <p>5 CHECK POOR CONTACT. Check poor contact in ECM connector.</p> | <p>Is there poor contact in ECM connector?</p> | <p>Repair the poor contact in ECM connector.</p> | <p>Replace the ECM. <Ref. to FU(H4DOTC)-48, Engine Control Module (ECM).></p> |

Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

BZ:DTC P0703 TORQUE CONVERTER/BRAKE SWITCH "B" CIRCUIT


DTC DETECTING CONDITION:

- Two consecutive driving cycles with fault
- GENERAL DESCRIPTION <Ref. to GD(H4DOTC)-181, DTC P0703 TORQUE CONVERTER/BRAKE SWITCH "B" CIRCUIT, Diagnostic Trouble Code (DTC) Detecting Criteria.>

CAUTION:

After repair or replacement of faulty parts, conduct Clear Memory Mode <Ref. to EN(H4DOTC)(diag)-46, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(H4DOTC)(diag)-39, PROCEDURE, Inspection Mode.>.

WIRING DIAGRAM:



EN-01253

Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

| Step | Check | Yes | No |
|----------|--|---|--|
| 1 | CHECK OPERATION OF BRAKE LIGHT. | Go to step 2. | Repair or replace the brake light circuit. |
| 2 | CHECK HARNESS BETWEEN TCM AND BRAKE LIGHT SWITCH CONNECTOR. 1) Disconnect the connectors from TCM and brake light switch. 2) Measure the resistance of harness between TCM and brake light switch connector. Connector & terminal (B55) No. 12 — (B65) No. 3: | Go to step 3. | Repair or replace the harness and connector. NOTE: In this case, repair the following: • Open circuit in harness between TCM and brake light switch connector • Poor contact in TCM connector • Poor contact in brake light switch connector |
| 3 | CHECK HARNESS BETWEEN TCM AND BRAKE LIGHT SWITCH CONNECTOR. Measure the resistance of harness between TCM and chassis ground. Connector & terminal (B55) No. 12 — Chassis ground: | Go to step 4. | Repair the ground short circuit in harness between TCM and brake light switch connector. |
| 4 | CHECK INPUT SIGNAL FOR TCM. 1) Connect the connectors to TCM and brake light switch. 2) Measure the voltage between TCM and chassis ground. Connector & terminal (B55) No. 12 (+) — Chassis ground (-): | Go to step 5. | Adjust or replace the brake light switch. <Ref. to LI-7, STOP LIGHT SWITCH, INSPECTION, Stop Light System.> |
| 5 | CHECK INPUT SIGNAL FOR TCM. Measure the voltage between TCM and chassis ground. Connector & terminal (B55) No. 12 (+) — Chassis ground (-): | Go to step 6. | Adjust or replace the brake light switch. <Ref. to LI-7, STOP LIGHT SWITCH, INSPECTION, Stop Light System.> |
| 6 | CHECK POOR CONTACT. Check poor contact in TCM connector. | Repair the poor contact in TCM connector. | Replace the TCM. <Ref. to 4AT-67, Transmission Control Module (TCM).> |

Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

CA:DTC P0705 TRANSMISSION RANGE SENSOR CIRCUIT (PRNDL INPUT)

GENERAL DESCRIPTION <Ref. to GD(H4DOTC)-182, DTC P0705 TRANSMISSION RANGE SENSOR CIRCUIT (PRNDL INPUT), Diagnostic Trouble Code (DTC) Detecting Criteria.>

NOTE:

For the diagnostic procedure, refer to AT section. <Ref. to 4AT(diag)-104, CHECK INHIBITOR SWITCH, Diagnostic Procedure without Diagnostic Trouble Code (DTC).>

CB:DTC P0710 TRANSMISSION FLUID TEMPERATURE SENSOR CIRCUIT

GENERAL DESCRIPTION <Ref. to GD(H4DOTC)-183, DTC P0710 TRANSMISSION FLUID TEMPERATURE SENSOR CIRCUIT, Diagnostic Trouble Code (DTC) Detecting Criteria.>

NOTE:

For the diagnostic procedure, refer to AT section. <Ref. to 4AT(diag)-43, DTC 27 ATF TEMPERATURE SENSOR, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>

CC:DTC P0716 TORQUE CONVERTER TURBINE SPEED SENSOR

GENERAL DESCRIPTION <Ref. to GD(H4DOTC)-184, DTC P0716 INPUT/TURBINE SPEED SENSOR CIRCUIT RANGE/PERFORMANCE, Diagnostic Trouble Code (DTC) Detecting Criteria.>

NOTE:

For the diagnostic procedure, refer to AT section. <Ref. to 4AT(diag)-57, DTC 36 TORQUE CONVERTER TURBINE SPEED SENSOR, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>

CD:DTC P0720 OUTPUT SPEED SENSOR CIRCUIT

GENERAL DESCRIPTION <Ref. to GD(H4DOTC)-185, DTC P0720 OUTPUT SPEED SENSOR CIRCUIT, Diagnostic Trouble Code (DTC) Detecting Criteria.>

NOTE:

For the diagnostic procedure, refer to AT section. <Ref. to 4AT(diag)-52, DTC 33 FRONT VEHICLE SPEED SENSOR, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>

CE:DTC P0726 ENGINE SPEED INPUT CIRCUIT RANGE/PERFORMANCE

GENERAL DESCRIPTION <Ref. to GD(H4DOTC)-186, DTC P0726 ENGINE SPEED INPUT CIRCUIT RANGE/PERFORMANCE, Diagnostic Trouble Code (DTC) Detecting Criteria.>

NOTE:

For the diagnostic procedure, refer to AT section. <Ref. to 4AT(diag)-39, DTC 11 ENGINE SPEED SIGNAL, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>

CF:DTC P0731 GEAR 1 INCORRECT RATIO

NOTE:

For the diagnostic procedure, refer to DTC P0734. <Ref. to EN(H4DOTC)(diag)-255, DTC P0734 GEAR 4 INCORRECT RATIO, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>

CG:DTC P0732 GEAR 2 INCORRECT RATIO

NOTE:

For the diagnostic procedure, refer to DTC P0734. <Ref. to EN(H4DOTC)(diag)-255, DTC P0734 GEAR 4 INCORRECT RATIO, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>

CH:DTC P0733 GEAR 3 INCORRECT RATIO

NOTE:

For the diagnostic procedure, refer to DTC P0734. <Ref. to EN(H4DOTC)(diag)-255, DTC P0734 GEAR 4 INCORRECT RATIO, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>

Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

CI: DTC P0734 GEAR 4 INCORRECT RATIO

DTC DETECTING CONDITION:

- Two consecutive driving cycles with fault
- GENERAL DESCRIPTION <Ref. to GD(H4DOTC)-190, DTC P0734 GEAR 4 INCORRECT RATIO, Diagnostic Trouble Code (DTC) Detecting Criteria.>

TROUBLE SYMPTOM:

Shift point too high or too low; engine brake not effective in “3” range; excessive shift shock; excessive tight corner “braking”

CAUTION:

After repair or replacement of faulty parts, conduct Clear Memory Mode <Ref. to EN(H4DOTC)(diag)-46, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(H4DOTC)(diag)-39, PROCEDURE, Inspection Mode.>.

WIRING DIAGRAM:

| Step | Check | Yes | No | |
|------|--|--|---|---|
| 1 | CHECK ANY OTHER DTC ON DISPLAY. | Is any other DTC displayed? | Inspect the relevant DTC using “List of Diagnostic Trouble Code (DTC)”. <Ref. to EN(H4DOTC)(diag)-71, List of Diagnostic Trouble Code (DTC).> | Go to step 2. |
| 2 | CHECK THROTTLE POSITION SENSOR CIRCUIT. Check the throttle position sensor circuit. <Ref. to 4AT(diag)-46, DTC 31 THROTTLE POSITION SENSOR, Diagnostic Procedure with Diagnostic Trouble Code (DTC).> | Is there any trouble in throttle position sensor circuit? | Repair or replace the throttle position sensor circuit. | Go to step 3. |
| 3 | CHECK FRONT VEHICLE SPEED SENSOR CIRCUIT. Check the front vehicle speed sensor circuit. <Ref. to 4AT(diag)-52, DTC 33 FRONT VEHICLE SPEED SENSOR, Diagnostic Procedure with Diagnostic Trouble Code (DTC).> | Is there any trouble in front vehicle speed sensor circuit? | Repair or replace the vehicle speed sensor 2 circuit. | Go to step 4. |
| 4 | CHECK TORQUE CONVERTER TURBINE SPEED SENSOR CIRCUIT. Check the torque converter turbine speed sensor circuit. <Ref. to 4AT(diag)-57, DTC 36 TORQUE CONVERTER TURBINE SPEED SENSOR, Diagnostic Procedure with Diagnostic Trouble Code (DTC).> | Is there any trouble in torque converter turbine speed sensor circuit? | Repair or replace the torque converter turbine speed sensor circuit. | Go to step 5. |
| 5 | CHECK POOR CONTACT. Check poor contact in TCM connector. | Is there poor contact in TCM connector? | Repair the poor contact in TCM connector. | Go to step 6. |
| 6 | CHECK MECHANICAL TROUBLE. Check mechanical trouble in automatic transmission. | Is there any mechanical trouble in automatic transmission? | Repair or replace the automatic transmission. <Ref. to 4AT-32, INSPECTION, Road Test.> | Replace the TCM. <Ref. to 4AT-67, Transmission Control Module (TCM).> |

Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

CJ:DTC P0741 TORQUE CONVERTER CLUTCH CIRCUIT PERFORMANCE OR STUCK OFF

DTC DETECTING CONDITION:

- Two consecutive driving cycles with fault
- GENERAL DESCRIPTION <Ref. to GD(H4DOTC)-191, DTC P0741 TORQUE CONVERTER CLUTCH CIRCUIT PERFORMANCE OR STUCK OFF, Diagnostic Trouble Code (DTC) Detecting Criteria.>

TROUBLE SYMPTOM:

- No lock-up (after engine warm-up)
- No shift or excessive tight corner “braking”

CAUTION:

After repair or replacement of faulty parts, conduct Clear Memory Mode <Ref. to EN(H4DOTC)(diag)-46, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(H4DOTC)(diag)-39, PROCEDURE, Inspection Mode.>.

| Step | Check | Yes | No |
|------|--|--|---|
| 1 | CHECK ANY OTHER DTC ON DISPLAY. | Is any other DTC displayed? | Inspect the relevant DTC using “List of Diagnostic Trouble Code (DTC)”. <Ref. to EN(H4DOTC)(diag)-71, List of Diagnostic Trouble Code (DTC).> |
| 2 | CHECK LOCK-UP DUTY SOLENOID CIRCUIT. Check the lock-up duty solenoid circuit. <Ref. to 4AT(diag)-87, DTC 77 LOCK-UP DUTY SOLENOID, Diagnostic Procedure with Diagnostic Trouble Code (DTC).> | Is there any trouble in lock-up duty solenoid circuit? | Repair or replace the lock-up duty solenoid circuit. |
| 3 | CHECK THROTTLE POSITION SENSOR CIRCUIT. Check the throttle position sensor circuit. <Ref. to 4AT(diag)-46, DTC 31 THROTTLE POSITION SENSOR, Diagnostic Procedure with Diagnostic Trouble Code (DTC).> | Is there any trouble in throttle position sensor circuit? | Repair or replace the throttle position sensor circuit. |
| 4 | CHECK TORQUE CONVERTER TURBINE SPEED SENSOR CIRCUIT. Check the torque converter turbine speed sensor circuit. <Ref. to 4AT(diag)-57, DTC 36 TORQUE CONVERTER TURBINE SPEED SENSOR, Diagnostic Procedure with Diagnostic Trouble Code (DTC).> | Is there any trouble in torque converter turbine speed sensor circuit? | Repair or replace the torque converter turbine speed sensor circuit. |
| 5 | CHECK ENGINE SPEED INPUT CIRCUIT. Check the engine speed input circuit. <Ref. to 4AT(diag)-39, DTC 11 ENGINE SPEED SIGNAL, Diagnostic Procedure with Diagnostic Trouble Code (DTC).> | Is there any trouble in engine speed input circuit? | Repair or replace the engine speed input circuit. |
| 6 | CHECK INHIBITOR SWITCH CIRCUIT. Check the inhibitor switch circuit. <Ref. to 4AT(diag)-104, CHECK INHIBITOR SWITCH, Diagnostic Procedure without Diagnostic Trouble Code (DTC).> | Is there any trouble in inhibitor switch circuit? | Repair or replace the inhibitor switch circuit. |

Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

| Step | Check | Yes | No |
|---|--|--|---|
| 7 CHECK BRAKE LIGHT SWITCH CIRCUIT. Check the brake light switch circuit. <Ref. to 4AT(diag)-103, CHECK BRAKE SWITCH, Diagnostic Procedure without Diagnostic Trouble Code (DTC).> | Is there any trouble in brake light switch circuit? | Repair or replace the brake light switch circuit. | Go to step 8 . |
| 8 CHECK ATF TEMPERATURE SENSOR CIRCUIT. Check the ATF temperature sensor circuit. <Ref. to 4AT(diag)-43, DTC 27 ATF TEMPERATURE SENSOR, Diagnostic Procedure with Diagnostic Trouble Code (DTC).> | Is there any trouble in ATF temperature sensor circuit? | Repair or replace the ATF temperature sensor circuit. | Go to step 9 . |
| 9 CHECK POOR CONTACT. Check poor contact in TCM connector. | Is there poor contact in TCM connector? | Repair the poor contact in TCM connector. | Go to step 10 . |
| 10 CHECK MECHANICAL TROUBLE. Check mechanical trouble in automatic transmission. | Is there any mechanical trouble in automatic transmission? | Repair or replace the automatic transmission. <Ref. to 4AT-32, INSPECTION, Road Test.> | Replace the TCM. <Ref. to 4AT-67, Transmission Control Module (TCM).> |

Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

CK:DTC P0743 TORQUE CONVERTER CLUTCH CIRCUIT ELECTRICAL

GENERAL DESCRIPTION <Ref. to GD(H4DOTC)-192, DTC P0743 TORQUE CONVERTER CLUTCH CIRCUIT ELECTRICAL, Diagnostic Trouble Code (DTC) Detecting Criteria.>

NOTE:

For the diagnostic procedure, refer to AT section. <Ref. to 4AT(diag)-87, DTC 77 LOCK-UP DUTY SOLENOID, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>

CL:DTC P0748 PRESSURE CONTROL SOLENOID "A" ELECTRICAL

GENERAL DESCRIPTION <Ref. to GD(H4DOTC)-193, DTC P0748 PRESSURE CONTROL SOLENOID "A" ELECTRICAL, Diagnostic Trouble Code (DTC) Detecting Criteria.>

NOTE:

For the diagnostic procedure, refer to AT section. <Ref. to 4AT(diag)-78, DTC 75 LINE PRESSURE DUTY SOLENOID, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>

CM:DTC P0753 SHIFT SOLENOID "A" ELECTRICAL

GENERAL DESCRIPTION <Ref. to GD(H4DOTC)-194, DTC P0753 SHIFT SOLENOID "A" ELECTRICAL, Diagnostic Trouble Code (DTC) Detecting Criteria.>

NOTE:

For the diagnostic procedure, refer to AT section. <Ref. to 4AT(diag)-65, DTC 71 SHIFT SOLENOID 1, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>

CN:DTC P0758 SHIFT SOLENOID "B" ELECTRICAL

GENERAL DESCRIPTION <Ref. to GD(H4DOTC)-195, DTC P0758 SHIFT SOLENOID "B" ELECTRICAL, Diagnostic Trouble Code (DTC) Detecting Criteria.>

NOTE:

For the diagnostic procedure, refer to AT section. <Ref. to 4AT(diag)-68, DTC 72 SHIFT SOLENOID 2, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>

CO:DTC P0771 LOW CLUTCH TIMING SOLENOID

GENERAL DESCRIPTION <Ref. to GD(H4DOTC)-196, DTC P0771 SHIFT SOLENOID "E" PERFORMANCE OR STUCK OFF, Diagnostic Trouble Code (DTC) Detecting Criteria.>

NOTE:

For the diagnostic procedure, refer to AT section. <Ref. to 4AT(diag)-71, DTC 73 LOW CLUTCH TIMING SOLENOID, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>

CP:DTC P0778 PRESSURECONTROL SOLENOID "B" ELECTRICAL

GENERAL DESCRIPTION <Ref. to GD(H4DOTC)-197, DTC P0778 PRESSURE CONTROL SOLENOID "B" ELECTRICAL, Diagnostic Trouble Code (DTC) Detecting Criteria.>

NOTE:

For the diagnostic procedure, refer to AT section. <Ref. to 4AT(diag)-83, DTC 76 2-4 BRAKE DUTY SOLENOID, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>

CQ:DTC P0785 SHIFT/TIMING SOLENOID

GENERAL DESCRIPTION <Ref. to GD(H4DOTC)-198, DTC P0785 SHIFT/TIMING SOLENOID, Diagnostic Trouble Code (DTC) Detecting Criteria.>

NOTE:

For the diagnostic procedure, refer to AT section. <Ref. to 4AT(diag)-74, DTC 74 2-4 BRAKE TIMING SOLENOID, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>

Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

CR:DTC P0851 NEUTRAL SWITCH INPUT CIRCUIT LOW (AT MODEL)

DTC DETECTING CONDITION:

- Two consecutive driving cycles with fault
- GENERAL DESCRIPTION <Ref. to GD(H4DOTC)-199, DTC P0851 NEUTRAL SWITCH INPUT CIRCUIT LOW (AT MODEL), Diagnostic Trouble Code (DTC) Detecting Criteria.>


TROUBLE SYMPTOM:

Erroneous idling

CAUTION:

After repair or replacement of faulty parts, conduct Clear Memory Mode <Ref. to EN(H4DOTC)(diag)-46, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(H4DOTC)(diag)-39, PROCEDURE, Inspection Mode.>.

WIRING DIAGRAM:



EN-01629

Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

| Step | Check | Yes | No |
|---|--|---|--|
| 1 CHECK DTC P0705 ON DISPLAY. | Is DTC P0705 indicated? | Inspect DTC P0705 using "List of Diagnostic Trouble Code (DTC)". <Ref. to EN(H4DOTC)(diag)-71, List of Diagnostic Trouble Code (DTC).> | Go to step 2. |
| 2 CHECK INPUT SIGNAL FOR ECM. 1) Turn the ignition switch to ON. 2) Place the select lever except for "N" and "P" positions. 3) Measure the voltage between ECM and chassis ground. Connector & terminal (B134) No. 8 (+) — Chassis ground (-): | Is the voltage 4.5 — 5.5 V? | Even if malfunction indicator light lights up, the circuit has returned to a normal condition at this time. | Go to step 3. |
| 3 CHECK HARNESS BETWEEN ECM AND TRANSMISSION HARNESS CONNECTOR. 1) Turn the ignition switch to OFF. 2) Disconnect the connectors from ECM and transmission harness connector (T3). 3) Measure the resistance of harness between ECM connector and chassis ground. Connector & terminal (B134) No. 8 — Chassis ground: | Is the resistance more than 1 MΩ? | Go to step 4. | Repair ground short circuit in harness between ECM and transmission harness connector. |
| 4 CHECK TRANSMISSION HARNESS CONNECTOR. 1) Disconnect the connector from inhibitor switch. 2) Measure the resistance of harness between transmission harness connector and engine ground. Connector & terminal (T3) No. 12 — Engine ground: | Is the resistance more than 1 MΩ? | Go to step 5. | Repair ground short circuit in harness between transmission harness and inhibitor switch connector. |
| 5 CHECK INHIBITOR SWITCH. Measure the resistance between inhibitor switch connector the receptacle's terminals in selector lever except for "N" position. Terminals No. 7 — No. 12: | Is the resistance more than 1 MΩ? | Go to step 6. | Replace the inhibitor switch. <Ref. to 4AT-46, Inhibitor Switch.> |
| 6 CHECK SELECTOR CABLE CONNECTION. | Is there any fault in selector cable connection to inhibitor switch? | Repair selector cable connection. <Ref. to CS-26, INSPECTION, Select Cable.> | Contact your SOA Service Center. NOTE: Inspection by DTM is required, because probable cause is deterioration of multiple parts. |

Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

CS:DTC P0851 NEUTRAL SWITCH INPUT CIRCUIT LOW (MT MODEL)

DTC DETECTING CONDITION:

- Two consecutive driving cycles with fault
- GENERAL DESCRIPTION <Ref. to GD(H4DOTC)-200, DTC P0851 NEUTRAL SWITCH INPUT CIRCUIT LOW (MT MODEL), Diagnostic Trouble Code (DTC) Detecting Criteria.>


TROUBLE SYMPTOM:

Erroneous idling

CAUTION:

After repair or replacement of faulty parts, conduct Clear Memory Mode <Ref. to EN(H4DOTC)(diag)-46, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(H4DOTC)(diag)-39, PROCEDURE, Inspection Mode.>.

WIRING DIAGRAM:



EN-01629

Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

| Step | Check | Yes | No |
|--|--|--|--|
| 1 CHECK INPUT SIGNAL FOR ECM. 1) Turn the ignition switch to ON. 2) Place the shift lever in neutral. 3) Measure the voltage between ECM and chassis ground. <i>Connector & terminal</i> <i>(B134) No. 8 (+) — Chassis ground (-):</i> | Is the voltage more than 10 V? | Go to step 2. | Go to step 4. |
| 2 CHECK INPUT SIGNAL FOR ECM. 1) Place the shift lever in a position except for neutral. 2) Measure the voltage between ECM and chassis ground. <i>Connector & terminal</i> <i>(B134) No. 8 (+) — Chassis ground (-):</i> | Is the voltage less than 1 V? | Go to step 3. | Go to step 4. |
| 3 CHECK POOR CONTACT. Check poor contact in ECM connector. | Is there poor contact in ECM connector? | Repair poor contact in ECM connector. | Contact your SOA Service Center. |
| 4 CHECK NEUTRAL POSITION SWITCH. 1) Turn the ignition switch to OFF. 2) Disconnect the connector from transmission harness. 3) Place the shift lever in neutral. 4) Measure the resistance between transmission harness and connector terminals. <i>Connector & terminal</i> <i>(T9) No. 1 — No. 3:</i> | Is the resistance more than 1 M Ω ? | Go to step 5. | Repair short circuit in transmission harness or replace neutral position switch. |
| 5 CHECK NEUTRAL POSITION SWITCH. 1) Place the shift lever in a position except for neutral. 2) Measure the resistance between transmission harness connector terminals. | Is the resistance less than 1 Ω ? | Go to step 6. | Repair short circuit in transmission harness or replace neutral position switch. |
| 6 CHECK HARNESS BETWEEN ECM AND NEUTRAL POSITION SWITCH CONNECTOR. Measure the resistance between ECM and chassis ground. <i>Connector & terminal</i> <i>(B134) No. 8 — Chassis ground:</i> | Is the resistance more than 1 M Ω ? | Go to step 7. | Repair ground short circuit in harness between ECM and transmission harness connector. |
| 7 CHECK HARNESS BETWEEN ECM AND NEUTRAL POSITION SWITCH CONNECTOR. 1) Disconnect the connector from ECM. 2) Measure the resistance of harness between ECM and transmission harness connector. <i>Connector & terminal</i> <i>(B134) No. 8 — (B128) No. 1:</i> | Is the resistance less than 1 Ω ? | Go to step 8. | Repair open circuit in harness between ECM and transmission harness connector. |
| 8 CHECK HARNESS BETWEEN ECM AND NEUTRAL POSITION SWITCH CONNECTOR. Measure the resistance of harness between transmission harness connector and engine ground. <i>Connector & terminal</i> <i>(B128) No. 1 — Engine ground:</i> | Is the resistance less than 5 Ω ? | Go to step 9. | Repair open circuit between transmission harness connector and engine ground terminal. |
| 9 CHECK POOR CONTACT. Check poor contact in transmission harness connector. | Is there poor contact in transmission harness connector? | Repair poor contact in transmission harness connector. | Contact your SOA Service Center. |

Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

CT:DTC P0852 NEUTRAL SWITCH INPUT CIRCUIT HIGH (AT MODEL)

DTC DETECTING CONDITION:

- Two consecutive driving cycles with fault
- GENERAL DESCRIPTION <Ref. to GD(H4DOTC)-201, DTC P0852 NEUTRAL SWITCH INPUT CIRCUIT HIGH (AT MODEL), Diagnostic Trouble Code (DTC) Detecting Criteria.>


TROUBLE SYMPTOM:

Erroneous idling

CAUTION:

After repair or replacement of faulty parts, conduct Clear Memory Mode <Ref. to EN(H4DOTC)(diag)-46, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(H4DOTC)(diag)-39, PROCEDURE, Inspection Mode.>.

WIRING DIAGRAM:



Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

| Step | Check | Yes | No |
|---|--|---|--|
| 1 CHECK DTC P0705 ON DISPLAY. | Is DTC P0705 indicated? | Inspect DTC P0705 using "List of Diagnostic Trouble Code (DTC)". <Ref. to EN(H4DOTC)(diag)-71, List of Diagnostic Trouble Code (DTC).> | Go to step 2. |
| 2 CHECK INPUT SIGNAL FOR ECM. 1) Turn the ignition switch to ON. 2) Measure the voltage between ECM and chassis ground in selector lever "N" and "P" positions. Connector & terminal (B134) No. 8 (+) — Chassis ground (-): | Is the voltage less than 1 V? | Go to step 3. | Go to step 5. |
| 3 CHECK INPUT SIGNAL FOR ECM. Measure the voltage between ECM and chassis ground in selector lever except for "N" and "P" positions. Connector & terminal (B134) No. 8 (+) — Chassis ground (-): | Is the voltage 4.5 — 5.5 V? | Go to step 4. | Go to step 5. |
| 4 CHECK POOR CONTACT. Check poor contact in ECM connector. | Is there poor contact in ECM connector? | Repair poor contact in ECM connector. | Contact your SOA Service Center. NOTE: Inspection by DTM is required, because probable cause is deterioration of multiple parts. |
| 5 CHECK INPUT SIGNAL FOR ECM. Measure the voltage between ECM and chassis ground. Connector & terminal (B134) No. 8 (+) — Chassis ground (-): | Is the voltage more than 10 V? | Repair battery short circuit in harness between ECM and inhibitor switch connector. | Go to step 6. |
| 6 CHECK HARNESS BETWEEN ECM AND INHIBITOR SWITCH CONNECTOR. 1) Turn the ignition switch to OFF. 2) Disconnect the connectors from ECM and inhibitor switch. 3) Measure the resistance of harness between ECM and inhibitor switch connector. Connector & terminal (B134) No. 8 — (T7) No. 12: | Is the resistance less than 1 Ω ? | Go to step 7. | Repair harness and connector. NOTE: In this case, repair the following: • Open circuit in harness between ECM and inhibitor switch connector • Poor contact in coupling connector • Poor contact in inhibitor switch connector • Poor contact in ECM connector |

Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

| Step | Check | Yes | No |
|---|---|--|--|
| <p>7 CHECK INHIBITOR SWITCH GROUND LINE. Measure the resistance of harness between inhibitor switch connector and engine ground. <i>Connector & terminal</i> <i>(T7) No. 7 — Engine ground:</i></p> | <p>Is the resistance less than 5 Ω?</p> | <p>Go to step 8.</p> | <p>Repair open circuit in harness between inhibitor switch connector and starter motor ground line.</p> <p>NOTE: In this case, repair the following:</p> <ul style="list-style-type: none"> • Open circuit in harness between inhibitor switch connector and starter motor ground line • Poor contact in starter motor connector • Poor contact in starter motor ground • Starter motor |
| <p>8 CHECK INHIBITOR SWITCH. Measure the resistance between inhibitor switch connector receptacle's terminals in selector lever "N" and "P" positions. <i>Terminals</i> <i>No. 7 — No. 12:</i></p> | <p>Is the resistance less than 1 Ω?</p> | <p>Go to step 9.</p> | <p>Replace the inhibitor switch. <Ref. to 4AT-46, Inhibitor Switch.></p> |
| <p>9 CHECK SELECTOR CABLE CONNECTION.</p> | <p>Is there any fault in selector cable connection to inhibitor switch?</p> | <p>Repair selector cable connection. <Ref. to CS-26, INSPECTION, Select Cable.></p> | <p>Contact your SOA Service Center.</p> <p>NOTE: Inspection by DTM is required, because probable cause is deterioration of multiple parts.</p> |

Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

CU:DTC P0852 NEUTRAL SWITCH INPUT CIRCUIT HIGH (MT MODEL)

DTC DETECTING CONDITION:

- Two consecutive driving cycles with fault
- GENERAL DESCRIPTION <Ref. to GD(H4DOTC)-202, DTC P0852 NEUTRAL SWITCH INPUT CIRCUIT HIGH (MT MODEL), Diagnostic Trouble Code (DTC) Detecting Criteria.>


TROUBLE SYMPTOM:

Erroneous idling

CAUTION:

After repair or replacement of faulty parts, conduct Clear Memory Mode <Ref. to EN(H4DOTC)(diag)-46, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(H4DOTC)(diag)-39, PROCEDURE, Inspection Mode.>.

WIRING DIAGRAM:



EN-01629

Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

| Step | Check | Yes | No |
|---|--|---|---|
| 1 CHECK INPUT SIGNAL FOR ECM. 1) Turn the ignition switch to ON. 2) Set the shift lever to except neutral position. 3) Measure the voltage between ECM and chassis ground. Connector & terminal (B134) No. 8 (+) — Chassis ground (-): | Is the voltage less than 1 V? | Go to step 2. | Go to step 4. |
| 2 CHECK INPUT SIGNAL FOR ECM. 1) Set the shift lever to neutral position. 2) Measure the voltage between ECM and chassis ground. Connector & terminal (B134) No. 8 (+) — Chassis ground (-): | Is the voltage more than 10 V? | Go to step 3. | Go to step 4. |
| 3 CHECK POOR CONTACT. Check poor contact in ECM connector. | Is there poor contact in ECM connector? | Repair the poor contact in ECM connector. | Contact your SOA Service Center. |
| 4 CHECK INPUT SIGNAL FOR ECM. 1) Disconnect ECM connector from ECM. 2) Measure the voltage between ECM and chassis ground. Connector & terminal (B134) No. 8 (+) — Chassis ground (-): | Is the voltage more than 10 V? | Repair the battery short circuit in harness between ECM and transmission connector. | Go to step 5. |
| 5 CHECK HARNESS BETWEEN ECM AND TRANSMISSION HARNESS CONNECTOR. 1) Turn the ignition switch to OFF. 2) Disconnect the connectors from ECM and transmission harness connector (T9). 3) Measure the resistance of harness between ECM and neutral switch connector. Connector & terminal (B134) No. 8 — (B128) No. 1: | Is the resistance less than 1 Ω ? | Go to step 6. | Repair the harness and connector. NOTE: In this case, repair the following: <ul style="list-style-type: none"> • Open circuit in harness between ECM and transmission harness • Poor contact in transmission harness connector • Poor contact in ECM connector |
| 6 CHECK NEUTRAL POSITION SWITCH GROUND LINE. Measure the resistance of harness between transmission harness connector and engine ground. Connector & terminal (B128) No. 3 — Engine ground: | Is the resistance less than 5 Ω ? | Go to step 7. | Repair the open circuit in harness of neutral position switch ground line. |
| 7 CHECK NEUTRAL POSITION SWITCH. 1) Set the shift lever to except neutral position. 2) Measure the resistance between transmission harness connector receptacle's terminals. Terminals No. 1 — No. 3: | Is the resistance less than 1 Ω ? | Go to step 8. | Replace the neutral position switch. |
| 8 CHECK POOR CONTACT. Check poor contact in the transmission harness connector. | Is there poor contact in the transmission harness connector? | Repair poor contact in transmission harness connector. | Contact your SOA Service Center. |

Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

CV:DTC P0864 TCM COMMUNICATION CIRCUIT RANGE/PERFORMANCE


DTC DETECTING CONDITION:

- Two consecutive driving cycles with fault
- GENERAL DESCRIPTION <Ref. to GD(H4DOTC)-203, DTC P0864 TCM COMMUNICATION CIRCUIT RANGE/PERFORMANCE, Diagnostic Trouble Code (DTC) Detecting Criteria.>

CAUTION:

After repair or replacement of faulty parts, conduct Clear Memory Mode <Ref. to EN(H4DOTC)(diag)-46, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(H4DOTC)(diag)-39, PROCEDURE, Inspection Mode.>.

WIRING DIAGRAM:



EN-01630

Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

| Step | Check | Yes | No |
|---|---|--|--|
| 1 CHECK DRIVING CONDITION. 1) Start and warm-up the engine until the radiator fan makes one complete rotation. 2) Drive the vehicle. | Is the AT shift control functioning properly? | Go to step 2. | Replace the TCM. <Ref. to 4AT-67, Transmission Control Module (TCM).> |
| 2 CHECK ACCESSORY. | Are car phone and/or CB installed on vehicle? | Repair the grounding line of car phone or CB system. | Replace the TCM. <Ref. to 4AT-67, Transmission Control Module (TCM).> |

Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

CW:DTC P0865 TCM COMMUNICATION CIRCUIT LOW


DTC DETECTING CONDITION:

- Two consecutive driving cycles with fault
- GENERAL DESCRIPTION <Ref. to GD(H4DOTC)-204, DTC P0865 TCM COMMUNICATION CIRCUIT LOW, Diagnostic Trouble Code (DTC) Detecting Criteria.>

CAUTION:

After repair or replacement of faulty parts, conduct Clear Memory Mode <Ref. to EN(H4DOTC)(diag)-46, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(H4DOTC)(diag)-39, PROCEDURE, Inspection Mode.>.

WIRING DIAGRAM:



EN-01630

Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

| Step | Check | Yes | No |
|--|---|---|--|
| 1 CHECK HARNESS BETWEEN ECM AND TCM CONNECTOR. 1) Turn the ignition switch to ON. 2) Measure the voltage between ECM and chassis ground. Connector & terminal (B135) No. 20 (+) — Chassis ground (-): | Is the voltage less than 1 V? | Go to step 2. | Even if malfunction indicator light lights up, the circuit has returned to a normal condition at this time. NOTE: In this case, repair the following: <ul style="list-style-type: none"> • Poor contact in ECM connector • Poor contact in TCM connector |
| 2 CHECK HARNESS BETWEEN ECM AND TCM CONNECTOR. 1) Turn the ignition switch to OFF. 2) Disconnect the connector from ECM and TCM. 3) Measure the resistance of harness between ECM and chassis ground. Connector & terminal (B135) No. 20 — Chassis ground: | Is the resistance less than 10 Ω ? | Go to step 3. | Repair the ground short circuit in harness between ECM and TCM connector. |
| 3 CHECK OUTPUT SIGNAL FOR ECM. 1) Connect the connector to ECM. 2) Turn the ignition switch to ON. 3) Measure the voltage between ECM and chassis ground. Connector & terminal (B135) No. 20 (+) — Chassis ground (-): | Is the voltage more than 5 V? | Go to step 4. | Repair the poor contact in ECM connector. |
| 4 CHECK DTC FOR AUTOMATIC TRANSMISSION. Read the DTC for automatic transmission. <Ref. to 4AT(diag)-24, Read Diagnostic Trouble Code (DTC).> | Does the DTC appear for automatic transmission? | Inspect the DTC for automatic transmission. <Ref. to 4AT(diag)-39, Diagnostic Procedure with Diagnostic Trouble Code (DTC).> | Replace the TCM. <Ref. to 4AT-67, Transmission Control Module (TCM).> |

Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

CX:DTC P0866 TCM COMMUNICATION CIRCUIT HIGH


DTC DETECTING CONDITION:

- Two consecutive driving cycles with fault
- GENERAL DESCRIPTION <Ref. to GD(H4DOTC)-205, DTC P0866 TCM COMMUNICATION CIRCUIT HIGH, Diagnostic Trouble Code (DTC) Detecting Criteria.>

CAUTION:

After repair or replacement of faulty parts, conduct Clear Memory Mode <Ref. to EN(H4DOTC)(diag)-46, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(H4DOTC)(diag)-39, PROCEDURE, Inspection Mode.>.

WIRING DIAGRAM:



EN-01630

Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

| Step | Check | Yes | No |
|--|--|---|--|
| 1 CHECK HARNESS BETWEEN ECM AND TCM CONNECTOR. 1) Turn the ignition switch to ON. 2) Measure the voltage between ECM and chassis ground. <i>Connector & terminal</i> <i>(B135) No. 20 (+) — Chassis ground (-):</i> | Is the voltage more than 10 V? | Repair the battery short circuit in harness between ECM and TCM connector. After repair, replace the ECM. <Ref. to FU(H4DOTC)-48, Engine Control Module (ECM).> | Go to step 2. |
| 2 CHECK HARNESS BETWEEN ECM AND TCM CONNECTOR. Measure the voltage between ECM connector and chassis ground. <i>Connector & terminal</i> <i>(B135) No. 20 (+) — Chassis ground (-):</i> | Is the voltage more than 4 V? | Go to step 5. | Go to step 3. |
| 3 CHECK HARNESS BETWEEN ECM AND TCM CONNECTOR. Measure the voltage between ECM connector and chassis ground. <i>Connector & terminal</i> <i>(B135) No. 20 (+) — Chassis ground (-):</i> | Is the voltage less than 1 V? | Repair the poor contact in ECM connector. | Go to step 4. |
| 4 CHECK OUTPUT SIGNAL FROM ECM. Measure the voltage between ECM and chassis ground. <i>Connector & terminal</i> <i>(B135) No. 20 (+) — Chassis ground (-):</i> | Does the voltage change between 1 and 4 V while monitoring the value with voltage meter? | Even if malfunction indicator light lights up, the circuit has returned to a normal condition at this time. NOTE: In this case, repair the following: • Poor contact in ECM connector • Poor contact in TCM connector | Contact your SOA Service Center. NOTE: Inspection by DTM is required, because probable cause is deterioration of multiple parts. |
| 5 CHECK HARNESS BETWEEN ECM AND TCM CONNECTOR. Measure the voltage between TCM and chassis ground. <i>Connector & terminal</i> <i>(B56) No. 20 (+) — Chassis ground (-):</i> | Is the voltage more than 4 V? | Go to step 6. | Repair the open circuit in harness between ECM and TCM connector. |
| 6 CHECK POOR CONTACT. Check poor contact in TCM connector. | Is there poor contact in TCM connector? | Repair the poor contact in TCM connector. | Check the TCM power supply line and grounding line. |

Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

CY:DTC P1086 TUMBLE GENERATED VALVE POSITION SENSOR 2 CIRCUIT LOW

DTC DETECTING CONDITION:

- Immediately at fault recognition
- GENERAL DESCRIPTION <Ref. to GD(H4DOTC)-206, DTC P1086 TUMBLE GENERATED VALVE POSITION SENSOR 2 CIRCUIT LOW, Diagnostic Trouble Code (DTC) Detecting Criteria.>


TROUBLE SYMPTOM:

- Erroneous idling
- Engine stalls.
- Poor driving performance

CAUTION:

After repair or replacement of faulty parts, conduct Clear Memory Mode <Ref. to EN(H4DOTC)(diag)-46, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(H4DOTC)(diag)-39, PROCEDURE, Inspection Mode.>.

WIRING DIAGRAM:



EN-01320

Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

| Step | Check | Yes | No |
|---|---|--|---|
| <p>1 CHECK CURRENT DATA. 1) Start the engine. 2) Read the data of throttle position sensor signal using Subaru Select Monitor or OBD-II general scan tool.</p> <p>NOTE: • Subaru Select Monitor For detailed operation procedure, refer to the "READ CURRENT DATA FOR ENGINE". <Ref. to EN(H4DOTC)(diag)-31, Subaru Select Monitor.> • OBD-II general scan tool For detailed operation procedures, refer to the OBD-II General Scan Tool Instruction Manual.</p> | <p>Is the voltage less than 0.1 V?</p> | <p>Go to step 2.</p> | <p>Even if malfunction indicator light lights up, the circuit has returned to a normal condition at this time. A temporary poor contact of the connector may be the cause.</p> <p>NOTE: In this case, repair the following: • Poor contact in throttle position sensor connector • Poor contact in ECM connector • Poor contact in coupling connector</p> |
| <p>2 CHECK INPUT SIGNAL FOR ECM. Measure the voltage between ECM connector and chassis ground while tumble generator valve is fully closed.</p> <p>Connector & terminal (B135) No. 9 (+) — Chassis ground (-):</p> | <p>Is the voltage more than 4.5 V?</p> | <p>Go to step 4.</p> | <p>Go to step 3.</p> |
| <p>3 CHECK INPUT SIGNAL FOR ECM. Measure the voltage between ECM connector and chassis ground.</p> <p>Connector & terminal (B135) No. 9 (+) — Chassis ground (-):</p> | <p>Shake the ECM harness and connector, while monitoring value of voltage meter. Does the voltage change?</p> | <p>Repair the poor contact in ECM connector.</p> | <p>Contact your SOA Service Center.</p> <p>NOTE: Inspection by DTM is required, because probable cause is deterioration of multiple parts.</p> |
| <p>4 CHECK INPUT SIGNAL FOR ECM. Measure the voltage between ECM connector and chassis ground.</p> <p>Connector & terminal (B135) No. 13 (+) — Chassis ground (-):</p> | <p>Is the voltage less than 0.1 V?</p> | <p>Go to step 6.</p> | <p>Go to step 5.</p> |
| <p>5 CHECK INPUT SIGNAL FOR ECM. (USING SUBARU SELECT MONITOR) Measure the voltage between ECM connector and chassis ground.</p> | <p>Shake the ECM harness and connector, while monitoring value of Subaru Select Monitor. Does the voltage change?</p> | <p>Repair the poor contact in ECM connector.</p> | <p>Go to step 6.</p> |

Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

| Step | Check | Yes | No |
|---|---|---|---|
| <p>6</p> <p>CHECK HARNESS BETWEEN ECM AND TUMBLE GENERATOR VALVE POSITION SENSOR CONNECTOR.</p> <p>1) Turn the ignition switch to OFF. 2) Disconnect the connectors from tumble generator valve position sensor. 3) Turn the ignition switch to ON. 4) Measure the voltage between tumble generator valve position sensor connector and engine ground.</p> <p>Connector & terminal (E50) No. 1 (+) — Engine ground (-):</p> | <p>Is the voltage more than 4.5 V?</p> | <p>Go to step 7.</p> | <p>Repair the harness and connector.</p> <p>NOTE: In this case, repair the following:</p> <ul style="list-style-type: none"> • Open circuit in harness between tumble generator valve position sensor and ECM connector • Poor contact in tumble generator valve position sensor connector • Poor contact in ECM connector • Poor contact in coupling connector • Poor contact in joint connector |
| <p>7</p> <p>CHECK HARNESS BETWEEN ECM AND TUMBLE GENERATOR VALVE POSITION SENSOR CONNECTOR.</p> <p>1) Turn the ignition switch to OFF. 2) Measure the resistance of harness between ECM connector and tumble generator valve position sensor connector.</p> <p>Connector & terminal (B135) No. 13 — (E50) No. 3:</p> | <p>Is the resistance less than 1 Ω?</p> | <p>Go to step 8.</p> | <p>Repair the harness and connector.</p> <p>NOTE: In this case, repair the following:</p> <ul style="list-style-type: none"> • Open circuit in harness between tumble generator valve position sensor and ECM connector • Poor contact in ECM connector • Poor contact in tumble generator valve position sensor connector • Poor contact in coupling connector |
| <p>8</p> <p>CHECK HARNESS BETWEEN ECM AND TUMBLE GENERATOR VALVE POSITION SENSOR CONNECTOR.</p> <p>Measure the resistance of harness between tumble generator valve position sensor connector and engine ground.</p> <p>Connector & terminal (E50) No. 3 — Engine ground:</p> | <p>Is the resistance more than 1 MΩ?</p> | <p>Go to step 9.</p> | <p>Repair the ground short circuit in harness between tumble generator valve position sensor and ECM connector.</p> |
| <p>9</p> <p>CHECK POOR CONTACT.</p> <p>Check poor contact in tumble generator valve position sensor connector.</p> | <p>Is there poor contact in tumble generator valve position sensor connector?</p> | <p>Repair the poor contact in tumble generator valve position sensor connector.</p> | <p>Replace the tumble generator valve position sensor. <Ref. to FU(H4DOTC)-40, Tumble Generator Valve Position Sensor.></p> |

Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

CZ:DTC P1087 TUMBLE GENERATED VALVE POSITION SENSOR 2 CIRCUIT HIGH

DTC DETECTING CONDITION:

- Immediately at fault recognition
- GENERAL DESCRIPTION <Ref. to GD(H4DOTC)-208, DTC P1087 TUMBLE GENERATED VALVE POSITION SENSOR 2 CIRCUIT HIGH, Diagnostic Trouble Code (DTC) Detecting Criteria.>


TROUBLE SYMPTOM:

- Erroneous idling
- Engine stalls.
- Poor driving performance

CAUTION:

After repair or replacement of faulty parts, conduct Clear Memory Mode <Ref. to EN(H4DOTC)(diag)-46, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(H4DOTC)(diag)-39, PROCEDURE, Inspection Mode.>.

WIRING DIAGRAM:



EN-01320

Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

| Step | Check | Yes | No |
|---|---|---|--|
| <p>1</p> <p>CHECK CURRENT DATA.</p> <p>1) Start the engine.</p> <p>2) Read the data of throttle position sensor signal using Subaru Select Monitor or OBD-II general scan tool.</p> <p>NOTE:</p> <ul style="list-style-type: none"> • Subaru Select Monitor <p>For detailed operation procedure, refer to the "READ CURRENT DATA FOR ENGINE". <Ref. to EN(H4DOTC)(diag)-31, Subaru Select Monitor.></p> <ul style="list-style-type: none"> • OBD-II general scan tool <p>For detailed operation procedures, refer to the OBD-II General Scan Tool Instruction Manual.</p> | <p>Is the voltage more than 4.9 V?</p> | <p>Go to step 2.</p> | <p>Even if malfunction indicator light lights up, the circuit has returned to a normal condition at this time. A temporary poor contact of the connector may be the cause.</p> <p>NOTE:</p> <p>In this case, repair the following:</p> <ul style="list-style-type: none"> • Poor contact in tumble generator valve position sensor connector • Poor contact in ECM connector • Poor contact in coupling connector |
| <p>2</p> <p>CHECK HARNESS BETWEEN TUMBLE GENERATOR VALVE POSITION SENSOR AND ECM CONNECTOR.</p> <p>1) Turn the ignition switch to OFF.</p> <p>2) Disconnect the connector from throttle position sensor.</p> <p>3) Measure the resistance of harness between throttle position sensor connector and engine ground.</p> <p>Connector & terminal (E50) No. 2 — Engine ground:</p> | <p>Is the resistance less than 5 Ω?</p> | <p>Go to step 3.</p> | <p>Repair the harness and connector.</p> <p>NOTE:</p> <p>In this case, repair the following:</p> <ul style="list-style-type: none"> • Open circuit in harness between tumble generator valve position sensor and ECM connector • Poor contact in coupling connector • Poor contact in joint connector |
| <p>3</p> <p>CHECK HARNESS BETWEEN THROTTLE POSITION SENSOR AND ECM CONNECTOR.</p> <p>1) Turn the ignition switch to ON.</p> <p>2) Measure the voltage between throttle position sensor connector and engine ground.</p> <p>Connector & terminal (E50) No. 3 (+) — Engine ground (-):</p> | <p>Is the voltage more than 4.9 V?</p> | <p>Repair the battery short circuit in harness between tumble generator valve position sensor and ECM connector. After repair, replace the ECM. <Ref. to FU(H4DOTC)-48, Engine Control Module (ECM).></p> | <p>Replace the tumble generator valve position sensor. <Ref. to FU(H4DOTC)-40, Tumble Generator Valve Position Sensor.></p> |

Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

DA:DTC P1088 TUMBLE GENERATED VALVE POSITION SENSOR 1 CIRCUIT LOW

DTC DETECTING CONDITION:

- Immediately at fault recognition
- GENERAL DESCRIPTION <Ref. to GD(H4DOTC)-210, DTC P1088 TUMBLE GENERATED VALVE POSITION SENSOR 1 CIRCUIT LOW, Diagnostic Trouble Code (DTC) Detecting Criteria.>


TROUBLE SYMPTOM:

- Erroneous idling
- Engine stalls.
- Poor driving performance

CAUTION:

After repair or replacement of faulty parts, conduct Clear Memory Mode <Ref. to EN(H4DOTC)(diag)-46, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(H4DOTC)(diag)-39, PROCEDURE, Inspection Mode.>.

WIRING DIAGRAM:



EN-01322

Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

| Step | Check | Yes | No |
|---|--|---|---|
| <p>1</p> <p>CHECK CURRENT DATA. 1) Start the engine. 2) Read the data of tumble generator valve position sensor signal using Subaru Select Monitor or OBD-II general scan tool.</p> <p>NOTE: • Subaru Select Monitor For detailed operation procedure, refer to the "READ CURRENT DATA FOR ENGINE". <Ref. to EN(H4DOTC)(diag)-31, Subaru Select Monitor.> • OBD-II general scan tool For detailed operation procedures, refer to the OBD-II General Scan Tool Instruction Manual.</p> | Is the voltage less than 0.1 V? | Go to step 2. | <p>Even if malfunction indicator light lights up, the circuit has returned to a normal condition at this time. A temporary poor contact of the connector may be the cause.</p> <p>NOTE: In this case, repair the following: • Poor contact in tumble generator valve position sensor connector • Poor contact in ECM connector • Poor contact in coupling connector</p> |
| <p>2</p> <p>CHECK INPUT SIGNAL FOR ECM. Measure the voltage between ECM connector and chassis ground while throttle valve is fully closed.</p> <p>Connector & terminal (B135) No. 9 (+) — Chassis ground (-):</p> | Is the voltage more than 4.5 V? | Go to step 4. | Go to step 3. |
| <p>3</p> <p>CHECK INPUT SIGNAL FOR ECM. Measure the voltage between ECM connector and chassis ground.</p> <p>Connector & terminal (B135) No. 9 (+) — Chassis ground (-):</p> | Shake the ECM harness and connector, while monitoring value of voltage meter. Does the voltage change? | Repair the poor contact in ECM connector. | <p>Contact your SOA Service Center.</p> <p>NOTE: Inspection by DTM is required, because probable cause is deterioration of multiple parts.</p> |
| <p>4</p> <p>CHECK INPUT SIGNAL FOR ECM. Measure the voltage between ECM connector and chassis ground.</p> <p>Connector & terminal (B135) No. 23 (+) — Chassis ground (-):</p> | Is the voltage less than 0.1 V? | Go to step 6. | Go to step 5. |
| <p>5</p> <p>CHECK INPUT SIGNAL FOR ECM. (USING SUBARU SELECT MONITOR) Measure the voltage between ECM connector and chassis ground.</p> | Shake the ECM harness and connector, while monitoring value of Subaru Select Monitor. Does the voltage change? | Repair the poor contact in ECM connector. | Go to step 6. |

Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

| Step | Check | Yes | No |
|---|---|---|--|
| <p>6</p> <p>CHECK HARNESS BETWEEN ECM AND TUMBLE GENERATOR VALVE POSITION SENSOR CONNECTOR.</p> <p>1) Turn the ignition switch to OFF. 2) Disconnect the connectors from throttle position sensor. 3) Turn the ignition switch to ON. 4) Measure the voltage between throttle position sensor connector and engine ground.</p> <p>Connector & terminal (E54) No. 1 (+) — Engine ground (-):</p> | <p>Is the voltage more than 4.5 V?</p> | <p>Go to step 7.</p> | <p>Repair the harness and connector.</p> <p>NOTE: In this case, repair the following:</p> <ul style="list-style-type: none"> • Open circuit in harness between tumble generator valve position sensor and ECM connector • Poor contact in throttle position sensor connector • Poor contact in ECM connector • Poor contact in coupling connector • Poor contact in joint connector |
| <p>7</p> <p>CHECK HARNESS BETWEEN ECM AND TUMBLE GENERATOR VALVE POSITION SENSOR CONNECTOR.</p> <p>1) Turn the ignition switch to OFF. 2) Measure the resistance of harness between ECM connector and throttle position sensor connector.</p> <p>Connector & terminal (B135) No. 23 — (E54) No. 3:</p> | <p>Is the resistance less than 1 Ω?</p> | <p>Go to step 8.</p> | <p>Repair the harness and connector.</p> <p>NOTE: In this case, repair the following:</p> <ul style="list-style-type: none"> • Open circuit in harness between tumble generator valve position sensor and ECM connector • Poor contact in ECM connector • Poor contact in tumble generator valve position sensor connector • Poor contact in coupling connector |
| <p>8</p> <p>CHECK HARNESS BETWEEN ECM AND THROTTLE POSITION SENSOR CONNECTOR.</p> <p>Measure the resistance of harness between tumble generator valve position sensor connector and engine ground.</p> <p>Connector & terminal (E54) No. 3 — Engine ground:</p> | <p>Is the resistance more than 1 MΩ?</p> | <p>Go to step 9.</p> | <p>Repair the ground short circuit in harness between tumble generator valve position sensor and ECM connector.</p> |
| <p>9</p> <p>CHECK POOR CONTACT.</p> <p>Check poor contact in tumble generator valve position sensor connector.</p> | <p>Is there poor contact in tumble generator valve position sensor connector?</p> | <p>Repair the poor contact in tumble generator valve position sensor connector.</p> | <p>Replace the tumble generator valve position sensor. <Ref. to FU(H4DOTC)-40, Tumble Generator Valve Position Sensor.></p> |

Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

DB:DTC P1089 TUMBLE GENERATED VALVE POSITION SENSOR 1 CIRCUIT HIGH

DTC DETECTING CONDITION:

- Immediately at fault recognition
- GENERAL DESCRIPTION <Ref. to GD(H4DOTC)-212, DTC P1089 TUMBLE GENERATED VALVE POSITION SENSOR 1 CIRCUIT HIGH, Diagnostic Trouble Code (DTC) Detecting Criteria.>


TROUBLE SYMPTOM:

- Erroneous idling
- Engine stalls.
- Poor driving performance

CAUTION:

After repair or replacement of faulty parts, conduct Clear Memory Mode <Ref. to EN(H4DOTC)(diag)-46, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(H4DOTC)(diag)-39, PROCEDURE, Inspection Mode.>.

WIRING DIAGRAM:



EN-01322

Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

| Step | Check | Yes | No |
|---|---|--|--|
| <p>1</p> <p>CHECK CURRENT DATA.</p> <p>1) Start the engine.</p> <p>2) Read the data of tumble generator valve position sensor signal using Subaru Select Monitor or OBD-II general scan tool.</p> <p>NOTE:</p> <ul style="list-style-type: none"> • Subaru Select Monitor <p>For detailed operation procedure, refer to the "READ CURRENT DATA FOR ENGINE". <Ref. to EN(H4DOTC)(diag)-31, Subaru Select Monitor.></p> <ul style="list-style-type: none"> • OBD-II general scan tool <p>For detailed operation procedures, refer to the OBD-II General Scan Tool Instruction Manual.</p> | <p>Is the voltage more than 4.9 V?</p> | <p>Go to step 2.</p> | <p>Even if malfunction indicator light lights up, the circuit has returned to a normal condition at this time. A temporary poor contact of the connector may be the cause.</p> <p>NOTE:</p> <p>In this case, repair the following:</p> <ul style="list-style-type: none"> • Poor contact in tumble generator valve position sensor connector • Poor contact in ECM connector • Poor contact in coupling connector |
| <p>2</p> <p>CHECK HARNESS BETWEEN TUMBLE GENERATOR VALVE POSITION SENSOR AND ECM CONNECTOR.</p> <p>1) Turn the ignition switch to OFF.</p> <p>2) Disconnect the connector from throttle position sensor.</p> <p>3) Measure the resistance of harness between tumble generator valve position sensor connector and engine ground.</p> <p>Connector & terminal (E54) No. 2 — Engine ground:</p> | <p>Is the resistance less than 5 Ω?</p> | <p>Go to step 3.</p> | <p>Repair the harness and connector.</p> <p>NOTE:</p> <p>In this case, repair the following:</p> <ul style="list-style-type: none"> • Open circuit in harness between tumble generator valve position sensor and ECM connector • Poor contact in coupling connector • Poor contact in joint connector |
| <p>3</p> <p>CHECK HARNESS BETWEEN TUMBLE GENERATOR VALVE POSITION SENSOR AND ECM CONNECTOR.</p> <p>1) Turn the ignition switch to ON.</p> <p>2) Measure the voltage between throttle position sensor connector and engine ground.</p> <p>Connector & terminal (E54) No. 3 (+) — Engine ground (-):</p> | <p>Is the voltage more than 4.9 V?</p> | <p>Repair the battery short circuit in harness between tumble generator valve position sensor and ECM connector. After repair, replace the ECM.</p> <p><Ref. to FU(H4DOTC)-48, Engine Control Module (ECM).></p> | <p>Replace the tumble generator valve position sensor.</p> <p><Ref. to FU(H4DOTC)-40, Tumble Generator Valve Position Sensor.></p> |

Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

DC:DTC P1090 TUMBLE GENERATED VALVE SYSTEM 1 (VALVE OPEN)

DTC DETECTING CONDITION:

- Immediately at fault recognition
- GENERAL DESCRIPTION <Ref. to GD(H4DOTC)-214, DTC P1090 TUMBLE GENERATED VALVE SYSTEM 1 (VALVE OPEN), Diagnostic Trouble Code (DTC) Detecting Criteria.>

CAUTION:

After repair or replacement of faulty parts, conduct Clear Memory Mode <Ref. to EN(H4DOTC)(diag)-46, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(H4DOTC)(diag)-39, PROCEDURE, Inspection Mode.>.

| Step | Check | Yes | No |
|---|---|---|-----------------------------------|
| 1 CHECK ANY OTHER DTC ON DISPLAY. | Is any other DTC displayed? | Inspect the relevant DTC using "List of Diagnostic Trouble Code (DTC)". <Ref. to EN(H4DOTC)(diag)-71, List of Diagnostic Trouble Code (DTC).> | Go to step 2. |
| 2 CHECK TUMBLE GENERATOR VALVE RH. 1) Remove the tumble generator valve assembly. 2) Check the tumble generator valve body. | Does the tumble generator valve move smoothly? (No dirt or foreign materials clogged) | Replace the tumble generator valve assembly. <Ref. to FU(H4DOTC)-39, Tumble Generator Valve Assembly.> | Clean the tumble generator valve. |

Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

DD:DTC P1091 TUMBLE GENERATED VALVE SYSTEM 1 (VALVE CLOSE)

DTC DETECTING CONDITION:

- Immediately at fault recognition
- GENERAL DESCRIPTION <Ref. to GD(H4DOTC)-215, DTC P1091 TUMBLE GENERATED VALVE SYSTEM 1 (VALVE CLOSE), Diagnostic Trouble Code (DTC) Detecting Criteria.>

CAUTION:

After repair or replacement of faulty parts, conduct Clear Memory Mode <Ref. to EN(H4DOTC)(diag)-46, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(H4DOTC)(diag)-39, PROCEDURE, Inspection Mode.>.

| Step | Check | Yes | No |
|---|---|--|-----------------------------------|
| 1 CHECK ANY OTHER DTC ON DISPLAY. | Is any other DTC displayed? | Inspect the relevant DTC using "List of Diagnostic Trouble Code (DTC)" <Ref. to EN(H4DOTC)(diag)-71, List of Diagnostic Trouble Code (DTC).> | Go to step 2. |
| 2 CHECK TUMBLE GENERATOR VALVE RH. 1) Remove the tumble generator valve assembly. 2) Check the tumble generator valve body. | Does the tumble generator valve move smoothly? (No dirt or foreign materials clogged) | Replace the tumble generator valve assembly. <Ref. to FU(H4DOTC)-39, Tumble Generator Valve Assembly.> | Clean the tumble generator valve. |

Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

DE:DTC P1092 TUMBLE GENERATED VALVE SYSTEM 2 (VALVE OPEN)

DTC DETECTING CONDITION:

- Immediately at fault recognition
- GENERAL DESCRIPTION <Ref. to GD(H4DOTC)-216, DTC P1092 TUMBLE GENERATED VALVE SYSTEM 2 (VALVE OPEN), Diagnostic Trouble Code (DTC) Detecting Criteria.>

CAUTION:

After repair or replacement of faulty parts, conduct Clear Memory Mode <Ref. to EN(H4DOTC)(diag)-46, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(H4DOTC)(diag)-39, PROCEDURE, Inspection Mode.>.

| Step | Check | Yes | No |
|---|---|---|-----------------------------------|
| 1 CHECK ANY OTHER DTC ON DISPLAY. | Is any other DTC displayed? | Inspect the relevant DTC using "List of Diagnostic Trouble Code (DTC)". <Ref. to EN(H4DOTC)(diag)-71, List of Diagnostic Trouble Code (DTC).> | Go to step 2. |
| 2 CHECK TUMBLE GENERATOR VALVE RH. 1) Remove the tumble generator valve assembly. 2) Check the tumble generator valve body. | Does the tumble generator valve move smoothly? (No dirt or foreign materials clogged) | Replace the tumble generator valve assembly. <Ref. to FU(H4DOTC)-39, Tumble Generator Valve Assembly.> | Clean the tumble generator valve. |

Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

DF:DTC P1093 TUMBLE GENERATED VALVE SYSTEM 2 (VALVE CLOSE)

DTC DETECTING CONDITION:

- Immediately at fault recognition
- GENERAL DESCRIPTION <Ref. to GD(H4DOTC)-217, DTC P1093 TUMBLE GENERATED VALVE SYSTEM 2 (VALVE CLOSE), Diagnostic Trouble Code (DTC) Detecting Criteria.>

CAUTION:

After repair or replacement of faulty parts, conduct Clear Memory Mode <Ref. to EN(H4DOTC)(diag)-46, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(H4DOTC)(diag)-39, PROCEDURE, Inspection Mode.>.

| Step | Check | Yes | No |
|---|---|---|-----------------------------------|
| 1 CHECK ANY OTHER DTC ON DISPLAY. | Is any other DTC displayed? | Inspect the relevant DTC using "List of Diagnostic Trouble Code (DTC)". <Ref. to EN(H4DOTC)(diag)-71, List of Diagnostic Trouble Code (DTC).> | Go to step 2. |
| 2 CHECK TUMBLE GENERATOR VALVE RH. 1) Remove the tumble generator valve assembly. 2) Check the tumble generator valve body. | Does the tumble generator valve move smoothly? (No dirt or foreign materials clogged) | Replace the tumble generator valve assembly. <Ref. to FU(H4DOTC)-39, Tumble Generator Valve Assembly.> | Clean the tumble generator valve. |

Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

DG:DTC P1094 TUMBLE GENERATED VALVE SIGNAL 1 CIRCUIT MALFUNCTION (OPEN)


DTC DETECTING CONDITION:

- Immediately at fault recognition
- GENERAL DESCRIPTION <Ref. to GD(H4DOTC)-218, DTC P1094 TUMBLE GENERATED VALVE SIGNAL 1 CIRCUIT MALFUNCTION (OPEN), Diagnostic Trouble Code (DTC) Detecting Criteria.>

CAUTION:

After repair or replacement of faulty parts, conduct Clear Memory Mode <Ref. to EN(H4DOTC)(diag)-46, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(H4DOTC)(diag)-39, PROCEDURE, Inspection Mode.>.

WIRING DIAGRAM:



EN-01631

Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

| Step | Check | Yes | No |
|--|--|--|---|
| <p>1</p> <p>CHECK HARNESS BETWEEN ECM AND TUMBLE GENERATOR VALVE ACTUATOR CONNECTOR.</p> <p>1) Turn the ignition switch to OFF. 2) Disconnect the connector from tumble generator valve and ECM connector. 3) Measure the resistance between tumble generator valve actuator and ECM connector.</p> <p>Connector & terminal (E55) No. 1 — (B136) No. 4: (E55) No. 2 — (B136) No. 5:</p> | <p>Is the resistance less than 1 Ω?</p> | <p>Go to step 2.</p> | <p>Repair the open circuit between ECM and tumble generator valve connector.</p> <p>NOTE: In this case, repair the following:</p> <ul style="list-style-type: none"> • Open circuit in harness between ECM and tumble generator valve actuator connector. • Poor contact in coupling connector. |
| <p>2</p> <p>CHECK POOR CONTACT. Check poor contact in tumble generator valve actuator connector.</p> | <p>Is there poor contact in tumble generator valve actuator connector?</p> | <p>Repair the poor contact in tumble generator valve actuator connector.</p> | <p>Replace the tumble generator valve Actuator. <Ref. to FU(H4DOTC)-41, Tumble Generator Valve Actuator.></p> |

Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

DH:DTC P1095 TUMBLE GENERATED VALVE SIGNAL 1 CIRCUIT MALFUNCTION (SHORT)


DTC DETECTING CONDITION:

- Immediately at fault recognition
- GENERAL DESCRIPTION <Ref. to GD(H4DOTC)-220, DTC P1095 TUMBLE GENERATED VALVE SIGNAL 1 CIRCUIT MALFUNCTION (SHORT), Diagnostic Trouble Code (DTC) Detecting Criteria.>

CAUTION:

After repair or replacement of faulty parts, conduct Clear Memory Mode <Ref. to EN(H4DOTC)(diag)-46, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(H4DOTC)(diag)-39, PROCEDURE, Inspection Mode.>.

WIRING DIAGRAM:



EN-01631

Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

| Step | Check | Yes | No |
|--|-------------------------------|--|---|
| <p>1</p> <p>CHECK HARNESS BETWEEN ECM AND TUMBLE GENERATOR VALVE ACTUATOR CONNECTOR.</p> <p>1) Turn the ignition switch to OFF. 2) Disconnect the connector from tumble generator valve connector. 3) Measure the voltage between tumble generator valve actuator and chassis ground.</p> <p>Connector & terminal (E55) No. 1 (+) — Chassis ground (-): (E55) No. 2 (+) — Chassis ground (-):</p> | Is the voltage less than 5 V? | Replace the tumble generator valve Actuator. <Ref. to FU(H4DOTC)-41, Tumble Generator Valve Actuator.> | Repair the battery short circuit between ECM and tumble generator valve actuator. |

Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

DI: DTC P1096 TUMBLE GENERATED VALVE SIGNAL 2 CIRCUIT MALFUNCTION (OPEN)


DTC DETECTING CONDITION:

- Immediately at fault recognition
- GENERAL DESCRIPTION <Ref. to GD(H4DOTC)-222, DTC P1096 TUMBLE GENERATED VALVE SIGNAL 2 CIRCUIT MALFUNCTION (OPEN), Diagnostic Trouble Code (DTC) Detecting Criteria.>

CAUTION:

After repair or replacement of faulty parts, conduct Clear Memory Mode <Ref. to EN(H4DOTC)(diag)-46, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(H4DOTC)(diag)-39, PROCEDURE, Inspection Mode.>.

WIRING DIAGRAM:



EN-01632

Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

| Step | Check | Yes | No |
|--|--|--|---|
| <p>1</p> <p>CHECK HARNESS BETWEEN ECM AND TUMBLE GENERATOR VALVE ACTUATOR CONNECTOR.</p> <p>1) Turn the ignition switch to OFF. 2) Disconnect the connector from tumble generator valve and ECM connector. 3) Measure the resistance between tumble generator valve actuator and ECM connector.</p> <p>Connector & terminal (E51) No. 1 — (B136) No. 10: (E51) No. 2 — (B136) No. 11:</p> | <p>Is the resistance less than 1 Ω?</p> | <p>Go to step 2.</p> | <p>Repair the open circuit between ECM and tumble generator valve connector.</p> <p>NOTE: In this case, repair the following:</p> <ul style="list-style-type: none"> • Open circuit in harness between ECM and tumble generator valve actuator connector. • Poor contact in coupling connector. |
| <p>2</p> <p>CHECK POOR CONTACT.</p> <p>Check poor contact in tumble generator valve actuator connector.</p> | <p>Is there poor contact in tumble generator valve actuator connector?</p> | <p>Repair the poor contact in tumble generator valve actuator connector.</p> | <p>Replace the tumble generator valve Actuator. <Ref. to FU(H4DOTC)-41, Tumble Generator Valve Actuator.></p> |

Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

DJ:DTC P1097 TUMBLE GENERATED VALVE SIGNAL 2 CIRCUIT MALFUNCTION (SHORT)


DTC DETECTING CONDITION:

- Immediately at fault recognition
- GENERAL DESCRIPTION <Ref. to GD(H4DOTC)-224, DTC P1097 TUMBLE GENERATED VALVE SIGNAL 2 CIRCUIT MALFUNCTION (SHORT), Diagnostic Trouble Code (DTC) Detecting Criteria.>

CAUTION:

After repair or replacement of faulty parts, conduct Clear Memory Mode <Ref. to EN(H4DOTC)(diag)-46, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(H4DOTC)(diag)-39, PROCEDURE, Inspection Mode.>.

WIRING DIAGRAM:



EN-01632

Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

| Step | Check | Yes | No |
|---|-------------------------------|--|---|
| 1 CHECK HARNESS BETWEEN ECM AND TUMBLE GENERATOR VALVE ACTUATOR CONNECTOR. 1) Turn the ignition switch to OFF. 2) Disconnect the connector from tumble generator valve connector. 3) Measure the voltage between tumble generator valve actuator and chassis ground. Connector & terminal <i>(E51) No. 1 (+) — Chassis ground (-):</i> <i>(E51) No. 2 (+) — Chassis ground (-):</i> | Is the voltage less than 5 V? | Replace the tumble generator valve Actuator. <Ref. to FU(H4DOTC)-41, Tumble Generator Valve Actuator.> | Repair the battery short circuit between ECM and tumble generator valve actuator. |

DK:DTC P1110 ATMOSPHERIC PRESSURE SENSOR CIRCUIT MALFUNCTION (LOW INPUT)

DTC DETECTING CONDITION:

- Immediately at fault recognition
- GENERAL DESCRIPTION <Ref. to GD(H4DOTC)-226, DTC P1110 ATMOSPHERIC PRESSURE SENSOR CIRCUIT MALFUNCTION (LOW INPUT), Diagnostic Trouble Code (DTC) Detecting Criteria.>

CAUTION:

After repair or replacement of faulty parts, conduct Clear Memory Mode <Ref. to EN(H4DOTC)(diag)-46, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(H4DOTC)(diag)-39, PROCEDURE, Inspection Mode.>.

| Step | Check | Yes | No |
|--|--|---|---------------------------|
| 1 CHECK ANY OTHER DTC ON DISPLAY. | Does the Subaru Select Monitor or OBD-II general scan tool indicate DTC P1110? | Replace the ECM. <Ref. to FU(H4DOTC)-48, Engine Control Module (ECM).> NOTE: Atmospheric pressure sensor is built into ECM. | A temporary poor contact. |

Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

DL:DTC P1111 ATMOSPHERIC PRESSURE SENSOR CIRCUIT MALFUNCTION (HIGH INPUT)

DTC DETECTING CONDITION:

- Immediately at fault recognition
- GENERAL DESCRIPTION <Ref. to GD(H4DOTC)-227, DTC P1111 ATMOSPHERIC PRESSURE SENSOR CIRCUIT MALFUNCTION (HIGH INPUT), Diagnostic Trouble Code (DTC) Detecting Criteria.>

CAUTION:

After repair or replacement of faulty parts, conduct Clear Memory Mode <Ref. to EN(H4DOTC)(diag)-46, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(H4DOTC)(diag)-39, PROCEDURE, Inspection Mode.>.

| Step | Check | Yes | No |
|--------------------------------------|--|---|------------------------------|
| 1 CHECK ANY OTHER DTC ON DISPLAY. | Does the Subaru Select Monitor or OBD-II general scan tool indicate DTC P1111? | Replace the ECM. <Ref. to FU(H4DOTC)-48, Engine Control Module (ECM).> NOTE: Atmospheric pres- sure sensor is built into ECM. | A temporary poor contact. |

Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

DM:DTC P1134 A/F SENSOR MICRO-COMPUTER PROBLEM


DTC DETECTING CONDITION:

- Immediately at fault recognition
- GENERAL DESCRIPTION <Ref. to GD(H4DOTC)-228, DTC P1134 A/F SENSOR MICRO-COMPUTER PROBLEM, Diagnostic Trouble Code (DTC) Detecting Criteria.>

CAUTION:

After repair or replacement of faulty parts, conduct Clear Memory Mode <Ref. to EN(H4DOTC)(diag)-46, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(H4DOTC)(diag)-39, PROCEDURE, Inspection Mode.>.

WIRING DIAGRAM:



EN-01610

| Step | Check | Yes | No |
|------|--|---|---------------------------|
| 1 | CHECK ANY OTHER DTC ON DISPLAY. Does the Subaru Select Monitor or OBD-II general scan tool indicate DTC P1134? | Replace the ECM. <Ref. to FU(H4DOTC)-48, Engine Control Module (ECM).> | A temporary poor contact. |

Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

DN:DTC P1152 O₂ SENSOR CIRCUIT RANGE/PERFORMANCE (LOW) (BANK1 SENSOR1)


DTC DETECTING CONDITION:

- Two consecutive driving cycles with fault
- GENERAL DESCRIPTION <Ref. to GD(H4DOTC)-230, DTC P1152 O₂ SENSOR CIRCUIT RANGE/PERFORMANCE (LOW) (BANK1 SENSOR1), Diagnostic Trouble Code (DTC) Detecting Criteria.>

CAUTION:

After repair or replacement of faulty parts, conduct Clear Memory Mode <Ref. to EN(H4DOTC)(diag)-46, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(H4DOTC)(diag)-39, PROCEDURE, Inspection Mode.>.

WIRING DIAGRAM:



EN-01610

Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

| Step | Check | Yes | No |
|---|--|--|--|
| <p>1</p> <p>CHECK HARNESS BETWEEN ECM AND FRONT OXYGEN (A/F) SENSOR CONNECTOR.</p> <p>1) Turn the ignition switch to OFF. 2) Disconnect the connectors from ECM and front oxygen (A/F) sensor connector. 3) Measure the resistance of harness between ECM and front oxygen (A/F) sensor connector.</p> <p>Connector & terminal (B84) No. 29 — (B18) No. 3: (B84) No. 19 — (B18) No. 4:</p> | <p>Is the resistance less than 1 Ω?</p> | <p>Go to step 2.</p> | <p>Repair the harness and connector.</p> <p>NOTE: In this case, repair the following:</p> <ul style="list-style-type: none"> • Open circuit in harness between ECM and front oxygen (A/F) sensor connector • Poor contact in front oxygen (A/F) sensor connector • Poor contact in ECM connector |
| <p>2</p> <p>CHECK POOR CONTACT.</p> <p>Check poor contact in front oxygen (A/F) sensor connector.</p> | <p>Is there poor contact in front oxygen (A/F) sensor connector?</p> | <p>Repair the poor contact in front oxygen (A/F) sensor connector.</p> | <p>Replace the front oxygen (A/F) sensor. <Ref. to FU(H4DOTC)-43, Front Oxygen (A/F) Sensor.></p> |

Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

DO:DTC P1153 O₂ SENSOR CIRCUIT RANGE/PERFORMANCE (HIGH) (BANK1 SENSOR1)


DTC DETECTING CONDITION:

- Two consecutive driving cycles with fault
- GENERAL DESCRIPTION <Ref. to GD(H4DOTC)-233, DTC P1153 O₂ SENSOR CIRCUIT RANGE/PERFORMANCE (HIGH) (BANK1 SENSOR1), Diagnostic Trouble Code (DTC) Detecting Criteria.>

CAUTION:

After repair or replacement of faulty parts, conduct Clear Memory Mode <Ref. to EN(H4DOTC)(diag)-46, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(H4DOTC)(diag)-39, PROCEDURE, Inspection Mode.>.

WIRING DIAGRAM:



EN-01610

Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

| Step | Check | Yes | No |
|---|-----------------------------------|---|--|
| 1 CHECK HARNESS BETWEEN ECM AND FRONT OXYGEN (A/F) SENSOR CONNECTOR. 1) Turn the ignition switch to OFF. 2) Disconnect the connector from ECM. 3) Measure the resistance of harness between ECM connector and chassis ground. <i>Connector & terminal</i> <i>(B84) No. 19 — Chassis ground:</i> | Is the resistance more than 1 MΩ? | Repair the ground short circuit in harness between ECM and front oxygen (A/F) sensor connector. | Go to step 2. |
| 2 CHECK HARNESS BETWEEN ECM AND FRONT OXYGEN (A/F) SENSOR CONNECTOR. Measure the resistance of harness between ECM connector and chassis ground. <i>Connector & terminal</i> <i>(B84) No. 29 — Chassis ground:</i> | Is the resistance more than 1 MΩ? | Repair the ground short circuit in harness between ECM and front oxygen (A/F) sensor connector. | Go to step 3. |
| 3 CHECK OUTPUT SIGNAL FOR ECM. 1) Connect the connector to ECM. 2) Turn the ignition switch to ON. 3) Measure the voltage between ECM connector and chassis ground. <i>Connector & terminal</i> <i>(B84) No. 19 (+) — Chassis ground (-):</i> | Is the voltage more than 4.5 V? | Go to step 4. | Go to step 5. |
| 4 CHECK OUTPUT SIGNAL FOR ECM. Measure the voltage between ECM connector and chassis ground. <i>Connector & terminal</i> <i>(B84) No. 19 (+) — Chassis ground (-):</i> | Is the voltage more than 10 V? | Repair the battery short circuit in harness between ECM and front oxygen (A/F) sensor connector. After repair, replace the ECM. <Ref. to FU(H4DOTC)-48, Engine Control Module (ECM).> | Repair the poor contact in ECM connector. |
| 5 CHECK OUTPUT SIGNAL FOR ECM. Measure the voltage between ECM connector and chassis ground. <i>Connector & terminal</i> <i>(B84) No. 29 (+) — Chassis ground (-):</i> | Is the voltage more than 4.95 V? | Go to step 6. | Replace the front oxygen (A/F) sensor. <Ref. to FU(H4DOTC)-43, Front Oxygen (A/F) Sensor.> |
| 6 CHECK OUTPUT SIGNAL FOR ECM. Measure the voltage between ECM connector and chassis ground. <i>Connector & terminal</i> <i>(B84) No. 29 (+) — Chassis ground (-):</i> | Is the voltage more than 10 V? | Repair the battery short circuit in harness between ECM and front oxygen (A/F) sensor connector. After repair, replace the ECM. <Ref. to FU(H4DOTC)-48, Engine Control Module (ECM).> | Repair the poor contact in ECM connector. |

Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

DP:DTC P1301 MISFIRE DETECTED (HIGH TEMPERATURE EXHAUST GAS)

DTC DETECTING CONDITION:

- Immediately at fault recognition
- GENERAL DESCRIPTION <Ref. to GD(H4DOTC)-236, DTC P1301 MISFIRE DETECTED (HIGH TEMPERATURE EXHAUST GAS), Diagnostic Trouble Code (DTC) Detecting Criteria.>


TROUBLE SYMPTOM:

- Erroneous idling
- Engine stalls.
- Poor driving performance

CAUTION:

After repair or replacement of faulty parts, conduct Clear Memory Mode <Ref. to EN(H4DOTC)(diag)-46, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(H4DOTC)(diag)-39, PROCEDURE, Inspection Mode.>.

WIRING DIAGRAM:



EN-01628

Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

| Step | Check | Yes | No |
|---|---|---|---|
| 1 CHECK ANY OTHER DTC. Conduct the troubleshooting for all DTC P0301, P0302, P0303 and P0304. <Ref. to EN(H4DOTC)(diag)-71, List of Diagnostic Trouble Code (DTC).> | Does failure for repair or replacement exist? | Repair or replace the failure, then replace precatalytic converter. | Contact your SOA Service Center. NOTE: Inspection by DTM is required, because probable cause is deterioration of multiple parts. |

Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

DQ:DTC P1312 EXHAUST GAS TEMPERATURE SENSOR MALFUNCTION


DTC DETECTING CONDITION:

- Immediately at fault recognition
- GENERAL DESCRIPTION <Ref. to GD(H4DOTC)-237, DTC P1312 EXHAUST GAS TEMPERATURE SENSOR MALFUNCTION, Diagnostic Trouble Code (DTC) Detecting Criteria.>

CAUTION:

After repair or replacement of faulty parts, conduct Clear Memory Mode <Ref. to EN(H4DOTC)(diag)-46, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(H4DOTC)(diag)-39, PROCEDURE, Inspection Mode.>.

WIRING DIAGRAM:



Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

| Step | Check | Yes | No |
|---|-----------------------------|---|--|
| 1 CHECK ANY OTHER DTC ON DISPLAY. | Is any other DTC displayed? | Inspect the relevant DTC using "List of Diagnostic Trouble Code (DTC)". <Ref. to EN(H4DOTC)(diag)-71, List of Diagnostic Trouble Code (DTC).> NOTE: In this case, it is not necessary to inspect DTC P1312. | Replace the exhaust gas temperature sensor. <Ref. to FU(H4DOTC)-47, Exhaust Temperature Sensor.> |

Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

DR:DTC P1400 FUEL TANK PRESSURE CONTROL SOLENOID VALVE CIRCUIT LOW


DTC DETECTING CONDITION:

- Two consecutive driving cycles with fault
- GENERAL DESCRIPTION <Ref. to GD(H4DOTC)-238, DTC P1400 FUEL TANK PRESSURE CONTROL SOLENOID VALVE CIRCUIT LOW, Diagnostic Trouble Code (DTC) Detecting Criteria.>

CAUTION:

After repair or replacement of faulty parts, conduct Clear Memory Mode <Ref. to EN(H4DOTC)(diag)-46, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(H4DOTC)(diag)-39, PROCEDURE, Inspection Mode.>.

WIRING DIAGRAM:



EN-03601

Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

| Step | Check | Yes | No |
|---|--|---------------------------------------|---|
| 1 CHECK OUTPUT SIGNAL FROM ECM. 1) Turn ignition switch to ON. 2) Measure the voltage between ECM and chassis ground. <i>Connector & terminal</i> <i>(B84) No. 22 (+) — Chassis ground (-):</i> | Is the voltage more than 10 V? | Go to step 2. | Go to step 3. |
| 2 CHECK FOR POOR CONTACT. Check for poor contact in ECM connector. | Is there poor contact in ECM connector? | Repair poor contact in ECM connector. | Contact with SOA Service Center. NOTE: Inspection by DTM is required, because probable cause is deterioration of multiple parts. |
| 3 CHECK HARNESS BETWEEN PRESSURE CONTROL SOLENOID VALVE AND ECM CONNECTOR. 1) Turn ignition switch to OFF. 2) Disconnect the connectors from pressure control solenoid valve and ECM. 3) Measure the resistance of harness between pressure control solenoid valve connector and chassis ground. <i>Connector & terminal</i> <i>(R68) No. 2 — Chassis ground:</i> | Is the resistance more than 1 M Ω ? | Go to step 4. | Repair short circuit to ground in harness between ECM and pressure control solenoid valve connector. |
| 4 CHECK HARNESS BETWEEN PRESSURE CONTROL SOLENOID VALVE AND ECM CONNECTOR. Measure the resistance of harness between ECM and pressure control solenoid valve connector. <i>Connector & terminal</i> <i>(B84) No. 22 — (R68) No. 2:</i> | Is the resistance less than 1 Ω ? | Go to step 5. | Repair harness and connector. NOTE: In this case, repair the following: <ul style="list-style-type: none"> • Open circuit in harness between ECM and pressure control solenoid valve connector • Poor contact in coupling connector |
| 5 CHECK PRESSURE CONTROL SOLENOID VALVE. Measure the resistance between pressure control solenoid valve terminals. <i>Terminals</i> <i>No. 1 — No. 2:</i> | Is the resistance 10 — 100 Ω ? | Go to step 6. | Replace the pressure control solenoid valve. <Ref. to EC(H4DOTC)-13, Pressure Control Solenoid Valve.> |

Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

| Step | Check | Yes | No |
|---|---|---|---|
| <p>6</p> <p>CHECK POWER SUPPLY TO PRESSURE CONTROL SOLENOID VALVE.</p> <p>1) Turn ignition switch to ON. 2) Measure the voltage between pressure control solenoid valve and chassis ground.</p> <p>Connector & terminal (R68) No. 1 (+) — Chassis ground (-):</p> | Is the voltage more than 10 V? | Go to step 7. | <p>Repair harness and connector.</p> <p>NOTE: In this case, repair the following:</p> <ul style="list-style-type: none"> • Open circuit in harness between main relay and pressure control solenoid valve connector • Poor contact in coupling connector • Poor contact in main relay connector |
| <p>7</p> <p>CHECK FOR POOR CONTACT.</p> <p>Check for poor contact in pressure control solenoid valve connector.</p> | Is there poor contact in pressure control solenoid valve connector? | Repair poor contact in pressure control solenoid valve connector. | <p>Contact with SOA Service Center.</p> <p>NOTE: Inspection by DTM is required, because probable cause is deterioration of multiple parts.</p> |

Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)


DS:DTC P1420 FUEL TANK PRESSURE CONTROL SOL. VALVE CIRCUIT HIGH DTC DETECTING CONDITION:

- Two consecutive driving cycles with fault
- GENERAL DESCRIPTION <Ref. to GD(H4DOTC)-240, DTC P1420 FUEL TANK PRESSURE CONTROL SOL. VALVE CIRCUIT HIGH, Diagnostic Trouble Code (DTC) Detecting Criteria.>

CAUTION:

After repair or replacement of faulty parts, conduct Clear Memory Mode <Ref. to EN(H4DOTC)(diag)-46, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(H4DOTC)(diag)-39, PROCEDURE, Inspection Mode.>.

WIRING DIAGRAM:



EN-03601

Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

| Step | Check | Yes | No |
|--|--|--|--|
| 1 CHECK INPUT SIGNAL FOR ECM. 1) Turn ignition switch to OFF. 2) Connect the test mode connector at the lower portion of instrument panel (on the driver's side). 3) Turn ignition switch to ON. 4) While operating the pressure control solenoid valve, measure voltage between ECM and chassis ground. NOTE: Pressure control solenoid valve operation can be executed using Subaru Select Monitor. For the procedure, refer to "Compulsory Valve Operation Check Mode". <Ref. to EN(H4DOTC)(diag)-47, Compulsory Valve Operation Check Mode.> Connector & terminal (B84) No. 22 (+) — Chassis ground (-): | Does the voltage value change 0 — 10 V? | Go to step 2. | The malfunction indicator light may light up, however, the circuit is returned to the normal status at the moment. In this case, repair poor contact in ECM connector. |
| 2 CHECK INPUT SIGNAL FOR ECM. 1) Turn ignition switch to ON. 2) Measure the voltage between ECM and chassis ground. Connector & terminal (B84) No. 22 (+) — Chassis ground (-): | Is the voltage more than 10 V? | Go to step 4. | Go to step 3. |
| 3 CHECK FOR POOR CONTACT. Check for poor contact in ECM connector. | Is there poor contact in ECM connector? | Repair poor contact in ECM connector. | Replace the ECM. <Ref. to FU(H4DOTC)-48, Engine Control Module (ECM).> |
| 4 CHECK HARNESS BETWEEN PRESSURE CONTROL SOLENOID VALVE AND ECM CONNECTOR. 1) Turn ignition switch to OFF. 2) Disconnect the connector from pressure control solenoid valve. 3) Turn ignition switch to ON. 4) Measure the voltage between ECM and chassis ground. Connector & terminal (B84) No. 22 (+) — Chassis ground (-): | Is the voltage more than 10 V? | Repair short circuit to battery in harness between ECM and pressure control solenoid valve connector. After repair, replace the ECM. <Ref. to FU(H4DOTC)-48, Engine Control Module (ECM).> | Go to step 5. |
| 5 CHECK PRESSURE CONTROL SOLENOID VALVE. 1) Turn ignition switch to OFF. 2) Measure the resistance between pressure control solenoid valve terminals. Terminals No. 1 — No. 2: | Is the resistance less than 1 Ω ? | Replace the pressure control solenoid valve <Ref. to EC(H4DOTC)-13, Pressure Control Solenoid Valve.> and the ECM <Ref. to FU(H4DOTC)-48, Engine Control Module (ECM).>. | Go to step 6. |
| 6 CHECK FOR POOR CONTACT. Check for poor contact in ECM connector. | Is there poor contact in ECM connector? | Repair poor contact in ECM connector. | Replace the ECM. <Ref. to FU(H4DOTC)-48, Engine Control Module (ECM).> |

Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

DT:DTC P1443 VENT CONTROL SOLENOID VALVE FUNCTION PROBLEM

DTC DETECTING CONDITION:

- Immediately at fault recognition
- GENERAL DESCRIPTION <Ref. to GD(H4DOTC)-241, DTC P1443 VENT CONTROL SOLENOID VALVE FUNCTION PROBLEM, Diagnostic Trouble Code (DTC) Detecting Criteria.>


TROUBLE SYMPTOM:

Improper fuel supply

CAUTION:

After repair or replacement of faulty parts, conduct Clear Memory Mode <Ref. to EN(H4DOTC)(diag)-46, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(H4DOTC)(diag)-39, PROCEDURE, Inspection Mode.>.

WIRING DIAGRAM:



EN-01634

Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

| Step | Check | Yes | No |
|------|---|--------------------------------|--|
| 1 | CHECK FOR OTHER DTC ON DISPLAY. | Is any other DTC displayed? | Inspect the relevant DTC using "List of Diagnostic Trouble Code (DTC)". <Ref. to EN(H4DOTC)(diag)-71, List of Diagnostic Trouble Code (DTC).> |
| 1 | CHECK FOR OTHER DTC ON DISPLAY. | Is any other DTC displayed? | Go to step 2. |
| 2 | CHECK VENT LINE HOSES. Check the following items. • Clogging of vent hoses between canister and drain valve • Clogging of vent hose between drain valve and air filter • Clogging of drain filter | Is there a fault in vent line? | Repair or replace faulty parts. Go to step 3. |
| 3 | CHECK DRAIN VALVE OPERATION. 1) Turn ignition switch to OFF. 2) Connect the test mode connector at the lower portion of instrument panel (on the driver's side). 3) Turn ignition switch to ON. 4) Operate the drain valve. NOTE: Drain valve operation can also be executed using Subaru Select Monitor. For the procedure, refer to "Compulsory Valve Operation Check Mode". <Ref. to EN(H4DOTC)(diag)-47, Compulsory Valve Operation Check Mode.> | Does the drain valve operate? | Contact with SOA Service Center. NOTE: Inspection by DTM is required, because probable cause is deterioration of multiple parts. Replace the drain valve. <Ref. to EC(H4DOTC)-19, Drain Valve.> |

Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

DU:DTC P1446 FUEL TANK SENSOR CONTROL VALVE CIRCUIT LOW


DTC DETECTING CONDITION:

- Two consecutive driving cycles with fault
- GENERAL DESCRIPTION <Ref. to GD(H4DOTC)-242, DTC P1446 FUEL TANK SENSOR CONTROL VALVE CIRCUIT LOW, Diagnostic Trouble Code (DTC) Detecting Criteria.>

CAUTION:

After repair or replacement of faulty parts, conduct Clear Memory Mode <Ref. to EN(H4DOTC)(diag)-46, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(H4DOTC)(diag)-39, PROCEDURE, Inspection Mode.>.

WIRING DIAGRAM:



EN-01635

Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

| Step | Check | Yes | No |
|---|--|---------------------------------------|---|
| 1 CHECK OUTPUT SIGNAL FROM ECM. 1) Turn ignition switch to ON. 2) Measure the voltage between ECM and chassis ground. <i>Connector & terminal</i> <i>(B84) No. 23 (+) — Chassis ground (-):</i> | Is the voltage more than 10 V? | Go to step 2. | Go to step 3. |
| 2 CHECK FOR POOR CONTACT. Check for poor contact in ECM connector. | Is there poor contact in ECM connector? | Repair poor contact in ECM connector. | The malfunction indicator light may light up, however, the circuit is returned to the normal status at the moment. (However, the possibility of poor contact still remains.) NOTE: In this case, repair the following: <ul style="list-style-type: none"> • Poor contact in fuel tank sensor control valve connector • Poor contact in ECM connector • Poor contact in coupling connector |
| 3 CHECK HARNESS BETWEEN FUEL TANK SENSOR CONTROL VALVE AND ECM CONNECTOR. 1) Turn ignition switch to OFF. 2) Disconnect the connectors from fuel tank sensor control valve and ECM. 3) Measure the resistance of harness between fuel tank sensor control valve connector and chassis ground. <i>Connector & terminal</i> <i>(R144) No. 2 — Chassis ground:</i> | Is the resistance more than 1 M Ω ? | Go to step 4. | Repair short circuit to ground in harness between ECM and fuel tank sensor control valve connector. |
| 4 CHECK HARNESS BETWEEN FUEL TANK SENSOR CONTROL VALVE AND ECM CONNECTOR. Measure the resistance of harness between ECM and fuel tank sensor control valve connector. <i>Connector & terminal</i> <i>(B84) No. 23 — (R144) No. 2:</i> | Is the resistance less than 1 Ω ? | Go to step 5. | Repair harness and connector. NOTE: In this case, repair the following: <ul style="list-style-type: none"> • Open circuit in harness between ECM and fuel tank sensor control valve connector • Poor contact in coupling connector |
| 5 CHECK FUEL TANK SENSOR CONTROL VALVE. Measure the resistance between fuel tank sensor control valve terminals. <i>Terminals</i> <i>No. 1 — No. 2:</i> | Is the resistance 10 — 100 Ω ? | Go to step 6. | Replace the fuel tank sensor control valve. <Ref. to EC(H4DOTC)-19, Drain Valve.> |

Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

| Step | Check | Yes | No |
|--|---|---|--|
| <p>6</p> <p>CHECK POWER SUPPLY TO FUEL TANK SENSOR CONTROL VALVE.</p> <p>1) Turn ignition switch to ON. 2) Measure the voltage between fuel tank sensor control valve and chassis ground.</p> <p>Connector & terminal (R144) No. 1 (+) — Chassis ground (-):</p> | <p>Is the voltage more than 10 V?</p> | <p>Go to step 7.</p> | <p>Repair harness and connector.</p> <p>NOTE: In this case, repair the following:</p> <ul style="list-style-type: none"> • Open circuit in harness between main relay and fuel tank sensor control valve • Poor contact in coupling connector • Poor contact in main relay connector |
| <p>7</p> <p>CHECK FOR POOR CONTACT.</p> <p>Check for poor contact in fuel tank sensor control valve connector.</p> | <p>Is there poor contact in fuel tank sensor control valve connector?</p> | <p>Repair poor contact in fuel tank sensor control valve connector.</p> | <p>Contact with SOA Service Center.</p> <p>NOTE: Inspection by DTM is required, because probable cause is deterioration of multiple parts.</p> |

Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

DV:DTC P1447 FUEL TANK SENSOR CONTROL VALVE CIRCUIT HIGH


DTC DETECTING CONDITION:

- Two consecutive driving cycles with fault
- GENERAL DESCRIPTION <Ref. to GD(H4DOTC)-244, DTC P1447 FUEL TANK SENSOR CONTROL VALVE CIRCUIT HIGH, Diagnostic Trouble Code (DTC) Detecting Criteria.>

CAUTION:

After repair or replacement of faulty parts, conduct Clear Memory Mode <Ref. to EN(H4DOTC)(diag)-46, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(H4DOTC)(diag)-39, PROCEDURE, Inspection Mode.>.

WIRING DIAGRAM:



EN-01635

Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

| Step | Check | Yes | No |
|---|--|---|--|
| 1 CHECK OUTPUT SIGNAL FROM ECM. 1) Turn ignition switch to ON. 2) Measure the voltage between ECM and chassis ground. Connector & terminal (B84) No. 23 (+) — Chassis ground (-): | Is the voltage more than 10 V? | Go to step 3. | Go to step 2. |
| 2 CHECK FOR POOR CONTACT. Check for poor contact in ECM connector. | Is there poor contact in ECM connector? | Repair poor contact in ECM connector. | Replace the ECM. <Ref. to FU(H4DOTC)-48, Engine Control Module (ECM).> |
| 3 CHECK HARNESS BETWEEN FUEL TANK SENSOR CONTROL VALVE AND ECM CONNECTOR. 1) Turn ignition switch to OFF. 2) Disconnect the connector from fuel tank sensor control valve. 3) Turn ignition switch to ON. 4) Measure the voltage between ECM and chassis ground. Connector & terminal (B84) No. 23 (+) — Chassis ground (-): | Is the voltage more than 10 V? | Repair short circuit to battery in harness between ECM and fuel tank sensor control valve connector. After repair, replace the ECM. <Ref. to FU(H4DOTC)-48, Engine Control Module (ECM).> | Go to step 4. |
| 4 CHECK FUEL TANK SENSOR CONTROL VALVE. 1) Turn ignition switch to OFF. 2) Measure the resistance between fuel tank sensor control valve terminals. Terminals No. 1 — No. 2: | Is the resistance less than 1 Ω ? | Replace the fuel tank sensor control valve <Ref. to EC(H4DOTC)-12, Fuel Tank Sensor Control Valve.> and the ECM <Ref. to FU(H4DOTC)-48, Engine Control Module (ECM).>. | Go to step 5. |
| 5 CHECK FOR POOR CONTACT. Check for poor contact in ECM connector. | Is there poor contact in ECM connector? | Repair poor contact in ECM connector. | Replace the ECM. <Ref. to FU(H4DOTC)-48, Engine Control Module (ECM).> |

Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

DW:DTC P1448 FUEL TANK SENSOR CONTROL VALVE RANGE/PERFORMANCE


DTC DETECTING CONDITION:

- Two consecutive driving cycles with fault
- GENERAL DESCRIPTION <Ref. to GD(H4DOTC)-246, DTC P1448 FUEL TANK SENSOR CONTROL VALVE RANGE PERFORMANCE, Diagnostic Trouble Code (DTC) Detecting Criteria.>

CAUTION:

After repair or replacement of faulty parts, conduct Clear Memory Mode <Ref. to EN(H4DOTC)(diag)-46, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(H4DOTC)(diag)-39, PROCEDURE, Inspection Mode.>.

WIRING DIAGRAM:



EN-01635

Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

| | Step | Check | Yes | No |
|---|---|--|---|--|
| 1 | CHECK FOR OTHER DTC ON DISPLAY. | Is any other DTC displayed? | Inspect the relevant DTC using the "List of Diagnostic Trouble Codes (DTC)". <Ref. to EN(H4DOTC)(diag)-71, List of Diagnostic Trouble Code (DTC).> | Go to step 2. |
| 2 | CHECK FUEL FILLER CAP. 1) Turn ignition switch to OFF. 2) Open the fuel flap. | Is the fuel filler cap tightened securely? | Go to step 3. | Tighten fuel filler cap securely. |
| 3 | CHECK EVAPORATIVE EMISSION LINE. NOTE: Check the following items. <ul style="list-style-type: none">• Disconnection, leakage and clogging of hoses between fuel tank pressure sensor and fuel tank.• Disconnection, leakage and clogging of hoses and pipes between fuel filler pipe and fuel tank. | Is there any trouble in evaporative emission line? | Repair the hoses and pipes. | Replace the fuel tank pressure sensor. |

Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

DX:DTC P1491 POSITIVE CRANKCASE VENTILATION (BLOW-BY) FUNCTION PROBLEM

DTC DETECTING CONDITION:

- Two consecutive driving cycles with fault
- GENERAL DESCRIPTION <Ref. to GD(H4DOTC)-249, DTC P1491 POSITIVE CRANKCASE VENTILATION (BLOW-BY) FUNCTION PROBLEM, Diagnostic Trouble Code (DTC) Detecting Criteria.>


TROUBLE SYMPTOM:

Erroneous idling

CAUTION:

After repair or replacement of faulty parts, conduct Clear Memory Mode <Ref. to EN(H4DOTC)(diag)-46, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(H4DOTC)(diag)-39, PROCEDURE, Inspection Mode.>.

WIRING DIAGRAM:



EN-01636

Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

| Step | Check | Yes | No |
|---|--|---|--|
| 1 CHECK BLOW-BY HOSE. Check the blow-by hose. | Is there disconnection or crack in blow-by hose? | Replace or repair blow-by hose. | Go to step 2. |
| 2 INSPECT HARNESS BETWEEN PCV DIAGNOSIS CONNECTOR AND ECM CONNECTOR. 1) Turn the ignition switch to OFF. 2) Disconnect the connector from PCV diagnosis connector and ECM. 3) Measure the resistance of harness between PCV diagnosis connector and ECM connector. <i>Connector & terminal</i> <i>(B137) No. 2 — (E61) No. 2:</i> | Is the resistance less than 1 Ω ? | Go to step 3. | Repair open circuit in harness between PCV diagnosis connector and ECM. |
| 3 INSPECT HARNESS BETWEEN PCV DIAGNOSIS CONNECTOR AND ECM CONNECTOR. Measure the resistance of harness between PCV diagnosis connector and chassis ground. <i>Connector & terminal</i> <i>(B137) No. 2 — Chassis ground:</i> | Is the resistance more than 1 M Ω ? | Go to step 4. | Repair short circuit to chassis ground in harness between PCV diagnosis connector and ECM. |
| 4 INSPECT PCV DIAGNOSIS CONNECTOR GROUND CIRCUIT. Measure the resistance between PCV diagnosis connector and engine ground. <i>Connector & terminal</i> <i>(B61) No. 1 — Engine ground:</i> | Is the resistance less than 5 Ω ? | Go to step 5. | Repair PCV diagnosis connector ground circuit. |
| 5 INSPECT PCV DIAGNOSIS CONNECTOR. Measure the resistance between PCV diagnosis connector and terminal. <i>Terminals</i> <i>No. 1 — No. 2:</i> | Is the resistance less than 1 Ω ? | Repair poor contact in ECM and PCV diagnosis connector. | Replace PCV diagnosis connector. |

DY:DTC P1518 STARTER SWITCH CIRCUIT LOW INPUT

DTC DETECTING CONDITION:

- Two consecutive driving cycles with fault
- GENERAL DESCRIPTION <Ref. to GD(H4DOTC)-251, DTC P1518 STARTER SWITCH CIRCUIT LOW INPUT, Diagnostic Trouble Code (DTC) Detecting Criteria.>

TROUBLE SYMPTOM:

Failure of engine to start

CAUTION:

After repair or replacement of faulty parts, conduct Clear Memory Mode <Ref. to EN(H4DOTC)(diag)-46, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(H4DOTC)(diag)-39, PROCEDURE, Inspection Mode.>.

Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

| Step | Check | Yes | No |
|---|---|---|---|
| 1 CHECK OPERATION OF STARTER MOTOR. | Does the starter motor operate when ignition switch is turned to START? | Repair the harness and connector. NOTE: In this case, repair the following: <ul style="list-style-type: none">• Open or ground short circuit in harness between ECM and starter motor connector• Poor contact in ECM connector | Check the starter motor circuit. <Ref. to EN(H4DOTC)(diag)-59, STARTER MOTOR CIRCUIT, Diagnostics for Engine Starting Failure.> |

Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

DZ:DTC P1544 EXHAUST GAS TEMPERATURE TOO HIGH

DTC DETECTING CONDITION:

- Immediately at fault recognition
- GENERAL DESCRIPTION <Ref. to GD(H4DOTC)-252, DTC P1544 EXHAUST GAS TEMPERATURE TOO HIGH, Diagnostic Trouble Code (DTC) Detecting Criteria.>


TROUBLE SYMPTOM:

- Erroneous idling
- Poor driving performance

CAUTION:

After repair or replacement of faulty parts, conduct Clear Memory Mode <Ref. to EN(H4DOTC)(diag)-46, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(H4DOTC)(diag)-39, PROCEDURE, Inspection Mode.>.

WIRING DIAGRAM:



EN-01628

Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

| Step | Check | Yes | No |
|--|-------------------------------------|--|---|
| 1 CHECK ANY OTHER DTC ON DISPLAY. | Is any other DTC displayed? | Inspect the relevant DTC using "List of Diagnostic Trouble Code (DTC)". <Ref. to EN(H4DOTC)(diag)-71, List of Diagnostic Trouble Code (DTC).> NOTE: In this case, it is not necessary to inspect DTC P1544. | Go to step 2. |
| 2 CHECK EXHAUST SYSTEM. Check the exhaust system parts. NOTE: Check the following items. <ul style="list-style-type: none">• Loose installation of exhaust manifold• Cracks or hole of exhaust manifold• Loose installation of front oxygen (A/F) sensor | Is there a fault in exhaust system? | Repair or replace the failure, then replace pre-catalytic converter. | Contact your SOA Service Center. NOTE: Inspection by DTM is required, because probable cause is deterioration of multiple parts. |

EA:DTC P1560 BACK-UP VOLTAGE CIRCUIT MALFUNCTION

DTC DETECTING CONDITION:

- Immediately at fault recognition
- GENERAL DESCRIPTION <Ref. to GD(H4DOTC)-253, DTC P1560 BACK-UP VOLTAGE CIRCUIT MALFUNCTION, Diagnostic Trouble Code (DTC) Detecting Criteria.>



CAUTION:

After repair or replacement of faulty parts, conduct Clear Memory Mode <Ref. to EN(H4DOTC)(diag)-46, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(H4DOTC)(diag)-39, PROCEDURE, Inspection Mode.>.

Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

WIRING DIAGRAM:



EN-01608

Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

| Step | Check | Yes | No |
|--|---|--|--|
| 1 CHECK INPUT SIGNAL FOR ECM. 1) Turn the ignition switch to OFF. 2) Measure the voltage between ECM and chassis ground. <i>Connector & terminal</i> <i>(B84) No. 10 (+) — Chassis ground (-):</i> | Is the voltage more than 10 V? | Repair the poor contact in ECM connector. | Go to step 2. |
| 2 CHECK HARNESS BETWEEN ECM AND MAIN FUSE BOX CONNECTOR. 1) Disconnect the connector from ECM. 2) Measure the resistance of harness between ECM and chassis ground. <i>Connector & terminal</i> <i>(B84) No. 10 — Chassis ground:</i> | Is the resistance less than 10 Ω ? | Repair the ground short circuit in harness between ECM connector and battery terminal. | Go to step 3. |
| 3 CHECK FUSE SBF-5. | Is the fuse blown? | Replace the fuse. | Repair the harness and connector. NOTE: In this case, repair the following: <ul style="list-style-type: none"> • Open circuit in harness between ECM and battery • Poor contact in ECM connector • Poor contact in battery terminal |

EB:DTC P1700 THROTTLE POSITION SENSOR

GENERAL DESCRIPTION <Ref. to GD(H4DOTC)-254, DTC P1700 THROTTLE POSITION SENSOR CIRCUIT MALFUNCTION FOR AT, Diagnostic Trouble Code (DTC) Detecting Criteria.>

NOTE:

For the diagnostic procedure, refer to AT section. <Ref. to 4AT(diag)-46, DTC 31 THROTTLE POSITION SENSOR, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>

Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

EC:DTC P1711 ENGINE TORQUE CONTROL SIGNAL 1 CIRCUIT MALFUNCTION

DTC DETECTING CONDITION:

- Two consecutive driving cycles with fault
- GENERAL DESCRIPTION <Ref. to GD(H4DOTC)-256, DTC P1711 ENGINE TORQUE CONTROL SIGNAL #1 CIRCUIT MALFUNCTION, Diagnostic Trouble Code (DTC) Detecting Criteria.>


TROUBLE SYMPTOM:

Excessive shift shock

CAUTION:

After repair or replacement of faulty parts, conduct Clear Memory Mode <Ref. to EN(H4DOTC)(diag)-46, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(H4DOTC)(diag)-39, PROCEDURE, Inspection Mode.>.

WIRING DIAGRAM:



Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

| Step | Check | Yes | No |
|---|---|--|---|
| 1 CHECK INPUT SIGNAL FOR ECM. 1) Turn the ignition switch to ON. 2) Measure the voltage between ECM and chassis ground. <i>Connector & terminal</i> <i>(B134) No. 19 (+) — Chassis ground (-):</i> | Is the voltage more than 4.5 V? | Go to step 2. | Go to step 4. |
| 2 CHECK INPUT SIGNAL FOR ECM. Measure the voltage between ECM and chassis ground. <i>Connector & terminal</i> <i>(B134) No. 19 (+) — Chassis ground (-):</i> | Is the voltage more than 10 V? | Repair the battery short circuit in harness between ECM and TCM connector. | Go to step 3. |
| 3 CHECK POOR CONTACT. Check poor contact in ECM connector. | Is there poor contact in ECM connector? | Repair the poor contact in ECM connector. | Replace the ECM. <Ref. to FU(H4DOTC)-48, Engine Control Module (ECM).> |
| 4 CHECK HARNESS BETWEEN ECM AND TCM CONNECTOR. 1) Turn the ignition switch to OFF. 2) Disconnect the connectors from ECM and TCM. 3) Measure the resistance of harness between ECM and TCM connector. <i>Connector & terminal</i> <i>(B134) No. 19 — (B56) No. 5:</i> | Is the resistance less than 1 Ω ? | Go to step 5. | Repair the open circuit in harness between ECM and TCM connector. |
| 5 CHECK HARNESS BETWEEN ECM AND TCM CONNECTOR. Measure the resistance of harness between ECM and chassis ground. <i>Connector & terminal</i> <i>(B134) No. 19 — Chassis ground:</i> | Is the resistance more than 1 $M\Omega$? | Go to step 6. | Repair the ground short circuit in harness between ECM and TCM connector. |
| 6 CHECK POOR CONTACT. Check poor contact in TCM connector. | Is there poor contact in TCM connector? | Repair the poor contact in TCM connector. | Replace the TCM. <Ref. to 4AT-67, Transmission Control Module (TCM).> |

Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

ED:DTC P1712 ENGINE TORQUE CONTROL SIGNAL 2 CIRCUIT MALFUNCTION

DTC DETECTING CONDITION:

- Two consecutive driving cycles with fault
- GENERAL DESCRIPTION <Ref. to GD(H4DOTC)-257, DTC P1712 ENGINE TORQUE CONTROL SIGNAL #2 CIRCUIT MALFUNCTION, Diagnostic Trouble Code (DTC) Detecting Criteria.>


TROUBLE SYMPTOM:

Excessive shift shock

CAUTION:

After repair or replacement of faulty parts, conduct Clear Memory Mode <Ref. to EN(H4DOTC)(diag)-46, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(H4DOTC)(diag)-39, PROCEDURE, Inspection Mode.>.

WIRING DIAGRAM:



Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

| Step | Check | Yes | No |
|---|---|--|---|
| 1 CHECK INPUT SIGNAL FOR ECM. 1) Turn the ignition switch to ON. 2) Measure the voltage between ECM and chassis ground. Connector & terminal (B134) No. 18 (+) — Chassis ground (-): | Is the voltage more than 4.5 V? | Go to step 2. | Go to step 4. |
| 2 CHECK INPUT SIGNAL FOR ECM. Measure the voltage between ECM and chassis ground. Connector & terminal (B134) No. 18 (+) — Chassis ground (-): | Is the voltage more than 10 V? | Repair the battery short circuit in harness between ECM and TCM connector. | Go to step 3. |
| 3 CHECK POOR CONTACT. Check poor contact in ECM connector. | Is there poor contact in ECM connector? | Repair the poor contact in ECM connector. | Replace the ECM. <Ref. to FU(H4DOTC)-48, Engine Control Module (ECM).> |
| 4 CHECK HARNESS BETWEEN ECM AND TCM CONNECTOR. 1) Turn the ignition switch to OFF. 2) Disconnect the connectors from ECM and TCM. 3) Measure the resistance of harness between ECM and TCM connector. Connector & terminal (B134) No. 18 — (B56) No. 4: | Is the resistance less than 1 Ω ? | Go to step 5. | Repair the open circuit in harness between ECM and TCM connector. |
| 5 CHECK HARNESS BETWEEN ECM AND TCM CONNECTOR. Measure the resistance of harness between ECM and chassis ground. Connector & terminal (B134) No. 18 — Chassis ground: | Is the resistance more than 1 $M\Omega$? | Go to step 6. | Repair the ground short circuit in harness between ECM and TCM connector. |
| 6 CHECK POOR CONTACT. Check poor contact in TCM connector. | Is there poor contact in TCM connector? | Repair the poor contact in TCM connector. | Replace the TCM. <Ref. to 4AT-67, Transmission Control Module (TCM).> |

Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

EE:DTC P2096 POST CATALYST FUEL TRIM SYSTEM TOO LEAN BANK 1


DTC DETECTING CONDITION:

- Two consecutive driving cycles with fault
- GENERAL DESCRIPTION <Ref. to GD(H4DOTC)-258, DTC P2096 POST CATALYST FUEL TRIM SYSTEM TOO LEAN BANK 1, Diagnostic Trouble Code (DTC) Detecting Criteria.>

CAUTION:

After repair or replacement of faulty parts, conduct Clear Memory Mode <Ref. to EN(H4DOTC)(diag)-46, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(H4DOTC)(diag)-39, PROCEDURE, Inspection Mode.>.

WIRING DIAGRAM:



EN-01611

Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

| Step | Check | Yes | No |
|--|----------------------------------|---|--|
| 1 CHECK ANY OTHER DTC ON DISPLAY. | Is any other DTC displayed? | Using the List of Diagnostic Trouble Code (DTC), check the appropriate DTC. <Ref. to EN(H4DOTC)(diag)-71, List of Diagnostic Trouble Code (DTC).> | Go to step 2. |
| 2 CHECK REAR OXYGEN SENSOR DATA. 1) Warm-up the engine until engine coolant temperature is above 70°C (158°F), and keep the engine speed at 2,000 rpm to 3,000 rpm for 2 minutes. 2) Read the data of rear oxygen sensor signal using Subaru Select Monitor or OBD-II general scan tool. NOTE: • Subaru Select Monitor For detailed operation procedure, refer to the "READ CURRENT DATA SHOWN ON DISPLAY FOR ENGINE". <Ref. to EN(H4DOTC)(diag)-31, Subaru Select Monitor.> • OBD-II general scan tool For detailed operation procedures, refer to the OBD-II General Scan Tool Instruction Manual. | Does the value fluctuate? | Go to step 6. | Go to step 3. |
| 3 CHECK REAR OXYGEN SENSOR DATA. Read the data of rear oxygen sensor signal using Subaru Select Monitor or OBD-II general scan tool. | Is the voltage 0.2 — 0.4 V? | Go to step 4. | Replace the rear oxygen sensor. <Ref. to FU(H4DOTC)-45, Rear Oxygen Sensor.> |
| 4 CHECK HARNESS BETWEEN ECM AND REAR OXYGEN SENSOR CONNECTOR. 1) Turn the ignition switch to OFF. 2) Disconnect the connectors from ECM and rear oxygen sensor. 3) Measure the resistance of harness between ECM and rear oxygen sensor connector. Connector & terminal (B135) No. 17 — (B19) No. 3: | Is the resistance more than 3 Ω? | Repair the open circuit in harness between ECM and rear oxygen sensor connector. | Go to step 5. |
| 5 CHECK HARNESS BETWEEN REAR OXYGEN SENSOR AND ECM CONNECTOR. 1) Turn the ignition switch to OFF. 2) Disconnect the connector from rear oxygen sensor. 3) Turn the ignition switch to ON. 4) Measure the voltage between rear oxygen sensor harness connector and engine ground or chassis ground. Connector & terminal (B19) No. 3 (+) — Engine ground (-): | Is the voltage more than 0.2 V? | Replace the rear oxygen sensor. <Ref. to FU(H4DOTC)-45, Rear Oxygen Sensor.> | Repair the harness and connector. NOTE: In this case, repair the following: • Open circuit in harness between rear oxygen sensor and ECM connector • Poor contact in rear oxygen sensor connector • Poor contact in ECM connector |

Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

| Step | Check | Yes | No |
|---|---|-------------------------------------|--|
| <p>6 CHECK EXHAUST SYSTEM. Check the exhaust system parts.</p> <p>NOTE: Check the following items.</p> <ul style="list-style-type: none"> • Loose installation of portions • Damage (crack, hole etc.) of parts • Looseness and ill fitting of parts between front oxygen (A/F) sensor and rear oxygen sensor | Is there a fault in exhaust system? | Repair or replace the faulty parts. | Go to step 7. |
| <p>7 CHECK AIR INTAKE SYSTEM.</p> | Are there holes, loose bolts or disconnection of hose on air intake system? | Repair the air intake system. | Go to step 8. |
| <p>8 CHECK FUEL PRESSURE.</p> <p>Warning:</p> <ul style="list-style-type: none"> • Place “NO FIRE” signs near the working area. • Be careful not to spill fuel on the floor. <ol style="list-style-type: none"> 1) Release the fuel pressure. <ol style="list-style-type: none"> (1) Disconnect the connector from fuel pump relay. (2) Start the engine and run it until it stalls. (3) After the engine stalls, crank it for 5 more seconds. (4) Turn the ignition switch to OFF. 2) Connect the connector to fuel pump relay. 3) Disconnect the fuel delivery hose from fuel filter, and connect fuel pressure gauge. 4) Install the fuel filler cap. 5) Start the engine and idle while gear position is neutral. 6) Measure the fuel pressure while disconnecting pressure regulator vacuum hose from intake manifold. <p>Warning: Before removing the fuel pressure gauge, release fuel pressure.</p> <p>NOTE: If the fuel pressure does not increase, squeeze fuel return hose 2 to 3 times, then measure fuel pressure again.</p> | Is the measured value 284 — 314 kPa (2.9 — 3.2 kg/cm ² , 41 — 46 psi)? | Go to step 9. | Repair the following items. Fuel pressure too high: <ul style="list-style-type: none"> • Clogged fuel return line or bent hose Fuel pressure too low: <ul style="list-style-type: none"> • Improper fuel pump discharge • Clogged fuel supply line |
| <p>9 CHECK FUEL PRESSURE. After connecting the pressure regulator vacuum hose, measure fuel pressure.</p> <p>Warning: Before removing the fuel pressure gauge, release fuel pressure.</p> <p>NOTE:</p> <ul style="list-style-type: none"> • If the fuel pressure does not increase, squeeze fuel return hose 2 to 3 times, then measure fuel pressure again. • If out of specification as measured at this step, check or replace the pressure regulator and pressure regulator vacuum hose. | Is the measured value 206 — 235 kPa (2.1 — 2.4 kg/cm ² , 30 — 34 psi)? | Go to step 10. | Repair the following items. Fuel pressure too high: <ul style="list-style-type: none"> • Faulty pressure regulator • Clogged fuel return line or bent hose Fuel pressure too low: <ul style="list-style-type: none"> • Faulty pressure regulator • Improper fuel pump discharge • Clogged fuel supply line |

Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

| Step | Check | Yes | No |
|--|--|---|---|
| <p>10 CHECK ENGINE COOLANT TEMPERATURE SENSOR.</p> <p>1) Start the engine and warm-up completely. 2) Read the data of engine coolant temperature sensor signal using Subaru Select Monitor or OBD-II general scan tool.</p> <p>NOTE: • Subaru Select Monitor For detailed operation procedure, refer to the "READ CURRENT DATA FOR ENGINE". <Ref. to EN(H4DOTC)(diag)-31, Subaru Select Monitor.> • OBD-II general scan tool For detailed operation procedures, refer to the OBD-II General Scan Tool Instruction Manual.</p> | <p>Is the temperature more than 60°C (140°F)?</p> | <p>Go to step 11.</p> | <p>Replace the engine coolant temperature sensor. <Ref. to FU(H4DOTC)-27, Engine Coolant Temperature Sensor.></p> |
| <p>11 CHECK MASS AIR FLOW AND INTAKE AIR TEMPERATURE.</p> <p>1) Start the engine and warm-up engine until coolant temperature is greater than 60°C (140°F). 2) Place the shift lever in neutral position. 3) Turn the A/C switch to OFF. 4) Turn all accessory switches to OFF. 5) Read the data of mass air flow and intake air temperature sensor signal using Subaru Select Monitor or OBD-II general scan tool.</p> <p>NOTE: • Subaru Select Monitor For detailed operation procedure, refer to the "READ CURRENT DATA FOR ENGINE". <Ref. to EN(H4DOTC)(diag)-31, Subaru Select Monitor.> • OBD-II general scan tool For detailed operation procedure, refer to the OBD-II General Scan Tool Instruction Manual.</p> | <p>Is the measured value within the followings? Ignition ON: 73.3 — 106.6 kPa (550 — 800 mmHg, 21.65 — 31.50 inHg) Idling: 24.0 — 41.3 kPa (180 — 310 mmHg, 7.09 — 12.20 inHg)</p> | <p>Go to step 12.</p> | <p>Replace the mass air flow and intake air temperature sensor. <Ref. to FU(H4DOTC)-32, Mass Air Flow and Intake Air Temperature Sensor.></p> |
| <p>12 CHECK MASS AIR FLOW AND INTAKE AIR TEMPERATURE SENSOR.</p> <p>1) Start the engine and warm-up engine until coolant temperature is greater than 60°C (140°F). 2) Place the shift lever in neutral position. 3) Turn the A/C switch to OFF. 4) Turn all accessory switches to OFF. 5) Open the front hood. 6) Measure the ambient temperature. 7) Read the data of mass air flow and intake air temperature sensor signal using Subaru Select Monitor or OBD-II general scan tool.</p> <p>NOTE: • Subaru Select Monitor For detailed operation procedure, refer to the "READ CURRENT DATA FOR ENGINE". <Ref. to EN(H4DOTC)(diag)-31, Subaru Select Monitor.> • OBD-II general scan tool For detailed operation procedure, refer to the OBD-II General Scan Tool Instruction Manual.</p> | <p>Subtract ambient temperature from intake air temperature. Is the obtained value -10°C — 50°C (14°F — 122°F)?</p> | <p>Contact your SOA Service Center. NOTE: Inspection by DTM is required, because probable cause is deterioration of multiple parts.</p> | <p>Check the mass air flow and intake air temperature sensor. <Ref. to FU(H4DOTC)-32, Mass Air Flow and Intake Air Temperature Sensor.></p> |

Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

EF:DTC P2097 POST CATALYST FUEL TRIM SYSTEM TOO RICH BANK 1


DTC DETECTING CONDITION:

- Two consecutive driving cycles with fault
- GENERAL DESCRIPTION <Ref. to GD(H4DOTC)-260, DTC P2097 POST CATALYST FUEL TRIM SYSTEM TOO RICH BANK 1, Diagnostic Trouble Code (DTC) Detecting Criteria.>

CAUTION:

After repair or replacement of faulty parts, conduct Clear Memory Mode <Ref. to EN(H4DOTC)(diag)-46, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(H4DOTC)(diag)-39, PROCEDURE, Inspection Mode.>.

WIRING DIAGRAM:



EN-01611

Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

| Step | Check | Yes | No |
|--|----------------------------------|---|--|
| 1 CHECK ANY OTHER DTC ON DISPLAY. | Is any other DTC displayed? | Using the List of Diagnostic Trouble Code (DTC), check the appropriate DTC. <Ref. to EN(H4DOTC)(diag)-71, List of Diagnostic Trouble Code (DTC).> | Go to step 2. |
| 2 CHECK REAR OXYGEN SENSOR DATA. 1) Warm-up the engine until engine coolant temperature is above 70°C (158°F), and keep the engine speed at 2,000 rpm to 3,000 rpm for 2 minutes. 2) Read the data of rear oxygen sensor signal using Subaru Select Monitor or OBD-II general scan tool. NOTE: • Subaru Select Monitor For detailed operation procedure, refer to the "READ CURRENT DATA SHOWN ON DISPLAY FOR ENGINE". <Ref. to EN(H4DOTC)(diag)-31, Subaru Select Monitor.> • OBD-II general scan tool For detailed operation procedures, refer to the OBD-II General Scan Tool Instruction Manual. | Does the value fluctuate? | Go to step 6. | Go to step 3. |
| 3 CHECK REAR OXYGEN SENSOR DATA. Read the data of rear oxygen sensor signal using Subaru Select Monitor or OBD-II general scan tool. | Is the voltage 0.2 — 0.4 V? | Go to step 4. | Replace the rear oxygen sensor. <Ref. to FU(H4DOTC)-45, Rear Oxygen Sensor.> |
| 4 CHECK HARNESS BETWEEN ECM AND REAR OXYGEN SENSOR CONNECTOR. 1) Turn the ignition switch to OFF. 2) Disconnect the connectors from ECM and rear oxygen sensor. 3) Measure the resistance of harness between ECM and rear oxygen sensor connector. <i>Connector & terminal</i> <i>(B135) No. 17 — (B19) No. 3:</i> | Is the resistance more than 3 Ω? | Repair the open circuit in harness between ECM and rear oxygen sensor connector. | Go to step 5. |
| 5 CHECK HARNESS BETWEEN REAR OXYGEN SENSOR AND ECM CONNECTOR. 1) Turn the ignition switch to OFF. 2) Disconnect the connector from rear oxygen sensor. 3) Turn the ignition switch to ON. 4) Measure the voltage between rear oxygen sensor harness connector and engine ground or chassis ground. <i>Connector & terminal</i> <i>(B19) No. 3 (+) — Engine ground (-):</i> | Is the voltage more than 0.2 V? | Replace the rear oxygen sensor. <Ref. to FU(H4DOTC)-45, Rear Oxygen Sensor.> | Repair the harness and connector. NOTE: In this case, repair the following: • Open circuit in harness between rear oxygen sensor and ECM connector • Poor contact in rear oxygen sensor connector • Poor contact in ECM connector |

Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

| Step | Check | Yes | No |
|--|---|-------------------------------------|--|
| <p>6 CHECK EXHAUST SYSTEM. Check the exhaust system parts.</p> <p>NOTE: Check the following items.</p> <ul style="list-style-type: none"> • Loose installation of portions • Damage (crack, hole etc.) of parts • Looseness and ill fitting of parts between front oxygen (A/F) sensor and rear oxygen sensor | Is there a fault in exhaust system? | Repair or replace the faulty parts. | Go to step 7. |
| <p>7 CHECK AIR INTAKE SYSTEM.</p> | Are there holes, loose bolts or disconnection of hose on air intake system? | Repair the air intake system. | Go to step 8. |
| <p>8 CHECK FUEL PRESSURE.</p> <p>Warning:</p> <ul style="list-style-type: none"> • Place “NO FIRE” signs near the working area. • Be careful not to spill fuel on the floor. <p>1) Release the fuel pressure. (1) Disconnect the connector from fuel pump relay. (2) Start the engine and run it until it stalls. (3) After the engine stalls, crank it for 5 more seconds. (4) Turn the ignition switch to OFF.</p> <p>2) Connect the connector to fuel pump relay. 3) Disconnect the fuel delivery hose from fuel filter, and connect fuel pressure gauge. 4) Install the fuel filler cap. 5) Start the engine and idle while gear position is neutral. 6) Measure the fuel pressure while disconnecting pressure regulator vacuum hose from intake manifold.</p> <p>Warning: Before removing the fuel pressure gauge, release fuel pressure.</p> <p>NOTE: If the fuel pressure does not increase, squeeze fuel return hose 2 to 3 times, then measure fuel pressure again.</p> | Is the measured value 284 — 314 kPa (2.9 — 3.2 kg/cm ² , 41 — 46 psi)? | Go to step 9. | <p>Repair the following items.</p> <p>Fuel pressure too high:</p> <ul style="list-style-type: none"> • Clogged fuel return line or bent hose <p>Fuel pressure too low:</p> <ul style="list-style-type: none"> • Improper fuel pump discharge • Clogged fuel supply line |
| <p>9 CHECK FUEL PRESSURE. After connecting the pressure regulator vacuum hose, measure fuel pressure.</p> <p>Warning: Before removing the fuel pressure gauge, release fuel pressure.</p> <p>NOTE:</p> <ul style="list-style-type: none"> • If the fuel pressure does not increase, squeeze fuel return hose 2 to 3 times, then measure fuel pressure again. • If out of specification as measured at this step, check or replace the pressure regulator and pressure regulator vacuum hose. | Is the measured value 206 — 235 kPa (2.1 — 2.4 kg/cm ² , 30 — 34 psi)? | Go to step 10. | <p>Repair the following items.</p> <p>Fuel pressure too high:</p> <ul style="list-style-type: none"> • Faulty pressure regulator • Clogged fuel return line or bent hose <p>Fuel pressure too low:</p> <ul style="list-style-type: none"> • Faulty pressure regulator • Improper fuel pump discharge • Clogged fuel supply line |

Diagnostic Procedure with Diagnostic Trouble Code (DTC)

ENGINE (DIAGNOSTICS)

| Step | Check | Yes | No |
|--|--|--|---|
| <p>10 CHECK ENGINE COOLANT TEMPERATURE SENSOR.</p> <p>1) Start the engine and warm-up completely. 2) Read the data of engine coolant temperature sensor signal using Subaru Select Monitor or OBD-II general scan tool.</p> <p>NOTE:</p> <ul style="list-style-type: none"> • Subaru Select Monitor <p>For detailed operation procedure, refer to the "READ CURRENT DATA FOR ENGINE". <Ref. to EN(H4DOTC)(diag)-31, Subaru Select Monitor.></p> <ul style="list-style-type: none"> • OBD-II general scan tool <p>For detailed operation procedures, refer to the OBD-II General Scan Tool Instruction Manual.</p> | <p>Is the temperature more than 60°C (140°F)?</p> | <p>Go to step 11.</p> | <p>Replace the engine coolant temperature sensor. <Ref. to FU(H4DOTC)-27, Engine Coolant Temperature Sensor.></p> |
| <p>11 CHECK MASS AIR FLOW AND INTAKE AIR TEMPERATURE.</p> <p>1) Start the engine and warm-up engine until coolant temperature is greater than 60°C (140°F). 2) Place the shift lever in neutral position. 3) Turn the A/C switch to OFF. 4) Turn all accessory switches to OFF. 5) Read the data of mass air flow and intake air temperature sensor signal using Subaru Select Monitor or OBD-II general scan tool.</p> <p>NOTE:</p> <ul style="list-style-type: none"> • Subaru Select Monitor <p>For detailed operation procedure, refer to the "READ CURRENT DATA FOR ENGINE". <Ref. to EN(H4DOTC)(diag)-31, Subaru Select Monitor.></p> <ul style="list-style-type: none"> • OBD-II general scan tool <p>For detailed operation procedure, refer to the OBD-II General Scan Tool Instruction Manual.</p> | <p>Is the measured value within the followings? Ignition ON: 73.3 — 106.6 kPa (550 — 800 mmHg, 21.65 — 31.50 inHg) Idling: 24.0 — 41.3 kPa (180 — 310 mmHg, 7.09 — 12.20 inHg)</p> | <p>Go to step 12.</p> | <p>Replace the mass air flow and intake air temperature sensor. <Ref. to FU(H4DOTC)-32, Mass Air Flow and Intake Air Temperature Sensor.></p> |
| <p>12 CHECK MASS AIR FLOW AND INTAKE AIR TEMPERATURE SENSOR.</p> <p>1) Start the engine and warm-up engine until coolant temperature is greater than 60°C (140°F). 2) Place the shift lever in neutral position. 3) Turn the A/C switch to OFF. 4) Turn all accessory switches to OFF. 5) Open the front hood. 6) Measure the ambient temperature. 7) Read the data of mass air flow and intake air temperature sensor signal using Subaru Select Monitor or OBD-II general scan tool.</p> <p>NOTE:</p> <ul style="list-style-type: none"> • Subaru Select Monitor <p>For detailed operation procedure, refer to the "READ CURRENT DATA FOR ENGINE". <Ref. to EN(H4DOTC)(diag)-31, Subaru Select Monitor.></p> <ul style="list-style-type: none"> • OBD-II general scan tool <p>For detailed operation procedure, refer to the OBD-II General Scan Tool Instruction Manual.</p> | <p>Subtract ambient temperature from intake air temperature. Is the obtained value -10°C — 50°C (14°F — 122°F)?</p> | <p>Contact your SOA Service Center.</p> <p>NOTE: Inspection by DTM is required, because probable cause is deterioration of multiple parts.</p> | <p>Check the mass air flow and intake air temperature sensor. <Ref. to FU(H4DOTC)-32, Mass Air Flow and Intake Air Temperature Sensor.></p> |

General Diagnostic Table

ENGINE (DIAGNOSTICS)

20. General Diagnostic Table

A: INSPECTION

1. ENGINE

NOTE:

Malfunction of parts other than those listed is also possible. <Ref. to ME(H4DOTC)-97, Engine Noise.>

| Symptom | Problem parts |
|---|--|
| 1. Engine stalls during idling. | 1) Idle air control solenoid valve 2) Manifold absolute pressure sensor 3) Mass air flow and intake temperature sensor 4) Ignition parts (*1) 5) Engine coolant temperature sensor (*2) 6) Crankshaft position sensor (*3) 7) Camshaft position sensor (*3) 8) Fuel injection parts (*4) |
| 2. Rough idling | 1) Idle air control solenoid valve 2) Manifold absolute pressure sensor 3) Mass air flow and intake temperature sensor 4) Engine coolant temperature sensor (*2) 5) Ignition parts (*1) 6) Air intake system (*5) 7) Fuel injection parts (*4) 8) Throttle position sensor 9) Crankshaft position sensor (*3) 10) Camshaft position sensor (*3) 11) Oxygen sensor 12) Fuel pump and fuel pump relay |
| 3. Engine does not return to idle. | 1) Idle air control solenoid valve 2) Engine coolant temperature sensor 3) Accelerator cable (*6) 4) Throttle position sensor 5) Manifold absolute pressure sensor 6) Mass air flow sensor |
| 4. Poor acceleration | 1) Manifold absolute pressure sensor 2) Mass air flow and intake temperature sensor 3) Throttle position sensor 5) Fuel pump and fuel pump relay 6) Engine coolant temperature sensor (*2) 7) Crankshaft position sensor (*3) 8) Camshaft position sensor (*3) 9) A/C switch and A/C cut relay 10) Engine torque control signal circuit 11) Ignition parts (*1) |
| 5. Engine stalls or engine sags or hesitates at acceleration. | 1) Manifold absolute pressure sensor 2) Mass air flow and intake temperature sensor 3) Engine coolant temperature sensor (*2) 4) Crankshaft position sensor (*3) 5) Camshaft position sensor (*3) 6) Purge control solenoid valve 7) Fuel injection parts (*4) 8) Throttle position sensor 9) Fuel pump and fuel pump relay |

General Diagnostic Table

ENGINE (DIAGNOSTICS)

| Symptom | Problem parts |
|------------------------------------|---|
| 6. Surge | <ol style="list-style-type: none">1) Manifold absolute pressure sensor2) Mass air flow and intake temperature sensor3) Engine coolant temperature sensor (*2)4) Crankshaft position sensor (*3)5) Camshaft position sensor (*3)6) Fuel injection parts (*4)7) Throttle position sensor8) Fuel pump and fuel pump relay |
| 7. Spark knock | <ol style="list-style-type: none">1) Manifold absolute pressure sensor2) Mass air flow and intake temperature sensor3) Engine coolant temperature sensor4) Knock sensor5) Fuel injection parts (*4)6) Fuel pump and fuel pump relay |
| 8. After-burning in exhaust system | <ol style="list-style-type: none">1) Manifold absolute pressure sensor2) Mass air flow and intake temperature sensor3) Engine coolant temperature sensor (*2)4) Fuel injection parts (*4)5) Fuel pump and fuel pump relay |

- *1: Check ignition coil & ignitor ASSY and spark plug.
- *2: Indicate the symptom occurring only in cold temperatures.
- *3: Ensure the secure installation.
- *4: Check fuel injector, fuel pressure regulator and fuel filter.
- *5: Inspect air leak in air intake system.
- *6: Adjust accelerator cable.

Brought to you by Eris Studios
NOT FOR RESALE