


6. Diagnostic Chart for On-board Diagnostics System

A: BASIC DIAGNOSTIC PROCEDURE



D: LIST OF TROUBLE CODE**1. TROUBLE CODE**

Trouble code	Item	Content of diagnosis	Abbr. (Select monitor)	Page
11	Duty solenoid A	Detects open or shorted drive circuit, as well as valve seizure.	PLDTY	—
12	Duty solenoid B	Detects open or shorted drive circuit, as well as valve seizure.	LUPTY	—
13	Shift solenoid 3	Detects open or shorted drive circuit, as well as valve seizure.	OVR	—
14	Shift solenoid 2	Detects open or shorted drive circuit, as well as valve seizure.	SFT2	—
15	Shift solenoid 1	Detects open or shorted drive circuit, as well as valve seizure.	SFT1	—
21	ATF temperature sensor	Detects open or shorted input signal circuit.	ATFT	—
22	Mass air flow signal	Detects open or shorted input signal circuit.	AFM	4
23	Engine speed signal	Detects open or shorted input signal circuit.	EREV	6
24	Duty solenoid C	Detects open or shorted drive circuit, as well as valve seizure.	4WDTY	—
25	Torque control signal	Detects open or shorted input signal circuit.	TQ.CT	8
31	Throttle position sensor	Detects open or shorted input signal circuit.	THV	10
32	Vehicle speed sensor 1	Detects open or shorted input signal circuit.	VSP1	—
33	Vehicle speed sensor 2	Detects open or shorted input signal circuit.	VSP2	—



7. Diagnostic Chart with Trouble Code

H: TROUBLE CODE 22

— MASS AIR FLOW SIGNAL —

DIAGNOSIS:


Input signal circuit of TCM from ECM is open or shorted.



B3M0475

1. CHECK TROUBLE CODE ON ENGINE SIDE.


Using Subaru select monitor or OBD-general scan tool, check trouble code of mass air flow sensor on engine side.



2. CHECK HARNESS CONNECTOR BETWEEN TCM AND ECM.


- 1) Turn ignition switch to OFF.
- 2) Disconnect connectors from TCM and ECM.
- 3) Measure resistance of harness connector between TCM and ECM.

Connector & terminal / Specified resistance:
(B54) No. 9 — (B84) No. 47 / 1 Ω, or less



- 4) Measure resistance of harness connector between TCM and body to make sure that circuit does not short.


Connector & terminal / Specified resistance:
(B54) No. 9 — Body / 1 MΩ, or more



3. CHECK INPUT SIGNAL FOR TCM.

- 1) Connect connectors to TCM and ECM.
- 2) Start the engine. (engine idling after warm-up)
- 3) Measure signal voltage between TCM connector terminal and body.

Connector & terminal / Specified voltage:
Engine warm-up;
(B54) No. 9 — Body / 0.5 — 1.22 V



● Using Subaru select monitor:

- (1) Connect connectors to TCM and ECM.
- (2) Turn ignition switch to OFF.
- (3) Connect the Subaru select monitor to data link connector.
- (4) Turn ignition switch to ON and Subaru select monitor switch to ON.
- (5) Start and warm-up the engine.

- (6) Read data on Subaru select monitor.
- (7) Designate mode using function key.

Function mode: F15

SPECIFIED DATA:

0.5 — 1.22 V (Engine warm-up)

AFM (F15)

0.6V



B3M0370

I: TROUBLE CODE 23**— ENGINE SPEED SIGNAL —****DIAGNOSIS:**


Engine speed input signal circuit is open or shorted.

TROUBLE SYMPTOM:

- No lock-up (after engine warm-up)
- AT OIL TEMP indicator remains on when vehicle speed is "0".




B2M0585



1. CHECK HARNESS AND CONNECTOR BETWEEN TCM AND ECM.


- 1) Turn ignition switch to OFF.
- 2) Disconnect connectors from TCM and ECM.
- 3) Measure resistance of harness connector between TCM and ECM.

Connector & terminal / Specified resistance:
(B54) No. 5 — (B84) No. 64 / 1 Ω , or less



- 4) Measure resistance of harness connector between TCM and body to make sure that circuit does not short.


Connector & terminal / Specified resistance:
(B54) No. 5 — Body / 1 M Ω , or more



2. CHECK INPUT SIGNAL FOR TCM.


- 1) Connect connectors to ECM and TCM.
- 2) Turn ignition switch ON (with engine OFF).
- 3) Measure signal voltage for TCM.

Connector & terminal / Specified voltage:
(B54) No. 5 — Body / 10.5 V, or more



● Using Subaru select monitor:

- (1) Connect connectors to ECM and TCM.
- (2) Turn ignition switch to OFF.
- (3) Connect the Subaru select monitor to data link connector.
- (4) Turn ignition switch to ON and Subaru select monitor switch to ON.



- (5) Start and warm-up the engine.
- (6) Operate at constant engine speed.
- (7) Read data on Subaru select monitor.
- (8) Designate mode using function key.



Function mode: F06

SPECIFIED DATA:


Same as tachometer reading (in combination meter)

K: TROUBLE CODE 25**— TORQUE CONTROL SIGNAL —****DIAGNOSIS:**

- Torque control signal is not emitted from TCM.
- The signal circuit is open or shorted.




B2M0598



1. CHECK HARNESS CONNECTOR BETWEEN TCM AND ECM.


- 1) Turn ignition switch to OFF.
- 2) Disconnect connectors from TCM and ECM.
- 3) Measure resistance of harness connector between TCM and ECM.

Connector & terminal / Specified resistance:
(B55) No. 16 — (B84) No. 79 / 1 Ω , or less



- 4) Measure resistance of harness connector between TCM and body to make sure that circuit does not short.

Connector & terminal / Specified resistance:
(B55) No. 16 — Body / 1 $M\Omega$, or more



2. CHECK OUTPUT SIGNAL FOR TCM.

- 1) Connect connectors to TCM and ECM.
- 2) Turn ignition switch to ON.
- 3) Measure signal voltage between TCM connector terminal and body.



Connector & terminal / Specified voltage:
(B55) No. 16 — Body / 5 $\pm$ 1 V

L: TROUBLE CODE 31**— THROTTLE POSITION SENSOR —****DIAGNOSIS:**


Input signal circuit of throttle position sensor is open or shorted.

TROUBLE SYMPTOM:

Shift point too high or too low; engine brake not effected in "3" range; excessive shift shock; excessive tight corner "braking"



B2M0613




1. CHECK HARNESS CONNECTOR BETWEEN TCM AND THROTTLE POSITION SENSOR.

- 1) Turn ignition switch to OFF.
- 2) Disconnect connector from TCM and throttle position sensor.
- 3) Measure resistance of harness connector between TCM and throttle position sensor.

Connector & terminal / Specified resistance:

(B54) No. 8 — (E13) No. 2 / 1 Ω , or less

(B56) No. 19 — (E13) No. 3 / 1 Ω , or less




- 4) Measure resistance of harness connector between TCM and body to make sure that circuit does not short.

Connector & terminal / Specified resistance:

(B54) No. 8 — Body / 1 M Ω , or more

(B56) No. 19 — Body / 1 M Ω , or more



2. CHECK THROTTLE POSITION SENSOR.

Measure resistance between throttle position sensor terminals.

Terminals / Specified resistance:


(E13) No. 1 — No. 2 / 0.3 — 0.7 k Ω

(Throttle fully closed.)

3 — 6 k Ω

(Throttle fully open.)

(E13) No. 1 — No. 3 / 3.5 — 6.5 k Ω



3. CHECK INPUT SIGNAL FOR TCM.


- 1) Connect connectors to TCM and throttle position sensor.
- 2) Turn ignition switch ON (with engine OFF).
- 3) Measure signal voltage input emitted from throttle position sensor with accelerator pedal fully depressed.

Connector & terminal / Specified voltage:

(B54) No. 8 — No. 7 /

0.5 $\pm$ 0.2 V (Throttle fully closed.)

4.6 $\pm$ 0.3 V (Throttle fully open.)




● Using Subaru select monitor:

- (1) Connect connectors to TCM and throttle position sensor.
- (2) Turn ignition switch to OFF.
- (3) Connect the Subaru select monitor to data link connector.
- (4) Turn ignition switch to ON and Subaru select monitor switch to ON.

THV (F09)

4.6V

B3M0383



B3M0238A

- (5) Designate mode using function key.
- (6) Read data on Subaru select monitor.

Function mode: F09**SPECIFIED DATA:** **0.5 ± 0.2 V (Throttle fully closed.)** **4.6 ± 0.3 V (Throttle fully open.)****[Must be changed correspondingly with accelerator pedal operation (from "released" to "depressed" position).]****4. CHECK POWER SUPPLY TO THROTTLE POSITION SENSOR.**

- 1) Turn ignition switch to OFF.
- 2) Disconnect connector from throttle position sensor.
- 3) Turn ignition switch to ON.
- 4) Measure power supply voltage to throttle position sensor.

Connector & terminal / Specified voltage:**(E13) No. 1 — Body / 5.12 ± 0.1 V**

- Using Subaru select monitor:

- (1) Turn ignition switch to OFF.
- (2) Connect the Subaru select monitor to data link connector.
- (3) Turn ignition switch to ON and Subaru select monitor switch to ON.


- (4) Designate mode using function key.
- (5) Read data on Subaru select monitor.

Function mode: F14**SPECIFIED DATA:** **5.12 ± 0.1 V**

THVCC (F14)

5.2V

OBD0506




OBD0145A

8. Diagnostic Chart with Select Monitor

B: LIST OF OUTPUT MODES

1. FUNCTION MODE

Mode	Contents	Abbr.	Unit	Contents of display	Page
F00	Mode display	—	—	AT or EGI mode (when monitor is connected.)	—
F01	Battery voltage	VB	V	Battery voltage applied to control unit.	—
F02	Vehicle speed sensor 1	VSP1	m/h	Vehicle speed (miles/h) sent from vehicle speed sensor 1.	—
F03	Vehicle speed sensor 1	VSP1	km/h	Vehicle speed (km/h) sent from vehicle speed sensor 1.	—
F04	Vehicle speed sensor 2	VSP2	m/h	Vehicle speed (miles/h) sent from vehicle speed sensor 2.	—
F05	Vehicle speed sensor 2	VSP2	km/h	Vehicle speed (km/h) sent from vehicle speed sensor 2.	—
F06	Engine speed	EREV	rpm	Engine speed sent from ECM.	—
F07	ATF temperature sensor	ATFT	°F	ATF temperature (°F) sent from ATF temperature sensor.	—
F08	ATF temperature sensor	ATFT	°C	ATF temperature (°C) sent from ATF temperature sensor.	—
F09	Throttle position sensor	THV	V	Voltage sent from throttle position sensor.	15
F10	Gear position	GEAR	—	Transmission gear position	—
F11	Line pressure duty	PLDTY	%	Duty ratio flowing through duty solenoid A.	16
F12	Lock-up duty	LUPTY	%	Duty ratio flowing through duty solenoid B.	17
F13	AWD duty	4WDTY	%	Duty ratio flowing through duty solenoid C.	18
F14	Throttle position sensor power supply	THVCC	V	Power supply voltage to throttle position sensor	19
F15	Mass air flow signal	AFM	V	Output voltage from air flow sensor	19



I: MODE F09

— THROTTLE POSITION SENSOR (THV) —


CONDITION:

- Ignition switch ON (with engine OFF)
- Measure voltage while operating throttle valve from a fully closed position to a fully open position.

SPECIFIED DATA:

- Fully closed position: 0.5 ± 0.2 V
- Fully open position: 4.6 ± 0.3 V
- From fully closed to fully open position: Voltage must smoothly decrease.
- Open harness: 5.0 ± 0.3 V
- Shorted harness: 0.00 V

Probable cause (if outside "specified data")



PLDTY (F11)

50%

G3M0731


K: MODE F11**— LINE PRESSURE DUTY (PLDTY) —****CONDITION:**


- After sufficient warm-up
- Ignition ON (engine OFF)
- N range

SPECIFIED DATA:

- Throttle fully closed: 100%
- Throttle fully open : 15% or less

Probable cause (if outside "specified data")






L: MODE F12 — LOCK-UP DUTY (LUDTY) — CONDITION:


- Idling (after sufficient warm-up) with lock-up system released.
- Driving at 75 km/h (47 MPH) (after sufficient warm-up) with lock-up system applied.

SPECIFIED DATA:

- Lock-up system released: 5%
- Lock-up system applied: 95%

Probable cause (if outside "specified data")




**M: MODE F13 — AWD DUTY (4WDTY) —****CONDITION:**


- After sufficient warm-up
- Ignition switch ON (engine OFF)
- FWD mode
- AWD mode, D range, full throttle

SPECIFIED DATA:

- 95% (FWD mode)
- 25%, max. (vehicle speed 0 m/h) (AWD mode)

Probable cause (if outside "specified data")





N: MODE F14
— THROTTLE POSITION SENSOR POWER SUPPLY (THVCC) —



CONDITION:

Ignition switch ON (engine OFF)

SPECIFIED DATA:

5.12 ± 0.1 V

Probable cause (Item outside "specified data")



O: MODE F15
— MASS AIR FLOW SIGNAL (AFM) —


CONDITION:

- Ignition switch ON (engine ON)
- N range
- Idling

SPECIFIED DATA:

Engine warm-up: 0.5 — 1.22 V

Probable cause (if outside "specified data")



DISPLAY

LED No.	Signal name	Symbol
1	FWD switch	FF
2	Kick-down switch	KD
3	—	—
4	—	—
5	Brake	BR
6	ABS switch	AB
7	Cruise control set	CR
8	Power switch	PW
9	—	—
10	—	—

FF	KD	—	—	BR
AB	CR	PW	—	—

1	2	3	4	5
6	7	8	9	10

P: MODE FA0

— SWITCH 1 (SW1) —

Reference values

- Lights up when the fuse is installed in FWD switch (No. 1).
- Lights up when the brake pedal is depressed (No. 5)
- Lights up when the ABS signal is entered (No. 6).
- Lights up when the cruise control is set (No. 7).

NOTE:

LED Nos. 2 and 8 do not come on.

DISPLAY

LED No.	Signal name	Symbol
1	N/P range switch	NP
2	R range switch	RR
3	D range switch	RD
4	3 range switch	R3
5	2 range switch	R2
6	1 range switch	R1
7	Diagnosis switch	SS
8	—	—
9	—	—
10	—	—

NP	RR	RD	R3	R2
R1	SS	—	—	—

1	2	3	4	5
6	7	8	9	10

Q: MODE FA1

— SWITCH 2 (SW2) —


Reference values

- Lights up when the N or P range is selected (No. 1).
- Lights up when the R range is selected (No. 2).
- Lights up when the D range is selected (No. 3).
- Lights up when the 3 range is selected (No. 4).
- Lights up when the 2 range is selected (No. 5).
- Lights up when the 1 range is selected (No. 6).
- Lights up when the diagnosis switch is connected (No. 7).

NOTE:

If each LED does not illuminate in the above conditions, inhibitor switch malfunction may occur. Perform diagnostics on inhibitor switch. <Ref. to 2-7 [T10AN0].☆2>

1. Electrical Components Location



B5M0402A

Connector No.	(AB1)	(AB2)	(AB3)	(AB6)	(AB7)	(AB8)	(AB9)	(AB10)
Pole	7	3	3	12	3	3	3	3
Color	Yellow	Yellow	Yellow	Yellow	Yellow	Yellow	Yellow	Yellow
Male/Female	Male	Female	Female	Female	Male	Male	Male	Female