

13.Drain Valve

A: SPECIFICATION

Canister is a non-disassembled part, so do not remove the drain valve from canister.

Refer to "Canister" for removal and installation procedure. <Ref. to EC(H4DOTC)-7, REMOVAL, Canister.> <Ref. to EC(H4DOTC)-7, INSTALLATION, Canister.>