

22.Piston

A: SPECIFICATION

Refer to “Cylinder Block” for removal and installation procedures of pistons. <Ref. to ME(H4DOTC)-65, REMOVAL, Cylinder Block.> <Ref. to ME(H4DOTC)-68, INSTALLATION, Cylinder Block.>