


29. Reduction Drive Gear

A: REMOVAL

- 1) Remove the transmission assembly from vehicle body. <Ref. to 4AT-34, REMOVAL, Automatic Transmission Assembly.>
- 2) Remove the rear wheel speed sensor, and separate the extension case from transmission case. <Ref. to 4AT-67, REMOVAL, Extension Case.>
- 3) Remove the reduction driven gear. <Ref. to 4AT-74, REMOVAL, Reduction Driven Gear.>
- 4) Using the ST, extract the reduction drive gear.

ST1 499737100 PULLER
ST2 899524100 PULLER SET




(A) Reduction drive gear

B: INSTALLATION

- 1) Install the reduction drive gear assembly.

NOTE:

Press-fit it to the bottom of bearing shoulder completely.




(A) Reduction drive gear

- 2) Install the reduction driven gear. <Ref. to 4AT-74, INSTALLATION, Reduction Driven Gear.>
- 3) Join the transmission case and the extension case, and then install the rear vehicle speed sensor. <Ref. to 4AT-67, INSTALLATION, Extension Case.>
- 4) Install the transmission assembly to the vehicle. <Ref. to 4AT-36, INSTALLATION, Automatic Transmission Assembly.>

C: DISASSEMBLY


- 1) Take out the seal ring.



(A) Seal ring
(B) Reduction drive shaft


- 2) Remove the ball bearing using ST.

ST 498077600 REMOVER



(A) Ball bearing
(B) Reduction drive gear


- 3) Apply vaseline to the outer surface of seal ring and shaft groove.



(A) Reduction drive gear

D: ASSEMBLY

- 1) Press-fit the reduction drive gear to shaft.
- 2) Press-fit the new ball bearing into reduction drive gear.
- 3) Apply vaseline onto the seal ring outer surface and shaft grooves.
- 4) Apply ATF to new seal rings and install them.



(A) Seal ring

(B) Reduction drive shaft

E: INSPECTION

- Rotate the bearing by hand, and check that it rotates smoothly.
- Check parts for holes, damage or adhesion of dust and other foreign particles.
- Inspect the extension end play, and adjust it to the standard value. <Ref. to 4AT-72, ADJUSTMENT, Transfer Clutch.>