


### 8. Rear Link

#### A: REMOVAL


- 1) Lift up the vehicle, and then remove the rear wheels.
- 2) Remove the rear stabilizer. <Ref. to RS-8, REMOVAL, Rear Stabilizer.>
- 3) Support the rear arm horizontally using a transmission jack.



RS-00052

(1) Rear arm  
(2) Transmission jack

- 4) Remove the bolts which secures the rear link to the rear arm.




RS-00080

- 5) Place alignment marks on the rear link adjusting bolt and sub frame.
- 6) Remove the bolt which secures the rear link to the sub frame, then remove the rear link.

#### CAUTION:

**When loosening the adjusting bolt, make sure to fix the bolt head in place when loosening the nut.**




RS-00081

#### B: INSTALLATION

- 1) Support the rear arm horizontally using a transmission jack.
- 2) Using new self-locking nuts, install the rear link.

#### NOTE:

Tighten the self-locking nut with the bolt head fixed in place when installing the adjusting bolt.



RS-00052

(1) Rear arm  
(2) Transmission jack

#### Tightening torque:

**Rear link-to-Sub frame**

**120 N·m (12.2 kgf·m, 89 ft-lb)**

**Rear link-to-Rear arm**

**57 N·m (5.8 kgf·m, 42 ft-lb)**


- 3) Inspect the wheel alignment and adjust if necessary.

#### C: DISASSEMBLY

Using the ST A and ST B, press the bushing out.

STA 20099AE000 INSTALLER & REMOVER


STB 20099AE000 INSTALLER & REMOVER



RS-00083

### D: ASSEMBLY

Using the ST A and ST B, press-fit the bushing.  
STA 20099AE000 INSTALLER & REMOVER  
STB 20099AE000 INSTALLER & REMOVER



### E: INSPECTION

- 1) Visually check the rear link for abnormal fatigue or damage.
- 2) Visually check the bushing for abnormal fatigue or damage.