

8. Trunk Lid

A: REMOVAL


1. TORSION BAR

- 1) Open the trunk lid.
- 2) Using the ST, remove the torsion bar from the hinge link.

ST 927780000 REMOVER

CAUTION:


During removal and installation, handle the torsion bar carefully, because it will generate reactive force.



- 3) Remove the torsion bars RH/LH.

2. TRUNK LID ARM


- 1) Disconnect the ground cable from the battery.
- 2) Open the trunk lid to remove the trunk lid trim, trunk lid arm cover and trunk room trim. <Ref. to EI-67, REMOVAL, Trunk Room Trim.>
- 3) Disconnect the trunk lid release cable. <Ref. to SL-42, REMOVAL, Trunk Lid Lock Assembly.>
- 4) Disconnect the connectors, and remove the harness clip, etc.
- 5) Remove the trunk lid mounting bolts, to remove the trunk lid panel from the trunk lid arm.



- 6) Remove the torsion bar from the trunk lid hinge link. <Ref. to EB-24, TORSION BAR, REMOVAL, Trunk Lid.>

- 7) Remove the rear shelf trim. <Ref. to EI-66, REMOVAL, Rear Shelf Trim.>


- 8) Remove the bolts, then remove the trunk lid arm.



EB-00157


3. TRUNK LID PANEL

- 1) Disconnect the ground cable from the battery.
- 2) Open the trunk lid to remove the trunk lid trim and trunk lid arm cover. <Ref. to EI-67, TRUNK ROOM TRIM, REMOVAL, Trunk Room Trim.>
- 3) Disconnect the connector to remove the trunk lid harness.
- 4) Remove the trunk lid lock assembly. <Ref. to SL-42, REMOVAL, Trunk Lid Lock Assembly.>
- 5) Remove the trunk lid garnish. <Ref. to EI-71, REMOVAL, Trunk Lid Garnish.>
- 6) Remove the license plate light cover.



EB-00159

- 7) Remove the bolts, then remove the trunk lid panel from the trunk lid arm.



EB-00066

B: INSTALLATION

- 1) Install in the reverse order of removal.
- 2) Apply grease to the rotating area of hinges and the torsion bar.
- 3) Install while paying attention to make a uniform clearance around the trunk lid panel. For the dimension of clearance, refer to "SPECIFICATION" in "General Description". <Ref. to EB-2, SPECIFICATION, General Description.>

Tightening torque:

Refer to "COMPONENT" of "General Description".

<Ref. to EB-11, REAR GATE PANEL, COMPONENT, General Description.>