



2. Throttle Body

A: REMOVAL

- 1) Disconnect the ground cable from battery.



- 2) Remove the air intake boot assembly. <Ref. to IN(H4SO)-8, REMOVAL, Air Intake Boot.>
- 3) Disconnect the throttle position sensor connector (A).
- 4) Remove the bolts (B) which secure the throttle body to the multi-function duct assembly, and remove the throttle body.



B: INSTALLATION

Install in the reverse order of removal.

NOTE:

Use a new gasket.



Tightening torque:

8 N·m (0.8 kgf·m, 5.9 ft-lb)

C: INSPECTION

1. THROTTLE SENSOR (METHOD WITH CIRCUIT TESTER)

- 1) Warm up the engine.
- 2) Remove the glove box lid assembly. <Ref. to EI-65, REMOVAL, Glove Box.>
- 3) Turn the ignition switch to ON. (engine OFF)
- 4) Measure the voltage between ECM connector terminals.



Throttle sensor	Accelerator pedal	Terminal No.	Standard
Main	Not depressed	18 (+) and 29 (-)	Approx. 0.9 V
Sub	Not depressed	28 (+) and 29 (-)	Approx. 1.7 V

- 5) After inspection, install the related parts in the reverse order of removal.

2. THROTTLE SENSOR (METHOD WITH SUBARU SELECT MONITOR)

- 1) Warm up the engine.
- 2) Turn the ignition switch to ON. (engine OFF)
- 3) Read the throttle opening angle signal and voltage of throttle sensor using Subaru Select Monitor. <Ref. to EN(H4SO)(diag)-34, READ CURRENT DATA FOR ENGINE (NORMAL MODE), OPERATION, Subaru Select Monitor.>

Throttle sensor	Throttle opening angle signal	Standard
Main	5%	Approx. 0.9 V
Sub	5%	Approx. 1.7 V

3. OTHER INSPECTIONS

- 1) Check that the throttle body has no deformation, cracks or other damages.
- 2) Check that the engine coolant hose has no cracks, damage or loose part.