

General Description

COOLING

1. General Description


A: SPECIFICATION

Cooling system			Electric fan + Forced engine coolant circulation system			
Total engine coolant capacity			ℓ (US qt, Imp qt)			
Water pump	Type	Centrifugal impeller type				
	Discharge performance	Discharge rate	ℓ (US gal, Imp gal) /min.	240 (63.4, 52.8)		
		Pump speed — Discharge pressure		4,956 rpm — 140 kPa (14.0 mAq)		
		Engine coolant temperature		80°C (176°F)		
	Impeller diameter	mm (in)		66 (2.60)		
	Number of impeller blades			8		
Thermostat	Pump sprocket outer diameter	mm (in)		60.60 (2.39)		
	Type	Wax pellet type				
	Starting temperature to open	80 — 84°C (176 — 183°F)				
	Fully opens	95°C (203°F)				
	Valve lift	mm (in)	9.0 (0.354) or more			
Radiator fan	Valve bore	mm (in)	35 (1.38)			
	Motor input	Main fan	W	200		
		Sub fan	W	200		
	Fan diameter / Blade	Main fan	320 mm (12.6 in)/5			
Radiator	Sub fan	320 mm (12.6 in)/7				
	Type	Down flow, pressure type				
	Core dimensions	Width × Height × Thickness	mm (in)	689.8 × 349.2 × 16 (27.16 × 13.75 × 0.63)		
	Pressure range in which cap valve is open	kPa (kg/cm ² , psi)	Positive pressure side	Standard 93 — 123 (0.95 — 1.25, 14 — 18)		
			Service limit	83 (0.85, 12)		
		Negative pressure side	Standard	-1.0 — -4.9 (-0.01 — -0.05, -0.1 — -0.7)		
	Fins	Corrugated fin type				
Reservoir tank	Capacity	ℓ (US qt, Imp qt)		0.45 (0.48, 0.40)		

	Recommended materials	Item number	Alternative
Coolant	SUBARU SUPER COOLANT (Concentrated type)	—	—
	SUBARU SUPER COOLANT (Diluted type)	K0670Y0001	
Water for dilution	Distilled water	—	Soft water or tap water
Cooling system protecting agent	Cooling system conditioner	SOA345001	—

B: COMPONENT

1. WATER PUMP AND WATER PIPE



CO-02659

(1)	Water pump ASSY	(6)	Oil pan upper
(2)	O-ring	(7)	Clip
(3)	Thermostat	(8)	Hose
(4)	Gasket	(9)	Water return pipe
(5)	Thermostat cover		

Tightening torque:N·m (kgf·m, ft·lb)


T1: 6.4 (0.7, 4.7)

T2: 16 (1.6, 11.8)

General Description

COOLING

2. ENGINE COOLANT TEMPERATURE SENSOR AND HEATER HOSE



CO-02609

(A) To the throttle body

(B) To the heater hose on body side

(C) To the throttle body

(1) Heater pipe

(4) Gasket

Tightening torque: N·m (kgf·m, ft·lb)

(2) Preheater hose

(5) Clip


T1: 19 (1.9, 14.0)

(3) Engine coolant temperature sensor

T2: 22 (2.2, 16.2)

3. RADIATOR AND RADIATOR FAN

- Radiator



CO-02604

(1) Radiator	(7) Radiator lower hose	(12) ATF pipe A
(2) Radiator upper bracket	(8) Radiator lower cushion	(13) ATF hose B
(3) Radiator upper cushion	(9) Drain plug	
(4) Radiator upper hose RH	(10) ATF hose A	
(5) Clip	(11) ATF pipe B	
(6) Radiator upper hose LH		


Tightening torque:N·m (kgf·m, ft·lb)

T: 12 (1.2, 8.9)

General Description

COOLING

- Radiator fan



(1) Radiator fan control unit	(6) Reservoir tank cap
(2) Radiator fan harness	(7) Reservoir tank
(3) Radiator sub fan motor	(8) Radiator fan shroud
(4) Radiator main fan motor	(9) Radiator main fan
(5) Over flow hose	(10) Radiator sub fan

Tightening torque:N·m (kgf·m, ft·lb)

T1: 2.6 (0.3, 1.9)

T2: 3.8 (0.4, 2.8)

T3: 6.3 (0.6, 4.6)


T4: 7.5 (0.8, 5.5)

C: CAUTION

- Wear appropriate work clothing, including a cap, protective goggles and protective shoes when performing any work.
- Remove contamination including dirt and corrosion before removal, installation or disassembly.
- Keep the disassembled parts in order and protect them from dust and dirt.
- Before removal, installation or disassembly, be sure to clarify the failure. Avoid unnecessary removal, installation, disassembly and replacement.
- Vehicle components are extremely hot after driving. Be wary of receiving burns from heated parts.
- Be sure to tighten fasteners including bolts and nuts to the specified torque.
- Place shop jacks or rigid racks at the specified points.
- Before disconnecting connectors of sensors or units, be sure to disconnect the ground cable from battery.
- Prepare a container and cloth to prevent scattering of engine coolant when performing work where engine coolant can be spilled. If the fuel spills, wipe it off immediately to prevent from penetrating into floor or flowing out for environmental protection.
- Follow all government and local regulations concerning disposal of refuse when disposing engine coolant.

D: PREPARATION TOOL

1. SPECIAL TOOL

ILLUSTRATION	TOOL NUMBER	DESCRIPTION	REMARKS
 ST1B022XU0	1B022XU0	SUBARU SELECT MONITOR III KIT	Used for troubleshooting the electrical system.

2. GENERAL TOOL

TOOL NAME	REMARKS
Circuit tester	Used for measuring resistance and voltage.
Radiator cap tester	Used for checking radiator and radiator cap.