


### 4. Muffler

#### A: REMOVAL

**CAUTION:**

Vehicle components are extremely hot after driving. Be wary of receiving burns from heated parts.

- 1) Lift up the vehicle.
- 2) Remove the muffler from rear exhaust pipe.




- 3) Apply a coat of spray type lubricant to the mating area of cushion rubber.
- 4) Remove the muffler from the cushion rubber.

**CAUTION:**


Be careful not to drop the muffler during removal.

**Tightening torque:**  
48 N·m (4.9 kgf-m, 35.4 ft-lb)



#### C: INSPECTION

- 1) Check the connections and welds for exhaust leaks.
- 2) Make sure there are no holes or rusting.
- 3) Check the cushion rubber for wear or crack.



#### B: INSTALLATION

Install in the reverse order of removal.

**NOTE:**

- Use a new gasket and self-locking nut.
- After assembling, degrease the lubricant which was applied to the cushion rubber while removing/installing.

# COOLING

# CO(H6DO)

---

	Page
1. General Description .....	2
2. Radiator Fan System .....	8
3. Engine Coolant .....	12
4. Water Pump .....	14
5. Thermostat .....	15
6. Radiator .....	17
7. Radiator Cap .....	20
8. Radiator Main Fan and Fan Motor .....	21
9. Radiator Sub Fan and Fan Motor .....	24
10. Reservoir Tank .....	25
11. Radiator Fan Control Unit .....	26
12. Engine Cooling System Trouble in General .....	27