

6. Floor Under Protector


A: REMOVAL

- 1) Lift up the vehicle.

NOTE:

A plate type lift cannot be used.

- 2) Remove the bolts and clips, and remove the front under protector.



B: INSTALLATION

Install each part in the reverse order of removal.

Tightening torque:

Refer to "COMPONENT" of "General Description". <Ref. to EI-2, FLOOR UNDER PROTECTOR, COMPONENT, General Description.>