

11.Read Current Data

A: OPERATION

For details concerning the operation procedure, refer to “PC application help for Subaru Select Monitor”.

B: LIST

Items to be displayed	Unit of measure	Remarks	Note
Trouble Code	—	DTC recorded in A/C CM	—
Engine Speed	rpm	Data value received by CAN	—
Heater Control Panel Setting Value (Driver's)	LO: 18°C (64°F) HI: 32°C (90°F)	Control panel display value	—
Heater Control Panel Setting Value (Passenger's)	LO: 18°C (64°F) HI: 32°C (90°F)	Control panel display value	—
Blower outlet Door Request Temperature	°C (°F)	A/C CM internal setting value	—
Blower outlet request temperature (Driver's)	°C (°F)	A/C CM internal setting value	—
Blower outlet request temperature (Passenger's)	°C (°F)	A/C CM internal setting value	—
Blower Fan Operating Condition	MANU/AUTO	A/C CM input value	—
A/C Operating Condition	MANU/AUTO	A/C CM input value	—
Fresh/Recircle Air Operating Condition	MANU/AUTO	A/C CM input value	—
Mode Operating Condition	MANU/AUTO	A/C CM input value	—
Rear Defogger	ON/OFF	A/C CM input value	—
In-vehicle Sensor Temperature	°C (°F)	A/C CM input value	—
Evaporator Temp.	°C (°F)	A/C CM input value	—
Quantity of Sunload	W/m ²	A/C CM input value	—
Refrigerant Pressure	MPa	A/C CM input value	—
Refrigerant Flow	kg/h	A/C CM input value	—
Airmix Door Actuator Position (Driver's)	%	A/C CM input value	—
Airmix Door Actuator Position (Passenger's)	%	A/C CM input value	—
Fresh/Recircle Air Door Actuator Position	%	A/C CM input value	—
Mode Door Actuator Position	%	A/C CM input value	—
Heater Water Temperature	°C (°F)	Data value received by CAN	—
Ambient Air Temperature	°C (°F)	Data value received by CAN	—
Vehicle Speed	km/h	Data value received by CAN	—
Accel. Opening Angle	%	Data value received by CAN	—
Airmix Actuator Position Target (Driver's)	%	A/C CM input value	—
Airmix Actuator Position Target (Passenger's)	%	A/C CM input value	—
Fresh/Recircle Air Door Actuator Position Target	%	A/C CM input value	—
Mode Door Actuator Position Target	%	A/C CM input value	—
Blower Fan Level	Level	A/C CM output value	—
Variable Flow Change Solenoid Duty	%	A/C CM output value	—
Evaporator Temperature Target	°C (°F)	A/C CM input value	—
Variable Load Compressor Torque Value	Nm	A/C CM input value	—
Request idle engine speed	rpm	A/C CM output value	—
Request engine speed	0: No request 1: Cooling H 2: Heating H 3: Cooling L 4: Heating L	A/C CM output value	—
Discharge pressure	MPa	A/C CM input value	—
Intake pressure	MPa	A/C CM input value	—
Cooler request distinction	No request/Request	A/C CM output value	—
Heater request distinction	No request/Request	A/C CM output value	—

NOTE:

For detailed operation procedures, refer to “PC application help for Subaru Select Monitor”.