

Diagnostics for A/C System Malfunction

HVAC SYSTEM (DIAGNOSTICS)

6. Diagnostics for A/C System Malfunction


A: A/C OR SELF-DIAGNOSIS SYSTEMS DO NOT OPERATE

TROUBLE SYMPTOM:

- Set temperature is not indicated on the display, switch LEDs are faulty and switches do not operate.
- Self-diagnosis system does not operate.

WIRING DIAGRAM:

- Auto A/C model




AC-02397

Diagnostics for A/C System Malfunction

HVAC SYSTEM (DIAGNOSTICS)

- Manual A/C model



AC-02405

Step	Check	Yes	No
1 CHECK CONNECTOR. Check for poor contact of the power supply circuit connectors.	Is there poor contact of connector?	Repair the connector.	Go to step 2.
2 CHECK FUSE. 1) Turn the ignition switch to OFF. 2) Remove fuses No. 4, No. 7, No. 12 and No. 31 from the fuse & relay box. 3) Check the condition of fuse.	Is the fuse blown out?	Replace the fuse.	Go to step 3.

Diagnostics for A/C System Malfunction

HVAC SYSTEM (DIAGNOSTICS)

Step	Check	Yes	No
3 CHECK A/C CONTROL PANEL POWER CIRCUIT. 1) Remove the A/C control panel. 2) Disconnect the A/C control panel harness connector. 3) Turn the ignition switch to ACC, and measure the voltage between A/C control panel harness connector terminal and chassis ground. Connector & terminal Auto A/C model (i88) No. 5 (+) — Chassis ground (-): Manual A/C model (i88) No. 7 (+) — Chassis ground (-):	Is the voltage 10 V or more?	Go to step 4.	Check for open or short circuit in the harness between A/C control panel and fuse.
4 CHECK A/C CONTROL PANEL POWER CIRCUIT. Measure the voltage between A/C control panel harness connector terminal and chassis ground after turning the ignition switch to ON. Connector & terminal Auto A/C model (i88) No. 6 (+) — Chassis ground (-): Manual A/C model (i88) No. 1 (+) — Chassis ground (-):	Is the voltage 10 V or more?	Go to step 5.	Check for open or short circuit in the harness between A/C control panel and fuse.
5 CHECK A/C CONTROL PANEL GROUND POWER CIRCUIT. Measure the resistance of harness between A/C control panel and chassis ground after turning the ignition switch to OFF. Connector & terminal Auto A/C model (i88) No. 12 — Chassis ground: Manual A/C model (i88) No. 11 — Chassis ground:	Is the resistance less than 10 Ω?	Go to step 6.	Repair the harness for ground line.
6 CHECK A/C CONTROL MODULE POWER CIRCUIT. Measure the voltage between A/C control module connector terminal and chassis ground after turning the ignition switch to OFF. Connector & terminal (i80) No. 1 (+) — Chassis ground (-):	Is the voltage 10 V or more?	Go to step 7.	Check for open or short circuit in the harness between A/C control module and fuse.
7 CHECK A/C CONTROL MODULE POWER CIRCUIT. Measure the voltage between A/C control module connector terminal and chassis ground after turning the ignition switch to ON. Connector & terminal (i80) No. 2 (+) — Chassis ground (-): (i80) No. 3 (+) — Chassis ground (-):	Is the voltage 10 V or more?	Go to step 8.	Check for open or short circuit in the harness between A/C control module and fuse.
8 CHECK A/C CONTROL MODULE GROUND CIRCUIT. Measure the resistance of harness between A/C control module and chassis ground. Connector & terminal (i80) No. 6 — Chassis ground:	Is the resistance less than 5 Ω?	Go to step 9.	Repair the harness for ground line.

Diagnostics for A/C System Malfunction

HVAC SYSTEM (DIAGNOSTICS)

Step	Check	Yes	No
9 CHECK COMMUNICATION CIRCUIT. Check the continuity of harness between A/C control panel and A/C control module. <i>Connector & terminal</i> <i>Auto A/C model</i> (i88) No. 10 — (i80) No. 18: (i88) No. 4 — (i80) No. 7: <i>Manual A/C model</i> (i88) No. 6 — (i80) No. 18: (i88) No. 12 — (i80) No. 7:	Is there continuity?	Go to step 10.	Repair the harness.
10 CHECK COMMUNICATION CIRCUIT HARNESS. Check the continuity between communication circuit harness and chassis ground. <i>Connector & terminal</i> (i80) No. 18 — <i>Chassis ground</i> : (i80) No. 7 — <i>Chassis ground</i> :	Is there continuity?	Repair or replace the short circuit of the harness.	Go to step 11.
11 CHECK COMMUNICATION CIRCUIT HARNESS. Check the continuity between communication circuit harness. <i>Connector & terminal</i> (i80) No. 18 — No. 7:	Is there continuity?	Repair or replace the short circuit of the harness.	Replace the A/C CM. <Ref. to AC-48, REMOVAL, Control Unit.>

Diagnostics for A/C System Malfunction

HVAC SYSTEM (DIAGNOSTICS)


B: BLOWER MOTOR DOES NOT ROTATE

TROUBLE SYMPTOM:

- Blower motor does not rotate.
- Blower motor does not rotate in "HI".

WIRING DIAGRAM:

- Auto A/C model




AC-02398

Diagnostics for A/C System Malfunction

HVAC SYSTEM (DIAGNOSTICS)

- Manual A/C model



AC-02406

Step	Check	Yes	No
1 CHECK CONNECTOR. Check for poor contact of the power supply circuit connectors.	Is there poor contact of connector?	Repair the connector.	Go to step 2.
2 CHECK FUSE. 1) Remove fuse No. 22 and 7 from fuse & relay box, and fuse No. 4 and 5 from the main fuse box. 2) Check the condition of fuse.	Is any fuse blown out?	Replace the fuse.	Go to step 3.
3 CHECK POWER SUPPLY FOR BLOWER MOTOR. 1) Turn the ignition switch to ON. 2) Turn the blower switch to ON. 3) Measure the voltage between blower motor and chassis ground. <i>Connector & terminal (i185) No. 2 (+) — Chassis ground (-):</i>	Is the voltage 10 V or more?	Go to step 5.	Go to step 4.

Diagnostics for A/C System Malfunction

HVAC SYSTEM (DIAGNOSTICS)

Step	Check	Yes	No
4 CHECK BLOWER MOTOR RELAY. 1) Turn the ignition switch to OFF. 2) Remove the blower motor relay. 3) Check the blower motor relay. <Ref. to AC-25, CHECK RELAY, INSPECTION, Relay and Fuse.>	Is the relay OK?	Repair the open circuit of blower motor power supply line harness.	Replace the blower motor relay. <Ref. to AC-25, LOCATION, Relay and Fuse.>
5 CHECK BLOWER MOTOR. 1) Disconnect the connector from blower motor. 2) Make sure the blower motor runs. <Ref. to AC-32, INSPECTION, Blower Motor.>	Does the blower motor run?	Auto A/C model Go to step 6 . Manual A/C model Go to step 8 .	Replace the blower motor. <Ref. to AC-31, REMOVAL, Blower Motor.>
6 CHECK A/C CONTROL MODULE. Replace the A/C control module with a properly functioning part.	Does the blower motor run?	Replace the A/C CM. <Ref. to AC-48, REMOVAL, Control Unit.>	Go to step 7 .
7 CHECK HARNESS. 1) Disconnect the auto A/C control module and the power transistor connector. 2) Using the tester, check the open or short circuit between terminals. <i>Connector & terminal</i> <i>Check open circuit</i> <i>(i185) No. 1 — (i183) No. 5:</i> <i>(i183) No. 3 — (i181) No. 8:</i> <i>(i183) No. 1 — (i181) No. 9:</i> <i>(i183) No. 4 — Chassis ground:</i> <i>Check short circuit</i> <i>(i185) No. 1 — Chassis ground:</i> <i>(i183) No. 3 — Chassis ground:</i> <i>(i183) No. 1 — Chassis ground:</i>	Is harness normal?	Replace the power transistor. <Ref. to AC-33, REMOVAL, Power Transistor (Auto A/C Model).>	Repair the harness.
8 CHECK BLOWER RESISTOR. Check the blower resistor. <Ref. to AC-35, INSPECTION, Blower Resistor (Manual A/C Model).>	Is the blower resistor OK?	Go to step 9 .	Replace the blower resistor. <Ref. to AC-34, REMOVAL, Blower Resistor (Manual A/C Model).>
9 CHECK BLOWER FAN SWITCH. Check the blower fan switch. <Ref. to AC-47, BLOWER SWITCH (MANUAL A/C MODEL), INSPECTION, Control Panel.>	Is the blower fan switch OK?	Repair the harness.	Replace the control panel. <Ref. to AC-44, MANUAL A/C MODEL, REMOVAL, Control Panel.>


C: BLOWER MOTOR TURNS AROUND EARLY

TROUBLE SYMPTOM:

- The blower rotates even though the blower switch is not turned on.
- The blower motor continues to rotate at high speed. (Not adjustable.)

WIRING DIAGRAM:

- Auto A/C model




AC-02398

Diagnostics for A/C System Malfunction

HVAC SYSTEM (DIAGNOSTICS)

- Manual A/C model



AC-02406

Step	Check	Yes	No
1 CHECK BLOWER MOTOR CIRCUIT. 1) Turn the ignition switch to OFF. 2) Disconnect the power transistor or the blower resistor connector. 3) Use a tester to measure the resistance between each terminal and chassis ground. Connector & terminal Auto A/C model (i183) No. 5 — Chassis ground: Manual A/C model (i184) No. 4 — Chassis ground: (i185) No. 1 — Chassis ground: (i182) No. 2 — Chassis ground: (i182) No. 3 — Chassis ground:	Is there continuity?	Repair or replace the short circuit of the harness.	Go to step 2.

Diagnostics for A/C System Malfunction

HVAC SYSTEM (DIAGNOSTICS)



Step	Check	Yes	No
2 CHECK HARNESS. 1) Remove the A/C CM. 2) Use a tester to measure the resistance between the power transistor connector and chassis ground. Connector & terminal <i>(i183) No. 1 — Chassis ground:</i>	Is there continuity?	Repair or replace the short circuit of the harness.	For auto A/C model, Go to step 3. For manual A/C model, replace the blower resistor. <Ref. to AC-34, REMOVAL, Blower Resistor (Manual A/C Model).>
3 CHECK POWER TRANSISTOR. 1) Connect the disconnected connectors. 2) Turn the ignition switch to ON. 3) Use a tester to measure the voltage between the power transistor connector and chassis ground. Connector & terminal <i>(i183) No. 1 (+) — Chassis ground (-):</i>	Is the voltage approx. 10 V when the fan switch is set to 1st, and approx. 1 V when set to 6th?	Replace the power transistor. <Ref. to AC-33, REMOVAL, Power Transistor (Auto A/C Model).>	Go to step 4.
4 CHECK A/C CM. 1) Turn the fan switch to OFF. 2) Disconnect the power transistor connector. 3) Use a tester to measure the resistance between the power transistor connector and chassis ground. Connector & terminal <i>(i183) No. 1 — Chassis ground:</i>	When the fan switch is OFF and other than OFF, does the resistance change?	Replace the power transistor. <Ref. to AC-33, REMOVAL, Power Transistor (Auto A/C Model).>	Replace the A/C CM. <Ref. to AC-48, REMOVAL, Control Unit.>

Diagnostics for A/C System Malfunction

HVAC SYSTEM (DIAGNOSTICS)

D: COMPARTMENT TEMPERATURE DOES NOT CHANGE, OR A/C SYSTEM DOES NOT RESPOND PROMPTLY

WIRING DIAGRAM:



AC-02130

Step	Check	Yes	No
1 CHECK DTC. 1) Turn the ignition switch to ON. 2) Read the DTC of the A/C system using the Subaru Select Monitor.	Is DTC detected?	Perform the diagnosis according to DTC. Go to step 2.	
2 CHECK AMOUNT OF REFRIGERANT. Check the refrigerant pressure. <Ref. to AC-19, PROCEDURE, Refrigerant Pressure with Manifold Gauge Set.>	Is the refrigerant pressure within the standard?	Go to step 3.	Check and repair the refrigerant leakage.

Diagnostics for A/C System Malfunction

HVAC SYSTEM (DIAGNOSTICS)

Step	Check	Yes	No
3 CHECK POWER SUPPLY OF CONTROL MODULE. 1) Disconnect the A/C CM connector. 2) Turn the ignition switch to ON. 3) Using a tester, measure the voltage between the connector terminal and chassis ground. <i>Connector & terminal</i> <i>(i80) No. 2 (+) — Chassis ground (-):</i>	Is the voltage 10 V or more?	Go to step 4.	Repair the defective power supply circuit.
4 CHECK CONTROL MODULE. 1) Disconnect the compressor solenoid connector. 2) Turn the ignition switch to ON. 3) Using the tester, measure the voltage between terminals. <i>Connector & terminal</i> <i>(i181) No. 2 — Chassis ground:</i>	Is the voltage 10 V or more?	Go to step 5.	Repair the defective harness.
5 CHECK HARNESS. 1) Disconnect the A/C CM connector. 2) Using a tester, check continuity between terminals. <i>Connector & terminal</i> <i>(B506) No. 2 — (i181) No. 2:</i>	Is there continuity?	Go to step 6.	Repair or replace the open circuit.
6 CHECK GROUND. Using a tester, check the continuity between the connector terminal and chassis ground. <i>Connector & terminal</i> <i>(B506) No. 1 — Chassis ground:</i>	Is there continuity?	Go to step 7.	Repair or replace the open circuit.
7 CHECK COMPRESSOR SOLENOID. Using the tester, measure the resistance between compressor solenoid terminals. <i>Connector & terminal</i> <i>(B506) No. 1 — No. 2:</i>	Is the resistance 10 — 12 Ω?	Replace the A/C CM. <Ref. to AC-48, REMOVAL, Control Unit.>	Replace the compressor solenoid. <Ref. to AC-49, REMOVAL, Compressor.>