

General Description

LIGHTING SYSTEM

1. General Description

A: SPECIFICATION

Headlight	High beam	12 V — 60 W	
	Low beam	12 V — 55 W	
Front turn signal light		12 V — 21 W	
Clearance/parking light		12 V — 5 W	
Side marker light		12 V — 5 W	
Front fog light		12 V — 55 W	
Side turn signal light (C6 model)		12 V — 1.4 W (LED)	
Rear combination light	Sedan model	Tail/stop light	12 V — 5 / 21 W
		Turn signal light	12 V — 21 W
		Back-up light	12 V — 16 W
	OUTBACK model	Tail light	12 V — 5 W
		Stop light	12 V — 21 W
		Turn signal light	12 V — 21 W
Rear finisher light	Sedan model	Tail light	12 V — 5 W
	OUTBACK model	Tail light	12 V — 5 W
		Back-up light	12 V — 16 W
License plate light		12 V — 5 W	
High-mounted stop light	Sedan model	12 V — 1 W (LED)	
	OUTBACK model	12 V — 2.1 W (LED)	
Room light		12 V — 8 W	
Spot map light		12 V — 8 W	
Luggage room light		12 V — 5 W	
Trunk room light		12 V — 5 W	
Glove box light		12 V — 1.4 W	
Door step light		12 V — 5 W	

B: CAUTION

- Before disassembling or reassembling parts, always disconnect the battery ground cable from battery. When replacing the audio, control module and other parts provided with memory functions, record the memory contents before disconnecting the battery ground cable. Otherwise, the memory is cleared.
- Reassemble the parts in the reverse order of disassembly procedure unless otherwise indicated.
- Connect the connectors securely during reassembly.
- After reassembly, make sure that the functional parts operate normally.
- Yellow connectors and harnesses with yellow tapes around them are the connectors and harnesses for the airbag system. Using a tester above such circuits may cause malfunction of airbag system. Follow the cautions for the airbag system in this case. <Ref. to AB-9, CAUTION, General Description.>
- Be careful not to damage the airbag system wiring harness when servicing electrical parts and switches.

C: PREPARATION TOOL

1. GENERAL TOOL

TOOL NAME	REMARKS
Circuit tester	Used for measuring resistance and voltage.
TORX® T30	Used for removing/installing driver's airbag module.