

## 26. Fuel Level Sensor

### A: REMOVAL

#### WARNING:

Place "NO OPEN FLAMES" signs near the working area.

#### CAUTION:


- Be careful not to spill fuel.
- If the fuel gauge indicates that two thirds or more of the fuel is remaining, be sure to drain fuel before starting work to avoid the fuel to spill.

#### NOTE:


The fuel level sensor is built in fuel pump assembly.

1) Remove the fuel pump assembly. <Ref. to FU(H6DO)-71, REMOVAL, Fuel Pump.>


2) Disconnect the connector from the fuel filter assembly.



3) Remove the harness from the claw of fuel chamber assembly.



4) Press two claws (A) of the fuel level sensor, and slide the fuel level sensor in the direction of the arrow to remove the fuel level sensor.



### B: INSTALLATION


Install in the reverse order of removal.

### C: INSPECTION

- 1) Check that the fuel level sensor has no damage.
- 2) Measure the fuel level sensor float position.

#### NOTE:

When inspecting the fuel level sensor, perform the work with the sensor installed to the fuel pump.




- (1) FULL
- (2) EMPTY
- (3) Fuel tank seating surface

Float position	Standard
FULL to Fuel tank seating surface (A)	$126.4 \pm 4$ mm ( $4.976 \pm 0.157$ in)
EMPTY to Fuel tank seating surface (B)	$11.0 \pm 4$ mm ( $0.433 \pm 0.157$ in)

# Fuel Level Sensor

## FUEL INJECTION (FUEL SYSTEMS)

3) Measure the resistance between fuel level sensor terminals.



Float position	Terminal No.	Standard
FULL (A)	1 and 4	$8.7 \pm 1.0 \Omega$
EMPTY (B)		$139.1 \pm 2.0 \Omega$