

## 12. Engine Cooling System Trouble in General

### A: INSPECTION

Trouble	Possible cause	Corrective action
Over-heating	a. Insufficient engine coolant	Replenish engine coolant, inspect for leakage, and repair it if necessary.
	b. Defective thermostat	Replace.
	c. Malfunction of water pump	Replace.
	d. Clogged engine coolant passage	Clean.
	e. Improper ignition timing	Inspect and repair the ignition control system. <Ref. to EN(H6DO)(diag)-2, PROCEDURE, Basic Diagnostic Procedure.>
	f. Clogged or leaking radiator	Clean, repair or replace.
	g. Defective radiator cap	Replace.
	h. Improper engine oil in engine coolant	Replace the engine coolant. If ineffective, check, repair or replace engine components.
	i. Air/fuel mixture ratio too lean	Inspect and repair the fuel injection system. <Ref. to EN(H6DO)(diag)-2, PROCEDURE, Basic Diagnostic Procedure.>
	j. Excessive back pressure in exhaust system	Clean or replace.
	k. Insufficient clearance between piston and cylinder	Adjust or replace.
	l. Dragging brake	Adjust.
	m. Defective radiator fan	Inspect the radiator fan relay, engine coolant temperature sensor or fan motor and replace them.
	a. Ambient temperature extremely low	Partly cover radiator front area.
Over-cooling	b. Defective thermostat	Replace.
	a. Loosened or damaged connecting units on hoses	Repair or replace.
Engine coolant leaks	b. Leakage from water pump	Replace.
	c. Leakage from water pipe	Repair or replace.
	d. Leakage around cylinder head gasket	Retighten cylinder head bolts or replace cylinder head gasket.
	e. Damaged or cracked cylinder head and cylinder block	Repair or replace.
	f. Damaged or cracked thermostat cover	Repair or replace.
	g. Leakage from radiator	Repair or replace.
	a. Defective radiator fan	Replace.
Noise	b. Defective water pump bearing	Replace water pump.
	c. Defective water pump mechanical seal	Replace water pump.

## **Engine Cooling System Trouble in General**

COOLING

---

# LUBRICATION

# *LU(H6DO)*

---

	Page
1. General Description .....	2
2. Oil Pressure System .....	7
3. Engine Oil .....	9
4. Oil Pan .....	11
5. Oil Pump .....	12
6. Oil Pressure Switch .....	14
7. Engine Oil Filter .....	15
8. Oil Cooler .....	16
9. Oil Level Switch .....	17
10. Engine Lubrication System Trouble in General .....	24