

19. ATF Cooler Pipe and Hose


A: REMOVAL

1) Remove the collector cover.

NOTE:

Follow the steps below when removing the collector cover.

- (1) Pull up the two points at the rear (A).
- (2) Pull up the two points at the front (B) while moving them forward.



2) Remove the battery.

3) Lift up the vehicle.


4) Remove the under cover. <Ref. to EI-32, REMOVAL, Front Under Cover.>

5) Remove the front exhaust pipe. <Ref. to EX(H6DO)-4, REMOVAL, Front Exhaust Pipe.>

6) Disconnect the ATF radiator inlet and outlet hoses from the radiator.

NOTE:


- Do not use a screwdriver or other pointed tools.
- If it is hard to remove the ATF radiator hose, wrap the hose with cloth to protect it from damage, turn it with pliers, and pull it straight out by hand.



7) Disconnect the ATF AT inlet and outlet hoses from the ATF cooler pipe.

NOTE:

- Do not use a screwdriver or other pointed tools.
- If it is hard to remove the ATF AT hose, wrap the hose with cloth to protect it from damage, turn it with pliers, and pull it straight out by hand.




8) Remove the oil charge pipe. <Ref. to 5AT-61, REMOVAL, Oil Charge Pipe.>

9) Remove the ATF cooler inlet pipe and outlet pipe from the transmission.

NOTE:

When disconnecting the ATF cooler outlet pipe, be careful not to lose the ball and spring used together with the retaining screw.



(A) ATF cooler outlet pipe


(B) ATF cooler inlet pipe

10) Lower the vehicle.

ATF Cooler Pipe and Hose


AUTOMATIC TRANSMISSION

11) Remove the ATF cooler pipe assembly mounting bolt.



12) Remove the engine coolant reservoir tank. <Ref. to CO(H6DO)-25, REMOVAL, Reservoir Tank.>

13) Detach the A/C pipe from clip.



14) Remove the ATF cooler pipe from frame.

CAUTION:

Be careful not to bend A/C pipe.

B: INSTALLATION


1) Install the ATF cooler pipe to frame.

CAUTION:

Be careful not to bend the A/C pipe, when installing the ATF cooler pipe.

Tightening torque:

7.5 N·m (0.8 kgf·m, 5.5 ft-lb)



2) Install the A/C pipe to clip.

3) Install the engine coolant reservoir tank. <Ref. to CO(H6DO)-25, INSTALLATION, Reservoir Tank.>

4) Lift up the vehicle.

5) Install the ATF cooler inlet and outlet pipes with new gaskets.

NOTE:


Use a new bolt for the converter case joint.

Tightening torque:

T1: 38 N·m (3.9 kgf·m, 28.0 ft-lb)

T2: 40 N·m (4.1 kgf·m, 29.5 ft-lb)

T3: 45 N·m (4.6 kgf·m, 33.2 ft-lb)




6) Install the oil charge pipe. <Ref. to 5AT-61, INSTALLATION, Oil Charge Pipe.>

7) Connect the ATF AT inlet and outlet hoses to the ATF cooler pipe on the transmission side.

NOTE:


- Use a new ATF AT hose.
- Install so that the ATF AT hose is not folded over, excessively bent or twisted.
- Insert the ATF AT hose into the specified position.



8) Connect the ATF radiator inlet and outlet hoses to the ATF cooler pipe on radiator side.

NOTE:

- Use a new ATF radiator hose.
- Install so that the ATF radiator hose is not folded over, excessively bent or twisted.
- Insert the ATF radiator hose into the specified position.



9) Install the front exhaust pipe. <Ref. to EX(H6DO)-5, INSTALLATION, Front Exhaust Pipe.>

10) Install the under cover. <Ref. to EI-32, INSTALLATION, Front Under Cover.>

11) Lower the vehicle.

12) Install the battery.

13) Check the ATF level. <Ref. to 5AT-28, INSPECTION, Automatic Transmission Fluid.>

NOTE:

Make sure there are no ATF leaks in joints between the transmission, radiator, ATF cooler pipes, and ATF cooler hoses.

14) Install the collector cover.

C: INSPECTION

Repair or replace each faulty ATF hose, ATF cooler pipes, clamps, and washers found in the inspection below.

- 1) Check for ATF leaks in joints between the transmission, radiator, ATF cooler pipes, and ATF hoses.
- 2) Check the clamp for deformation.
- 3) Lightly bend the ATF hose and check for cracks on the surface or other damages.
- 4) Pinch the ATF hose with your fingers and check for poor elasticity.
- 5) Check for peeling, cracks, and deformation at the tip of the ATF hose.