

1. Basic Diagnostic Procedure

A: BASIC PROCEDURES

1. GENERAL DESCRIPTION

The most important purpose of diagnostics is to quickly determine which part is malfunctioning, to save time and labor.

2. IDENTIFICATION OF TROUBLE SYMPTOM

Determine what the problem is based on the symptom.

3. PROBABLE CAUSE OF TROUBLE

Look at the wiring diagram and check the system's circuit. Then check the switch, relay, fuse, ground, etc.

4. LOCATION AND REPAIR OF TROUBLE

- 1) Using the diagnostics, narrow down the causes.
- 2) If necessary, use a voltmeter, ohmmeter, etc.
- 3) Before replacing certain component parts (switch, relay, etc.), check the power supply, ground, for open wiring harness, poor connectors, etc. If no problem is encountered, check the component parts.


5. SYSTEM OPERATION CHECK

After repairing, ensure that the system operates properly.

B: BASIC INSPECTION

1. VOLTAGE MEASUREMENT

- 1) Using a voltmeter, connect the negative lead to a good ground point or negative battery terminal and the positive lead to the connector or component terminal.
- 2) Contact the positive lead of the voltmeter on connector (A). The voltmeter will indicate a voltage.
- 3) Shift the positive lead to connector (B). The voltmeter will indicate no voltage.



- 4) With the test set-up held as it is, turn the switch ON. The voltmeter will indicate a voltage and, at the same time, the light will come on.

- 5) The circuit is in good order. If a problem such as a light failing to illuminate occurs, use the procedures outlined above to track down the malfunction.


2. CIRCUIT CONTINUITY CHECKS

- 1) Disconnect the battery terminal or connector so there is no voltage between the check points. Contact the two leads of an ohmmeter to each of the check points.

If the circuit has diodes, reverse the two leads and check again.

- 2) Use an ohmmeter to check for diode continuity. When contacting the negative lead to the diode positive side and the positive lead to the negative side, there should be continuity.

When contacting the two leads in reverse, there should be no continuity.



- 3) The symbol "○ — ○" indicates that continuity exists between two points or terminals. For example, when a switch position is at "3", continuity exists among terminals 1, 3 and 6, as shown in the table below.

Terminal	1	2	3	4	5	6
Switch Position						
OFF						
1	○ — ○				○ — ○	
2	○ — ○			○ — ○		○ — ○
3	○ — ○		○ — ○			○ — ○
4	○ — ○	○ — ○				○ — ○

WI-02741


Basic Diagnostic Procedure

WIRING SYSTEM

3. HOW TO DETERMINE AN OPEN CIRCUIT


1) WITH VOLTMETER:

An open circuit is determined by measuring the voltage between respective connectors and ground using a voltmeter, starting with the connector closest to the power supply. The power supply must be turned ON so that current flows in the circuit. If voltage is not present between a particular connector and ground, the circuit between that connector and the previous connector is open.



2) WITH OHMMETER:


Disconnect all connectors affected, and check continuity in the wiring between adjacent connectors. When the ohmmeter indicates "infinite", the wiring is open.



4. HOW TO DETERMINE A SHORT CIRCUIT


1) WITH TEST LIGHT:

Connect a test light (rated at approx. 3 watts) in place of the blown fuse and allow current to flow through the circuit. Disconnect one connector at a time from the circuit. Starting with the one located farthest from the power supply. If the test light goes out when a connector is disconnected, the wiring between that connector and the next connector (farther from the power supply) is shorted.



2) WITH OHMMETER:

Disconnect all affected connectors, and check continuity between each connector and ground. When the ohmmeter indicates continuity between a particular connector and a ground, that connector is shorted.




C: HOW TO READ WIRING DIAGRAMS

1. WIRING DIAGRAM





The wiring diagram of each system is illustrated so that you can understand the path through which the electric current flows from the battery.

Sketches and codes are used in the diagrams. They should read as follows:

- Each connector and its terminal position are indicated by a sketch of the connector in a disconnected state which is viewed from the front.



- The number of poles or pins, presence of a lock are indicated in the sketch of each connector. In the sketch, the highest pole number refers to the number of poles which the connector has. For example, the sketch of the connector shown in figure indicates the connector has 9 poles.

Connector used in vehicle	Connector shown in wiring diagram												
	Sketch	Symbol	Number of poles										
	Double frames Indicates a lock is included. <table border="1"><tr><td>4</td><td>3</td><td></td><td>2</td><td>1</td></tr><tr><td>9</td><td>8</td><td>7</td><td>6</td><td>5</td></tr></table> Indicates the number of poles.	4	3		2	1	9	8	7	6	5		Numbered in order from upper right to lower left.
4	3		2	1									
9	8	7	6	5									
	Indicates a lock is included. <table border="1"><tr><td>1</td><td>2</td><td></td><td>3</td><td>4</td></tr><tr><td>5</td><td>6</td><td>7</td><td>8</td><td>9</td></tr></table> Single frame	1	2		3	4	5	6	7	8	9		Numbered in order from upper left to lower right
1	2		3	4									
5	6	7	8	9									


WI-02747

WI-02747

Basic Diagnostic Procedure

WIRING SYSTEM

- When one set of connectors is viewed from the front side, the pole numbers of one connector are symmetrical to those of the other. When these two connectors are connected as a unit, the poles which have the same number are joined.




• WIRING DIAGRAM:

The connectors are numbered along with the number of poles, external colors, and mating connections in the accompanying list.


- The sketch of each connector in the wiring diagram usually shows the (A) side of the connector. The relationship between the wire color, terminal number and connector is described in the figure.

NOTE:

A wire which runs in one direction from a connector terminal sometimes may have a different color from that which runs in the other direction from that terminal.




- In the wiring diagram, connectors which have no terminal number refer to one-pole types. Sketches of these connectors are omitted intentionally.




- The following color codes are used to indicate the colors of the wires.

Color code	Color
L	Blue
B	Black
Y	Yellow
G	Green
R	Red
W	White
Br	Brown
Lg	Light green
Gr	Gray
P	Pink
Or	Orange
Sb	Light blue
V	Violet
SA	Sealed (Inner)
SB	Sealed (Outer)



- The wire color code, which consists of two letters (or three letters including Br or Lg), indicates the standard color (base color of the wire covering) by its first letter and the stripe marking by its second letter.



- The table lists the nominal sectional areas and allowable currents of the wires.

CAUTION:


When replacing or repairing a wire, be sure to use the same size and type of the wire which was originally used.

NOTE:

- The allowable current in the table indicates the tolerable amperage of each wire at an ambient temperature of 40°C (104°F).
- The allowable current changes with ambient temperature. Also, it changes if a bundle of more than two wires is used.

Nominal sectional area mm ²	No. of strands/ strand diameter	Outside diameter of wiring mm	Allowable current Amps/ 40°C (104°F)
0.3	7/0.26	1.8	7
0.5	7/0.32	2.2 (or 2.0)	12
0.75	30/0.18	2.6 (or 2.4)	16
0.85	11/0.32	2.4 (or 2.2)	16
1.25	16/0.32	2.7 (or 2.5)	21
2	26/0.32	3.1 (or 2.9)	28
3	41/0.32	3.8 (or 3.6)	38
5	65/0.32	4.6 (or 4.4)	51
8	50/0.45	5.5	67


- Each unit is either directly grounded to the body or indirectly grounds through a harness ground terminal. Different symbols are used in the wiring diagram to identify the two grounding systems.



- The ground points shown in the wiring diagram refer to the following:

NOTE:


All wiring harnesses are provided with a ground point which should be securely connected.



Basic Diagnostic Procedure

WIRING SYSTEM

- Relays are classified as normally-open or normally-closed.
- The normally-closed relay has one or more contacts. The wiring diagram shows the relay mode when the energizing circuit is OFF.



Key to symbols:


○ —▶ : Current flows.

× —▶ : Current does not flow.

WI-02752

- Each connector number shown in the wiring diagram corresponds to that in the wiring harness. The location of each connector in the actual vehicle is determined by reading the first character of the connector (for example, a "F" for F8, "i" for i16, etc.) and the type of wiring harness. The first character of each connector number corresponds to the area or system of the vehicle.

Symbol	Wiring harness and cord
F	Front wiring harness
B	Bulkhead wiring harness
E	Engine wiring harness
T	Transmission cord
D	Door cord LH & RH, Rear gate cord Rear door cord LH & RH, Rear defogger cord
i	Instrument panel wiring harness
R	Rear wiring harness, Fuel tank cord, Roof cord, Rear gate cord, Rear defogger ground cord (Sedan model)
AB	Airbag wiring harness




Basic Diagnostic Procedure

WIRING SYSTEM

D: SYMBOLS IN WIRING DIAGRAMS

A number of symbols are used in each wiring diagram to easily identify parts or circuits.



1. RELAY

A symbol used to indicate a relay.

2. CONNECTOR 1

The sketch of the connector indicates the one-pole types.

3. WIRING CONNECTION

Some wiring diagrams are indicated in foldouts for convenience. Wiring destinations are indicated where necessary by corresponding symbols. (When two pages are needed for clear indication)

4. FUSE NO. & RATING

The "FUSE No. & RATING" corresponds with that used in the fuse box (main fuse box, fuse and joint box).

5. CONNECTOR 2

- Each connector is indicated by a symbol.
- Each terminal number is indicated in the corresponding wiring diagram in an abbreviated form.
- For example, terminal number "G4" refers to No. 4 terminal of connector (G: F41) shown in the connector sketch.

6. CONNECTOR SKETCH

- Each connector sketch clearly identifies the shape and color of a connector as well as terminal locations. Non-colored connectors are indicated in white or natural color.
- When more than two types of connector number are indicated in a connector sketch, it means that the same type connectors are used.

7. GROUND

Each grounding point can be located easily by referring to the corresponding wiring harness.

8. DIODE


A symbol is used to indicate a diode.

9. WIRE TRACING ON EXTENDED WIRING DIAGRAMS

For a wiring diagram extending over at least two pages, a symbol (consisting of the same characters with arrows), facilitates wire tracing from one page to the next.

A $\longleftrightarrow$ B, B $\longleftrightarrow$ B

10. SYMBOLS OF WIRE CONNECTION AND CROSSING



11. POWER SUPPLY CIRCUIT

A symbol is used to indicate the power supply in each wiring diagram.

"MB-5", "MB-6", etc., which are used as power supply symbols throughout the text, correspond with those shown in the "DC POWER SUPPLY CIRCUIT" in the wiring diagram.

Accordingly, using the "DC POWER SUPPLY CIRCUIT" and wiring diagrams permits service personnel to understand the entire electrical arrangement of a system.

12. CLASSIFICATION BY SPECIFICATION









When the wiring diagram differ according to vehicle specifications, the specification difference is described by using abbreviations.




Basic Diagnostic Procedure

WIRING SYSTEM

E: CONNECTOR SYMBOL IN WIRING HARNESS

A number of connector symbols are used in each wiring diagram to easily identify the wiring harness connectors.

Standard type: Female		
Pole: From 1 to 8	Pole: From 9 to 20	Pole: More than 21
		
		
Standard type: Male		
		
		

Water proof type: Female		
Pole: From 1 to 8	Pole: From 9 to 20	Pole: More than 21
		
		
Water proof type: Male		
		
		

WI-02756

F: ABBREVIATION IN WIRING DIAGRAMS

Abbr.	Full name
A/C	Air Conditioner
A/F	Air/Fuel (Air fuel ratio sensor)
ABS	Anti-lock Brake System
ACC	Accessory
ALT	Generator
Assy	Assembly
AT	Electronically controlled fully-automatic
AUX	Auxiliary
AWD	All Wheel Drive
CAN	Controller Area Network
CPU	Central Processing Unit
ECM	Engine Control Module (ECM)
EEPROM	Electronically Erasable and Programmable Read Only Memory
F/B	Fuse & Relay box
FWD	Front Wheel Drive
GPS	Global Positioning System
H/L	Headlight
I/F	Interface
IG	Ignition
L, LH	Left Hand
LCD	Liquid Crystal Display
M/B	Main fuse box
MFD	Multi Function Display
OP	Optional Parts or Open
PWM	Pulse Width Modulation
R, RH	Right Hand
SBF	Slow Blow Fuse
ST	Starter
TCS	Traction Control System
TCM	AT Control Module
TPM	Tire Pressure Monitor
U, UP	Up
VDC	Vehicle Dynamics Control
VVL	Variable Valve Lift


2. Working Precautions

A: PRECAUTIONS WHEN WORKING WITH THE PARTS MOUNTED ON THE VEHICLE


- 1) When working under a vehicle which is jacked-up, always be sure to use rigid rack.
- 2) The parking brake must always be applied during working. Also, in automatic transmission vehicles, keep the select lever set to the P (Parking) range.
- 3) Be sure the workshop is properly ventilated when running the engine. Further, be careful not to touch the belt or fan while the engine is operating.
- 4) Be careful not to touch hot metal parts, especially the radiator and exhaust system immediately after the engine has been turned off.

B: PRECAUTIONS IN TROUBLE DIAGNOSIS AND REPAIR OF ELECTRIC PARTS

- 1) The battery cable must be disconnected from the battery's (-) terminal, and the ignition switch must be set to the OFF position, unless otherwise required by the diagnostics.
- 2) Securely fasten the wiring harness with clamps and clips so that the harness does not interfere with the body end parts or edges and bolts or screws.
- 3) When installing parts, be careful not to catch them on the wiring harness.
- 4) When disconnecting a connector, do not pull the wires, but pull while holding the connector body.




- 5) Some connectors are provided with a lock. One type of such a connector is disconnected by pushing the lock, and the other, by moving the lock up. In either type the lock shape must be identified before attempting to disconnect the connector. To connect, insert the connector until it snaps and confirm that it is connected securely.



- 6) When checking continuity between connector terminals, or measuring voltage across the terminal and ground, always contact tester probe(s) on terminals from the wiring connection side. If the probe is too thick to gain access to the terminal, use "mini" test leads.

To check water-proof connectors (which are not measurable from the wiring side), contact test probes on the terminal side. Be careful not to bend or damage the terminals.





- 7) Sensors, relays, electrical unit, etc., are sensitive to strong impacts. Handle them with care so that they are not dropped or mishandled.

3. Power Supply Circuit

A: WIRING DIAGRAM


P-SUP-01

P-SUP-01




Power Supply Circuit

WIRING SYSTEM



Power Supply Circuit


WIRING SYSTEM



WI-11681

WIRING SYSTEM


WIRING SYSTEM



P-SUP-04

Power Supply Circuit

WIRING SYSTEM



WI-11683

Power Supply Circuit

WIRING SYSTEM

No.	Load
MB-1	Fail safe relay
MB-2	VDC control module
MB-4	A/C relay holder
MB-5	Mirror heater relay
	Rear defogger
MB-6	Body integrated unit
MB-7	A/C relay holder
MB-8	Main fan motor
MB-9	ECM
MB-10	A/C relay holder
MB-11	A/C relay holder
MB-14	Combination switch (Lighting)
MB-15	Combination meter
MB-16	Headlight RH
MB-17	Headlight LH
MB-18	Daytime running light control module
MB-19	Horn
MB-20	Horn
MB-21	Body integrated unit
	Remote engine start control module
	Horn Switch
MB-22	Main relay
MB-23	Main relay 2
	Main relay
MB-24	Electronic throttle control relay
MB-25	Fuel pump relay
MB-26	TCM
MB-27	ECM
	Data link connector
MB-28	Key warning switch
	Key illumination
	Turn signal and hazard unit
	Body integrated unit
MB-29	Spot map light
	Vanity mirror illumination LH
	Vanity mirror illumination light RH
	Puddle light LH
	Puddle light RH
	Foot light (Driver's seat)
	Foot light (Passenger's seat)
	Home link
	Body integrated unit
	Room light
MB-30	Power window circuit breaker
MB-31	F/B fuse No. 16
MB-32	Parking switch
MB-33	Blower fan relay
MB-34	Accessory relay 2
	Vacuum pump relay
FB-1	Trailer connector

No.	Load
FB-3	Stop light & brake switch
	Stop light switch
FB-4	Mirror heater relay
	Wiper deicer relay
FB-5	Seat heater relay
FB-6	Body integrated unit
FB-8	Rear cooler relay
FB-9	Front fog light relay
FB-10	MFD
	Impact sensor
	Audio
	Keyless entry control module
	Second-row seat foot light RH
	TV monitor
	Navigation module
	Front step light LH
	Front step light RH
	Rear Entertainment
	Rear step light RH
FB-11	Second-row seat foot light LH
	Luggage room light
	Rear gate light
	Rear step light LH
FB-13	Navigation module
FB-17	TPM control module
	Warning box (Driver's side)
	Warning box (Passenger's side)
	Rear view camera module
FB-18	Combination meter
	Auto A/C control module
	Body integrated unit
FB-19	Remote control mirror switch
FB-20	Accessory relay 2
	Seat heater relay
	Shade mirror
FB-21	Rear accessory power supply socket (Third-row seat)
	Rear accessory power supply socket (Luggage room)
FB-23	Rear wiper motor
FB-24	Body integrated unit
	Rear washer motor
FB-25	MFD
	Audio
	TV monitor
	Navigation module
	Rear view camera module
	AUX box unit
FB-25	Rear Entertainment



No.	Load
FB-27	Combination Switch (Wiper)
	Front wiper motor
	Wiper relay unit
FB-28	Key warning switch
	Body integrated unit
FB-29	TCM
	Auto A/C control module
FB-32	Open/Close switch
	Sunroof control unit
	Stop light & brake switch
	Tilt switch
	Data link connector
	Wiper deicer relay
FB-34	Turn signal and hazard unit
FB-35	Daytime running light control module
	Daytime running light relay
	Back-up light relay
FB-36	MFD
	Warning box (Passenger's side)
	Combination meter
FB-37	Body integrated unit
FB-38	ECM
	P-VIGN relay
	TCM
	Fuel pump relay
FB-39	Airbag control module
FB-41	Airbag control module
FB-42	Power window relay
FB-44	VDC control module
	Steering angle sensor
	Yaw rate sensor
FB-45	A/C control panel
	Rear cooler relay
FB-46	A/C relay holder
	FRESH/RECIRC actuator
	Auto A/C control module
	Pressure switch
	Blower fan relay
FB-47	Occupant detection control module
FB-48	TPM control module
	Power seat LH (with memory)
FB-49	Impact sensor
	TV monitor
ACC-1	Front washer motor
ALT-1	ECM
ST-1	Inhibitor relay
ST-2	Starter relay

Ground Circuit

WIRING SYSTEM

4. Ground Circuit

A: WIRING DIAGRAM




RELAY BLOCK

WI-11684

GND-02

GND-02



B421 (GREEN)




B146 (GRAY)




D: B144 (BROWN)



D: B152 (GRAY)




A: B242




B116




B71




B70




A: B54




B334




B: B55 (GRAY)




C: B281



B: B280




B36 (BLUE)



WI-11685

Ground Circuit



WIRING SYSTEM



WI-11686

Ground Circuit


WIRING SYSTEM



WI-11725

Ground Circuit

WIRING SYSTEM




Ground Circuit

WIRING SYSTEM


GND-06

GND-06




WI-11726

WIRING SYSTEM



GND-08


GND-08



WI-12823

Ground Circuit

WIRING SYSTEM



T1

1

2

3

B12 (BROWN)

1

2

3

4

5

6

7

8

B11 (GRAY)

1

2

3

4

5

6

7

8

9

10

11

12

13

14

15

16

17

18

19

20

A: B54

1

2

3

4

5

6

7

8

9

10

11

12

13

14

15

16

17

18

19

20

21

22

23

24

B: B55 (GRAY)

1

2

3

4

5

6

7

8

9

10

11

12

13

14

15

16

17

18

19

20

21

22


23

24

WI-11688

GND-10

GND-10



E10 (LIGHT GRAY)

E57 (BLACK)

D: B137

A: B134

B21 (BLACK)

E14 (BLUE)

1 2 3 4 5 6

1	2	3	4	5	6	7
8	9	10	11	12	13	14
15	16	17	18	19	20	21
22	23	24	25	26	27	28
29	30	31	32	33	34	35

1	2	3	4	5	6	7
8	9	10	11	12	13	14
15	16	17	18	19	20	21
22	23	24	25	26	27	28
29	30	31	32	33	34	35

1	2	3	4	5	6	7	8	9	10	11
12	13	14	15	16	17	18	19	20	21	22
23	24	25	26	27	28	29	30	31	32	33
34	35	36	37	38	39	40	41	42	43	44
45	46	47	48	49	50	51	52	53	54	55


WI-11689

Engine Electrical System


WIRING SYSTEM

5. Engine Electrical System

A: WIRING DIAGRAM




WI-11690



WI-11691

Engine Electrical System


WIRING SYSTEM




WI-11728

E/G-02


E/G-02





Engine Electrical System


WIRING SYSTEM




WI-11694

Engine Electrical System

WIRING SYSTEM




WI-11729




E24 (LIGHT GRAY)	B426	B22 (BROWN)	B: B135	C: B136																																																																																															
E25 (DARK GRAY)	<table><tr><td>1</td><td>2</td><td>3</td><td>4</td></tr><tr><td>5</td><td>6</td><td>7</td><td>8</td></tr></table>	1	2	3	4	5	6	7	8	<table><tr><td>1</td><td>2</td><td>3</td><td>4</td></tr><tr><td>5</td><td>6</td><td>7</td><td>8</td></tr><tr><td>9</td><td>10</td><td>11</td><td>12</td></tr><tr><td>13</td><td>14</td><td>15</td><td>16</td></tr></table>	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	<table><tr><td>1</td><td>2</td><td>3</td><td>4</td><td>5</td><td>6</td><td>7</td></tr><tr><td>8</td><td>9</td><td>10</td><td>11</td><td>12</td><td>13</td><td>14</td></tr><tr><td>15</td><td>16</td><td>17</td><td>18</td><td>19</td><td>20</td><td>21</td></tr><tr><td>22</td><td>23</td><td>24</td><td>25</td><td>26</td><td>27</td><td>28</td></tr><tr><td>29</td><td>30</td><td>31</td><td>32</td><td>33</td><td>34</td><td>35</td></tr></table>	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24	25	26	27	28	29	30	31	32	33	34	35	<table><tr><td>1</td><td>2</td><td>3</td><td>4</td><td>5</td><td>6</td></tr><tr><td>7</td><td>8</td><td>9</td><td>10</td><td>11</td><td>12</td></tr><tr><td>13</td><td>14</td><td>15</td><td>16</td><td>17</td><td>18</td></tr><tr><td>19</td><td>20</td><td>21</td><td>22</td><td>23</td><td>24</td></tr><tr><td>25</td><td>26</td><td>27</td><td>28</td><td>29</td><td>30</td></tr><tr><td>31</td><td>32</td><td>33</td><td>34</td><td>35</td><td></td></tr></table>	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24	25	26	27	28	29	30	31	32	33	34	35	
1	2	3	4																																																																																																
5	6	7	8																																																																																																
1	2	3	4																																																																																																
5	6	7	8																																																																																																
9	10	11	12																																																																																																
13	14	15	16																																																																																																
1	2	3	4	5	6	7																																																																																													
8	9	10	11	12	13	14																																																																																													
15	16	17	18	19	20	21																																																																																													
22	23	24	25	26	27	28																																																																																													
29	30	31	32	33	34	35																																																																																													
1	2	3	4	5	6																																																																																														
7	8	9	10	11	12																																																																																														
13	14	15	16	17	18																																																																																														
19	20	21	22	23	24																																																																																														
25	26	27	28	29	30																																																																																														
31	32	33	34	35																																																																																															
E47 (LIGHT GRAY)																																																																																																			
E61 (DARK GRAY)																																																																																																			
<table><tr><td>1</td><td>2</td></tr><tr><td>3</td><td>4</td></tr></table>	1	2	3	4																																																																																															
1	2																																																																																																		
3	4																																																																																																		

Engine Electrical System

WIRING SYSTEM



B3 (BLACK)	B315 (BLACK)	B: B135
1 2 3 4 5	1 2 3 4 5 6	1 2 3 4 5 6 7
		8 9 10 11 12 13 14 15 16 17 18 19
		20 21 22 23 24 25 26 27
		28 29 30 31 32 33 34 35



E10 (LIGHT GRAY)

E14 (BLUE)

E48 (BLUE)

E75 (BLACK)

1

2

B20 (BROWN)

1

2

3

4

5

6

7

8

9

10

11

12

13

14

15

16

A: B134

1

2

3

4

5

6

7

8

9

10

11

12

13

14

15

16

17

18

19

20

21

22

23

24

25

26

27

28

29

30


31

32

33







34

WIRING SYSTEM



Engine Electrical System


WIRING SYSTEM



WI-11731

Engine Electrical System


WIRING SYSTEM



WI-11698

E/G-12

E/G-12



(DARK GRAY) E5 (DARK GRAY) E17 (DARK GRAY)
(DARK GRAY) E6 (DARK GRAY) E43 (DARK GRAY)
(DARK GRAY) E16 (DARK GRAY) E44 (DARK GRAY)

1 2

D: B137



1	2	3	4	5	6	7
8	9	10	11	12	13	14
15	16	17	18	19	20	21
22	23	24	25	26	27	28
29	30	31				

B21 (BLACK)


1	2	3	4	5	6	7	8	9	10	11
12	13	14	15	16	17	18	19	20	21	22
23	24	25	26	27	28	29	30	31	32	33
34	35	36	37	38	39	40	41			
42	43	44	45	46	47					
48	49	50	51	52	53	54				

E/G-13

E/G-13



WI-11733




WI-11734

Vacuum Pump Control System

WIRING SYSTEM

6. Vacuum Pump Control System

A: WIRING DIAGRAM




WI-11699

AT Control System


WIRING SYSTEM

7. AT Control System

A: WIRING DIAGRAM



WI-11700





AT Control System

WIRING SYSTEM

5AT-01







5AT-01




WI-11701

5AT-02

5AT-02




WI-11702



5AT-04

5AT-04



B356 (BLACK)

A: B54

B: B55 (GRAY)

B357 (BLACK)




1	2	3	4	5	6	7	8	9
10	11	12	13	14	15	16	17	18
19	20	21				22	23	24

1	2	3	4	5	6	7	8	9
10	11	12	13	14	15	16	17	18
19	20	21				22	23	24

WI-11736

AT Control System







WIRING SYSTEM




WI-11704

5AT-06

5AT-06



B: B55 (GRAY)




WI-11737

AT Shift Lock Control System

WIRING SYSTEM

8. AT Shift Lock Control System


A: WIRING DIAGRAM



WI-11705

9. TPM Control System



A: WIRING DIAGRAM



WI-11753

VDC-02


VDC-02




WI-11707

Vehicle Dynamics Control System

WIRING SYSTEM



WI-12612



WI-11708


Air Conditioning System

WIRING SYSTEM

11. Air Conditioning System


A: WIRING DIAGRAM

1. FRONT A/C



Air Conditioning System

WIRING SYSTEM





WI-11710

Air Conditioning System

WIRING SYSTEM

F-A/C-03


F-A/C-03



WI-11738

Air Conditioning System

WIRING SYSTEM




WI-11739

Air Conditioning System

WIRING SYSTEM


2. REAR A/C



WI-11711


12. Airbag System

A: WIRING DIAGRAM




Airbag System

WIRING SYSTEM



Airbag System


WIRING SYSTEM



WI-11741

Airbag System

WIRING SYSTEM




WI-11742

Airbag System

WIRING SYSTEM

A/B-05

A/B-05



(AB24) (YELLOW)
1 2

(AB26) (BLACK)
(AB33) (BLACK)
1 2

(AB28) (YELLOW)
(AB34) (YELLOW)
1 2 3 4

(AB18) (YELLOW)
1 2 3 4
5 6 7 8 9 10 11 12
13 14 15 16 17 18 19 20


WI-11743

Occupant Detection System

WIRING SYSTEM

13. Occupant Detection System


A: WIRING DIAGRAM



WI-11744

14. Immobilizer System

A: WIRING DIAGRAM




WI-11745

Cruise Control System

WIRING SYSTEM

15. Cruise Control System

A: WIRING DIAGRAM




WI-11746

Cruise Control System

WIRING SYSTEM

C/C-02

C/C-02



B47 (BROWN) B362 (BLACK)

i126 (BLACK)

A: i10 (GREEN)

A: B134

B: B135

1	2
3	4
5	6

1	2	3	4
5	6	7	8

1	2	3	4	5	6
7	8	9	10	11	12

1	2	3	4	5	6	7			8	9	10	11	12	13	14
15	16	17	18	19	20	21	22	23	24	25	26	27	28	29	30

C: B136

	1	2	3	4			5	6		
	7	8	9	10	11	12	13	14	15	16
17	18	19	20	21	22	23	24	25	26	27
28	29	30				31	32	33	34	35


1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17
18	19	20	21	22	23	24	25	26	27	28	29	30	31	32	33	34

1	2			3	4	5	6	7			
8	9	10	11	12	13	14	15	16	17	18	19
20	21	22	23			24	25			26	27
28	29	30	31			32	33			34	35

WI-11747

Cruise Control System



WIRING SYSTEM



WI-11713

16.CAN Communication System


A: WIRING DIAGRAM



WI-11748

CAN Communication System


WIRING SYSTEM



WI-11714


17.Radiator Fan System

A: WIRING DIAGRAM



18.Charging System


A: WIRING DIAGRAM



WI-11754

19. Starter System

A: WIRING DIAGRAM




WI-11755

Remote Engine Start System

WIRING SYSTEM

20.Remote Engine Start System


A: WIRING DIAGRAM



WI-11821

Remote Engine Start System


WIRING SYSTEM



WI-15664


Remote Engine Start System

WIRING SYSTEM




WI-11823

1. DRIVER'S SEAT (WITHOUT MEMORY)



3. PASSENGER'S SIDE





WI-11824

Seat Belt Warning System

WIRING SYSTEM

22.Seat Belt Warning System

A: WIRING DIAGRAM



WI-11758

A: WIRING DIAGRAM




Headlight System

WIRING SYSTEM


24.Headlight System

A: WIRING DIAGRAM



Headlight System

WIRING SYSTEM



(B406) (BLACK) (B405) (BROWN) B: (B96) (BLACK) A: (B242) (B71) (B225) (BLACK)

1	2
---	---

1	2	3	4
---	---	---	---

1	2	3	4	5	6	7	8
---	---	---	---	---	---	---	---

1	2	3	4	5
6	7	8	9	10

1	2	3	4	5	6	7	8
9	10	11	12	13	14	15	16
17							

1	2	9	13	17	21
3	4	10	14	18	22
5	6	11	15	19	23
7	8	12	16	20	24
		25	29	33	37
		26	30	34	38
		27	31	32	35
		28	36	39	40

RELAY BLOCK


WI-11761

H/L-03



25.Front Fog Light System


A: WIRING DIAGRAM



WI-11763

27. Stop Light System

A: WIRING DIAGRAM




WI-11765

Clearance Light and Illumination Light System

WIRING SYSTEM

28. Clearance Light and Illumination Light System



A: WIRING DIAGRAM



WI-15656


Clearance Light and Illumination Light System

WIRING SYSTEM




Clearance Light and Illumination Light System

WIRING SYSTEM




WIRING SYSTEM



Clearance Light and Illumination Light System


WIRING SYSTEM



WI-11769

29. Turn Signal Light and Hazard Light System


A: WIRING DIAGRAM



WI-11770

Turn Signal Light and Hazard Light System


WIRING SYSTEM



WI-11771

30. Interior Light System


A: WIRING DIAGRAM



WI-11772

Interior Light System



WIRING SYSTEM



WI-11773

Interior Light System


WIRING SYSTEM



WI-11774


Interior Light System

WIRING SYSTEM




C/L-05

C/L-05




Interior Light System

WIRING SYSTEM



31.Front Wiper and Washer System

A: WIRING DIAGRAM




WI-11780

Rear Wiper and Washer System

WIRING SYSTEM

32.Rear Wiper and Washer System


A: WIRING DIAGRAM



WI-11781

33. Wiper Deicer System

A: WIRING DIAGRAM




WI-11782

Washer Level Warning Light System

WIRING SYSTEM

34. Washer Level Warning Light System


A: WIRING DIAGRAM



WI-11783


35.Audio System

A: WIRING DIAGRAM




WI-11784


WIRING SYSTEM



AUDIO-03




A: WIRING DIAGRAM



Navigation System


WIRING SYSTEM



WI-11788

NAVI-03

NAVI-03



B: i120 (BLACK)

i131 (BLACK)


1	2	3	4	5	6	7	8	9	10
11	12	13	14	15	16	17	18	19	20

Navigation System

WIRING SYSTEM

NAVI-04

NAVI-04



i118 (BLACK)


i121 (BLACK)

1	2	3	4
5	6	7	8

WI-11790

37.Rearview Camera System

A: WIRING DIAGRAM




WI-16190

Multi-function Display (MFD) System

WIRING SYSTEM

38.Multi-function Display (MFD) System



A: WIRING DIAGRAM



WI-11792

MFD-02

MFD-02




WI-11793

Rear Entertainment System

WIRING SYSTEM

39.Rear Entertainment System

A: WIRING DIAGRAM





WI-11795

Rear Entertainment System

WIRING SYSTEM

RES-02

RES-02




WI-12824

Rear Entertainment System

WIRING SYSTEM

RES-03

RES-03



*1 : TERMINAL No.
OPTIONAL
ARRANGEMENT

R241			
1	2	3	4

R261					
1	2	3	4	5	6

R217				
R235				
1	2	3	4	5
6	7	8	9	10

R254			
1	2		3
5	6	7	8
10	11	12	13

R236																							
1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24







WI-11796

40.Front Accessory Power Supply Socket System

A: WIRING DIAGRAM

FAPS-01

FAPS-01




WI-11797

WIRING SYSTEM


A: WIRING DIAGRAM

RAPS-01



42.Horn System

A: WIRING DIAGRAM




Power Window System

WIRING SYSTEM

43. Power Window System

A: WIRING DIAGRAM




WI-11800

Power Window System

WIRING SYSTEM

P/W-02

P/W-02



D13 (GRAY)

1	2
---	---

D128

1	2	3	4	5	6
---	---	---	---	---	---

D17

1	2	3	4
4	5	6	7

D7

1	2	3	4	5	6	7
8	9	10	11	12	13	14

D83


1	2	3	4
5	6	7	8
9	10	11	12
13	14	15	16
17	18	19	20
21	22	23	24
25			

D84

WI-11801

Power Window System

WIRING SYSTEM




WI-11802

Power Window System


WIRING SYSTEM

P/W-04

P/W-04



*1 : TERMINAL No. OPTIONAL ARRANGEMENT AMONG 1, 2, 3, 4, 5 AND 6



WI-11803

Rear Defogger System






WIRING SYSTEM

44.Rear Defogger System

A: WIRING DIAGRAM

R/DEF-01

R/DEF-01





WI-11804

A: WIRING DIAGRAM

R/M-01



R/M-01



WI-11805

R/M-02


R/M-02



WI-11806

46. Combination Meter System


A: WIRING DIAGRAM



WI-11750

Combination Meter System


WIRING SYSTEM



WI-11715

Combination Meter System


WIRING SYSTEM



WI-11716

Combination Meter System


WIRING SYSTEM



WI-11717

47.Speedmeter System

A: WIRING DIAGRAM



(BLACK) i99 i126 (BLACK)

(BLACK) i100 i127 (BLACK)

1	2	3	4	5	6
7	8	9	10	11	12

1	2	3	4		5	6	7	8	9	
10	11	12	13	14	15	16	17	18	19	20

B38

A: i10 (GREEN)

1	2	3	4	5	6	7		8	9	10	11	12	13	14	
15	16	17	18	19	20	21	22	23	24	25	26	27	28	29	30


B310 (BLACK)

1	2	3	4	5	6	7	8	9	10	11	12	13	14
15	16	17	18	19	20	21	22	23	24	25	26	27	28
29	30	31	32	33	34	35	36	37	38	39	40	41	42
43	44	45	46										

WI-11718


48. Fuel Gauge System

A: WIRING DIAGRAM



49. Coolant Temperature System

A: WIRING DIAGRAM





Oil Pressure Warning Light System

WIRING SYSTEM

50.Oil Pressure Warning Light System


A: WIRING DIAGRAM



WI-11809

51. Parking Brake / Brake Fluid Level Warning Light System

A: WIRING DIAGRAM




WI-11810

Sunroof Control System

WIRING SYSTEM


52.Sunroof Control System

A: WIRING DIAGRAM




WI-11811

A: WIRING DIAGRAM




Keyless Entry System

WIRING SYSTEM




WI-11720




Keyless Entry System

WIRING SYSTEM



54.Security System


A: WIRING DIAGRAM



WI-11722

Security System

WIRING SYSTEM




WI-11752

WIRING SYSTEM


A: WIRING DIAGRAM

D/T-01



56.Harness Components Location

A: LOCATION



WI-11827

- | | | |
|-------------------------------------|-------------------------|------------------------------|
| (1) Front wiring harness | (6) Rear door cord RH | (10) Rear door cord LH |
| (2) Engine wiring harness | (7) Rear wiring harness | (11) Front door cord LH |
| (3) Bulkhead wiring harness | (8) Roof cord | (12) Transmission cord |
| (4) Instrument panel wiring harness | (9) Rear gate cord | (13) Rear oxygen sensor cord |
| (5) Front door cord RH | | |

Front Wiring Harness

WIRING SYSTEM


57.Front Wiring Harness

A: LOCATION

Connector				Connecting to	
No.	Pole	Color	Area	No.	Description
F5	1	Black	B-1		Horn
F6	2	Gray	C-1		Front fog light RH
F7	8	Gray	C-1		Headlight and front clearance light & front turn signal light RH
F16	2	Gray	C-2		Sub fan motor
F17	3	Gray	C-2		Main fan motor
F21	2	Gray	D-3		Front fog light LH
F23	8	Gray	C-3		Headlight and front clearance light & front turn signal light LH
F25	1	★	C-2		Generator terminal B
F26	3	Green	C-2		Generator
F27	31	Black	B-4		Relay holder
F35	12	Blue	B-4		Main fuse box (M/B)
F36	7	★	B-4		
F37	20	★	B-4		
F47	1	Black	C-2		Horn
F78	2	Black	C-2		Ambient sensor
F102	2	Black	B-1		Keyless buzzer
F108	18	Gray	B-4		Through joint connector
F109	24	★	B-3		
F110	1	Black	C-2		Magnet clutch
★ : White or natural color					

Front Wiring Harness

WIRING SYSTEM



WI-11826

Bulkhead Wiring Harness (In Engine Compartment)

WIRING SYSTEM

58.Bulkhead Wiring Harness (In Engine Compartment)

A: LOCATION


Connector				Connecting to	
No.	Pole	Color	Area	No.	Description
B3	5	Black	B-2		Air flow sensor
B6	2	Gray	B-2		Front ABS wheel speed sensor RH
B8	5	Gray	B-4		Front wiper motor
B10	4	Gray	B-4		Pressure switch
B11	20	Gray	B-3	T4	Transmission harness
B12	8	Brown	B-3	T3	
B14	1	Black	B-3		Starter (Magnet)
B15	2	Gray	B-4		Front ABS wheel speed sensor LH
B16	2	Gray	B-4		Brake fluid level switch
B20	16	Brown	B-3	E1	Engine wiring harness
B21	54	Black	B-3	E2	
B22	16	Brown	B-3	E3	
B143	20	★	B-4		Main fuse box (M/B)
B144	9	Brown	B-4		
B145	7	Brown	B-4		
B146	6	Gray	C-4		Front washer motor
B186	8	★	B-4		Main fuse box (M/B)
B310	46	Black	B-2		VDC control module
B329	2	Black	B-2		Hood switch
B360	16	Gray	C-4	F109	Through joint connector
B361	14	Gray	B-4	F108	
B407	2	Black	B-5		Puddle light LH
B409	4	Black	B-5		Wiper relay unit
B410	3	Gray	B-5		
B411	3	Black	B-4		Pressure sensor
B417	2	Gray	C-3		Vacuum pump
B422	4	Black	B-3		Vacuum pump relay
B423	8	Black	B-3		VDC relay
B430	2	Black	B-2		Puddle light RH
B432	8	Black	B-4		SBF holder
B433	2	★	B-4		Main fuse box (M/B)

★ : White or natural color

Connector				Connecting to	
No.	Pole	Color	Area	No.	Description
AB13	2	Yellow	C-3		Front sub sensor LH
AB16	2	Yellow	C-1		Front sub sensor RH

Bulkhead Wiring Harness (In Engine Compartment)

WIRING SYSTEM



WI-11813

Bulkhead Wiring Harness (In Compartment)

WIRING SYSTEM

59.Bulkhead Wiring Harness (In Compartment)

A: LOCATION

Connector				Connecting to	
No.	Pole	Color	Area	No.	Description
B31	12	Yellow	C-1	AB1	Airbag wiring harness
B32	8	★	C-2		Turn signal and hazard unit
B36	28	Blue	B-2	i1	Instrument panel wiring harness
B38	20	★	B-5	i3	
B41	2	★	C-2		Power window circuit breaker
B47	6	Brown	B-5		Main relay
B52	24	★	B-2		Fuse & relay box (F/B)
B54	24	★	C-3		TCM
B55	24	Gray	C-3		
B65	4	Black	B-3		Stop light & brake switch
B68	8	★	B-3		Roll connector
B69	4	★	B-3		Parking switch
B70	18	★	B-3		Combination switch (Rear wiper & washer switch)
B71	17	★	B-3		Combination switch (Front fog light switch & lighting switch)
B72	6	★	B-3		Ignition switch
B77	7	Green	B-4		Mode actuator
B86	5	★	B-4		Blower fan controller
B87	2	★	C-5		Blower fan motor
B88	2	★	B-4		Evaporator thermo switch
B90	12	★	B-4	R50	Roof cord
B91	7	Green	B-4		FRESH/RECIRC actuator
B96	8	Black	B-2		Daytime running light control module
B97	20	★	C-1	R2	Rear wiring harness
B98	24	Black	B-5	R1	
B116	12	★	C-4		Select lever
B122	8	★	D-5		Joint connector (E/G)
B134	34	★	C-4		ECM
B135	35	★	C-4		
B136	35	★	C-4		
B137	31	★	D-5		
B152	10	Gray	B-2		Fuse & relay box (F/B)
B158	8	★	B-2		
B159	9	Brown	B-2		
B177	2	★	B-4		Wiper deicer

Connector				Connecting to	
No.	Pole	Color	Area	No.	Description
B225	40	Black	C-2		Seat heater relay
					Starter relay
					Power window relay
					Fuse (Relay block)
					Accessory relay 2
					Front fog light relay
					Mirror heater relay
					Daytime running light relay
					Wiper deicer relay
B231	4	★	B-3		Steering angle sensor
B235	7	Green	B-4		Passenger's side air mix actuator
B242	10	★	B-2		Daytime running light control module
B280	30	★	C-3		Body integrated unit
B281	28	★	C-3		
B282	16	★	C-5		Auto A/C control module
B283	26	★	C-5		Auto A/C control module (Rear defogger switch)
B315	6	Black	B-4		Accelerator pedal position sensor
B327	6	Brown	B-5		Main relay 2
B330	4	Black	B-5		Inhibitor relay
B331	20	★	B-4		CAN joint connector
B333	2	★	B-1		Short connector
B334	24	★	B-2		Remote engine start control module
B350	4	★	B-3		Key actuator
B351	2	Black	B-4		Antenna
B356	4	Black	C-3		Back-up light relay
B357	4	Black	C-3		P-VIGN relay
B359	5	Black	D-4		Yaw rate sensor
B362	8	Black	B-5		Relay holder
B370	4	Brown	B-4		Diode (Tail & engine status)
B373	2	★	B-1		Fuse & relay box (F/B)
B390	7	Green	B-4		Driver's side air mix actuator
B402	16	Black	B-2		Data link connector
B403	25	★	B-2	i2	Instrument panel wiring harness
B404	1	Black	B-2		Parking brake switch
B405	4	Brown	B-2		Diode (Daytime running light & parking brake)

Bulkhead Wiring Harness (In Compartment)


WIRING SYSTEM

Connector				Connecting to	
No.	Pole	Color	Area	No.	Description
B406	2	Black	B-1		Diode (Daytime running light indicator)
B413	2	★	B-3		In-vehicle sensor
B414	2	★	B-4		Key illumination
B416	8	★	D-4		CAN joint connector
B418	2	★	B-4		Foot light (Passenger's seat)
B419	7	★	B-4		Blower relay
B420	2	Green	C-4		Test mode connector
B421	2	Green	C-4		
B424	8	★	D-5		Joint connector
B426	8	★	D-5		
B431	2	★	B-3		Foot light (Driver's seat)
★ : White or natural color					

Connector				Connecting to	
No.	Pole	Color	Area	No.	Description
AB1	12	Yellow	C-1	B31	Bulkhead wiring harness
AB2	4	Yellow	B-4	AB7	Inflator (Driver's seat) (Roll connector)
AB6	28	Yellow	C-3		Airbag control module
AB9	4	Yellow	C-3		Inflator (Passenger's seat)
AB35	2	Black	B-1		Fuse & relay box (F/B)
AB55	2	Yellow	B-5	AB5 7	Rear wiring harness

Bulkhead Wiring Harness (In Compartment)

WIRING SYSTEM



WI-11814

60.Engine Wiring Harness and Transmission Cord

A: LOCATION

Connector				Connecting to	
No.	Pole	Color	Area	No.	Description
E1	16	Brown	A-3	B20	Bulkhead wiring harness
E2	54	Black	A-3	B21	
E3	16	Brown	C-3	B22	
E4	2	Blue	A-2		Purge control solenoid valve
E5	2	Dark gray	A-2		Fuel injector No. 1
E6	2	Dark gray	A-2		Fuel injector No. 3
E8	2	Black	B-4		Engine coolant temperature sensor
E10	2	Light gray	B-4		Crankshaft position sensor
E11	1	★	B-1		Oil pressure switch
E14	2	Blue	A-3		Knock sensor 1
E16	2	Dark gray	B-4		Fuel injector No. 2
E17	2	Dark gray	B-4		Fuel injector No. 4
E19	1	★	B-3		Power steering oil pressure switch
E24	4	Light gray	D-3		Front oxygen (A/F) sensor LH
E25	4	Dark gray	D-3		Rear oxygen sensor LH
E28	3	Black	A-3		Intake manifold pressure sensor
E31	3	Black	B-1		Ignition coil No. 1
E32	3	Black	C-4		Ignition coil No. 2
E33	3	★	B-2		Ignition coil No. 3
E34	3	★	B-4		Ignition coil No. 4
E43	2	Dark gray	A-2		Fuel injector No. 5
E44	2	Dark gray	B-5		Fuel injector No. 6
E45	3	Black	B-2		Ignition coil No. 5
E46	3	Black	B-5		Ignition coil No. 6
E47	4	Light gray	C-3		Front oxygen (A/F) sensor RH
E48	2	Blue	A-4		Knock sensor 2
E57	6	Black	A-3		Electronic throttle control
E61	4	Dark gray	C-3		Rear oxygen sensor RH
E67	2	Black	B-1		Oil flow control solenoid valve RH
E68	2	Black	C-4		Oil flow control solenoid valve LH
E69	2	Blue	A-2		Oil switching solenoid valve RH
E70	2	Blue	B-5		Oil switching solenoid valve LH
E71	1	★	A-3		Variable valve lift diagnosis oil pressure switch RH
E72	1	★	B-5		Variable valve lift diagnosis oil pressure switch LH
E73	3	Gray	A-2		Camshaft position sensor RH
E74	3	Gray	B-5		Camshaft position sensor LH
E75	2	Black	B-5		Oil temperature sensor
E76	6	Dark gray	A-3	E77	Engine wiring harness
E77	6	Dark gray	A-3	E76	


★ : White or natural color

Engine Wiring Harness and Transmission Cord

WIRING SYSTEM

Connector				Connecting to	
No.	Pole	Color	Area	No.	Description
T1	3	★	D-3		Torque converter turbine speed sensor 1
T3	8	Brown	D-2	B12	Bulkhead wiring harness
T4	20	Gray	D-3	B11	
T5	16	Green	D-3		Control valve assembly
T6	12	Green	D-3		

★ : White or natural color



61. Instrument Panel Wiring Harness

A: LOCATION

Connector				Connecting to	
No.	Pole	Color	Area	No.	Description
i1	28	Blue	B-1	B36	Bulkhead wiring harness
i2	25	★	B-1	B403	
i3	20	★	B-5	B38	
i5	20	★	C-1		Fuse & relay box (F/B)
i6	16	★	C-2		Remote control mirror switch
i10	30	Green	B-2		Combination meter
i11	14	Green	B-2		
i22	4	★	B-3		Hazard switch
i23	2	★	B-4		Glove box illumination
i26	16	★	C-4		Audio
i29	1	Black	C-4		Audio bracket earth
i51	2	★	B-5		Sunload sensor
i53	22	Blue	C-5	R98	Rear wiring harness
i76	25	★	C-1	D84	Front door cord LH
i78	15	Blue	C-2		Push switch
i79	6	★	C-2		Illumination control module
i82	12	Blue	B-2		Joint connector
i83	12	Blue	B-2		
i84	35	Gray	C-3		Body integrated unit
i85	14	★	C-4		Audio
i88	8	Black	C-4		A/C control panel
i96	8	★	B-5		Keyless entry control module
i97	22	★	C-3		Joint ground connector
i98	22	★	B-3		
i99	12	Black	C-5		
i100	12	Black	B-5		
i101	25	★	C-5	D83	Front door cord RH
i102	20	Blue	C-1	R167	Rear wiring harness
i106	4	★	B-3		TV monitor
i113	12	★	B-5		Joint connector
i114	12	★	B-5		
i116	10	Green	B-4		Warning box (Passenger's side)
i117	8	★	B-3		MFD switch
i118	8	Black	B-3		Navigation system switch
i119	16	Black	B-3		TV monitor
i120	20	Black	B-3		
i121	8	Black	B-3		Navigation system switch
i122	22	Green	B-3		MFD
i123	14	Green	B-3		Warning box (Driver's side)
i124	12	Gray	C-2		Joint connector
i125	12	Gray	C-2		
i126	12	Black	C-2		
i127	12	Black	C-2		
i129	8	★	C-3		Impact sensor
i130	22	★	C-3	R230	Rear wiring harness LH (CTR)
i131	20	Black	C-4		Audio unit


Instrument Panel Wiring Harness

WIRING SYSTEM

Connector				Connecting to	
No.	Pole	Color	Area	No.	Description
i132	22	★	B-5	R243	Roof harness
i133	5	Green	B-3		TV monitor (Rear entertainment)
i134	3	★	B-2		Turn signal hazard relay (Sound)
i141	4	★	C-1		CAN joint connector
i142	4	★	C-1		
i143	4	★	C-2		Joint connector
i144	4	★	C-2		
i145	32	★	C-3		Switching module
★ : White or natural color					

Instrument Panel Wiring Harness

WIRING SYSTEM



WI-11816

Rear Wiring Harness

WIRING SYSTEM

62.Rear Wiring Harness

A: LOCATION

1. PASSENGER'S SIDE

Connector				Connecting to	
No.	Pole	Color	Area	No.	Description
R1	24	Black	C-1	B98	Bulkhead wiring harness
R10	10	★	B-3	D22	Rear door cord (Passenger's side)
R12	3	★	B-2		Front door switch RH
R15	14	★	C-3	R60	Fuel cord 1
R16	3	★	B-3		Rear door switch RH
R44	6	★	C-3		Seat heater RH & second-row seat foot light RH
R47	3	Black	C-5		Fuel tank pressure sensor
R50	12	★	C-1	B90	Bulkhead wiring harness
R51	2	★	B-2		Vanity mirror illumination light RH
R52	3	★	B-3		Room light (without DVD)
R55	10	Gray	B-4		Sunroof control unit and motor
R56	6	Gray	B-3		Spot map light
R57	3	★	B-3		Shade mirror
R58	6	Gray	C-4		Fuel gauge main unit
R59	2	★	C-4		Fuel gauge sub unit
R60	14	★	C-3	R15	Rear wiring harness
R98	22	Blue	C-1	i53	Instrument panel wiring harness
R109	2	Black	C-3		Power seat RH
R117	2	★	A-4		Super woofer
R122	10	Black	B-4		Fuel pump control unit
R128	5	★	B-3		Open/Close switch
R143	2	Gray	C-5		Drain valve
R187	5	Black	B-3		Tilt switch
R233	4	★	C-3		Joint connector
R234	1	Black	C-5		Thermo switch
R235	10	★	A-5	R248	Tail harness
R236	24	★	B-4		Rear entertainment unit (Roof)
R237	4	★	B-3		Joint connector
R238	4	★	B-3		
R239	4	★	B-4		
R240	4	★	B-4		
R241	4	★	A-2		
R243	22	★	C-1	i132	Instrument panel wiring harness
R249	2	Gray	C-3		Rear ABS wheel speed sensor LH
R250	3	★	B-4		Room light (with DVD)
R251	4	★	B-2		Joint connector
R252	12	Gray	C-2		
R253	12	Gray	C-2		
R255	4	★	C-2		
R256	4	★	C-2		
R257	2	★	B-3		Rear tweeter RH
R270	2	★	B-4		Home link
R277	1	Black	C-4		Bracket earth (Rear differential gear oil temperature switch)

★ : White or natural color


Rear Wiring Harness

WIRING SYSTEM

Connector				Connecting to	
No.	Pole	Color	Area	No.	Description
AB18	20	Yellow	D-3		Airbag control module
AB24	2	Yellow	C-3		Inflator (Side) RH
AB26	2	Black	B-2		Pretensioner RH
AB28	4	Yellow	B-2		Side airbag sensor RH
AB33	2	Black	A-4		Inflator (Curtain) RH
AB34	4	Yellow	B-3		Curtain airbag sensor RH
AB56	3	Brown	C-2		Belt tension sensor (Occupant detection control module)
AB57	2	Yellow	C-1	AB55	Bulkhead harness
AB61	6	Gray	C-2	AB59	Occupant detection control module

Rear Wiring Harness

WIRING SYSTEM



WI-11817

Rear Wiring Harness

WIRING SYSTEM

2. DRIVER'S SIDE

Connector				Connecting to	
No.	Pole	Color	Area	No.	Description
R2	20	Black	D-2	B97	Bulkhead wiring harness
R8	4	★	C-2		Front seat belt switch LH
R9	3	★	C-3		Front door switch LH
R13	10	★	C-3	D28	Rear door cord LH
R22	3	★	C-4		Rear door switch LH
R28	4	★	B-5		Rear combination light LH
R41	6	★	C-2		Seat heater LH & second-row seat foot light LH
R167	20	Blue	D-2	i102	Instrument panel wiring harness
R168	20	★	D-1		Fuse & relay box (F/B)
R185	24	Gray	C-4		Rear view camera module
R188	4	Black	C-2		Power seat LH
R211	12	★	D-2		TPM control module
R215	14	★	B-5	R247	Tail harness
R216	12	Black	B-5	R246	Tail harness (Joint connector)
R217	10	★	B-5	R245	Tail harness (Rear entertainment)
R218	4	★	B-5		Rear A/C relay
R219	4	★	B-5		Blower fan resistor
R220	2	★	B-5		Blower fan motor
R221	4	★	C-3		Joint connector
R222	4	★	C-3		
R224	12	★	D-2		
R225	12	★	D-2		
R226	10	★	C-2		Navigation module
R227	12	Black	D-2		Joint connector
R228	12	Black	D-2		
R229	11	★	C-1	R272	Console pocket
R230	22	★	C-1	i130	Instrument panel wiring harness (Center)
R232	2	Gray	C-4		Rear ABS wheel speed sensor LH
R254	14	★	B-4	R260	Adapter code
R272	11	★	C-1	R229	Rear harness
R273	2	★	B-1		Cup holder illumination
R274	2	★	B-2		Front accessory power supply socket
R275	2	★	B-2		
R276	10	★	B-2		Blower fan switch
R280	6	Gray	C-2	R282	Console pocket
R281	4	★	D-2		Joint connector
R282	6	Gray	C-2	R280	Rear harness
R283	6	★	B-2		Front AUX terminal box
R287	6	Gray	B-4		Joint connector
R288	1	★	C-5		Rear view camera ground

★ : White or natural color


Rear Wiring Harness

WIRING SYSTEM

Connector				Connecting to	
No.	Pole	Color	Area	No.	Description
AB17	20	Yellow	C-1		Airbag control module
AB19	2	Yellow	C-2		Inflator (Side) LH
AB21	2	Black	C-3		Pretensioner LH
AB23	4	Yellow	C-3		Side airbag sensor LH
AB31	2	Black	B-4		Inflator (Curtain) LH
AB32	4	Yellow	C-4		Curtain airbag sensor LH
AB51	2	Yellow	C-2		Buckle switch LH
AB52	2	Yellow	C-2		Seat position LH

Rear Wiring Harness

WIRING SYSTEM



WI-11818

Door Cord

WIRING SYSTEM


63.Door Cord

A: LOCATION

Connector				Connecting to	
No.	Pole	Color	Area	No.	Description
D2	2	★	C-3		Front door speaker LH
D3	2	Gray	C-4		Front power window motor LH
D5	8	Gray	C-3		Remote control mirror LH
D7	16	★	C-3		Power window main switch
D10	2	★	C-4		Front step light LH
D12	2	★	C-2		Front door speaker RH
D13	2	Gray	C-2		Front power window motor RH
D15	8	Gray	B-2		Remote control mirror RH
D17	8	★	B-2		Front power window sub switch
D18	4	★	B-2		Front door lock actuator RH
D20	2	★	C-3		Front step light RH
D22	10	★	B-3	R10	Rear wiring harness RH
D23	2	Black	B-3		Rear door speaker RH
D24	2	Gray	C-4		Rear power window motor LH
D25	8	★	B-4		Rear power window sub-switch LH
D26	4	★	B-5		Rear door lock actuator LH
D28	10	★	C-4	R13	Rear wiring harness LH
D29	2	Black	C-4		Rear door speaker LH
D30	2	Gray	B-3		Rear power window motor RH
D31	8	★	B-3		Rear power window sub-switch RH
D32	4	★	B-3		Rear door lock actuator RH
D72	4	★	C-4		Front door lock actuator LH
D83	25	★	B-2	i101	Instrument panel wiring harness
D84	25	★	C-3	i76	
D93	2	★	C-3		Front door tweeter LH
D97	2	★	B-2		Front door tweeter RH
D125	5	★	B-2		Passenger's seat door lock switch
D126	4	★	B-2		Joint connector
D127	4	★	B-2		
D128	6	★	B-2		
D129	2	★	B-3		Rear step light RH
D130	2	★	C-4		Rear step light LH
D131	4	★	C-3		Joint connector
D132	4	★	C-3		
D133	4	★	C-3		

★ : White or natural color

WIRING SYSTEM



Rear Wiring Harness and Rear Gate Cord

WIRING SYSTEM

64.Rear Wiring Harness and Rear Gate Cord


A: LOCATION

Connector				Connecting to	
No.	Pole	Color	Area	No.	Description
D33	12	Gray	C-4	R38	Rear wiring harness
D34	2	★	C-4	R37	
D35	10	★	C-4	R39	
D37	3	★	B-3		Luggage room light
D39	2	★	B-3		High-mounted stop light
D43	4	★	B-4		Rear wiper motor
D44	2	★	B-4		License plate light
D87	2	★	B-5		Back-up light RH
D89	2	★	B-5		Rear defogger
D91	2	★	B-3		Back-up light LH
D134	2	Gray	B-3		Tail light LH
D135	2	★	B-4		Rear gate release switch
D136	1	★	B-3		Antenna amplifier
D137	2	★	B-4		License plate light
D138	3	★	B-5		Rear gate light
D139	2	Gray	B-5		Tail light RH
D140	4	★	A-4		Rear gate release actuator
D141	4	★	B-4		Joint connector
★ : White or natural color					

Connector				Connecting to	
No.	Pole	Color	Area	No.	Description
R26	4	★	C-4		Rear combination light RH
R37	2	★	C-4	D34	Rear gate cord
R38	12	Gray	C-4	D33	
R39	10	★	C-4	D35	
R79	6	★	D-3		Trailer connector
R245	10	★	C-4	R235	Roof code (Rear entertainment)
R246	12	Black	C-2	R216	Rear wiring harness (Through joint connector)
R247	14	★	C-1	R215	Rear wiring harness
R248	10	★	C-2	R235	
★ : White or natural color					

Rear Wiring Harness and Rear Gate Cord

WIRING SYSTEM



WI-11820

Rear Wiring Harness and Rear Gate Cord

WIRING SYSTEM
