

IMPORTANT

WARNING/CAUTION/NOTE

Please read this manual and follow its instructions carefully. To emphasize special information, the words

⚠ WARNING, **⚠ CAUTION** and **NOTE** have special meanings. Pay special attention to the messages highlighted by these signal words.

⚠ WARNING

Indicates a potential hazard that could result in death or injury.

⚠ CAUTION

Indicates a potential hazard that could result in vehicle damage.

NOTE:

Indicates special information to make maintenance easier or instructions clearer.

⚠ WARNING

This service manual is intended for authorized Suzuki dealers and qualified service technicians only. Inexperienced technicians or technicians without the proper tools and equipment may not be able to properly perform the services described in this manual.


Improper repair may result in injury to the technician and may render the vehicle unsafe for the driver and passengers.

⚠ WARNING

For vehicles equipped with a Supplemental Restraint (Air Bag) System:

- Service on and around the air bag system components or wiring must be performed only by an authorized SUZUKI dealer. Refer to “Air Bag System Components and Wiring Location View” under “General Description” in air bag system section in order to confirm whether you are performing service on or near the air bag system components or wiring. Please observe all WARNINGS and “Service Precautions” under “On-Vehicle Service” in air bag system section before performing service on or around the air bag system components or wiring. Failure to follow WARNINGS could result in unintentional activation of the system or could render the system inoperative. Either of these two conditions may result in severe injury.
 - If the air bag system and another vehicle system both need repair, Suzuki recommends that the air bag system be repaired first, to help avoid unintended air bag system activation.
 - Do not modify the steering wheel, instrument panel or any other air bag system component on or around air bag system components or wiring. Modifications can adversely affect air bag system performance and lead to injury.
 - If the vehicle will be exposed to temperatures over 93 °C (200 °F), for example, during a paint baking process, remove the air bag system components, that is air bag (inflator) modules, SDM and/or seat belt with pretensioner, beforehand to avoid component damage or unintended activation.
-

The circle with a slash in this manual means “Don’t do this” or “Don’t let this happen”.



FOREWORD

This manual (Volumes 1 and 2) contains procedures for diagnosis, maintenance, adjustments, minor service operations, replacement of components (Service) and for disassembly and assembly of major components (Unit Repair-Overhaul).

VOLUME 1 contains General information, Engine, Suspension, Drive/Axle and Brakes sections (Sections 0 – 5).
VOLUME 2 contains Transmission/Transaxle, Steering, HVAC, Restraint, Body/Cab/Accessories and Control Systems sections (Sections 6 – 10).

Applicable Model:

SX4 (RW420) produced at KOSAI plant in Japan with following vehicle identification number (VIN)

RW420 (Hatchback)

XSJSAGYA41S#####X ~

XSJSAGYB41S#####X ~

JS2YA41S##### ~

RW420 (Sedan)

XSJSAGYC41S#####X ~

JS2YC41S##### ~

The contents are classified into sections each of which is given a section number as indicated in the Table of Contents on following page. And on the first page of each individual section is an index of that section.

This manual should be kept in a handy place for ready reference of the service work.

Strict observance of the so specified items will enable one to obtain the full performance of the vehicle.

When replacing parts or servicing by disassembling, it is recommended to use SUZUKI genuine parts, tools and service materials as specified in each description.

All information, illustrations and specifications contained in this literature are based on the latest product information available at the time of publication approval. And used as the main subject of description is the vehicle of standard specifications among others.

Therefore, note that illustrations may differ from the vehicle being actually serviced.

The right is reserved to make changes at any time without notice.

SUZUKI MOTOR CORPORATION

RECOMMENDATION OF GENUINE SUZUKI PARTS AND ACCESSORIES USE

SUZUKI strongly recommends the use of genuine SUZUKI parts* and accessories. Genuine SUZUKI parts and accessories are built to the highest standards of quality and performance, and are designed to fit the vehicle's exact specifications.

A wide variety of non-genuine replacement parts and accessories for SUZUKI vehicles are currently available in the market. Using these parts and accessories can affect the vehicle performance and shorten its useful life. Therefore, installation of non-genuine SUZUKI parts and accessories is not covered under warranty.

Non-Genuine SUZUKI Parts and Accessories

Some parts and accessories may be approved by certain authorities in your country.

Some parts and accessories are sold as SUZUKI authorized replacement parts and accessories. Some genuine SUZUKI parts and accessories are sold as re-use parts and accessories. These parts and accessories are non-genuine Suzuki parts and accessories and use of these parts are not covered under warranty.

Re-use of Genuine SUZUKI Parts and Accessories

The resale or re-use of the following items which could give rise to safety hazards for users is expressly forbidden:

- 1) Airbag components and all other pyrotechnic items, including their components (e.g. cushion, control devices and sensors)
- 2) Seatbelt system, including their components (e.g. webbing, buckles, and retractors)

The air bag and seat belt pretensioner components contain explosive chemicals. These components should be removed and disposed of properly by SUZUKI authorized service shop or scrap yard to avoid unintended explosion before scrapping.

*The parts remanufactured under SUZUKI's approval can be used as genuine SUZUKI parts in Europe.

TABLE OF CONTENTS

Volume 1

Precautions.....	00-i
Precautions	00-1
General Information	0-i
General Information	0A-1
Maintenance and Lubrication	0B-1
Engine	1-i
Precautions	1-1
Engine General Information and Diagnosis	1A-1
Aux. Emission Control Devices	1B-1
Engine Electrical Devices.....	1C-1
Engine Mechanical.....	1D-1
Engine Lubrication System	1E-1
Engine Cooling System.....	1F-1
Fuel System	1G-1
Ignition System.....	1H-1
Starting System.....	1I-1
Charging System.....	1J-1
Exhaust System	1K-1
Suspension	2-i
Precautions	2-1
Suspension General Diagnosis	2A-1
Front Suspension.....	2B-1
Rear Suspension.....	2C-1
Wheels and Tires	2D-1
Driveline / Axle	3-i
Precautions	3-1
Drive Shaft / Axle	3A-1
Differential	3B-1
Transfer.....	3C-1
Propeller Shaft	3D-1
Brakes	4-i
Precautions	4-1
Brake Control System and Diagnosis	4A-1
Front Brakes.....	4B-1
Rear Brakes	4C-1
Parking Brake.....	4D-1
ABS	4E-1
Transmission / Transaxle	5-i
Precautions	5-1
Automatic Transmission/Transaxle	5A-1
Manual Transmission/Transaxle	5B-1
Clutch	5C-1

Volume 2

Precautions.....	00-i
Precautions	00-1
Steering.....	6-i
Precautions	6-1
Steering General Diagnosis	6A-1
Steering Wheel and Column	6B-1
Power Assisted Steering System	6C-1
HVAC	7-i
Precautions	7-1
Heater and Ventilation.....	7A-1
Air Conditioning System.....	7B-1
Restraint.....	8-i
Precautions	8-1
Seat Belts.....	8A-1
Air Bag System	8B-1
Body, Cab and Accessories	9-i
Precautions	9-1
Wiring Systems	9A-1
Lighting Systems.....	9B-1
Instrumentation / Driver Info. / Horn	9C-1
Wipers / Washers.....	9D-1
Glass / Windows / Mirrors	9E-1
Security and Locks.....	9F-1
Seats	9G-1
Interior Trim	9H-1
Hood / Fenders / Doors.....	9J-1
Body Structure	9K-1
Paint / Coatings.....	9L-1
Exterior Trim.....	9M-1
Control Systems.....	10-i
Precautions	10-1
Cruise Control System	10A-1
Body Electrical Control System	10B-1
Immobilizer Control System	10C-1
Keyless Start System	10E-1

00

0

1

2

3

4

5

6

7

8

9

10

Section 00

00

Precautions

CONTENTS

Precautions 00-1**Precautions..... 00-1**

Precautions for Vehicles Equipped with a Supplemental Restraint (Air Bag) System	00-1
General Precautions	00-3
Warning for Wheel (with tire) Removal	00-6
Precautions in Servicing 4WD Model.....	00-7
Precautions for Catalytic Converter	00-8
Precautions for Installing Mobile Communication Equipment.....	00-8
Precaution for CAN Communication System	00-8

Precautions for Electrical Circuit Service 00-8

Air Bag Warning 00-10

Fastener Caution..... 00-10

Suspension Caution 00-11

Wheels and Tires Caution..... 00-11

ABS Caution..... 00-11

Brake Caution 00-11

Repair Instructions 00-12

Electrical Circuit Inspection Procedure 00-12

Intermittent and Poor Connection Inspection 00-14

Precautions


Precautions

Precautions for Vehicles Equipped with a Supplemental Restraint (Air Bag) System

S7RW0C0000001

▲ WARNING

- The configuration of air bag system parts are as shown in the figure. When it is necessary to service (remove, reinstall and inspect) these parts, be sure to follow procedures described in "Precautions on Service and Diagnosis of Air Bag System in Section 8B". Failure to follow proper procedures could result in possible air bag system activation, personal injury, damage to parts or air bag system being unable to activate when necessary.
- If the air bag system and another vehicle system both need repair, SUZUKI recommends that the air bag system be repaired first, to help avoid unintended air bag system activation.
- Do not modify the steering wheel, dashboard, or any other air bag system components. Modifications can adversely affect air bag system performance and lead to injury.
- If the vehicle will be exposed to temperatures over 93 °C (200 °F) (for example, during a paint baking process), remove the air bag system components beforehand to avoid component damage or unintended air bag system activation.



I5RW0A000001-01


1. Air bag wire harness (in floor, main and instrument panel harness)	6. Driver air bag (inflator) module
2. Passenger air bag (inflator) module	7. Side air bag (inflator) module (if equipped)
3. SDM	8. Curtain air bag (inflator) module (if equipped)
4. Seat belt pretensioner	9. Forward impact sensor
5. Contact coil	10. Side impact sensor (if equipped)

Diagnosis

- When troubleshooting air bag system, be sure to follow "Diagnosis" in Air Bag System section. Bypassing these procedures may result in extended diagnostic time, incorrect diagnosis, and incorrect parts replacement.
- Never use electrical test equipment other than that specified.

▲ WARNING

Never attempt to measure the resistance of the air bag (inflator) modules (driver, passenger, side and curtain) and seat belt pretensioners (driver and passenger). It is very dangerous as the electric current from the tester may deploy the air bag or activate the pretensioner.



I4RS0A000002-02

Servicing and Handling

▲ WARNING


Many of service procedures require disconnection of “A/B” fuse and all air bag (inflator) module(s) from initiator circuit to avoid an accidental deployment.

Driver, Passenger, Side and Curtain Air Bag (Inflator) Modules



- For handling and storage of a live air bag (inflator) module, select a place where the ambient temperature below 65 °C (150 °F), without high humidity and away from electric noise.
- When carrying a live air bag (inflator) module, make sure the bag opening is pointed away from you. In case of an accidental deployment, the bag will then deploy with minimal chance of injury. Never carry the air bag (inflator) module by the wires or connector on the underside of the module. When placing a live air bag (inflator) module on a bench or other surface, always face the bag up, away from the surface. As the live passenger air bag (inflator) module must be placed with its bag (trim cover) facing up, place it on the workbench with a slit (1) or use the workbench vise (2) to hold it securely at its lower mounting bracket (3). It is also prohibited to place anything on top of the trim cover and stack air bag (inflator) modules. This is necessary so that a free space is provided to allow the air bag to expand in the unlikely event of accidental deployment. Otherwise, personal injury may result.
- Never dispose of live (undeployed) air bag (inflator) modules (driver, passenger, side and curtain). If disposal is necessary, be sure to deploy them according to deployment procedures described in “Air Bag (Inflator) Module and Seat Belt Pretensioner Disposal in Section 8B” before disposal.
- The air bag (inflator) module immediately after deployment is very hot. Wait for at least half an hour to cool it off before proceeding the work.

- After an air bag (inflator) module has been deployed, the surface of the air bag may contain a powdery residue. This powder consists primarily of cornstarch (used to lubricate the bag as it inflates) and by-products of the chemical reaction. As with many service procedures, gloves and safety glasses should be worn.

[A]



[B]



I7RW0C000001-01

[A]: Always carry air bag (inflator) module with trim cover (air bag opening) away from body.

[B]: Always place air bag (inflator) module on workbench with trim cover (air bag opening) up, away from loose objects.

⚠ WARNING**SDM**

- For handling and storage of a SDM, select a place where the ambient temperature below 65 °C (150 °F), without high humidity and away from electric noise.
- During service procedures, be very careful when handling a Sensing and Diagnostic Module (SDM). Never strike or jar the SDM.
- Never power up the air bag system when the SDM is not rigidly attached to the vehicle. All SDM and mounting bracket fasteners must be carefully torqued and the arrow must be pointing toward the front of the vehicle to ensure proper operation of the air bag system. The SDM could be activated when powered while not rigidly attached to the vehicle which could cause deployment and result in personal injury.

⚠ WARNING**Driver and Passenger Seat Belt Pretensioners**

- For handling and storage of a live seat belt pretensioner, select a place where the ambient temperature below 65 °C (150 °F), without high humidity and away from electric noise.
- Never carry seat belt pretensioner by wire or connector of pretensioner. When placing a live seat belt pretensioner on the workbench or some place like that, never put something on seat belt pretensioner. Otherwise, personal injury may result.
- Never dispose of live (inactivated) seat belt pretensioners (driver and passenger). If disposal is necessary, be sure to activate them according to activation procedures described in "Air Bag (Inflator) Module and Seat Belt Pretensioner Disposal in Section 8B" before disposal.
- The seat belt pretensioner immediately after activation is very hot. Wait for at least half an hour to cool it off before proceeding the work.
- With many service procedures, gloves and safety glasses should be worn to prevent any possible irritation of the skin or eyes.

- Even when the accident was light enough not to cause air bags to activate, be sure to inspect system parts and other related parts according to instructions under "Repair and Inspection Required after Accident in Section 8B".
- When servicing parts other than air bag system, if shocks may be applied to air bag system component parts, remove those parts beforehand.
- When handling the air bag (inflator) modules (driver, passenger, side and curtain), seat belt pretensioners (driver and passenger), forward sensor, side sensors or SDM, be careful not to drop it or apply an impact to it. If an excessive impact was applied, never attempt disassembly or repair but replace it with a new one.
- When grease, cleaning agent, oil, water, etc. has got onto air bag (inflator) modules (driver, passenger, side and curtain) or seat belt pretensioners (driver and passenger), wipe off immediately with a dry cloth.
- Air bag wire harness is included in floor and instrument panel wire harnesses. Air bag wire harness branched off from floor and instrument panel wire harnesses can be identified easily as it is covered with a yellow protection tube and it has yellow connectors. Be very careful when handling it.
- When an open in air bag wire harness, damaged wire harness, connector or terminal is found, replace wire harness, connectors and terminals as an assembly.
- Do not apply power to the air bag system unless all components are connected or a diagnostic flow requests it, as this will set a DTC.
- Never use air bag system component parts from another vehicle.
- When using electric welding, be sure to disconnect all air bag (inflator) module connectors and pretensioner connectors from air bag wire harness respectively.
- Never expose air bag system component parts directly to hot air (drying or baking the vehicle after painting) or flames.
- WARNING / CAUTION labels are attached on each part of air bag system components. Be sure to follow the instructions.
- After vehicle is completely repaired, perform "Air Bag Diagnostic System Check in Section 8B".

General Precautions

S7RW0C0000002


The WARNING and CAUTION describe some general precautions that you should observe when servicing a vehicle. These general precautions apply to many of the service procedures, and they will not necessarily be repeated with each procedure to which they apply.

⚠ WARNING

- Whenever raising a vehicle for service, be sure to follow the instructions under "Vehicle Lifting Points in Section 0A".
- When it is necessary to do service work with the engine running, make sure that the parking brake is set fully and the transmission is in Neutral (for manual transmission vehicles) or Park (for automatic transmission vehicles). Keep hands, hair, clothing, tools, etc. away from the fan and belts when the engine is running.
- When it is necessary to run the engine indoors, make sure that the exhaust gas is forced outdoors.
- Do not perform service work in areas where combustible materials can come in contact with a hot exhaust system. When working with toxic or flammable materials (such as gasoline and refrigerant), make sure that the area you work in is well-ventilated.
- To avoid getting burned, keep away from hot metal parts such as the radiator, exhaust manifold, tail pipe, muffler, etc.
- New and used engine oil can be hazardous. Children and pets may be harmed by swallowing new or used oil. Keep new and used oil and used engine oil filters away from children and pets. Continuous contact with used engine oil has been found to cause [skin] cancer in laboratory animals. Brief contact with used oil may irritate skin. To minimize your exposure to used engine oil, wear a long-sleeve shirt and moisture-proof gloves (such as dish washing gloves) when changing engine oil. If engine oil contacts your skin, wash thoroughly with soap and water. Launder any clothing or rags if wet with oil, recycle or properly dispose of used oil and filters.
- Be sure to observe following instructions when handling service materials such as fuel, oil, fluid, coolant, grease, sealant, thread lock cement, etc. Otherwise, your health may be ruined.
 - Whenever handling any of these service materials, wear safety glasses to protect your eyes. If it gets into your eye, it may cause inflammation.
 - Whenever handling any of these service materials, wear moisture-proof gloves to protect your skin. If it adheres to your skin, it may cause inflammation.


- Do not swallow any of these service materials. It would cause diarrhea or nausea.
- Keep all these materials out of children's reach.
- Make sure the bonnet is fully closed and latched before driving. If it is not, it can fly up unexpectedly during driving, obstructing your view and resulting in an accident.

- Before starting any service work, cover fenders, seats and any other parts that are likely to get scratched or stained during servicing. Also, be aware that what you wear (e.g., buttons) may cause damage to the vehicle's finish.



I2RH01010025-01


- When performing service to electrical parts that does not require use of battery power, disconnect the negative cable of the battery.
- When disconnecting the negative cable from the battery, be careful to the following.
 - Check and record DTCs in ECM and/or TCM if necessary before disconnecting.
 - Record displayed contents of the clock and/or audio system, etc. before disconnecting and reset it as before after connecting.
 - For vehicle equipped with electric throttle body system, perform electric throttle body system calibration referring to "Electric Throttle Body System Calibration in Section 1C" after reconnecting the negative cable to the battery.



I2RH01010026-01


00-5 Precautions:

- When removing the battery, be sure to disconnect the negative cable first and then the positive cable. When reconnecting the battery, connect the positive cable first and then the negative cable, and replace the terminal cover.




I2RH01010027-01

- When removing parts that are to be reused, be sure to keep them arranged in an orderly manner so that they may be reinstalled in the proper order and position.



I5RW0A000002-01


- Whenever you use oil seals, gaskets, packing, O-rings, locking washers, split pins, self-locking nuts, and certain other parts as specified, be sure to use new ones. Also, before installing new gaskets, packing, etc., be sure to remove any residual material from the mating surfaces.



I2RH01010029-01

- Make sure that all parts used in reassembly are perfectly clean. When use of a certain type of lubricant, bond or sealant is specified, be sure to use the specified type.

“A”: Water tight sealant 99000-31250 (SUZUKI Bond No.1207F)




I2RH01010030-01

- Be sure to use special tools when instructed.

Special tool


(A): 09917-98221

(B): 09916-58210




I2RH01010031-01

- When disconnecting vacuum hoses, attach a tag describing the correct installation positions so that the hoses can be reinstalled correctly.




I2RH01010032-01

- After servicing fuel, oil, coolant, vacuum, exhaust or brake systems, check all lines related to the system for leaks.



I2RH01010033-01

- For vehicles equipped with fuel injection systems, never disconnect the fuel line between the fuel pump and injector without first releasing the fuel pressure, or fuel can be sprayed out under pressure.
- When performing a work that produces a heat exceeding 80 °C (176 °F) in the vicinity of the electrical parts, remove the heat sensitive electrical part(s) beforehand.




I2RH01010034-01

- Use care not to expose connectors and electrical parts to water which will be a cause of a trouble.



I2RH01010035-01

- Always be careful not to handle electrical parts (computer, relay, etc.) in a rough manner or drop them.



I2RH01010036-01

Warning for Wheel (with tire) Removal

S7RW0C0000003

⚠ WARNING

When removing any of these wheels installed with wheel bolts or nuts, never remove all wheel bolts or nuts at the same time. Leave at least 1 bolt or nut for each wheel as it is to prevent wheel from dropping. When removing this remaining 1 bolt or nut, hold wheel and tire so as not to allow them to come off.


Precautions in Servicing 4WD Model

S7RW0C0000004


⚠ CAUTION

- Never perform any of the following [A], [B] and [C] types of service work.
If it is performed while 4WD-auto mode or 4WD-lock mode is selected, front wheels (or rear wheels) drive rear wheels (or front wheels) and vehicle accident, drivetrain damage and personal injury may result. Also, if it is performed while 2WD mode is selected, the coupling may be damaged because of the difference in revolution speed between front wheels and rear wheels.


[A]



[B]




[C]



I3RH0A000004-03

[A]:	Testing with 2-wheel chassis dynamometer or speedometer tester.
[B]:	Driving front wheels, which are jacked up.
[C]:	Towing under the condition where either front or rear wheels can not rotate.

- When testing with 2-wheel chassis dynamometer or speedometer tester, be sure to select 4WD system to 4WD-auto or 4WD-lock modes and use 2-wheel free roller together or make the vehicle as front wheel drive by removing propeller shaft.
- When testing with 2-wheel brake tester, be sure to observe the following instructions. Otherwise, drive train damage and personal injury may result.
 - Shift transaxle to N (Neutral) position.
 - Select 4WD system to 2WD mode.
 - Run engine at specified idle speed.
 - Rotate wheels (tires) by brake tester at vehicle speed below 5 km/h (3 mile/h).
 - Do not rotate wheels (tires) for 1 min. or more.
- When using On-vehicle type wheel balancing equipment (1), be sure to select 4WD system to 4WD-auto or 4WD-lock modes and jack up all four wheels, off the ground completely and support vehicle with safety stands (2).
Be careful of the other wheels, which will rotate at the same time.
Using it with 2WD mode may damage coupling.



I3RH01010062-01

- This vehicle should be towed under one of the following conditions:
 - With all wheels on a flatbed truck.
 - With all wheels on the ground.

Precautions for Catalytic Converter

S7RW0C0000005

For vehicles equipped with a catalytic converter, use only unleaded gasoline and be careful not to let a large amount of unburned gasoline enter the converter or it can be damaged.

- Conduct a spark jump test only when necessary, make it as short as possible, and do not open the throttle.
- Conduct engine compression checks within the shortest possible time.
- Avoid situations which can result in engine misfire (e.g. starting the engine when the fuel tank is nearly empty.)

Precautions for Installing Mobile Communication Equipment

S7RW0C0000006

When installing mobile communication equipment such as CB (Citizens-Band)-radio or cellular-telephone, be sure to observe the following precautions.


Failure to follow cautions may adversely affect electronic control system.

- Keep the antenna as far away as possible from the vehicle's electronic control unit.
- Keep the antenna feeder more than 20 cm (7.9 in.) away from electronic control unit and its wire harnesses.
- Do not run the antenna feeder parallel with other wire harnesses.
- Confirm that the antenna and feeder are correctly adjusted.

Precaution for CAN Communication System


S7RW0C0000007

- The loose (1) in the wire harnesses twist of the CAN lines except around the connector (3) should be within 100 mm (3.9 in.). Refer to the wiring diagram for the CAN lines discrimination. Excessively-loosed lines may be influenced by the electric noise.



I4JA01000002-01

- Do not connect terminals of the CAN line using a bypass wire (1). Otherwise, the CAN line may be influenced by the electric noise.




I4JA01000003-01

Precautions for Electrical Circuit Service


S7RW0C0000008

- When replacing a fuse, make sure to use a fuse of the specified capacity. Use of a fuse with a larger capacity will cause a damage to the electrical parts and a fire.



I2RH01010038-01


- When disconnecting and connecting coupler, make sure to turn ignition switch OFF, or electronic parts may get damaged.



I2RH01010039-01


00-9 Precautions:

- When disconnecting connectors, never pull the wiring harness. Unlock the connector lock first and then pull them apart by holding connectors themselves.




I2RH01010040-01

- When connecting connectors, also hold connectors and put them together until they lock securely (a click is heard).




I2RH01010041-01

- When installing the wiring harness, fix it with clamps so that no slack is left.




I2RH01010042-01

- When installing vehicle parts, be careful so that the wiring harness is not interfered with or caught by any other part.




I2RH01010043-01

- To avoid damage to the harness, protect its part which may contact against a part forming a sharp angle by winding tape or the like around it.




I2RH01010044-01

- Be careful not to touch the electrical terminals of parts which use microcomputers (e.g. electronic control unit like as ECM, PCM, P/S controller, etc.). The static electricity from your body can damage these parts.



I3RM0A000004-01

- Never connect any tester (voltmeter, ohmmeter, or whatever) to electronic control unit when its coupler is disconnected. Attempt to do it may cause damage to it.
- Never connect an ohmmeter to electronic control unit with its coupler connected to it. Attempt to do it may cause damage to electronic control unit and sensors.
- Be sure to use a specified voltmeter / ohmmeter. Otherwise, accurate measurements may not be obtained or personal injury may result. If not specified, use a voltmeter with high impedance ($M \Omega/V$ minimum) or a digital type voltmeter.
- When taking measurements at electrical connectors using a tester probe, be sure to insert the probe (2) from the wire harness side (backside) of the connector (1).




I2RH01010046-01

- When connecting meter probe (2) from terminal side of coupler (1) because it can't be connected from harness side, use extra care not to bend male terminal of coupler or force its female terminal open for connection.


In case of such coupler as shown connect probe as shown to avoid opening female terminal.

Never connect probe where male terminal is supposed to fit.



I2RH01010047-01

- When checking connection of terminals, check its male half for bend and female half for excessive opening and both for locking (looseness), corrosion, dust, etc.
- Before measuring voltage at each terminal, check to make sure that battery voltage is 11 V or higher. Such terminal voltage check at low battery voltage will lead to erroneous diagnosis.



I2RH01010048-01

Air Bag Warning

S7RW0C0000009

⚠ WARNING

For vehicles equipped with Supplemental Restraint (Air Bag) System:

- Service on and around the air bag system components or wiring must be performed only by an authorized SUZUKI dealer. Refer to "Air Bag System Components, Wiring and Connectors Location in Section 8B" in order to confirm whether you are performing service on or near the air bag system components or wiring. Please observe all WARNINGS in Air Bag System section and "Precautions on Service and Diagnosis of Air Bag System in Section 8B" before performing service on or around the air bag system components or wiring. Failure to follow WARNINGS could result in unintentional activation of the system or could render the system inoperative. Either of these two conditions may result in severe injury.
- Technical service work must be started at least 90 seconds after the ignition switch is turned to the LOCK position and the negative cable is disconnected from the battery. Otherwise, the system may be activated by reserve energy in the Sensing and Diagnostic Module (SDM).

Fastener Caution

S7RW0C0000010

⚠ CAUTION

When fasteners are removed, always reinstall them at the same location from which they were removed. If a fastener needs to be replaced, use the correct part number fastener for that application. If the correct part number fastener is not available, a fastener of equal size and strength (or stronger) may be used. Fasteners that are not reused, and those requiring thread-locking compound, will be called out. The correct torque value must be used when installing fasteners that require it. If the conditions are not followed, parts or system damage could result.

Suspension Caution

S7RW0C0000011

⚠ CAUTION

- All suspension fasteners are an important attaching part in that it could affect the performance of vital parts and systems, and/or could result in major repair expense. They must be replaced with one of the same part number or with an equivalent part if replacement becomes necessary. Do not use a replacement part of lesser quality or substitute design. Torque values must be used as specified during reassembly to assure proper retention of this part.
- Never attempt to heat, quench or straighten any suspension part. Replace it with a new part or damage to the part may result.

Wheels and Tires Caution

S7RW0C0000012

⚠ CAUTION

All wheel fasteners are important attaching parts in that they could affect the performance of vital parts and systems, and/or could result in major repair expense. They must be replaced with one of the same part number or with an equivalent part if replacement becomes necessary. Do not use a replacement part of lesser quality or substitute design. Torque values must be used as specified during reassembly to assure proper retention of all parts. There is to be no welding as it may result in extensive damage and weakening of the metal.

ABS Caution

S7RW0C0000014

- When ABS control module is removed / installed, do not use impact wrenches which generate shock or impact to avoid damaging sensors in ABS control module.

Brake Caution

S7RW0C0000013

⚠ CAUTION

All brake fasteners are important attaching parts in that they could affect the performance of vital parts and systems, and/or could result in major repair expense. They must be replaced with one of same part number or with an equivalent part if replacement becomes necessary. Do not use a replacement part of lesser quality or substitute design. Torque values must be used as specified during reassembly to assure proper retention of all parts. There is to be no welding as it may result in extensive damage and weakening of the metal.

Repair Instructions

Electrical Circuit Inspection Procedure

S7RW0C0006001

While there are various electrical circuit inspection methods, described here is a general method to check its open and short circuit by using an ohmmeter and a voltmeter.


Open Circuit Check

Possible causes for the open circuit are as follows. As the cause is in the connector or terminal in many cases, they need to be checked particularly carefully.

- Loose connection of connector
- Poor contact of terminal (due to dirt, corrosion or rust on it, poor contact tension, entry of foreign object etc.)
- Wire harness being open


When checking system circuits including an electronic control unit such as ECM, TCM, ABS control module, etc., it is important to perform careful check, starting with items which are easier to check.

- 1) Disconnect negative (–) cable from battery
- 2) Check each connector at both ends of the circuit being checked for loose connection. Also check lock condition of connector if equipped with connector lock.



I2RH01010049-01


- 3) Using a test male terminal, check both terminals of the circuit being checked for contact tension of its female terminal. Check each terminal visually for poor contact (possibly caused by dirt, corrosion, rust entry of foreign object, etc.). At the same time, check to make sure that each terminal is locked in the connector fully.



I2RH01010050-01

1. Check contact tension by inserting and removing just for once.

- 4) Using continuity check or voltage check the following procedure, check the wire harness for open circuit and poor connection with its terminals. Locate abnormality, if any.




I2RH01010051-01

1. Looseness of crimping	3. Thin wire (single strand of wire)
2. Open	


Continuity Check

- 1) Measure resistance between connector terminals at both ends of the circuit being checked (between "A-1" and "C-1" in the figure). If no continuity is indicated (infinity or over limit), that means that the circuit is open between terminals "A-1" and "C-1".



I2RH01010052-01

- 2) Disconnect the connector included in the circuit (connector-B in the figure) and measure resistance between terminals "A-1" and "B-1". If no continuity is indicated, that means that the circuit is open between terminals "A-1" and "B-1". If continuity is indicated, there is an open circuit between terminals "B-1" and "C-1" or an abnormality in connector-B.



I2RH01010053-01

Voltage Check

If voltage is supplied to the circuit being checked, voltage check can be used as circuit check.

- 1) With all connectors connected and voltage applied to the circuit being checked, measure voltage between each terminal and body ground.
 - a) If measurements were taken as shown in the figure and results were as listed in the following, it means that the circuit is open between terminals "B-1" and "A-1".

Voltage between

"C-1" and body ground: Approx. 5 V

"B-1" and body ground: Approx. 5 V

"A-1" and body ground: 0 V


- b) Also, if measured values were as listed in the following, it means that there is a resistance (abnormality) of such level that corresponds to the voltage drop in the circuit between terminals "A-1" and "B-1".

Voltage between

"C-1" and body ground: Approx. 5 V

"B-1" and body ground: Approx. 5 V

"A-1" and body ground: Approx. 3 V

**Short Circuit Check (Wire Harness to Ground)**


- 1) Disconnect negative (-) cable at battery.
- 2) Disconnect connectors at both ends of the circuit to be checked.

NOTE


If the circuit to be checked is connected to other parts (1), disconnect all connectors of those parts.

Otherwise, diagnosis will be misled.

- 3) Measure resistance between terminal at one end of circuit ("A-1" terminal in the figure) and body ground. If continuity is indicated, it means that there is a short to ground between terminals "A-1" and "C-1" of the circuit.



- 4) Disconnect the connector included in circuit (connector-B) and measure resistance between "A-1" and body ground. If continuity is indicated, it means that the circuit is shorted to the ground between terminals "A-1" and "B-1".




Intermittent and Poor Connection Inspection

S7RW0C0006002


Most intermittent are caused by faulty electrical connections or wiring, although a sticking relay or solenoid can occasionally be at fault. When checking it for proper connection, perform careful check of suspect circuits for:

- Poor mating of connector halves, or terminals not fully seated in the connector body (backed out).
- Dirt or corrosion on the terminals. The terminals must be clean and free of any foreign material which could impede proper terminal contact. However, cleaning the terminal with a sand paper or the like is prohibited.
- Damaged connector body, exposing the terminals to moisture and dirt, as well as not maintaining proper terminal orientation with the component or mating connector.



I2RH01010057-01


- Improperly formed or damaged terminals. Check each connector terminal in problem circuits carefully to ensure good contact tension by using the corresponding mating terminal. If contact tension is not enough, reform it to increase contact tension or replace.



I5RH01000007-01


- | |
|---|
| 1. Check contact tension by inserting and removing just once. |
| 2. Check each terminal for bend and proper alignment. |

- Poor terminal-to-wire connection. Check each wire harness in problem circuits for poor connection by shaking it by hand lightly. If any abnormal condition is found, repair or replace.



I2RH01010059-01

- Wire insulation which is rubbed through, causing an intermittent short as the bare area touches other wiring or parts of the vehicle.
- Wiring broken inside the insulation. This condition could cause continuity check to show a good circuit, but if only 1 or 2 strands of a multi-strand-type wire are intact, resistance could be far too high. If any abnormality is found, repair or replace.



I2RH01010060-01

Section 0

General Information

CONTENTS

0

General Information	0A-1	Fuel Tank Inspection	0B-4
General Description	0A-1	PCV Valve Inspection	0B-4
Abbreviations	0A-1	Fuel Evaporative Emission Control System	
Symbols	0A-2	Inspection	0B-4
Wire Color Symbols	0A-2	Brake Discs and Pads Inspection	0B-4
Fasteners Information	0A-3	Brake Drums and Shoes (Rear) Inspection	0B-4
Vehicle Lifting Points	0A-5	Brake Hoses and Pipes Inspection	0B-4
Vehicle Identification Number	0A-6	Brake Fluid Replacement	0B-4
Engine Identification Number	0A-6	Brake Lever and Cable Inspection	0B-4
Transmission Identification Number	0A-6	Clutch Pedal Inspection	0B-4
Component Location	0A-7	Clutch Fluid Inspection	0B-4
Warning, Caution and Information Labels		Tires Inspection	0B-4
Location	0A-7	Wheel Discs Inspection	0B-4
Maintenance and Lubrication	0B-1	Wheel Bearing Inspection	0B-4
Precautions	0B-1	Suspension System Inspection	0B-4
Precautions for Maintenance and Lubrication	0B-1	Steering System Inspection	0B-4
Scheduled Maintenance	0B-1	Drive Shaft (Axle) Boots Inspection	0B-4
Maintenance Schedule under Normal Driving		Propeller Shaft (4WD) Inspection	0B-4
Conditions	0B-1	Manual Transaxle Oil Inspection	0B-4
Maintenance Recommended under Severe		Manual Transaxle Oil Replacement	0B-4
Driving Conditions	0B-2	Automatic Transaxle Fluid Level Inspection	0B-4
Repair Instructions	0B-3	Automatic Transaxle Fluid Replacement	0B-4
Accessory Drive Belt Inspection	0B-3	Automatic Transaxle Fluid Cooler Hose	
Accessory Drive Belt Replacement	0B-3	Inspection	0B-4
Valve Lash (Clearance) Inspection	0B-3	Transfer Oil Inspection (4WD)	0B-5
Engine Oil and Filter Change	0B-3	Transfer Oil Replacement (4WD)	0B-5
Engine Coolant Change	0B-3	Rear Differential Oil Inspection (4WD)	0B-5
Exhaust System Inspection	0B-3	Rear Differential Oil Replacement (4WD)	0B-5
Spark Plug Replacement	0B-3	All Latches, Hinges and Locks Inspection	0B-5
Air Cleaner Filter Inspection	0B-3	HVAC Air Filter (If Equipped) Inspection	0B-5
Air Cleaner Filter Replacement	0B-3	HVAC Air Filter (If Equipped) Replacement	0B-5
Fuel Lines and Connections Inspection	0B-3	Final Inspection for Maintenance Service	0B-5
Fuel Filter Replacement	0B-3	Special Tools and Equipment	0B-6
		Recommended Fluids and Lubricants	0B-6

General Information

General Description

Abbreviations

S7RW0C0101001

A:
ABDC: After Bottom Dead Center
ABS: Anti-lock Brake System
AC: Alternating Current
A/C: Air Conditioning
A-ELR: Automatic-Emergency Locking Retractor
A/F: Air Fuel Mixture Ratio
ALR: Automatic Locking Retractor
API: American Petroleum Institute
APP sensor: Accelerator Pedal Position Sensor
A/T: Automatic Transmission, Automatic Transaxle
ATDC: After Top Dead Center
ATF: Automatic Transmission Fluid, Automatic Transaxle Fluid
B:
B+: Battery Positive Voltage
BBDC: Before Bottom Dead Center
BCM: Body Electrical Control Module
BTDC: Before Top Dead Center
C:
CAN: Controller Area Network
CKT: Circuit
CKP Sensor: Crankshaft Position Sensor
CMP Sensor: Camshaft Position Sensor
CO: Carbon Monoxide
CPP Switch: Clutch Pedal Position Switch (Clutch Switch, Clutch Start Switch)
CPU: Central Processing Unit
CRS: Child Restraint System
D:
DC: Direct Current
DLC: Data Link Connector (Assembly Line Diag. Link, ALDL, Serial Data Link, SDL)
DOHC: Double Over Head Camshaft
DOJ: Double Offset Joint
DRL: Daytime Running Light
DTC: Diagnostic Trouble Code (Diagnostic Code)
E:
EBCM: Electronic Brake Control Module, ABS Control Module
EBD: Electronic Brake Force Distribution
ECM: Engine Control Module
ECT Sensor: Engine Coolant Temperature Sensor (Water Temp. Sensor, WTS)
EFE Heater: Early Fuel Evaporation Heater (Positive Temperature Coefficient, PTC Heater)
EGR: Exhaust Gas Recirculation
EGRT Sensor: EGR Temperature Sensor (Recirculated Exhaust Gas Temp. Sensor, REGTS)
EPS: Electronic Power Steering
EVAP: Evaporative Emission
EVAP Canister: Evaporative Emission Canister (Charcoal Canister)

F:
4WD: 4 Wheel Drive
G:
GEN: Generator
GND: Ground
GPS: Global Positioning System
H:
HVAC: Heating, Ventilating and Air Conditioning
HC: Hydrocarbons
HO2S: Heated Oxygen Sensor
I:
IAC Valve: Idle Air Control Valve (Idle Speed Control Solenoid Valve, ISC Solenoid Valve)
IAT Sensor: Intake Air Temperature Sensor (Air temperature Sensor, ATS)
ICM: Immobilizer Control Module
IG: Ignition
IMT: Intake Manifold Tuning
ISC Actuator: Idle Speed Control Actuator
ISO: International Organization for Standardization
J:
JIS: Japanese Industrial Standards
L:
LH: Left Hand
LHD: Left Hand Drive vehicle
LSPV: Load Sensing Proportioning Valve
M:
MAF Sensor: Mass Air Flow Sensor (Air Flow Sensor, AFS, Air Flow Meter, AFM)
MAP Sensor: Manifold Absolute Pressure Sensor (Pressure Sensor, PS)
Max: Maximum
MFI: Multiport Fuel Injection (Multipoint Fuel Injection)
Min: Minimum
MIL: Malfunction Indicator Lamp ("SERVICE ENGINE SOON" Light)
M/T: Manual Transmission, Manual Transaxle
N:
NOx: Nitrogen Oxides
O:
OBD: On-Board Diagnostic System (Self-Diagnosis Function)
O/D: Overdrive
OHC: Over Head Camshaft
O2S: Oxygen Sensor
P:
PCM: Powertrain Control Module
PCV: Positive Crankcase Ventilation
PNP: Park / Neutral Position
P/S: Power Steering
PSP Switch: Power Steering Pressure Switch (P/S Pressure Switch)
R:
RH: Right Hand
RHD: Right Hand Drive vehicle

S:**SAE:** Society of Automotive Engineers**SDM:** Sensing and Diagnostic Module (Air Bag Controller, Air bag Control Module)**SDT:** Smart Diagnostic Tester**SFI:** Sequential Multiport Fuel Injection**SOHC:** Single Over Head Camshaft**T:****TBI:** Throttle Body Fuel Injection (Single-Point Fuel Injection, SPI)**TCC:** Torque Converter Clutch**TCM:** Transmission Control Module (A/T Controller, A/T Control Module)**TDC:** Top Dead Center**TP Sensor:** Throttle Position Sensor**TVV:** Thermal Vacuum Valve (Thermal Vacuum

Switching Valve, TVSV, Bimetal Vacuum Switching Valve, BVSV)

TWC: Three Way Catalytic Converter (Three Way Catalyst)**2WD:** 2 Wheel Drive**U:****USB:** Universal Serial Bus**V:****VIN:** Vehicle Identification Number**VSS:** Vehicle Speed Sensor**VVT:** Variable Valve Timing (Camshaft Position Control)**W:****WU-OC:** Warm Up Oxidation Catalytic Converter**WU-TWC:** Warm Up Three Way Catalytic Converter**Symbols**

S7RW0C0101002

Symbol	Definition	Symbol	Definition
	Tightening torque		Apply SUZUKI BOND NO. 1216B 99000-31230
	Apply oil (engine, transmission, transfer, differential)		Apply SILICONE SEALANT 99000-31120
	Apply fluid (brake, power steering or automatic transmission fluid)		Apply SEALING COMPOUND 366E 99000-31090
	Apply SUZUKI SUPER GREASE A 99000-25010		
	Apply SUZUKI SUPER GREASE C 99000-25030		Apply THREAD LOCK 1322 99000-32110
	Apply SUZUKI SUPER GREASE E 99000-25050		Apply THREAD LOCK 1333B 99000-32020
	Apply SUZUKI SUPER GREASE H 99000-25120		Apply THREAD LOCK 1342 99000-32050
	Apply SUZUKI SUPER GREASE I 99000-25210		
	Apply SUZUKI BOND NO. 1215 99000-31110		Do not reuse
	Apply SUZUKI BOND NO. 1207F 99000-31250		Note on reassembly
	Apply SUZUKI BOND NO. 1217G 99000-31260		

Wire Color Symbols

S7RW0C0101003


Symbol	Wire Color	Symbol	Wire Color
B	BLK	O, Or	ORN
Bl	BLU	R	RED
Br	BRN	W	WHT
G	GRN	Y	YEL
Gr	GRY	P	PNK
Lbl	LT BLU	V	PPL
Lg	LT GRN		

0A-3 General Information:

There are two kinds of colored wire used in this vehicle. One is single-colored wire and the other is dual-colored (striped) wire.

The single-colored wire uses only one color symbol (i.e. “GRN”).

The dual-colored wire uses two color symbols (i.e. “GRN/YEL”). The first symbol represents the base color of the wire (“GRN” in the figure) and the second symbol represents the color of the stripe (“YEL” in the figure).



I2RH01010010-01

Fasteners Information

S7RW0C0101004

Metric Fasteners

Most of the fasteners used for this vehicle are JIS-defined and ISO-defined metric fasteners. When replacing any fasteners, it is most important that replacement fasteners be the correct diameter, thread pitch and strength.



 CAUTION

Even when the nominal diameter (1) of thread is the same, the thread pitch (2) or the width across flats (3) may vary between ISO and JIS. Refer to JIS-TO-ISO Main Fasteners Comparison Table below for the difference. Installing a mismatched bolt or nut will cause damage to the thread.

Before installing, check the thread pitch for correct matching and then tighten it by hand temporarily. If it is tight, recheck the thread pitch.

JIS-TO-ISO Main Fasteners Comparison Table

		Nominal diameter				
		M6	M8	M10	M12	M14
JIS	Thread pitch	1.0	1.25	1.25	1.25	1.5
	Width across flats	10	12	14	17	19
ISO	Thread pitch	1.0	1.25	1.5	1.5	1.5
	Width across flats	10	13	16	18	21




I4RH0A010005-01

Fastener Strength Identification

Most commonly used metric fastener strength property classes are 4T, 6.8, 7T, 8.8 and radial line with the class identification embossed on the head of each bolt. Some metric nuts will be marked with punch, 6 or 8 mark strength identification on the nut face. Figure shows the different strength markings.

When replacing metric fasteners, be careful to use bolts and nuts of the same strength or greater than the original fasteners (the same number marking or higher). It is likewise important to select replacement fasteners of the correct diameter and thread pitch. Correct replacement bolts and nuts are available through the parts division.

Metric bolts: Identification class numbers or marks correspond to bolt strength (increasing numbers represent increasing strength).



I5RH01010001-01

1. Nut strength identification




Standard Tightening Torque

Each fastener should be tightened to the torque specified in each section. If no description or specification is provided, refer to the following tightening torque chart for the applicable torque for each fastener. When a fastener of greater strength than the original one is used, however, use the torque specified for the original fastener.

NOTE

- For the flanged bolt, flanged nut and self-lock nut of 4T and 7T strength, add 10% to the tightening torque given in the following chart.
- The following chart is applicable only where the fastened parts are made of steel light alloy.

Tightening torque chart

Strength	Unit	Thread diameter (Nominal diameter) (mm)								
		4	5	6	8	10	12	14	16	18
A equivalent of 4T strength fastener	N·m	1.5	3.0	5.5	13	29	45	65	105	160
	kgf·m	0.15	0.30	0.55	1.3	2.9	4.5	6.5	10.5	16
	lb·ft	1.0	2.5	4.0	9.5	21.0	32.5	47.0	76.0	116.0
 I2RH01010012-01	N·m	2.4	4.7	8.4	20	42	80	125	193	280
	kgf·m	0.24	0.47	0.84	2.0	4.2	8.0	12.5	19.3	28
	lb·ft	2.0	3.5	6.0	14.5	30.5	58.0	90.5	139.5	202.5
 I2RH01010013-01	N·m	2.4	4.9	8.8	21	44	84	133	203	298
	kgf·m	0.24	0.49	0.88	2.1	4.4	8.4	13.3	20.3	29.8
	lb·ft	2.0	3.5	6.5	15.5	32.0	61.0	96.5	147.0	215.5
 I2RH01010014-01	N·m	2.3	4.5	10	23	50	85	135	210	240
	kgf·m	0.23	0.45	1.0	2.3	5.0	8.5	13.5	21	24
	lb·ft	2.0	3.5	7.5	17.0	36.5	61.5	98.0	152.0	174.0
 I2RH01010015-01	N·m	3.1	6.3	11	27	56	105	168	258	373
	kgf·m	0.31	0.63	1.1	2.7	5.6	10.5	16.8	25.8	37.3
	lb·ft	2.5	4.5	8.0	19.5	40.5	76.0	121.5	187.0	270.0
 I2RH01010016-01	N·m	3.2	6.5	12	29	59	113	175	270	395
	kgf·m	0.32	0.65	1.2	2.9	5.9	11.3	17.5	27	39.5
	lb·ft	2.5	5.0	9.0	21.0	43.0	82.0	126.5	195.5	286.0
 I2RH01010017-01	N·m	3.1	6.3	11	27	56	105	168	258	373
	kgf·m	0.31	0.63	1.1	2.7	5.6	10.5	16.8	25.8	37.3
	lb·ft	2.5	4.5	8.0	19.5	40.5	76.0	121.5	187.0	270.0

*:Self-lock nut


Vehicle Lifting Points

S7RW0C0101005

⚠ WARNING

- Before applying hoist to underbody, always take vehicle balance throughout service into consideration. Vehicle balance on hoist may change depending on what part to be removed.
- Before lifting up the vehicle, check to be sure that end of hoist arm is not in contact with brake pipe, fuel pipe, bracket or any other part.
- When using frame contact hoist, apply hoist as shown (right and left at the same position). Lift up the vehicle till 4 tires are a little off the ground and make sure that the vehicle will not fall off by trying to move vehicle body in both ways. Work can be started only after this confirmation.
- Make absolutely sure to lock hoist after vehicle is hoisted up.

When Using Frame Contact Hoist



I5RW0A010001-02

1. Vehicle front	3. Floor jack position	5. Cap
2. Support position for frame contact hoist and safety stand	4. Body mounting stay	

When Using Floor Jack



⚠ WARNING

If the vehicle to be jacked up only at the front or rear end, be sure to block the wheels on ground in order to ensure safety. After the vehicle is jacked up, be sure to support it on stands. It is extremely dangerous to do any work on the vehicle raised on jack alone.

⚠ CAUTION



Never apply jack against rear suspension parts (i.e., torsion beam, etc.) or vehicle floor, or it may get deformed.

In raising front or rear vehicle end off the floor by jacking, be sure to put the jack against engine front mounting member (1) or rear jacking bracket (2).



I5RW0A010002-02

To perform service with either front or rear vehicle end jacked up, be sure to place safety stands (1) under shaded position of vehicle body (front) or body mounting stay (2) (rear) so that vehicle body is securely supported. And then check to ensure that vehicle body does not slide on safety stands (1) and the vehicle is held stable for safety's sake.




I5RW0A010003-03

[A]: Front	3. Cap
[B]: Rear	

Vehicle Identification Number

S7RW0C0101006

The number is punched on the front dash panel in engine room and it is also attached on the left side of instrument panel depending on the vehicle specification.




I5RW0C010002-01

Engine Identification Number

S7RW0C0101007

The number is punched on cylinder block.




I3RH01010003-01

Transmission Identification Number

S7RW0C0101008

The automatic transmission identification number is located on transmission case.




I4RS0A010008-01

Component Location

Warning, Caution and Information Labels Location


S7RW0C0103001

The figure shows main labels among others that are attached to vehicle component parts.
When servicing and handling parts, refer to WARNING / CAUTION instructions printed on labels.
If any WARNING / CAUTION label is found stained or damaged, clean or replace it as necessary.



I5RW0C010001-02

1. Air bag label on sun visor (if equipped)	3. Engine cooling fan label	5. Jack label
2. Radiator cap label	4. Steering shaft joint cover label	



I7RW0A010001-01

1. Air bag label on driver air bag (inflator) module	7. Pretensioner label on seat belt retractor
2. Air bag label on contact coil assembly	8. Side/Curtain air bag label on pillar (both right and left sides) (if equipped)
3. Air bag label on passenger air bag (inflator) module	[A]: These labels are attached on vehicle equipped with air bag system only.
4. Air bag label on side air bag (inflator) module (if equipped)	[B]: Sedan model
5. Air bag label on curtain air bag (inflator) module	[C]: Hatchback model
6. Air bag label on SDM	

Maintenance and Lubrication

Precautions

Precautions for Maintenance and Lubrication

S7RW0C0200001

Air Bag Warning

Refer to “Air Bag Warning in Section 00”.

Scheduled Maintenance

Maintenance Schedule under Normal Driving Conditions

S7RW0C0205001

NOTE

- This interval should be judged by odometer reading or months, whichever comes first.
- This table includes service as scheduled up to 90,000 km (54,000 miles) mileage. Beyond 90,000 km (54,000 miles), carry out the same services at the same intervals respectively.

Interval				Km (x 1,000)	15	30	45	60	75	90
				Miles (x 1,000)	9	18	27	36	45	54
				Months	12	24	36	48	60	72
Engine										
Accessory drive belt (I: ⚙, R: ⚙)					—	—	I	—	—	R
Valve lash (clearance) (I: ⚙)					—	—	I	—	—	I
Engine oil and oil filter (R: ⚙)					R	R	R	R	R	R
Engine coolant (R: ⚙)					—	—	R	—	—	R
Exhaust system (I: ⚙)					—	I	—	I	—	I
Ignition system										
Spark plugs (R: ⚙)	When unleaded fuel is used	Vehicle with HO2S	Nickel spark plug	—	—	R	—	—	R	
		Vehicle without HO2S	Nickel spark plug	—	R	—	R	—	R	
	When leaded fuel is used, refer to “Maintenance Recommended under Severe Driving Conditions”.									
Fuel system										
Air cleaner filter (R: ⚙, I: ⚙)			Paved-road	I	I	R	I	I	R	
			Dusty conditions	Refer to “Maintenance Recommended under Severe Driving Conditions”.						
Fuel lines and connections (I: ⚙)					—	I	—	I	—	I
Fuel filter (R: ⚙)					Replace every 105,000 km (63,000 miles)					
Fuel tank (I: ⚙)					—	—	I	—	—	I
Emission control system										
PCV valve (I: ⚙)		Vehicle with HO2S			—	—	—	—	—	I
		Vehicle without HO2S			—	—	I	—	—	I
Fuel evaporative emission control system (I: ⚙)					—	—	—	—	—	I
Brake										
Brake discs and pads (thickness, wear, damage) (I: ⚙)					I	I	I	I	I	I
Brake drums and shoes (wear, damage) (I: ⚙)					—	I	—	I	—	I
Brake hoses and pipes (leakage, damage, clamp) (I: ⚙)					—	I	—	I	—	I
Brake fluid (R: ⚙)					—	R	—	R	—	R
Brake lever and cable (damage, stroke, operation) (I: ⚙)					Inspect at first 15,000 km (9,000 miles only)					
Chassis and body										
Clutch pedal (travel) Clutch fluid (leakage, level) (I: ⚙ / ⚙)					—	I	—	I	—	I
Tires (wear, damage, rotation) / wheels (damage) (I: ⚙ / ⚙)					I	I	I	I	I	I
Suspension system (tightness, damage, rattle, breakage) (I: ⚙)					—	I	—	I	—	I
Steering system (tightness, damage, breakage, rattle) (I: ⚙)					—	I	—	I	—	I

Interval	Km (x 1,000)	15	30	45	60	75	90
	Miles (x 1,000)	9	18	27	36	45	54
	Months	12	24	36	48	60	72
Drive shaft (axle) boots / Propeller shaft (4WD) (I: ⚙) (I: ⚙)		—	—	I	—	—	I
Manual transaxle oil (leakage, level) (I: ⚙ 1st 15,000 km only) (R: ⚙)		I	—	R	—	—	R
Automatic transaxle fluid	Fluid level (I: ⚙)	—	I	—	I	—	I
	Fluid change (R: ⚙)	Replace every 165,000 km (99,000 miles)					
	Fluid hose (I: ⚙)	—	—	—	I	—	—
Transfer oil (4WD) (leakage, level) (I: ⚙)		I	—	I	—	I	—
Rear differential oil (4WD) (leakage, level) (I: ⚙) (R: ⚙ 1st 15,000 km only)		R or I	—	I	—	I	—
All latches, hinges and locks (I: ⚙)		—	I	—	I	—	I
HVAC air filter (if equipped) (I: ⚙) (R: ⚙)		—	I	R	—	I	R

NOTE

- “R”: Replace or change
- “I”: Inspect and correct, replace or lubricate if necessary
- For spark plugs, replace every 50,000 km if the local law requires.
- Nickel spark plug: BKR6E-11 (NGK)

Maintenance Recommended under Severe Driving Conditions

S7RW0C0205002

If the vehicle is usually used under the conditions corresponding to any severe condition code given below, IT IS RECOMMENDED that applicable maintenance operation be performed at the particular interval as shown in the following table.

Severe condition code:

A: Repeated short trips

B: Driving on rough and/or muddy roads

C: Driving on dusty roads

D: Driving in extremely cold weather and/or salted roads

E: Repeated short trips in extremely cold weather

F: Leaded fuel use

G: — — — — —

H: Towing a trailer (if admitted)

Severe condition code	Maintenance		Maintenance operation	Maintenance interval
— B C D — — — —	Accessory drive belt		⚙ I	Every 15,000 km (9,000 miles) or 12 months
			⚙ R	Every 45,000 km (27,000 miles) or 36 months
A — C D E F — H	Engine oil and oil filter		⚙ R	Every 7,500 km (4,500 miles) or 6 months
— — C — — — — —	Air cleaner filter *1		⚙ I	Every 2,500 km (1,500 miles)
			⚙ R	Every 30,000 km (18,000 miles) or 24 months
A B C — E F — H	Spark plugs	Nickel plug	⚙ R	Every 10,000 km (6,000 miles) or 8 months
— B C D — — — H	Wheel bearings		⚙ I	Every 15,000 km (9,000 miles) or 12 months
— B — D E — — H	Drive shaft boots / Propeller shaft (4WD)		⚙ / ⚙ I	Every 15,000 km (9,000 miles) or 12 months

Severe condition code	Maintenance	Maintenance operation	Maintenance interval
- B - - E - - H	Manual transaxle oil Transfer oil (4WD) Differential oil (4WD)	 /  /  R	First time only: 15,000 km (9,000 miles) or 12 months
			Second time and after: Every 30,000 km (18,000 miles) or 24 months reckoning from 0 km (0 mile) or 0 month
- B - - E - - H	Automatic transaxle fluid	 R	Every 30,000 km (18,000 miles) or 24 months
- - C D - - - -	HVAC air filter (if equipped) *2	 I	Every 15,000 km (9,000 miles) or 12 months
		 R	Every 45,000 km (27,000 miles) or 36 months

NOTE

- “I”: Inspect and correct or replace if necessary
- “R”: Replace or change
- *1: Inspect or replace more frequently if the vehicle is used under dusty conditions.
- *2: Clean or replace more frequently if the air from the air conditioning decreases.

Repair Instructions

Accessory Drive Belt Inspection

S7RW0C0206001

▲ WARNING

All inspection and replacement are to be performed with ENGINE NOT RUNNING.

Water Pump and Generator Drive Belt

Inspect belt for cracks, cuts, deformation, wear, cleanliness and tension referring to “Water Pump and Generator Drive Belt On-Vehicle Inspection in Section 1J”.

Accessory Drive Belt Replacement

S7RW0C0206002

Water Pump and Generator Drive Belt

Replace belt with new one referring to “Water Pump and Generator Drive Belt Removal and Installation in Section 1J”.

Valve Lash (Clearance) Inspection

S7RW0C0206003

Inspect intake and exhaust valve lash and adjust as necessary referring to “Valve Lash (Clearance) Inspection in Section 1D”.

Engine Oil and Filter Change

S7RW0C0206004

Replace engine oil and filter referring to “Engine Oil and Filter Change in Section 1E”.

Engine Coolant Change

S7RW0C0206005

Change engine coolant with new one referring to “Cooling System Flush and Refill in Section 1F”.

Exhaust System Inspection

S7RW0C0206006

Check exhaust system referring to “Exhaust System Check in Section 1K”.

Spark Plug Replacement

S7RW0C0206007

Replace spark plugs with new ones referring to “Spark Plug Removal and Installation in Section 1H”.

Air Cleaner Filter Inspection

S7RW0C0206008

Check air cleaner filter referring to “Air Cleaner Filter Inspection and Cleaning in Section 1D”.

Air Cleaner Filter Replacement

S7RW0C0206009

Replace air cleaner filter referring to “Air Cleaner Filter Removal and Installation in Section 1D”.

Fuel Lines and Connections Inspection

S7RW0C0206010

Check fuel line and connection referring to “Fuel Tank, Cap Gasket and Fuel Line Inspection in Section 1G”.

Fuel Filter Replacement

S7RW0C0206011

Replace fuel filter referring to “Fuel Filter Replacement in Section 1G”.

Fuel Tank Inspection

S7RW0C0206012

Check fuel tank referring to “Fuel Tank, Cap Gasket and Fuel Line Inspection in Section 1G”.

PCV Valve Inspection

S7RW0C0206013

Check PCV valve and hose referring to “PCV Valve Inspection in Section 1B” and “PCV Hose Inspection in Section 1B”.

Fuel Evaporative Emission Control System Inspection

S7RW0C0206014

Check EVAP canister and fuel vapor hose referring to “EVAP Canister Inspection in Section 1B” and “Vacuum Hose and Purge Valve Chamber Inspection in Section 1B”.

Brake Discs and Pads Inspection

S7RW0C0206015

Check disc brake pads and discs referring to “Front Disc Brake Pad Inspection in Section 4B”, “Front Brake Disc Inspection in Section 4B”, “Rear Disc Brake Pad Inspection: Disc in Section 4C” and “Rear Brake Disc Inspection: Disc in Section 4C”.

Brake Drums and Shoes (Rear) Inspection

S7RW0C0206040

Check rear brake drums and brake linings referring to “Rear Brake Drum and Shoe Inspection: Drum in Section 4C”.

Brake Hoses and Pipes Inspection

S7RW0C0206016

Check brake hoses and pipes referring to “Brake Hose and Pipe Inspection in Section 4A”.

Brake Fluid Replacement

S7RW0C0206017

Change brake fluid referring to “Brake Fluid Replacement in Section 4A”.

Brake Lever and Cable Inspection

S7RW0C0206018

Check brake lever and cable referring to “Parking Brake Cable Components in Section 4D”.

Clutch Pedal Inspection

S7RW0C0206041

Check clutch pedal travel.
For checking procedure, refer to “Clutch Pedal Inspection in Section 5C”.

Clutch Fluid Inspection

S7RW0C0206019

Check clutch system for crack, damage and clutch fluid leakage and fluid level referring to “Clutch Fluid Level Inspection in Section 5C”.

Tires Inspection

S7RW0C0206020

Check tires for uneven or excessive wear, damage and inflating pressure, and rotate tires referring to “Tires Inspection in Section 2D”.

Wheel Discs Inspection

S7RW0C0206021

Check wheel discs referring to “Wheel Discs Inspection in Section 2D”.

Wheel Bearing Inspection

S7RW0C0206022

Check front and rear wheel bearings referring to “Wheel Bearing Inspection in Section 2A”.

Suspension System Inspection

S7RW0C0206023

Check suspension system referring to “Suspension System Inspection in Section 2A”.

Steering System Inspection

S7RW0C0206024

Check steering system referring to “Steering System Inspection in Section 6A”.

Drive Shaft (Axle) Boots Inspection

S7RW0C0206025

Check front and rear (if equipped) drive shaft boots referring to “Front Drive Shaft Assembly On-Vehicle Inspection: Front in Section 3A”.

Propeller Shaft (4WD) Inspection

S7RW0C0206026

Check propeller shaft referring to “Propeller Shaft Inspection in Section 3D”.

Manual Transaxle Oil Inspection

S7RW0C0206027

Check transaxle oil for leakage, contamination and level referring to “Manual Transaxle Oil Level Check in Section 5B”.

Manual Transaxle Oil Replacement

S7RW0C0206028

Change transaxle oil with new specified oil referring to “Manual Transaxle Oil Change in Section 5B”.

Automatic Transaxle Fluid Level Inspection

S7RW0C0206029

Check fluid for leakage, contamination and level referring to “A/T Fluid Level Check in Section 5A”.

Automatic Transaxle Fluid Replacement

S7RW0C0206030

Change fluid referring to “A/T Fluid Change in Section 5A”.

Automatic Transaxle Fluid Cooler Hose Inspection

S7RW0C0206031

Check automatic transaxle fluid cooler hose referring to “A/T Fluid Cooler Hoses Inspection in Section 5A”.

Transfer Oil Inspection (4WD)

S7RW0C0206032

Check transfer oil for leakage, contamination and level referring to "Transfer Oil Level Check in Section 3C".

Transfer Oil Replacement (4WD)

S7RW0C0206033

Change transfer oil with new specified oil referring to "Transfer Oil Change in Section 3C".

Rear Differential Oil Inspection (4WD)

S7RW0C0206034

Check differential oil for leakage, contamination and level referring to "Rear Differential Oil Level Check in Section 3B".

Rear Differential Oil Replacement (4WD)

S7RW0C0206035

Change differential oil with new specified oil referring to "Rear Differential Oil Change in Section 3B".

All Latches, Hinges and Locks Inspection

S7RW0C0206036

Check all latches, hinges and locks referring to "All Latches, Hinges and Locks Inspection in Section 9J".

HVAC Air Filter (If Equipped) Inspection

S7RW0C0206037

Check HVAC air filter for dirt and dust referring to "HVAC Air Filter Inspection (If Equipped) in Section 7A".

HVAC Air Filter (If Equipped) Replacement

S7RW0C0206038

Replace HVAC air filter with new one referring to "HVAC Air Filter Removal and Installation (If Equipped) in Section 7A".

Final Inspection for Maintenance Service

S7RW0C0206039

⚠ WARNING

When carrying out road tests, select a safe place where no man or no running vehicle is seen so as to prevent any accident.

Seats

Check that seat slides smoothly and locks securely at any position. Also check that reclining mechanism of front seat back allows it to be locked at any angle.

Seat Belt

Inspect belt system including webbing, buckles, latch plates, retractors and anchors for damage or wear. Check that seat belt is securely locked. If "REPLACE BELT" label on seat belt is visible, replace belt.

Battery Electrolyte Level Check

Check that the electrolyte level of all battery cells is between the upper and lower level lines on the case. If battery is equipped with built-in indicator, check battery condition by the indicator.

Accelerator Pedal Operation

Check that pedal operates smoothly without getting caught or interfered by any other part.

Engine Start

Check engine start for readiness.

⚠ WARNING

Before performing the following check, be sure to have enough room around the vehicle. Then, firmly apply both the parking brake and the regular brakes. Do not use the accelerator pedal. If the engine starts, be ready to turn off the ignition promptly. Take these precautions because the vehicle could move without warning and possibly cause personal injury or property damage.

On automatic transaxle vehicles, try to start the engine in each select lever position. The starting motor should crank only in "P" (Park) or "N" (Neutral).

On manual transaxle vehicles, place the shift lever in "Neutral," depress clutch pedal fully and try to start.

Exhaust System Check

Check for leakage, cracks or loose supports.

Clutch (for Manual Transaxle)

Check for the following.

- Clutch is completely released when depressing clutch pedal,
- No slipping clutch occurs when releasing pedal and accelerating.
- Clutch itself is free from any abnormal condition.

Gearshift or Select Lever

Check gear shift or select lever for smooth shifting to all positions and for good performance of transaxle in any position.

With automatic transaxle equipped vehicle, also check that shift indicator indicates properly according to which position select lever is shifted to.

With automatic transaxle equipped vehicle, make sure that vehicle is at complete stop when shifting select lever to "P" range position and release all brakes.

Brake

Foot brake

Check the following:

- that brake pedal has proper travel,
- that brake works properly,
- that it is free from noise,
- that vehicle does not pull to one side when brake is applied.
- and that brake do not drag.

Parking brake

Check that lever has proper travel.

▲ WARNING

With vehicle parked on a fairly steep slope, make sure nothing is in the way downhill to avoid any personal injury or property damage. Be prepared to apply regular brake quickly even if vehicle should start to move.

Check to ensure that parking brake is fully effective when the vehicle is stopped on the safe slope and brake lever is pulled all the way.

Steering

- Check to ensure that steering wheel is free from instability, or abnormally heavy feeling.
- Check that the vehicle does not wander or pull to one side.

Engine

- Check that engine responds readily at all speeds.
- Check that engine is free from abnormal noise and abnormal vibration.

Body, Wheels and Power Transmitting System

Check that body, wheels and power transmitting system are free from abnormal noise and abnormal vibration or any other abnormal condition.

Meters and Gauge

Check that speedometer, odometer, fuel meter, temperature gauge, etc. are operating accurately.

Lights

Check that all lights operate properly.

Windshield Defroster

Periodically check that air comes out from defroster outlet when operating heater or air conditioning. Set mode control lever to defroster position and fan switch lever to highest position for this check.

Special Tools and Equipment

Recommended Fluids and Lubricants

S7RW0C0208001

Engine oil	SG, SH, SJ, SL or SM grade (Refer to "Engine Oil and Filter Change in Section 1E" for engine oil viscosity.)
Engine coolant (Ethylene glycol base coolant)	"Antifreeze/Anticorrosion coolant"
Brake fluid	Refer to reservoir cap of brake master cylinder.
Manual transaxle oil	Refer to "Manual Transaxle Oil Change in Section 5B".
Automatic transaxle fluid	Refer to "A/T Fluid Change in Section 5A".
Transfer oil (4WD)	Refer to "Transfer Oil Change in Section 3C".
Rear differential (4WD)	Refer to "Rear Differential Oil Change in Section 3B".
Door hinges	Engine oil or water resistance chassis grease
Hood latch assembly	Engine oil or water resistance chassis grease
Key lock cylinder	Spray lubricant

Section 1

Engine

CONTENTS

Precautions	1-1	DTC Check	1A-29
Precautions.....	1-1	DTC Clearance	1A-29
Precautions for Engine.....	1-1	Troubleshooting for Communication Error with Scan Tool Using CAN.....	1A-29
Engine General Information and Diagnosis	1A-1	DTC Table	1A-34
Precautions.....	1A-1	Fail-Safe Table	1A-40
Precautions on Engine Service	1A-1	Scan Tool Data	1A-42
Precaution on On-Board Diagnostic (OBD) System	1A-1	Visual Inspection	1A-47
Precautions in Diagnosing Trouble	1A-1	Engine Basic Inspection.....	1A-47
Precautions for DTC Troubleshooting.....	1A-2	Engine Symptom Diagnosis	1A-49
Precautions of ECM Circuit Inspection.....	1A-2	MIL Does Not Come ON with Ignition Switch ON and Engine Stop (but Engine Can Be Started)	1A-55
Precautions of Electric Throttle Body System Calibration	1A-2	MIL Remains ON after Engine Starts.....	1A-57
Precaution on CAN Troubleshooting	1A-3	DTC P0030: HO2S Heater Control Circuit (Sensor-1, Bank-1).....	1A-58
General Description	1A-4	DTC P0031 / P0032: HO2S Heater Control Circuit Low / High (Sensor-1, Bank-1).....	1A-59
Statement on Cleanliness and Care	1A-4	DTC P0037 / P0038: HO2S Heater Control Circuit Low / High (Sensor-2, Bank-1).....	1A-61
Engine Diagnosis General Description	1A-5	DTC P0101: Mass or Volume Air Flow Circuit Range / Performance	1A-62
On-Board Diagnostic System Description.....	1A-5	DTC P0102 / P0103: Mass or Volume Air Flow Circuit Low / High Input	1A-64
DLC (Data Link Connector) Description.....	1A-8	DTC P0111: Intake Air Temperature Sensor 1 Circuit Range / Performance.....	1A-66
Engine and Emission Control System Description	1A-8	DTC P0112 / P0113: Intake Air Temperature Sensor Circuit Low / High Input.....	1A-66
CAN Communication System Description.....	1A-8	DTC P0116: Engine Coolant Temperature Circuit Range / Performance.....	1A-68
Air Intake System Description	1A-10	DTC P0117 / P0118: Engine Coolant Temperature Circuit Low / High	1A-70
Electric Throttle Body System Description	1A-11	DTC P0122 / P0123: Throttle / Pedal Position Sensor / Switch "A" Circuit Low / High	1A-71
Description of Electric Throttle Body System Calibration	1A-12	DTC P0131 / P0132: O2 Sensor Circuit Low Voltage / High Voltage (Sensor-1, Bank-1).....	1A-74
A/F Sensor Description	1A-12	DTC P0133: O2 Sensor Circuit Slow Response / Performance (Sensor-1, Bank- 1).....	1A-75
Electronic Control System Description.....	1A-13	DTC P0134: O2 Sensor Circuit No Activity Detected (Sensor-1, Bank-1)	1A-77
Engine and Emission Control Input / Output Table	1A-13	DTC P0137 / P0138: O2 Sensor (HO2S) Circuit Low Voltage / High Voltage (Sensor- 2, Bank-1).....	1A-78
Schematic and Routing Diagram.....	1A-17		
Engine and Emission Control System Diagram	1A-17		
Engine and Emission Control System Flow Diagram	1A-19		
ECM Input / Output Circuit Diagram.....	1A-20		
Component Location	1A-24		
Electronic Control System Components Location	1A-24		
Diagnostic Information and Procedures.....	1A-25		
Engine and Emission Control System Check....	1A-25		
Malfunction Indicator Lamp (MIL) Check	1A-28		

DTC P0140: O2 Sensor (HO2S) Circuit No Activity Detected (Sensor-2, Bank-1)	1A-80	DTC U0073: Control Module Communication Bus Off	1A-125
DTC P0171 / P0172: System Too Lean / Too Rich (Sensor-1, Bank-1)	1A-81	DTC U0101: Lost Communication with TCM ..	1A-125
DTC P0222 / P0223: Throttle Position Sensor (Sub) Circuit Low / High	1A-83	DTC U0121: Lost Communication with ABS / ESP® Control Module	1A-125
DTC P0300 / P0301 / P0302 / P0303 / P0304: Random Misfire Detected / Cylinder 1 / Cylinder 2 / Cylinder 3 / Cylinder 4 Misfire Detected	1A-85	DTC U0140: Lost Communication with Body Control Module	1A-125
DTC P0327 / P0328: Knock Sensor Circuit Low / High	1A-87	Troubleshooting for CAN-DTC	1A-125
DTC P0335: Crankshaft Position Sensor "A" Circuit	1A-88	Inspection of ECM and Its Circuits	1A-130
DTC P0340: Camshaft Position Sensor "A" Circuit	1A-90	ECM Power and Ground Circuit Check	1A-148
DTC P0420: Catalyst System Efficiency Below Threshold (Bank-1)	1A-92	Fuel Injector Circuit Check	1A-151
DTC P0443: EVAP Emission System Purge Control Valve Circuit	1A-94	Fuel Pump and Its Circuit Check	1A-153
DTC P0462 / P0463: Fuel Level Sensor Circuit Low / High	1A-96	Fuel Pressure Check	1A-156
DTC P0480: Fan 1 Control Circuit	1A-98	A/C Condenser Cooling Fan Control System Inspection	1A-158
DTC P0481: Fan 2 Control Circuit	1A-101	A/C System Circuits Check	1A-160
DTC P0500: Vehicle Speed Sensor "A"	1A-103	Electric Load Signal Circuit Check	1A-163
DTC P0504: Brake Switch "A"/"B" Correlation ..	1A-104	Radiator Cooling Fan Low Speed Control System Check	1A-165
DTC P0532 / P0533: A/C Refrigerant Pressure Sensor Circuit Low / High	1A-106	Radiator Cooling Fan High Speed Control System Check	1A-167
DTC P0601 / P0602 / P0607: Internal Control Module Memory Check Sum Error / Control Module Programming Error / Control Module Performance	1A-107	Repair Instructions	1A-168
DTC P0616 / P0617: Starter Relay Circuit Low / High	1A-108	Idle Speed and IAC Throttle Valve Opening Inspection	1A-168
DTC P0660 / P0662: Intake Manifold Tuning Valve Control Circuit Open / High	1A-110	Special Tools and Equipment	1A-169
DTC P1510: ECM Back-Up Power Supply Malfunction	1A-111	Special Tool	1A-169
DTC P2101: Throttle Actuator Control Motor Circuit Range / Performance	1A-112	Aux. Emission Control Devices	1B-1
DTC P2102: Throttle Actuator Control Motor Circuit Low	1A-113	Diagnostic Information and Procedures	1B-1
DTC P2103: Throttle Actuator Control Motor Circuit High	1A-115	EVAP Canister Purge System Inspection	1B-1
DTC P2111: Throttle Actuator Control System - Stuck Open	1A-115	Repair Instructions	1B-2
DTC P2119: Throttle Actuator Control Throttle Body Range / Performance	1A-116	EVAP System Components	1B-2
DTC P2122 / P2123: Throttle / Pedal Position Sensor / Switch "D" Circuit Low / High	1A-117	EVAP Canister Purge Inspection	1B-2
DTC P2127 / P2128: Throttle / Pedal Position Sensor / Switch "E" Circuit Low / High Input ..	1A-119	EVAP Canister Purge Valve and Its Circuit Inspection	1B-3
DTC P2135: Throttle / Pedal Position Sensor / Switch "A" / "B" Voltage Correction	1A-121	Vacuum Passage Inspection	1B-4
DTC P2138: Pedal Position Sensor (Main / Sub) Voltage Correction	1A-122	Vacuum Hose and Purge Valve Chamber Inspection	1B-4
DTC P2195 / P2196: O2 Sensor Signal Stuck Lean / Stuck Rich (Sensor-1, Bank-1)	1A-123	EVAP Canister Purge Valve Inspection	1B-4
DTC P2227 / P2228 / P2229: Barometric Pressure Circuit Performance / Low / High ...	1A-124	EVAP Canister Removal and Installation	1B-5
		EVAP Canister Inspection	1B-5
		PCV Hose Inspection	1B-5
		PCV Valve Removal and Installation	1B-5
		PCV Valve Inspection	1B-6
		Specifications	1B-6
		Tightening Torque Specifications	1B-6
		Special Tools and Equipment	1B-6
		Recommended Service Material	1B-6
		Special Tool	1B-6
		Engine Electrical Devices	1C-1
		Repair Instructions	1C-1
		Engine Control Module (ECM) Removal and Installation	1C-1
		Electric Throttle Body Assembly On-Vehicle Inspection	1C-2
		Electric Throttle Body System Calibration	1C-4
		Accelerator Pedal Position (APP) Sensor Assembly On-Vehicle Inspection	1C-4

Accelerator Pedal Position (APP) Sensor Assembly Removal and Installation	1C-5	Cylinder Head Cover Removal and Installation	1D-12
Accelerator Pedal Position (APP) Sensor Assembly Inspection	1C-5	Engine Mountings Components	1D-14
Engine Coolant Temperature (ECT) Sensor Removal and Installation	1C-6	Engine Assembly Removal and Installation	1D-15
Engine Coolant Temperature (ECT) Sensor Inspection	1C-6	Timing Chain Cover Components	1D-19
Air Fuel Ratio (A/F) Sensor On-Vehicle Inspection	1C-7	Timing Chain Cover Removal and Installation	1D-19
Heated Oxygen Sensor (HO2S) Heater On-Vehicle Inspection	1C-7	Timing Chain Cover Cleaning and Inspection	1D-22
Air Fuel Ratio (A/F) Sensor, Heated Oxygen Sensor (HO2S) Removal and Installation	1C-7	2nd Timing Chain and Chain Tensioner Components	1D-22
Camshaft Position (CMP) Sensor Removal and Installation	1C-8	2nd Timing Chain and Chain Tensioner Removal and Installation	1D-23
Camshaft Position (CMP) Sensor Inspection	1C-8	2nd Timing Chain and Chain Tensioner Inspection	1D-26
Crankshaft Position (CKP) Sensor Removal and Installation	1C-8	1st Timing Chain and Chain Tensioner Components	1D-27
Crankshaft Position (CKP) Sensor Inspection	1C-9	1st Timing Chain and Chain Tensioner Removal and Installation	1D-27
Knock Sensor Removal and Installation	1C-9	1st Timing Chain and Chain Tensioner Inspection	1D-29
Engine and Emission Control System Relay Inspection	1C-10	Camshafts, Tappet and Shim Components	1D-30
Mass Air Flow (MAF) and Intake Air Temperature (IAT) Sensor On-Vehicle Inspection	1C-10	Camshafts, Tappet and Shim Removal and Installation	1D-31
Mass Air Flow (MAF) and Intake Air Temperature (IAT) Sensor Removal and Installation	1C-11	Camshaft, Tappet and Shim Inspection	1D-32
Mass Air Flow (MAF) and Intake Air Temperature (IAT) Sensor Inspection	1C-11	Valves and Cylinder Head Components	1D-35
IMT Valve Actuator Inspection	1C-12	Valves and Cylinder Head Removal and Installation	1D-35
Specifications	1C-12	Valves and Cylinder Head Disassembly and Reassembly	1D-37
Tightening Torque Specifications	1C-12	Valves and Valve Guides Inspection	1D-40
Engine Mechanical	1D-1	Cylinder Head Inspection	1D-42
General Description	1D-1	Valve Spring Inspection	1D-43
Engine Construction	1D-1	Pistons, Piston Rings, Connecting Rods and Cylinders Components	1D-44
IMT (Intake Manifold Tuning) System Description	1D-2	Pistons, Piston Rings, Connecting Rods and Cylinders Removal and Installation	1D-45
Diagnostic Information and Procedures	1D-3	Pistons, Piston Rings, Connecting Rods and Cylinders Disassembly and Reassembly	1D-46
Compression Check	1D-3	Pistons, Piston Rings, Connecting Rods and Cylinders Inspection and Cleaning	1D-48
Engine Vacuum Check	1D-4	Main Bearings, Crankshaft and Cylinder Block Components	1D-55
Valve Lash (Clearance) Inspection	1D-4	Main Bearings, Crankshaft and Cylinder Block Removal and Installation	1D-56
Repair Instructions	1D-7	Main Bearings, Crankshaft and Cylinder Block Inspection	1D-59
Air Cleaner Components	1D-7	Specifications	1D-65
Air Cleaner Assembly Removal and Installation	1D-8	Tightening Torque Specifications	1D-65
Air Cleaner Filter Removal and Installation	1D-8	Special Tools and Equipment	1D-67
Air Cleaner Filter Inspection and Cleaning	1D-8	Recommended Service Material	1D-67
Electric Throttle Body and Intake Manifold Components	1D-9	Special Tool	1D-67
Electric Throttle Body On-Vehicle Inspection	1D-10	Engine Lubrication System	1E-1
Electric Throttle Body Assembly Removal and Installation	1D-10	General Description	1E-1
Electric Throttle Body Cleaning	1D-10	Engine Lubrication Description	1E-1
Intake Manifold Removal and Installation	1D-11	Diagnostic Information and Procedures	1E-2
IMT Valve Actuator Removal and Installation	1D-12	Oil Pressure Check	1E-2
Cylinder Head Cover Components	1D-12	Repair Instructions	1E-3
		Engine Oil and Filter Change	1E-3
		Oil Pan and Oil Pump Strainer Components	1E-5

Oil Pan and Oil Pump Strainer Removal and Installation	1E-6	Fuel Hose Disconnecting and Reconnecting	1G-5
Oil Pan and Oil Pump Strainer Cleaning	1E-7	Fuel Pressure Relief Procedure	1G-7
Oil Pump Components	1E-8	Fuel Leakage Check Procedure	1G-7
Oil Pump Removal and Installation	1E-9	Fuel Tank, Cap Gasket and Fuel Line Inspection	1G-7
Oil Pump Disassembly and Reassembly	1E-10	Fuel Pipe Removal and Installation	1G-8
Oil Pump Inspection	1E-10	Fuel Injector On-Vehicle Inspection	1G-8
Specifications	1E-11	Fuel Injector Removal and Installation	1G-9
Tightening Torque Specifications	1E-11	Fuel Injector Inspection	1G-10
Special Tools and Equipment	1E-12	Fuel Filler Cap Inspection	1G-11
Recommended Service Material	1E-12	Fuel Tank Inlet Valve Removal and Installation	1G-12
Special Tool	1E-12	Fuel Tank Inlet Valve Inspection	1G-12
Engine Cooling System	1F-1	Fuel Tank Removal and Installation	1G-12
General Description	1F-1	Fuel Tank Inspection	1G-15
Cooling System Description	1F-1	Fuel Tank Purging Procedure	1G-15
Coolant Description	1F-1	Fuel Pump On-Vehicle Inspection	1G-15
Schematic and Routing Diagram	1F-2	Fuel Filter Replacement	1G-16
Coolant Circulation	1F-2	Fuel Pump Assembly Removal and Installation	1G-16
Diagnostic Information and Procedures	1F-3	Main Fuel Level Sensor Removal and Installation	1G-17
Engine Cooling Symptom Diagnosis	1F-3	Fuel Pump Inspection	1G-17
Repair Instructions	1F-4	Specifications	1G-18
Cooling System Components	1F-4	Tightening Torque Specifications	1G-18
Coolant Level Check	1F-5	Special Tools and Equipment	1G-18
Engine Cooling System Inspection and Cleaning	1F-5	Special Tool	1G-18
Cooling System Draining	1F-5	Ignition System	1H-1
Cooling System Flush and Refill	1F-6	General Description	1H-1
Cooling Water Pipes or Hoses Removal and Installation	1F-6	Ignition System Construction	1H-1
Thermostat Removal and Installation	1F-7	Schematic and Routing Diagram	1H-2
Thermostat Inspection	1F-7	Ignition System Wiring Circuit Diagram	1H-2
Radiator Cooling Fan Assembly Inspection	1F-8	Component Location	1H-3
Radiator Cooling Fan Relay Inspection	1F-8	Ignition System Components Location	1H-3
Radiator Cooling Fan Assembly Removal and Installation	1F-8	Diagnostic Information and Procedures	1H-3
Radiator Cooling Fan Disassembly and Reassembly	1F-9	Ignition System Check	1H-3
Radiator On-Vehicle Inspection and Cleaning	1F-9	Ignition System Symptom Diagnosis	1H-5
Radiator Removal and Installation	1F-9	Reference Waveform of Ignition System	1H-5
Water Pump Removal and Installation	1F-10	Ignition Spark Test	1H-5
Water Pump Inspection	1F-10	Repair Instructions	1H-6
Specifications	1F-10	Spark Plug Removal and Installation	1H-6
Tightening Torque Specifications	1F-10	Spark Plug Inspection	1H-6
Fuel System	1G-1	Ignition Coil Assembly (Including ignitor) Removal and Installation	1H-6
Precautions	1G-1	Ignition Coil Assembly (Including ignitor) Inspection	1H-6
Precautions on Fuel System Service	1G-1	Ignition Timing Inspection	1H-7
General Description	1G-1	Specifications	1H-8
Fuel System Description	1G-1	Tightening Torque Specifications	1H-8
Fuel Delivery System Description	1G-1	Special Tools and Equipment	1H-8
Fuel Pump Description	1G-2	Special Tool	1H-8
Schematic and Routing Diagram	1G-2	Starting System	1I-1
Fuel Delivery System Diagram	1G-2	Schematic and Routing Diagram	1I-1
Diagnostic Information and Procedures	1G-2	Cranking System Circuit Diagram	1I-1
Fuel Pressure Inspection	1G-2	Diagnostic Information and Procedures	1I-1
Fuel Cut Operation Inspection	1G-3	Cranking System Symptom Diagnosis	1I-1
Repair Instructions	1G-4	Cranking System Test	1I-3
Fuel System Components	1G-4		

Repair Instructions	1I-4	Water Pump and Generator Drive Belt On-	
Starting Motor Unit Components.....	1I-4	Vehicle Inspection	1J-8
Starting Motor Dismounting and Remounting	1I-4	Water Pump and Generator Drive Belt	
Starting Motor Components	1I-5	Removal and Installation.....	1J-8
Starting Motor Inspection	1I-6	Generator Unit Components	1J-9
Specifications.....	1I-9	Generator Dismounting and Remounting.....	1J-10
Cranking System Specifications.....	1I-9	Generator Components.....	1J-11
Tightening Torque Specifications.....	1I-9	Generator Inspection.....	1J-12
Special Tools and Equipment	1I-9	Specifications.....	1J-15
Recommended Service Material	1I-9	Charging System Specifications	1J-15
Charging System	1J-1	Tightening Torque Specifications.....	1J-15
General Description	1J-1	Exhaust System	1K-1
Battery Description.....	1J-1	General Description	1K-1
Generator Description.....	1J-2	Exhaust System Description	1K-1
Diagnostic Information and Procedures	1J-4	Diagnostic Information and Procedures	1K-1
Battery Inspection	1J-4	Exhaust System Check	1K-1
Generator Symptom Diagnosis	1J-4	Repair Instructions	1K-2
Generator Test (Undercharged Battery		Exhaust System Components.....	1K-2
Check).....	1J-5	Exhaust Manifold Removal and Installation	1K-3
Generator Test (Overcharged Battery Check)	1J-6	Exhaust Pipe and Muffler Removal and	
Repair Instructions	1J-6	Installation	1K-4
Jump Starting in Case of Emergency.....	1J-6	Specifications.....	1K-5
Battery Dismounting and Remounting	1J-7	Tightening Torque Specifications.....	1K-5

Precautions

Precautions

Precautions for Engine

S7RW0C1000001

Air Bag Warning

Refer to “Air Bag Warning in Section 00”.

Precautions on Engine Service

Refer to “Precautions on Engine Service in Section 1A”.

Precautions in Diagnosing Trouble

Refer to “Precautions in Diagnosing Trouble in Section 1A”.

Precautions for DTC Troubleshooting

Refer to “Precautions for DTC Troubleshooting in Section 1A”.

Precautions of ECM Circuit Inspection

Refer to “Precautions of ECM Circuit Inspection in Section 1A”.

Precautions on Fuel System Service

Refer to “Precautions on Fuel System Service in Section 1G”.

Precaution for CAN Communication System

Refer to “Precaution for CAN Communication System in Section 00”.

Precautions for Catalytic Converter

Refer to “Precautions for Catalytic Converter in Section 00”.

Precautions for Electrical Circuit Service

Refer to “Precautions for Electrical Circuit Service in Section 00”.

Precautions of Electric Throttle Body System Calibration

Refer to “Precautions of Electric Throttle Body System Calibration in Section 1A”.

Precaution on CAN Troubleshooting

Refer to “Precaution on CAN Troubleshooting in Section 1A”.

Engine General Information and Diagnosis


Precautions

Precautions on Engine Service

S7RW0C1100001

The following information on engine service should be noted carefully, as it is important in preventing damage, and in contributing to reliable engine performance.

- When raising or supporting engine for any reason, do not use a jack under oil pan. Due to small clearance between oil pan and oil pump strainer, jacking against oil pan may cause it to be bent against strainer resulting in damaged oil pick-up unit.
- It should be kept in mind, while working on engine, that 12-volt electrical system is capable of violent and damaging short circuits. When performing any work where electrical terminals could possibly be grounded, ground cable of the battery should be disconnected at battery.
- Any time the air cleaner, throttle body or intake manifold is removed, the intake opening should be covered. This will protect against accidental entrance of foreign material which could follow intake passage into cylinder and cause extensive damage when engine is started.
- When disconnecting couplers, don't pull wire harness but make sure to hold coupler itself. With lock type coupler, be sure to unlock before disconnection. Attempt to disconnect coupler without unlocking may result in damage to coupler. When connecting lock type coupler, insert it till clicking sound is heard and connect it securely.



IYSQ01110001-01

- According to the specification / market of the vehicle, immobilizer system parts may not be equipped. Be sure to keep it in mind during servicing the vehicle.

Precaution on On-Board Diagnostic (OBD) System

S7RW0C1100002

There are two types of On-Board Diagnostic (OBD) system, Euro OBD system and non-Euro-OBD system, depending on the vehicle specification. It is possible to identify each OBD system by checking if it is Gulf Cooperation Council (GCC) spec. or not.

- Euro OBD model is Non-GCC spec.
- Non-Euro OBD model is GCC spec.

As the diagnosis function is different between these two types, be sure to fully understand the OBD system referring to "On-Board Diagnostic System Description".

OBD System Summary Table

	Euro OBD model (Non-GCC spec.)	Non-Euro-OBD model (GCC spec.)
Quantity of DTC related to engine control	Approx. 100	Approx. 50 to 80
Freeze frame data	Available	Not available
SUZUKI scan tool (SUZUKI- SDT)	Available	Available
CAN communication OBD generic scan tool	Available	Not available

Precautions in Diagnosing Trouble

S7RW0C1100003

NOTE

There are two types of OBD system depending on the vehicle specification. For identification, refer to "Precaution on On-Board Diagnostic (OBD) System".

- Don't disconnect ECM couplers from ECM, battery cable from battery, ECM ground wire harness from engine or main fuse before confirming diagnostic information (DTC, freeze frame data, etc.) stored in ECM memory. Such disconnection will erase memorized information in ECM memory.
- Diagnostic information stored in ECM memory can be cleared as well as checked by using SUZUKI scan tool or CAN communication OBD generic scan tool. Before using scan tool, read its Operator's (Instruction) Manual carefully to have good understanding as to what functions are available and how to use it.
- For Euro OBD model, it is indistinguishable which module turns on MIL because not only ECM but also TCM turns on MIL (For details of on-board diagnostic system for A/T model, refer to "On-Board Diagnostic System Description in Section 5A").

1A-2 Engine General Information and Diagnosis:

- Therefore, check both ECM and TCM for DTC when MIL lights on.
- When checking ECM for DTC, keep in mind that DTC is displayed on the scan tool as follows depending on the scan tool used.
 - SUZUKI scan tool displays DTC detected by ECM.
 - CAN communication OBD generic scan tool displays DTC detected by each of ECM and TCM simultaneously.
- Priorities for diagnosing troubles
If two or more diagnostic trouble codes (DTCs) are stored, proceed to the flow of the DTC which has detected earliest in the order and follow the instruction in that table.
If no instructions are given, DTCs according to the following priorities.
 - a. Diagnostic trouble codes (DTCs) other than DTC P0171 / P0172 (Fuel system too lean/too rich) and DTC P0300 / P0301 / P0302 / P0303 / P0304 (Misfire detected)
 - b. DTC P0171 / P0172 (Fuel system too lean/too rich)
 - c. DTC P0300 / P0301 / P0302 / P0303 / P0304 (Misfire detected)
- Be sure to read "Precaution for CAN Communication System in Section 00" before inspection and observe what is written there.
- ECM Replacement
When substituting a known-good ECM, check for the following conditions. Neglecting this check may cause damage to known good ECM.
 - Resistance value of all relays, actuators is as specified respectively.
 - APP sensor, TP sensor and A/C refrigerant pressure sensor are in good condition and none of power circuits of these sensors is shorted to ground.
- Communication of ECM, BCM, combination meter, keyless start control module, ABS / control module, 4WD control module and TCM, is established by CAN (Controller Area Network). (For more detail of CAN communication for ECM, refer to "CAN Communication System Description"). Therefore, handle CAN communication line with care referring to "Precaution for CAN Communication System in Section 00".
- Immobilizer transponder code registration after replacing ECM (Immobilizer model)
When ECM is replaced with new one or with another one, make sure to register immobilizer transponder code to ECM correctly according to "Procedure after ECM Replacement in Section 10C".

Precautions for DTC Troubleshooting

S7RW0C1100004

- Before performed trouble shooting, be sure to read the "Precautions of ECM Circuit Inspection".
- When measuring circuit voltage, resistance and/or pulse signal at ECM connector, connect the special tool to ECM and/or the ECM connectors referring to "Inspection of ECM and Its Circuits".
- Upon completion of inspection and repair work, perform "DTC Confirmation Procedure" and confirm that the trouble has been corrected.

Precautions of ECM Circuit Inspection

S7RW0C1100005

- ECM connectors are waterproofed. Each terminal of the ECM connectors is sealed up with the grommet. Therefore, when measuring circuit voltage, resistance and/or pulse signal at ECM connector, do not insert the tester's probe into the sealed terminal at the harness side. When measuring circuit voltage, resistance and/or pulse signal at ECM connector, connect the special tool to the ECM connectors. And, insert the tester's probe into the special tool's connectors at the harness side, and then measure voltage, resistance and/or pulse signal. Or, ECM and its circuits may be damaged by water.
- Wire colors of the special tool's connectors are different from the ones of the ECM connectors. However, the circuit arrangement of the special tool's connectors is same as the one of the ECM connectors. Therefore, measure circuit voltage and resistance by identifying the terminal location subject to the measurement.

Precautions of Electric Throttle Body System Calibration

S7RW0C1100006


After performing one of works described below, it is necessary to re-register the completely closed throttle valve reference position stored in memory of ECM. (For detailed information, refer to "Description of Electric Throttle Body System Calibration".) For the procedure to register such data in ECM, refer to "Electric Throttle Body System Calibration in Section 1C".

- To shut off backup power of ECM for such purposes of battery replacement or "DOME" fuse removal.
- To erase DTCs P0607, P0122, P0123, P0222, P0223, P2101, P2102, P2103, P2111, P2119, P2122, P2123, P2127, P2128, P2135 and/or P2138.
- To replace ECM.
- To replace throttle body and/or APP sensor assembly.

Precaution on CAN Troubleshooting

S7RW0C1100007

CAN schematic and routing diagram



I6RW0C110002-03

No.	Part Name	Communication with scan tool	Monitor of CAN-DTC
1.	ABS control module	K-line	Not available
2.	ECM	CAN	Available
3.	TCM	CAN	Available
4.	BCM	K-line	Available
5.	Keyless start control module	Not available	Available
6.	4WD control module	K-line	Available
7.	Combination meter	Not available	Not available
8.	CAN junction connector	—	—
9.	DLC	—	—

Outline of troubleshooting

When there is a trouble with CAN, perform “Troubleshooting for Communication Error with Scan Tool Using CAN” and/or “Troubleshooting for CAN-DTC”. Not using this procedure or performing troubleshooting in any other way may skip some check points resulting in misdiagnosis or take a longer time than necessary.

- 1) Checking connector related to CAN
- 2) Checking CAN line
- 3) Checking each control module/sensor using “DTC check” or “Bus Check”
- 4) Checking power and ground connection of each control module/sensor

CAN-DTC

Even when DTC related to CAN (= CAN-DTC) as described below is detected, it is not possible to point out the specific trouble point by CAN-DTC itself. Be sure to troubleshoot according to “Troubleshooting for CAN-DTC”.

CAN-DTC table

Detected Control Module	CAN-DTC
ECM	U0073/U0101/U0121/U0140/P1618
TCM	U0073/U0100
BCM	U0073/U0100/U0101/U0155/U1144
4WD control module	U0073/U0100/U0121/U0155
Keyless start control module	No.31/No.33

Communication with scan tool

- K line or CAN line is used for communication between each control module and scan tool.
Refer to “CAN schematic and routing diagram: ” to determine which line is used for communication between each control module and scan tool.
- ECM and TCM use CAN line for communication with scan tool. Even if CAN has a trouble other than between DLC and BCM, communication may also fail between scan tool and these control modules. In such case, perform troubleshooting according to “Troubleshooting for Communication Error with Scan Tool Using CAN”.
- BCM, ABS control module and 4WD control module use K-line for communication with scan tool. Even if CAN has a trouble, it is possible to communicate between scan tool and these control modules.

Bus check with SUZUKI scan tool

SUZUKI scan tool (SUZUKI-SDT) efficiently diagnoses a CAN bus malfunction by “Communication Bus Check” and “Communication Malfunction DTC” under “Bus check”.

“Communication Bus Check” can display all control modules/sensors name communicated by CAN.

Also, “Communication Malfunction DTC” can display only CAN-DTC which is detected by the control modules (ECM and TCM) communicating with scan tool using CAN line.

General Description

Statement on Cleanliness and Care

S7RW0C1101001

An automobile engine is a combination of many machined, honed, polished and lapped surfaces with tolerances that are measured in the thousands of an millimeter (ten thousands of an inch).


Accordingly, when any internal engine parts are serviced, care and cleanliness are important.

It should be understood that proper cleaning and protection of machined surfaces and friction areas is part of the repair procedure. This is considered standard shop practice even if not specifically stated.

- A liberal coating of engine oil should be applied to friction areas during assembly to protect and lubricate the surfaces on initial operation.
- Whenever valve train components, pistons, piston rings, connecting rods, rod bearings, and crankshaft journal bearings are removed for service, they should be retained in order.

At the time of installation, they should be installed in the same locations and with the same mating surfaces as when removed.

- Battery cables should be disconnected before any major work is performed on the engine.
Failure to disconnect cables may result in damage to wire harness or other electrical parts.
- The four cylinders of the engine are identified by numbers; No.1 (1), No.2 (2), No.3 (3) and No.4 (4) counted from crankshaft pulley side to flywheel side.



I7RW01110001-03

[A]: Forward

Engine Diagnosis General Description

S7RW0C1101002

NOTE

There are two types of OBD system depending on the vehicle specification. For identification, refer to "Precaution on On-Board Diagnostic (OBD) System".

The engine and emission control systems in this vehicle are controlled by ECM. ECM has an On-Board Diagnostic system which detects a malfunction in this system and abnormality of those parts that influence the engine exhaust emission. When diagnosing engine troubles, be sure to have full understanding of the outline of "On-Board Diagnostic System Description" and each item in "Precautions in Diagnosing Trouble" and execute diagnosis according to "Engine and Emission Control System Check".

There is a close relationship between the engine mechanical, engine cooling system, ignition system, exhaust system, etc. and the engine and emission control system in their structure and operation. In case of an engine trouble, even when the malfunction indicator lamp (MIL) doesn't turn ON, it should be diagnosed according to "Engine and Emission Control System Check".

On-Board Diagnostic System Description

S7RW0C1101003

NOTE



There are two types of OBD system depending on the vehicle specification. For identification, refer to "Precaution on On-Board Diagnostic (OBD) System".

Euro OBD model

ECM in this vehicle has the following functions.

- When the ignition switch is turned ON with the engine at a stop, malfunction indicator lamp (MIL) (1) turns ON to check the MIL (1) and its circuit.
- When ECM detects a malfunction which gives an adverse effect to vehicle emission while the engine is running, it makes MIL in the meter cluster of the instrument panel turn ON or flash (flashing only when detecting a misfire which can cause damage to the catalyst) and stores the malfunction area in its memory.
(If it detects that continuously 3 driving cycles are normal after detecting a malfunction, however, it makes MIL turn OFF although DTC stored in its memory will remain.)
- As a condition for detecting a malfunction in some areas in the system being monitored by ECM and turning on MIL due to that malfunction, 2 driving cycle detection logic is adopted to prevent erroneous detection.

- When a malfunction is detected, engine and driving conditions are stored in ECM memory as freeze frame data. (For the details, refer to description on "Freeze Frame Data: ".)
- It is possible to communicate via DLC (data link connector) (3) by using not only SUZUKI scan tool (SUZUKI-SDT) (2) but also CAN communication OBD generic scan tool. (Diagnostic information can be accessed by using a scan tool.)



I7RW01110012-01

Warm-Up Cycle

A warm-up cycle means sufficient vehicle operation such that the coolant temperature has risen by at least 22 °C (40 °F) from engine starting and reaches a minimum temperature of 70 °C (160 °F).

Driving Cycle

A "Driving Cycle" consists of engine startup, and engine shutoff.

2 Driving Cycle Detection Logic

The malfunction detected in the first driving cycle is stored in ECM memory (in the form of pending DTC and freeze frame data) but the MIL does not light at this time. It lights up at the second detection of same malfunction also in the next driving cycle.

Pending DTC

Pending DTC means a DTC detected and stored temporarily at 1 driving cycle of the DTC which is detected in the 2 driving cycle detection logic.

1A-6 Engine General Information and Diagnosis:

Freeze Frame Data

ECM stores the engine and driving conditions (in the form of data as shown) at the moment of the detection of a malfunction in its memory. This data is called “Freeze frame data”.

Therefore, it is possible to know engine and driving conditions (e.g., whether the engine was warm or not, where the vehicle was running or stopped, where air/fuel mixture was lean or rich) when a malfunction was detected by checking the freeze frame data. Also, ECM has a function to store each freeze frame data for three different malfunctions in the order as the malfunction is detected. Utilizing this function, it is possible to know the order of malfunctions that have been detected. Its use is helpful when rechecking or diagnosing a trouble.

Freeze flame data (for example)

Function View System Bar Help				
Sub System / Freeze Frame Data				
P0100	Mass or Volume Air Flow Circuit Malfunction			
Parameter	Value	Units		
Calculated Engine Speed	15	%		
Vehicle Speed	15	MPH		
Engine Speed	2500	rpm		
Ignition Advance	10	deg		
Intake Air Temperature	165	F		
Throttle Position #1	20	%		
MIL Status	ON			
Vapor Pressure	-1.116	V		
Shift Position	D			
				Exit
DTC	Data List	View	Active Test	Utility

15RW0C110028-03

Priority of freeze frame data

ECM has 4 frames where the freeze frame data can be stored. The first frame stores the freeze frame data of the malfunction which was detected first. However, the freeze frame data stored in this frame is updated according to the priority described below. (If malfunction as described in the upper square “1” below is detected while the freeze frame data in the lower square “2” has been stored, the freeze frame data “2” will be updated by the freeze frame data “1”.)

Priority	Freeze frame data in frame 1
1	Freeze frame data at initial detection of malfunction among misfire detected (P0300 – P0304), fuel system too lean (P0171) and fuel system too rich (P0172)
2	Freeze frame data when a malfunction other than those in “1” above is detected.

In the 2nd through the 4th frames, the freeze frame data of each malfunction is stored in the order as the malfunction is detected. These data are not updated.

Shown in the table below are examples of how freeze frame data are stored when two or more malfunctions are detected.

Frame		Frame 1	Frame 2	Frame 3	Frame 4
Malfunction detection order		Freeze frame data	1st freeze frame data	2nd freeze frame data	3rd freeze frame data
1	No malfunction detected	—	—	—	—
2	P0116 (Pending DTC)	P0116 data	P0116 data	—	—
3	No malfunction detected	P0116 data	P0116 data	—	—
4	No malfunction detected	—	—	—	—
5	P0111 (Pending DTC)	P0111 data	P0111 data	—	—
6	P0111 P0116 (Pending DTC)	P0111 data	P0111 data	P0116 data	—
7	P0300 (Pending DTC)	P0300 data	P0111 data	P0116 data	P0300 data
8	P0300	P0300 data	P0111 data	P0300 data	—

—: No freeze frame data

Freeze frame data clearance

The freeze frame data is cleared at the same time as clearance of DTC or Pending DTC.

Non-Euro-OBD Model



ECM diagnosis troubles which may occur in the area including the following parts when the ignition switch is ON and the engine is running, and indicates the result by turning on malfunction indicator lamp (MIL) (1).

- Heated oxygen sensor
- A/F sensor
- ECT sensor
- TP sensor
- MAF sensor
- IAT sensor
- CMP sensor
- CKP sensor
- Knock sensor
- Wheel speed sensor
- CPU (Central Processing Unit) of ECM
- APP sensor
- Radiator cooling fan relay
- EVAP canister purge valve
- Starter relay

ECM and MIL operate as follows.

- MIL lights when the ignition switch is turned ON (but the engine at stop) with the diagnosis switch terminal ungrounded regardless of the condition of Engine and Emission control system. This is only to check MIL in the combination meter and its circuit.
- If the above areas of Engine and Emission control system is free from any trouble after the engine start (while engine is running), MIL turns OFF.
- When ECM detects a trouble which has occurred in the above areas, it makes MIL turn ON while the engine is running to warn the driver of such occurrence of trouble and at the same time it stores the trouble area in ECM back-up memory. (The memory is kept as it is even if the trouble was only temporary and disappeared immediately. And it is not erased unless the power to ECM is shut off for specified time or it is cleared by SUZUKI scan tool (SUZUKI SDT) (2).)

For further detail of the checking / cleaning DTC procedure, refer to "DTC Check" and "DTC Clearance".



I7RW01110012-01

For information about the following items, refer to "Euro OBD model: ".

- Warm-up cycle
- Driving cycle
- 2 driving cycle detection logic
- Pending DTC

DLC (Data Link Connector) Description


S7RW0C1101004

NOTE

There are two types of OBD system depending on the vehicle specification. For identification, refer to "Precaution on On-Board Diagnostic (OBD) System".

DLC (1) is in compliance with SAE J1962 in its installation position, the shape of connector and pin assignment.

OBD CAN Hi line (6) and Low line (3) (CAN line of ISO 15765-4) are used for SUZUKI scan tool (SUZUKI-SDT) (7) or CAN communication OBD generic scan tool to communicate with ECM (included in immobilizer control) and TCM.



I7RW01110092-01

- | | |
|----|---|
| 2. | B + (Unswitched vehicle battery positive) |
| 4. | ECM ground (Signal ground) |
| 5. | Vehicle body ground (Chassis ground) |

Engine and Emission Control System Description

S7RW0C1101005

The engine and emission control system is divided into 4 major sub-systems: air intake system, fuel delivery system, electronic control system and emission control system.

Air intake system includes air cleaner, throttle body and intake manifold.

Fuel delivery system includes fuel pump, delivery pipe, etc.

Electronic control system includes ECM, various sensors and controlled devices.


Emission control system includes EVAP and PCV systems.

CAN Communication System Description

S7RW0C1101006

ECM (2), ABS control module (1), TCM (3), BCM (4), 4WD control module (6), combination meter (7) and keyless start control module (5) communicate control data between each control module.

Communication of each control module is established by CAN (Controller Area Network) communication system.



- | | |
|----|------------------------|
| 8. | CAN junction connector |
| 9. | DLC |

I6RW0C110003-02

CAN communication system uses the serial communication in which data is transmitted at a high speed. It uses a twisted pair of two communication lines for the high-speed data transmission. As one of its characteristics, multiple control modules can communicate simultaneously. In addition, it has a function to detect a communication error automatically. Each module reads necessary data from the received data and transmits data. ECM communicates control data with each control module as follows.

ECM Transmission Data

			TCM	BCM	Combination meter	4WD control module	Keyless Start control module
ECM		DATA	Engine torque signal	○		○	
			Accelerator pedal position signal	○		○	
			Engine speed signal	○	○	○	
			Throttle position signal	○			
			Driving cycle active	○			
			Warm up cycle active	○			
			Immobilizer indicator light control signal		○		
			MIL control signal		○		
			Engine coolant temperature signal	○	○		
			Fuel level signal		○		
			Cruise control signal	○			
			"CRUSE" and "SET" indication light control signal		○		
			Vehicle speed signal		○		○
			Brake pedal switch signal	○	○	○	
			A/C compressor clutch signal		○		
			Fuel consumption signal		○		
			Odometer signal		○		
			A/C refrigerant pressure signal		○		
			Engine type signal		○	○	
			ECM-keyless start control module code				○

ECM Reception Data

				TCM	BCM	ABS control module	4WD control module	Keyless start control module
ECM	Receive	DATA	Torque request signal	○				
			Transmission actual gear position signal	○				
			MIL control signal	○				
			Transmission warning light signal	○				
			Transmission selector lever position signal	○				
			Transmission oil temperature signal	○				
			Vehicle speed pulse signal	○				
			A/C switch ON signal		○			
			Electric load signal		○			
			Wheel speed signal (front right)			○		
			Wheel speed signal (front left)			○		
			ABS active			○		
			4WD mode status				○	
			ECM-keyless start control module code					○
			ID code of keyless start control module					○


I6RW0C110005-04

Air Intake System Description

S7RW0C1101007

The main components of the air intake system are air cleaner (1), air cleaner outlet hose (2), electric throttle body (3) (for the details, refer to “Electric Throttle Body System Description”), intake manifold tuning (IMT) valve (4) which adjusts the distributor pipe length of intake manifold to “A” or “B” (for the details, refer to “IMT (Intake Manifold Tuning) System Description in Section 1D”) and intake manifold (5).

The air (by the amount corresponding to throttle valve (6) opening and engine speed) is filtered by the air cleaner, distributed by the intake, and finally drawn into each combustion chamber. Electric throttle body is not equipped with IAC valve for idle speed control. Idle speed control is done by the throttle actuator (7) which opens/closes the throttle valve. (For the details, refer to “Electric Throttle Body System Description”).



I7RW01110005-02

Electric Throttle Body System Description

S7RW0C1101008

The Electric Throttle Body System consists of electric throttle body assembly, accelerator pedal position (APP) sensor assembly, ECM and throttle actuator control relay.

Among them, assembly components are as follows.


- Electric throttle body assembly: throttle valve, throttle actuator, 2 throttle position (TP) sensors
- APP sensor assembly: Accelerator pedal, 2 APP sensors

Operation Description

ECM (5) detects opening (depressed extent of pedal) of the accelerator pedal based on signal voltage of the APP sensor (1) and using that data and engine operation condition, it calculates the optimum throttle valve opening. On the other hand, it detects the throttle valve opening based on the signal voltage of TP sensor (3) included in the throttle body (2) and compares it with the above calculated optimum throttle valve opening. When there is a difference between them, ECM controls the duty ratio (100% – 0%) of throttle actuator control according to this difference to drive the throttle actuator (motor) (4) included in the throttle body. When there is no difference, ECM controls the duty ratio of throttle actuator control to about 15% to maintain the throttle valve opening. In this way, the throttle valve (17) is opened and closed to achieve the optimum throttle valve opening.

In this system, TP sensor and APP sensor have 2 sensors (main and sub) each, highly accurate and highly reliable control and abnormality detection are assured. Also, when ECM detects an abnormality in the system, it turns off the throttle actuator control relay (8) to stop controlling the throttle actuator. When the throttle actuator control relay is turned off, the throttle valve is fixed at the opening of about 7° from its completely closed position (default opening) by the force of the return spring and open spring included in the throttle body.

This throttle body is not equipped with IAC valve for idle speed control. Idle speed control is done by the throttle actuator which opens/closes the throttle valve.



I4RS0B110007-02

6. CPU	11. APP sensor (main) signal	15. Drive signal of throttle actuator
7. Drive circuit of throttle actuator	12. APP sensor (sub) signal	16. Power supply of throttle actuator
9. From "THR MOT" fuse	13. TP sensor (main) signal	18. Control signal of throttle actuator control relay
10. From main relay	14. TP sensor (sub) signal	

Description of Electric Throttle Body System Calibration

S7RW0C1101009

ECM calculates controlled opening of the throttle valve on the basis of the completely closed throttle valve position of the electric throttle body system. The completely closed position data is saved in memory of ECM. However, the completely closed position of the throttle valve of the electric throttle body system (signal voltage from TP sensor when throttle is completely closed) differs one from the other depending on individual differences of the throttle valve and TP sensor. As such individual differences must be taken into account for controlling the throttle valve, it is necessary to register the completely closed throttle valve position data in ECM. When such data is registered in ECM, it is saved in RAM (memory) of ECM and used as the base data for controlling the throttle valve. This data is cleared, when any of the works described in "Precautions of Electric Throttle Body System Calibration" is performed.

Also, after replacement of the throttle body and/or APP sensor assembly, the completely closed position data in memory of ECM must be cleared once and a new one must be registered, or ECM cannot judge the complete closure position properly.

For the procedure to register such data, refer to “Electric Throttle Body System Calibration in Section 1C”. (After the completely closed position data is cleared, ECM, for the first time only, opens and closes the throttle valve for about 5 sec. after the ignition switch is turned ON position, for registration of the completely closed throttle valve position. If the engine is started during this registration process, such symptom as “longer cranking time” or “slow rise of revolution speed immediately after start-up” may occur. However, turning OFF the ignition switch once and restarting will set correct registration.)

A/F Sensor Description

S7RW0C1101010

A/F sensor (1), in place of the conventional HO2S-1, is installed in the center of the exhaust manifold joining section and it consists of a zirconia element (2) which causes the output current to vary according to difference in the oxygen concentration and a heater (3) which activates the element.


A/F sensor detects oxygen concentration in exhaust gas (9) (A/F ratio of the air-fuel mixture) linearly, ranging from LEAN to RICH.

Operation

ECM (5) controls the sensor heater (3) and keeps the sensor element temperature at the specified level (about 750 °C) constantly so that the A/F sensor is activated in the specified way for accurate A/F detection. When the sensor element reaches the specified temperature (it is activated), its impedance drops to the specified value (approx. 30 Ω) by its characteristic.

When a certain voltage (about 0.4 V) is applied between sensor elements in this state, circuit current corresponding to the sensor element impedance flows in the sensor circuit. ECM detects this circuit current and judges whether the sensor is in the active state or not. At this time, sensor current is output linearly in the range of +0.01 mA to +some mA on the lean side and -0.01 mA to - some mA on the rich side. The variation in these ranges depends on the difference from the stoichiometry A/F ratio, that is, the amount of oxygen between the atmosphere side (6) and exhaust manifold (7).

According to this sensor output, ECM executes A/F feedback (fuel trim) to achieve the target A/F ratio.



I7RW01110007-02

4. 0.4 V	10. Electrode	12. CPU	14. Rich
8. A/F sensor connector	11. A/F signal processing circuit	13. Lean	

Electronic Control System Description

S7RW0C1101011

The electronic control system consists of 1) various sensors which detect the state of engine and driving conditions, 2) ECM which controls various devices according to the signals from the sensors and 3) various controlled devices. Functionally, it is divided into the following sub systems:

- Fuel injection control system
- Ignition control system
- IMT valve control system
- Electric Throttle Body Control System
- Fuel pump control system
- Radiator cooling fan control system
- Evaporative emission control system
- A/F sensor heater control system
- HO2S heater control system
- A/C control system
- Immobilizer control system
- Generator control system
- Controller (computer) communication system

Especially, ECM, BCM, combination meter, TCM, ABS control module, 4WD control module and keyless start control module intercommunicate by means of CAN (Controller Area Network) communication.

Refer to "Engine and Emission Control System Flow Diagram" and "ECM Input / Output Circuit Diagram".

Engine and Emission Control Input / Output Table

S7RW0C1101012

Function	Output	Input
Main relay control	Main relay	• Ignition switch
Fuel pump control	Fuel pump relay	• CKP sensor • Ignition switch • Starter switch • Immobilizer control module (in ECM)
Injection control	Fuel injection	• CKP sensor • CMP sensor • MAF sensor • IAT sensor • TP sensor • ECT sensor • A/F sensor • HO2S • P/S control module • ABS control module • Transmission range sensor • Brake light switch • A/C switch • Blower speed selector • Barometric pressure sensor • Ignition switch • Starter switch • Immobilizer control module (in ECM)

1A-14 Engine General Information and Diagnosis:

Function	Output	Input
A/F sensor and HO2S heater control	A/F sensor and HO2S	• Ignition switch • MAF sensor • ECT sensor • IAT sensor • TP sensor • CKP sensor
Idle speed control	Throttle actuator	• CKP sensor • MAF sensor • IAT sensor • TP sensor • ECT sensor • APP sensor • Wheel speed sensor (VSS) • A/C refrigerant pressure sensor • A/C evaporator outlet air temp. sensor • P/S control module • ABS control module • Transmission range sensor • Transmission fluid temperature sensor • Lighting switch • Rear end door defogger switch • Brake light switch • A/C switch • Blower speed selector • Barometric pressure sensor • Ignition switch • Starter switch • Immobilizer control module (in ECM)
Ignition control	Ignition coil with igniter	• Ignition switch • Starter switch • MAF sensor • IAT sensor • TP sensor • ECT sensor • CKP sensor • CMP sensor • Knock sensor • Wheel speed sensor (VSS) • Transmission range sensor • Barometric pressure sensor • Immobilizer control module (in ECM)

Function	Output	Input
EVAP purge control	EVAP canister purge valve	• Barometric pressure sensor • Ignition switch • A/C switch • Blower fan selector • A/F sensor • MAF sensor • IAT sensor • TP sensor • ECT sensor • CKP sensor
Radiator cooling fan control	Radiator cooling fan relay No.1, No.2 and No.3	• Ignition switch • A/C switch • Blower fan selector • Wheel speed sensor (VSS) • ECT sensor • A/C refrigerant pressure sensor • A/C evaporator outlet air temp. sensor
MIL control	MIL	• Barometric pressure sensor • Ignition switch • Wheel speed sensor (VSS) • A/F sensor • HO2S • MAF sensor • IAT sensor • TP sensor • ECT sensor • APP sensor • CKP sensor • CMP sensor • Knock sensor • Immobilizer control module (in ECM)
Throttle actuator power supply control	Throttle actuator control relay	• Ignition switch • TP sensor • APP sensor
IMT valve control	IMT valve actuator	• Ignition switch • ECT sensor • TP sensor • CMP sensor
Generator control	Generator	• Ignition switch • TP sensor • ECT sensor • CKP sensor • CMP sensor • Wheel speed sensor (VSS) • Blower fan switch • Lighting switch • Rear end door defogger switch


1A-16 Engine General Information and Diagnosis:

Function	Output	Input
A/C compressor control	A/C compressor relay	• Ignition switch • Starter switch • ECT sensor • A/C refrigerant pressure sensor • A/C evaporator outlet air temp. sensor • Blower fan switch • A/C switch • Wheel speed sensor (VSS) • TP sensor • CKP sensor
A/C condenser cooling fan control	A/C condenser cooling fan relay	• Wheel speed sensor (VSS) • A/C refrigerant pressure sensor • A/C evaporator outlet air temp. sensor • ECT sensor • A/C switch • Blower fan switch • Ignition switch

Schematic and Routing Diagram

Engine and Emission Control System Diagram

S7RW0C1102001




I6RW0C110008-01

1A-18 Engine General Information and Diagnosis:

1. Air cleaner	15. HO2S	29. Throttle actuator control relay
2. MAF and IAT sensor	16. Warm-up three way catalytic converter	30. Radiator cooling fan relay
3. TP sensor	17. Three way catalytic converter	31. A/C condenser cooling fan relay
4. Throttle actuator	18. ECM	32. A/C compressor relay
5. IMT valve actuator	19. Barometric pressure sensor	33. Clutch switch (cruise control model)
6. EVAP canister purge valve	20. CMP sensor	34. Brake switch (cruise control model)
7. EVAP canister	21. CKP sensor	35. APP sensor
8. Vapor control valve (assembled into the fuel tank)	22. TCM	36. Brake light
9. Fuel pump	23. ABS control module	37. Brake light switch
10. Fuel injector	24. To other control module and DLC connected CAN	38. Starting motor control relay
11. Ignition coil assembly	25. P/S control module	39. Main relay
12. ECT sensor	26. Immobilizer coil antenna	40. Ignition switch
13. Knock sensor	27. Generator	41. Starter magnetic switch
14. A/F sensor	28. A/C refrigerant pressure sensor	42. Battery

Engine and Emission Control System Flow Diagram


S7RW0C1102002



I6RW0C110006-01

ECM Input / Output Circuit Diagram

S7RW0C1102003




I6RW0C110007-01

1. ECM	26. To BCM	51. Ignition coil assembly (for No.1 spark plug)
2. APP sensor assembly	27. IMT valve actuator	52. Ignition coil assembly (for No.2 spark plug)
3. Shield wire	28. Throttle actuator control relay	53. Ignition coil assembly (for No.3 spark plug)
4. CMP sensor	29. "THR MOT" fuse	54. Ignition coil assembly (for No.4 spark plug)
5. CKP sensor	30. Electric throttle body assembly	55. Brake light

6. MAF and IAT sensor	31. Throttle actuator	56. Brake light switch
7. ECT sensor	32. TP sensor	57. "STOP" fuse
8. A/C refrigerant pressure sensor	33. Fuel injector No.1	58. "IG COIL" fuse
9. A/C evaporator outlet air temp. sensor (Manual A/C model)	34. Fuel injector No.2	59. Main relay
10. Generator	35. Fuel injector No.3	60. "IG2 SIG" fuse
11. HO2S	36. Fuel injector No.4	61. "DOME" fuse
12. A/F sensor	37. EVAP canister purge valve	62. "FI" fuse
13. Knock sensor	38. P/S control module	63. Ignition switch
14. Cruise control switch	39. Fuel pump relay	64. "IGN" fuse
15. Brake switch (cruise control model)	40. Fuel pump	65. Transmission range switch (A/T model)
16. Clutch switch (cruise control model)	41. Radiator cooling fan relay No.1	66. Starting motor control relay
17. ABS control module	42. Radiator cooling fan relay No.2	67. Starting motor
18. To other control module and DLC connected CAN	43. Radiator cooling fan relay No.3	68. "ST" fuse
19. TCM	44. Radiator cooling fan motor	69. "ST SIG". fuse
20. Fuel level sensor	45. "RDTR" fuse	70. Immobilizer coil antenna
21. Blower motor relay	46. A/C condenser cooling fan relay	71. Main fuse box
22. Blower motor	47. A/C condenser cooling fan motor	72. Battery
23. Blower speed selector (Auto A/C model)	48. A/C compressor relay	73. Barometric pressure sensor
24. Blower speed selector (Manual A/C model)	49. A/C compressor	74. Engine ground
25. A/C switch	50. "A/C" fuse	75. Body ground

Terminal Arrangement of ECM Coupler (Viewed from Harness Side)



Connector: C01

Terminal	Wire color	Circuit	Terminal	Wire color	Circuit
1	BLU/YEL	Fuel injector No.1	31	BLK	Ground for A/F sensor heater
2	BLU/WHT	Fuel injector No.2	32	RED	Heater output of A/F sensor
3	—	—	33	BLK	Shield ground for TP sensor circuit
4	—	—	34	—	—
5	—	—	35	—	—
6	—	—	36	BLU	CKP sensor (–)
7	—	—	37	BLK	A/F sensor signal (–)
8	—	—	38	WHT	A/F sensor signal (+)
9	—	—	39	BLK/RED	Ground for HO2S
10	—	—	40	WHT	TP sensor (sub) signal
11	BRN	Oxygen signal of HO2S	41	BLK	Ground for TP sensor
12	RED/BLU	A/C refrigerant pressure sensor signal	42	YEL	IMT valve actuator (+)
13	BLU/BLK	EVAP canister purge valve output	43	YEL/BLK	IMT valve actuator (–)
14	GRY/RED	Output of 5 V power source for A/C refrigerant pressure sensor	44	YEL	Output of throttle actuator
15	BLK	Ground for ECM	45	BLU	Output of throttle actuator
16	BLU/RED	Fuel injector No.3	46	—	—
17	BLU/ORN	Fuel injector No.4	47	RED/BLU	Heater output of HO2S
18	GRN	Ignition coil No.4	48	BLK/ORN	Ground for ECM
19	GRN/BLK	Ignition coil No.3	49	WHT	CAN (low) communication line (active low signal) to TCM
20	GRN/WHT	Ignition coil No.2	50	RED	CAN (high) communication line (active high signal) to TCM
21	GRN/YEL	Ignition coil No.1	51	PNK	CKP sensor (+)
22	YEL/GRN	Starting motor signal	52	RED/YEL	CMP sensor signal
23	—	—	53	RED	Output for 5 V power source of TP sensor
24	LT GRN	ECT sensor signal	54	GRN	TP sensor (main) signal
25	LT GRN/BLK	IAT sensor signal	55	—	—
26	PNK/BLK	MAF sensor signal	56	RED	Knock sensor signal
27	GRY	Ground for MAF sensor	57	GRY/BLU	Ground for sensors
28	BLU/YEL	Generator control signal output	58	BLK/ORN	Ground for ECM
29	BLK	Ground for ECM	59	—	—
30	BLK	Ground for ECM	60	—	—

Connector: E01

Terminal	Wire color	Circuit	Terminal	Wire color	Circuit
1	BLK/RED	Main power supply	31	—	—
2	WHT/RED	Power source for ECM internal memory	32	—	—
3	—	—	33	—	—
4	RED	CAN (high) communication line (active high signal) to ABS control module	34	—	—
5	—	—	35	BLU/WHT	Electric load signal for heater blower motor
6	RED/WHT	Cruise control main switch signal	36	ORN	Ground for sensor
7	LT GRN/BLK	Clutch pedal position switch signal (cruise control model)	37	—	—
8	GRN/YEL	Brake pedal position switch (cruise control model)	38	—	—
9	—	—	39	—	—
10	—	—	40	—	—
11	—	—	41	WHT/BLK	A/C evaporator outlet air temp. sensor signal (Manual A/C model)
12	—	—	42	—	—
13	YEL/RED	Clock signal for immobilizer coil antenna	43	—	—
14	—	—	44	BRN	Engine speed signal output for P/S control module
15	GRN/WHT	Fuel pump relay output	45	—	—
16	BLK/RED	Main power supply	46	LT GRN	Radiator cooling fan relay No.1 output
17	GRN	Power supply of throttle actuator drive circuit	47	GRN	Radiator cooling fan relay No.2/No.3 output
18	—	—	48	RED/BLK	A/C condenser cooling fan relay output
19	WHT	CAN (low) communication line (active low signal) to ABS control module	49	GRY	A/C compressor relay output
20	GRN/WHT	Brake light switch signal	50	BRN	Throttle actuator control relay output
21	BLK/YEL	Cruise control command switch ground	51	WHT	Ground for APP sensor (sub)
22	LT GRN	Cruise control command switch signal	52	YEL	APP sensor (sub) signal
23	—	—	53	RED	Output for 5 V power source of APP sensor (sub)
24	YEL/RED	Fuel level sensor signal	54	BLU	Ground for APP sensor (main)
25	—	—	55	GRN	APP sensor (main) signal
26	—	—	56	BRN	Output for 5 V power source of APP sensor (main)
27	RED/BLU	EPS active signal (idle up signal)	57	—	—
28	YEL/BLK	Serial communication line for immobilizer coil antenna	58	—	—
29	BLK/WHT	Ignition switch signal	59	—	—
30	WHT	Starting motor control relay output	60	BRN/WHT	Main power supply relay output


Component Location

Electronic Control System Components Location

S7RW0C1103001

NOTE

The figure shows left-hand steering vehicle. For right-hand steering vehicle, parts with (*) are installed at the opposite side.



I6RW0C110009-02

Information sensors	Control devices	Others
1. MAF and IAT sensor	a: Fuel injector	A: ECM
2. Electric throttle body assembly (built-in TP sensor and throttle actuator)	b: EVAP canister purge valve	B: Combination meter
3. Brake light switch	c: Fuel pump relay	C: EVAP canister
4. ECT sensor	d: MIL	D: A/C evaporator temperature sensor
5. A/F sensor	e: Radiator cooling fan relay No.1	E: DLC
6. HO2S	f: IMT valve actuator	F: P/S control module
7. Battery	g: Ignition coil assembly (with ignitor)	G: TCM
8. CMP sensor	h: Main relay	H: BCM
9. CKP sensor	i: Radiator cooling fan relay No.2	I: Immobilizer coil antenna
10. Fuel level sensor	j: Radiator cooling fan relay No.3	J: Fuse box No.2
11. Knock sensor	k: Starting motor control relay	K: A/C refrigerant pressure sensor
12. APP sensor	l: Immobilizer indicator light	L: ABS control module
13. Front wheel speed sensor (VSS)	m: Throttle actuator control relay	

Diagnostic Information and Procedures

Engine and Emission Control System Check

S7RW0C1104001

Refer to the following items for the details of each step.

Step	Action	Yes	No
1	☛ Customer complaint analysis 1) Perform customer complaint analysis referring to "Customer Complaint Analysis". <i>Was customer complaint analysis performed?</i>	Go to Step 2.	Perform customer complaint analysis.
2	☛ DTC / Freeze frame data check, record and clearance 1) Check for DTC (including pending DTC) referring to "DTC / Freeze Frame Data Check, Record and Clearance". <i>Is there any DTC(s)?</i>	Print DTC and freeze frame data or write them down and clear them by referring to "DTC Clearance", and go to Step 3.	Go to Step 4.
3	☛ Visual inspection 1) Perform visual inspection referring to "Visual Inspection". <i>Is there any faulty condition?</i>	Repair or replace malfunction part, and go to Step 11.	Go to Step 5.
4	☛ Visual inspection 1) Perform visual inspection referring to "Visual Inspection". <i>Is there any faulty condition?</i>	Repair or replace malfunction part, and go to Step 11.	Go to Step 8.
5	☛ Trouble symptom confirmation 1) Confirm trouble symptom referring to "Trouble Symptom Confirmation". <i>Is trouble symptom identified?</i>	Go to Step 6.	Go to Step 7.
6	☛ Rechecking and record of DTC / Freeze frame data 1) Recheck for DTC and freeze frame data referring to "DTC Check". <i>Is there any DTC(s)?</i>	Go to Step 9.	Go to Step 8.
7	☛ Rechecking and record of DTC / Freeze frame data 1) Recheck for DTC and freeze frame data referring to "DTC Check". <i>Is there any DTC(s)?</i>	Go to Step 9.	Go to Step 10.
8	☛ Engine basic inspection and engine symptom diagnosis 1) Check and repair according to "Engine Basic Inspection" and "Engine Symptom Diagnosis". <i>Are check and repair complete?</i>	Go to Step 11.	Check and repair malfunction part(s), and go to Step 11.
9	☛ Troubleshooting for DTC 1) Check and repair according to applicable DTC diag. flow. <i>Are check and repair complete?</i>	Go to Step 11.	Check and repair malfunction part(s), and go to Step 11.
10	☛ Intermittent problems check 1) Check for intermittent problems referring to "Intermittent Problems Check". <i>Is there any faulty condition?</i>	Repair or replace malfunction part(s), and go to Step 11.	Go to Step 11.

1A-26 Engine General Information and Diagnosis:

Step	Action	Yes	No
11	 Final confirmation test 1) Clear DTC if any. 2) Perform final confirmation test referring to “Final Confirmation Test”. <i>Is there any problem symptom, DTC or abnormal condition?</i>	Go to Step 6.	End.

Step 1: Customer Complaint Analysis

Record details of the problem (failure, complaint) and how it occurred as described by the customer. For this purpose, use of such an inspection form will facilitate collecting information to the point required for proper analysis and diagnosis.

Customer problem inspection form (Example)

User name:	Model:	VIN:	
Date of issue:	Date Reg.	Date of problem:	Mileage:

PROBLEM SYMPTOMS	
☐ Difficult Starting ☐ No cranking ☐ No initial combustion ☐ No combustion ☐ Poor starting at (☐ cold ☐ warm ☐ always) ☐ Other _____	☐ Poor Driveability ☐ Hesitation on acceleration ☐ Back fire/ ☐ After fire ☐ Lack of power ☐ Surging ☐ abnormal knocking ☐ Other _____
☐ Poor Idling ☐ Poor fast idle ☐ Abnormal idling speed (☐ High ☐ Low) (r/min.) ☐ Unstable ☐ Hunting (r/min. to r/min.) ☐ Other _____	☐ Engine Stall when ☐ Immediately after start ☐ Accel. pedal is depressed ☐ Accel. pedal is released ☐ Load is applied ☐ A/C ☐ Electric load ☐ P/S ☐ Other _____ ☐ Other _____
☐ OTHERS:	

VEHICLE/ENVIRONMENTAL CONDITION WHEN PROBLEM OCCURS	
Environmental Condition	
Weather	☐ Fair ☐ Cloudy ☐ Rain ☐ Snow ☐ Always ☐ Other _____
Temperature	☐ Hot ☐ Warm ☐ Cool ☐ Cold (°F/ °C) ☐ Always
Frequency	☐ Always ☐ Sometimes (times/ day, month) ☐ Only once ☐ Under certain condition
Road	☐ Urban ☐ Suburb ☐ Highway ☐ Mountainous (☐ Uphill ☐ Downhill) ☐ Tarmacadam ☐ Gravel ☐ Other _____
Vehicle Condition	
Engine condition	☐ Cold ☐ Warming up phase ☐ Warmed up ☐ Always ☐ Other at starting ☐ Immediately after start ☐ Racing without load ☐ Engine speed (r/min)
Vehicle condition	During driving: ☐ Constant speed ☐ Accelerating ☐ Decelerating ☐ Right hand corner ☐ Left hand corner ☐ When shifting (Lever position) ☐ At stop ☐ Vehicle speed when problem occurs (km/h, Mile/h) ☐ Other

Malfunction indicator lamp condition	☐ Always ON ☐ Sometimes ON ☐ Always OFF ☐ Good condition
Diagnostic trouble code	First check: ☐ No code ☐ Malfunction code () Second check: ☐ No code ☐ Malfunction code ()

I2RH01110010-02

NOTE

This form is a standard sample. It should be modified according to conditions characteristic of each market.

Step 2: DTC / Freeze Frame Data Check, Record and Clearance

First, check DTC (including pending DTC), referring to "DTC Check". If DTC is indicated, print it and freeze frame data or write them down and then clear them by referring to "DTC Clearance". DTC indicates malfunction that occurred in the system but does not indicate whether it exists now or it occurred in the past and the normal condition has been restored now. To check which case applies, check the symptom in question according to Step 5 and recheck DTC according to Step 6 and 7. Attempt to diagnose a trouble based on DTC in this step only or failure to clear the DTC in this step will lead to incorrect diagnosis, trouble diagnosis of a normal circuit or difficulty in troubleshooting.

Step 3 and 4: Visual Inspection

As a preliminary step, be sure to perform visual check of the items that support proper function of the engine referring to "Visual Inspection".

Step 5: Trouble Symptom Confirmation

Based on information obtained in "Step 1: Customer Complaint Analysis: " and "Step 2: DTC / Freeze Frame Data Check, Record and Clearance: ", confirm trouble symptoms. Also, reconfirm DTC according to "DTC Confirmation Procedure" described in each DTC diag. flow.

Step 6 and 7: Rechecking and Record of DTC / Freeze Frame Data

Refer to "DTC Check" for checking procedure.

Step 8: Engine Basic Inspection and Engine Symptom Diagnosis

Perform basic engine check according to "Engine Basic Inspection" first. When the end of the flow has been reached, check the parts of the system suspected as a possible cause referring to "Engine Symptom Diagnosis" and based on symptoms appearing on the vehicle (symptoms obtained through steps of customer complaint analysis, trouble symptom confirmation and/or basic engine check) and repair or replace faulty parts, if any.

Step 9: Troubleshooting for DTC (See each DTC Diag. Flow)

Based on the DTC indicated in Step 6 or 7 and referring to the applicable DTC diag. flow, locate the cause of the trouble, namely in a sensor, switch, wire harness, connector, actuator, ECM or other part and repair or replace faulty parts.

Step 10: Intermittent Problems Check

Check parts where an intermittent trouble is easy to occur (e.g., wire harness, connector, etc.), referring to "Intermittent and Poor Connection Inspection in Section 00" and related circuit of DTC recorded in Step 2.


Step 11: Final Confirmation Test

Confirm that the problem symptom has gone and the engine is free from any abnormal conditions. If what has been repaired is related to the DTC, clear the DTC once, perform DTC confirmation procedure and confirm that no DTC is indicated.

Malfunction Indicator Lamp (MIL) Check

S7RW0C1104002

- 1) Turn ON ignition switch (with engine at stop) and check that MIL (1) lights.
If MIL does not light up (or MIL dims) but engine can be starting, go to "MIL Does Not Come ON with Ignition Switch ON and Engine Stop (but Engine Can Be Started)" for troubleshooting.
If MIL does not light with ignition switch ON and engine does not start though it is cranked up, go to "ECM Power and Ground Circuit Check".
- 2) Start engine and check that MIL turns OFF.
If MIL remains ON and no DTC is stored in ECM, go to "MIL Remains ON after Engine Starts" for troubleshooting.



I4RS0A110012-01

DTC Check

S7RW0C1104003


NOTE

- There are two types of OBD system depending on the vehicle specification. For identification, refer to "Precaution on On-Board Diagnostic (OBD) System".
- The MIL is turned on when the ECM and/or TCM detect malfunction(s). Each ECM and TCM stores diagnostic information as the diagnostic trouble code (DTC) in its memory and outputs the DTC to the scan tool. Therefore, check both of the ECM and TCM for any DTC with the scan tool because the DTC stored in ECM and TCM is not read and displayed at a time. However, each of the ECM and TCM needs not to be checked with the generic scan tool because the DTC stored in ECM and TCM is read and displayed at a time.

- 1) Prepare CAN communication OBD generic scan tool or SUZUKI scan tool.

Special tool**(A): SUZUKI scan tool (SUZUKI-SDT)**

- 2) With ignition switch OFF, connect it to DLC (1) located on underside of instrument panel at driver's seat side.



15RW0C110011-01

- 3) Turn ignition switch ON and confirm that MIL lights.
- 4) Read DTC and freeze frame data according to instructions displayed on scan tool and print them or write them down. Refer to scan tool operator's manual for details.
If communication between scan tool and ECM is not possible, go to "Troubleshooting for Communication Error with Scan Tool Using CAN".
- 5) After completing the check, turn ignition switch off and disconnect scan tool from DLC.

DTC Clearance

S7RW0C1104004

- 1) With ignition switch OFF, connect CAN communication OBD generic scan tool or SUZUKI scan tool to DLC.

- 2) Turn ignition switch ON.

- 3) Erase DTC and pending DTC according to instructions displayed on scan tool. Freeze frame data is cleared with the DTC. Refer to scan tool operator's manual for details.
If communication between scan tool and ECM is not possible, go to "Troubleshooting for Communication Error with Scan Tool Using CAN".

- 4) After completing the clearance, turn ignition switch off and disconnect scan tool from DLC.

NOTE

DTC and freeze frame data stored in ECM memory are also cleared in the following cases. Be careful not to clear them before keeping their record.

- When power to ECM is cut off (by disconnecting battery cable, removing fuse or disconnecting ECM (connectors)).
- When the same malfunction (DTC) is not detected again during 40 engine warm-up cycles (refer to Warm-Up Cycle of "On-Board Diagnostic System Description").

Troubleshooting for Communication Error with Scan Tool Using CAN


S7RW0C1104005

Perform this troubleshooting when it is not possible to communicate between scan tool and ECM/TCM.

NOTE

- When performing this troubleshooting, be sure to have full understanding of "Precaution on CAN Troubleshooting" and observe it.
- It may be possible that CAN system has trouble because of fuse blown or low battery voltage. Before troubleshooting, check to make sure that fuse, battery voltage and generator status are normal.
- When disconnecting each control module connector in this troubleshooting, various DTCs will be detected. Be sure to clear DTCs in the following control modules after completing this troubleshooting.
 - ECM
 - BCM
 - TCM
 - Keyless start control module
 - 4WD control module
 - HVAC control module (Auto A/C model)
 - P/S control module

Wiring Diagram



I6RW0C110010-02



[A]: DLC (viewed from terminal side)	2. ECM
[B]: ABS control module connector (viewed from terminal side)	3. ABS control module
[C]: ECM connector (viewed from harness side)	4. BCM
[D]: TCM connector (viewed from harness side)	5. Keyless start control module
[E]: BCM connector (viewed from harness side)	6. 4WD control module
[F]: 4WD control module connector (viewed from harness side)	7. Combination meter
[G]: Combination meter connector (viewed from terminal side)	8. CAN junction connector
[H]: Keyless start control module connector (viewed from harness side)	9. DLC
1. TCM	

Trouble area

- Scan tool
- Connector related to CAN line (included in DLC)
- CAN line
- Power or ground circuit of DLC
- Control module communicated by CAN
 - ECM

- TCM
- ABS control module
- BCM
- Combination meter
- Keyless start control module
- 4WD control module
- Power or ground circuit of control module communicated by CAN

Troubleshooting

Step	Action	Yes	No
1	Scan tool check 1) Disconnect scan tool from DLC with ignition switch turned OFF. 2) Check for proper connection to all terminals of scan tool connector. 3) If OK, connect scan tool to another vehicle of this type with ignition switch turned OFF. 4) Check communication between scan tool and ECM by DTC check in ECM. <i>Is it possible to check DTC in ECM?</i>	Go to Step 2.	Scan tool faulty. Refer to its operator's manual.
2	DLC power circuit check 1) Check for proper connection to all DLC (1) terminals with ignition switch turned OFF. 2) If OK, measure voltage between +B terminal (2) of DLC and vehicle body ground with ignition switch turned to ON position.  I7RW01110096-01 <i>Is voltage 10 – 14 V?</i>	Go to Step 3.	Repair power circuit.
3	DLC ground circuit check 1) Ignition switch turn to OFF position. 2) Check DLC (1) ground circuits as follows. • Measure resistance between signal ground terminal (2) of DLC and vehicle body ground. • Measure resistance between body ground terminal (3) of DLC and vehicle body ground.  I7RW01110097-01 <i>Is resistance 1 Ω or less?</i>	Go to Step 4.	Repair ground circuit(s).

1A-32 Engine General Information and Diagnosis:

Step	Action	Yes	No
4	DTC Check 1) Turn ignition switch to OFF position. 2) Connect scan tool to DLC. 3) Check DTC in the following control modules that communicate with scan tool by K-line. • BCM • Keyless start control module • 4WD control module <i>Is there any DTC other than CAN-DTC?</i>	Go to applicable troubleshooting of DTC other than CAN-DTC.	Go to Step 5.
5	CAN line check between DLC and BCM 1) Turn ignition switch to OFF position. 2) Disconnect BCM connector from BCM. 3) Check for proper connection to all terminals of BCM connector. 4) If OK, check CAN lines between DLC and BCM connector for open, short to power circuit, short to ground circuit, short to other CAN line and high resistance. <i>Are CAN lines between DLC and BCM connector in good condition?</i>	Go to Step 6.	Repair CAN line.
6	Control module connector check 1) Turn ignition switch to OFF position. 2) Disconnect all the following control module connectors. • Control modules communicated by CAN – ECM – TCM – ABS control module – BCM – Combination meter – Keyless start control module – 4WD control module 3) Check for proper connection to each CAN line terminal of all control module (communicated by CAN) connectors. 4) If OK, connect connectors of all control module/sensor communicated by CAN securely. 5) Check communication between scan tool and ECM/TCM by DTC check in ECM/TCM. <i>Is it possible to check DTC in ECM and TCM?</i>	Intermittent trouble. Check for intermittent referring to "Intermittent and Poor Connection Inspection in Section 00".	Go to Step 7.

Step	Action	Yes	No
7	CAN line check 1) Turn ignition switch to OFF position. 2) Disconnect connectors of all control module communicated by CAN. 3) Check all the following CAN lines for open, short to power circuit, short to ground circuit, short to other CAN line and high resistance. • Between BCM connector and ABS control module connector • Between ABS control module connector and ECM connector • Between ECM connector and TCM connector • Between BCM connector and keyless start control module connector • Between combination meter connector and 4WD control module connector • Between BCM connector and combination meter connector <i>Are all CAN lines in good condition?</i>	Go to Step 8.	Repair CAN line.
8	Communication check between scan tool and ECM 1) Turn ignition switch to OFF position. 2) Connect ECM, BCM, ABS control module and combination meter connectors. 3) Check communication between scan tool and ECM by DTC check in ECM. <i>Is it possible to check DTC in ECM?</i>	A/T model: Go to Step 9. M/T model: Substitute a known-good ECM and recheck.	Go to Step 4 through Step 11 of "Troubleshooting for CAN-DTC".
9	Communication check between scan tool and TCM 1) Turn ignition switch to OFF position. 2) Connect TCM connectors. 3) Check communication between scan tool and TCM by DTC check in TCM. <i>Is it possible to check DTC in TCM?</i>	Identify malfunction control module by performing Step 13 through Step 14 of "Troubleshooting for CAN-DTC".	Go to Step 10.
10	Internal circuit check in ECM 1) Turn ignition switch to OFF position and then disconnect negative (–) cable at battery. 2) Disconnect TCM connectors. 3) Measure resistance between the followings • Between CAN High terminal on DLC and "C06-17" terminal on TCM connector • Between CAN Low terminal on DLC and "C06-7" terminal on TCM connector <i>Is each resistance 0 – 1 Ω?</i>	Substitute a known-good TCM and recheck.	Substitute a known-good ECM and recheck.

DTC Table

NOTE

- There are two types of OBD system depending on the vehicle specification.
For non-Euro-OBD model, refer to “Precaution on On-Board Diagnostic (OBD) System”.
- For non-Euro-OBD model, some of DTC No. with delta (Δ) mark in the following table can not be detected by ECM depending on vehicle specification and local regulation.
- With the CAN communication generic scan tool, only star (*) marked DTC No. in the following table can be read.
- When DTC P0300 / P0301 / P0302 / P0303 / P0304 is detected, MIL blinks or lights up according to detecting condition. For details, refer to “DTC P0300 / P0301 / P0302 / P0303 / P0304: Random Misfire Detected / Cylinder 1 / Cylinder 2 / Cylinder 3 / Cylinder 4 Misfire Detected”.

DTC No.	Detecting item	Detecting condition (DTC will set when detecting:)	DTC	MIL
* Δ P0030	HO2S Heater Control Circuit (Bank-1 Sensor-1)	Impedance of A/F sensor element is higher than 50 Ω for 20 sec. even though A/F sensor heater is turned ON	2 driving cycles	2 driving cycles
*P0031	HO2S Heater Control Circuit Low (Bank-1 Sensor-1)	Heater control circuit voltage of A/F sensor is lower than specification for more than specified time even though control duty ratio of A/F sensor heater is less than 90% with engine running. (Heater control duty pulse is not detected in its circuit of ECM)	2 driving cycles	2 driving cycles
*P0032	HO2S Heater Control Circuit High (Bank-1 Sensor-1)	Heater control circuit voltage of A/F sensor is higher than specification for more than specified time even though control duty ratio of A/F sensor heater is more than 10% with engine running. (Heater control duty pulse is not detected in its circuit of ECM)	2 driving cycles	2 driving cycles
*P0037	HO2S Heater Control Circuit Low (Bank-1 Sensor-2)	HO2S circuit voltage is lower than specification for specified time even though control duty ratio of HO2S heater is less than 75% with engine running. (Heater control duty pulse is not detected in its monitor signal)	2 driving cycles	2 driving cycles
*P0038	HO2S Heater Control Circuit High (Bank-1 Sensor-2)	HO2S circuit voltage is higher than specification for specified time even though control duty ratio of HO2S heater is more than 25% with engine running. (Heater control duty pulse is not detected in its monitor signal)	2 driving cycles	2 driving cycles
* Δ P0101	Mass or Volume Air Flow Circuit Range / Performance	MAF sensor signal is higher or lower than estimated range based on engine speed and throttle angle for 7 sec.	2 driving cycles	2 driving cycles
*P0102	Mass or Volume Air Flow Circuit Low Input	Output voltage of MAF sensor is lower than 0.15 V for 5 sec.	1 driving cycle	1 driving cycle
*P0103	Mass or Volume Air Flow Circuit High Input	Output voltage of MAF sensor is higher than 4.85 V for 5 sec.	1 driving cycle	1 driving cycle
* Δ P0111	Intake Air Temperature Sensor 1 Circuit Range / Performance	Variation of IAT sensor signal is less than 15 V for 10 minutes even though ECT reaches 70 °C (158 °F).	2 driving cycles	2 driving cycles
*P0112	Intake Air Temperature Sensor 1 Circuit Low	Circuit voltage of IAT sensor is lower than 0.15 V for 5 sec.	1 driving cycle	1 driving cycle
*P0113	Intake Air Temperature Sensor 1 Circuit High	Circuit voltage of IAT sensor is higher than 4.85 V for 5 sec.	1 driving cycle	1 driving cycle
* Δ P0116	Engine Coolant Temperature Circuit Range / Performance	ECT sensor values is less than 10 °C (50 °F) while engine is running under more than specified engine load (more than 1000 rpm) after 2 to 1116 min. (depending on ECT at engine start) elapsed from engine start.	2 driving cycles	2 driving cycles
*P0117	Engine Coolant Temperature Circuit Low	Circuit voltage of ECT sensor is lower than 0.15 V for 5 sec.	1 driving cycle	1 driving cycle
*P0118	Engine Coolant Temperature Circuit High	Circuit voltage of ECT sensor is higher than 4.85 V for 5 sec.	1 driving cycle	1 driving cycle

DTC No.	Detecting item	Detecting condition (DTC will set when detecting:)	DTC	MIL
*P0122	Throttle/Pedal Position Sensor/Switch "A" (Main) Circuit Low	Output voltage of TP sensor (main) is lower than 0.3 V.	1 driving cycle	1 driving cycle
*P0123	Throttle/Pedal Position Sensor/Switch "A" (Main) Circuit High	Output voltage of TP sensor (main) is higher than 4.6 V.	1 driving cycle	1 driving cycle
*P0131	O2 Sensor (HO2S) Circuit Low Voltage (Bank-1 Sensor-1)	A/F sensor terminal voltage is lower than 1.8 V or A/F sensor output current is lower than -5 mA for 5 sec. with engine running.	2 driving cycles	2 driving cycles
*P0132	O2 Sensor (HO2S) Circuit High Voltage (Bank-1 Sensor-1)	A/F sensor terminal voltage is higher than 3.8 V or A/F sensor output current is higher than 5 mA for 5 sec. with engine running.	2 driving cycles	2 driving cycles
*△P0133	O2 Sensor (HO2S) Circuit Slow Response (Bank-1 Sensor-1)	Ratio between integrated value of A/F sensor output variation and integrated value of short term fuel trim variation is more than specification while vehicle is running.	2 driving cycles	2 driving cycles
*△P0134	O2 Sensor (HO2S) No Activity Detected (Bank-1 Sensor-1)	Impedance of A/F sensor element is higher than 500 Ω for 15 sec. even though A/F sensor heater is turned ON for specified time with engine running.	2 driving cycles	2 driving cycles
*△P0137	O2 Sensor (HO2S) Circuit Low Voltage (Bank-1 Sensor-2)	HO2S voltage is lower than 0.4 V for specified time while vehicle is driving with high engine load (high speed). And HO2S max. voltage minus HO2S min. voltage is lower than 0.2 V.	2 driving cycles	2 driving cycles
*△P0138	O2 Sensor (HO2S) Circuit High Voltage (Bank-1 Sensor-2)	HO2S voltage is higher than 0.85 V for specified time while vehicle is driving with high engine load (high speed). And HO2S max. voltage minus HO2S min. voltage is lower than 0.2 V.	2 driving cycles	2 driving cycles
*P0140	O2 Sensor Circuit No Activity Detected (Bank-1 Sensor-2)	Output voltage of HO2S is higher than 4.5 V for 0.5 sec.	2 driving cycles	2 driving cycles
*△P0171	Fuel System Too Lean	Total fuel trim (short term fuel trim + long term fuel trim) is higher than specified range for 10 sec. 3 times.	2 driving cycles	2 driving cycles
*△P0172	Fuel System Too Rich	Total fuel trim (short term fuel trim + long term fuel trim) is lower than specified range for 10 sec. 3 times.	2 driving cycles	2 driving cycles
*P0222	Throttle/Pedal Position Sensor/Switch "B" Circuit Low	Output voltage of TP sensor (sub) is lower than 0.74 V.	1 driving cycle	1 driving cycle
*P0223	Throttle/Pedal Position Sensor/Switch "B" Circuit High	Output voltage of TP sensor (sub) is higher than 4.74 V.	1 driving cycle	1 driving cycle
*△P0300	Random/Multiple Cylinder Misfire Detected	- Misfire, which causes catalyst to overheat during 200 engine revolutions, is detected at 2 or more cylinders. (MIL blinks as long as this misfire occurs continuously.) - Misfire, which affects exhaust emission adversely during 1000 engine revolution, is detected at 2 or more cylinders.	2 driving cycles	2 driving cycles
*△P0301 / *△P0302 / △*P0303 / *△P0304	Cylinder 1,2,3,4 Misfire Detected	- Misfire, which causes catalyst to overheat during 200 engine revolutions, is detected at 1 cylinder. (MIL blinks as long as this misfire occurs continuously.) - Misfire, which affects exhaust emission adversely during 1000 engine revolution, is detected at 1 cylinder.	2 driving cycles	2 driving cycles
*P0327	Knock Sensor 1 Circuit Low	Output voltage of knock sensor is lower than 1.23 V for 5 sec.	1 driving cycle	1 driving cycle

1A-36 Engine General Information and Diagnosis:

DTC No.	Detecting item	Detecting condition (DTC will set when detecting:)	DTC	MIL
✎ *P0328	Knock Sensor 1 Circuit High	Output voltage of knock sensor is higher than 3.91 V for 5 sec.	1 driving cycle	1 driving cycle
✎ *P0335	Crankshaft Position (CKP) Sensor "A" Circuit	CKP sensor signal is not detected for 2 sec. even though starter is operated.	1 driving cycle	1 driving cycle
✎ *P0340	Camshaft Position (CMP) Sensor "A" Circuit	If either of the following condition is fulfilled: • CMP sensor pulse is lower than 20 pulses per crankshaft 8 revolutions. • CMP sensor pulse is higher than 28 pulses per crankshaft 8 revolutions. • CMP sensor pulse is lower than 20 pulses per crankshaft 8 revolutions from engine start.	1 driving cycle	1 driving cycle
✎ *△P0420	Catalyst System Efficiency below Threshold	Ratio of integrated value of HO2S output variation per integrated value of A/F sensor output variation is more than specification while vehicle is running after warmed up.	2 driving cycles	2 driving cycles
✎ *P0443	Evaporative Emission System Purge Control Valve Circuit	• Monitor signal of EVAP canister purge valve is not varied for 5 sec. even though EVAP canister purge valve control duty is between 10% and 90%. • Monitor signal of EVAP canister purge valve is lower than specified voltage for 5 sec. even though EVAP canister purge valve control duty is 0%.	2 driving cycles	2 driving cycles
✎ P0462	Fuel Level Sensor "A" Circuit Low	Circuit voltage of fuel level sensor is lower than 0.11 V for 5 sec. with engine running.	1 driving cycle	Not applicable
✎ P0463	Fuel Level Sensor "A" Circuit High	Circuit voltage of fuel level sensor is lower than 4.77 V for more than 5 sec. with engine running.	1 driving cycle	Not applicable
✎ *P0480	Fan 1 Control Circuit	Monitor signal of radiator cooling fan relay No.1 is lower than specified voltage for 5 sec. even though radiator cooling fan relay No.1 is OFF.	1 driving cycle	1 driving cycle
✎ *P0481	Fan 2 Control Circuit	Monitor signal of A/C condenser cooling fan relay is lower than specified voltage for 5 sec. even though A/C switch is ON and A/C condenser fan is OFF.	2 driving cycles	2 driving cycles
✎ *P0500	Vehicle Speed Sensor "A" (VSS)	• Vehicle speed signal is lower than 2 km/h (1.2 mph) for 4 sec. while fuel shuts off at deceleration below 3,600 rpm. • Vehicle speed signal is lower than 2 km/h (1.2 mph) for 4 sec. even though engine is running at D-Range with more than 3,600 rpm (A/T model).	2 driving cycles	2 driving cycles
✎ P0504	Brake Switch "A"/"B" Correlation	If either of the following condition is fulfilled: • Brake pedal switch signal (ON) and brake light switch signal (ON) are detected at a time. • Brake pedal switch signal (OFF) and brake light switch signal (OFF) are detected at a time.	1 driving cycle	Not applicable
✎ P0532	A/C Refrigerant Pressure Sensor "A" Circuit Low	Output voltage of A/C refrigerant pressure sensor is lower than 0.2 V for 5 sec.	1 driving cycle	Not applicable
✎ P0533	A/C Refrigerant Pressure Sensor "A" Circuit High	Output voltage of A/C refrigerant pressure sensor is higher than 4.93 V for 5 sec.	1 driving cycle	Not applicable
✎ *P0601	Internal Control Module Memory Check Sum Error	Data write error or check sum error.	1 driving cycle	1 driving cycle
✎ P0602	Control Module Programming Error	Data programming error	1 driving cycle	Not applicable
✎ *P0607	Control Module Performance	ECM internal processor error.	1 driving cycle	1 driving cycle
✎ *△P0616	Starter Relay Circuit Low	Starter switch signal is not detected even though engine speed is 500 rpm or more.	2 driving cycles	2 driving cycles
✎ *P0617	Starter Relay Circuit High	Starter switch signal is detected for 180 sec.	2 driving cycles	2 driving cycles

DTC No.	Detecting item	Detecting condition (DTC will set when detecting:)	DTC	MIL
☞ P0660	Intake Manifold Tuning Valve Control Circuit/ Open	Monitor signal of IMT valve is different from command signal for 5 sec.	1 driving cycle	Not applicable
☞ P0662	Intake Manifold Tuning Valve Control Circuit High	Circuit voltage of IMT valve is higher than specification for 5 sec. when engine revolution is 3,000 rpm or less.	1 driving cycle	Not applicable
☞ *P1510	ECM Back-Up Power Supply Malfunction	Backup power voltage of internal circuit is lower than specified voltage for 5 sec.	1 driving cycle	1 driving cycle
☞ *P2101	Throttle Actuator Control Motor Circuit Range / Performance	Throttle actuator control circuit is higher than specified current or temperature for 0.5 sec.	1 driving cycle	1 driving cycle
☞ *P2102	Throttle Actuator Control Motor Circuit Low	Power supply voltage of throttle actuator control relay is lower than 5 V for 0.5 sec. even though throttle actuator control relay turned on.	1 driving cycle	1 driving cycle
☞ *P2103	Throttle Actuator Control Motor Circuit High	Power supply voltage of throttle actuator control relay is higher than 5 V for 0.6 sec. even though throttle actuator control relay is turned off.	1 driving cycle	1 driving cycle
☞ *P2111	Throttle Actuator Control System - Stuck Open	Throttle position does not change by 2° during diagnosing throttle valve at ignition switch turned OFF.	1 driving cycle	1 driving cycle
☞ *P2119	Throttle Actuator Control Throttle Body Range / Performance	Difference between the measured (actual) throttle valve opening angle and the target throttle valve opening angle which is calculated based on accelerator pedal opening angle and engine condition is more than specification for specified time.	1 driving cycle	1 driving cycle
☞ *P2122	Throttle/Pedal Position Sensor/Switch "D" Circuit Low Input	Output voltage of APP sensor (main) is lower than 0.45 V for 0.5 sec.	1 driving cycle	1 driving cycle
☞ *P2123	Throttle/Pedal Position Sensor/Switch "D" Circuit High Input	Output voltage of APP sensor (main) is higher than 4.8 V for 0.5 sec.	1 driving cycle	1 driving cycle
☞ *P2127	Throttle/Pedal Position Sensor/Switch "E" Circuit Low Input	Output voltage of APP sensor (sub) is lower than 0.23 V for 0.5 sec.	1 driving cycle	1 driving cycle
☞ *P2128	Throttle/Pedal Position Sensor/Switch "E" Circuit High Input	Output voltage of APP sensor (sub) is higher than 2.4 V for 0.5 sec.	1 driving cycle	1 driving cycle
☞ *P2135	Throttle/Pedal Position Sensor/Switch "A" / "B" Voltage Correlation	Difference between the opening angle based on TP sensor (main) and the opening angle based on TP sensor (sub) is more than specification for 0.2 sec.	1 driving cycle	1 driving cycle
☞ *P2138	Throttle/Pedal Position Sensor/Switch "D" / "E" Voltage Correlation	Difference between the opening angle based on APP sensor (main) and the opening angle based on APP sensor (sub) is more than specification for 0.5 sec.	1 driving cycle	1 driving cycle
☞ *P2195	O2 Sensor Signal Stuck Lean (Bank-1 Sensor-1)	A/F sensor signal is higher than 1.15 for 10 sec. even though HO2S voltage is higher than 0.2 V while vehicle is running after warmed up.	2 driving cycles	2 driving cycles
☞ *P2196	O2 Sensor Signal Stuck Rich (Bank-1 Sensor-1)	A/F sensor signal is lower than 0.85 for 10 sec. even though HO2S voltage is lower than 0.7 V while vehicle is running after warmed up.	2 driving cycles	2 driving cycles
☞ *P2227	Barometric Pressure Circuit Performance	Difference between barometric pressure value and estimated barometric pressure value (according to engine load rate and engine speed) is higher than 25 kPa for 1.25 sec.	2 driving cycles	2 driving cycles
☞ *P2228	Barometric Pressure Circuit Low	Output signal of barometric pressure sensor is lower than 1.95 V for 0.5 sec.	1 driving cycle	1 driving cycle
☞ *P2229	Barometric Pressure Circuit High	Output signal of barometric pressure sensor is higher than 4.7 V for 0.5 sec.	1 driving cycle	1 driving cycle

1A-38 Engine General Information and Diagnosis:

DTC No.	Detecting item	Detecting condition (DTC will set when detecting:)	DTC	MIL
U0073	Control Module Communication Bus Off	Transmission error that is inconsistent between transmission data and transmission monitor (CAN bus monitor) data is detected more than 30 times continuously.	1 driving cycle	Not applicable
*U0101	ECM Lost Communication With TCM	Reception error of communication data for TCM is detected for longer than specified time.	1 driving cycle	1 driving cycle
*U0121	ECM Lost Communication With ABS / ESP® Control Module	Reception error of communication data for ABS / ESP® control module assembly is detected for longer than specified time.	1 driving cycle	1 driving cycle
U0140	ECM Lost Communication With BCM	Reception error of communication data for BCM is detected for longer than specified time.	1 driving cycle	Not applicable
P1614	Transponder response error	Refer to "DTC Table in Section 10C".	1 driving cycle	Not applicable
P1615	ID code does not registered (vehicle equipped with keyless start system only)	Refer to "DTC Table in Section 10C".	1 driving cycle	Not applicable
P1616	Different registration ID codes (vehicle equipped with keyless start system only)	Refer to "DTC Table in Section 10C".	1 driving cycle	Not applicable
P1618	CAN communication error (reception error for keyless start control module) (vehicle equipped with keyless start system only)	Refer to "DTC Table in Section 10C".	1 driving cycle	Not applicable
P1621	Immobilizer communication line error	Refer to "DTC Table in Section 10C".	1 driving cycle	Not applicable
P1622	EEPROM error	Refer to "DTC Table in Section 10C".	1 driving cycle	Not applicable
P1623	Unregistered transponder	Refer to "DTC Table in Section 10C".	1 driving cycle	Not applicable
P1625	Immobilizer antenna error	Refer to "DTC Table in Section 10C".	1 driving cycle	Not applicable
P1636	Immobilizer information registration failure	Refer to "DTC Table in Section 10C".	1 driving cycle	Not applicable
P1638	Immobilizer information mismatched	Refer to "DTC Table in Section 10C".	1 driving cycle	Not applicable

For Vehicle Equipped with A/T

NOTE

There are two types of OBD system depending on the vehicle specification.
For identification, refer to "Precaution on On-Board Diagnostic (OBD) System".

When using CAN communication OBD generic scan tool, not only the previous star (*) marked ECM DTC(s) but also the following DTC(s) is displayed on CAN communication OBD generic scan tool simultaneously.

DTC No.	Detecting item	Detecting condition (DTC will set when detecting:)	Driving cycle when MIL lighted
P0602	Control Module Programming Error	Refer to "DTC Table in Section 5A".	
P0705	Transmission Range Sensor Circuit Malfunction (P R N D L Input)		
P0707	Transmission Range Sensor Circuit Low		
P0711	Transmission Fluid Temperature Sensor "A" Circuit Range/ Performance		
P0712	Transmission Fluid Temperature Sensor "A" Circuit Low		
P0713	Transmission Fluid Temperature Sensor "A" Circuit High		
P0717	Input Speed Sensor "A" Circuit No Signal		
P0722	Output Speed Sensor Circuit No Signal		
P0741	Torque Converter Clutch Circuit Performance or Stuck Off		
P0742	Torque Converter Clutch Circuit Stuck On		
P0751	Shift Solenoid "A" Performance or Stuck Off		
P0752	Shift Solenoid "A" Stuck On		
P0756	Shift Solenoid "B" Performance or Stuck Off		
P0757	Shift Solenoid "B" Stuck On		
P0961	Pressure Control Solenoid "A" Control Circuit Range/ Performance		
P0962	Pressure Control Solenoid "A" Control Circuit Low		
P0963	Pressure Control Solenoid "A" Control Circuit High		
P0973	Shift Solenoid "A" Control Circuit Low		
P0974	Shift Solenoid "A" Control Circuit High		
P0976	Shift Solenoid "B" Control Circuit Low		
P0977	Shift Solenoid "B" Control Circuit High		
P1702	Internal Control Module Memory Check Sum Error		
P1723	Range Select Switch Malfunction		
P2763	Torque Converter Clutch Pressure Control Solenoid Control Circuit High		
P2764	Torque Converter Clutch Pressure Control Solenoid Control Circuit Low		
U0073	Control Module Communication Bus Off		
U0100	Lost Communication With ECM / PCM "A"		

Fail-Safe Table

When any of the following DTCs is detected, ECM enters fail-safe mode as long as malfunction continues to exist but that mode is canceled when ECM detects normal condition after that.

DTC No.	Detected item	Fail-safe operation
P0030	HO2S Heater Control Circuit (Bank-1 Sensor-1)	ECM stops air/fuel ratio feed back (closed loop) control.
P0031	HO2S Heater Control Circuit Low (Bank-1 Sensor-1)	
P0032	HO2S Heater Control Circuit High (Bank-1 Sensor-1)	
P0037	HO2S Heater Control Circuit Low (Bank-1 Sensor-2)	ECM stops HO2S heater control.
P0038	HO2S Heater Control Circuit High (Bank-1 Sensor-2)	
P0102	Mass or Volume Air Flow Circuit Low Input	- ECM calculates intake air volume according to engine load and engine speed. - ECM stops EVAP canister purge valve control.
P0103	Mass or Volume Air Flow Circuit High Input	
P0112	Intake Air Temperature Sensor 1 Circuit Low	- ECM controls actuators assuming that intake air temperature is 20 °C (68 °F). - ECM stops IAC feedback control. - ECM stops air/fuel ratio feed back (closed loop) control.
P0113	Intake Air Temperature Sensor 1 Circuit High	
P0117	Engine Coolant Temperature Circuit Low	- ECM controls actuators assuming that engine coolant temperature is 80 °C (176 °F). - ECM operates radiator cooling fan. (high speed) - ECM operates condenser fan. - ECM stops air/fuel ratio feed back (closed loop) control. - ECM stops IAC feedback control. - ECM stops A/C control.
P0118	Engine Coolant Temperature Circuit High	
P0122	Throttle/Pedal Position Sensor/Switch "A" (Main) Circuit Low	- ECM turns off throttle actuator control relay and throttle valve is fixed at the opening of about 7° from its completely closed position (default opening). - ECM controls fuel cut at specified engine speed. - ECM stops air/fuel ratio feed back (closed loop) control.
P0123	Throttle/Pedal Position Sensor/Switch "A" (Main) Circuit High	
P0131	O2 Sensor (HO2S) Circuit Low Voltage (Bank-1 Sensor-1)	- ECM stops A/F sensor heater control. - ECM stops EVAP canister purge valve control. - ECM stops air/fuel ratio feed back (closed loop) control.
P0132	O2 Sensor (HO2S) Circuit High Voltage (Bank-1 Sensor-1)	
P0134	O2 Sensor (HO2S) No Activity Detected (Bank-1 Sensor-1)	
P0137	O2 Sensor (HO2S) Circuit Low Voltage (Bank-1 Sensor-2)	ECM stops HO2S feed back control.
P0138	O2 Sensor (HO2S) Circuit High Voltage (Bank-1 Sensor-2)	
P0140	O2 Sensor (HO2S) Circuit No Activity Detected (Sensor-2, Bank-1)	
P0171	Fuel System Too Lean	ECM stops EVAP canister purge valve control.
P0172	Fuel System Too Rich	
P0222	Throttle/Pedal Position Sensor/Switch "B" Circuit Low	- ECM turns off throttle actuator control relay and throttle valve is fixed at the opening of about 7° from its completely closed position. (default opening). - ECM controls fuel cut at specified engine speed. - ECM stops air/fuel ratio feed back (closed loop) control.
P0223	Throttle/Pedal Position Sensor/Switch "B" Circuit High	

DTC No.	Detected item	Fail-safe operation
☞ P0327	Knock Sensor 1 Circuit Low	- ECM stops knock control. - ECM controls fuel cut at specified engine speed.
☞ P0328	Knock Sensor 1 Circuit High	
☞ P0335	Crankshaft Position (CKP) Sensor "A" Circuit	- ECM controls ignition timing. - ECM controls fuel cut at specified engine speed.
☞ P0340	Camshaft Position (CMP) Sensor "A" Circuit	- ECM controls ignition timing. - ECM controls fuel cut at specified engine speed. - ECM stops knock control.
☞ P0500	Vehicle Speed Sensor "A" (VSS)	- ECM controls actuators assuming that vehicle speed is 0 km/h (0 mph). - ECM stops IAC feedback control.
☞ P0532	A/C Refrigerant Pressure Sensor "A" Circuit Low	ECM stops A/C control.
☞ P0533	A/C Refrigerant Pressure Sensor "A" Circuit High	
☞ P0607	Control Module Performance	- ECM turns off throttle actuator control relay and throttle valve is fixed at the opening of about 7° from its completely closed position (default opening). - ECM controls fuel cut at specified engine speed.
☞ P0660	Intake Manifold Tuning Valve Control Circuit/Open	ECM stops IMT valve control.
☞ P0662	Intake Manifold Tuning Valve Control Circuit High	
☞ P2101	Throttle Actuator Control Motor Circuit Range / Performance	- ECM turns off throttle actuator control relay and throttle valve is fixed at the opening of about 7° from its completely closed position. (default opening). - ECM controls fuel cut at specified engine speed.
☞ P2102	Throttle Actuator Control Motor Circuit Low	
☞ P2103	Throttle Actuator Control Motor Circuit High	ECM controls fuel cut at specified engine speed.
☞ P2111	Throttle Actuator Control System - Stuck Open	- ECM turns off throttle actuator control relay and throttle valve is fixed at the opening of about 7° from its completely closed position (default opening). - ECM controls fuel cut at specified engine speed.
☞ P2119	Throttle Actuator Control Throttle Body Range / Performance	- ECM turns off throttle actuator control relay and throttle valve is fixed at the opening of about 7° from its completely closed position (default opening). - ECM controls fuel cut at specified engine speed.
☞ P2122	Throttle/Pedal Position Sensor/Switch "D" Circuit Low Input	Lower upper limit of accelerator demand target throttle opening.
☞ P2123	Throttle/Pedal Position Sensor/Switch "D" Circuit High Input	
☞ P2127	Throttle/Pedal Position Sensor/Switch "E" Circuit Low Input	
☞ P2128	Throttle/Pedal Position Sensor/Switch "E" Circuit High Input	
☞ P2135	Throttle/Pedal Position Sensor/Switch "A" / "B" Voltage Correlation	- ECM turns off throttle actuator control relay and throttle valve is fixed at the opening of about 7° from its completely closed position (default opening). - ECM controls fuel cut at specified engine speed.
☞ P2138	Throttle/Pedal Position Sensor/Switch "D" / "E" Voltage Correlation	

1A-42 Engine General Information and Diagnosis:

DTC No.	Detected item	Fail-safe operation
P2228	Barometric Pressure Circuit Low	ECM controls actuators assuming that barometric pressure is 101 kPa (760 mmHg).
P2229	Barometric Pressure Circuit High	

Scan Tool Data

S7RW0C1104008

As the data values are standard values estimated on the basis of values obtained from the normally operating vehicles by using a scan tool, use them as reference values. Even when the vehicle is in good condition, there may be cases where the checked value does not fall within each specified data range. Therefore, judgment as abnormal should not be made by checking with these data alone.

Also, conditions that can be checked by the scan tool are those detected by ECM and output from ECM as commands and there may be cases where the engine or actuator is not operating (in the condition) as indicated by the scan tool. Be sure to use the timing light to check the ignition timing. (Refer to "Ignition Timing Inspection in Section 1H".)

NOTE

- There are two types of OBD system depending on the vehicle specification. For identification, refer to "Precaution on On-Board Diagnostic (OBD) System".
- With the generic scan tool, only star (*) marked data in the following table can be read.
- When checking the data with the engine running at idle or racing, be sure to shift M/T gear to the neutral gear position and A/T gear to the "Park" position and pull the parking brake fully. Also, if nothing or "no load" is indicated, turn OFF A/C, all electric loads, P/S and all the other necessary switches.

	Scan tool data	Vehicle condition	Normal condition / reference values
*	COOLANT TEMP (ENGINE COOLANT TEMP.)	At specified idle speed after warming up	80 – 100 °C, 176 – 212 °F
*	INTAKE AIR TEMP.	At specified idle speed after warming up	–5 °C (23 °F) + environmental temp. to 40 °C (104 °F) + environmental temp.
*	ENGINE SPEED	It idling with no load after warming up	Desired idle speed ± 50 rpm
	DESIRED IDLE (DESIRED IDLE SPEED)	It idling with radiator cooling fan stopped and all electrical parts turned OFF after warming up, M/T at neutral	Approx. 730 rpm
*	MAF (MASS AIR FLOW RATE)	At specified idle speed with no load after warming up	1.0 – 4.0 g/s 0.14 – 0.52 lb/min.
		At 2500 r/min. with no load after warming up	4.0 – 12.0 g/s 0.53 – 1.58 lb/min.
*	CALC LOAD (CALCULATED LOAD VALUE)	At specified idle speed with no load after warming up	10 – 30%
		At 2500 r/min. with no load after warming up	10 – 30%
*	THROTTLE POSITION (ABSOLUTE THROTTLE POSITION)	Ignition switch ON / warmed up engine stopped	Accelerator pedal released Accelerator pedal depressed fully
			0 – 5% 90 – 100%
*	BAROMETRIC PRES	—	Barometric pressure is displayed
	FUEL TANK LEVEL	Ignition switch ON	0 – 100%
	BATTERY VOLTAGE	Ignition switch ON / engine at stop	10 – 14 V
	BRAKE SWITCH	Ignition switch ON	Brake pedal is released Brake pedal is depressed
			OFF ON
	IMT VALVE ACTUATOR	Accelerator pedal depressed fully and engine speed at 5200 rpm or less	CLOSE
		Accelerator pedal depressed fully and engine speed at 5200 rpm or more	OPEN
*	FUEL SYSTEM B1 (FUEL SYSTEM STATUS)	At specified idle speed after warming up	CL (closed loop)
*	O2S B1 S2 (HO2S)	At 2000 r/min. for 3 min. or longer after warming up	0.1 – 0.95 V
*	SHORT FT B1 (SHORT TERM FUEL TRIM)	At specified idle speed after warming up	–20 – +20%

	Scan tool data	Vehicle condition		Normal condition / reference values
*	🔧 LONG FT B1 (LONG TERM FUEL TRIM)	At specified idle speed after warming up		-20 – +20%
	🔧 TOTAL FT B1 (TOTAL FUEL TRIM)	At specified idle speed after warming up		-35 – +35%
*	🔧 A/F B1 S1 CURRENT (A/F SENSOR OUTPUT CURRENT)	At specified idle speed after warming up		-0.20 – 0.10 mA
	🔧 FUEL CUT	Engine at fuel cut condition		CUT
		Engine at other than fuel cut condition		STOP
	🔧 O2S B1 S2 ACT (HO2S)	At specified idle speed after warming up		ACTIVE
	🔧 A/F B1 S1 ACT (A/F SENSOR)	At specified idle speed after warming up		ACTIVE
	🔧 CANIST PRG DUTY (EVAP CANISTER PURGE FLOW DUTY)	At specified idle speed after warming up		0%
*	🔧 IGNITION ADVANCE (IGNITION TIMING ADVANCE FOR NO.1 CYLINDER)	At specified idle speed with no load after warming up		3 – 17° BTDC
	🔧 FUEL PUMP	Within 2 sec. after ignition switch ON or engine running		ON
		Engine at stop with ignition switch ON		OFF
	🔧 STARTER SW (STARTER SWITCH)	Ignition switch is turned to ST (engine cranking) position		ON
	🔧 A/C PRESSURE (A/C REFRIGERANT ABSOLUTE PRESSURE)	Engine running	A/C ON (A/C is operating) at ambient temperature: 30 °C (86 °F) and humidity: 50%	1240 – 1620 kPa For more details, refer to pressure of high pressure gage under “A/C System Performance Inspection: Manual Type in Section 7B”.
			A/C OFF (A/C is not operating) at ambient temperature: 30 °C (86 °F) and engine coolant temperature: 90 – 100 °C (194 – 212 °F)	600 – 1000 kPa After longer than 10 min from A/C switch turned off
	🔧 A/C SWITCH	Engine running after warming up, A/C not operating		OFF
		Engine running after warming up, A/C operating		ON
	🔧 A/C COMP RELAY	Engine running	A/C switch and blower motor switch turned ON	ON
			A/C switch and blower motor switch turned OFF	OFF
	🔧 BLOWER FAN	Ignition switch ON	Blower fan switch: 3rd speed position or more	ON
			Blower fan switch: 1st speed position	OFF
	🔧 ELECTRIC LOAD	Ignition switch ON / Headlight, small light, rear defogger all turned OFF		OFF
		Ignition switch ON / Headlight, small light, rear defogger turned ON		ON
	🔧 TP SENSOR 1 VOLT (TP SENSOR (MAIN) OUTPUT VOLTAGE)	Ignition switch ON after warmed up engine	Accelerator pedal released	0.45 – 0.75 V
			Accelerator pedal depressed fully	3.67 – 4.25 V
	🔧 TP SENSOR 2 VOLT (TP SENSOR (SUB) OUTPUT VOLTAGE)	Ignition switch ON after warmed up engine	Accelerator pedal released	1.33 – 1.63 V
			Accelerator pedal depressed fully	3.67 – 4.67 V

1A-44 Engine General Information and Diagnosis:

	Scan tool data	Vehicle condition		Normal condition / reference values
	APP SENSOR 1 VOLT (APP SENSOR (MAIN) OUTPUT VOLTAGE)	Ignition switch ON after warmed up engine	Accelerator pedal released	0.55 – 0.95 V
			Accelerator pedal depressed fully	3.50 – 4.40 V
	APP SENSOR 2 VOLT (APP SENSOR (SUB) OUTPUT VOLTAGE)	Ignition switch ON after warmed up engine	Accelerator pedal released	0.17 – 0.58 V
			Accelerator pedal depressed fully	1.65 – 2.20 V
*	ACCEL POSITION (ABSOLUTE ACCELERATOR PEDAL POSITION)	Ignition switch ON after warmed up engine	Accelerator pedal released	0 – 5%
			Accelerator pedal depressed fully	90 – 100%
*	TARGET THROTTLE POSI (TARGET THROTTLE VALVE POSITION)	Ignition switch ON after warmed up engine	Accelerator pedal released	0 – 5%
			Accelerator pedal depressed fully	90 – 100%
	IAC THROTTLE OPENING (IDLE AIR CONTROL THROTTLE VALVE OPENING)	It idling with no load after warming up		5 – 55%
	THROTTLE MOTOR VOLT	Ignition switch ON / engine at stop		10.0 – 14.0 V
	CLOSED THROTTLE POS (CLOSED THROTTLE POSITION)	Throttle valve at idle position		ON
		Throttle valve opens larger than idle position		OFF
	THROTTLE MOTOR RELAY	At specified idle speed after warming up		ON
*	VEHICLE SPEED	At stop		0 km/h (0 mph)
	INJ PULSE WIDTH B1 (FUEL INJECTION PULSE WIDTH)	At specified idle speed with no load after warming up		2.0 – 4.0 msec.
		At 2500 r/min. with no load after warming up		2.0 – 3.6 msec.
	RADIATOR FAN (RADIATOR COOLING FAN CONTROL RELAY)	Ignition switch ON	Engine coolant temp.: 97°C (206°F) or less	OFF
			Engine coolant temp.: 97°C (206°F) – 102°C (215°F)	Low
			Engine coolant temp.: 102°C (215°F) or more	High
	A/C COND FAN (A/C CONDENSER COOLING FAN CONTROL RELAY)	Engine running	- Blower fan speed selector ON and A/C or defroster switch ON with engine running - Engine coolant temperature at more than 110°C (230°F) with engine running	ON
			Blower motor switch and/or A/C or defroster switch turned OFF	OFF
	PNP SIGNAL (TRANSMISSION RANGESENSOR) (A/T model)	Ignition switch ON / selector lever in "P" or "N" position		P/N
		Ignition switch ON / selector lever in other than "P" or "N" position		D

Scan Tool Data Definitions
COOLANT TEMP (ENGINE COOLANT TEMPERATURE, °C, °F)

It is detected by engine coolant temp. sensor.

INTAKE AIR TEMP. (°C, °F)

It is detected by intake air temp. sensor.

ENGINE SPEED (rpm)

It is computed by reference pulses from the camshaft position sensor.

DESIRED IDLE (DESIRED IDLE SPEED, rpm)

The Desired Idle Speed is an ECM internal parameter which indicates the ECM requested idle. If the engine is not running, this number is not valid.

MAF (MASS AIR FLOW RATE, g/s, lb/min.)

It represents total mass of air entering intake manifold which is measured by mass air flow sensor.

CALC LOAD (CALCULATED LOAD VALUE, %)

Engine load displayed as a percentage of maximum possible load. Value is calculated mathematically using the formula: actual (current) intake MAF ÷ maximum possible intake MAF × 100%

THROTTLE POS (ABSOLUTE THROTTLE POSITION, %)

When TP sensor is at fully closed position, throttle opening is indicated as 0 – 5% and 90 – 100% full open position.

BAROMETRIC PRESS (kPa, in.Hg)

This parameter represents a measurement of barometric air pressure and is used for altitude correction of the fuel injection quantity.

FUEL TANK LEVEL (%)

This parameter indicates approximate fuel level in fuel tank. As detectable range of fuel level sensor is set as 0 to 100%, however, with some models whose fuel tank capacity is smaller, indicated fuel level may be only 70% even when fuel tank is full.

BATTERY VOLTAGE (V)

This parameter indicates battery positive voltage inputted from main relay to ECM.

BRAKE SW (ON/OFF)

This parameter indicates the state of the brake switch.

IMT VALVE ACTUATOR (INTAKE MANIFOLD TUNING VALVE, OPEN/CLOSE)

This parameter indicates the state of IMT valve actuator.

FUEL SYSTEM B1 (FUEL SYSTEM STATUS)

Air/fuel ratio feedback loop status displayed as one of the followings.

OL: Open-loop has not yet satisfied engine conditions (ECT > 10°C, IAT, TP, A/F sensor/system = OK) to go closed loop.

CL: Closed-loop using oxygen sensor(s) as feedback for fuel control.

OL-DRIVE: Open-loop due to driving conditions (Power enrichment, etc.).

OL-FAULT: Open-loop due to detected system fault.

O2S SENSOR B1 S2 (HEATED OXYGEN SENSOR-2, V)

It indicates output voltage of HO2S installed on exhaust No.1 pipe (post-WU-TWC). It is used to detect catalyst deterioration.

SHORT FT B1 (SHORT TERM FUEL TRIM, %)

Short term fuel trim value represents short term corrections to the air/fuel mixture computation. A value of 0 indicates no correction, a value greater than 0 means an enrichment correction, and a value less than 0 implies an enleanment correction.

LONG FT B1 (LONG TERM FUEL TRIM, %)

Long term fuel trim value represents long term corrections to the air/fuel mixture computation. A value of 0 indicates no correction, a value greater than 0 means an enrichment correction, and a value less than 0 implies an enleanment correction.

TOTAL FT TRIM B1 (TOTAL FUEL TRIM, %)

The value of Total Fuel Trim is obtained by calculating based on values of Short Term Fuel Trim and Long Term Fuel Trim. This value indicates how much correction is necessary to keep the air/fuel mixture stoichiometrical.

A/F B1 S1 CURRENT (A/F SENSOR OUTPUT CURRENT, mA)

This parameter indicates output current of A/F sensor installed on exhaust No.1 pipe (pre-WU-TWC).

FUEL CUT (ON/OFF)

CUT: Fuel being cut (output signal to injector is stopped)
STOP: Fuel not being cut

O2S B1 S2 ACT (HEATED OXYGEN SENSOR-2, ACTIVE / INACTIVE)

This parameter indicates activation condition of HO2S
ACTIVE: Activating
INACTIVE: warming up or at stop.

A/F B1 S1 ACT (A/F SENSOR, ACTIVE / INACTIVE)

This parameter indicates activation condition of A/F sensor
ACTIVE: Activating
INACTIVE: warming up or at stop

CANIST PRG DUTY (EVAP CANISTER PURGE FLOW DUTY, %)

This parameter indicates valve ON (valve open) time rate within a certain set cycle of EVAP canister purge valve which controls the amount of EVAP purge.

IGNITION ADVANCE (IGNITION TIMING ADVANCE FOR NO.1 CYLINDER, °)

Ignition timing of No.1 cylinder is commanded by ECM. The actual ignition timing should be checked by using the timing light.

FUEL PUMP (ON/OFF)

ON is displayed when ECM activates the fuel pump via the fuel pump relay switch.

STARTER SW (STARTER SWITCH, ON / OFF)

This parameter indicates condition of starting motor relay output.

ON: Starting motor relay is ON

OFF: Starting motor relay is OFF

A/C PRESSURE (A/C REFRIGERANT ABSOLUTE PRESSURE, kPa)

This parameter indicates A/C refrigerant absolute pressure calculated by ECM.

A/C SWITCH (ON/OFF)

ON: Command for A/C operation being output from ECM to HVAC.

OFF: Command for A/C operation not being output.

A/C COMP RELAY (A/C COMPRESSOR RELAY, ON/OFF)

This parameter indicates the state of the A/C switch.

BLOWER FAN (ON/OFF)

This parameter indicates the state of the blower fan motor switch.

ELECTRIC LOAD (ON/OFF)

ON: Headlight, small light or rear defogger ON signal inputted.

OFF: Above electric loads all turned OFF.

TP SENSOR 1 VOLT (TP SENSOR (MAIN) OUTPUT VOLTAGE, V)

TP Sensor (Main) reading provides throttle valve opening information in the form of voltage.

TP SENSOR 2 VOLT (TP SENSOR (SUB) OUTPUT VOLTAGE, V)

TP Sensor (Sub) reading provides throttle valve opening information in the form of voltage.

APP SENSOR 1 VOLT (APP SENSOR (MAIN) OUTPUT VOLTAGE, V)

APP Sensor (Main) reading provides accelerator pedal opening information in the form of voltage.

APP SENSOR 2 VOLT (APP SENSOR (SUB) OUTPUT VOLTAGE, V)

APP Sensor (Sub) reading provides accelerator pedal opening information in the form of voltage.

ACCEL POSITION (ABSOLUTE ACCELERATOR PEDAL POSITION, %)

When accelerator pedal is at fully released position, accelerator pedal is indicated as 0 – 5% and 90 – 100% fully depressed position.

TARGET THROTTLE POSI (TARGET THROTTLE VALVE POSITION, %)

Target Throttle Valve Position is ECM internal parameter which indicates the ECM requested throttle valve position.

IAC THROTTLE OPENING (IDLE AIR (SPEED) CONTROL THROTTLE VALVE OPENING, %)

This parameter indicates throttle valve opening of idle air control in %.

(100% indicates the maximum idle air flow.)

THROTTLE MOTOR VOLT (V)

This parameter indicates power supply voltage of throttle actuator (motor) control circuit (input voltage from throttle actuator control relay).

CLOSED THROTTLE POS (CLOSED THROTTLE POSITION, ON/OFF)

This parameter reads ON when throttle valve is fully closed, or OFF when it is not fully closed.

THROTTLE MOTOR RELAY (ON / OFF)

ON: Throttle actuator (motor) control activated by ECM.

OFF: Throttle actuator (motor) control stopped by ECM.

VEHICLE SPEED (km/h, mph)

It is computed based on pulse signals from front wheel speed sensors.

INJ PULSE WIDTH (FUEL INJECTION PULSE WIDTH, msec.)

This parameter indicates time of the injector drive (valve opening) pulse which is output from ECM (but injector drive time of NO.1 cylinder for multiport fuel injection).

RADIATOR FAN (RADIATOR COOLING FAN CONTROL RELAY, Low/High/OFF)

Low: ON command being output to radiator cooling fan relay No.1.

High: ON command being output to radiator cooling fan relay No.2 and No.3.

OFF: No command being output.

A/C COND FAN (A/C CONDENSER COOLING FAN CONTROL RELAY, ON / OFF)

ON: ON command being output to A/C condenser cooling fan relay.

OFF: No command being output.

PNP SIGNAL (TRANSMISSION RANGE SENSOR, P/N or D range)

Whether the transmission range switch at P or N range or other range is displayed. If at P or N range, "P/N" is displayed and if at other than "P" and "N", "D" is displayed.

Visual Inspection

S7RW0C1104009

Visually check the following parts and systems.

Inspection Item		Referring section
Engine oil	Level, leakage	"Engine Oil and Filter Change in Section 0B"
Engine coolant	Level, leakage	"Coolant Level Check in Section 1F"
Fuel	Level, leakage	"Fuel Leakage Check Procedure in Section 1G"
A/T fluid	Level, leakage	"Automatic Transaxle Fluid Level Inspection in Section 0B"
Air cleaner element	Dirt, clogging	"Accessory Drive Belt Inspection in Section 0B"
Battery	Fluid level, corrosion of terminal	"Battery Description in Section 1J"
Water pump belt	Tension, damage	"Accessory Drive Belt Inspection in Section 0B"
Throttle valve	Operating sound	"Electric Throttle Body Assembly On-Vehicle Inspection in Section 1C"
Vacuum hoses of air intake system	Disconnection, looseness, deterioration, bend	"Vacuum Hose and Purge Valve Chamber Inspection in Section 1B"
Connectors of electric wire harness	Disconnection, friction	
Fuses	Burning	"Intermittent and Poor Connection Inspection in Section 00"
Parts	Installation, deformation	—
Bolt	Looseness	—
Other parts that can be checked visually		—
Also add the following items at engine start, if possible		
MIL	Operation	"Malfunction Indicator Lamp (MIL) Check"
Charging light	Operation	"Generator Symptom Diagnosis in Section 1J"
Engine oil pressure light	Operation	"Oil Pressure Switch Inspection in Section 9C"
Engine coolant temp. meter	Operation	"Engine Coolant Temperature (ECT) Sensor Inspection in Section 9C"
Fuel level meter	Operation	"Fuel Level Sensor Inspection in Section 9C"
Tachometer	Operation	—
Exhaust system	Leakage of exhaust gas, noise	—
Abnormal air being inhaled from air intake system		—
Other parts that can be checked visually		—

Engine Basic Inspection


S7RW0C1104010

This check is very important for troubleshooting when ECM has detected no DTC and no abnormality has been found in "Visual Inspection".

Follow the flow carefully.

Step	Action	Yes	No
1	Was "Engine and Emission Control System Check" performed?	Go to Step 2.	Go to "Engine and Emission Control System Check".
2	Check battery voltage Is it 11 V or more?	Go to Step 3.	Charge or replace battery.
3	Is vehicle equipped with keyless start control system?	Go to Step 4.	Go to Step 5.
4	Check keyless start control system for operation 1) Check keyless start control system referring to "Keyless Start System Operation Inspection in Section 10E". Is check result satisfactory?	Go to Step 5.	Keyless start control system malfunction.

1A-48 Engine General Information and Diagnosis:

Step	Action	Yes	No
5	<i>Is engine cranked?</i>	Go to Step 6.	Go to "Cranking System Symptom Diagnosis in Section 1I".
6	<i>Does engine start?</i>	Go to Step 7.	Go to Step 9.
7	Check idle speed 1) Check engine idle speed referring to "Idle Speed and IAC Throttle Valve Opening Inspection". <i>Is check result as specified?</i>	Go to Step 8.	Go to "Engine Symptom Diagnosis".
8	Check ignition timing 1) Check ignition timing referring to "Ignition Timing Inspection in Section 1H". <i>Is check result as specified?</i>	Go to "Engine Symptom Diagnosis".	Check ignition control related parts referring to "Ignition Timing Inspection in Section 1H".
9	Check immobilizer system for operation 1) Check immobilizer control system referring to "Immobilizer Control System Check in Section 10C". <i>Is it in good condition?</i>	Go to Step 10.	Immobilizer control system malfunction.
10	Check fuel supply 1) Check to make sure that enough fuel is filled in fuel tank. 2) Turn ON ignition switch for 2 sec. and then OFF. 3) Repeat Step 2) a few times. <i>Is fuel pressure felt from fuel feed hose when ignition switch is turned ON?</i>  I5RW0A110014-01	Go to Step 12.	Go to Step 11.
11	Check fuel pump for operation <i>Was fuel pump operating sound heard from fuel filler for about 2 sec. after ignition switch ON and stop?</i>	Go to "Fuel Pressure Check".	Go to "Fuel Pump and Its Circuit Check".
12	Check ignition spark 1) Check ignition spark referring to "Ignition Spark Test in Section 1H". <i>Is it in good condition?</i>	Go to Step 13.	Go to "Ignition System Symptom Diagnosis in Section 1H".
13	Check fuel injector circuit 1) Check fuel injector circuit referring to "Fuel Injector Circuit Check". <i>Is it in good condition?</i>	Go to "Engine Symptom Diagnosis".	Go to "Fuel Injector Inspection in Section 1G".

Engine Symptom Diagnosis

Perform troubleshooting referring to the followings when ECM has detected no DTC and no abnormality has been found in "Visual Inspection" and "Engine Basic Inspection".

Condition	Possible cause	Correction / Reference Item
Hard starting (Engine cranks OK)	Faulty spark plug	"Spark Plug Inspection in Section 1H"
	Faulty ignition coil	"Ignition Coil Assembly (Including ignitor) Inspection in Section 1H"
	Dirty or clogged fuel hose or pipe	"Fuel Pressure Check"
	Malfunctioning fuel pump	"Fuel Pressure Check"
	Air drawn in through intake manifold gasket or throttle body gasket	Check air intake system.
	Faulty electric throttle body assembly	"Electric Throttle Body Assembly On-Vehicle Inspection in Section 1C"
	Faulty APP sensor assembly	"Accelerator Pedal Position (APP) Sensor Assembly Inspection in Section 1C"
	Faulty ECT sensor or MAF sensor	"Engine Coolant Temperature (ECT) Sensor Inspection in Section 1C" or "Mass Air Flow (MAF) and Intake Air Temperature (IAT) Sensor Inspection in Section 1C"
	Faulty ECM	"Inspection of ECM and Its Circuits".
	Low compression	"Compression Check in Section 1D"
	Poor spark plug tightening or faulty gasket	"Spark Plug Removal and Installation in Section 1H"
	Compression leak from valve seat	"Valves and Valve Guides Inspection in Section 1D"
	Sticky valve stem	"Valves and Valve Guides Inspection in Section 1D"
	Weak or damaged valve springs	"Valve Spring Inspection in Section 1D"
	Compression leak at cylinder head gasket	"Cylinder Head Inspection in Section 1D"
	Sticking or damaged piston ring	"Pistons, Piston Rings, Connecting Rods and Cylinders Inspection and Cleaning in Section 1D"
	Worn piston, ring or cylinder	"Pistons, Piston Rings, Connecting Rods and Cylinders Inspection and Cleaning in Section 1D"
	Malfunctioning PCV valve	"PCV Valve Inspection in Section 1B"
Low oil pressure	Improper oil viscosity	"Engine Oil and Filter Change in Section 0B"
	Malfunctioning oil pressure switch	"Oil Pressure Switch Inspection in Section 9C"
	Clogged oil strainer	"Oil Pan and Oil Pump Strainer Cleaning in Section 1E"
	Functional deterioration of oil pump	"Oil Pump Inspection in Section 1E"
	Worn oil pump relief valve	"Oil Pump Inspection in Section 1E"
	Excessive clearance in various sliding parts	—
Engine noise – Valve noise	Improper valve lash	"Camshaft, Tappet and Shim Inspection in Section 1D"
	Worn valve stem and guide	"Valves and Valve Guides Inspection in Section 1D"
NOTE		
Before checking mechanical noise, make sure that:	Weak or broken valve spring	"Valve Spring Inspection in Section 1D"
	Warped or bent valve	"Valves and Valve Guides Inspection in Section 1D"
- Specified spark plug is used. - Specified fuel is used.		

1A-50 Engine General Information and Diagnosis:

Condition	Possible cause	Correction / Reference Item
Engine noise – Piston, ring and cylinder noise NOTE Before checking mechanical noise, make sure that: • Specified spark plug is used. • Specified fuel is used.	Worn piston, ring and cylinder bore	"Pistons, Piston Rings, Connecting Rods and Cylinders Inspection and Cleaning in Section 1D"
Engine noise – Connecting rod noise NOTE Before checking mechanical noise, make sure that: • Specified spark plug is used. • Specified fuel is used.	Worn piston, ring and cylinder bore	"Pistons, Piston Rings, Connecting Rods and Cylinders Inspection and Cleaning in Section 1D"
	Worn connecting rod bearing	"Pistons, Piston Rings, Connecting Rods and Cylinders Inspection and Cleaning in Section 1D"
	Worn crank pin	"Pistons, Piston Rings, Connecting Rods and Cylinders Inspection and Cleaning in Section 1D"
	Loose connecting rod bolts	"Pistons, Piston Rings, Connecting Rods and Cylinders Removal and Installation in Section 1D"
	Low oil pressure	Condition "Low oil pressure"
Engine noise – Crankshaft noise NOTE Before checking mechanical noise, make sure that: • Specified spark plug is used. • Specified fuel is used.	Low oil pressure	Condition "Low oil pressure"
	Worn main bearing	"Main Bearings, Crankshaft and Cylinder Block Inspection in Section 1D"
	Worn crankshaft journal	"Main Bearings, Crankshaft and Cylinder Block Inspection in Section 1D"
	Loose bearing cap bolts	"Main Bearings, Crankshaft and Cylinder Block Removal and Installation in Section 1D"
	Excessive crankshaft thrust play	"Main Bearings, Crankshaft and Cylinder Block Inspection in Section 1D"
Engine overheating	Inoperative thermostat	"Thermostat Inspection in Section 1F"
	Poor water pump performance	"Water Pump Inspection in Section 1F"
	Clogged or leaky radiator	"Radiator On-Vehicle Inspection and Cleaning in Section 1F"
	Improper engine oil grade	"Engine Oil and Filter Change in Section 0B"
	Clogged oil filter or oil strainer	"Oil Pressure Check in Section 1E"
	Poor oil pump performance	"Oil Pressure Check in Section 1E"
	Faulty radiator cooling fan control system	"Radiator Cooling Fan Low Speed Control System Check" or "Radiator Cooling Fan High Speed Control System Check"
	Dragging brakes	"Brakes Symptom Diagnosis in Section 4A"
	Slipping clutch (M/T model)	"Clutch System Symptom Diagnosis in Section 5C"
	Blown cylinder head gasket	"Cylinder Head Inspection in Section 1D"
	Air mixed in cooling system	

Condition	Possible cause	Correction / Reference Item
Poor gasoline mileage	Faulty spark plug (improper gap, heavy deposits and burned electrodes, etc.)	"Spark Plug Inspection in Section 1H"
	High idle speed	Condition "Improper engine idling or engine fails to idle"
	Poor performance of ECT sensor or MAF sensor	"Engine Coolant Temperature (ECT) Sensor Inspection in Section 1C" or "Mass Air Flow (MAF) and Intake Air Temperature (IAT) Sensor Inspection in Section 1C"
	Faulty electric throttle body assembly	"Electric Throttle Body Assembly On-Vehicle Inspection in Section 1C"
	Faulty APP sensor assembly	"Accelerator Pedal Position (APP) Sensor Assembly Inspection in Section 1C"
	Faulty fuel injector(s)	"Fuel Injector Circuit Check"
	Faulty ECM	"Inspection of ECM and Its Circuits"
	Low compression	"Compression Check in Section 1D"
	Poor valve seating	"Valves and Valve Guides Inspection in Section 1D"
	Dragging brakes	"Brakes Symptom Diagnosis in Section 4A"
	Slipping clutch (M/T model)	"Clutch System Symptom Diagnosis in Section 5C"
	Thermostat out of order	"Thermostat Inspection in Section 1F"
	Improper tire pressure	"Tires Description in Section 2D"
	Fuel pressure out of specification	"Fuel Pressure Check"
Excessive engine oil consumption – Oil leakage	Blown cylinder head gasket	"Cylinder Head Inspection in Section 1D"
	Leaky camshaft oil seals	"Camshaft, Tappet and Shim Inspection in Section 1D"
Excessive engine oil consumption – Oil entering combustion chamber	Sticky piston ring	"Pistons, Piston Rings, Connecting Rods and Cylinders Inspection and Cleaning in Section 1D"
	Worn piston and cylinder	"Pistons, Piston Rings, Connecting Rods and Cylinders Inspection and Cleaning in Section 1D"
	Worn piston ring groove and ring	"Pistons, Piston Rings, Connecting Rods and Cylinders Inspection and Cleaning in Section 1D"
	Improper location of piston ring gap	"Pistons, Piston Rings, Connecting Rods and Cylinders Disassembly and Reassembly in Section 1D"
	Worn or damaged valve stem seal	"Valves and Valve Guides Inspection in Section 1D"
	Worn valve stem	"Valves and Valve Guides Inspection in Section 1D"
Engine hesitates – Momentary lack of response as accelerator is depressed. Can occur at all vehicle speeds. Usually most severe when first trying to make vehicle move, as from a stop sign	Spark plug faulty or plug gap out of adjustment	"Spark Plug Inspection in Section 1H"
	Fuel pressure out of specification	"Fuel Pressure Check"
	Poor performance of ECT sensor or MAF sensor	"Engine Coolant Temperature (ECT) Sensor Inspection in Section 1C" or "Mass Air Flow (MAF) and Intake Air Temperature (IAT) Sensor Inspection in Section 1C"
	Faulty electric throttle body assembly	"Electric Throttle Body Assembly On-Vehicle Inspection in Section 1C"
	Faulty APP sensor assembly	"Accelerator Pedal Position (APP) Sensor Assembly Inspection in Section 1C"
	Faulty fuel injector	"Fuel Injector Circuit Check"
	Faulty ECM	"Inspection of ECM and Its Circuits"
	Engine overheating	Condition "Engine overheating"
	Low compression	"Compression Check in Section 1D"

1A-52 Engine General Information and Diagnosis:

Condition	Possible cause	Correction / Reference Item
Surge – Engine power variation under steady throttle or cruise. Feels like vehicle speeds up and down with no change in accelerator pedal	Faulty spark plug (excess carbon deposits, improper gap, burned electrodes, etc.)	<i>“Spark Plug Inspection in Section 1H”</i>
	Variable fuel pressure	<i>“Fuel Pressure Check”</i>
	Kinky or damaged fuel hose and lines	<i>“Fuel Pressure Check”</i>
	Faulty fuel pump (clogged fuel filter)	<i>“Fuel Pump and Its Circuit Check”</i>
	Poor performance of MAF sensor	<i>“Mass Air Flow (MAF) and Intake Air Temperature (IAT) Sensor Inspection in Section 1C”</i>
	Faulty fuel injector	<i>“Fuel Injector Circuit Check”</i>
	Faulty ECM	<i>“Inspection of ECM and Its Circuits”</i>
	Faulty electric throttle body assembly	<i>“Electric Throttle Body Assembly On-Vehicle Inspection in Section 1C”</i>
	Faulty APP sensor assembly	<i>“Accelerator Pedal Position (APP) Sensor Assembly Inspection in Section 1C”</i>
Excessive detonation – Engine makes continuously sharp metallic knocks that change with throttle opening. Sounds like popcorn popping	Faulty spark plug	<i>“Spark Plug Inspection in Section 1H”</i>
	Engine overheating	<i>Condition “Engine overheating”</i>
	Clogged fuel filter (faulty fuel pump) or fuel lines	<i>“Fuel Pressure Check” or “Fuel Pump and Its Circuit Check”</i>
	Air drawn in through intake manifold or throttle body gasket	<i>Check air intake system.</i>
	Poor performance of knock sensor, ECT sensor or MAF sensor	<i>“DTC P0327 / P0328: Knock Sensor Circuit Low / High”, “Engine Coolant Temperature (ECT) Sensor Inspection in Section 1C” or “Mass Air Flow (MAF) and Intake Air Temperature (IAT) Sensor Inspection in Section 1C”</i>
	Faulty fuel injector(s)	<i>“Fuel Injector Circuit Check”</i>
	Faulty ECM	<i>“Inspection of ECM and Its Circuits”</i>
	Excessive combustion chamber deposits	<i>“Cylinder Head Inspection in Section 1D” and “Pistons, Piston Rings, Connecting Rods and Cylinders Inspection and Cleaning in Section 1D”</i>
	Fuel pressure out of specification – Dirty fuel filter – Dirty or clogged fuel hose or pipe – Faulty fuel pressure regulator – Faulty fuel pump	<i>Refer to “Fuel Pressure Check”.</i>

Condition	Possible cause	Correction / Reference Item
Engine has no power	Faulty spark plug	"Spark Plug Inspection in Section 1H"
	Faulty ignition coil with ignitor	"Ignition Coil Assembly (Including ignitor) Inspection in Section 1H"
	Faulty knock sensor	"DTC P0327 / P0328: Knock Sensor Circuit Low / High"
	Clogged fuel hose or pipe	"Fuel Pressure Check"
	Malfunctioning fuel pump	"Fuel Pump and Its Circuit Check"
	Air drawn in through intake manifold gasket or throttle body gasket	Check air intake system.
	Engine overheating	Condition "Engine overheating"
	Poor performance of ECT sensor or MAF sensor	"Engine Coolant Temperature (ECT) Sensor Inspection in Section 1C" or "Mass Air Flow (MAF) and Intake Air Temperature (IAT) Sensor Inspection in Section 1C"
	Faulty electric throttle body assembly	"Electric Throttle Body Assembly On-Vehicle Inspection in Section 1C"
	Faulty APP sensor assembly	"Accelerator Pedal Position (APP) Sensor Assembly Inspection in Section 1C"
	Faulty fuel injector(s)	"Fuel Injector Circuit Check"
	Faulty ECM	"Inspection of ECM and Its Circuits"
	Dragging brakes	"Brakes Symptom Diagnosis in Section 4A"
	Slipping clutch (M/T model)	"Clutch System Symptom Diagnosis in Section 5C"
	Low compression	"Compression Check in Section 1D"
	Faulty IMT valve actuator	"IMT Valve Actuator Inspection in Section 1C"
Improper engine idling or engine fails to idle	Faulty spark plug	"Spark Plug Inspection in Section 1H"
	Faulty ignition coil with ignitor	"Ignition Coil Assembly (Including ignitor) Inspection in Section 1H"
	Fuel pressure out of specification	"Fuel Pressure Check"
	Leaky manifold, throttle body, or cylinder head gasket	Check air intake system.
	Faulty evaporative emission control system	"EVAP Canister Purge Inspection in Section 1B"
	Faulty fuel injector(s)	"Fuel Injector Circuit Check"
	Poor performance of ECT sensor or MAF sensor	"Engine Coolant Temperature (ECT) Sensor Inspection in Section 1C" or "Mass Air Flow (MAF) and Intake Air Temperature (IAT) Sensor Inspection in Section 1C"
	Faulty electric throttle body assembly	"Electric Throttle Body Assembly On-Vehicle Inspection in Section 1C"
	Faulty APP sensor assembly	"Accelerator Pedal Position (APP) Sensor Assembly Inspection in Section 1C"
	Faulty ECM	"Inspection of ECM and Its Circuits"
	Loose connection or disconnection of vacuum hoses	Check connection or disconnection of vacuum.
	Malfunctioning PCV valve	"PCV Valve Inspection in Section 1B"
	Engine overheating	Condition "Engine overheating"
	Low compression	"Compression Check in Section 1D"
	Faulty electric load parts (headlight, blower motor and/or rear defogger)	"Electric Load Signal Circuit Check"
	Faulty generator and/or its circuit	"Generator Test (Undercharged Battery Check) in Section 1J"
	Faulty idle air flow malfunction	"Idle Speed and IAC Throttle Valve Opening Inspection"

1A-54 Engine General Information and Diagnosis:

Condition	Possible cause	Correction / Reference Item
Excessive hydrocarbon (HC) emission or carbon monoxide (CO)	Faulty spark plug	<i>"Spark Plug Inspection in Section 1H"</i>
	Faulty ignition coil with ignitor	<i>"Ignition Coil Assembly (Including ignitor) Inspection in Section 1H"</i>
	Low compression	<i>"Compression Check in Section 1D"</i>
	Lead contamination of three way catalytic converter	<i>Check for absence of filler neck restrictor.</i>
	Faulty evaporative emission control system	<i>"EVAP Canister Purge Inspection in Section 1B"</i>
	Fuel pressure out of specification	<i>"Fuel Pressure Check"</i>
	Closed loop system (A/F feedback compensation) fails (Faulty TP sensor, Poor performance of ECT sensor or MAF sensor)	<i>"Electric Throttle Body Assembly On-Vehicle Inspection in Section 1C", "Engine Coolant Temperature (ECT) Sensor Inspection in Section 1C" or "Mass Air Flow (MAF) and Intake Air Temperature (IAT) Sensor Inspection in Section 1C"</i>
	Faulty electric throttle body assembly	<i>"Electric Throttle Body Assembly On-Vehicle Inspection in Section 1C"</i>
	Faulty APP sensor assembly	<i>"Accelerator Pedal Position (APP) Sensor Assembly Inspection in Section 1C"</i>
	Faulty injector(s)	<i>"Fuel Injector Circuit Check"</i>
	Faulty ECM	<i>"Inspection of ECM and Its Circuits"</i>
	Engine not at normal operating temperature	—
	Clogged air cleaner	<i>"Air Cleaner Filter Inspection and Cleaning in Section 1D"</i>
	Vacuum leaks	<i>"Engine Vacuum Check in Section 1D"</i>
Excessive nitrogen oxides (NOx) emission	Improper ignition timing	<i>"Ignition Timing Inspection in Section 1H"</i>
	Lead contamination of catalytic converter	<i>Check for absence of filler neck restrictor.</i>
	Fuel pressure out of specification	<i>"Fuel Pressure Check"</i>
	Closed loop system (A/F feedback compensation) fails (Faulty TP sensor, Poor performance of ECT sensor or MAF sensor)	<i>"Electric Throttle Body Assembly On-Vehicle Inspection in Section 1C", "Engine Coolant Temperature (ECT) Sensor Inspection in Section 1C" or "Mass Air Flow (MAF) and Intake Air Temperature (IAT) Sensor Inspection in Section 1C"</i>
	Faulty electric throttle body assembly	<i>"Electric Throttle Body Assembly On-Vehicle Inspection in Section 1C"</i>
	Faulty APP sensor assembly	<i>"Accelerator Pedal Position (APP) Sensor Assembly Inspection in Section 1C"</i>
	Faulty injector(s)	<i>"Fuel Injector Circuit Check"</i>
	Faulty ECM	<i>"Inspection of ECM and Its Circuits"</i>

Troubleshooting

NOTE

When measuring circuit voltage, resistance and/or pulse signal at ECM connector, connect the special tool to ECM and/or the ECM connectors referring to "Inspection of ECM and Its Circuits".

Step	Action	Yes	No
1	MIL power supply check 1) Turn ignition switch to ON position. <i>Do other warning lights come ON?</i>	Go to Step 2.	Go to Step 4.
2	DTC check in ECM 1) Connect scan tool to DLC with ignition switch turned OFF. 2) Turn ON ignition switch and check DTC in ECM. <i>Is there DTC(s) U0073 and/or U0121?</i>	Go to applicable DTC diag. flow.	Go to Step 3.
3	DTC check in BCM 1) Check DTC in BCM. <i>Is there DTC U0100?</i>	Go to applicable DTC diag. flow.	Substitute a known-good combination meter and recheck. If MIL still remains OFF, substitute a known-good ECM and recheck.
4	CAN communication line circuit check 1) Check CAN communication line circuit between control modules for open, short, high resistance and connections referring to Step 5 to 10 under "Troubleshooting for Communication Error with Scan Tool Using CAN". <i>Is circuit in good condition?</i>	Go to Step 5.	Repair or replace.
5	"METER" fuse check 1) Turn ignition switch to OFF position. 2) Check for fuse blown at "METER" fuse in junction block. <i>Is "METER" fuse in good condition?</i>	Go to Step 6.	Replace "METER" fuse and check for short.
6	Combination meter power supply check 1) Remove combination meter referring to "Combination Meter Removal and Installation in Section 9C". 2) Check for proper connection to combination meter connector at "G241-31" and "G241-16" terminals. 3) If OK, then turn ignition switch to ON position and measure voltage between combination meter connector at "G241-31" terminal and vehicle body ground. <i>Is it 10 – 14 V?</i>	Go to Step 7.	"RED/BLK" wire is open circuit.
7	Combination meter circuit check 1) Turn ignition switch to OFF position. 2) Measure resistance between "G241-16" terminal of combination meter connector and vehicle body ground. <i>Is resistance 1 Ω or less?</i>	Substitute a known-good combination meter and recheck. If MIL still remains OFF, substitute a known-good ECM and recheck.	"BLK" wire is open or high resistance circuit.

MIL Remains ON after Engine Starts

S7RW0C1104013

Wiring Diagram

Refer to "MIL Does Not Come ON with Ignition Switch ON and Engine Stop (but Engine Can Be Started)".

Circuit Description

When the ignition switch is turned ON, ECM causes the main relay to turn ON (close the contact point). Then, ECM being supplied with the main power, transmits indication ON signal of MIL to combination meter in order to turn MIL ON. And then, combination meter turns MIL ON. When the engine starts to run and no malfunction is detected in the system, ECM transmits MIL indication OFF signal to combination meter in order to turn MIL OFF. And then, combination meter turns MIL OFF, but if a malfunction was or is detected, MIL remains ON even when the engine is running.


Troubleshooting**NOTE**

When measuring circuit voltage, resistance and/or pulse signal at ECM connector, connect the special tool to ECM and/or the ECM connectors referring to "Inspection of ECM and Its Circuits".

Step	Action	Yes	No
1	DTC check 1) Start engine and recheck DTC of ECM and TCM while engine running. <i>Is there any DTC(s)?</i>	Go to Step 2 of "Engine and Emission Control System Check", Step 2 of "A/T System Check in Section 5A".	Go to Step 2.
2	CAN communication line circuit check 1) Check CAN communication line circuit between control modules for open, short, high resistance and connections referring to Step 5 to 10 under "Troubleshooting for Communication Error with Scan Tool Using CAN". <i>Is circuit in good condition?</i>	Substitute a known-good combination meter and recheck. If MIL still remains ON, substitute a known-good ECM and recheck.	Repair or replace CAN communication circuit.

DTC P0030: HO2S Heater Control Circuit (Sensor-1, Bank-1)

S7RW0C1104014

Wiring Diagram

I7RW01110088-02

A1: Signal (+) circuit of A/F sensor	B2: Ground circuit of HO2S	5. "IG COIL" fuse
A2: Signal (-) circuit of A/F sensor	B3: Control circuit of HO2S heater	6. A/F sensor
A3: Control circuit of A/F sensor heater	1. HO2S	7. Sensor heater
A4: Control ground circuit of A/F sensor heater	2. Shield wire	
A5: Power supply circuit of A/F sensor heater and HO2S heater	3. Ignition switch	
B1: Signal circuit of HO2S	4. ECM	

A/F Sensor Description

Refer to "A/F Sensor Description".

DTC Detecting Condition and Trouble Area

DTC detecting condition	Trouble area
Impedance of A/F sensor element is higher than 50 Ω for 20 sec. even though A/F sensor logic heater is turned ON. (2 driving cycle detection logic)	- A/F sensor heater and/or its circuit - ECM

DTC Confirmation Procedure

- 1) With ignition switch turned OFF, connect scan tool.
- 2) Turn ON ignition switch and clear DTC using scan tool.
- 3) Start engine and warm up to normal operating temperature.
- 4) Run engine at idle speed for 5 min. or more.
- 5) Check DTC and pending DTC.

DTC Troubleshooting

Step	Action	Yes	No
1	Was "Engine and Emission Control System Check" performed?	Go to Step 2.	Go to "Engine and Emission Control System Check".
2	DTC check Is there any DTC(s) other than P0030?	Go to applicable DTC diag. flow.	Go to Step 3.
3	Wire harness check 1) Disconnect connectors from A/F sensor and ECM with ignition switch turned OFF. 2) Check for proper connection to A/F sensor terminals and ECM terminals. 3) If connections are OK, check that A/F sensor circuit is as follows. - Insulation resistance of wire harness is infinity between "Signal (+) circuit of A/F sensor" terminal and each other terminal at A/F sensor connector. - Wiring harness resistance of "Signal (+) circuit of A/F sensor", "Signal (-) circuit of A/F sensor", "Control circuit of A/F sensor heater" and "Control ground circuit of A/F sensor heater" is less than 1 Ω. Are they in good condition?	Replace A/F sensor and recheck. If this DTC is detected again, substitute a known-good ECM.	Repair or replace defective wiring harness / connector.

DTC P0031 / P0032: HO2S Heater Control Circuit Low / High (Sensor-1, Bank-1)

S7RW0C1104015

Wiring Diagram

Refer to "DTC P0030: HO2S Heater Control Circuit (Sensor-1, Bank-1)".

A/F Sensor Description

Refer to "A/F Sensor Description"

DTC Detecting Condition and Trouble Area

DTC detecting condition	Trouble area
P0031: Heater control circuit voltage of A/F sensor is lower than specification for more than specified time even though control duty ratio of A/F sensor heater is less than 90% with engine running. (Heater control duty pulse is not detected in its circuit of ECM) (2 driving cycle detection logic) P0032: Heater control circuit voltage of A/F sensor is higher than specification for more than specified time even though control duty ratio of A/F sensor heater is more than 10% with engine running. (Heater control duty pulse is not detected in its circuit of ECM) (2 driving cycle detection logic)	- A/F sensor heater and/or its circuit - ECM

DTC Confirmation Procedure

- 1) With ignition switch turned OFF, connect scan tool to DLC.
- 2) Turn ON ignition switch and clear DTC.
- 3) Start engine and warm up to normal operating temperature.
- 4) Run engine at idle speed for 1 min. or more.
- 5) Check DTC and pending DTC.

DTC Troubleshooting

Step	Action	Yes	No
1	Was "Engine and Emission Control System Check" performed?	Go to Step 2.	Go to "Engine and Emission Control System Check".
2	A/F sensor heater circuit check 1) Disconnect connector from A/F sensor with ignition switch turned OFF. 2) Check for proper terminal connection to A/F sensor connector. 3) If connections are OK, measure circuit voltage between "Power supply circuit of A/F sensor heater" and vehicle body ground with ignition switch turned ON. <i>Is measured voltage 10 – 14 V?</i>	Go to Step 3.	Repair or replace defective wiring harness / connector.
3	A/F sensor heater circuit check 1) Check that A/F sensor heater control circuit is as follows. • Circuit voltage between "Control circuit of A/F sensor heater" and vehicle body ground is 0 V with ignition switch turned ON. <i>Is it good condition?</i>	Go to Step 4.	Repair or replace defective wiring harness / connector.
4	A/F sensor heater circuit check 1) Disconnect connectors from ECM and check for proper terminal connection to ECM connector. 2) If connections are OK, check that A/F sensor heater circuit is as follows. • Insulation resistance of wire harness is infinity between "Control circuit of A/F sensor heater" terminal and each other terminal at A/F sensor connector. • Wiring harness resistance of "Control circuit of A/F sensor heater" and "Control ground circuit of A/F sensor heater" is less than 1 Ω. • Insulation resistance between "Control circuit of A/F sensor heater" and "Control ground circuit of A/F sensor heater" is infinity. <i>Are they in good condition?</i>	Go to Step 5.	Repair or replace defective wiring harness / connector.
5	A/F sensor heater check 1) Check heater resistance of A/F sensor referring to "Air Fuel Ratio (A/F) Sensor On-Vehicle Inspection in Section 1C". <i>Is A/F sensor heater in good condition?</i>	Substitute a known-good ECM and recheck.	Replace A/F sensor.

DTC P0037 / P0038: HO2S Heater Control Circuit Low / High (Sensor-2, Bank-1)

S7RW0C1104016

Wiring Diagram

Refer to "DTC P0030: HO2S Heater Control Circuit (Sensor-1, Bank-1)".

DTC Detecting Condition and Trouble Area

DTC detecting condition	Trouble area
P0037: HO2S circuit voltage is lower than specification for specified time even though control duty ratio of HO2S heater is less than 75% with engine running. (Heater control duty pulse is not detected in its monitor signal) (2 driving cycle detection logic) P0038: HO2S circuit voltage is higher than specification for specified time even though control duty ratio of HO2S heater is more than 25% with engine running. (Heater control duty pulse is not detected in its monitor signal) (2 driving cycle detection logic)	- HO2S heater and/or its circuit - ECM

DTC Confirmation Procedure

- 1) With ignition switch turned OFF, connect scan tool to DLC.
- 2) Turn ON ignition switch and clear DTC.
- 3) Start engine and warm up to normal operating temperature.
- 4) Run engine at idle speed for 1 min. or more.
- 5) Check DTC and pending DTC.


DTC Troubleshooting

Step	Action	Yes	No
1	Was "Engine and Emission Control System Check" performed?	Go to Step 2.	Go to "Engine and Emission Control System Check".
2	HO2S heater and its circuit check 1) Disconnect connector from HO2S with ignition switch turned OFF. 2) Check for proper terminal connection to HO2S connector. 3) If connections are OK, check that HO2S heater power supply circuit is as follows. • Circuit voltage between "Power supply circuit of HO2S heater" and vehicle body ground is battery voltage with ignition switch turned ON. Is it in good condition?	Go to Step 3.	Repair or replace defective wiring harness / connector.
3	HO2S heater circuit check 1) Check that HO2S heater control circuit is as follows. • Circuit voltage between "Control circuit of HO2S heater" and vehicle body ground is 0 V with ignition switch turned ON. Is it good condition?	Go to Step 4.	Repair or replace defective wiring harness / connector.

Step	Action	Yes	No
4	HO2S heater circuit check 1) Disconnect connectors from ECM and check for proper terminal connection to ECM connector. 2) If connections are OK, check that HO2S heater circuit is as follows. - Insulation resistance of wire harness is infinity between "Control circuit of HO2S heater" terminal and each other terminal at HO2S connector. - Wiring harness resistance of "Control circuit of HO2S heater" is less than 1 Ω. - Insulation resistance between "Control circuit of HO2S heater" and vehicle body ground is infinity. <i>Is it in good condition?</i>	Go to Step 5.	Repair or replace defective wiring harness / connector.
5	HO2S heater check 1) Check heater resistance of HO2S referring to "Heated Oxygen Sensor (HO2S) Heater On-Vehicle Inspection in Section 1C". <i>Is HO2S heater in good condition?</i>	Substitute a known-good ECM and recheck.	Replace HO2S.

DTC P0101: Mass or Volume Air Flow Circuit Range / Performance

S7RW0C1104017

Wiring Diagram

I7RW01110046-03

A1: MAF sensor power supply circuit	B2: IAT sensor ground circuit	4. ECM	8. "IGN" fuse
A2: MAF sensor signal circuit	1. MAF and IAT sensor	5. To other sensors	9. "FI" fuse
A3: MAF sensor ground circuit	2. Ignition switch	6. "IG COIL" fuse	
B1: IAT sensor signal circuit	3. Main relay	7. Fuse box No.2	

DTC Detecting Condition and Trouble Area

DTC detecting condition	Trouble area
MAF sensor signal is higher or lower than estimated range based on engine speed and throttle angle for 7 sec. (2 driving cycle detection logic)	• Air intake system (Clog or leakage) • MAF sensor and/or its circuit • Exhaust system (clogged WU-TWC converter) • TP sensor and/or its circuit • ECM

DTC Confirmation Procedure**NOTE**

Check to make sure that the following conditions are satisfied when using this “DTC Confirmation Procedure”.

- Intake air temperature at engine start: -10°C (14°F) to 80°C (176°F)
- Intake air temperature: -10°C (14°F) to 70°C (158°F)
- Engine coolant temperature: 70°C (158°F) to 150°C (302°F)
- Altitude (barometric pressure): 2400 m, 8000 ft or less (560 mmHg, 75 kPa or more)
- The following DTCs are not detected: DTC P0171 / P0172 / P0300 / P0301 / P0302 / P0303 / P0304 and DTCs related to ECT sensor, IAT sensor, Barometric pressure sensor, TP sensor and MAF sensor (other than P0101)

- 1) With ignition switch OFF, connect scan tool.
- 2) Turn ON ignition switch and clear DTC by using scan tool.
- 3) Start engine and run it at idle for 1 min.
- 4) Stop vehicle and check DTC and pending DTC.

DTC Troubleshooting

Step	Action	Yes	No
1	Was “Engine and Emission Control System Check” performed?	Go to Step 2.	Go to “Engine and Emission Control System Check”.
2	Visual inspection 1) Check MAF sensor and air intake system for: • Objects which block measuring duct and resistor of MAF sensor. • Other air flow which does not pass the MAF sensor. Are they in good condition?	Go to Step 3.	Repair or replace.
3	MAF sensor performance check 1) With ignition switch OFF, connect scan tool to DLC. 2) Start engine and warm up to normal operation temperature. 3) Check MAF value using scan tool. (Refer to “Scan Tool Data” for normal value.) Is normal value indicated?	Intermittent trouble. Check for intermittent referring to “Intermittent and Poor Connection Inspection in Section 00”.	Go to Step 4.
4	Wire harness check 1) Check power supply, signal and ground circuits of MAF sensor for condition referring to Step 3 and 4 of “DTC P0102 / P0103: Mass or Volume Air Flow Circuit Low / High Input”. Are they in good condition?	Go to Step 5.	Repair or replace.

1A-64 Engine General Information and Diagnosis:

Step	Action	Yes	No
5	MAF sensor signal check 1) Turn ignition switch OFF position. 2) Connect connectors to MAF sensor and ECM. 3) Check MAF sensor signal voltage referring to "Mass Air Flow (MAF) and Intake Air Temperature (IAT) Sensor On-Vehicle Inspection in Section 1C". <i>Is each value within specified range?</i>	Substitute a known-good ECM and recheck.	Replace MAF and IAT sensor.

DTC P0102 / P0103: Mass or Volume Air Flow Circuit Low / High Input

S7RW0C1104018

Wiring Diagram

Refer to "DTC P0101: Mass or Volume Air Flow Circuit Range / Performance".

DTC Detecting Condition and Trouble Area


DTC detecting condition	Trouble area
DTC P0102: Output voltage of MAF sensor is lower than 0.15 V for 5 sec. (1 driving cycle detection logic)	• MAF sensor and/or its circuit • ECM
DTC P0103: Output voltage of MAF sensor is higher than 4.85 V for 5 sec. (1 driving cycle detection logic)	

DTC Confirmation Procedure

- 1) With ignition switch OFF, connect scan tool.
- 2) Turn ON ignition switch and clear DTC by using scan tool.
- 3) Turn ignition switch to ON position.
- 4) Check DTC.

DTC Troubleshooting

Step	Action	Yes	No
1	<i>Was "Engine and Emission Control System Check" performed?</i>	Go to Step 2.	Go to "Engine and Emission Control System Check".
2	MAF sensor and its circuit check 1) Connect scan tool to DLC with ignition switch turned OFF. 2) Start engine and check MAF value displayed on scan tool. (Refer to "Scan Tool Data" for normal value.) <i>Is normal value indicated?</i>	Intermittent trouble. Check for intermittent referring to "Intermittent and Poor Connection Inspection in Section 00".	Go to Step 3.

Step	Action	Yes	No
3	MAF sensor power supply voltage check 1) Disconnect connector from MAF sensor with ignition switch turned OFF. 2) Check for proper terminal connection to MAF sensor and ECM connectors. 3) If connections are OK, turn ignition switch to ON position. 4) Check that MAF sensor power supply voltage is battery voltage.  I7RW01110047-01 <i>Is it in good condition?</i>	Go to Step 4.	Repair or replace MAF sensor power supply circuit.
4	Wire harness check 1) Turn ignition switch OFF position. 2) Disconnect connector from ECM. 3) Check that MAF sensor circuit is as follows. • Wiring harness resistance of each MAF sensor signal circuit and ground circuit is less than 3 Ω. • Insulation resistance between MAF sensor signal circuit and vehicle body ground is Infinity. • Insulation resistance of wire harness is infinity between MAF sensor signal terminal and each other terminal at MAF and IAT sensor connector. • Circuit voltage of each MAF sensor signal circuit and ground circuit is 0 – 1 V with ignition switch turned ON. <i>Are they in good condition?</i>	Go to Step 5.	Repair or replace defective wire harness.
5	MAF sensor signal check 1) Turn ignition switch OFF position. 2) Connect connectors to MAF sensor and ECM. 3) Check MAF sensor signal voltage referring to “Mass Air Flow (MAF) and Intake Air Temperature (IAT) Sensor On-Vehicle Inspection in Section 1C”. <i>Is each value within specified range?</i>	Substitute a known-good ECM and recheck.	Replace MAF and IAT sensor.

DTC P0111: Intake Air Temperature Sensor 1 Circuit Range / Performance

S7RW0C1104019

Wiring Diagram

Refer to "DTC P0101: Mass or Volume Air Flow Circuit Range / Performance".

DTC Detecting Condition and Trouble Area

DTC detecting condition	Trouble area
Variation of IAT sensor signal is less than 15 mV for 10 minutes even though ECT reaches 70 °C (158 °F). (2 driving cycle detection logic)	- IAT sensor and/or its circuit - ECM

DTC Confirmation Procedure**NOTE**

Check to make sure that the following conditions are satisfied when using this "DTC Confirmation Procedure".

- Intake air temperature at engine start: -10 °C (14 °F) to 80 °C (176 °F)
- Intake air temperature: -10 °C (14 °F) to 70 °C (158 °F)
- Engine coolant temperature: 70 °C (158 °F) to 150 °C (302 °F)
- Altitude (barometric pressure): 2400 m, 8000 ft or less (560 mmHg, 75 kPa or more)
- The following DTCs are not detected: DTCs related to ECT sensor, IAT sensor (other than P0111) and barometric pressure sensor

- 1) With ignition switch OFF, connect scan tool.
- 2) Turn ON ignition switch, clear DTC.
- 3) Start engine and warm up to normal operating temperature.
- 4) Drive vehicle more than 37 mph (60 km/h) for 15 min.
- 5) Stop vehicle and run engine at idle speed.
- 6) Check DTC and pending DTC.

DTC Troubleshooting

Step	Action	Yes	No
1	Was "Engine and Emission Control System Check" performed?	Go to Step 2.	Go to "Engine and Emission Control System Check".
2	IAT sensor check 1) Check IAT sensor for performance referring to "Mass Air Flow (MAF) and Intake Air Temperature (IAT) Sensor Inspection in Section 1C". <i>Is it in good condition?</i>	Go to Step 3.	Replace MAF and IAT sensor.
3	Wire harness check 1) Check signal and ground circuits of IAT sensor for condition referring to Step 2 and 3 of "DTC P0112 / P0113: Intake Air Temperature Sensor Circuit Low / High Input". <i>Are they in good condition?</i>	Substitute a known-good ECM and recheck.	Repair or replace.

DTC P0112 / P0113: Intake Air Temperature Sensor Circuit Low / High Input

S7RW0C1104020

Wiring Diagram

Refer to "DTC P0101: Mass or Volume Air Flow Circuit Range / Performance".

DTC Detecting Condition and Trouble Area

DTC detecting condition	Trouble area
P0112: Circuit voltage of IAT sensor is lower than 0.15 V for 5 sec. (1 driving cycle detection logic)	• IAT sensor and/or its circuit • ECM
P0113: Circuit voltage of IAT sensor is higher than 4.85 V for 5 sec. (1 driving cycle detection logic)	

DTC Confirmation Procedure

- 1) With ignition switch OFF, connect scan tool.
- 2) Turn ON ignition switch and clear DTC by using scan tool.
- 3) Start engine and run it for 10 sec.
- 4) Check DTC.


DTC Troubleshooting**NOTE**

When DTC P0113 and P0118 are indicated together, it is possible that IAT sensor ground is open.

Step	Action	Yes	No
1	Was "Engine and Emission Control System Check" performed?	Go to Step 2.	Go to "Engine and Emission Control System Check".
2	Wire harness check 1) Turn ignition switch OFF position. 2) Disconnect connectors from IAT sensor and ECM. 3) Check for proper terminal connection to IAT sensor and ECM connectors. 4) If connections are OK, check that IAT sensor circuit is as follows. • Wiring harness resistance of each IAT sensor signal and ground circuit is less than 3 Ω. • Insulation resistance of IAT sensor signal circuit is infinity between IAT sensor connector and vehicle body ground. • Insulation resistance of wire harness is infinity between IAT sensor signal terminal and each other terminal at MAF and IAT sensor connector. • Circuit voltage of each IAT sensor signal and ground circuit is 0 – 1 V with ignition switch turned ON. Are they in good condition?	Go to Step 3.	Repair or replace defective wire harness.
3	IAT sensor reference voltage check 1) Connect connectors to ECM. 2) Turn ignition switch to ON position. 3) Check that IAT sensor signal voltage is 5 V between IAT sensor connector and vehicle body ground. Is it in good condition?	Go to Step 4.	Substitute a known-good ECM and recheck.
4	IAT sensor check 1) Check IAT sensor for performance referring to "Mass Air Flow (MAF) and Intake Air Temperature (IAT) Sensor Inspection in Section 1C". Is it in good condition?	Substitute a known-good ECM and recheck.	Replace MAF and IAT sensor.

DTC P0116: Engine Coolant Temperature Circuit Range / Performance

S7RW0C1104021

Wiring Diagram

I7RW01110049-03

DTC Detecting Condition and Trouble Area

DTC detecting condition	Trouble area
ECT sensor value is less than 10 °C (50 °F) while engine is running under more than specified engine load (more than 1000 rpm) after 2 to 1116 min. (depending on ECT at engine start) elapsed from engine start. (2 driving cycle detection logic, monitoring once per driving cycle)	- ECT sensor and/or its circuit - Thermostat - ECM

DTC Confirmation Procedure**⚠ WARNING**

- When performing a road test, select a place where there is no traffic or possibility of a traffic accident and very careful during testing to avoid occurrence of an accident.
- Road test should be carried out with 2 persons, a driver and a tester, on a level road.


NOTE

Check to make sure that the following conditions are satisfied when using this "DTC Confirmation Procedure".

- Intake air temperature at engine start: -10 °C (14 °F) to 80 °C (176 °F)
- Intake air temperature: -10 °C (14 °F) to 70 °C (158 °F)
- Altitude (barometric pressure): 2400 m, 8000 ft or less (560 mmHg, 75 kPa or more)
- The following DTCs are not detected: DTCs related to MAF sensor, ECT sensor (other than P0116), IAT sensor and barometric pressure sensor

- With ignition switch OFF, connect scan tool.
- Turn ON ignition switch, clear DTC.
- Drive vehicle more than 40 mph (65 km/h) for more than 12 minutes.
- Stop vehicle.
- Check DTC and pending DTC.

DTC Troubleshooting

Step	Action	Yes	No
1	Was "Engine and Emission Control System Check" performed?	Go to Step 2.	Go to "Engine and Emission Control System Check".
2	DTC check Is there DTC(s) other than P0116?	Go to applicable DTC diag.flow.	Go to Step 3.
3	Engine coolant temperature check 1) With ignition switch OFF, connect scan tool to DLC. 2) With ignition switch ON, check engine coolant temperature displayed on scan tool. (ECT 1) 3) Warm up engine to normal operating temperature. 4) Check engine coolant temperature displayed on scan tool. (ECT 2) Is difference between ECT 1 and ECT 2 less than 2 °C?	Go to Step 5.	Go to Step 4.
4	Thermostat check 1) Check thermostat referring to "Thermostat Inspection in Section 1F". Is thermostat in good condition?	Go to Step 5.	Replace thermostat.
5	ECT sensor circuit check 1) With ignition switch OFF, connect scan tool to DLC and disconnect ECT sensor connector (1). 2) With ignition switch ON, check engine coolant temperature displayed on scan tool. ECT sensor temperature specifications Signal wire terminal (2) and ground wire terminal (3) in ECT sensor connector are shorted by service wire (4): 130 °C (266 °F) Signal wire terminal (2) and ground wire terminal (3) in ECT sensor connector are opened: -40 °C (-40 °F)  I6JB01110032-01 Is check result as specified?	Go to Step 6.	Check ECT sensor signal and ground circuits referring to Step 2 of "DTC P0117 / P0118: Engine Coolant Temperature Circuit Low / High".
6	ECT sensor performance check 1) Check ECT sensor referring to "Engine Coolant Temperature (ECT) Sensor Inspection in Section 1C". Is check result as specified?	Substitute a known-good ECM and recheck.	Replace ECT sensor.

DTC P0117 / P0118: Engine Coolant Temperature Circuit Low / High

S7RW0C1104022

Wiring Diagram

Refer to "DTC P0116: Engine Coolant Temperature Circuit Range / Performance".

DTC Detecting Condition and Trouble Area

DTC detecting condition	Trouble area
P0117: Circuit voltage of ECT sensor is lower than 0.15 V for 5 sec. (1 driving cycle detection logic)	- ECT sensor and/or its circuit - ECM
P0118: Circuit voltage of ECT sensor is higher than 4.85 V for 5 sec. (1 driving cycle detection logic)	

DTC Confirmation Procedure

- 1) With ignition switch OFF, connect scan tool.
- 2) Turn ON ignition switch and clear DTC by using scan tool.
- 3) Start engine and run it for 10 sec.
- 4) Check DTC.

DTC Troubleshooting**NOTE**


When DTC P0118 and P0113 are indicated together, it is possible that ECT sensor ground circuit is open.

Step	Action	Yes	No
1	Was "Engine and Emission Control System Check" performed?	Go to Step 2.	Go to "Engine and Emission Control System Check".
2	Wire harness check 1) Turn ignition switch OFF position. 2) Disconnect connectors from ECT sensor and ECM. 3) Check for proper terminal connection to ECT sensor and ECM connectors. 4) If connections are OK, check that ECT sensor circuit is as follows. • Wiring harness resistance of each ECT sensor signal and ground circuit is less than 3 Ω. • Insulation resistance of ECT sensor signal circuit is infinity between ECT sensor connector and vehicle body ground. • Insulation resistance of wire harness is infinity between ECT sensor signal terminal and each other terminal at ECT sensor connector. • Circuit voltage of each ECT sensor signal and ground circuit is 0 – 1 V with ignition switch turned ON. Are they in good condition?	Go to Step 3.	Repair or replace defective wire harness.
3	ECT sensor reference voltage check 1) Connect connectors to ECM. 2) Turn ignition switch to ON position. 3) Check that ECT sensor signal voltage is 5 V between ECT sensor connector and vehicle body ground. Is it in good condition?	Go to Step 4.	Substitute a known-good ECM and recheck.

Step	Action	Yes	No
4	ECT sensor check 1) Check ECT sensor for performance referring to “Engine Coolant Temperature (ECT) Sensor Inspection in Section 1C”. <i>Is it in good condition?</i>	Substitute a known-good ECM and recheck.	Replace ECT sensor.

DTC P0122 / P0123: Throttle / Pedal Position Sensor / Switch “A” Circuit Low / High

S7RW0C1104023

Wiring Diagram

I7RW01110050-03

A1: TP sensor power supply circuit	C1: Control circuit of throttle actuator (+)	7. Main relay
A2: TP sensor (main) signal circuit	C2: Control circuit of throttle actuator (–)	8. Fuse Box No.2
A3: TP sensor (sub) signal circuit	1. Electric throttle body assembly	9. “THR MOT” fuse
A4: TP sensor ground circuit	2. Throttle actuator	10. “FI” fuse
B1: Power supply circuit of throttle actuator control relay (switch side)	3. TP sensor (main)	11. “IGN” fuse
B2: Control circuit of throttle actuator control relay (switch side)	4. TP sensor (sub)	12. “IG COIL” fuse
B3: Power supply circuit of throttle actuator control relay (coil side)	5. Throttle actuator control relay	13. Ignition switch
B4: Control circuit of throttle actuator control relay (coil side)	6. ECM	

1A-72 Engine General Information and Diagnosis:

DTC Detecting Condition and Trouble Area

DTC detecting condition	Trouble area
P0122: Output voltage of TP sensor (main) is lower than 0.3 V. (1 driving cycle detection logic)	• Electric throttle body assembly • TP sensor main circuit • ECM
P0123: Output voltage of TP sensor (main) is higher than 4.6 V. (1 driving cycle detection logic)	

DTC Confirmation Procedure

- 1) With ignition switch OFF, connect scan tool.
- 2) Turn ON ignition switch and clear DTC by using scan tool.
- 3) Start engine and run it for 10 sec.
- 4) Check DTC.

DTC Troubleshooting

NOTE

- When DTC P0122 and P0222 are indicated together, it is possible that TP sensor power supply circuit is open.
- When DTC P0123 and P0223 are indicated together, it is possible that TP sensor power supply circuit is shorted to power circuit and/or TP sensor ground circuit is open.

Step	Action	Yes	No
1	Was "Engine and Emission Control System Check" performed?	Go to Step 2.	Go to "Engine and Emission Control System Check".
2	TP sensor and its circuit check 1) Connect scan tool to DLC with ignition switch turned OFF. 2) Turn ON ignition switch, check "TP Sensor 1 Volt" displayed on scan tool when accelerator pedal is released and depressed fully. <i>Is displayed TP sensor value as described voltage in "Scan Tool Data"?</i>	Intermittent trouble. Check for intermittent referring to "Intermittent and Poor Connection Inspection in Section 00".	Go to Step 3.

Step	Action	Yes	No
3	Wire harness check 1) Turn ignition switch OFF position. 2) Disconnect connectors from TP sensor and ECM. 3) Check for proper terminal connection to electric throttle body assembly and ECM connectors. 4) If connections are OK, check that TP sensor (main) circuit is as follows. • Wiring harness resistance of each TP sensor (main) signal, power supply and ground circuit is less than 3 Ω. • Insulation resistance of each TP sensor (main) signal and power supply circuit is infinity between TP sensor connector and vehicle body ground. • Insulation resistance of wire harness is infinity between TP sensor (main) signal terminal and each other terminal at TP sensor connector. • Circuit voltage of each TP sensor (main) signal, power supply and ground circuit is 0 – 1 V with ignition switch turned ON. <i>Are they in good condition?</i>	Go to Step 4.	Repair or replace defective wire harness.
4	TP sensor circuit voltage check 1) Connect connectors to ECM. 2) Turn ignition switch ON position. 3) Check that TP sensor circuit voltage is as follows. • Between TP sensor power supply terminal and TP sensor ground terminal is 5 V. • Between TP sensor (main) signal terminal and TP sensor ground terminal is 5 V. <i>Is it in good condition?</i>	Go to Step 5.	Substitute a known-good ECM and recheck.
5	TP sensor check 1) Check TP sensor for performance referring to “Electric Throttle Body Assembly On-Vehicle Inspection in Section 1C”. <i>Is it in good condition?</i>	Substitute a known-good ECM and recheck.	Replace electric throttle body assembly.

DTC P0131 / P0132: O2 Sensor Circuit Low Voltage / High Voltage (Sensor-1, Bank-1)

S7RW0C1104024

Wiring Diagram

Refer to "DTC P0030: HO2S Heater Control Circuit (Sensor-1, Bank-1)".

DTC Detecting Condition and Trouble Area

DTC detecting condition	Trouble area
DTC P0131: A/F sensor terminal voltage is lower than 1.8 V or A/F sensor output current is lower than -5 mA for 5 sec. with engine running. (2 driving cycle detection logic) DTC P0132: A/F sensor terminal voltage is higher than 3.8 V or A/F sensor output current is higher than 5 mA for 5 sec. with engine running. (2 driving cycle detection logic)	- A/F sensor and/or its circuit - ECM

DTC Confirmation Procedure**NOTE**

Check to make sure that the following conditions are satisfied when using this "DTC Confirmation Procedure".

- The following DTCs are not detected: DTCs related to A/F sensor heater

- 1) With ignition switch OFF, connect scan tool to DLC.
- 2) Turn ON ignition switch and clear DTC.
- 3) Start engine and warm up to normal operating temperature.
- 4) Run engine at idle speed for 1 min. or more.
- 5) Check DTC and pending DTC.

DTC Troubleshooting

Step	Action	Yes	No
1	Was "Engine and Emission Control System Check" performed?	Go to Step 2.	Go to "Engine and Emission Control System Check".
2	Is there DTC(s) other than A/F sensor?	Go to applicable DTC diag. flow.	Go to Step 3.
3	A/F sensor signal check 1) Connect scan tool to DLC with ignition switch turned OFF. 2) Warm up engine to normal operating temperature and keep it at 2000 r/min. for 60 sec. 3) Repeat racing engine (Repeat depressing accelerator pedal 5 to 6 times continuously to enrich A/F mixture and take foot off from pedal to enlean it). Does A/F sensor output current between -0.2 mA and 0.2 mA?	Intermittent trouble. Check for intermittent referring to "Intermittent and Poor Connection Inspection in Section 00".	Go to Step 4.

Step	Action	Yes	No
4	A/F sensor circuit check 1) Disconnect connector from A/F sensor and ECM with ignition switch turned OFF. 2) Check for proper connection of each A/F sensor circuit terminal to A/F sensor connector and to ECM connector. 3) If connections are OK, check A/F sensor circuit for the following. - Resistance of each sensing circuit wire of A/F sensor between A/F sensor connector and ECM connector is less than 2 Ω - Resistance between sensing circuit wires of A/F sensor connector are infinity - Resistance between each sensing circuit wire of A/F sensor connector and vehicle body ground is infinity - Voltage of between each sensing circuit wire of A/F sensor connector and vehicle body ground is 0 V with ignition switch tuned ON <i>Is it in good condition?</i>	Replace A/F sensor and recheck. If this DTC is detected again, substitute a known-good ECM.	Repair or replace defective wire.

DTC P0133: O2 Sensor Circuit Slow Response / Performance (Sensor-1, Bank-1)

S7RW0C1104025

Wiring Diagram

Refer to "DTC P0030: HO2S Heater Control Circuit (Sensor-1, Bank-1)".

A/F Sensor Description

Refer to "A/F Sensor Description".

DTC Detecting Condition and Trouble Area

DTC detecting condition	Trouble area
Ratio between integrated value of A/F sensor output variation and integrated value of short term fuel trim variation is more than specification while vehicle is running. (2 driving cycle detection logic, monitoring once per driving cycle)	A/F sensor

DTC Confirmation Procedure

⚠ WARNING

- When performing a road test, select a place where there is no traffic or possibility of a traffic accident and be very careful during testing to avoid occurrence of an accident.
- Road test should be carried out by 2 persons, a driver and a tester, on a level road.

NOTE

Check to make sure that the following conditions are satisfied when using this “DTC Confirmation Procedure”.

- Intake air temperature at engine start: -10°C (14°F) to 80°C (176°F)
- Intake air temperature: -10°C (14°F) to 70°C (158°F)
- Engine coolant temperature: 70°C (158°F) to 150°C (302°F)
- Altitude (barometric pressure): 2400 m, 8000 ft or less (560 mmHg, 75 kPa or more)
- The following DTCs are not detected: DTCs related to MAF sensor, ECT sensor, IAT sensor, barometric pressure sensor and VSS

- 1) With ignition switch turned OFF, connect scan tool.
- 2) Turn ON ignition switch and clear DTC using scan tool.
- 3) Start engine and warm up to normal operating temperature.
- 4) Drive vehicle at 40 mph (65 km/h) or higher.
- 5) Keep above vehicle speed for 6 min. or more.
- 6) Stop vehicle.
- 7) Check whether O2 sensor readiness/monitoring test has completed or not by using scan tool.
If O2 sensor readiness/monitoring test has not completed, check vehicle conditions (environmental) and repeat Steps 3) through 6).
- 8) Check DTC and pending DTC.

DTC Troubleshooting

Step	Action	Yes	No
1	Was “Engine and Emission Control System Check” performed?	Go to Step 2.	Go to “Engine and Emission Control System Check”.
2	DTC check Is there DTC(s) other than P0133?	Go to applicable DTC diagnosis flow.	Go to Step 3.
3	A/F sensor circuit check 1) Disconnect connector from A/F sensor with ignition switch turned OFF. 2) Check for proper terminal connection to A/F sensor connector. 3) If connections are OK, check that A/F sensor circuit is as follows. • Wiring harness resistance of each “Signal (+) circuit of A/F sensor” and “Signal (–) circuit of A/F sensor” is less than 1 Ω. Is it in good condition?	Replace A/F sensor.	Repair or replace defective wiring harness / connector.

DTC P0134: O2 Sensor Circuit No Activity Detected (Sensor-1, Bank-1)

S7RW0C1104026

Wiring Diagram

Refer to "DTC P0030: HO2S Heater Control Circuit (Sensor-1, Bank-1)".

A/F Sensor Description

Refer to "A/F Sensor Description".

DTC Detecting Condition and Trouble Area

DTC detecting condition	Trouble area
Impedance of A/F sensor element is higher than 500 Ω for 15 sec. even though A/F sensor heater is turned ON for specified time with engine running. (2 driving cycle detection logic)	- A/F sensor and/or its circuit - ECM

DTC Confirmation Procedure**NOTE**

Check to make sure that the following conditions are satisfied when using this "DTC Confirmation Procedure".

- The following DTCs are not detected: DTCs related to A/F sensor heater

- 1) With ignition switch OFF, connect scan tool to DLC.
- 2) Turn ON ignition switch and clear DTC.
- 3) Start engine and warm up to normal operating temperature.
- 4) Run engine at idle speed for 2 min. or more.
- 5) Check DTC and pending DTC.

DTC Troubleshooting

Step	Action	Yes	No
1	Was "Engine and Emission Control System Check" performed?	Go to Step 2.	Go to "Engine and Emission Control System Check".
2	A/F sensor signal check 1) Connect scan tool with ignition switch turned OFF. 2) Warm up engine to normal operating temperature and keep it at 2000 r/min. for 60 sec. 3) Repeat racing engine (Repeat depressing accelerator pedal 5 to 6 times continuously to enrich A/F mixture and take foot off from pedal to enlean it). 4) Check for A/F sensor output current displayed on scan tool. Does A/F sensor output current between -0.2 mA and 0.2 mA?	Intermittent trouble. Check for intermittent referring to "Intermittent and Poor Connection Inspection in Section 00".	Go to Step 3.

1A-78 Engine General Information and Diagnosis:

Step	Action	Yes	No
3	A/F sensor circuit check 1) Disconnect connector from A/F sensor with ignition switch turned OFF. 2) Check for proper terminal connection to A/F sensor connector. 3) If connections are OK, check that A/F sensor circuit is as follows. Wiring harness resistance of each "Signal (+) circuit of A/F sensor", "Signal (–) circuit of A/F sensor", "Control circuit of A/F sensor heater" and "Control ground circuit of A/F sensor heater" is less than 1 Ω. <i>Are they in good condition?</i>	Replace A/F sensor and recheck. If this DTC is detected again, substitute a known-good ECM and recheck.	Repair or replace defective wiring harness / connector.

DTC P0137 / P0138: O2 Sensor (HO2S) Circuit Low Voltage / High Voltage (Sensor-2, Bank-1)

S7RW0C1104027

Wiring Diagram

Refer to "DTC P0030: HO2S Heater Control Circuit (Sensor-1, Bank-1)".

DTC Detecting Condition and Trouble Area

DTC detecting condition	Trouble area
DTC P0137: HO2S voltage is lower than 0.4 V for specified time while vehicle is driving with high engine load (high speed). And HO2S max. voltage minus HO2S min. voltage is less than 0.2 V. (2 driving cycle detection logic)	- HO2S and/or its circuit - Fuel system - ECM - Fuel shortage - Exhaust system - Air intake system
DTC P0138: HO2S voltage is higher than 0.85 V for specified time while vehicle is driving with high engine load (high speed). And HO2S max. voltage minus HO2S min. voltage is less than 0.2 V. (2 driving cycle detection logic)	

DTC Confirmation Procedure**⚠ WARNING**

- When performing a road test, select a place where there is no traffic or possibility of a traffic accident and be very careful during testing to avoid occurrence of an accident.
- Road test should be carried out by 2 persons, a driver and a tester, on a level road.

NOTE

Check to make sure that the following conditions are satisfied when using this "DTC Confirmation Procedure".

- Intake air temperature at engine start: –10 °C (14 °F) to 80 °C (176 °F)
- Intake air temperature: –10 °C (14 °F) to 70 °C (158 °F)
- Engine coolant temperature: 70 °C (158 °F) to 150 °C (302 °F)
- Altitude (barometric pressure): 2400 m, 8000 ft or less (560 mmHg, 75 kPa or more)
- The following DTCs are not detected: DTCs related to MAF sensor, ECT sensor, IAT sensor, barometric pressure sensor, HO2S heater and VSS

- With ignition switch turned OFF, connect scan tool.
- Turn ON ignition switch and clear DTC using scan tool.
- Start engine and warm up to normal operating temperature.
- Increase vehicle speed to 60 – 80 km/h (37 – 50 mile/h) at 5th gear or D range.
- Release accelerator pedal and with engine brake applied, keep vehicle coasting (with fuel cut for 12 sec. or more), then stop vehicle and run engine at idle speed for 60 sec. or more.

- 6) Repeat Step 4).
- 7) Keep above vehicle speed for 8 min. or more. (Throttle valve opening is kept constant in this step.)
- 8) Repeat Step 5).
- 9) Check DTC and pending DTC.

DTC Troubleshooting

Step	Action	Yes	No
1	Was "Engine and Emission Control System Check" performed?	Go to Step 2.	Go to "Engine and Emission Control System Check".
2	Is there DTC(s) other than fuel system (DTC P0171 / P0172) and HO2S (DTC P0140)?	Go to applicable DTC diag. flow.	Go to Step 3.
3	HO2S and its circuit check 1) Connect scan tool to DLC with ignition switch turned OFF. 2) Warm up engine to normal operating temperature and keep it at 2000 r/min. for 60 sec. 3) Repeat racing engine (Repeat depressing accelerator pedal 5 to 6 times continuously to enrich A/F mixture and take foot off from pedal to enlean it). <i>Does HO2S output voltage indicate approx. 0 V for a few seconds, then approx. 0.7 V?</i>	Intermittent trouble. Check for intermittent referring to "Intermittent and Poor Connection Inspection in Section 00".	Go to Step 4.
4	HO2S circuit check 1) Disconnect connector from HO2S and ECM with ignition switch turned OFF. 2) Check for proper connection of each HO2S circuit terminal to HO2S connector and to ECM connector. 3) If connections are OK, check HO2S circuit for the following. - Wiring harness resistance of each "Signal circuit of HO2S" and "Ground circuit of HO2S" is less than 1 Ω. - Insulation resistance between "Signal circuit of HO2S" and vehicle body ground is infinity. - Insulation resistance of wire harness is infinity between "Signal circuit of HO2S" terminal and each other terminal at HO2S connector. - Circuit voltage between "Signal circuit of HO2S" and vehicle body ground is 0 V with ignition switch turned ON. <i>Are they in good condition?</i>	Go to Step 5.	Repair or replace defective wiring harness / connector.
5	HO2S heater circuit check 1) Check HO2S heater circuit referring to Step 2 to 4 of "DTC P0037 / P0038: HO2S Heater Control Circuit Low / High (Sensor-2, Bank-1)". <i>Is circuit in good condition?</i>	Go to Step 6.	Repair or replace defective wiring harness / connector.
6	Exhaust system check 1) Check exhaust system for exhaust gas leakage. <i>Is it OK?</i>	Go to Step 7.	Repair leakage of exhaust system.
7	Fuel injectors and its circuit check 1) Check fuel injectors referring to "Fuel Injector Inspection in Section 1G". <i>Is check result satisfactory?</i>	Go to Step 8.	Faulty injection(s) or its circuit.

1A-80 Engine General Information and Diagnosis:

Step	Action	Yes	No
8	Air intake system check 1) Check air intake system for clog or leak. <i>Is it OK?</i>	Replace HO2S and recheck. If this DTC is detected again, substitute a known-good ECM.	Repair or replace air intake system.

DTC P0140: O2 Sensor (HO2S) Circuit No Activity Detected (Sensor-2, Bank-1)

S7RW0C1104028

Wiring Diagram

Refer to "DTC P0030: HO2S Heater Control Circuit (Sensor-1, Bank-1)".

DTC Detecting Condition and Trouble Area

DTC detecting condition	Trouble area
Output voltage of HO2S is higher than 4.5 V for 0.5 sec. (2 driving cycle detection logic)	- HO2S and/or its circuit - ECM

DTC Confirmation Procedure**NOTE**

Check to make sure that the following conditions are satisfied when using this "DTC Confirmation Procedure".

- The following DTCs are not detected: DTCs related to HO2S heater**

- 1) With ignition switch turned OFF, connect scan tool.
- 2) Turn ON ignition switch and clear DTC using scan tool.
- 3) Start engine and warm up to normal operating temperature.
- 4) Check DTC and pending DTC.

DTC Troubleshooting

Step	Action	Yes	No
1	<i>Was "Engine and Emission Control System Check" performed?</i>	Go to Step 2.	Go to "Engine and Emission Control System Check".
2	Wire harness check 1) Disconnect connector from HO2S and ECM with ignition switch turned OFF. 2) Check for proper connection of each HO2S circuit terminal to HO2S connector and to ECM connector. 3) If connections are OK, check HO2S circuit for the following. - Wiring harness resistance of each "Signal circuit of HO2S" and "Ground circuit of HO2S" is less than 1 Ω. - Insulation resistance between "Signal circuit of HO2S" and vehicle body ground is infinity. - Insulation resistance of wire harness is infinity between "Signal circuit of HO2S" terminal and each other terminal at HO2S connector. - Circuit voltage between "Signal circuit of HO2S" and vehicle body ground is 0 V with ignition switch turned ON. <i>Are they in good condition?</i>	Go to Step 3.	Repair or replace defective wiring harness / connector.

Step	Action	Yes	No
3	HO2S heater circuit check 1) Check HO2S heater circuit referring to Step 2 to 4 of "DTC P0037 / P0038: HO2S Heater Control Circuit Low / High (Sensor-2, Bank-1)". <i>Is circuit in good condition?</i>	Replace HO2S and recheck. If this DTC is detected again, substitute a known-good ECM.	Repair or replace defective wiring harness / connector.

DTC P0171 / P0172: System Too Lean / Too Rich (Sensor-1, Bank-1)

S7RW0C1104029

Wiring Diagram

Refer to "DTC P0030: HO2S Heater Control Circuit (Sensor-1, Bank-1)".

A/F Sensor Description

Refer to "A/F Sensor Description".

DTC Detecting Condition and Trouble Area

DTC detecting condition	Trouble area
DTC P0171: Total fuel trim (short term fuel trim + long term fuel trim) is higher than specified range for 10 sec. 3 times. (2 driving cycle detection logic) DTC P0172: Total fuel trim (short term fuel trim + long term fuel trim) is lower than specified range for 10 sec. 3 times. (2 driving cycle detection logic)	• Vacuum leakage • Exhaust gas leakage • Fuel pressure out of specification • Fuel injector • A/F sensor • MAF sensor • ECT sensor • ECM

DTC Confirmation Procedure**⚠ WARNING**

- When performing a road test, select a place where there is no traffic or possibility of a traffic accident and be very careful during testing to avoid occurrence of an accident.
- Road test should be carried out by 2 persons, a driver and a tester, on a level road.

NOTE

Check to make sure that the following conditions are satisfied when using this "DTC Confirmation Procedure".

- Intake air temperature at engine start: -10 °C (14 °F) to 80 °C (176 °F)
- Intake air temperature: -10 °C (14 °F) to 70 °C (158 °F)
- Altitude (barometric pressure): 2400 m, 8000 ft or less (560 mmHg, 75 kPa or more)
- The following DTCs are not detected: DTCs related to MAF sensor, ECT sensor, IAT sensor, barometric pressure sensor and A/F sensor

- 1) With ignition switch turned OFF, connect scan tool.
- 2) Turn ON ignition switch and print Freeze Frame Data or write them down using scan tool.
- 3) Clear DTC using scan tool.
- 4) Start engine and warm up to normal operating temperature.
- 5) Operate vehicle with condition as noted freeze frame data for 5 min.
- 6) Stop vehicle and check DTC and pending DTC.

DTC Troubleshooting

Step	Action	Yes	No
1	Was "Engine and Emission Control System Check" performed?	Go to Step 2.	Go to "Engine and Emission Control System Check".
2	Is there DTC(s) other than fuel system (DTC P0171 / P0172 / 2195 / 2196)?	Go to applicable DTC diag. flow.	Go to Step 3.
3	Intake system and exhaust system for leakage check 1) Check intake system and exhaust system for leakage. <i>Are intake system and exhaust system in good condition?</i>	Go to Step 4.	Repair or replace defective parts.
4	Fuel pressure check 1) Check fuel pressure referring to "Fuel Pressure Check". <i>Is check result satisfactory?</i>	Go to Step 5.	Repair or replace defective parts.
5	Fuel injectors and its circuit check 1) Check fuel injectors referring to "Fuel Injector Inspection in Section 1G". <i>Is check result satisfactory?</i>	Go to Step 6.	Faulty injection(s) or its circuit.
6	MAF sensor visual inspection 1) Check MAF sensor and air intake system. • Objects which block measuring duct and resistor of MAF sensor. • Other air flow which does not pass MAF sensor. <i>Are they in good condition?</i>	Go to Step 7.	Repair or replace defective part.
7	MAF sensor for performance check 1) With ignition switch turned OFF, connect scan tool to DLC. 2) Start engine and warm up to normal operating temperature. 3) Check MAF value using scan tool (Refer to "Scan Tool Data" for normal value.). <i>Is each value within specified range?</i>	Go to Step 8.	Go to "DTC P0101: Mass or Volume Air Flow Circuit Range / Performance".
8	ECT sensor for performance check 1) Check ECT sensor performance referring to Step 2 to 3 and 5 of "DTC P0116: Engine Coolant Temperature Circuit Range / Performance". <i>Is check result satisfactory?</i>	Go to Step 9.	Faulty ECT sensor or its circuit.
9	A/F sensor for performance check 1) Check A/F sensor referring to Step 3 and 4 of "DTC P0131 / P0132: O2 Sensor Circuit Low Voltage / High Voltage (Sensor-1, Bank-1)". <i>Is check result satisfactory?</i>	Replace A/F sensor and recheck. If this DTC is detected again, substitute a known-good ECM.	Repair or replace defective circuit.

DTC P0222 / P0223: Throttle Position Sensor (Sub) Circuit Low / High

S7RW0C1104030

Wiring Diagram

Refer to "DTC P0122 / P0123: Throttle / Pedal Position Sensor / Switch "A" Circuit Low / High".

DTC Detecting Condition and Trouble Area

DTC detecting condition	Trouble area
DCT P0222: Output voltage of TP sensor (sub) is lower than 0.74 V. (1 driving cycle detection logic)	- TP sensor (sub) circuit - Electric throttle body assembly - ECM
DCT P0223: Output voltage of TP sensor (sub) is higher than 4.74 V. (1 driving cycle detection logic)	

DTC Confirmation Procedure

- 1) With ignition switch turned OFF, connect scan tool.
- 2) Turn ON ignition switch and clear DTC by using scan tool.
- 3) Start engine and it for 10 sec.
- 4) Check DTC.

DTC Troubleshooting**NOTE**

- When DTC P0122 and P0222 are indicated together, it is possible that TP sensor power supply circuit is open.
- When DTC P0123 and P0223 are indicated together, it is possible that TP sensor power supply circuit is shorted to power circuit and/or TP sensor ground circuit is open.

Step	Action	Yes	No
1	Was "Engine and Emission Control System Check" performed?	Go to Step 2.	Go to "Engine and Emission Control System Check".
2	TP sensor and its circuit check 1) Connect scan tool to DLC with ignition switch turned OFF. 2) Turn ON ignition switch, check "TP Sensor 2 Volt" displayed on scan tool when accelerator pedal is idle position and fully depressed. <i>Is displayed TP sensor value as described voltage in "Scan Tool Data"?</i>	Intermittent trouble. Check for intermittent referring to "Intermittent and Poor Connection Inspection in Section 00".	Go to Step 3.

1A-84 Engine General Information and Diagnosis:

Step	Action	Yes	No
3	Wire harness check 1) Turn ignition switch OFF position. 2) Disconnect connectors from TP sensor and ECM. 3) Check for proper terminal connection to electric throttle body assembly and ECM connectors. 4) If connections are OK, check that TP sensor (sub) circuit is as follows. • Wiring harness resistance of each TP sensor (sub) signal, power supply and ground circuit is less than 3 Ω. • Insulation resistance of each TP sensor (sub) signal and power supply circuit is infinity between TP sensor connector and vehicle body ground. • Insulation resistance of wire harness is infinity between TP sensor (sub) signal terminal and each other terminal at TP sensor connector. • Circuit voltage of each TP sensor (sub) signal, power supply and ground circuit is 0 – 1 V with ignition switch turned ON. <i>Are they in good condition?</i>	Go to Step 4.	Repair or replace defective wire harness.
4	TP sensor power supply voltage check 1) Connect connectors to ECM. 2) Turn ignition switch ON position. 3) Check that TP sensor power supply circuit voltage is 5 V between TP sensor power supply terminal and TP sensor ground terminal of TP sensor connector. <i>Is it in good condition?</i>	Go to Step 5.	Repair or replace TP sensor power supply circuit. If circuit is OK, substitute a known-good ECM and recheck.
5	TP sensor check 1) Check TP sensor for performance referring to “Electric Throttle Body Assembly On-Vehicle Inspection in Section 1C”. <i>Is it in good condition?</i>	Substitute a known-good ECM and recheck.	Replace electric throttle body assembly.

DTC P0300 / P0301 / P0302 / P0303 / P0304: Random Misfire Detected / Cylinder 1 / Cylinder 2 / Cylinder 3 / Cylinder 4 Misfire Detected

S7RW0C1104031

System Description

ECM measure the angle of the crankshaft based on the pulse signal from the CKP sensor and CMP sensor for each cylinder. If it detects a large change in the angle speed of the crankshaft, it concludes occurrence of a misfire. When the number of misfire is counted by ECM beyond the DTC detecting condition, it determine the cylinder where the misfire occurred and output it as DTC.

DTC Detecting Condition and Trouble Area

DTC detecting condition	Trouble area
P0300: - Misfire, which causes catalyst to overheat during 200 engine revolutions, is detected at 2 or more cylinders. (MIL blinks as long as this misfire occurs continuously.) - Misfire, which affects exhaust emission adversely during 1000 engine revolution, is detected at 2 or more cylinders. (2 driving cycle detection logic)	- Ignition system - Fuel injector and its circuit - Fuel pressure - Fuel level sensor - Abnormal air drawn in - Engine compression - Valve lash (clearance) - Valve timing - Fuel shortage - Exhaust system - Fuel of poor quality
P0301, P0302, P0303, P0304 - Misfire, which causes catalyst to overheat during 200 engine revolutions, is detected at 1 cylinder. (MIL blinks as long as this misfire occurs continuously.) - Misfire, which affects exhaust emission adversely during 1000 engine revolution, is detected at 1 cylinder. (2 driving cycle detection logic)	

DTC Confirmation Procedure**⚠ WARNING**

- When performing a road test, select a place where there is no traffic or possibility of a traffic accident and very careful during testing to avoid occurrence of an accident.
- Road test should be carried out with 2 persons, a driver and a tester, on a level road.

NOTE

Check to make sure that the following conditions are satisfied when using this "DTC Confirmation Procedure".

- Intake air temperature at engine start: -10°C (14°F) to 80°C (176°F)
- Intake air temperature: -10°C (14°F) to 70°C (158°F)
- Engine coolant temperature: 70°C (158°F) to 150°C (302°F)
- Altitude (barometric pressure): 2400 m, 8000 ft or less (560 mmHg, 75 kPa or more)
- The following DTCs are not detected: DTCs related to MAF sensor, ECT sensor, IAT sensor, barometric pressure sensor, TP sensor, CKP sensor and CMP sensor


- With ignition switch turned OFF, connect scan tool.
- Turn ON ignition switch and print Freeze Frame Data or write them down using scan tool.
- Clear DTC using scan tool.
- Drive vehicle under freeze frame data condition as noted for 1 min. or more.
- Stop vehicle and check DTC and pending DTC.

DTC Troubleshooting

Step	Action	Yes	No
1	Was "Engine and Emission Control System Check" performed?	Go to Step 2.	Go to "Engine and Emission Control System Check".
2	Does fuel level meter indicate "E" level (empty)?	Add fuel and recheck.	Go to Step 3.
3	Air intake system and exhaust system inspection 1) Check air intake system and exhaust system for leakage. <i>Are intake system and exhaust system in good condition?</i>	Go to Step 4.	Repair or replace.
4	Ignition system inspection 1) Check spark plug and ignition spark of cylinder where misfire occurs, referring to "Spark Plug Inspection in Section 1H" and "Ignition Spark Test in Section 1H". <i>Is it in good condition?</i>	Go to Step 5.	Faulty ignition coil, wire harness or spark plug. If OK, substitute a known good ECM and recheck.
5	Fuel injector and its circuit check 1) Check fuel injector circuit referring to "Fuel Injector Circuit Check". <i>Is it in good condition?</i>	Go to Step 6.	Repair or replace.
6	Fuel pressure inspection 1) Check fuel pressure referring to "Fuel Pressure Check". <i>Is check result satisfactory?</i>	Go to Step 7.	Repair or replace.
7	Fuel injector inspection 1) Check fuel injector(s) referring to "Fuel Injector Inspection in Section 1G". <i>Is check result satisfactory?</i>	Go to Step 8.	Replace.
8	Ignition timing check 1) Check ignition timing referring to "Ignition Timing Inspection in Section 1H". <i>Is check result satisfactory?</i>	Go to Step 9.	Check related sensors.
9	Fuel level sensor inspection 1) Check fuel level sensor referring to "Fuel Level Sensor Inspection in Section 9C". <i>Is check result satisfactory?</i>	Go to Step 10.	Repair or replace.
10	Engine mechanical systems check 1) Check engine mechanical parts or system which can cause engine rough idle or poor performance. • Engine compression: Refer to "Compression Check in Section 1D". • Valve lash: Refer to "Valve Lash (Clearance) Inspection in Section 1D". • Valve timing: Refer to "2nd Timing Chain and Chain Tensioner Removal and Installation in Section 1D" and "1st Timing Chain and Chain Tensioner Removal and Installation in Section 1D". <i>Are they in good condition?</i>	Check wire harness and connection of ECM ground, ignition system and fuel injector for intermittent open and short.	Repair or replace.

DTC P0327 / P0328: Knock Sensor Circuit Low / High

S7RW0C1104032

Wiring Diagram

I7RW01110055-02

DTC Detecting Condition and Trouble Area

DTC detecting condition	Trouble area
DTC P0327: Output voltage of knock sensor is lower than 1.23 V for 5 sec. (1 driving cycle detection logic)	- Knock sensor and/or its circuit - ECM
DTC P0328: Output voltage of knock sensor is higher than 3.91 V for 5 sec. (1 driving cycle detection logic)	

DTC Confirmation Procedure

- 1) Connect scan tool to DLC with ignition switch turned OFF.
- 2) Turn ON ignition switch and clear DTC pending DTC and freeze frame data by using scan tool.
- 3) Start engine and run it for 1 minute.
- 4) Check DTC.

DTC Troubleshooting

Step	Action	Yes	No
1	Was "Engine and Emission Control System Check" performed?	Go to Step 2.	Go to "Engine and Emission Control System Check".
2	Knock sensor circuit voltage check 1) Turn ignition switch OFF position. 2) Disconnect connector from knock sensor. 3) Check for proper terminal connection to knock sensor and ECM connectors. 4) If connections are OK, turn ignition switch to ON position. 5) Check that circuit voltage is 5 V between knock sensor signal circuit of knock sensor connector and vehicle body ground. Is it in good condition?	Replace knock sensor.	Go to Step 3.


1A-88 Engine General Information and Diagnosis:

Step	Action	Yes	No
3	Wire harness check 1) Disconnect connector from ECM with ignition switch turned OFF. 2) Check that knock sensor signal circuit is as follows. • Wiring harness resistance of knock sensor signal circuit is less than 3 Ω. • Insulation resistance of knock sensor signal circuit is infinity between knock sensor connector and vehicle body ground. • Circuit voltage of knock sensor signal circuit is 0 – 1 V with ignition switch turned ON. <i>Are they in good condition?</i>	Substitute a known-good ECM and recheck.	Repair or replace defective wire harness.

DTC P0335: Crankshaft Position Sensor “A” Circuit

S7RW0C1104033

Wiring Diagram



I6RW0C110012-01

S: CKP sensor signal circuit	5. Ignition switch	11. "IG COIL" fuse
G: CKP sensor ground circuit	6. Starting motor	12. Starting motor magnet clutch
1. CKP sensor	7. Starting motor control relay	13. "IGN" fuse
2. Sensor plate on crankshaft	8. Transmission range switch (A/T model)	14. Shield wire
3. ECM	9. Fuse box No.2	
4. "ST" fuse	10. "ST SIG" fuse	

DTC Detecting Condition and Trouble Area

DTC detecting condition	Trouble area
CKP sensor signal is not detected for 2 sec. even though starter is operated. (1 driving cycle detection logic)	• CKP sensor and/or its circuit • Sensor plate teeth damaged • ECM • Engine start signal circuit

DTC Confirmation Procedure

NOTE

Check to make sure that the following conditions are satisfied when using this “DTC Confirmation Procedure”.

- The following DTCs are not detected: DTCs related to starter relay


- 1) With ignition switch OFF, connect scan tool.
- 2) Turn ON ignition switch and clear DTC by using scan tool.
- 3) Crank engine for 3 – 5 sec.
- 4) Check DTC.

DTC Troubleshooting

Step	Action	Yes	No
1	Was “Engine and Emission Control System Check” performed?	Go to Step 2.	Go to “Engine and Emission Control System Check”.
2	CKP sensor and connector for proper installation check <i>Is CKP sensor installed properly and connector connected securely?</i>	Go to Step 3.	Correct.
3	Wire harness check 1) Turn ignition switch OFF position. 2) Disconnect connector from ECM. 3) Check that CKP sensor circuit is as follows. • Wiring harness resistance of CKP sensor signal circuit is less than 3 Ω. • Insulation resistance of each CKP sensor signal and ground circuit between CKP sensor connector and vehicle body ground is infinity. • Insulation resistance of wire harness is infinity between CKP sensor signal terminal and each other terminal at CKP sensor connector. • Circuit voltage of each CKP sensor signal circuit and ground circuit is 0 – 1 V with ignition switch turned ON. <i>Are they in good condition?</i>	Go to Step 4.	Repair or replace defective wire harness.
4	Engine start signal check 1) Check starting motor circuit referring to Step 3 of “DTC P0616 / P0617: Starter Relay Circuit Low / High”. <i>Is check result satisfactory?</i>	Go to Step 5.	Repair or replace.
5	CKP sensor check 1) Check CKP sensor and sensor rotor referring to “Crankshaft Position (CKP) Sensor Inspection in Section 1C”. <i>Are they in good condition?</i>	Substitute a known-good ECM and recheck.	Replace CKP sensor and/or sensor rotor.

DTC P0340: Camshaft Position Sensor “A” Circuit

S7RW0C1104034

Wiring Diagram

I6RW0C110013-01

P: CMP sensor power supply circuit	1. CMP sensor	4. Main relay	7. "FI" fuse
S: CMP sensor signal circuit	2. Signal sensor	5. Ignition switch	8. "IG COIL" fuse
G: CMP sensor ground circuit	3. ECM	6. Fuse box No.2	9. "IGN" fuse

System Description

The CMP sensor located on the cylinder head cover consists of the signal generator (magnetic sensor) and signal rotor (intake camshaft portion).

The signal generator generates reference signal through slits in the slit plate which turns together with the camshaft.

Reference signal

The CMP sensor generates 6 pulses of signals each of which has a different waveform length while the camshaft makes one full rotation. Refer to "Inspection of ECM and Its Circuits".

Based on these signals, ECM judges which cylinder piston is in the compression stroke and the engine speed.

DTC Detecting Condition and Trouble Area

DTC detecting condition	Trouble area
If either of the following condition is fulfilled: - CMP sensor pulse is lower than 20 pulses per crankshaft 8 revolutions. - CMP sensor pulse is higher than 28 pulses per crankshaft 8 revolutions. - CMP sensor pulse is lower than 20 pulses per crankshaft 8 revolutions from engine start. (1 driving cycle detection logic)	- CMP sensor and/or its circuit - Signal rotor teeth damaged - ECM

DTC Confirmation Procedure

NOTE

Check to make sure that the following conditions are satisfied when using this “DTC Confirmation Procedure”.

- The following DTCs are not detected: DTCs related to CKP sensor

- 1) With ignition switch OFF, connect scan tool.
- 2) Turn ON ignition switch and clear DTC by using scan tool.
- 3) Crank engine for 5 sec.
- 4) Check DTC.

DTC Troubleshooting

Step	Action	Yes	No
1	Was “Engine and Emission Control System Check” performed?	Go to Step 2.	Go to “Engine and Emission Control System Check”.
2	CMP sensor and connector for proper installation check <i>Is CMP sensor installed properly and connector connected securely?</i>	Go to Step 3.	Correct.
3	CMP sensor power supply voltage check 1) Disconnect connector from CMP sensor with ignition switch turned OFF. 2) Check for proper terminal connection to CMP sensor and ECM connectors. 3) If connections are OK, turn ignition switch to ON position. 4) Check that CMP sensor power supply voltage is battery voltage between CMP sensor connector and vehicle body ground. <i>Is it in good condition?</i>	Go to Step 4.	CMP sensor power supply circuit is open or shorted to ground.
4	Wire harness check 1) Turn ignition switch OFF position. 2) Disconnect connector from ECM. 3) Check that CMP sensor circuit is as follows. • Wiring harness resistance of CMP sensor signal circuit is less than 3 Ω. • Insulation resistance of each CMP sensor signal and ground circuit between CMP sensor connector and vehicle body ground is infinity. • Insulation resistance of wire harness is infinity between CMP sensor signal terminal and each other terminal at CMP sensor connector. • Circuit voltage of each CMP sensor signal circuit and ground circuit is 0 – 1 V with ignition switch turned ON. <i>Are they in good condition?</i>	Go to Step 5.	Repair or replace defective wire harness.
5	CMP sensor signal circuit voltage check 1) Check that CMP sensor signal circuit voltage is 5 V between CMP sensor connector and vehicle body ground. <i>Is it in good condition?</i>	Go to Step 6.	Substitute a known-good ECM and recheck.


1A-92 Engine General Information and Diagnosis:

Step	Action	Yes	No
6	CMP sensor check 1) Check CMP sensor and sensor rotor referring to "Camshaft Position (CMP) Sensor Inspection in Section 1C". <i>Are they in good condition?</i>	Substitute a known-good ECM and recheck.	Replace CMP sensor and/or sensor rotor.

DTC P0420: Catalyst System Efficiency Below Threshold (Bank-1)

S7RW0C1104035

System and Wiring Diagram



I7RW01110058-03

System Description

ECM monitors oxygen concentration in the exhaust gas which has passed the warm up three way catalytic converter by HO2S. When the catalyst is functioning properly, the variation cycle of HO2S output voltage (oxygen concentration) is slower than that of A/F sensor output signal because the amount of oxygen in the exhaust gas is stored in warm up three way catalytic converter.

A/F Sensor Description

Refer to "A/F Sensor Description".

DTC Detecting Condition and Trouble Area

DTC detecting condition	Trouble area
Ratio of integrated value of HO2S output variation per integrated value of A/F sensor output variation is more than specification while vehicle is running after warmed up. (2 driving cycle detection logic, monitoring once per driving cycle)	- Exhaust gas leak - Warm up three way catalytic converter - HO2S - A/F sensor

DTC Confirmation Procedure

⚠ WARNING

- When performing a road test, select a place where there is no traffic or possibility of a traffic accident and very careful during testing to avoid occurrence of an accident.
- Road test should be carried out with 2 persons, a driver and a tester, on a level road.

NOTE

Check to make sure that the following conditions are satisfied when using this “DTC Confirmation Procedure”.

- Intake air temperature at engine start: -10°C (14°F) to 80°C (176°F)
- Intake air temperature: -10°C (14°F) to 70°C (158°F)
- Engine coolant temperature: 70°C (158°F) to 150°C (302°F)
- Altitude (barometric pressure): 2400 m, 8000 ft or less (560 mmHg, 75 kPa or more)
- The following DTCs are not detected: DTCs related to ECT sensor, IAT sensor, MAF sensor, barometric pressure sensor and VSS

- 1) Connect scan tool to DLC with ignition switch turned OFF.
- 2) Turn ON ignition switch and clear DTC using scan tool.
- 3) Start engine and warm up to normal operating temperature.
- 4) Increase vehicle speed to 50 – 60 mph (80 – 100 km/h).
- 5) Keep above vehicle speed for 10 min. or more.
- 6) Stop vehicle.
- 7) Check whether catalyst readiness/monitoring test has completed or not by using scan tool.
If catalyst readiness/monitoring test has not completed, check vehicle conditions (environmental) and repeat Steps 4) through 6).
- 8) Check DTC and pending DTC.


DTC Troubleshooting

Step	Action	Yes	No
1	Was “Engine and Emission Control System Check” performed?	Go to Step 2.	Go to “Engine and Emission Control System Check”.
2	Exhaust system visual inspection 1) Check exhaust system for leaks, damage and loose. <i>Is it in good condition?</i>	Go to Step 3.	Repair or replace.
3	HO2S circuit check 1) Check signal and ground circuits of HO2S for high resistance referring to step 3 of “DTC P0137 / P0138: O2 Sensor (HO2S) Circuit Low Voltage / High Voltage (Sensor-2, Bank-1)”. <i>Are they in good condition?</i>	Go to Step 4.	Repair or replace.
4	1) Replace exhaust manifold (built in warm up three way catalytic converter) and exhaust center pipe (built in three way catalytic converter). 2) Perform DTC confirmation procedure. <i>Is DTC P0420 still detected?</i>	Substitute a known-good ECM and recheck.	End.

DTC P0443: EVAP Emission System Purge Control Valve Circuit

S7RW0C1104036

Wiring Diagram



I6RW0C110014-01

P: EVAP canister purge valve power supply circuit	2. Main relay	5. Ignition switch	8. "IGN" fuse
C: EVAP canister purge valve control circuit	3. "IG COIL" fuse	6. ECM	
1. EVAP canister purge valve	4. Fuse box No.2	7. "FI" fuse	

DTC Detecting Condition and Trouble Area

DTC detecting condition	Trouble area
- Monitor signal of EVAP canister purge valve is not varied for 5 sec. even though EVAP canister purge valve control duty is between 10% and 90%. - Monitor signal of EVAP canister purge valve is lower than specified voltage for 5 sec. even though EVAP canister purge valve control duty is 0%. (2 driving cycle detection logic)	- EVAP canister purge valve and/or its circuit - ECM

DTC Confirmation Procedure

⚠ WARNING

- When performing a road test, select a place where there is no traffic or possibility of a traffic accident and be very careful during testing to avoid occurrence of an accident.
- Road test should be carried out with 2 persons, a driver and a tester, on a level road.

- With ignition switch turned OFF, connect scan tool.
- Turn ON ignition switch and clear DTC by using scan tool.
- Start engine and warm it up to normal operating temperature.
- Drive vehicle at more than 40 km/h (25 mph) for 5 min. or more.
- Stop vehicle and check DTC and pending DTC.


DTC Troubleshooting

Step	Action	Yes	No
1	Was "Engine and Emission Control System Check" performed?	Go to Step 2.	Go to "Engine and Emission Control System Check".
2	EVAP canister purge valve power supply voltage check 1) Disconnect connector from EVAP canister purge valve with ignition switch turned OFF. 2) Check for proper terminal connection to EVAP canister purge valve and ECM connectors. 3) If connections are OK, check that EVAP canister purge valve power supply voltage is battery voltage between EVAP canister purge valve connector and vehicle body ground with ignition switch turned ON. <i>Is it in good condition?</i>	Go to Step 3.	Repair or replace EVAP canister purge valve power supply circuit.
3	Wire harness check 1) Disconnect connector from ECM with ignition switch turned OFF. 2) Check that EVAP canister purge valve circuit is as follows. • Wiring harness resistance of EVAP canister purge valve control circuit is less than 3 Ω. • Insulation resistance of EVAP canister purge valve control circuit is infinity between EVAP canister purge valve connector and vehicle body ground. • Circuit voltage of EVAP canister purge valve control circuit is 0 – 1 V with ignition switch turned ON. <i>Are they in good condition?</i>	Go to Step 4.	Repair or replace defective wire harness.
4	EVAP canister purge valve check 1) Check EVAP canister purge valve coil resistance referring to "EVAP Canister Purge Valve Inspection in Section 1B". <i>Is it in good condition?</i>	Substitute a known-good ECM and recheck.	Replace EVAP canister purge valve.

DTC P0462 / P0463: Fuel Level Sensor Circuit Low / High

S7RW0C1104037

Wiring Diagram



1. Fuel pump assembly					3. Fuel level sensor					5. ECM					7. Fuel pump relay					9. "IGN" fuse				
2. Fuel pump					4. "IG COIL" fuse					6. Main relay					8. "FI" fuse									

DTC Detecting Condition and Trouble Area

DTC detecting condition	Trouble area
DTC P0462: Circuit voltage of fuel level sensor is lower than 0.11 V for 5 sec. with engine running. (1 driving cycle detection logic but MIL does not light up)	- Fuel level sensor and/or its circuit - ECM
DTC P0463: Circuit voltage of fuel level sensor is lower than 4.77 V for more than 5 sec. with engine running. (1 driving cycle detection logic but MIL does not light up)	

DTC Confirmation Procedure



- 1) With ignition switch OFF, connect scan tool.
- 2) Turn ON ignition switch and clear DTC by using scan tool.
- 3) Start engine and run it for 10 sec.
- 4) Check DTC and pending DTC.

DTC Troubleshooting

Step	Action	Yes	No
1	Was "Engine and Emission Control System Check" performed?	Go to Step 2.	Go to "Engine and Emission Control System Check".
2	Fuel level sensor performance check 1) Check fuel level sensor for performance referring to "Fuel Level Sensor Inspection in Section 9C". Is it in good condition?	Go to Step 3.	Replace fuel level sensor.
3	Wire harness check 1) Disconnect connectors from ECM with ignition switch turned OFF. 2) Check for proper terminal connection to fuel level sensor and ECM connectors. 3) If connections are OK, check that fuel level sensor circuit is as follows. • Wiring harness resistance of fuel level sensor circuit is less than 3Ω. • Insulation resistance of fuel level sensor circuit is infinity between fuel level sensor connector and vehicle body ground. • Insulation resistance of wire harness is infinity between fuel level sensor terminal and each other terminal at fuel level sensor connector. • Circuit voltage of fuel level sensor circuit is 0 – 1 V with ignition switch turned ON. Are they in good condition?	Substitute a known-good ECM and recheck.	Repair or replace defective wire harness.

DTC P0480: Fan 1 Control Circuit

S7RW0C1104038

Wiring Diagram

I6RW0C110015-01

A1: Radiator cooling fan relay power supply circuit	4. Radiator cooling fan relay No.2	9. ECT sensor
A2: Radiator cooling fan relay control circuit	5. Radiator cooling fan relay No.3	10. "IG COIL" fuse
1. Fuse Box No.2	6. Radiator cooling fan motor	11. "IGN" fuse
2. Ignition switch	7. Main relay	12. "FI" fuse
3. Radiator cooling fan relay No.1	8. ECM	13. "RDTR" fuse


DTC Detecting Condition and Trouble Area

DTC detecting condition	Trouble area
Monitor signal of radiator cooling fan relay No.1 is lower than specified voltage for 5 sec. even though radiator cooling fan relay No.1 is OFF. (1 driving cycle detection logic)	- Radiator cooling fan relay No.1 and/or its circuit - ECM


DTC Confirmation Procedure

- 1) With ignition switch turned OFF, connect scan tool.
- 2) Turn ON ignition switch and clear DTC by using scan tool.
- 3) Start engine and warm up to normal operating temperature.
- 4) Keep engine at idle speed until engine coolant temperature reaches 102 °C (216 °F) or more.
- 5) Check DTC.

DTC Troubleshooting


Step	Action	Yes	No
1	Was "Engine and Emission Control System Check" performed?	Go to Step 2.	Go to "Engine and Emission Control System Check".
2	Wire harness check 1) Turn ignition switch to OFF position. 2) Check for proper terminal connection to radiator cooling fan relay (No.1, No.2 or No.3) and ECM connectors. 3) If connections are OK, recheck DTC. Is DTC P0480 detected again?	Go to Step 3.	Intermittent trouble.
3	Circuit fuse check 1) Check "RDTR" fuse (1) in fuse box No.2 with ignition switch turned OFF.  Is "RDTR" fuse in good condition?	Go to Step 4.	Check for short in circuits connected to this fuse.
4	Radiator cooling fan control circuit voltage check 1) Turn ignition switch to OFF position. 2) Disconnect connectors from ECM. 3) Turn ignition switch ON position. 4) Check that radiator cooling fan relay (No.1, No.2 or No.3) control circuit voltage is battery voltage between ECM connector and vehicle body ground. Is it in good condition?	Substitute a known-good ECM and recheck.	Go to Step 5.

1A-100 Engine General Information and Diagnosis:

Step	Action	Yes	No
5	Radiator cooling fan control circuit voltage check 1) Turn ignition switch to OFF position. 2) Remove radiator cooling fan relay No.1 (1), No.2 (2) or No.3 (3). 3) Turn ignition switch ON position. 4) Check that radiator cooling fan relay (No.1, No.2 or No.3) power supply voltage is battery voltage between radiator cooling fan relay (No.1, No.2 or No.3) connector and vehicle body ground.  I7RW01110066-01 <i>Is it in good condition?</i>	Go to Step 6.	Repair or replace power supply circuit of radiator cooling fan relay (No.1, No.2 or No.3).
6	Radiator cooling fan relay check 1) Check radiator cooling fan relay No.1, No.2 or No.3 for operation referring to "Radiator Cooling Fan Relay Inspection in Section 1F". <i>Is it in good condition?</i>	Repair or replace control circuit of radiator cooling fan relay (No.1, No.2 or No.3). If circuit is OK, substitute a known-good ECM and recheck.	Replace radiator cooling fan relay No.1, No.2 or No.3.

DTC P0481: Fan 2 Control Circuit

S7RW0C1104039

Wiring Diagram

I6RW0C110016-01

A1: A/C condenser cooling fan relay power supply circuit	4. A/C compressor relay	9. "A/C" fuse
A2: A/C condenser cooling fan relay control circuit	5. A/C condenser cooling fan motor	10. "IG COIL" fuse
1. Fuse Box No.2	6. A/C compressor	11. "IGN" fuse
2. Ignition switch	7. ECM	12. Main relay
3. A/C condenser cooling fan relay	8. "FI" fuse	


DTC Detecting Condition and Trouble Area

DTC detecting condition	Trouble area
Monitor signal of A/C condenser cooling fan relay is lower than specified voltage for 5 sec. even though A/C switch is ON and A/C condenser fan is OFF. (2 driving cycle detection logic)	- A/C condenser cooling fan relay and/or its circuit - ECM

DTC Confirmation Procedure

- 1) With ignition switch turned OFF, connect scan tool.
- 2) Turn ON ignition switch and clear DTC by using scan tool.
- 3) Start engine and run it at idle speed.
- 4) Select blower selector at 1st position or more.
- 5) Turn on A/C switch.
- 6) Wait until A/C condenser fan stops.
- 7) Check DTC and pending DTC.


DTC Troubleshooting

Step	Action	Yes	No
1	Was "Engine and Emission Control System Check" performed?	Go to Step 2.	Go to "Engine and Emission Control System Check".
2	Wire harness check 1) Turn ignition switch to OFF position. 2) Check for proper terminal connection to A/C condenser cooling fan relay and ECM connectors. 3) If connections are OK, recheck DTC. Is DTC P0481 detected again?	Go to Step 3.	Intermittent trouble.
3	Circuit fuse check 1) Check "A/C" fuse (1) in fuse box No.2 with ignition switch turned OFF.  Is "A/C" fuse in good condition?	Go to Step 4.	Check for short in circuits connected to this fuse.
4	A/C condenser fan control circuit voltage check 1) Turn ignition switch to OFF position. 2) Disconnect connectors from ECM. 3) Turn ignition switch ON position. 4) Check that A/C condenser cooling fan relay control circuit voltage is battery voltage between ECM connector and vehicle body ground. Is it in good condition?	Substitute a known-good ECM and recheck.	Go to Step 5.
5	A/C condenser fan control circuit voltage check 1) Turn ignition switch to OFF position. 2) Remove A/C condenser cooling fan relay. 3) Turn ignition switch ON position. 4) Check that A/C condenser cooling fan relay power supply voltage is battery voltage between A/C condenser cooling fan relay connector and vehicle body ground. Is it in good condition?	Go to Step 6.	Repair or replace power supply circuit of A/C condenser cooling fan relay.
6	A/C condenser fan relay check 1) Check A/C condenser cooling fan relay for operation referring to "Radiator Cooling Fan Relay Inspection in Section 1F". Is it in good condition?	Repair or replace control circuit of A/C condenser cooling fan relay. If circuit is OK, substitute a known-good ECM and recheck.	Replace A/C condenser cooling fan relay.

DTC P0500: Vehicle Speed Sensor “A”

S7RW0C1104040

Wiring Diagram



I7RW01110069-01

DTC Detecting Condition and Trouble Area

DTC detecting condition	Trouble area
- Vehicle speed signal is lower than 2 km/h (1.2 mph) for 4 sec. while fuel shuts off at deceleration below 3,600 rpm. - Vehicle speed signal is lower than 2 km/h (1.2 mph) for 4 sec. even though engine is running at D-Range with more than 3,600 rpm (A/T model). (2 driving cycle detection logic)	- Wheel speed sensor (VSS) and/or its circuit - ABS control module - ECM

DTC Confirmation Procedure

⚠ WARNING

- When performing a road test, select a place where there is no traffic or possibility of a traffic accident and be very careful during testing to avoid occurrence of an accident.
- Road test should be carried out by 2 persons, a driver and a tester.

- With ignition switch turned OFF, connect scan tool.
- Turn ON ignition switch and clear DTC using scan tool.
- Warm up engine to normal operating temperature.
- Drive vehicle at 4,000 rpm (engine speed) with 3rd gear (M/T model) or “3” range (A/T model).
- Release accelerator pedal and with engine brake applied, keep vehicle coasting for 6 sec. or more (fuel cut condition for 5 sec. or more) and stop vehicle.
- For A/T model, drive vehicle at more than 3,700 rpm for 10 sec.
- Check DTC and pending DTC.

DTC Troubleshooting

NOTE


Make sure that DTC of CAN communication is not detected by ECM.

Step	Action	Yes	No
1	Was "Engine and Emission Control System Check" performed?	Go to Step 2.	Go to "Engine and Emission Control System Check".
2	Vehicle speed signal check <i>Is vehicle speed displayed on scan tool in Step 4) and 5) of "DTC Confirmation Procedure"?</i>	Intermittent trouble. Check for intermittent referring to "Intermittent and Poor Connection Inspection in Section 00".	Go to Step 3.
3	DTC check in ABS / EPS® control module 1) Connect scan tool to DLC with ignition switch turned OFF. 2) Check DTC in ABS control module. <i>Is there DTC(s) of front wheel speed sensor detected?</i>	Go to applicable DTC diag. Flow.	Check for intermittent referring to "Intermittent and Poor Connection Inspection in Section 00". If OK, substitute a known-good ECM and recheck.

DTC P0504: Brake Switch "A"/"B" Correlation

S7RW0C1104041

Wiring Diagram



I7RW01110070-02

A1: Power supply circuit of brake pedal switch	1. Brake switch	5. Brake light	9. "IGN" fuse
A2: Control circuit of brake pedal switch	2. Brake light switch	6. "IG1 SIG" fuse	
B1: Power supply circuit of brake light switch	3. Brake pedal switch	7. "STOP" fuse	
B2: Control circuit of brake light switch	4. ECM	8. Ignition switch	

DTC Detecting Condition and Trouble Area

DTC detecting condition	Trouble area
If either of the following condition is fulfilled: • Brake pedal switch signal (ON) and brake light switch signal (ON) are detected at a time. • Brake pedal switch signal (OFF) and brake light switch signal (OFF) are detected at a time. (1 driving cycle detection logic but MIL does not light up)	• Brake light switch and/or its circuit • Brake pedal switch and/or its circuit • ECM

DTC Confirmation Procedure**⚠ WARNING**

- When performing a road test, select a place where there is no traffic or possibility of a traffic accident and be very careful during testing to avoid occurrence of an accident.
- Road test should be carried out by 2 persons, a driver and a tester.

- 1) With ignition switch turned OFF, connect scan tool to DLC.
- 2) Turn ON ignition switch and clear DTC.
- 3) Start engine and warm up to normal operating temperature. (ECT approx. 90 – 95 °C, 194 – 203 °F)
- 4) Drive vehicle at 50 km/h (80 mph) or higher for 3 min. or more.
- 5) Stop vehicle.
- 6) Depress brake pedal for 3 times.
- 7) Check DTC.

DTC Troubleshooting

Step	Action	Yes	No
1	Was "Engine and Emission Control System Check" performed?	Go to Step 2.	Go to "Engine and Emission Control System Check".
2	Brake switch check 1) Check brake switch referring to "Brake Light Switch Inspection in Section 9B". Is it in good condition?	Go to Step 3.	Replace brake switch.
3	Brake switch power circuit check 1) Disconnect connector from brake switch connector with ignition switch turned OFF. 2) Check for proper connection to brake switch connector. 3) If connections are OK, check that circuit voltage between "Power supply circuit of brake pedal switch" or "Power supply circuit of brake light switch" and vehicle body ground is battery voltage with ignition switch turned ON. Are they in good condition?	Go to Step 4.	Check related fuse and repair defective circuit.


1A-106 Engine General Information and Diagnosis:

Step	Action	Yes	No
4	Brake switch signal circuit check 1) Disconnect connectors from ECM with ignition switch turned OFF. 2) Check for proper connection of each switch circuit terminal to ECM connector. 3) If connections are OK, check that brake switch circuit is as follows. • Wiring harness resistance of each “Control circuit of brake pedal switch” and “Control circuit of brake light switch” is less than 1 Ω. • Insulation resistance of wire harness is infinity between “Control circuit of brake pedal switch” or “Control circuit of brake light switch” and vehicle body ground. • Insulation resistance of wire harness is infinity between “Control circuit of brake pedal switch” and “Control circuit of brake light switch”. • Circuit voltage between “Control circuit of brake pedal switch” or “Control circuit of brake light switch” and vehicle body ground is 0 V with ignition switch turned ON. <i>Are they in good condition?</i>	Substitute a known-good ECM and recheck.	Repair or replace defective wire.

DTC P0532 / P0533: A/C Refrigerant Pressure Sensor Circuit Low / High

S7RW0C1104042

Wiring Diagram



I6RW0C110017-03

DTC Detecting Condition and Trouble Area

DTC detecting condition	Trouble area
DTC P0532: Output voltage of A/C refrigerant pressure sensor is lower than 0.2 V for 5 sec. (1 driving cycle detection logic but MIL does not light up)	• A/C refrigerant pressure sensor and/or its circuit • ECM
DTC P0533: Output voltage of A/C refrigerant pressure sensor is higher than 4.93 V for 5 sec. (1 driving cycle detection logic but MIL does not light up)	

DTC Confirmation Procedure

- 1) With ignition switch turned OFF, connect scan tool.
- 2) Turn ON ignition switch and clear DTC by using scan tool.
- 3) Check DTC.

DTC Troubleshooting

Step	Action	Yes	No
1	Was "Engine and Emission Control System Check" performed?	Go to Step 2.	Go to "Engine and Emission Control System Check".
2	A/C refrigerant pressure sensor and its circuit check 1) Check A/C refrigerant pressure sensor and its circuit for condition referring to "A/C Refrigerant Pressure Sensor and Its Circuit Inspection: Manual Type in Section 7B". Is it in good condition?	Substitute a known-good ECM and recheck.	Repair or replace defective parts.

DTC P0601 / P0602 / P0607: Internal Control Module Memory Check Sum Error / Control Module Programming Error / Control Module Performance

S7RW0C1104043

System Description

Internal control module is installed in ECM.

DTC Detecting Condition and Trouble Area**NOTE**

After reprogramming of ECM is executed, if the DTC P0601 and/or P0602 are indicated, it is possible that the reprogramming of ECM is not completed correctly.

DTC detecting condition	Trouble area
DTC P0601: Data write error or check sum error. (1 driving cycle detection logic, monitoring once per driving cycle)	• ECM power supply circuit and or ground circuit • ECM
DTC P0602: Data programming error. (1 driving cycle detection logic but MIL does not light up)	
DTC P0607: ECM internal processor error. (1 driving cycle detection logic)	

DTC Confirmation Procedure

- 1) With ignition switch OFF, connect scan tool.
- 2) Turn ON ignition switch and clear DTC by using scan tool.
- 3) Start engine and run it at idle if possible.
- 4) Check DTC.


DTC Troubleshooting

Step	Action	Yes	No
1	DTC recheck 1) Clear DTC referring to "DTC Clearance". 2) Turn OFF ignition switch. 3) Turn ON ignition switch and check DTC. <i>Is DTC P0601 or P0607 still indicated?</i>	Go to Step 2.	Intermittent trouble. Check for intermittent referring to "Intermittent and Poor Connection Inspection in Section 00".
2	ECM reprogramming check <i>Was reprogramming of ECM executed?</i>	Execute reprogramming of ECM correctly once again.	Go to Step 3.
3	ECM power and ground circuit check 1) Check that ECM power supply circuit and ECM ground circuit is in good condition referring to "ECM Power and Ground Circuit Check". <i>Are checking results OK?</i>	Substitute a known-good ECM and recheck.	Repair ECM power or ground circuit.

DTC P0616 / P0617: Starter Relay Circuit Low / High

S7RW0C1104044

Wiring Diagram



I6RW0C110018-00

A1: Start signal circuit	4. Fuse box No.2	8. "ST SIG" fuse
1. ECM	5. Transmission range switch (A/T model)	9. "ST" fuse
2. Starter motor	6. Starting motor control relay	10. "IGN" fuse
3. Ignition switch	7. "IG COIL" fuse	11. Starting motor magnet clutch

Circuit Description

Engine start signal is sent from engine starter circuit while engine cranking.

DTC Detecting Condition and Trouble Area

DTC detecting condition	Trouble area
P0616: Starter switch signal is not detected even though engine speed is 500 rpm or more. (2 driving cycle detection logic)	• Engine start signal circuit • ECM
P0617: Starter switch signal is detected for 180 sec. (2 driving cycle detection logic)	

DTC Confirmation Procedure

- 1) With ignition switch OFF, connect scan tool.
- 2) Turn ON ignition switch and clear DTC by using scan tool.
- 3) Start engine and run it for 1 minute.
- 4) Check DTC and pending DTC.


DTC Troubleshooting

Step	Action	Yes	No
1	Was "Engine and Emission Control System Check" performed?	Go to Step 2.	Go to "Engine and Emission Control System Check".
2	Engine start signal check 1) Connect scan tool to DLC with ignition switch turned OFF. 2) Turn ignition switch to ON position. 3) Check engine start signal of "STARTER SW" under "Data List" displayed on scan tool. • Ignition switch is at "START" position: "ON". • Ignition switch is at other than "START" position: "OFF". Does "STARTER SW" signal correctly?	Intermittent trouble. Check for intermittent referring to "Intermittent and Poor Connection Inspection in Section 00".	Go to Step 3.
3	Engine start signal check 1) Disconnect connectors from ECM with ignition switch turned OFF. 2) Check that circuit voltage between start signal terminal of ECM connector and vehicle body ground. • Ignition switch is at "START" position: 8 – 14 V • Ignition switch is at other than "START" position: 0 – 1 V Is it in good condition?	Substitute a known-good ECM and recheck.	Repair or replace start signal circuit.

DTC P0660 / P0662: Intake Manifold Tuning Valve Control Circuit Open / High

S7RW0C1104045

Wiring Diagram



I7RW01110073-04

DTC Detecting Condition and Trouble Area

DTC detecting condition	Trouble area
DTC P0660: Monitor signal of IMT valve is different from command signal for 5 sec. (1 driving cycle detection logic but MIL does not light up)	• IMT valve and/or its circuit • ECM
DTC P0662: Circuit voltage of IMT valve is higher than specification for 5 sec. when engine revolution is 3,000 rpm or less. (1 driving cycle detection logic but MIL does not light up)	

DTC Confirmation Procedure

NOTE

Check to make sure that the following conditions are satisfied when using this “DTC Confirmation Procedure”.

- The following DTC is not detected (when DTC P0660 is detected): DTC P0662

- 1) With ignition switch turned OFF, connect scan tool.
- 2) Turn ON ignition switch and clear DTC by using scan tool.
- 3) Start engine and run it for 10 sec.
- 4) Check DTC.


DTC Troubleshooting

Step	Action	Yes	No
1	Was "Engine and Emission Control System Check" performed?	Go to Step 2.	Go to "Engine and Emission Control System Check".
2	IMT valve control circuit check 1) Disconnect connectors from IMT valve and ECM with ignition switch turned OFF. 2) Check for proper terminal connection to IMT valve and ECM connectors. 3) If connection are OK, check that IMT valve circuit is as follows. • Wiring harness resistance of IMT valve control circuit is less than 3 Ω. • Insulation resistance of IMT valve control circuit is infinity between IMT valve connector and vehicle body ground. • Insulation resistance of wire harness is infinity between IMT valve control terminal and each other terminal at IMT valve connector. • Circuit voltage of IMT vacuum solenoid valve control circuit is 0 – 1 V with ignition switch turned ON. <i>Are they in good condition?</i>	Go to Step 3.	Repair or replace IMT valve control circuit.
3	IMT vacuum solenoid valve check 1) Check IMT valve referring to "IMT Valve Actuator Inspection in Section 1C". <i>Is it in good condition?</i>	Substitute a known-good ECM and recheck.	Replace IMT valve.

DTC P1510: ECM Back-Up Power Supply Malfunction

S7RW0C1104046

Wiring Diagram



I7RW01110080-01

1A-112 Engine General Information and Diagnosis:

Circuit Description

Battery voltage is supplied so that DTC memory, values for engine control learned by ECM, etc. are kept in ECM even when the ignition switch is turned OFF.

DTC Detecting Condition and Trouble Area

DTC detecting condition	Trouble area
Backup power voltage of internal circuit is lower than specified voltage for 5 sec. (1 driving cycle detection logic)	• Battery voltage supply circuit • ECM

DTC Confirmation Procedure

- 1) With ignition switch OFF, connect scan tool.
- 2) Turn ON ignition switch and clear DTC by using scan tool.
- 3) Run engine at idle speed for 1 min.
- 4) Check DTC.

DTC Troubleshooting

Step	Action	Yes	No
1	Was "Engine and Emission Control System Check" performed?	Go to Step 2.	Go to "Engine and Emission Control System Check".
2	Battery voltage supply circuit check 1) Turn ignition switch to OFF position. 2) Remove ECM from its bracket with ECM connectors connected. 3) Measure ECM back-up power supply voltage between ECM connector and vehicle body ground. <i>Is voltage 10 – 14 V?</i>	Intermittent trouble. Check for intermittent referring to "Intermittent and Poor Connection Inspection in Section 00". If OK, substitute a known-good ECM and recheck.	ECM back-up power supply circuit is open or short.

DTC P2101: Throttle Actuator Control Motor Circuit Range / Performance

S7RW0C1104047

Wiring Diagram

Refer to "DTC P0122 / P0123: Throttle / Pedal Position Sensor / Switch "A" Circuit Low / High".

DTC Detecting Condition and Trouble Area

DTC detecting condition	Trouble area
Throttle actuator control circuit is higher than specified current or temperature for 0.5 sec. (1 driving cycle detection logic)	• Throttle actuator control circuit • Electric throttle body assembly • ECM

DTC Confirmation Procedure

- 1) With ignition switch turned OFF, connect scan tool.
- 2) Turn ON ignition switch and clear DTC by using scan tool.
- 3) Keep the accelerator pedal at idle position for 2 sec.
- 4) Keep the accelerator pedal at fully depressed position for 2 sec.
- 5) Repeat Step 3) and 4) for 3 times.
- 6) Check DTC.

DTC Troubleshooting

Step	Action	Yes	No
1	Was "Engine and Emission Control System Check" performed?	Go to Step 2.	Go to "Engine and Emission Control System Check".
2	DTC check 1) Check DTC. <i>Is any DTC(s) detected?</i>	Go to applicable DTC diag. flow.	Go to Step 3.
3	Throttle actuator circuit check 1) Disconnect connectors from electric throttle body assembly and ECM with ignition switch turned OFF. 2) Check for proper terminal connection to electric throttle body assembly and ECM connectors. 3) If connections are OK, check that throttle actuator control circuit is as follows. - Wiring harness resistance of each throttle actuator control circuit (+) and (–) is less than 3 Ω - Insulation resistance between throttle actuator control circuit (+) or (–) and vehicle body ground is Infinity - Insulation resistance of wire harness is infinity between throttle actuator control circuit (+) and each other terminal at electric throttle body connector - Circuit voltage of throttle actuator control circuit (+) and (–) is 0 – 1 V with ignition switch turned ON. <i>Are they in good condition?</i>	Go to Step 4.	Repair or replace.
4	Electric throttle body assembly check 1) Check electric throttle body for performance referring to "Electric Throttle Body Assembly On-Vehicle Inspection in Section 1C". <i>Is it in good condition?</i>	Substitute a known-good ECM and recheck.	Repair or replace electric throttle body assembly.

DTC P2102: Throttle Actuator Control Motor Circuit Low

S7RW0C1104048

Wiring Diagram

Refer to "DTC P0122 / P0123: Throttle / Pedal Position Sensor / Switch "A" Circuit Low / High".

DTC Detecting Condition and Trouble Area

DTC detecting condition	Trouble area
Power supply voltage of throttle actuator control relay is lower than 5 V for 0.5 sec. even though throttle actuator control relay turned on. (1 driving cycle detection logic)	- Throttle actuator control relay and/or its circuit - ECM

DTC Confirmation Procedure

- 1) With ignition switch turned OFF, connect scan tool.
- 2) Turn ON ignition switch and clear DTC by using scan tool.
- 3) Keep ignition switch is at ON position for 5 sec. or longer.
- 4) Check DTC.

DTC Troubleshooting

Step	Action	Yes	No
1	Was "Engine and Emission Control System Check" performed?	Go to Step 2.	Go to "Engine and Emission Control System Check".
2	Throttle actuator control relay circuit check 1) Remove throttle actuator control relay with ignition switch turned OFF. 2) Check for proper terminal connection to throttle actuator control relay and ECM connectors. 3) If connections are OK, turn ignition switch to ON position. 4) Check that circuit voltage of throttle actuator control relay (coil side and switch side) power supply circuit is battery voltage. <i>Is it in good condition?</i>	Go to Step 3.	Repair or replace power supply circuit of throttle actuator control relay (coil side and/or switch side).
3	Throttle actuator control relay check 1) Check throttle actuator control relay for operation referring to "Engine and Emission Control System Relay Inspection in Section 1C". <i>Is it in good condition?</i>	Go to Step 4.	Replace throttle actuator control relay.
4	Wire harness check 1) Disconnect connectors from ECM with ignition switch turned OFF. 2) Check that throttle actuator control relay (coil side and switch side) circuit is as follows. • Wiring harness resistance of throttle actuator control relay (coil side and switch side) control circuit is less than 3 Ω • Insulation resistance between throttle actuator control relay (coil side and switch side) control circuit and vehicle body ground is Infinity • Insulation resistance of wire harness is infinity between throttle actuator control relay (coil side) terminal and each other terminal at throttle actuator control relay connector • Circuit voltage of throttle actuator control relay (coil side and switch side) control circuit is 0 – 1 V with ignition switch turned ON <i>Are they in good condition?</i>	Substitute a known-good ECM and recheck.	Repair or replace control circuit of throttle actuator control relay (coil side and/or switch side) is open, short or high resistance.

DTC P2103: Throttle Actuator Control Motor Circuit High

S7RW0C1104049

Wiring Diagram

Refer to "DTC P0122 / P0123: Throttle / Pedal Position Sensor / Switch "A" Circuit Low / High".

DTC Detecting Condition and Trouble Area

DTC detecting condition	Trouble area
Power supply voltage of throttle actuator control relay is higher than 5 V for 0.6 sec. even though throttle actuator control relay is turned off. (1 driving detection logic)	- Throttle actuator control relay and/or its circuit - ECM

DTC Confirmation Procedure

- 1) With ignition switch turned OFF, connect scan tool.
- 2) Turn ON ignition switch and clear DTC by using scan tool.
- 3) Keep ignition switch is at ON position for 5 sec. or longer.
- 4) Check DTC.

DTC Troubleshooting

Step	Action	Yes	No
1	Was "Engine and Emission Control System Check" performed?	Go to Step 2.	Go to "Engine and Emission Control System Check".
2	Throttle actuator control relay circuit check 1) Check throttle actuator control relay circuit referring to step 4 of "DTC P2102: Throttle Actuator Control Motor Circuit Low". <i>Are they in good condition?</i>	Go to Step 3.	Repair or replace control circuit of throttle actuator control relay.
3	Electric throttle body assembly check 1) Check electric throttle body for performance referring to "Electric Throttle Body Assembly On-Vehicle Inspection in Section 1C". <i>Is it in good condition?</i>	Substitute a known-good ECM and recheck.	Repair or replace electric throttle body assembly.

DTC P2111: Throttle Actuator Control System - Stuck Open

S7RW0C1104050

Wiring Diagram

Refer to "DTC P0122 / P0123: Throttle / Pedal Position Sensor / Switch "A" Circuit Low / High".

DTC Detecting Condition and Trouble Area

DTC detecting condition	Trouble area
Throttle position does not change by 2° during diagnosing throttle valve at ignition switch turned OFF. (1 driving detection logic)	- Electric throttle body assembly - ECM

DTC Confirmation Procedure

- 1) With ignition switch turned OFF, connect scan tool.
- 2) Turn ON ignition switch and clear DTC using scan tool.
- 3) Ignition switch turned OFF for 20 sec. or more.
- 4) Turn ON ignition switch and check DTC.

DTC Troubleshooting

Step	Action	Yes	No
1	Was "Engine and Emission Control System Check" performed?	Go to Step 2.	Go to "Engine and Emission Control System Check".
2	Electric throttle body assembly check 1) Check electric throttle body for operation and condition referring to "Electric Throttle Body Assembly On-Vehicle Inspection in Section 1C". <i>Is it in good condition?</i>	Substitute a known-good ECM and recheck.	Repair or replace electric throttle body assembly.

DTC P2119: Throttle Actuator Control Throttle Body Range / Performance

S7RW0C1104051

Wiring Diagram

Refer to "DTC P0122 / P0123: Throttle / Pedal Position Sensor / Switch "A" Circuit Low / High".

DTC Detecting Condition and Trouble Area

DTC detecting condition	Trouble area
Difference between the measured (actual) throttle valve opening angle and the target throttle valve opening angle which is calculated based on accelerator pedal opening angle and engine condition is more than specification for specified time. (1 driving detection logic)	• Throttle actuator control circuit • Electric throttle body assembly • ECM

DTC Confirmation Procedure

- 1) With ignition switch turned OFF, connect scan tool.
- 2) Turn ON ignition switch and clear DTC by using scan tool.
- 3) Keep the accelerator pedal at idle position for 2 sec.
- 4) Keep the accelerator pedal at fully depressed position for 2 sec.
- 5) Repeat Step 3) and 4) for 3 times.
- 6) Check DTC.


DTC Troubleshooting

Step	Action	Yes	No
1	Was "Engine and Emission Control System Check" performed?	Go to Step 2.	Go to "Engine and Emission Control System Check".
2	Electric throttle body assembly system check 1) Connect scan tool to DLC with ignition switch turned OFF. 2) Turn ON ignition switch, check each voltage of "TP Sensor 1 Volt" and "TP Sensor 2 Volt" displayed on scan tool when accelerator pedal is idle position and fully depressed. <i>Is displayed each TP sensor value as described voltage in "Scan Tool Data"?</i>	Intermittent trouble. Check for intermittent referring to "Intermittent and Poor Connection Inspection in Section 00".	Go to Step 3.

Step	Action	Yes	No
3	Wire harness check 1) Disconnect connectors from electric throttle body assembly and ECM with ignition switch turned OFF. 2) Check for proper terminal connection to electric throttle body assembly connector and ECM. 3) If connection are OK, check that throttle actuator control circuit is as follows. • Wiring harness resistance of throttle actuator control circuit (+) and (–) is less than 3 Ω • Insulation resistance between throttle actuator control circuit (+) and (–) and vehicle body ground is Infinity • Insulation resistance between throttle actuator control circuit (+) and (–) is infinity • Circuit voltage of throttle actuator control circuit (+) and (–) is 0 – 1 V with ignition switch turned ON <i>Are they in good condition?</i>	Go to Step 4.	Repair or replace control circuit of throttle actuator (+) and/or (–) is open, short or high resistance.
4	Electric throttle body assembly check 1) Check electric throttle body for operation and condition referring to “Electric Throttle Body Assembly On-Vehicle Inspection in Section 1C”. <i>Is it in good condition?</i>	Substitute a known-good ECM and recheck.	Repair or replace electric throttle body assembly.

DTC P2122 / P2123: Throttle / Pedal Position Sensor / Switch “D” Circuit Low / High

S7RW0C1104052

Wiring Diagram

I7RW01110083-02

A1: APP sensor (main) power supply circuit	B2: APP sensor (sub) signal circuit	3. APP sensor (sub)
A2: APP sensor (main) signal circuit	B3: APP sensor (sub) ground circuit	4. ECM
A3: APP sensor (main) ground circuit	1. APP sensor assembly	5. Ground of APP sensor for shield wire
B1: APP sensor (sub) power supply circuit	2. APP sensor (main)	

DTC Detecting Condition and Trouble Area

DTC detecting condition	Trouble area
DTC P2122: Output voltage of APP sensor (main) is lower than 0.45 V for 0.5 sec. (1 driving cycle detection logic)	• APP sensor (main) and/or its circuit • ECM
DTC P2123: Output voltage of APP sensor (main) is higher than 4.8 V for 0.5 sec. (1 driving cycle detection logic)	

DTC Confirmation Procedure

- 1) With ignition switch turned OFF, connect scan tool.
- 2) Turn ON ignition switch and clear DTC by using scan tool.
- 3) Keep the accelerator pedal at idle position for 2 sec.
- 4) Keep the accelerator pedal at fully depressed position for 2 sec.
- 5) Repeat Step 3) and 4) for 3 times.
- 6) Check DTC.

DTC Troubleshooting

Step	Action	Yes	No
1	Was "Engine and Emission Control System Check" performed?	Go to Step 2.	Go to "Engine and Emission Control System Check".
2	APP sensor assembly mounting check 1) Check that APP sensor assembly has been mounted to vehicle body properly (no pinched floor carpet, etc.). Is it in good condition?	Go to Step 3.	Reinstall APP sensor assembly properly referring to "Accelerator Pedal Position (APP) Sensor Assembly Removal and Installation in Section 1C".
3	APP sensor (main) and its circuit check 1) Connect scan tool to DLC with ignition switch turned OFF. 2) Turn ON ignition switch, check "APP Sensor 1 Volt" displayed on scan tool when accelerator pedal is released and fully depressed. Is displayed APP sensor value as described voltage in "Scan Tool Data"?	Intermittent trouble. Check for intermittent referring to "Intermittent and Poor Connection Inspection in Section 00".	Go to Step 4.

Step	Action	Yes	No
4	Wire harness check 1) Turn ignition switch OFF position. 2) Disconnect connectors from APP sensor and ECM. 3) Check for proper terminal connection to APP sensor and ECM connectors. 4) If connections are OK, check that APP sensor (main) circuit is as follows. • Wiring harness resistance of each APP sensor (main) power supply, signal and ground circuit is less than 3 Ω • Insulation resistance of each APP sensor (main) power supply and signal circuit is infinity between APP sensor connector and vehicle body ground. • Insulation resistance of wire harness is infinity between APP sensor (main) power supply terminal and each other terminal at APP sensor connector. • Circuit voltage of each APP sensor (main) power supply, signal and ground circuit is 0 – 1 V with ignition switch turned ON <i>Are they in good condition?</i>	Go to Step 5.	Repair or replace APP sensor (main) power supply, signal and/or ground circuit(s).
5	APP sensor power supply voltage check 1) Connect connectors to ECM. 2) Turn ignition switch ON position. 3) Check that circuit voltage is 5 V between APP sensor (main) power supply terminal and vehicle body ground. <i>Is it in good condition?</i>	Go to Step 6.	Substitute a known-good ECM and recheck.
6	APP sensor check 1) Check APP sensor for performance referring to “Accelerator Pedal Position (APP) Sensor Assembly Inspection in Section 1C”. <i>Is it in good condition?</i>	Substitute a known-good ECM and recheck.	Replace APP sensor assembly.

DTC P2127 / P2128: Throttle / Pedal Position Sensor / Switch “E” Circuit Low / High Input

S7RW0C1104053

Wiring Diagram

Refer to “DTC P2122 / P2123: Throttle / Pedal Position Sensor / Switch “D” Circuit Low / High”.

DTC Detecting Condition and Trouble Area

DTC detecting condition	Trouble area
DTC P2127: Output voltage of APP sensor (sub) is lower than 0.23 V for 0.5 sec. (1 driving cycle detection logic)	• APP sensor (sub) and/or its circuit • ECM
DTC P2128: Output voltage of APP sensor (sub) is higher than 2.4 V for 0.5 sec. (1 driving cycle detection logic)	

DTC Confirmation Procedure

- 1) With ignition switch turned OFF, connect scan tool.
- 2) Turn ON ignition switch and clear DTC by using scan tool.
- 3) Keep the accelerator pedal at idle position for 2 sec.
- 4) Keep the accelerator pedal at fully depressed position for 2 sec.
- 5) Repeat Step 3) and 4) for 3 times.
- 6) Check DTC.

DTC Troubleshooting

Step	Action	Yes	No
1	Was "Engine and Emission Control System Check" performed?	Go to Step 2.	Go to "Engine and Emission Control System Check".
2	APP sensor assembly mounting check 1) Check that APP sensor assembly has been mounted to vehicle body properly (no pinched floor carpet, etc.). <i>Is it in good condition?</i>	Go to Step 3.	Reinstall APP sensor assembly properly referring to "Accelerator Pedal Position (APP) Sensor Assembly Removal and Installation in Section 1C".
3	APP sensor (sub) and its circuit check 1) Connect scan tool to DLC with ignition switch turned OFF. 2) Turn ON ignition switch, check "APP Sensor 2 Volt" displayed on scan tool when accelerator pedal is idle position and fully depressed. <i>Is displayed APP sensor value as described voltage in "Scan Tool Data"?</i>	Intermittent trouble. Check for intermittent referring to "Intermittent and Poor Connection Inspection in Section 00".	Go to Step 4.
4	Wire harness check 1) Turn ignition switch OFF position. 2) Disconnect connectors from APP sensor and ECM. 3) Check for proper terminal connection to APP sensor and ECM connectors. 4) If connections are OK, check that APP sensor (sub) circuit is as follows. • Wiring harness resistance of each APP sensor (sub) power supply, signal and ground circuit is less than 3 Ω • Insulation resistance of each APP sensor (sub) power supply and signal circuit is infinity between APP sensor connector and vehicle body ground. • Insulation resistance of wire harness is infinity between APP sensor (sub) power supply terminal and each other terminal at APP sensor connector. • Circuit voltage of each APP sensor (sub) power supply, signal and ground circuit is 0 – 1 V with ignition switch turned ON <i>Are they in good condition?</i>	Go to Step 5.	Repair or replace APP sensor (sub) power supply, signal and/or ground circuit(s).

Step	Action	Yes	No
5	APP sensor power supply voltage check 1) Connect connectors to ECM. 2) Turn ignition switch ON position. 3) Check that circuit voltage is 5 V between APP sensor (sub) power supply terminal and vehicle body ground. <i>Is it in good condition?</i>	Go to Step 6.	Substitute a known-good ECM and recheck.
6	APP sensor check 1) Check APP sensor for performance referring to "Accelerator Pedal Position (APP) Sensor Assembly On-Vehicle Inspection in Section 1C". <i>Is it in good condition?</i>	Substitute a known-good ECM and recheck.	Replace APP sensor assembly.

DTC P2135: Throttle / Pedal Position Sensor / Switch "A" / "B" Voltage Correction

S7RW0C1104054

Wiring Diagram

Refer to "DTC P0122 / P0123: Throttle / Pedal Position Sensor / Switch "A" Circuit Low / High".

DTC Detecting Condition and Trouble Area

DTC detecting condition	Trouble area
Difference between the opening angle based on TP sensor (main) and the opening angle based on TP sensor (sub) is more than specification for 0.2 sec. (1 driving cycle detection logic)	- TP sensor and/or its circuit - Electric throttle body assembly - ECM

DTC Confirmation Procedure

- 1) With ignition switch turned OFF, connect scan tool.
- 2) Turn ON ignition switch and clear DTC by using scan tool.
- 3) Keep the accelerator pedal at idle position for 2 sec.
- 4) Keep the accelerator pedal at fully depressed position for 2 sec.
- 5) Repeat Step 3) and 4) for 3 times.
- 6) Check DTC.

DTC Troubleshooting

Step	Action	Yes	No
1	Was "Engine and Emission Control System Check" performed?	Go to Step 2.	Go to "Engine and Emission Control System Check".
2	TP sensor and its circuit check 1) Connect scan tool to DLC with ignition switch turned OFF. 2) Turn ON ignition switch, check "TP Sensor 1 Volt" and "TP Sensor 2 Volt" displayed on scan tool when accelerator pedal is released and fully depressed. <i>Is displayed TP sensor value as described voltage in "Scan Tool Data"?</i>	Intermittent trouble. Check for intermittent referring to "Intermittent and Poor Connection Inspection in Section 00".	Go to Step 3.
3	TP sensor check 1) Check TP sensor for performance referring to "Electric Throttle Body Assembly On-Vehicle Inspection in Section 1C". <i>Is it in good condition?</i>	Go to Step 4.	Replace electric throttle body assembly.

1A-122 Engine General Information and Diagnosis:

Step	Action	Yes	No
4	Wire harness check 1) Check TP sensor (main and sub) circuit for condition. For TP sensor (main) circuit, refer to Step 3 of "DTC P0122 / P0123: Throttle / Pedal Position Sensor / Switch "A" Circuit Low / High". For TP sensor (sub) circuit, refer to Step 3 of "DTC P0222 / P0223: Throttle Position Sensor (Sub) Circuit Low / High". <i>Is it in good condition?</i>	Substitute a known-good ECM and recheck.	Repair or replace.

DTC P2138: Pedal Position Sensor (Main / Sub) Voltage Correction

S7RW0C1104055

Wiring Diagram

Refer to "DTC P0122 / P0123: Throttle / Pedal Position Sensor / Switch "A" Circuit Low / High".

DTC Detecting Condition and Trouble Area

DTC detecting condition	Trouble area
Difference between the opening angle based on APP sensor (main) and the opening angle based on APP sensor (sub) is more than specification for 0.5 sec. (1 driving detection logic)	• APP sensor (main) and/or its circuit • APP sensor assembly • ECM

DTC Confirmation Procedure

- 1) With ignition switch turned OFF, connect scan tool.
- 2) Turn ON ignition switch and clear DTC by using scan tool.
- 3) Keep the accelerator pedal at idle position for 2 sec.
- 4) Keep the accelerator pedal at fully depressed position for 2 sec.
- 5) Repeat Step 3) and 4) for 3 times.
- 6) Check DTC.

DTC Troubleshooting

Step	Action	Yes	No
1	<i>Was "Engine and Emission Control System Check" performed?</i>	Go to Step 2.	Go to "Engine and Emission Control System Check".
2	TP sensor and its circuit check 1) Connect scan tool to DLC with ignition switch turned OFF. 2) Turn ON ignition switch, check "APP Sensor 1 Volt" and "APP Sensor 2 Volt" displayed on scan tool when accelerator pedal is idle position and fully depressed. <i>Is displayed each APP sensor value as described voltage in "Scan Tool Data"?</i>	Intermittent trouble. Check for intermittent referring to "Intermittent and Poor Connection Inspection in Section 00".	Go to Step 3.
3	APP sensor check 1) Check APP sensor for performance referring to "Accelerator Pedal Position (APP) Sensor Assembly On-Vehicle Inspection in Section 1C". <i>Is it in good condition?</i>	Go to Step 4.	Replace APP sensor assembly.

Step	Action	Yes	No
4	Wire harness check 1) Check APP sensor (main and sub) circuit for condition. For APP sensor (main) circuit, refer to Step 4 of "DTC P2122 / P2123: Throttle / Pedal Position Sensor / Switch "D" Circuit Low / High". For TP sensor (sub) circuit, refer to Step 4 of "DTC P2127 / P2128: Throttle / Pedal Position Sensor / Switch "E" Circuit Low / High Input". <i>Is it in good condition?</i>	Substitute a known-good ECM and recheck.	Repair or replace.

DTC P2195 / P2196: O2 Sensor Signal Stuck Lean / Stuck Rich (Sensor-1, Bank-1)

S7RW0C1104056

Wiring Diagram

Refer to "DTC P0030: HO2S Heater Control Circuit (Sensor-1, Bank-1)".

A/F Sensor Description

Refer to "A/F Sensor Description".

DTC Detecting Condition and Trouble Area

DTC detecting condition	Trouble area
DTC P2195: A/F sensor signal is higher than 1.15 for 10 sec. even though HO2S voltage is higher than 0.2 V while vehicle is running after warmed up. (2 driving cycle detection logic) DTC P2196: A/F sensor signal is lower than 0.85 for 10 sec. even though HO2S voltage is lower than 0.7 V while vehicle is running after warmed up. (2 driving cycle detection logic)	- A/F sensor and/or its circuit - ECM

DTC Confirmation Procedure**▲ WARNING**

- When performing a road test, select a place where there is no traffic or possibility of a traffic accident and very careful during testing to avoid occurrence of an accident.
- Road test should be carried out with 2 persons, a driver and a tester, on a level road.

NOTE

Check to make sure that the following conditions are satisfied when using this "DTC Confirmation Procedure".

- Intake air temperature at engine start: -10 °C (14 °F) to 80 °C (176 °F)
- Intake air temperature: -10 °C (14 °F) to 70 °C (158 °F)
- Altitude (barometric pressure): 2400 m, 8000 ft or less (560 mmHg, 75 kPa or more)
- Engine coolant temperature: 70 °C (158 °F) to 150 °C(302 °F)
- The following DTCs are not detected: ECT sensor, IAT sensor, MAF sensor and barometric pressure sensor

- With ignition switch OFF, connect scan tool.
- Turn ON ignition switch and clear DTC by using scan tool.
- Start engine and warm up to normal operating temperature.
- Drive vehicle at 40 mph (60 km/h) or higher.
- Keep above vehicle speed for 4 min. or more. (Throttle valve opening is kept constant in this step.)
- Check DTC and pending DTC.

DTC Troubleshooting

Step	Action	Yes	No
1	Was "Engine and Emission Control System Check" performed?	Go to Step 2.	Go to "Engine and Emission Control System Check".
2	DTC check <i>Is there any DTC(s)?</i>	Go to applicable DTC.	Go to Step 3.
3	A/F sensor circuit check 1) Disconnect connector from A/F sensor with ignition switch turned OFF. 2) Check for proper terminal connection to A/F sensor connector. 3) If connections are OK, check that A/F sensor circuit is as follows. Wiring harness resistance of each "Signal (+) circuit of A/F sensor" and "Signal (-) circuit of A/F sensor" is less than 1 Ω. <i>Is it in good condition?</i>	Replace A/F sensor and recheck. If this DTC is detected again, substitute a known-good ECM.	Repair or replace defective wiring harness / connector.

DTC P2227 / P2228 / P2229: Barometric Pressure Circuit Performance / Low / High

S7RW0C1104057

System Description

Barometric pressure sensor is installed in ECM.

DTC Detecting Condition and Trouble Area

DTC detecting condition	Trouble area
DTC P2227: Difference between barometric pressure value and estimated barometric pressure (according engine load rate and engine speed) is more than 25 kPa for 1.25 sec. (2 driving cycle detection logic, monitoring once per driving cycle)	Barometric pressure sensor in ECM
DTC P2228: Output signal of barometric pressure sensor is higher than 4.7 V for 0.5 sec. (1 driving cycle detection logic)	
DTC P2229: Output signal of barometric pressure sensor is lower than 1.95 V for 0.5 sec. (1 driving cycle detection logic)	

DTC Confirmation Procedure

DTC P2227 / P2228 / P2229

- 1) Connect scan tool to DLC with ignition switch turned OFF.
- 2) Turn ON ignition switch and clear DTC and freeze frame data by using scan tool and warm up engine to normal operating temperature.
- 3) Check DTC and pending DTC.

DTC Troubleshooting

Step	Action	Yes	No
1	Was "Engine and Emission Control System Check" performed?	Go to Step 2.	Go to "Engine and Emission Control System Description".
2	DTC check <i>Is there any DTC(s) other than P2227, P2228 and P2229?</i>	Go to applicable DTC diag. flow.	Substitute a known good ECM and recheck.

DTC U0073: Control Module Communication Bus Off

S7RW0C1104058

Refer to "Troubleshooting for CAN-DTC".

DTC U0101: Lost Communication with TCM

S7RW0C1104059

Refer to "Troubleshooting for CAN-DTC".

DTC U0121: Lost Communication with ABS / ESP® Control Module

S7RW0C1104060

Refer to "Troubleshooting for CAN-DTC".

DTC U0140: Lost Communication with Body Control Module

S7RW0C1104061

Refer to "Troubleshooting for CAN-DTC".

Troubleshooting for CAN-DTC

S7RW0C1104062

Perform this troubleshooting when CAN-DTC is detected.

NOTE

- When performing this troubleshooting, be sure to have full understanding of "Precaution on CAN Troubleshooting" and observe it.
- It may be possible that CAN system has trouble because of fuse blown or low battery voltage. Before troubleshooting, check to make sure that fuse, battery voltage and generator status are normal.
- When performing "Communication Bus Check" using SUZUKI scan tool (SUZUKI-SDT) in each step of this troubleshooting, use the following table to determine whether the control module is in good condition or not.
Also, while performing "Communication Bus Check", do not perform any work other than instructed in this troubleshooting. Or, it may occur that display of control module/sensor on SUZUKI-SDT screen and/or its background color may change.

Judgment	Display of Communication Bus Check
Normal	• All connected control modules/sensors (communicated by CAN) are displayed and its back ground color is "White".
Abnormal	• Even one of connected control modules/sensors (communicated by CAN) is not displayed. • Display of even one of connected control modules/sensors (communicated by CAN) changes. • Background color of even one of connected control modules/sensors (communicated by CAN) is displayed in "Gray" or "Light green". • Background color of even one of connected control modules/sensors (communicated by CAN) changes

- When disconnecting each control module connector in this troubleshooting, various DTCs will be detected. Be sure to clear DTCs in the following control modules after completing this troubleshooting.
 - ECM
 - BCM
 - TCM
 - Keyless start control module
 - 4WD control module
 - HVAC control module (Auto A/C model)
 - P/S control module

Wiring Diagram

Refer to "Troubleshooting for Communication Error with Scan Tool Using CAN".


Trouble area

Refer to "Troubleshooting for Communication Error with Scan Tool Using CAN".

Troubleshooting

Step	Action	Yes	No
1	DTC Check 1) Turn ignition switch to OFF position. 2) Connect scan tool to DLC. 3) Check DTC in the following control modules. • ECM • TCM • BCM • Keyless start control module • 4WD control module <i>Is there any DTC other than CAN-DTC?</i>	Go to applicable troubleshooting of DTC other than CAN-DTC.	Go to Step 2.
2	Control module connector check 1) Turn ignition switch to OFF position. 2) Be sure to disconnect scan tool from DLC. 3) Disconnect all the following control module connectors. • Control modules communicated by CAN – ECM – TCM – ABS control module – BCM – Combination meter – Keyless start control module – 4WD control module 4) Check for proper connection to terminal of each CAN line of all control module (communicated by CAN) connectors. 5) If OK, connect all connectors of control module communicated by CAN securely. 6) Recheck DTC for all control modules communicated by CAN. <i>Is there any CAN-DTC?</i>	Go to Step 3.	Intermittent trouble. Check for intermittent referring to “Intermittent and Poor Connection Inspection in Section 00”.

Step	Action	Yes	No
3	CAN line check 1) Turn ignition switch to OFF position. 2) Disconnect connectors of all control module communicated by CAN. 3) Check all the following CAN lines for open, short to power circuit, short to ground circuit, short to other CAN line and high resistance. • Between BCM connector and DLC • Between BCM connector and ABS control module connector • Between ABS control module connector and ECM connector • Between ECM connector and TCM connector • Between BCM connector and keyless start control module connector • Between combination meter connector and 4WD control module connector • Between BCM connector and combination meter connector <i>Are all CAN lines in good condition?</i>	Go to Step 4.	Repair CAN line.
4	Power and ground circuits check of BCM, ECM, ABS control module and combination meter 1) Check power and ground circuits the following control module. • ECM: Refer to "ECM Power and Ground Circuit Check". • BCM: Refer to "BCM Power Circuit and Ground Circuit Check in Section 10B". • Combination meter: Refer to "Combination Meter Circuit Diagram in Section 9C". • ABS control module: Refer to "ABS Hydraulic Unit / Control Module Assembly Power and Ground Circuit Check in Section 4E". <i>Are they in good condition?</i>	Go to Step 5.	Repair power and/or ground circuit.
5	CAN communication check of BCM, ECM, ABS control module and combination meter 1) Turn ignition switch to OFF position. 2) Connect BCM, ECM, ABS control module and combination meter connectors. 3) Perform "Communication Bus Check" under "Bus Check" using SUZUKI-SDT with ignition switch turned ON. <i>Are all of BCM, ECM, ABS control module and combination meter normally displayed?</i>	Go to Step 12.	Go to Step 6.

Step	Action	Yes	No
6	Terminating resistance check in ECM and combination meter 1) Turn ignition switch to OFF position and then disconnect negative (–) cable at battery. 2) Measure resistance between CAN High terminal (2) and CAN Low terminal (3) on DLC (1).  I7RW01110098-01 <i>If resistance 57 – 67 Ω?</i>	Go to Step 7.	Go to Step 8.
7	Substitute ECM and recheck 1) Substitute a known-good ECM and recheck. <i>Is it in good condition?</i>	End.	Substitute a known-good combination meter and recheck. If NG, go to Step 11.
8	Terminating resistance check in ECM 1) Make sure that ignition switch is OFF position and battery negative (–) cable is disconnected. 2) Disconnect combination meter connector. 3) Measure resistance between CAN high terminal and CAN low terminal on DLC as the same manner as Step 6. <i>Is resistance 114 – 134 Ω?</i>	Substitute a known-good combination meter.	Go to Step 9.
9	Internal circuit check in BCM 1) Make sure that ignition switch is OFF position and battery negative (–) cable is disconnected. 2) Disconnect ABS control module connector. 3) Measure resistance between the followings - Between CAN high terminal on DLC and “E08-2” terminal on ABS control module connector - Between CAN low terminal on DLC and “E08-13” terminal on ABS control module connector <i>Is each resistance 0 – 1 Ω?</i>	Go to Step 10.	Substitute a known-good BCM.
10	Internal circuit check in ABS control module 1) Make sure that ignition switch is OFF position and battery negative (–) cable is disconnected. 2) Connect ABS control module connector and disconnect ECM connector. 3) Measure resistance between the followings - Between CAN High terminal on DLC and “E01-4” terminal on ECM connector - Between CAN Low terminal on DLC and “E01-19” terminal on ECM connector <i>If each resistance 0 – 1 Ω?</i>	Substitute a known-good ECM and recheck. If NG, go to step 11.	Substitute a known-good ABS control module.
11	Substitute BCM and recheck 1) Substitute a known-good BCM and recheck. <i>Is it in good condition?</i>	End.	Substitute a known-good ABS control module.

Step	Action	Yes	No
12	CAN communication check of TCM 1) Turn ignition switch to OFF position. 2) Connect TCM connectors. 3) Perform "Communication Bus Check" under "Bus Check" using SUZUKI-SDT with ignition switch turned ON. <i>Are all of BCM, ECM, ABS control module, combination meter and TCM normally displayed?</i>	Go to Step 13.	Check power and ground circuits of TCM referring to "TCM Power and Ground Circuit Check in Section 5A". If OK, substitute a known-good TCM.
13	CAN communication check of keyless start control module 1) Turn ignition switch to OFF position. 2) Connect keyless start control module connector. 3) Perform "Communication Bus Check" under "Bus Check" using SUZUKI-SDT with ignition switch turned ON. <i>Are all of BCM, ECM, ABS control module, combination meter, TCM and keyless start control module normally displayed?</i>	Go to Step 14.	Check power and ground circuits of keyless start control module referring to "Keyless Start Control Module Power and Ground Circuit Check in Section 10E". If OK, substitute a known-good keyless start control module.
14	CAN communication check of 4WD control module 1) Turn ignition switch to OFF position. 2) Connect combination meter connector and 4WD control module. 3) Perform "Communication Bus Check" under "Bus Check" on SUZUKI-SDT with ignition switch turned ON. <i>Are all of BCM, ECM, ABS control module, combination meter, TCM, keyless start control module, combination meter and 4WD control module normally displayed?</i>	Recheck DTC.	Check power and ground circuits of 4WD control module referring to "Step 2" and "Step 3" under "DTC C1240: 4WD Control Module Power Supply Circuit Malfunction in Section 3B". If OK, substitute a known-good 4WD control module.

Inspection of ECM and Its Circuits

ECM and its circuits can be checked by measuring voltage, pulse signal and resistance with special tool connected.

⚠ CAUTION

ECM cannot be checked by itself. It is strictly prohibited to connect voltmeter or ohmmeter to ECM with ECM connectors disconnected from it.

Voltage Check

- 1) Remove ECM (1) from its bracket referring to “Engine Control Module (ECM) Removal and Installation in Section 1C”.
- 2) Connect special tool between ECM and ECM connectors securely.


Special tool

(A): 09933-06320

- 3) Check voltage and/or pulse signal using voltmeter (2) and oscilloscope (3).


NOTE

- As each terminal voltage is affected by battery voltage, confirm that it is 11 V or more when ignition switch is turned ON.
- Voltage with asterisk (*) cannot be measured with voltmeter because it is pulse signal. Use oscilloscope for its check if necessary.
- Before performed this inspection, be sure to read the “Precautions of ECM Circuit Inspection”.



I5JB0A110073-01

Viewed from harness side



I7RW01110015-01

Terminal No.	Wire color	Circuit	Normal voltage	Condition	Remarks
C01-1	BLU/ YEL	Fuel injector No.1	10 – 14 V	IG switch: ON	—
			*0 – 0.6 V ↑↓ 10 – 14 V (“Reference waveform No.1: ”, “Reference waveform No.2: ” and “Reference waveform No.24: ”)	Engine: Idle speed after warming up	Output signal is active low pulse. Pulse frequency varies depending on engine speed.
C01-2	BLU/ WHT	Fuel injector No.2	10 – 14 V	IG switch: ON	—
			*0 – 0.6 V ↑↓ 10 – 14 V (“Reference waveform No.1: ” and “Reference waveform No.3: ”)	Engine: Idle speed after warming up	Output signal is active low pulse. Pulse frequency varies depending on engine speed.
C01-3	—	—	—	—	—
C01-4	—	—	—	—	—
C01-5	—	—	—	—	—
C01-6	—	—	—	—	—
C01-7	—	—	—	—	—
C01-8	—	—	—	—	—
C01-9	—	—	—	—	—
C01-10	—	—	—	—	—
C01-11	BRN	Oxygen signal of HO2S	4 – 5 V	IG switch: ON	—
			*Approx. 0.7 V (“Reference waveform No.4: ” and “Reference waveform No.5: ”)	Engine: Idle speed after warming up	
C01-12	RED/ BLU	A/C refrigerant pressure sensor signal	1.38 – 1.52 V	Engine: Running A/C switch: OFF Blower selector: OFF A/C refrigerant pressure: 800 kPa (116 psi)	—
			2.15 – 2.38 V	Engine: Running A/C switch: ON Blower selector > OFF A/C refrigerant pressure: 1400 kPa (203 psi)	
			2.67 – 2.95 V	Engine: Running A/C switch: ON Blower selector > OFF A/C refrigerant pressure: 1800 kPa (261 psi)	
C01-13	BLU/ BLK	EVAP canister purge valve output	10 – 14 V	Engine: Stop IG switch: ON	—
			*0 – 0.6 V ↑↓ 10 – 14 V (“Reference waveform No.6: ”)	EVAP canister purge valve: 52% (using scan tool)	Output signal is active low duty pulse. Duty ratio varies depending on vehicle condition.
C01-14	GRY/ RED	Output of 5 V power source for A/C refrigerant pressure sensor	4.5 – 5.5 V	IG switch: ON	—

1A-132 Engine General Information and Diagnosis:

Terminal No.	Wire color	Circuit	Normal voltage	Condition	Remarks
C01-15	BLK	Ground for ECM	Below 0.3 V	IG switch: ON	—
C01-16	BLU/ RED	Fuel injector No.3	10 – 14 V	IG switch: ON	—
			*0 – 0.6 V ↑↓ 10 – 14 V ("Reference waveform No.1: " and "Reference waveform No.7: ")	Engine: Idle speed after warming up	Output signal is active low pulse. Pulse frequency varies depending on engine speed.
C01-17	BLU/ ORN	Fuel injector No.4	10 – 14 V	IG switch: ON	—
			*0 – 0.6 V ↑↓ 10 – 14 V ("Reference waveform No.1: " and "Reference waveform No.8: ")	Engine: Idle speed after warming up	Output signal is active low pulse. Pulse frequency varies depending on engine speed.
C01-18	GRN	Ignition coil No.4	0 – 0.6 V	IG switch: ON	—
			*0 – 0.6 V ↑↓ 4 – 6 V ("Reference waveform No.9: " and "Reference waveform No.10: ")	Engine: Idle speed after warming up	Output signal is active high pulse. Pulse frequency varies depending on engine speed.
C01-19	GRN/ BLK	Ignition coil No.3	0 – 0.6 V	IG switch: ON	—
			*0 – 0.6 V ↑↓ 4 – 6 V ("Reference waveform No.9: " and "Reference waveform No.11: ")	Engine: Idle speed after warming up	Output signal is active high pulse. Pulse frequency varies depending on engine speed.
C01-20	GRN/ WHT	Ignition coil No.2	0 – 0.6 V	IG switch: ON	—
			*0 – 0.6 V ↑↓ 4 – 6 V ("Reference waveform No.9: " and "Reference waveform No.12: ")	Engine: Idle speed after warming up	Output signal is active high pulse. Pulse frequency varies depending on engine speed.
C01-21	GRN/ YEL	Ignition coil No.1	0 – 0.6 V	IG switch: ON	—
			*0 – 0.6 V ↑↓ 4 – 6 V ("Reference waveform No.9: " and "Reference waveform No.13: ")	Engine: Idle speed after warming up	Output signal is active high pulse. Pulse frequency varies depending on engine speed.
C01-22	YEL/ GRN	Starting motor signal	0 – 1 V	IG switch: ON	—
			8 – 14 V	IG switch: ST (engine cranking)	
C01-23	—	—	—	—	—

Terminal No.	Wire color	Circuit	Normal voltage	Condition	Remarks
C01-24	LT GRN	ECT sensor signal	3.3 – 3.8 V	IG switch: ON ECT: 0 °C (32 °F)	—
			1.38 – 1.72 V	IG switch: ON ECT: 50 °C (122 °F)	
			0.40 – 0.53 V	IG switch: ON ECT: 100 °C (212 °F)	
C01-25	LT GRN/ BLK	IAT sensor signal	3.18 – 3.67 V	IG switch: ON IAT: 0 °C (32 °F)	—
			1.32 – 1.65 V	IG switch: ON IAT: 40 °C (104 °F)	
			0.46 – 0.60 V	IG switch: ON IAT: 80 °C (176 °F)	
C01-26	PNK/ BLK	MAF sensor signal	0.5 – 1.0 V	Engine: Stop IG switch: ON	—
			1.3 – 1.8 V ("Reference waveform No.14: ")	Engine: Idle speed after warming up	
C01-27	GRY	Ground for MAF sensor	Below 0.3 V	IG switch: ON	—
C01-28	BLU/ YEL	Generator control signal output	0 – 1 V	Engine: Stop IG switch: ON	—
			4 – 6 V	Engine: Idle speed after warming up	
C01-29	BLK	Ground for ECM	Below 0.3 V	IG switch: ON	—
C01-30	BLK	Ground for ECM	Below 0.3 V	IG switch: ON	—
C01-31	BLK	Ground for A/F sensor heater	Below 0.3 V	IG switch: ON	—
C01-32	RED	Heater output of A/F sensor	10 – 14 V	IG switch: ON	Output signal is active low duty pulse. Duty ratio varies depending on engine condition.
			*0 – 1 V ↑↓ 10 – 14 V ("Reference waveform No.15: ")	Engine: Idle speed after warming up	
C01-33	BLK	Shield ground for TP sensor circuit	Below 0.3 V	IG switch: ON	—
C01-34	—	—	—	—	—
C01-35	—	—	—	—	—
C01-36	BLU	CKP sensor (–)	0 – 1 V	IG switch: ON	Output signal is sinusoidal waveform. Waveform frequency varies depending on engine speed. (30 (36 – 6) pulses are generated per 1 crankshaft revolution.)
			*4 – 6 V ↑↓ –4 – –6 V ("Reference waveform No.17: " and "Reference waveform No.18: ")	Engine: Idle speed after warming up	
C01-37	BLK	A/F sensor signal (–)	2.35 – 2.55 V ("Reference waveform No.15: ")	Engine: Idle speed after warming up	—
C01-38	WHT	A/F sensor signal (+)	2.7 – 2.9 V ("Reference waveform No.15: ")	Engine: Idle speed after warming up	—
C01-39	BLK/ RED	Ground for HO2S	Below 0.3 V	IG switch: ON	—

1A-134 Engine General Information and Diagnosis:

Terminal No.	Wire color	Circuit	Normal voltage	Condition	Remarks
C01-40	WHT	TP sensor (sub) signal	1.33 – 1.63 V	IG switch: ON Engine: After warmed up Accelerator pedal: Released	—
			3.67 – 4.67 V	IG switch: ON Engine: After warmed up Accelerator pedal: Depressed fully	
C01-41	BLK	Ground for TP sensor	Below 0.3 V	IG switch: ON	—
C01-42	YEL	IMT valve actuator (+)	2 – 4 V	Engine: Stop IG switch: ON	Output signal is duty pulse. Duty ratio varies depending on IMT valve operation.
			0 – 1 V ↑↓ 10 – 14 V ("Reference waveform No.16: ")	Engine: Idle speed after warming up	
C01-43	YEL/ BLK	IMT valve actuator (–)	2 – 4 V	Engine: Stop IG switch: ON	Output signal is duty pulse. Duty ratio varies depending on IMT valve operation.
			0 – 1 V ↑↓ 10 – 14 V ("Reference waveform No.16: ")	Engine: Idle speed after warming up	
C01-44	YEL	Output of throttle actuator	0 – 1 V	IG switch: ON Engine: After warmed up Accelerator pedal: Released	Output signal is duty pulse. Duty ratio varies depending on throttle valve and accelerator pedal position.
			*0 – 1 V ↑↓ 10 – 14 V ("Reference waveform No.19: " and "Reference waveform No.20: ")	IG switch: ON Engine: After warmed up Accelerator pedal: Depressed fully	
C01-45	BLU	Output of throttle actuator	0 – 1 V	IG switch: ON Engine: After warmed up Accelerator pedal: Depressed fully	Output signal is duty pulse. Duty ratio varies depending on throttle valve and accelerator pedal position.
			*0 – 1 V ↑↓ 10 – 14 V ("Reference waveform No.19: " and "Reference waveform No.20: ")	IG switch: ON Engine: After warmed up Accelerator pedal: Released	
C01-46	—	—	—	—	—
C01-47	RED/ BLU	Heater output of HO2S	10 – 14 V	IG switch: ON	Output signal is active low duty pulse. Duty ratio varies depending on engine condition.
			*0 – 1 V ↑↓ 10 – 14 V ("Reference waveform No.4: " and "Reference waveform No.5: ")	Engine: Idle speed after warming up	
C01-48	BLK/ ORN	Ground for ECM	Below 0.3 V	IG switch: ON	—

Terminal No.	Wire color	Circuit	Normal voltage	Condition	Remarks
C01-49	WHT	CAN (low) communication line (active low signal) to TCM	1.5 – 2.5 V ("Reference waveform No.25: ")	Engine: Stop IG switch: ON	CAN communication signal is serial communication signal pulse. Pulse signal displayed with a regular frequency varies depending on engine condition.
C01-50	RED	CAN (high) communication line (active high signal) to TCM	2.5 – 3.5 V ("Reference waveform No.25: ")	Engine: Stop IG switch: ON	CAN communication signal is serial communication signal pulse. Pulse signal displayed with a regular frequency varies depending on engine condition.
C01-51	PNK	CKP sensor (+)	0 – 1 V	IG switch: ON	—
			*4 – 6 V ↑↓ –4 – –6 V ("Reference waveform No.17: " and "Reference waveform No.18: ")	Engine: Idle speed after warming up	Output signal is sinusoidal waveform. Waveform frequency varies depending on engine speed. (30 (36 – 6) pulses are generated per 1 crankshaft revolution.)
C01-52	RED/ YEL	CMP sensor signal	0 – 1 V or 4 – 5 V	IG switch: ON	—
			*0 – 0.6 V ↑↓ 4 – 5 V ("Reference waveform No.17: " and "Reference waveform No.18: ")	Engine: Idle speed after warming up	Sensor signal is pulse. Pulse frequency varies depending on engine speed. (6 pulses are generated per 1 camshaft revolution.)
C01-53	RED	Output for 5 V power source of TP sensor	4.5 – 5.5 V	IG switch: ON	—
C01-54	GRN	TP sensor (main) signal	0.45 – 0.75 V	IG switch: ON Engine: After warmed up Accelerator pedal: Released	—
			3.67 – 4.25 V	IG switch: ON Engine: After warmed up Accelerator pedal: Depressed fully	
C01-55	—	—	—	—	—
C01-56	RED	Knock sensor signal	2 – 3 V ("Reference waveform No.21: " and "Reference waveform No.22: ")	Engine: Running at 4000 r/min. after warmed up	—
C01-57	GRY/ BLU	Ground for sensors	Below 0.3 V	IG switch: ON	—
C01-58	BLK/ ORN	Ground for ECM	Below 0.3 V	IG switch: ON	—
C01-59	—	—	—	—	—
C01-60	—	—	—	—	—

1A-136 Engine General Information and Diagnosis:

Terminal No.	Wire color	Circuit	Normal voltage	Condition	Remarks
E01-1	BLK/ RED	Main power supply	10 – 14 V	IG switch: ON	—
E01-2	WHT/ RED	Power source for ECM internal memory	10 – 14 V	IG switch: ON	—
E01-3	—	—	—	—	—
E01-4	RED	CAN (high) communication line (active high signal) to ABS control module	*2.5 – 4.5 V ("Reference waveform No.23: ")	Engine: Stop IG switch: ON	CAN communication line signal is pulse. Pulse signal displayed with a regular frequency which varies depending on engine condition.
E01-5	—	—	—	—	—
E01-6	RED/ WHT	Cruise control main switch signal	10 – 14 V	IG switch: ON Cruise control main switch: ON (keep pushing)	—
E01-7	LT GRN/ BLK	Clutch switch signal (cruise control model)	10 – 14 V	IG switch: ON Clutch pedal: Released	—
			0 – 1 V	IG switch: ON Clutch pedal: Depressed fully	
E01-8	GRN/ YEL	Brake switch signal (cruise control model)	10 – 14 V	IG switch: ON Brake light: OFF	—
			0 – 1 V	IG switch: ON Brake light: ON	
E01-9	—	—	—	—	—
E01-10	—	—	—	—	—
E01-11	—	—	—	—	—
E01-12	—	—	—	—	—
E01-13	YEL/ RED	Clock signal for immobilizer coil antenna	10 – 14 V	IG switch: ON	—
E01-14	—	—	—	—	—
E01-15	GRN/ WHT	Fuel pump relay output	0 – 2.5 V	Time: Within 2 sec. after turning ignition switch ON Engine: Running	—
			10 – 14 V	Time: After 2 sec. after turning ignition switch ON Engine: Stop	
E01-16	BLK/ RED	Main power supply	10 – 14 V	IG switch: ON	—
E01-17	GRN	Power supply of throttle actuator drive circuit	10 – 14 V	IG switch: ON	—
E01-18	—	—	—	—	—
E01-19	WHT	CAN (low) communication line (active low signal) to ABS control module	*0.5 – 2.5 V ("Reference waveform No.23: ")	Engine: Stop IG switch: ON	CAN communication line signal is pulse. Pulse signal displayed with a regular frequency which varies depending on engine condition.
E01-20	GRN/ WHT	Brake light switch signal	0 – 1 V	IG switch: ON Brake light: OFF	—
			10 – 14 V	IG switch: ON Brake light: ON	
E01-21	BLK/ YEL	Cruise control command switch ground	Below 1.3 V	IG switch: ON	—

Terminal No.	Wire color	Circuit	Normal voltage	Condition	Remarks
E01-22	LT GRN	Cruise control command switch signal	4 – 6 V	IG switch: ON	—
E01-23	—	—	—	—	—
E01-24	YEL/ RED	Fuel level sensor signal	0 – 6 V	IG switch: ON	Voltage varies depends on fuel level
E01-25	—	—	—	—	—
E01-26	—	—	—	—	—
E01-27	RED/ BLU	EPS active signal (idle up signal)	Approx. 12 V	Ignition switch ON	—
			0 – 1 V	Engine idling and turned steering wheel to the right or left until it stops	
E01-28	YEL/ BLK	Serial communication line for immobilizer coil antenna	10 – 14 V	IG switch: ON	—
E01-29	BLK/ WHT	Ignition switch signal	0 – 1 V	IG switch: OFF	—
			10 – 14 V	IG switch: ON	
E01-30	WHT	Starting motor control relay output	0 – 1 V	IG switch: ON	—
				IG switch: ST (engine cranking)	—
E01-31	—	—	—	—	—
E01-32	—	—	—	—	—
E01-33	—	—	—	—	—
E01-34	—	—	—	—	—
E01-35	BLU/ WHT	Electric load signal for heater blower motor	0 – 14 V	IG switch: ON Blower selector < 3rd position (Manual A/C model)	—
				IG switch: ON Blower selector < 2nd position (Auto A/C model)	
			0 – 1 V	IG switch: ON Blower selector > 2nd position	—
E01-36	ORN	Ground for sensors	Below 0.3 V	IG switch: ON	—
E01-37	—	—	—	—	—
E01-38	—	—	—	—	—
E01-39	—	—	—	—	—
E01-40	—	—	—	—	—
E01-41	WHT/ BLK	A/C evaporator outlet air temp. sensor signal (manual A/C model)	3.4 – 3.7 V	IG switch: ON A/C evaporator outlet temperature: 0 °C (32 °F).	—
			2.5 – 2.8 V	IG switch: ON A/C evaporator outlet temperature: 15 °C (59 °F).	
			1.7 – 2.0 V	IG switch: ON A/C evaporator outlet temperature: 30 °C (86 °F).	
		A/C evaporator outlet air temp. sensor signal (auto A/C model)	0 – 2 V	IG switch: ON	
E01-42	—	—	—	—	—
E01-43	—	—	—	—	—

1A-138 Engine General Information and Diagnosis:


Terminal No.	Wire color	Circuit	Normal voltage	Condition	Remarks
E01-44	BRN	Engine speed signal output for P/S control module	*0 – 1 V ↑↓ 8 – 14 V (“Reference waveform No.26: ” and “Reference waveform No.27: ”)	While engine running.	Output signal is pulse. Pulse frequency varies depending on engine speed. (2 pulses are generated per 1 crankshaft revolution.) (3000 r/min. = 100 Hz)
E01-45	—	—	—	—	—
E01-46	LT GRN	Radiator cooling fan relay No.1 output	10 – 14 V	IG switch: ON ECT < 97 °C (206 °F) A/C refrigerant pressure < 1500 kPa (215 psi) A/C switch: ON Engine: Running	—
			0 – 2 V	IG switch: ON ECT > 97 °C (206 °F) A/C refrigerant pressure > 1500 kPa (215 psi) A/C switch: ON Engine: Running	
E01-47	GRN	Radiator cooling fan relay No.2 and No.3 output	10 – 14 V	IG switch: ON ECT < 102 °C (216 °F) A/C refrigerant pressure < 1800 kPa (258 psi) A/C switch: ON Engine: Running	—
			0 – 2 V	IG switch: ON ECT > 102 °C (216 °F) A/C refrigerant pressure > 1800 kPa (258 psi) A/C switch: ON Engine: Running	
E01-48	RED/ BLK	A/C condenser cooling fan relay	0 – 1 V	Blower selector > OFF A/C switch: ON Defroster switch: ON Engine: Running ECT > 110 °C (230 °F) Engine: Running	—
			10 – 14 V	Except the above mentioned-condition with engine running	
E01-49	GRY	A/C compressor relay output	10 – 14 V	Engine: Running A/C switch: OFF Blower selector: OFF	—
			0 – 1 V	Engine: Running A/C switch: ON Blower selector > OFF	
E01-50	BRN	Throttle actuator control relay output	0 – 1 V	IG switch: ON	—
E01-51	WHT	Ground for APP sensor (sub)	Below 0.3 V	IG switch: ON	—

Terminal No.	Wire color	Circuit	Normal voltage	Condition	Remarks
E01-52	YEL	APP sensor (sub) signal	0.17 – 0.58 V	IG switch: ON Engine: After warmed up Accelerator pedal: Released	—
			1.65 – 2.20 V	IG switch: ON Engine: After warmed up Accelerator pedal: Depressed fully	
E01-53	RED	Output for 5 V power source of APP sensor (sub)	4.5 – 5.5 V	IG switch: ON	—
E01-54	BLU	Ground for APP sensor (main)	Below 0.3 V	IG switch: ON	—
E01-55	GRN	APP sensor (main) signal	0.55 – 0.95 V	IG switch: ON Engine: After warmed up Accelerator pedal: Released	—
			3.50 – 4.40 V	IG switch: ON Engine: After warmed up Accelerator pedal: Depressed fully	
E01-56	BRN	Output for 5 V power source of APP sensor (main)	4.5 – 5.5 V	IG switch: ON	—
E01-57	—	—	—	—	—
E01-58	—	—	—	—	—
E01-59	—	—	—	—	—
E01-60	BRN/ WHT	Main power supply relay output	10 – 14 V	IG switch: OFF	—
			0 – 2 V	IG switch: ON	

Reference waveform No.1

Fuel injector signal (1) with engine idling

Measurement terminal	CH1: "C01-1" (No.1), C01-2 (No.2), C01-16 (No.3) or C01-17 (No.4) to "C01-58"
Oscilloscope setting	CH1: 20 V/DIV TIME: 1 ms/DIV
Measurement condition	- After warmed up to normal operating temperature - Engine at specified idle speed




I5JB0A110074-01

- | |
|--|
| 2. Fuel injection pulse width: 2-4 msec. |
| 3. 10 – 14 V |

Reference waveform No.2

No.1 fuel injector signal (2) with engine idling

Measurement terminal	CH1: "C01-52" to "C01-58" CH2: "C01-1" to "C01-58"
Oscilloscope setting	CH1: 5 V/DIV, CH2: 20 V/DIV TIME: 40 ms/DIV
Measurement condition	- After warmed up to normal operating temperature - Engine at specified idle speed




I5JB0A110075-01

- | |
|---|
| 1. Cylinder reference signal (CMP reference signal) |
| 3. 720° crank angle |

Reference waveform No.3

No.2 fuel injector signal (2) with engine idling

Measurement terminal	CH1: "C01-52" to "C01-58" CH2: "C01-2" to "C01-58"
Oscilloscope setting	CH1: 5 V/DIV, CH2: 20 V/DIV TIME: 40 ms/DIV
Measurement condition	- After warmed up to normal operating temperature - Engine at specified idle speed




I5JB0A110076-01

1. Cylinder reference signal (CMP reference signal)
2. 720° crank angle

Reference waveform No.4

HO2S signal (1) with engine idling

Measurement terminal	CH1: "C01-11" to "C01-39" CH2: "C01-47" to "C01-58"
Oscilloscope setting	CH1: 500 mV/DIV, CH2: 10 V/DIV TIME: 200 ms/DIV
Measurement condition	- After warmed up to normal operating temperature - Engine at specified idle speed




I7RW01110093-01

2. HO2S heater signal
3. One duty cycle

Reference waveform No.5

HO2S signal (1) with engine racing

Measurement terminal	CH1: "C01-11" to "C01-39" CH2: "C01-47" to "C01-58"
Oscilloscope setting	CH1: 500 mV/DIV, CH2: 10 V/DIV TIME: 200 ms/DIV
Measurement condition	- After warmed up to normal operating temperature - Engine racing




I7RW01110094-01

2. HO2S heater signal
3. Engine racing

Reference waveform No.6

EVAP canister purge valve signal

Measurement terminal	CH1: "C01-13" to "C01-58"
Oscilloscope setting	CH1: 10 V/DIV TIME: 40 ms/DIV
Measurement condition	- After warmed up to normal operating temperature - Set EVAP canister purge valve at 52% by using "Active Test" of scan tool




I4RS0B110067-01

1. ON signal
2. OFF signal
3. One duty cycle
4. 10 - 14 V

Reference waveform No.7

No.3 fuel injector signal (2) with engine idling

Measurement terminal	CH1: "C01-52" to "C01-58" CH2: "C01-16" to "C01-58"
Oscilloscope setting	CH1: 5 V/DIV, CH2: 20 V/DIV TIME: 40 ms/DIV
Measurement condition	- After warmed up to normal operating temperature - Engine at specified idle speed




I5JB0A110081-01

- | |
|---|
| 1. Cylinder reference signal (CMP reference signal) |
| 3. 720° crank angle |

Reference waveform No.8

No.4 fuel injector signal (2) with engine idling

Measurement terminal	CH1: "C01-52" to "C01-58" CH2: "C01-17" to "C01-58"
Oscilloscope setting	CH1: 5 V/DIV, CH2: 20 V/DIV TIME: 40 ms/DIV
Measurement condition	- After warmed up to normal operating temperature - Engine at specified idle speed




I5JB0A110082-01

- | |
|---|
| 1. Cylinder reference signal (CMP reference signal) |
| 3. 720° crank angle |

Reference waveform No.9

Ignition coil signal (1) with engine idling

Measurement terminal	CH1: "C01-18", "C01-19", "C01-20" or "C01-21" to "C01-58"
Oscilloscope setting	CH1: 2 V/DIV TIME: 2 ms/DIV
Measurement condition	- After warmed up to normal operating temperature - Engine at specified idle speed




I7RW01110017-01

- | | |
|------------|------------------------------|
| 2. 4 – 6 V | 3. Ignition coil pulse width |
|------------|------------------------------|

Reference waveform No.10

Ignition coil No.4 signal (2) with engine idling

Measurement terminal	CH1: "C01-52" to "C01-58" CH2: "C01-18" to "C01-58"
Oscilloscope setting	CH1: 2 V/DIV, CH2: 2 V/DIV TIME: 40 ms/DIV
Measurement condition	- After warmed up to normal operating temperature - Engine at specified idle speed




I5JB0A110084-01

- | |
|---|
| 1. Cylinder reference signal (CMP reference signal) |
| 3. 720° crank angle |

Reference waveform No.11

Ignition coil No.3 signal (2) with engine idling

Measurement terminal	CH1: "C01-52" to "C01-58" CH2: "C01-19" to "C01-58"
Oscilloscope setting	CH1: 2 V/DIV, CH2: 2 V/DIV TIME: 40 ms/DIV
Measurement condition	- After warmed up to normal operating temperature - Engine at specified idle speed




I5JB0A110085-01

1. Cylinder reference signal (CMP reference signal)
2. 720° crank angle

Reference waveform No.12

Ignition coil No.2 signal (1) with engine idling

Measurement terminal	CH1: "C01-52" to "C01-58" CH2: "C01-20" to "C01-58"
Oscilloscope setting	CH1: 2 V/DIV, CH2: 2 V/DIV TIME: 40 ms/DIV
Measurement condition	- After warmed up to normal operating temperature - Engine at specified idle speed




I7RW0110018-01

2. Cylinder reference signal (CMP reference signal)
3. 720° crank angle

Reference waveform No.13

Ignition coil No.1 signal (1) with engine idling

Measurement terminal	CH1: "C01-52" to "C01-58" CH2: "C01-21" to "C01-58"
Oscilloscope setting	CH1: 2 V/DIV, CH2: 2 V/DIV TIME: 40 ms/DIV
Measurement condition	- After warmed up to normal operating temperature - Engine at specified idle speed




I7RW0110019-01

2. Cylinder reference signal (CMP reference signal)
3. 720° crank angle

Reference waveform No.14

MAF sensor signal (1) with engine racing

Measurement terminal	CH1: "C01-26" to "C01-27" CH2: "C01-54" to "C01-41"
Oscilloscope setting	CH1: 1 V/DIV, CH2: 1 V/DIV TIME: 200 ms/DIV
Measurement condition	- After warmed up to normal operating temperature - Engine racing




I5JB0A110088-02

2. TP sensor (main) signal
3. Racing
4. Idle

Reference waveform No.15

A/F sensor signal with engine idling

Measurement terminal	CH1: "C01-38" to "C01-58" CH2: "C01-37" to "C01-58" CH3: "C01-32" to "C01-31"
Oscilloscope setting	CH1: 500 mV/DIV, CH2: 500 mV/DIV, CH3: 10 V/DIV TIME: 100 ms/DIV
Measurement condition	- After warmed up to normal operating temperature - Engine at specified idle speed




I7RW01110020-01

1. A/F sensor signal (+)	3. A/F sensor heater signal
2. A/F sensor signal (-)	4. One duty cycle

Reference waveform No.16

IMT valve actuator signal with engine racing

Measurement terminal	CH1: "C01-42" to "C01-58" CH2: "C01-43" to "C01-58"
Oscilloscope setting	CH1: 10 V/DIV, CH2: 10 V/DIV TIME: 200 ms/DIV
Measurement condition	- After warmed up to normal operating temperature - Engine racing




I7RW01110021-01

1. IMT valve actuator signal (+)	3. IMT valve open
2. IMT valve actuator signal (-)	

Reference waveform No.17

CMP sensor signal with engine idling

Measurement terminal	CH1: "C01-52" to "C01-58" CH2: "C01-51" to "C01-36"
Oscilloscope setting	CH1: 2 V/DIV, CH2: 5 V/DIV TIME: 20 ms/DIV
Measurement condition	- After warmed up to normal operating temperature - Engine at specified idle speed




I7RW01110023-01

1. Cylinder reference signal (CMP reference signal)
2. CKP signal
3. 360° crank angle
4. 4 - 5 V
5. 36 - 6 = 30 CKP pulse

Reference waveform No.18

CMP sensor signal with engine idling

Measurement terminal	CH1: "C01-52" to "C01-58" CH2: "C01-51" to "C01-36"
Oscilloscope setting	CH1: 2 V/DIV, CH2: 5 V/DIV TIME: 10 ms/DIV
Measurement condition	- After warmed up to normal operating temperature - Engine at specified idle speed




I7RW01110024-01

1. Cylinder reference signal (CMP reference signal)
2. CKP signal
3. 30° crank angle
4. 10° crank angle
5. 360° crank angle
6. 36 - 6 = 30 CKP pulse

Reference waveform No.19

Throttle actuator output signal with ignition switch turned ON

Measurement terminal	CH1: "C01-45" to "C01-58" CH2: "C01-44" to "C01-58"
Oscilloscope setting	CH1: 5 V/DIV, CH2: 5 V/DIV TIME: 2 ms/DIV
Measurement condition	- After warmed up to normal operating temperature - Ignition switch turned ON and accelerator pedal at idle position




1. Throttle actuator drive signal ("C01-45" terminal)
2. Throttle actuator drive signal ("C01-44" terminal)
3. ON signal
4. OFF signal
5. One duty cycle

Reference waveform No.20

Throttle actuator output signal with ignition switch turned ON

Measurement terminal	CH1: "C01-45" to "C01-58" CH2: "C01-44" to "C01-58"
Oscilloscope setting	CH1: 5 V/DIV, CH2: 5 V/DIV TIME: 2 ms/DIV
Measurement condition	- After warmed up to normal operating temperature - Ignition switch turned ON and accelerator pedal at full depressed position




1. Throttle actuator drive signal ("C01-45" terminal)
2. Throttle actuator drive signal ("C01-44" terminal)
3. ON signal
4. OFF signal
5. One duty cycle

Reference waveform No.21

Knock sensor signal at engine speed 4000 r/min.


Measurement terminal	CH1: "C01-56" to "C01-58"
Oscilloscope setting	CH1: 1 V/DIV TIME: 10 ms/DIV
Measurement condition	- After warmed up to normal operating temperature - Run engine at 4000 r/min.



Reference waveform No.22

Knock sensor signal at engine speed 4000 r/min.

Measurement terminal	CH1: "C01-56" to "C01-58"
Oscilloscope setting	CH1: 1 V/DIV TIME: 200 μ s/DIV
Measurement condition	- After warmed up to normal operating temperature - Run engine at 4000 r/min.




I4RS0B110073-01

Reference waveform No.23

CAN communication line signal from ABS / ESP® control module with ignition switch turned ON

Measurement terminal	CH1: "E01-4" to "C01-58" CH2: "E01-19" to "C01-58"
Oscilloscope setting	CH1: 1 V/DIV, CH2: 1 V/DIV TIME: 40 μ s/DIV
Measurement condition	Ignition switch turned ON (Signal pattern is depending on communication data)




I7RW01110028-01

1. CAN communication line signal (High)
2. CAN communication line signal (Low)

Reference waveform No.24

Ignition coil signal and fuel injector signal with engine cranking

Measurement terminal	CH1: "C01-52" to "C01-58" CH2: "C01-21" to "C01-58" CH3: "C01-1" to "C01-58" CH4: "C01-22" to "C01-58"
Oscilloscope setting	CH1: 5 V/DIV, CH2: 5 V/DIV CH3: 50 V/DIV, CH4: 10 V/DIV TIME: 200 ms/DIV
Measurement condition	- After warmed up to normal operating temperature - Engine at cranking




I7RW01110029-01

1. Cylinder reference signal (CMP reference signal)
2. Ignition coil signal
3. No.1 fuel injector signal
4. Engine start signal

Reference waveform No.25

CAN communication line signal from TCM with ignition switch turned ON

Measurement terminal	CH1: "C01-50" to "C01-58" CH2: "C01-49" to "C01-58"
Oscilloscope setting	CH1: 1 V/DIV, CH2: 1 V/DIV TIME: 40 μ s/DIV
Measurement condition	Ignition switch turned ON (Signal pattern is depending on communication data)




I7RW01110030-01

1. CAN communication line signal (High)
2. CAN communication line signal (Low)

Reference waveform No.26

Ignition pulse (engine revolution) signal (2) with engine idling

Measurement terminal	CH1: "C01-52" to "C01-58" CH2: "E01-44" to "C01-58"
Oscilloscope setting	CH1: 5 V/DIV, CH2: 5 V/DIV TIME: 40 ms/DIV
Measurement condition	• After warmed up to normal operating temperature • Engine at specified idle speed




I7RW01110089-01

1. Cylinder reference signal (CMP reference signal)
3. 720° crank angle

Reference waveform No.27

Ignition pulse (engine revolution) signal (2) with engine idling

Measurement terminal	CH1: "C01-52" to "C01-58" CH2: "E01-44" to "C01-58"
Oscilloscope setting	CH1: 5 V/DIV, CH2: 5 V/DIV TIME: 10 ms/DIV
Measurement condition	• After warmed up to normal operating temperature • Engine at specified idle speed



I7RW01110090-01

1. Cylinder reference signal (CMP reference signal)
3. 360° crank angle
4. 2 to 4 msec.
5. 10 – 14 V

Resistance Check

1) Remove ECM from its bracket referring to “Engine Control Module (ECM) Removal and Installation in Section 1C”.

⚠ CAUTION

Never touch terminals of ECM itself or connect voltmeter or ohmmeter (2).

2) Connect special tool to ECM connectors (1) securely.

NOTE

Do not connect the other connector of special tool to ECM.


Special tool

(A): 09933-06320

3) Check resistance between each pair of terminals of special tool connectors (2) as listed in the following table.

⚠ CAUTION

- **Be sure to connect ohmmeter probe from wire harness side of coupler.**
- **Be sure to turn OFF ignition switch for this check.**
- **Resistance in the following table represents that measured when parts temperature is 20 °C (68 °F).**





I7RW01110032-02

Terminals	Circuit	Standard resistance	Condition
E01-60 to E01-29	Main relay	160 – 240 Ω	Battery disconnected and ignition switch turned ON
E01-15 to E01-29	Fuel pump relay	160 – 240 Ω	—
C01-16 to E01-1/16	No.3 fuel injector	10.8 – 18.2 Ω	—
C01-17 to E01-1/16	No.4 fuel injector		
C01-13 to E01-1/16	EVAP canister purge valve	22 – 26 Ω	—
C01-2 to E01-1/16	No.2 fuel injector	10.8 – 18.2 Ω	—
C01-1 to E01-1/16	No.1 fuel injector	10.8 – 18.2 Ω	—
E01-50 to E01-1/16	Throttle actuator control relay	160 – 240 Ω	—

ECM Power and Ground Circuit Check

S7RW0C1104064

Wiring Diagram



I6RW0C110019-01

1. Fuse box No.2	5. "IG COIL" fuse	9. "DOME" fuse	12-1. TP sensor (main)
2. Ignition switch	6. ECM	10. A/C refrigerant pressure sensor	12-2. TP sensor (sub)
3. Main relay	7. "IGN" fuse	11-1. APP sensor (main)	
4. Junction block	8. "FI" fuse	11-2. APP sensor (sub)	


Circuit Description

When the ignition switch is turned ON, the main relay turns ON (the contact point closes) and the main power is supplied to ECM. And then ECM supplies 5 V power to each sensor (A/C refrigerant pressure sensor, APP sensor and TP sensor).

If 5 V power circuit to each sensors from ECM is shorted to ground, ECM stops engine and emission control operation.


Troubleshooting**NOTE**

- Before performed troubleshooting, be sure to read the “Precautions of ECM Circuit Inspection”.
- When measuring circuit voltage, resistance and/or pulse signal at ECM connector, connect the special tool to ECM and/or the ECM connectors referring to “Inspection of ECM and Its Circuits”.

Step	Action	Yes	No
1	Circuit fuse check 1) Disconnect connectors from ECM with ignition switch turned OFF. 2) Check for proper connection to ECM connector at “E01-2”, “E01-29”, “E01-60”, “E01-1”, “E01-16”, “C01-15”, “C01-30”, “C01-29”, “C01-48” and “C01-58” terminals. 3) If OK, check “DOME” fuse and “IG COIL” fuse for blowing. <i>Are “DOME” fuse and “IG COIL” fuse in good condition?</i>	Go to Step 2.	Replace fuse (s) and check for short in circuits connected to fuse(s).
2	Power supply circuit check 1) Measure voltage between “E01-2” terminal of ECM connector and body ground. <i>Is voltage 10 – 14 V?</i>	Go to Step 3.	“WHT/RED” wire is open circuit.
3	Ignition signal check 1) Turn ignition switch to ON position. 2) Measure voltage between “E01-29” terminal of ECM connector and body ground. <i>Is voltage 10 – 14 V?</i>	Go to Step 4.	“BLK/WHT” or “GRN” wire is open circuit.
4	Main relay circuit check 1) Turn ignition switch to OFF position. 2) Check “FI” fuse (1) (15 A) in fuse box No.2 for blowing.  3) If OK, measure voltage between “E01-60” terminal of ECM connector and body ground. <i>Is voltage 10 – 14 V?</i>	Go to Step 5.	Go to Step 9.

I7RW01110034-01

1A-150 Engine General Information and Diagnosis:


Step	Action	Yes	No
5	Main relay circuit check 1) Connect connectors to ECM with ignition switch turned OFF. 2) Turn ignition switch to ON position. 3) Measure voltage between "E01-60" terminal of ECM connector and body ground. <i>Is voltage 0 – 1 V?</i>	Go to Step 7.	Go to Step 6.
6	ECM ground circuit check 1) Turn ignition switch to OFF position. 2) Disconnect connectors from ECM. 3) Measure resistance between each "C01-15", "C01-30", "C01-29", "C01-48" and "C01-58" terminals of ECM connector and body ground. <i>Is resistance 1 Ω or less?</i>	Substitute a known-good ECM and recheck.	"BLK/ORN" or "BLK" wire is open or high resistance circuit.
7	Main relay circuit check 1) Disconnect connectors from ECM with ignition switch turned OFF. 2) Using service wire, ground "E01-60" terminal of ECM connector and measure voltage between each "E01-1" and "E01-16" terminals of ECM connector and body ground. <i>Is voltage 10 – 14 V?</i>	Go to Step 11.	Go to Step 8.
8	Main relay circuit check 1) Remove main relay (1) from fuse box No.2.  I7RW01110035-01 2) Check for proper connection to main relay connector at "BLK/YEL" and "BLK/RED" wire terminals. 3) If OK, measure resistance between each "E01-1" and "E01-16" wire terminals of ECM connector and "BLK/RED" wire terminal of main relay connector. <i>Is resistance 1 Ω or less?</i>	Go to Step 9.	"BLK/RED" wire is open circuit or high resistance circuit.
9	Main relay circuit check 1) Remove main relay from fuse box No.2 with ignition switch turned OFF. 2) Measure voltage between "BLK/YEL" wire terminal of main relay connector and body ground. <i>Is voltage 10 – 14 V?</i>	Go to Step 10.	"BLK/YEL" wire is open circuit.

Step	Action	Yes	No
10	Main relay check 1) Check main relay referring to "Engine and Emission Control System Relay Inspection in Section 1C". <i>Is main relay in good condition?</i>	"BRN/WHT" wire is open or high resistance circuit.	Replace main relay.
11	Sensor 5 V power source circuit check 1) Connect connectors to ECM with ignition switch turned OFF. 2) Turn ON ignition switch, measure each voltage between "C01-14", "E01-56", "E01-53" and "C01-53", terminal of ECM connector and vehicle body ground. <i>Is each voltage 4 – 6 V?</i>	ECM power and ground circuit is in good condition.	Go to Step 12.
12	Sensor 5 V power source circuit check 1) Disconnect connectors from ECM, TP sensor, A/C refrigerant pressure sensor and APP sensor with ignition switch turned OFF. 2) Measure each resistance between, "C01-14", "E01-56", "E01-53" and "C01-53" terminal of ECM connector and vehicle body ground. <i>Is each resistance infinity?</i>	Check internal short circuit of TP sensor, A/C refrigerant pressure sensor and/or APP sensor.	"GRY/RED", "RED" and/or "BRN" wire is shorted to ground circuit.

Fuel Injector Circuit Check

S7RW0C1104065

Wiring Diagram



I7RW01110036-01

1. Fuse box No.2	3. ECM	5. No.2 injector	7. No.4 injector	9. Ignition switch	11. "IGN" fuse
2. Main relay	4. No.1 injector	6. No.3 injector	8. "IG COIL" fuse	10. "FI" fuse	

Troubleshooting

NOTE


- Before performed troubleshooting, be sure to read the “Precautions of ECM Circuit Inspection”.
- When measuring circuit voltage, resistance and/or pulse signal at ECM connector, connect the special tool to ECM and/or the ECM connectors referring to “Inspection of ECM and Its Circuits”.

Step	Action	Yes	No
1	Fuel injector check for operating sound 1) Using sound scope, check each injector for operating sound at engine cranking. <i>Do all 4 injector make operating sound?</i>	Fuel injectors circuit is in good condition.	Go to Step 2.
2	Fuel injector resistance check 1) Disconnect connectors from fuel injectors with ignition switch turned OFF. 2) Check for proper connection to fuel injector at each terminals. 3) If OK, check all 4 fuel injectors for resistance referring to “Fuel Injector On-Vehicle Inspection in Section 1G”. <i>Are all injectors in good condition?</i>	Go to Step 3.	Faulty fuel injector.
3	Fuel injector insulation resistance check 1) Check that there is insulation between each fuel injector terminal and engine ground. <i>Is there insulation?</i>	Go to Step 4.	Faulty fuel injector.
4	Fuel injector power supply check 1) Measure voltage between each “BLK/RED” wire terminal of fuel injector connector and engine ground with ignition switch turned ON. <i>Is voltage 10 – 14 V?</i>	Go to Step 5.	“BLK/RED” wire is open or shorted to ground circuit. If it is in good condition, go to “ECM Power and Ground Circuit Check”.
5	Wire circuit check 1) Turn OFF ignition switch. 2) Disconnect connectors from ECM. 3) Measure resistance between each “BLU/YEL”, “BLU/WHT”, “BLU/RED”, “BLU/ORN” wire terminal of fuel injector connector and vehicle body ground. <i>Is resistance infinity?</i>	Go to Step 6.	“BLU/YEL”, “BLU/WHT”, “BLU/RED” and/or “BLU/ORN” wire(s) are shorted to ground.
6	Wire circuit check 1) Measure voltage between each “BLU/YEL”, “BLU/WHT”, “BLU/RED”, “BLU/ORN” wire terminal of fuel injector connector and vehicle body ground with ignition switch turned ON. <i>Is voltage 0 V?</i>	Go to Step 7.	“BLU/YEL”, “BLU/WHT”, “BLU/RED” and/or “BLU/ORN” wire(s) are shorted to power supply circuit.
7	Fuel injector drive signal check 1) Connect connectors to each fuel injector and ECM with ignition switch turned OFF. 2) Turn ON ignition switch. 3) Measure voltage between each “C01-1”, “C01-2”, “C01-16”, “C01-17” terminal of ECM connector and vehicle body ground. <i>Is voltage 10 – 14 V?</i>	Check fuel injector referring to “Fuel Injector Inspection in Section 1G”. If check result is satisfactory, substitute a known-good ECM and recheck.	“BLU/YEL”, “BLU/WHT”, “BLU/RED” and/or “BLU/ORN” wire(s) are open circuit.

Fuel Pump and Its Circuit Check

S7RW0C1104066

Wiring Diagram




I7RW01110037-01

1. Fuse box No.2	3. ECM	5. Fuel pump	7. Ignition switch	9. "IGN" fuse
2. Main relay	4. Fuel pump relay	6. "IG COIL" fuse	8. "FI" fuse	

Troubleshooting

NOTE

- Before performed troubleshooting, be sure to read the “Precautions of ECM Circuit Inspection”.
- When measuring circuit voltage, resistance and/or pulse signal at ECM connector, connect the special tool to ECM and/or the ECM connectors referring to “Inspection of ECM and Its Circuits”.

Step	Action	Yes	No
1	Fuel pump control system check for operation <i>Is fuel pump heard to operate 2 sec. after ignition switch is turned ON?</i>  I2RH01110132-01	Fuel pump circuit is in good condition.	Go to Step 2.
2	Fuel pump relay power supply check 1) Disconnect fuel pump relay from fuse box No.2 with ignition switch turned OFF. 2) Check for proper connection to fuel pump relay at each terminal. 3) If OK, turn ON ignition switch, measure voltage between “BLK/WHT” wire terminal of fuel pump relay connector and engine ground. <i>Is voltage 10 – 14 V?</i>	Go to Step 3.	“BLK/WHT” wire is open or shorted to ground circuit.
3	Fuel pump relay power supply check 1) Turn ON ignition switch, measure voltage between “BLK/RED” wire terminal of fuel pump relay connector and engine ground. <i>Is voltage 10 – 14 V?</i>	Go to Step 4.	“BLK/RED” wire is open circuit.
4	Fuel pump relay check 1) Check fuel pump relay referring to “Engine and Emission Control System Relay Inspection in Section 1C”. <i>Is relay in good condition?</i>	Go to Step 5.	Faulty relay.
5	Fuel pump relay drive signal check 1) Connect fuel pump relay to fuse box No.2. 2) Connect voltmeter between “E01-15” terminal of ECM connector and vehicle body ground. 3) Measure voltage 2 sec. after ignition switch is turned ON. <i>Is voltage 10 – 14 V?</i>	Go to Step 6.	“GRN/WHT” wire is open circuit or shorted to ground circuit.

Step	Action	Yes	No
6	Fuel pump relay drive signal check 1) Measure voltage within 2 sec. after ignition switch is turned ON. <i>Is voltage 0 – 1 V?</i>	Go to Step 7.	Substitute a known-good ECM and recheck.
7	Wire circuit check 1) Turn OFF ignition switch. 2) Detach fuel tank referring to “Fuel Tank Removal and Installation in Section 1G”. 3) Disconnect connector from fuel pump. 4) Measure resistance between “PNK” wire terminal of fuel pump connector and vehicle body ground. <i>Is resistance infinity?</i>	Go to Step 8.	“PNK” wire is shorted to ground.
8	Fuel pump circuit check 1) Connect service wire between “E01-15” terminal of ECM connector and vehicle body ground. 2) Turn ON ignition switch, measure voltage between “PNK” terminal at fuel pump connector and vehicle body ground. <i>Is voltage 10 – 14 V?</i>	Go to Step 9.	“PNK” wire is open circuit.
9	Fuel pump circuit check 1) Turn OFF ignition switch. 2) Measure resistance between “BLK” wire terminal at fuel pump connector and vehicle body ground. <i>Is resistance less than 5 Ω?</i>	Faulty fuel pump.	“BLK” wire is open circuit.


Fuel Pressure Check

S7RW0C1104067

System Diagram

Special tool

- (A): 09912-58442
- (B): 09912-58432
- (C): 09912-58490



I7RW01110038-01

1. Injector	2. Delivery pipe	3. Fuel pump	4. Fuel filter	5. Fuel pressure regulator
-------------	------------------	--------------	----------------	----------------------------

Troubleshooting

NOTE


Before using the following flow chart, chart check to make sure that battery voltage is higher than 11 V. If battery voltage is low, pressure becomes lower than specification even if fuel pump and line are in good condition.

Step	Action	Yes	No
1	Fuel pump operating sound check 1) Remove fuel filler cap and then turn ON ignition switch. <i>Can you hear operating sound?</i>	Go to Step 2.	Go to "Fuel Pump and Its Circuit Check".
2	Fuel pressure check 1) Check fuel pressure referring to "Fuel Pressure Inspection in Section 1G". <i>Is check result satisfactory?</i>	Go to Step 3.	Go to Step 6.
3	Fuel pressure check 1) Start engine and warm it up to normal operating temperature. 2) Keep engine speed at 4000 rpm. <i>Does fuel pressure show about the same value as Step 2?</i>	Go to Step 4.	Go to Step 8.
4	Fuel line check 1) Check fuel pipe, fuel hose and joint for fuel leakage. <i>Are they in good condition?</i>	Go to Step 5.	Repair or replace defective part.
5	Fuel line check 1) Check fuel pipe, fuel hose and joint for damage or deform. <i>Are they in good condition?</i>	Fuel system is in good condition.	Repair or replace damaged or damaged part.
6	<i>Was fuel pressure higher than specification in Step 2?</i>	Go to Step 7.	Go to Step 8.
7	Fuel line check 1) Check fuel pipe, fuel hose and joint for damage or deform. <i>Are they in good condition?</i>	Faulty fuel pressure regulator.	Repair or replace damaged or damaged part.
8	Fuel line check 1) Check fuel pipe, fuel hose and joint for damage or deform. <i>Are they in good condition?</i>	Clogged fuel filter, faulty fuel pump, faulty fuel pressure regulator or fuel leakage from hose connection in fuel tank.	Repair or replace defective part.

A/C Condenser Cooling Fan Control System Inspection

S7RW0C1104068

Wiring Diagram



I6RW0C110020-01

1. Fuse box No.2	4. A/C compressor relay	7. ECM	10. "IG COIL" fuse
2. Ignition switch	5. A/C condenser cooling fan motor	8. "FI" fuse	11. "IGN" fuse
3. A/C condenser cooling fan relay	6. A/C compressor	9. "A/C" fuse	12. Main relay

Troubleshooting

Step	Action	Yes	No
1	Check A/C condenser fan control system <i>Is A/C condenser fan started when A/C is operating?</i>	System is in good condition.	Go to Step 2.
2	Check A/C condenser fan relay and its circuit 1) Connect scan tool to DLC with ignition switch OFF. 2) Check pending DTC and DTC with scan tool. <i>Is DTC P0481 displayed?</i>	Go to "DTC P0481: Fan 2 Control Circuit".	Go to Step 3.
3	Check A/C refrigerant 1) Check amount of A/C refrigerant referring to "A/C System Performance Inspection: Manual Type in Section 7B". <i>Is it good condition?</i>	Go to Step 4.	Recharge refrigerant.

Step	Action	Yes	No
4	Check wire circuit 1) Disconnect A/C condenser cooling fan relay from fuse box No.2 with ignition switch turned OFF. 2) Turn ON ignition switch, measure voltage between engine ground and "BLU/YEL" wire terminal of A/C condenser cooling fan relay connector. <i>Is voltage 10 – 14V?</i>	Go to Step 7.	Go to Step 5.
5	Check wire circuit 1) Disconnect A/C compressor relay from fuse box No.2 with ignition switch turn OFF. 2) Turn ON ignition switch, measure voltage between engine ground and "BLU/YEL" wire terminal of A/C compressor relay connector. <i>Is voltage 10 – 14 V?</i>	Faulty A/C compressor relay.	Go to Step 6.
6	Check wire circuit 1) Remove "A/C" fuse "20 A" from fuse box No.2 with ignition switch turned OFF. 2) Measure resistance between "BLU/YEL" wire terminal of main fuse connector and engine ground. <i>Is resistance infinity?</i>	Open wire in "BLU/YEL" circuit. If OK, go to Step 7.	"BLU/YEL" wire shorted to ground circuit.
7	Check wire circuit 1) Disconnect connector from A/C condenser cooling fan with ignition switch tun OFF. 2) Measure resistance between engine ground and "RED" wire terminal of A/C condenser fan connector. <i>Is resistance infinity?</i>	Go to Step 8.	"RED" wire shorted to ground circuit.
8	Check A/C condenser cooling fan control relay 1) Check A/C condenser cooling fan control relay referring to "A/C System Relay Inspection: Manual Type in Section 7B". <i>Is result in good condition?</i>	Go to Step 9.	Replace relay.
9	Check wire circuit 1) Install "A/C" fuse "20 A" to fuse box No.2. 2) Connect A/C condenser cooling fan relay to fuse box No.2 with ignition switch turn OFF. 3) Start engine then turn ON A/C switch and blower motor switch. 4) Measure voltage between engine ground and "RED" wire terminal in A/C condenser fan harness connector. <i>Is voltage 10 – 14 V?</i>	Go to Step 10.	Open wire in "RED" circuit.
10	Check wire circuit 1) Disconnect connector from A/C condenser cooling fan with ignition switch turned OFF. 2) Measure resistance between "BLK" wire terminal of A/C condenser cooling fan connector and engine ground. <i>Is resistance below 1 Ω?</i>	Go to Step 11.	Open or high resistance wire in "BLK" circuit.



1A-160 Engine General Information and Diagnosis:

Step	Action	Yes	No
11	Check A/C condenser cooling fan 1) Check A/C condenser cooling fan operates referring to "Condenser Cooling Fan Inspection: Manual Type in Section 7B". <i>Is it good condition?</i>	Substitute a known-good ECM and recheck.	Faulty A/C condenser cooling fan.

A/C System Circuits Check

S7RW0C1104069

Wiring Diagram



I6RW0C110021-01

1. BCM	9. A/C compressor	17. Main relay
2. ABS control module	10. A/C condenser cooling fan motor relay	18. "IG COIL" fuse
3. Blower speed selector (Auto A/C model)	11. A/C condenser cooling fan motor	19. A/C switch
4. ECM	12. "FI" fuse	20. Blower motor
5. A/C evaporator outlet air temp. sensor (Manual A/C model)	13. "IGN" fuse	21. Blower speed selector (Manual A/C model)
6. "IG2 SIG" fuse	14. Ignition switch	22. Blower motor relay

7. "A/C" fuse	15. A/C refrigerant pressure sensor	23. "BLW" fuse
8. A/C compressor relay	16. ECT sensor	

Troubleshooting

NOTE

- Before performed troubleshooting, be sure to read the "Precautions of ECM Circuit Inspection".
- When measuring circuit voltage, resistance and/or pulse signal at ECM connector, connect the special tool to ECM and/or the ECM connectors referring to "Inspection of ECM and Its Circuits".
- When A/C evaporator outlet air temp. is below 2 °C (35.6 °F), A/C remains OFF ("E01-49" terminal voltage becomes 10 – 14 V). This condition is not abnormal.

Step	Action	Yes	No
1	Reception data check from BCM 1) Connect scan tool to DLC with ignition switch turned OFF. 2) Turn ON ignition switch. 3) Check DTC for CAN-DTC. <i>Is there any CAN-DTC?</i>	Go to "Troubleshooting for CAN-DTC".	Go to Step 2.
2	DTC check of HVAC control module 1) Check HVAC control module for DTC. <i>Is there DTC(s)?</i>	Go to applicable DTC diag. flow.	Go to Step 3.
3	A/C switch signal circuit check 1) Start engine and select "Data List" mode on scan tool. 2) Check A/C switch signal under the following conditions respectively. <u>A/C switch signal</u> Engine running, A/C switch OFF: OFF Engine running, A/C switch ON and blower speed selector turned 1st position or more: ON <i>Is check result satisfactory?</i>	Go to Step 4.	Check HVAC control module and its circuit.
4	DTC check of ECT sensor circuit 1) Check ECM for DTC of ECT sensor circuit. <i>Is there DTC P0116, DTC P0117 or DTC P0118?</i>	Go to applicable DTC diag. flow.	Go to Step 5.
5	A/C condenser cooling fan control system check <i>Is A/C condenser cooling fan started when A/C and blower speed selector switch are turned ON with engine running?</i>	Go to Step 11.	Go to Step 6.
6	A/C condenser cooling fan control circuit check 1) Check DTC with scan tool. <i>Is DTC P0481 displayed?</i>	Go to "DTC P0481: Fan 2 Control Circuit".	Go to Step 7.
7	DTC check of A/C refrigerant pressure sensor circuit 1) Connect scan tool to DLC with ignition switch turned OFF. 2) Turn ON ignition switch. 3) Check ECM for DTC of A/C refrigerant pressure sensor circuit. <i>Is there DTC P0532 or DTC P0533?</i>	Go to applicable DTC diag. flow.	Go to Step 8.


1A-162 Engine General Information and Diagnosis:

Step	Action	Yes	No
8	A/C refrigerant pressure sensor voltage check 1) Check A/C refrigerant pressure sensor voltage referring to "Inspection of ECM and Its Circuits". <i>Is voltage within specified value?</i>	Go to Step 9.	Check amount of refrigerant. If OK, replace A/C refrigerant pressure sensor.
9	A/C evaporator temperature sensor check 1) Check A/C evaporator temperature sensor referring to "Evaporator Temperature Sensor Inspection: Manual Type in Section 7B". <i>Is resistance within specification?</i>	Go to Step 10.	Faulty A/C evaporator temperature sensor.
10	A/C condenser cooling fan check 1) Check A/C condenser cooling fan referring to "Condenser Cooling Fan Inspection: Manual Type in Section 7B". <i>Is check result satisfactory?</i>	A/C condenser cooling fan drive circuit malfunction. If circuit is OK, go to Step 5.	Replace A/C condenser cooling fan motor.
11	A/C compressor control system check <i>Is A/C compressor started when A/C and blower speed selector switch are turned ON with engine running?</i>	A/C system is in good condition.	Go to Step 12.
12	A/C compressor relay circuit check 1) Measure voltage between "E01-49" wire terminal of ECM connector and vehicle body ground under the following conditions respectively. <u>Voltage between "E01-49" terminal of ECM connector and ground</u> While engine running and A/C switch turned OFF: 10 – 14 V While engine running, A/C and blower speed selector switch turned ON: 0 – 1 V <i>Is check result satisfactory?</i>	Go to Step 13.	Go to Step 14.
13	A/C compressor relay check 1) Check A/C compressor relay referring to "A/C System Relay Inspection: Manual Type in Section 7B". <i>Is it in good condition?</i>	A/C compressor drive circuit malfunction.	Replace A/C compressor relay.
14	A/C compressor relay circuit check 1) Remove A/C compressor relay with ignition switch turned OFF. 2) Turn ON ignition switch, measure voltage between "BLU/YEL" wire terminal of A/C compressor relay connector and vehicle body ground. <i>Is voltage 10 – 14 V?</i>	Go to Step 15.	"BLU/YEL" wire is open circuit.
15	A/C compressor relay check 1) Check A/C compressor relay referring to "A/C System Relay Inspection: Manual Type in Section 7B". <i>Is it in good condition?</i>	"GRY" wire is open circuit. If OK, substitute a known-good ECM and recheck.	Replace A/C compressor relay.

Electric Load Signal Circuit Check

S7RW0C1104070

Wiring Diagram



I6RW0C110022-01

1. ECM	7. Junction block	13. "IG COIL" fuse
2. ABS control module	8. Blower motor relay	14. "IG2 SIG" fuse
3. BCM	9. Blower motor	15. "BLW" fuse
4. Electric load signal (blower motor signal, rear defogger signal and headlight signal), etc.	10. Blower speed selector (Auto A/C model)	16. "FI" fuse
5. Fuse box No.2	11. Blower speed selector (Manual A/C model)	17. "IGN" fuse
6. Ignition switch	12. Main relay	

Troubleshooting

NOTE



- Before performed troubleshooting, be sure to read the “Precautions of ECM Circuit Inspection”.
- When measuring circuit voltage, resistance and/or pulse signal at ECM connector, connect the special tool to ECM and/or the ECM connectors referring to “Inspection of ECM and Its Circuits”.

Step	Action	Yes	No
1	DTC check 1) Connect scan tool to DLC with ignition switch turned OFF. 2) Turn ON ignition switch and check DTC. <i>Is there any CAN-DTC?</i>	Go to “Troubleshooting for CAN-DTC”.	Go to Step 2.
2	Electric load signal circuit check 1) Start engine and select “Data List” mode on scan tool. 2) Check electric load signal under following conditions respectively. <u>Blower fan signal (Manual A/C model)</u> Blower speed selector turned 2nd position or less: OFF Blower speed selector turned to 3rd position or more: ON <u>Blower fan signal (Automatic A/C model)</u> Blower speed selector OFF or 1st position: OFF Blower speed selector turned to 3rd position or more: ON <u>Radiator fan signal</u> Engine coolant temperature is lower than 97 °C (206 °F): OFF Engine coolant temperature is higher than 97 °C (206 °F): ON <u>Electric load signal</u> Engine running, rear defogger switch, small light or headlight switch OFF: OFF Engine running, rear defogger switch, small light or headlight switch ON: ON <i>Is check result satisfactory?</i>	Electric load signal circuit is in good condition.	Check defective signal circuit.

Radiator Cooling Fan Low Speed Control System Check

S7RW0C1104071

Wiring Diagram



I7RW01110043-02

1. Fuse box No.2	5. Radiator cooling fan relay No. 3	9. ECT sensor	13. "RDTR" fuse
2. Ignition switch	6. Radiator cooling fan motor	10. "IG COIL" fuse	
3. Radiator cooling fan relay No. 1	7. Main relay	11. "IGN" fuse	
4. Radiator cooling fan relay No. 2	8. ECM	12. "FI" fuse	

Troubleshooting

⚠ WARNING

Keep hands, tools, and clothing away from radiator cooling fan to help prevent personal injury. This fan is electric and can come on whether or not the engine is running. The fan can start automatically in response to the ECT sensor with the ignition switch at the "ON" position.

NOTE

- Before performed troubleshooting, be sure to read the "Precautions of ECM Circuit Inspection".
- When measuring circuit voltage, resistance and/or pulse signal at ECM connector, connect the special tool to ECM and/or the ECM connectors referring to "Inspection of ECM and Its Circuits".

Step	Action	Yes	No
1	<i>Is there DTC(s) of ECT sensor circuit (DTC P0116 / P0117 / P0118) and/or radiator cooling fan circuit (DTC P0480)?</i>	Go to corresponding DTC flow.	Go to Step 2.
2	Low speed radiator cooling fan control circuit check 1) Connect scan tool to DLC with ignition switch turned OFF. 2) Start engine and select "Data List" mode on scan tool. 3) Warm up engine until coolant temp. is 97 °C, 206.6 °F or higher and A/C switch turns OFF. (If engine coolant temp. dose not rise, check engine cooling system or ECT sensor.) <i>Is radiator cooling fan started at low speed when engine coolant temp. reached above temp.?</i>	Radiator cooling fan low speed control system is in good condition.	Perform from Step 2 to Step 6 of "DTC P0480: Fan 1 Control Circuit". If OK, Go to Step 3.
3	Radiator cooling fan control check 1) Disconnect radiator cooling fan relays No. 2 and No. 3 from fuse box No.2 with ignition switch turned OFF. 2) Run engine when ECT is over 97 °C, 206.6 °F. 3) Measure voltage between vehicle body ground and "BLU/RED" wire terminal of disconnected radiator cooling fan motor connector. <i>Is voltage 10 – 14 V?</i>	Go to Step 4.	"BLU/RED" wire is open or high resistance circuit.
4	Check radiator cooling fan wire circuit check 1) Turn ignition switch to OFF position. 2) Measure resistance between "BLK" wire terminal of disconnected radiator cooling fan motor connector and vehicle body ground. <i>Is resistance below 1 Ω?</i>	Go to Step 5.	"BLK" wire is open or high resistance circuit.
5	Radiator cooling fan check 1) Check radiator cooling fan referring to "Radiator Cooling Fan Assembly Inspection in Section 1F". <i>Is it in good condition?</i>	Substitute a known-good ECM and recheck.	Faulty radiator cooling fan.

Radiator Cooling Fan High Speed Control System Check

S7RW0C1104072

Wiring Diagram

Refer to "Radiator Cooling Fan Low Speed Control System Check".

Troubleshooting

⚠ WARNING

Keep hands, tools, and clothing away from radiator cooling fan to help prevent personal injury. This fan is electric and can come on whether or not the engine is running. The fan can start automatically in response to the ECT sensor with the ignition switch at the "ON" position.

NOTE

- Before performed troubleshooting, be sure to read the "Precautions of ECM Circuit Inspection".
- When measuring circuit voltage, resistance and/or pulse signal at ECM connector, connect the special tool to ECM and/or the ECM connectors referring to "Inspection of ECM and Its Circuits".

Step	Action	Yes	No
1	Low speed radiator cooling fan control circuit check 1) Check low speed radiator cooling fan control circuit referring to "Radiator Cooling Fan Low Speed Control System Check". <i>Is it in good condition?</i>	Go to Step 2.	Repair or replace faulty condition.
2	High speed radiator cooling fan control circuit check 1) Start engine and select "Data List" mode on scan tool. 2) Warm up engine until coolant temp. is 102.5 °C, 216.5 °F or higher and A/C switch turns OFF. (If engine coolant temp. dose not rise, check engine cooling system or ECT sensor.) <i>Is radiator cooling fan started at high speed when engine coolant temp. reached above temp?</i>	Radiator cooling fan control system is in good condition.	Perform from Step 2 to Step 6 of "DTC P0480: Fan 1 Control Circuit". If OK, Go to Step 3.
3	Radiator cooling fan check 1) Check radiator cooling fan referring to "Radiator Cooling Fan Assembly Inspection in Section 1F". <i>Is it in good condition?</i>	Substitute a known-good ECM and recheck.	Faulty radiator cooling fan.

Repair Instructions

Idle Speed and IAC Throttle Valve Opening Inspection

S7RW0C1106001

Before idle speed check, make sure of the following.

- Lead wires and hoses of electronic fuel injection and engine and emission control systems are connected securely.
- Valve lash is checked according to maintenance schedule.
- Ignition timing is within specification.
- All accessories (wipers, heater, lights, A/C, etc.) are out of service.
- Air cleaner has been properly installed and is in good condition.
- There are no abnormal air drawn in from air intake system.
- There are no obstruction in PCV valve or its hoses.

After all items are confirmed, check idle speed and IAC throttle opening as follows.


NOTE

Before starting engine, place transmission gear shift lever in "Neutral" (shift selector lever to "P" range for A/T vehicle), and set parking brake and block drive wheels.

- 1) Connect SUZUKI scan tool to DLC (1) with ignition switch turned OFF.

Special tool

(A): SUZUKI scan tool (SUZUKI-SDT)



I5RW0C110011-01

- 2) Warm up engine to normal operating temperature.
- 3) Check engine idle speed and "IAC throttle opening" by using "Data List" mode on scan tool to check "IAC throttle opening".

If check result is out of specification, inspect the followings.

- EVAP canister purge control system referring to "EVAP Canister Purge Inspection in Section 1B".
- Electric load signal circuit referring to "Electric Load Signal Circuit Check".
- PCV system referring to "PCV Hose Inspection in Section 1B".
- Electric throttle body assembly referring to "Electric Throttle Body Assembly On-Vehicle Inspection in Section 1C".

Engine idle speed

A/C OFF: 680 – 780 rpm (IAC throttle opening: 10 – 20%)





A/C ON: 750 – 850 rpm (IAC throttle opening: 15 – 25%)

- 4) Check that specified engine idle speed is obtained with A/C turned ON if vehicle is equipped with A/C. If not, check A/C system referring to "A/C System Circuits Check".

Special Tools and Equipment

Special Tool

S7RW0C1108001

09912-58432 Fuel pressure gauge hose This tool is included in fuel pressure gauge set (09912-58413).  	09912-58442 Fuel pressure gauge This tool is included in fuel pressure gauge set (09912-58413).  
09912-58490 3-way joint & hose  	09933-06320 ECM check harness (120P)  /  
SUZUKI scan tool (SUZUKI-SDT) — This kit includes following items. 1. SUZUKI-SDT 2. DLC3 cable 3. USB cable 4. AC/DC power supply 5. Voltage meter probe 6. Storage case  /  	


Aux. Emission Control Devices

Diagnostic Information and Procedures

EVAP Canister Purge System Inspection


S7RW0C1204001

- 1) Warm up engine to normal operating temperature.
- 2) Hoist vehicle so that all wheels rotate freely.



IYSQ01124001-01

- 3) Set M/T in "Neutral" or A/T in "P" position and parking brake.
- 4) Disconnect purge hose (1) from purge valve chamber.
- 5) Place finger against the end of disconnected purge hose (1) and check that vacuum is not felt there when engine is running at idle speed.




I7RW01120001-01

- 6) Release parking brake lever, set M/T in "1st" or A/T in "L".
- 7) Also check that vacuum is felt when engine speed is increased to higher than about 1,500 r/min. and keep it for 3 min. or more. If check result is not described in Steps 5) and 7), check EVAP canister purge valve, wire harness and vacuum passage.

Repair Instructions

EVAP System Components

S7RW0C1206001



I6RW0C120001-01

1. EVAP canister	7. Purge hose No.1	13. Clamp
2. EVAP canister bracket	8. Purge pipe No.1	14. Vapor control hose
3. Suction hose	9. Purge pipe No.2	15. To intake manifold
4. EVAP canister purge valve	10. EVAP canister purge hose	16. To fuel tank
5. EVAP canister purge valve bracket	11. Purge valve chamber	17. To fuel filler neck
6. Purge hose No.3	12. Purge hose No.2	(a) : 5 N·m (0.5 kgf-m, 4.0 lb-ft)


EVAP Canister Purge Inspection

S7RW0C1206002

NOTE

Before inspection, check to make sure that gear shift lever is in neutral position (with A/T model, selector lever in "P" range) and that parking brake lever is pulled all the way up.

- 1) Disconnect purge hose (1) from purge valve chamber.
- 2) Place finger against the end of disconnected hose and check that vacuum is not felt there when engine is cool and running at idle speed. If check result is not satisfactory, check EVAP canister purge valve, wire harness and ECM.



I7RW01120001-01

EVAP Canister Purge Valve and Its Circuit Inspection

S7RW0C1206003

⚠ WARNING

Do not apply vacuum by mouth; otherwise harmful fuel vapor can be breathed in.

⚠ CAUTION

Do not apply vacuum more than -86 kPa (-12.47 psi); otherwise EVAP canister purge valve could be damaged.


1) Prepare to operate EVAP canister purge valve as follows.

a) When using SUZUKI scan tool:

- Connect SUZUKI scan tool to DLC (1) with ignition switch turned OFF and disconnect purge valve vacuum hoses from intake manifold and purge pipe.
- Turn ON ignition switch, clear DTC and select "Active Test" mode on SUZUKI scan tool.

Special tool

(A): SUZUKI scan tool (SUZUKI-SDT)




I5RW0C110011-01

b) When not using SUZUKI scan tool:

NOTE

Before performed this check, be sure to read the "Precautions of ECM Circuit Inspection in Section 1A".

- Disconnect hoses from intake manifold and purge valve chamber.
- Connect special tool between ECM and ECM connector referring to "Inspection of ECM and Its Circuits in Section 1A".
- Turn ON ignition switch.
Using service wire, ground "C01-13" terminal (1) circuit of special tool (valve ON: "B") and unground it (valve OFF: "A").



I7RW01120002-01

2) Check purge valve (2) for operation and vacuum passage for clog when valve is switched ON and OFF by using SUZUKI scan tool or service wire. If check result is not satisfactory, check hoses, EVAP canister purge valve, wire harness and connections.


EVAP canister purge valve specification

Valve OFF [A]: When vacuum (-53 kPa (-7.69 psi) to -67 kPa (-9.72 psi)) is applied to hose (1), vacuum is maintained.

Valve ON [B]: When vacuum is applied to hose (1), air goes into hose.

Special tool

(A): 09917-47011




I7RW01120003-01

Vacuum Passage Inspection

S7RW0C1206004

Start engine and run it at idle speed. Disconnect purge hose No.3 (1) from EVAP canister purge valve (2). With finger placed against disconnected hose, check that vacuum is applied.

If it is not applied, clean vacuum passage by blowing compressed air.



I5RW0A120003-01

Vacuum Hose and Purge Valve Chamber Inspection

S7RW0C1206005

Check hoses and purge valve chamber for connection, leakage, clog and deterioration referring to "EVAP System Components".

Replace as necessary.

EVAP Canister Purge Valve Inspection

S7RW0C1206006

⚠ WARNING


Do not apply vacuum by mouth; otherwise harmful fuel vapor can be breathed in.

⚠ CAUTION

Do not apply vacuum more than -86 kPa (-12.47 psi); otherwise EVAP canister purge valve could be damaged.

- 1) With ignition switch turned OFF, disconnect coupler and vacuum hoses from canister purge valve.
- 2) Remove EVAP canister purge valve from intake manifold.
- 3) Check resistance between two terminals of EVAP canister purge valve.
If resistance is as specified, proceed to next operation check. If not, replace EVAP canister purge valve.

EVAP canister purge valve resistance
22 – 26 Ω at 20 °C (68 °F)



I3RM0A120008-01

- 4) Check EVAP canister purge valve for operation using special tool as follows.



⚠ WARNING

Do not suck the air through valve. Fuel vapor inside valve is harmful.

Special tool

(A): 09917-47011

- a) With coupler disconnected, apply vacuum (-53 kPa (-7.69 psi) to -67 kPa (-9.72 psi)) to pipe (1). If vacuum can be applied, go to next step. If vacuum can not be applied, replace EVAP canister purge valve.
- b) In this state, connect 12 V-battery to EVAP canister purge valve terminals. If vacuum can not be applied, EVAP canister purge valve is in good condition.
If applied, replace EVAP canister purge valve.



I3RB0A120007-01


- 5) Install EVAP canister purge valve to intake manifold.
- 6) Connect coupler and vacuum hoses to canister purge valve.

EVAP Canister Removal and Installation

S7RW0C1206007

Removal

- 1) Disconnect negative cable at battery.
- 2) Hoist vehicle.
- 3) Remove EVAP canister as follows.
 - a) Disconnect hoses (1) from EVAP canister (2).
 - b) Remove EVAP canister bracket (3) with EVAP canister from vehicle body.
 - c) Remove EVAP canister from EVAP canister bracket.



I7RW01120014-01

Installation

Reverse removal procedure for installation noting the following.

- When installing hoses, do not apply soap, grease or oil to insertion part.
- For quick joint, push joint into pipe till joint lock clicks and check that quick joint does not pull out without unlocking joint lock.


EVAP Canister Inspection

S7RW0C1206008

⚠ WARNING

Do not suck nozzles on EVAP canister. Fuel vapor inside EVAP canister is harmful.

- 1) Check outside of EVAP canister visually.
 - 2) Disconnect vacuum hoses from EVAP canister.
 - 3) Check that there is no restriction of flow through purge pipe (1) and air pipe (2) when air is blown (4) into tank pipe (3).
- If any faulty condition is found in this inspection, replace EVAP canister.



I6RW0C120002-01

PCV Hose Inspection

S7RW0C1206009

Check hoses for connection, leakage, clog and deterioration.

Replace as necessary.

PCV Valve Removal and Installation

S7RW0C1206010

Removal

- 1) Remove air cleaner referring to "Air Cleaner Assembly Removal and Installation in Section 1D".
- 2) Disconnect PCV hose from PCV valve.
- 3) Remove PCV valve from cylinder head cover.

Installation

Reverse removal procedure for installation noting the following.

- Apply sealant to thread part of PCV valve (1).


"A": Water tight sealant 99000-31250 (SUZUKI Bond No.1207F)

- Tighten PCV valve to specified torque.

Tightening torque

PCV valve (a): 27 N·m (2.7 kgf-m, 19.5 lb-ft)

- Connect PCV hose to PCV valve securely.




I7RW01120005-01

PCV Valve Inspection


S7RW0C1206011

- 1) Remove PCV valve referring to "PCV Valve Removal and Installation".
- 2) Connect PCV valve to hose and install plug to cylinder head cover hole.
- 3) Run engine at idle.
- 4) Place your finger over end of PCV valve (1) to check for vacuum.
If there is no vacuum, check for clogged valve.
Replace as necessary.



I5JA01121009-01

- 5) After checking vacuum, stop engine and remove PCV valve (1).
Shake valve and listen for rattle of check needle inside the valve. If valve does not rattle, replace PCV valve.



I4JA01121012-01

- 6) After checking, remove plug and install PCV valve referring to "PCV Valve Removal and Installation".
- 7) Install air cleaner referring to "Air Cleaner Assembly Removal and Installation in Section 1D".

Specifications**Tightening Torque Specifications**

S7RW0C1207001

Fastening part	Tightening torque			Note
	N·m	kgf·m	lb·ft	
PCV valve	27	2.7	19.5	

NOTE

The specified tightening torque is also described in the following.
"EVAP System Components"

Reference:

For the tightening torque of fastener not specified in this section, refer to "Fasteners Information in Section 0A".

Special Tools and Equipment**Recommended Service Material**

S7RW0C1208001


Material	SUZUKI recommended product or Specification		Note
Water tight sealant	SUZUKI Bond No.1207F	P/No.: 99000-31250	

Special Tool

S7RW0C1208002


09917-47011

Vacuum pump gauge



SUZUKI scan tool (SUZUKI-SDT)

—
This kit includes following items. 1. SUZUKI-SDT 2. DLC3 cable 3. USB cable 4. AC/DC power supply 5. Voltage meter probe 6. Storage case



Engine Electrical Devices

Repair Instructions

Engine Control Module (ECM) Removal and Installation

S7RW0C1306001

⚠ CAUTION

As ECM consists of precision parts, be careful not to expose it to excessive shock.


NOTE

For vehicle equipped with immobilizer control system:

If ECM is replaced with new one or with another one, make sure to register immobilizer transponder code to ECM correctly according to "Procedure after ECM Replacement in Section 10C".


Removal

- 1) Disconnect negative cable at battery.
- 2) Remove ECM cover.
- 3) Disconnect connectors from ECM as follows.
 - a) Push lock (1) to release locking of lock lever (2).
 - b) Turn lock lever to arrow direction until it stops.



I4RS0A130003-01

- 4) Remove ECM (1) from its bracket by removing its mounting bolts (2).




I5RW0A130001-01

Installation


Reverse removal procedure noting the following:

- Connect connectors to ECM as follows.
 - a. Make sure that lock lever of ECM connector is unlock position.




I4RS0B130021-01

- b. Insert ECM connectors to ECM until it stops with unlocked lock lever.



I4RS0B130022-01

- c. Lock ECM connectors securely by pulling its lock lever up.



I4RS0A130004-01

Electric Throttle Body Assembly On-Vehicle Inspection

S7RW0C1306002

⚠ WARNING

Never touch throttle valve with finger while ignition switch is turned ON and accelerator pedal is depressed. Otherwise, injury may result by pinching the finger between throttle valve and throttle body housing.

⚠ CAUTION


- Do not disassemble electric throttle body assembly.
- Do not expose electric throttle body assembly to excessive shock like a dropping it. If electric throttle body assembly has been exposed to excessive shock, it should be replaced.
- Be careful not to accrete a foreign material (like dust and/or metallic particle) to the throttle body housing and/or throttle valve. Otherwise, the throttle body assembly is breaking down by throttle valve accretion.
- Do not apply excessive moving force to throttle valve for throttle valve operation check and/or TP sensor performance check.
Otherwise, the throttle body assembly is breaking down by damaging the internal resinous gear of throttle valve actuator.

Throttle Valve Visual Check

- 1) Remove air cleaner outlet hose.
- 2) Check that there isn't any foreign matter caught between throttle valve and throttle body housing. If there is, take it out after removing throttle body referring to "Electric Throttle Body Assembly Removal and Installation in Section 1D" and clean inside of throttle body thoroughly.


Throttle Valve Operation Check

- 1) Remove air cleaner outlet hose.
- 2) Turn OFF ignition switch.
- 3) Move throttle valve with finger to its full open position and check that it moves smoothly.
- 4) Move throttle valve with finger to its completely closed position and check that it moves smoothly.



I5JB0A130013-01

- 5) Take off finger from throttle valve (1) which is at full open position and check that it moves smoothly by its return spring and open spring force back to default position (position where throttle valve is open by 7° (2) from completely closed position).
- 6) Take off finger from throttle valve (1) which is at completely closed position and check that it moves smoothly by its return spring and open spring force back to default position.




I5JB0A130035-01

If check result is not satisfactory, replace electric throttle body assembly.

Electric Throttle Body Assembly Operation Check

- 1) Remove air cleaner outlet hose.
- 2) Turn ON ignition switch.
- 3) Depress accelerator pedal gradually and check that throttle valve moves smoothly until it opens fully.
- 4) Release accelerator pedal depressed in Step 3) and check that throttle valve (1) moves back to default position (position where throttle valve is open by 7° (2) from its completely closed position).



I5JB0A130035-01

If check result is satisfactory, electric throttle body system is in good condition. If check result is not satisfactory, proceed to next step.

- 5) Perform "Accelerator Pedal Position (APP) Sensor Assembly On-Vehicle Inspection", "Throttle Actuator (Motor) Check" and "Throttle Position Sensor Performance Check".


If check results are not satisfactory, replace electric throttle body assembly.

If check results are satisfactory, wire circuit and/or ECM are faulty.

Throttle Actuator (Motor) Check

- 1) Turn OFF ignition switch.
- 2) Disconnect connector from electric throttle body assembly.
- 3) Measure resistance between "M1" terminal (1) and "M2" terminal (2) of electric throttle body assembly. If measured resistance is out of specified value, replace electric throttle body assembly.

Throttle actuator (motor) resistance
0.3 – 100 Ω at 20 °C, 68 °F




I7RW01130003-01

Throttle Position (TP) Sensor Performance Check


- 1) Remove air cleaner outlet hose.
- 2) Turn OFF ignition switch.
- 3) Disconnect connector from electric throttle body assembly.
- 4) Check TP sensor (main and sub) output voltage as the following steps.

- a) For TP sensor (main), arrange 3 new 1.5 V batteries (1) in series (check that total voltage is 4.5 – 5.0 V) and connect its positive terminal to "Vin" terminal (2) and negative terminal to "Ground" terminal (3) of sensor. Then using voltmeter, connect positive terminal to "Vout 1" terminal (4) of sensor and negative terminal to battery.



I7RW01130004-01

- b) For TP sensor (sub), arrange 3 new 1.5 V batteries (1) in series (check that total voltage is 4.5 – 5.0 V) and connect its positive terminal to "Vin" terminal (2) and negative terminal to "Ground" terminal (3) of sensor. Then using voltmeter, connect positive terminal to "Vout 2" terminal (4) of sensor and negative terminal to battery.



I7RW01130005-01


- c) Measure output voltage variation while throttle valve is opened and closed as the following specification.

If sensor voltage is out of specified value and linear variation as the following graph, replace electric throttle body assembly.

TP sensor output voltage

TP sensor (main) [A]: 0.45 – 4.88 V, varying according to throttle valve opening by finger (Voltage should vary by 0.04 V for each 1° valve opening)

TP sensor (sub) [B]: 1.33 – 5.007 V, varying according to throttle valve opening by finger (Voltage should vary by about 0.032 V for each 1° valve opening)



I7RW01130019-05

[C]: TP sensor (main) output voltage
[D]: TP sensor (sub) output voltage
[E]: Throttle valve opening
[F]: Position where throttle valve is open by 7° from completely closed position (default position)
[G]: Angle obtained when accelerator pedal is depressed fully (84°)
[H]: Angle obtained when throttle valve is fully opened with finger (96°)

Electric Throttle Body System Calibration

S7RW0C1306003

NOTE



If the service described under the “Precautions of Electric Throttle Body System Calibration in Section 1A” is performed, calibrate electric throttle body system as follows.

- 1) If electric throttle body assembly and/or APP sensor assembly are replaced, perform the following steps.
 - a) Disconnect negative cable at battery for 20 seconds or more for the purpose of clearing calibration data of closed throttle position from memory in ECM.
 - b) Connect negative cable to battery.
- 2) Keep ignition switch at ON position for 5 seconds or more without running engine.

Accelerator Pedal Position (APP) Sensor Assembly On-Vehicle Inspection

S7RW0C1306004

- 1) Check that APP sensor assembly has been mounted to vehicle body properly (no pinched floor carpet, etc.).
If mounting is not properly, reinstall APP sensor assembly properly referring to “Accelerator Pedal Position (APP) Sensor Assembly Removal and Installation”.
- 2) Connect scan tool to DLC with ignition switch turned OFF.
- 3) Turn ON ignition switch and select “Data List” mode on scan tool.
- 4) Check that APP sensor voltage varies as the following graph.
If sensor voltage is out of specified value or does not vary linearly as the following graph, check APP sensor assembly referring to “Accelerator Pedal Position (APP) Sensor Assembly Inspection”.



I7RW01130020-01

[A]: APP sensor (main) voltage
[B]: APP sensor (sub) voltage
[C]: Voltage
[D]: Idle position of accelerator pedal
[E]: Full depressed position of accelerator pedal

Accelerator Pedal Position (APP) Sensor Assembly Removal and Installation

S7RW0C1306005

⚠ CAUTION

- Do not expose APP sensor assembly to excessive shock like a dropping it. If APP sensor assembly has been exposed to excessive shock, it should be replaced.
- Be careful not to expose sensor section of APP sensor assembly to water.

NOTE

After replacing APP sensor assembly, perform calibration of throttle valve referring to "Electric Throttle Body System Calibration".

Removal

- 1) Disconnect negative cable at battery.
- 2) Disconnect connector from APP sensor assembly.
- 3) Remove APP sensor assembly from its bracket.


Installation

Reverse removal procedure for installation noting the following.

- Tighten APP sensor assembly upper nut (1) first and then lower nuts (2) to specified torque.

Tightening torque

APP sensor assembly nut (a): 6 N·m (0.6 kgf-m, 4.5 lb-ft)



I5RW0A130004-01


- Connect connector to APP sensor assembly securely.

Accelerator Pedal Position (APP) Sensor Assembly Inspection

S7RW0C1306006


Check APP sensor (main and sub) output voltage as the following steps.

- 1) For APP sensor (main), arrange 3 new 1.5 V batteries (1) in series (check that total voltage is 4.5 – 5.0 V) and connect its positive terminal to "Vin 1" terminal (2) and negative terminal to "Ground 1" terminal (3) of sensor. Then using voltmeter, connect positive terminal to "Vout 1" terminal (4) of sensor and negative terminal to battery.




I5RW0A130005-01

- 2) For APP sensor (sub), arrange 3 new 1.5 V batteries (1) in series (check that total voltage is 4.5 – 5.0 V) and connect its positive terminal to "Vin 2" terminal (2) and negative terminal to "Ground 2" terminal (3) of sensor. Then using voltmeter, connect positive terminal to "Vout 2" terminal (4) of sensor and negative terminal to battery.



I5RW0A130006-02

- 3) Measure output voltage variation while accelerator pedal is released and fully depressed as the following graph.
- If sensor voltage is out of specified value or does not vary linearly as the following graph, replace APP sensor assembly.



[C]: Voltage
[D]: Idle position of accelerator pedal
[E]: Fully depressed position of accelerator pedal

Engine Coolant Temperature (ECT) Sensor Removal and Installation

S7RW0C1306007

Removal


- 1) Disconnect negative cable at battery.
- 2) Drain coolant referring to "Cooling System Description in Section 1F".

⚠ WARNING

To avoid danger of being burned, do not remove radiator cap while engine and radiator are still hot.

Scalding fluid and steam can be blown out under pressure if cap is taken off too soon.

- 3) Disconnect connector from ECT sensor (1).



I7RW01130006-01

- 4) Remove ECT sensor from water outlet cap.


Installation

Reverse removal procedure noting the following.

- Clean mating surfaces of ECT sensor and water outlet cap.
- Check O-ring for damage and replace, if necessary.
- Tighten ECT sensor (1) to specified torque.

Tightening torque

ECT sensor (a): 12.5 N·m (1.25 kgf-m, 9.0 lb-ft)



I7RW01130007-01


- Connect connector to ECT sensor securely.
- Refill coolant referring to "Cooling System Flush and Refill in Section 1F".

Engine Coolant Temperature (ECT) Sensor Inspection

S7RW0C1306008

Immerse temperature sensing part of ECT sensor in water (or ice) and measure resistance between sensor terminals while heating water gradually.

If measured resistance doesn't show such characteristic as shown, replace ECT sensor.



[A]: Lower limit	[D]: Resistance
[B]: Normal	[E]: Temperature
[C]: Upper limit	

Air Fuel Ratio (A/F) Sensor On-Vehicle Inspection

S7RW0C1306009

Heater

- 1) Disconnect A/F sensor connector.
- 2) Using ohmmeter, measure resistance of Sensor heater between terminals "V_B" and "GND" at sensor connector. If found faulty, replace A/F sensor.

NOTE

Temperature of sensor affects resistance value largely. Make sure that sensor heater is at correct temperature.

A/F sensor heater resistance
2 – 3 Ω at 20 °C (68 °F)

Viewed from terminal side



I7RW01130009-02

- 3) Connect A/F sensor connector securely.

Heated Oxygen Sensor (HO2S) Heater On-Vehicle Inspection

S7RW0C1306010


- 1) Disconnect sensor connector.
- 2) Using ohmmeter, measure resistance of sensor heater between terminals "V_B" and "GND" at sensor connector. If found faulty, replace oxygen sensor.

NOTE

Temperature of sensor affects resistance value largely. Make sure that sensor heater is at correct temperature.

HO2S heater resistance
5.0 – 6.4 Ω at 20 °C (68 °F)

Viewed from terminal side



I5JB0A130024-03

- 3) Connect sensor connector securely.

Air Fuel Ratio (A/F) Sensor, Heated Oxygen Sensor (HO2S) Removal and Installation

S7RW0C1306011

Removal

⚠ WARNING

To avoid danger of being burned, do not touch exhaust system when system is hot. A/F sensor and/or HO2S removal should be performed when system is cool.

- 1) Disconnect negative cable at battery.
- 2) Disconnect connector of A/F sensor and/or HO2S.
- 3) Remove A/F sensor (1) and/or HO2S (2) from exhaust No.1 pipe.

Installation

Reverse removal procedure noting the following.

- Tighten A/F sensor (1) to specified torque.


Tightening torque

A/F sensor (a): 45 N·m (4.5 kgf-m, 32.5 lb-ft)

- Tighten HO2S (2) to specified torque.

Tightening torque

HO2S (b): 45 N·m (4.5 kgf-m, 32.5 lb-ft)



I7RW01130010-01

Camshaft Position (CMP) Sensor Removal and Installation

S7RW0C1306012

Removal


- 1) Disconnect negative cable at battery.
- 2) Remove air cleaner case referring to "Air Cleaner Assembly Removal and Installation in Section 1D".
- 3) Disconnect connector from CMP sensor.
- 4) Remove camshaft position sensor from cylinder head cover.

Installation

- 1) Install CMP sensor to cylinder head cover.

Tightening torque

CMP sensor bolt (a): 11 N·m (1.1 kgf-m, 8.0 lb-ft)



I7RW01130011-01


- 2) Connect connector to CMP sensor securely.
- 3) Install air cleaner case referring to "Air Cleaner Assembly Removal and Installation in Section 1D".
- 4) Connect negative cable to battery.

Camshaft Position (CMP) Sensor Inspection

S7RW0C1306013

Visual Check

- Check that O-ring is free from damage.
- Check that end face of sensor and signal rotor tooth are free from any metal particles and damage.




I4RS0B130015-01

Performance Check

- 1) Remove metal particles on end face of CMP sensor, if any.
- 2) Arrange 12 V battery (1) and connect its positive terminal to "Vin" terminal (2) and negative terminal to "Ground" terminal (3) of sensor. Then using ohmmeter, measure resistance between "Vout" terminal (4) of sensor and negative terminal of battery by passing magnetic substance (iron) (5) while keeping approximately 1 mm (0.03 in.) gap with respect to end face of CMP sensor. If resistance does not vary as specified below, replace CMP sensor.

CMP sensor resistance

Resistance varies from less than 220 Ω (ON) to infinity (OFF) or from infinity (OFF) to less than 220 Ω (ON)



I7RW01130012-01

Crankshaft Position (CKP) Sensor Removal and Installation

S7RW0C1306014

Removal

- 1) Remove transmission assembly from vehicle referring to "Automatic Transaxle Unit Dismounting and Remounting in Section 5A" or "Manual Transaxle Assembly Disassembly and Reassembly in Section 5B".
- 2) Remove drive plate or flywheel from crankshaft.
- 3) Disconnect connector from crankshaft position sensor.
- 4) Remove CKP sensor (1) from cylinder block (2).

1C-9 Engine Electrical Devices:


Installation

Reverse removal procedure noting the following.

- Apply engine oil to O-ring of sensor.
- Tighten CKP sensor bolt to specified torque.

Tightening torque

CKP sensor bolt (a): 11 N·m (1.1 kgf-m, 8.0 lb-ft)



- Connect connector and fix wire harness with clamp securely.

Crankshaft Position (CKP) Sensor Inspection

S7RW0C1306015


Waveform Check

Using oscilloscope, check that CKP sensor signal is outputted properly referring to "Reference waveform No.19" and "Reference waveform No.20" of "Inspection of ECM and Its Circuits in Section 1A".

If sensor signal is outputted properly, CKP sensor is in good condition.

Visual Check

- Check that O-ring is free from damage.
- Check that end face of sensor and signal plate tooth are free from any metal particles and damage.




Resistance Check

Measure resistance between "1" and "2" terminals of CKP sensor.

CKP sensor resistance

480 – 660 Ω at 20 °C, 68 °F

If measured resistance is out of specified value, replace CKP sensor.



Knock Sensor Removal and Installation

S7RW0C1306016

Removal

- 1) Disconnect negative cable at battery.
- 2) Hoist vehicle.
- 3) Remove right side drive shaft referring to "Front Drive Shaft Assembly Removal and Installation: Front in Section 3A".
- 4) Disconnect knock sensor connector (1).
- 5) Remove knock sensor (2) from cylinder block.

Installation

Reverse removal procedure for installation.

Tightening torque

Knock sensor (a): 22 N·m (2.2 kgf-m, 16.0 lb-ft)





Engine and Emission Control System Relay Inspection

S7RW0C1306017

Main, Fuel Pump, Starting Motor Control, Throttle Actuator Control and Radiator Cooling Fan Relays

- 1) Disconnect negative cable at battery.
- 2) Remove main relay (1), fuel pump relay (3), starting motor control relay (2), throttle actuator control relay (4) and/or radiator cooling fan relay (5) from individual circuit fuse box No.1.
- 3) Check that there is no continuity between terminal "C" and "D". If there is continuity, replace relay.
- 4) Connect battery positive (+) terminal to terminal "B" of relay. Connect battery negative (-) terminal to terminal "A" of relay. Check for continuity between terminal "C" and "D". If there is no continuity when relay is connected to the battery, replace relay.



I5RW0A130014-01


Mass Air Flow (MAF) and Intake Air Temperature (IAT) Sensor On-Vehicle Inspection

S7RW0C1306018

NOTE

Before performed this inspection, be sure to read the "Precautions of ECM Circuit Inspection in Section 1A".

- 1) Disconnect MAF and IAT sensor connector.
- 2) Connect voltmeter to "BLU/RED" wire terminal (2) of MAF and IAT sensor connector (1) disconnected and ground.




I7RW01130013-01

- 3) Turn ON ignition switch and check that voltage is battery voltage.
If not, check if wire harness is open or connection is poor.
- 4) Turn OFF ignition switch and connect connector to MAF and IAT sensor.
- 5) Connect special tool between ECM and ECM connector referring to "Inspection of ECM and Its Circuits in Section 1A".
- 6) Turn ON ignition switch and check MAF signal voltage between "C01-26" terminal circuit and "C01-27" terminal circuit of special tool.

MAF signal voltage between "C01-26" terminal circuit and "C01-27" terminal circuit of special tool

MAF signal voltage of MAF and IAT sensor with ignition switch turned ON: 0.5 – 1.0 V



I7RW01130014-01

- 7) Start engine and check that voltage is lower than 5 V and it rises as engine speed increases.

MAF signal voltage between "C01-26" terminal circuit and "C01-27" terminal circuit of special tool

MAF signal reference voltage of MAF and IAT sensor at specified Idle speed: 1.0 – 1.5 V

- 8) If check result is not as specified above, cause may lie in wire harness, connector connection, MAF and IAT sensor or ECM.

Mass Air Flow (MAF) and Intake Air Temperature (IAT) Sensor Removal and Installation


S7RW0C1306019

⚠ CAUTION

- Do not disassemble MAF and IAT sensor.
- Do not expose MAF and IAT sensor to any shock.
- Do not clean MAF and IAT sensor.
- If MAF and IAT sensor has been dropped, it should be replaced.
- Do not blow compressed air by using air gun or the like.
- Do not put finger or any other object into MAF and IAT sensor. Malfunction may occur.

Removal

- 1) Disconnect negative cable at battery.
- 2) Disconnect MAF and IAT sensor connector.
- 3) Remove air cleaner case referring to "Air Cleaner Assembly Removal and Installation in Section 1D".
- 4) Remove MAF and IAT sensor (1) from air cleaner case.



I7RW01130015-01


Installation

Reverse removal procedure noting the followings.

- Tighten MAF and IAT sensor screws to specified torque.

Tightening torque

MAF and IAT sensor screw (a): 1.2 N·m (0.12 kgf·m, 0.9 lb·ft)



I7RW01130016-01

- Connect MAF and IAT sensor connector securely.

Mass Air Flow (MAF) and Intake Air Temperature (IAT) Sensor Inspection

S7RW0C1306020

⚠ CAUTION

Do not heat up MAF and IAT sensor more than 100 °C (212 °F). Otherwise, MAF and IAT sensor will be damaged.



- Check sensor O-ring (1) for damage and deterioration. Replace as necessary.
- Blow hot air to temperature sensing part (2) of MAF and IAT sensor (3) using hot air drier (4) and measure resistance between sensor terminals while heating air gradually.
If measured resistance does not show such characteristic as shown, replace MAF and IAT sensor.

Intake air temperature sensor resistance

-20 °C (-4 °F): 13.6 – 18.4 kΩ

20 °C (68 °F): 2.21 – 2.69 kΩ

60 °C (140 °F): 0.493 – 0.667 kΩ



I7RW01130017-01

[A]: Lower limit	[D]: Resistance
[B]: Nominal	[E]: Temperature
[C]: Upper limit	5. Temperature gauge

IMT Valve Actuator Inspection


S7RW0C1306021

⚠ CAUTION

Be sure not to apply battery voltage to IMT valve actuator for 10 seconds or more.

- 1) Connect battery positive (+) and negative (–) terminals to IMT valve actuator (1) as shown in table below. If it does not operate as specified direction, replace IMT valve actuator.

Rotative direction	a	b
clockwise	+	–
counterclockwise	–	+



I7RW01130018-01

Specifications

Tightening Torque Specifications

S7RW0C1307001

Fastening part	Tightening torque			Note
	N·m	kgf·m	lb·ft	
APP sensor assembly nut	6	0.6	4.5	☞
ECT sensor	12.5	1.25	9.0	☞
A/F sensor	45	4.5	32.5	☞
HO2S	45	4.5	32.5	☞
CMP sensor bolt	11	1.1	8.0	☞
CKP sensor bolt	11	1.1	8.0	☞
Knock sensor	22	2.2	16.0	☞
MAF and IAT sensor screw	1.2	0.12	0.9	☞

Reference:

For the tightening torque of fastener not specified in this section, refer to “Fasteners Information in Section 0A”.


Engine Mechanical

General Description

Engine Construction

S7RW0C1401001


The engine is water-cooled, in line 4 cylinders, 4 stroke cycle gasoline unit with its DOHC (Double over head camshaft) valve mechanism arranged for "V" type valve configuration consisting of 16 valves (4 valves/one cylinder). The double overhead camshaft is mounted over the cylinder head; it is driven from crankshaft through timing chains, and no push rods are provided in the valve train system.



I7RW01140075-01

IMT (Intake Manifold Tuning) System Description

S7RW0C1401002



I7RW01140002-04

[A]: IMT valve open	1. IMT valve actuator	3. Engine torque
[B]: IMT valve closed	2. Intake manifold	4. Engine speed

IMT (Intake manifold tuning) system varies effective length of intake pipe by opening and closing IMT valve in order to improve air volumetric efficiency.

As intake valve in cylinder head is opened and closed repeatedly, intake air pulsation always exists. If intake valve is opened when air pressure is momentarily maximum, intake air volumetric efficiency is increased. This momentary maximum air pressure depends on effective intake pipe length.

When IMT valve is fully open [A]:

The effective intake pipe length is shorter. Engine torque between middle and high engine speed ranges is improved, whilst it drops between low and middle engine speed ranges.

When IMT valve is totally closed [B]:

The effective intake pipe length is longer. Engine torque between middle and high engine speed ranges drops, while it is improved between low and middle ranges.

IMT system utilizes this characteristic of engine. IMT valve is closed between low and middle engine speed ranges, and opened between middle and high engine speed ranges.

In this way, engine torque is improved in whole engine speed ranges.

Diagnostic Information and Procedures

Compression Check

S7RW0C1404001

Check compression pressure on all 4 cylinders as follows:

- 1) Warm up engine.
- 2) Stop engine after warming up.


NOTE

After warming up engine, place transmission gear shift lever in "Neutral" (shift selector lever to "P" range for A/T model), and set parking brake and block drive wheels.

- 3) Remove ignition coils and all spark plugs referring to "Ignition Coil Assembly (Including ignitor) Removal and Installation in Section 1H".
- 4) Disconnect fuel injector wire harness at the connector.
- 5) Install special tool (Compression gauge) into spark plug hole.


Special tool

- (A): 09915-64512
(B): 09915-64530
(C): 09915-67010



I5JB0A142001-01

- 6) Disengage clutch (to lighten starting load on engine) for M/T vehicle, and depress accelerator pedal all the way to make throttle fully open.



I2RH01140004-01

- 7) Crank engine with fully charged battery, and read the highest pressure on compression gauge.

NOTE

- For measuring compression pressure, crank engine at least 250 r/min by using fully charged battery.
- If measured compression pressure is lower than limit value, check installation condition of special tool.

Compression pressure

Standard: 1400 kPa (14.0 kgf/cm², 199.0 psi)

Limit: 1100 kPa (11.0 kgf/cm², 158.0 psi)

Max. difference between any two cylinders: 100 kPa (1.0 kgf/cm², 14.2 psi)

- 8) Carry out Steps 5) through 7) on each cylinder to obtain 4 readings.
- 9) After checking, install spark plugs and ignition coils referring to "Ignition Coil Assembly (Including ignitor) Removal and Installation in Section 1H".
- 10) Connect injector wire harness at connector.
- 11) Install air cleaner assembly referring to "Air Cleaner Assembly Removal and Installation".

Engine Vacuum Check

S7RW0C1404002


The engine vacuum that develops in the intake line is a good indicator of the condition of the engine. The vacuum checking procedure is as follows:

- 1) Warm up engine to normal operating temperature.

NOTE

After warming up engine, be sure to place transaxle gear shift lever in "Neutral" (Shift selector lever to "P" range for A/T model), and set parking brake and block drive wheels.

- 2) Stop engine and turn off the all electric switches.
- 3) Remove air cleaner assembly referring to "Air Cleaner Assembly Removal and Installation".
- 4) Remove hose (1) from PCV valve (2).




I7RW01140008-01

- 5) Connect special tool (Vacuum gauge) to PCV hose (1).

Special tool

(A): 09915-67311

- 6) Blind PCV valve (2) using tape (3) or the like.



I7RW01140009-01

- 7) Install air cleaner assembly referring to "Air Cleaner Assembly Removal and Installation".
- 8) Run engine at specified idle speed and read vacuum gauge. Vacuum should be within specification.

Vacuum specification (at sea level)


59 – 73 kPa (45 – 55 cmHg, 17.7 – 21.6 in.Hg) at specified idle speed

- 9) After checking, remove air cleaner assembly.
- 10) Disconnect special tool (Vacuum gauge) from PCV valve.
- 11) Detach blind cap from PCV valve.
- 12) Connect PCV hose to PCV valve.
- 13) Install air cleaner assembly.

Valve Lash (Clearance) Inspection



S7RW0C1404003

- 1) Remove negative (–) cable at battery.
- 2) Remove cylinder head cover referring to "Cylinder Head Cover Removal and Installation".
- 3) Using 17 mm wrench, turn crankshaft pulley (1) clockwise until index (2) of cylinder block and index (3) of crankshaft pulley (1) are aligned.



I7RW01140010-01

- 4) Check whether cam position (1) of No.1 cylinder is at the specified position [A] as shown in figure. If cam position is [B], locate cam position to [A] by turning crankshaft one rotation.



I5JB0A142064-01

[A]: TDC in compression for No.1 cylinder

[B]: TDC in exhaust for No.1 cylinder

1D-5 Engine Mechanical:

- 5) Check valve lashes with thickness gauge (1) according to the following procedure.
 - a) Check valve lashes of cylinder No.1.
 - b) Turn crankshaft pulley by 180° clockwise.
 - c) Check valve lashes of cylinder No.3.
 - d) In the same manner as b) – c), check valve lashes of cylinder No.4 then cylinder No.2.

If valve lash is out of specification, record valve lash and adjust it to specification by replacing shim.


Valve clearance specification

When cold (Coolant temperature is 15 – 25 °C (59 – 77 °F)):

- Intake: 0.18 – 0.22 mm (0.007 – 0.009 in.)
- Exhaust: 0.28 – 0.32 mm (0.011 – 0.013 in.)

When hot (Coolant temperature is 60 – 68 °C (140 – 154 °F)):


- Intake: 0.21 – 0.27 mm (0.008 – 0.011 in.)
- Exhaust: 0.30 – 0.36 mm (0.012 – 0.014 in.)



I7RW01140011-01

Shim Replacement

- 1) Close the valve whose shim (2) is to be replaced by turning crankshaft, then turn tappet (3) till its cut section (1) faces inside as shown in the figure.




I2RH0B140006-01

- 2) Lift down the valve by turning crankshaft to 360°.
- 3) Hold tappet at that position using special tool as follows.
 - a) Remove its housing bolts.
 - b) Check housing No. and select special tool corresponding to housing No., referring to "Special tool selection table".

Special tool selection table

No. on camshaft housing	Embossed mark on special tool
I2, I3, I4, I5	IN
E2, E3, E4, E5	EX




I5JB0A142066-01

- | |
|--------------------------------------|
| A: I: Intake side or E: Exhaust side |
| B: Position from timing chain side |
| C: Pointing to timing chain side |

- c) Hold down the tappet so as not to contact the shim by installing special tool on camshaft housing with housing bolt (1) tighten housing bolts by hand.

Special tool

(A): 09916–66510




I7RW01140012-01

- 4) Turn camshaft by approximately 90° clockwise and remove shim (3).

⚠ WARNING

Never put in the hand between camshaft and tappet.



I2RH0B140013-01

1. Special tool

2. Magnet

- 5) Using a micrometer (2), measure the thickness of the removed shim (1), and determine replacement shim by calculating the thickness of new shim with the following formula and table.

Shim thickness specification

Intake side:

$$A = B + C - 0.20 \text{ mm (0.008 in.)}$$


Exhaust side:

$$A = B + C - 0.30 \text{ mm (0.012 in.)}$$

A: Thickness of new shim

B: Thickness of removed shim

C: Measured valve clearance



I2RH0B140014-01

For example of intake side:

When thickness of removed shim is 2.40 mm (0.094 in.), and measured valve clearance is 0.46 mm (0.018 in.).

$$A = 2.40 \text{ mm (0.094 in.)} + 0.46 \text{ mm (0.018 in.)} - 0.20 \text{ mm (0.008 in.)} = 2.66 \text{ mm (0.105 in.)}$$


Calculated thickness of new shim = 2.66 mm (0.105 in.)

- 6) Select new shim No. (1) with a thickness as close as possible to calculated value.

Available new shims No.

Thickness mm (in.)	Shim No.	Thickness mm (in.)	Shim No.
2.175 (0.0856)	218	2.600 (0.1024)	260
2.200 (0.0866)	220	2.620 (0.1031)	262
2.225 (0.0876)	223	2.640 (0.1039)	264
2.250 (0.0886)	225	2.660 (0.1047)	266
2.280 (0.0898)	228	2.680 (0.1055)	268
2.300 (0.0906)	230	2.700 (0.1063)	270
2.320 (0.0913)	232	2.720 (0.1071)	272
2.340 (0.0921)	234	2.740 (0.1079)	274
2.360 (0.0929)	236	2.760 (0.1087)	276
2.380 (0.0937)	238	2.780 (0.1094)	278
2.400 (0.0945)	240	2.800 (0.1102)	280
2.420 (0.0953)	242	2.820 (0.1110)	282
2.440 (0.0961)	244	2.840 (0.1118)	284
2.460 (0.0969)	246	2.860 (0.1126)	286
2.480 (0.0976)	248	2.880 (0.1134)	288
2.500 (0.0984)	250	2.900 (0.1142)	290
2.520 (0.0992)	252	2.920 (0.1150)	292
2.540 (0.1000)	254	2.950 (0.1161)	295
2.560 (0.1008)	256	2.975 (0.1171)	298
2.580 (0.1016)	258	3.000 (0.1181)	300

- 7) Install new shim facing shim No. side with tappet.




I2RH0B140015-01

- 8) Lift valve by turning crankshaft counterclockwise (in opposite direction against above Step 4)) and remove special tool.

Special tool

(A): 09916-66510



I3RM0A140006-01


1. Tappet

2. Camshaft

1D-7 Engine Mechanical:

9) Install camshaft housing (1) and tighten bolts to specified torque.

Tightening torque
Camshaft housing bolt (a): 11 N·m (1.1 kgf-m, 8.0 lb-ft)



I2RH0B140149-01

10) Turn crankshaft pulley more than 4 rotations.


11) Check valve clearance again.

12) After checking and adjusting all valves, install cylinder head cover referring to “Cylinder Head Cover Removal and Installation”.

Repair Instructions

Air Cleaner Components

S7RW0C1406001



I7RW01140014-02


1. Air cleaner assembly	3. Air cleaner inlet hose	5. To electric throttle body
2. Air cleaner outlet hose	4. Air cleaner suction pipe	(a) : 3 N·m (0.3 kgf-m, 2.5 lb-ft)

Air Cleaner Assembly Removal and Installation

S7RW0C1406002

Removal

- 1) Remove air cleaner inlet hose (2) and outlet hose.
- 2) Disconnect MAF sensor connector (3).
- 3) Remove air cleaner case (1).



I7RW01140017-01


Installation

- 1) Install air cleaner case (1).
- 2) Connect MAF sensor connector (3), and tighten hose clamp to specified torque.

Tightening torque

Air cleaner outlet hose clamp: 3 N·m (0.3 kgf-m, 2.5 lb-ft)

- 3) Install air cleaner inlet hose (2) and outlet hose.




I7RW01140017-01

Air Cleaner Filter Removal and Installation

S7RW0C1406003

Removal

- 1) Open air cleaner case (1) by unhooking its clamps (2).
- 2) Remove air cleaner filter.



I7RW01140020-01

Installation

Reverse removal procedure for installation.

Air Cleaner Filter Inspection and Cleaning


S7RW0C1406004

Inspection

Check that filter is not excessively dirty, damaged or oily, clean filter with compressed air from air outlet side of filter.

Cleaning


Blow off dust by compressed air from air outlet side of filter.



I2RH01140007-01

Electric Throttle Body and Intake Manifold Components

S7RW0C1406005



I7RW01140021-03

 1. Intake manifold : Never disassemble intake manifold. Disassembly will spoil its original performance. If faulty condition is found, replace it with new one.	4. Electric throttle body assembly
2. O-ring	 (a) : 6 N·m (0.6 kgf-m, 4.5 lb-ft)
3. IMT valve actuator	 : Do not reuse.

Electric Throttle Body On-Vehicle Inspection

S7RW0C1406006


Check electric throttle body assembly referring to "Throttle Valve Operation Check" and "Electric Throttle Body Assembly Operation Check" under "Electric Throttle Body Assembly On-Vehicle Inspection in Section 1C".

Electric Throttle Body Assembly Removal and Installation

S7RW0C1406007

Removal

- 1) Disconnect negative (–) cable at battery.
- 2) Drain coolant.
- 3) Remove air cleaner assembly referring to "Air Cleaner Assembly Removal and Installation".
- 4) Disconnect engine coolant hoses (1) from electric throttle body assembly (2).
- 5) Disconnect connector (3) from electric throttle body assembly.
- 6) Remove stiffener (4).




I7RW01140022-03

- 7) Remove electric throttle body assembly from intake manifold.

Installation

- 1) Clean mating surfaces, and install new throttle body gasket to intake manifold.
- 2) Install electric throttle body assembly (2) with stiffener (4) to intake manifold.
- 3) Connect connector (3) to electric throttle body assembly securely.
- 4) Connect engine coolant hoses (1) to electric throttle body assembly (2).



I7RW01140022-03

- 5) Install air cleaner assembly referring to "Air Cleaner Assembly Removal and Installation".
- 6) Refill coolant referring to "Cooling System Flush and Refill in Section 1F".
- 7) Connect negative (–) cable at battery.
- 8) Perform calibration of electric throttle body assembly referring to "Electric Throttle Body System Calibration in Section 1C" if replaced.

Electric Throttle Body Cleaning

S7RW0C1406008

Clean electric throttle body assembly referring to "Throttle Valve Operation Check" under "Electric Throttle Body Assembly On-Vehicle Inspection in Section 1C".

Intake Manifold Removal and Installation


S7RW0C1406009

⚠ CAUTION

Never disassemble intake manifold. Disassembly will spoil its original performance. If faulty condition is found, replace it with new one.

Removal

- 1) Disconnect negative (–) cable at battery.
- 2) Drain cooling.
- 3) Remove electric throttle body assembly referring to “Electric Throttle Body Assembly Removal and Installation”.
- 4) Disconnect the following electric lead wires:
 - IMT connector (1)
- 5) Disconnect the following hoses:
 - Brake booster hose (2) from intake manifold
 - PCV hose (3) from PCV valve
 - Vacuum hose (4) from EVAP canister purge valve
 - Breather hose from intake manifold
- 6) Remove harness brackets (5) from intake manifold.



I7RW01140023-01


- 7) Remove intake manifold and O-ring from cylinder head.

Installation

Reverse removal procedure for installation noting the followings.

- Use new intake manifold O-ring.
- Install intake manifold bolts (2) and nuts (1) as shown in figure.
Apply thread lock cement to intake manifold bolt.

“A”: Thread lock cement 99000–32110 (Thread Lock Cement Super 1322)



I7RW01140024-05


- Check to ensure that all removed parts are back in place.
Reinstall any necessary parts which have not been reinstalled.
- Refill cooling system referring to “Cooling System Flush and Refill in Section 1F”.
- Upon completion of installation, turn ignition switch ON but engine OFF and check for fuel leaks.
- Finally, start engine and check for engine coolant leaks.

IMT Valve Actuator Removal and Installation

S7RW0C1406010

Removal

- 1) Disconnect negative (–) cable at battery.
- 2) Disconnect IMT valve actuator connector.
- 3) Remove IMT valve actuator (1) and O-ring (2) from intake manifold (3).



I7RW01140025-01


Installation

Reverse removal procedure noting the followings.

- Use new O-ring (1).
- Tighten IMT valve actuator bolt (2) to specified torque.

Tightening torque


IMT valve actuator bolt (a): 6 N·m (0.6 kgf-m, 4.5 lb-ft)



I7RW01140026-01

Cylinder Head Cover Components

S7RW0C1406011



I7RW01140027-01


1.	Cylinder head cover
2.	O-ring
3.	Cylinder head cover gasket
4.	Cylinder head cover nut
	Tighten 11 N·m (1.1 kgf-m, 8.0 lb-ft) by specified procedure.
	Do not reuse.

Cylinder Head Cover Removal and Installation

S7RW0C1406012


Removal

- 1) Disconnect negative (–) cable at battery.
- 2) Remove ignition coils referring to "Ignition Coil Assembly (Including ignitor) Removal and Installation in Section 1H".
- 3) Remove oil level gauge (1).
- 4) Disconnect CMP sensor connector (2) and then remove CMP sensor (7) from cylinder head cover.
- 5) Disconnect breather hose (3) and PCV hose (4) from cylinder head cover (5).
- 6) Remove harness bracket (6) from cylinder head cover (5).



I7RW01140028-01

- 7) Remove PCV valve from cylinder head cover.
- 8) Remove cylinder head cover nuts in such order as indicated in the figure.




I5JB0A142013-01

- 9) Remove cylinder head cover from cylinder head.
- 10) Remove cylinder head side seals from cylinder head.

Installation

- 1) Install PCV valve to cylinder head cover referring to "PCV Valve Removal and Installation in Section 1B".
- 2) Remove oil, old sealant and dust from sealing surfaces on cylinder head and cover.
- 3) Install new cylinder head side seals (1) to cylinder head.
- 4) Apply sealant "A" to cylinder head sealing surface area as shown in figure.

"A": Water tight sealant 99000-31250 (SUZUKI Bond No.1207F)




I5JB0A142067-01

- 5) Apply engine oil to new O-rings.
- 6) Install new O-rings (3) and new cylinder head cover gasket (2) to cylinder head cover (1).

NOTE

Be sure to check each of these parts for deterioration or any damage before installation and replace if found defective.

- 7) Install cylinder head cover to cylinder head.




I5JB0A142068-02

- 8) Tighten cylinder head cover nuts in such order as indicated in the figure a little at a time till they are tightened to specified torque.
 - Use new seal washers.


Tightening torque

Cylinder head cover nut (a): Tighten 11 N·m (1.1 kgf-m, 8.0 lb-ft) by the specified procedure



I5JB0A142014-01

- 9) Install oil level gauge (1).
- 10) Install CMP sensor (5) to cylinder head cover referring to "Camshaft Position (CMP) Sensor Removal and Installation in Section 1C".
- 11) Connect CMP sensor connector (4).
- 12) Connect breather hose (2) and PCV hose (3) to cylinder head cover.
- 13) Install harness bracket (6) to cylinder head cover.




I7RW01140029-03

- 14) Install ignition coils referring to "Ignition Coil Assembly (Including ignitor) Removal and Installation in Section 1H".
- 15) Install air cleaner case referring to "Air Cleaner Assembly Removal and Installation".
- 16) Connect negative (-) cable at battery.

Engine Mountings Components

S7RW0C1406013



I7RW01140031-02

[A]: 2WD model	6. Engine left mounting :Be sure to direct paint mark to forward.	16. Paint mark
[B]: 4WD model	7. Engine rear mounting :Be sure to direct paint mark to forward.	17. Mounting member
[C]: M/T model	8. Engine rear mounting No.1 bracket	18. Mounting member nut Tighten order: "a" → "b"
[D]: A/T model	9. Engine rear mounting No.2 bracket	19. Mounting member bolt Tighten order: "a" → "b"
F: Vehicle forward	10. Engine front mounting bracket	[a]: 25 N·m (2.5 kgf-m, 18.0 lb-ft)
1. Engine right mounting No.1 bracket	11. Engine front mounting :Be sure to direct paint mark to forward.	[b]: 93 N·m (9.3 kgf-m, 67.5 lb-ft)
2. Engine right mounting No.2 bracket	12. Transfer	[c]: 55 N·m (5.5 kgf-m, 40.0 lb-ft)
3. Generator bracket	13. Suspension frame	[d]: 65 N·m (6.5 kgf-m, 47.0 lb-ft)

1D-15 Engine Mechanical:

4. Engine right mounting	14. Dynamic damper	⊗ : Do not reuse.
5. Engine left mounting bracket	15. Mounting member cushion	

Engine Assembly Removal and Installation

S7RW0C1406014

Removal

- 1) Relieve fuel pressure according to "Fuel Pressure Relief Procedure in Section 1G".
- 2) Disconnect negative and positive cables at battery.
- 3) Disconnect ECM connectors.
- 4) Remove battery and battery tray with ECM.
- 5) Remove right and left side engine under covers.
- 6) Remove water pump and generator drive belt referring to "Water Pump and Generator Drive Belt Removal and Installation in Section 1J".
- 7) Drain engine oil.
- 8) Drain transaxle oil.
- 9) Drain transfer oil (4WD model).
- 10) Drain coolant.
- 11) Remove air cleaner assembly referring to "Air Cleaner Assembly Removal and Installation".
- 12) With hose connected, detach A/C compressor from its bracket referring to "Compressor Assembly Removal and Installation: Manual Type in Section 7B".

⚠ CAUTION

Suspend removed A/C compressor at a place where no damage will be caused during removal and installation of engine assembly.

- 13) Remove condenser cooling fan from radiator referring to "Condenser Cooling Fan Removal and Installation: Automatic Type in Section 7B".

- 14) Disconnect the following electric wires/connectors and each clamps.






- Electric throttle body (1)
- ECT sensor (2)
- CMP sensor (3)
- Ignition coil assembly (4)
- Injector (5)
- HO2S (6)
- A/F sensor (7)
- Engine oil pressure switch (8)
- CKP sensor (9)
- Knock sensor (10)
- Generator (11)
- Starting motor (12)
- Ground terminal (13) from cylinder block
- Ground terminal (14) from exhaust manifold
- Battery ground cable (15) from transaxle
- Back-up light switch (16) (M/T model)
- Torque sensor (17)
- P/S motor (18)
- Output shaft speed sensor (VSS) (20) (A/T model)
- Solenoid valve (21) (A/T model)
- Transmission range sensor (22) (A/T model)
- Input shaft speed sensor (23) (A/T model)
- IMT sensor (24)

- 15) Disconnect the following cables, and remove control cable bracket (25).

- Gear select control cable (26) (M/T model)
- Gear shift control cable (27) (M/T model)
- A/T select cable with select cable bracket (28) (A/T model)



16) Disconnect the following hoses.

- Brake booster hose (29) from intake manifold
- Radiator inlet and outlet hoses from radiator
- Heater inlet and outlet hoses (31) from heater core
- Fuel feed hose (32) from fuel feed pipe
- Purge hose (33) from purge valve
- Clutch hose (30) from transaxle (M/T model)
- A/T fluid cooler hoses (A/T model)




I6RW0C140001-01

- 17) Disconnect right and left drive shaft joints from differential gear referring to "Front Drive Shaft Assembly Removal and Installation: Front in Section 3A".
- 18) Remove exhaust center pipe referring to "Exhaust System Components in Section 1K".
- 19) Disconnect propeller shaft from transfer referring to "Propeller Shaft Assembly Removal and Installation in Section 3D" (4WD model).
- 20) Disconnect steering lower shaft from pinion shaft referring to "Steering Lower Shaft Removal and Installation in Section 6B".
- 21) Fix radiator to body with rope in order to avoid the radiator fall off when front lower cross member lowered.
- 22) Fix transaxle to suspension frame with rope in order to avoid the engine assembly inclines when engine assembly lowered.



I7RW01140072-02

- 23) Support front suspension frame and front lower cross member using jack at hatched parts (1) indicated in figure.





I7RW01140073-01

[A]: View A	[C]: M/T model
[B]: A/T model	35. Steering gear box


1D-17 Engine Mechanical:

- 24) Remove engine right mounting (1), engine right mounting No.1 bracket (2) and engine left mounting bracket bolt and nuts(3).



I7RW01140034-01

- 25) Remove suspension frame mounting bolts (1) and front lower cross member bolts (2).



I5RW0A140014-01

- 26) Lower engine with transaxle, front suspension frame, front lower cross member, transfer (4WD model) and steering gear case.

⚠ CAUTION

Before lowering engine, in order to avoid damage to A/C compressor, make clearance by rising it.

- 27) Disconnect steering gear case from suspension frame referring to "Steering Gear Case Assembly Components in Section 6C", if necessary.
28) Disconnect transfer.
29) Disconnect transaxle from engine.
30) Remove clutch cover and clutch disk referring to "Clutch Cover, Clutch Disc and Flywheel Removal and Installation in Section 5C", if necessary (M/T model).

Installation

- 1) Install clutch cover and clutch disk referring to "Clutch Cover, Clutch Disc and Flywheel Removal and Installation in Section 5C", if necessary (M/T model).
- 2) Connect transaxle to engine referring to "Manual Transaxle Unit Dismounting and Remounting in Section 5B" or "Automatic Transaxle Unit Dismounting and Remounting in Section 5A", if removed.
- 3) Connect transfer to suspension frame referring to "Transfer Dismounting and Remounting in Section 3C", if removed (4WD model).
- 4) Connect steering gear case to suspension frame referring to "Steering Gear Case Assembly Components in Section 6C", if removed.
- 5) Lift engine with transaxle, front suspension frame, front lower cross member, transfer (4WD model) and steering gear case into engine compartment with jack.

⚠ CAUTION


Before lifting engine, in order to avoid damage to A/C compressor, make clearance by rising it.

- 6) Tighten suspension frame mounting bolts and front lower cross member bolts, and then tighten bolts to specified torque.

Tightening torque




Suspension frame mounting bolt (a): 150 N·m (15.0 kgf-m, 108.5 lb-ft)

Front lower cross member bolt (b): 55 N·m (5.5 kgf-m, 40.0 lb-ft)



I5RW0A140016-01

- 7) Install engine right mounting, engine right mounting No.1 bracket and engine left mounting bracket, and then tighten bolts and nuts to specified torque referring to "Engine Mountings Components".
 - 8) Remove jack.
 - 9) Connect steering lower shaft to pinion shaft referring to "Steering Lower Shaft Removal and Installation in Section 6B".
 - 10) Connect propeller shaft referring to "Propeller Shaft Assembly Removal and Installation in Section 3D" (4WD model).
 - 11) Install exhaust center pipe referring to "Exhaust System Components in Section 1K".
 - 12) Connect right and left drive shaft joints to differential gear referring to "Front Drive Shaft Assembly Removal and Installation: Front in Section 3A".
 - 13) Reverse disconnected hoses, cables and electric wires for connection noting the following.
Tighten bolts and nuts to specified torque.
- Tightening torque**
Starting motor terminal nut (a): 11 N·m (1.1 kgf-m, 8.0 lb-ft)
Generator terminal nut (b): 5 N·m (0.5 kgf-m, 4.0 lb-ft)
Battery ground bolt (c): 25 N·m (2.5 kgf-m, 18.0 lb-ft)
Ground terminal bolt (d): 11 N·m (1.1 kgf-m, 8.0 lb-ft)
- 14) Install condenser cooling fan to radiator referring to "Condenser Cooling Fan Removal and Installation: Manual Type in Section 7B".
 - 15) Install A/C compressor to its bracket (if removed) referring to "Compressor Assembly Removal and Installation: Manual Type in Section 7B".
 - 16) Install air cleaner assembly referring to "Air Cleaner Assembly Removal and Installation".
 - 17) Check to ensure that all removed parts are back in place. Reinstall any necessary parts which have not been reinstalled.
 - 18) Refill coolant referring to "Cooling System Flush and Refill in Section 1F".
 - 19) Refill transfer oil referring to "Transfer Oil Change in Section 3C" (4WD model).
 - 20) Refill transaxle oil referring to "Manual Transaxle Oil Change in Section 5B" or "A/T Fluid Change in Section 5A".
 - 21) Refill engine oil referring to "Engine Oil and Filter Change in Section 1E".
 - 22) Install water pump and generator drive belt referring to "Water Pump and Generator Drive Belt Removal and Installation in Section 1J".
 - 23) Install right and left side engine under covers.
 - 24) Install battery and battery tray with ECM.
 - 25) Connect ECM connectors.
 - 26) Connect negative and positive cable at battery.
 - 27) Verify that there is no fuel leakage, coolant leakage, oil leakage and exhaust gas leakage at each connection.




I7RW01140035-04

[A]: M/T model

[B]: A/T model

Timing Chain Cover Components

S7RW0C1406015



I7RW01140039-01

1. Crankshaft pulley bolt	6. Timing chain cover bolt and nut	(a) : 150 N·m (15.0 kgf-m, 108.5 lb-ft)
2. Crankshaft pulley	7. Idler pulley	(b) : 11 N·m (1.1 kgf-m, 8.0 lb-ft)
3. Oil seal : Apply engine oil to oil seal lip.	8. Idler pulley nut	(c) : 42 N·m (4.2 kgf-m, 30.5 lb-ft)
4. Timing chain cover : See "A" : See "B"	9. Generator belt tensioner bolt	(d) : 25 N·m (2.5 kgf-m, 18.0 lb-ft)
5. Generator belt tensioner	10. Pin	: Do not reuse.
"A": Apply sealant 99000-31140 to the mating surface of cylinder and cylinder head.		
"B": Apply sealant 99000-31260 to the mating surface of timing chain cover referring to the figure of Step 3) of "Installation" under "Timing Chain Cover Removal and Installation".		

Timing Chain Cover Removal and Installation

S7RW0C1406016

Removal

- 1) Remove engine assembly from vehicle referring to "Engine Assembly Removal and Installation".
- 2) Remove oil pan referring to "Oil Pan and Oil Pump Strainer Removal and Installation in Section 1E".
- 3) Remove cylinder head cover referring to "Cylinder Head Cover Removal and Installation".
- 4) Remove crankshaft pulley bolt.
To lock crankshaft pulley (1), use special tool (camshaft pulley holder) as shown in figure.

Special tool


(A): 09917-68221

NOTE

Be sure to use the following bolts instead of pins in order to fix crankshaft pulley by special tool.

Bolt size: M8, P1.25 L = 25 mm (0.98 in.)

Strength: 7T




I2RH01140051-01

2. Bolt

3. Wrench


5) Remove crankshaft pulley (1).

To remove crankshaft pulley, use special tools (Steering wheel remover, Bearing puller attachment) with it as shown in figure.

Special tool**(A): 09944-36011****(B): 09926-58010**

I2RH01140052-01


6) Remove idler pulley (1), water pump pulley (2) and belt tensioner (3).



I2RH01140054-01

7) Remove timing chain cover bolts (2) and nut (1).

8) Remove timing chain cover (3).




I7RW01140041-01

Installation

- 1) Clean sealing surfaces on timing chain cover, cylinder block and cylinder head.
Remove oil, old sealant and dust from sealing surface.
- 2) Install new oil seal (2) to timing chain cover using special tool, if removed.

NOTE

When installing new oil seal (2), drive it until its surface is flush with edge of timing chain cover (1).

Special tool**(A): 09913-75510**

I2RH01140061-01



3) Apply sealant “A” and “B” to specific area as shown in figure.

“A”: Sealant 99000–31260 (SUZUKI Bond No.1217G)

“B”: Water tight sealant 99000–31140 (SUZUKI Bond No.1207B)

Sealant amount for timing chain cover

- “a”: 3 mm (0.12 in.)
- “b”: 2 mm (0.08 in.)
- “c”: 4 mm (0.16 in.)
- “d”: 16 mm (0.63 in.)
- “e”: 14 mm (0.55 in.)
- “f”: 65 mm (2.56 in.)
- “g”: 73 mm (2.87 in.)



I7RW01140045-01

1. Timing chain cover	5. Rub into
2. Cylinder head	6. Jig
3. Cylinder head gasket	[C]: View C
4. Cylinder block	


4) Apply engine oil to oil seal lip, then install timing chain cover (1). Tighten bolts and nut to specified torque.

NOTE

Before installing timing chain cover, check that pin is securely fitted.

Tightening torque

Timing chain cover bolt and nut (a): 11 N·m (1.1 kgf-m, 8.0 lb-ft)



I2RH01140057-01

5) Install belt idler pulley (1). Tighten nut to specified torque.

Tightening torque


Idler pulley nut (a): 42 N·m (4.2 kgf-m, 30.5 lb-ft)

6) Install belt tensioner (2). Tighten bolts to specified torque.

Tightening torque

Generator belt tensioner bolt (b): 25 N·m (2.5 kgf-m, 18.5 lb-ft)

7) Install water pump pulley (3).



I2RH01140058-01

- 8) Install cylinder head cover referring to "Cylinder Head Cover Removal and Installation".
- 9) Install oil pan. Refer to "Oil Pan and Oil Pump Strainer Removal and Installation in Section 1E" for installation.
- 10) Install crankshaft pulley. To lock crankshaft pulley (1), use special tool (camshaft pulley holder) as shown in figure.

Special tool**(A): 09917-68221****NOTE**


Be sure to use the following bolts instead of pins in order to fix crank pulley by special tool.

Bolt size: M8, P1.25 L = 25 mm (0.98 in.)

Strength: 7T

Tightening torque

Crankshaft pulley bolt (a): 150 N·m (15.0 kgf-m, 108.5 lb-ft)



I2RH01140060-01

2. Bolt

3. Wrench

- 11) Install engine assembly to vehicle referring to "Engine Assembly Removal and Installation".

Timing Chain Cover Cleaning and Inspection

S7RW0C1406017

Clean

Clean sealing surface on timing chain cover, crank case, cylinder block and cylinder head.


Remove oil, old sealant, and dust from sealing surface.

Inspection

Check oil seal lip for fault or other damage. Replace as necessary.

2nd Timing Chain and Chain Tensioner Components

S7RW0C1406018



I7RW01140049-01


1. 2nd timing chain : Apply engine oil	6. Camshaft timing sprocket bolt	: 11 N·m (1.1 kgf-m, 8.0 lb-ft)
2. Timing chain tensioner adjuster No.2 : Apply engine oil to sliding surface.	7. Timing chain tensioner adjuster No.2 nut	: 80 N·m (8.0 kgf-m, 58.0 lb-ft)
3. Tensioner adjuster No.2 gasket	8. Timing chain tensioner adjuster No.2 bolt	: 45 N·m (4.5 kgf-m, 32.5 lb-ft)
4. Intake camshaft timing sprocket	9. Knock pin	: Do not reuse.
5. Exhaust camshaft timing sprocket	10. Oil relief valve	

2nd Timing Chain and Chain Tensioner Removal and Installation

S7RW0C1406019

⚠ CAUTION

After 2nd timing chain is removed, never turn intake camshaft, exhaust camshaft and crankshaft independently more than such an extent as shown. If turned, interference may occur between piston and valves and valves themselves, and parts related to piston and valves may be damaged.




I5JB0A142060-01

1. Knock pin of intake camshaft
2. Knock pin of exhaust camshaft
3. Timing mark of intake side
4. Timing mark of exhaust side
5. Match mark on crank timing sprocket
6. Timing mark on lower crankcase
"a": Camshafts (IN & EX) allowable turning range..... Within 20° on both right and left
"b": Crankshaft allowable turning range..... Within 90° on both right and left

Removal


- 1) Remove timing chain cover. Refer to "Timing Chain Cover Removal and Installation" for removal.
- 2) Turn crankshaft clockwise to meet the following conditions.
 - Mark on crank sprocket match with mark on lower crankcase (I).
 - Arrow mark on idler sprocket points upward (II).
 - Marks on cam sprockets match with marks on cylinder head (III).



I7RW01140050-01


- | |
|---|
| 1. Timing marks of intake camshaft timing sprocket |
| 2. Timing marks of exhaust camshaft timing sprocket |
| 3. Arrow mark on idler sprocket |
| 4. Timing mark of crankshaft timing sprocket |

- 3) Remove timing chain tensioner adjuster No.2 (1) and gasket. To remove them, slacken 2nd timing chain by turning intake camshaft counterclockwise a little while pushing back pad.



I2RH01140064-01


- 4) Remove intake and exhaust camshaft timing sprocket bolts (1). To remove them, fit a spanner (4) to hexagonal part (3) at the center of camshaft to hold it stationary.
- 5) Remove camshaft timing sprockets and 2nd timing chain (2).



I7RW01140052-01


Installation

- 1) Check that match mark (1) on crank timing sprocket is in match with timing mark (2) on lower crankcase as shown in figure.



I2RH01140067-01


- 2) Check that arrow mark (1) on idler sprocket faces upward as shown in figure.
- 3) Check that knock pins of intake (2) and exhaust (3) camshafts are aligned with timing marks on cylinder head as shown in figure.



I2RH01140068-01

- | |
|--------------------------------|
| 4. Timing mark of intake side |
| 5. Timing mark of exhaust side |

- 4) Install 2nd timing chain by aligning yellow plate (1) of 2nd timing chain and match marks on idler sprocket.



I2RH01140069-01

- | |
|--|
| 2. Match mark of 2nd timing chain (Arrow mark) |
|--|

- 5) Install sprockets to intake and exhaust camshafts by aligning dark blue plate of 2nd timing chain, match marks on intake sprocket and exhaust sprocket respectively.


⚠ CAUTION

Do not turn more than allowable turning range.

If turned excessively, valve and piston may be damaged.

NOTE

As an arrow mark is provided on both sides, camshaft timing sprocket has no specific installation direction.




I2RH01140070-01

- | |
|---|
| 1. Dark blue plate |
| 2. Arrow mark on intake camshaft timing sprocket |
| 3. Arrow mark on exhaust camshaft timing sprocket |

- 6) Tighten intake and exhaust camshaft timing sprocket bolts (1) to specified torque. To tighten it, fit a spanner (2) to hexagonal part (3) at the center of camshaft to hold it stationary.


Tightening torque

Camshaft timing sprocket bolt (a): 80 N·m (8.0 kgf-m, 57.5 lb-ft)



I7RW01140053-01

- 7) Push back plunger (1) into tensioner body (2), and hold it at the position by inserting stopper (3) into body.



I2RH01140072-01


- 8) Install timing chain tensioner adjuster No.2 (1) with new gasket.

Tightening torque

Timing chain tensioner adjuster No.2 bolt (a): 11 N·m (1.1 kgf-m, 8.0 lb-ft)


Timing chain tensioner adjuster No.2 nut (b): 45 N·m (4.5 kgf-m, 33.0 lb-ft)

- 9) Pull out stopper (2) from timing chain tensioner adjuster No.2.



I2RH01140073-01

- 10) Turn crankshaft two rotations clockwise, and then align timing mark (1) on crankshaft and timing mark (2) on cylinder block as shown in figure. At this time, check timing marks (3, 5 and 7) of sprockets are in match with timing marks (4, 6 and 8) of cylinder head, cylinder block and lower crank case.



I7RW01140056-01

3.	Timing mark on crank timing sprocket
4.	Timing mark on lower crankcase
5.	Timing mark on intake camshaft timing sprocket
6.	Timing mark of intake camshaft timing sprocket
7.	Timing mark on exhaust camshaft timing sprocket
8.	Timing mark of exhaust camshaft timing sprocket


- 11) Apply oil to timing chains, tensioner, tensioner adjusters, sprockets and guides.
- 12) Install timing chain cover. Refer to "Timing Chain Cover Removal and Installation" for installation.
- 13) Install cylinder head cover. Refer to "Cylinder Head Cover Removal and Installation" for installation.
- 14) Install oil pan. Refer to "Oil Pan and Oil Pump Strainer Removal and Installation in Section 1E" for installation.
- 15) Install engine assembly to vehicle referring to "Engine Assembly Removal and Installation".

2nd Timing Chain and Chain Tensioner Inspection

S7RW0C1406020

Timing Chain Guide No.2

Check shoe (2) for wear or damage.




I2RH01140075-01

1. Timing chain guide No.2

Camshaft Sprocket


Check teeth of sprocket for wear or damage.



I2RH01140076-01

Timing Chain


Check timing chain for wear or damage.



I2RH01140077-01

Tensioner Adjuster No.2


Check shoe (1) for wear or damage and latch functions properly.



I2RH01140078-01

1st Timing Chain and Chain Tensioner Components

S7RW0C1406021



I5JB0A142027-01

1. 1st timing chain	6. Timing chain tensioner adjuster No.1	(a) : 25 N·m (2.5 kgf-m, 18.0 lb-ft)
2. Idler sprocket	7. Timing chain guide No.1	(b) : 9 N·m (0.9 kgf-m, 6.5 lb-ft)
3. Idler sprocket shaft	8. Timing chain tensioner nut	(c) : 11 N·m (1.1 kgf-m, 8.0 lb-ft)
4. Crankshaft timing sprocket	9. Timing chain guide No.1 bolt	⌚ : Apply engine oil to sliding surface.
5. Timing chain tensioner	10. Timing chain tensioner adjuster No.1 bolt	

1st Timing Chain and Chain Tensioner Removal and Installation


S7RW0C1406022

⚠ CAUTION

After timing chain is removed, never turn crankshaft and camshafts independently more than its allowable turning range described referring to “2nd Timing Chain and Chain Tensioner Removal and Installation”. If turned, interference may occur between piston and valves and valves themselves, and parts related to piston and valves may be damaged.

Removal


- 1) Remove 2nd timing chain. Refer to “2nd Timing Chain and Chain Tensioner Removal and Installation” for removal.
- 2) Remove timing chain guide No.1 (1).
- 3) Remove timing chain tensioner adjuster No.1 (2).
- 4) Remove timing chain tensioner (3).
- 5) Remove idler sprocket (6) and 1st timing chain (5).
- 6) Remove crankshaft timing sprocket (4).



I4RH01140029-01

Installation


- 1) Install crankshaft timing sprocket (2) as shown in figure.



I7RW01140057-01


1. Crankshaft	3. Cylinder block
---------------	-------------------

- 2) Check that match mark (1) on crankshaft timing sprocket is in match with timing mark (2) on lower crankcase.




I2RH01140082-01

- 3) Apply engine oil to idler sprocket shaft and bush of idler sprocket (1).
 4) Install idler sprocket and idler sprocket shaft.
 5) Install 1st timing chain by aligning dark blue plate (4) of 1st timing chain (3) and match mark (2) on idler sprocket (1).



I2RH01140084-01

- 6) Bring gold plate (4) of 1st timing chain (3) into match with match mark (2) on crankshaft timing sprocket (1).




I2RH01140085-01

- 7) Apply engine oil to sliding surface of timing chain tensioner (1) and then install it as shown in figure. Tighten tensioner nut to specified torque.

Tightening torque


Timing chain tensioner nut (a): 25 N·m (2.5 kgf-m, 18.0 lb-ft)



I2RH01140086-01

2. Spacer

- 8) With latch of tensioner adjuster No.1 returned and plunger (1) pushed back into body, insert stopper (4) into latch (2) and body (3).
 After inserting it, check to make sure that plunger will not come out.




I2RH01140087-01

- 9) Install timing chain tensioner adjuster No.1 (1).

Tightening torque

Timing chain tensioner adjuster No.1 bolt (a): 11 N·m (1.1 kgf-m, 8.0 lb-ft)

- 10) Pull out stopper (2) from timing chain tensioner adjuster No.1.




I7RW01140058-01

- 11) Apply engine oil to sliding surface of timing chain guide No.1 (1) and then install it.
Tighten guide bolts to specified torque.


Tightening torque

Timing chain guide No.1 bolt (a): 9 N·m (0.9 kgf-m, 6.5 lb-ft)



I2RH01140089-01

- 12) Check that dark blue and gold plates of 1st timing chain are in match with match marks on sprockets respectively.



I2RH01140090-01

1. Match mark on idler sprocket
2. Dark blue plate
3. Match mark on crankshaft timing sprocket
4. Gold plate


- 13) Install 2nd timing chain. Refer to “2nd Timing Chain and Chain Tensioner Removal and Installation” for installation.
- 14) Install timing chain cover. Refer to “Timing Chain Cover Removal and Installation” for installation.
- 15) Install cylinder head cover. Refer to “Cylinder Head Cover Removal and Installation” for installation.
- 16) Install oil pan. Refer to “Oil Pan and Oil Pump Strainer Removal and Installation in Section 1E” for installation.
- 17) Install engine assembly to vehicle referring to “Engine Assembly Removal and Installation”.

1st Timing Chain and Chain Tensioner Inspection

S7RW0C1406023

Timing Chain Guide No.1

Check shoe for wear or damage.




I2RH01140091-01

1. Timing chain guide No.1

Timing Chain Tensioner


Check shoe (1) for wear or damage.



I2RH01140092-01

Crankshaft Timing Sprocket


Check teeth of sprocket for wear or damage.



I2RH01140093-01

Idler Sprocket


Check teeth and bush (1) of sprocket for wear or damage.



I2RH01140094-01

1st Timing Chain


Check timing chain for wear or damage.



I2RH01140077-01

Timing Chain Tensioner Adjuster No.1


Check that latch (1) and tooth surface (2) are free from damage and latch functions properly.



I2RH01140095-01

Camshafts, Tappet and Shim Components

S7RW0C1406024



I7RW01140059-01

1. Intake camshaft	5. Exhaust camshaft housing	9. Timing chain guide No.2
2. Exhaust camshaft	6. Shim : Direct shim No. side toward tappet.	10. Camshaft housing bolt
3. Camshaft housing	7. Tappet	: Tighten 11 N·m (1.1 kgf-m, 8.0 lb-ft) by the specified procedure.
4. Intake camshaft housing	8. Oil relief valve	: Apply engine oil to sliding surface of each part.

Camshafts, Tappet and Shim Removal and Installation


S7RW0C1406025

⚠ CAUTION

- Keep working table, tools and hands clean while overhauling.
- Use special care to handle aluminum parts so as not to damage them.
- Do not expose removed parts to dust. Keep them always clean.

Removal

- 1) Remove 2nd timing chain. Refer to "2nd Timing Chain and Chain Tensioner Removal and Installation" for removal.
- 2) Loosen camshaft housing bolts in such order as indicated in figure and remove them.



I5JB0A142029-01


- 3) Remove camshaft housings.
- 4) Remove camshafts.
- 5) Remove tappets with shims.

Installation

- 1) Apply engine oil around tappet (1) and shim, and then install tappets with shims to cylinder head.



NOTE

When installing shim, make sure to direct shim No. side toward tappet.



I5JB0A142030-01


- 2) Match match mark (1) on crank timing sprocket and mating surface of cylinder block (3) and lower crankcase (2) as shown in figure.
At this time, make sure that arrow mark (4) on idler sprocket (5) at the position as shown in figure.



I7RW01140060-01

- 3) Install camshafts.


Apply oil to sliding surface of each camshaft and camshaft journal then install them by aligning match marks on cylinder head and camshafts as shown in figure.



I5JB0A142031-01

- | |
|-----------------------------------|
| 1. Knock pin of intake camshaft |
| 2. Knock pin of exhaust camshaft |
| 3. Match mark of intake camshaft |
| 4. Match mark of exhaust camshaft |


- 4) Install camshaft housing pins (3) as shown in figure.



I4RH01140032-01

- | | |
|--------------------|---------------------|
| 1. Intake camshaft | 2. Exhaust camshaft |
|--------------------|---------------------|

- 5) Check position of camshaft housings.
Embossed marks are provided on each camshaft housing, indicating position and direction for installation. Install housings as indicated by these marks.




I2RH01140106-01

- | |
|--------------------------------------|
| 1. I: Intake side or E: Exhaust side |
| 2. Position from timing chain side |
| 3. Pointing to timing chain side |

- 6) After applying oil to housing bolts, tighten them temporarily first. Then tighten them by following numerical order in figure.
Tighten a little at a time and evenly among bolts and repeat tightening sequence two or three times before they are tightened to specified torque.


Tightening torque

Camshaft housing bolt (a): Tighten 11 N·m (1.1 kgf·m, 8.0 lb·ft) by the specified procedure



I5JB0A142032-01

- 7) Turn crankshaft clockwise then align crankshaft timing sprocket key (1) with timing mark (2).



I5JB0A142033-01

- 8) Install 2nd timing chain. Refer to "2nd Timing Chain and Chain Tensioner Removal and Installation" for installation.
- 9) Install timing chain cover. Refer to "Timing Chain Cover Removal and Installation" for installation.
- 10) Install cylinder head cover. Refer to "Cylinder Head Cover Removal and Installation" for installation.
- 11) Install oil pan. Refer to "Oil Pan and Oil Pump Strainer Removal and Installation in Section 1E" for installation.
- 12) Install engine assembly to vehicle referring to "Engine Assembly Removal and Installation".
- 13) Check valve lashes referring to "Valve Lash (Clearance) Inspection".

Camshaft, Tappet and Shim Inspection


S7RW0C1406026

Cam Wear

Using a micrometer, measure cam height. If measured height is below its limit, replace camshaft.

Cam height "a"

Cam height	Standard	Limit
Intake cam	45.669 – 45.829 mm (1.798 – 1.8043 in.)	45.550 mm (1.793 in.)
Exhaust cam	45.550 – 45.710 mm (1.7933 – 1.7996 in.)	45.430 mm (1.789 in.)



I5JB0A142034-01


Camshaft Runout

Set camshaft between two "V" blocks, and measure its runout by using a dial gauge.

If measured runout exceeds the specified limit, replace camshaft.

Runout limit

0.03 mm (0.0012 in.)




I2RH01140109-01

Camshaft Journal Wear

Check camshaft journals and camshaft housings for pitting, scratches, wear or damage.

If any malcondition is found, replace camshaft or cylinder head with housing. Never replace cylinder head without replacing housings.



IYSQ01143105-01

Check clearance by using gauging plastic. Checking procedure is as follows.


- 1) Clean housings and camshaft journals.
- 2) Make sure that all tappets with shims are removed and install camshafts to cylinder head.
- 3) Place a piece of gauging plastic to full width of journal of camshaft (parallel to camshaft).
- 4) Install camshaft housing.
- 5) Tighten camshaft housing bolts in such order as indicated in figure a little at a time till they are tightened to specified torque.

NOTE

Do not rotate camshaft while gauging plastic is installed.

Tightening torque

Camshaft housing bolt (a): Tighten 11 N·m (1.1 kgf-m, 8.0 lb-ft) by the specified procedure




I5JB0A142035-02

- 6) Remove housing, and using scale (2) on gauging plastic envelop (1), measure gauging plastic width at its widest point.

Journal clearance

Standard	Limit
0.020 – 0.074 mm (0.0008 – 0.0029 in.)	0.12 mm (0.0047 in.)





IYSQ01143107-01

If measured camshaft journal clearance exceeds limit, measure journal (housing) bore and outside diameter of camshaft journal. Replace camshaft or cylinder head assembly whichever the difference from specification is greater.

Camshaft journal


Item	Standard
Camshaft journal bore diameter. (IN & EX) [A]	26.000 – 26.033 mm (1.0236 – 1.0249 in.)
Camshaft journal O.D. (IN & EX) [B]	25.959 – 25.980 mm (1.0221 – 1.0228 in.)



I5JB0A142036-01

Wear of Tappet and Shim

Check tappet and shim for pitting, scratches, or damage. If any malfunction is found, replace.




I2RH0B140085-01

Measure cylinder head bore and tappet outside diameter to determine cylinder head-to-tappet clearance. If clearance exceeds limit, replace tappet or cylinder head.


Cylinder head bore and tappet outside diameter

Item	Standard	Limit
Tappet outside diameter [A]	32.456 – 32.472 mm (1.2778 – 1.2784 in.)	—
Cylinder head bore [B]	32.500 – 32.525 mm (1.2795 – 1.2805 in.)	—
Cylinder head to tappet clearance	0.028 – 0.069 mm (0.0011 – 0.0027 in.)	0.15 mm (0.0059 in.)

[A]




[B]




I5JB0A142038-01

Oil Relief Valve

Check oil relief valve for clogging and ball for being stuck.



I2RH01140111-01



I5JB0A142039-01

1. Cylinder block	7. Valve stem seal	13. Cylinder head bolt (M6) : Be sure to tighten cylinder head bolt (M6) after securing cylinder head bolt (M10).
2. Cylinder head	8. Valve spring	14. Knock pin
3. Cylinder head gasket : Identification number provided on gasket comes to crankshaft pulley side, facing up.	9. Valve spring retainer	: Tighten 52 N·m (5.2 kgf·m, 38.0 lb·ft), 82 N·m (8.2 kgf·m, 59.5 lb·ft), 0 N·m (0 kgf·m, 0 lb·ft), 52 N·m (5.2 kgf·m, 38.0 lb·ft) and 103 N·m (10.3 kgf·m, 74.5 lb·ft) by the specified procedure.
4. Intake valve	10. Valve cotter	: 11 N·m (1.1 kgf·m, 8.0 lb·ft)
5. Exhaust valve	11. Valve guide	: Do not reuse.
6. Valve spring seat	12. Cylinder head bolt (M10)	: Apply engine oil to sliding surface of each part.

Valves and Cylinder Head Removal and Installation


S7RW0C1406028

Removal

- 1) Remove camshafts, tappets and shims. Refer to “Camshafts, Tappet and Shim Removal and Installation” for removal.
- 2) Loosen cylinder head bolts in such order as numbered in figure and remove them.

NOTE

Don’t forget to remove cylinder head bolt (M6) (3) as shown in figure.




I5JB0A142040-02

1. Crankshaft pulley side	2. Flywheel side
---------------------------	------------------

- 3) Check all around cylinder head for any other parts required to be removed or disconnected and remove or disconnect whatever necessary.
- 4) Remove cylinder head with intake manifold, exhaust manifold and water outlet cap. Use lifting device, if necessary.


Installation

- 1) Match match mark (1) on crank timing sprocket and mating surface (2) of cylinder block and lower crankcase.



I2RH01140118-01

- 2) Clean mating surface of cylinder head and cylinder block (2). Remove oil, old gasket and dust from mating surface.
- 3) Install knock pins (3) to cylinder block.
- 4) Install new cylinder head gasket (1) to cylinder block. Identification number (6) provided on gasket comes to crankshaft pulley side (4), facing up (toward cylinder head side).




I5JB0A142041-01

5. Flywheel side

- 5) Install cylinder head to cylinder block.

Apply engine oil to cylinder head bolts and tighten them gradually as follows.

- a) Tighten cylinder head bolts (M10) to 52 N·m (5.2 kgf-m, 38.0 lb-ft) according to numerical order in figure.
- b) In the same manner as in step a), retighten cylinder head bolts (M10) to 82 N·m (8.2 kgf-m, 59.5 lb-ft).




I5JB0A142042-01

1. Crankshaft pulley side

2. Flywheel side

- c) Loosen cylinder head bolts (M10) until tightening torque is reduced to 0 according to numerical order in figure.



I5JB0A142043-01

1. Crankshaft pulley side


2. Flywheel side

- d) Tighten cylinder head bolts (M10) to 52 N·m (5.2 kgf-m, 38.0 lb-ft) according to numerical order in figure.
- e) In the same manner as in step b), retighten cylinder head bolts (M10) to 103 N·m (10.3 kgf-m, 74.5 lb-ft).
- f) Tighten cylinder head bolt (M6) to specified torque.

Tightening torque

Cylinder head bolt (M10) (a): Tighten 52 N·m (5.2 kgf-m, 38.0 lb-ft), 82 N·m (8.2 kgf-m, 59.5 lb-ft), 0 N·m (0 kgf-m, 0 lb-ft), 52 N·m (5.2 kgf-m, 38.0 lb-ft) and 103 N·m (10.3 kgf-m, 74.5 lb-ft) by the specified procedure

Cylinder head bolt (M6) (b): 11 N·m (1.1 kgf-m, 8.0 lb-ft)



I7RW01140061-01

1. Crankshaft pulley side

2. Flywheel side

- 6) Install camshafts, tappets and shims. Refer to "Camshafts, Tappet and Shim Removal and Installation" for installation.
- 7) Install 1st timing chain. Refer to "1st Timing Chain and Chain Tensioner Removal and Installation" for installation.
- 8) Install 2nd timing chain. Refer to "2nd Timing Chain and Chain Tensioner Removal and Installation" for installation.
- 9) Install timing chain cover. Refer to "Timing Chain Cover Removal and Installation" for installation.
- 10) Check intake and exhaust valve lashes referring to "Valve Lash (Clearance) Inspection".
- 11) Install cylinder head cover referring to "Cylinder Head Cover Removal and Installation".
- 12) Install oil pan referring to "Oil Pan and Oil Pump Strainer Removal and Installation in Section 1E".
- 13) Install engine assembly to vehicle referring to "Engine Assembly Removal and Installation".

Valves and Cylinder Head Disassembly and Reassembly

S7RW0C1406029

Disassembly

- 1) When servicing cylinder head, remove intake manifold, injectors, exhaust manifold and water outlet cap from cylinder head.
- 2) Using special tools, compress valve springs and then remove valve cotter (1) also by using special tool.



Special tool

(A): 09916-14510

(B): 09916-16510

(C): 09919-28610

(D): 09916-84511




I5JB0A142045-01

- 3) Release special tool, and remove spring retainers and valve springs.
- 4) Remove valve from combustion chamber side.
- 5) Remove valve stem seal (1) from valve guide, and then valve spring seat (2).

NOTE

Do not reuse seal once disassembled. Be sure to use new seal when assembling.



I2RH01140125-01


- 6) Using special tool (Valve guide remover), drive valve guide out from combustion chamber side to valve spring side.

Special tool

(A): 09916-46020

NOTE

Do not reuse valve guide once disassembled. Be sure to use new valve guide (oversize) when assembling.



I2RH01140126-01

- 7) Place disassembled parts except valve stem seal and valve guide in order so that they can be installed in their original positions.


Reassembly

- 1) Before installing valve guide into cylinder head, ream guide hole with special tool (11 mm reamer) so as to remove burrs and make it truly round.

Special tool

(A): 09916-34542

(B): 09916-38210



I2RH01140127-01

- 2) Install valve guide to cylinder head.
Heat cylinder head uniformly at a temperature of 80 to 100 °C (176 to 212 °F) so that head will not be distorted, and drive new valve guide into hole with special tools.
Drive in new valve guide until special tool (Valve guide installer) contacts cylinder head.
After installing, make sure that valve guide protrudes by specified value from cylinder head.

Special tool

(A): 09916-57350

(B): 09916-57340

NOTE

- Do not reuse valve guide once disassembled. Install new valve guide (Oversize).
- Intake and exhaust valve guides are identical.


Valve guide oversize

0.03 mm (0.0012 in.)

Valve guide protrusion "a"

In: 14.5 mm (0.57 in.)

Ex: 13.5 mm (0.53 in.)




I2RH01140128-01

- 3) Ream valve guide bore with special tool (6.0 mm reamer). After reaming, clean bore.

Special tool

(A): 09916-34542

(B): 09916-37810



I2RH01140127-01

- 4) Install valve spring seat to cylinder head.
- 5) Install new valve stem seal (1) to valve guide. After applying engine oil to seal and spindle of special tool (Valve guide installer handle), fit oil seal to spindle, and then install seal to valve guide by pushing special tool by hand. After installing, check to be sure that seal is properly fixed to valve guide.


Special tool

(A): 09917-98221

(B): 09916-57350

NOTE

- Do not reuse seal once disassembled. Be sure to install new seal.
- When installing, never tap or hit special tool with a hammer or else. Install seal to guide only by pushing special tool by hand. Tapping or hitting special tool may cause damage to seal.




I2RH01140129-01

- 6) Install valve to valve guide. Before installing valve to valve guide, apply engine oil to stem seal, valve guide bore, and valve stem.



I2RH01140130-01

- 7) Install valve spring and spring retainer. Each valve spring has top end (large-pitch end (1)) and bottom end (small-pitch end (2)). Be sure to position spring in place with its bottom end (small-pitch end) facing the bottom (valve spring seat side).



I2RH0B140100-01

A: Valve spring retainer side

B: Valve spring seat side

- 8) Using special tool (Valve lifter), compress valve spring and fit two valve cotter (1) into groove in valve stem.


Special tool

(A): 09916-14510

(B): 09916-16510

(C): 09919-28610

(D): 09916-84511



I2RH01140132-01

- 9) Install intake manifold referring to "Intake Manifold Removal and Installation".
- 10) Install exhaust manifold referring to "Exhaust Manifold Removal and Installation in Section 1K".
- 11) Install injectors referring to "Fuel Injector Removal and Installation in Section 1G".

Valves and Valve Guides Inspection

S7RW0C1406030

Valve Guide


Valve stem-to-guide clearance

Using a micrometer and bore gauge, take diameter readings on valve stems and guides to check stem-to-guide clearance.
Be sure to take reading at more than one place along the length of each stem and guide.
If clearance exceeds limit, replace valve and valve guide.


Valve stem and valve guide specification

Item		Standard	Limit
Valve stem diameter [A]	In	5.965 – 5.980 mm (0.2348 – 0.2354 in.)	—
	Ex	5.940 – 5.955 mm (0.2339 – 0.2344 in.)	—
Valve guide bore [B]	In & Ex	6.000 – 6.012 mm (0.2362 – 0.2366 in.)	—
Stem-to-guide clearance	In	0.020 – 0.047 mm (0.0008 – 0.0018 in.)	0.070 mm (0.0028 in.)
	Ex	0.045 – 0.072 mm (0.0017 – 0.0028 in.)	0.090 mm (0.0035 in.)

[A]



[B]




I4RS0B140016-01

Valve stem end deflection

If bore gauge is not available, check end deflection of valve stem with a dial gauge instead.
Move stem end in directions (1) and (2) to measure end deflection.
If deflection exceeds its limit, replace valve stem and valve guide.

Valve stem end deflection limit

In: 0.14 mm (0.005 in.)
Ex: 0.18 mm (0.007 in.)




IYSQ01141096-01

Valve

Visual inspection

- Remove all carbon from valves.
- Inspect each valve for wear, burn or distortion at its face and stem end, as necessary, replace it.
- Inspect valve stem end face for pitting and wear. If pitting or wear is found there, valve stem end may be resurfaced, but not too much to grind off its chamber. When it is worn out too much that its chamber is gone, replace valve.



I2RH01140135-01

Valve head thickness

Measure thickness "a" of valve head. If measured thickness exceeds limit, replace valve.

Valve head thickness "a"

Intake


Standard: 1.25 – 1.55 mm (0.049 – 0.061 in.)

Limit: 0.9 mm (0.035 in.)

Exhaust

Standard: 1.45 – 1.75 mm (0.057 – 0.069 in.)

Limit: 1.1 mm (0.04 in.)




I2RH0B140102-01

Valve head radial runout

Check each valve for radial runout with a dial gauge and "V" block. To check runout, rotate valve slowly. If runout exceeds its limit, replace valve.

Valve head radial runout

Limit: 0.08 mm (0.003 in.)



I2RH01140136-01


Seating contact width

Create contact pattern on each valve in the usual manner, i.e., by giving uniform coat of marking compound to valve seat and by rotatingly tapping seat with valve head. Valve lapper (tool used in valve lapping) must be used.

Pattern produced on seating face of valve must be a continuous ring without any break, and the width of pattern must be within specified range.

Standard seating width "a" revealed by contact pattern on valve face

Intake and Exhaust: 1.0 – 1.4 mm (0.0389 – 0.0551 in.)



I2RH0B140103-01

Valve seat repair

A valve seat not producing a uniform contact with its valve or showing width of seating contact that is out of specified range must be repaired by regrinding or by cutting and regrinding and finished by lapping.

1) Exhaust valve seat:

Use valve seat cutters (1) to make two cuts as illustrated in the figure. Two cutters must be used: the first for making 15° angle, and the second for making 45° angle. The second cut must be made to produce desired seat width.

Seat width for exhaust valve seat

"a": 1.0 – 1.4 mm (0.0389 – 0.0551 in.)

2) Intake valve seat:


Use valve seat cutters (1) to make three cuts as illustrated in the figure. Three cutters must be used: the 1st for making 25° angle, the 2nd for making 60° angle, and 3rd for making 45° angle. The 3rd cut (45°) must be made to produce desired seat width.

Seat width for intake valve seat

"b": 1.0 – 1.4 mm (0.0389 – 0.0551 in.)

3) Valve lapping:

Lap valve on seat in two steps, first with coarse size lapping compound applied to face and the second with fine-size compound, each time using valve lapper according to usual lapping method.



I5JB0A142047-02


Cylinder Head Inspection

S7RW0C1406031

- Remove all carbon deposits from combustion chambers.

NOTE

Do not use any sharp-edged tool to scrape off carbon deposits. Be careful not to scuff or nick metal surfaces when decarbonizing. The same applies to valves and valve seats, too.




I2RH0B140105-01

1D-43 Engine Mechanical:

- Check cylinder head for cracks on intake and exhaust ports, combustion chambers, and head surface. Using a straightedge and thickness gauge, check flatness of gasketed surface at a total of 6 locations. If distortion limit is exceeded, correct gasketed surface with a surface plate and abrasive paper of about #400 (Waterproof silicon carbide abrasive paper): place abrasive paper on and over surface plate, and rub gasketed surface against paper to grind off high spots. Should this fail to reduce thickness gauge readings to within limit, replace cylinder head. Leakage of combustion gases from this gasketed joint is often due to warped gasketed surface: such leakage results in reduced power output.

Distortion for cylinder head surface on piston side
Limit: 0.03 mm (0.001 in.)




I2RH0B140106-01

- Distortion of manifold seating faces:
Check seating faces of cylinder head for manifolds, using a straightedge and thickness gauge, in order to determine whether these faces should be corrected or cylinder head replaced.

Distortion for cylinder head surface on intake and exhaust manifold

Limit: 0.05 mm (0.002 in.)



I2RH0B140107-01

Valve Spring Inspection

S7RW0C1406032

Valve Spring Free Length and Preload

Referring to data, check to be sure that each spring is in sound condition, free of any evidence of breakage or weakening. Remember, weakened valve springs can cause chatter, not to mention possibility of reducing power output due to gas leakage caused by decreased seating pressure.

Valve spring free length


Standard: 51.13 mm (2.013 in.)

Limit: 50.13 mm (1.974 in.)

Valve spring preload

Standard: 209 – 241 N (20.9 – 24.1 kgf) for 37.60 mm (46.1 – 53.1 lb/1.480 in.)

Limit: 208 N (20.8 kgf) for 37.60 mm (45.9 lb/1.480 in.)




I2RH01140143-01

Spring Squareness

Use a square and surface plate to check each spring for squareness in terms of clearance between end of valve spring and square. Valve springs found to exhibit a larger clearance than limit must be replaced.

Valve spring squareness


Limit: 2.2 mm (0.087 in.)



I2RH01140144-01

Pistons, Piston Rings, Connecting Rods and Cylinders Components

S7RW0C1406033



I5JB0A142048-02

1. Top ring : "R" mark provided on piston ring comes to facing up.	8. Piston pin
2. 2nd ring : "R" mark provided on piston ring comes to facing up.	9. Piston pin circlip
3. Oil ring	10. Connecting rod bolt : Check connecting rod bolt, plastic deformation tightening bolt, for deformation when reuse it due to plastic deformation tightening referring to "Connecting rod bolt" under "Pistons, Piston Rings, Connecting Rods and Cylinders Inspection and Cleaning" if it is reused.
4. Piston	: Tighten 15 N-m (1.5 kgf-m, 11.0 lb-ft) 45° and 45° by the specified procedure.
5. Connecting rod : See "C"	: Apply engine oil to sliding surface of each part.
6. Connecting rod bearing cap : See "A"	: Do not reuse.
7. Connecting rod bearing : See "B"	
"A": Point arrow mark on cap to crankshaft pulley side. Do not apply engine oil to inner surface of bearing cap.	
"B": Do not apply engine oil between connecting rod big end and bearing, between cap and bearing.	
"C": Apply engine oil to sliding surface except inner surface of connecting rod big end. Oil hole comes on intake side.	

Pistons, Piston Rings, Connecting Rods and Cylinders Removal and Installation

S7RW0C1406034

Removal

- 1) Remove oil pump with oil pump strainer. Refer to "Oil Pump Removal and Installation in Section 1E" for removal.
- 2) Remove cylinder head. Refer to "Valves and Cylinder Head Removal and Installation" for removal.
- 3) Mark cylinder number on all pistons, connecting rods and connecting rod caps.
- 4) Remove connecting rod bearing caps.
- 5) Clean carbon from top of cylinder bore before removing piston from cylinder.
- 6) Push piston and connecting rod assembly out through the top of cylinder bore.


Installation

- 1) Apply engine oil to pistons, piston rings, cylinder walls, connecting rod bearings and crank pins.

NOTE

Do not apply oil between connecting rod and bearing or between bearing cap and bearing.

- 2) When installing piston and connecting rod assembly into cylinder bore, point front mark (3) on piston head to crankshaft pulley side (1).




I5JB0A142049-01

2. Flywheel side

- 3) Install piston and connecting rod assembly into cylinder bore. Use special tool (Piston ring compressor) to compress rings. Guide connecting rod into place on crankshaft. Using a hammer handle, tap piston head to install piston into bore. Hold ring compressor firmly against cylinder block until all piston rings have entered cylinder bore.

Special tool

(A): 09916-77310


I2RH01140149-01

- 4) Install connecting rod bearing cap (1) as follows.


NOTE

If connecting rod bolt is reused, make sure to check connecting rod bolt for deformation referring to "Connecting Rod Bolt Deformation (Plastic Deformation Tightening Bolt)" under "Pistons, Piston Rings, Connecting Rods and Cylinders Inspection and Cleaning".

- a) Point arrow mark (2) on cap to crankshaft pulley side.
- b) Apply engine oil to new connecting rod bolts (3).
- c) Tighten all connecting rod bolts to 15 N·m (1.5 kgf-m, 11.0 lb-ft).
- d) Retighten them by turning through 45°.
- e) Repeat step d) once again.

Tightening torque

Connecting rod bolt (a): Tighten 15 N·m (1.5 kgf-m, 11.0 lb-ft), 45° and 45° by the specified procedure



I4RH01140037-01


- 5) Install cylinder head. Refer to "Valves and Cylinder Head Removal and Installation" for installation.
- 6) Install oil pan. Refer to "Oil Pan and Oil Pump Strainer Removal and Installation in Section 1E" for installation.
- 7) Install camshafts and tappets and shims. Refer to "Camshafts, Tappet and Shim Removal and Installation".
- 8) Install 1st timing chain. Refer to "1st Timing Chain and Chain Tensioner Removal and Installation" for installation.
- 9) Install 2nd timing chain. Refer to "2nd Timing Chain and Chain Tensioner Removal and Installation" for installation.
- 10) Install timing chain cover. Refer to "Timing Chain Cover Removal and Installation" for installation.
- 11) Check intake and exhaust valve lashes referring to "Valve Lash (Clearance) Inspection".
- 12) Install cylinder head cover referring to "Cylinder Head Cover Removal and Installation".
- 13) Install engine assembly to vehicle referring to "Engine Assembly Removal and Installation".

Pistons, Piston Rings, Connecting Rods and Cylinders Disassembly and Reassembly

S7RW0C1406035


Disassembly

- 1) Using piston ring expander, remove two compression rings (Top and 2nd) and oil ring from piston.
- 2) Remove piston pin from connecting rod.
 - Ease out piston pin circlips (1), as shown.



I2RH01140151-01

- Force piston pin out.




I2RH01140152-01

Reassembly

NOTE

Two sizes of piston are available as standard size spare part so as to ensure proper piston-to-cylinder clearance. When installing a standard size piston, make sure to match piston with cylinder as follows.

- 1) Each piston (1) has stamped number (2) as shown. It represents outer diameter of piston.
- 2) There are also painted color (3) of red or blue on cylinder block (2) as shown.



I5JB0A142050-01

4. Crank shaft pulley side	7. No.2 cylinder
5. Flywheel side	8. No.3 cylinder
6. No.1 cylinder	9. No.4 cylinder

- 3) Stamped number on piston and painted color (or stamped number) on cylinder block should correspond. That is, install number "2" stamped piston to cylinder which is identified with blue painted (or "2" stamped) and a number "1" piston to cylinder with red painted (or "1" stamped).

Also, a letter "A" or "B" is stamped on piston head but ordinarily it is not necessary to discriminate each piston by this letter.


Piston outer diameter and cylinder bore diameter specification

Piston		Cylinder	
Number	Outer diameter	Paint (Number)	Bore diameter
1	83.9800 – 83.9900 mm (3.3063 – 3.3066 in.)	Red (1)	84.0101 – 84.0200 mm (3.3075 – 3.3078 in.)
2	83.9700 – 83.9799 mm (3.3059 – 3.3062 in.)	Blue (2)	84.0000 – 84.0100 mm (3.3071 – 3.3074 in.)

- 4) Install piston pin to piston (1) and connecting rod (3):
After applying engine oil to piston pin, piston pin holes in piston and inner surface of connecting rod small end, fit connecting rod to piston as shown in figure and insert piston pin to piston and connecting rod, and install piston pin circlips.

NOTE

- Oil hole (4) comes on intake side.
- Circlip (5) should be installed so that circlip end gap comes within such range as indicated by arrow.




I7RW01140062-01

"a": 90°	4. Oil hole
2. Front mark	


- 5) Install piston rings to piston:

- As indicated in figure at the left, 1st and 2nd rings have "R" mark respectively. When installing these piston rings to piston, direct marked side of each ring toward top of piston.
- 1st ring (1) differs from 2nd ring (2) in thickness, shape and color of surface contacting cylinder wall. Distinguish 1st ring from 2nd ring by referring to figure.
- When installing oil ring (3), install spacer first and then two rails.



I7RW01140063-01

- 6) After installing three rings (1st, 2nd and oil rings), distribute their end gaps as shown in figure.



I5JB0A142053-01

1. Front mark
2. 1st ring end gap
3. 2nd ring end gap and oil ring spacer gap
4. Oil ring upper rail gap
5. Oil ring lower rail gap
6. Intake side
7. Exhaust side

Pistons, Piston Rings, Connecting Rods and Cylinders Inspection and Cleaning

S7RW0C1406036

Inspection Cylinder

- Inspect cylinder walls for scratches, roughness, or ridges which indicate excessive wear. If cylinder bore is very rough or deeply scratched, or ridged, rebore cylinder and use over size piston.
- Using a cylinder gauge, measure cylinder bore in thrust and axial directions at two positions as shown in figure.
If any of following conditions is noted, rebore cylinder.
 - 1) Cylinder bore diameter exceeds limit.
 - 2) Difference of measurements at two positions exceeds taper limit.
 - 3) Difference between thrust and axial measurements exceeds out-of-round limit.

Cylinder bore diameter

Standard: 84.000 – 84.020 mm (3.3070 – 3.3078 in.)



Limit: 84.050 mm (3.3090 in.)

Taper and out-of-round

Limit: 0.10 mm (0.004 in.)

NOTE

If any one of four cylinders has to be rebored, rebore all four to the same next oversize. This is necessary for the sake of uniformity and balance.



I5JB0A142046-01


1. 50 mm (1.96 in.)	2. 95 mm (3.74 in.)
---------------------	---------------------

Pistons

- Inspect piston for faults, cracks or other damages. Damaged or faulty piston should be replaced.
- Piston diameter:
As indicated in figure, piston diameter should be measured at a position 26.5 mm (1.04 in.) ("a") from piston skirt end in the direction perpendicular to piston pin.

Piston diameter

Standard	83.9700 – 83.9900 mm (3.3059 – 3.3067 in.)
Oversize: 0.50 mm (0.0196 in.)	84.4700 – 84.4900 mm (3.3256 – 3.3264 in.)



I2RH01140157-01

- Piston clearance:
Measure cylinder bore diameter and piston diameter to find their difference which is piston clearance. Piston clearance should be within specification as follows. If it is out of specification, rebore cylinder and use oversize piston.

Piston clearance

0.02 – 0.04 mm (0.0008 – 0.0015 in.)


NOTE

Cylinder bore diameters used here are measured in thrust direction at two positions.

- Ring groove clearance:
Before checking, piston grooves must be clean, dry and free of carbon.
Fit new piston ring (1) into piston groove, and measure clearance between ring and ring land by using thickness gauge (2).
If clearance is out of specification, replace piston.

Ring groove clearance

Item	Standard	Limit
Top ring	0.03 – 0.07 mm (0.0120 – 0.0027 in.)	0.12 mm (0.0047 in.)
2nd ring	0.02 – 0.06 mm (0.0008 – 0.0023 in.)	0.1 mm (0.0039 in.)
Oil ring	0.06 – 0.15 mm (0.0024 – 0.0059 in.)	—



I2RH01140159-01

Piston pin

- Check piston pin, connecting rod small end bore and piston bore for wear or damage, paying particular attention to condition of small end bore bush. If pin, connecting rod small end bore or piston bore is badly worn or damaged, replace pin, connecting rod or piston.
- Piston pin clearance: Check piston pin clearance in small end.
Replace connecting rod if its small end is badly worn or damaged or if measured clearance exceeds limit.

Piston pin clearance in small end

Standard: 0.003 – 0.014 mm (0.0001 – 0.0005 in.)

Piston pin clearance in piston

Standard: 0.006 – 0.017 mm (0.00024 – 0.00067 in.)

Small-end bore [A]


21.003 – 21.011 mm (0.8269 – 0.8272 in.)

Piston pin diameter [B]

20.997 – 21.000 mm (0.8267 – 0.8268 in.)

Piston bore

21.006 – 21.014 mm (0.8270 – 0.8273 in.)



I5JB0A142054-02

Piston rings

To measure end gap, insert piston ring (2) into cylinder bore and then measure the gap by using thickness gauge (1).

If measured gap is out of specification, replace ring.

NOTE


Clean carbon and any other dirt from top of cylinder bore before inserting piston ring.

Piston ring end gap

Item	Standard	Limit
Top ring	0.20 – 0.33 mm (0.0079 – 0.0129 in.)	0.7 mm (0.0276 in.)
2nd ring	0.33 – 0.48 mm (0.0129 – 0.0188 in.)	0.7 mm (0.0276 in.)
Oil ring	0.20 – 0.50 mm (0.0079 – 0.0196 in.)	1.8 mm (0.0709 in.)

Piston rings end gap

“a”: 120 mm (4.72 in.)




I2RH01140161-01

Connecting rod


- **Big-end side clearance:**
Check big-end of connecting rod for side clearance, with rod fitted and connected to its crank pin in the normal manner. If measured clearance is found to exceed its limit, replace connecting rod.

Big-end side clearance

Standard	Limit
0.25 – 0.40 mm (0.0099 – 0.0150 in.)	0.45 mm (0.0177 in.)




- **Connecting rod alignment:**
Mount connecting rod on aligner to check it for bow and twist. If limit is exceeded, replace it.

Limit on bow**0.05 mm (0.0020 in.)****Limit on twist****0.10 mm (0.0039 in.)****Crank pin and connecting rod bearings**

- Inspect crank pin for uneven wear or damage. Measure crank pin for out-of-round or taper with a micrometer. If crank pin is damaged, or out-of round or taper is out of limit, replace crankshaft or regrind crank pin.

Connecting rod bearing and crank pin


Item	Standard
Crank pin diameter	49.982 – 50.000 mm (1.9768 – 1.9685 in.)

Out-of-round**“A” – “B”****Taper****“a” – “b”****Out-of-round and taper limits****0.01 mm (0.0004 in.)**

- **Connecting rod bearing general information:**


Inspect bearing shells for signs of fusion, pitting, burn or flaking and observe contact pattern. Bearing shells found in defective condition must be replaced.

Two kinds of connecting rod bearings are available; standard size bearing and 0.25 mm (0.0098 in.) undersize bearing. For identification of undersize bearing, it is painted red (1) at the position as indicated in the figure, undersize bearing thickness is 1.605 – 1.615 mm (0.0632 – 0.0635 in.) at the center of it.



• **Connecting rod bearing clearance:**

- a. Before checking bearing clearance, clean bearing and crank pin.
- b. Install bearing in connecting rod and bearing cap.
- c. Place a piece of gauging plastic (1) to full width of crank pin as contacted by bearing (parallel to crankshaft), avoiding oil hole.



I2RH01140165-01


- d. Install connecting rod bearing cap (1) as follows.
 - i. Point arrow mark (2) on cap to crankshaft pulley side.
 - ii. Apply engine oil to connecting rod bolts (3).
 - iii. Tighten all connecting rod bolts to 15 N·m (1.5 kgf-m, 11.0 lb-ft).
 - iv. Retighten them by turning through 45°.
 - v. Repeat step d) once again.

Tightening torque

Connecting rod bolt (a): Tighten 15 N·m (1.5 kgf-m, 11.0 lb-ft), 45° and 45° by the specified procedure

NOTE

Do not turn crankshaft with gauging plastic installed.



I4RH01140037-01


- e. Remove connecting rod bearing cap, and using a scale (2) on gauging plastic envelope, measure gauging plastic (1) width at the widest point (clearance).

If clearance exceeds its limit, select connecting rod bearing referring to "Pistons, Piston Rings, Connecting Rods and Cylinders Inspection and Cleaning" below mentioned item.

After selecting new bearing, recheck clearance.

Bearing clearance

Standard	Limit
0.045 – 0.063 mm (0.0018 – 0.0025 in.)	0.08 mm (0.0031 in.)



I2RH01140167-01

- f. If clearance can not be brought to within its limit even by using a new standard size bearing, replace crankshaft or regrind crankpin to undersize as follows.

- Install 0.25 mm undersize bearing to connecting rod big end.
- Measure bore diameter of connecting rod big end.
- Regrind crankpin to the following finished diameter.

Finished crankpin diameter = Measured big end bore diameter (including undersize bearing) – 0.054 mm (0.0021 in.)

- Confirm that bearing clearance is within the standard value.

NOTE

After checking the connecting rod bearing clearance, make sure to check for "Connecting rod bolt" under "Pistons, Piston Rings, Connecting Rods and Cylinders Inspection and Cleaning".

• **Selection of connecting rod bearings:**


NOTE

- If bearing is in malcondition or bearing clearance is out of specification, select a new standard bearing according to the following procedure and install it.
- When replacing crankshaft or connecting rod and its bearing due to any reason, select new standard bearings to be installed referring to numbers stamped on connecting rod and its cap and/or alphabets stamped on crank web of No. 3 cylinder.

- a. Check stamped numbers on connecting rod and its cap as shown.
Three kinds of numbers ("1", "2" and "3") represent the following connecting rod big end inside diameters.
For example, stamped number "1" indicates that corresponding connecting rod big-end inside diameter is 53.0000 – 53.0060 mm (2.0867 – 2.0868 in.).

Connecting rod big-end inside diameter

Stamped numbers	Connecting rod big-end inside diameter
1	53.0000 – 53.0060 mm (2.0867 – 2.0868 in.)
2	53.0061 – 53.0120 mm (2.0869 – 2.0870 in.)
3	53.0121 – 53.0180 mm (2.0871 – 2.0873 in.)



I7RW01140064-01

[A]: Connecting rod big-end inside diameter number

[B]: Weight indication mark (It is not necessary in servicing)


- b. Next, check crank pin diameter. On crank web of No. 3 cylinder, four alphabets are stamped as shown in the figure.

Three kinds of alphabet ("A", "B" and "C") represent the following crank pin diameter respectively.

For example, stamped "A" indicates that corresponding crank pin diameter is 49.9940 – 50.0000 mm (1.9683 – 1.9685 in.).

Crank pin diameter

Stamped alphabet	Crank pin diameter (without bearing)
A	49.9940 – 50.0000 mm (1.9683 – 1.9685 in.)
B	49.9880 – 49.9939 mm (1.9681 – 1.9682 in.)
C	49.9820 – 49.9879 mm (1.9677 – 1.9680 in.)



I5JB0A142055-01

[A]: Crankshaft pin diameter for No.1 cylinder

[B]: Crankshaft pin diameter for No.2 cylinder

[C]: Crankshaft pin diameter for No.3 cylinder


[D]: Crankshaft pin diameter for No.4 cylinder

- c. There are 5 kinds of standard bearings differing in thickness. To distinguish them, they are painted in the following colors at the position as indicated in the figure.

Each color indicated the following thickness at the center of bearing.

Standard size of connecting rod bearing thickness

Color painted	Bearing thickness
Green	1.482 – 1.485 mm (0.05835 – 0.05846 in.)
Black	1.485 – 1.488 mm (0.05847 – 0.05858 in.)
Colorless	1.488 – 1.491 mm (0.05859 – 0.05870 in.)
Yellow	1.491 – 1.494 mm (0.05871 – 0.05881 in.)
Blue	1.494 – 1.497 mm (0.05882 – 0.05893 in.)



IYSQ01141169-01

1. Paint

- d. From number stamped on connecting rod and its cap and alphabet stamped on crank web No. 3 cylinder, determine new standard bearing to be installed to connecting rod big-end inside, by referring to the table.

For example, if number stamped on connecting rod and its cap is "1" and alphabet stamped on crank web No. 3 cylinder is "B", install a new standard bearing painted in "Black" to its connecting rod big-end inside.

Specifications of new standard connecting rod bearing size

		Number stamped on connecting rod and its cap (Connecting rod big end inside diameter)		
		1	2	3
Alphabet stamped on crank web of No. 3 cylinder (Crank pin diameter)	A	Green	Black	Colorless
	B	Black	Colorless	Yellow
	C	Colorless	Yellow	Blue

- e. Check bearing clearance with newly selected standard bearing referring to "Crank pin and connecting rod bearings: ".
If clearance still exceeds its limit, use next thicker bearing and recheck clearance.

• **Connecting rod bolt**

Measure each thread diameter of connecting rod bolts (1) at "A" on 28.5 mm (1.12 in.) from bolt mounting surface and "B" on 42.0 mm (1.65 in.) from bolt mounting surface by using a micrometer (2). Calculate difference in diameters ("A" – "B"). If it exceeds limit, replace connecting rod.



Connecting rod bolt measurement points

"a": 28.5 mm (1.12 in.)

"b": 42.0 mm (1.65 in.)

Connecting rod bolt diameter difference

limit ("A" – "B"): 0.1 mm (0.004 in.)




I4RH01140043-01

Cleaning

Clean carbon from piston head and ring grooves, using a suitable tool.

Main Bearings, Crankshaft and Cylinder Block Components

S7RW0C1406037



I7RW01140065-01

1. Cylinder block	10. Flywheel	⚙️(a) : Tighten 40 N-m (4.0 kgf-m, 29.0 lb-ft), 0 N-m (0 kgf-m, 0 lb-ft), 40 N-m (4.0 kgf-m, 29.0 lb-ft) and 58 N-m (5.8 kgf-m, 42.0 lb-ft) by the specified procedure.
⚙️1207F 2. Lower crankcase : Apply sealant 99000-31250 to mating surface.	11. Water pump	⚙️(b) : Tighten 26 N-m (2.6 kgf-m, 19.0 lb-ft) by the specified procedure.
3. Crankshaft	12. Heater outlet pipe	⚙️(c) : 70 N-m (7.0 kgf-m, 51.0 lb-ft)
4. O-ring	13. CKP sensor	⚙️(d) : 11 N-m (1.1 kgf-m, 8.0 lb-ft)
5. Oil pump chain	14. Crankcase bolt (10 mm thread diameter)	⚙️(e) : 22 N-m (2.2 kgf-m, 16.0 lb-ft)
⚙️ 6. Main bearing : Do not apply engine oil between cylinder block and bearing, between lower crankcase and bearing. Upper half of bearing has an oil groove.	15. Crankcase bolt (8 mm thread diameter)	⚙️(f) : 3 N-m (0.3 kgf-m, 2.5 lb-ft)
7. Thrust bearing	16. Flywheel or drive plate bolt	⊗ : Do not reuse.

8. Rear oil seal	17. Knock sensor	 : Apply engine oil to inside / sliding surface.
9. Check valve	18. Oil pump chain guide	

Main Bearings, Crankshaft and Cylinder Block Removal and Installation


S7RW0C1406038

Removal

- 1) Remove engine assembly from vehicle. Refer to "Engine Assembly Removal and Installation".
- 2) Remove flywheel (drive plate for A/T) by using special tool.

Special tool


(A): 09924-17811



I2RH01140169-01


1. Flywheel bolt

- 3) Remove pistons and connecting rods referring to "Pistons, Piston Rings, Connecting Rods and Cylinders Removal and Installation".
- 4) Remove CKP sensor (1).




I2RH01140170-01

- 5) Remove water pump (1) and heater outlet pipe (3).
- 6) Remove engine front mounting brackets (2).



I7RW01140066-01

- 7) Loosen crankcase bolts, in sequence shown in figure and remove them.



I4RH01140045-01

- | |
|--|
| 1. Lower crankcase |
| 2. Crankcase bolts (10 mm thread diameter) |
| 3. Crankcase bolts (8 mm thread diameter) |

- 8) Remove crankshaft from cylinder block.


Installation

NOTE

- All parts to be installed must be perfectly clean.
- Be sure to oil crankshaft journals, journal bearings, thrust bearings, crankpins, connecting rod bearings, pistons, piston rings and cylinder bores.
- Journal bearings, crankcase (bearings caps), connecting rods, rod bearings, rod bearing caps, pistons and piston rings are in combination sets. Do not disturb combination and try to see that each part goes back to where it came from, when installing.
- Clean mating surface of cylinder block and lower crankcase, remove oil, old sealant and dust from mating surface.


1D-57 Engine Mechanical:

- 1) Fit main bearings to cylinder block (1).
One of two halves of main bearing (4) has oil groove (3).
Install this half with oil groove to cylinder block and another half without oil groove to lower crankcase.
Make sure that two halves are painted in the same color.
- 2) Install new O-ring (2) to cylinder block.
- 3) Install knock pins (5) to cylinder block.




I4RH01140055-01

- 4) Put crankshaft (1) with oil pump chain to cylinder block.



I2RH01140175-01

- 5) Install thrust bearings (1) to cylinder block between No.2 and No.3 cylinders. Face oil groove (2) sides to crank weds.



I6RW0B140014-01


- 6) Apply sealant "A" to lower crankcase (1) mating surface area as shown in figure.

"A": Water tight sealant 99000-31250 (SUZUKI Bond No.1207F)

Sealant amount for lower crankcase

Width "a": 3 mm (0.12 in.)

Height "b": 2 mm (0.08 in.)




I2RH01140176-01

2. Bearing

- 7) Install lower crankcase (1) to cylinder block.
Apply engine oil to all crankcase bolts ((1) – (10)) and tighten them gradually as follows.

- a) Tighten bolts ((1) – (10)) to 40 N·m (4.0 kgf-m, 29.0 lb-ft) according to numerical order in figure.




I7RW01140067-01

2. Crankshaft pulley side

3. Flywheel side

- b) Loosen bolts ((1) – (10)) until tightening torque is reduced to 0 according to numerical order in figure.



I7RW01140069-01

2. Crankshaft pulley side

3. Flywheel side

- c) Tighten bolts ((1) – (10)) to 40 N·m (4.0 kgf-m, 29.0 lb-ft) according to numerical order in figure.
- d) In the same manner as in step c), retighten bolts ((1) – (10)) to 58 N·m (5.8 kgf-m, 42.0 lb-ft).
- e) Tighten bolts ((11) – (22)) to specified torque according to numerical order in figure.


Tightening torque

Crankcase bolt with 10 mm thread diameter ((1) – (10)): Tighten 40 N·m (4.0 kgf-m, 29.0 lb-ft), 0 N·m (0 kgf-m, 0 lb-ft), 40 N·m (4.0 kgf-m, 29.0 lb-ft), 58 N·m (5.8 kgf-m, 42.0 lb-ft) by the specified procedure

Crankcase bolt with 8 mm thread diameter ((11) – (22)): Tighten 26 N·m (2.6 kgf-m, 19.0 lb-ft) by the specified procedure

NOTE

- After tightening crankcase bolts, check to be sure that crankshaft rotates smoothly when turned by hand.
- Use new crankcase bolt (10 mm thread diameter).



I7RW01140071-01

2. Crankshaft pulley side

3. Flywheel side


- 8) Pull out dowel pin (2) from crankshaft (1) and then install rear oil seal (3) until it becomes flush with cylinder block surface using special tools and plastic hammer.

Special tool

(A): 09911-97710

(B): 09911-97811

- 9) Install dowel pin (2).



I5JB0A142058-01


4. Crankshaft side

5. Oil seal side

- 10) Install CKP sensor (1) and fix its wire harness with bracket.

Tightening torque

CKP sensor bolt (a): 11 N·m (1.1 kgf-m, 8.0 lb-ft)



I2RH01140179-01

11) Install flywheel (drive plate for A/T).

Using special tool, lock flywheel or drive plate, and tighten flywheel or drive plate bolts (1) to specified torque.

NOTE


Use new flywheel or drive plate bolt.

Special tool

(A): 09924-17811

Tightening torque


Flywheel or drive plate bolt (a): 70 N·m (7.0 kgf-m, 51.0 lb-ft)



I2RH01140180-01

12) Install engine front mounting brackets (1). Tighten bracket bolts to specified torque.**Tightening torque**

Engine front mounting bracket bolt (a): 55 N·m (5.5 kgf-m, 40.0 lb-ft)

13) Install water pump (2) and heater outlet pipe (3). Refer to "Water Pump Removal and Installation in Section 1F".

I2RH01140181-01

14) Install pistons and connecting rods. Refer to "Pistons, Piston Rings, Connecting Rods and Cylinders Removal and Installation".**15) Install oil pump. Refer to "Oil Pump Removal and Installation in Section 1E".****16) Install cylinder head assembly to cylinder. Refer to "Valves and Cylinder Head Removal and Installation".****17) Install camshafts and tappets and shims. Refer to "Camshafts, Tappet and Shim Removal and Installation" for installation.****18) Check intake and exhaust valve lashes referring to "Valve Lash (Clearance) Inspection".****19) Install, timing chain sprockets, timing chains, timing chain tensioner, tensioner adjusters, timing chain guides, timing chain cover, crankshaft pulley, water pump pulley. Refer to "Timing Chain Cover Removal and Installation", "2nd Timing Chain and Chain Tensioner Removal and Installation" and "1st Timing Chain and Chain Tensioner Removal and Installation".****20) Install cylinder head cover referring to "Cylinder Head Cover Removal and Installation".****21) Install oil pump strainer and oil pan referring to "Oil Pan and Oil Pump Strainer Removal and Installation in Section 1E".****22) Install clutch cover and clutch disc to flywheel (for M/T vehicle). For clutch installation, refer to "Clutch Cover, Clutch Disc and Flywheel Removal and Installation in Section 5C".****23) Install engine assembly to vehicle. Refer to "Engine Assembly Removal and Installation".****Main Bearings, Crankshaft and Cylinder Block Inspection**


S7RW0C1406039

Crankshaft**Crankshaft runout**

Using a dial gauge, measure runout at center journal. Rotate crankshaft slowly. If runout exceeds its limit, replace crankshaft.

Limit on runout

0.06 mm (0.0023 in.)



I2RH01140182-01

Crankshaft thrust play

Measure this play with crankshaft set in cylinder block in the normal manner, that is, with thrust bearing and lower crankcase installed. Tighten crankcase bolts referring to "Main Bearings, Crankshaft and Cylinder Block Removal and Installation".


Use a dial gauge to read displacement in axial (thrust) direction of crankshaft.

If its limit is exceeded, replace thrust bearing with new standard one or oversize one to obtain standard thrust play.

Crankshaft Thrust Play

Standard: 0.10 – 0.35 mm (0.0039 – 0.0137 in.)


Limit: 0.42 mm (0.0149 in.)



I2RH01140183-01

Thickness of crankshaft thrust bearing

Standard	2.425 – 2.475 mm (0.09796 – 0.09992 in.)
Oversize: 0.125 mm (0.0049 in.)	2.488 – 2.538 mm (0.09548 – 0.09744 in.)



I2RH01140184-01

1. Thrust bearing

2. Oil groove

Out-of-round and taper (uneven wear) of journals

An unevenly worn crankshaft journal shows up as a difference in diameter at a cross section or along its length (or both). This difference, if any, is determined by taking micrometer readings. If any one of journals is badly damaged or if amount of uneven wear in the sense exceeds its limit, regrind or replace crankshaft.

Limit on out-of-round and taper


0.01 mm (0.0004 in.)

Out-of-round

"A" – "B"

Taper


"a" – "b"



I2RH01140185-01

Main Bearings**Main bearings general information**

- Service main bearings are available in standard size and 0.25 mm (0.0098 in.) undersize, and standard size has 5 kinds of bearings differing in tolerance.
- Upper half of bearing (1) has oil groove (2) as shown in figure.
Install this half with oil groove to cylinder block.
- Lower half of bearing does not have oil groove.



I2RH01140186-01


Main bearings inspection

Check bearings for pitting, scratches, wear or damage. If any malfunction is found, replace both upper and lower halves. Never replace either half without replacing the other half.

Main bearing clearance

Check clearance by using gauging plastic according to the following procedure.

- 1) Remove lower crankcase.
- 2) Clean bearings and main journals.
- 3) Place a piece of gauging plastic (1) to full width of bearing (parallel to crankshaft) on journal, avoiding oil hole.



I2RH01140187-01

- 4) Install lower crankcase to cylinder block referring to "Main Bearings, Crankshaft and Cylinder Block Removal and Installation".

NOTE

Do not rotate crankshaft while gauging plastic is installed.

- 5) Remove lower crankcase and using scale (2) on gauging plastic envelop (1), measure gauging plastic width at its widest point. If clearance exceeds its limit, replace bearing. Always replace both upper and lower inserts as a unit.


A new standard bearing may produce proper clearance. If not, it will be necessary to regrind crankshaft journal for use of 0.25 mm undersize bearing.

After selecting new bearing, recheck clearance.

Main bearing clearance

Standard: 0.020 – 0.038 mm (0.00079 – 0.00149 in.)

Limit: 0.063 mm (0.0024 in.)



I2RH01140188-01

Selection of main bearings**STANDARD BEARING:**

If engine is under the following conditions, select a new standard bearing as followings and install it.


- Bearing is in malcondition.
- Bearing clearance is out of specification.
- Crankshaft or cylinder block is replaced.

- 1) First check journal diameter. As shown in figure, crank web No.2 has stamped numbers. Six kinds of numbers ("4" through "9") represent the following journal diameters.

Journal diameter

Stamped numbers	Journal diameter
4	58.0030 – 58.0060 mm (2.28358 – 2.28369 in.)
5	58.0000 – 58.0029 mm (2.28346 – 2.28357 in.)
6	57.9970 – 57.9999 mm (2.28334 – 2.28345 in.)
7	57.9940 – 57.9969 mm (2.28323 – 2.28333 in.)
8	57.9910 – 57.9939 mm (2.28311 – 2.28322 in.)
9	57.9880 – 57.9909 mm (2.28299 – 2.28310 in.)

Stamped numbers on crank web No.2 (3) represent journal diameters marked with an arrow in figure respectively. For example, stamped number "5" indicates that corresponding journal diameter is 58.0000 – 58.0029 mm (2.28346 – 2.28357 in.).



I4RH01140047-01

1. Crankshaft pulley side

2. Flywheel side

- 2) Next, check journal bore diameter. On lower crankcase five alphabets are stamped as shown in figure.


Three kinds of alphabets ("A", "B" and "C") represent the following journal bore diameters.

Journal bore diameter

Stamped alphabet	Journal bore diameter
A	61.9940 – 62.0000 mm (2.44070 – 2.44094 in.)
B	62.0001 – 62.0060 mm (2.44095 – 2.44117 in.)
C	62.0061 – 62.0120 mm (2.44118 – 2.44141 in.)

Stamped alphabets on lower crankcase represent journal diameter marked with an arrow in figure respectively.

For example, stamped alphabet "A" at No.2 journal indicates that (journal) bore diameter of No.2 journal is 61.9940 – 62.0000 mm (2.44070 – 2.44094 in.).




I4RH01140048-01

1. No.1 journal	5. No.5 journal
2. No.2 journal	6. Crankshaft pulley side
3. No.3 journal	7. Flywheel side
4. No.4 journal	

- 3) There are 5 kinds of standard bearings differing in thickness. To distinguish them, they are painted (1) in the following colors at the position as indicated in figure.
Each color indicates the following thickness at the center of bearing.

Standard size main bearing thickness

Color painted	Bearing thickness
Green	1.9910 – 1.9940 mm (0.07839 – 0.07850 in.)
Black	1.9940 – 1.9970 mm (0.07851 – 0.07862 in.)
Colorless (no painted)	1.9970 – 2.0000 mm (0.07863 – 0.07874 in.)
Yellow	2.0000 – 2.0030 mm (0.07874 – 0.07885 in.)
Blue	2.0030 – 2.0060 mm (0.07886 – 0.07897 in.)



I2RH01140191-01

- 4) From number stamped on crank web No.2 and alphabets stamped on lower crankcase, determine new standard bearing to be installed to journal by referring to table shown.
For example, if number stamped on crank web No.2 is "5" and alphabet stamped on lower crankcase is "A", install new standard bearings painted in "Green" to cylinder block side journal and "Black" to lower crankcase side journal.

NOTE

The meaning of "Upper" and "Lower" described in below table are the following.

- Upper: It is instruction of main bearing installed in cylinder block side journal.
- Lower: It is instruction of main bearing installed in lower crankcase side journal.

Main bearing cross-reference table (new standard bearing)

		Standard number on crank web No.2					
		4	5	6	7	8	9
Standard alphabet on lower crankcase	A	Green	Upper: Green Lower: Black	Black	Upper: Black Lower: Colorless	Colorless	Upper: Colorless Lower: Yellow
	B	Black	Upper: Black Lower: Colorless	Colorless	Upper: Colorless Lower: Yellow	Yellow	Upper: Yellow Lower: Blue
	C	Colorless	Upper: Colorless Lower: Yellow	Yellow	Upper: Yellow Lower: Blue	Blue	Blue


- 5) Check main bearing clearance with newly selected standard bearing referring to “Main Bearing Clearance”.
If clearance still exceeds its limit, use next thicker bearing and recheck clearance.

UNDERSIZE BEARING (0.25 mm):

- 0.25 mm undersize bearing is available, in five kinds varying in thickness.
To distinguish them, each bearing is painted (1) in the following colors at such position as indicated in figure.
Each color represents the following thickness at the center of bearing.


Undersize main bearing thickness

Color painted	Bearing thickness
Green & Red	2.1160 – 2.1190 mm (0.08331 – 0.08342 in.)
Black & Red	2.1190 – 2.1220 mm (0.08343 – 0.08354 in.)
Red only	2.1220 – 2.1250 mm (0.08355 – 0.08366 in.)
Yellow & Red	2.1250 – 2.1280 mm (0.08367 – 0.08377 in.)
Blue & Red	2.1280 – 2.1310 mm (0.08378 – 0.08389 in.)



I2RH01140192-01

- If necessary, regrind crankshaft journal and select under-size bearing to use with it as follows.
 - Regrind journal to the following finished diameter.
Finished journal diameter
57.7380 – 57.7560 mm (2.27315 – 2.27385 in.)
 - Using micrometer, measure reground journal diameter.
Measurement should be taken in two directions perpendicular to each other in order to check for out-of-round.
 - Using journal diameter measured and alphabets stamped on lower crankcase, select an undersize bearing by referring to the following table.
Check bearing clearance with newly selected undersize bearing.



I2RH01140193-01


Undersize bearing specification

		Measured journal diameter		
		57.7500 – 57.7560 mm (2.27362 – 2.27385 in.)	57.7440 – 57.7499 mm (2.27338 – 2.27361 in.)	57.7380 – 57.7439 mm (2.27315 – 2.27337 in.)
Alphabets stamped on lower crankcase	A	Green & Red	Black & Red	Red only
	B	Black & Red	Red only	Yellow & Red
	C	Red only	Yellow & Red	Blue & Red

Crankshaft Position Sensor Plate

Check teeth of plate for damage.

If any damage is found, replace crankshaft (1).




I2RH01140194-01

2. Crankshaft position sensor plate

Oil Pump Sprocket

Check teeth of sprocket for wear or damage.

If any damage or wear is found, replace crankshaft (1).



I2RH01140195-01

2. Oil pump sprocket

Oil Pump Chain

Check oil pump chain for wear or damage.




I2RH01140196-01

Flywheel

- If ring gear is damaged, cracked or worn, replace flywheel.
- If the surface contacting clutch disc is damaged, or excessively worn, replace flywheel.
- Check flywheel for face runout with a dial gauge. If runout exceeds its limit, replace flywheel.

Limit on runout

0.2 mm (0.0078 in.)




I2RH01140198-01

Cylinder Block

- Distortion of gasketed surface.
- Using straightedge and thickness gauge, check gasketed surface for distortion and, if flatness exceeds its limit, correct it.

Flatness Limit

0.06 mm (0.0024 in.)



I2RH01140199-01

Honing or reboring cylinders

- 1) When any cylinder needs reboring, all other cylinders must also be rebored at the same time.

Upsize piston specification




Size	Piston diameter
STD	83.970 – 83.990 mm (3.3059 – 3.3067 in.)
O/S 0.50	84.470 – 84.490 mm (3.3256 – 3.3264 in.)

- 2) Using micrometer, measure piston diameter.
- 3) Calculate cylinder bore diameter to be rebored as follows.
- $$D = A + B - C$$
- D: Cylinder bore diameter to be rebored.
A: Piston diameter as measured.
B: Piston clearance = 0.02 – 0.04 mm (0.0008 – 0.0015 in.)
C: Allowance for honing = 0.02 mm (0.0008 in.)
- 4) Rebore and hone cylinder to calculated dimension.

NOTE

Before reboring, install lower crankcase and tighten to specification to avoid distortion of bearing bores.

- 5) Measure piston clearance after honing.



I5JB0A142059-01

"e": 50 mm (1.96 in.)	"g": 26.5 mm (1.04 in.)
"f": 95 mm (3.74 in.)	

Check Valve

Check check valve for clogging and ball for being stuck.



I2RH01140201-01

Specifications**Tightening Torque Specifications**

S7RW0C1407001

Fastening part	Tightening torque			Note
	N·m	kgf·m	lb·ft	
Camshaft housing bolt	11	1.1	8.0	☞
Air cleaner outlet hose clamp	3	0.3	2.5	☞
IMT valve actuator bolt	6	0.6	4.5	☞
Cylinder head cover nut	Tighten 11 N·m (1.1 kgf·m, 8.0 lb·ft) by the specified procedure			☞
Suspension frame mounting bolt	150	15.0	108.5	☞
Front lower cross member bolt	55	5.5	40.0	☞
Starting motor terminal nut	11	1.1	8.0	☞
Generator terminal nut	5	0.5	4.0	☞
Battery ground bolt	25	2.5	18.0	☞
Ground terminal bolt	11	1.1	8.0	☞

Fastening part	Tightening torque			Note
	N·m	kgf-m	lb-ft	
Timing chain cover bolt and nut	11	1.1	8.0	
Idle pulley nut	42	4.2	30.5	
Generator belt tensioner bolt	25	2.5	18.5	
Crankshaft pulley bolt	150	15.0	108.5	
Camshaft timing sprocket bolt	80	8.0	57.5	
Timing chain tensioner adjuster No.2 bolt	11	1.1	8.0	
Timing chain tensioner adjuster No.2 nut	45	4.5	33.0	
Timing chain tensioner nut	25	2.5	18.0	
Timing chain tensioner adjuster No.1 bolt	11	1.1	8.0	
Timing chain guide No.1 bolt	9	0.9	6.5	
Camshaft housing bolt	Tighten 11 N·m (1.1 kgf-m, 8.0 lb-ft) by the specified procedure			 / 
Cylinder head bolt (M10)	Tighten 52 N·m (5.2 kgf-m, 38.0 lb-ft), 82 N·m (8.2 kgf-m, 59.5 lb-ft), 0 N·m (0 kgf-m, 0 lb-ft), 52 N·m (5.2 kgf-m, 38.0 lb-ft) and 103 N·m (10.3 kgf-m, 74.5 lb-ft) by the specified procedure			
Cylinder head bolt (M6)	11	1.1	8.0	
Connecting rod bolt	Tighten 15 N·m (1.5 kgf-m, 11.0 lb-ft), 45° and 45° by the specified procedure			 / 
Crankcase bolt with 10 mm thread diameter ((1) – (10))	Tighten 40 N·m (4.0 kgf-m, 29.0 lb-ft), 0 N·m (0 kgf-m, 0 lb-ft), 40 N·m (4.0 kgf-m, 29.0 lb-ft), 58 N·m (5.8 kgf-m, 42.0 lb-ft) by the specified procedure			
Crankcase bolt with 8 mm thread diameter ((11) – (22))	Tighten 26 N·m (2.6 kgf-m, 19.0 lb-ft) by the specified procedure			
CKP sensor bolt	11	1.1	8.0	
Flywheel or drive plate bolt	70	7.0	51.0	
Engine front mounting bracket bolt	55	5.5	40.0	

NOTE

The specified tightening torque is also described in the following.

“Air Cleaner Components”

“Electric Throttle Body and Intake Manifold Components”

“Cylinder Head Cover Components”

“Engine Mountings Components”

“Timing Chain Cover Components”

“2nd Timing Chain and Chain Tensioner Components”

“1st Timing Chain and Chain Tensioner Components”

“Camshafts, Tappet and Shim Components”

“Valves and Cylinder Head Components”

“Pistons, Piston Rings, Connecting Rods and Cylinders Components”

“Main Bearings, Crankshaft and Cylinder Block Components”

Reference:

For the tightening torque of fastener not specified in this section, refer to “Fasteners Information in Section 0A”.

Special Tools and Equipment

Recommended Service Material

S7RW0C1408001

Material	SUZUKI recommended product or Specification		Note
Sealant	SUZUKI Bond No.1217G	P/No.: 99000-31260	
Thread lock cement	Thread Lock Cement Super 1322	P/No.: 99000-32110	
Water tight sealant	SUZUKI Bond No.1207B	P/No.: 99000-31140	
	SUZUKI Bond No.1207F	P/No.: 99000-31250	 / 

NOTE

Required service material is also described in the following.

“Timing Chain Cover Components”

“2nd Timing Chain and Chain Tensioner Components”

“1st Timing Chain and Chain Tensioner Components”

“Camshafts, Tappet and Shim Components”











“Valves and Cylinder Head Components”

“Pistons, Piston Rings, Connecting Rods and Cylinders Components”

“Main Bearings, Crankshaft and Cylinder Block Components”

Special Tool

S7RW0C1408002

09911-97710 Oil seal guide 		09911-97811 Oil seal installer 	
09913-75510 Bearing installer 		09915-64512 Compression gauge 	
09915-64530 Compression gauge hose 		09915-67010 Compression gauge attachment (C) 	
09915-67311 Vacuum gauge 		09916-14510 Valve lifter  / 	
09916-16510 Valve lifter attachment  / 		09916-34542 Reamer handle  / 	

09916-37810 Valve guide reamer (6 mm)	09916-38210 Valve guide reamer (11 mm)
09916-46020 Valve guide remover	09916-57340 Valve guide installer attachment
09916-57350 Valve guide installer handle (6 mm)	09916-66510 Tappet holder
09916-77310 Piston ring compressor (50-125 mm)	09916-84511 Forceps
09917-68221 Camshaft pulley holder	09917-98221 Valve guide stem attachment
09919-28610 Protector sleeve	09924-17811 Flywheel holder
09926-58010 Bearing remover attachment	09944-36011 Steering wheel remover

Engine Lubrication System

General Description

Engine Lubrication Description

S7RW0C1501001


The oil pump is trochoid type, and mounted under the crankshaft. Oil is drawn up through the oil pump strainer and passed through the pump to the oil filter.

The filtered oil flows into two paths in cylinder block.

In one path, oil reaches the crankshaft journal bearings. Oil from the crankshaft journal bearings is supplied to the connecting rod bearings by means of intersecting passages drilled in the crankshaft.

In the other path oil goes up to the cylinder head and lubricates valves and camshafts, etc., after passing through the internal oilway of camshafts.

An oil relief valve is provided on the oil pump. This valve starts relieving oil pressure when the pressure exceeds specified pressure.



I7RW01150001-01

Diagnostic Information and Procedures

Oil Pressure Check

S7RW0C1504001

⚠ WARNING

To avoid danger of being burned, do not touch exhaust manifold when exhaust system is hot.


When servicing, be sure to perform it after exhaust system has cooled down.

NOTE

Prior to checking oil pressure, check the following.

- **Oil level in oil pan**
If oil level is low, add oil up to Full level hole on oil level gauge referring to "Engine Oil and Filter Change".
- **Oil quality**
If oil is discolored, or deteriorated, change it. For particular oil to be used, refer to "Engine Oil and Filter Change".
- **Oil leaks**
If leak is found, repair it.

- 1) Disconnect oil pressure switch connector.
- 2) Remove oil pressure switch (1) from cylinder block.



I7RW01150002-01

2. Engine front mounting bracket

- 3) Install special tool (Oil pressure gauge) to vacated threaded hole.


Special tool

(A): 09915-77311

(B): 09915-78211

⚠ CAUTION

Be careful not to make special tool touch Exhaust manifold when installing because Exhaust manifold becomes very hot.



I7RW01150003-02

- 4) Start engine and warm it up to normal operating temperature.

NOTE

Be sure to place transmission gear shift lever in "Neutral" (shift selector lever to "P" range for A/T model), and set parking brake and block drive wheels.

- 5) After warming up, raise engine speed to 4,000 r/min and measure oil pressure.

Oil pressure specification

More than 390 kPa (3.9 kgf/cm², 55.5 psi)


- 6) After checking oil pressure, stop engine and remove oil pressure gauge.
- 7) Before reinstalling oil pressure switch (2), be sure to wrap its screw threads with sealing tape (1) and tighten switch to specified torque.

Tightening torque

Oil pressure switch (a): 13 N·m (1.3 kgf-m, 9.5 lb-ft)

NOTE

If sealing tape edge is bulged out from screw threads of switch, cut it off.



I7RW01150004-01

- 8) Start engine and check oil pressure switch for oil leakage. If oil leakage is found, repair it.
- 9) Connect oil pressure switch connector.

Repair Instructions

Engine Oil and Filter Change

S7RW0C1506001


▲ WARNING

- New and used engine oil can be hazardous.
Be sure to read “WARNING” in “General Precautions in Section 00” and observe what is written there.
- Step 1) – 7) outlined below must be performed with **ENGINE NOT RUNNING**. For Step 8), be sure to have adequate ventilation while engine is running.

Use only engine oil of SG, SH, SJ, SL or SM grade. Select the appropriate oil viscosity according to the chart [A].

It is highly recommended to use SAE 5W-30 oil. However, SAE 10W-30 oil is usable for ambient temperatures above – 18 °C (0 °F).

[A]



Before draining engine oil, check engine for oil leakage. If any evidence of leakage is found, make sure to correct defective part before proceeding to the following work.

- 1) Remove right side engine under cover.
- 2) Drain engine oil by removing drain plug.
- 3) After draining oil, wipe drain plug clean. Reinstall drain plug.


Tightening torque

Engine oil drain plug (a): 35 N·m (3.5 kgf-m, 25.5 lb-ft)

- 4) Loosen oil filter by using oil filter wrench (special tool).

Special tool


(A): 09915-40611



I5JB0A020020-01

NOTE

Before fitting new oil filter, be sure to oil its O-ring. Use engine oil for this purpose.



IYSQ01020009-01

- 5) Screw new filter on oil filter stand by hand until the filter O-ring contacts mounting surface.


⚠ CAUTION

To tighten oil filter properly, it is important to accurately identify the position at which filter O-ring first contacts mounting surface.

- 6) Tighten the filter (1) 3/4 turn from the point of contact with the mounting surface using an oil filter wrench (2).

Tightening torque

Oil filter (a): 14 N·m (1.4 kgf-m, 10.5 lb-ft) for reference



I5JB0A020021-01

- 7) Replenish oil until oil level is brought to FULL level mark on dipstick (oil pan and oil filter capacity). The filler inlet is at the top of the cylinder head cover.

NOTE

Engine oil capacity is specified as the following.

However, note that the amount of oil required when actually changing oil may somewhat differ from the data depending on various conditions (temperature, viscosity, etc.).

Engine oil specification

Oil pan capacity: About 4.3 liters (9.1 / 7.6 US / Imp pt.)


Oil filter capacity: About 0.2 liter (0.4 / 0.3 US / Imp pt.)

Others: About 0.3 liter (0.6 / 0.5 US / Imp pt.)

Total: About 4.8 liters (10.1 / 8.4 US / Imp pt.)

- 8) Check oil filter and drain plug for oil leakage.

- 9) Start engine and run it for 3 minutes. Stop it and wait another 5 minutes before checking oil level. Add oil, as necessary, to bring oil level to FULL level mark (1) on dipstick.




IYSQ01020012-01

2. Low level mark (hole)

Oil Pan and Oil Pump Strainer Components

S7RW0C1506002



I7RW01150005-01


1. Oil pan : Apply sealant 99000-31260 to mating surface.	10. Clutch housing plate upper bolt : Tighten upper bolt first, then tighten lower bolt.
2. Oil pump strainer	11. Clutch housing plate lower bolt : Tighten upper bolt first, then tighten lower bolt.
3. O-ring	12. Clutch housing plate
4. Oil pump strainer bolt	: 11 N·m (1.1 kgf-m, 8.0 lb-ft)
5. Oil pan bolt and nut	: 55 N·m (5.5 kgf-m, 40.0 lb-ft)
6. Transmission case No.1 bolt	: 35 N·m (3.5 kgf-m, 25.5 lb-ft)
7. Drain plug	: 25 N·m (2.5 kgf-m, 18.0 lb-ft)
8. Gasket	: 30 N·m (3.0 kgf-m, 22.0 lb-ft)
9. Baffle plate	: Do not reuse.

Oil Pan and Oil Pump Strainer Removal and Installation

S7RW0C1506003


Removal

- 1) Remove oil level gauge.
- 2) Raise vehicle.
- 3) Remove engine under cover.
- 4) Remove exhaust No.1 pipe referring to "Exhaust System Components in Section 1K".
- 5) Remove transfer referring to "Transfer Dismounting and Remounting in Section 3C" (4WD model).
- 6) Remove clutch housing plate (1).



I7RW01150006-01

- 7) Drain engine oil by removing drain plug (1).



I7RW01150007-01

- 8) Cut sealant at hatched part shown in the figure using special tool and hammer (1).


Special tool

(A): 09921-96510

NOTE

Be careful not to damage stud bolt (4) between oil pan and crankcase when cutting sealant.

- 9) Remove oil pan (2), oil pump strainer (3) and O-rings (5) from lower crankcase.



I7RW01150008-02


1E-7 Engine Lubrication System:

Installation

- 1) Install new O-rings (2) to oil pump strainer (1) securely as shown in figure.
Tighten strainer bolts to specified torque.

Tightening torque

Oil pump strainer bolt (a): 11 N·m (1.1 kgf-m, 8.0 lb-ft)




- 2) Apply sealant to oil pan (1) mating surface continuously as shown in figure.

“A”: Sealant 99000–31260 (SUZUKI Bond No.1217G)

Sealant amount for oil pan

Width “a”: 2 mm (0.08 in.)

Height “b”: 2 mm (0.08 in.)



- 3) After fitting oil pan (1) to cylinder block, run in securing bolts and start tightening at the center: move wrench outward, tightening one bolt at a time. Tighten bolts and nuts to specified torque.

Tightening torque


Oil pan bolt and nut (a): 11 N·m (1.1 kgf-m, 8.0 lb-ft)

Transmission case No.1 bolt (b): 55 N·m (5.5 kgf-m, 40.0 lb-ft)

- 4) Install new gasket and drain plug (2) to oil pan after applying engine oil.
Tighten drain plug to specified torque.

Tightening torque

Oil drain plug (c): 35 N·m (3.5 kgf-m, 25.5 lb-ft)




- 5) Install clutch housing plate (1).
Tighten upper bolt first, then tighten lower bolt to specified torque.

Tightening torque

Clutch housing plate upper bolt (a): 30 N·m (3.0 kgf-m, 22.0 lb-ft)

Clutch housing plate lower bolt (b): 11 N·m (1.1 kgf-m, 8.0 lb-ft)



- 6) Install transfer referring to “Transfer Dismounting and Remounting in Section 3C” (4WD model).
- 7) Install exhaust No.1 pipe referring to “Exhaust System Components in Section 1K”.
- 8) Install engine under cover.
- 9) Install oil level gauge.
- 10) Refill engine with engine oil referring to “Engine Oil and Filter Change”.


Oil Pan and Oil Pump Strainer Cleaning

S7RW0C1506004

- Clean mating surface of oil pan and cylinder block. Remove oil, old sealant and dust from mating surfaces and oil pan inside.
- Clean oil pump strainer screen.

Oil Pump Components

S7RW0C1506005



I7RW01150011-01

1. Cylinder block	8. Oil pump relief valve retainer	15. Baffle plate bolt (M6 bolt)
2. Oil pump relief valve set : Replace as a set.	9. Oil pump chain guide	16. Oil pump sprocket cover
3. Baffle plate	10. Oil pump chain guide plate	17. Oil pump sprocket cover bolt
4. Pin No.1	11. Oil pump chain guide nut	(a) : 25 N·m (2.5 kgf-m, 18.0 lb-ft)
5. Pin No.2	12. Oil pump case No.1	(b) : 12 N·m (1.2 kgf-m, 9.0 lb-ft)
6. Oil pump mounting bolt (M8 bolt)	13. Oil pump case No.2	(c) : 28 N·m (2.5 kgf-m, 20.5 lb-ft)
7. Oil pump case bolt	14. Pin No.3	(d) : 11 N·m (1.1 kgf-m, 8.0 lb-ft)

Oil Pump Removal and Installation


S7RW0C1506006

⚠ CAUTION

Don't remove sprocket and inner rotor from oil pump, otherwise damage of oil pump center shaft and abnormal operation of oil pump could result.


Removal

- 1) Disconnect negative (–) cable at battery.
- 2) Drain engine oil.
- 3) Remove oil pan and oil pump strainer.
Refer to "Oil Pan and Oil Pump Strainer Removal and Installation".
- 4) Remove baffle plate from lower crank case (1).
- 5) Remove oil pump chain guide.
- 6) Remove oil pump sprocket cover (1).



I7RW01150012-01

- 7) Remove oil pump (2) with sprocket from lower crank case (1).



I2RH01150016-01

Installation


- 1) Install oil pump (2) and baffle plate to lower crank case (1) and tighten bolts to specified torque.

NOTE

When installing oil pump, be careful not to allow pins to fall off.

Tightening torque

Oil pump mounting bolt (M8 bolt) (a): 25 N·m (2.5 kgf-m, 18.0 lb-ft)
Baffle plate bolt (M6 bolt): 11 N·m (1.1 kgf-m, 8.0 lb-ft)




I2RH01150017-01

- 2) Install oil pump chain guide (1), and tighten bolts to specified torque.

Tightening torque

Oil pump chain guide nut (a): 11 N·m (1.1 kgf-m, 8.0 lb-ft)




I5JB0A152011-01

- 3) Install oil pump sprocket cover (1), and tighten bolts to specified torque.

Tightening torque

Oil pump sprocket cover bolt (a): 11 N·m (1.1 kgf-m, 8.0 lb-ft)



I7RW01150013-01

- 4) Install oil pan and oil pump strainer.
Refer to "Oil Pan and Oil Pump Strainer Removal and Installation".
- 5) Refill engine with engine oil referring to "Engine Oil and Filter Change".
- 6) Connect negative cable at battery.
- 7) After completing installation, check oil pressure by running engine. Refer to "Oil Pressure Check".

Oil Pump Disassembly and Reassembly

S7RW0C1506007

⚠ CAUTION

Don't remove sprocket and inner rotor from oil pump, otherwise damage of oil pump center shaft and abnormal operation of oil pump could result.

Disassembly

- Disassemble oil pump referring to "Oil Pump Components".


Reassembly

- 1) Wash, clean and then dry all disassembled parts.
- 2) Apply thin coat of engine oil to inner and outer rotors, and inside surfaces of oil pump case.
- 3) Install outer rotor to pump case No.1.
- 4) Install relief valve (3), relief spring (2) and retainer (1) to oil pump case No.2 (4).
Tighten retainer to specified torque.

Tightening torque

Oil pump relief valve retainer (a): 28 N·m (2.8 kgf-m, 20.5 lb-ft)

- 5) Install oil pump case pins (5) to oil pump case No.2.




I2RH01150020-01

- 6) Assemble oil pump. After assembling oil pump, check to be sure that rotor turns smoothly by hand.

Tightening torque

Oil pump case bolt (a): 12 N·m (1.2 kgf-m, 9.0 lb-ft)




I2RH01150021-01

Oil Pump Inspection

S7RW0C1506008

Visual Inspection

- Check outer rotor (3), inner rotor and oil pump cases (1), (2) for excessive wear or damage.
If abnormal condition is found in above checks, replace oil pump assembly.
- Check relief valve (4) for excessive wear or damage.
If abnormal condition is found in above checks, replace oil pump relief valve set.



I2RH01150022-01

5. Relief spring


6. Retainer

Relief Valve Spring Free Length and Load

- Measure free length and tension of oil relief spring.
If the measured values of length or tension is less than the specification, replace oil pump relief valve set.

Oil relief spring

Item	Standard
Spring free length	63.5 mm (2.5 in.)
Spring preload	85.0 N for 52.0 mm (8.5 kgf for 52.0 mm, 19.0 lb/2.05 in.)



I2RH01150023-01

1E-11 Engine Lubrication System:


Radial Clearance

Check radial clearance between outer rotor (2) and case No.1 (1), using thickness gauge (4).

If clearance exceeds its limit, replace oil pump assembly.

Limit on radial clearance between outer rotor and case

0.20 mm (0.0079 in.)



I2RH01150024-01

3. Inner rotor


Side Clearance

Using straightedge (5) and thickness gauge (4), measure side clearance.

If side clearance exceeds its limit, replace oil pump assembly.

Limit on side clearance

0.11 mm (0.0043 in.)



I2RH01150025-01

1. Oil pump case No.1

2. Outer rotor

3. Inner rotor

Specifications

Tightening Torque Specifications

S7RW0C1507001

Fastening part	Tightening torque			Note
	N-m	kgf-m	lb-ft	
Oil pressure switch	13	1.3	9.5	☞
Engine oil drain plug	35	3.5	25.5	☞
Oil filter	14 N-m (1.4 kgf-m, 10.5 lb-ft) for reference			☞
Oil pump strainer bolt	11	1.1	8.0	☞
Oil pan bolt and nut	11	1.1	8.0	☞
Transmission case No.1 bolt	55	5.5	40.0	☞
Oil drain plug	35	3.5	25.5	☞
Clutch housing plate upper bolt	30	3.0	22.0	☞
Clutch housing plate lower bolt	11	1.1	8.0	☞
Oil pump mounting bolt (M8 bolt)	25	2.5	18.0	☞
Baffle plate bolt (M6 bolt)	11	1.1	8.0	☞
Oil pump chain guide nut	11	1.1	8.0	☞
Oil pump sprocket cover bolt	11	1.1	8.0	☞
Oil pump relief valve retainer	28	2.8	20.5	☞
Oil pump case bolt	12	1.2	9.0	☞

NOTE

The specified tightening torque is also described in the following.

“Oil Pan and Oil Pump Strainer Components”

“Oil Pump Components”

Reference:

For the tightening torque of fastener not specified in this section, refer to “Fasteners Information in Section 0A”.

Special Tools and Equipment

Recommended Service Material

S7RW0C1508001





Material	SUZUKI recommended product or Specification		Note
Sealant	SUZUKI Bond No.1217G	P/No.: 99000-31260	

NOTE

Required service material is also described in the following.
 “Oil Pan and Oil Pump Strainer Components”

Special Tool

S7RW0C1508002

09915-40611 Oil filter wrench socket  	09915-77311 Oil pressure gauge  
09915-78211 Oil pressure gauge attachment  	09921-96510 Oil pan seal cutter  

Engine Cooling System

General Description

Cooling System Description

S7RW0C1601001

The cooling system consists of the radiator cap, radiator, coolant reservoir, hoses, water pump, cooling fan and thermostat. The radiator is of tube-and-fin type.

Coolant Description

S7RW0C1601002

▲ WARNING

- Do not remove radiator cap to check engine coolant level; check coolant visually at the see-through coolant reservoir. Coolant should be added only to reservoir as necessary.
- As long as there is pressure in the cooling system, the temperature can be considerably higher than the boiling temperature of the solution in the radiator without causing the solution to boil. Removal of the radiator cap while engine is hot and pressure is high will cause the solution to boil instantaneously and possibly with explosive force, spewing the solution over engine, fenders and person removing cap. If the solution contains flammable anti-freeze such as alcohol (not recommended for use at any time), there is also the possibility of causing a serious fire.
- Check to make sure that engine coolant temperature is cold before removing any part of cooling system.
- Also be sure to disconnect negative cable from battery terminal before removing any part.

The coolant recovery system is standard. The coolant in the radiator expands with heat, and the coolant is overflowed to the reservoir.

When the system cools down, the coolant is drawn back into the radiator.

The cooling system has been filled with a quality coolant that is a 50/50 mixture of water and ethylene glycol antifreeze.

This 50/50 mixture coolant solution provides freezing protection to -36°C (-33°F).

- Maintain cooling system freeze protection at -36°C (-33°F) to ensure protection against corrosion and loss of coolant from boiling. This should be done even if freezing temperatures are not expected.
- Add ethylene glycol base coolant when coolant has to be added because of coolant loss or to provide added protection against freezing at temperature lower than -36°C (-33°F).

NOTE

- Alcohol or methanol base coolant or plain water alone should not be used in cooling system at any time as damage to cooling system could occur.
- Coolant must be mixed with demineralized water or distilled water.

Anti-freeze proportioning table

		M/T model	A/T model
Freezing temperature	$^{\circ}\text{C}$	-36	-36
	$^{\circ}\text{F}$	-33	-33
Anti-freeze / Anti-corrosion coolant concentration	%	50	50
Ratio of compound to cooling water	ltr.	3.00/3.00	3.15/3.15
	US pt.	6.34/6.34	6.66/6.66
	Imp pt.	5.28/5.28	5.54/5.54

Coolant capacity

M/T model:

- Engine, radiator and heater: 5.3 liters (11.20/9.33 US/Imp pt.)
- Reservoir: 0.7 liters (1.48/1.23 US/Imp pt.)
- Total: 6.0 liters (12.68/10.56 US/Imp pt.)

A/T model:


- Engine, radiator and heater: 5.6 liters (11.83/9.86 US/Imp pt.)
- Reservoir: 0.7 liters (1.48/1.23 US/Imp pt.)
- Total: 6.3 liters (13.31/11.09 US/Imp pt.)

Schematic and Routing Diagram

Coolant Circulation

S7RW0C1602001


While the engine is warmed up (thermostat closed), coolant circulates as follows.



I5RW0C160001-02

1. Radiator inlet hose	3. Thermostat	5. Throttle body	7. Heater core
2. Radiator outlet hose	4. Water pump	6. Engine	8. Radiator

When coolant is warmed up to normal temperature and the thermostat opens, coolant passes through the radiator core to be cooled as follows.



I5RW0C160002-02

1. Radiator inlet hose	3. Thermostat	5. Throttle body	7. Heater core
2. Radiator outlet hose	4. Water pump	6. Engine	8. Radiator

Diagnostic Information and Procedures

Engine Cooling Symptom Diagnosis


S7RW0C1604001

Condition	Possible cause	Correction / Reference Item
Engine overheats (Radiator fan operates)	Loose or broken water pump belt	<i>Adjust or replace.</i>
	Not enough coolant	<i>Check coolant level and add as necessary.</i>
	Faulty thermostat	<i>Replace.</i>
	Faulty water pump	<i>Replace.</i>
	Dirty or bent radiator fins	<i>Clean or remedy.</i>
	Coolant leakage on cooling system	<i>Repair.</i>
	Clogged radiator	<i>Check and replace radiator as necessary.</i>
	Faulty radiator cap	<i>Replace.</i>
	Dragging brakes	<i>Adjust brake.</i>
	Slipping clutch	<i>Replace.</i>
	Poor charge battery	<i>Check and replace as necessary.</i>
	Poor generation generator	<i>Check and repair.</i>
	ECT sensor faulty	<i>Check and replace as necessary.</i>
	Radiator fan motor faulty	<i>Check and replace as necessary.</i>
	ECM faulty	<i>Check and replace as necessary.</i>
	Wiring or grounding faulty	<i>Repair as necessary.</i>
	Equipped with too much electric load part(s)	<i>Dismount.</i>
Engine overheats (Radiator fan does not operate)	Fuse blown	<i>Check 30 A fuse of relay/fuse box and check for short circuit to ground.</i>
	Radiator cooling fan relay faulty	<i>Check and replace as necessary.</i>
	ECT sensor faulty	<i>Check and replace as necessary.</i>
	Radiator cooling fan motor faulty	<i>Check and replace as necessary.</i>
	Wiring or grounding faulty	<i>Repair as necessary.</i>
	ECM faulty	<i>Check and replace as necessary.</i>

Repair Instructions

Cooling System Components

S7RW0C1606001



I7RW01160001-03

1. Radiator	9. Water outlet cap gasket	17. Radiator cooling fan assembly For disassembly and reassembly, refer to "Radiator Cooling Fan Disassembly and Reassembly".
2. Reservoir	10. O-ring	18. To cylinder head
3. Radiator cap	11. Water pump	19. To throttle body
4. Drain plug	12. Thermostat	20. To heater core
5. Radiator outlet hose	13. Thermostat cap	(a) : 12.5 N·m (1.25 kgf-m, 9.0 lb-ft)
6. Radiator inlet hose	14. Heater outlet pipe	(X) : Do not reuse.
7. Water outlet cap	15. Heater inlet hose	
8. ECT sensor	16. Heater outlet hose	

Coolant Level Check

S7RW0C1606002

⚠ WARNING

To help avoid danger of being burned, do not remove radiator cap while engine and radiator are still hot. Scalding fluid and steam can be blown out under pressure if radiator cap is taken off too soon.

To check level, lift hood and look at "see-through" coolant reservoir.

It is not necessary to remove radiator cap to check coolant level.


When engine is cool, check coolant level in reservoir (1).

A normal coolant level should be between FULL mark (2) and LOW mark (3) on reservoir (1).

If coolant level is below LOW mark (3), remove reservoir cap (4) and add proper coolant to reservoir to bring coolant level up to FULL mark (2).

NOTE

If proper quality antifreeze is used, there is no need to add extra inhibitors or additives that claim to improve system. They may be harmful to proper operation of system, and are unnecessary expense.



I6RW0C160001-01

Engine Cooling System Inspection and Cleaning

S7RW0C1606003

⚠ WARNING

To help avoid danger of being burned, do not remove radiator cap while engine and radiator are still hot. Scalding fluid and steam can be blown out under pressure if cap is taken off too soon.



- 1) Check cooling system for leakage or damage.
- 2) Wash radiator cap and filler neck with clean water by removing radiator cap when engine is cold.
- 3) Check coolant for proper level and freeze protection.
- 4) Using a pressure tester (1), check system and radiator cap (2) for proper pressure holding capacity. If replacement of cap is required, use a proper cap for this vehicle.

NOTE

After installing radiator cap to radiator, make sure that the ear of cap lines is parallel to radiator.

Cooling system and radiator cap holding pressure (for inspection)

110 kPa (1.1 kgf/cm², 15.6 psi)



I5RH01160001-01

- 5) Tighten hose clamps and inspect all hoses. Replace hoses whenever cracked, swollen or otherwise deteriorated.

- 6) Clean frontal area of radiator core.


Cooling System Draining

S7RW0C1606004

⚠ WARNING

To help avoid danger of being burned, do not remove radiator cap while engine and radiator are still hot. Scalding fluid and steam can be blown out under pressure if cap is taken off too soon.

- 1) Remove radiator cap.
- 2) Drain coolant from radiator drain plug (1).
- 3) After draining coolant, be sure to tighten drain plug (1) securely.



I4RS0A160003-01

Cooling System Flush and Refill

S7RW0C1606005


⚠ WARNING

To help avoid danger of being burned, do not remove radiator cap while engine and radiator are still hot. Scalding fluid and steam can be blown out under pressure if cap is taken off too soon.

NOTE


For detail of coolant specification, refer to "Coolant Description".

- 1) Remove radiator cap when engine is cool as follows.
 - a) Turn cap counterclockwise slowly until it reaches a "stop" (Do not press down while turning it).
 - b) Wait until pressure is relieved (indicated by a hissing sound) then press down on cap and continue to turn it counterclockwise.
- 2) With radiator cap removed, run engine until upper radiator hose is hot (this shows that thermostat is open and coolant is flowing through system).
- 3) Stop engine and drain coolant from radiator drain plug (1).
- 4) Close radiator drain plug. Add water until system is filled and run engine until upper radiator hose is hot again.
- 5) Repeat Steps 3) and 4) several times until drained liquid is nearly colorless.
- 6) Close radiator drain plug (1) tightly.



I4RS0A160003-01

- 7) Remove reservoir cap (2) and reservoir (1).
- 8) Pour out any fluid, scrub and clean inside of reservoir with soap and water. Flush it well with clean water and drain. Reinstall reservoir.
- 9) Fill reservoir with coolant up to "FULL" level mark (3).
- 10) Install reservoir cap (2) on reservoir.
- 11) Fill radiator with coolant up to bottom of radiator filler neck and install radiator cap, making sure that the ear of cap lines is parallel to radiator.
- 12) Run engine at idle speed.
- 13) Run engine until radiator fan motor is operated.
- 14) Stop engine and wait until engine comes cooled down to help avoid danger of being burned.
- 15) Add coolant to radiator up to bottom of radiator filler neck, and install radiator cap, making sure that the ear of cap lines is parallel to radiator.
- 16) Repeat Step 12) through 15).
- 17) Confirm that reservoir coolant level is "FULL" level mark (3). If coolant is insufficient, repeat Step 9) and 10).



I6RW0C160002-01

Cooling Water Pipes or Hoses Removal and Installation

S7RW0C1606006

Removal

- 1) Drain coolant.
- 2) To remove these pipes or hoses, loosen clamp on each hose and pull hose end off.

Installation

Install removed parts in reverse order of removal procedure, noting the following.


- Tighten each clamp securely referring to "Cooling System Components".
- Refill cooling system referring to Step 6) to 17) of "Cooling System Flush and Refill".

Thermostat Removal and Installation

S7RW0C1606007

Removal

- 1) Drain coolant.
- 2) Disconnect radiator outlet hose from thermostat cap (1).
- 3) Remove thermostat cap (1) from water pump (2).
- 4) Remove thermostat from water pump (2).




I5JB0A161009-01

Installation

Reverse removal procedure for installation noting the following points.

- When positioning thermostat (1) on water pump case, be sure to position it so that air bleed valve (2) comes at match mark (3) and into the recession of water pump case.




I2RH01160010-01

- Use new O-ring when installing.
- Refill cooling system referring to Step 9) to 17) of "Cooling System Flush and Refill".
- Verify that there is no coolant leakage at each connection.

Thermostat Inspection

S7RW0C1606008

- Make sure that air bleed valve (1) of thermostat is clean.
- Check to make sure that valve seat (2) is free from foreign matters which would prevent valve from seating tight.
- Check thermostat seal (3) for breakage, deterioration or any other damage.



I3RM0A160008-01

- Check thermostatic movement of wax pellet as follows:
 - a. Immerse thermostat (1) in water, and heat water gradually.
 - b. Check that valve starts to open at specific temperature.

Temperature at which valve begins to open

80 – 84 °C (176 – 183 °F)


Temperature at which valve become fully open

95 – 97 °C (203 – 206 °F)

Valve lift

More than 8 mm (0.31 in.) at 95 °C (203 °F)

If valve starts to open at a temperature substantially below or above specific temperature, thermostat unit should be replaced with a new one. Such a unit, if reused, will bring about overcooling or overheating tendency.



I2RH01160012-01


2. Thermometer

3. Heater

Radiator Cooling Fan Assembly Inspection


S7RW0C1606009

- 1) Check continuity between each terminals. If there is no continuity, replace radiator fan assembly.



I7RW01160002-02

- 2) Connect battery to radiator fan motor connector as shown in figure, then check that the radiator fan motor operates smoothly, fan speed varies and that specified current. If radiator fan motor does not operate smoothly, replace radiator fan assembly.

Reference: Fan motor specified current at 12 V**LOW: 4.8 – 7.8 A****HIGH: 7.4 – 10.9 A**

I7RW01160003-01



[A]: LOW

[B]: HIGH

Radiator Cooling Fan Relay Inspection

S7RW0C1606010

- 1) Disconnect negative (–) cable at battery.
- 2) Remove radiator cooling fan relay No.1 (1), No.2 (2) and/or No.3 (3) from relay box.
- 3) Check radiator cooling fan relays as follows.
 - a) Check that there is no continuity between terminals “C” and “D”. If there is continuity, replace relay.
 - b) Connect battery positive (+) terminal to terminal “B” of relay.
 - c) Connect battery negative (–) terminal to terminal “A” of relay.
 - d) Check continuity between terminals “C” and “D”. If there is no continuity, replace relay.



I7RW01160004-01

Radiator Cooling Fan Assembly Removal and Installation


S7RW0C1606011

⚠ CAUTION

Never disassemble radiator cooling fan. Disassembly will spoil its original function. If faulty condition is found, replace it with new one as an assembly.

Removal


- 1) Disconnect negative (–) cable at battery.
- 2) Disconnect connector (1) of cooling fan motor.
- 3) Drain coolant referring to “Cooling System Draining”.
- 4) Remove radiator inlet hose (2), reservoir (3), air suction hose (4) and air cleaner suction pipe (5).



I7RW01160005-02

1F-9 Engine Cooling System:

- 5) Remove cooling fan mounting bolts (1).
- 6) Remove radiator cooling fan assembly (2).



I7RW01160006-01

Installation

Reverse removal procedure for installation noting the following.


- Refill cooling system referring to Step 9) to 17) of “Cooling System Flush and Refill”.
- After installation, verify there is no coolant leakage at each connection.

Radiator Cooling Fan Disassembly and Reassembly

S7RW0C1606012

Disassembly

- 1) Remove fan (1) from cooling fan motor (2).
- 2) Remove fan motor (2) from cooling fan guide (3).



I5RW0C160005-01

Reassembly

Reverse disassembly procedures for reassembly.

Radiator On-Vehicle Inspection and Cleaning


S7RW0C1606013

Inspection

Check radiator for leakage or damage. Straighten bent fins, if any.

Cleaning

Clean frontal area of radiator cores.



I2RH01160014-01

Radiator Removal and Installation

S7RW0C1606014

Removal

- 1) Disconnect negative (–) cable at battery.
- 2) Drain coolant referring to “Cooling System Draining”.
- 3) Remove front bumper referring to “Front Bumper and Rear Bumper Components in Section 9K”.
- 4) Drain A/T fluid.
- 5) Remove A/T fluid cooler inlet and outlet hoses.
- 6) Remove cooling fan assembly referring to “Radiator Cooling Fan Assembly Removal and Installation”.
- 7) Remove condenser cooling fan referring to “Condenser Cooling Fan Removal and Installation: Manual Type in Section 7B”.
- 8) Remove radiator outlet hose from radiator.
- 9) Fix condenser to body with rope in order to avoid the condenser fall off when remove radiator.
- 10) Remove radiator from vehicle.

Installation

Reverse removal procedures, noting the following.


- Refill cooling system referring to Step 9) to 17) of “Cooling System Flush and Refill”.
- Refill A/T fluid referring to “A/T Fluid Change in Section 5A”.
- After installation, verify there is no coolant leakage each connection.

Water Pump Removal and Installation

S7RW0C1606015

Removal

- 1) Disconnect negative (–) cable at battery.
- 2) Drain coolant referring to “Cooling System Draining”.
- 3) Remove water pump and generator drive belt referring to “Water Pump and Generator Drive Belt Removal and Installation in Section 1J”.
- 4) Remove front bumper referring to “Front Bumper and Rear Bumper Components in Section 9K”.
- 5) Remove exhaust manifold referring to “Exhaust Manifold Removal and Installation in Section 1K”.
- 6) Remove heater pipe (2) from water pump and cylinder block.
- 7) Remove thermostat referring to “Thermostat Removal and Installation”.
- 8) Remove water pump (1) from cylinder block (3).



I5JB0A161016-01

Installation

Reverse removal procedure for installation noting the following points.

- Use new O-ring when installing.
- Install water pump assembly to cylinder block and tighten bolts to specified torque.

Tightening torque**Water pump bolt: 25 N·m (2.5 kgf-m, 18.0 lb-ft)**


- Refill cooling system referring to Step 9) to 17) of “Cooling System Flush and Refill”.
- Verify that there is no coolant leakage at each connection.

Water Pump Inspection

S7RW0C1606016

⚠ CAUTION**Do not disassemble water pump.****If any repair is required on pump, replace it as assembly.**

Rotate water pump by hand to check for smooth operation. If pump does not rotate smoothly or makes abnormal noise, replace it.



I2RH0B160019-01

Specifications**Tightening Torque Specifications**

S7RW0C1607001

Fastening part	Tightening torque			Note
	N·m	kgf-m	lb-ft	
Water pump bolt	25	2.5	18.0	⌚

NOTE

The specified tightening torque is also described in the following.
“Cooling System Components”

Reference:

For the tightening torque of fastener not specified in this section, refer to “Fasteners Information in Section 0A”.

Fuel System

Precautions

Precautions on Fuel System Service

S7RW0C1700001

⚠ WARNING

Before attempting service of any type on fuel system, the following should be always observed in order to reduce the risk of fire and personal injury.

- Disconnect negative cable at battery.
- Do not smoke, and place no smoking signs near work area.
- Be sure to have CO₂ fire extinguisher handy.
- Be sure to perform work in a well-ventilated area and away from any open flames (such as gas hot heater).
- Wear safety glasses.
- To relieve fuel vapor pressure in fuel tank, remove fuel filler cap from fuel filler neck and then reinstall it.
- As fuel feed line is still under high fuel pressure even after stopping engine, loosening or disconnecting fuel feed line directly may cause dangerous spout of fuel. Before loosening or disconnecting fuel feed line, make sure to relieve fuel pressure referring to “Fuel Pressure Relief Procedure”.
- A small amount of fuel may be released when the fuel line is disconnected. In order to reduce the risk of personal injury, cover a shop cloth to the fitting to be disconnected. Be sure to put that cloth in an approved container after disconnecting.
- Never run engine with fuel pump relay disconnected when engine and exhaust system are hot.
- Note that fuel hose connection varies with each type of pipe. Be sure to connect and clamp each hose correctly referring to “Fuel Hose Disconnecting and Reconnecting”. After connecting, make sure that it has no twist or kink.
- When installing injector or fuel feed pipe, lubricate its O-ring with gasoline.
- When servicing the fuel tank, it should be treated with respect, with no contact with sharp edges or hot surfaces. In addition, the fuel tank should not be dropped since fuel tank, fuel pump and other components can be damaged by the impact. If dropped, all components should be replaced because there is a risk of damage.

General Description

Fuel System Description

S7RW0C1701001

⚠ CAUTION

This engine requires the unleaded fuel only. The leaded and/or low lead fuel can result in engine damage and reduce the effectiveness of the emission control system.

The main components of the fuel system are fuel tank, fuel pump assembly (with fuel filter, fuel level gauge, fuel pressure regulator), fuel feed line and fuel vapor line. For the details of fuel flow, refer to “Fuel Delivery System Diagram”.

Fuel Delivery System Description

S7RW0C1701002

The fuel delivery system consists of the fuel tank, fuel pump assembly (with built-in fuel filter and fuel pressure regulator), delivery pipe, injectors and fuel feed line.

The fuel in the fuel tank is pumped up by the fuel pump, sent into delivery pipe and injected by the injectors.

As the fuel pump assembly is equipped with built-in fuel filter and fuel pressure regulator, the fuel is filtered and its pressure is regulated before being sent to the feed pipe.

The excess fuel at fuel pressure regulation process is returned back into the fuel tank.


Also, fuel vapor generated in fuel tank is led through the fuel vapor line into the EVAP canister.

For system diagram, refer to “Fuel Delivery System Diagram”.

Fuel Pump Description

S7RW0C1701003

The fuel pump (1) is an in-tank type electric pump. Incorporated in the pump assembly are; a fuel filter (2), a fuel pressure regulator (3) and a fuel level sensor (gauge) (4).




I7RW01170001-01

Schematic and Routing Diagram

Fuel Delivery System Diagram

S7RW0C1702001



I7RW01170002-02

1. Fuel tank	4. Delivery pipe	7. Fuel filter
2. Fuel pump assembly	5. Fuel injector	8. Fuel level sensor (gauge)
3. Fuel pressure regulator	6. Fuel feed line	9. Fuel pump

Diagnostic Information and Procedures

Fuel Pressure Inspection

S7RW0C1704001

⚠ WARNING

Before starting the following procedure, be sure to observe "Precautions on Fuel System Service" in order to reduce the risk of fire and personal injury.


- 1) Relieve fuel pressure in fuel feed line referring to "Fuel Pressure Relief Procedure".
- 2) Disconnect fuel feed hose from fuel delivery pipe.
- 3) Connect special tools and hose between fuel feed hose (1) and fuel delivery pipe as shown in figure, and clamp hoses securely in order to ensure that no leaks occur during checking.

Special tool

(A): 09912-58442

(B): 09912-58432

(C): 09912-58490



I7RW01170003-01

1G-3 Fuel System:

- 4) Check that battery voltage is 11 V or more.
- 5) Measure fuel pressure at each condition.
If measured pressure is out of specification, refer to "Fuel Pressure Check in Section 1A" and check each possibly defective part. Replace if found defective.
 - a) Turn ignition switch ON to operate fuel pump and after 2 seconds turn it OFF. Repeat this 3 or 4 times and then check fuel pressure.

Fuel pressure specification

With fuel pump operating and engine stopped: 360 – 400 kPa (3.6 – 4.0 kgf/cm², 51.2 – 56.9 psi)

- b) Start engine and warm it up to normal operating temperature, and measure fuel pressure at idling.

Fuel pressure specification

At specified idle speed: 360 – 400 kPa (3.6 – 4.0 kgf/cm², 51.2 – 56.9 psi)

- c) Stop engine, and measure fuel pressure at one minute after stopping.

Fuel pressure specification


With 1 min. after engine (fuel pump) stop (Pressure reduces as time passes): Over 250 kPa (2.5 kgf/cm², 35.6 psi)

- 6) After checking fuel pressure, remove fuel pressure gauge.

⚠ WARNING

As fuel feed line is still under high fuel pressure, make sure to release fuel pressure according to the following procedures.

- Place fuel container under joint.
- Cover joint with rag (1) and loosen joint nut slowly in order to release fuel pressure gradually.



I5RW0A170003-01

- 7) Remove special tools from fuel delivery pipe and fuel feed hose.
- 8) Connect fuel feed hose to fuel delivery pipe and clamp it securely.
- 9) With engine OFF and ignition switch ON, check for fuel leaks.


Fuel Cut Operation Inspection

S7RW0C1704002

NOTE

Before inspection, make sure that gear shift lever is in neutral position (shift select lever is "P" range for A/T vehicle), A/C is OFF and parking brake lever is pulled all the way up.

- 1) Warm engine up to normal operating temperature.
- 2) While listening to sound of injector (2) by using sound scope (1) or such, increase engine speed to higher than 3,000 r/min.



I2RH0B170004-01

- 3) Check to make sure that injector operation sound is stop when throttle valve is closed instantly and it is heard again when engine speed is reduced to approx. 2,000 r/min or less.



1G-5 Fuel System:

8. Delivery pipe bolt	18. Cushion	⊗ : Do not reuse.
9. Fuel tank bolt	19. Grommet	

Fuel Hose Disconnecting and Reconnecting

S7RW0C1706002

⚠ WARNING



Before starting the following procedure, be sure to observe “Precautions on Fuel System Service” in order to reduce the risk of fire and personal injury.

Connection Other Than Quick Joint

- Clamp around fuel tank

NOTE


Be sure to install hose to spool of pipe surely.



I7RW01170005-01

[A]: Connection A	"b": 30 mm (1.18 in.)	1. Pipe
[B]: Connection B	"c": 38 mm (1.50 in.)	2. Hose
[C]: Connection C	"d": 5 – 12 mm (0.20 – 0.48 in.)	3. Clamp
[D]: Connection D	"e": 7 – 14 mm (0.28 – 0.55 in.)	⊗(a) : 1.5 N·m (0.15 kgf·m, 1.0 lb·ft)
"a": 3 – 7 mm (0.12 – 0.28 in.)	"f": 2 mm (0.08 in.)	

Clamp other than around fuel tank



I7RW01170007-01

[A]:	With short pipe, fit hose as far as it reaches pipe joint as shown.
[B]:	With the following type pipe, fit hose as far as its peripheral projection as shown.
[C]:	With bent pipe, fit hose as its bent part as shown or till depth "b".
[D]:	With straight pipe, fit hose till depth "b".
[E]:	With red marked pipe, fit hose end reaches red mark on pipe.
"a":	Clamp securely at a position 3 – 7 mm (0.12 – 0.27 in.) from hose end.
"b":	20 – 30 mm (0.79 – 1.18 in.)
"c":	0 – 5 mm (0 – 0.19 in.)
4.	Red mark

Quick Joint


Disconnecting

- 1) Remove mud, dust and/or foreign material between pipe (1) and quick joint (2) by blowing compressed air.
- 2) Unlock joint lock by inserting special tool between pipe and quick joint.

Special tool

(A): 09919-47020

- 3) Disconnect quick joint from pipe.



I4RS0A170019-01

Reconnecting

Insert quick joint to fuel pipe until they lock securely (a click is heard), and confirm that quick joint is not disconnected by hand.

Fuel Pressure Relief Procedure

S7RW0C1706003


⚠ CAUTION

This work must not be done when engine is hot. If done so, it may cause adverse effect to catalyst.

NOTE

If ECM detects DTC(s) after servicing, clear DTC(s) referring to “DTC Clearance in Section 1A”.

- 1) Make sure that engine is cold.
- 2) Shift transaxle gear shift lever in “Neutral” (shift select lever in “P” range for A/T model), set parking brake and block drive wheels.
- 3) Remove relay / fuse box cover.
- 4) Disconnect fuel pump relay (1) from relay / fuse box (2).
- 5) Remove fuel filler cap in order to release fuel vapor pressure in fuel tank, and then reinstall it.
- 6) Start engine and run it until engine stops for lack of fuel. Repeat cranking engine 2 – 3 times for about 3 seconds each time in order to dissipate fuel pressure in lines. Fuel connections are now safe for servicing.
- 7) After servicing, connect fuel pump relay (1) to relay / fuse box and install relay / fuse box cover.



I5RW0A170007-01

Fuel Leakage Check Procedure

S7RW0C1706004

After performing any service on fuel system, check to make sure that there are no fuel leakages as follows.

- 1) Turn ON ignition switch for 3 seconds (to operate fuel pump) and then turn it OFF.
Repeat this (ON and OFF) 3 or 4 times and apply fuel pressure to fuel line until fuel pressure is felt by hand placed on fuel feed hose.
- 2) In this state, check to see that there are no fuel leakages from any part of fuel system.


Fuel Tank, Cap Gasket and Fuel Line Inspection

S7RW0C1706005

⚠ CAUTION

Due to the fact that fuel feed line is under high pressure, use special care when servicing it.

- Check fuel filler cap (1) and fuel lines for loose connection, deterioration or damage which could cause leakage. Make sure all clamps are secure.
- Check fuel tank for damage, cracks, fuel leakage, corrosion and tank bolt looseness.
- Check fuel filler cap gasket (2) for an even filler neck imprint or any damage.
- Replace any damaged or deteriorated parts.
There should be no sign of fuel leakage or moisture at any fuel connection.



I7RW01020001-01

Fuel Pipe Removal and Installation

S7RW0C1706006

⚠ WARNING

Before starting the following procedure, be sure to observe "Precautions on Fuel System Service" in order to reduce the risk of fire and personal injury.


Removal

- 1) Relieve fuel pressure in fuel feed line according to "Fuel Pressure Relief Procedure".
- 2) Disconnect negative (–) cable at battery.
- 3) Disconnect fuel hose (3) from fuel pipe (2) at the front and rear of each fuel pipe referring to "Fuel Hose Disconnecting and Reconnecting".
- 4) Mark the location of clamps (1) on fuel pipes (2), so that the clamps can be reinstalled to where they were.
- 5) Remove clamps (1) from vehicle body, fuel pipes and brake pipes.

⚠ CAUTION

Be careful not to bent and damage fuel pipes and brake pipes when removing clamp.

- 6) Remove fuel pipe (2).



I5RW0A170009-01


Installation

- 1) Install clamps to marked location on pipes. If clamp is deformed, its claw is bent or broken, replace it with new one.
- 2) Install pipes with pipe clamps to vehicle.
- 3) Connect fuel hoses and pipes to each pipe referring to "Fuel Hose Disconnecting and Reconnecting".
- 4) Connect negative cable at battery.
- 5) With engine OFF, turn ignition switch to ON position and check for fuel leaks.

Fuel Injector On-Vehicle Inspection

S7RW0C1706007

- 1) Using sound scope (1) or such, check operating sound of injector (2) when engine is running or cranking.
Cycle of operating sound should vary according to engine speed.
If no sound or an unusual sound is heard, check injector circuit (wire or connector) or injector.




I2RH0B170007-01

- 2) Disconnect connector (1) from injector, connect ohmmeter between terminals of injector and check resistance.
If resistance is out of reference value greatly, replace.

Reference resistance of fuel injector

12.0 Ω at 20 °C, 68 °F



I2RH0B170008-01

- 3) Connect connector to injector securely.

Fuel Injector Removal and Installation


S7RW0C1706008

⚠ WARNING

Before starting the following procedure, be sure to observe "Precautions on Fuel System Service" in order to reduce the risk of fire and personal injury.

Removal

- 1) Relieve fuel pressure according to "Fuel Pressure Relief Procedure".
- 2) Disconnect negative cable at battery.
- 3) Remove air cleaner case and air suction hose referring to "Air Cleaner Assembly Removal and Installation in Section 1D".
- 4) Disconnect fuel injector connector.
- 5) Disconnect fuel feed hose (4) from fuel delivery pipe (1).
- 6) Remove fuel delivery pipe bolts (2).
- 7) Remove fuel injector(s) (3).




Installation

Reverse removal procedure for installation noting the following.

- Replace injector O-ring (1) with new one using care not to damage it.
- Check if cushion (2) is scored or damaged. If it is, replace with new one.
- Apply thin coat of fuel to O-rings (1), and then install injectors (3) into delivery pipe (4) and cylinder head. Make sure that injectors rotate smoothly (6). If not, probable cause is incorrect installation of O-ring. Replace O-ring with new one.
- Tighten delivery pipe bolts (5) to specified torque and make sure that injectors rotate smoothly.

Tightening torque

Fuel delivery pipe bolt (a): 25 N·m (2.5 kgf-m, 18.0 lb-ft)



- After installation, with engine OFF and ignition switch ON, check for fuel leaks around fuel line connection.

Fuel Injector Inspection

S7RW0C1706009

⚠ WARNING

- Before starting the following procedure, be sure to observe "Precautions on Fuel System Service" in order to reduce the risk of fire and personal injury.
- Put injector and battery as far away as possible in order to reduce risk of fire and personal injury when connecting/disconnecting test lead to/from battery.

- 1) Relieve fuel pressure according to "Fuel Pressure Relief Procedure" if equipped.
- 2) Disconnect fuel feed hose from delivery pipe.
- 3) Set special tools as follows.


Special tool

(A): 09912-58421

(B): 09930-88530

(C): 09912-57610

- a) Fit washer (1) (inside diameter 13.5 – 14.5 mm (0.532 – 0.570 in.)) to injector (2), and then install injector to special tool (A).
- b) Connect special tool (B) to injector.
- c) Install special tool (C) to special tool (A).
- d) Connect fuel feed hose to special tool (A).




I6RW0B170014-01

- 4) Install suitable vinyl tube onto injector nozzle to prevent fuel from splashing out when injecting.
- 5) Put graduated cylinder under injector.
- 6) Operate fuel pump and apply fuel pressure to injector as follows:
 - a) When using scan tool:
 - i) Connect scan tool to DLC with ignition switch OFF.
 - ii) Turn ignition switch ON, clear DTC and select "Active Test" mode on scan tool.
 - iii) Turn fuel pump ON by using scan tool.

Special tool

(A): SUZUKI scan tool (SUZUKI-SDT)




I5RW0C110011-01

- b) When not using scan tool:
 - i) Remove fuel pump relay from connector.
 - ii) Connect two terminals of relay connector using service wire (1) as shown in figure.

⚠ CAUTION

Check to make sure that connection is made between correct terminals. Wrong connection can cause damage to ECM, wire harness, etc.

- iii) Turn ignition switch ON.



I5RW0A170011-02

- 7) Apply battery voltage to injector (1) for 15 seconds and measure injected fuel volume with graduated cylinder. Test each injector two or three times. If injected volume is out of reference value greatly, replace injector.


Reference injected fuel volume

Approx. 65 cc/15 sec. (2.20/2.29 US/Imp oz/15 sec.)

- 8) Check fuel leakage from injector nozzle. Do not operate injector for this check (but fuel pump should be at work). If fuel leaks (1) more than the following specifications, replace.

Fuel leakage

Less than 1 drop/min.



I2RH0B170013-01

- 9) Remove injector from special tool (A) and disconnect special tool (B) from injector.

⚠ CAUTION

As fuel feed line is still under high fuel pressure even after inspection, removing injector directly may cause dangerous spout of fuel. Before removing injector, make sure to relieve fuel pressure as follows.

- 1. Stop operation of fuel pump.**
- 2. Put graduated cylinder under injector.**
- 3. Apply battery voltage to injector until no fuel is injected from injector.**

- 10) Carry out Steps 3) through 9) on each injector to obtain 4 readings.
- 11) After checking, disconnect fuel feed hose from special tool (A) and remove special tool (B).
- 12) Connect fuel feed hose to delivery pipe.

Fuel Filler Cap Inspection

S7RW0C1706010


⚠ WARNING

Before starting the following procedure, be sure to observe "Precautions on Fuel System Service" in order to reduce the risk of fire and personal injury.

Remove cap (1), and check gasket for even filler neck imprint, and deterioration or any damage. If gasket (2) is in malcondition, replace cap.

NOTE

If cap requires replacement, only a cap with the same features should be used. Failure to use correct cap can result in fire and personal injury.



I2RH01170008-01

Fuel Tank Inlet Valve Removal and Installation

S7RW0C1706011

⚠ WARNING


Before starting the following procedure, be sure to observe "Precautions on Fuel System Service" in order to reduce the risk of fire and personal injury.

Removal

- 1) Remove fuel tank referring to "Fuel Tank Removal and Installation".
- 2) Remove fuel tank inlet valve (1) using flat head rod (2) or the like.

⚠ CAUTION


Be careful not to damage fuel tank inlet valve (1) with flat head rod (2) or the like.



I7RW01170013-01

Installation

- 1) Install fuel tank inlet valve (1) to fuel tank.



I2RH0B170018-01

- 2) Install fuel tank referring to "Fuel Tank Removal and Installation".

Fuel Tank Inlet Valve Inspection


S7RW0C1706012

⚠ WARNING

Before starting the following procedure, be sure to observe "Precautions on Fuel System Service" in order to reduce the risk of fire and personal injury.

Check fuel tank inlet valve for the following. If any damage or malfunction is found, replace.

- Damage
- Smooth opening and closing



I2RH0B170019-01

Fuel Tank Removal and Installation

S7RW0C1706013

⚠ WARNING


Before starting the following procedure, be sure to observe "Precautions on Fuel System Service" in order to reduce the risk of fire and personal injury.

Removal

- 1) Relieve fuel pressure in fuel feed line according to "Fuel Pressure Relief Procedure".
- 2) Disconnect negative cable at battery.
- 3) Remove fuel filler cap.
- 4) Insert hose of a hand operated pump into fuel filler hose (1) and drain fuel in space "A" as shown in figure.

⚠ CAUTION

Do not force pump hose into fuel tank.




I4RS0B170022-01

2. Inlet check valve

1G-13 Fuel System:

- 5) Hoist vehicle, and remove clamp (2), fuel filler hose (1) and breather hose (3) from fuel filler neck.




I7RW01170014-01

- 6) Remove EVAP canister referring to “EVAP Canister Removal and Installation in Section 1B”.
- 7) Remove exhaust center pipe referring to “Exhaust Pipe and Muffler Removal and Installation in Section 1K”.
- 8) Remove propeller shaft (4WD model) referring to “Propeller Shaft Assembly Removal and Installation in Section 3D”.
- 9) Due to absence of fuel tank drain plug, drain fuel tank by pumping fuel out through fuel tank filler. Use hand operated pump device to drain fuel tank.

⚠ CAUTION


- Do not force pump hose into fuel tank.
- Never store fuel in an open container due to possibility of fire or explosion.

- 10) Disconnect quick joint (1) from fuel pipes (2) referring to “Fuel Hose Disconnecting and Reconnecting”.




I5RW0A170014-02

- 11) Support fuel tank (1) with jack (2) and remove its mounting bolts (3).



I5RW0A170013-01

- 12) Lower fuel tank a little as to disconnect wire harness at connector (1) and ground wire (2), then remove fuel tank.



I7RW01170009-01

Installation

⚠ CAUTION

- When connecting joint, clean outside surfaces of pipe where joint is to be inserted, push joint into pipe till joint lock clicks and check to ensure that pipes are connected securely, or fuel leak may occur.
- Never let the fuel hoses touch the wheel speed sensor harness (if equipped).

- 1) If parts have been removed from fuel tank, install them before installing fuel tank to vehicle.
- 2) Raise fuel tank (1) with jack (2) and connect fuel pump connector (3), ground wire (4) and clamp wire harness.


Tightening torque

Ground wire bolt (a): 11 N·m (1.1 kgf-m, 8.0 lb-ft)

- 3) Install fuel tank to vehicle, and tighten new fuel tank bolts to specified torque.

Tightening torque

Fuel tank bolt (b): 45 N·m (4.5 kgf-m, 33.0 lb-ft)




I7RW01170010-01

- 4) Connect fuel filler hose (1) and breather hose (2) to filler neck (3) as shown in figure, and clamp them securely.


Tightening torque

Fuel tank hose clamp (a): 1.5 N·m (0.15 kgf-m, 1.0 lb-ft)



I6RW0C170003-01

- 5) Connect fuel feed hose (1) and vapor hose (2) to each pipe as shown in figure, and clamp them securely.



I5RW0A170018-01

- 6) Install exhaust center pipe referring to "Exhaust Pipe and Muffler Removal and Installation in Section 1K".
- 7) Install propeller shaft (4WD model) referring to "Propeller Shaft Assembly Removal and Installation in Section 3D".
- 8) Install EVAP canister referring to "EVAP Canister Removal and Installation in Section 1B".
- 9) Connect negative (–) cable at battery.
- 10) With engine OFF, turn ignition switch to ON position and check for fuel leaks.

Fuel Tank Inspection

S7RW0C1706014

After removing fuel tank, check hoses and pipes connected to fuel tank for leaks, loose connections, deterioration or damage. Also check fuel pump assembly gaskets for leaks, visually inspect fuel tank for leaks and damage.

Replace any damaged or malfunctioned parts.

Fuel Tank Purging Procedure

S7RW0C1706015

⚠ WARNING

- Before starting the following procedure, be sure to observe "Precautions on Fuel System Service" in order to reduce the risk of fire and personal injury.
- This purging procedure will not remove all fuel vapor.
Do not attempt any repair on tank using heat of flame as an explosion resulting in personal injury could occur.

⚠ CAUTION

Never remain water in fuel tank after washing, or fuel tank inside will get corrosion.

The following procedure are used for purging fuel tank.

- 1) After removing fuel tank, remove all hoses, pipes and fuel pump assembly from fuel tank.
- 2) Drain all remaining fuel from tank.
- 3) Place fuel tank to flushing area.
- 4) Fill tank with warm water or tap water, and agitate vigorously and drain. Repeat this washing until inside of tank is clean. Replace tank if its inside is rusty.
- 5) Completely flush out remaining water after washing.
- 6) Be sure to dry fuel tank assembly thoroughly out of direct sunlight after washing.

Fuel Pump On-Vehicle Inspection

S7RW0C1706016


⚠ WARNING

Before starting the following procedure, be sure to observe "Precautions on Fuel System Service" in order to reduce the risk of fire and personal injury.

NOTE


The fuel pressure regulator is incorporated with the fuel pump assembly so individual inspection of it is impossible.

- 1) Remove filler cap and turn ON ignition switch (2). Then fuel pump operating sound should be heard from fuel filler (1) for about 2 seconds and stop. Be sure to reinstall fuel filler cap after checking. If the check result is not satisfactory, go to "Fuel Pump and Its Circuit Check in Section 1A".



IVSY01170013-01

- 2) Turn OFF ignition switch and leave over 10 minutes as it is.
- 3) Fuel pressure should be felt at fuel feed hose (1) for about 2 seconds after ignition switch ON. If fuel pressure is not felt, go to "Fuel Pressure Check in Section 1A".



I5RW0A170019-01

Fuel Filter Replacement


S7RW0C1706017

⚠ WARNING

This work must be performed in a well ventilated area and away from any open flames (such as gas hot water heaters).

Fuel filter (1) is installed in fuel pump assembly (2) in fuel tank.

Replace fuel pump assembly with new one periodically, referring to for "Fuel Pump Assembly Removal and Installation" removal and installation.



I2RH01020012-01

Fuel Pump Assembly Removal and Installation


S7RW0C1706018

⚠ WARNING

Before starting the following procedure, be sure to observe "Precautions on Fuel System Service" in order to reduce the risk of fire and personal injury.

Removal

- 1) Remove fuel tank from vehicle. Refer to "Fuel Tank Removal and Installation".
- 2) Disconnect fuel pipe (1) from fuel pump assembly (2) referring to "Fuel Hose Disconnecting and Reconnecting".



I7RW01170011-01


- 3) Remove fuel pump assembly and earth bracket from fuel tank.

Installation

⚠ CAUTION

When connecting joint, clean outside surface of pipe where joint is to be inserted, push joint into pipe till joint lock clicks and check to ensure that pipes are connected securely, or fuel leak may occur.

- 1) Clean mating surfaces of fuel pump assembly (1) and fuel tank.
- 2) Put plate (2) on fuel pump assembly (1) by matching the protrusion of fuel pump assembly (3) to plate hole (4) as shown.




I5JB0A171025-01

- 3) Install new gasket (2), fuel pump assembly (1) and earth bracket (5) with plate (3) to fuel tank (4).


Tightening torque

Fuel pump assembly bolt (a): 11 N·m (1.1 kgf-m, 8.0 lb-ft)



I7RW01170012-01

- 4) Connect fuel feed pipe (1) to fuel pump assembly (2).



I7RW01170011-01


- 5) Install fuel tank to vehicle. Refer to "Fuel Tank Removal and Installation".

Main Fuel Level Sensor Removal and Installation

S7RW0C1706019

⚠ CAUTION


- Do not touch resister plate (1) and deform arm (2). It may cause main fuel level sensor to fail.
- Be very careful not to cause damage to fuel tube installed section (sealed section in bore). If it be damaged, replace it with new one, or fuel will leak from the part.



I4RS0A170016-01

Removal

- 1) Remove fuel pump assembly from fuel tank referring to "Fuel Pump Assembly Removal and Installation".
- 2) Disconnect main fuel level sensor connector (3).
- 3) With pressing snap-fit part (2), remove main fuel level sensor (1) by sliding it in the arrow direction as shown in figure.



I5JB0A171026-01


Installation

Reverse removal procedure for installation.

Fuel Pump Inspection

S7RW0C1706020

- Check fuel pump assembly for damage.
- Check fuel suction filter for evidence of dirt and contamination.
If present, replace or clean and check for presence of dirt in fuel tank.
- For electrical circuit, refer to "Fuel Pressure Check in Section 1A".
- For inspection of main fuel level sensor (1), refer to "Fuel Level Sensor Inspection in Section 9C".



I5JB0A171027-01

Specifications

Tightening Torque Specifications

S7RW0C1707001

Fastening part	Tightening torque			Note
	N·m	kgf-m	lb-ft	
Fuel delivery pipe bolt	25	2.5	18.0	☞
Ground wire bolt	11	1.1	8.0	☞
Fuel tank bolt	45	4.5	33.0	☞
Fuel tank hose clamp	1.5	0.15	1.0	☞
Fuel pump assembly bolt	11	1.1	8.0	☞

NOTE

The specified tightening torque is also described in the following.

“Fuel System Components”

“Fuel Hose Disconnecting and Reconnecting”








Reference:

For the tightening torque of fastener not specified in this section, refer to “Fasteners Information in Section 0A”.

Special Tools and Equipment

Special Tool

S7RW0C1708001

09912-57610 Injector checking tool plate 	09912-58421 Checking tool set This kit includes the following items. 1. Tool body and washer, 2. Body plug, 3. Body attachment-1, 4. Holder, 5. Return hose and clamp, 6. Body attachment-2 and washer, 7. Hose attachment-1, 8. Hose attachment-2 ☞ 
09912-58432 Fuel pressure gauge hose This tool is included in fuel pressure gauge set (09912-58413). ☞ 	09912-58442 Fuel pressure gauge This tool is included in fuel pressure gauge set (09912-58413). ☞ 
09912-58490 3-way joint & hose 	09919-47020 Quick joint remover 
09930-88530 Injector test lead 	SUZUKI scan tool (SUZUKI-SDT) — This kit includes following items. 1. SUZUKI-SDT 2. DLC3 cable 3. USB cable 4. AC/DC power supply 5. Voltage meter probe 6. Storage case ☞ 

Ignition System

General Description

Ignition System Construction

S7RW0C1801001

The ignition system is an electronic (distributor less) ignition system. Especially, a direct ignition system is adopted. They consists of the parts as described below.

- **ECM**

It detects the engine and vehicle conditions through the signals from the sensors, determines the most suitable ignition timing and time for electricity to flow to the primary coil and sends a signal to the ignitor (power unit) in the ignition coil assembly.

- **Ignition coil assembly (including an ignitor)**

The ignition coil assembly has a built-in ignitor which turns ON and OFF the current flow to the primary coil according to the signal from ECM. When the current flow to the primary coil is turned OFF, a high voltage is induced in the secondary coil.

One ignition coil is in charge of ignition of one cylinder only.

- **Spark plugs**

- **CMP sensor and CKP sensor**

Using signals from these sensors, ECM identifies the specific cylinder whose piston is in the compression stroke, detects the crank angle and adjusts initial ignition timing automatically.


- **TP sensor, ECT sensor, MAF sensor, IAT sensor, knock sensor, wheel speed sensor (VSS) and other sensors / switches**

Although ignition system does not have a distributor and high-tension cords, each cylinder has an ignition coil assembly (ignitor and ignition coil) and the secondary voltage which occurred in the ignition coil is sent to the spark plug directly. Also, the signal (s) are sent from the CMP sensor to ECM so as to control each ignition coil independently through the ignitor (in ignition coil assembly).

Schematic and Routing Diagram

Ignition System Wiring Circuit Diagram

S7RW0C1802001




I7RW01180001-02

1. Ignition switch	8. No.4 spark plug	15. "IG COIL" fuse
2. Main relay	9. Sensed information (ECT sensor, MAF and IAT sensor, TP sensor, Knock sensor, wheel speed signal (ABS), Electric load signal, Engine start signal, Torque reduction signal (TCM))	16. Ignition coil assembly for No.1
3. CMP sensor	10. ECM	17. Ignition coil assembly for No.2
4. CKP sensor	11. Fuse box No.2	18. Ignition coil assembly for No.3
5. No.1 spark plug	12. "IGN" fuse	19. Ignition coil assembly for No.4
6. No.2 spark plug	13. "FI" fuse	
7. No.3 spark plug	14. Junction block	

Component Location

Ignition System Components Location

S7RW0C1803001



I7RW01180002-01

1. ECM	6. Electric throttle body assembly	11. Ignition coil assembly for No.1
2. CMP sensor	7. Knock sensor	12. Ignition coil assembly for No.2
3. CKP sensor	8. DLC	13. Ignition coil assembly for No.3
4. ECT sensor	9. Front wheel speed sensor (VSS)	14. Ignition coil assembly for No.4
5. MAF and IAT sensor	10. Fuse box No.2	15. ABS control module

Diagnostic Information and Procedures

Ignition System Check

S7RW0C1804001

Step	Action	Yes	No
1	Was "Engine and Emission Control System Check" performed?	Go to Step 2.	Go to "Engine and Emission Control System Check in Section 1A".
2	Ignition spark test 1) Check all spark plugs for condition and type referring to "Spark Plug Inspection". 2) If OK, perform ignition spark test referring to "Ignition Spark Test". Is spark emitted from all spark plugs?	Go to Step 11.	Go to Step 3.
3	DTC check 1) Perform DTC check referring to "DTC Check in Section 1A". Is DTC stored in ECM?	Go to applicable DTC diag. flow.	Go to Step 4.

Step	Action	Yes	No
4	Electrical connection check 1) Check ignition coil assemblies for electrical connection. <i>Are they connected securely?</i>	Go to Step 5.	Connect securely.
5	Ignition coil assembly power supply and ground circuit check 1) Check ignition coil assembly power supply and ground circuits for open and short. <i>Are circuits in good condition?</i>	Go to Step 6.	Repair or replace.
6	Ignition coil assembly check 1) Check ignition coil for resistance referring to "Ignition Coil Assembly (Including ignitor) Inspection". <i>Is check result satisfactory?</i>	Go to Step 7.	Replace ignition coil assembly.
7	CKP sensor check 1) Check CKP sensor referring to "Crankshaft Position (CKP) Sensor Inspection in Section 1C". <i>Is check result satisfactory?</i>	Go to Step 8.	Tighten CKP sensor bolt, replace CKP sensor or CKP sensor plate.
8	CMP sensor check 1) Check CMP sensor referring to "Camshaft Position (CMP) Sensor Inspection in Section 1C". <i>Is check result satisfactory?</i>	Go to Step 9.	Tighten CMP sensor bolt, replace CMP sensor or intake camshaft.
9	Ignition trigger signal circuit check 1) Check ignition trigger signal wire for open, short and poor connection. <i>Is circuit in good condition?</i>	Go to Step 10.	Repair or replace.
10	A known-good ignition coil assembly substitution 1) Substitute a known-good ignition coil assembly and then repeat Step 2. <i>Is check result of Step 2 satisfactory?</i>	Go to Step 11.	Substitute a known-good ECM and then repeat Step 2.
11	Ignition timing check 1) Check initial ignition timing and ignition timing advance referring to "Ignition Timing Inspection". <i>Is check result satisfactory?</i>	System is in good condition.	Go to Step 12.
12	Knock sensor check 1) Confirm that knock sensor circuit is in good condition referring to "DTC P0327 / P0328: Knock Sensor Circuit Low / High in Section 1A". 2) Check oscilloscope waveform of knock sensor signal referring to "Reference waveform No.23" and "Reference waveform No.24" under "Inspection of ECM and Its Circuits in Section 1A". <i>Is check result satisfactory?</i>	Check CMP sensor, CMP sensor rotor tooth of camshaft, CKP sensor, CKP sensor plate and/or input signals related to this system.	Substitute a known-good knock sensor and recheck.

Ignition System Symptom Diagnosis

S7RW0C1804002

Condition	Possible cause	Correction / Reference Item
Engine cranks, but will not start or hard to start (No spark)	Blown fuse for ignition coil	Replace.
	Loose connection or disconnection of lead wire	Connect securely.
	Faulty spark plug(s)	Replace.
	Faulty ignition coil(s)	Replace.
	Faulty CKP sensor or CKP sensor plate	Clean, tighten or replace.
	Faulty CMP sensor or sensor rotor tooth of camshaft	Clean, tighten or replace.
	Faulty ECM	Replace.
Poor fuel economy or engine performance	Incorrect ignition timing	Check related sensors and CKP sensor plate.
	Faulty spark plug(s)	Adjust, clean or replace.
	Faulty ignition coil assembly	Replace.
	Faulty CKP sensor or CKP sensor plate	Clean, tighten or replace.
	Faulty CMP sensor or sensor rotor tooth of camshaft	Clean, tighten or replace.
	Faulty knock sensor	Replace.
	Faulty ECM	Replace.

Reference Waveform of Ignition System

S7RW0C1804003

Refer to "Reference waveform No.11 to 15" and "Reference waveform No.19 and 20" under "Inspection of ECM and Its Circuits in Section 1A" for waveform of Ignition trigger signal.

Ignition Spark Test


S7RW0C1804004

- 1) Disconnect all injector couplers from injectors.

▲ WARNING

Without disconnection of injector couplers, combustible gas may come out from spark plug holes during this test and may get ignited in engine room.

- 2) Remove spark plug and check it for condition and type referring to "Spark Plug Inspection".
- 3) If OK, connect ignition coil coupler to ignition coil assembly and connect spark plug to ignition coil assembly.
- 4) Ground spark plug.
- 5) Crank engine and check if each spark plug sparks.



I7RW01180003-03

- 6) If no spark is emitted, inspect the related parts as described in "Ignition System Symptom Diagnosis".

Repair Instructions

Spark Plug Removal and Installation

S7RW0C1806001

Removal

- 1) Remove ignition coil assemblies referring to "Ignition Coil Assembly (Including ignitor) Removal and Installation".
- 2) Remove spark plugs.

Installation

- 1) Install spark plugs and tighten them to specified torque.

Tightening torque

Spark plug: 25 N·m (2.5 kgf-m, 18.0 lb-ft)

- 2) Install ignition coil assemblies referring to "Ignition Coil Assembly (Including ignitor) Removal and Installation".

Spark Plug Inspection

S7RW0C1806002

Inspect spark plug for the following:

- Electrode wear
- Carbon deposits
- Insulator damage


If any abnormality is found, adjust air gap, clean with spark plug cleaner or replace them with specified new plugs.

Spark plug air gap "a"

: 1.0 – 1.1 mm (0.040 – 0.043 in.)

Spark plug type

NGK: BKR6E-11 (Nickel)



IYSQ01181012-01


Ignition Coil Assembly (Including ignitor) Removal and Installation

S7RW0C1806003

Removal

- 1) Disconnect negative cable at battery.
- 2) Remove air cleaner case referring to "Air Cleaner Assembly Removal and Installation in Section 1D".
- 3) Disconnect ignition coil coupler.

- 4) Remove ignition coil bolts (1), and then pull out ignition coil assembly (2).




I7RW01180004-01

Installation

- 1) Install ignition coil assembly (2).
- 2) Tighten ignition coil bolts (1) to specified torque, and then connect ignition coil coupler.

Tightening torque

Ignition coil bolt (a): 6.5 N·m (0.65 kgf-m, 5.0 lb-ft)



I7RW01180005-01

- 3) Install air cleaner case referring to "Air Cleaner Assembly Removal and Installation in Section 1D".
- 4) Connect negative cable to battery.

Ignition Coil Assembly (Including ignitor) Inspection

S7RW0C1806004

Check ignition coil assembly for the following:

- Damage
- Deterioration
- Terminal for corrosion

If any abnormality is found, replace ignition coil assembly.


Ignition Timing Inspection

S7RW0C1806005

NOTE

- Ignition timing is not adjustable. If ignition timing is out of specification, check system related parts.
- Before starting engine, place transmission gear shift lever in "Neutral" (shift selector lever to "P" range for A/T model), and set parking brake.

1) Detach timing hole cover (1).




I7RW01180006-01

2) Connect scan tool to DLC (1) with ignition switch OFF.

Special tool

(A): SUZUKI scan tool (SUZUKI-SDT)



I5RW0C110011-01

- 3) Start engine and warm it up to normal operating temperature.
- 4) Make sure that all of electrical loads except ignition are switched off.
- 5) Check to be sure that idle speed is within specification referring to "Idle Speed and IAC Throttle Valve Opening Inspection in Section 1A".
- 6) Fix ignition timing by using "Fixed Spark" of "Misc Test" mode on scan tool.

7) Set timing light to ignition coil harness for No.1 cylinder and check that ignition timing is within specification.

Initial ignition timing


Fixed with SUZUKI scan tool: 2° – 8° BTDC (at specified idle speed)

Ignition order

1 – 3 – 4 – 2

Special tool

(A): 09930-76420



I7RW01180008-01

- | |
|--|
| 1. Timing mark on clutch housing or torque converter housing |
| 2. Timing mark BTDC 5° |

8) If ignition timing is out of specification, check the followings.

- CKP sensor
- CKP sensor plate
- TP sensor
- CMP sensor
- CMP sensor rotor tooth of camshaft
- Wheel speed sensor (VSS)
- Knock sensor
- Timing chain cover installation

9) After checking initial ignition timing, release ignition timing fixation by using SUZUKI scan tool.

10) With engine idling (throttle opening at closed position and vehicle stopped), check that ignition timing is about 3° – 17° BTDC. (Constant variation within a few degrees from 3° – 17° BTDC indicates no abnormality but proves operation of electronic timing control system.) Also, check that increasing engine speed advances ignition timing. If the check results are not satisfactory, check CKP sensor and ECM.

Specifications

Tightening Torque Specifications

S7RW0C1807001

Fastening part	Tightening torque			Note
	N·m	kgf·m	lb·ft	
Spark plug	25	2.5	18.0	🔧
Ignition coil bolt	6.5	0.65	5.0	🔧



Reference:

For the tightening torque of fastener not specified in this section, refer to “Fasteners Information in Section 0A”.

Special Tools and Equipment

Special Tool

S7RW0C1808001


09930-76420 Timing-light (dry cell type) 🔧 	SUZUKI scan tool (SUZUKI-SDT) — This kit includes following items. 1. SUZUKI-SDT 2. DLC3 cable 3. USB cable 4. AC/DC power supply 5. Voltage meter probe 6. Storage case 🔧 
---	---

Starting System

Schematic and Routing Diagram

Cranking System Circuit Diagram

S7RW0C1902001



I4RS0A190001-01

1. Pinion drive lever	6. Magnetic switch contacts	11. Ignition & Starter switch
2. Pinion & Over-running clutch	7. Pull-in coil	12. Battery
3. Magnetic switch	8. Starting motor	13. To ECM
4. Hold-in coil	9. Starting motor control relay	
5. Plunger	10. A/T: Transmission range sensor (shift switch)	

Diagnostic Information and Procedures

Cranking System Symptom Diagnosis

S7RW0C1904001

Possible symptoms due to starting system trouble would be as follows:

- Starting motor does not run (or runs slowly)
- Starting motor runs but fails to crank engine
- Abnormal noise is heard

Proper diagnosis must be made to determine exactly where the cause of each trouble lies in battery, wiring harness, (including starting motor switch), starting motor or engine.

Do not remove motor just because starting motor does not run. Check following items and narrow down scope of possible causes.

- 1) Condition of trouble
- 2) Tightness of battery terminals (including ground cable connection on engine side) and starting motor terminals
- 3) Discharge of battery
- 4) Mounting of starting motor

Condition	Possible cause	Correction / Reference Item
Motor not running (No operating sound of magnetic switch)	Transmission range sensor is not in P or N, or not adjusted (A/T model)	<i>Shift in P or N, or adjust sensor.</i>
	Battery run down	<i>Recharge battery.</i>
	Battery voltage too low due to battery deterioration	<i>Replace battery.</i>
	Poor contact in battery terminal connection	<i>Retighten or replace.</i>
	Loose grounding cable connection	<i>Retighten.</i>
	Fuse set loose or blown off	<i>Tighten or replace.</i>
	Poor contacting action of ignition switch and magnetic switch	<i>Replace.</i>
	Lead wire coupler loose in place	<i>Retighten.</i>
	Open-circuit between ignition switch and magnetic switch	<i>Repair.</i>
	Open-circuit in pull-in coil	<i>Replace magnetic switch.</i>
	Brushes are seating poorly or worn down	<i>Repair or replace.</i>
	Poor sliding of plunger and/or pinion	<i>Repair.</i>
	Faulty starting motor control relay	<i>"Engine and Emission Control System Relay Inspection in Section 1C".</i>
	Faulty ECM and its circuit	<i>"Inspection of ECM and Its Circuits in Section 1A".</i>
Motor not running (Operating sound of magnetic switch heard)	Battery run down	<i>Recharge battery.</i>
	Battery voltage too low due to battery deterioration	<i>Replace battery.</i>
	Loose battery cable connections	<i>Retighten.</i>
	Burnt main contact point, or poor contacting action of magnetic switch	<i>Replace magnetic switch.</i>
	Brushes are seating poorly or worn down	<i>Repair or replace.</i>
	Weakened brush spring	<i>Replace.</i>
	Burnt commutator	<i>Replace armature.</i>
	Layer short-circuit of armature	<i>Replace.</i>
	Crankshaft rotation obstructed	<i>Repair.</i>
Starting motor running but too slow (small torque) (If battery and wiring are satisfactory, inspect starting motor)	Insufficient contact of magnetic switch main contacts	<i>Replace magnetic switch.</i>
	Layer short-circuit of armature	<i>Replace.</i>
	Disconnected, burnt or worn commutator	<i>Replace armature.</i>
	Worn brushes	<i>Replace brush.</i>
	Weakened brush springs	<i>Replace spring.</i>
	Burnt or abnormally worn end bush	<i>Replace bush.</i>
Starting motor running, but not cranking engine	Worn pinion tip	<i>Replace over-running clutch.</i>
	Poor sliding of over-running clutch	<i>Repair.</i>
	Over-running clutch slipping	<i>Replace over-running clutch.</i>
	Worn teeth of ring gear	<i>Replace flywheel or drive plate.</i>
Noise	Abnormally worn bush	<i>Replace bush.</i>
	Worn pinion or worn teeth of ring gear	<i>Replace pinion or flywheel or drive plate.</i>
	Poor sliding of pinion (failure in return movement)	<i>Repair or replace.</i>
	Worn internal or planetary gear teeth	<i>Replace.</i>
	Lack of oil in each part	<i>Lubricate.</i>
Starting motor does not stop running	Fused contact points of magnetic switch	<i>Replace magnetic switch.</i>
	Short-circuit between turns of magnetic switch coil (layer short-circuit)	<i>Replace magnetic switch.</i>
	Failure of returning action in ignition switch	<i>Replace.</i>

Cranking System Test

S7RW0C1904002

⚠ CAUTION


Each test must be performed within 3 – 5 seconds to avoid coil from burning.

Pull-in Test

Connect battery to the magnetic switch as shown. Check that plunger and pinion move outward. If plunger and pinion don't move, replace the magnetic switch.

NOTE

Before testing, disconnect lead wire from terminal M (2).




I2RH01190002-01

- | |
|--------------------------------|
| 1. Terminal "S" |
| 3. Lead wire (switch to motor) |

Hold-in Test


While connected as the figure with plunger out, disconnect negative lead from terminal "M". Check that plunger and pinion remain out. If plunger and pinion return inward, replace the magnetic switch.



I2RH01190003-01

Plunger and Pinion Return Test

Disconnect negative lead from starting motor body. Check that plunger and pinion return inward. If plunger and pinion don't return, replace the magnetic switch.




I2RH01190004-01

No-load Performance Test

Connect battery and ammeter to starter as shown. Check that starter rotates smoothly and steadily with pinion moving out. Check that ammeter indicates specified current.

Specified current (No-load performance test)
90 A MAX. at 11 V




I2RH01190005-01

Repair Instructions

Starting Motor Unit Components

S7RW0C1906001



I7RW01190001-01


1. Starting motor	4. Plate
2. Magnetic switch lead wire	(a) : 11 N·m (1.1 kgf-m, 8.0 lb-ft)
3. Battery cable	(b) : 25 N·m (2.5 kgf-m, 18.5 lb-ft)

Starting Motor Dismounting and Remounting

S7RW0C1906002

Dismounting

- 1) Remove battery and battery tray with ECM.
- 2) Remove magnetic switch lead wire (1) and battery cable (2).
- 3) Remove starting motor mount bolt (3) and then starting motor (4) and bracket (5).



I7RW01190002-01


Remounting

Reverse dismounting procedure for remounting noting the following.

- Tighten each bolts and nuts to specified torque.

Tightening torque


Battery cable nut (a): 11 N·m (1.1 kgf-m, 8.0 lb-ft)
Starting motor mount bolt (b): 25 N·m (2.5 kgf-m, 18.5 lb-ft)



I7RW01190003-01

Starting Motor Components

S7RW0C1906003



I7RW01190004-01


1. Front housing	7. Lever	13. Internal gear	19. Brush
2. Bush	8. Plunger	14. Planetary carrier shaft	20. Brush holder
3. Snap ring	9. Plate	15. Planetary gear	21. Rear bracket
4. Pinion stop ring	10. Seal rubber	16. Packing	: Apply grease 99000-25011 to sliding surface of each part.
5. Pinion gear	11. Magnetic switch	17. Yoke	22. Rear bush
6. Over-running clutch	12. Ball	18. Armature	: Do not reuse.

Starting Motor Inspection

S7RW0C1906004

Plunger


Inspect plunger for wear. Replace if necessary.



I2RH01190008-01

Magnetic Switch


Push in plunger and release it. The plunger should return quickly to its original position. Replace if necessary.



I2RH01190009-01

Pull-in coil open circuit test


Check for continuity across magnetic switch "S" terminal (1) and "M" terminal (2). If no continuity, coil is open and should be replaced.



I2RH01190010-01

Hold-in coil open circuit test


Check for continuity across magnetic switch "S" terminal (1) and coil case. If no continuity, coil is open and should be replaced.



I2RH01190011-01

Rear Bracket Bush

Inspect bush for wear or damage. Replace if necessary.



I2RH01190012-01

Brush


- Check brushes for wear. Measure length of brushes and if below the limit, replace the brush.

Brush length

Standard: 12.3 mm (0.48 in.)

Limit: 7.0 mm (0.28 in.)

- Install brushes to each brush holder and check for smooth movement.



I2RH01190013-01

Spring

Inspect brush springs for wear, damage or other abnormal conditions. Replace if necessary.

Brush spring tension


Standard: 2.2 kg (4.85 lb)

Limit: 0.6 kg (1.32 lb)

11-7 Starting System:

Brush Holder


- Check movement of brush in brush holder. If brush movement within brush holder is sluggish, check brush holder for distortion and sliding faces for contamination. Clean or correct as necessary.
- Check for continuity across insulated brush holder (positive side) and grounded brush holder (negative side). If continuity exists, brush holder is grounded due to defective insulation and should be replaced.



I2RH01190014-01

Armature

- Inspect commutator for dirt or burn. Correct with sandpaper or lathe, if necessary.



I7RW01190005-02

1. Sandpaper of #300 – 400

- Check commutator for uneven wear with armature (1) supported on V-blocks (2). If deflection of dial gauge (4) pointer exceeds limit, repair or replace.


NOTE

The following specification presupposes that the armature is free from bend. Bent armature must be replaced.

Commutator out of round

Standard: 0.05 mm (0.002 in.) or less

Limit: 0.4 mm (0.015 in.)



I2RH01190016-01


3. Magnetic stand

- Inspect the commutator for wear. If diameter is below limit, replace the armature.

Commutator outside diameter

Standard: 29.4 mm (1.16 in.)

Limit: 28.8 mm (1.13 in.)




I2RH01190017-01

- Inspect the commutator (1) for insulator (2) depth. Correct or replace if below limit.

Commutator insulator depth "a"

Standard: 0.4 – 0.6 mm (0.015 – 0.024 in.)

Limit: 0.2 mm (0.008 in.)




I7RW01190006-02

[A]: Correct


[B]: Incorrect

- Check the commutator and armature core. If there is continuity, the armature is grounded and must be replaced.



I2RH01190019-01


- Check for continuity between segments. If there is no continuity at any test point, there is an open circuit and the armature must be replaced.



I2RH01190020-01

Gears


Inspect the internal gear and the planetary gears for wear, damage or other abnormal conditions. Replace if necessary.



I2RH01190021-01


Pinion and Over-running Clutch

- Inspect the pinion for wear, damage or other abnormal conditions. Check that clutch locks up when turned in direction of drive and rotates smoothly in reverse direction. Replace if necessary.



I2RH01190022-01


- Inspect the spline teeth for wear or damage. Replace if necessary. Inspect the pinion for smooth movement.



I2RH01190023-01

Front Housing Bush

Inspect the bush for wear or damage. Replace if necessary.



I2RH01190024-01

Specifications

Cranking System Specifications

S7RW0C1907001

Voltage		12 volts	
Output		1.4 kW	
Rating		30 seconds	
Direction of rotation		Clockwise as viewed from pinion side	
Brush length		Standard: 12.3 mm (0.48 in.)	Limit: 7.0 mm (0.28 in.)
Number of pinion teeth		8	
Performance		Condition	Guarantee
Around at 20 °C (68 °F)	No load characteristic	11.0 V	90 A maximum 2,000 rpm minimum
	Load characteristic	7.5 V 300 A	11 N·m (1.1 kgf-m, 8.0 lb-ft) minimum 840 rpm minimum
	Locked characteristic	3.0 V	860 A maximum 20 N·m (2.0 kgf-m, 14.5 lb-ft) minimum
	Magnetic switch operating voltage		8 volts maximum

Tightening Torque Specifications

S7RW0C1907002

Fastening part	Tightening torque			Note
	N·m	kgf-m	lb-ft	
Battery cable nut	11	1.1	8.0	☞
Starting motor mount bolt	25	2.5	18.5	☞

NOTE

The specified tightening torque is also described in the following.
“Starting Motor Unit Components”

Reference:

For the tightening torque of fastener not specified in this section, refer to “Fasteners Information in Section 0A”.

Special Tools and Equipment

Recommended Service Material

S7RW0C1908001

NOTE

Required service material is also described in the following.
“Starting Motor Components”

Charging System

General Description

Battery Description

S7RW0C1A01001

The battery has three major functions in the electrical system.

- It is a source of electrical energy for cranking the engine.
- It acts as a voltage stabilizer for the electrical system.
- It can, for a limited time, provide energy when the electrical load exceeds the output of the generator.

Carrier and Hold-Down

The battery carrier should be in good condition so that it will support the battery securely and keep it level.

Before installing the battery, the battery carrier and hold-down clamp should be clean and free from corrosion and make certain there are no parts in carrier.

To prevent the battery from shaking in its carrier, the hold-down bolts should be tight enough but not over-tightened.

Electrolyte Freezing

The freezing point of electrolyte depends on its specific gravity. Since freezing may ruin a battery, it should be protected against freezing by keeping it in a fully charged condition. If a battery is frozen accidentally, it should not be charged until it is warmed.

Sulfation

If the battery is allowed to stand for a long period in discharged condition, the lead sulfate becomes converted into a hard, crystalline substance, which will not easily turn back to the active material again during the subsequent recharging. "Sulfation" means the result as well as the process of that reaction.


Such a battery can be revived by very slow charging and may be restored to usable condition but its capacity is lower than before.

Built-in Indicator (if equipped)

The battery has a built-in temperature compensated indicator (1) in the top of the battery. This indicator is to be used with the following diagnostic procedure.

When checking the indicator, make sure that the battery has a clean top. A light may be needed in some poorly-lit areas.

Three types of indication available under normal operation are as follows.



IYSQ011A0001-01

1J-2 Charging System:

- **Green Dot:**

Battery is sufficiently charged for testing.

- **Dark:**

Battery must be charged before testing.




If there is a cranking complaint, battery should be tested as described in "Battery Inspection".

Charging and electrical systems should also be checked at this time.

- **Clear or Light Yellow:**

This means that fluid level is below the bottom of hydrometer. Its possible cause is excessive or prolonged charging, a broken case, excessive tipping or normal battery deterioration.

When the battery is found in such condition, it is possible that high charging voltage is caused by the faulty charging system and therefore, charging and electrical systems need to be checked. If there is a trouble in cranking and its cause lies in the battery, it should be replaced.

Diagnosis	OK	Charging necessary	Low Level Electrolyte Replace Battery
Indicator	 IYSQ011A0002-01 Green dot	 IYSQ011A0065-01 Dark	 IYSQ011A0066-01 Clear
Gravity Ball	 IYSQ011A0067-01	 IYSQ011A0068-01	 IYSQ011A0069-01


Generator Description

S7RW0C1A01002

The generator is a small and high performance type with an IC regulator incorporated. The internal components are connected electrically as shown in the following figure.


The generator features are as follows:

- Solid state regulator is mounted inside the generator.
- All regulator components are enclosed into a solid mold.
- This unit along with the brush holder assembly is attached to the rear housing.
- The IC regulator uses integrated circuits and controls the voltage produced by the generator, and the voltage setting cannot be adjusted.
- The generator rotor bearings contain enough grease to eliminate the need for periodic lubrication. Two brushes carry current through the two slip rings to the field coil mounted on the rotor, and under normal conditions will provide long period of attention-free service.
- The stator windings are assembled on the inside of a laminated core that forms part of the generator frame.



I7RW011A0006-02

1. Generator with regulator assembly	5. Field coil (rotor coil)	9. ECM	13. IG fuse
2. I.C. regulator	6. Charge indicator light	10. BCM	14. METER fuse
3. Stator coil	7. Main switch	11. Combination meter	
4. Diode	8. Battery	12. CAN driver	



I5JB0A1A0004-01

1. Pulley	6. Field coil	11. Rear housing	IG: Ignition terminal
2. Pulley nut	7. Rectifier	B: Generator output (Battery terminal)	L: Light terminal
3. Rotor fan	8. Brush	C: Generator cut	
4. Stator coil	9. Regulator	E: Ground	
5. Stator core	10. Front housing	FR: Field duty monitor	

Diagnostic Information and Procedures

Battery Inspection

S7RW0C1A04001

Common Causes of Failure

A battery is not designed to last indefinitely; however, with proper care, it will provide many years of service. If the battery performs satisfactorily during test but fails to operate properly for no apparent reason, the following are some factors that may point to the cause of trouble:

- Accessories left on overnight or for an extended period without the generator operating.
- Slow average driving speeds for short periods.
- Electrical load exceeding generator output particularly with addition of aftermarket equipment.
- Defects in charging system such as high resistance, slipping drive belt, loose generator output terminal, faulty generator or voltage regulator. Refer to "Generator Symptom Diagnosis".
- Battery abuse, including failure to keep battery cable terminals clean and tight or loose battery hold down.
- Mechanical problems in electrical system such as shorted or pinched wires.

Visual inspection

Check for obvious damage, such as cracked or broken case or cover, that could permit loss of electrolyte. If obvious damage is noted, replace battery. Determine cause of damage and correct as needed.

Generator Symptom Diagnosis

S7RW0C1A04002

A charging circuit wiring diagram for generator connection is shown in "Generator Description". To avoid damage, always follow these precautions:

CAUTION

- Do not mistake polarities of "IG" terminal and "L" terminal.
- Do not create a short circuit between "IG" and "L" terminals. Always connect these terminals through a light.
- Do not connect any load between "L" and "E" terminals.
- When connecting charger or booster battery to vehicle battery, refer to "Jump Starting in Case of Emergency".

Trouble in charging system will show up as one or more of the following conditions:

- 1) Faulty charge indicator light operation.
- 2) An undercharged battery as evidenced by slow cranking or indicator clear with dark on light yellow dot.
- 3) An overcharged battery as evidenced by excessive spewing of electrolyte from vents.

Condition	Possible cause	Correction / Reference Item
Noisy generator	Loose drive belt	<i>Adjust or replace drive belt.</i>
	Loose drive belt pulley	<i>Check generator.</i>
	Loose mounting bolts	<i>Check mounting condition.</i>
	Worn or dirty bearings	<i>Check generator.</i>
	Defective diode or stator	<i>Check generator.</i>
Charge indicator light does not light with ignition ON and engine off	Fuse blown	<i>Check fuse.</i>
	Indicator light (LED) faulty	<i>Check BCM, combination meter and/or CAN communication line.</i>
	Wiring connection loose	<i>Tighten loose connection.</i>
	IC regulator faulty	<i>Check generator.</i>
	Poor contact between brush and slip ring	<i>Repair or replace.</i>
Charge indicator light does not go out with engine running Battery requires frequent recharging	Drive belt loose or worn	<i>Adjust or replace drive belt.</i>
	IC regulator or generator faulty	<i>Check charging system.</i>
	Wiring faulty	<i>Repair wiring.</i>

Generator Test (Undercharged Battery Check)

S7RW0C1A04003

This condition, as evidenced by slow cranking or indicator clear with dark or light yellow dot can be caused by one or more of the following conditions even though indicator light may be operating normal. The following procedure also applies to cars with voltmeter and ammeter.


- 1) Make sure that undercharged condition has not been caused by accessories left on for extended period of time.
- 2) Check drive belt for proper tension.
- 3) If battery defect is suspected, refer to "Battery Description".
- 4) Inspect wiring for defects. Check all connections for tightness and cleanliness, battery cable connections at battery, starting motor, ignition ground cable and no "C" terminal circuit at ground.
- 5) Connect switch (6), load (5), battery (4), voltmeter (3) and ammeter (2) to generator (1) as shown in figure.

Voltmeter: Set between generator "B" terminal and ground.

Ammeter: Set between generator "B" terminal and battery (+) terminal.

NOTE

Use fully charged battery.



IYSQ011A0007-01

- 6) Measure current and voltage.

No-Load Check

- 1) Run engine from idling up to 2000 rpm and read meters.

NOTE

Turn off switches of all accessories (wiper, heater etc.).


Specification for undercharged battery (No-load check)

Current: 10 A

Voltage: 14.2 – 14.8 V (at 20 °C, 68 °F)

NOTE


Consideration should be taken that voltage will differ somewhat with regulator case temperature as shown in figure.



I6RS0B1A1002-01

[A]:	Regulated voltage (V)
[B]:	Heat sink temperature (°C)

- 2) Using service wire, ground "C" terminal (1) of generator.



I5JB0A1A0011-01

- 3) Measure voltage between "B" terminal of generator and body ground.

Voltage: 12.5 – 13.1 V (at 20 °C, 68 °F)

- **If voltage is higher than standard value**
If voltage is higher than standard value, check ground of brushes.
If brushes are not grounded, replace IC regulator.
If voltage is lower than standard value, proceed to the following check.

Load Check


- 1) Run engine at 2000 rpm and turn on head light and heater motor.
- 2) Measure current and if it is less than 30 A repair or replace generator.

1J-6 Charging System:

Generator Test (Overcharged Battery Check)

S7RW0C1A04004

- 1) To determine battery condition, refer to "Battery Description".
- 2) If obvious overcharge condition exists as evidenced by excessive spewing of electrolyte, measure generator "B" terminal voltage at engine 2000 rpm.



I6RS0B1A1002-01

[A]: Regulated voltage (V)

[B]: Heat sink temperature (°C)

- 3) If measured voltage is higher than upper limit value, proceed to disassemble generator.
- 4) Check ground of brushes. If brushes are not grounded, replace IC regulator. Then check field coil for grounds and shorts, referring to "Generator Inspection".

Repair Instructions

Jump Starting in Case of Emergency

S7RW0C1A06001

With Auxiliary (Booster) Battery

⚠ CAUTION

If vehicle is manual transmission model and has a catalytic converter, do not push or tow it to start. Damage to its emission system and/or to other parts may result.

Both booster and discharged battery should be treated carefully when using jumper cables. Follow the procedure outlined as follows, being careful not to cause sparks.

⚠ WARNING

- Departure from these conditions or procedure described as follows could result in:
 - a. Serious personal injury (particularly to eyes) or property damage from such causes as battery explosion, battery acid, or electrical burns.
 - b. Damage to electronic components of either vehicle.
- Never expose battery to open flame or electric spark. Batteries generate gas which is flammable and explosive.
- Remove rings, watches, and other jewelry. Wear approved eye protection.

- Do not allow battery fluid to contact eyes, skin, fabrics, or painted surface as fluid is a corrosive acid. Flush any contacted area with water immediately and thoroughly.
- Be careful so that metal tools or jumper cables do not contact positive battery terminal (or metal in contact with it) and any other metal on vehicle, because a short circuit could occur.
- Batteries should always be kept out of reach of children.

- 1) Set parking brake and place automatic transmission in PARK (NEUTRAL on manual transmission).
- 2) Turn OFF ignition switch, turn OFF lights and all other electrical loads.
- 3) Check built-in indicator (if equipped). If it is clear or light yellow, replace the battery.
- 4) Attach end of one jumper cable to positive terminal of booster battery and the other end of the same cable to positive terminal of discharged battery. (Use 12-volt battery only to jump start engine).
- 5) Attach one end of the remaining negative cable to negative terminal of booster battery, and the other end to a solid engine ground (such as exhaust manifold) at least 45 cm (18 in.) away from battery of vehicle being started.

⚠ WARNING

Do not connect negative cable directly to negative terminal of dead battery.

- 6) Start engine of vehicle with booster battery and turn off electrical accessories. Then start engine of the vehicle with discharged battery.
- 7) Disconnect jumper cable in the exact reverse order.

With Charging Equipment

⚠ CAUTION

When jump starting engine with charging equipment, be sure equipment used is 12-volt and negative ground. Do not use 24-volt charging equipment. Using such equipment can cause serious damage to electrical system or electronic parts.

Battery Dismounting and Remounting

S7RW0C1A06002

⚠ WARNING

When handling battery, following safety precautions should be followed:

- Hydrogen gas is produced by battery. A flame or spark near battery may cause the gas to ignite.
- Battery fluid is highly acidic. Avoid spilling on clothing or other fabric. Any spilled electrolyte should be flushed with large quantity of water and cleaned immediately.

Dismounting

- 1) Disconnect negative cable.
- 2) Disconnect positive cable.
- 3) Remove retainer.
- 4) Remove battery.

Handling

When handling battery, the following safety precautions should be followed:


- Hydrogen gas is produced by battery. A flame or spark near battery may cause the gas to ignite.
- Battery fluid is highly acidic. Avoid spilling on clothing or other fabric. Any spilled electrolyte should be flushed with large quantity of water and cleaned immediately.

Remounting

- 1) Reverse removal procedure.
- 2) Tighten battery cables securely.

NOTE

Check to be sure that ground cable has enough clearance to hood panel by terminal.




I7RW011A0005-01

1. Battery	4. Retainer
2. Positive cable	5. Nut
3. Negative cable	

Water Pump and Generator Drive Belt On-Vehicle Inspection

S7RW0C1A06003

- Inspect belt for cracks, cuts, deformation, wear and cleanliness. If any of these conditions are found, replace belt, referring to “Water Pump and Generator Drive Belt Removal and Installation”.
- Check to make sure that tension indicators are as follows in the figure by using mirror.
 - If the tension indicator “B” is found to the left of the indicator “A”, replace the generator belt.
 - If new generator belt has been installed, indicator “A” should be within “a” of the figure. If it isn’t, it means that belt is not installed properly. Reinstall it properly.



I7RW0C1A0002-01

[A]: A/C model	2. Crankshaft pulley	5. Tensioner
[B]: Non-A/C model	3. Water pump pulley	6. Power steering pump pulley
1. Water pump and generator drive belt	4. Tension pulley	7. Magnet clutch pulley

Water Pump and Generator Drive Belt Removal and Installation


S7RW0C1A06004

Removal

⚠ WARNING

Disconnect negative (–) cable at battery before removing and installing generator belt.

- Hoist vehicle.
- Remove right side engine under cover.
- Loosen tensioner by turning the tensioner pulley (2) clockwise.
- While holding the tensioner and belt loose, remove generator belt (1).



I3TR011A4001-01


3. Tensioner pulley bolt

Installation

- 1) Loosen tensioner by turning the tensioner pulley (2) clockwise.
- 2) While holding the tensioner, install generator belt (1).
- 3) Install right side engine under cover.

NOTE

- Make sure that the belt fits each pulley's groove properly.
- After installing generator belt, make sure that tension indicator is within standard range referring to "Water Pump and Generator Drive Belt On-Vehicle Inspection".




I3TR011A4001-01

3. Tensioner pulley bolt

Generator Unit Components

S7RW0C1A06005



I7RW011A0002-01


1. "B" terminal wire	5. Generator pivot bolt	(a) : 5.0 N-m (0.5 kgf-m, 4.0 lb-ft)
2. coupler	6. "B" terminal nut	(b) : 52.5 N-m (5.25 kgf-m, 38.0 lb-ft)
3. Water pump and generator drive belt	7. Generator cover	(c) : 25 N-m (2.5 kgf-m, 18.5 lb-ft)
4. Generator mounting bolt	8. Generator	

Generator Dismounting and Remounting

S7RW0C1A06006

Dismounting

- 1) Disconnect negative (–) cable at battery.
- 2) Remove water pump and generator drive belt referring to “Water Pump and Generator Drive Belt Removal and Installation”.
- 3) Remove air cleaner case referring to “Air Cleaner Assembly Removal and Installation in Section 1D”.
- 4) Remove intake manifold referring to “Intake Manifold Removal and Installation in Section 1D”.
- 5) Remove generator cover (1).
- 6) Disconnect “B” terminal wire (2) and coupler (3) from generator.
- 7) Remove generator mounting bolt (4) and generator pivot bolt (5) from generator.
- 8) Remove generator (6) from engine.



I7RW011A0003-01

Remounting

Reverse dismounting procedure, noting the following.


- Tighten each bolts and nuts to specified torque.

Tightening torque

“B” terminal nut (a): 5 N·m (0.5 kgf-m, 4.0 lb-ft)

Generator mounting bolt (b): 25 N·m (2.5 kgf-m, 18.5 lb-ft)


Generator pivot bolt (c): 52.5 N·m (5.25 kgf-m, 38.0 lb-ft)



I7RW011A0004-01

Generator Components

S7RW0C1A06007



I4RS0B1A0007-01


1. Pulley nut	6. Drive end bearing	11. Rear housing	16. "B" terminal nut
2. Pulley	7. Bearing retainer	12. Rectifier	: 118 N·m (11.8 kgf-m, 85.5 lb-ft)
3. Front housing	8. Rotor	13. Regulator	: 4.5 N·m (0.45 kgf-m, 3.5 lb-ft)
4. Stator	9. Rear end bearing	14. Brush	: 3.5 N·m (0.35 kgf-m, 2.5 lb-ft)
5. Frame bolt	10. Retainer screw	15. "B" terminal	: 5.0 N·m (0.5 kgf-m, 4.0 lb-ft)

Generator Inspection

S7RW0C1A06008


Rotor

- Using ohmmeter, connect positive terminal to “FR” terminal and connect negative terminal to “B” terminal of generator, check that continuity between “B” terminal and “FR” terminal. If there is no continuity, replace rotor or regulator.




I5JB0A1A0012-01

- Using ohmmeter, check for continuity between slip rings of rotor. If there is no continuity, replace rotor (1).

Resistance between slip rings of rotor**1.7 – 2.0 Ω** 

IYSQ011A0035-01

- Using ohmmeter, check that there is no continuity between slip ring and rotor core. If there is continuity, replace rotor (1).




IYSQ011A0036-01

- Check slip rings for roughness or scoring. If rough or scored, replace rotor.


Stator

- Using ohmmeter, check all leads for continuity. If there is no continuity, replace stator (1).



IYSQ011A0037-01

- Using ohmmeter, check that there is no continuity between coil leads (2) and stator core (1). If there is continuity, replace stator.



IYSQ011A0038-01


Brush and brush holder

Check each brush for wear by measuring its length. If brush is found worn down to service limit, replace brush.

Brush length "a"

Standard: 16 mm (0.63 in.)

Limit: 5 mm (0.20 in.)




IYSQ011A0039-01

1J-14 Charging System:

Rectifier

- 1) Using ohmmeter, check continuity between each of upper and lower rectifier bodies and each diode lead (2).
Check both directions by reversing probes of ohmmeter and there should be only one-way continuity in each case.
If check result is not satisfactory, replace rectifier (1).
- 2) In the same manner as described in above Step 1), check that there is only one-way continuity between both leads of diode trio.




IYSQ011A0040-01

Condenser

Check condenser capacity.

Condenser capacity

0.5 μF



IYSQ011A0041-01

1. Rectifier	2. Condenser
--------------	--------------

Specifications

Charging System Specifications

S7RW0C1A07001

Battery

Battery

: 55B24R (42.5AH/5HR) 12V

Battery type	55B24R
Rated Capacity AH/5HR, 12 Volts	42.5
Electrolyte L (US/Imp. pt)	2.8 (5.92/4.93)
Electrolyte S.G.	1.28 when fully charged at 20 °C (68 °F)

Generator

Type	80 A type
Rated voltage	12 V
Nominal output	80 A
Permissible max. speed	18000 r/min (rpm)
No-load speed	1200 r/min (rpm)
Setting voltage	14.2 to 14.8 V
Permissible ambient temperature	−30 to 100 °C (−22 to 212 °F)
Polarity	Negative ground
Rotation	Clockwise viewed from pulley side

Tightening Torque Specifications

S7RW0C1A07002

Fastening part	Tightening torque			Note
	N·m	kgf·m	lb·ft	
“B” terminal nut	5	0.5	4.0	☞
Generator mounting bolt	25	2.5	18.5	☞
Generator pivot bolt	52.5	5.25	38.0	☞

NOTE

The specified tightening torque is also described in the following.

“Generator Unit Components”

“Generator Components”

Reference:

For the tightening torque of fastener not specified in this section, refer to “Fasteners Information in Section 0A”.

Exhaust System

General Description

Exhaust System Description

S7RW0C1B01001

The exhaust system consists of the exhaust manifold, exhaust No.1 pipe with WU-TWC (Warm Up Three Way Catalytic Converter), exhaust No.2 pipe and exhaust center pipe with TWC (Three Way Catalytic Converter), muffler, seal, gasket and etc.

The WU-TWC and TWC are an emission control device added to the exhaust system to lower the levels of Hydrocarbon (HC), Carbon Monoxide (CO), and Oxides of Nitrogen (NOx) pollutants in the exhaust gas.

Diagnostic Information and Procedures

Exhaust System Check


S7RW0C1B04001

▲ WARNING

To avoid the danger of being burned, do not touch the exhaust system when the system is hot. Any service on the exhaust system should be performed when the system is cool.

At every interval of periodic maintenance service, and when vehicle is raised for other service, check exhaust system as follows:

- Check rubber mountings for damage, deterioration, and out of position.



IYSY011B0003-01

- Check exhaust system for leakage, loose connection, dent and damage.
If bolts or nuts are loosened, tighten them to specified torque referring to “Exhaust System Components”.
- Check nearby body areas damaged, missing, or mispositioned part, open seam, hole connection or any other defect which could permit exhaust fumes to seep into vehicle.
- Make sure that exhaust system components have enough clearance from underbody to avoid overheating and possible damage to passenger compartment carpet.
- Any defect should be fixed at once.


Repair Instructions

Exhaust System Components

S7RW0C1B06001

▲ WARNING

To avoid the danger of being burned, do not touch the exhaust system when the system is hot. Any service on the exhaust system should be performed when the system is cool.



I7RW0C1B0001-01

[A]: View A	10. Seal ring	23. Exhaust pipe No.1 stiffener bolt
[B]: View B	11. Exhaust No.2 pipe	24. Catalytic heat insulator nut
[C]: Sedan model	12. Exhaust center pipe	25. Exhaust pipe clamp bolt
[D]: Hatchback model	13. Exhaust pipe clamp	(a) : 45 N-m (4.5 kgf-m, 32.5 lb-ft)
1. Exhaust manifold cover	14. Muffler	(b) : Tighten 50 N-m (5.0 kgf-m, 36.5 lb-ft) by the specified procedure.
2. Exhaust manifold : See "A"	15. Tail pipe	(c) : 65 N-m (6.5 kgf-m, 47.0 lb-ft)

1K-3 Exhaust System:

3. Exhaust manifold gasket	16. Muffler mounting No. 1	 (d) : 43 N·m (4.3 kgf-m, 31.5 lb-ft)
4. Engine hook	17. Muffler mounting No. 2	 (e) : Tighten 65 N·m (6.5 kgf-m, 47.0 lb-ft) by the specified procedure.
5. A/F sensor	18. Catalyst heat insulator	 (f) : 2 N·m (0.2 kgf-m, 1.5 lb-ft)
6. Gasket	19. Exhaust manifold bolt	 (g) : 29 N·m (2.9 kgf-m, 21.0 lb-ft)
7. Exhaust No.1 pipe	20. Exhaust manifold nut	 : Do not reuse.
8. HO2S	21. Exhaust No.1 pipe nut	
 9. Exhaust No.1 pipe stiffener : See "B"	22. Exhaust pipe bolt	
"A": Tighten exhaust manifold nuts and bolts the following tightening order as shown in [A]. Tightening order: a → b → c → d → e → f → g → h → i		
"B": Tighten exhaust No.1 pipe stiffener bolt (a) first and next (b) as shown in [B].		

Exhaust Manifold Removal and Installation


S7RW0C1B06002

Removal

WARNING


To avoid danger of being burned, do not service exhaust system while it is still hot. Service should be performed after system cools down.

- 1) Disconnect negative (–) cable at battery.
- 2) Remove engine hood referring to "Hood Removal and Installation in Section 9J".
- 3) Remove air cleaner assembly referring to "Air Cleaner Assembly Removal and Installation in Section 1D".
- 4) Disconnect ground wire (1) and remove exhaust manifold cover (2).




I7RW011B0002-01

- 5) Remove right and left side engine under covers.
- 6) Remove exhaust No.1 pipe referring to "Exhaust Pipe and Muffler Removal and Installation".
- 7) Support engine assembly by using chain hoist (1) and hook (2) as shown in figure.



I7RW011B0003-01


- 8) Remove engine right mounting No.1 bracket and engine right mounting No.2 bracket referring to "Engine Mountings Components in Section 1D".
- 9) Loosen exhaust manifold bolts and nuts in numerical order ("1" through "9") as shown in figure, and remove them.
- 10) Remove exhaust manifold (1), engine hook (2) and gasket from cylinder head.



I7RW011B0004-02

Installation

- 1) Install new exhaust manifold gasket (1) to cylinder head.




I2RH01140031-01

- 2) Install exhaust manifold (1) and engine hook (2), and tighten exhaust manifold bolts and nuts to specified torque according to numerical order ("1" through "9") as shown as in figure.

Tightening torque


Exhaust manifold bolt (a): Tighten 50 N·m (5.0 kgf-m, 36.5 lb-ft) by the specified procedure

Exhaust manifold nut (b): Tighten 50 N·m (5.0 kgf-m, 36.5 lb-ft) by the specified procedure



I7RW011B0006-01

- 3) Install engine right mounting No.1 bracket and engine right mounting No.2 bracket referring to "Engine Mountings Components in Section 1D".
- 4) Install exhaust No.1 pipe referring to "Exhaust Pipe and Muffler Removal and Installation".
- 5) Install exhaust manifold cover (1) and connect ground wire (2).



I7RW011B0007-01

- 6) Install air cleaner assembly referring to "Air Cleaner Assembly Removal and Installation in Section 1D".
- 7) Install right and left side engine under covers.
- 8) Install engine hood referring to "Hood Removal and Installation in Section 9J".
- 9) Connect negative (-) cable at battery.
- 10) Check exhaust system for exhaust gas leakage.

Exhaust Pipe and Muffler Removal and Installation

S7RW0C1B06003

For replacement of exhaust pipe, be sure to hoist vehicle and observe WARNING under "Exhaust System Components" and the following.

⚠ CAUTION

Exhaust pipe have three way catalytic converter in it, it should not be exposed to any impulse.

Be careful not to drop it or hit it against something.

- Tighten bolts and nuts to specified torque when installing. Refer to "Exhaust System Components".
- The tightening order of exhaust No.1 pipe stiffener bolts when installing referring to "Exhaust System Components".
- After installation, start engine and check each joint of exhaust system for leakage.

Specifications

Tightening Torque Specifications

S7RW0C1B07001

Fastening part	Tightening torque			Note
	N·m	kgf-m	lb-ft	
Exhaust manifold bolt	Tighten 50 N·m (5.0 kgf-m, 36.5 lb-ft) by the specified procedure			
Exhaust manifold nut	Tighten 50 N·m (5.0 kgf-m, 36.5 lb-ft) by the specified procedure			

NOTE

The specified tightening torque is also described in the following.
“Exhaust System Components”

Reference:
For the tightening torque of fastener not specified in this section, refer to “Fasteners Information in Section 0A”.

Section 2

Suspension

CONTENTS

Precautions	2-1	
Precautions.....	2-1	
Precautions on Suspension	2-1	
Suspension General Diagnosis.....	2A-1	
Diagnostic Information and Procedures.....	2A-1	
Suspension, Wheels and Tires Symptom		
Diagnosis	2A-1	
Repair Instructions	2A-3	
Suspension System Inspection	2A-3	
Wheel Bearing Inspection	2A-3	
Front Suspension	2B-1	
General Description	2B-1	
Front Suspension Construction.....	2B-1	
Front Wheel Alignment Construction	2B-2	
Repair Instructions	2B-2	
Front Wheel Alignment Inspection and		
Adjustment	2B-2	
Camber and Caster Check	2B-3	
Steering Angle Check	2B-4	
Front Strut Assembly Components	2B-4	
Front Strut Assembly Removal and		
Installation	2B-5	
Front Strut Assembly Disassembly and		
Reassembly	2B-6	
Front Strut Assembly Check	2B-7	
Front Wheel Hub and Steering Knuckle		
Components.....	2B-8	
Front Wheel Hub, Steering Knuckle and		
Wheel Bearing Removal and Installation	2B-8	
Front Wheel Bearing and Wheel Hub		
Inspection.....	2B-12	
Suspension Control Arm Removal and		
Installation	2B-13	
Suspension Control Arm Bush Disassembly		
and Assembly	2B-14	
Suspension Control Arm / Steering Knuckle		
Check	2B-14	
Suspension Control Arm Bush Check.....	2B-14	
Suspension Control Arm Joint Check	2B-15	
Front Suspension Frame, Stabilizer Bar and/		
or Bush Components	2B-15	
Front Suspension Frame, Stabilizer Bar and/		
or Bush Removal and Installation (2WD		
Model)	2B-16	
Front Suspension Frame, Stabilizer Bar and/		
or Bush Removal and Installation (4WD		
Model)	2B-18	
Front Suspension Frame Check	2B-19	
Front Stabilizer Bar, Bush and/or Joint Check ..	2B-19	
Front Suspension Fasteners Check.....	2B-19	
Specifications.....	2B-20	
Tightening Torque Specifications	2B-20	
Special Tools and Equipment	2B-21	
Recommended Service Material	2B-21	
Special Tool	2B-21	
Rear Suspension	2C-1	
General Description	2C-1	
Rear Suspension Constructions.....	2C-1	
Repair Instructions	2C-2	
Rear Wheel Alignment Inspection	2C-2	
Rear Shock Absorber Removal and		
Installation	2C-2	
Rear Shock Absorber Inspection	2C-4	
Rear Shock Absorber Bush Inspection	2C-4	
Rear Coil Spring Removal and Installation	2C-4	
Spring Upper Seat / Spring Lower Seat		
Inspection.....	2C-6	
Rear Axle Removal and Installation (Rear		
Drum Brake Model)	2C-6	
Rear Axle Removal and Installation (Rear		
Disc Brake Model).....	2C-7	
Rear Axle and Coil Spring Inspection	2C-9	
Rear Axle Bush Inspection.....	2C-9	
Rear Wheel Hub Assembly Inspection.....	2C-9	
Rear Wheel Hub Assembly Removal and		
Installation (Rear Drum Brake Model).....	2C-10	
Rear Wheel Hub Assembly Removal and		
Installation (Rear Disc Brake Model).....	2C-12	
Rear Suspension Fasteners Inspection	2C-13	
Specifications.....	2C-14	
Tightening Torque Specifications	2C-14	
Wheels and Tires	2D-1	
Precautions.....	2D-1	
Precautions in Wheels and Tires Servicing.....	2D-1	

General Description	2D-1
Tires Description	2D-1
Wheels Description	2D-2
Irregular and/or Premature Wear Description	2D-3
Wear Indicators Description	2D-3
Radial Tire Waddle Description.....	2D-4
Radial Tire Lead / Pull Description.....	2D-5
Balancing Wheels Description	2D-5
Repair Instructions	2D-5
Wheel Discs Inspection.....	2D-5

Tires Inspection	2D-5
Wheel Balance Inspection and Adjustment.....	2D-5
Tire Rotation.....	2D-6
Wheel (with Tire) Removal and Installation.....	2D-6
Tire Mounting and Dismounting	2D-7
Tire Repair	2D-7
Specifications	2D-7
Wheels and Tires Specifications	2D-7
Tightening Torque Specifications.....	2D-7

Precautions

Precautions

Precautions on Suspension

S7RW0C2000001

Suspension Caution

Refer to "Suspension Caution in Section 00".

Wheels and Tires Caution

Refer to "Wheels and Tires Caution in Section 00".

General Precautions

Refer to "General Precautions in Section 00".

Vehicle Lifting Points

Refer to "Vehicle Lifting Points in Section 0A".

Fastener Caution

Refer to "Fastener Caution in Section 00".

Fastener Information

Refer to "Fasteners Information in Section 0A".

Brake Caution

Refer to "Brake Caution in Section 00".

Suspension General Diagnosis

Diagnostic Information and Procedures

Suspension, Wheels and Tires Symptom Diagnosis


S7RW0C2104001

Condition	Possible cause	Correction / Reference Item
Vehicle pulls (Leads)	Mismatched or uneven tires	Replace tires.
	Tires not adequately inflated	Adjust tire pressure.
	Broken or sagging coil springs	Replace coil springs.
	Radial tire lateral force	Replace tire.
	Disturbed wheel alignment	Check and adjust wheel alignment.
	Brake dragging in one road wheel	Repair brake.
	Loose, bent or broken front or rear suspension parts	Tighten or replace related suspension parts.
Abnormal or excessive tire wear	Sagging or broken coil springs	Replace coil springs.
	Tire out of balance	Adjust balance or replace tire.
	Disturbed wheel alignment	Check and adjust wheel alignment.
	Faulty strut (shock absorber)	Replace strut (shock absorber).
	Hard driving	Replace tires.
	Overloaded vehicle	Replace tires.
	Not rotated tires	Replace or rotate tires.
	Worn or loose wheel bearings	Replace wheel bearings.
	Wobbly wheel or tire	Replace wheel or tire.
	Tires not adequately inflated	Adjust tire pressure.
	Front suspension frame and/or suspension control arm are transformed	Check and replace.
Wheel tramp	Blister or bump on tire	Replace tire.
	Improper strut (shock absorber) action	Replace strut (shock absorber).
Shimmy, shake or vibration	Tire or wheel out of balance	Balance wheel or replace tire and/or wheel.
	Loosen wheel bearings	Replace wheel bearings.
	Worn tie-rod ends	Replace tie-rod ends.
	Worn lower ball joints	Replace suspension control arms.
	Excessive wheel runout	Repair or replace wheel and/or tire.
	Blister or bump on tire	Replace tire.
	Excessively loaded radial runout of tire / wheel assembly	Replace tire or wheel.
	Disturbed wheel alignment	Check and adjust wheel alignment.
	Loose or worn steering linkage	Tighten or replace steering linkage.
Abnormal noise, front end	Loose steering gear case bolts	Tighten steering gear case bolts.
	Worn, sticky or loose tie-rod ends, lower ball joints, tie-rod inside ball joints or drive shaft joints	Replace tie-rod ends, suspension arms, tie-rods or drive shaft joints.
	Damaged struts or mountings	Repair or replace struts or mountings.
	Worn suspension arm bushes	Replace suspension arm bushes.
	Loose stabilizer bar	Tighten bolts or nuts and/or replace bushes.
	Loose wheel bolts	Tighten wheel bolts.
	Loose suspension bolts or nuts	Tighten suspension bolts or nuts.
	Broken or damaged wheel bearings	Replace wheel bearings.
	Broken suspension springs	Replace suspension springs.
	Worn strut bearings	Replace strut bearings.
Low or uneven trim height See NOTE *1.	Malfunction of Power Steering System	Check and correct malfunction.
	Broken or sagging coil springs	Replace coil springs.
	Over loaded	Check loading.
	Incorrect coil springs	Replace coil springs.
Ride too soft	Tires not adequately inflated	Adjust tire pressure.
	Faulty strut (shock absorber)	Replace strut (shock absorber).

Condition	Possible cause	Correction / Reference Item
Suspension bottoms	Overloaded	<i>Check loading.</i>
	Faulty strut (shock absorber)	<i>Replace strut (shock absorber).</i>
	Incorrect, broken or sagging coil springs	<i>Replace coil springs.</i>
Body leans or sways in corners	Loose stabilizer bar	<i>Tighten stabilizer bar bolts or nuts, or replace bushes.</i>
	Faulty strut (shock absorber) or mounting	<i>Replace strut (shock absorber) or tighten mounting.</i>
	Broken or sagging coil springs	<i>Replace coil springs.</i>
	Overloaded	<i>Check loading.</i>
Cupped tires	Front struts defective	<i>Replace struts.</i>
	Worn wheel bearings	<i>Replace wheel bearings.</i>
	Excessive tire or wheel run-out	<i>Replace tire and/or wheel.</i>
	Worn ball joints	<i>Replace suspension control arms.</i>
	Tire out of balance	<i>Adjust tire balance.</i>

NOTE

***1: Right-to-left trim height ("H") difference should be within 15 mm (0.6 in.) with curb weight. (same with rear side.)**




I2RH01210001-01

Repair Instructions

Suspension System Inspection


S7RW0C2106001

- Inspect front struts and rear shock absorbers for evidence of oil leakage, dents or any other damage on sleeves; and inspect anchor ends for deterioration. Replace defective parts, if any.
- Check front and rear suspension systems for damaged, loose or missing parts; also for parts showing signs of wear or lack of lubrication. Repair or replace defective parts, if any.



I4RS0A020011-01

- Check front suspension arm ball joint stud dust seals for leakage, detachment, tear or any other damage. Replace defective boot, if any.




I4RS0A020012-01

Wheel Bearing Inspection

S7RW0C2106002

- 1) Check front wheel bearing for wear, damage, abnormal noise or rattles. For details, refer to "Front Wheel Bearing and Wheel Hub Inspection in Section 2B".
- 2) Check rear wheel bearing for wear, damage, abnormal noise or rattles. For details, refer to "Rear Wheel Hub Assembly Inspection in Section 2C".



I2RH01020023-01

Front Suspension


General Description

Front Suspension Construction

S7RW0C2201001

⚠ CAUTION

There are two types of front suspension mounting bolt. One is pre-coated with friction stabilizer. The other is not. Never reuse pre-coated bolt to prevent it from loosening. Be sure to replace pre-coated bolt with a new one whenever loosening once.



I7RW0C220007-01

[A]: Non-pre-coated bolt	7. Tie-rod	⌚(f) : 200 N·m (20.0 kgf-m, 145.0 lb-ft)
[B]: Pre-coated bolt with friction stabilizer	8. Front suspension frame	⌚(g) : 23 N·m (2.3 kgf-m, 17.0 lb-ft)
1. Front strut assembly	9. Suspension control arm	⌚(h) : 95 N·m (9.5 kgf-m, 69.0 lb-ft)
2. Front drive shaft	⌚(a) : 140 N·m (14.0 kgf-m, 101.5 lb-ft)	⌚(i) : 55 N·m (5.5 kgf-m, 40.0 lb-ft)
3. Steering knuckle	⌚(b) : 150 N·m (15.0 kgf-m, 108.5 lb-ft)	⊗ : Do not reuse.
4. Front wheel hub	⌚(c) : 50 N·m (5.0 kgf-m, 36.5 lb-ft)	F: Forward
5. Stabilizer joint	⌚(d) : 45 N·m (4.5 kgf-m, 32.5 lb-ft)	
6. Stabilizer bar	⌚(e) : 60 N·m (6.0 kgf-m, 43.5 lb-ft)	

2B-2 Front Suspension:

Front Wheel Alignment Construction

S7RW0C2201002

Among factors for front wheel alignment, only toe setting can be adjusted. Camber and caster are not adjustable. Therefore, should camber or caster be out of specification due to the damage caused by hazardous road conditions or collision, whether the damage is in body or in suspension should be determined and damaged body should be repaired or damaged suspension should be replaced.

Preliminary Checks Prior to Adjustment Front Wheel Alignment

Steering and vibration complaints are not always the result of improper wheel alignment. An additional item to be checked is the possibility of tire lead due to worn or improperly manufactured tires. "Lead" is the vehicle deviation from a straight path on a level road without hand pressure on the steering wheel. Refer to "Radial Tire Lead / Pull Description in Section 2D" in order to determine if the vehicle has a tire lead problem. Before making any adjustment affecting wheel alignment, the following checks and inspections should be made to ensure correctness of alignment readings and alignment adjustments:

- Check all tires for proper inflation pressures and approximately the same tread wear.
- Check for looseness of ball joints. Check tie-rod ends; if excessive looseness is noted, it must be corrected before adjusting.
- Check for run-out of wheels and tires.
- Check vehicle trim heights; if it is out of limit and a correction is needed, it must be done before adjusting toe.
- Check for looseness of suspension control arms.
- Check for loose or missing stabilizer bar attachments.
- Consideration must be given to excess loads, such as tool boxes. If this excess load is normally carried in vehicle, it should remain in vehicle during alignment checks.
- Consider condition of equipment being used to check alignment and follow manufacturer's instructions.
- Regardless of equipment used to check alignment, vehicle must be placed on a level surface.

NOTE

To prevent possible incorrect reading of toe, camber or caster, vehicle front and rear end must be moved up and down a few times before inspection.

Repair Instructions

Front Wheel Alignment Inspection and Adjustment

S7RW0C2206001

Toe Inspection and Adjustment


Preparation for toe inspection and adjustment.

- Place vehicle in unloaded state on level surface.
- Set steering wheel in straight state.
- Check that inflation pressure of each tire is adjusted properly and wheel is free from deflection.
- Check that each suspension part is free from bend, dent, wear or damage in any other form.
- Check that ground clearance at the right and left is just about the same.

Inspection

Measure toe with toe-in gauge (1).

If toe is not within specified value, adjust it at the tie-rod.




I2RH01220062-01

Toe (Total) ("b" – "a")**2WD:**

- Front: 1.0 ± 1.0 mm (0.0394 ± 0.0394 in.)

4WD:

- Front: 2.0 ± 1.0 mm (0.0787 ± 0.0394 in.)


**Adjustment****⚠ CAUTION**

- Make sure that rack boot is not twisted. Otherwise, rack boot may be broken.

- 1) Check tie-rod length referring to "Tie-Rod End Initial Position Setting in Section 6C".
If necessary, adjust tie-rod initial length.
- 2) Loosen tie-rod end lock nuts.
- 3) Tighten or loosen right and left tie-rods by same amount to align toe to specification.
- 4) After adjustment, tighten lock nuts to specified torque.

Tightening torque

Tie-rod end lock nut (a): 45 N·m (4.5 kgf-m, 32.5 lb-ft)



I3RM0A630030-01

Camber and Caster Check

S7RW0C2206020

Check camber and caster by camber caster kingpin gauge (1) and turning radius gauge (2). If measured value is out of specified value, check following items for damage, deformation and crack.

- Strut and component
- Suspension control arm and bush
- Suspension frame
- Wheel hub, steering knuckle or wheel bearing
- Vehicle body

Camber "a"**2WD:**

- Front: $-10' \pm 1^\circ$

4WD:

- Front: $+16' \pm 1^\circ$

Camber "b"**2WD:**



- Front: $3^\circ 40' \pm 2^\circ$

4WD:

- Front: $3^\circ 34' \pm 2^\circ$


NOTE

Camber and caster are not adjustable structure.

[A]**[B]**

I7RW0C220002-01

[A]: Camber (Front view)	F: Forward
[B]: Caster (Side view)	S: Body center
"c": 90°	T: Center line of wheel



I7RW0C220003-01

Steering Angle Check

S7RW0C2206021

When tie-rod or tie-rod end was replaced, adjust toe and then also steering angle with turning radius gauge. If measured value is out of specified value, check following items for damage, deformation and crack.

- Steering gear case assembly
- Strut and component
- Suspension control arm and bush
- Suspension frame
- Wheel hub, steering knuckle or wheel bearing
- Vehicle body

Steering angle

2WD:

- Inside: $36^{\circ} \pm 2^{\circ}$
 - Outside: $32^{\circ}6'$ (Reference)
- 4WD:
- Inside: $37.4^{\circ} \pm 2^{\circ}$
 - Outside: $32^{\circ}36'$ (Reference)

Reference information

Side slip

When checked with side slip tester, side slip should satisfy following specification.

Side slip (On one person)

IN 3.0 to 0 mm/m (IN 0.118 to 0 in./3.3 ft)

If side slip is greatly difference, front wheel alignment may not be correct.

Toe angle

When checked front toe angle with total wheel alignment tester or the like, refer to the following specification.

Toe angle (Each wheel)

2WD:

Front: IN $1' \pm 2'$


4WD:

Front: IN $7' \pm 2'$

If front toe angle is out of specification, measure toe with toe-in gauge and then adjust it at the tie-rod.

Front Strut Assembly Components

S7RW0C2206002



I7RW01220003-03

1. Front strut	6. Coil spring upper seat	11. Strut nut	(a) : 50 N·m (5.0 kgf-m, 36.5 lb-ft)
2. Coil spring	7. Strut bearing	12. Strut bracket bolt : Insert from vehicle front side.	(b) : 55 N·m (5.5 kgf-m, 40.0 lb-ft)

3. Bump stopper	8. Strut support	13. Strut bracket nut	 (c) : 140 N·m (14.0 kgf-m, 101.5 lb-ft)
4. Strut dust cover	9. Strut support lower nut	14. Stabilizer joint nut	 : Do not reuse.
5. Coil spring seat	10. Rebound stopper	15. Stabilizer joint	

Front Strut Assembly Removal and Installation


S7RW0C2206003

⚠ CAUTION

When rebound stopper and strut assembly were removed, check strut support lower nut for specified torque before installing strut assembly.

Removal

- 1) Remove hood rear seal (1), and then remove cowl top garnish (2) from vehicle.




I5RW0A220003-01

NOTE


When servicing component parts of strut assembly, beforehand loosen strut nut a little before removing strut assembly. This will make service work easier. Note that the nut must not be removed at this point.

- 2) Hoist vehicle, allowing front suspension to hang free.
- 3) Remove wheel and disconnect stabilizer joint (1) from strut bracket.
When loosening joint nut, hold stud with hexagon wrench (2).



I5RW0A220004-01

- 4) Remove brake hose mounting bolt (1). Remove brake hose (2) from bracket and wheel speed sensor harness (3) from strut bracket as shown in figure.
- 5) Remove strut bracket bolts and nuts (4).




I5RW0A220005-01

- 6) Remove strut nut (1), and remove rebound stopper (2).

NOTE

Hold strut by hand so that it will not fall off.



I4RS0A220006-01

- 7) Remove strut assembly.

Installation

⚠ CAUTION

Strut bracket nut is pre-coated with friction stabilizer. Never reuse the removed strut bracket nut. Otherwise, nut may loosen.

Install strut assembly by reversing removal procedure, noting the following instructions.

- Insert bolts in such direction as shown in figure.
- Tighten all fasteners to specified torque.

Tightening torque

Strut bracket nut (a): 140 N·m (14.0 kgf-m, 101.5 lb-ft)

Brake hose mounting bolt (c): 26 N·m (2.6 kgf-m, 19.0 lb-ft)

Stabilizer joint nut (d): 50 N·m (5.0 kgf-m, 36.5 lb-ft)

2B-6 Front Suspension:




- Lower hoist and vehicle in unloaded condition, tighten strut nut (b) to specified torque.

Tightening torque

Strut nut (b): 50 N·m (5.0 kgf-m, 36.5 lb-ft)

NOTE

Don't twist brake hose and wheel speed sensor harness when installing them.



I5RW0A220006-01

- Tighten wheel nut to specified torque.

Tightening torque

Wheel nut: 85 N·m (8.5 kgf-m, 61.5 lb-ft)

- After installation, confirm front wheel alignment.

Front Strut Assembly Disassembly and Reassembly


S7RW0C2206004

Disassembly

- 1) Attach special tool (A) to coil spring as shown. Turn special tool bolts alternately until coil spring tension is released. Rotate the strut around its axis to confirm that the coil spring is released or not.


Special tool

(A): 09943-25010



I5RW0A220007-01

- 2) While keeping coil spring compressed with special tools, remove strut support lower nut with hexagon wrench as shown figure.



I5RW0A220008-01


- 3) Disassemble front strut assembly.

Reassembly

- 1) Compress coil spring using special tool (spring compressor) until total length becomes about 280 mm (11.0 in.) as shown.

Length

"a": 280 mm (11.0 in.)




I5RW0A220009-01

U: Upper side (small dia.)
L: Lower side (large dia.)

- 2) Install compressed coil spring to strut, and place coil spring end (2) onto spring lower seat (1) as shown.


NOTE

End of coil spring must not interfere with step of spring lower seat.



I4RS0A220011-01

- 3) Install bump stopper and strut dust cover onto strut rod. For installing direction, refer to the figure in "Front Strut Assembly Components".
- 4) Pull strut rod as far up as possible and use care not to allow it to retract into strut.
- 5) Install spring seat on coil spring and then spring upper seat (1) aligning "OUT" mark (3) on spring upper seat and center of strut bracket (2).




I4RS0A220012-01

- 6) Install bearing (3), strut support (2) and strut support lower nut (1) in this sequence. Tighten strut support lower nut (1) to specified torque. When tightening strut support lower nut, hold stud with hexagon wrench.

Tightening torque

Strut support lower nut (a): 55 N·m (5.5 kgf-m, 40.0 lb-ft)




I5RW0A220010-02

Front Strut Assembly Check

S7RW0C2206005

- Inspect strut for oil leakage, damage or deformation. If defect is found, replace strut as an assembly unit, because it can not be disassembled.



I4RS0A220014-01


2B-8 Front Suspension:

- Inspect strut function referring to the following procedures:
 - 1) Check and adjust tire pressures as specified.
 - 2) Bounce vehicle body up and down 3 or 4 times continuously by pushing front end of the vehicle side body to check strut.
Also, note how many times vehicle body rebounds to stop after force application.
 - 3) Repeat the same procedure to the other strut to confirm that the both side struts equally respond.

- If conditions of struts are in doubt, compare them with known-good vehicle or strut.
- Inspect bearing for wear, abnormal noise or gripping. If defective, replace.
 - Inspect coil spring seat for cracks or deformation. If defective, replace.
 - Inspect bump stopper for deterioration. If defective, replace.
 - Inspect rebound stopper and strut mount for wear, cracks or deformation. If defective, replace.

Front Wheel Hub and Steering Knuckle Components

S7RW0C2206006



I7RW0C220004-01

1. Front wheel hub	4. Steering knuckle	7. Dust cover
2. Circlip	5. Drive shaft nut : Calk, after tightening.	(a) : 200 N·m (20.0 kgf-m, 145.0 lb-ft)
3. Wheel bearing : Face grooved rubber seal side to wheel hub.	6. Hub bolt	X : Do not reuse.

Front Wheel Hub, Steering Knuckle and Wheel Bearing Removal and Installation


S7RW0C2206007

CAUTION

When removing and installing steering knuckle assembly, be careful not to damage dust boots of control arm joint by drive shaft dust cover and brake dust cover.

Removal

- 1) Hoist vehicle and remove wheel.
- 2) Uncaulk drive shaft nut (1).
- 3) Depress foot brake pedal and hold it. Remove drive shaft nut (1).



I5JB0A220013-01

- 4) Remove caliper carrier bolts and then caliper (1) with carrier.


NOTE

Hang removed caliper with a wire hook or the like (3) so as to prevent brake hose (4) from bending, twisting or tension.

Do not depress brake pedal during caliper removal.

Don't operate brake pedal with caliper removed.

- 5) Pull brake disc (2) off by using two 8 mm bolts.



I5JB0A220014-01

- 6) Pull out wheel hub (1) with special tools.


Special tool

(A): 09943-17912

(B): 09942-15511

⚠ CAUTION


When wheel hub is removed, replace wheel bearing with new one.



I2RH01220028-01

- 7) Disconnect tie-rod end from steering knuckle referring to "Tie-Rod End Removal and Installation in Section 6C".

- 8) Remove wheel speed sensor (1) from knuckle.




I5RW0A220013-01

- 9) Loosen strut bracket nuts (1).

- 10) Remove ball joint bolt (4) and washer (3).


- 11) Remove strut bracket bolts (5) from strut bracket and then steering knuckle (2).



F: Forward

I7RW0C220005-01

- 12) Uncaulk and remove dust cover (1).




I2RH01220032-01

2B-10 Front Suspension:

- 13) Remove circlip from knuckle.
- 14) Using hydraulic press (1) and special tool, remove wheel bearing.

Special tool

- (A): 09913-75510
(B): 09943-37910




I5RW0A220014-01

- 15) Remove wheel bearing outside inner race (1).

Special tool

- (A): 09913-65810
(B): 09913-85230




I7RW01220005-01

- 16) Remove hub bolts (1) with copper hammer or hydraulic press.

⚠ CAUTION

Never remove bolt unless replacement is necessary.

Be sure to use a new bolt for replacement.



I7RW01220006-01

Installation

⚠ CAUTION


- **Never reuse wheel bearing and circlip. Otherwise, abnormal noise and abnormal vibration or any other abnormal condition may occur.**
- **Never reuse the removed strut bracket nut. Otherwise, nut may loosen.**

For installation, reverse removal procedure, noting the following instructions.

- 1) Face grooved rubber seal side (1) of new wheel bearing (2) upward as shown in figure and press-fit it into knuckle (3) using special tool.

Special tool


- (A): 09913-75510
(B): 09944-78220
(C): 09925-14520



I5RW0A220016-01


4. Encoder

- 2) Install new circlip (1).



I2RH01220037-01

- 3) Insert new hub bolt (1) in hub hole. Rotate hub bolt slowly to assure that serrations are aligned with those made by original bolt.




I7RW01220015-01

- 4) Drive in dust cover so that dimensions "a" and "b" become equal as shown in figure.


CAUTION

When drive in dust cover, be careful not to deform it.



I2RH01220038-01

- 5) Caulk more than 6 places with a punch.




I2RH01220039-01

- 6) Using special tool and hydraulic press, press fit wheel hub (1) into wheel bearing (2) (Face grooved rubber seal side to wheel hub).

Special tool

(A): 09913-75510




I7RW01220007-01

- 7) Apply grease lightly to end face of inner ring (1).

"A": Grease 99000-25121 (SUZUKI Super Grease H)


NOTE

Do not apply the grease to the encoder section to avoid the encoder malfunction.



I5RW0B220001-01

- 8) Install steering knuckle with wheel hub and bearing (1) so that foreign material should not enter wheel speed sensing point "a".



I7RW01220008-02

- | | |
|----|---------------|
| 2. | Wheel encoder |
| 3. | Drive shaft |

2B-12 Front Suspension:

- 9) Install ball joint bolt (1), washer (2), strut bracket bolts (4) and new nuts (3) from the direction shown in figure.
- 10) Tighten suspension arm ball joint bolt (2) to specified torque.


Tightening torque

Suspension arm ball joint bolt (a): 60 N·m (6.0 kgf-m, 43.5 lb-ft)

- 11) Tighten new strut bracket nuts (3) to specified torque.

Tightening torque


Strut bracket nut (b): 140 N·m (14.0 kgf-m, 101.5 lb-ft)



- 12) Install wheel speed sensor (1).

Tightening torque

Wheel speed sensor mounting bolt (a): 11 N·m (1.1 kgf-m, 8.0 lb-ft)



- 13) Connect tie-rod end to steering knuckle referring to "Tie-Rod End Removal and Installation in Section 6C".
- 14) Install brake disc (2) and brake caliper (3).
- 15) Tighten caliper carrier bolt to specified torque.

Tightening torque

Caliper carrier bolt: 85 N·m (8.5 kgf-m, 61.5 lb-ft)

- 16) Depress foot brake pedal and hold it there.
Tighten new drive shaft nut (1) to specified torque.

Tightening torque

Drive shaft nut (a): 200 N·m (20.0 kgf-m, 145.0 lb-ft)


⚠ CAUTION

Never reuse drive shaft nut (1).

- 17) Caulk drive shaft nut (1) as shown.

⚠ CAUTION

Be careful not to damage the drive shaft nut while caulking it. If it is damaged, replace it with new one.



- 18) Tighten wheel nuts to specified torque.

Tightening torque


Wheel nut: 85 N·m (8.5 kgf-m, 61.5 lb-ft)

- 19) Confirm front wheel alignment referring to "Front Wheel Alignment Inspection and Adjustment".

Front Wheel Bearing and Wheel Hub Inspection

S7RW0C2206022


- Check wheel bearing noise and smooth wheel rotation by rotating wheel. If defective, replace bearing.



- Check wear of wheel bearing. When measuring thrust play, apply a dial gauge to wheel hub as shown in figure.

Front wheel bearing thrust play

Limit: 0.1 mm (0.004 in.)



I8RW01220008-02

Suspension Control Arm Removal and Installation


S7RW0C2206009

⚠ CAUTION

When removing and installing steering knuckle assembly, be careful not to damage dust boots of control arm joint by drive shaft dust cover and brake dust cover.

Removal

- 1) Hoist vehicle and remove wheel.
- 2) Remove steering knuckle with front wheel hub referring to "Front Wheel Hub, Steering Knuckle and Wheel Bearing Removal and Installation".
- 3) Remove suspension control arm bolts (1).
- 4) Remove suspension control arm (2).



I5RW0A220019-01


Installation

⚠ CAUTION

Suspension control arm bolt is pre-coated with friction stabilizer. Never reuse the removed bolt.

Otherwise, bolt may loosen.

- 1) Install suspension control arm as shown but tighten suspension control arm bolts (1) only temporarily.



I5RW0A220020-01

- 2) Install steering knuckle with front wheel hub referring to "Front Wheel Hub, Steering Knuckle and Wheel Bearing Removal and Installation".
- 3) Install wheel and tighten wheel nuts to specified torque.


Tightening torque

Wheel nut: 85 N·m (8.5 kgf-m, 61.5 lb-ft)

- 4) Lower hoist with vehicle in unloaded condition, tighten control arm bolts to specified torque.

Tightening torque

Suspension control arm bolt (a): 95 N·m (9.5 kgf-m, 69.0 lb-ft)



I5RW0A220021-01


- 5) Confirm front wheel alignment referring to "Front Wheel Alignment Inspection and Adjustment".

Suspension Control Arm Bush Disassembly and Assembly

S7RW0C2206010

Disassembly

- 1) Cut off bush flange (rubber) (1) with knife.




I4RS0B220019-01

- 2) Push out bush by using hydraulic press (2) and special tools.

Special tool

(A): 09943-76310

(B): 09913-75821



I4RS0B220020-01

Assembly

⚠ CAUTION

Be sure to use new bush.

- 1) Front bush
Press-fit front bush (1) by using special tools and press (2).


Special tool

(A): 09943-76310

(B): 09913-75821


NOTE

- Before installing bush, apply soap water on its circumference to facilitate bush installation.



I4RS0B220021-01

- 2) Press-fit bush (1) so that dimensions "A" and "B" in figure become equal.



I4RS0A220033-01

Suspension Control Arm / Steering Knuckle Check


S7RW0C2206011

Inspect for cracks, deformation or damage.
If defective, replace.

Suspension Control Arm Bush Check

S7RW0C2206012

Inspect for damage, wear or deterioration.
If defective, replace.



I4RS0B220022-01

Suspension Control Arm Joint Check


S7RW0C2206013

- Check smooth rotation of ball stud.
- Check damages of ball stud.
- Check damages of dust cover.

NOTE

Suspension control arm and arm joint cannot be separated.


If there is any damage to either parts, control arm must be replaced as a complete unit.



I4RS0B220023-01

Front Suspension Frame, Stabilizer Bar and/or Bush Components

S7RW0C2206014



I7RW0C220008-01

[A]: Non-pre-coated bolt	3. Stabilizer mounting bracket	7. Front suspension frame	⚙️(c) : 150 N·m (15.0 kgf·m, 108.5 lb·ft)
[B]: Pre-coated bolt with friction stabilizer	4. Stabilizer bar mounting bracket bolt	8. Front suspension frame mounting bolt	❌ : Do not reuse.
1. Stabilizer bar	5. Suspension control arm	⚙️(a) : 23 N·m (2.3 kgf·m, 17.0 lb·ft)	
2. Stabilizer bush	6. Suspension control arm mounting bolt	⚙️(b) : 95 N·m (9.5 kgf·m, 69.0 lb·ft)	

Front Suspension Frame, Stabilizer Bar and/or Bush Removal and Installation (2WD Model)

S7RW0C2206015

⚠ WARNING


When supporting and installing front suspension frame, be sure to apply some supporting equipment (such as mission jack) at well-balanced position in the center section of front suspension frame so as to prevent from its drop. Otherwise drop and injure.

⚠ CAUTION

When removing and installing suspension control arm, be careful not to damage dust boots of suspension control arm joint by drive shaft dust cover and brake dust cover.


Removal

- 1) Disconnect negative (–) cable at battery.
- 2) Remove air cleaner assembly referring to “Air Cleaner Assembly Removal and Installation in Section 1D”.
- 3) Remove hood referring to “Hood Removal and Installation in Section 9J”.
- 4) Disconnect steering lower shaft from pinion shaft referring to “Steering Lower Shaft Removal and Installation in Section 6B”.
- 5) Hoist vehicle and remove front wheels.
- 6) Remove exhaust No.1, No.2 and center pipes referring to “Exhaust System Components in Section 1K”.
- 7) Remove suspension control arms and disconnect stabilizer joints.
- 8) Disconnect tie-rod end from steering knuckle referring to “Tie-Rod End Removal and Installation in Section 6C”.
- 9) Disconnect torque sensor connector and P/S motor connector from steering gear case referring to “Steering Gear Case Assembly Removal and Installation in Section 6C”.
- 10) Support engine assembly by using chain hoist (1).




I7RW01220010-01

- 11) Support front suspension frame (2) with mission jack (1).




I4RS0A220042-01

- 12) Remove engine rear mounting, mounting member bolt and front suspension frame mounting bolts (1).



I7RW01220012-01

- 13) Lower front suspension frame and steering gear case.
- 14) Remove steering gear case assembly from front suspension frame.
- 15) Remove stabilizer bar (1) with stabilizer bush from suspension frame (2).



I7RW01220016-01

Installation

⚠ CAUTION

There are two types of front suspension mounting bolt. One is pre-coated with friction stabilizer. The other is not. Never reuse pre-coated bolt to prevent it from loosening. Be sure to replace pre-coated bolt with a new one whenever loosening once.

- 1) Install stabilizer bar (1), stabilizer bush (2) and stabilizer mounting bracket (3) to front suspension frame as shown in figure while ensuring that stabilizer is centered, side-to-side.

NOTE

- For proper installing direction of stabilizer mounting bracket (3), place oblong to rear and circular hole to front.
- For correct installation of stabilizer bar, side-to-side, be sure that stopper ring (4) on stabilizer bar aligns with stabilizer bush, both right and left, as shown in figure.


- 2) Tighten stabilizer bar mounting bracket bolts to specified torque.

NOTE

Tighten stabilizer bar mounting bracket rear bolt (5) after front bolt (6).

Tightening torque


Stabilizer bar mounting bracket bolt (a): Tighten 23 N·m (2.3 kgf-m, 17.0 lb-ft) to specified procedure



I5RW0A220029-02


F. Forward

- 3) Install steering gear case assembly to front suspension frame referring to "Steering Gear Case Assembly Removal and Installation in Section 6C".
- 4) Support front suspension frame (2) with mission jack (1) and jack up it.



I4RS0A220042-01

- 5) Align lugs (1) (right and left) of front suspension frame with whole (2) in vehicle body.



I5RW0A220030-01

2B-18 Front Suspension:

- 6) Tighten front suspension frame bolts to specified torque.

Tightening torque


Front suspension frame mounting bolt (Non-pre-coated bolt): 150 N·m (15.0 kgf-m, 108.5 lb-ft)

Front suspension frame mounting bolt (Pre-coated bolt with friction stabilizer): 95 N·m (9.5 kgf-m, 69.0 lb-ft)

- 7) Remove mission jack from front suspension frame.
- 8) Install engine rear mounting and tighten mounting member bolts referring to "Engine Mountings Components in Section 1D".
- 9) Remove chain hoist from engine assembly.
- 10) Connect torque sensor connector and P/S motor connector to steering gear case referring to "Steering Gear Case Assembly Removal and Installation in Section 6C".
- 11) Install suspension control arms referring to "Suspension Control Arm Removal and Installation".
- 12) Install stabilizer joint (1) and tighten nut to specified torque.
When tightening nut, hold stud with hexagon wrench (2).

Tightening torque

Stabilizer joint nut (a): 50 N·m (5.0 kgf-m, 36.5 lb-ft)



I5RW0A220033-01

- 13) Connect tie-rod end to steering knuckle referring to "Tie-Rod End Removal and Installation in Section 6C".
- 14) Install exhaust No.1, No.2 and center pipe referring to "Exhaust System Components in Section 1K".
- 15) Install wheel and tighten nut to specified torque.

Tightening torque

Wheel nut: 85 N·m (8.5 kgf-m, 61.5 lb-ft)

- 16) Install air cleaner assembly referring to "Air Cleaner Assembly Removal and Installation in Section 1D".
- 17) Install hood referring to "Hood Removal and Installation in Section 9J".
- 18) Lower hoist and vehicle in unloaded condition, tighten suspension control arm bolts to specified torque.

Tightening torque

Suspension control arm bolt: 95 N·m (9.5 kgf-m, 69.0 lb-ft)

- 19) Connect negative (-) cable at battery.
- 20) Confirm front wheel alignment referring to "Front Wheel Alignment Inspection and Adjustment".

Front Suspension Frame, Stabilizer Bar and/or Bush Removal and Installation (4WD Model)

S7RW0C2206016

⚠ WARNING


When supporting and installing front suspension frame, be sure to apply some supporting equipment (such as mission jack) at well-balanced position in the center section of front suspension frame so as to prevent from its drop. Otherwise drop and injure.

⚠ CAUTION

When removing and installing suspension control arm, be careful not to damage dust boots of suspension control arm joint by drive shaft dust cover and brake dust cover.

Removal

- 1) Remove front suspension frame, steering gear case assembly and transfer all together referring to "Transfer Dismounting and Remounting in Section 3C".
- 2) Remove steering gear case assembly from front suspension frame.
- 3) Remove stabilizer bar (1) with bush from front suspension frame (2).



I7RW01220016-01

Installation

⚠ CAUTION

There are two types of front suspension mounting bolt. One is pre-coated with friction stabilizer. The other is not. Never reuse pre-coated bolt to prevent it from loosening. Be sure to replace pre-coated bolt with a new one whenever loosening once.


Install front suspension frame by reversing removal procedure, noting the following instruction.

- Tighten all fastener to specified torque referring to "Front Suspension Construction".

Front Suspension Frame Check

S7RW0C2206017

Inspect for cracks, deformation or damage.
If defective, replace.




I5RW0A220034-01

Front Stabilizer Bar, Bush and/or Joint Check

S7RW0C2206018

Stabilizer Bar


Inspect for damage or deformation.
If defective, replace.



I5RW0A220035-01

Stabilizer Bush

Inspect for damage, wear or deterioration.
If defective, replace.



I5RW0A220036-01


Stabilizer Joint

- 1) Check for smooth rotation.
- 2) Check damages of ball stud.
- 3) Check damages of dust cover.

NOTE

Stabilizer joint (1) cannot be disassembled.

If there is any damage to either parts, stabilizer joint must be replaced as a complete unit.



I4RH01220007-01

Front Suspension Fasteners Check

S7RW0C2206019

Check each bolt and nut fastening suspension parts for tightness. Tighten loose one, if any, to specified torque, referring to "Front Suspension Construction".

Specifications

Tightening Torque Specifications

S7RW0C2207001

Fastening part	Tightening torque			Note
	N·m	kgf·m	lb·ft	
Tie-rod end lock nut	45	4.5	32.5	🔩
Strut bracket nut	140	14.0	101.5	🔩 / 🔩
Brake hose mounting bolt	26	2.6	19.0	🔩
Stabilizer joint nut	50	5.0	36.5	🔩 / 🔩
Strut nut	50	5.0	36.5	🔩
Wheel nut	85	8.5	61.5	🔩 / 🔩 / 🔩 / 🔩
Strut support lower nut	55	5.5	40.0	🔩
Suspension arm ball joint bolt	60	6.0	43.5	🔩
Wheel speed sensor mounting bolt	11	1.1	8.0	🔩
Caliper carrier bolt	85	8.5	61.5	🔩
Drive shaft nut	200	20.0	145.0	🔩
Suspension control arm bolt	95	9.5	69.0	🔩 / 🔩
Stabilizer bar mounting bracket bolt	Tighten 23 N·m (2.3 kgf·m, 17.0 lb·ft) to specified procedure			🔩
Front suspension frame mounting bolt (Non-pre-coated bolt)	150	15.0	108.5	🔩
Front suspension frame mounting bolt (Pre-coated bolt with friction stabilizer)	95	9.5	69.0	🔩

NOTE

The specified tightening torque is also described in the following.

“Front Suspension Construction”

“Front Strut Assembly Components”

“Front Wheel Hub and Steering Knuckle Components”

“Front Suspension Frame, Stabilizer Bar and/or Bush Components”

Reference:

For the tightening torque of fastener not specified in this section, refer to “Fasteners Information in Section 0A”.

Special Tools and Equipment











Recommended Service Material

S7RW0C2208001

Material	SUZUKI recommended product or Specification	Note
Grease	SUZUKI Super Grease H	P/No.: 99000-25121

Special Tool

S7RW0C2208002


09913-65810 Crankshaft bearing puller 🔧		09913-75510 Bearing installer 🔧 / 🔧 / 🔧	
09913-75821 Bearing installer attachment 🔧 / 🔧		09913-85230 Bearing remover tool 🔧	
09925-14520 Bearing and oil seal installer (80 x 50 mm) 🔧		09942-15511 Sliding hammer 🔧	
09943-17912 Wheel hub remover 🔧		09943-25010 Spring compressor 🔧	
09943-37910 Bearing installer & remover 🔧		09943-76310 Bush remover 🔧 / 🔧	
09944-78220 Bearing installer support 🔧			

Rear Suspension

General Description

Rear Suspension Constructions

S7RW0C2301001



I7RW0C230001-01

F: Forward	6. Upper bush	16. Rear wheel hub assembly
[A]: 2WD model	7. Vehicle body	17. Rear drive shaft nut
[B]: 4WD model	8. Rear shock absorber	18. Rear drive shaft
[C]: Rear drum brake model	9. Lower washer	(a) : 73 N·m (7.3 kgf-m, 53.0 lb-ft)
[D]: Rear disc brake model	10. Lower nut	(b) : 30 N·m (3.0 kgf-m, 22.0 lb-ft)
1. Coil spring	11. Rear axle	(c) : 175 N·m (17.5 kgf-m, 127.0 lb-ft)
2. Spring upper seat	12. Rear hub bolt	(d) : 90 N·m (9.0 kgf-m, 65.0 lb-ft)
3. Spring lower seat	13. Rear axle bolt	: Do not reuse.
4. Upper nut	14. Brake back plate	
5. Upper washer	15. Brake dust cover	

Repair Instructions

Rear Wheel Alignment Inspection

S7RW0C2306013

Measure toe and camber referring to "Inspection" under "Front Wheel Alignment Inspection and Adjustment in Section 2B".

NOTE

Rear suspension is not adjustable structure.

Toe (total)

Rear: $\text{IN } 5.0 \pm 5.0 \text{ mm (IN } 0.1969 \pm 0.1969 \text{ in.)}$

Camber

Rear: $-1^\circ \pm 1^\circ$

If measured value is out of specified value, check following items for damage, deformation and crack.

- Rear axle (torsion beam)
- Wheel hub or wheel bearing
- Vehicle body

Reference information

Toe angle

When checked rear toe angle with total wheel alignment tester or the like, refer to the following specification.

Toe angle (Each wheel)


Rear: $\text{IN } 17' \pm 17'$

Rear Shock Absorber Removal and Installation

S7RW0C2306002


Removal

- 1) Hoist vehicle and remove rear wheel.
- 2) For hatchback model, remove access hole cover (1) in quarter inner trim (2).





I5RW0A230002-02

- 3) For sedan model, remove quarter inner trim (1).




I7RW0C230002-01

- 4) Support rear axle by using floor jack to prevent it from lowering.
- 5) Remove absorber lower nut (1) and lower washer.
- 6) Remove absorber upper nut (2). Then remove shock absorber (3), upper washers.



I5RW0A230003-01

- 7) Remove absorber upper bushes (1).



I5RW0A230004-01


2C-3 Rear Suspension:

Installation

- 1) Install absorber upper bushes (1).

NOTE


For proper installing direction of absorber upper bushes (1), refer to the figure.



- 2) Install shock absorber (1), upper washers (2). Tighten new rear shock absorber upper nut (4) and lower nut (5) temporarily at this step.

⚠ CAUTION

Use new rear shock absorber upper nut. Otherwise, nut may loosen.



- 3) Remove floor jack from rear axle.
- 4) Install rear wheel and tighten wheel nuts to specified torque.

Tightening torque



Wheel nut: 85 N·m (8.5 kgf-m, 61.5 lb-ft)

- 5) Lower hoist and bounce vehicle up and down several times to stabilize suspension.
- 6) Tighten nuts to specified torque.

Tightening torque

Rear shock absorber upper nut (a): 30 N·m (3.0 kgf-m, 22.0 lb-ft)

Rear shock absorber lower nut (b): 90 N·m (9.0 kgf-m, 65.0 lb-ft)



I5RW0A230006-01

- 7) For hatchback model, install access hole cover in quarter inner trim.
- 8) For sedan model, install quarter inner trim.

Rear Shock Absorber Inspection


S7RW0C2306003

- Inspect for deformation or damage.
 - Inspect bushes for wear or damage.
 - Inspect for evidence of oil leakage.
- Replace any defective parts.

⚠ WARNING

When handling rear shock absorber (1) in which high-pressure gas is sealed, make sure to observe the following precautions.

- Don't disassemble it.
 - Don't put it into the fire.
 - Don't store it where it gets hot.
 - Before disposing it, be sure to drill a hole (approximately 3 mm (0.12 in.) diameter) (2) in it where indicated by arrow in the figure and let gas and oil out.
- Be sure to wear eye shield since the gas itself is harmless but the absorber drill hole debris maybe blown out.



I5RW0A230007-01

Rear Shock Absorber Bush Inspection

S7RW0C2306004

Inspect for cracks, deformation or damage. Replace any defective parts.



I4RS0A230008-01

Rear Coil Spring Removal and Installation

S7RW0C2306005

⚠ CAUTION


Removal and Installation both coil springs (right and left) at the same time to avoid rear axle twisting and other damage.

Removal

- 1) Hoist vehicle and remove rear wheels.
- 2) Dismount rear differential (4WD model) referring to "Rear Differential Dismounting and Remounting in Section 3B".
- 3) Remove rear fender lining (1) and then loosen rear axle bolt (2) a little.


⚠ CAUTION

Do not reuse rear axle bolt. Otherwise, bolt may loosen.



I5RW0A230008-01

- 4) Support both ends of rear axle (1) by using two floor jacks (2).



I5RW0A230009-01

2C-5 Rear Suspension:


- 5) Detach each lower end (2) of shock absorbers (1) (right and left) from rear axle.
- 6) Lower rear axle gradually as far down as the coil spring can be removed.

⚠ CAUTION


Be careful not to lower rear axle down too much.

It may cause damage to brake flexible hose, wheel speed sensor lead wire and parking brake cable.

- 7) Remove coil spring (3).



- 8) Remove spring upper seat (1) from vehicle body and lower seat (2) from rear axle.




I5RW0A230011-01

Installation

⚠ CAUTION


Install spring upper seat (1) and spring low seat (2) to specified direction. Otherwise noise may occur from coil spring while the vehicle is moving.

- 1) Install spring upper seat (1) to vehicle body and lower seat (2) to rear axle.
- 2) Install coil spring (3) on spring lower seat (2) of rear axle and place coil spring end (4) onto spring lower seat (2) as shown in figure.



[A]: Left side	F: Forward
[B]: Right side	"a": 10 mm max
U: Upward	

- 3) Jack up rear axle and then install shock absorbers (1) lower end to rear axle. Install washers and tighten shock absorber lower nuts (2) temporarily at this step.



I4RS0A230012-01

- 4) Remove floor jacks from rear axle.
- 5) Remount rear differential (4WD model) referring to "Rear Differential Dismounting and Remounting in Section 3B".
- 6) Install wheel and tighten wheel nuts to specified torque.

Tightening torque

Wheel nut: 85 N·m (8.5 kgf-m, 61.5 lb-ft)

- 7) Lower hoist and bounce vehicle up and down several times to stabilize suspension.
- 8) Tighten absorber lower nuts and rear axle bolts to specified torque.

NOTE

When tightening these nuts and bolts, be sure that vehicle is not on hoist and in unloaded condition.

Tightening torque

Rear shock absorber lower nut: 90 N·m (9.0 kgf-m, 65.0 lb-ft)


Rear axle bolt: 73 N·m (7.3 kgf-m, 53.0 lb-ft)

- 9) Install rear fender lining.

Spring Upper Seat / Spring Lower Seat Inspection

S7RW0C2306006

Inspect for cracks, deformation or damage.
Replace any defective part.



I4RS0A230015-01

Rear Axle Removal and Installation (Rear Drum Brake Model)


S7RW0C2306014

⚠ CAUTION

**Do not drop brake fluid onto painted surface.
Painted surfaces will be damaged.**


Removal

- 1) Hoist vehicle and remove rear wheels.
- 2) Remove rear brake drums.
- 3) Disconnect brake pipes (1) from brake hoses (2) and remove E-rings (3).



I5RW0A230013-01

- 4) Remove rear wheel hubs referring to Step 2) to 6) of "Removal" under "Rear Wheel Hub Assembly Removal and Installation (Rear Drum Brake Model)".
- 5) Remove exhaust center pipe.
- 6) Remove coil springs referring to "Rear Coil Spring Removal and Installation".
- 7) Disconnect wheel speed sensor clamps (1) and parking brake cable nuts (2) from rear axle.



I5RW0A230015-01

- 8) While supporting rear axle (1) at both ends remove rear axle bolts and then remove rear axle from chassis by lowering floor jack gradually.
- 9) Remove brake pipes from rear axle, if necessary.

Installation

- 1) Install brake pipes to rear axle, if removed.
- 2) Place rear axle on floor jacks.
Then install rear axle and new rear axle bolts (1) and tighten bolts temporarily.




I5RW0A230017-01

2C-7 Rear Suspension:

- 3) Install coil springs referring to "Rear Coil Spring Removal and Installation".
- 4) For 4WD model, install rear differential, propeller shaft and rear drive shaft referring to "Rear Differential Dismounting and Remounting in Section 3B".
- 5) Install exhaust center pipe.
- 6) Install rear wheel hubs referring to Step 2) to 6) of "Installation" under "Rear Wheel Hub Assembly Removal and Installation (Rear Drum Brake Model)".
- 7) Connect brake flexible hoses (1) to bracket on rear axle with E-rings (2) and tighten brake pipe flare nuts (3) to specified torque.

Tightening torque

Brake pipe flare nut (a): 16 N·m (1.6 kgf-m, 11.5 lb-ft)




I5RW0A230019-01

- 8) Install wheel speed sensor clamps (2) and tighten parking brake cable nuts (1) to specified torque.

Tightening torque

Parking brake cable clamp nut (a): 26 N·m (2.6 kgf-m, 19.0 lb-ft)



I5RW0A230020-01

- 9) Install brake drums.
- 10) Fill reservoir with brake fluid and bleed brake system. For bleeding operation, see "Air Bleeding of Brake System in Section 4A".
- 11) Install wheel and tighten wheel nuts to specified torque.

Tightening torque

Wheel nut: 85 N·m (8.5 kgf-m, 61.5 lb-ft)

- 12) Adjust parking brake cable. For adjustment, refer to "Parking Brake Inspection and Adjustment in Section 4D".
- 13) Lower hoist and bounce vehicle up and down several times to stabilize suspension.
- 14) Tighten shock absorber lower nuts and rear axle bolts to specified torque.

NOTE

When tightening these nuts and bolts, be sure that vehicle is not on hoist and in unloaded condition.

Tightening torque

Rear shock absorber lower nut: 90 N·m (9.0 kgf-m, 65.0 lb-ft)

Rear axle bolt: 73 N·m (7.3 kgf-m, 53.0 lb-ft)

- 15) Check to ensure that brake drum is free from dragging and proper braking is obtained.
- 16) Perform brake test (foot brake and parking brake).
- 17) Check each installed part for fluid leakage.

Rear Axle Removal and Installation (Rear Disc Brake Model)


S7RW0C2306015

⚠ CAUTION

Do not allow brake fluid to get on painted surfaces. Painted surface will be damaged.


Removal

- 1) Hoist vehicle and remove rear wheels.
- 2) Remove exhaust center pipe and muffler.
- 3) Remove rear brake caliper, brake flexible hose and parking brake cable referring to "Rear Disc Brake Caliper Removal and Installation: Disc in Section 4C".
- 4) Disconnect brake pipes (1) from brake hoses (2) and remove E-rings (3).



I5RW0A230013-01

- 5) Disconnect rear wheel speed sensor connectors and then remove rear wheel hubs referring to "Removal" under "Rear Wheel Hub Assembly Removal and Installation (Rear Disc Brake Model)".
- 6) For 4WD model, remove propeller shaft, rear drive shaft and rear differential referring to "Rear Differential Dismounting and Remounting in Section 3B".
- 7) Remove coil springs referring to "Rear Coil Spring Removal and Installation".
- 8) Disconnect wheel speed sensor clamps (1) and parking brake cable nuts (2) from rear axle.



I5RW0A230015-01

- 9) While supporting rear axle (1) at both ends remove rear axle bolts and then remove rear axle from chassis by lowering floor jack gradually.
- 10) Remove brake pipes from rear axle, if necessary.

Installation

- 1) Install brake pipes to rear axle, if removed.
- 2) Place rear axle on floor jacks.
Then install rear axle and new rear axle bolts (1) and tighten bolts temporarily.




I5RW0A230017-01

- 3) Install coil springs referring to "Rear Coil Spring Removal and Installation".
- 4) For 4WD model, install rear differential, propeller shaft and rear drive shaft referring to "Rear Differential Dismounting and Remounting in Section 3B".
- 5) Install rear wheel hubs referring to Step 2) to 4) of "Installation" under "Rear Wheel Hub Assembly Removal and Installation (Rear Disc Brake Model)".
- 6) Connect brake flexible hoses (1) to bracket on rear axle with E-rings (2) and tighten brake pipe flare nuts (3) to specified torque.

Tightening torque

Brake pipe flare nut (a): 16 N·m (1.6 kgf-m, 11.5 lb-ft)




I5RW0A230019-01

- 7) Install rear brake caliper, brake flexible hose and parking brake cable referring to "Rear Disc Brake Caliper Removal and Installation: Disc in Section 4C".
- 8) Install wheel speed sensor clamps (2) and tighten parking brake cable nuts (1) to specified torque.

Tightening torque

Parking brake cable clamp nut (a): 26 N·m (2.6 kgf-m, 19.0 lb-ft)



I5RW0A230020-01

2C-9 Rear Suspension:

- 9) Install exhaust center pipe and muffler.
- 10) Fill reservoir with brake fluid and bleed brake system. For bleeding operation, see "Air Bleeding of Brake System in Section 4A".
- 11) Install wheel and tighten wheel nuts to specified torque.

Tightening torque

Wheel nut: 85 N·m (8.5 kgf-m, 61.5 lb-ft)

- 12) Adjust parking brake cable. For adjustment, refer to "Parking Brake Inspection and Adjustment in Section 4D".
- 13) Lower hoist and bounce vehicle up and down several times to stabilize suspension.
- 14) Tighten shock absorber lower nuts and rear axle bolts to specified torque.

NOTE

When tightening these nuts and bolts, be sure that vehicle is not on hoist and in unloaded condition.

Tightening torque

Rear shock absorber lower nut: 90 N·m (9.0 kgf-m, 65.0 lb-ft)


Rear axle bolt: 73 N·m (7.3 kgf-m, 53.0 lb-ft)

- 15) Perform brake test (foot brake and parking brake).
- 16) Check each installed part for fluid leakage.

Rear Axle and Coil Spring Inspection

S7RW0C2306016

- Inspect for cracks, deformation or damage.
 - Inspect bush for damage, wear or breakage.
- Replace any defective part.



I5RW0A230022-01

Rear Axle Bush Inspection

S7RW0C2306017


Inspect for cracks, deformation or damage. If necessary, replace rear axle assembly.

Rear Wheel Hub Assembly Inspection

S7RW0C2306018

- Check noise and smooth rotation of wheel by rotating wheel.

If it is defective, replace wheel hub assembly.




I8RW01230001-01

- Measure thrust play of wheel hub using dial gauge as shown in figure. When the thrust play exceeds limit, replace wheel hub assembly.

Rear wheel hub thrust play limit

"a": 0.1 mm (0.004 in.)



I8RW01230004-01



Rear Wheel Hub Assembly Removal and Installation (Rear Drum Brake Model)

S7RW0C2306019

⚠ CAUTION



Do not allow brake fluid to get on painted surfaces. Painted surface will be damaged.

- 1) Hoist vehicle and remove rear wheel.
- 2) Pull up parking brake lever.
Remove rear drive shaft (4WD model) referring to "Rear Drive Shaft Assembly Removal and Installation: Rear in Section 3A".
- 3) Remove brake drum and rear brake shoe.
- 4) Disconnect brake pipe flare nut (1) from wheel cylinder (3) and put bleeder plug cap (4) onto pipe (2) to prevent fluid from spilling.



I5RW0A230024-01

- 5) Disconnect wheel speed sensor connector (1) (4WD model).
- 6) Remove wheel speed sensor (3) (2WD model).
- 7) Remove brake back plate (2) and rear wheel hub from rear axle.



I8RW01230005-01

[A]: 4WD model


[B]: 2WD model

- 8) If necessary, remove wheel stud bolts (1) with copper hammer or hydraulic press.

⚠ CAUTION

Never remove bolt unless replacement is necessary.

Be sure to use a new bolt for replacement.




I5JB0A220016-01

Installation

⚠ CAUTION

Rear hub bolt is pre-coated with friction stabilizer. Never reuse the removed bolt. Otherwise, bolt may loosen.

- 1) Insert wheel stud bolt (1) in hub hole. Rotate wheel stud bolt slowly to assure that serrations are aligned with those made by original bolt.



I5JB0A220017-01

- 2) Install brake back plate, rear wheel hub and new rear hub bolts and then tighten rear hub bolts to specified torque.



Tightening torque

Rear hub bolt (a): 73 N·m (7.3 kgf-m, 53.0 lb-ft)

- 3) Connect wheel speed sensor connector (1) (4WD model).
- 4) Install wheel speed sensor (2) and tighten wheel speed sensor bolt to specified torque (2WD model).

Tightening torque

Wheel speed sensor bolt (b): 11 N·m (1.1 kgf-m, 8.0 lb-ft)



I8RW01230006-01


[A]: 4WD model

[B]: 2WD model

- 5) Connect brake pipe (1) to wheel cylinder and tighten brake pipe flare nut to specified torque.

Tightening torque

Brake pipe flare nut (a): 16 N·m (1.6 kgf-m, 11.5 lb-ft)



I5RW0A230018-01


- 6) Install brake drum referring to Step 1) and 2) of "Installation" under "Rear Brake Drum Removal and Installation: Drum in Section 4C".
- 7) Pull up parking brake lever.
Install new rear drive shaft nut (1) to specified torque, and then caulk drive shaft nut (1) (4WD model).

⚠ CAUTION

- **Never reuse rear drive shaft nut.**
- **Be careful not to damage the rear drive shaft nut while caulking it. If it is damaged, replace it with new one.**

Tightening torque

Drive shaft nut (a): 175 N·m (17.5 kgf-m, 127.0 lb-ft)



I7RW01230012-01

- 8) Fill reservoir with brake fluid and bleed brake system. For bleeding operation, see "Air Bleeding of Brake System in Section 4A".
- 9) Install wheel and tighten wheel nuts to specified torque.

Tightening torque

Wheel nut: 85 N·m (8.5 kgf-m, 61.5 lb-ft)



- 10) Adjust parking brake cable. For adjustment, refer to "Parking Brake Inspection and Adjustment in Section 4D".
- 11) Check to ensure that brake drum is free from dragging and proper braking is obtained.
- 12) Perform brake test (foot brake and parking brake).
- 13) Check each installed part for fluid leakage.

Rear Wheel Hub Assembly Removal and Installation (Rear Disc Brake Model)

S7RW0C2306020

Removal

- 1) Hoist vehicle and remove rear wheel.
- 2) Pull up parking brake lever.
Remove rear drive shaft (4WD model) referring to "Rear Drive Shaft Assembly Removal and Installation: Rear in Section 3A".
- 3) Remove rear brake caliper assembly and rear brake disc referring to "Rear Brake Disc Removal and Installation: Disc in Section 4C".
- 4) Disconnect wheel speed sensor connector (1) (4WD model).
- 5) Remove wheel speed sensor (4) (2WD model).
- 6) Remove brake dust cover (2) and rear wheel hub assembly (3) from rear axle.



I8RW01230007-01

[A]: 4WD model

[B]: 2WD model

- 7) If necessary, remove stud bolts from rear wheel hub assembly referring to Step 7) under "Removal" of "Rear Wheel Hub Assembly Removal and Installation (Rear Drum Brake Model)".

Installation

⚠ CAUTION

Rear hub bolt is pre-coated with friction stabilizer.
Never reuse the removed bolt. Otherwise, bolt may loosen.

- 1) Install stud bolts to rear wheel hub assembly referring to Step 1) under "Installation" of "Rear Wheel Hub Assembly Removal and Installation (Rear Drum Brake Model)", if removed.
- 2) Install rear brake dust cover (1), rear wheel hub assembly (2) and then tighten new rear hub bolts to specified torque.



Tightening torque

Rear hub bolt (a): 73 N·m (7.3 kgf-m, 53.0 lb-ft)

- 3) Connect wheel speed sensor connector (3) (4WD model).
- 4) Install wheel speed sensor (4) and tighten wheel speed sensor bolt to specified torque (2WD model).

Tightening torque

Wheel speed sensor bolt (b): 11 N·m (1.1 kgf-m, 8.0 lb-ft)



I8RW01230008-01

[A]: 4WD model

[B]: 2WD model


- 5) Install rear brake disc and rear brake caliper assembly referring to "Rear Brake Disc Removal and Installation: Disc in Section 4C".
- 6) Pull up parking brake lever.
 Install new rear drive shaft nut (1) to specified torque, and then caulk drive shaft nut (1) (4WD model).

⚠ CAUTION

- **Never reuse rear drive shaft nut.**
- **Be careful not to damage the rear drive shaft nut while caulking it. If it is damaged, replace it with new one.**

Tightening torque

Drive shaft nut (a): 175 N·m (17.5 kgf-m, 127.0 lb-ft)



I7RW01230016-01

- 7) Install wheel and tighten wheel nuts to specified torque.

Tightening torque

Wheel nut: 85 N·m (8.5 kgf-m, 61.5 lb-ft)

- 8) Adjust parking brake cable. For adjustment, refer to "Parking Brake Inspection and Adjustment in Section 4D".
- 9) Upon completion of installation, perform brake test.

Rear Suspension Fasteners Inspection

S7RW0C2306012

Check each bolt and nut fastening suspension parts for tightness. Tighten loose one, if any, to specified torque referring to the figure in "Rear Suspension Constructions".

Specifications

Tightening Torque Specifications

S7RW0C2307001

Fastening part	Tightening torque			Note
	N·m	kgf-m	lb-ft	
Wheel nut	85	8.5	61.5	⌚ / ⌚ / ⌚ / ⌚ / ⌚ / ⌚
Rear shock absorber upper nut	30	3.0	22.0	⌚
Rear shock absorber lower nut	90	9.0	65.0	⌚ / ⌚ / ⌚ / ⌚
Rear axle bolt	73	7.3	53.0	⌚ / ⌚ / ⌚
Brake pipe flare nut	16	1.6	11.5	⌚ / ⌚ / ⌚
Parking brake cable clamp nut	26	2.6	19.0	⌚ / ⌚
Rear hub bolt	73	7.3	53.0	⌚ / ⌚
Wheel speed sensor bolt	11	1.1	8.0	⌚ / ⌚
Drive shaft nut	175	17.5	127.0	⌚ / ⌚

NOTE

The specified tightening torque is also described in the following.
 “Rear Suspension Constructions”

Reference:

For the tightening torque of fastener not specified in this section, refer to “Fasteners Information in Section 0A”.

Wheels and Tires

Precautions

Precautions in Wheels and Tires Servicing

S7RW0C2400001

- Wheel repairs that use welding, heating, or peeling are not approved. All damaged wheels should be replaced.

Studs

If a broken stud is found, replace it referring to “Front Wheel Hub, Steering Knuckle and Wheel Bearing Removal and Installation in Section 2B”, “Rear Wheel Hub Assembly Removal and Installation (Rear Drum Brake Model) in Section 2C” or “Rear Wheel Hub Assembly Removal and Installation (Rear Disc Brake Model) in Section 2C”.

General Description

Tires Description

S7RW0C2401001

The tire is of tubeless type. The tire is designed to operate satisfactorily with loads up to the full rated load capacity when inflated to the recommended inflation pressures.

Correct tire pressures and driving habits have an important influence on tire life. Heavy cornering, excessively rapid acceleration, and unnecessary sharp braking increase tire wear.

Tire Placard

The “Tire Placard” is located on the left or right door lock pillar and should be referred to tire information.

The placard lists the maximum load, tire size and cold tire pressure where applicable.

NOTE

Whether rim size and/or maximum load are listed or not depends on regulations of each country.

Inflation of Tires

The pressure recommended for any model is carefully calculated to give a satisfactory ride, stability, steering, tread wear, tire life and resistance to bruises.

Tire pressure, with tires cold, (after vehicle has set for 3 hours or more, or driven less than one mile) should be checked monthly or before any extended trip. Set to the specifications on the “Tire Placard” located on the left or right door lock pillar.

It is normal for tire pressure to increase when the tires become hot during driving.

Do not bleed or reduce tire pressure after driving.

Bleeding reduces the “Cold Inflation Pressure”.

Higher than recommended pressure can cause:

- Hard ride
- Tire bruising or carcass damage
- Rapid tread wear at center of tire

Unequal pressure on same axle can cause:

- Uneven braking
- Steering lead
- Reduced handling
- Swerve on acceleration

Lower than recommended pressure can cause:

- Tire squeal on turns
- Hard Steering
- Rapid and uneven wear on the edges of the tread
- Tire rim bruises and rupture
- Tire cord breakage
- High tire temperature
- Reduced handling
- High fuel consumption

Matched Tires and Wheels (Steel Type)


Tires and wheels are match mounted at the assembly plant.

This means that the radially stiffest part of the tire, or “high spot”, is matched to the smallest radius or “low spot” of the wheel.

This is done to provide the smoothest possible ride.

The “high spot” of the tire is originally marked by paint dot (1) on the outboard sidewall. This paint dot will eventually wash off the tire.

The “low spot” of the wheel is originally marked by paint dot (2) on the wheel rim-flange. Properly assembled, the wheel rims’ paint dot should be aligned with the tires’ paint dot as shown in figure.



I2RH01240001-01

Whenever a tire is dismounted from its wheel, it should be remounted so that the tire and wheel are matched. If the tire’s paint dot cannot be located, a line should be scribed on the tire and wheel before dismounting to assure that it is remounted in the same position.

Replacement Tires

When replacement is necessary, the original equipment type tire should be used. Refer to the Tire Placard.

Replacement tires should be of the same size, load range and construction as those originally on the vehicle. Use of any other size or type tire may affect ride, handling, speedometer / odometer calibration, vehicle ground clearance and tire or snow chain clearance to the body and chassis.

It is recommended that new tires be installed in pairs on the same axle. If necessary to replace only one tire, it should be paired with the tire having the most tread, to equalize braking traction.

⚠ WARNING

Do not mix different types of tires on the same vehicle such as radial, bias and bias-belted tires except in emergencies, because handling may be seriously affected and may result in loss of control.

The metric term for tire inflation pressure is the kilo pascal (kPa). Tire pressures is usually printed in both kPa and kgf/cm² on the “Tire Placard”.

Metric tire gauges are available from tool suppliers.

The chart, shown in the table, converts commonly used inflation pressures from kPa to kgf/cm² and psi.

	kPa	kgf/cm ²	psi
Conversion: 1 psi =	160	1.6	23
6.895 kPa 1 kgf/cm ² =	180	1.8	26
98.066 kPa	200	2.0	29
	220	2.2	32
	240	2.4	35
	260	2.6	38
	280	2.8	41
	300	3.0	44
	320	3.2	47
	340	3.4	50

Wheels Description

S7RW0C2401002

Wheel Maintenance

Wheel repairs that use welding, heating, or peening are not approved. All damaged wheels should be replaced.

Replacement Wheels

Wheels must be replaced if they are bent, dented, have excessive lateral or radial runout, air leak through welds, have elongated bolt holes, if lug wheel bolts won’t stay tight, or if they are heavily rusted. Wheels with greater runout than shown in the following may cause objectional vibrations.

Replacement wheels must be equivalent to the original equipment wheels in load capacity, diameter, rim with offset and mounting configuration. A wheel of improper size or type may affect wheel and bearing life, brake cooling, speedometer / odometer calibration, vehicle ground clearance and tire clearance to body and chassis.

How to Measure Wheel Runout

To measure the wheel runout, it is necessary to use an accurate dial indicator. The tire may be on or off the wheel. The wheel should be installed to the wheel balancer of the like for proper measurement.

Take measurements of both lateral runout “a” and radial runout “b” at both inside and outside of the rim flange. With the dial indicator set in place securely, turn the wheel one full revolution slowly and record every reading of the indicator.

When the measured runout exceeds the specification and correction by the balancer adjustment is impossible, replace the wheel. If the reading is affected by welding, paint or scratch, it should be ignored.

2D-3 Wheels and Tires:

Lateral runout limit "a"


Aluminum wheel: 0.3 mm (0.012 in.)

Steel wheel: 0.9 mm (0.035 in.)

Radial runout limit "b"

Aluminum wheel: 0.3 mm (0.012 in.)

Steel wheel: 0.7 mm (0.028 in.)




I4RS0A240001-01

Metric Lug Nuts and Wheel Studs

All models use metric lug nuts and wheel studs.

Metric lug nuts and wheel studs size

M12 x 1.25



I2RH01240003-01

Irregular and/or Premature Wear Description



S7RW0C2401003

Irregular and premature wear has many causes. Some of them are as follows: incorrect inflation pressures, lack of tire rotation, driving habits, improper alignment. If the following conditions are noted, tire rotation is necessary:

- Front tire wear is different from rear's.
- Uneven wear exists across tread of any tires.
- Both sides of front tire wears are not even.
- Both sides of rear tire wears are not even.
- There is cupping, flat spotting, etc.

A wheel alignment check is necessary if following conditions are noted:

- Both sides of front tire wears are not even.
- Wear is uneven across the tread of any front tire.
- Front tire treads have scuffed appearance with "feather" edges on one side of tread ribs or blocks.



I3RH0A240002-01

[A]: Hard Cornering, under inflation or lack of tire rotation


[B]: Incorrect wheel alignment, tire construction not uniform or wheel heavy acceleration

Wear Indicators Description

S7RW0C2401004

Original equipment tires have built-in tread wear indicators (1) to show when they need replacement. These indicators (1) will appear as 12 mm (0.47 in.) wide bands when the tire tread depth becomes 1.6 mm (0.063 in.).

When the indicators (1) appear in 3 or more grooves at 6 locations, tire replacement is recommended.



I2RH01240005-01

Radial Tire Waddle Description

S7RW0C2401005


Waddle is side to side movement at the front and/or rear of the vehicle. It is caused by the steel belt not being straight within the tire. It is most noticeable at a low speed, 8 to 48 kph (5 to 30 mph).

It is possible to locate the faulty tire by road testing the vehicle. If it is on the rear, the rear end of the vehicle shakes from side to side or "waddles". To the driver in the seat, it feels as though someone is pushing on the side of vehicle.

If the faulty tire is on the front, waddling is more visual. The front sheet metal appears to be moving back and forth and the driver feels as though he is at the pivot point in vehicle.

Waddle can be quickly diagnosed by using Tire Problem Detector (TPD) and following the equipment manufacture's recommendations.


If TPD is not available, an alternative method of substituting known-good tire / wheel assemblies can be used as follows, although it takes a longer time.



I2RH01240006-01

- 1) Ride vehicle to determine whether the front or rear waddles.
- 2) Install tires and wheels that are known to be good (on similar vehicle) in place of those on waddling end of vehicle. If waddling end cannot be identified, substitute rear ones.
- 3) Road test again. If improvement is noted, reinstall originals one at a time till waddle causal tire is found. If no improvement is noted, install known-good tires in place of all four. Then reinstall originals in the same manner.

Equipment manufacture's recommendations



I2RH01240007-01

Radial Tire Lead / Pull Description

S7RW0C2401006

“Lead / Pull” is the deviation of the vehicle from a straight path on a level road even with no pressure on the steering wheel.

Lead is usually caused by the following conditions.

- Improper tire and wheel alignment.
- Uneven brake assemblies.
- Tire construction.

The way in which a tire is built can produce lead in a vehicle. An example of this is placement of the belt. Off center belts on radial tires can cause the tire to develop a side force while rolling straight down the road. If one side of the tire has a little larger diameter than the other, the tire will tend to roll to one side. This will develop a side force which can produce vehicle lead.


The procedure in the figure (Lead Diagnosis) should be used to make sure that wheel alignment is not mistaken for tire lead.

- Part of the lead diagnosis procedure is different from the proper tire rotation pattern currently in the owner and service manuals. If a medium to high mileage tire is moved to the other side of the vehicle, be sure to check that ride roughness has not developed
- Rear tires will not cause lead.

Balancing Wheels Description

S7RW0C2401007


There are two types of wheel and tire balance: static and dynamic. Static balance, as shown in figure, is the equal distribution of weight around the wheel. Wheels that are statically unbalanced cause a bouncing action called tramp. This condition will eventually cause uneven tire wear.



I2RH01240008-01

1. Heavy spot wheel tramp	[A]: Before correction
2. Balance weights addition point	[B]: Corrective weights
3. C/L of spindle	

Dynamic balance, as shown in figure, is the equal distribution of weight on each side of the wheel centerline so that when the tire spins there is no tendency for the assembly to move from side to side. Wheels that are dynamically unbalanced may cause shimmy.



I2RH01240009-01

1. Heavy spot wheel shimmy	[C]: Before correction
2. Balance weights addition point	[D]: Corrective weights
3. C/L of spindle	

Repair Instructions**Wheel Discs Inspection**

S7RW0C2406001

Inspect each wheel disc for dents, distortion and cracks. A disc in badly damaged condition must be replaced.

Tires Inspection

S7RW0C2406002

- 1) Check tires for uneven or excessive wear, or damage referring to “Irregular and/or Premature Wear Description” and “Wear Indicators Description” for details.
- 2) Rotate tires. For details, refer to “Tire Rotation”.

Wheel Balance Inspection and Adjustment

S7RW0C2406003

Refer to “Balancing Wheels Description”. Deposits of mud, etc. must be cleaned from inside of rim.

⚠ WARNING

Stones should be removed from the tread in order to avoid operator injury during spin balancing and to obtain good balance.

Each tire should be inspected for any damage, then balanced according to equipment manufacturer’s recommendation.

Off-Vehicle Balancing

Most electronic off-vehicle balancers are more accurate than the on-vehicle spin balancers. They are easy to use and give a dynamic (two plane) balance. Although they do not correct for drum or disc unbalance as does on-vehicle spin balancing, this is overcome by their accuracy, usually to within 1/8 ounce.

On-Vehicle Balancing

On-vehicle balancing methods vary with equipment and tool manufacturers. Be sure to follow each manufacturer's instructions during balancing operation.

⚠ WARNING

Wheel spin should be limited to 55 km/h (35 mph) as indicated on speedometer.

This limit is necessary because speedometer only indicates one-half of actual wheel speed when one drive wheel is spinning and the other drive wheel is stopped.

Unless care is taken in limiting drive wheel spin, spinning wheel can reach excessive speeds. This can result in possible tire disintegration or differential failure, which could cause serious personal injury or extensive vehicle damage.

⚠ CAUTION

For vehicle equipped with ABS, using on-vehicle balancing method with ignition switch ON may set malfunction diagnostic trouble code (DTC) of ABS even when system is in good condition.


Never turn ignition switch ON while spinning wheel.

Tire Rotation

S7RW0C2406004

To equalize wear, rotate tires periodically as shown in figure.

Refer to "Wheel (with Tire) Removal and Installation".



I7RW01240001-02

F: Forward

Wheel (with Tire) Removal and Installation

S7RW0C2406005

Removal

⚠ CAUTION

Never use heat to loosen tight wheel because the application of heat to wheel causes the wheel life shorter and the wheel bearing damage.

- 1) Loosen wheel nuts by approximately 180° (half a rotation).
- 2) Hoist vehicle.
- 3) Make sure that the vehicle will not fall off by trying to move vehicle body in both ways.
- 4) Remove wheel nuts except one.
- 5) Support the wheel and/or tire not to drop the wheel and then remove the nut left with the wheel.

Installation

For installation, reverse removal procedure, noting the following.

- Wheel nuts must be tightened in sequence and to specified torque to avoid bending wheel or brake disc or drum as shown in the figure.

NOTE


Before installing wheels, remove any build-up of corrosion on wheel mounting surface and brake disc mounting surface by scraping and wire brushing. Installing wheels without good metal-to-metal contact at mounting surfaces can cause wheel nuts to loosen, which can later allow a wheel to come off while vehicle is moving.

Tightening order

"1" - "2" - "3" - "4" - "5"

Tightening torque

Wheel nut (a): 85 N·m (8.5 kgf-m, 61.5 lb-ft)



IYSQ01240008-01

Tire Mounting and Dismounting

S7RW0C2406006

⚠ WARNING

Do not stand over tire when inflating. Bead may break when bead snaps over rim's safety hump and cause serious personal injury. Do not exceed specified pressure when inflating. If specified pressure will not seat beads, deflate, re-lubricate and reinflate. Over inflation may cause bead to break and cause serious personal injury.

Use a tire changing machine to mount or dismount tires. Follow equipment manufacturer's instructions. Do not use hand tools or tire irons alone to change tires as they may damage tire beads or wheel rim.

Rim bead seats should be cleaned with a wire brush or coarse steel wool to remove lubricants, old rubber and light rust. Before mounting or dismounting a tire, bead area should be well lubricated with approved tire lubricant.

After mounting, inflate 330 kPa (47.9 psi) pressure so that beads are completely seated. Then adjust pressure to specified shown in the tire placard.

Tire Repair

S7RW0C2406007

There are many different materials and techniques on the market to repair tires. As not all of these work on all types of tires, tire manufacturers have published detailed instructions on how and when to repair tires. These instructions can be obtained from each tire manufacturer.

Specifications

Wheels and Tires Specifications

S7RW0C2407001

Hatchback Model

Tire size (Standard)

: 205/60 R16 92H

Wheel size (Standard)

: 16 x 6J (for 205/60 R16)

Sedan Model

Tire size (Standard)

: 195/65R15 91H

Wheel size (Standard)

: 15 x 6J (for 195/65R15)

Tightening torque

Wheel nut: 85 N·m (8.5 kgf-m, 61.5 lb-ft)

NOTE

- Tire inflation pressure should be checked when tires are cool.
- Specified tire inflation pressure should be found on tire placard or in owner's manual which came with the vehicle.

Tightening Torque Specifications

S7RW0C2407002

Fastening part	Tightening torque			Note
	N·m	kgf-m	lb-ft	
Wheel nut	85	8.5	61.5	🔧 / 🔧

Reference:

For the tightening torque of fastener not specified in this section, refer to "Fasteners Information in Section 0A".

Section 3

Driveline / Axle

CONTENTS

Precautions	3-1	Precautions.....	3B-1
Precautions.....	3-1	Precaution for Rear Differential Oil Leakage.....	3B-1
Precautions on Driveline / Axle	3-1	Precautions in Diagnosing Trouble	3B-1
Drive Shaft / Axle	3A-1	General Description	3B-2
Front.....	3A-1	Rear Differential Description	3B-2
General Description	3A-1	Coupling Description	3B-2
Front Drive Shaft Construction.....	3A-1	4WD Control System Description.....	3B-3
Component Location	3A-1	Function of 4WD Control System Component	3B-3
Front Drive Shaft Assembly Components		Input / Output Signal Table of 4WD Control	
Location	3A-1	Module	3B-3
Diagnostic Information and Procedures.....	3A-2	On-Board Diagnostic System Description	3B-4
Front Drive Shaft Symptom Diagnosis	3A-2	CAN Communication System Description.....	3B-5
Repair Instructions	3A-2	Schematic and Routing Diagram	3B-6
Front Drive Shaft Components	3A-2	4WD Control System Wiring Circuit Diagram.....	3B-6
Front Drive Shaft Assembly On-Vehicle		Component Location	3B-7
Inspection.....	3A-2	4WD Control System Components Location.....	3B-7
Front Drive Shaft Assembly Removal and		Diagnostic Information and Procedures.....	3B-8
Installation	3A-2	4WD Control System Check	3B-8
Front Drive Shaft Disassembly and		4WD Position Indicator Operation Check.....	3B-10
Reassembly	3A-4	4WD Control System Operation Inspection	3B-10
Center Shaft and Center Bearing Support		Visual Inspection	3B-10
Disassembly and Reassembly (2WD Model)	3A-7	DTC Check.....	3B-11
Specifications.....	3A-8	DTC Clearance	3B-11
Tightening Torque Specifications.....	3A-8	DTC Table	3B-12
Special Tools and Equipment.....	3A-9	Fail-Safe Table.....	3B-12
Recommended Service Material	3A-9	Scan Tool Data	3B-13
Special Tool	3A-9	Rear Differential Symptom Diagnosis	3B-14
Rear.....	3A-10	4WD Control Symptom Diagnosis.....	3B-14
General Description	3A-10	4WD Position Indicator Does Not Come ON at	
Rear Drive Shaft Construction	3A-10	Ignition Switch ON but Engine Stops	3B-15
Repair Instructions	3A-10	4WD Position Indicator Remains ON Steady	
Rear Drive Shaft Components	3A-10	at Ignition Switch ON.....	3B-16
Rear Drive Shaft Assembly Removal and		DTC C1240: 4WD Control Module Power	
Installation	3A-11	Supply Circuit Malfunction.....	3B-17
Rear Drive Shaft Disassembly and		DTC C1243: Internal Circuit Malfunction of	
Reassembly	3A-11	4WD Control Module.....	3B-18
Specifications.....	3A-13	DTC C1250: Coupling Air Temperature	
Tightening Torque Specifications.....	3A-13	Sensor Circuit Open.....	3B-18
Special Tools and Equipment.....	3A-13	DTC C1251: Coupling Air Temperature	
Recommended Service Material	3A-13	Sensor Circuit Short.....	3B-20
Special Tool	3A-13	DTC C1252: Coupling Assembly Circuit Open ..	3B-21
Differential.....	3B-1	DTC C1253: Coupling Assembly Circuit Short ..	3B-23
		DTC C1254: 2WD/4WD Switch Malfunction	3B-24
		DTC U0073: Control Module Communication	
		Bus Off	3B-26

DTC U0100: Lost Communication with ECM.....	3B-26	Diagnostic Information and Procedures	3C-1
DTC U0121: Lost Communication with ABS / ESP® Control Module.....	3B-26	Transfer Symptom Diagnosis.....	3C-1
DTC U0155: Lost Communication with Instrument Panel Cluster (IPC) Control Module	3B-26	Repair Instructions	3C-2
Inspection of 4WD Control Module and Its Circuits	3B-26	Transfer Oil Level Check.....	3C-2
Repair Instructions	3B-29	Transfer Oil Change	3C-2
Rear Differential Oil Level Check	3B-29	Transfer Dismounting and Remounting	3C-3
Rear Differential Oil Change	3B-29	Transfer Assembly Components	3C-5
2WD/4WD Switch Removal and Installation	3B-30	Transfer Assembly Disassembly and Reassembly	3C-6
2WD/4WD Switch Inspection	3B-30	Reduction Drive Gear Assembly Disassembly and Reassembly	3C-8
4WD Control Module Removal and Installation	3B-30	Reduction Driven Gear Assembly Disassembly and Reassembly	3C-9
Coupling Air Temperature Sensor Removal and Installation	3B-30	Transfer Right Case and Left Case Disassembly and Reassembly	3C-10
Coupling Air Temperature Sensor Inspection ...	3B-31	Transfer Output Retainer Assembly Disassembly and Reassembly	3C-11
Coupling Assembly Inspection	3B-31	Transfer Assembly Inspection	3C-15
Rear Differential Mountings Components	3B-32	Bevel Gear Tooth Contact Inspection	3C-15
Front Mounting Arm and/or Rear Mounting Bracket Assembly Removal and Installation ...	3B-33	Specifications	3C-17
Rear Mounting Bracket Assembly Disassembly and Reassembly	3B-33	Tightening Torque Specifications	3C-17
Rear Differential Dismounting and Remounting	3B-33	Special Tools and Equipment	3C-18
Rear Differential Components	3B-34	Recommended Service Material	3C-18
Rear Differential Disassembly and Reassembly	3B-35	Special Tool	3C-18
Rear Differential Inspection	3B-46	Propeller Shaft.....	3D-1
Specifications	3B-46	General Description	3D-1
Tightening Torque Specifications	3B-46	Propeller Shaft Construction	3D-1
Special Tools and Equipment	3B-47	Diagnostic Information and Procedures	3D-1
Recommended Service Material	3B-47	Propeller Shaft Symptom Diagnosis	3D-1
Special Tool	3B-47	Repair Instructions	3D-1
Transfer	3C-1	Propeller Shaft Joint Check.....	3D-1
General Description	3C-1	Propeller Shaft Assembly Removal and Installation	3D-2
Transfer Description.....	3C-1	Propeller Shaft Inspection	3D-2
		Specifications	3D-2
		Tightening Torque Specifications.....	3D-2

Precautions

Precautions

Precautions on Driveline / Axle

S7RW0C3000001

Precaution for Rear Differential Oil Leakage

Refer to "Precaution for Rear Differential Oil Leakage in Section 3B".

Precautions in Diagnosing Trouble

Refer to "Precautions in Diagnosing Trouble in Section 3B".

Precaution on CAN Troubleshooting

Refer to "Precaution on CAN Troubleshooting in Section 1A".

Drive Shaft / Axle

Front

General Description

Front Drive Shaft Construction


S7RW0C3111001

A constant velocity ball joint is used on the wheel side of both right and left side drive shaft assemblies. A tripod type constant velocity joint is used on the differential side and center shaft side. The drive shaft can slide through the tripod joint in the extension/contraction direction.

Component Location

Front Drive Shaft Assembly Components Location

S7RW0C3113001



I7RW0C311001-03

1. To transaxle	6. Center shaft assembly (if equipped)	 : 85 N·m (8.5 kgf-m, 61.5 lb-ft)
2. Drive shaft assembly	7. Center bearing support bolts (if equipped)	 : 55 N·m (5.5 kgf-m, 40.0 lb-ft)
3. Ball stud bolt	8. Washer	 : Do not reuse.
 4. Drive shaft nut : After tightening nut to specified torque, caulk nut securely.	 : 60 N·m (6.0 kgf-m, 43.5 lb-ft)	
5. Wheel nut	 : 200 N·m (20.0 kgf-m, 145.0 lb-ft)	

Diagnostic Information and Procedures

Front Drive Shaft Symptom Diagnosis


S7RW0C3114001

Condition	Possible cause	Correction / Reference Item
Abnormal noise	Worn or breakage of the drive shaft joint	Replace.
	Worn or breakage of the center bearing	Replace.

Repair Instructions

Front Drive Shaft Components

S7RW0C3116001



I6RW0C311002-01

1. Circlip	9. Center bearing support
2. Snap ring	10. Center bearing
3. Boot band (Large)	11. Center shaft
4. Boot	12. Damper (if equipped)
5. Boot band (Small)	13. Differential side joint (Constant velocity tripod joint) : Apply dark gray grease included in spare part to joint
6. Wheel side joint (Constant velocity ball joint) : Apply black grease included spare part to joint.	14. Center shaft side joint (Constant velocity tripod joint) : Apply dark gray grease included in spare part to joint
7. Oil seal : Apply grease to oil seal lip.	15. Tripod joint spider : Never disassemble
8-1. Center bearing support circlip (M/T model only)	Do not reuse.
8-2. Center bearing support circlip	

Front Drive Shaft Assembly On-Vehicle Inspection

S7RW0C3116002

- Check boots for breakage or deterioration.
 - Check wheel side joint for rattle or smooth rotation.
 - Check differential side (or center shaft side) joint for smooth rotation.
- If any abnormality is found, replace.


Front Drive Shaft Assembly Removal and Installation

S7RW0C3116003

Removal

- 1) Hoist vehicle and remove front wheel.


- 2) Undo caulking and remove drive shaft nut (1) with brake pedal depressed.



I6RW0B310005-01


3A-3 Drive Shaft / Axle: Front

- 3) Drain transaxle oil and transfer oil (4WD model).
- 4) Disconnect tie-rod end (1) from steering knuckle (2) using puller (3).




I3RM0A310003-01

- 5) Remove brake hose mounting bolt (1) and brake hose (2) from bracket and then detach wheel speed sensor harness (3) from strut bracket.
- 6) Remove suspension control arm ball joint bolt (4) from knuckle.



I6RW0C311003-01


- 7) Disconnect front suspension control arm ball joint stud from steering knuckle.
- 8) Using tire lever (1) or plastic hammer (3), pull out drive shaft joint (2) so as to release snap ring fitting of joint spline at differential side or at center shaft.



I5RW0A311003-01

[A]: Left side shaft	[C]: Right side shaft of 4WD model
[B]: Right side shaft of 2WD model	

- 9) Remove drive shaft assembly.
- 10) Remove center bearing support bolts (3) and remove center bearing support (2) with center shaft (1) from differential side gear.



I2RH01310007-01

Installation

⚠ CAUTION

- Be careful not to damage oil seals and boots when installing drive shaft.
- Do not hit joint boot with hammer. Inserting joint only by hands is allowed.
- Make sure that differential side joint is inserted fully and its snap ring is seated as it was.

Install drive shaft assembly by reversing removal procedure and noting the following points.

- Tighten each bolt and nut to the specified torque referring to "Front Drive Shaft Assembly Components Location: Front" and "Steering Gear Case Assembly Components in Section 6C".
- Tighten brake hose mounting bolt to specified torque.

Tightening torque

Brake hose mounting bolt: 25 N·m (2.5 kgf-m, 18.0 lb-ft)

- Fill transaxle with oil as specified referring to "Manual Transaxle Oil Change in Section 5B" or "A/T Fluid Change in Section 5A" and "Transfer Oil Change in Section 3C" (4WD model).
- Check toe setting referring to "Front Wheel Alignment Inspection and Adjustment in Section 2B" and adjust as required.

Front Drive Shaft Disassembly and Reassembly

S7RW0C3116004

Disassembly


⚠ CAUTION

- Disassembly of wheel side joint is not allowed. If any noise or damage exists in it, replace it as assembly.
- Do not disassemble tripod joint spider. If any malfunction is found in it, replace it as differential side joint assembly.


1) Remove differential side (or center shaft side) boot big band (1) as follows.

- For boot big band without joint:
Remove boot big band by tapping boot and band with plastic hammer. If it is hard to remove boot big band, cut it using a nipper or an iron saw with care not to damage joint housing.
- For boot big band with joint:
Draw hooks of boot big band together and remove band.

[A]



[B]




I4RH0A310004-01

[A]: For boot big band without joint

[B]: For boot big band with joint

2) Wipe off grease from shaft and take off snap ring (1) using snap ring pliers (2).




I7RW01311003-01

3) Remove tripod joint spider (1) using 3 arms puller (2).

⚠ CAUTION

To prevent any problem caused by washing solution, do not wash tripod joint except its housing. Degreasing of tripod joint with cloth is allowed.




I3RH0A311004-01

4) Remove differential side (or center shaft side) boot small band, and then pull out differential side (or center shaft side) boot from shaft.

5) Remove damper from shaft, if equipped.

6) Undo caulking (5) of wheel side boot big band (1) and small band (3) using flat end rod (2) or the like, then pull out wheel side boot (4) from shaft.



I4RS0A310006-01


Reassembly

Judging from abnormality noted before disassembly and what is found through visual check of component parts after disassembly, prepare replacing parts and proceed to reassembly.

Make sure that wheel side joint assembly (1) and tripod joint housing (2) are washed thoroughly and air dried. Replace boot(s) (3) with new one(s).

⚠ CAUTION

- Do not wash boots in degreaser such as gasoline or kerosene. etc. Washing in degreaser causes deterioration of boot.
- To ensure full performance of joint as designed, be sure to distinguish between two types of grease in repair set and apply specified volume to respective joint referring to the followings for identification of the grease.



I4RS0A310007-01

[A]: Wheel side [B]: Differential side (or center shaft side)

- 1) Wash disassembled parts (except boots). After washing, dry parts completely by blowing air.
- 2) Clean boots with cloth.
- 3) Apply grease to wheel side joint. Use specified grease in tube in wheel side boot set as a spare parts.


Grease color

: Black

Amount

: 70 – 90 g (2.5 – 3.2 oz)

- 4) Install wheel side boot on shaft.
- 5) Fill up boot inside with specified grease.
- 6) Place new wheel side boot big band (3) and small band (4) onto boot putting band outer end (1) against forward rotation (2) as shown in figure.



I4RS0A310009-01

- 7) Fasten boot bands (1) securely using special tool as shown in figure.

⚠ CAUTION


Do not squeeze or distort boot when fastening it with bands. Distorted boot caused by squeezing air may reduce its durability.

Distance "a"

: 2.6 ± 1.4 mm (0.102 ± 0.055 in.)

Special tool

(A): 09943-57010



I5RS0B310008-01

- 8) Install damper (1) to specified position on drive shaft, if equipped.


Drive shaft damper installing position (right side)

"a": 359 mm (14.1 in.) (2WD model)

"a": 362 mm (14.3 in.) (4WD model)

Drive shaft damper installing position (left side)

"a": 252 mm (9.9 in.) (M/T model)




I4RS0B310002-01

- 9) Set new differential side (or center shaft side) small band and new differential side (or center shaft side) boot (1) on shaft temporarily, and then apply grease to tripod joint (2). Use specified grease in tube included in spare parts.
- 10) Install tripod joint spider (3) on shaft using special tool with hammer, directing its chamfered spline toward wheel side, and then fasten it with new snap ring (4) using snap ring pliers (5).

Special tool

(A): 09925-98221



I7RW01311004-01

- 11) Apply grease (including in spare parts) to inside of tripod joint housing (1), joint it with tripod joint.


Grease color

"A": Dark gray

Amount

"A": 95 – 115 g (3.4 – 4.1 oz) (right side)

"A": 90 – 110 g (3.2 – 3.9 oz) (left side)



I4RS0B310003-01


- 12) Fit boot (1) to grooves of shaft and housing (2) adjust length to specification below.
- 13) Insert screw driver into boot and allow air to enter boot so that air pressure in boot becomes the same as atmospheric pressure.

Drive shaft boot fixing position (distance between housing end and small boot band)

Left side drive shaft "a": 167.8 mm (6.61 in.) (M/T model)

Left side drive shaft "a": 171.2 mm (6.74 in.) (A/T model)

Right side drive shaft "b": 191.0 mm (7.52 in.)



I4RS0B310004-01


[A]: Drive shaft inserted into differential side

[B]: Drive shaft inserted into center shaft side

CAUTION

- Bend each boot band against forward rotation.
- Do not squeeze or distort boot when fastening it with bands. Distorted boot caused by squeezing air may reduce its durability.

- 14) Place differential side (or center shaft side) boot new big band (3) and new small band (4) onto boot putting band outer end (1) against forward rotation (2) as shown in figure.





I4RS0B310007-01

- 15) Fasten differential side (or center shaft side) boot big band (1) and small band (5) by drawing hooks (2) with special tool and engage hooks (3) in slot and window (4).

Special tool

(A): 09943-57021




I4RS0B310008-02

Center Shaft and Center Bearing Support Disassembly and Reassembly (2WD Model)

S7RW0C3116005


Disassembly

- 1) Using hydraulic press (1), draw out center shaft (2) from center bearing.
- 2) Remove oil seals from center bearing support (3).



I3RM0A310012-01

- 3) Remove bearing support circlip (1) using snap ring pliers (2).



I7RW01311005-01


- 4) Remove center bearing from center bearing support.

Reassembly


Reassemble center shaft by reversing disassembly procedure and noting the following points.

- When installing bearing support circlip (1), make sure that it fits in circlip groove in center bearing support (2) securely as shown.

[A]



[B]



I7RW01311006-02

[A]: A/T model

[B]: M/T model

- When installing left oil seal (1) and right oil seal (2) using special tool, use care so that oil seals in proper direction and position as shown in figure.

Special tool
: 09925-15410

Distance

A/T model

“a”: 0 – 1 mm (0 – 0.04 in.)

“b”: 11 – 12 mm (0.43 – 0.47 in.)


M/T model

“a”: 6 – 7 mm (0.24 – 0.35 in.)


“b”: 2 – 3 mm (0.08 – 0.12 in.)

- Be sure to apply grease to oil seal lip and bearing side space indicated in figure.

“A”: Grease 99000-25011 (SUZUKI Super Grease A)



- Press-fit center shaft (1) from left oil seal (2) side.



Specifications

Tightening Torque Specifications

S7RW0C3117001

Fastening part	Tightening torque			Note
	N·m	kgf-m	lb-ft	
Brake hose mounting bolt	25	2.5	18.0	⌚

NOTE

The specified tightening torque is also described in the following.
“Front Drive Shaft Assembly Components Location: Front”

Reference:

For the tightening torque of fastener not specified in this section, refer to “Fasteners Information in Section 0A”.

Special Tools and Equipment

Recommended Service Material

S7RW0C3118001





Material	SUZUKI recommended product or Specification		Note
Grease	SUZUKI Super Grease A	P/No.: 99000–25011	

NOTE

Required service material is also described in the following.
“Front Drive Shaft Components: Front”

Special Tool

S7RW0C3118002

09925–15410 Oil seal installer 		09925–98221 Bearing installer 	
09943–57010 Band compressor 		09943–57021 Pliers, Low-Profile Clamp 	

Rear

General Description

Rear Drive Shaft Construction


S7RW0C3121001

Refer to "Front Drive Shaft Construction: Front".

Repair Instructions

Rear Drive Shaft Components

S7RW0C3126001



I5RW0A312001-01


1. Differential side joint (Constant velocity DOJ) : Apply dark gray grease included in spare part to joint.	6. Wheel side joint (Constant velocity ball joint) : Apply black grease included in spare part to joint.	11. Boot (wheel side)
2. Snap ring	7. Cage	: 175 N·m (17.5 kgf-m, 126.5 lb-ft)
3. Boot band (Large)	8. Drive shaft nut : After tightening nut, caulk nut securely.	: 50 N·m (5.0 kgf-m, 36.5 lb-ft)
4. Boot (Differential side)	9. Rear drive shaft flange nut	: Do not reuse.
5. Boot band (Small)	10. Circlip	

Rear Drive Shaft Assembly Removal and Installation

S7RW0C3126002


Removal

- 1) Hoist vehicle and remove rear wheel.
- 2) Undo caulking of drive shaft nut (1) and then remove drive shaft nut with pull up parking brake lever.



I7RW01230013-01

- 3) Remove rear drive shaft flange nuts (1), and then remove rear drive shaft.



I5RW0A312006-02

Installation

Install drive shaft assembly by reversing removal procedure and noting the following points.

⚠ CAUTION

- **Protect boots from any damage, preventing them from unnecessary contact while installing drive shaft.**
 - **Do not hit joint boot with hammer. Inserting joint only by hands is allowed.**
-
- Tighten each nuts to specified torque referring to "Rear Drive Shaft Components: Rear".

Rear Drive Shaft Disassembly and Reassembly


S7RW0C3126003

Disassembly


Refer to "Front Drive Shaft Disassembly and Reassembly: Front" note the following point which is different from the front drive shaft is described.

- Remove differential side boot big band and small band as follows.
 - For boot big band (and small band) without joint [A]: Remove boot big band (and small band) by tapping boot and band with plastic hammer. If it is hard to remove boot big band (and small band), cut it using a nipper or an iron saw with care not to damage joint housing.
 - For boot big band (and small band) with joint [B]: Draw hooks of boot big band (and small band) together and remove band.

[A]



[B]



I5RW0A312003-01

Reassembly

Refer to "Front Drive Shaft Disassembly and Reassembly: Front" note the following points which is different from the front drive shaft is described.

- Apply grease to each joint.

Grease color

Wheel side: Black

Differential side: Dark gray

Amount


Wheel side: 50 – 70 g (1.8 – 2.5 oz)

Differential side: 70 – 90 g (2.5 – 3.2 oz)

- Drive in the cage (1) by using special tool.

Special tool

(A): 09913-84510




I5RS0B310009-01

- Fit differential side boot as follows.
 - Fit boot (1) to grooves of shaft and housing (2) adjust length to specification below.
 - Insert screw driver into boot and allow air to enter boot so that air pressure in boot becomes the same as atmospheric pressure.

Drive shaft boot fixing position (distance between housing end and small boot band center)

Left side and right side drive shafts "a": 142.5 mm (5.61 in.)




I5RW0A312007-01

- Fasten differential side boot band as follows.

⚠ CAUTION

- **Bend each boot band against forward rotation.**
- **Do not squeeze or distort boot when fastening it with bands. Distorted boot caused by squeezing air may reduce its durability.**

- Place differential side boot new big band (3) and new small band onto boot putting band outer end (1) against forward rotation (2) as shown in figure.




I5RW0A312004-01

- Fasten differential side boot new big band (1) and new small band by drawing hooks (2) with special tool and engage hooks (3) in slot and window (4).

Special tool

(A): 09943-57021



I5RW0A312005-01

Specifications

Tightening Torque Specifications

S7RW0C3127001

NOTE

The specified tightening torque is also described in the following.
“Rear Drive Shaft Components: Rear”

Reference:

For the tightening torque of fastener not specified in this section, refer to “Fasteners Information in Section 0A”.

Special Tools and Equipment

Recommended Service Material



S7RW0C3128001

NOTE

Required service material is also described in the following.
“Rear Drive Shaft Components: Rear”

Special Tool

S7RW0C3128002

09913-84510 Bearing installer 		09943-57021 Pliers, Low-Profile Clamp 	
--	--	---	--

Differential

Precautions

Precaution for Rear Differential Oil Leakage

S7RW0C3200001

Whenever vehicle is hoisted for any other service work than oil change, also be sure to check for oil leakage.

Precautions in Diagnosing Trouble

S7RW0C3200002


- Do not disconnect the following parts before confirming diagnostic information (DTC, etc.) stored in 4WD control module memory. These actions will erase memorized information in 4WD control module memory.
 - Disconnection of coupler from 4WD control module
 - Disconnection of battery cable from battery
 - Disconnection of ground wire harness of 4WD control module
 - Disconnect main fuse from fuse box
- Diagnostic information stored in 4WD control module memory can be cleared as well as checked by using SUZUKI scan tool. Before using scan tool, read its Operator's (Instruction) Manual carefully to have good understanding as to what functions are available and how to use it.
- Be sure to read "Precautions for Electrical Circuit Service" before inspection and observe what is written there.

General Description

Rear Differential Description

S7RW0C3201001

The differential assembly uses a hypoid bevel pinion and gear. The differential assembly is decisive in that the drive power is concentrated there. Therefore, use of genuine parts and specified torque is compulsory. Further, because of sliding tooth meshing with high pressure between hypoid bevel pinion and gear, it is mandatory to lubricate them by hypoid gear oil.



I5RW0A320001-01

1. Companion flange	5. Drive bevel pinion (hypoid gear)	9. Differential pinion
2. Coupling case	6. Differential case	10. Drive bevel gear (hypoid gear)
3. Coupling assembly	7. Differential cover	
4. Differential carrier	8. Differential side gear	

Coupling Description

S7RW0C3201002

Coupling is installed in the forward of rear differential. The road situation and driving are judged with 4WD control module based on information from sensor and each control module, and the distribution of driving force of the front and rear wheel has been changed by controlling the current to coupling. Coupling air temperature sensor is installed in coupling case and measures the temperature in coupling. 4WD system has three driving mode (2WD, 4WD-auto, 4WD-lock). The mode corresponding to the running situation can be selected by 2WD/4WD switch.

4WD Control System Description

S7RW0C3201003

4WD Shift Control

The 4WD control module operates the coupling assembly according to the 2WD/4WD switch operation to obtain the selected position (2WD, 4WD-auto or 4WD-lock). Also, the 4WD control system has 4WD AUTO indicator and 4WD LOCK indicator in order to inform the 4WD control system condition.

Indicator Operation

The 4WD control module outputs operation signal of the 4WD AUTO indicator and the 4WD LOCK indicator. Indicators as follows in order to inform what state the 4WD control system is.

Operation Indicator		Condition (when any one of the following conditions is satisfied)
4WD AUTO indicator	OFF	- Ignition switch is OFF. - Vehicle is at "2WD" position or "4WD-lock" position.
	ON	- Within 2 seconds after ignition switch is turn ON (checking indicator operation). - Vehicle is at "4WD-auto" position. 4WD control module detects DTC of 4WD control system.
	Blinking at intervals of 2 seconds continuously	4WD control module detects the rotation difference of front wheel and rear wheel and/or temperature of transfer more than specified temperature.
4WD LOCK indicator	OFF	- Ignition switch is OFF. - Vehicle is at "2WD" position or "4WD-auto" position.
	ON	- Within 2 seconds after ignition switch is turn ON (checking indicator operation). - Vehicle is at "4WD-lock" position. 4WD control module detects DTC of 4WD control system.

Function of 4WD Control System Component

S7RW0C3201004

Part Name	Function
2WD/4WD switch	Output ON and OFF signal of 2WD/4WD switch to 4WD control module.
4WD AUTO indicator	Indicates vehicle is at 4WD-auto mode or not.
4WD LOCK indicator	Indicates vehicle is at 4WD-lock mode or not.
4WD control module	- Controlled of current to coupling assembly and vehicle switching to each position. - Diagnosis 4WD control system components. - Output operation signal of indicator to BCM.
Coupling assembly	The driving force of corresponding to the signal from 4WD control module transmitted to the rear wheel.

Input / Output Signal Table of 4WD Control Module

S7RW0C3201005

4WD control module outputs the following signals to coupling assembly, indicators, according to the 2WD/4WD switch operation.


		Output signal (to each component parts)		
		Coupling assembly	4WD AUTO indicator	4WD LOCK indicator
Input signal	2WD/4WD switch	○	○	○
	Coupling air temperature sensor		○	
	ECM	○		
	ABS / ESP® control module	○	○	○

On-Board Diagnostic System Description

S7RW0C3201006

For 4WD control system, 4WD control module has the following functions.

- When ignition switch is turned ON with engine at stop, 4WD AUTO indicator (1) and 4WD LOCK indicator (2) turn on at the same time for 2 seconds in order to check operation of these indicators.
- When 4WD control module detects any malfunction in the following area, 4WD AUTO indicator (1) and 4WD LOCK indicator (2) flash continuously or turn on and 4WD control module comes into fail-safe mode. For details of fail safe mode, refer to "Fail-Safe Table".
 - 2WD/4WD switch
 - Coupling air temperature sensor
 - Coupling assembly
- DTC can be checked by using SUZUKI scan tool (3) connected to DLC (4).
- When 4WD control module detects any malfunction, 4WD control module will switch off the current to coupling assembly and vehicle is changed to 2WD position.



I5RW0A320004-01

DLC (Data Link Connector)

Refer to "Data Link Connector (DLC)" under "On-Board Diagnostic System Description in Section 1A".

CAN Communication System Description

S7RW0C3201007

Refer to “CAN Communication System Description in Section 1A” for CAN communication system description.

When 4WD control module receive the signal of abnormal as following information, vehicle is not changed to 4WD-auto and 4WD-lock mode.

4WD Control Module Transmission Data

				ECM	Combination Meter	ESP® hydraulic unit / control module (if equipped)
4WD control module		DATA	4WD mode status	○		
			4WD auto mode indication status		○	
			4WD lock mode indication status		○	
			4WD diagnostic trouble codes		○	
			4WD clutch control request impossibility			○
			4WD clutch engagement percent			○

I7RW01320013-01

4WD Control Module Reception Data


				ECM	ABS hydraulic unit /control module (if equipped)	ESP® hydraulic unit /control module (if equipped)
4WD control module		DATA	Accelerator position	○		
			Engine speed	○		
			Brake pedal switch signal	○		
			Engine type signal	○		
			Engine torque signal	○		
			Wheel speed signal (front right)		○	○
			Wheel speed signal (front left)		○	○
			Wheel speed signal (rear right)		○	○
			Wheel speed signal (rear left)		○	○
			ABS active		○	○
			ESP® status signal			○
			Clutch control request for 4WD active			○
			Clutch control request percent			○

I7RW01320002-03

Schematic and Routing Diagram

4WD Control System Wiring Circuit Diagram


S7RW0C3202001



I7RW01320001-01

1. Coupling assembly	5. ABS / ESP® control module	9. "4WD" switch	13. "4WD" fuse
2. Coupling air temperature sensor	6. ECM	10. "4WD lock" switch	14. Main fuse box
3. Combination meter	7. 4WD control module	11. Data link connector (DLC)	
4. BCM	8. 2WD/4WD switch	12. "IG COIL" fuse	

Terminal Arrangement of 4WD Control Module



[A]: Connector "G26" viewed from harness side


I4JA01332038-01

Terminal	Circuit	Terminal	Circuit
G26-2	Coupling assembly (power)	G26-14	"4WD lock" switch
G26-3	Coupling assembly (ground)	G26-21	Data link connector (DLC)
G26-10	Ground	G26-22	CAN communication line (high)
G26-11	Power source for internal memory	G26-23	CAN communication line (low)
G26-12	Power source	G26-24	Coupling air temperature sensor (ground)
G26-13	4WD switch	G26-25	Coupling air temperature sensor (power)

Component Location

4WD Control System Components Location

S7RW0C3203001



I5RW0A320002-04

1. 4WD control module	3. 4WD LOCK indicator	5. Coupling assembly
2. 4WD AUTO indicator	4. 2WD/4WD switch	6. Coupling air temperature sensor

Diagnostic Information and Procedures

4WD Control System Check

S7RW0C3204001

Refer to the following items for the details of each step.

Step	Action	Yes	No
1	🔧 Customer complaint analysis 1) Perform customer complaint analysis. <i>Was customer complaint analysis performed?</i>	Go to Step 2.	Perform customer complaint analysis.
2	🔧 DTC check, record and clearance 1) Check for DTC. <i>Is there any DTC(s)?</i>	Print DTC or write them down and clear them by referring to "DTC Clearance". Go to Step 3.	Go to Step 4.
3	🔧 Visual inspection 1) Perform visual inspection. <i>Is there any faulty condition?</i>	Repair or replace malfunction part. Go to Step 11.	Go to Step 5.
4	🔧 Visual inspection 1) Perform visual inspection. <i>Is there any faulty condition?</i>	Repair or replace malfunction part. Go to Step 11.	Go to Step 8.
5	🔧 Trouble symptom confirmation 1) Select 2WD/4WD switch to "2WD", "4WD-auto" and "4WD-lock" positions referring to "4WD Control System Operation Inspection". 2) Confirm trouble symptom. <i>Is trouble symptom identified?</i>	Go to Step 6.	Go to Step 7.
6	🔧 Rechecking and record of DTC 1) Recheck for DTC referring to "DTC Check". <i>Is there any DTC(s)?</i>	Go to Step 9.	Go to Step 8.
7	🔧 Rechecking and record of DTC 1) Recheck for DTC referring to "DTC Check". <i>Is there any DTC(s)?</i>	Go to Step 9.	Go to Step 10.
8	🔧 4WD control symptom diagnosis 1) Check and repair according to "4WD Control Symptom Diagnosis". <i>Are check and repair complete?</i>	Go to Step 11.	Check and repair malfunction part(s). Go to Step 11.
9	🔧 Troubleshooting for DTC 1) Check and repair according to applicable DTC flow. <i>Are check and repair complete?</i>	Go to Step 11.	Check and repair malfunction part(s). Go to Step 11.
10	🔧 Check for intermittent problems 1) Check for intermittent problems referring to "Intermittent and Poor Connection Inspection in Section 00". <i>Is there any faulty condition?</i>	Repair or replace malfunction part(s). Go to Step 11.	Go to Step 11.
11	🔧 Final confirmation test 1) Clear DTC if any. 2) Perform final confirmation test. <i>Is there any problem symptom, DTC or abnormal condition?</i>	Go to Step 6.	END.

Detail of 4WD Control System Check**Step 1. Customer complaint analysis**

Record details of the problem (failure, complaint) and how it occurred as described by the customer.

For this purpose, use of such a questionnaire form as shown in the following will facilitate collecting information to the point required for proper analysis and diagnosis.

Customer questionnaire (Example)

Customer's name:	Model:	VIN:	
Date of issue:	Date of Reg:	Date of problem:	Mileage:

Problem Symptoms	• 4WD position indicator abnormal: fails to turn on / fails to turn off / flashes • Abnormal noise while vehicle running: from coupling assembly other _____ • No changed to "2WD" mode • No changed to "4WD-lock" mode • No changed to "4WD-auto" mode
Frequency of Occurrence	• Continuous / Intermittent (_____ times a day, a month) / other _____
Conditions for Occurrence of Problem	• When starting: at initial start only / at every start / other _____ • Vehicle speed: while accelerating / while decelerating / at stop / while turning / while running at constant speed / other _____ • Road surface condition: Paved road / rough road / snow-covered road / other _____
Environmental Condition	• Wheather: fine / cloudy / rain / snow / other • Temperature: _____ °F (_____ °C)
Diagnostic Trouble Code	• First check: _____ Normal code / malfunction code (_____) • Second check after test drive: Normal code / malfunction code (_____)

I7RW01320003-01

NOTE

The form is a standard sample. It should be modified according to conditions characteristic of each market.

Step 2. DTC check, record and clearance

First, referring to "DTC Check", check DTC and pending DTC. If DTC exists, print or write down DTC and then clear malfunction DTC(s) by referring to "DTC Clearance". Malfunction DTC indicates malfunction in the system but it is not possible to know from it whether the malfunction is occurring now or it occurred in the past and normal condition has been restored. In order to know that, check symptom in question according to Step 5 and then recheck DTC according to Step 6.

Diagnosing a trouble based on the DTC in this step only or failure to clear the DTC in this step may result in an faulty diagnosis, trouble diagnosis of a normal circuit or difficulty in troubleshooting which is otherwise unnecessary.

Step 3 and 4. Visual inspection

As a preliminary step, be sure to perform visual check of the items that support proper function of the 4WD control system referring to "Visual Inspection".

Step 5. Trouble symptom confirmation

Check trouble symptoms based on information obtained in "Step 1. Customer complaint analysis: " and "Step 2. DTC check, record and clearance: ".
Also, reconfirm DTC according to "DTC Confirmation Procedure" described in each DTC flow.

Step 6 and 7. Rechecking and record of DTC

Refer to "DTC Check" for checking procedure.

Step 8. 4WD control symptom diagnosis

Check the parts of the system suspected as a possible cause referring to "4WD Control Symptom Diagnosis".

Step 9. Troubleshooting for DTC

Based on the DTC indicated in Step 6 / 7 and referring to "applicable DTC flow", locate the cause of the trouble, namely in a sensor, switch, wire harness, connector, coupling assembly, 4WD control module or other part and repair or replace faulty parts.

Step 10. Check for intermittent problem

Check parts where an intermittent trouble is easy to occur (e.g. wire harness, connector, etc.), referring to "Intermittent and Poor Connection Inspection in Section 00" and related circuit of DTC recorded in Step 2.

Step 11. Final confirmation test

Confirm that the problem symptom has gone and the vehicle is free from any abnormal conditions. If what has been repaired is related to the malfunction DTC, clear the DTC once and check to ensure that no malfunction DTC is indicated.

4WD Position Indicator Operation Check

S7RW0C3204002

- 1) Turn ignition switch to OFF position.
- 2) Check that 4WD position indicators turn on for about 2 seconds and then turns off.
If any faulty condition is found, proceed to "4WD Position Indicator Does Not Come ON at Ignition Switch ON but Engine Stops" or "4WD Position Indicator Remains ON Steady at Ignition Switch ON".

4WD Control System Operation Inspection

S7RW0C3204003

NOTE

- It automatically changes into "4WD-auto" position, when the vehicle speed becomes specified speed or more at "4WD-lock" position. It is "4WD-auto" position until switch will be selected to "4WD-lock" position at next time.
- When ABS operates while changed of each position, it is discontinued of change. End of the ABS operation, and then returned to the position of before.

- 1) Inspect switch operation from "4WD-auto" to "2WD" as follows.
 - a) Start engine.
 - b) Push 2WD/4WD switch to "2WD" position.
 - c) Check that 4WD AUTO indicator and 4WD LOCK indicator not come ON.
- 2) Inspect switch operation from "2WD" to "4WD-auto" as follows.
 - a) Start engine.
 - b) Push 2WD/4WD switch to "AUTO" position.
 - c) Check that 4WD AUTO indicator comes ON steady and 4WD LOCK indicator not come ON.
- 3) Inspect switch operation from "4WD-auto" to "4WD-lock" as follows.
 - a) Start engine.
 - b) Push 2WD/4WD switch to "LOCK" position, and keep it for 3 seconds or more.
 - c) Check that 4WD AUTO indicator not come ON and 4WD LOCK indicator comes ON steady.
- 4) Inspect switch operation from "4WD-lock" to "4WD-auto" as follows.
 - a) Start engine.
 - b) Push 2WD/4WD switch to "AUTO" position.
 - c) Check that 4WD AUTO indicator comes ON steady and 4WD LOCK indicator not come ON.

Visual Inspection

S7RW0C3204004


Check the following parts and systems visually.

Inspection Item	Referring
• Rear differential oil ---- level, leakage • Transfer gear oil ---- level, leakage • Manual transmission oil ---- level, leakage • Rear differential mounting(s) ---- wear and looseness • Fuses ---- burning • Battery ---- fluid level, corrosion of terminal • Connectors of electric wire harness ---- disconnection, friction • Other parts that can be checked visually	"Rear Differential Oil Change" "Transfer Oil Change in Section 3C" "Manual Transaxle Oil Change in Section 5B" "Battery Inspection in Section 1J" "Intermittent and Poor Connection Inspection in Section 00"

DTC Check

S7RW0C3204005

- 1) Turn ignition switch to OFF position.
- 2) Connect SUZUKI scan tool to data link connector (DLC) (1) located on underside of instrument panel.

Special tool**(A): SUZUKI scan tool**


I5RW0A320008-01

- 3) Turn ignition switch to ON position.
- 4) Read DTC according to instructions displayed on SUZUKI scan tool and print it or write it down. Refer to SUZUKI scan tool operator's manual for further details.
If communication between SUZUKI scan tool and 4WD control module is not possible, check if SUZUKI scan tool is communicable by connecting it to 4WD control module in another vehicle. If communication is possible in this case, SUZUKI scan tool is in good condition. Then check data link connector and serial data line (circuit) in the vehicle with which communication was not possible.
- 5) After completing the check, turn ignition switch OFF and disconnect SUZUKI scan tool from data link connector (DLC).

DTC Clearance

S7RW0C3204006

- 1) Turn ignition switch to OFF position.
- 2) Connect SUZUKI scan tool to data link connector (DLC) (1) located on underside of instrument panel.

Special tool**(A): SUZUKI scan tool**

I5RW0A320008-01

- 3) Turn ignition switch to ON position.
- 4) Erase DTC according to instructions displayed on SUZUKI scan tool. Refer to SUZUKI scan tool operator's manual for further details.
- 5) After completing clearance, turn ignition switch OFF and disconnect SUZUKI scan tool from data link connector (DLC).
- 6) Perform "DTC Check" and confirm that NO CODES is displayed.

NOTE

DTC stored in 4WD control module memory are also cleared in the following cases. Be careful not to clear them before keeping their record.

- When power to 4WD control module is cut off (by disconnecting battery cable, removing fuse or disconnecting 4WD control module connectors).
- When the same malfunction (DTC) is not detected again during 40 engine warm-up cycles.

DTC Table

S7RW0C3204007

DTC No.	Detecting item	Detecting condition (DTC will set when detecting)	4WD position Indicator
C1240	4WD control module power supply circuit malfunction	Battery voltage is lower than lower limit voltage for 4WD control module diagnosis.	○
C1243	Internal circuit malfunction of 4WD control module	Internal power supply malfunction of 4WD control module	○
C1250	Coupling air temperature sensor open	Sensor output voltage too high	○
C1251	Coupling air temperature sensor short	Sensor output voltage too low	○
C1252	Coupling assembly open	2WD/4WD switch is changed of 4WD lock position, and then vehicle is not changed for more than 5 seconds.	○
C1253	Coupling assembly short	2WD/4WD switch is changed of 4WD lock position, and then vehicle is not changed for more than 5 seconds.	○
C1254	2WD/4WD switch malfunction	Different switch combination from specification is detected more than 5 seconds.	○
U0073	Control module communication bus off	Transmitting and receiving error of 4WD control module for specified time continuously	○
U0100	Lost communication with ECM	Receiving error of 4WD control module from ECM for specified time continuously	○
U0121	Lost communication with ABS / ESP® control module	Receiving error of 4WD control module from ABS / ESP® control module for specified time continuously	○
U0155	Lost communication with instrument panel cluster control module	Receiving error of 4WD control module from combination meter for specified time continuously	○

NOTE

“O” in transfer position indicator column of the above table means indicator lights up when DTC is detected.

Fail-Safe Table

S7RW0C3204008

This function is provided by the safe mechanism that assures safe driveability even when the coupling assembly, switch, sensor or its circuit fails. The following table shows the fail safe function for each fail condition of sensor, coupling assembly, switch, 4WD control module or its circuit.

DTC No.	Trouble Area	Fail-Safe Operation
C1240	4WD control module power supply circuit malfunction	4WD control module controls the current and fixed the vehicle to 2WD mode.
C1243	Internal circuit malfunction of 4WD control module	
C1250	Coupling air temperature sensor open	
C1251	Coupling air temperature sensor short	
C1252	Coupling assembly open	
C1253	Coupling assembly short	
C1254	2WD/4WD switch malfunction	
U0073	Control module communication bus off	
U0100	Lost communication with ECM	
U0121	Lost communication with ABS / ESP® control module	
U0155	Lost communication with instrument panel cluster control module	

Scan Tool Data

Scan tool data	Vehicle condition		Normal condition / reference values
⚙ Accel pedal Pos	Ignition switch ON after warmed up engine	Accelerator pedal released	0 – 5%
		Accelerator pedal depressed fully	90 – 100%
⚙ Engine speed	At engine idle speed		Engine idle speed is display
⚙ 4WD mode	2WD/4WD switch selected to 2WD position		2WD
	2WD/4WD switch selected to AUTO position		AUTO
	2WD/4WD switch selected to LOCK position		LOCK
	ABS operating		ABS mode
	Ignition switch ON and engine stop		Relay off
	Stability control operating		Yaw cont
⚙ 4WD current	ESP® operating		ESP® mode
	Engine running		0 – 200 mA
⚙ Battery voltage	At engine idle speed		10 – 14 V
⚙ Coupling temp	Engine running		–40 °C – 100 °C (–40 °F – 212 °F)
⚙ Wheel speed (F)	Vehicle stop		0 km/h, 0 MPH
⚙ Wheel speed (R)	Vehicle stop		0 km/h, 0 MPH
⚙ F-R Wheel speed Diff	Vehicle stop		0 rpm
⚙ 4WD duty	Ignition switch ON and 2WD/4WD switch selected to 2WD position		0%

Scan Tool Data Definitions

Accel pedal Pos (Accelerator pedal position) (%)

Accelerator pedal opening ratio detected by signal on CAN communication line fed from ECM.

Engine Speed (RPM)

This parameter indicates engine revolution calculated by 4WD control module.

4WD mode (2WD / AUTO / LOCK / ABS mode / Yaw cont / ESP® req)

This parameter indicates 4WD mode according to 2WD/4WD switch signal status detected by 4WD control module.

4WD current (A)

This parameter indicates input current of coupling assembly.

Battery voltage (V)

This parameter indicates battery voltage detected by 4WD control module.

Coupling temp (°C, °F)

Coupling temperature detected by coupling air temperature sensor installed in coupling assembly.

Wheel speed (F), Wheel speed (R) (km/h, mph)

Wheel speed is an ABS / ESP® control module internal parameter. It is computed by reference pulses from the wheel speed sensor.

F-R Wheel speed diff (Front-rear wheel speed differential) (rpm)

This parameter indicates rotation difference between front wheel and rear wheel detected by 4WD control module.

4WD duty (%)

This parameter indicates operation rate of coupling assembly.

Rear Differential Symptom Diagnosis

S7RW0C3204010

Condition	Possible cause	Correction / Reference Item
Gear noise	Deteriorated or water mixed lubricant	Repair and replenish referring to "Rear Differential Oil Change".
	Inadequate or insufficient lubricant	Repair and replenish referring to "Rear Differential Oil Change".
	Maladjusted backlash between drive bevel pinion and gear	Adjust as prescribed referring to "Rear Differential Disassembly and Reassembly".
	Improper tooth contact in the mesh between drive bevel pinion and gear	Adjust or replace referring to "Rear Differential Disassembly and Reassembly".
	Loose drive bevel gear securing bolts	Replace or retighten referring to "Rear Differential Disassembly and Reassembly".
	Damaged differential gear(s) or differential pinion(s)	Replace referring to "Rear Differential Inspection".
Bearing noise	(Constant noise) Deteriorated or water mixed lubricant	Repair and replenish referring to "Rear Differential Oil Change".
	(Constant noise) Inadequate or insufficient lubricant	Repair and replenish referring to "Rear Differential Oil Change".
	(Noise while coasting) Damaged bearing(s) of drive bevel pinion	Replace referring to "Rear Differential Inspection".
	(Noise while turning) Damaged differential side bearing(s) or axle bearing(s)	Replace referring to "Rear Differential Inspection".
Oil leakage	Clogged breather plug	Clean.
	Worn or damaged oil seal	Replace.
	Excessive oil	Adjust oil level referring to "Rear Differential Oil Change".
	Loose differential carrier bolts	Replace or retighten.

4WD Control Symptom Diagnosis

S7RW0C3204011

Diagnose 4WD system after performing the following inspections.


- Perform 4WD control system check referring to "4WD Control System Check".

Condition	Possible cause	Correction / Reference Item
4WD system does not operate	2WD/4WD switch faulty	Check switch referring to "2WD/4WD Switch Inspection".
	Coupling air temperature sensor faulty	Check coupling air temperature sensor referring to "Coupling Air Temperature Sensor Inspection".
	Coupling assembly faulty	Check coupling assembly referring to "Coupling Assembly Inspection".
	Wiring or grounding faulty	Repair as necessary.
	4WD control module faulty	Check 4WD control module referring to "Inspection of 4WD Control Module and Its Circuits".
	MAF sensor faulty	Check MAF sensor and its circuit.
	Accelerator pedal position (APP) sensor faulty	Check accelerator pedal position (APP) sensor and its circuit.
	CKP sensor faulty	Check CKP sensor and its circuit.
	Front and/or rear wheel speed sensor faulty	Check front and/or rear wheel speed sensor and its circuit.
	Steering angle sensor faulty	Check steering angle sensor and its circuit.
	ABS / ESP® control module faulty	Check ABS / ESP® control module and its circuit.
	ECM faulty	Check ECM and its circuit.
Noise	Damaged or worn bearing(s)	Refer to "Rear Differential Inspection".


4WD Position Indicator Does Not Come ON at Ignition Switch ON but Engine Stops

S7RW0C3204012

Wiring Diagram



[A]



I7RW01320004-01

[A]: 4WD control module connector "G26" (viewed from harness side)	4. Combination meter
1. Main fuse box	5. 4WD AUTO indicator
2. Junction block assembly	6. 4WD LOCK indicator
3. "METER" fuse	7. 4WD control module

Circuit Description

4WD position indicator operates according to the signal from 4WD control module. If the 4WD control system is in good condition, 4WD position indicator light up for 2 seconds when ignition switch is turned to ON position, and then turned to OFF position. If an abnormality is detected in the system, 4WD position indicator remains lighting.

Troubleshooting

Step	Action	Yes	No
1	4WD position indicator power supply check 1) Turn ignition switch to ON position. <i>Do other indicators come ON?</i>	Go to Step 2.	Go to Step 3.
2	Check DTC 1) Connect scan tool to DLC with ignition switch OFF. 2) Turn ignition switch to ON position and check DTC. <i>Is there DTC(s) U0073, U0100, U0121 and/or U0155?</i>	Go to applicable DTC diag. flow.	Substitute a known-good combination meter and recheck. If 4WD position indicator still remains off, substitute a known-good 4WD control module and recheck.

3B-16 Differential:

Step	Action	Yes	No
3	CAN communication circuit check 1) Check CAN communication circuit between combination meter and 4WD control module referring to “DTC U0073: Control Module Communication Bus Off”. <i>Is CAN communication circuit in good condition?</i>	Go to Step 4.	Repair or replace.
4	“METER” fuse check 1) Turn ignition switch to OFF position. 2) Check for fuse blown to “METER” fuse in junction block assembly. <i>Is “METER” fuse in good condition?</i>	Go to Step 5.	Replace “METER” fuse and check for short.
5	Combination meter power supply check 1) Remove combination meter referring to “Combination Meter Removal and Installation in Section 9C”. 2) Check proper connection to “WHT/RED” and “BLK” wire terminal of combination meter connector. 3) If OK, then turn ignition switch to ON position and measure voltage between “WHT/RED” wire terminal of combination meter connector and vehicle body ground. <i>Is it 10 – 14 V?</i>	Go to Step 6.	“WHT/RED” wire is open circuit.
6	Combination meter ground circuit check 1) Turn ignition switch to OFF position. 2) Measure resistance between “BLK” wire terminal of combination meter connector and vehicle body ground. <i>Is resistance 1 Ω or less?</i>	Substitute a known-good combination meter and recheck. If 4WD position indicator still remains OFF, substitute a known-good 4WD control module and recheck.	“BLK” wire is open or high resistance circuit.

4WD Position Indicator Remains ON Steady at Ignition Switch ON

S7RW0C3204013

Wiring Diagram

Refer to “4WD Position Indicator Does Not Come ON at Ignition Switch ON but Engine Stops”.

Circuit Description


Transfer position indicator operates according to the signal from 4WD control module. If the 4WD control system is in good condition, 4WD position indicator light up for 2 seconds when ignition switch is turned to ON position, and then turned to OFF position. If an abnormality is detected in the system, 4WD position indicator remains lighting.

Troubleshooting

Step	Action	Yes	No
1	Check DTC 1) Check DTC referring to “DTC Check”. <i>Is there any DTC(s)?</i>	Perform DTC flow to repair and retry.	Go to Step 2.
2	CAN communication circuit check 1) Check CAN communication circuit between combination meter and 4WD control module referring to “DTC U0073: Control Module Communication Bus Off”. <i>Is CAN communication circuit in good condition?</i>	Substitute a known-good combination meter and recheck. If 4WD position indicator still remains off, substitute a known-good 4WD control module and recheck.	Repair or replace.

DTC C1240: 4WD Control Module Power Supply Circuit Malfunction

S7RW0C3204014

Wiring Diagram

[A]: 4WD control module connector "G26" (viewed from harness side)	3. "4WD" fuse
1. 4WD control module	4. Main fuse box
2. "IG COIL" fuse	

DTC Detecting Condition and Trouble Area

DTC detecting condition	Trouble area
4WD control module power supply voltage is out of specification.	• 4WD control module power supply circuit

DTC Confirmation Procedure

- 1) Clear DTC using scan tool.
- 2) Turn ignition switch to ON position for 10 seconds.
- 3) Check DTC.

Troubleshooting

Step	Action	Yes	No
1	Was "4WD control system check" performed?	Go to Step 2.	Go to "4WD Control System Check".
2	4WD control module power circuit check 1) Disconnect 4WD control module connector with ignition switch OFF. 2) Check for proper connection to "G26" terminal of 4WD control module connector. 3) If connection is OK, measure voltage between "G26-11" terminal of 4WD control module connector and vehicle body ground with ignition switch ON. Is it 10 – 14 V?	Go to Step 3.	"4WD" fuse blown, "WHT/RED" or "YEL" wire is circuit open or circuit short.

3B-18 Differential:

Step	Action	Yes	No
3	Ground circuit check 1) Turn ignition switch to OFF position. 2) Check for proper connection to "G26-10" terminal of 4WD control module connector. 3) If OK, measure resistance between "G26-10" terminal of 4WD control module connector and vehicle body ground. <i>If resistance 1 Ω or less?</i>	Substitute a known-good 4WD control module and recheck.	Repair ground circuit.

DTC C1243: Internal Circuit Malfunction of 4WD Control Module

S7RW0C3204015

DTC Detecting Condition and Trouble Area

DTC detecting condition	Trouble area
Internal power supply malfunction of 4WD control module	4WD control module

DTC Confirmation Procedure

- 1) Clear DTC using scan tool.
- 2) Start engine and run it for 10 seconds. or more.
- 3) Stop vehicle and check DTC.


Troubleshooting

Substitute a known-good 4WD control module and recheck.

DTC C1250: Coupling Air Temperature Sensor Circuit Open

S7RW0C3204016

Wiring Diagram



[A]: 4WD control module connector "G26" (viewed from harness side)	2. 4WD control module
1. Coupling air temperature sensor	

DTC Detecting Condition and Trouble Area

DTC detecting condition	Trouble area
Input signal from coupling air temperature sensor is higher than specified value.	- Coupling air temperature sensor - Coupling air temperature sensor circuit 4WD control module

DTC Confirmation Procedure

- 1) Clear DTC using scan tool.
- 2) Turn ignition switch to ON position for 10 seconds.
- 3) Check DTC.


Troubleshooting

Step	Action	Yes	No
1	<i>Was "4WD control system check" performed?</i>	Go to Step 2.	Go to "4WD Control System Check".
2	Coupling air temperature sensor circuit check 1) Disconnect connector from coupling air temperature sensor with ignition switch turned OFF. 2) Check for proper connection to "BRN" and "ORN" terminals of coupling air temperature sensor connector. 3) If connection is OK, measure voltage between "BRN" terminal of coupling air temperature sensor connector and vehicle body ground with ignition switch turned ON. <i>Is it 4 – 6 V?</i>	Go to Step 3.	Go to Step 5.
3	Coupling assembly ground circuit check 1) Disconnect connector from 4WD control module with ignition switch turned OFF. 2) Measure resistance between "ORN" terminal of coupling air temperature sensor connector and "G26-24" terminal of 4WD control module connector with ignition switch turned OFF. <i>Is resistance below 5 Ω?</i>	Go to Step 4.	"ORN" wire is open or high resistance.
4	Coupling air temperature sensor check 1) Check coupling air temperature sensor referring to "Coupling Air Temperature Sensor Inspection". <i>Is it in good condition?</i>	Substitute a known-good 4WD control module and recheck.	Replace coupling air temperature sensor.
5	Coupling assembly circuit check 1) Disconnect connector from 4WD control module with ignition switch turned OFF. 2) Check for proper connection to "G26-25" and "G26-24" terminals of 4WD control module connector. 3) If connection is OK, measure resistance between "G26-25" terminal of 4WD control module connector and vehicle body ground. <i>Is resistance below 5 Ω?</i>	"BRN" wire is open or high resistance circuit.	Substitute a known-good 4WD control module and recheck.

DTC C1251: Coupling Air Temperature Sensor Circuit Short

S7RW0C3204017

Wiring Diagram



[A]: 4WD control module connector "G26" (viewed from harness side)	2. 4WD control module
1. Coupling air temperature sensor	

DTC Detecting Condition and Trouble Area

DTC detecting condition	Trouble area
Input signal from coupling air temperature sensor is lower than specified value.	- Coupling air temperature sensor - Coupling air temperature sensor circuit 4WD control module

DTC Confirmation Procedure

- 1) Clear DTC using scan tool.
- 2) Turn ignition switch to ON position for 10 seconds.
- 3) Check DTC.

Troubleshooting


Step	Action	Yes	No
1	Was "4WD control system check" performed?	Go to Step 2.	Go to "4WD Control System Check".
2	Coupling air temperature sensor circuit check 1) Disconnect connector from coupling air temperature sensor with ignition switch turned OFF. 2) Check for proper connection to "BRN" and "ORN" terminals of coupling air temperature sensor connector. 3) If connection is OK, measure voltage between "BRN" terminal of coupling air temperature sensor connector and vehicle body ground with ignition switch turned ON. Is it 4 – 6 V?	Go to Step 3.	Go to Step 5.

Step	Action	Yes	No
3	Coupling assembly ground circuit check 1) Disconnect connector from 4WD control module with ignition switch turned OFF. 2) Measure resistance between "ORN" terminal of coupling air temperature sensor connector and "G26-24" terminal of 4WD control module connector with ignition switch turned OFF. <i>Is resistance above 1 MΩ?</i>	Go to Step 4.	"ORN" wire is shorted to ground circuit.
4	Coupling air temperature sensor check 1) Check coupling air temperature sensor referring to "Coupling Air Temperature Sensor Inspection". <i>Is it in good condition?</i>	Substitute a known-good 4WD control module and recheck.	Replace coupling air temperature sensor.
5	Coupling assembly circuit check 1) Disconnect connector from 4WD control module with ignition switch turned OFF. 2) Check for proper connection to "G26-25" and "G26-24" terminals of 4WD control module connector. 3) If connection is OK, measure resistance between "G26-25" terminal of 4WD control module connector and vehicle body ground. <i>Is resistance above 1 MΩ?</i>	"BRN" wire is shorted to ground circuit.	Substitute a known-good 4WD control module and recheck.

DTC C1252: Coupling Assembly Circuit Open

S7RW0C3204018

Wiring Diagram



I7RW01320007-01

[A]: 4WD control module connector "G26" (viewed from harness side)	1. Coupling assembly
[B]: Coupling assembly connector "L102" (viewed from harness side)	2. 4WD control module

DTC Detecting Condition and Trouble Area

DTC detecting condition	Trouble area
2WD/4WD switch is changed of 4WD lock position, and then vehicle is not changed for more than 5 seconds.	- Coupling assembly - Coupling assembly circuit 4WD control module

DTC Confirmation Procedure


- 1) Clear DTC using scan tool.
- 2) Start engine and select 2WD/4WD switch to "LOCK" position.
- 3) Keep engine running at 2000 rpm for 10 seconds. or more.
- 4) Stop engine and check DTC.

Troubleshooting

Step	Action	Yes	No
1	<i>Was "4WD control system check" performed?</i>	Go to Step 2.	Go to "4WD Control System Check".
2	Coupling assembly circuit check 1) Disconnect coupling assembly connector "L102" with ignition switch turned OFF. 2) Check for proper connection to "L102-1" and "L102-4" terminals of coupling assembly connector. 3) If connection is OK, measure voltage between "L102-1" terminal of coupling assembly connector and vehicle body ground. <i>Is it 10 – 14 V?</i>	Go to Step 3.	Go to Step 6.
3	Coupling assembly ground circuit check 1) Measure resistance between "L102-4" terminal of coupling assembly connector and vehicle body ground with ignition switch turned OFF. <i>Is resistance below 5 Ω?</i>	Go to Step 4.	Go to Step 5.
4	Coupling assembly check 1) Check coupling assembly referring to "Coupling Assembly Inspection". <i>Is it in good condition?</i>	Substitute a known-good 4WD control module and recheck.	Replace coupling assembly.
5	Coupling assembly circuit check 1) Disconnect connector from 4WD control module connector "G26" with ignition switch turned OFF. 2) Check for proper connection to "G26-2" and "G26-3" terminals of 4WD control module connector. 3) If connection is OK, measure resistance between "G26-2" terminal of 4WD control module connector and vehicle body ground. <i>Is resistance below 5 Ω?</i>	"YEL" wire is open or high resistance circuit.	Substitute a known-good 4WD control module and recheck.
6	Coupling assembly circuit check 1) Disconnect connector from 4WD control module connector "G26" with ignition switch turned OFF. 2) Check for proper connection to "G26-3" terminal of 4WD control module connector. 3) If connection is OK, measure resistance between "G26-3" terminal of 4WD control module connector and "L102-1" terminal of coupling assembly connector. <i>Is resistance below 5 Ω?</i>	Substitute a known-good 4WD control module and recheck.	"GRY" wire is open or high resistance circuit.

DTC C1253: Coupling Assembly Circuit Short

S7RW0C3204019

Wiring Diagram

I7RW01320007-01

[A]: 4WD control module connector "G26" (viewed from harness side)	1. Coupling assembly
[B]: Coupling assembly connector "L102" (viewed from harness side)	2. 4WD control module

DTC Detecting Condition and Trouble Area

DTC detecting condition	Trouble area
2WD/4WD switch is changed of 4WD lock position, and then vehicle is not changed for more than 5 seconds.	- Coupling assembly - Coupling assembly circuit 4WD control module

DTC Confirmation Procedure

- 1) Clear DTC using scan tool.
- 2) Start engine and select 2WD/4WD switch to "LOCK" position.
- 3) Keep engine running at 2000 rpm for 10 seconds. or more.
- 4) Stop engine and check DTC.

Troubleshooting

Step	Action	Yes	No
1	Was "4WD control system check" performed?	Go to Step 2.	Go to "4WD Control System Check".
2	Coupling assembly circuit check 1) Disconnect coupling assembly connector "L102" with ignition switch turned OFF. 2) Check for proper connection to "L102-1" and "L102-4" terminals of coupling assembly connector. 3) If connection is OK, measure voltage between "L102-1" terminal of coupling assembly connector and vehicle body ground. Is it 10 – 14 V?	Go to Step 3.	Go to Step 6.
3	Coupling assembly ground circuit check 1) Measure resistance between "L102-4" terminal of coupling assembly connector and vehicle body ground with ignition switch turned OFF. Is resistance below 5 Ω?	Go to Step 4.	Go to Step 5.


3B-24 Differential:

Step	Action	Yes	No
4	Coupling assembly check 1) Check coupling assembly referring to “Coupling Assembly Inspection”. <i>Is it in good condition?</i>	Substitute a known-good 4WD control module and recheck.	Replace coupling assembly.
5	Coupling assembly circuit check 1) Disconnect connector from 4WD control module connector “G26” with ignition switch turned OFF. 2) Check for proper connection to “G26-2” and “G26-3” terminals of 4WD control module connector. 3) If connection is OK, measure resistance between “G26-2” terminal of 4WD control module connector and vehicle body ground. <i>Is resistance above 1 MΩ?</i>	“YEL” wire is shorted to ground circuit.	Substitute a known-good 4WD control module and recheck.
6	Coupling assembly circuit check 1) Disconnect connector from 4WD control module connector “G26” with ignition switch turned OFF. 2) Check for proper connection to “G26-3” terminal of 4WD control module connector. 3) If connection is OK, measure resistance between “G26-3” terminal of 4WD control module connector and “L102-1” terminal of coupling assembly connector. <i>Is resistance above 1 MΩ?</i>	Substitute a known-good 4WD control module and recheck.	“GRY” wire is shorted to ground circuit.

DTC C1254: 2WD/4WD Switch Malfunction

S7RW0C3204020

Wiring Diagram



I7RW01320008-01

[A]: 4WD control module connector “G26” (viewed from harness side)	2. 2WD/4WD switch
[B]: 2WD/4WD switch connect “L174” (viewed from harness side)	3. “4WD” switch
1. 4WD control module	4. “4WD-lock” switch

DTC Detecting Condition and Trouble Area

DTC detecting condition	Trouble area
2WD/4WD switch combination different from specification is detected for more than 5 seconds.	• 2WD/4WD switch • 2WD/4WD switch circuit • 4WD control module

DTC Confirmation Procedure

- 1) Clear DTC using scan tool.
- 2) Select 2WD/4WD switch to "2WD" position and keep its position for 10 seconds. Similarly select 2WD/4WD switch to "AUTO" and "LOCK" position.
- 3) Check DTC.

Troubleshooting

Step	Action	Yes	No
1	<i>Was "4WD control system check" performed?</i>	Go to Step 2.	Go to "4WD Control System Check".
2	2WD/4WD switch circuit check 1) Disconnect 2WD/4WD switch connector "L174" with ignition switch turned OFF. 2) Check for proper connection to "L174-1" and "L174-5" terminals of 2WD/4WD switch connector. 3) If connection is OK, measure voltage between "L174-1" terminal or "L174-5" terminal of 2WD/4WD switch connector and vehicle body ground. <i>Is it 10 – 14 V?</i>	Go to Step 3.	Go to Step 5.
3	2WD/4WD switch ground circuit check 1) Measure resistance between "L174-4" terminal of 2WD/4WD switch connector and vehicle body ground with ignition switch turned OFF. <i>Is resistance below 5 Ω?</i>	Go to Step 4.	"BLK/ORN" wire is shorted to ground.
4	2WD/4WD switch check 1) Check 2WD/4WD switch referring to "2WD/4WD Switch Inspection". <i>Is it in good condition?</i>	Substitute a known-good 4WD control module and recheck.	Replace 2WD/4WD switch.
5	2WD/4WD switch circuit check 1) Disconnect connector from 4WD control module connector "G26" with ignition switch turned OFF. 2) Check for shorted to ground in related circuits. • Between "G26-13" terminal of 4WD control module connector and "L174-1" terminal of 2WD/4WD switch connector. • Between "G26-14" terminal of 4WD control module connector and "L174-5" terminal of 2WD/4WD switch connector. <i>Are they in good condition?</i>	Substitute a known-good 4WD control module and recheck.	Repair circuit.

DTC U0073: Control Module Communication Bus Off

S7RW0C3204021

Refer to “Troubleshooting for CAN-DTC in Section 1A”.

DTC U0100: Lost Communication with ECM

S7RW0C3204022

Refer to “Troubleshooting for CAN-DTC in Section 1A”.

DTC U0121: Lost Communication with ABS / ESP® Control Module

S7RW0C3204023

Refer to “Troubleshooting for CAN-DTC in Section 1A”.

DTC U0155: Lost Communication with Instrument Panel Cluster (IPC) Control Module

S7RW0C3204024

Refer to “Troubleshooting for CAN-DTC in Section 1A”.

Inspection of 4WD Control Module and Its Circuits

S7RW0C3204025

4WD control module and its circuits can be checked at coupler connected to 4WD control module by measuring voltage, pulse signal.

⚠ CAUTION


4WD control module cannot be checked by itself. It is strictly prohibited to connect voltmeter or ohmmeter to 4WD control module with couplers disconnected from it.

Voltage and Signal Check

- 1) Check voltage using voltmeter (1) connected to each terminal of couplers.
- 2) Check signal using oscilloscope (2) connected to each terminal of couplers.


NOTE

- As each terminal voltage is affected by the battery voltage, confirm that it is 11 V or more when ignition switch is turned ON.
- Pulse signal cannot be measured by voltmeter. It can be measured by oscilloscope.
- Item with asterisk (*) in normal voltage column can be read only by oscilloscope.



I4JA01332053-01

Terminal arrangement of 4WD control module connector (Viewed from harness side)



I4JA01332054-01

Terminal Number	Wire Color	Circuit	Normal Voltage	Condition
G26-1	—	—	—	—
G26-2	GRN	Coupling assembly (ground)	About 5 V	Ignition switch turned ON position
G26-3	YEL	Coupling assembly (power)	10 – 12 V	- Run engine at idle speed and 2WD/4WD switch at 4WD lock position - Selector lever at “P” or “N” range (A/T model)
			*0 – 12 V (“Reference waveform No.1: ”)	- Run engine at idle speed and 2WD/4WD switch at 4WD lock position - Selector lever at other than “P” or “N” range (A/T model) or depress accelerator pedal (M/T model)
			About 5 V	Above-mentioned condition
G26-4	—	—	—	—
G26-5	—	—	—	—
G26-6	—	—	—	—
G26-7	—	—	—	—
G26-8	—	—	—	—
G26-9	—	—	—	—
G26-10	BLK	Ground	0 – 1 V	—
G26-11	WHT/RED	Power source for internal memory	10 – 14 V	—
G26-12	RED/BLK	Power source	10 – 14 V	Ignition switch turned ON position
G26-13	RED/WHT	4WD switch	0 – 1 V	Ignition switch turned ON position and 2WD/4WD switch at 4WD auto or 4WD lock position
			10 – 14 V	Ignition switch turned ON position and 2WD/4WD switch at 2WD position
G26-14	GRN/YEL	4WD lock switch	0 – 1 V	Ignition switch turned ON position and 2WD/4WD switch kept pushing at 4WD lock position
			10 – 14 V	Ignition switch turned ON position and 2WD/4WD switch released at 4WD lock position
G26-15	—	—	—	—
G26-16	—	—	—	—
G26-17	—	—	—	—
G26-18	—	—	—	—
G26-19	—	—	—	—
G26-20	—	—	—	—
G26-21	BLU	Data link connector (DLC)	10 – 14 V	Ignition switch turned ON position
G26-22	RED	CAN communication line (High)	*2.5 – 3.6 V (“Reference waveform No.2: ”)	Ignition switch turned ON position
G26-23	WHT	CAN communication line (Low)	*1.6 – 2.5 V (“Reference waveform No.2: ”)	Ignition switch turned ON position


3B-28 Differential:

Terminal Number	Wire Color	Circuit	Normal Voltage	Condition
G26-24	ORN	Coupling air temperature sensor (ground)	About 2.5 V	Ignition switch turned ON position
G26-25	BRN	Coupling air temperature sensor (power)	About 2.5 V	Ignition switch turned ON position
G26-26	—	—	—	—

Reference waveform No.1

Coupling assembly signal

Measurement terminal	CH1: "G26-3" to "G26-2"
Oscilloscope setting	CH1: 5 V / DIV TIME: 400 μs / DIV
Measurement condition	- Run engine at idle speed and 2WD/4WD switch at 4WD lock position - Selector lever at other than "P" or "N" range (A/T model) - Depress accelerator pedal (M/T model)




I7RW01320011-01

Reference waveform No.2

CAN communication signal

Measurement terminal	CH1: "G26-22" to "G26-10" CH2: "G26-23" to "G26-10"
Oscilloscope setting	CH1: 1 V / DIV, CH2: 1 V / DIV TIME: 400 μs / DIV
Measurement condition	Ignition switch ON position



I7RW01320012-01

- | |
|---|
| 1. CAN communication line signal (high) |
| 2. CAN communication line signal (low) |

Repair Instructions

Rear Differential Oil Level Check


S7RW0C3206001

- 1) Lift up vehicle and check oil leakage. Repair leaky point, if any.
 - 2) Remove oil level / filler plug (1) and check oil contamination and oil level is lower end of oil level / filler plug hole (2).
- If oil is excessive dirty or insufficient, replace oil or pour specified oil up to plug hole.
- 3) Apply sealant to thread of level / filler plug, and then tighten it to specified torque.

“A”: Sealant 99000–31260 (SUZUKI Bond No.1217G)

Tightening torque

Differential oil level / filler plug (a): 23 N·m (2.3 kgf-m, 17.0 lb-ft)



I5RW0A320015-01

Rear Differential Oil Change

S7RW0C3206002

- 1) Before changing oil, be sure to stop engine and lift vehicle horizontally.
- 2) With vehicle lifted up, check leakage. If leakage exists, correct it.

NOTE

Whenever vehicle is hoisted for any other service work than oil change, also be sure to check for oil leakage.

- 3) Remove oil filler plug (2).
- 4) Remove drain plug (1), and drain old oil.
- 5) Apply sealant to thread of drain plug (1), and tighten it to specified torque.

“A”: Sealant 99000–31260 (SUZUKI Bond No.1217G)

Tightening torque

Differential oil drain plug (a): 23 N·m (2.3 kgf-m, 17.0 lb-ft)

- 6) Pour new specified oil until oil level reaches bottom of oil filler plug hole (3) as shown in figure.

NOTE

- Hypoid gear oil must be used for differential.
- It is highly recommended to use API GL-5 80W-90 gear oil.

Differential oil specification

: API GL-5 (For SAE classification, refer to viscosity chart [A] in figure.)

Rear differential oil capacity



Reference: 0.7 – 0.9 liters (1.5/1.2 – 1.9/1.6 US/ Imp. pt.)

- 7) Apply sealant to thread of level / filler plug, and then tighten it to specified torque.

“A”: Sealant 99000–31260 (SUZUKI Bond No.1217G)

Tightening torque

Differential oil level / filler plug (b): 23 N·m (2.3 kgf-m, 17.0 lb-ft)




I5RW0A320016-02

2WD/4WD Switch Removal and Installation

S7RW0C3206003

Removal

- 1) Disconnect negative cable at battery.
- 2) Remove console box (2).
- 3) Remove 2WD/4WD switch (1) from console box.



I5RW0A320017-02


Installation

Reverse removal procedure for installation.

2WD/4WD Switch Inspection

S7RW0C3206004

Check 2WD/4WD switch for continuity between terminals at each switch position.
If check result is not as specified, replace switch.



Terminal	1	2	3	4	5
Switch position					
2WD				○	○
AUTO		○	○	○	○
LOCK	○	○	○	○	○


I5RW0A320018-02

4WD Control Module Removal and Installation

S7RW0C3206005

Removal

- 1) Disconnect negative cable at battery.
- 2) Remove center ventilation louver referring to “Center Ventilation Louver Removal and Installation in Section 7A”.
- 3) Disconnect connector (1) from 4WD control module.
- 4) Remove 4WD control module (2).



I5RW0A320019-01

Installation


Reverse removal procedure for installation.

Coupling Air Temperature Sensor Removal and Installation

S7RW0C3206006

Removal

- 1) Dismount rear differential referring to “Rear Differential Dismounting and Remounting”.
- 2) Remove coupling air temperature sensor (1) from rear differential (2).



I5RW0A320020-02

Installation

Reverse removal procedure for installation, noting the following point.

- Tighten coupling air temperature sensor to specified torque.

Tightening torque

Coupling air temperature sensor: 18 N·m (1.8 kgf·m, 13.0 lb·ft)

Coupling Air Temperature Sensor Inspection


S7RW0C3206007

⚠ CAUTION

Do not heat up coupling air temperature sensor more than 100 °C (212 °F). Otherwise, coupling air temperature sensor will be damaged.

- Blow hot air to temperature sensing part (2) of coupling air temperature sensor (3) using hot air drier (4) and measure resistance between sensor terminals while heating air gradually.

If measured resistance does not show such characteristic as shown, replace air temperature sensor.




I5RW0A320021-01

[A]: Lower limit	[D]: Resistance
[B]: Normal	[E]: Temperature
[C]: Upper limit	1. Temperature gauge

Coupling Assembly Inspection

S7RW0C3206008


- Check coupling assembly for oil leakage. If leakage exists, replace it.
- Measure resistance between “a” terminal and “b” terminal of coupling connector (1). If measured resistance is out of specification, check harness for open or short. If OK, replace coupling assembly.

Coupling assembly resistance**: 2 – 3 Ω**

I5RW0A320064-01

Rear Differential Mountings Components

S7RW0C3206009



I7RW01320010-01

1. Rear differential	6. Front mounting to body bolt	11. Rear mounting bolt	(b) : 50 N·m (5.0 kgf-m, 36.0 lb-ft)
2. Front mounting arm	7. Front mounting to body nut	12. Damper	X : Do not reuse.
3. Mounting arm bolt	8. Rear mounting bracket	13. Damper nut	
4. Front mounting	9. Rear mounting bracket bolt	14. Protector	
5. Front mounting bolt	10. Rear mounting	(a) : 80 N·m (8.0 kgf-m, 58.0 lb-ft)	

Front Mounting Arm and/or Rear Mounting Bracket Assembly Removal and Installation

S7RW0C3206010

Remove and install front mounting arm and/or rear mounting bracket after rear differential removed. For tightening torque of each bolt and nut, refer to "Rear Differential Mountings Components".

Rear Mounting Bracket Assembly Disassembly and Reassembly

S7RW0C3206011


Disassembly

Drive out mountings from rear mounting bracket using special tool and hydraulic press.

Special tool

(A): 09913-70123

(B): 09951-26020



I5RW0A320023-02


Reassembly

Press mountings in rear mounting bracket using special tool and hydraulic press with caring its installation position shown in figure.

Special tool

(A): 09913-85210

(B): 09951-26020




I5RW0A320024-02

Rear Differential Dismounting and Remounting

S7RW0C3206012

Dismounting

- 1) Lift up vehicle and drain oil from rear differential.
- 2) Remove propeller shaft referring to "Propeller Shaft Assembly Removal and Installation in Section 3D".
- 3) Remove rear drive shafts assembly referring to "Rear Drive Shaft Assembly Removal and Installation: Rear in Section 3A".
- 4) Support rear differential (3) with transmission jack (4).
- 5) Remove mounting arm bolts (2) and rear mounting bolts (1), and then lower rear differential with rear mounting bracket.



I5RW0A320025-01


Remounting

Reverse dismounting procedure for remounting of rear differential, noting the following points.

- Tighten each bolt to specified torque referring to "Rear Differential Mountings Components".
- Fill gear oil to rear differential referring to "Rear Differential Oil Change".

Rear Differential Components

S7RW0C3206013



I5RW0A320026-02

1. Flange nut	13. Differential cover bolt	25. Differential gear
2. Companion flange	14. Spacer	26. Spring washer
3. Oil seal : Apply grease 99000-25010 to oil seal lip.	15. Rear bearing	27. Thrust washer
4. Coupling front bearing	16. Shim	28. Pinion shaft
5. Coupling case : Apply sealant 99000-31260 to mating surface of carrier and coupling case.	17. Bevel pinion	29. Pinion shaft pin
6. Coupling assembly : Never disassemble.	18. Shim	30. Coupling case bolt
7. Snap ring	19. Differential side bearing	(a) : 23 N-m (2.3 kgf-m, 17.0 lb-ft)
8. Bevel pinion nut : Tighten nut so as rotation torque of bevel pinion to be in specified value.	20. Bevel gear	(b) : 125 N-m (12.5 kgf-m, 90.5 lb-ft)
9. Front bearing	21. Differential case	(c) : 78 N-m (7.8 kgf-m, 56.5 lb-ft)
10. Differential carrier : Apply sealant 99000-31260 to mating surface of carrier and rear cover.	22. Bevel gear bolt	: Do not reuse.
11. Coupling air temperature sensor	23. Pinion washer	: Apply differential oil.

Rear Differential Disassembly and Reassembly


S7RW0C3206014

Disassembly

- 1) Remove rear mounting bracket from rear differential referring to "Front Mounting Arm and/or Rear Mounting Bracket Assembly Removal and Installation".
- 2) Remove drive shaft flanges.
- 3) Separate coupling case from differential carrier using special tool.


Special tool**: 09912-34510**

- 4) Hold companion flange with special tool and then remove flange nut.

Special tool**(A): 09930-40113**

I5RW0A320027-01

- 5) Remove companion flange (1) from pinion. Use special tool if it is hard to remove.


Special tool**(A): 09913-65135**

I5RW0A320028-01

- 6) Remove coupling assembly (1) by using hydraulic press.

⚠ CAUTION


Do not drop coupling assembly. If it is dropped, replace it with a new one.



I5RW0A320029-01


- 7) Disassemble coupling case as follows, if necessary.

- a) Remove oil seal using special tool.

Special tool**(A): 09913-50121**

I5RW0A320030-01

- b) Remove snap ring using snap ring pliers.
- c) Remove bearing using special tool and hydraulic press.

Special tool**(A): 09913-75830**


I5RW0A320031-01

3B-36 Differential:

- 8) Remove oil seals from rear differential (1) using special tool.

Special tool

(A): 09913-50121




I5RW0A320032-01

- 9) Remove differential cover (1) using special tool, and then take out differential assembly, outer race and shim all at once.

Special tool

(A): 09912-34510




I5RW0A320033-01

- 10) Pull out differential side bearings (1) using special tools.

Special tool

(A): 09913-60910


(B): 09925-88210



I5RW0A320034-02

- 11) Remove drive bevel gear (hypoid gear), differential gears, differential pinions and pinion shaft as follows.

- a) With aluminum plates (2) placed on vise first, grip differential case with it and remove drive bevel gear (hypoid gear) (3) by removing its bolts (1).




I5RW0A320035-01

- b) Drive out differential side pinion shaft pin with special tool and hammer.

Special tool

(B): 09922-85811

- c) Disassemble differential gears (2), pinions (3), washers and shaft (4) in differential case (1).




I5RW0A320036-01

- 12) Remove bevel pinion nut with special tool.


Special tool

(A): 09927-27910




I5RW0A320037-04

- 13) Remove rear bearing (2) from drive bevel pinion (1) by using bearing puller (3) and hydraulic press.




I3RH01322026-01

- 14) Using a hammer and brass bar (1), drive out front bearing outer race (2).



I5RW0A320038-01

- 15) Using a hammer and brass bar (1), drive out rear bearing outer race (2).



I5RW0A320039-01

Reassembly

Judging from faulty conditions noted before disassembly and what is found through visual check of bearing and gear tooth etc. after disassembly, prepare replacing parts and proceed to reassembly according to procedures as described in the following.

⚠ CAUTION


- Bevel gear and pinion must be replaced as a set when either replacement becomes necessary.
- When replacing taper roller bearing, replace as inner race & outer race assembly.

- 1) Press-fit bevel pinion bearing outer races to differential carrier (1) by using special tools and hydraulic press as shown in the figure.

Special tool

(A): 09913-85210

(B): 09913-75510




I5RW0A320040-02

- 2) After applying differential oil to differential gears (4), pinions (5), pinion shaft (3), side washers (1), spring washers (7) and pinion washers (2), install them in differential case (6).

For correct installing direction of side washers and spring washers, refer to figure.


NOTE

Used left and right differential side washers are not interchangeable.



I5RW0A320041-01

- 3) Check pinion gear (1) for smooth rotation.




I3RH01322031-01

3B-38 Differential:

- 4) Align holes of pinion shaft and differential case and drive in differential pinion shaft pin till they are flush with end surface of case.

Special tool

(A): 09922-85811



I5RW0A320042-01


- 5) Put bevel gear (2) on differential case (3) and tighten new bolts (1) to specified torque.

⚠ CAUTION

Use of any other bolts than that specified is prohibited.

Tightening torque

Bevel gear bolt (a): 73 N·m (7.3 kgf-m, 52.0 lb-ft)




I5RW0A320043-01

- 6) Press-fit differential right side bearing (1) with special tools and hydraulic press.

Special tool

(A): 09913-80113

(B): 09926-48010



I5RW0A320044-01

- 7) Hold differential right side bearing (2) with special tool and press-fit differential left side bearing (1) with special tools and hydraulic press.

NOTE


Be sure to use bearing holder for the purpose of protecting lower bearing.

Special tool

(A): 09913-80113

(B): 09926-48010

(C): 09925-88210



I5RW0A320045-01

- 8) To engage drive bevel pinion and gear correctly, it is pre-required to install drive bevel pinion to differential carrier properly by using adjusting shim as described on the followings. Shown below is relative positions of drive bevel pinion, differential carrier and mounting dummy.

Special tool

(A): 09922-76120

(B): 09922-76250

(C): 09922-76140


(D): 09922-76420

(E): 09922-76330

(F): 09922-76150

(G): 09922-76340

(H): 09922-76530



1. Front bearing	"a": Pinion dummy height + Attachment height 49 mm/1.929 in.
2. Differential carrier	"b": Axle dummy radius 31 mm/1.220 in.
3. Rear bearing	"a" + "b": Mounting dummy size 80 mm/3.149 in.
4. Spacer	"c": Measured dimension
5. Drive bevel pinion	"d": Drive bevel pinion mounting distance 80 mm/3.149 in.
6. Drive bevel gear	"e": Shim size for mounting distance adjustment ("e" = "c")

I5RW0A320046-03

3B-40 Differential:

- 9) Set special tools and make drive bevel pinion mounting dummy.

Special tool

(A): 09922-76120


(B): 09922-76250

- 10) Install dial gauge (1) to mounting dummy as shown in figure.

Special tool set distance

"a": 38.0 mm (1.496 in.)

"b": 0 mm (0.000 in.)



- 11) Set special tools and make drive bevel pinion dummy.


Special tool

(A): 09922-76140

(B): 09922-76420

(C): 09922-76330

(D): 09922-76340



- 12) Apply gear oil to drive bevel pinion bearings, install special tools with bearings to differential carrier as shown in figure.

Special tool

(A): 09922-76140

(B): 09922-76420

(C): 09922-76330


(D): 09922-76340

(E): 09922-76150

(F): 09922-76530

NOTE

This installation requires no spacer or oil seal.




- 13) Tighten bevel pinion nut (special tool) (1) so that specified bearing preload is obtained.

NOTE

Before taking measurement, check for rotation by hand more than 15 revolutions.

Pinion bearing preload (at 50 r/min)


: 1.3 – 2.6 N·m (13.0 – 26.0 kgf-cm, 11.3 – 22.6 lb-in.)



- 14) Set dial gauge to bevel pinion mounting dummy and make 0 (zero) adjustment on surface plate.

NOTE

- When setting dial gauge to mounting dummy, tighten screw lightly. Be careful not to overtighten it, which will cause damage to dial gauge.
- With dial gauge set, turn dummy back and forth by hand a couple of times and attain accurate 0 (zero) adjustment.
- It is desirable that short pointer indicates beyond 2 mm when long one is at 0 (zero).




I5RW0A320051-01

- 15) Place zero-adjusted mounting dummy (1) and dial gauge set on pinion dummy (2) and take measurement between zero position and extended dial gauge measuring tip.

NOTE

- Repeat turning back and forth of dummy and measure distance as far as top surface of pinion dummy accurately.
- When dial gauge measuring tip extends from 0 (zero) position, pointer turns counterclockwise.



I5RW0A320052-01

- 16) Necessary adjusting shim thickness is the same value as measured value by dial gauge.

$$\text{Necessary shim thickness "e"} = \text{Dial gauge measured value "c"}$$


- 17) Select adjusting shim(s) (2) closest to obtained value from among the following available sizes and put it in place and then press-fit rear bearing (1) to bevel pinion (3).

Available shim thickness

0.30, 0.60, 0.63, 0.66, 0.69, 0.72, 0.75, 0.78, 0.81, 0.84 and 0.87 mm (0.012, 0.023, 0.024, 0.026, 0.027, 0.028, 0.030, 0.031, 0.032, 0.033 and 0.034 in.)

Special tool

(D): 09925-18011




I3RH01322055-01

- 18) With new pinion spacer (2) inserted as shown in figure, install front bearing (1) to differential carrier (3).

NOTE

Apply differential oil to front and rear bearings.



I5RW0A320053-01

3B-42 Differential:

- 19) Using special tool and plastic hammer, drive oil seal (2) into differential carrier (1) as shown in figure. Then apply grease to oil seal lip.

NOTE

Install oil seal horizontally to surface of differential carrier.

"A": Grease 99000-25010 (SUZUKI Super Grease A)


Distance between differential carrier and oil seal

"a"

: 0.5 – 1.5 mm (0.02 – 0.06 in.)

Special tool

(A): 09913-85210



I5RW0A320054-02

- 20) Tighten bevel pinion nut (1) gradually with special tool to specified torque while turning bevel pinion. Set bearing preload of bevel pinion to specification.

NOTE

- Before taking measurement with torque wrench, check for smooth rotation with turning bevel pinion 15 revolutions or more by hand.
- Be sure to tighten gradually and carefully till specified pinion bearing preload is obtained. Turning back overtightened flange nuts should be avoided.
- Measure pinion bearing preload while turning bevel pinion about 50 rpm.
- Write down measured value of bevel pinion bearing preload for differential side bearing shim adjustment.

Special tool


(A): 09927-27910

Tightening torque

Bevel pinion nut: 230 – 340 N·m (23.0 – 34.0 kgf-m, 166.5 – 246.0 lb-ft)

Bevel pinion bearing preload (Bevel pinion rotational torque)

: 1.3 – 2.6 N·m (13.0 – 26.0 kgf-cm, 11.3 – 22.6 lb-in.)



I5RW0A320055-03

- 21) Install differential case assembly, bearing outer races, removed shim and differential cover, temporarily.

NOTE

- Used left and right outer races are not interchangeable.
- When measuring bevel pinion bearing preload, install differential cover with sealant not applied.

- 22) Select differential side bearing shim so that bevel pinion bearing preload may be specified value.

NOTE


Select shims so that thickness of right side shims and left side shims become almost even.

Bevel pinion bearing preload

Preload measured in Step 20) + 0.3 – 0.7 N·m (3 – 7 kgf-cm, 2.6 – 6.0 lb-in.)

Available shim thickness

0.45, 2.30, 2.35, 2.40, 2.45, 2.50, 2.55, 2.60, 2.65 and 2.70 mm (0.017, 0.090, 0.092, 0.094, 0.096, 0.098, 0.100, 0.102, 0.104 and 0.106 in.)



I5RW0A320056-01

- 23) Remove differential cover.
- 24) To measure bevel gear backlash, set dial gauge at right angle to bevel gear tooth, fix drive bevel pinion and read dial gauge while moving bevel gear. If bevel gear backlash is out of specification, repeat Step 22).

NOTE

- Be sure to apply measuring tip of dial gauge at right angles to convex side of tooth.
- Measure at least 4 points on drive bevel gear periphery.


Drive bevel gear backlash

0.1 – 0.2 mm (0.004 – 0.008 in.)

Special tool

(A): 09900–20607

(B): 09900–20701




I5RW0A320057-01

- 25) As final step, check gear tooth contact as follows.

- After cleaning 10 drive bevel gear teeth, paint them with gear marking compound evenly by using brush (1) or sponge etc.
- Turn gear to bring its painted part in mesh with drive bevel pinion and turn it back and forth by hand to repeat their contact.
- Bring painted part up and check contact pattern, referring to the following table. If contact pattern is not normal, readjust or replace as necessary according to instruction in the table.



NOTE





Be careful not to turn drive bevel gear more than one full revolution, for it will hinder accurate check.



I5JB0A321040-02

A: Paint gear marking compound evenly

Tooth Contact Pattern	Diagnosis and Remedy	
 I5JB0A321041-05	Normal	
 IYSQ01321072-01	High Contact Pinion is positioned too far from the center of drive bevel gear (1). • Increase thickness of pinion (2) height adjusting shim and position pinion closer to gear center. • Adjust drive bevel gear backlash to specification.	 IYSQ01321073-01


Tooth Contact Pattern	Diagnosis and Remedy	
 IYSQ01321074-01	Low Contact Pinion is positioned too close to the center of drive bevel gear (1). - Decrease thickness of pinion (2) height adjusting shim and position pinion farther from gear center. - Adjust drive bevel gear backlash to specification.	 IYSQ01321076-01
 IYSQ01321077-01	If adjustment is impossible, replace differential carrier.	
 IYSQ01321078-01	- Check seating of bevel gear or differential case. (Check bevel gear for runout.) - If adjustment is impossible, replace drive bevel gear and pinion set or differential carrier.	
 IYSQ01321079-01	Replace drive bevel gear and pinion set or differential case.	

26) Clean mating surface of differential carrier (1) and differential cover, apply sealant to carrier as shown in figure by such amount that its section is 1.5 mm (0.059 in.) in diameter, mate differential cover with differential carrier, and then tighten bolts to specified torque.

“A”: Sealant 99000–31260 (SUZUKI Bond No.1217G)

Tightening torque

Differential cover bolt: 23 N·m (2.3 kgf-m, 17.0 lb-ft)




I5RW0A320058-02

27) Assemble coupling case as follows.

- a) Install bearing using special tool and hydraulic press.

Special tool

(A): 09913–75830



I5RW0A320059-02

- b) Install snap ring using snap ring pliers.
- c) Apply grease to oil seal lip, install oil seal (2) to coupling case (1) using special tool as shown in figure.


NOTE

Install oil seal horizontally to surface of coupling case.

“A”: Grease 99000–25010 (SUZUKI Super Grease A)


Distance between case and oil seal “a”
: 1.5 – 2.5 mm (0.06 – 0.10 in.)

Special tool
(A): 09913–75810



I5RW0A320060-02

- 28) Install spacer (1) to coupling assembly (2) as shown in figure.




I5RW0A320065-01

- 29) Install grommet of coupling harness into groove of coupling case and then install coupling assembly by using hydraulic press.
- 30) Install companion flange to pinion, and then hold companion flange with special tool and tighten flange nut.

Tightening torque
Flange nut: 110 N·m (11.0 kgf-m, 79.5 lb-ft)

Special tool
(A): 09930–40113



I5RW0A320061-01



- 31) Clean mating surface of differential carrier (1) and coupling case (2), apply sealant to carrier as shown in figure by such amount that its section is 1.5 mm (0.059 in.) in diameter, mate coupling case with differential carrier as shown in figure, and then tighten bolts to specified torque.

“A”: Sealant 99000–31260 (SUZUKI Bond No.1217G)

Tightening torque
Coupling case bolt (a): 23 N·m (2.3 kgf-m, 17.0 lb-ft)

NOTE

Install coupling pin (3) by fitting it to groove (4) of coupling case.



I5RW0A320062-04

3B-46 Differential:

- 32) Apply grease to oil seal lip, and then install oil seals (1) to rear differential (2) using special tool as shown in figure.

NOTE

Install oil seal horizontally to surface of rear differential case.

“A”: Grease 99000–25010 (SUZUKI Super Grease A)


Distance between rear differential and oil seal

“a”

: 1.0 – 2.0 mm (0.04 – 0.08 in.)

Special tool

(A): 09913–75810



I5RW0A320063-02

- 33) Install drive shaft flange.

- 34) Install rear mounting bracket to rear differential referring to “Front Mounting Arm and/or Rear Mounting Bracket Assembly Removal and Installation”.

Rear Differential Inspection

S7RW0C3206015

- Check companion flange for wear or damage.
- Check bearings for wear or discoloration.
- Check differential carrier for cracks.
- Check drive bevel pinion and bevel gear for wear or cracks.
- Check side gears, pinion gears and pinion shaft for wear or damage.
- Check side gear spline for wear or damage.

Specifications

Tightening Torque Specifications

S7RW0C3207001

Fastening part	Tightening torque			Note
	N·m	kgf-m	lb-ft	
Differential oil level / filler plug	23	2.3	17.0	🔧 / 🛢️
Differential oil drain plug	23	2.3	17.0	🔧
Coupling air temperature sensor	18	1.8	13.0	🔧
Bevel gear bolt	73	7.3	52.0	🔧
Bevel pinion nut	230 – 340	23.0 – 34.0	166.5 – 246.0	🔧
Differential cover bolt	23	2.3	17.0	🔧
Flange nut	110	11.0	79.5	🔧
Coupling case bolt	23	2.3	17.0	🔧

NOTE

The specified tightening torque is also described in the following.

“Rear Differential Mountings Components”

“Rear Differential Components”

Reference:

For the tightening torque of fastener not specified in this section, refer to “Fasteners Information in Section 0A”.

Special Tools and Equipment

Recommended Service Material

S7RW0C3208001












Material	SUZUKI recommended product or Specification		Note
Grease	SUZUKI Super Grease A	P/No.: 99000-25010	🔧 / 🔧 / 🔧
Sealant	SUZUKI Bond No.1217G	P/No.: 99000-31260	🔧 / 🔧 / 🔧 / 🔧 / 🔧

NOTE

Required service material is also described in the following.
 “Rear Differential Components”

Special Tool

S7RW0C3208002

09900-20607 Dial gauge 🔧		09900-20701 Magnetic stand 🔧	
09912-34510 Case separator 🔧 / 🔧		09913-50121 Oil seal remover 🔧 / 🔧	
09913-60910 Bearing and gear puller (40-60mm) 🔧		09913-65135 Bearing puller 🔧	
09913-70123 Bearing installing tool 🔧		09913-75510 Bearing installer 🔧	
09913-75810 Bearing installer 🔧 / 🔧		09913-75830 Steering pinion bush installer 🔧 / 🔧	
09913-80113 Bearing installer 🔧 / 🔧		09913-85210 Bearing installer 🔧 / 🔧 / 🔧	

3B-48 Differential:

09922-76120 Mounting dummy shaft 	09922-76140 Bevel pinion shaft 
09922-76150 Bevel pinion nut 	09922-76250 Bevel gear dummy 
09922-76330 Bevel pinion rear collar 	09922-76340 Bevel pinion rear collar 
09922-76420 Bevel pinion front collar 	09922-76530 Bevel pinion gauge block 
09922-85811 Spring pin remover (4.5 mm) 	09925-18011 Transmission gear, bush and bearing installer 
09925-88210 Bearing puller attachment 	09926-48010 Universal joint assembling tool 
09927-27910 Holder, bevel pinion 	09930-40113 Flywheel rotor holder 


09951-26020

Bush remover & installer
support

SUZUKI scan tool

—

This kit includes following items. 1. Tech 2, 2. PCMCIA card, 3. DLC cable, 4. SAE 16/19 adapter, 5. Cigarette cable, 6. DLC loop back adapter, 7. Battery power cable, 8. RS232 cable, 9. RS232 adapter, 10. RS232 loop back connector, 11. Storage case, 12. 




Transfer

General Description

Transfer Description

S7RW0C3301001

The transfer is mounted on transaxle case by fastening bolt with reduction drive gear in transfer and differential case in transaxle coupled by involute spline. Driving force from transaxle is transmitted to propeller shaft through reduction drive gear, reduction driven gear and bevel gear of transfer. As bevel gears, which change the direction of driving torque axis to the direction of the angle with 90 degrees, hypoid gears are provided. Hypoid gears have an advantage of preventing gear noise, at the same time, they require accurate adjustment of tooth contact and backlash.



I5RW0A330001-01

1. Intermediate shaft	5. Reduction driven gear	9. Transfer output retainer
2. Left case	6. Bevel gear	10. Transfer output flange
3. Reduction drive gear	7. Bevel pinion	
4. Right case	8. Spacer	

Diagnostic Information and Procedures

Transfer Symptom Diagnosis

S7RW0C3304001

Condition	Possible cause	Correction / Reference Item
Noise	Inadequate or insufficient lubricant	Replenish.
	Damaged or worn bearing(s)	Replace.
	Damaged or worn gear(s)	Replace.
	Preload of taper roller bearing is reduced	Adjust.

Repair Instructions

Transfer Oil Level Check


S7RW0C3306001

- 1) Lift up vehicle and check oil leakage. Repair leaky point, if any.
- 2) Remove oil level / filler plug (1) and check oil contamination and oil level is lower end of oil level / filler plug hole (2).
If oil is excessive dirty or insufficient, replace oil or pour specified oil up to plug hole.
- 3) Apply sealant to thread of level / filler plug, and then tighten it to specified torque.

"A": Sealant 99000-31260 (SUZUKI Bond No.1217G)

Tightening torque

Transfer oil level / filler plug (a): 23 N·m (2.3 kgf-m, 17.0 lb-ft)



I5RW0A330002-01

Transfer Oil Change

S7RW0C3306002

- 1) Before changing oil, be sure to stop engine and lift vehicle horizontally.
- 2) Check leakage.
If leakage exists, correct it.

NOTE

Whenever vehicle is hoisted for any other service work than oil change, also be sure to check for oil leakage.

- 3) Remove oil filler plug (2).
- 4) Remove drain plug (1), and drain oil.
- 5) Apply sealant to thread of drain plug (1), and tighten it to specified torque.

"A": Sealant 99000-31260 (SUZUKI Bond No.1217G)

Tightening torque

Transfer oil drain plug (a): 23 N·m (2.3 kgf-m, 17.0 lb-ft)

- 6) Pour new specified oil up to lower end of oil level / filler plug hole (3).

NOTE

It is highly recommended to use API GL-5 80W-90 gear oil.

Transfer oil specification

: API GL-5 (For SAE classification, refer to viscosity chart [A] in figure.)

Transfer oil capacity



Reference: 0.6 liters (1.2/1.0 US/Imp. pt)

- 7) Apply sealant to thread of level / filler plug, and then tighten it to specified torque.

"A": Sealant 99000-31260 (SUZUKI Bond No.1217G)

Tightening torque

Transfer oil level / filler plug (b): 23 N·m (2.3 kgf-m, 17.0 lb-ft)






I5RW0A330003-01

Transfer Dismounting and Remounting

S7RW0C3306003

Dismounting

- 1) Disconnect negative (–) cable at battery.
- 2) Drain transaxle oil and transfer oil.
- 3) Remove drive shaft assembly referring to “Front Drive Shaft Assembly Removal and Installation: Front in Section 3A”.
- 4) Remove exhaust No.1, No.2 and center pipes referring to “Exhaust Pipe and Muffler Removal and Installation in Section 1K”.
- 5) Remove propeller shaft referring to “Propeller Shaft Assembly Removal and Installation in Section 3D”.
- 6) Remove engine rear mounting upper nut (1), lower nut (3) and stiffeners (2).




I7RW01330001-01

3.	Transfer
4.	Engine rear mounting
5.	Front suspension frame

- 7) Carry out Step 2) to 12) of “Removal” under “Front Suspension Frame, Stabilizer Bar and/or Bush Removal and Installation (2WD Model) in Section 2B” in order to lower transfer with front suspension frame.
- 8) Remove front suspension frame front mounting bolt and loosen front suspension frame rear mounting bolt a little.
- 9) Remove transfer to transaxle bolts (1) and nut (3) (A/T model), and then separate transfer (2) with engine rear mounting from transaxle.

NOTE

When separate transfer and engine rear mounting from transaxle, check front suspension frame for dent. If any dent is found on it, apply rust retardant it.



I7RW01330002-01

- 10) Remove front suspension frame rear bolt.

⚠ CAUTION

When removing transfer, be careful not to drop it. Otherwise, transfer damage and personal injury may result.


- 11) Lower front suspension frame with steering gear case and transfer, and then remove transfer.

Remounting

Reverse dismounting procedure for remounting of transfer, noting the following points.

- Apply grease to left case (1) and new O-ring (2) as shown in figure.
- Use new O-ring.
- Apply grease to O-ring (2).

“A”: Grease 99000–25010 (SUZUKI Super Grease A)



I7RW01330003-01

- Tighten front suspension bolts to specified torque referring to “Front Suspension Construction in Section 2B”.
- Tighten bolts and nut specified torque as follows.


Tightening torque

Stiffener No.1 bolt and No.2 bolt (a): 55 N·m (5.5 kgf-m, 40.0 lb-ft)

Transfer to transaxle bolt (b): 98 N·m (9.8 kgf-m, 71.0 lb-ft)

Engine rear mounting upper nut (c): 25 N·m (2.5 kgf-m, 18.0 lb-ft)

Engine rear mounting lower nut (d): 55 N·m (5.5 kgf-m, 40.0 lb-ft)




I7RW01330004-01

- Pour transaxle oil and transfer oil referring to “Manual Transaxle Oil Change in Section 5B” or “A/T Fluid Change in Section 5A” and “Transfer Oil Change”.
- Confirm front wheel alignment referring to “Front Wheel Alignment Inspection and Adjustment in Section 2B”.

Transfer Assembly Components

S7RW0C3306004



I5RW0A330007-05

1. Transfer output flange nut : After tightening nut so as rotational torque of bevel pinion to be in specified value, caulk nut securely.	15. Dowel pin	29. Transfer right case : Apply sealant 99000-31260 to mating surface with right case.
2. Transfer output flange	16. Oil drain plug : Apply sealant 99000-31260 to thread part.	30. Oil level / filler plug : Apply sealant 99000-31260 to thread part.
3. Oil seal : Apply grease 99000-25010 to oil seal lip.	17. Transfer left case : Apply grease 99000-25010 to left case.	31. Left case oil seal No.1 : Apply grease 99000-25010 to oil seal lip.
4. Pinion shaft rear taper roller bearing	18. Transfer case bolt	32. Left case oil seal No.2 : Apply grease 99000-25010 to oil seal lip.
5. Transfer output retainer bolt	19. Reduction drive gear left bearing	33. Right case oil seal No.3 : Apply grease 99000-25010 to oil seal lip.
6. O-ring : Apply grease 99000-25010 to all around surface.	20. Reduction drive gear	34. Right case oil seal No.2 : Apply grease 99000-25010 to oil seal lip.
7. Shim	21. Reduction driven gear left taper roller bearing	35. Right case oil seal No.1 : Apply grease 99000-25010 to oil seal lip.
8. Spacer	22. Reduction driven gear right taper roller bearing	36. Transfer output retainer
9. Pump seal	23. Reduction drive gear right bearing	(a) : 55 N·m (5.5 kgf-m, 40.0 lb-ft)
10. Pinion shaft front taper roller bearing	24. Intermediate shaft	(b) : 21 N·m (2.1 kgf-m, 15.5 lb-ft)
11. Bevel pinion	(c) 25. Oil protect plate bolt : Apply thread lock cement 99000-32110 to thread part.	(c) : 23 N·m (2.3 kgf-m, 17.0 lb-ft)

12. Bevel gear	26. Snap ring	 : 9 N·m (0.9 kgf-m, 6.5 lb-ft)
13. Reduction driven gear	27. Oil protect plate	 : Do not reuse.
14. Intermediate shaft bearing	28. Shim	 : Apply transfer oil.

Transfer Assembly Disassembly and Reassembly

S7RW0C3306005

Disassembly


NOTE

It is possible to disassemble transfer assembly without removing intermediate shaft with Step 1) to 4) performed if not necessary.

- 1) Remove right case oil seal No.1 (1) from transfer right case using special tool.

Special tool
: 09913-50121

- 2) Remove snap ring (2) by using snap ring pliers.
- 3) Remove intermediate shaft (4) with intermediate shaft bearing (3) from transfer assembly.
- 4) Remove intermediate shaft bearing (3) from intermediate shaft (4) by using bearing puller and hydraulic press.



I5RW0A330008-01

- 5) Remove transfer output retainer assembly (1) and shim (3) by removing retainer bolts (2).
- 6) Remove transfer case bolts (4).
- 7) Separate transfer right case (5) from transfer left case (6) by using special tool.


Special tool
(A): 09912-34510

- 8) Remove reduction drive gear assembly (7) and reduction driven gear assembly (9).
- 9) Remove shim (10) and bearing outer races (8).

NOTE

When it is difficult to remove bearing outer races from cases, remove them with special tool.

Special tool
(B): 09944-96011





I5RW0A330009-03

11. Dowel pin

Reassembly

- 1) Select appropriate shim as follows.
 - a) Measure distance "a" between taper roller bearing outer races of reduction driven gear assembly (1).
 - b) Measure depth "b" of left case (2) and "c" of right case (3).
 - c) Obtain adjusting shim thickness by the following equation.

$$\begin{array}{l} \text{Necessary} \\ \text{shim} \\ \text{thickness} \end{array} = \begin{array}{l} \text{Depth} \\ \text{"b"} \end{array} + \begin{array}{l} \text{Depth} \\ \text{"c"} \end{array} - \begin{array}{l} \text{Distanc} \\ \text{e "a"} \end{array} + \begin{array}{l} 0.1 \text{ mm} \\ (0.004 \\ \text{in.}) \end{array}$$



I5RW0A330010-01

3C-7 Transfer:

- d) Select a shim which is close to half thickness of the calculated value (necessary shim thickness) from among the available shims to install it between bearing and case at each of right and left sides.

For example:


Measure distance "a" is 110.75 mm (4.360 in.).
Measure depth "b" is 85.8 mm (3.378 in.).
Measure depth "c" is 26.55 mm (1.045 in.).
Necessary shim thickness = 85.8 mm (3.378 in.) + 26.55 mm (1.045 in.) – 110.75 mm (4.360 in.) + 0.1 mm (0.004 in.) = 1.7 mm (0.067 in.)
 $1.7 \text{ mm (0.067 in.)} \div 2 = 0.85 \text{ mm (0.033 in.)}$
Calculated thickness of new shim = 0.85 mm (0.033 in.)

Available reduction driven gear shim thickness

0.60, 0.65, 0.70, 0.75, 0.80, 0.85, 0.90, 0.95, 1.00 and 1.05 mm (0.024, 0.026, 0.028, 0.030, 0.031, 0.033, 0.035, 0.037, 0.039 and 0.041 in.)

- 2) Clean mating surface of right and left cases, and apply sealant to right case (1) as shown in figure by such amount that its section is 1.2 mm (0.047 in.) in diameter.

"A": Sealant 99000–31260 (SUZUKI Bond No.1217G)



I5RW0A330011-01


- 3) Assemble the following parts in right and left cases by reversing disassembling procedure.

- Reduction drive gear assembly (1)
- Reduction driven gear assembly (3)
- Bearing outer races (2)
- Reduction driven gear shims (5)
- Dowel pin (6)

- 4) Tighten transfer case bolts (4) to specified torque.

Tightening torque

Transfer case bolt (a): 23 N·m (2.3 kgf-m, 17.0 lb-ft)




I5RW0A330012-02

- 5) Select bevel pinion shim (3) referring to step 1) of "Reassembly" under "Transfer Output Retainer Assembly Disassembly and Reassembly".
- 6) Inspect tooth contact according to "Bevel Gear Tooth Contact Inspection".
- 7) Install transfer output retainer assembly (2) with bevel pinion shim (3) to transfer left case (4) by tightening retainer bolt (1) to specified torque.

Tightening torque

Transfer output retainer bolt (a): 55 N·m (5.5 kgf-m, 40.0 lb-ft)



I5RW0A330013-02

- 8) Install bolt to bolt hole of flange (2), set dial gauge measuring tip at right angles to bolt (1) as shown in figure. Holding reduction driven gear by hand, take measurement backlash of pinion and bevel gear.

NOTE


If backlash exceeds specification given below, adjust it by changing thickness ratio of shims assembled in right and left cases in Step 3).

Special tool

(A): 09900–20607

(B): 09900–20701

Bevel pinion & bevel gear backlash
: 0.1 – 0.2 mm (0.0039 – 0.0078 in.)




I5RW0A330014-02

- 9) Install intermediate shaft bearing (1) to intermediate shaft (2) by using special tool.


Special tool

(A): 09913-84510



I5RW0A330015-01

- 10) Install intermediate shaft (2) with bearing (3) in transfer.
- 11) Install new snap ring (1) to transfer right case by using snap ring pliers.



I5RW0A330016-02

- 12) Apply grease to new right case oil seal No.1 lip.

“A”: Grease 99000-25010 (SUZUKI Super Grease A)


- 13) Drive right case oil seal No.1 (1) in transfer right case (2) by using special tool and hammer.

Special tool

(A): 09925-15410

Intermediate output oil seal installing depth

“a”: 1.0 – 1.5 mm (0.04 – 0.06 in.)



I5RW0A330017-02

Reduction Drive Gear Assembly Disassembly and Reassembly


S7RW0C3306006

Disassembly

Remove bearings (1) from reduction drive gear (2) using special tool, bearing puller (3) and hydraulic press (4).

Special tool

(A): 09913-85230




I5RW0A330018-01

Reassembly

- 1) Clean all components thoroughly, inspect them for any abnormality and replace with new one as necessary.
- 2) Install bearings (1) to reduction drive gear (2) using special tool, bearing puller (3) and hydraulic press (4).

Special tool

(A): 09913-85230



I5RW0A330019-01

Reduction Driven Gear Assembly Disassembly and Reassembly


S7RW0C3306007

Disassembly

- 1) Remove left bearing (1) and bevel gear (2) using special tool, bearing puller (3) and hydraulic press (4).

Special tool


(A): 09925-98220




- 2) In order to remove right bearing (1) from reduction driven gear (2), grind with a grinder (3) one part "a" of bearing as illustrated till it becomes thin.

⚠ CAUTION

Be careful not to grind too far not to damage reduction driven gear.



- 3) Break with a chisel (1) the thin ground bearing (2), and it can be removed.



Reassembly

⚠ CAUTION


- Bevel gear and pinion must be replaced as a set when either replacement becomes necessary.
- When replacing taper roller bearing, replace as inner race and outer race assembly.

- 1) Install right bearing (1) to reduction driven gear (2) using special tools and hydraulic press.

Special tool

(A): 09924-74510

(B): 09925-16310




- 2) Install bevel gear (1) to reduction driven gear (2) using special tools and hydraulic press.

Special tool

(A): 09924-07710

(B): 09924-84510-005

(C): 09925-15410




- 3) Install left bearing (1) to reduction driven gear (2) using special tools and hydraulic press.

Special tool

(A): 09913-84510

(B): 09924-84510-005



I5RW0A330025-02

Transfer Right Case and Left Case Disassembly and Reassembly


S7RW0C3306008

Disassembly

- 1) Remove oil seals from right case (1) using special tool, if necessary.


Special tool

(A): 09925-15410



I5RW0A330026-01

- 2) Remove oil plate (1) from right case (2), if necessary.



I5RW0A330027-01

- 3) Remove oil seals from left case using flat end rod or the like, if necessary.

Reassembly

- 1) When installing oil seal No.2 (1) and No.3 (2) to right case (3) using special tool, use care so that oil seals in proper direction and position as shown in figure. Apply grease to oil seal lip.

Special tool


(A): 09925-15410

“A”: Grease 99000-25010 (SUZUKI Super Grease A)

Oil seals installing depth

“a”: 23.5 – 24.0 mm (0.925 – 0.945 in.)

“b”: 38.0 – 39.0 mm (1.496 – 1.535 in.)



I5RW0A330028-01

- 2) Install oil plate to right case.

Tightening torque

Oil plate bolt: 9 N·m (0.9 kgf-m, 6.5 lb-ft)


- 3) When installing new oil seal No.1 (1) and No.2 (2) to left case (3) using special tool, use care so that oil seals in proper direction as shown in figure. Apply grease to oil seal lip.

Special tool

(A): 09913-85210 (For oil seal No.1)

(A): 09944-88210 (For oil seal No.2)

“A”: Grease 99000-25010 (SUZUKI Super Grease A)



I5RW0A330029-01

Transfer Output Retainer Assembly Disassembly and Reassembly


S7RW0C3306009

Disassembly


- 1) Uncaulk transfer output flange nut.
- 2) Remove transfer output flange nut while holding flange (1) by using special tool.

Special tool


(A): 09930-40113




- 3) Remove transfer output flange (1) by bearing puller (2).



- 4) Drive out bevel pinion (1) from transfer output retainer by tapping it with plastic hammer (2).




- 5) Drive out front taper roller bearing (1) from bevel pinion (3) by using bearing puller (2) and hydraulic press.




- 6) Remove oil seal (1) by using special tool.

Special tool


(A): 09913-50121



- 7) Remove rear taper roller bearing (1), pump seal (3) and spacers (2).



- 8) Drive out outer races (2) (front and rear) by using brass bar (1).




Reassembly

⚠ CAUTION

- Bevel gear and pinion must be replaced as a set when either replacement becomes necessary.
- When replacing taper roller bearing, replace as inner race and outer race assembly.

1) To mesh bevel gears correctly, it is prrequired to install bevel pinion to transfer output retainer properly by using adjusting shim (bevel pinion shim) as follows.

- a) Install front taper roller bearing (1) to bevel pinion dummy (special tools).


Special tool**(A): 09922-76140****(B): 09922-76430**

I3RH01332053-01

- b) Install bevel pinion dummy (1), rear taper roller bearing (2) and special tools to transfer output retainer (3).

Special tool**(A): 09922-76140****(B): 09922-76430****(C): 09922-76340****(D): 09922-76150****NOTE**

This installation requires no spacer or oil seal.



I5RW0A330035-01

"a": Pinion dummy height 40 mm (1.575 in.)

"b": Height from retainer installation face to top surface of pinion dummy

"c": Distance from retainer installation face to end face of bearing race


- c) Tighten bevel pinion nut (special tool) so that specified bearing preload is obtained.

NOTE

Before taking measurement, check for rotation by hand more than 15 revolutions.

Tightening torque

Rotational torque of bevel pinion (Bearing preload): 0.50 – 1.30 N·m (0.05 – 0.13 kgf-m, 0.35 – 0.95 lb-ft)




I5RW0A330036-02

3C-13 Transfer:

- d) Measure height "b" in figure by using vernier caliper.
Calculate "c" by using measured value.


$$\text{Distance "c"} = \text{Height "b"} - \text{Height "a"} \quad 40 \text{ mm} \quad (1.575 \text{ in.})$$



I5RW0A330046-01

- e) Obtain adjusting shim thickness by the following equation.

Necessary shim thickness "f"	=	Distance "c"	+	Distance "d"	-	Distance "e"
				74.0 mm (2.913 in.)		101.95 mm (4.014 in.)



I5RW0A330037-01

"d": Pinion shaft mounting distance 74.0 mm (2.913 in.)
"e": Distance from end face of left case to axis of reduction driven gear 101.95 mm (4.014 in.)
"f": Necessary shim thickness

- f) Select a shim closest to the calculated value (necessary shim thickness) from among the available shims or combine shims to become closest to calculated value.

For example:

Measure distance "b" is 69.95 mm (2.754 in.).
 $\text{"c"} = 69.95 \text{ mm (2.754 in.)} - 40.0 \text{ mm (1.575 in.)} = 29.95 \text{ mm (1.179 in.)}$
 $\text{"f"} = 29.95 \text{ mm (1.179 in.)} + 74.0 \text{ mm (2.913 in.)} - 101.95 \text{ mm (4.014 in.)} = 2.0 \text{ mm (0.079 in.)}$
 Calculated thickness of new shim = 2.0 mm (0.079 in.)


Available bevel pinion shim thickness

0.30, 1.85, 1.88, 1.91, 1.94, 1.97, 2.00, 2.03, 2.06, 2.09, 2.12 and 2.15 mm (0.012, 0.072, 0.074, 0.075, 0.076, 0.077, 0.078, 0.079, 0.081, 0.082, 0.083 and 0.084 in.)

- 2) Press-fit outer races (front and rear) by using special tool and hydraulic press.

Special tool

(A): 09913-75520




I5RW0A330038-01

- 3) Press-fit front taper roller bearing (1) by using special tool and hydraulic press.


Special tool

(A): 09925-18011



I5RW0A330039-01

- 4) Install bevel pinion with new pinion shaft spacers (1) and new pump seal (2) to transfer output retainer (3).




I5RW0A330040-02

- 5) Drive in rear taper roller bearing by using special tool and tapping lightly with plastic hammer.

Special tool

(A): 09913-84510



I5RW0A330041-02

- 6) Apply grease to new oil seal lip.

“A”: Grease 99000-25010 (SUZUKI Super Grease A)

- 7) Drive in oil seal (1) by using special tools and hammer.


Special tool

(A): 09940-54910

(B): 09913-76010

Transfer output flange oil seal installing depth

“a”: 21.0 – 22.0 mm (0.82 – 0.86 in.)



I5RW0A330042-02

- 8) Install transfer output flange (1) by tapping with plastic hammer and tighten transfer output flange nut gradually so as rotational torque of bevel pinion to be in specified value.

NOTE



- If rotational torque of bevel pinion exceeds specification given in the following, replace pinion shaft spacers and tighten flange nut.
- Before taking measurement of rotational torque, rotate pinion over ten rounds in advance.

Bevel pinion bearing preload

: 0.5 – 1.3 N·m (0.05 – 0.13 kgf-m, 0.35 – 0.95 lb-ft)

Special tool


(A): 09930-40113



I5RW0A330043-01

2. Torque wrench

- 9) Caulk transfer output flange nut (1).



I5RW0A330044-01

Transfer Assembly Inspection

S7RW0C3306010

- Check each bearing for smooth rotation, wear or discoloration
If found abnormal, replace.
- Check oil seal for leakage and its lip for excessive hardness
If either is found, replace.
- Check transfer case for cracks.
- Check bevel pinion and bevel gears for wear or cracks.


Bevel Gear Tooth Contact Inspection

S7RW0C3306011

- 1) After cleaning tooth surface of bevel gear (1), paint them with gear marking compound evenly by using brush or sponge etc.

NOTE

When applying red lead paste to teeth, be sure to paint tooth surfaces uniformly. The paste must not be too dry or too fluid.









I3RH01332043-01

- 2) Install transfer output retainer assembly referring to "Transfer Assembly Disassembly and Reassembly".
- 3) Turn transfer output flange clockwise and counterclockwise repeatedly, and remove transfer output retainer assembly and bevel gear shims from transfer assembly.
- 4) Bring painted part up and check contact pattern referring to the following chart. If contact pattern is not normal, readjust or replace as necessary according to instruction in chart.

NOTE

- **Be careful not to turn bevel gear more than one full revolution, for it will hinder accurate check.**
- **If bevel gear back lash and bevel pinion shims are adjusted properly, correct tooth contact should be provided.**
If correct tooth contact is not provided even when they are adjusted properly, however, there may be an abnormal condition in worn tooth, transfer case or retainer. Check each component and replace as necessary.

Gear tooth contact table

Tooth contact pattern	Diagnosis and remedy
 I5RW0A330045-01	Normal
 I3RH01332045-01	High contact Pinion is positioned too far from the center of drive bevel gear. • Decrease thickness of bevel pinion shim and position pinion closer to gear center. • Adjust drive bevel gear backlash to specification.
 I3RH01332046-01	Low contact Pinion is positioned too close to the center of drive bevel gear. • Increase thickness of bevel pinion shim and position pinion farther from gear center. • Adjust drive bevel gear backlash to specification.
 I3RH01332047-01	These contact patterns indicate that the "offset" of reduction driven gear is too much or too little. The remedy is to change the division of the bevel gear shim(s).
 I3RH01332048-01	These contact patterns, located on toe or heel on both drive and coast sides, mean that 1) both pinion and gear are defective, 2) retainer is not true, or 3) gear is not properly seated on transfer case. The remedy is to replace the defective member.
 I3RH01332049-01	Irregular patterns: If the pattern is not oval, it means that bevel gear is defective. High or low spots on tooth surfaces or on the seat of bevel gear are the cause of irregular patterns appearing on some teeth. The remedy is to replace the pinion and gear set and, if the seat is defective, so is transfer case.

Specifications

Tightening Torque Specifications

S7RW0C3307001

Fastening part	Tightening torque			Note
	N·m	kgf·m	lb·ft	
Transfer oil level / filler plug	23	2.3	17.0	👉 / 👉
Transfer oil drain plug	23	2.3	17.0	👉
Stiffener No.1 bolt and No.2 bolt	55	5.5	40.0	👉
Transfer to transaxle bolt	98	9.8	71.0	👉
Engine rear mounting upper nut	25	2.5	18.0	👉
Engine rear mounting lower nut	55	5.5	40.0	👉
Transfer case bolt	23	2.3	17.0	👉
Transfer output retainer bolt	55	5.5	40.0	👉
Oil plate bolt	9	0.9	6.5	👉
Rotational torque of bevel pinion (Bearing preload)	0.50 – 1.30	0.05 – 0.13	0.35 – 0.95	👉

NOTE

The specified tightening torque is also described in the following.
 “Transfer Assembly Components”

Reference:

For the tightening torque of fastener not specified in this section, refer to “Fasteners Information in Section 0A”.

Special Tools and Equipment

Recommended Service Material

S7RW0C3308001













Material	SUZUKI recommended product or Specification		Note
Grease	SUZUKI Super Grease A	P/No.: 99000-25010	 /  /  /  / 
Sealant	SUZUKI Bond No.1217G	P/No.: 99000-31260	 /  /  / 

NOTE












Required service material is also described in the following.
 “Transfer Assembly Components”

Special Tool

S7RW0C3308002

09900-20607 Dial gauge 		09900-20701 Magnetic stand 	
09912-34510 Case separator 		09913-50121 Oil seal remover  / 	
09913-75520 Bearing installer 		09913-76010 Bearing installer 	
09913-84510 Bearing installer  /  / 		09913-85210 Bearing installer 	
09913-85230 Bearing remover tool  / 		09922-76140 Bevel pinion shaft  / 	
09922-76150 Bevel pinion nut 		09922-76340 Bevel pinion rear collar 	

3C-19 Transfer:

09922-76430 Bevel pinion front collar ⌚ / ⌚		09924-07710 Synchronizer hub installer ⌚	
09924-74510 Bearing and oil seal handle ⌚		09924-84510-005 Bearing installer attachment (D) ⌚ / ⌚	
09925-15410 Oil seal installer ⌚ / ⌚ / ⌚ / ⌚		09925-16310 Bearing installer ⌚	
09925-18011 Transmission gear, bush and bearing installer ⌚		09925-98220 Bearing installer ⌚	
09930-40113 Flywheel rotor holder ⌚ / ⌚		09940-54910 Front fork oil seal install driver ⌚	
09944-88210 Bearing housing installer ⌚		09944-96011 Bearing outer race remover ⌚	


Propeller Shaft

General Description

Propeller Shaft Construction

S7RW0C3401001

Universal joints and ball joint require no maintenance. They are lubricated for life and can not be lubricated on the vehicle. If a universal joint becomes noisy or worn, it must be replaced.
The propeller shaft is a balanced unit. Handle it carefully so that balance can be maintained.



I5RW0A340004-01

1. Propeller shaft flange bolt	(a) : 23 N·m (2.3 kgf-m, 17.0 lb-ft)
2. Center support nut	(b) : 55 N·m (5.5 kgf-m, 40.0 lb-ft)
3. Propeller shaft assembly	

Diagnostic Information and Procedures

Propeller Shaft Symptom Diagnosis

S7RW0C3404001

Condition	Possible cause	Correction / Reference Item
Abnormal noise	Loose propeller shaft flange bolt and/or center support nut	<i>Tighten propeller shaft flange bolt and/or center support nut.</i>
	Spider bearing worn out or stuck	<i>Replace propeller shaft.</i>
	Wear spider	<i>Replace propeller shaft.</i>
Vibration	Deformed propeller shaft	<i>Replace.</i>


Repair Instructions

Propeller Shaft Joint Check

S7RW0C3406001

If universal joints and ball joint are suspected of producing chattering or rattling noise, inspect them for wear. For universal joint, check to see if cross spider rattles in yokes are worn down and replace defective propeller shaft assembly with new one.
Noise coming from universal joint and ball joint can be easily distinguished from other noises because rhythm of chattering or rattling is in step with cruising speed.

Noise is pronounced particularly on standing start or in coasting condition (when braking effect of engine is showing in the drive line).



I5JB0A340003-01



3D-2 Propeller Shaft:

Propeller Shaft Assembly Removal and Installation

S7RW0C3406002

Removal

- 1) Hoist vehicle.
- 2) Before removing propeller shaft assembly, give match marks (2) on joint flange and propeller shaft as shown.
- 3) Separate propeller shaft assembly (1) from transfer output flange and rear differential flange.




I5RW0A340002-01

- 4) Remove propeller shaft by removing center support nuts (1).

⚠ CAUTION

Use care not to drop it. Otherwise, vibration may occur during driving.



I5RW0A340003-01

Installation

Reverse removal procedure to install propeller shaft, noting the following point.

- When installing propeller shaft, align the match marks (2). Otherwise, vibration may occur during driving.
- Use the following specification to torque each bolt and nut.

Tightening torque

Propeller shaft bolt: 23 N·m (2.3 kgf-m, 17.0 lb-ft)

Center support nut: 55 N·m (5.5 kgf-m, 40.0 lb-ft)

Propeller Shaft Inspection

S7RW0C3406003

- 1) Check propeller shaft joints for wear, play and damage. If any defect is found, replace.
- 2) Check propeller shaft center support for biting of foreign matter, crack, abnormal noise and damage. If any defect is found, replace.

Specifications

Tightening Torque Specifications

S7RW0C3407001

Fastening part	Tightening torque			Note
	N·m	kgf-m	lb-ft	
Propeller shaft bolt	23	2.3	17.0	☞
Center support nut	55	5.5	40.0	☞

NOTE

The specified tightening torque is also described in the following.
“Propeller Shaft Construction”

Reference:

For the tightening torque of fastener not specified in this section, refer to “Fasteners Information in Section 0A”.

Section 4

Brakes

CONTENTS

Precautions	4-1	Recommended Service Material	4A-17
Precautions.....	4-1	Special Tool	4A-17
Precautions for Brakes.....	4-1		
Brake Control System and Diagnosis ...	4A-1	Front Brakes	4B-1
Precautions.....	4A-1	Repair Instructions	4B-1
Precautions on Brake.....	4A-1	Front Disc Brake Components	4B-1
General Description	4A-1	Front Disc Brake Pad On-Vehicle Inspection.....	4B-2
Brakes Construction.....	4A-1	Front Disc Brake Pad Removal and	
Brake Pedal Foot Protection System		Installation.....	4B-2
Construction (If Equipped)	4A-2	Front Disc Brake Pad Inspection.....	4B-3
Diagnostic Information and Procedures.....	4A-2	Front Disc Brake Caliper Removal and	
Brakes Diagnosis Note	4A-2	Installation	4B-3
Brakes Symptom Diagnosis	4A-3	Front Disc Brake Caliper Disassembly and	
Repair Instructions	4A-5	Assembly.....	4B-4
Brake Pedal Components	4A-5	Front Disc Brake Caliper Check.....	4B-6
Brake Pedal Free Height Inspection	4A-5	Front Brake Disc Removal and Installation	4B-7
Brake Pedal Play Inspection	4A-5	Front Brake Disc Inspection	4B-7
Excessive Pedal Travel Inspection	4A-5	Specifications.....	4B-8
Master Cylinder and Brake Fluid Level		Tightening Torque Specifications	4B-8
Inspection.....	4A-6	Special Tools and Equipment.....	4B-8
Brake Fluid Replacement.....	4A-6	Recommended Service Material	4B-8
Brake Light Switch Adjustment	4A-6	Special Tool	4B-8
Air Bleeding of Brake System	4A-6		
Front Brake Hose and Pipe Components	4A-8	Rear Brakes.....	4C-1
Front Brake Hose and Pipe Removal and		Drum	4C-1
Installation	4A-9	Repair Instructions	4C-1
Rear Brake Hose and Pipe Components.....	4A-10	Rear Drum Brake Components.....	4C-1
Rear Brake Hose and Pipe Removal and		Rear Brake Drum Removal and Installation.....	4C-2
Installation	4A-11	Rear Brake Drum and Shoe Inspection	4C-2
Brake Hose and Pipe Inspection.....	4A-11	Rear Brake Shoe On-Vehicle Inspection	4C-3
Master Cylinder and Brake Booster		Rear Brake Shoe Removal and Installation	4C-3
Components.....	4A-12	Rear Brake Adjuster and Shoe Lever Check	4C-4
Master Cylinder Reservoir Removal and		Wheel Cylinder Removal and Installation	4C-4
Installation	4A-12	Wheel Cylinder Inspection	4C-5
Master Cylinder Removal and Installation.....	4A-13	Brake Back Plate Removal and Installation	4C-5
Master Cylinder Inspection	4A-14	Specifications.....	4C-6
Booster Operation Inspection	4A-15	Tightening Torque Specifications	4C-6
Brake Booster Removal and Installation	4A-16	Special Tools and Equipment.....	4C-6
Brake Booster Inspection	4A-16	Recommended Service Material	4C-6
Booster Push Clevis Rod Adjustment	4A-17	Disc.....	4C-7
Specifications.....	4A-17	Repair Instructions	4C-7
Tightening Torque Specifications.....	4A-17	Rear Disc Brake Components.....	4C-7
Special Tools and Equipment.....	4A-17	Rear Disc Brake Pad Removal and	
		Installation	4C-8

Rear Disc Brake Caliper Removal and Installation	4C-9	Serial Data Link Circuit Check	4E-15
Rear Disc Brake Pad Inspection	4C-11	DTC C1013: Control Module Mismatch	4E-17
Rear Disc Brake Caliper Disassembly and Assembly	4C-11	DTC C1015: G Sensor Circuit (4WD Model).....	4E-18
Rear Disc Brake Caliper Check	4C-13	DTC 1016: Brake Light Switch	4E-19
Rear Brake Disc Removal and Installation.....	4C-13	DTC C1021 / C1022 / C1025 / C1026 / C1031 / C1032 / C1035 / C1036: Wheel Speed Sensor Circuit / Sensor or Encoder.....	4E-20
Rear Brake Disc Inspection.....	4C-14	DTC C1033: Wheel Speed Sensor Deviation ...	4E-22
Specifications	4C-14	DTC C1041 / C1042 / C1045 / C1046 / C1051 / C1052 / C1055 / C1056: Inlet / Outlet Solenoid	4E-23
Tightening Torque Specifications.....	4C-14	DTC C1057: Power Supply Voltage Too High / Too Low	4E-24
Special Tools and Equipment	4C-15	DTC C1061: Pump Motor Circuit	4E-25
Recommended Service Material	4C-15	DTC C1063: Solenoid Valve Power Supply Driver Circuit	4E-26
Special Tool	4C-15	DTC C1071: Control Module Internal Defect ...	4E-27
Parking Brake	4D-1	ABS Hydraulic Unit / Control Module Assembly Power and Ground Circuit Check ...	4E-27
Repair Instructions	4D-1	Repair Instructions	4E-28
Parking Brake Cable Components.....	4D-1	ABS Hydraulic Unit Operation Check.....	4E-28
Parking Brake Inspection and Adjustment	4D-2	ABS Hydraulic Unit / Control Module Assembly Components	4E-29
Parking Brake Cable Removal and Installation	4D-3	ABS Hydraulic Unit / Control Module Assembly On-Vehicle Inspection	4E-30
Parking Brake Lever Removal and Installation ...	4D-3	ABS Hydraulic Unit / Control Module Assembly Removal and Installation	4E-30
Specifications	4D-4	Front and Rear Wheel Speed Sensor On-Vehicle Inspection	4E-31
Tightening Torque Specifications.....	4D-4	Front Wheel Speed Sensor Removal and Installation	4E-32
ABS	4E-1	Front and Rear Wheel Speed Sensor Inspection.....	4E-33
Precautions	4E-1	Rear Wheel Speed Sensor Removal and Installation (4WD Model).....	4E-33
Precautions in Diagnosing Troubles	4E-1	Rear Wheel Speed Sensor Removal and Installation (2WD Model).....	4E-33
Precautions in On-Vehicle Service.....	4E-1	Front Wheel Speed Sensor Encoder On-Vehicle Inspection	4E-34
General Description	4E-2	Front Wheel Speed Sensor Encoder Removal and Installation	4E-34
ABS Description	4E-2	Rear Wheel Speed Sensor Encoder On-Vehicle Inspection	4E-34
ABS Hydraulic Unit / Control Module Assembly Description	4E-3	Rear Wheel Speed Sensor Encoder Removal and Installation	4E-34
CAN Communication System Description.....	4E-3	G Sensor Removal and Installation (4WD Model)	4E-35
Schematic and Routing Diagram	4E-4	G Sensor Inspection (4WD Model)	4E-35
ABS Schematic	4E-4	Specifications	4E-36
ABS Wiring Circuit Diagram	4E-5	Tightening Torque Specifications.....	4E-36
Component Location	4E-7	Special Tools and Equipment	4E-36
ABS Components Location	4E-7	Special Tool	4E-36
Diagnostic Information and Procedures	4E-7		
ABS Check.....	4E-7		
ABS Warning Light Check.....	4E-9		
EBD Warning Light (Brake Warning Light) Check	4E-9		
DTC Check.....	4E-10		
DTC Table.....	4E-10		
DTC Clearance	4E-10		
Scan Tool Data	4E-11		
ABS Warning Light Does Not Come ON at Ignition Switch ON	4E-12		
ABS Warning Light Comes ON Steady.....	4E-13		
EBD Warning Light (Brake Warning Light) Comes ON Steady	4E-14		

Precautions

Precautions

Precautions for Brakes

S7RW0C4000001

Suspension Caution

Refer to "Suspension Caution in Section 00".

Wheels and Tires Caution

Refer to "Wheels and Tires Caution in Section 00".

Brake Caution

Refer to "Brake Caution in Section 00".

General Precautions

Refer to "General Precautions in Section 00".

Vehicle Lifting Points

Refer to "Vehicle Lifting Points in Section 0A".

Fastener Caution

Refer to "Fastener Caution in Section 00".

Fastener Information

Refer to "Fasteners Information in Section 0A".

Precaution on CAN Troubleshooting

Refer to "Precaution on CAN Troubleshooting in Section 1A".

Brake Control System and Diagnosis

Precautions

Precautions on Brake

S7RW0C4100001

Air Bag Warning

Refer to “Air Bag Warning in Section 00”.

Brakes Diagnosis Note

Refer to “Brakes Diagnosis Note”.

General Description

Brakes Construction

S7RW0C4101001


When the foot brake pedal is depressed, hydraulic pressure is developed in the master cylinder to actuate pistons (two in front disc brake, two in rear disc brake or four in rear drum brake).

The master cylinder is a tandem master cylinder. Brake pipes are connected to the master cylinder and they make two independent circuits. One connects front right & rear left brakes and the other connects front left & rear right brakes. In this brake system, the front wheel brake is disc brake type and the rear wheel brake is disc brake type or drum brake type (leading / trailing shoes).

The parking brake system is mechanical. It applies brake force to only rear wheels by means of the cable and mechanical linkage system. The same brake pads (or brake shoes) of rear disc brake (or rear drum brake) are used for both parking and foot brakes.

NOTE

- The figures show LH steering vehicle.
- The difference between RH steering vehicle and LH steering vehicle is the location of the brake master cylinder, the brake booster and ABS hydraulic unit / control module assembly.



I7RW01410001-01

1. Brake booster	4. Primary side	7. Parking brake cable
2. Master cylinder	5. ABS hydraulic unit / control module assembly	8. 4-way joint
3. Secondary side	6. Parking brake lever	A: Forward


Brake Pedal Foot Protection System Construction (If Equipped)

S7RW0C4101002

Should a front crash occur and the engine push the dash panel toward the interior side, the brake pedal bracket is also pushed toward the interior side. In this case, the brake pedal lever comes off from the brake pedal, thereby preventing the brake pedal from moving rearward.

⚠ CAUTION

Never disassemble brake pedal assembly. Disassemble will spoil its original function. If faulty condition is found, replace it with new one.



I6RW0C410001-02

[A]: Before crash	2. Brake booster	5. Brake pedal bracket
[B]: After crash	3. Brake pedal lever	
1. Brake pedal	4. Booster push clevis rod	

Diagnostic Information and Procedures

Brakes Diagnosis Note

S7RW0C4104001

Road Testing Brakes

Brakes should be tested on dry, clean, smooth and reasonably level roadway which is not crowned. Road test brakes by making brake applications with both light and heavy pedal forces at various speeds to determine if the vehicle stops evenly and effectively. Also drive vehicle to see if it leads to one side or the other without brake application. If it does, check the tire pressure, front wheel alignment and front suspension attachments for looseness. See diagnosis table for other causes.

Brake Fluid Leaks

Check the master cylinder fluid levels. While a slight drop in reservoir level does result from normal lining wear, an abnormally low level indicates a leak in the system. In such a case, check the entire brake system for leakage. If even a slight evidence of leakage is noted, the cause should be corrected or defective parts should be replaced.

Substandard or Contaminated Brake Fluid

Improper brake fluid, mineral oil or water in the fluid may cause the brake fluid to boil or the rubber components (piston cups and brake hoses) in the hydraulic system to deteriorate. If the above fluid is included in the system, replace the master cylinder, reservoir and other rubber components (hoses). The master cylinder is disassemble parts to maintain the performance. The system must be flushed if there is any doubt as to the grade of fluid in the system or if fluid has been used which contained parts that have been subjected to contaminated fluid.

Brakes Symptom Diagnosis

Condition	Possible cause	Correction / Reference Item
Not enough braking force	Brake fluid leakage from brake lines	Locate leaking point and repair.
	Brake disc or pad stained with fluid, grease or other oil	Clean or replace.
	Overheated brakes	Determine cause and repair.
	Poor contact of shoes on brake drum (rear drum brake model)	Repair for proper contact.
	Brake shoe stained with oil or wet with water (rear drum brake model)	Replace.
	Badly worn brake pad	Replace.
	Defective wheel cylinders (rear drum brake model)	Repair or replace.
	Malfunctioning caliper assembly	Repair or replace.
	Air in system	Bleed system.
	Brake booster internal failure	Replace brake booster.
	Negative pressure for brake booster is inadequate	Check engine condition and vacuum hose.
	Malfunctioning ABS	Check system and replace as necessary.
Brake pull (Brakes not working in unison)	Pad, disc, shoe and/or drum are wet with water or stained with oil in some brakes	Clean or replace.
	Drum-to-shoe clearance out of adjustment in some brakes (Malfunctioning auto adjusting mechanism) (rear drum brake model)	Check for inoperative auto adjusting mechanism.
	Disc and/or drum are out of round in some brakes	Replace.
	Tires are inflated unequally	Inflate equally.
	Malfunction in wheel cylinders (rear drum brake model)	Repair or replace.
	Disturbed front wheel alignment	Adjust as prescribed.
	Unmatched tires on same axle	Tires with approximately the same amount of tread should be used on the same axle.
	Restricted brake pipes or hoses	Check for soft hoses and damaged lines. Replace with new hoses and new double-walled steel brake tubing.
	Malfunctioning caliper assembly	Caliper should slide. Check for stuck or sluggish pistons and proper lubrication of caliper slide pin.
	Loose suspension parts	Check all suspension mountings.
Noise (High pitched squeak without brake applied)	Loose calipers	Check and torque bolts to specifications.
	Contact wear indicator to brake disc	Replace brake pad.
Excessive pedal travel (Pedal stroke too large)	Worn rear brake shoe	Replace brake shoe.
	Partial brake system failure	Check brake systems and repair as necessary.
Brake locked	Brake fluid leaking	Repair the leaking point, and bleed air.
	Air in system (soft / spongy pedal)	Bleed system.
	Rear brake system not adjusted (malfunctioning auto adjusting mechanism)	Adjust rear brakes. Repair auto adjusting mechanism.
	Bent brake shoes (drum brake model)	Replace brake shoes.
	Malfunctioning ABS	Check system referring to "ABS Check in Section 4E".

Condition	Possible cause	Correction / Reference Item
Dragging brakes (A very light drag is present in all brakes immediately after pedal is released)	Master cylinder pistons not returning correctly	Replace master cylinder.
	Restricted brake pipes or hoses	Check for soft hoses or damaged pipes and replace with new hoses and/or new brake piping.
	Incorrect parking brake adjustment on rear brakes	Check and adjust to correct specifications.
	Weakened or broken return springs in the brake	Replace.
	Sluggish parking brake cables or linkage	Repair or replace.
	Wheel cylinder or caliper piston sticking	Repair as necessary.
	Badly worn piston seal in caliper	Replace piston seal.
	Improper brake pedal free height	Check brake pedal free height.
Pedal pulsation (Pedal pulsates when depressed for braking)	Damaged wheel bearings	Replace wheel bearings.
	Distorted steering knuckle or rear wheel spindle or rear axle shaft	Replace knuckle or rear wheel spindle or rear axle shaft.
	Excessive disc lateral runout	Check per instructions. If not within specifications, replace or machine disc.
	Rear drums out of round (rear drum brake model)	Repair or replace drum as necessary. Check runout.
Braking noise	Glazed brake pad and/or brake shoe	Repair or replace brake pad and/or brake shoe.
	Worn or distorted brake shoe (rear drum brake model)	Replace brake shoe.
	Loose front wheel bearings	Replace wheel hub.
	Distorted backing plates or loose mounting bolts	Replace or retighten securing bolts.
	Contact wear indicator to brake disc	Replace brake pads.
Brake warning light lights after engine start	Parking brake applied	Release parking brake and check that brake warning light turns off.
	Insufficient amount of brake fluid	Investigate leaky point, correct it and add brake fluid.
	Brake fluid leaking	Investigate leaky point, correct it and add brake fluid.
	Brake warning light circuit faulty	Repair circuit.
	Malfunctioning EBD system	Check system referring to "EBD Warning Light (Brake Warning Light) Comes ON Steady in Section 4E".
Brake warning light turns on when brake is applied	Brake fluid leaking	Investigate leaky point, correct it and add brake fluid.
	Insufficient amount of brake fluid	Investigate leaky point, correct it and add brake fluid.
Brake warning light fails to turn on even when parking brake is applied	Brake warning light circuit faulty	Replace bulb or repair circuit.
ABS warning light turns on after engine start	Malfunctioning ABS	Check system referring to "ABS Check in Section 4E".
ABS warning light turns on when brake is applied	Malfunctioning ABS	Check system referring to "ABS Check in Section 4E".
ABS warning light does not turn on for 2 sec. after ignition switch has turned ON	Bulb burnt out	Replace bulb.
	Malfunctioning ABS	Check system referring to "ABS Check in Section 4E".
ABS warning light flashes	New ABS hydraulic unit / control module assembly installed.	Perform "ABS Hydraulic Unit Operation Check in Section 4E".


Repair Instructions

Brake Pedal Components

S7RW0C4106021

CAUTION

If equipped Brake Pedal Foot Protection System, never disassemble brake pedal assembly. Disassemble will spoil its original function. If faulty condition is found, replace it with new one.



I6RW0C410004-01


[A]: A/T model	(a) : 13 N·m (1.3 kgf-m, 9.5 lb-ft)
1. Brake pedal	(b) : 23 N·m (2.3 kgf-m, 16.5 lb-ft)
2. Brake pedal bracket	

Brake Pedal Free Height Inspection

S7RW0C4106001

- 1) Check brake pedal free height. If it is not within specification, check and adjust following item 2) to 6).

Brake pedal free height “a” from carpet
“a”: 111 – 131 mm (4.4 – 5.1 in.)



I7RW01410015-01


- 2) Check measurement between booster mounting surface and center of clevis pin hole. When booster push rod clevis has been reinstalled, it is important that the measurement is adjusted (refer to “Brake Booster Inspection”).
- 3) Check brake light switch position. Adjust it if it is out of specification.
- 4) Check pedal for dent.
- 5) Check brake booster for installation.
- 6) Check brake booster push rod for length.

Brake Pedal Play Inspection

S7RW0C4106002

Pedal play should be within the following specification. If out of specification, check brake light switch for proper installation position and adjust if necessary. Also check pedal shaft bolt and booster clevis pin installation for looseness and replace if defective.

Brake pedal play
“a”: 1 – 8 mm (0.04 – 0.31 in.)



I3RH0A410010-01


Excessive Pedal Travel Inspection

S7RW0C4106003

- 1) Start engine.
- 2) Depress brake pedal a few times.
- 3) With brake pedal depressed with approximately 300 N (30 kg, 66 lbs) load, measure brake pedal to wall (dash panel silencer) clearance “a”. If clearance is out of specification, possible causes are as follows. If clearance “a” is less than specification, the most possible cause is that air is in lines or brake fluid leakage.
- Should clearance “a” remain less than specification even after bleeding of system, other possible but infrequent cause is malfunction of booster push rod length out of adjustment.
- Bleed brake system. Refer to “Air Bleeding of Brake System”.
 - Remove brake drums for adjuster inspection (rear drum brake model). (Refer to “Rear Brake Drum Removal and Installation: Drum in Section 4C”.) If defective, correct or replace.

Brake pedal arm to wall clearance "a"

When pedal is depressed at 300 N (30 kg, 66 lbs): Over 40 mm (1.57 in.)



I6RW0C410006-01

Master Cylinder and Brake Fluid Level Inspection

S7RW0C4106004


⚠ CAUTION

Do not use shock absorber fluid or any other fluid which contains mineral oil. Do not use a container which has been used for mineral oil or a container which is wet from water. Mineral oil will cause swelling and distortion of rubber parts in hydraulic brake system and water mixed into brake fluid will lower fluid boiling point. Keep all fluid containers capped to prevent contamination.

NOTE

Be sure to use particular brake fluid either as indicated on reservoir cap of that vehicle or recommended in owner's manual which comes along with that vehicle. Use of any other fluid is strictly prohibited. Fluid level should be between MIN and MAX lines marked on reservoir. When brake warning light lights sometimes during driving, replenish fluid to MAX level. When fluid decreases quickly, inspect brake system for leakage. Correct leaky points and then refill to specified level.

- 1) Check master cylinder, reservoir and reservoir hose (if equipped) for crack, damage and brake fluid leakage. If any faulty condition exists, correct or replace.
- 2) Check that brake fluid level is between MAX (1) and MIN marks (2) on reservoir.



I7RW01410004-01

Brake Fluid Replacement

S7RW0C4106022

Change brake fluid as follows.

Drain existing fluid from brake system completely, fill system with specified fluid and carry out air purge operation.

For air purge procedure refer to "Air Bleeding of Brake System".


Brake Light Switch Adjustment

S7RW0C4106005

Adjustment should be made as follows. Pull up brake pedal toward you and while holding it there, adjust switch position so that clearance between end of thread and brake pedal is as specified. Then lock it by turning clockwise.

Clearance "a" between brake pedal and brake light switch

"a": 0.5 – 1.5 mm (0.02 – 0.05 in.)



I5RW0A410005-01

Air Bleeding of Brake System

S7RW0C4106006

⚠ CAUTION


Brake fluid is extremely damaging to paint. If fluid should accidentally touch painted surface, immediately wipe fluid from paint and clean painted surface.

Bleeding operation is necessary to remove air whenever it entered hydraulic brake system.

Hydraulic lines of brake system are based on the diagonal split system. When a brake pipe or hose was disconnected at the wheel, bleeding operation must be performed at both ends of the line of the removed pipe or hose. When any joint part of the master cylinder or other joint part between the master cylinder and each brake (wheel) was removed, the hydraulic brake system must be bled at all 4 wheel brakes.

NOTE

Perform bleeding operation starting with rear brake caliper or wheel cylinder farthest from master cylinder and then at front caliper of the same brake line. Do the same on the other brake line.




I7RW01410005-01

1. Right front brake caliper	3. Right rear brake caliper or wheel cylinder
2. Left front brake caliper	4. Left rear brake caliper or wheel cylinder

- 1) Fill master cylinder reservoir with specified brake fluid and keep at least one-half full of fluid during bleeding operation.


Brake fluid

Refer to reservoir cap (1).




I7RW01410006-01

- 2) Remove bleeder plug cap. Attach a vinyl tube (1) to bleeder plug, and insert the other end into container (2).



I2RH01410015-01

- 3) Depress brake pedal several times, and then while holding it depressed, loosen bleeder plug about one-third to one-half turn.
- 4) When fluid pressure in cylinder is almost depleted, retighten bleeder plug.
- 5) Repeat this operation until there are no more air bubbles in hydraulic line.



I2RH01410016-01


- 6) When bubbles stop, depress and hold brake pedal and tighten bleeder plug.

Tightening torque

Front brake caliper bleeder plug: 9 N·m (0.9 kgf-m, 6.5 lb-ft)

Rear brake caliper bleeder plug: 9 N·m (0.9 kgf-m, 6.5 lb-ft)

Rear wheel cylinder bleeder plug: 8 N·m (0.8 kgf-m, 6.0 lb-ft)




I2RH01410017-01

- 7) Then attach bleeder plug cap.
- 8) After completing bleeding operation, apply fluid pressure to pipe line and check for leakage.
- 9) Replenish fluid into reservoir up to specified level referring to "Master Cylinder and Brake Fluid Level Inspection".
- 10) Check brake pedal for sponginess. If found spongy, repeat entire procedure of bleeding.

Front Brake Hose and Pipe Components

S7RW0C4106018



I6RW0C410002-01

[A]: LHD	4. From ABS hydraulic unit to left front brake	9. Master cylinder fixing nut
[B]: RHD	5. ABS hydraulic unit / control module assembly	(a) : 18 N-m (1.8 kgf-m, 13.0 lb-ft)
1. From master cylinder primary to ABS hydraulic unit	6. Master cylinder	(b) : 16 N-m (1.6 kgf-m, 12.0 lb-ft)
2. From master cylinder secondary to ABS hydraulic unit	7. From ABS hydraulic unit to left rear brake	(c) : 11 N-m (1.1 kgf-m, 8.0 lb-ft)
3. From ABS hydraulic unit to right front brake	8. From ABS hydraulic unit to right rear brake	(d) : 9 N-m (0.9 kgf-m, 6.5 lb-ft)

Front Brake Hose and Pipe Removal and Installation

S7RW0C4106007

⚠ CAUTION

Do not allow brake fluid to get on painted surfaces. Painted surfaces will be damaged by brake fluid, flush it with water immediately if any fluid is spilled.

Removal

- 1) Hoist vehicle and remove tire and wheel.

NOTE

This operation is not necessary, when removing pipes which is connecting master cylinder.

- 2) Clean dirt and foreign material from both flexible hose end and pipe end fittings.
- 3) Drain brake fluid in reservoir.
- 4) Remove brake flexible hose or pipe.


Installation

Reverse brake flexible hose removal procedure, noting the following.

- Make sure that steering wheel is in straight-forward position and flexible hose has not twist or kink.
- Install clamps and tighten nuts referring to “Front Brake Hose and Pipe Components”.
- Install brake flexible hose (1) to caliper as shown in figure.

Tightening torque

Flexible hose joint bolt (a): 23 N·m (2.3 kgf-m, 17.0 lb-ft)



I7RW01410007-02

- | |
|-----------------------|
| 2. Location mark |
| 3. Outside of vehicle |
| 4. Inside of vehicle |

- Check to make sure that flexible hose doesn't contact any part of suspension, both in extreme right and extreme left turn conditions. If it does at any point, remove and correct. Fill and maintain brake fluid level in reservoir.
- Bleed brake system. Refer to “Air Bleeding of Brake System”.
- Perform brake test and check installed part for fluid leakage.

Rear Brake Hose and Pipe Removal and Installation

S7RW0C4106008

⚠ CAUTION

Do not allow brake fluid to get on painted surfaces. Painted surfaces will be damaged by brake fluid, flush it with water immediately if any fluid is spilled.

Removal

- 1) Hoist vehicle and remove tire and wheel.
- 2) Clean dirt and foreign material from both flexible hose end and pipe end fittings.
- 3) Drain brake fluid in reservoir.
- 4) Remove brake flexible hose or pipe.

Installation

Reverse brake flexible hose removal procedure, noting the following.

- Install clamps and tighten nuts referring to “Rear Brake Hose and Pipe Components”.
- Fill and maintain brake fluid level in reservoir.
- Bleed brake system. Refer to “Air Bleeding of Brake System”.
- Perform brake test and check each installed part for fluid leakage.
- When installing hose, make sure that it has no twist or kink.

Brake Hose and Pipe Inspection

S7RW0C4106020


Perform this inspection where there is enough light and use a mirror as necessary.

- Check brake hoses and pipes for proper hookup, leaks, cracks, chafing and other damage.
- Check that hoses and pipes are clear of sharp edges and moving parts.

Replace these parts as necessary.

⚠ CAUTION

After replacing brake pipe or hose, be sure to carry out air purge operation referring to “Air Bleeding of Brake System”.




I4RS0A020008-01

Master Cylinder and Brake Booster Components

S7RW0C4106010

CAUTION

Never disassemble master cylinder and brake booster. Disassembly will spoil its original function. If faulty condition is found, replace it with new one.



I7RW01410017-03

1. Reservoir	6. O-ring	11. Brake vacuum hose : Be sure to direct location mark (12) to upward as shown in figure.
 2. Grommet : Apply brake fluid.	7. Brake booster	 (a) : 18 N·m (1.8 kgf·m, 13.0 lb·ft)
3. Master cylinder	8. Clevis pin	 (b) : 13 N·m (1.3 kgf·m, 9.5 lb·ft)
4. Reservoir connect pin	9. Clip	 : Do not reuse.
5. Master cylinder fixing nut	10. Gasket	 : Apply grease to piston rod (Grease included in spare parts to master cylinder or brake booster.)

Master Cylinder Reservoir Removal and Installation


S7RW0C4106011

CAUTION

Do not allow brake fluid to get on painted surfaces. Painted surfaces will be damaged by brake fluid, flush it with water immediately if any fluid is spilled.

Removal

- 1) Clean outside of reservoir and master cylinder.
- 2) Disconnect fluid level switch coupler (1) and clamp (3) from reservoir (2).




I7RW01410009-01

4A-13 Brake Control System and Diagnosis:

- 3) Drain brake fluid in reservoir.
- 4) Disconnect clutch reservoir hose from reservoir (M/T model).
- 5) Remove reservoir connector pin (1) by using special tool and then reservoir.

Special tool


(A): 09916-44310



I5JB0A410013-02

Installation

- 1) When using new grommets (2), lubricate them with the same fluid as the one to fill reservoir with. Then press-fit grommets (2) to master cylinder (3).
- 2) Install reservoir (1) to master cylinder.




I7RW01410010-02

- 3) Drive in reservoir connector pin (2) by using special tool (A). Till both of its ends at the right and left of reservoir (1) becomes the same length.


Special tool

(A): 09916-44310



I7RW01410011-01

- 4) Connect clutch reservoir hose to reservoir (M/T model).
- 5) Connect fluid level switch coupler (1) and clamp (3) to reservoir (2).



I7RW01410009-01

- 6) Fill reservoir with specified brake fluid up to its MAX level.
- 7) After completing the work, bleed air from brake system referring to "Air Bleeding of Brake System" and bleed air from clutch system referring to "Air Bleeding of Clutch System in Section 5C" (M/T model).
- 8) Check each installed parts for fluid leakage.
- 9) Perform brake test and check fluid leakage.

Master Cylinder Removal and Installation


S7RW0C4106012

⚠ CAUTION

- **Never disassemble master cylinder since the master cylinder is supplied as assembly parts.**
If faulty condition is found, replace it with new one.
- **Do not allow brake fluid to get on painted surfaces. Painted surfaces will be damaged by brake fluid, flush it with water immediately if any fluid is spilled.**


Removal

- 1) Clean outside of master cylinder.
- 2) Disconnect fluid level switch coupler (1) and clamp (3) from reservoir (2).



I7RW01410009-01

- 3) Drain brake fluid in reservoir.
- 4) Disconnect clutch reservoir hose from reservoir (M/T model).
- 5) Disconnect brake pipes (1) connected to master cylinder.
- 6) Remove master cylinder fixing nuts (2).
- 7) Remove master cylinder (3) and O-ring.




I7RW01410012-01

Installation

- 1) Install new O-ring (2) to master cylinder assembly (1).
- 2) Apply grease to piston rod "A".
Use specified grease in spare to master cylinder or brake booster as supply parts.
- 3) Install master cylinder assembly (1) to brake booster (3) and tighten master cylinder fixing nuts to specified torque.

Tightening torque

Master cylinder fixing nut (a): 18 N·m (1.8 kgf-m, 13.0 lb-ft)




I7RW01410019-01

- 4) Connect brake pipe to master cylinder and tighten flare nuts to specified torque.

Tightening torque

Brake pipe flare nut (a): 16 N·m (1.6 kgf-m, 12.0 lb-ft)



I7RW01410013-01

- 5) Connect clutch reservoir hose to reservoir and install reservoir hose clamp (M/T model).
- 6) Connect fluid level switch connector and clamp.
- 7) Fill reservoir with specified brake fluid up to its MAX level.
- 8) After completing the work, bleed air from brake and clutch system referring to "Air Bleeding of Brake System" and bleed air from clutch system referring to "Air Bleeding of Clutch System in Section 5C" (M/T model).
- 9) Check each installed parts for fluid leakage.
- 10) Check brake pedal for play referring to "Brake Pedal Play Inspection".
- 11) Perform brake test and check fluid leakage.


Master Cylinder Inspection

S7RW0C4106013

- Check master cylinder for brake fluid leakage, corrosion and smooth operation.
- Inspect distance "a" to be the following.
If measurement is out of specification, replace master cylinder assembly.

Distance

"a": 72.0 mm (2.83 in.) or more



I7RW01410014-01

Booster Operation Inspection

S7RW0C4106014


There are two ways to perform this inspection, with and without a tester. Ordinarily, it is possible to roughly determine its condition without using a tester.

NOTE

For this check, make sure that no air is in hydraulic line.

Check Air Tightness

- 1) Start engine.
- 2) Stop engine after running for 1 – 2 minutes.
- 3) Depress brake pedal several times with the same load as in ordinary braking and observe pedal travel. If pedal goes down deep the first time but its travel decreases as it is depressed the second and more times, air tightness is obtained.




I2RH01410005-01

1. 1st	2. 2nd	3. 3rd
--------	--------	--------

- 4) If pedal travel doesn't change, air tightness isn't obtained.

NOTE

If defective, inspect vacuum lines and sealing parts, and replace any faulty part. When this has been done, repeat the entire test.




I2RH01410006-01

1. 1st, 2nd, 3rd


Check Operation

- 1) With engine stopped, depress brake pedal several times with the same load and make sure that pedal travel doesn't change.



I2RH01410007-01


- 2) Start engine while depressing brake pedal. If pedal travel increases a little, operation is satisfactory. But no change in pedal travel indicates malfunction.



I2RH01410008-01

Check Air Tightness Under Load


- 1) With engine running, depress brake pedal. Then stop engine while holding brake pedal depressed.



I2RH01410009-01

H: Hold

- 2) Hold brake pedal depressed for 30 seconds. If pedal height does not change, condition is good. But it isn't if pedal rises.



I2RH01410010-01


H: Hold
T: 30 seconds

Brake Booster Removal and Installation

S7RW0C4106015

Removal

- 1) Remove master cylinder assembly from booster referring to "Master Cylinder Removal and Installation".
- 2) Disconnect vacuum hose from booster referring to "Master Cylinder and Brake Booster Components".
- 3) Remove front brake pipe (from master cylinder primary and secondary to ABS hydraulic unit pipe) referring to "Front Brake Hose and Pipe Removal and Installation".
- 4) Remove clip (1) and then remove push rod clevis pin (2).
- 5) Loosen booster mounting nuts (3) and then remove booster.




I5RW0A410019-02

Installation

- 1) Install booster to dash panel. Then connect push rod clevis pin (2) and clip (1).
- 2) Tighten booster mounting nuts (3) to specified torque.

Tightening torque

Booster mounting nut (a): 13 N·m (1.3 kgf-m, 9.5 lb-ft)



I5RW0A410021-02

- 3) Connect vacuum hose to booster referring to "Master Cylinder and Brake Booster Components".
- 4) Install front brake pipe (from master cylinder primary and secondary to ABS hydraulic unit pipe) referring to "Front Brake Hose and Pipe Removal and Installation".
- 5) Install master cylinder assembly to booster referring to "Master Cylinder Removal and Installation".
- 6) Fill reservoir with specified fluid.
- 7) Bleed air from brake system referring to "Air Bleeding of Brake System".
- 8) Check pedal height and play referring to "Brake Pedal Free Height Inspection" and "Brake Pedal Play Inspection".
- 9) Check each installed part for fluid leakage and perform brake test.

Brake Booster Inspection

S7RW0C4106016

- Check brake booster for damage and operation.
 - Check boot for damage and deterioration.
 - Check for push clevis rod distance.
- If any malfunction is found, replace brake booster.

Booster Push Clevis Rod Adjustment

S7RW0C4106017


Install push clevis rod (1) so that measurement “a” is obtained and torque nut (2) to specification.

Tightening torque

Clevis pin lock nut (a): 26 N·m (2.6 kgf-m, 19.0 lb-ft)

Clevis installing position (length “a”)

“a”: 129.5 – 130.5 mm (5.10 – 5.13 in.)



IYSQ01410050-01

Specifications

Tightening Torque Specifications

S7RW0C4107001

Fastening part	Tightening torque			Note
	N-m	kgf-m	lb-ft	
Front brake caliper bleeder plug	9	0.9	6.5	🔧
Rear brake caliper bleeder plug	9	0.9	6.5	🔧
Rear wheel cylinder bleeder plug	8	0.8	6.0	🔧
Flexible hose joint bolt	23	2.3	17.0	🔧
Master cylinder fixing nut	18	1.8	13.0	🔧
Brake pipe flare nut	16	1.6	12.0	🔧
Booster mounting nut	13	1.3	9.5	🔧
Clevis pin lock nut	26	2.6	19.0	🔧

NOTE

The specified tightening torque is also described in the following.

“Brake Pedal Components”

“Front Brake Hose and Pipe Components”

“Rear Brake Hose and Pipe Components”

“Master Cylinder and Brake Booster Components”

Reference:

For the tightening torque of fastener not specified in this section, refer to “Fasteners Information in Section 0A”.

Special Tools and Equipment

Recommended Service Material

S7RW0C4108001

NOTE

Required service material is also described in the following.

“Master Cylinder and Brake Booster Components”

Special Tool

S7RW0C4108002


09916-44310 Valve guide remover (5 mm) 🔧 / 🔧 	
--	--

Front Brakes

Repair Instructions

Front Disc Brake Components

S7RW0C4206001



I8RW01420001-01

1. Caliper	9. Disc brake piston : Apply rubber grease included in piston seal set or brake fluid to contact surface of cylinder.	17. Brake flexible hose : Be sure to direct mark (18) to inside of vehicle "I" as shown in figure.
2. Caliper pin bolt	10. Pad spring : Apply grease included in brake pad spare parts to inside.	(a) : 26 N·m (2.6 kgf-m, 19.0 lb-ft)
3. Pin boot	11. Brake disc	(b) : 23 N·m (2.3 kgf-m, 17.0 lb-ft)
4. Slide pin : Apply rubber grease included in slide pin / boot set.	12. Brake caliper carrier	(c) : 9 N·m (0.9 kgf-m, 6.5 lb-ft)
5. Brake pad	13. Caliper carrier bolt	(d) : 85 N·m (8.5 kgf-m, 61.5 lb-ft)
6. Shim	14. Bleeder plug	: Do not reuse.
7. Cylinder boot : Apply small amount of rubber grease included in piston seal set or brake fluid.	15. Flexible hose joint bolt	
8. Piston seal : Apply small amount of rubber grease included in piston seal set or brake fluid.	16. Hose washer	

4B-2 Front Brakes:

Front Disc Brake Pad On-Vehicle Inspection

S7RW0C4206002


Inspect pad linings periodically according to maintenance schedule whenever wheels are removed (for tire rotation or other reason). Take a look through each end and inspection hole of caliper and check lining thickness of outside and inside pads.

If lining is worn and its thickness ("a" in figure) is less than limit, all pads must be replaced at the same time.

Front brake pad thickness "a" (lining thickness)

Standard: 10 mm (0.39 in.)

Limit: 2 mm (0.08 in.)



I7RW01420009-01

Front Disc Brake Pad Removal and Installation


S7RW0C4206003

NOTE

When replacing brake pad, replace it both side brake caliper as the set.

Removal

- 1) Hoist vehicle and remove front wheel.
- 2) Remove caliper pin bolts (1).



I7RW01420003-01


- 3) Remove caliper (1) from caliper carrier (2).

NOTE

Hang removed caliper (1) with a wire hook (4) or the like so as to prevent brake hose from bending and twisting excessively or being pulled.


Don't operate brake pedal with brake pads removed.

- 4) Remove brake pads (3).



I7RW01420010-01


- 5) Remove brake pad spring (1) as show in figure.



I7RW01420014-01

Installation

- 1) Apply small amount of pad grease "a" (included in spare parts) to pad spring and set brake pad spring as shown in figure.




I7RW01420011-01

- 2) Set brake pad springs (1), and install brake pads (2) and shims (4).

NOTE

Install the brake pad with wear indicator (3) to the vehicle center side of front right brake pad.




I7RW01420012-01

- 3) Install caliper and tighten caliper pin bolts to specified torque.

Tightening torque

Caliper pin bolt (a): 26 N·m (2.6 kgf-m, 19.0 lb-ft)



I7RW01420005-02

- 4) Install front wheel referring to "Wheel (with Tire) Removal and Installation in Section 2D".
5) Check brake effectiveness.

Front Disc Brake Pad Inspection

S7RW0C4206004

Check pad lining for wear. When the wear exceeds limit, replace with new one.

⚠ CAUTION

Never polish pad lining with sandpaper. If lining is polished with sandpaper, hard particles of sandpaper will be deposited in lining and may damage disc. When pad lining requires correction, replace it with a new one.


Front disc brake pad thickness (lining thickness)

Standard: 10 mm (0.39 in.)

Limit: 2 mm (0.08 in.)

NOTE

When pads are removed, visually inspect caliper for brake fluid leak. Correct leaky point, if any.




I2RH01420005-01

Front Disc Brake Caliper Removal and Installation

S7RW0C4206005


Removal

- 1) Hoist vehicle and remove front wheel.
- 2) Remove brake flexible hose joint bolt (1) from caliper (2). As this will allow fluid to flow out of hose (3), have a container ready beforehand.



I7RW01420006-01

- 3) Remove caliper pin bolts (1).



I7RW01420003-01

- 4) Remove caliper from caliper carrier.

Installation


- 1) Install caliper to caliper carrier.
- 2) Tighten caliper pin bolts to specified torque.

NOTE

Make sure that boots are fit into groove securely.

Tightening torque

Caliper pin bolt (a): 26 N·m (2.6 kgf-m, 19.0 lb-ft)



I7RW01420005-02

4B-4 Front Brakes:

- 3) Connect flexible hose (3) to caliper as shown in figure.
- 4) Tighten flexible hose joint bolt to specified torque.

Tightening torque

Flexible hose joint bolt (a): 23 N·m (2.3 kgf-m, 17.0 lb-ft)


⚠ WARNING

- Make sure that flexible hose is not twisted when tightening joint bolt. If it is twisted, reconnect it using care not to twist it.
- Be sure to direct mark (1) to inside of vehicle (2) as shown in figure.

- 5) Tighten bleeder plug to specified torque.

Tightening torque

Bleeder plug (b): 9 N·m (0.9 kgf-m, 6.5 lb-ft)



I7RW01420007-02

- 6) Install front wheel referring to "Wheel (with Tire) Removal and Installation in Section 2D".
- 7) After completing the installation, fill reservoir with brake fluid and bleed air from brake system referring to "Air Bleeding of Brake System in Section 4A".
- 8) Check every installed part for fluid leakage.
- 9) Perform brake test and check fluid leakage.

Front Disc Brake Caliper Disassembly and Assembly

S7RW0C4206006

Disassembly


⚠ CAUTION

Clean around caliper with brake fluid before disassembly.

- 1) Remove disc brake piston with air blown into flexible hose joint bolt installation hole.

⚠ WARNING

Do not apply too highly compressed air which will cause piston to jump out of cylinder. Place a cloth (1) to prevent piston from damage. It should be taken out gradually with moderately compressed air. Do not place your fingers in front of piston when using compressed air.




I2RH01420011-01

- 2) Remove cylinder boot.
- 3) Remove piston seal using a thin blade like a thickness gauge, etc.

⚠ CAUTION

Be careful not to damage inside (bore side) of cylinder.



I2RH01420013-01

- 4) Remove bleeder plug and cap from caliper.


Assembly

Assemble parts in reverse order of disassembly, observing the following instructions.

⚠ CAUTION

- **Wash each part cleanly before installation in the same fluid as the one used in master cylinder reservoir.**
- **Never use other fluid or volatile solvent.**
- **Before installing piston seal and cylinder boot to cylinder, apply rubber grease included in piston seal set or brake fluid to them.**
- **Install a new piston seal into groove in cylinder securely making sure that it is not twisted.**
- **After reassembling brake lines, bleed air from them.**

Before installing caliper to carrier, install slide pins with rubber grease included in slide pin / boot set applied into caliper carrier hole and check for its smooth movement in thrust direction.



IYSQ01420021-01


Check all around piston for rust, corrosion and any other damage. If it is found faulty, replace piston or brake caliper.



I8RW01420002-01


- Install piston seal, boot and piston to caliper referring to the following instructions.

- 1) Replace with a new piston seal (1) at every overhaul. After applying rubber grease included in piston seal set or brake fluid, fit piston seal (1) into groove in cylinder taking care not to twist it.



I2RH01420017-01


- 2) Before inserting piston (1) into cylinder, apply rubber grease included in piston seal set or brake fluid to new boot (a) and install it onto piston as shown.



I4RS0B420015-01

- | | |
|----|---------------------------------------|
| A: | 1 grooved side directed cylinder side |
| B: | 2 grooved side directed pad side |

- 3) Fit boot as it is in figure into boot groove in cylinder with fingers.




I2RH01420019-01

4B-6 Front Brakes:

- 4) Insert piston into cylinder by hand and fit boot in boot groove in piston.

NOTE

Check that boot is fitted in boot groove securely all around piston and cylinder.




I2RH01420020-01

- 5) To confirm that boot is fitted in its groove in cylinder properly, pull piston out of cylinder a little but do not take it all out.

NOTE

Boot's face (1) should be at the same level from cylinder's face (2) all around.

- 6) Insert piston into cylinder by hand.



I4RS0A420004-01

Front Disc Brake Caliper Check

S7RW0C4206010

⚠ CAUTION

Perform this check in the following case.


- When replacing the brake pad with new one.
- When checking the thickness of brake pad.
- Before disassembling the brake caliper.

Caliper (body) and Carrier

Check brake caliper body and carrier for deformation, crack, damage and rust. If defective, replace brake caliper and carrier.

Cylinder Boot

Check cylinder boot (1) for break, chap and brake fluid leak. If defective, overhaul or replace brake caliper.




I8RW01420003-01

Slide pin

Before installing caliper to carrier, check for its smooth movement in thrust direction.

If defective, replace slide pin and boot.



I8RW01420004-01

Front Brake Disc Removal and Installation

S7RW0C4206008

⚠ CAUTION


During removal, be careful not to damage brake flexible hose and not to depress brake pedal.

Removal

- 1) Hoist vehicle and remove front wheel.
- 2) Remove caliper assembly by removing caliper carrier bolts (2 pcs).


NOTE

Hang removed caliper with a wire hook or the like so as to prevent brake hose from bending and twisting excessively or being pulled.



I4RS0B420010-01

- 3) Pull brake disc off by using 8 mm bolts (1) (2 pcs).



I5RW0A420003-01

Installation

- 1) Install caliper assembly to steering knuckle.


⚠ CAUTION

Make sure that flexible hose is not twisted when installing caliper assembly. If it is twisted, reinstall it using care not to twist it.

- 2) Tighten caliper carrier bolts to specified torque.

Tightening torque

Caliper carrier bolt (a): 85 N·m (8.5 kgf-m, 61.5 lb-ft)



I4RS0B420012-01

- 3) Install front wheel referring to "Wheel (with Tire) Removal and Installation in Section 2D".
- 4) Perform brake test.

Front Brake Disc Inspection

S7RW0C4206009

- Using magnetic stand and with dial gauge positioned at about 10 mm (0.39 in.) inward from periphery of disc, measure deflection of disc. If it exceeds the limit, correct or replace the brake disc.


Front brake disc deflection

Limit: 0.10 mm (0.004 in.) max.

Special tool

(A): 09900-20607

(B): 09900-20701




I4RS0B420013-01

- Using micrometer, measure thickness of brake disc. If it is less than limit, replace brake disc.

Front brake disc thickness "a"

Standard: 22.0 mm (0.87 in.)

Limit: 20.0 mm (0.79 in.)



I4RS0B420014-01

Specifications

Tightening Torque Specifications

S7RW0C4207001

Fastening part	Tightening torque			Note
	N·m	kgf·m	lb·ft	
Caliper pin bolt	26	2.6	19.0	🔧 / 🔧
Flexible hose joint bolt	23	2.3	17.0	🔧
Bleeder plug	9	0.9	6.5	🔧
Caliper carrier bolt	85	8.5	61.5	🔧

NOTE

The specified tightening torque is also described in the following.
“Front Disc Brake Components”

Reference:

For the tightening torque of fastener not specified in this section, refer to “Fasteners Information in Section 0A”.

Special Tools and Equipment

Recommended Service Material



S7RW0C4208001

NOTE

Required service material is also described in the following.
“Front Disc Brake Components”

Special Tool

S7RW0C4208002

09900–20607 Dial gauge 🔧 	09900–20701 Magnetic stand 🔧 
---	---


Rear Brakes

Drum

Repair Instructions

Rear Drum Brake Components

S7RW0C4316001



I6RW0D430001-01


1. Brake drum	10. Wheel cylinder	19. Bleeder plug
2. Brake shoe	11. Brake back plate	: 73 N·m (7.3 kgf-m, 53 lb-ft)
3. Shoe return spring	12. Rear wheel hub	: 12 N·m (1.2 kgf-m, 9.0 lb-ft)
4. Brake adjuster	13. Nut (4WD model)	: 7 N·m (0.7 kgf-m, 5.0 lb-ft)
5. Antirattle spring	14. Parking cable	: 175 N·m (17.5 kgf-m, 127.0 lb-ft)
6. Hold down spring	15. Rear wheel hub mounting bolt	: Heat-resistant brake grease
7. Shoe hold down pin	16. Wheel cylinder mounting bolt	: Do not reuse.
8. Push nut	17. Rear axle	: Apply brake fluid
9. Brake shoe lever	18. Plug	F: Forward

Rear Brake Drum Removal and Installation

S7RW0C4316002

Removal


- 1) Hoist vehicle and remove rear wheel referring to "Wheel (with Tire) Removal and Installation in Section 2D".
- 2) Release parking brake lever.
- 3) Remove brake drum (1) by using 8 mm bolts (2) (2 pcs).



I7RW01431002-01

Installation


- 1) Before installing brake drum, to maximize brake shoe-to-drum clearance, put screwdriver between rod (1) and ratchet (2) and push down ratchet.



I4RS0A430006-01

NOTE

The figure show ratchet position where brake shoe-to-drum clearance is maximum.



I2RH01430009-01

1. Rod

2. Ratchet

- 2) Confirm that inside of brake drum and brake shoes are free from dirt and oil. And then install brake drum.
- 3) Adjust parking brake cable referring to "Parking Brake Inspection and Adjustment in Section 4D".
- 4) Install rear wheel referring to "Wheel (with Tire) Removal and Installation in Section 2D".
- 5) Check to ensure that brake drum is free from dragging and proper braking is obtained. Perform brake test (foot brake and parking brake).

Rear Brake Drum and Shoe Inspection

S7RW0C4316003

Brake Drum


Inspect brake drum for wear.

If drum inner diameter exceeds the limit or uneven or stepped wear is excessive, replace the drum.

Rear brake drum inner diameter "a"

Standard: 220 mm (8.66 in.)

Limit: 222 mm (8.74 in.)



IYSQ01430007-01

Cracked, Scored or Grooved Drum

A cracked drum is unsafe for further service and must be replaced. Do not attempt to weld a cracked drum.

Smooth up any slight scores. Heavy or extensive scoring will cause excessive brake lining wear and it will probably be necessary to resurface drum braking surface.

If brake linings are slightly worn and drum is grooved, drum should be polished with fine emery cloth in the direction of drum depth but not circumferentially along drum inner.

NOTE

When drum is removed, visually inspect wheel cylinder for brake fluid leakage. Correct leaky point, if any.

Brake Shoe

⚠ CAUTION


Never polish lining with sandpaper. If lining is polished with sandpaper, hard particles of sandpaper will be deposited in lining and may damage drum. When it is required to correct lining, replace it with a new one.

Measure thickness of brake shoe (1). Also, check surface of lining for hardening, excessive wear. If necessary, replace new brake shoes.

Rear brake shoe lining thickness "a"

Standard: 4.0 mm (0.157 in.)

Limit: 1.0 mm (0.04 in.)



I8RW01431001-01

Rear Brake Shoe On-Vehicle Inspection


S7RW0C4316004

Amount of brake shoe wear can be checked as follows.

- 1) Hoist vehicle.
- 2) Remove rubber cover (plug) (1) from brake back plate.
- 3) Through hole of back plate, visually check for thickness of brake shoe lining (2). If lining thickness is less than specified wear limit, replace all brake shoes with new ones.

Lining thickness "a"

Service limit: 1.0 mm (0.04 in.)



I4RS0B430004-01

Rear Brake Shoe Removal and Installation


S7RW0C4316005

NOTE

When replacing brake shoe, replace it on the right and left.


Removal

- 1) Remove brake drum referring to "Rear Brake Drum Removal and Installation: Drum".
- 2) Push and rotate 90° hold down pin (1) and remove hold down pin (1) and hold down spring (2).




I7RW01431003-01

- 3) Remove return springs, brake shoes and adjuster.
- 4) Disconnect parking brake shoe lever (1) from parking brake cable (2).



I2RH01430013-01

- 5) Remove push nut (1).
- 6) Remove parking brake shoe lever (2) from shoe rim (3).




I4RS0A430014-01

4C-4 Rear Brakes: Drum

Installation

Install parts in reverse order of removal, noting the following.

- Before installing rear brake shoe to brake back plate, clean brake back plate and apply heat-resistance brake grease to A on which shoe rims rest.



I6JB0A430002-01


- Push and rotate 90° hold down pin and install hold down pin and hold down spring.
- Install brake drum referring to "Rear Brake Drum Removal and Installation: Drum".

Rear Brake Adjuster and Shoe Lever Check

S7RW0C4316006

- Check ratchet of brake adjuster (1) assembly for wear or damage.
- Check shoe return spring, antirattle spring, quadrant spring and shoe hold down spring for damage, corrosion and weakening.
- Check for smooth movement of brake shoe lever (2) along shoe rim.

If any defective or malfunction is found, repair or replace.



I4RS0A430016-01

Wheel Cylinder Removal and Installation

S7RW0C4316007



⚠ CAUTION

Do not allow brake fluid to get on painted surfaces. Painted surfaces will be damaged by brake fluid, flush it with water immediately if any fluid is spilled.

Removal

- 1) Remove brake drum referring to "Rear Brake Drum Removal and Installation: Drum".

- 2) Remove brake shoe referring to "Rear Brake Shoe Removal and Installation: Drum".
- 3) Loosen brake pipe flare nut (1) but only within the extent that fluid does not leak.
- 4) Remove wheel cylinder mounting bolt (3). Disconnect brake pipe from wheel cylinder and put bleeder plug cap (2) onto pipe to prevent fluid from spilling.



I7RW01431004-01

Installation

- 1) Take off bleeder plug cap from brake pipe and connect pipe to wheel cylinder (1) just enough to prevent fluid from leaking.
- 2) Install wheel cylinder (1) to brake back plate (2), and tighten wheel cylinder mounting bolt to specified torque.

Tightening torque


Wheel cylinder mounting bolt (a): 12 N·m (1.2 kgf-m, 9.0 lb-ft)

- 3) Tighten flare nut of brake pipe (3) to specified torque.

Tightening torque

Rear brake pipe flare nut (b): 16 N·m (1.6 kgf-m, 12.0 lb-ft)

- 4) Install bleeder plug cap (4) taken off from pipe back to bleeder plug.



I7RW01431005-01

- 5) Install brake shoes. Refer to "Rear Brake Shoe Removal and Installation: Drum".
- 6) Install brake drum. Refer to "Rear Brake Drum Removal and Installation: Drum".
- 7) Fill reservoir with brake fluid and bleed brake system. For bleeding operation refer to "Air Bleeding of Brake System in Section 4A".
- 8) Adjust parking brake cable referring to "Parking Brake Inspection and Adjustment in Section 4D".
- 9) Install rear wheel.
- 10) Check to ensure that brake drum is free from dragging and proper braking is obtained. Remove vehicle from hoist and perform brake test (foot brake and parking brake).

Wheel Cylinder Inspection

S7RW0C4316008


- Inspect wheel cylinder for wear, cracks, corrosion or damage, and check for fluid leakage.
 - Inspect boots for breakage, crack and damage.
- If any malfunction is found, replace wheel cylinder.

Brake Back Plate Removal and Installation

S7RW0C4316009

Removal

- 1) Remove brake drum referring to "Rear Brake Drum Removal and Installation: Drum".
- 2) Remove brake shoe referring to "Rear Brake Shoe Removal and Installation: Drum".
- 3) Remove wheel cylinder referring to "Wheel Cylinder Removal and Installation: Drum".
- 4) Remove parking brake cable (1) from brake back plate.



I4RS0A430020-01


- 5) Remove rear wheel hub referring to "Rear Wheel Hub Assembly Removal and Installation (Rear Drum Brake Model) in Section 2C".
- 6) Remove brake back plate.

Installation

- 1) Install brake back plate (1) and rear wheel hub referring to "Rear Wheel Hub Assembly Removal and Installation (Rear Drum Brake Model) in Section 2C".
- 2) Install parking brake cable (1) to brake back plate.

Tightening torque

Parking cable cap nut (a): 11 N·m (1.1 kgf-m, 8.0 lb-ft)



I4RS0A430024-01

- 3) Install wheel cylinder and connect brake pipe flare nut, and then tighten wheel cylinder bolts and flare nut to specified torque referring to "Wheel Cylinder Removal and Installation: Drum".
- 4) Install brake shoe referring to "Rear Brake Shoe Removal and Installation: Drum".
- 5) Install brake drum referring to "Rear Brake Drum Removal and Installation: Drum".
- 6) Fill reservoir with brake fluid and bleed brake system. For bleeding operation refer to "Air Bleeding of Brake System in Section 4A".
- 7) Adjust parking brake cable referring to "Parking Brake Inspection and Adjustment in Section 4D".
- 8) Install rear wheel referring to "Wheel (with Tire) Removal and Installation in Section 2D".
- 9) Check to ensure that brake drum is free from dragging and proper braking is obtained. Perform brake test (foot brake and parking brake).

Specifications

Tightening Torque Specifications

S7RW0C4317001

Fastening part	Tightening torque			Note
	N·m	kgf·m	lb·ft	
Wheel cylinder mounting bolt	12	1.2	9.0	☞
Rear brake pipe flare nut	16	1.6	12.0	☞
Parking cable cap nut	11	1.1	8.0	☞

NOTE

The specified tightening torque is also described in the following.
“Rear Drum Brake Components: Drum”

Reference:

For the tightening torque of fastener not specified in this section, refer to “Fasteners Information in Section 0A”.

Special Tools and Equipment

Recommended Service Material

S7RW0C4318001

NOTE


Required service material is also described in the following.
“Rear Drum Brake Components: Drum”

Disc

Repair Instructions

Rear Disc Brake Components

S7RW0C4326001



I7RW01432001-02

1. Caliper	11. Brake caliper carrier	21. Shaft cover : Apply rubber grease.
2. Caliper pin bolt	12. Caliper carrier bolt	22. Lever
3. Boot	13. Rear caliper bleeder plug	23. Washer
4. No.1 slide pin : Apply rubber grease.	14. Bleeder plug cap	24. Parking nut
5. Brake pad	15. Brake flexible hose	: 23 N·m (2.3 kgf-m, 17.0 lb-ft)
6. Return spring	16. Flexible hose joint bolt	: 27 N·m (2.7 kgf-m, 19.5 lb-ft)
7. Pad spring	17. Hose washer	: 60 N·m (6.0 kgf-m, 43.5 lb-ft)
8. Disk brake piston : Apply brake fluid to contact surface of cylinder.	18. Brake disc	: 9 N·m (0.9 kgf-m, 6.5 lb-ft)
9. Piston seal : Apply small amount of brake fluid to all around part of piston seal.	19. No.2 slide pin : Apply rubber grease.	: Do not reuse.
10. Cylinder boot : Apply small amount of brake fluid.	20. Pad shim	

Rear Disc Brake Pad Removal and Installation

S7RW0C4326002

NOTE


When replacing brake pad, replace it on the right and left.

Removal

- 1) Hoist vehicle and remove wheel.
- 2) Release parking brake lever.
- 3) Remove caliper pin bolts (1).
- 4) Remove caliper (2) from caliper carrier.

NOTE

Hang removed caliper (2) with a wire hook or the like so as to prevent brake hose from bending and twisting excessively or being pulled.
Don't operate brake pedal with brake pads removed.



I7RW01432008-01


- 5) Remove brake pads and pad springs.

Installation

- 1) Turn brake caliper piston clockwise to obtain clearance between brake disc and pads.


Special tool

(A): 09945-16060





I6RS0B431004-01

- 2) Clean (and degrease) pad spring installation face (3) of caliper carrier (1).
- 3) Attach pad springs (2) to caliper carrier (1).



I6RS0B431005-03

- 4) Before installing brake pad shims (1), apply small amount of grease (included in spare parts) to mating surfaces of brake pad and pad shim.
- 5) Set pad shims (1) to brake pads (2).




I6RS0B431006-02

- 6) With lug (1) of brake pad matched with dent (2) of brake piston, install caliper (3) to caliper carrier.
- 7) Tighten caliper pin bolts (4) to specified torque.

Tightening torque

Caliper pin bolt (a): 23 N·m (2.3 kgf-m, 17 lb-ft)



I6RS0B431007-01

- 8) Install rear wheel referring to "Wheel (with Tire) Removal and Installation in Section 2D".
- 9) After completion of installation, check for brake effectiveness.

Rear Disc Brake Caliper Removal and Installation


S7RW0C4326003

⚠ CAUTION

Do not allow brake fluid to get on painted surfaces. Painted surfaces will be damaged by brake fluid, flush it with water immediately if any fluid is spilled.


Removal

- 1) Hoist vehicle and remove rear wheel.
- 2) Release parking brake lever.
- 3) Remove clip (1).




I6RS0B431008-01

- 4) Loosen brake pipe flare nut (1) using by flare nut wrench. Then remove clip (2).
- 5) Remove flexible hose joint bolt (3), and disconnect brake flexible hose (4) from brake caliper.




I7RW01432009-01

- 6) Remove caliper pin bolts.
- 7) Remove caliper from brake caliper carrier.
- 8) Disconnect parking brake cable (1) from lever (2) while rotating lever in direction of arrow.



I6RS0B431011-01

- 9) Remove brake pads, slide pins and slide pin boots from brake caliper carrier.
- 10) Remove brake caliper carrier (1) from rear axle (2).




I7RW01432010-01

Installation

- 1) Install brake caliper carrier (1) to rear axle (2).

Tightening torque

Brake caliper carrier bolt (a): 60 N·m (6.0 kgf-m, 43.5 lb-ft)




I7RW01432011-01

4C-10 Rear Brakes: Disc

- 2) Install new slide pin boots (1) to brake caliper carrier.
- 3) Apply rubber grease to slide pins, then install slide pin (2) to front side and slide pin (3) to rear side of brake caliper carrier.

NOTE


Be sure not to install wrongly because the shape of slide pins are different as shown below.



- 4) Pass parking brake cable (1) through bracket (3) of caliper.
- 5) Hang parking brake cable on lever (2) as follows.

NOTE

Make sure that lever (4) contacts pin (5).



- 6) Install brake pads and caliper referring to "Rear Disc Brake Pad Removal and Installation: Disc".
- 7) Connect flexible hose (4) with new washers (5) to caliper and brake pipe temporarily by hand. Then install clip (2).
- 8) Tighten flexible hose joint bolt (3) and brake pipe flare nut (1).


⚠ WARNING

Make sure that flexible hose is not twisted when tightening joint bolt. If it is twisted, reconnect it using care not to twist it.


Tightening torque

Flexible hose joint bolt (a): 23 N·m (2.3 kgf-m, 17.0 lb-ft)

Brake pipe flare nut (b): 16 N·m (1.6 kgf-m, 12.0 lb-ft)



- 9) Install brake cable clip (1) securely to bracket (2).



- 10) After reassembling brake lines, bleed air from them referring to "Air Bleeding of Brake System in Section 4A".
- 11) Check to make sure that system is free from fluid leakage.
- 12) Check to make sure that parking brake lever stroke is as specified. If not, adjust. Refer to "Parking Brake Cable Components in Section 4D".
- 13) Install rear wheel referring to "Wheel (with Tire) Removal and Installation in Section 2D".
- 14) Remove vehicle from hoist and perform brake test (foot brake and parking brake).

Rear Disc Brake Pad Inspection

S7RW0C4326004

Check pad lining for wear. When wear exceeds limit, replace with new one.

CAUTION

Never polish pad lining with sandpaper. If lining is polished with sandpaper, hard particles of sandpaper will be deposited in lining and may damage disc. When pad lining requires correction, replace it with a new one.


Rear disc brake pad thickness (lining thickness)

Standard: 9.0 mm (0.354 in.)

Limit: 1.0 mm (0.039 in.)

NOTE

When pads are removed, visually inspect caliper for brake fluid leak. Correct leaky point, if any.



I6RS0B431034-01

Rear Disc Brake Caliper Disassembly and Assembly

S7RW0C4326005

Disassembly

CAUTION

Clean around caliper with brake fluid before disassembly.


- 1) Remove disc brake piston (1) by turning piston counterclockwise with special tool.

CAUTION

Be careful not to damage inside (bore side) of cylinder.

Special tool

(A): 09945-16060




I6RS0B431013-01

- 2) Remove cylinder boot and piston seal (1).


CAUTION

Be careful not to damage inside (bore side) of cylinder.



I6RS0B431014-01

- 3) Remove bleeder plug and cap from caliper.
- 4) Remove return spring (1), parking nut (2), washer (3), lever (4) and shaft cover (5).



I6RS0B431015-01


Assembly

⚠ CAUTION

- Wash each part cleanly before installation in the same fluid as the one used in master cylinder reservoir.
- Never use other fluid or thinner.
- Before installing caliper to brake caliper carrier, install slide pins with grease applied into carrier hole and check for its smooth movement in thrust direction.
- Before installing piston seal to cylinder, apply fluid to them.
- Install a piston seal into groove in cylinder securely making sure that it is not twisted.

Before install piston to brake caliper, check piston and caliper as below.


- Check all around piston for rust, corrosion and any other damage. If it is found faulty, replace piston or brake caliper.



I6RS0B431020-01

- Push in adjusting bolt (1) by hand and move lever to check that adjusting bolt (1) moves smoothly in the arrow direction.

Also, check adjusting bolt (1) for any damage. If it is found faulty, replace brake caliper.



I6RS0B431021-01


- 1) Apply thread lock cement to shaft thread (6) of caliper.

“A”: Thread lock cement 99000–32110 (Thread Lock Cement Super 1322)

- 2) Apply grease to inside of new shaft cover (1).
- 3) Install new shaft cover, lever (2), washer (3), parking nut (4) and return spring (5) to caliper.


Tightening torque

Parking nut (a): 27 N·m (2.7 kgf-m, 19.5 lb-ft)



I7RW01432003-01

- 4) Install bleeder plug and cap to caliper.
- 5) Install new piston seal to caliper.
- 6) Before inserting piston (2) into cylinder, install boot (1) onto piston as shown.




I7RW01432004-02

[A]: Cylinder side

[B]: Brake pad side

- 7) Fit boot as it is in figure into boot groove in cylinder with fingers.



I6RS0B431033-01


- 8) Turn brake caliper piston clockwise to obtain clearance between brake disc and pads.

NOTE

Check that boot is fitted in boot groove securely all around piston.

Special tool

(A): 09945-16060



I7RW01432005-01

Rear Disc Brake Caliper Check

S7RW0C4326009

NOTE

Perform this check in the following case.


- When replacing the brake pad with new one.
- When checking the thickness of brake pad.
- Before disassembling the brake caliper.

Caliper (body) and Carrier

Check brake caliper (body) and carrier for deformation, crack, damage and rust. If defective, replace brake caliper and carrier.

Cylinder Boot

Check cylinder boot (1) for break, chap and brake fluid leak. If defective, overhaul or replace brake caliper.




I8RW01432002-01

Slide pin and Boot

Before installing caliper to carrier, check for its smooth movement in thrust direction.

If defective, replace slide pin and boot.



I6RS0B431022-01

Rear Brake Disc Removal and Installation

S7RW0C4326007

⚠ CAUTION

During removal, be careful not to damage brake flexible hose and not to depress brake pedal.

Removal


- 1) Hoist vehicle and remove wheel.
- 2) Remove brake caliper assembly referring to "Rear Disc Brake Caliper Removal and Installation: Disc".

NOTE

Hang removed caliper with a wire hook or the like so as to prevent brake hose from bending and twisting excessively or being pulled.

Don't operate brake pedal with brake pads removed.

- 3) Pull brake disc off by using 8 mm bolts (1) (2 pcs).



I7RW01432006-01

4C-14 Rear Brakes: Disc


Installation

Install in reverse order of removal nothing the following.

- Tighten caliper carrier bolts to specified torque.

Tightening torque

Caliper carrier bolt (a): 60 N·m (6.0 kgf-m, 43.5 lb-ft)



I7RW01432013-01

- Install rear wheel referring to “Wheel (with Tire) Removal and Installation in Section 2D”.
- Upon completion of installation, perform brake test.

Rear Brake Disc Inspection

S7RW0C4326008

- Using magnetic stand and with dial gauge positioned at about 10 mm (0.39 in.) inward from periphery of disc, measure deflection of disc.
If limit value is exceeded, replace correct or replace.


Rear brake disc deflection

Limit: 0.10 mm (0.004 in.) max.

Special tool

(A): 09900-20607

(B): 09900-20701




I6RS0B431031-01

- Using micrometer, measure thickness of brake disc.
If limit value is exceeded, replace brake disc.

Rear brake disc thickness

Standard: 9 mm (0.354 in.)

Limit: 8 mm (0.315 in.)



I6RS0B431032-01

Specifications

Tightening Torque Specifications

S7RW0C4327001

Fastening part	Tightening torque			Note
	N·m	kgf-m	lb-ft	
Caliper pin bolt	23	2.3	17	☞
Brake caliper carrier bolt	60	6.0	43.5	☞
Flexible hose joint bolt	23	2.3	17.0	☞
Brake pipe flare nut	16	1.6	12.0	☞
Parking nut	27	2.7	19.5	☞
Caliper carrier bolt	60	6.0	43.5	☞

NOTE

The specified tightening torque is also described in the following.
“Rear Disc Brake Components: Disc”

Reference:

For the tightening torque of fastener not specified in this section, refer to “Fasteners Information in Section 0A”.

Special Tools and Equipment

Recommended Service Material

S7RW0C4328001




Material	SUZUKI recommended product or Specification		Note
Thread lock cement	Thread Lock Cement Super 1322	P/No.: 99000–32110	

NOTE

Required service material is also described in the following.
“Rear Disc Brake Components: Disc”

Special Tool

S7RW0C4328002



09900–20607 Dial gauge 	09900–20701 Magnetic stand 
09945–16060 Piston installer handle 	

Parking Brake

Repair Instructions

Parking Brake Cable Components

S7RW0C4406001



[a]: Disc brake type	3. Equalizer	10. Parking cable clamp bolt	[D]: View [D]
[b]: Drum brake type	4. Parking cable bracket	11. Parking cable clamp nut	[E]: View [E]
T: Top side	5. Parking cable bracket bolt	12. Vehicle body	[F]: View [F]
F: Forward side	6. Grommet	13. Caliper lever	[G]: View [G]
R: Right side	7. Parking cable cap nut	[A]: View [A]	 (a) : 26 N·m (2.6 kgf-m, 19.0 lb-ft)
1. Parking brake lever assembly	8. Brake back plate	[B]: View [B]	 (b) : 11 N·m (1.1 kgf-m, 8.0 lb-ft)
2. Parking brake lever bolt	9. Parking brake shoe lever	[C]: View [C]	

Parking Brake Inspection and Adjustment

S7RW0C4406002

Inspection

Hold center of parking brake lever grip and pull it up with 200 N (20 kg, 44 lbs) force.

With parking brake lever pulled up as shown, count ratchet notches. There should be 4 – 9 notches.

Also, check if both right and left rear wheels are locked firmly.

To count number of notches easily, listen to click sounds that ratchet makes while pulling parking brake lever without pressing its button.


One click sound corresponds to one notch.

If number of notches is out of specification, adjust cable referring to adjustment procedure so as to obtain specified parking brake stroke.

NOTE

Check tooth tip of each notch for damage or wear.

If any damage or wear is found, replace parking brake lever.



I4RS0B440002-01

Adjustment

NOTE


Make sure for the following conditions before cable adjustment.

- **No air is trapped in brake system.**
- **Brake pedal travel is proper.**
- **Start engine and then brake pedal has been depressed at least 3 times with about 150 N (15 kg, 33 lbs) load.**
- **Parking brake lever (1) has been pulled up a few times with about 200 N (20 kg, 44 lbs) load.**

If parking brake cable is replaced with new one, pull up parking brake lever a few times with about 500 N (50 kg, 110 lbs) force.

Drum brake

After confirming that the conditions are all satisfied, adjust parking brake lever stroke by loosening or tightening adjust nut (2).




I4RS0A440003-01

NOTE

Check brake drum for dragging after adjustment.

Disc brake


- 1) Release parking brake lever (1).
- 2) Loosen parking brake lever adjust nut (2) fully.



I4RS0A440003-01

4D-3 Parking Brake:


- 3) Make sure that lever (3) contacts pin (4).



I7RW01440002-01

1. Parking brake cable	2. Brake caliper
------------------------	------------------

- 4) Pull up parking brake lever 1 notch.
- 5) Rotate rear wheel by hand and fasten parking lever adjust nut until dragging rear wheel lightly.



I7RW01440006-01

- 6) Release parking brake lever and then make sure that there is no drag in rear wheel. If there is, repeats go to step 2).
- 7) Make sure that the number of notch is between 4 and 9 when operating parking brake lever.
- 8) If the number of notch is not between 4 and 9, replace parking brake cable and/or inspect rear brake caliper.

Parking Brake Cable Removal and Installation

S7RW0C4406003

Removal

NOTE

When it is necessary to remove both right and left parking brake cables, repeat below steps 2) and 6) on right and left wheels.

- 1) Hoist vehicle.
- 2) Remove wheel.
- 3) Disconnect parking brake cable from equalizer (parking brake lever) and clamps.
- 4) Remove brake drum. Refer to "Rear Brake Drum Removal and Installation: Drum in Section 4C" (drum brake model).
- 5) Disconnect parking brake cable from brake shoe lever referring to "Rear Brake Shoe Removal and Installation: Drum in Section 4C" (drum brake model).
- 6) Disconnect parking brake cable from lever referring to "Rear Disc Brake Caliper Removal and Installation: Disc in Section 4C" (disc brake model).
- 7) Remove parking brake cable and parking cable bracket.

Installation

Install it by reversing removal procedure, noting the following points.


- Install clamps properly referring to "Parking Brake Cable Components".
- Tighten bolts and nuts to specified torque referring to "Parking Brake Cable Components".
- Adjust parking brake cable. Refer to "Parking Brake Inspection and Adjustment".
- Check brake disc or brake drum for dragging and brake system for proper performance. Brake test should be performed.

Parking Brake Lever Removal and Installation

S7RW0C4406004

Removal

- 1) Remove console box.
- 2) Block vehicle wheels and release parking brake lever.
- 3) Disconnect lead wire of parking brake switch at coupler.
- 4) Loosen parking brake cable adjusting nut (1).




I4RS0A440004-01

- 5) Remove parking brake lever bolts (1) and then remove parking brake lever assembly (2) with equalizer (3).

NOTE

Don't disassemble parking brake lever switch. It must be removed and installed as a complete switch assembly.



I5RW0A440002-01


Installation

- 1) Install in reverse order of removal procedure.

Check equalizer inclined angle.

Tightening torque

Parking brake lever bolt (a): 26 N·m (2.6 kgf-m, 19.0 lb-ft)



I5RW0A440003-01

- 2) After all parts are installed, parking brake lever needs to be adjusted. Refer to "Parking Brake Inspection and Adjustment".
- 3) Check disc brake or brake drum for dragging and brake system for proper performance. After removing vehicle from hoist, brake test should be performed.

Specifications

Tightening Torque Specifications

S7RW0C4407001

Fastening part	Tightening torque			Note
	N·m	kgf-m	lb-ft	
Parking brake lever bolt	26	2.6	19.0	☞

NOTE

The specified tightening torque is also described in the following.
"Parking Brake Cable Components"

Reference:

For the tightening torque of fastener not specified in this section, refer to "Fasteners Information in Section 0A".

ABS


Precautions

Precautions in Diagnosing Troubles

S7RW0C4500001

To ensure that the trouble diagnosis is done accurately and smoothly, observe the following and follow “ABS Check”.

- Diagnostic information stored in ABS control module memory can be cleared as well as checked by using SUZUKI scan tool. Before using scan tool, read its Operator's (Instruction) Manual carefully to have good understanding as to what functions are available and how to use it.
- If the vehicle was operated in any of the following ways, ABS warning light may light momentarily but this does not indicate anything abnormal in ABS.
 - The vehicle was driven with parking brake pulled.
 - The vehicle was driven with brake dragging.
 - The vehicle was stuck in mud, sand, etc.
 - Wheel spin occurred while driving.
 - Wheel(s) was rotated while the vehicle was jacked up.
- Be sure to read “Precautions for Electrical Circuit Service in Section 00” and “Precaution for CAN Communication System in Section 00” before inspection and observe what is written there.
- Be sure to use the trouble diagnosis procedure as described in “ABS Check”. Failure to follow it may result in incorrect diagnosis. (Some other diagnosis trouble code may be stored by mistake in the memory of ABS control module during inspection.)
- When disconnecting ABS hydraulic unit / control module connector (1), pull up lock lever (2) of connector.
When connecting, set the connector on ABS hydraulic unit / control module assembly and pull down the lock lever (2) until it locks.



I5RW0A450001-01

[A]: Disconnect	C: Pull up to disconnect
[B]: Connect	D: Pull down to connect

- Communication of ECM, BCM, combination meter, 4WD control module (if equipped), keyless start control module (if equipped), TCM (if equipped), data link connector and ABS control module is established by CAN (Control Area Network).
Therefore, be sure to read “Precautions for Installing Mobile Communication Equipment in Section 00” before inspection and handling CAN communication line.

Precautions in On-Vehicle Service

S7RW0C4500002

When connector is connected to ABS hydraulic unit / control module assembly, do not disconnect connectors of sensors with ignition switch ON. Otherwise, DTC will be set in ABS control module.

General Description

ABS Description

S7RW0C4501001

The ABS (Antilock Brake System) controls the fluid pressure applied to the wheel cylinder of each brake from the master cylinder so that each wheel is not locked even when hard braking is applied.

This ABS has also the following function.

While braking is applied, but before ABS control becomes effective, braking force is distributed between the front and rear so as to prevent the rear wheels from being locked too early for better stability of the vehicle.

The main component parts of this ABS include the following parts in addition to those of the conventional brake system.

- Wheel speed sensor which senses revolution speed of each wheel and outputs its signal.
 - Rear wheel speed sensor of 4WD vehicle is integrated in rear wheel hub assembly and supplied as rear wheel hub assembly part.
 - Front wheel speed sensor and rear wheel speed sensor of 2WD model are separated from wheel hub assembly and supplied as spare parts.
- ABS warning light which lights to inform abnormality when system fails to operate properly.
- ABS hydraulic unit / control module assembly is incorporated ABS control module, ABS hydraulic unit (actuator assembly), solenoid valve power supply driver (transistor), solenoid valve driver (transistor), pump motor driver (transistor).
 - ABS control module which sends operation signal to ABS hydraulic unit to control fluid pressure applied to each wheel cylinder based on signal from each wheel speed sensor so as to prevent wheel from locking.
 - ABS hydraulic unit which operates according to signal from ABS control module to control fluid pressure applied to wheel cylinder of each 4 wheels.
 - Solenoid valve power supply driver (transistor) which supplies power to solenoid valve in ABS hydraulic unit.
 - Solenoid valve driver (transistor) which controls each solenoid valves in ABS hydraulic unit.
 - Pump motor driver (transistor) which supplies power to pump motor in ABS hydraulic unit.
- G sensor which detects body deceleration speed for 4WD model.

This ABS is equipped with Electronic Brake force Distribution (EBD) system that controls a fluid pressure of rear wheels to best condition, which is the same function as that of proportioning valve, by the signal from wheel sensor independently of change of load due to load capacity and so on. And if the EBD system fails to operate properly, the brake warning light lights to inform abnormality.


ABS Hydraulic Unit / Control Module Assembly Description

S7RW0C4501002

ABS control module is a component of ABS hydraulic unit / control module assembly and has the following functions.

Self-Diagnosis Function

ABS control module diagnoses conditions of the system component parts (whether or not there is any abnormality) all the time and indicates the results (warning of abnormality occurrence and DTC) through the ABS warning light as described.



- When ignition switch is turned ON, ABS warning light lights for 2 seconds to check its circuit.
- When no abnormality has been detected (the system is in good condition), ABS warning light turns OFF after 2 seconds.
- When an abnormality in the system is detected, ABS warning light lights and the area where that abnormality lies is stored in the memory of EEPROM in ABS control module.

CAN Communication System Description

S7RW0C4501003

Refer to “CAN Communication System Description in Section 1A” for CAN communication system description. ABS control module communicates control data with each control module as follows.

ABS Control Module Transmission Data


				ECM	Combination Meter	4WD control module
ABS control module	Transmit	DATA	Wheel speed signal (Front-right)	○		○
			Wheel speed signal (Front-left)	○		○
			Wheel speed signal (Rear-right)			○
			Wheel speed signal (Rear-left)			○
			ABS active	○		○
			ABS indication		○	
			EBD indication		○	

I7RW01450001-06

Schematic and Routing Diagram

ABS Schematic

S7RW0C4502001




4E-5 ABS:

1. ABS hydraulic unit / control module assembly	9. Brake light switch	17. Wheel speed sensor (Left-rear)
2. ABS control module	10. ABS warning light	18. Battery
3. ABS hydraulic unit	11. EBD warning light (Brake warning light)	19. Ignition switch
4. Solenoid valve power supply driver (transistor)	12. Light driver module	20. G sensor (4WD model)
5. Solenoid valve driver (transistor)	13. Data link connector	21. ECM
6. Pump motor driver (transistor)	14. Wheel speed sensor (Right-front)	22. Combination meter
7. Solenoid valve	15. Wheel speed sensor (Left-front)	23. 4WD control module
8. Pump motor	16. Wheel speed sensor (Right-rear)	

ABS Wiring Circuit Diagram

S7RW0C4502002



I6RW0C450001-01

[A]: Terminal arrangement of ABS control module connector (viewed from terminal side)	12. BCM	24. Right-rear wheel speed sensor
1. Battery	13. Brake fluid level switch	25. ABS hydraulic unit / control module assembly
2. Main fuse box	14. Parking brake switch	26. Brake light switch
3. Ignition switch	15. CAN junction connector	27. Brake light
4. Junction block assembly	16. Keyless start control module	28. To ECM and shift lock relay (A/T model)


5. Combination meter	17. Data link connector (DLC)	29. Pump motor driver (transistor)
6. ABS warning light	18. To BCM, 4WD control module, P/S control module, HVAC control module (auto A/C model) and SDM	30. Pump motor
7. EBD warning light (brake warning light)	19. ECM	31. Solenoid valve power supply driver
8. Light driver module	20. TCM (A/T model)	32. Solenoid valve
9. CAN driver	21. Left-front wheel speed sensor	33. Solenoid valve driver (transistor)
10. G sensor (4WD model)	22. Right-front wheel speed sensor	
11. 4WD control module	23. Left-rear wheel speed sensor	

Terminal	Circuit
E08	1 CAN communication line (high) for ECM
	2 CAN communication line (high) for BCM
	3 G sensor ground (4WD model)
	4 —
	5 —
	6 G sensor signal (4WD mode)
	7 Brake light switch
	8 —
	9 Ignition switch
	10 Left-rear wheel speed sensor (–)
	11 Left-front wheel speed sensor (+)
	12 CAN communication line (low) for ECM
	13 CAN communication line (low) for BCM
	14 —
	15 —
	16 Data link connector
	17 Right-front wheel speed sensor (–)
	18 Right-front wheel speed sensor (+)
	19 Right-rear wheel speed sensor (–)
	20 Right-rear wheel speed sensor (+)
	21 Left-rear wheel speed sensor (+)
	22 Left-front wheel speed sensor (–)
	23 Ground for solenoid valve
	24 Power supply for solenoid valve
	25 Power supply for pump motor
	26 Ground for pump motor

Component Location

ABS Components Location

S7RW0C4503001



I5RW0A450006-02

1. ABS hydraulic unit / control module assembly	5. EBD warning light (Brake warning light)
2. Wheel speed sensors	6. Wheel speed sensor encoder (included in wheel hub assembly)
3. Brake light switch	7. Data link connector
4. ABS warning light	8. G sensor (4WD model)

Diagnostic Information and Procedures

ABS Check

S7RW0C4504001

Refer to the following items for the details of each step.

Step	Action	Yes	No
1	🔧 Malfunction analysis 1) Perform "Customer complaint analysis: ". 2) Perform "Problem symptom confirmation: ". 3) Perform "DTC check, record and clearance: " and recheck DTC. <i>Is there any malfunction DTC?</i>	Go to Step 4.	Go to Step 2.
2	🔧 Driving test 1) Perform "Step 2: Driving Test: ". <i>Is trouble symptom identified?</i>	Go to Step 3.	Go to Step 6.
3	🔧 DTC check 1) Perform "DTC Check". <i>Is it malfunction code?</i>	Go to Step 4.	Go to Step 5.
4	🔧 ABS check 1) Inspect and repair referring to applicable DTC flow. <i>Does trouble recur?</i>	Go to Step 5.	Go to Step 7.
5	🔧 Brakes diagnosis 1) Inspect and repair referring to "Brakes Symptom Diagnosis in Section 4A". <i>Does trouble recur?</i>	Go to Step 3.	Go to Step 7.

Step	Action	Yes	No
6	☞ Check for intermittent problem 1) Check intermittent troubles referring to “Intermittent and Poor Connection Inspection in Section 00” and related circuit of trouble code recorded in Step 1. <i>Does trouble recur?</i>	Go to Step 4.	Go to Step 7.
7	☞ Final confirmation test 1) Perform “Step 7: Final Confirmation Test: ”. <i>Does trouble recur?</i>	Go to Step 3.	End.

Step 1: Malfunction Analysis

Customer complaint analysis

Record details of the problem (failure, complaint) and how it occurred as described by the customer.

For this purpose, use of such a questionnaire form as shown in the following will facilitate collecting information to the point required for proper analysis and diagnosis.

Customer questionnaire (Example)

Customer's name:	Model:	VIN:	
Date of issue:	Date of Reg:	Date of problem:	Mileage:

Problem Symptoms	• ABS warning light abnormal: fails to turn on/fails to go off/flashes • Abnormal noise while vehicle is running: from motor, from valve, other_____ • Wheel is locked at braking: • Pump motor does not stop (running): • Braking does not work: • Other:
Frequency of occurrence	• Continuous/Intermittent (_____ times a day, a month)/ other_____
Conditions for Occurrence of Problem	• Vehicle at stop & ignition switch ON: • When starting: at initial start only/at every start/Other_____ • Vehicle speed: while accelerating/while decelerating/at stop/ while turning/while running at constant speed/ other_____ • Road surface condition: Paved road/rough road/snow-covered road/ other_____ • Chain equipment:
Environmental Condition	• Weather: fair/cloudy/rain/snow/other_____ • Temperature: °F (_____ °C)
Diagnostic Trouble Code	• First check: _____ Normal code/malfunction code (_____) • Second check after test drive: Normal code/malfunction code (_____)

Problem symptom confirmation

Check if what the customer claimed in "Customer Questionnaire" is actually found in the vehicle and if that symptom is found, whether it is identified as a failure. (This step should be shared with the customer if possible.) Check warning lights related to brake system referring to "EBD Warning Light (Brake Warning Light) Check" and "ABS Warning Light Check".

DTC check, record and clearance

Perform "DTC Check" procedure, record it and then clear it referring to "DTC Clearance".
Recheck DTC referring to "DTC Check".
When DTC which is recorded at DTC check procedure is detected again after performing DTC clearance, go to "Step 4: ABS Check:" to proceed the diagnosis.
When DTC which is recorded at DTC check procedure is not indicated anymore after performing DTC clearance, ABS control module does not perform the system diagnosis, or temporary abnormality may occur, therefore go to "Step 2: Driving Test:" to proceed the diagnosis.

Step 2: Driving Test

Test drive the vehicle at 40 km/h (25 MPH) for more than a minute and check if any trouble symptom (such as abnormal lighting of ABS warning light) exists.
If the malfunction DTC is confirmed again at ignition switch ON, driving test as described is not necessary. Proceed to Step 3.

Step 3: DTC Check

Recheck DTC referring to "DTC Check".

Step 4: ABS Check

According to ABS Check for the DTC confirmation in Step 3, locate the cause of the trouble, namely in a sensor, switch, wire harness, connector, actuator assembly or other part and repair or replace faulty parts.

Step 5: Brakes Diagnosis

Check the parts or system suspected as a possible cause referring to "Brakes Symptom Diagnosis in Section 4A" and based on symptoms appearing on the vehicle (symptom obtained through Steps 1 and 2 and repair or replace faulty parts, if any).

Step 6: Check for Intermittent Problem

Check parts where an intermittent trouble is easy to occur (e.g., wire harness, connector, etc.), referring to "Intermittent and Poor Connection Inspection in Section 00" and related circuit of trouble code recorded in Step 1 to 3.


Step 7: Final Confirmation Test

Confirm that the problem symptom has gone and the ABS is free from any abnormal conditions. If what has been repaired is related to the malfunction DTC, clear the DTC once referring to "DTC Clearance" and perform test driving and confirm that no DTC is indicated.

ABS Warning Light Check

S7RW0C4504002

- 1) Turn ignition switch ON.
- 2) Check that ABS warning light (1) comes ON for about 2 seconds and then goes off.
If any faulty condition is found, advance to "ABS Warning Light Does Not Come ON at Ignition Switch ON" or "ABS Warning Light Comes ON Steady".



I4RS0A450007-01


EBD Warning Light (Brake Warning Light) Check

S7RW0C4504003

NOTE

Perform this check on a level place.

- 1) Turn ignition switch ON with parking brake applied.
- 2) Check that EBD warning light (brake warning light) (1) is turned ON.
- 3) Release parking brake with ignition switch ON and check that EBD warning light (brake warning light) goes off.
If it doesn't go off, go to "EBD Warning Light (Brake Warning Light) Comes ON Steady".




I4RS0A450008-01

DTC Check

S7RW0C4504004

- 1) Turn ignition switch to OFF position.
- 2) Connect SUZUKI scan tool to data link connector (1).

Special tool**(A): SUZUKI scan tool**

ISRW0A450007-01

- 3) Turn ignition switch to ON position.
- 4) Read DTC according to instructions displayed on SUZUKI scan tool and print it or write it down. Refer to SUZUKI scan tool operator's manual for further details.

NOTE

If SUZUKI scan tool can not communicate ABS hydraulic unit / control module, perform "Serial Data Link Circuit Check".

- 5) After completing the check, turn ignition switch off and disconnect SUZUKI scan tool from DLC.

DTC Table

S7RW0C4504005

⚠ CAUTION

Be sure to perform "ABS Check" before starting diagnosis.

DTC (displayed on SUZUKI scan tool)	Diagnostic Items	
NO DTC	Normal	
 C1013	Control module mismatch	
 C1015	G sensor circuit (for 4WD model)	
 C1016	Brake light switch	
 C1021	RF	Wheel speed sensor circuit
 C1025	LF	
 C1031	RR	
 C1035	LR	
 C1022	RF	Wheel speed sensor or encoder
 C1026	LF	
 C1032	RR	
 C1036	LR	
 C1033	Wheel speed sensor deviation	

DTC (displayed on SUZUKI scan tool)	Diagnostic Items	
 C1041	RF	Inlet solenoid
 C1045	LF	
 C1051	RR	
 C1055	LR	
 C1042	RF	Outlet solenoid
 C1046	LF	
 C1052	RR	
 C1056	LR	
 C1057	Power supply voltage too high / too low	
 C1061	Pump motor circuit	
 C1063	Solenoid valve power supply driver circuit	
 C1071	Control module internal defect	

DTC Clearance

S7RW0C4504006

⚠ WARNING

When performing a driving test, select a safe place where there is neither any traffic nor any traffic accident possibility and be very careful during testing to avoid occurrence of an accident.

After repair or replace malfunction part(s), clear all DTCs by performing the following procedure or using SUZUKI scan tool.

- 1) Connect SUZUKI scan tool to data link connector in the same manner as when making this connection for DTC check.
- 2) Turn ignition switch to ON position.
- 3) Erase DTC according to instructions displayed on scan tool. Refer to scan tool operator's manual for further details.

NOTE

For DTC C1022, C1026, C1032, C1036 and C1061, confirm that ABS warning light turns off after performing Step 2 of "Test Driving" under "ABS Check", and then clear the DTCs.

- 4) After completing the clearance, turn ignition switch OFF and disconnect scan tool from data link connector.
- 5) Perform "Driving Test" (Step 2 of "ABS Check") and "DTC Check" and confirm that NO DTC is displayed on scan tool.

Scan Tool Data

S7RW0C4504007

The parameter data below are values measured with the scan tool when the normally operating vehicle is under the following conditions. When taking measurements for comparison by using the scan tool, be sure to check that the vehicle is under the following conditions.

- Apply parking brake and block wheels.
- Ignition switch ON.
- Turn OFF air conditioner (if equipped).
- Apply no load to power steering (if equipped). (Don't turn it)
- Turn OFF all electric loads (except ignition).
- No DTC.
- ABS is not operated. (Normal braking operation)

Scan Tool Data		Standards	Condition
🔧 Battery Voltage		10.0 – 16.0 V	—
🔧 Pump Motor Driver		0.0 V	—
🔧 RF Wheel Speed		0 km/h, 0.0 MPH	Vehicle stop
🔧 LF Wheel Speed		0 km/h, 0.0 MPH	Vehicle stop
🔧 RR Wheel Speed		0 km/h, 0.0 MPH	Vehicle stop
🔧 LR Wheel Speed		0 km/h, 0.0 MPH	Vehicle stop
🔧 Brake Switch		ON	Brake pedal depressed
		OFF	Brake pedal released
🔧 G sensor		0.00G (4WD model)	Place vehicle on the level
		2.54G (2WD model)	Place vehicle on the level
🔧 Solenoid Valve Power Supply Driver		ON	Ignition switch ON
🔧 Inlet Solenoid	RF	OFF	Vehicle stop
	LF		
	RR		
	LR		
🔧 Outlet Solenoid	RF	OFF	Vehicle stop
	LF		
	RR		
	LR		

Scan Tool Data Definition**Battery Volt (V)**

Battery Voltage is an analog input signal read by the ABS control module. Certain ABS control module functions will be modified if the battery voltage falls below or rises above programmed thresholds.

Pump Motor Driver (V)

This parameter indicates the operational condition of the pump motor driver (transistor).

RF Wheel Speed, LF Wheel Speed, RR Wheel Speed and LR Wheel Speed (km/h, MPH)

Wheel speed is an ABS control module internal parameter. It is computed by reference pulses from the wheel speed sensor.

Brake Switch (ON, OFF)

This switch signal informs the ABS control module whether the brake is active or not.

G Sensor (G)

4WD model: Vehicle acceleration is measured by G sensor and output to ABS control module as the linear voltage.

2WD model: Fixed 2.54 G.

Solenoid Valve Power Supply Driver (ON, OFF)

ABS control module monitor the supply voltage to solenoid valve power supply driver. If the voltage is supplied, ON is displayed. Beside, OFF is displayed.

Inlet Solenoid RF, Inlet Solenoid LF, Inlet Solenoid RR, Inlet Solenoid LR (ON, OFF)

This parameter indicates the operational condition of the inlet solenoid valve.


Outlet Solenoid RF, Inlet Solenoid LF, Inlet Solenoid RR, Inlet Solenoid LR (ON, OFF)

This parameter indicates the operational condition of the outlet solenoid valve.

ABS Warning Light Does Not Come ON at Ignition Switch ON

S7RW0C4504008

Wiring Diagram



I6RW0C450002-01

[A]: ABS control module connector (viewed from terminal side)	7. EBD warning light (brake warning light)
[B]: Combination meter connector (viewed from terminal side)	8. Light driver module
[C]: BCM (viewed from harness side)	9. CAN driver
1. Battery	10. BCM
2. Main fuse box	11. Brake fluid level switch
3. Ignition switch	12. Parking brake switch
4. Junction block assembly	13. ABS hydraulic unit / control module assembly
5. Combination meter	14. CAN junction connector
6. ABS warning light	

Circuit Description

ABS control module transmits indication ON signal of ABS warning light to combination meter in order to turn ABS warning light ON. And then, combination meter turns ABS warning light ON.

If the ABS is in good condition, ABS control module transmits indication ON signal to combination meter in order to turn ABS warning light ON at the ignition switch ON, keeps it ON for 2 seconds and then turns it OFF. If an abnormality in the system is detected, ABS warning light is turned ON continuously by ABS control module. Also, it is turned ON continuously by light driver module when ABS control module connector is disconnected.

Troubleshooting

Step	Action	Yes	No
1	Warning light check 1) Turn ignition switch to ON position. <i>Do other warning lights come ON?</i>	Substitute a known-good combination meter and recheck. If warning light remains OFF, substitute a known-good ABS hydraulic unit / control module assembly and recheck.	Go to Step 2.
2	Fuse check <i>Is circuit fuse for combination meter in good condition?</i>	Go to Step 3.	Replace fuse and check for short circuit to ground.
3	Combination meter power source circuit check 1) Remove combination meter with ignition switch turned OFF. 2) Check for proper connection to "RED/BLK" and "BLK" wire of combination meter connector. 3) If OK then turn ON ignition switch and measure voltage at "RED/BLK" wire of combination meter connector and vehicle body ground. <i>Is it 10 – 14 V?</i>	Go to Step 4.	Repair power source circuit for combination meter.
4	Combination meter ground circuit check 1) Measure resistance between "BLK" wire of combination meter connector and vehicle body ground. <i>Is resistance less than 2 Ω?</i>	Substitute a known-good combination meter and recheck.	"BLK" circuit open or high resistance.

ABS Warning Light Comes ON Steady

S7RW0C4504009

Wiring Diagram

Refer to "Warning Diagram" under "ABS Warning Light Does Not Come ON at Ignition Switch ON".

Circuit Description

Refer to "Circuit Description" under "ABS Warning Light Does Not Come ON at Ignition Switch ON".

Troubleshooting

Step	Action	Yes	No
1	DTC check 1) Perform diagnostic trouble code check. <i>Is there any DTC(s)?</i>	Go to Step 7 of "ABS Check".	Go to Step 2.
2	ABS hydraulic unit / control module assembly power and ground circuit check 1) Check that ABS hydraulic unit / control module assembly power supply circuit and ground circuit is in good condition referring to "ABS Hydraulic Unit / Control Module Assembly Power and Ground Circuit Check". <i>Are check results OK?</i>	Go to Step 3.	Repair ABS hydraulic unit / control module assembly power or ground circuit.

Step	Action	Yes	No
3	CAN communication line circuit check 1) Turn ignition switch to OFF position. 2) Disconnect connectors of all control modules communicating by means of CAN. 3) Check for proper connection to CAN communication line wire. 4) If OK then check CAN communication line circuit between control modules for open, short and high resistance. <i>Is each CAN communication line circuit in good condition?</i>	Substitute a known-good combination meter and recheck. If warning light remains ON, substitute a known-good ABS hydraulic unit / control module assembly and recheck.	Repair circuit and recheck.

EBD Warning Light (Brake Warning Light) Comes ON Steady

S7RW0C4504010

Wiring Diagram

Referring to "Wiring Diagram" under "ABS Warning Light Does Not Come ON at Ignition Switch ON".

Circuit Description

EBD warning light (brake warning light) is controlled by ABS control module and BCM through light driver module in combination meter.

If EBD system is in good condition, ABS control module turns EBD warning light ON at the ignition switch ON, keeps it ON for 2 seconds and then turns it OFF.

EBD warning light is turned ON continuously at the following conditions.

- EBD system is an abnormality
- Connector of ABS control module is disconnected
- Parking brake switch is ON
- Brake fluid level is lower than minimum level

The information of parking brake switch and brake fluid level are transmitted from BCM to light driver module in combination meter through CAN communication line.

Troubleshooting


Step	Action	Yes	No
1	Parking brake and brake fluid level check 1) Make sure that: • Parking brake is completely released. • Brake fluid level is upper than the minimum level. <i>Are the check results OK?</i>	Go to Step 2.	Release parking brake completely and/or replenish brake fluid.
2	ABS warning light operation check 1) Turn ignition switch to ON position. <i>Does ABS warning light come on steady?</i>	Perform "ABS Warning Light Comes ON Steady" previously outlined.	Go to Step 3.
3	Parking brake switch circuit and brake fluid level switch circuit check 1) Release parking brake completely, and replenish brake fluid. 2) Disconnect BCM connectors with ignition switch turned OFF. 3) Measure resistance between each terminal of "E04-5", "L01-6" and vehicle body ground. <i>Are resistance $\infty \Omega$?</i>	Go to Step 4.	Check each applicable circuit for short to vehicle body ground. If OK then check parking brake switch and/or brake fluid level switch.

Step	Action	Yes	No
4	DTC check of BCM 1) Connect scan tool to data link connector with ignition switch turned OFF. 2) Turn ignition switch to ON position and check DTC of BCM. <i>Is there DTC U0073?</i>	Go to "DTC U0073 (No. 0073): Control Module Communication Bus Off in Section 10B".	Go to Step 5.
5	CAN communication line circuit check 1) Turn ignition switch to OFF position. 2) Disconnect connectors of all control modules communicating by means of CAN. 3) Check for proper connection to CAN communication line wire. 4) If OK then check CAN communication line circuit between control modules for open, short and high resistance. <i>Is each CAN communication line circuit in good condition?</i>	Substitute a known-good combination meter and recheck. If EBD warning light remains OFF, substitute a known-good BCM and/or ABS hydraulic unit / control module assembly and recheck.	Repair CAN communication line circuit.

Serial Data Link Circuit Check

S7RW0C4504011

Wiring Diagram



I6RW0C450003-01

[A]: ABS control module connector (viewed from terminal side)	4. Junction block assembly	10. BCM
[B]: BCM connector (viewed from harness side)	5. Combination meter	11. Data link connector (DLC)
[C]: Combination meter connector (viewed from terminal side)	6. ABS warning light	12. ABS hydraulic unit / control module assembly
1. Battery	7. EBD warning light (brake warning light)	13. CAN junction connector

2. Main fuse box	8. Light driver module	14. To BCM, 4WD control module, P/S control module, HVAC control module (auto A/C model) and SDM
3. Ignition switch	9. CAN driver	


Trouble shooting

Step	Action	Yes	No
1	Scan tool communication check <i>Can scan tool communicate with BCM?</i>	Go to Step 2.	Go to Step 3.
2	ABS hydraulic unit / control module assembly power and ground circuit check 1) Check that ABS hydraulic unit / control module assembly power supply circuit and ground circuit is in good condition referring to "ABS Hydraulic Unit / Control Module Assembly Power and Ground Circuit Check". <i>Are check results OK?</i>	Go to Step 3.	Repair ABS hydraulic unit / control module assembly power or ground circuit.
3	Data link connector power source circuit check 1) Disconnect scan tool from data link connector. 2) Check for proper connection to scan tool. 3) If OK then turn ignition switch to ON position, and measure voltage between terminal B of data link connector and vehicle body ground. <i>Is voltage 10 – 12 V?</i>	Go to Step 4.	Terminal B circuit open or shorted to ground.
4	Data link connector ground circuit check 1) Turn ignition switch to OFF position, and measure resistance between the following terminals: • Terminal G of data link connector and vehicle body ground. • Terminal G1 of data link connector and vehicle body ground. <i>Are resistance less than 2 Ω?</i>	Go to Step 5.	Terminal G and/or G1 wire circuit open or high resistance.
5	Serial communication circuit check 1) Turn ignition switch to OFF position. 2) Disconnect connectors of all control modules communicating by serial data circuit. 3) Check proper connection at serial data circuit terminals. 4) If OK, then check for high resistance, open or short to power circuit or ground in serial data circuit. <i>Is check result in good condition?</i>	Go to Step 6.	Repair serial data circuit and recheck.
6	CAN communication line circuit check 1) Disconnect connectors of all control modules communicating by means of CAN. 2) Check for proper connection to CAN communication line wire. 3) If OK then check CAN communication line circuit between control modules for open, short and high resistance. <i>Is each CAN communication line circuit in good condition?</i>	Substitute a known-good ABS hydraulic unit / control module assembly and recheck.	Repair CAN communication line circuit and recheck.

DTC C1013: Control Module Mismatch

S7RW0C4504012

Wiring Diagram



I7RW01450005-04

[A]: ABS control module connector (viewed from terminal side)	3. Ignition switch	6. ABS hydraulic unit / control module assembly
1. Battery	4. Junction block assembly	
2. Main fuse box	5. G sensor (4WD model)	

DTC Detecting Condition and Trouble Area

DTC Detecting Condition	Trouble Area
Abnormal signal is inputted to a no-used terminal of control module while running or wrong ABS control module is installed.	• ABS control module

NOTE

When ABS hydraulic unit / control module assembly for 4WD model is installed to 2WD model, this DTC is set. Replace to the correct ABS hydraulic unit / control module assembly.

Troubleshooting

Step	Action	Yes	No
1	1) Disconnect ABS hydraulic unit / control module connector with ignition switch turned OFF. 2) Turn ignition switch to ON position. 3) Measure voltage between terminal of "E08-6" and vehicle body ground. <i>Is it 0.3 V or more?</i>	"GRN/YEL" wire short to power source circuit.	Substitute a known-good ABS hydraulic unit / control module assembly and recheck.

DTC C1015: G Sensor Circuit (4WD Model)

S7RW0C4504013

Wiring Diagram

Refer to "Wiring Diagram" under "DTC C1013: Control Module Mismatch".

DTC Detecting Condition and Trouble Area

DTC Detecting Condition	Trouble Area
- G sensor signal voltage is out of specified range. - Vehicle behavior and G sensor signal is disagreed.	- G sensor - G sensor circuit - ABS control module

NOTE

When a vehicle is lifted up and its wheel(s) is turned, this DTC is set.
In such case, clear the DTC and check again.


Troubleshooting

Step	Action	Yes	No
1	Was "ABS Check" performed?	Go to Step 2.	Go to "ABS Check".
2	Is G sensor installed its bracket securely?	Go to Step 3.	Tighten G sensor bolt and recheck.
3	G sensor check 1) Disconnect G sensor connector and ABS hydraulic unit / control module connector with ignition switch turned OFF. 2) Check for proper connection to G sensor connector and ABS hydraulic unit / control module terminals of "E08-3" and "E08-6". 3) If OK then check G sensor referring to "G Sensor Inspection (4WD Model)". Is it in good condition?	Go to Step 4.	Replace G sensor.
4	G sensor power source voltage check 1) Turn ignition switch to ON position and measure voltage between "GRN/ORN" terminal of G sensor connector and vehicle body ground. Is it 10 – 14 V?	Go to Step 5.	"GRN/ORN" circuit open.
5	G sensor signal circuit and ground circuit check 1) Measure resistance between following terminals. - Between "E08-3" terminal and "GRN/BLK" terminal of G sensor. - Between "E08-6" terminal and "GRN/YEL" terminal of G sensor. Is each resistance less than 2 Ω ?	Go to Step 6.	"GRN/BLK" and/or "GRN/YEL" wire circuits in open or high resistance.
6	G sensor ground circuit check 1) Connect ABS hydraulic unit / control module connector with ignition switch turned OFF. 2) Turn ignition switch to ON position and measure voltage between "GRN/BLK" terminal of G sensor connector and vehicle body ground. Is it 0 V?	Substitute a known-good ABS hydraulic unit / control module assembly and recheck.	"GRN/BLK" circuit to power circuit.

DTC 1016: Brake Light Switch

S7RW0C4504014

Wiring Diagram



I7RW01450006-05

[A]: ABS control module connector (viewed from terminal side)	3. Ignition switch	6. Brake light
1. Battery	4. Junction block assembly	7. ABS hydraulic unit / control module assembly
2. Main fuse box	5. Brake light switch	8. To ECM and shift lock relay (A/T model)

DTC Detecting Condition and Trouble Area

DTC Detecting Condition	Trouble Area
Brake light switch signal voltage becomes 4.8 – 8.0 V for specified time.	• Brake light circuit • Brake light switch • ABS control module

NOTE


When a vehicle is lifted up and its wheel(s) is turned, this DTC is set.
In such case, clear the DTC and check again.

Troubleshooting

Step	Action	Yes	No
1	Was “ABS Check” performed?	Go to Step 2.	Go to “ABS Check”.
2	Brake light operation check 1) Turn ignition switch to ON position and depress brake pedal. Does brake light turn ON?	Go to Step 3.	Repair brake light switch, brake light and/or brake light circuit and recheck.
3	Brake light switch signal circuit check 1) Disconnect ABS hydraulic unit / control module and brake light switch connector with ignition switch turned OFF. 2) Check for proper connection to “E08-7” terminal of ABS hydraulic unit / control module and “GRN/WHT” wire terminal of brake light switch. 3) If OK then measurer resistance between terminal of “E08-7” and “GRN/WHT” wire terminal of brake light switch connector. Is it less than 2 Ω?	Substitute a known-good ABS hydraulic unit / control module and recheck.	“GRN/WHT” wire open or high resistance.

DTC C1021 / C1022 / C1025 / C1026 / C1031 / C1032 / C1035 / C1036: Wheel Speed Sensor Circuit / Sensor or Encoder

S7RW0C4504015

DTC C1021 / C1025 / C1031 / C1035: Right-Front / Left-Front / Right-Rear / Left-Rear Wheel Speed Sensor Circuit**DTC C1022 / C1026 / C1032 / C1036: Right-Front / Left-Front / Right-Rear / Left-Rear Wheel Speed Sensor or Encoder****Wiring Diagram**

I7RW01450007-03

[A]: ABS control module connector (viewed from terminal side)	4. Junction block assembly	8. Right-rear wheel speed sensor
1. Battery	5. Left-front wheel speed sensor	9. ABS hydraulic unit / control module assembly
2. Main fuse box	6. Right-front wheel speed sensor	
3. Ignition switch	7. Left-rear wheel speed sensor	

DTC Detecting Condition and Trouble Area

DTC Detecting Condition	Trouble Area
C1021, C1025, C1031, C1035: Wheel speed sensor circuit is opened, shorted to power, ground and/or each other circuit. C1022, C1026, C1032, C1036: - Wheel speed is different from other wheel speed (vehicle speed) for more than specified time. - Abnormal wheel speed sensor signal is detected for more than specified time.	- Wheel speed sensor - Wheel speed sensor circuit - Wheel encoder - ABS control module

NOTE

When the vehicle was operated in any of the following ways, one of these DTCs may be set even when the sensor is in good condition. If such possibility is suspected, clear DTC once referring to "DTC Clearance" and after performing the driving test as described in Step 2 of "ABS Check", check whether or not any abnormality exists.

- The vehicle was driven with parking brake pulled.
- Wheel spin occurred while driving.
- Wheel(s) was turned while the vehicle was jacked up.
- The vehicle was stuck.

DTC Troubleshooting

Step	Action	Yes	No
1	Was "ABS Check" performed?	Go to Step 2.	Go to "ABS Check".
2	Check tire condition 1) Check that tire pressure is specifications. <i>Are they in good condition?</i>	Go to Step 3.	Replace tire or adjust tire pressure and recheck.
3	Wheel speed sensor circuit check 1) Disconnect ABS hydraulic unit / control module connector and applicable wheel speed sensor connector with ignition switch turned OFF. 2) Check for proper connection to ABS hydraulic unit / control module connector at applicable terminals and terminals of applicable wheel speed sensor. 3) If OK then check applicable wheel speed sensor circuit for open, short and high resistance. <i>Is each applicable wheel speed sensor circuit in good condition?</i>	Go to Step 4.	Repair circuit and recheck
4	Wheel speed sensor check 1) Inspection applicable wheel speed sensor referring to "Front and Rear Wheel Speed Sensor Inspection". <i>Is it in good condition?</i>	Go to Step 5.	Clean or replace.
5	Wheel speed sensor encoder check 1) Inspection applicable wheel speed sensor encoder referring to "Front Wheel Speed Sensor Encoder On-Vehicle Inspection" and/or "Rear Wheel Speed Sensor Encoder On-Vehicle Inspection". <i>Is it in good condition?</i>	Go to Step 6.	Clean or replace wheel hub assembly.
6	Wheel speed sensor signal check 1) Inspection applicable wheel speed sensor referring to "Front and Rear Wheel Speed Sensor On-Vehicle Inspection". <i>Is it in good condition?</i>	Substitute a known-good wheel hub assembly and recheck. If DTC detected, substitute a known-good ABS hydraulic unit / control module and recheck.	Replace wheel speed sensor and recheck.

DTC C1033: Wheel Speed Sensor Deviation

S7RW0C4504016

Wiring Diagram

Refer to "Wiring Diagram" under "DTC C1021 / C1022 / C1025 / C1026 / C1031 / C1032 / C1035 / C1036: Wheel Speed Sensor Circuit / Sensor or Encoder".

DTC Detecting Condition and Trouble Area


DTC Detecting Condition	Trouble Area
- Three or more sensor signals seem to be effected by temporary failure suspicion at the same time. - One wheel or more are controlled by ABS for more than specified time.	- Wheel speed sensor - Wheel speed sensor circuit - Wheel encoder - ABS control module - Tire (flat tire)

DTC Troubleshooting

Step	Action	Yes	No
1	<i>Was "ABS Check" performed?</i>	Go to Step 2.	Go to "ABS Check".
2	Check DTC for ABS 1) Connect scan tool to DLC with ignition switch turned OFF. 2) Turn ignition switch ON and check DTC for ABS. <i>Is DTC C1021, C1022, C1025, C1026, C1031, C1032, C1035 and/or C1036 detected together?</i>	Go to "DTC C1021 / C1022 / C1025 / C1026 / C1031 / C1032 / C1035 / C1036: Wheel Speed Sensor Circuit / Sensor or Encoder" and recheck.	Go to Step 3.
3	Check tire condition 1) Check that tire pressure is specifications. <i>Are they in good condition?</i>	Go to Step 4.	Replace tire or adjust tire pressure and recheck.
4	Wheel speed sensor circuit check 1) Disconnect ABS hydraulic unit / control module connector and all wheel speed sensor connectors with ignition switch turned OFF. 2) Check for proper connection to ABS hydraulic unit / control module connector and terminals of wheel speed sensor. 3) If OK then check all wheel speed sensors circuit for open, short and high resistance. <i>Are wheel speed sensor circuits in good condition?</i>	Go to Step 5.	Repair circuit and recheck.
5	Wheel speed sensor check 1) Inspection all wheel speed sensors referring to "Front and Rear Wheel Speed Sensor Inspection". <i>Are they in good condition?</i>	Go to Step 6.	Clean or replace.
6	Wheel speed sensor encoder check 1) Inspection all wheel speed sensor encoders referring to "Front Wheel Speed Sensor Encoder On-Vehicle Inspection" and "Rear Wheel Speed Sensor Encoder On-Vehicle Inspection". <i>Are they in good condition?</i>	Go to Step 7.	Clean or replace wheel hub assembly.
7	Wheel speed sensor signal check 1) Inspection all wheel speed sensors referring to "Front and Rear Wheel Speed Sensor On-Vehicle Inspection". <i>Are they in good condition?</i>	Substitute a known-good wheel hub assembly and recheck. If DTC detected, substitute a known-good ABS hydraulic unit / control module and recheck.	Replace wheel speed sensor and recheck.

DTC C1041 / C1042 / C1045 / C1046 / C1051 / C1052 / C1055 / C1056: Inlet / Outlet Solenoid

S7RW0C4504017

DTC C1041 / C1045 / C1051 / C1055: Right-Front / Left-Front / Right-Rear / Left- Rear Inlet Solenoid**DTC C1042 / C1046 / C1052 / C1056: Right-Front / Left-Front / Right-Rear / Left- Rear Outlet Solenoid****Wiring Diagram**

I7RW01450008-02

[A]: ABS control module assembly connector (viewed from terminal side)	4. ABS hydraulic unit / control module assembly
1. Battery	5. Solenoid valve power supply driver (transistor)
2. Main fuse box	6. Solenoid valve driver
3. Solenoid valve	

DTC Detecting Condition and Trouble Area

DTC Detecting Condition	Trouble Area
- Solenoid valve circuit is opened, shorted to power, ground and/or each valve in ABS hydraulic unit / control module assembly. - Mismatching solenoid output and solenoid monitor is detected.	ABS control module


DTC Troubleshooting

Step	Action	Yes	No
1	Was "ABS Check" performed?	Go to Step 2.	Go to "ABS Check".
2	ABS hydraulic unit / control module power source circuit check - Turn ignition switch to OFF position. - Disconnect ABS hydraulic unit / control module connector. - Check for proper connection to ABS hydraulic unit / control module connector at terminal "E08-24" and "E08-23". - If OK, then measure voltage between terminal "E08-24" of module connector and "E08-23". Is it 10 – 14 V?	Substitute a known-good ABS hydraulic unit / control module assembly and recheck.	"WHT/BLU" or "BLK" circuit open or high resistance.

DTC C1057: Power Supply Voltage Too High / Too Low

S7RW0C4504018

Wiring Diagram



I7RW01450009-03

[A]: ABS control module connector (viewed from terminal side)	2. Main fuse box	4. Junction block assembly
1. Battery	3. Ignition switch	5. ABS hydraulic unit control module assembly

DTC Detecting Condition and Trouble Area

DTC Detecting Condition	Trouble Area
ABS control module power supply voltage is too high or too low.	• ABS control module power supply circuit • ABS control module


DTC Troubleshooting

Step	Action	Yes	No
1	Was "ABS Check" performed?	Go to Step 2.	Go to "ABS Check".
2	Check ABS hydraulic unit / control module assembly power and ground circuit 1) Check that ABS hydraulic unit / control module assembly power supply circuit and ground circuit is in good condition referring to "ABS Hydraulic Unit / Control Module Assembly Power and Ground Circuit Check". Are check results OK?	Go to Step 3	Repair ABS hydraulic unit / control module assembly power or ground circuit.
3	ABS hydraulic unit / control module power source voltage check 1) Measure battery voltage with engine running at 3000 rpm. Is voltage 15 V or less?	Substitute a known-good ABS hydraulic unit / control module assembly and recheck.	Check charging system referring to "Generator Test (Overcharged Battery Check) in Section 1J".

DTC C1061: Pump Motor Circuit

S7RW0C4504019

Wiring Diagram



17RW01450010-02

[A]: ABS control module connector (viewed from terminal side)	3. Pump motor driver (transistor)
1. Battery	4. ABS pump motor
2. Main fuse box	5. ABS hydraulic unit / control module assembly

DTC Detecting Condition and Trouble Area


DTC Detecting Condition	Trouble Area
- Defective pump motor and/or motor power supply voltage is too low. - Pump motor circuit in ABS control module is opened, shorted to power or ground circuit.	- Pump Motor and/or Motor Driver power supply circuit - ABS control module

DTC Troubleshooting

Step	Action	Yes	No
1	Was "ABS Check" performed?	Go to Step 2.	Go to "ABS Check".
2	Check ABS hydraulic unit / control module assembly power and ground circuit 1) Check that ABS hydraulic unit / control module assembly power supply circuit and ground circuit is in good condition referring to "ABS Hydraulic Unit / Control Module Assembly Power and Ground Circuit Check". Are check results OK?	Substitute a known-good ABS hydraulic unit / control module assembly and recheck.	Repair ABS hydraulic unit / control module assembly power or ground circuit.

DTC C1063: Solenoid Valve Power Supply Driver Circuit

S7RW0C4504020

Wiring Diagram

I7RW01460015-01

[A]: ABS control module connector (viewed from terminal side)	4. Junction block assembly
1. Battery	5. Solenoid valve power supply driver (transistor)
2. Main fuse box	6. To solenoid valve
3. Ignition switch	7. ABS hydraulic unit / control module assembly

DTC Detecting Condition and Trouble Area

DTC Detecting Condition	Trouble Area
- Solenoid valve power supply driver circuit is opened, shorted to power and ground circuit in ABS control module. - Solenoid valve power supply voltage is too low. - Solenoid valve power supply driver is stuck to ON or OFF position. - Output circuit from control unit is opened or shorted in ABS control module. - Mismatching solenoid output and solenoid monitor is detected.	- Solenoid valve power supply circuit - ABS control module

DTC Troubleshooting

Step	Action	Yes	No
1	Was "ABS Check" performed?	Go to Step 2.	Go to "ABS Check".
2	Check ABS hydraulic unit / control module assembly power and ground circuit 1) Check that ABS hydraulic unit / control module assembly power supply circuit and ground circuit is in good condition referring to "ABS Hydraulic Unit / Control Module Assembly Power and Ground Circuit Check". Are check results OK?	Substitute a known-good ABS hydraulic unit / control module assembly and recheck.	Repair ABS hydraulic unit / control module assembly power or ground circuit.

DTC C1071: Control Module Internal Defect

S7RW0C4504021

DTC Detecting Condition and Trouble Area

DTC Detecting Condition	Trouble Area
ABS control module internal defect is detected.	• ABS control module


DTC Troubleshooting

Step	Action	Yes	No
1	Was “ABS Check” performed?	Go to Step 2.	Go to “ABS Check”.
2	Check ABS hydraulic unit / control module assembly power and ground circuit 1) Check that ABS hydraulic unit / control module assembly power supply circuit and ground circuit is in good condition referring to “ABS Hydraulic Unit / Control Module Assembly Power and Ground Circuit Check”. <i>Are check results OK?</i>	Substitute a known-good ABS hydraulic unit / control module assembly and recheck.	Repair ABS hydraulic unit / control module assembly power or ground circuit.

ABS Hydraulic Unit / Control Module Assembly Power and Ground Circuit Check

S7RW0C4504022

Wiring Diagram



I6RW0C450004-01

[A]: ABS control module connector (viewed from terminal side)	5. ABS hydraulic unit / control module assembly
1. Battery	6. To pump motor driver
2. Main fuse box	7. Solenoid valve power supply driver
3. Ignition switch	8. To solenoid valve
4. Junction block assembly	

Circuit Description

When the ignition switch is turned ON, power supply is supplied to ABS control module. And, power supply is supplied to pump motor and solenoid valve in other line by the switching function in ABS control module.

Troubleshooting

Step	Action	Yes	No
1	Check fuse <i>Are main fuses and circuit fuses for ABS in good condition?</i>	Go to Step 2.	Replace fuse and check for short circuit to ground.
2	Check ABS control module power supply circuit 1) Turn ignition switch to OFF position. 2) Disconnect ABS control module connector. 3) Check for proper connection to ABS control module connector at terminals "E08-9", "E08-23", "E08-24", and "E08-25". 4) If OK, then turn ignition switch to ON position and measure voltage between terminal "E08-9" and vehicle body ground. <i>Is it 10 – 14 V?</i>	Go to Step 3.	"GRN/ORN" circuit open.
3	Pump motor and solenoid valve power supply circuit 1) Turn ignition switch to OFF position. 2) Measure voltage between each terminal of "E08-24", "E08-25" and vehicle body ground. <i>Are they 10 – 14 V?</i>	Go to Step 4.	"WHT/BLU" and/or "WHT/RED" circuit open.
4	Check ABS hydraulic unit / control module assembly ground circuit 1) Measure resistance between terminal "E08-23" and vehicle body ground. <i>Is resistance less than 2 Ω?</i>	ABS hydraulic unit / control module assembly power and ground circuits are in good condition.	"BLK" circuit open or high resistance.

Repair Instructions


ABS Hydraulic Unit Operation Check

S7RW0C4506001

- 1) Check that basic brake system other than ABS is in good condition.
- 2) Check that battery voltage is 11 V or more.
- 3) Hoist vehicle.
- 4) Set transmission to neutral (P range for A/T) and release parking brake.
- 5) Turn each wheel gradually by hand to check if brake dragging occurs. If it does, correct.
- 6) Connect SUZUKI scan tool to data link connector (DLC) (1) with ignition switch OFF.


Special tool

(A): SUZUKI scan tool



I5RW0A450007-01

- 7) Turn ignition switch to ON position and select menu to “HYDRAULIC CONTROL TEST” under “miscellaneous test” (“MISC. TEST”) mode of SUZUKI scan tool.
- 8) Perform the following checks with help of another person.
Brake pedal (1) should be depressed and then select testing wheel by SUZUKI scan tool and the wheel (2) should be turned by another person’s hand. At this time, check that:
- Operation sound of solenoid is heard and the wheel turns only about 0.5 sec. (Brake force is depressurized).
 - Operation sound of pump motor is heard and pulsation is felt at brake pedal.



I4RH01450021-01


- 9) Check for all 4-wheels condition respectively. If a faulty condition is found, replace ABS hydraulic unit / control module assembly.
- 10) After completing the check, turn ignition switch to OFF position and disconnect SUZUKI scan tool from DLC.

ABS Hydraulic Unit / Control Module Assembly Components

S7RW0C4506002

⚠ CAUTION

Never disassemble ABS hydraulic unit / control module assembly, loosen blind plug or remove motor. Performing any of these prohibited services will affect original performance of ABS hydraulic unit / control module assembly.



I6RW0C450006-01

1. ABS hydraulic unit / control module assembly	(a) : 16 N·m (1.6 kgf-m, 11.5 lb-ft)	(c) : 26 N·m (2.6 kgf-m, 19.0 lb-ft)
2. Bracket	(b) : 9 N·m (0.9 kgf-m, 6.5 lb-ft)	

ABS Hydraulic Unit / Control Module Assembly On-Vehicle Inspection

S7RW0C4506003

⚠ CAUTION

Never disassemble ABS hydraulic unit / control module assembly, loosen blind plug or remove motor. Performing any of these prohibited services will affect original performance of ABS hydraulic unit / control module assembly.

Check hydraulic unit for fluid leakage.
If any, repair or replace.

ABS Hydraulic Unit / Control Module Assembly Removal and Installation


S7RW0C4506004

⚠ CAUTION

Never disassemble ABS hydraulic unit / control module assembly, loosen blind plug or remove motor. Performing any of these prohibited services will affect original performance of ABS hydraulic unit / control module assembly.

Removal

- 1) Disconnect negative cable from battery.
- 2) Disconnect ABS hydraulic unit / control module assembly connector (1) by pull up the lock (2).



I5RW0A450001-01

[A]: Disconnect	C: Pull up to disconnect
[B]: Connect	D: Pull down to connect


- 3) Using special tool, loosen flare nuts (1) and disconnect brake pipes (2) from ABS hydraulic unit / control module assembly (3).

Special tool

(A): 09950-78220

NOTE

Put bleeder plug cap or the like onto pipe to prevent fluid from spilling. Do not allow brake fluid to get on painted surfaces.




I5RW0A450020-01

- 4) Remove ABS hydraulic unit / control module with bracket from vehicle by removing two bracket bolts.
- 5) Remove bolt and pull out ABS hydraulic unit / control module assembly (1) from bracket (3) using flat end rod or the like (2).

⚠ CAUTION

- Do not give an impact to hydraulic unit.
- Use care not to allow dust to enter hydraulic unit.
- Do not place hydraulic unit on its side or upside down. Handling it in inappropriate way will affect its original performance.



I5RW0A450021-01

Installation

1) Install hydraulic unit / control module assembly by reversing removal procedure noting the following. Install ABS hydraulic unit / control module assembly bracket bolt as follows.


- Tighten bracket bolt (1) and (2) by hand.
- Then tighten bracket bolt to specified torque.
Tightening order (1) → (2)

Tightening torque

Brake pipe flare nut (a): 16 N·m (1.6 kgf-m, 11.5 lb-ft)

ABS hydraulic unit / control module assembly bolt (b): 9 N·m (0.9 kgf-m, 6.5 lb-ft)

ABS hydraulic unit / control module assembly bracket bolt (c): 26 N·m (2.6 kgf-m, 19.0 lb-ft)



I6RW0C450011-01

- Bleed air from brake system referring to “Air Bleeding of Brake System in Section 4A”.
- Check each installed part for fluid leakage and perform “ABS Hydraulic Unit Operation Check”.

NOTE

For new ABS hydraulic unit / control module assembly, if “ABS Hydraulic Unit Operation Check” has not been performed, ABS warning light may flash when ignition switch is turned ON position. Accordingly preform “ABS Hydraulic Unit Operation Check” to stop flashing of ABS warning light.

Front and Rear Wheel Speed Sensor On-Vehicle Inspection


S7RW0C4506005

Output Voltage Inspection

- Disconnect negative (–) cable from battery.
- Hoist vehicle a little.
- Disconnect wheel speed sensor connector.
- Set up measuring device as shown in figure, the resistance to 115 Ω and the power supply voltage to 12 V.

⚠ CAUTION

Incorrect voltage and/or wrong connection cause damage to wheel speed sensor.



I5JB0A450026-03


1. Wheel speed sensor connector	4. “BLK” wire terminal
2. Resistance (115 Ω)	5. Power supply (12 V)
3. “WHT” wire terminal	

- 5) Measure voltage at resistance without wheel rotation. If voltage is out of specification, check sensor, mating encoder and their installation conditions.

Voltage at the resistance (115 Ω) without wheel rotation
680 – 960 mV

- 6) Measure voltage at resistance with wheel rotation and confirm voltage alternately changes between high and low voltages. If voltage does not change with wheel rotation, check sensor, mating encoder and their installation conditions.

Voltage at the resistance (115 Ω) with wheel rotation
High voltage “a”: 1360 – 1930 mV
Low voltage “b”: 680 – 960 mV




Reference

When using oscilloscope for this check, check if peak-to-peak voltage and waveform meet specification.

Peak-to-peak voltage at the resistance (115 Ω) with wheel rotation

High voltage “a”: 1360 to 1930 mV
Low voltage “b”: 680 to 960 mV



Front Wheel Speed Sensor Removal and Installation


S7RW0C4506006

⚠ CAUTION

- Do not pull wire harness when removing and installing front wheel speed sensor.
- Do not cause damage to surface of front wheel speed sensor and do not allow dust, etc. to enter its installation hole.

Removal

- 1) Disconnect negative (–) cable from battery.
- 2) Disconnect front wheel speed sensor connector (1).
- 3) Hoist vehicle and remove wheel.
- 4) Remove harness clamp, clamp bolt (2).
- 5) Remove front wheel speed sensor (3) from knuckle.



I5RW0A450023-01

Installation

- 1) Check that no foreign material is attached to sensor (1) and wheel speed sensor encoder (included in wheel hub assembly).
- 2) Install it by reversing removal procedure.


NOTE

Before fitting wheel speed sensor, be sure to silicon grease to its O-ring.

Tightening torque


Front wheel speed sensor bolt (a): 11 N·m (1.1 kgf-m, 8.0 lb-ft)

Front wheel speed sensor harness clamp bolt (b): 11 N·m (1.1 kgf-m, 8.0 lb-ft)



I5RW0A450025-01

- 3) Check that there is no clearance between sensor and knuckle.



I5RW0A450024-01

[A]: OK


[B]: NG

Front and Rear Wheel Speed Sensor Inspection

S7RW0C4506007

Check sensor for damage.

If any malcondition is found, replace.



I5JB0A450031-01

Rear Wheel Speed Sensor Removal and Installation (4WD Model)

S7RW0C4506008

⚠ CAUTION

Rear wheel speed sensor is included in rear wheel hub assembly. If rear wheel speed sensor needs to be replaced, replace it as a rear wheel hub assembly.

For removal and Installation of rear wheel speed sensor (included in rear wheel hub), refer to "Rear Wheel Hub Assembly Removal and Installation (Rear Drum Brake Model) in Section 2C" or "Rear Wheel Hub Assembly Removal and Installation (Rear Disc Brake Model) in Section 2C".

Rear Wheel Speed Sensor Removal and Installation (2WD Model)

S7RW0C4506009

⚠ CAUTION

- Do not pull wire harness when removing and installing rear wheel speed sensor.
- Do not cause damage to surface of rear wheel speed sensor and do not allow dust, etc. to enter its installation hole.

Removal

- 1) Disconnect negative (–) cable from battery.
- 2) Hoist vehicle, and remove wheel.
- 3) Disconnect rear wheel speed sensor connector.
- 4) Remove harness clamp.
- 5) Remove rear wheel speed sensor from wheel hub.

Installation

- 1) Check that no foreign material is attached to sensor and encoder (included in wheel hub assembly).
- 2) Install it by reversing removal procedure.


NOTE

Before fitting wheel speed sensor, be sure to silicon grease to its O-ring.

Tightening torque

Rear wheel speed sensor bolt: 11 N·m (1.1 kgf-m, 8.0 lb-ft)

- 3) Check that there is no clearance between sensor and wheel hub.



I5RW0A450024-01

[A]: OK

[B]: NG

Front Wheel Speed Sensor Encoder On-Vehicle Inspection


S7RW0C4506010

Before inspecting front wheel speed sensor encoder, remove front drive shaft referring to “Front Drive Shaft Assembly Removal and Installation: Front in Section 3A”.

- Check sensor encoder (1) for crack, damage or deformation.
- Turn wheel and check if sensor encoder rotation is free from eccentricity and looseness.

- Check that no foreign material is attached.

If any faulty is found, clean or replace. Refer to “Front Wheel Hub, Steering Knuckle and Wheel Bearing Removal and Installation in Section 2B”.



I5RW0A450026-01

Front Wheel Speed Sensor Encoder Removal and Installation

S7RW0C4506011

⚠ CAUTION

Front wheel speed sensor encoder is included in front wheel hub assembly. If front wheel speed sensor encoder needs to be replaced, replace it as a front wheel hub assembly.

For removal and installation of front wheel hub assembly, referring to “Front Wheel Hub, Steering Knuckle and Wheel Bearing Removal and Installation in Section 2B”.

Rear Wheel Speed Sensor Encoder On-Vehicle Inspection

S7RW0C4506012

For 2WD model

Before inspecting rear wheel speed sensor encoder, remove rear wheel speed sensor referring to “Rear Wheel Speed Sensor Removal and Installation (2WD Model)”.

- Check encoder (1) for crack, damage or deformation.
- Turn wheel and check if encoder rotation is free from eccentricity and looseness.

- Check that no foreign material is attached.

If any faulty is found, clean or replace. Refer to “Rear Wheel Hub Assembly Removal and Installation (Rear Drum Brake Model) in Section 2C” or “Rear Wheel Hub Assembly Removal and Installation (Rear Disc Brake Model) in Section 2C”.

Rear Wheel Speed Sensor Encoder Removal and Installation

S7RW0C4506013

⚠ CAUTION

Rear wheel speed sensor encoder is included in rear wheel hub assembly. If rear wheel speed sensor encoder needs to be replaced, replace it as a rear wheel hub assembly.

For removal and installation of rear wheel hub assembly, referring to “Rear Wheel Hub Assembly Removal and Installation (Rear Drum Brake Model) in Section 2C” or “Rear Wheel Hub Assembly Removal and Installation (Rear Disc Brake Model) in Section 2C”.

G Sensor Removal and Installation (4WD Model)


S7RW0C4506014

⚠ CAUTION


- Do not drop and shock G sensor. It will affect its original performance.
- Regarding G sensor removal and installation, confirm specified torque and use hand tool to avoid damage.

Removal

- 1) Disconnect negative (–) cable from battery.
- 2) Remove center console box.
- 3) Disconnect G sensor connector, and remove G sensor (1).

**Installation**

- 1) Install G sensor (1), and connect G sensor connector.

Tightening torque**G sensor bolt (a): 3.0 N·m (0.3 kgf-m, 2.2 lb-ft)**

- 2) Install center console box.
- 3) Connect negative cable to battery.


G Sensor Inspection (4WD Model)

S7RW0C4506015

Connect positive cable of 12 V battery to “A” terminal of sensor and ground cable to “C” terminal.

Then using voltmeter, check voltage between terminals “B” and “C”.

If measured voltage is not as specified, replace G sensor.

G sensor specification**When placed horizontally: 2 – 3 V****When placed upright with arrow upward: 3 – 4 V****When placed upright with arrow downward: 1 – 2 V**

I5RW0A450029-01

[A]: Horizontal	[C]: Upright with arrow downward
[B]: Upright with arrow upward	

Specifications

Tightening Torque Specifications

S7RW0C4507001

Fastening part	Tightening torque			Note
	N·m	kgf·m	lb·ft	
Brake pipe flare nut	16	1.6	11.5	🔧
ABS hydraulic unit / control module assembly bolt	9	0.9	6.5	🔧
ABS hydraulic unit / control module assembly bracket bolt	26	2.6	19.0	🔧
Front wheel speed sensor bolt	11	1.1	8.0	🔧
Front wheel speed sensor harness clamp bolt	11	1.1	8.0	🔧
Rear wheel speed sensor bolt	11	1.1	8.0	🔧
G sensor bolt	3.0	0.3	2.2	🔧

NOTE

The specified tightening torque is also described in the following.
“ABS Hydraulic Unit / Control Module Assembly Components”


Reference:

For the tightening torque of fastener not specified in this section, refer to “Fasteners Information in Section 0A”.

Special Tools and Equipment

Special Tool

S7RW0C4508001

09950-78220 Flare nut wrench (10 mm) 🔧 	SUZUKI scan tool — This kit includes following items. 1. Tech 2, 2. PCMCIA card, 3. DLC cable, 4. SAE 16/19 adapter, 5. Cigarette cable, 6. DLC loop back adapter, 7. Battery power cable, 8. RS232 cable, 9. RS232 adapter, 10. RS232 loop back connector, 11. Storage case, 12. 🔧 / 🔧 
--	--

Section 5

Transmission / Transaxle

CONTENTS

Precautions	5-1	Stall Test	5A-26
Precautions.....	5-1	Time Lag Test	5A-27
Precautions on Transmission / Transaxle.....	5-1	Line Pressure Test	5A-28
Automatic Transmission/Transaxle	5A-1	Engine Brake Test.....	5A-29
Precautions.....	5A-1	“P” Range Test.....	5A-29
Precautions in Diagnosing Trouble	5A-1	A/T Symptom Diagnosis.....	5A-30
General Service Procedure Information.....	5A-1	Transmission Warning Light Circuit Check –	
Precautions for Disassembly and		Light Does Not Come “ON” at Ignition Switch	
Reassembly	5A-1	ON (Non-Euro-OBd Model)	5A-33
General Description	5A-2	Transmission Warning Light Circuit Check –	
A/T Description	5A-2	Light Remains “ON” at Ignition Switch ON	
Clutch / Brake / Planetary Gear Function of		(Non-Euro-OBd Model).....	5A-33
Automatic Transaxle	5A-6	DTC P0705: Transmission Range Sensor	
Table of Component Operation.....	5A-7	Circuit Malfunction (P R N D L Input).....	5A-34
Operation of Shift Solenoid Valves and TCC		DTC P0707: Transmission Range Sensor	
Solenoid Valve	5A-7	Circuit Low	5A-35
Automatic Gear Shift Table	5A-7	DTC P0711: Transmission Fluid Temperature	
Brake Interlock System Construction	5A-9	Sensor “A” Circuit Range / Performance.....	5A-37
A/T Diagnosis General Description	5A-9	DTC P0712: Transmission Fluid Temperature	
On-Board Diagnostic System Description.....	5A-10	Sensor “A” Circuit Low	5A-38
CAN Communication System Description.....	5A-10	DTC P0713: Transmission Fluid Temperature	
Schematic and Routing Diagram.....	5A-11	Sensor “A” Circuit High	5A-39
Electronic Shift Control Input / Output		DTC P0717: Input Speed Sensor “A” Circuit	
Diagram	5A-11	No Signal.....	5A-40
Transmission Control Module (TCM) Wiring		DTC P0722: Output Speed Sensor Circuit No	
Diagram	5A-12	Signal	5A-42
Component Location	5A-13	DTC P0741 / P0742: Torque Converter	
Electronic Shift Control System Components		Clutch Circuit Performance or Stuck OFF /	
Location	5A-13	Stuck ON.....	5A-43
Diagnostic Information and Procedures	5A-14	DTC P0751 / P0752: Shift Solenoid “A”	
A/T System Check	5A-14	Performance or Stuck OFF / Shift Solenoid	
Visual Inspection	5A-16	“A” Stuck ON	5A-44
Malfunction Indicator Lamp (MIL) Check	5A-17	DTC P0756 / P0757: Shift Solenoid “B”	
Transmission Warning Light Check (Non-		Performance or Stuck OFF / Shift Solenoid	
Euro-OBd Model)	5A-17	“B” Stuck ON	5A-45
DTC Table.....	5A-17	DTC P0961: Pressure Control Solenoid “A”	
DTC Check	5A-19	Control Circuit Range / Performance	5A-46
DTC Clearance	5A-20	DTC P0962: Pressure Control Solenoid “A”	
Fail Safe Table	5A-20	Control Circuit Low.....	5A-47
Scan Tool Data	5A-21	DTC P0963: Pressure Control Solenoid “A”	
A/T Basic Check	5A-23	Control Circuit High.....	5A-48
Road Test	5A-24	DTC P0973 / P0976: Shift Solenoid “A”	
Manual Road Test.....	5A-25	Control Circuit Low / Shift Solenoid “B”	
		Control Circuit Low.....	5A-49

DTC P0974 / P0977: Shift Solenoid “A” Control Circuit High / Shift Solenoid “B” Control Circuit High	5A-51	Automatic Transaxle Unit Dismounting and Remounting	5A-80
DTC P0602 / P1702: Control Module Programming Error / Internal Control Module Check Sum Error	5A-52	Automatic Transaxle Assembly Components	5A-82
DTC P1723: Range select switch malfunction ..	5A-53	Automatic Transaxle Unit Disassembly	5A-85
DTC P2763: Torque Converter Clutch Pressure Control Solenoid Control Circuit High	5A-54	Oil Pump 2nd Coast Brake and 2nd Brake Components	5A-92
DTC P2764: Torque Converter Clutch Pressure Control Solenoid Control Circuit Low	5A-55	2nd Coast Brake and 2nd Brake Preliminary Check	5A-93
DTC U0073: Control Module Communication Bus Off	5A-56	Oil Pump, 2nd Coast Brake and 2nd Brake Disassembly and Reassembly	5A-93
DTC U0100: Lost Communication with ECM ..	5A-56	Oil Pump, 2nd Brake and 2nd Coast Brake Inspection	5A-98
Inspection of TCM and Its Circuits	5A-57	One-Way No. 1 Clutch Components	5A-100
TCM Power and Ground Circuit Check	5A-61	One-Way No. 1 Clutch Operation Check	5A-100
Brake Interlock System Inspection	5A-63	One-Way No. 1 Clutch Disassembly and Reassembly	5A-100
Repair Instructions	5A-64	One-Way No. 1 Clutch Inspection	5A-101
A/T Fluid Level Check	5A-64	Forward and Direct Clutch Components	5A-102
A/T Fluid Change	5A-64	Forward and Direct Clutch Preliminary Check ..	5A-103
Select Lever Components	5A-65	Forward and Direct Clutch Disassembly and Reassembly	5A-103
Select Lever Assembly Removal and Installation	5A-65	Forward and Direct Clutch Inspection	5A-107
Select Lever Knob Installation	5A-65	1st / Reverse Brake and One-Way No. 2 Clutch Components	5A-108
Select Lever Inspection	5A-65	1st / Reverse Brake and One-Way No. 2 Clutch Operation Check	5A-109
“3” Position Switch Inspection	5A-66	1st / Reverse Brake and One-Way No. 2 Clutch Disassembly and Reassembly	5A-109
Shift Lock Solenoid Inspection	5A-66	1st / Reverse Brake and One-Way No. 2 Clutch Inspection	5A-110
Shift Lock Solenoid Replacement	5A-66	Underdrive Clutch and One-Way No. 3 Clutch Components	5A-111
Select Cable Components	5A-67	Underdrive Clutch and One-Way No. 3 Clutch Preliminary Check	5A-112
Select Cable Removal and Installation	5A-67	Underdrive Clutch and One-Way No. 3 Clutch Operation Check	5A-112
Select Cable Adjustment	5A-67	Underdrive Clutch and One-Way No. 3 Clutch Disassembly and Reassembly	5A-112
Key Interlock Cable Removal and Installation ..	5A-68	Underdrive Clutch and One-Way No. 3 Clutch Inspection	5A-115
Transmission Range Sensor Inspection and Adjustment	5A-70	Planetary Gear Components	5A-116
Output Shaft Speed Sensor Removal and Installation	5A-71	Planetary Gear Disassembly and Reassembly	5A-117
Output Shaft Speed Sensor Inspection	5A-72	Planetary Gear Inspection	5A-117
Input Shaft Speed Sensor Removal and Installation	5A-72	Underdrive Brake Components	5A-118
Input Shaft Speed Sensor Inspection	5A-72	Underdrive Brake Disassembly and Reassembly	5A-118
Transmission Fluid Temperature Sensor Removal and Installation	5A-72	Underdrive Brake Inspection	5A-119
Transmission Fluid Temperature Sensor Inspection	5A-73	Reduction Drive Gear Assembly Operation Check	5A-119
Solenoid Valves (Shift Solenoid Valves, TCC Solenoid Valve and Pressure Control Solenoid Valve) Removal and Installation	5A-73	Underdrive Gear Assembly Components	5A-120
Solenoid Valves (Shift Solenoid Valves and TCC Solenoid Valve) Inspection	5A-75	Underdrive Gear Preliminary Check	5A-120
Pressure Control Solenoid Valve Inspection	5A-77	Valve Body Assembly Components	5A-121
Transmission Control Module (TCM) Removal and Installation	5A-78	Valve Body Assembly Disassembly and Reassembly	5A-122
Differential Side Oil Seal Replacement	5A-78	Differential Components	5A-123
A/T Fluid Cooler Hoses Inspection	5A-79	Differential Preliminary Check	5A-123
A/T Fluid Cooler Hoses Replacement	5A-79	Differential Gear Assembly Removal and Installation	5A-124
A/T Relay Inspection	5A-79	Transaxle Rear Cover Components	5A-126
Automatic Transaxle Unit Components	5A-80		

Transaxle Rear Cover Disassembly and Reassembly	5A-126	Gear Shift Shaft Components	5B-36
Transaxle Rear Cover Inspection.....	5A-127	5th and Reverse Gear Shift Shafts Disassembly and Reassembly	5B-36
Automatic Transaxle Unit Assembly	5A-127	Gear Shift Shaft and Fork Inspection	5B-36
Specifications	5A-139	Differential Components.....	5B-37
Bearing and Race Installation Specification....	5A-139	Differential Disassembly and Reassembly	5B-37
Tightening Torque Specifications.....	5A-140	Specifications	5B-39
Special Tools and Equipment	5A-141	Tightening Torque Specifications.....	5B-39
Recommended Service Material	5A-141	Special Tools and Equipment	5B-40
Special Tool	5A-141	Recommended Service Material	5B-40
Manual Transmission/Transaxle	5B-1	Special Tool	5B-40
General Description	5B-1	Clutch	5C-1
Manual Transaxle Construction	5B-1	General Description	5C-1
Diagnostic Information and Procedures	5B-6	Clutch (Hydraulic Type) Construction	5C-1
Manual Transaxle Symptom Diagnosis.....	5B-6	Diagnostic Information and Procedures	5C-2
Repair Instructions	5B-6	Clutch System Symptom Diagnosis	5C-2
Manual Transaxle Oil Level Check	5B-6	Repair Instructions	5C-3
Manual Transaxle Oil Change	5B-7	Clutch Pedal Inspection	5C-3
Differential Side Oil Seal Replacement.....	5B-8	Clutch Fluid Level Inspection	5C-3
Gear Shift Control Lever and Cable Components.....	5B-9	Air Bleeding of Clutch System.....	5C-4
Gear Shift Control Lever and Cable Removal and Installation.....	5B-10	Clutch Pedal Position (CPP) Switch Removal and Installation	5C-4
Gear Select Control Cable Adjustment.....	5B-10	Clutch Pedal Position (CPP) Switch Inspection and Adjustment.....	5C-5
Back Up Light Switch Removal and Installation	5B-11	Clutch Fluid Pipe and Hose Components	5C-5
Back Up Light Switch Inspection.....	5B-11	Clutch Fluid Pipe Removal and Installation.....	5C-6
Manual Transaxle Unit Components.....	5B-12	Clutch Fluid Pipe Inspection.....	5C-6
Manual Transaxle Unit Dismounting and Remounting.....	5B-13	Clutch Master Cylinder Removal and Installation	5C-6
Gear Shift and Select Shaft Assembly Components.....	5B-14	Clutch Operating Cylinder Assembly Removal and Installation.....	5C-7
Gear Shift and Select Shaft Assembly Removal and Installation.....	5B-15	Clutch Operating Cylinder Assembly Inspection.....	5C-8
Gear Shift and Select Shaft Assembly Disassembly and Reassembly	5B-16	Clutch Cover, Clutch Disc and Flywheel Components.....	5C-8
Manual Transaxle Assembly Components.....	5B-17	Clutch Cover, Clutch Disc and Flywheel Removal and Installation.....	5C-9
Fifth Gear Disassembly and Reassembly	5B-18	Clutch Cover and Clutch Disc Inspection	5C-11
Manual Transaxle Assembly Disassembly and Reassembly	5B-20	Specifications	5C-11
Right Case Disassembly and Reassembly	5B-25	Tightening Torque Specifications.....	5C-11
Left Case Disassembly and Reassembly.....	5B-26	Special Tools and Equipment	5C-12
Input Shaft and Countershaft Components.....	5B-28	Recommended Service Material	5C-12
Input Shaft Disassembly and Reassembly.....	5B-29	Special Tool	5C-12
Countershaft Disassembly and Reassembly	5B-32		

Precautions

Precautions

Precautions on Transmission / Transaxle

S7RW0C5000001

Air Bag Warning

Refer to “Air Bag Warning in Section 00”.

Precautions in Diagnosing Trouble

Refer to “Precautions in Diagnosing Trouble in Section 5A”.

Precautions for Disassembly and Reassembly

Refer to “Precautions for Disassembly and Reassembly in Section 5A”.

Precaution on CAN Troubleshooting

Refer to “Precaution on CAN Troubleshooting in Section 1A”.

Automatic Transmission/Transaxle

Precautions

Precautions in Diagnosing Trouble

S7RW0C5100001

- Don't disconnect couplers from TCM, battery cable from battery, TCM ground wire harness from engine or main fuse before checking the diagnosis information (DTC, freeze frame data, etc.) stored in TCM memory. Such disconnection will clear memorized information in TCM memory.
- Diagnostic information stored in TCM memory can be cleared as well as checked by using SUZUKI scan tool or CAN communication OBD generic scan tool. Before using scan tool, read its Operator's (Instruction) Manual carefully to have good understanding as to what functions are available and how to use it.
It is indistinguishable which module turns on MIL because not only ECM but also TCM turns on MIL. Therefore, check both ECM and TCM for DTC when MIL lights on.
When checking TCM for DTC, keep in mind that DTC is displayed on the scan tool as follows depending on the scan tool used.
 - SUZUKI scan tool displays DTC detected by TCM.
 - CAN communication OBD generic scan tool displays DTC detected by each of ECM and TCM simultaneously.
- Be sure to read "Precautions for Electrical Circuit Service in Section 00" before inspection and observe what is written there.
- TCM replacement
 - When substituting a known-good TCM, check that all relays and actuators have resistance of specified value.
Neglecting this check may result in damage to good TCM.
- Communication of ECM, BCM, combination meter, keyless start control module (if equipped), ABS control module, 4WD control module (if equipped), TCM and DLC, is established by CAN (Controller Area Network). (For more detail of CAN communication system, refer to "CAN Communication System Description"). Therefore, handle CAN communication line with care referring to "Precaution for CAN Communication System in Section 00".

General Service Procedure Information

S7RW0C5100002

When repairing automatic transaxle, it is necessary to conduct the on-vehicle test to investigate where the cause of the trouble lies first.
Then whether overhaul should be done or not is determined. If the transaxle is disassembled without such preliminary procedure, not only the cause of the trouble would be unknown, but also a secondary trouble may occur and often time would be wasted.

Precautions for Disassembly and Reassembly

S7RW0C5100003

As the automatic transaxle consists of high precision component, the following cautions should be strictly observed when handling its parts in disassembly and reassembly.

- Disassembling valve body assembly is prohibited essentially. However, a few parts can be disassembled. When disassembling valve body component parts, confirm whether their parts are allowed to disassemble or not referring to "Valve Body Assembly Disassembly and Reassembly".
- Make sure to wash dirt off from the transaxle so that no such dirt will enter the transaxle during dismounting and remounting.
- Select a clean place free from dust and dirt for overhauling.
- Place a rubber mat on the work bench to protect parts from damage.
- Work gloves or shop cloth should not be used. (Use a nylon cloth or a paper towel.)
- When separating the case joint, do not pry with a screwdriver or such but tap with a plastic hammer lightly.
- Make sure to wash dirt off from the transaxle so that no such dirt will enter the transaxle during disassembly and reassembly.
- Wash the disassembled parts in ATF (Automatic Transaxle Fluid) or kerosene (using care not to allow ATF or kerosene to get on your face, etc.) and confirm that each fluid passage is not clogged by blowing air into it. But use ATF to wash the friction plates resin washers and rubber parts.
- Replace each gasket, oil seal and O-ring with a new one.
- Apply ATF to sliding or rotating parts before reassembly.
- A new friction plates should be soaked in ATF at least 2 hours before use.

Part Inspection and Correction Table

Part	Inspect for	Correction
Casted part, machined part	Small flaw, burr	Remove with oil stone
	Deep or grooved flaw	Replace part
	Clogged fluid passage	Clean with air or wire
	Flaw on installing surface, residual gasket	Remove with oil stone or replace part
	Crack	Replace part
Bearing	Unsmooth rotation	Replace
	Streak, pitting, flaw, crack	Replace
Bushing, thrust washer	Flaw, burr, wear, burning	Replace
Oil seal, gasket	Flawed or hardened seal ring	Replace
	Worn seal ring on its periphery or side	Replace
	Piston seal ring, oil seal, gasket, etc.	Replace
Gear	Flaw, burr	Replace
	Worn gear tooth	Replace
Splined part	Burr, flaw, torsion	Correct with oil stone or replace
Snap ring	Wear, flaw, distortion	Replace
	No interference	Replace
Thread	Burr	Replace
	Damage	Replace
Spring	Settling, sign of burning	Replace
Friction plate	Wear, burning, distortion, damaged claw	Replace
Separator plate, retaining plate	Wear, burning, distortion, damaged claw	Replace
Sealing surface (where lip contacts)	Flaw, rough surface, stepped wear, foreign material	Replace

General Description


A/T Description

S7RW0C5101001

This automatic transaxle is a full automatic type with 4-speed.


The torque converter is a 3-element, 1-step and 2-phase type and is equipped with an electronically controlled lock-up mechanism. The gear shift device consists of 3 sets of planetary gear units, 3 disc type clutches, 3 disc type brakes, a band type brake and 3 one-way clutches. The gear shift is done by selecting one of 7 positions ("P", "R", "N", "D", "3", "2" and "L") by means of the select lever installed on the floor.

2WD



I4RH01510001-01

1. Torque converter clutch (TCC)	7. 1st / reverse brake	13. Countershaft	19. Torque converter
2. One-way No. 1 clutch	8. Rear planetary gear	14. One-way No. 3 clutch	20. Oil pump
3. 2nd coast brake	9. Forward clutch	15. U/D clutch	21. Drive plate mounting nut
4. 2nd brake	10. Direct clutch	16. U/D brake	
5. Counter drive gear	11. Input shaft	17. U/D planetary gear	
6. One-way No. 2 clutch	12. Front planetary gear	18. Differential gear	



I7RW01510061-01


1. Torque converter clutch (TCC)	7. 1st / reverse brake	13. Countershaft	19. Torque converter
2. One-way No. 1 clutch	8. Rear planetary gear	14. One-way No. 3 clutch	20. Oil pump
3. 2nd coast brake	9. Forward clutch	15. U/D clutch	21. Drive plate mounting nut
4. 2nd brake	10. Direct clutch	16. U/D brake	
5. Counter drive gear	11. Input shaft	17. U/D planetary gear	
6. One-way No. 2 clutch	12. Front planetary gear	18. Differential gear	

Specifications

Item		Specifications		
Torque converter	Type	3-element, 1-step, 2-phase type (with TCC (lock-up) mechanism)		
Oil pump	Type	Internal gear type oil pump		
	Drive system	Engine driven		
Gear change device	Type	Forward 4-step, reverse 1-step planetary gear type		
	Shift position	"P" range	Gear in neutral, output shaft fixed, engine start	
		"R" range	Reverse	
		"N" range	Gear in neutral, engine start	
		"D" range	Forward 1st ↔ 2nd ↔ 3rd ↔ 4th automatic gear change	
		"3" range	Forward 1st ↔ 2nd ↔ 3rd ← 4th automatic gear change	
		"2" range	Forward 1st ↔ 2nd ← 3rd automatic gear change	
		"L" range	Forward 1st ← 2nd reduction, and fixed at 1st gear	
	Gear ratio	1st	3.672	
		2nd	2.098	
		3rd	1.391	
		4th (overdrive gear)	1.000	
		Reverse (reverse gear)	4.021	
	Control elements	Wet type multi-disc clutch... 3 sets Band type brake... 1 set Wet type multi-disc brake... 3 sets One-way clutch... 3 sets		
	Reduction gear ratio	0.982		
	Final gear reduction ratio	2.863		
Lubrication	Lubrication system	Forced feed system by oil pump		
Cooling	Cooling system	Radiator assisted cooling (water-cooled)		
Fluid used	An equivalent of DEXRON®-III			

Clutch / Brake / Planetary Gear Function of Automatic Transaxle

S7RW0C5101002



I4RH01510003-01

1. 2nd coast brake	6. One-way No. 2 clutch	11. U/D planetary gear	16. Countershaft
2. 2nd brake	7. Front planetary gear	12. U/D clutch	17. Front differential
3. One-way No. 1 clutch	8. Rear planetary gear	13. One-way No. 3 clutch	
4. Counter drive gear	9. Forward clutch	14. U/D brake	
5. 1st / reverse brake	10. Direct clutch	15. Input shaft	

Functions

Part name	Function
Forward clutch	Meshes input shaft and rear planetary ring gear.
Direct clutch	Meshes input shaft and front and rear planetary sun gears.
U/D clutch	Meshes underdrive planetary carrier and underdrive planetary sun gear.
2nd coast brake	Fixes front and rear planetary sun gears.
2nd brake	Fixes outer race of one-way No. 1 clutch, to prevent front and rear planetary sun gears from turning counterclockwise (reverse direction of engine input rotation direction).
1st / reverse brake	Fixes front planetary ring gear.
U/D brake	Fixes underdrive planetary sun gear.
One-way No. 1 clutch	Prevents front and rear planetary sun gears from turning counterclockwise only when 2nd brake is at work.
One-way No. 2 clutch	Prevents front planetary ring gear from turning counterclockwise.
One-way No. 3 clutch	Prevents underdrive planetary sun gear from turning clockwise.

Table of Component Operation

S7RW0C5101003

		Forward clutch	Direct clutch	U/D clutch	2nd coast brake	2nd brake	1st/reverse brake	U/D brake	One-way No. 1 clutch	One-way No. 2 clutch	One-way No. 3 clutch
P		×	×	×	×	×	×	○	×	×	×
R		×	○	×	×	×	○	○	×	×	×
N		×	×	×	×	×	×	○	×	×	×
D	1st	○	×	×	×	×	×	○	×	○	○
	2nd	○	×	×	○	○	×	○	○	×	○
	3rd	○	×	○	○	○	×	×	○	×	×
	4th	○	○	○	×	○	×	×	×	×	×
2	1st	○	×	×	×	×	×	○	×	○	○
	2nd	○	×	×	○	○	×	○	○	×	○
	3rd	○	×	○	○	○	×	×	○	×	×
L	1st	○	×	×	×	×	○	○	×	○	○
	2nd	○	×	×	○	○	×	○	○	×	○

○: ON

×: OFF

Operation of Shift Solenoid Valves and TCC Solenoid Valve

S7RW0C5101004

Range		D				2			L		R	P & N
Gear		1st	2nd	3rd	4th	1st	2nd	3rd	1st	2nd	Rev	—
Solenoids	Shift solenoid valve-A (No. 1)	×	○	○	×	×	○	○	×	○	×	×
	Shift solenoid valve-B (No. 2)	○	○	×	×	○	○	×	○	○	○	○
	TCC solenoid valve	×	×	(○)	(○)	×	×	×	×	×	×	×

○: ON (Turn power on)

×: OFF (Turn power off)

(○): ON only when lock-up function operates

	Valve status	
	Turn power ON	Turn power OFF
Shift solenoid valve-A (No. 1)	Open	Close
Shift solenoid valve-B (No. 2)	Open	Close
TCC solenoid valve	Close	Open

Automatic Gear Shift Table

S7RW0C5101005

Automatic gear shift schedule is shown in the following table. Test-drive the vehicle on a flat road in the D position.

Euro OBD Model

1. Shift Point in “D”, “3” and/or “2” range

	Throttle opening (%)	Shift	Vehicle speed km/h (mph)	Remark
UP shift	Over 90%	1st → 2nd	56 – 62 (35 – 39)	
		2nd → 3rd	111 – 117 (69 – 73)	
		3rd → 4th	172 – 178 (107 – 111)	
	50%	1st → 2nd	29 – 35 (18 – 22)	
		2nd → 3rd	48 – 54 (30 – 34)	
		3rd → 4th	70 – 76 (43 – 47)	
	10%	1st → 2nd	10 – 16 (6 – 10)	
		2nd → 3rd	22 – 28 (14 – 17)	
		3rd → 4th	39 – 45 (24 – 28)	

5A-8 Automatic Transmission/Transaxle:

	Throttle opening (%)	Shift	Vehicle speed km/h (mph)	Remark
DOWN shift	Over 90%	4th → 3rd	162 – 168 (101 – 104)	
		3rd → 2nd	107 – 113 (66 – 70)	
		2nd → 1st	42 – 48 (26 – 30)	
	50%	4th → 3rd	62 – 68 (39 – 42)	
		3rd → 2nd	25 – 31 (16 – 19)	
		2nd → 1st	8 – 14 (5 – 9)	
	0%	4th → 3rd	22 – 28 (14 – 17)	With applying brake pedal (coast down condition)
		3rd → 2nd	8 – 14 (5 – 9)	
		2nd → 1st	8 – 14 (5 – 9)	

2. Lock-up point in “D” and/or “3” range

	Lock-up clutch status	Throttle opening (%)	Vehicle speed km/h (mph)	Remark
3rd gear lock-up	ON	Over 90%	147 – 153 (91 – 95)	3 range only
		50%	67 – 73 (42 – 45)	
	OFF	Over 90%	122 – 128 (76 – 80)	
		50%	50 – 56 (31 – 35)	
4th gear lock-up	ON	Over 90%	167 – 173 (104 – 108)	
		50%	69 – 75 (43 – 47)	
	OFF	Over 90%	157 – 163 (98 – 101)	
		50%	67 – 73 (42 – 45)	

Non-Euro-OBD Model
1. Shift Point in “D”, “3” and/or “2” range

	Throttle opening (%)	Shift	Vehicle speed km/h (mph)	Remark
UP shift	Over 90%	1st → 2nd	57 – 62 (35 – 39)	
		2nd → 3rd	112 – 117 (70 – 73)	
		3rd → 4th	173 – 178 (108 – 111)	
	50%	1st → 2nd	30 – 35 (19 – 22)	
		2nd → 3rd	48 – 53 (30 – 33)	
		3rd → 4th	71 – 76 (44 – 47)	
	10%	1st → 2nd	14 – 19 (9 – 12)	
		2nd → 3rd	25 – 30 (16 – 19)	
		3rd → 4th	40 – 45 (25 – 28)	
DOWN shift	Over 90%	4th → 3rd	162 – 167 (101 – 104)	
		3rd → 2nd	107 – 112 (66 – 70)	
		2nd → 1st	42 – 48 (26 – 30)	
	50%	4th → 3rd	63 – 68 (39 – 42)	
		3rd → 2nd	25 – 30 (16 – 19)	
		2nd → 1st	8 – 13 (5 – 8)	
	0%	4th → 3rd	23 – 28 (14 – 17)	With applying brake pedal (coast down condition)
		3rd → 2nd	8 – 13 (5 – 8)	
		2nd → 1st	8 – 13 (5 – 8)	

2. Lock-up point in “D” and/or “3” range

	Lock-up clutch status	Throttle opening (%)	Vehicle speed km/h (mph)	Remark
3rd gear lock-up	ON	Over 80%	148 – 153 (92 – 95)	3 range only
		50%	71 – 76 (44 – 47)	
	OFF	Over 85%	123 – 128 (76 – 80)	
		50%	53 – 58 (33 – 36)	
4th gear lock-up	ON	Over 80%	168 – 173 (104 – 108)	
		50%	71 – 76 (44 – 47)	
	OFF	Over 85%	157 – 162 (98 – 101)	
		50%	67 – 72 (42 – 45)	

NOTE

The gear change is done at the shift point different from the above while any of the following control functions is working. Bear this in mind when performing inspection.

- **Slope Shift Control**
When the AT controller makes up-slope judgment, Slope Shift Control (on up-slope) is executed by changing the gear change point to the high-speed side so as to reduce frequent up-shift and downshift operations.
- **Cruise Shift Control**
Cruise Shift Control is executed by selecting appropriate gear according to requirement for retaining a constant vehicle speed or acceleration so as to reduce frequent up-shift and down-shift operations while cruising.

Brake Interlock System Construction


S7RW0C5101006

Shift Lock Solenoid Control

This system consists of shift lock solenoid control system and interlock cable control system. The shift lock solenoid control system is so designed that the select lever can not be shifted from "P" range position unless ignition switch is turned to "ON" or "ACC" position and the brake pedal is depressed. And interlock cable control system is so designed that select lever cannot be shifted from "P" range position unless ignition switch is turned to "ACC" or "ON" position. Also, ignition key cannot be pulled out of key slot unless select lever is in "P" range.

Shift Lock Solenoid Manual Release

Remove plug cap of select lever and push down shift lock solenoid valve release plate (1) inside of plug hole with a slotted head screwdriver or the like. Then, select lever can be moved from "P" range position to another range even without depressing the brake pedal. (To shift select lever from "P" range to any other position, turn ignition switch to ACC or ON position.)



I7RW01510001-01

A/T Diagnosis General Description

S7RW0C5101007

This vehicle is equipped with an electronic transaxle control system, which controls the automatic shift up and shift down timing, TCC operation, etc. suitably to vehicle driving conditions.

TCM has an On-Board Diagnosis System which detects a malfunction in this system.

When diagnosing a trouble in transaxle including this system, be sure to have full understanding of the outline of "On-Board Diagnostic System Description" and each item in "Precautions in Diagnosing Trouble" and execute diagnosis according to "A/T System Check" to obtain correct result smoothly.

NOTE

There are two type of On-Board Diagnostic System, Euro OBD system and non-Euro-OBd system depending on the vehicle specification. For identification, refer to "Precaution on On-Board Diagnostic (OBD) System in Section 1A".

On-Board Diagnostic System Description

S7RW0C5101008


NOTE

There are two types of OBD system depending on the vehicle specification. For identification, refer to "Precaution on On-Board Diagnostic (OBD) System in Section 1A".

For automatic transaxle control system, TCM has following functions.

- For Euro OBD model, when the ignition switch is turned ON with the engine at a stop, MIL (1) turns ON to check the bulb of the MIL.
- For Euro OBD model, when TCM detects a malfunction in A/T control system TCM desires turning on MIL and stores malfunction DTC in TCM memory. (If it detects that continuously 3 driving cycles are normal after detecting a malfunction, however, it makes MIL turn OFF although DTC stored in its memory will remain.)
- For Euro OBD model, it is possible to communicate with TCM through data link connector (DLC) (2) by using not only SUZUKI scan tool (3) but also CAN communication OBD generic scan tool. (Diagnostic information can be checked and erased by using scan tool.)
- For non-Euro-OBD model, when ignition switch is turned ON with no malfunction in A/T control system is detected, transmission warning light (4) lights for about 2 seconds after ignition switch is turned ON and then goes OFF for bulb check.

- For non-Euro-OBD model, when TCM detects a malfunction in A/T control system, it indicates transmission warning light (4) and stores malfunction DTC in its memory.



I6RW0B510001-01

- For information about the following items, refer to "On-Board Diagnostic System Description in Section 1A".
 - Warm-up cycle
 - Driving cycle
 - 2 driving cycle detection logic
 - Pending DTC
 - Freeze frame date

CAN Communication System Description

S7RW0C5101009

Refer to "CAN Communication System Description in Section 1A" for CAN communication System description. TCM communicates control data with each control module as follows.

TCM Transmission Data

Reception unit Transmit data of TCM	ECM	Combination meter	BCM	4WD control module (if equipped)
Transmission warning light signal	○	○		
MIL control signal	○	○		
A/T select lever position signal	○	○	○	○
Transmission actual gear position signal	○			
Transmission oil temperature signal	○			
Torque request signal	○			

I6RW0C510001-02

TCM Reception Data


Reception data from ECM	Engine torque signal
	Accelerator pedal position signal
	Engine speed signal
	Throttle position signal
	A/C compressor clutch signal
	Engine coolant temperature signal
	Vehicle speed pulse signal
	Brake pedal switch signal
	Driving cycle active
	Warm up cycle active

I6RW0C510002-01

Schematic and Routing Diagram

Electronic Shift Control Input / Output Diagram


S7RW0C5102001



I6RW0C510003-01

Transmission Control Module (TCM) Wiring Diagram

S7RW0C5102002



I6RW0C510004-01

[A]: Terminal arrangement of TCM connector (viewed from harness side)	11. Keyless start control module (if equipped)	22. Shift solenoid valve-B (No. 2)
1. TCM	12. Select lever assembly	23. TCC (Lock-up) solenoid valve
2. Input shaft speed sensor	13. "3" position switch	24. Pressure control solenoid
3. Output shaft speed sensor	14. Shift lock solenoid	25. Ignition switch
4. ECM	15. Brake light switch	26. A/T relay
5. ABS control module	16. Backup light	27. Starting motor relay
6. Junction connector	17. Transmission range sensor	28. Inhibitor switch (built-in transmission range sensor)
7. Combination meter	18. Data link connector (DLC)	29. TO BCM
8. Starting motor	19. Automatic transmission	30. To Data link connector
9. BCM	20. Transmission fluid temperature sensor	31. Transmission warning light (non-Euro-OBD model)
10. 4WD control module (if equipped)	21. Shift solenoid valve-A (No. 1)	32. MIL


Component Location

Electronic Shift Control System Components Location

S7RW0C5103001

NOTE

Below figure shows left-hand steering vehicle. For right-hand steering vehicle, parts with (*) are installed at the opposite side.



I6RW0C510005-01

1. Engine	6. A/T relay	11. Output shaft speed sensor	16. Pressure control solenoid
2. Transaxle	7. ECM	12. Input shaft speed sensor	17. TCC solenoid
3. MIL	8. "3" position switch	13. Transmission range sensor	18. Transmission fluid temperature sensor
4. Transaxle select lever position indicator	9. DLC	14. Shift solenoid-A (No. 1)	19. Transmission warning light (non-Euro-OBD model)
5. BCM	10. TCM	15. Shift solenoid-B (No. 2)	

Diagnostic Information and Procedures

A/T System Check

S7RW0C5104001

Refer to the following items for the details of each step.

Step	Action	Yes	No
1	☞ Customer complaint analysis 1) Perform customer complaint analysis. <i>Was customer complaint analysis performed?</i>	Go to Step 2.	Perform customer complaint analysis.
2	☞ DTC / freeze frame data check, record and clearance 1) Check for DTC (including pending DTC). <i>Is there any DTC(s)?</i>	Print DTC and freeze frame data or write them down and clear them by referring to "DTC Clearance". Then go to Step 3.	Go to Step 4.
3	☞ Visual inspection 1) Perform visual inspection. <i>Is there any faulty condition?</i>	Repair or replace malfunction part. Then go to Step 11.	Go to Step 5.
4	☞ Visual inspection 1) Perform visual inspection. <i>Is there any faulty condition?</i>	Repair or replace malfunction part. Then go to Step 11.	Go to Step 8.
5	☞ Trouble symptom confirmation 1) Confirm trouble symptom. <i>Is trouble symptom identified?</i>	Go to Step 6.	Go to Step 7.
6	☞ Rechecking and recording of DTC / freeze frame data 1) Recheck for DTC and freeze frame data referring to "DTC Check". <i>Is there any DTC(s)?</i>	Go to Step 9.	Go to Step 8.
7	☞ Rechecking and recording of DTC / freeze frame data 1) Recheck for DTC and freeze frame data referring to "DTC Check". <i>Is there any DTC(s)?</i>	Go to Step 9.	Go to Step 10.
8	☞ A/T basic check and A/T symptom diagnosis 1) Check and repair according to "A/T Basic Check" and "A/T Symptom Diagnosis". <i>Are check and repair completed?</i>	Go to Step 11.	Check and repair malfunction part(s). Then go to Step 11.
9	☞ Troubleshooting for DTC 1) Check and repair according to applicable DTC flow. <i>Are check and repair completed?</i>	Go to Step 11.	Check and repair malfunction part(s). Then go to Step 11.
10	☞ Check for intermittent problems 1) Check for intermittent problem. <i>Is there any faulty condition?</i>	Repair or replace malfunction part(s). Then go to Step 11.	Go to Step 11.
11	☞ Final confirmation test 1) Clear DTC if any. 2) Perform final confirmation test. <i>Is there any problem symptom, DTC or abnormal condition?</i>	Go to Step 6.	End.

Step 1. Customer Complaint Analysis

Record details of the problem (failure, complaint) and how it occurred as described by the customer.

For this purpose, use of such an inspection form as shown in the following page as an example will facilitate collecting information to the point required for proper analysis and diagnosis.

Customer problem inspection form (Example)

User name:	Model:	VIN:	
Date of issue:	Date of Reg.:	Date of problem:	Mileage:

PROBLEM SYMPTOMS	
☐	Vehicle does not move (R, D, 3, 2, L or any range)
☐	No upshift automatically (☐ 1st to 2nd ☐ 2nd to 3rd ☐ 3rd to 4th ☐ 2 range ☐ 3 range ☐ D range)
☐	No downshift automatically (☐ 3rd to 2nd ☐ 2nd to 1st ☐ 4th to 3rd ☐ 2 range ☐ 3 range ☐ D range)
☐	No gear change manually (☐ 1st ↔ 3rd ☐ 3rd ↔ 4th)
☐	TCC no lock-up ☐ TCC no lock-up off
☐	Automatic shift point too high or too low
☐	Excessive gear change shock (1st/2nd/3rd/4th/Reverse)
☐	No kickdown
☐	Transmission slipping in (1st/2nd/3rd/4th/Reverse)
☐	Others _____

VEHICLE/ENVIRONMENTAL CONDITION WHEN PROBLEM OCCURS	
Environmental Condition	
Weather	☐ Fair ☐ Cloudy ☐ Rain ☐ Always ☐ Other _____
Temperature	(°F/ °C) ☐ Hot ☐ Warm ☐ Cool ☐ Cold ☐ always
Frequency	☐ Always ☐ Sometimes (times/ day, month) ☐ Only once ☐ Under certain condition
Read	☐ Urban ☐ Suburb ☐ Highway ☐ Mountainous ☐ Uphill ☐ Downhill ☐ Tarmacadam
	☐ Gravel ☐ Other _____
Vehicle Condition	
Engine & transmission condition	☐ Cold/ ☐ Warming up phase/ ☐ Warmed up Engine speed (r/min.) Throttle opening (☐ Idle/ ☐ About % ☐ full) “3” position switch (☐ ON/ ☐ OFF)
Vehicle condition	☐ At stop/ ☐ During driving (☐ Constant speed ☐ Accelerating ☐ Decelerating ☐ Braking) ☐ Right hand corner ☐ Left hand corner ☐ Vehicle speed (km/h mile/h) ☐ Other _____

Transmission warning light	☐ Blink ☐ Always ON ☐ Sometimes ON ☐ Always OFF ☐ Good condition
Malfunction indicator lamp	☐ Blink ☐ Always ON ☐ Sometimes ON ☐ Always OFF ☐ Good condition
Diagnostic trouble code	First check: ☐ No code ☐ Malfunction code () Second check: ☐ No code ☐ Malfunction code ()

I7RW01510006-04

NOTE

The form is a standard sample. It should be modified according to conditions characteristic of each market.

Step 2. DTC / Freeze Frame Data Check, Record and Clearance

First, referring to “DTC Check”, check DTC (including pending DTC). If DTC exists, print or write down DTC and freeze frame data and then clear malfunction DTC(s) by referring to “DTC Clearance”. Malfunction DTC indicates malfunction in the system but it is not possible to know from it whether the malfunction is occurring now or it occurred in the past and normal condition has been restored. In order to know that, check symptom in question according to Step 5 and then recheck DTC according to Step 6.

Diagnosing a trouble based on the DTC in this step only or failure to clear the DTC in this step may result in a faulty diagnosis, trouble diagnosis of a normal circuit or difficulty in troubleshooting which is otherwise unnecessary.

Step 3 and 4. Visual Inspection

As a preliminary step, be sure to perform visual check of the items that support proper function of the A/T and engine referring to “Visual Inspection”.

Step 5. Trouble Symptom Confirmation

Check trouble symptoms based on information obtained in Step 1 Customer Complaint Analysis and Step 2 DTC / Freeze Frame Data Check, Record and Clearance. Also, reconfirm DTC according to “DTC Confirmation Procedure” described in each DTC Flow.

Step 6 and 7. Rechecking and Record of DTC

Refer to “DTC Check” for checking procedure.

Step 8. A/T Basic Check and A/T Symptom Diagnosis

Perform basic check of A/T according to “A/T Basic Check” first. When the end of the flow has been reached, check the parts of the system suspected as a possible cause referring to “A/T Symptom Diagnosis” and based on symptoms appearing on the vehicle (symptoms obtained through steps of customer complaint analysis, trouble symptom confirmation and/or A/T basic check) and repair or replace faulty parts, if any.

Step 9. Troubleshooting for DTC

Based on the DTC indicated in Step 6 / 7 and referring to “DTC Table”, locate the cause of the trouble, namely in a sensor, switch, wire harness, connector, actuator, TCM or other part and repair or replace faulty parts.

Step 10. Check for Intermittent Problem

Check parts where an intermittent trouble is easy to occur (e.g. wire harness, connector, etc.), referring to “Intermittent and Poor Connection Inspection in Section 00” and related circuit of DTC recorded in Step 2.

Step 11. Final Confirmation Test

Confirm that the problem symptom has gone and the vehicle is free from any abnormal conditions. If what has been repaired is related to the malfunction DTC, clear the DTC once and check to ensure that no malfunction DTC is indicated.

Visual Inspection

Visually check the following parts and systems.

S7RW0C5104002


Inspection item	Referring section
• A/T fluid – level, leakage, color	“A/T Fluid Level Check”
• A/T fluid hoses – disconnection, looseness, deterioration	“A/T Fluid Cooler Hoses Inspection”
• A/T select cable – installation	“Select Cable Removal and Installation”
• Engine oil – level, leakage	“Engine Oil and Filter Change in Section 0B”
• Engine coolant – level, leakage	“Engine Coolant Change in Section 0B”
• Engine mountings – play, looseness, damage	“Engine Assembly Removal and Installation in Section 1D”
• Suspension – play, looseness	“Suspension, Wheels and Tires Symptom Diagnosis in Section 2A”
• Drive shafts – damage	“Front Drive Shaft Assembly Removal and Installation: Front in Section 3A”
• Battery – indicator condition, corrosion of terminal	
• Connectors of electric wire harness – disconnection, friction	“Electronic Shift Control System Components Location”
• Fuses – burning	
• Parts – installation, damage	
• Bolts – looseness	
• Other parts that can be checked visually	
Also check the following items at engine start, if possible.	
• Malfunction indicator lamp – Operation	“Malfunction Indicator Lamp (MIL) Check”
• Transmission warning light – Operation	“Transmission Warning Light Check (Non-Euro-OBD Model)”
• Charge warning light – Operation	“Generator Symptom Diagnosis in Section 1J”

Inspection item	Referring section
• Engine oil pressure warning light – Operation	“Oil Pressure Warning Light Symptom Diagnosis in Section 9C”
• Engine coolant temp. meter – Operation	
• Other parts that can be checked visually	

Malfunction Indicator Lamp (MIL) Check

S7RW0C5104003

Refer to the same item in “Malfunction Indicator Lamp (MIL) Check in Section 1A” for checking procedure.



I5RW0C510009-01

1. MIL

Transmission Warning Light Check (Non-Euro-OBD Model)

S7RW0C5104004

- 1) Turn ignition switch ON.
- 2) Check that transmission warning light lights for about 2 – 4 sec. and then goes OFF.
If anything faulty is found, advance “Transmission Warning Light Circuit Check – Light Does Not Come “ON” at Ignition Switch ON (Non-Euro-OBD Model)” or “Transmission Warning Light Circuit Check – Light Remains “ON” at Ignition Switch ON (Non-Euro-OBD Model)”.

DTC Table

S7RW0C5104005

NOTE

- There are two types of OBD system depending on the vehicle specification. For identification, refer to “Precaution on On-Board Diagnostic (OBD) System in Section 1A”.
- With the CAN communication OBD generic scan tool, DTC No. with delta (Δ) mark in the following table can not be read.
- A: Driving cycles when MIL lighting and storing DTC in TCM memory for Euro OBD model.
- B: Driving cycles when transmission warning light lighting and storing DTC in TCM memory for non-Euro-OBD model.
- 1 driving cycle: MIL or transmission warning light lights up when DTC is detected during 1 driving cycle.
- 2 driving cycles: MIL or transmission warning light lights up when the same DTC is detected also in the next driving cycle after DTC is detected and stored temporarily in the first driving cycle.
- Driving cycle with (*): MIL or transmission warning light does not light up but TCM detects and stores DTC.

DTC No.	Detecting item	Detecting condition (DTC will set when detecting:)	A	B
Δ P0602	Control Module Programming Error	Data programming error	—	—
P0705	Transmission Range Sensor Circuit Malfunction (P R N D L Input)	Multiple signals are inputted simultaneously from transmission range sensor for 10 seconds or more.	1 driving cycle	1 driving cycle
P0707	Transmission Range Sensor Circuit Low	Transmission range sensor signal (P, R, N, D, 2, or L) is not inputted for more than 30 seconds when vehicle speed is higher than 30 km/h (19 mile/h).	2 driving cycles	2 driving cycles

5A-18 Automatic Transmission/Transaxle:

DTC No.	Detecting item	Detecting condition (DTC will set when detecting:)	A	B
☞ P0711	Transmission Fluid Temperature Sensor "A" Circuit Range/Performance	Transmission fluid temperature is no change and less than 20 °C (68 °F) while vehicle is running at 40 km/h (25 mile/h) or more for 10 minutes or more.	2 driving cycles	2 driving cycles*
☞ P0712	Transmission Fluid Temperature Sensor "A" Circuit Low	Transmission fluid temperature sensor signal voltage is less than specified value for more than 5 minutes while engine is running.	1 driving cycle	1 driving cycle
☞ P0713	Transmission Fluid Temperature Sensor "A" Circuit High	Transmission fluid temperature sensor signal voltage is higher than specified value for 12 minutes while vehicle is running.	1 driving cycle	1 driving cycle
☞ P0717	Input Speed Sensor "A" Circuit No Signal	Pulse signals of input shaft speed sensor are not input although pulse signals of output shaft speed sensor are input while vehicle is running.	1 driving cycle	1 driving cycle
☞ P0722	Output Speed Sensor Circuit No Signal	Pulse signals of output shaft speed sensor are not input although pulse signals of input shaft speed sensor are input while vehicle is running.	1 driving cycle	1 driving cycle
☞ P0741	Torque Converter Clutch Circuit Performance or Stuck Off	Difference between engine speed and input shaft speed is larger than specification while TCC solenoid valve is turned ON.	2 driving cycles	2 driving cycles*
☞ P0742	Torque Converter Clutch Circuit Stuck On	Difference between engine speed and input shaft speed is smaller than specification while TCC solenoid valve is turned OFF.	2 driving cycles	2 driving cycles*
☞ P0751	Shift Solenoid "A" Performance or Stuck Off	Actual gear position is different from commanded gear position of TCM (Shift solenoid valve – A does not turn ON).	2 driving cycles	2 driving cycles*
☞ P0752	Shift Solenoid "A" Stuck On	Actual gear position is different from commanded gear position of TCM (Shift solenoid valve – A does not turn OFF).	2 driving cycles	2 driving cycles*
☞ P0756	Shift Solenoid "B" Performance or Stuck Off	Actual gear position is different from commanded gear position of TCM (Shift solenoid valve – B does not turn ON).	2 driving cycles	2 driving cycles*
☞ P0757	Shift Solenoid "B" Stuck On	Actual gear position is different from commanded gear position of TCM (Shift solenoid valve – B does not turn OFF).	2 driving cycles	2 driving cycles*
☞ P0961	Pressure Control Solenoid "A" Control Circuit Range/Performance	Difference between actual current of pressure control solenoid valve and current of pressure control solenoid valve calculated by TCM is more than specification.	1 driving cycle	1 driving cycle
☞ P0962	Pressure Control Solenoid "A" Control Circuit Low	Value of pressure control solenoid valve output current is too low for 12.5 seconds or more.	1 driving cycle	1 driving cycle
☞ P0963	Pressure Control Solenoid "A" Control Circuit High	Value of pressure control solenoid valve output current is too high for 12.5 seconds or more.	1 driving cycle	1 driving cycle
☞ P0973	Shift Solenoid "A" Control Circuit Low	Difference between command signal and monitor signal of shift solenoid valve – A (shift solenoid valve – A circuit is shorted to ground).	1 driving cycle	1 driving cycle
☞ P0974	Shift Solenoid "A" Control Circuit High	Difference between command signal and monitor signal of shift solenoid valve – A (shift solenoid valve – A circuit is open or shorted to power supply circuit).	1 driving cycle	1 driving cycle
☞ P0976	Shift Solenoid "B" Control Circuit Low	Difference between command signal and monitor signal of shift solenoid valve – B (shift solenoid valve – B circuit is shorted to ground).	1 driving cycle	1 driving cycle
☞ P0977	Shift Solenoid "B" Control Circuit High	Difference between command signal and monitor signal of shift solenoid valve – B (shift solenoid valve – B circuit is open or shorted to power supply circuit).	1 driving cycle	1 driving cycle
☞ P1702	Internal Control Module Memory Check Sum Error	Data write error or check sum error.	1 driving cycle	1 driving cycle

DTC No.	Detecting item	Detecting condition (DTC will set when detecting:)	A	B
 △P1723	Range Select Switch Malfunction	"3" position switch ON signal is inputted although transmission range sensor signal is inputted P, R, N or L range.	1 driving cycle*	1 driving cycle*
 P2763	Torque Converter Clutch Pressure Control Solenoid Control Circuit High	Difference between command signal and monitor signal of TCC lock-up solenoid valve (TCC lock-up solenoid valve circuit is open or shorted to power supply circuit).	1 driving cycle	1 driving cycle
 P2764	Torque Converter Clutch Pressure Control Solenoid Control Circuit Low	Difference between command signal and monitor signal of TCC lock-up solenoid valve (TCC lock-up solenoid valve circuit is shorted to ground).	1 driving cycle	1 driving cycle
 U0073	Control Module Communication Bus Off	Transmission error that is inconsistent between transmission data and transmission monitor (CAN bus monitor) data is detected more than 30 times continuously.	1 driving cycle	1 driving cycle
 U0100	Lost Communication With ECM / PCM "A"	Reception error of communication data for ECM is detected for longer than specified time continuously.	1 driving cycle	1 driving cycle

DTC Check

S7RW0C5104006


NOTE

- There are two types of OBD system depending on the vehicle specification. For identification, refer to "Precaution on On-Board Diagnostic (OBD) System in Section 1A".
- For Euro OBD model, the MIL is turned on when the ECM and/or TCM detect malfunction(s). Each control module stores diagnostic information as the diagnostic trouble code (DTC) in its memory and outputs the DTC to the scan tool. Therefore, check both of the control modules for any DTC with the SUZUKI scan tool because the DTC stored in ECM and TCM is not read and displayed at a time. However, each of the control modules needs not to be checked with the CAN communication OBD generic scan tool because the DTC stored in ECM and TCM is read and displayed at a time. In case using CAN communication OBD generic scan tool, refer to "DTC Table in Section 1A".

- 1) Prepare CAN communication OBD generic scan tool or SUZUKI scan tool.
- 2) Turn ignition switch to OFF position.
- 3) Connect scan tool to data link connector (DLC) (1).

Special tool

(A): SUZUKI scan tool (SUZUKI-SDT)



I5RW0C510072-01

- 4) Turn ignition switch to ON position.
- 5) Read DTC, pending DTC and freeze frame data according to instructions displayed on scan tool and print it down. Refer to scan tool operator's manual for further details.
If communication between scan tool and TCM is not possible, go to "Troubleshooting for Communication Error with Scan Tool Using CAN in Section 1A".
- 6) After completing the check, turn ignition switch off and disconnect scan tool from DLC.

DTC Clearance

After repair or replace malfunction part(s), clear all DTCs by performing the following procedure.

- 1) Connect SUZUKI scan tool to data link connector in the same manner as when making this connection for "DTC Check".
- 2) Turn ignition switch to ON position.
- 3) Erase DTC and pending DTC according to instructions displayed on scan tool. Refer to scan tool operator's manual for further details.
- 4) After completing the clearance, turn ignition switch OFF and disconnect scan tool from DLC.

NOTE

DTC and freeze frame data stored in TCM memory are also cleared in the following cases. Be careful not to clear them before keeping their record.

- **When the same malfunction (DTC) is not detected again during 40 engine warm-up cycles.**

Fail Safe Table

S7RW0C5104008

This function is provided by the safe mechanism that assures safe driveability even when the solenoid valve, sensor or its circuit fails. The following table shows the fail safe function for each fail condition of sensor, solenoid, TCM or its circuit.

DTC No.	Trouble area	Fail safe operation
P0705	Transmission Range Sensor Circuit Malfunction (P R N D L Input)	TCM assumes position of transmission range sensor to be the following order of priority depending on input signals. N > R > L > 2 > 3 > D > P
P0707	Transmission Range Sensor Circuit Low	TCM assumes shift position to be D range.
P0712	Transmission Fluid Temperature Sensor "A" Circuit Low	TCM assumes transmission fluid temperature to be 200 °C (392 °F) and controls transaxle.
P0713	Transmission Fluid Temperature Sensor "A" Circuit High	
P0717	Input Speed Sensor "A" Circuit No Signal	Line pressure is controlled to maximum pressure, lock-up function is inhibited and gear position is fixed according to select lever position as follows. • D range: Fixed to 4th gear position • 3 range: Fixed to 4th gear position • 2 range: Fixed to 3rd gear position • L range: Fixed to 1st gear position
P0722	Output Speed Sensor Circuit No Signal	
P0961	Pressure Control Solenoid "A" Control Circuit Range/Performance	Line pressure is controlled to maximum pressure, lock-up function is inhibited and gear position is fixed according to select lever position as follows. • D range: Fixed to 4th gear position • 3 range: Fixed to 4th gear position • 2 range: Fixed to 3rd gear position • L range: Fixed to 1st gear position
P0962	Pressure Control Solenoid "A" Control Circuit Low	
P0963	Pressure Control Solenoid "A" Control Circuit High	
P0973	Shift Solenoid "A" Control Circuit Low	
P0974	Shift Solenoid "A" Control Circuit High	
P0976	Shift Solenoid "B" Control Circuit Low	
P0977	Shift Solenoid "B" Control Circuit High	
P1702	Internal control module memory check sum error	

DTC No.	Trouble area	Fail safe operation
P2763	Torque Converter Clutch Pressure Control Solenoid Control Circuit High	TCM is controlled as follows. - Gear position is fixed in 1st gear when vehicle speed is 10 km/h (6 mile/h) or less. - Up shifting to 4th gear is inhibited when transmission fluid temperature is 150 °C (302 °F) or more.
P2764	Torque Converter Clutch Pressure Control Solenoid Control Circuit Low	
U0073	Control Module Communication Bus Off	TCM is controlled as follows. - Line pressure is controlled to maximum pressure. - TCM assumes throttle position signal to be 0%. - TCM assumes engine speed to be 0 RPM. - After 15 minutes pass from detecting malfunction, TCM assumes engine coolant temperature to be 90 °C (194 °F). - Gear position is fixed according to select lever position as follows. - D range: Fixed to 4th gear position 3 range: Fixed to 4th gear position 2 range: Fixed to 3rd gear position - L range: Fixed to 1st gear position
U0100	Lost Communication With ECM / PCM "A"	TCM is controlled as follows. - Line pressure is controlled to maximum pressure. - Lock-up function is inhibited. - TCM assumes throttle position signal to be 100%. - TCM assumes engine speed to be 0 RPM. - After 15 minutes pass from detecting malfunction, TCM assumes engine coolant temperature to be 90 °C (194 °F). - Gear position is fixed according to select lever position as follows. - D range: Fixed to 4th gear position 3 range: Fixed to 4th gear position 2 range: Fixed to 3rd gear position - L range: Fixed to 1st gear position

Scan Tool Data

S7RW0C5104009

As the data values given in the following table are standard values estimated on the basis of values obtained from the normally operating vehicles by using a scan tool, use them as reference values. Even when the vehicle is in good condition, there may be cases where the checked value does not fall within each specified data range. Therefore, judgment as abnormal should not be made by checking with these data alone.

Also, condition in the following table that can be checked by the scan tool are those detected by TCM and output from TCM as commands and there may be cases where the automatic transaxle or actuator is not operating (in the condition) as indicated by the scan tool.

Scan tool data	Vehicle condition	Normal condition / reference values
Input shaft revolution	Ignition switch ON and engine stop	0 RPM
	At 60 km/h (37.5 mile/h) constant speed, 20% or less throttle opening and 3rd gear ("3" range)	2300 RPM (displayed in increments of 50 rpm)
Output shaft revolution	At vehicle stop	0 RPM
	At 60 km/h (37.5 mile/h) constant speed, 20% or less throttle opening and 3rd gear ("3" range)	2300 RPM (displayed in increments of 50 rpm)
Battery voltage	Ignition switch ON and engine stop	Battery voltage is displayed
ATF temperature	Ignition switch ON and engine stop	A/T fluid temperature is displayed
Pressure control Sol	At specified idle speed after warming up	0%
Vehicle speed	—	Vehicle speed is displayed

5A-22 Automatic Transmission/Transaxle:

Scan tool data	Vehicle condition	Normal condition / reference values
⚙ Gear position	Ignition switch ON and select lever is in "P" position	P or N
	Ignition switch ON and select lever is in "R" position	R
	Ignition switch ON and select lever is in "N" position	P or N
	Ignition switch ON and select lever is in "D" position	1
	Ignition switch ON and select lever is in "3" position	1
	Ignition switch ON and select lever is in "2" position	1
	Ignition switch ON and select lever is in "L" position	1
⚙ Throttle position	Ignition switch ON and select pedal released	0 – 12%
	Ignition switch ON and select pedal depressed fully	90 – 100%
⚙ Accel actual position	Ignition switch ON and select pedal released	0 – 12%
	Ignition switch ON and select pedal depressed fully	90 – 100%
⚙ Engine speed	At specified idle speed after warming up	Engine revolution speed is displayed
⚙ Coolant temperature	Ignition switch ON and engine stop	Engine coolant temperature is displayed
⚙ Cruise control signal	Ignition switch ON and cruise control switch OFF	OFF
	Ignition switch ON and cruise control switch ON	ON
⚙ Transaxle range	Ignition switch ON and engine stop	Select lever position is displayed
⚙ "3" position switch	Ignition switch ON and select lever to "3" or "2" range	ON
	Ignition switch ON and select lever to other than "3" or "2" range	OFF
⚙ Shift solenoid A (CMD)	At vehicle stop	OFF
	At 60 km/h (37.5 mile/h) constant speed, 20% or less throttle opening and 3rd gear ("3" range)	ON
⚙ Shift solenoid B (CMD)	At vehicle stop	ON
	At 60 km/h (37.5 mile/h) constant speed, 20% or less throttle opening and 3rd gear ("3" range)	OFF
⚙ TCC solenoid (CMD)	At vehicle stop	OFF
	At 80 km/h (50 mile/h) constant speed, 20% or less throttle opening and 4th gear ("D" range)	ON
⚙ Shift solenoid A (Mon)	At vehicle stop	OFF
	At 60 km/h (37.5 mile/h) constant speed, 20% or less throttle opening and 3rd gear ("3" range)	ON
⚙ Shift solenoid B (Mon)	At vehicle stop	ON
	At 60 km/h (37.5 mile/h) constant speed, 20% or less throttle opening and 3rd gear ("3" range)	OFF
⚙ TCC solenoid (Mon)	At vehicle stop	OFF
	At 80 km/h (50 mile/h) constant speed, 20% or less throttle opening and 4th gear ("D" range)	ON
⚙ Brake switch	Ignition switch ON and brake pedal released	OFF
	Ignition switch ON and brake pedal depressed	ON
⚙ MIL request	Ignition switch ON	OFF

Scan Tool Data Definitions:**Input shaft revolution (RPM)**

It indicates input shaft revolution computed by reference pulses coming from input shaft speed sensor on transmission case.

Output shaft revolution (RPM)

It indicates output shaft revolution computed by reference pulses coming from output shaft speed sensor on transmission case.

Battery voltage (V)

It indicates battery voltage read by TCM as analog input signal by TCM.

ATF temperature (°C, °F)

It indicates ATF temperature detected by signal from transmission fluid temperature sensor installed in valve body.

Pressure control Sol (pressure control solenoid valve) (%)

Electric current value ratio between electric current value being outputted from TCM to solenoid and maximum value can be outputted by TCM.

Vehicle speed (km/h, mile/h)

Vehicle speed computed by reference pulses coming from output shaft speed sensor on transaxle case.

Gear position (P, R, N, D, 3, 2 or L)

This parameter is indicated actual gear position.

Throttle position (%)

It indicates throttle valve opening ratio sent from ECM through CAN communication line.

Accel actual position (accelerator pedal actual position) (%)

It indicates accelerator pedal opening ratio detected by signal through CAN communication line fed from ECM.

Engine speed (RPM)

It indicates engine speed computed by signal through CAN communication line fed from ECM.

Coolant temperature (engine coolant temperature) (°C, °F)

It indicates engine coolant temperature detected by signal through CAN communication line fed from ECM.

Cruise control signal (ON, OFF)

ON: Signal which inform that lock-up inhibit signal from ECM is turned ON.

OFF: Signal which inform that lock-up inhibit signal from ECM is turned OFF.

Transaxle range (P, R, N, D, 3, 2 or L)

It indicates transmission range according to transmission range switch signal.

“3” position switch (ON, OFF)

Inputted signal from “3” position switch in select lever.

ON: Shift select lever to “3” or “2” range

OFF: Shift select lever to other above range

Shift solenoid A (COM) (command signal of shift solenoid valve - A) (ON, OFF)

ON: ON command being outputted to shift solenoid valve-A.

OFF: ON command not being outputted to shift solenoid valve-A.

Shift solenoid B (COM) (command signal of shift solenoid valve - B) (ON, OFF)

ON: ON command being outputted to shift solenoid valve-B.

OFF: ON command not being outputted to shift solenoid valve-B.

TCC solenoid (COM) (command signal of torque converter clutch solenoid valve) (ON, OFF)

ON: ON command being outputted to TCC solenoid valve.

OFF: ON command not being outputted to TCC solenoid valve.

Shift solenoid A (Mon) (monitor signal of shift solenoid valve - A) (ON, OFF)

ON: Electricity being passed to shift solenoid valve-A.

OFF: Electricity not being passed to shift solenoid valve-A.

Shift solenoid B (Mon) (monitor signal of shift solenoid valve - B) (ON, OFF)

ON: Electricity being passed to shift solenoid valve-B.

OFF: Electricity not being passed to shift solenoid valve-B.

TCC solenoid (Mon) (monitor signal of torque converter clutch solenoid valve) (ON, OFF)

ON: Electricity being passed to TCC solenoid valve.

OFF: Electricity not being passed to TCC solenoid valve.

Brake switch (ON, OFF)

Brake light switch position detected by signal through CAN communication line fed from ECM.

ON: Brake pedal depressed

OFF: Brake pedal released

MIL request (ON, OFF)

ON: Signal which TCM requires combination meter to turn on MIL.

OFF: Signal which TCM does not require combination meter to turn on MIL.

A/T Basic Check

S7RW0C5104010

This check is important for troubleshooting when TCM has detected no DTC and no abnormality has been noted in visual inspection. Follow the flow table carefully.

Step	Action	Yes	No
1	Was “A/T System Check” preformed?	Go to Step 2.	Go to “A/T System Check”.
2	Perform “Road Test” Is it OK?	Go to Step 3.	Proceed to “Troubleshooting” in “Road Test”.
3	Perform “Manual Road Test” Is it OK?	Go to Step 4.	Proceed to “Troubleshooting” in “Manual Road Test”.
4	Perform “Engine Brake Test” Is it OK?	Go to Step 5.	Proceed to “Troubleshooting” in “Engine Brake Test”.

5A-24 Automatic Transmission/Transaxle:

Step	Action	Yes	No
5	Perform "Stall Test" <i>Is it OK?</i>	Go to Step 6.	Proceed to "Troubleshooting" in "Stall Test".
6	Perform "Time Lag Test" <i>Is it OK?</i>	Go to Step 7.	Proceed to "Troubleshooting" in "Time Lag Test".
7	Perform "Line Pressure Test" <i>Is it OK?</i>	Go to Step 8.	Proceed to "Troubleshooting" in "Line Pressure Test".
8	1) Proceed to "Trouble Diagnosis 1" in "A/T Symptom Diagnosis". <i>Is trouble identified?</i>	Repair or replace faulty parts.	Go to Step 9.
9	1) Proceed to "Trouble Diagnosis 2" in "A/T Symptom Diagnosis". <i>Is trouble identified?</i>	Repair or replace faulty parts.	Proceed to "Trouble Diagnosis 3" in "A/T Symptom Diagnosis".

Road Test

S7RW0C5104011

This test is to check if upshift, downshift and lock-up take place at specified speeds while actually driving vehicle on a level road.

▲ WARNING

- Carry out test in very little traffic area to prevent an accident.
- Test requires 2 persons, a driver and a tester.

- 1) Warm up engine.
- 2) With engine running at idle, shift select "D" range.
- 3) Accelerate vehicle speed by depressing accelerator pedal gradually.
- 4) While driving in "D" range, check if gear shift and lock-up occur properly as shown in "Automatic Gear Shift Table".

Troubleshooting

Condition	Possible cause	Correction / Reference Item
Unable to run in any forward positions	Faulty forward clutch	<i>Inspect. If NG, replace.</i>
Unable to run in reverse position	Faulty direct clutch	<i>Inspect. If NG, replace.</i>
	Faulty 1st / reverse brake	<i>Inspect. If NG, replace.</i>
	Faulty U/D brake	<i>Inspect. If NG, replace.</i>
Unable to run in all range	Faulty valve body component	<i>Replace valve body assembly.</i>
	Faulty oil pump	<i>Inspect. If NG, replace.</i>
	Seized or broken planetary gear	<i>Inspect. If NG, replace.</i>
	Faulty torque converter	<i>Inspect. If NG, replace.</i>
	Damaged drive plate	<i>Inspect. If NG, replace.</i>
1 → 2 upshift fails to occur	Malfunction of throttle position sensor	<i>Inspect. If NG, replace.</i>
	Malfunction of transmission range sensor	<i>Inspect. If NG, replace.</i>
	Faulty valve body component	<i>Replace valve body assembly.</i>
	Faulty 2nd coast brake	<i>Inspect. If NG, replace.</i>
	Faulty 2nd brake	<i>Inspect. If NG, replace.</i>
2 → 3 upshift fails to occur	Faulty one-way clutch No. 1	<i>Inspect. If NG, replace.</i>
	Malfunction of throttle position sensor	<i>Inspect. If NG, replace.</i>
	Malfunction of transmission range sensor	<i>Inspect. If NG, replace.</i>
	Faulty valve body component	<i>Replace valve body assembly.</i>
	Faulty U/D clutch	<i>Inspect. If NG, replace.</i>

Condition	Possible cause	Correction / Reference Item
3 → 4 upshift fails to occur	Malfunction of "3" position switch	<i>Inspect. If NG, replace.</i>
	Malfunction of engine coolant temperature sensor	<i>Inspect. If NG, replace.</i>
	Malfunction of throttle position sensor	<i>Inspect. If NG, replace.</i>
	Malfunction of transmission range sensor	<i>Inspect. If NG, replace.</i>
	Malfunction of transmission fluid temperature sensor	<i>Inspect. If NG, replace.</i>
	Faulty valve body component	<i>Replace valve body assembly.</i>
	Faulty direct clutch	<i>Inspect. If NG, replace.</i>
Gear shift point is incorrect	Abnormal engine condition	<i>Inspect and repair engine.</i>
	Malfunction of throttle position sensor	<i>Inspect. If NG, replace.</i>
TCC (lock-up) function does not operate	Malfunction of brake light switch	<i>Inspect. If NG, replace.</i>
	Malfunction of engine coolant temperature sensor	<i>Inspect. If NG, replace.</i>
	Malfunction of throttle position sensor	<i>Inspect. If NG, replace.</i>
	Malfunction of transmission range sensor	<i>Inspect. If NG, replace.</i>
	Malfunction of transmission fluid temperature sensor	<i>Inspect. If NG, replace.</i>
	Faulty valve body component	<i>Replace valve body assembly.</i>
	Faulty torque converter	<i>Replace torque converter.</i>

Manual Road Test


S7RW0C5104012

⚠ WARNING

- Carry out test in very little traffic area to prevent an accident.
- Test requires 2 persons, a driver and a tester.

The purpose of this test is to judge whether causal factor of trouble which occurred in automatic transaxle is electrical or mechanical by disconnecting valve body harness connector (1) and fixing automatic transaxle gear position.

- 1) Start engine and warm it up to normal operating temperature.
- 2) Turn ignition switch to OFF position and disconnect valve body harness connector (1).



I7RW01510007-01

- 3) Turn OFF all electrical loads.
With select lever shifted to each range ("L", "2", "3" and "D"), drive vehicle at 1,000 rpm engine speed and then check vehicle speed by referring to "Fixed gear position".
If vehicle speed is not as specified in "Fixed gear position" table, go to troubleshooting.

5A-26 Automatic Transmission/Transaxle:

- 4) Connect valve body harness connector and clear DTC.

Fixed gear position

Select lever position	Fixed gear position	Vehicle speed
L range	1st gear	Approx. 11.31 km/h (7.0 mile/h)
2 range	3rd gear	Approx. 29.87 km/h (18.6 mile/h)
3 range	4th gear	Approx. 41.55 km/h (25.8 mile/h)
D range		
R range	Reverse gear	Approx. 10.33 km/h (6.4 mile/h)

Troubleshooting

Condition	Possible cause	Correction / Reference Item
Selected gear is not correct	Faulty valve body component	<i>Replace valve body.</i>
	Faulty clutch or brake	<i>Inspect clutch and brake. If any parts are faulty, replace them.</i>

Stall Test

S7RW0C5104013

This test is to check overall performance of automatic transaxle and engine by measuring stall speed at "D" and "R" ranges. Be sure to perform this test only when transaxle fluid is at normal operating temperature and its level is between FULL and LOW marks.

CAUTION

- Do not run engine at stall more than 5 seconds continuously, for fluid temperature may rise excessively high.
- After performing stall test, be sure to leave engine running at idle for longer than 1 minute before another stall test.

- 1) Apply parking brake and block wheels.
- 2) Warm up engine to normal operating temperature.
- 3) Turn OFF all electrical loads.
- 4) Depress brake pedal fully.
- 5) Shift select lever to "D" and depress accelerator pedal fully while watching tachometer. Read engine rpm quickly when it has become constant (stall speed).
- 6) Release accelerator pedal immediately after stall speed is checked.
- 7) In the same way, check stall speed in "R" range.
- 8) Stall speed should be within following specification.

Engine stall speed

Standard: 2,050 – 2,450 rpm

Troubleshooting

Condition	Possible cause	Correction / Reference Item
Lower than standard level in both "D" and "R" range	Engine output torque failure	<i>Inspect and repair engine.</i>
	Faulty one-way clutch of torque converter	<i>Replace torque converter.</i>
Higher than standard level in "D" range	Malfunction of pressure control solenoid valve (Low line pressure)	<i>Inspect. If NG, replace valve body assembly.</i>
	Malfunction of primary regulator valve (Low line pressure)	<i>Replace valve body assembly.</i>
	Clogged oil strainer	<i>Replace.</i>
	Faulty oil pump	<i>Inspect. If NG, replace.</i>
	Slippery forward clutch	<i>Inspect. If NG, replace.</i>
	Faulty one-way No. 3 clutch	<i>Inspect. If NG, replace.</i>
	Leakage from "D" range fluid pressure circuit	<i>Overhaul or replace valve body assembly.</i>

Condition	Possible cause	Correction / Reference Item
Higher than standard level in "R" range	Malfunction of pressure control solenoid valve (Low line pressure)	<i>Inspect. If NG, replace valve body assembly.</i>
	Malfunction of primary regulator valve (Low line pressure)	<i>Replace valve body assembly.</i>
	Clogged oil strainer	<i>Replace.</i>
	Faulty oil pump	<i>Inspect. If NG, replace.</i>
	Slippery direct clutch	<i>Inspect. If NG, replace.</i>
	Slippery 1st / reverse brake	<i>Inspect. If NG, replace.</i>
	Leakage from "R" range fluid pressure circuit	<i>Overhaul or replace valve body assembly.</i>
Higher than standard level in both "D" and "R" range	Malfunction of pressure control solenoid valve (Low line pressure)	<i>Inspect. If NG, replace valve body assembly.</i>
	Malfunction of primary regulator valve (Low line pressure)	<i>Replace valve body assembly.</i>
	Clogged oil strainer	<i>Replace.</i>
	Faulty oil pump	<i>Inspect. If NG, replace.</i>
	Faulty U/D brake	<i>Inspect. If NG, replace.</i>
	Leakage from both "D" and "R" range fluid pressure circuit	<i>Overhaul or replace valve body assembly.</i>

Time Lag Test

S7RW0C5104014

This test is to check conditions of clutch, reverse brake and fluid pressure. "Time lag" means time elapsed since select lever is shifted with engine idling till shock is felt.

- 1) With chocks placed before and behind front and rear wheels respectively, depress brake pedal.
- 2) Start engine.
- 3) With stop watch ready, shift select lever from "N" to "D" range and measure time from that moment till shock is felt.
- 4) Similarly measure time lag by shifting select lever from "N" to "R" range.

Gear shifting time lag

"N" → "D": Less than 0.7 sec.

"N" → "R": Less than 1.2 sec.

NOTE

- When repeating this test, be sure to wait at least one minute after select lever is shifted back to "N" range.
- Engine should be warmed up fully for this test.
- Repeat test 3 times and take average of those data for final time lag data.

Troubleshooting

Condition	Possible cause	Correction / Reference Item
N → "D" time lag exceeds specification	Malfunction of pressure control solenoid valve (Low line pressure)	<i>Inspect. If NG, replace valve body assembly.</i>
	Malfunction of primary regulator valve (Low line pressure)	<i>Replace valve body assembly.</i>
	Clogged oil strainer	<i>Replace.</i>
	Faulty oil pump	<i>Inspect. If NG, replace.</i>
	Slippery forward clutch	<i>Inspect. If NG, replace.</i>
	Faulty one-way No. 2 clutch	<i>Inspect. If NG, replace.</i>
	Leakage from "D" range fluid pressure circuit	<i>Overhaul or replace valve body assembly.</i>

Condition	Possible cause	Correction / Reference Item
<i>N</i> → “R” time lag exceeds specification	Malfunction of pressure control solenoid valve (Low line pressure)	<i>Inspect. If NG, replace valve body assembly.</i>
	Malfunction of primary regulator valve (Low line pressure)	<i>Replace valve body assembly.</i>
	Clogged oil strainer	<i>Replace.</i>
	Faulty oil pump	<i>Inspect. If NG, replace.</i>
	Slippery direct clutch	<i>Inspect. If NG, replace.</i>
	Slippery 1st / reverse brake	<i>Inspect. If NG, replace.</i>
	Slippery U/D brake	<i>Inspect. If NG, replace.</i>
	Leakage from “R” range fluid pressure circuit	<i>Overhaul or replace valve body assembly.</i>

Line Pressure Test

S7RW0C5104015

Purpose of this test is to check operating conditions of each part by measuring fluid pressure in fluid pressure line.
Line pressure test requires following conditions.


- Automatic fluid is at normal operating temperature (70 – 80 °C / 158 – 176 °F).
 - Fluid is filled to proper level (between FULL and LOW on dipstick).
 - Air conditioner switch is turned OFF.
- 1) Apply parking brake securely and place chocks against wheels.
 - 2) Remove fluid pressure check hole plug bolt.
 - 3) Attach oil pressure gauge to fluid pressure check hole in transaxle case.

Special tool

(A): 09925–37811–001

⚠ CAUTION

After attaching oil pressure gauge, check that no fluid leakage exists.



I4RH01510010-01

- 4) Depress foot brake fully, run engine at idle and stall then check fluid pressure in “D” and “R” ranges.

⚠ CAUTION

- Do not continue running engine at stall speed longer than 5 seconds.
- After performing line pressure test, be sure to leave engine running at idle for longer than one minute before performing another line pressure test.

Automatic transmission line pressure

	“D” range	“R” range
At idle speed	3.5 – 4.1 kg/cm ² 49 – 58 psi	5.9 – 6.2 kg/cm ² 84 – 88 psi
At stall speed	10.5 – 13.5 kg/cm ² 149 – 192 psi	16.1 – 20.3 kg/cm ² 229 – 289 psi

Troubleshooting

Condition	Possible cause	Correction / Reference Item
Higher than standard level in each range	Malfunction of pressure control solenoid valve	<i>Inspect. If NG, replace valve body assembly.</i>
	Malfunction of primary regulator valve	<i>Replace valve body assembly.</i>
Lower than standard level in each range	Malfunction of pressure control solenoid valve	<i>Inspect. If NG, replace valve body assembly.</i>
	Malfunction of primary regulator valve	<i>Replace valve body assembly.</i>
	Clogged oil strainer	<i>Replace.</i>
	Faulty oil pump	<i>Inspect. If NG, replace.</i>
	Leakage from U/D brake fluid pressure circuit	<i>Overhaul or replace valve body assembly.</i>
Lower than standard level only in "D" range	Leakage from "D" range fluid pressure circuit	<i>Overhaul or replace valve body assembly.</i>
Lower than standard level only in "R" range	Leakage from "R" range fluid pressure circuit	<i>Overhaul or replace valve body assembly.</i>

Engine Brake Test

S7RW0C5104016

⚠ WARNING

Before test, make sure that there is no vehicle behind so as to prevent rear-end collision.

- 1) While driving vehicle in 3rd gear of "D" range, shift select lever down to "2" range and check if engine brake operates.
- 2) In the same way as in Step 1), check engine brake for operation when select lever is shifted down to "L" range.
- 3) Engine brake should operate in the test.

Troubleshooting

Condition	Possible cause	Correction / Reference Item
Failure to operate when shifted down to "2" range	Faulty valve body component	<i>Replace valve body assembly.</i>
	Faulty O/D and 2nd coast brake	<i>Inspect. If NG, replace.</i>
Failure to operate when shifted down to "L" range	Faulty valve body component	<i>Replace valve body assembly.</i>
	Faulty 1st and reverse brake	<i>Inspect. If NG, replace.</i>

"P" Range Test

S7RW0C5104017

- 1) Stop vehicle on a slope of 5 degrees or more, shift select lever to "P" range and at the same time apply parking brake.
- 2) After stopping engine, depress brake pedal and release parking brake.
- 3) Then, release brake pedal gradually and check that vehicle remains stationary.
- 4) Depress brake pedal and shift select lever to "N" range.
- 5) Then, release brake pedal gradually and check that vehicle moves.

⚠ WARNING

Before test, make sure no one is around vehicle or down on a slope and keep watchful for safety during test.

Troubleshooting

Condition	Possible cause	Correction / Reference Item
Vehicle moves at "P" range or remains stationary at "N" range	Defective parking lock pawl or spring	<i>Inspect. If NG, repair.</i>

A/T Symptom Diagnosis

Trouble Diagnosis 1

Electrical repair

Condition	Possible cause	Correction / Reference Item
No up-shift (fixed gear position)	Battery voltage abnormality	Inspect charging system referring to "Generator Test (Undercharged Battery Check) in Section 1J" or "Generator Test (Overcharged Battery Check) in Section 1J".
	Input shaft speed sensor circuit faulty	Inspect circuit for open, short and intermittent. If NG, repair.
	Output shaft speed sensor circuit faulty	Inspect circuit for open, short and intermittent. If NG, repair.
	Pressure control solenoid valve circuit faulty	Inspect circuit for open, short and intermittent. If NG, repair.
	Shift solenoid valve-A (No. 1) circuit faulty	Inspect circuit for open, short and intermittent. If NG, repair.
	Shift solenoid valve-B (No. 2) circuit faulty	Inspect circuit for open, short and intermittent. If NG, repair.
	CAN communication circuit faulty	Inspect circuit for open, short and intermittent. If NG, repair.
	TCM	Substitute a known-good TCM and recheck.
Poor 1 → 2 shift	ECM	Substitute a known-good ECM and recheck.
	Transmission range sensor circuit faulty	Inspect circuit for open, short and intermittent. If NG, repair.
	TCM	Substitute a known-good TCM and recheck.
Poor 2 → 3 shift	ECM	Substitute a known-good ECM and recheck.
	Transmission range sensor circuit faulty	Inspect circuit for open, short and intermittent. If NG, repair.
	TCM	Substitute a known-good TCM and recheck.
Poor 3 → 4 shift	ECM	Substitute a known-good ECM and recheck.
	Transmission range sensor circuit faulty	Inspect circuit for open, short and intermittent. If NG, repair.
	CAN communication circuit faulty	Inspect circuit for open, short and intermittent. If NG, repair.
	Engine coolant temperature sensor circuit faulty	Inspect circuit for open, short and intermittent referring to "Engine Coolant Temperature (ECT) Sensor Inspection in Section 1C". If NG, repair.
	"3" position switch circuit faulty	Inspect circuit for open, short and intermittent. If NG, repair.
	TCM	Substitute a known-good TCM and recheck.
Incorrect gear shift point	ECM	Substitute a known-good ECM and recheck.
	Throttle position sensor circuit faulty	Inspect circuit for open, short and intermittent referring to "Electric Throttle Body Assembly On-Vehicle Inspection in Section 1C". If NG, repair.
	Throttle position sensor faulty	Inspect referring to "Electric Throttle Body Assembly On-Vehicle Inspection in Section 1C". If NG, repair.
	TCM	Substitute a known-good TCM and recheck.
	ECM	Substitute a known-good ECM and recheck.

Condition	Possible cause	Correction / Reference Item
Non operate TCC (lock-up) system	TCC solenoid valve circuit faulty	<i>Inspect circuit for open, short and intermittent. If NG, repair.</i>
	Transmission range sensor circuit faulty	<i>Inspect circuit for open, short and intermittent. If NG, repair.</i>
	Transmission fluid temperature sensor circuit faulty	<i>Inspect circuit for open, short and intermittent. If NG, repair.</i>
	Throttle position sensor circuit faulty	<i>Inspect circuit for open, short and intermittent referring to "Electric Throttle Body Assembly On-Vehicle Inspection in Section 1C". If NG, repair.</i>
	Engine coolant temperature sensor circuit faulty	<i>Inspect circuit for open, short and intermittent referring to "Engine Coolant Temperature (ECT) Sensor Inspection in Section 1C". If NG, repair.</i>
	Brake light switch circuit faulty	<i>Inspect circuit for open, short and intermittent. If NG, repair.</i>
	CAN communication circuit faulty	<i>Inspect circuit for open, short and intermittent. If NG, repair.</i>
	TCM	<i>Substitute a known-good TCM and recheck.</i>
	ECM	<i>Substitute a known-good ECM and recheck.</i>
Higher or lower stall speed	Pressure control solenoid valve circuit faulty	<i>Inspect circuit for open, short and intermittent. If NG, repair.</i>
	TCM	<i>Substitute a known-good TCM and recheck.</i>
Excessive "N" → "D" or "N" → "R" time lag	Pressure control solenoid valve circuit faulty	<i>Inspect circuit for open, short and intermittent. If NG, repair.</i>
	TCM	<i>Substitute a known-good TCM and recheck.</i>
Higher or lower line pressure	Pressure control solenoid valve circuit faulty	<i>Inspect circuit for open, short and intermittent. If NG, repair.</i>
	TCM	<i>Substitute a known-good TCM and recheck.</i>

Trouble Diagnosis 2

On-vehicle repair

Condition	Possible cause	Correction / Reference Item
Unable to run in all range	Faulty valve body component	<i>Replace valve body assembly.</i>
Poor 1 → 2 shift, excessive shock or slippage	Engine abnormal condition	<i>Inspect and repair engine.</i>
	Malfunction of shift solenoid valve-A	<i>Inspect. If NG, replace.</i>
	Malfunction of transmission range sensor	<i>Inspect. If NG, replace.</i>
	Malfunction of transmission fluid temperature sensor	<i>Inspect. If NG, replace.</i>
	Malfunction of throttle position sensor	<i>Inspect referring to "Electric Throttle Body Assembly On-Vehicle Inspection in Section 1C". If NG, replace.</i>
	Malfunction of pressure control solenoid valve	<i>Inspect. If NG, replace valve body assembly.</i>
	Faulty valve body component	<i>Replace valve body assembly.</i>
Poor 2 → 3 shift, excessive shock or slippage	Engine abnormal condition	<i>Inspect and repair engine.</i>
	Malfunction of shift solenoid valve-B	<i>Inspect. If NG, replace.</i>
	Malfunction of transmission range sensor	<i>Inspect. If NG, replace.</i>
	Malfunction of transmission fluid temperature sensor	<i>Inspect. If NG, replace.</i>
	Malfunction of throttle position sensor	<i>Inspect referring to "Electric Throttle Body Assembly On-Vehicle Inspection in Section 1C". If NG, replace.</i>
	Malfunction of pressure control solenoid valve	<i>Inspect. If NG, replace valve body assembly.</i>
	Faulty valve body component	<i>Replace valve body assembly.</i>

5A-32 Automatic Transmission/Transaxle:

Condition	Possible cause	Correction / Reference Item
Poor 3 → 4 shift, excessive shock or slippage	Engine abnormal condition	<i>Inspect and repair engine.</i>
	Malfunction of transmission range sensor	<i>Inspect. If NG, replace.</i>
	Malfunction of transmission fluid temperature sensor	<i>Inspect. If NG, replace.</i>
	Malfunction of "3" position switch	<i>Inspect. If NG, replace.</i>
	Malfunction of engine coolant temperature sensor	<i>Inspect referring to "Engine Coolant Temperature (ECT) Sensor Inspection in Section 1C". If NG, replace.</i>
	Malfunction of throttle position sensor	<i>Inspect referring to "Electric Throttle Body Assembly On-Vehicle Inspection in Section 1C". If NG, replace.</i>
	Malfunction of pressure control solenoid valve	<i>Inspect. If NG, replace valve body assembly.</i>
	Faulty valve body component	<i>Replace valve body assembly.</i>
Incorrect shift point	Engine abnormal condition	<i>Inspect and repair engine.</i>
Non operate TCC (lock-up) system	Malfunction of TCC solenoid valve	<i>Inspect. If NG, replace.</i>
	Malfunction of transmission fluid temperature sensor	<i>Inspect. If NG, replace.</i>
	Malfunction of throttle position sensor	<i>Inspect referring to "Electric Throttle Body Assembly On-Vehicle Inspection in Section 1C". If NG, replace.</i>
	Malfunction of engine coolant temperature sensor	<i>Inspect referring to "Engine Coolant Temperature (ECT) Sensor Inspection in Section 1C". If NG, replace.</i>
	Malfunction of brake light switch	<i>Inspect referring to "Brake Light Switch Inspection in Section 9B". If NG, replace.</i>
	Faulty valve body component	<i>Replace valve body assembly.</i>
Excessive "N" → "D" or "N" → "R" time lag	Pressure control solenoid valve faulty	<i>Inspect. If NG, replace valve body assembly.</i>
	Primary regulator valve faulty	<i>Replace valve body assembly.</i>

Trouble Diagnosis 3
Off-vehicle repair

Condition	Possible cause	Correction / Reference Item
Unable to run in any forward positions	Faulty forward clutch	<i>Inspection. If NG, replace.</i>
Unable to run in reverse position	Faulty direct clutch	<i>Inspection. If NG, replace.</i>
	Faulty 1st / reverse brake	<i>Inspection. If NG, replace.</i>
	Faulty U/D brake	<i>Inspection. If NG, replace.</i>
Unable to run in all range	Faulty oil pump	<i>Inspection. If NG, replace.</i>
	Seized or broken planetary gear	<i>Inspection. If NG, replace.</i>
	Faulty torque converter	<i>Inspection. If NG, replace.</i>
	Damaged drive plate	<i>Inspection. If NG, replace.</i>
Poor 1 → 2 shift, excessive shock or slippage	Faulty 2nd coast brake	<i>Inspection. If NG, replace.</i>
	Faulty 2nd brake	<i>Inspection. If NG, replace.</i>
	Faulty one-way clutch No. 1	<i>Inspection. If NG, replace.</i>
Poor 2 → 3 shift, excessive shock or slippage	Faulty U/D clutch	<i>Inspection. If NG, replace.</i>
Poor 3 → 4 shift, excessive shock or slippage	Faulty direct clutch	<i>Inspection. If NG, replace.</i>
Non operate TCC (lock-up) system	Faulty torque converter	<i>Replace torque converter.</i>

Condition	Possible cause	Correction / Reference Item
Excessive "N" → "D" time lag	Clogged oil strainer	<i>Replace.</i>
	Faulty oil pump	<i>Inspection. If NG, replace.</i>
	Slippery forward clutch	<i>Inspection. If NG, replace.</i>
	Faulty one-way No. 2 clutch	<i>Inspection. If NG, replace.</i>
	Leakage from "D" range fluid pressure circuit	<i>Overhaul or replace valve body assembly.</i>
Excessive "N" → "R" time lag	Clogged oil strainer	<i>Replace.</i>
	Faulty oil pump	<i>Inspection. If NG, replace.</i>
	Slippery direct clutch	<i>Inspection. If NG, replace.</i>
	Slippery 1st / reverse brake	<i>Inspection. If NG, replace.</i>
	Slippery U/D brake	<i>Inspection. If NG, replace.</i>
	Leakage from "R" range fluid pressure circuit	<i>Overhaul or replace valve body assembly.</i>
Poor engine brake in downshift to "L" range	Faulty 1st / reverse brake	<i>Inspection. If NG, replace.</i>

Transmission Warning Light Circuit Check – Light Does Not Come "ON" at Ignition Switch ON (Non-Euro-OBD Model)

S7RW0C5104019

Troubleshooting

Step	Action	Yes	No
1	Combination Meter Power Supply Check 1) Turn ignition switch ON. <i>Does other indicator / warning lights in combination meter comes ON?</i>	Go to Step 2.	Repair combination meter power supply circuit referring to "Combination Meter Circuit Diagram in Section 9C".
2	1) TCM power and ground circuit check referring to "TCM Power and Ground Circuit Check". <i>Is it in good condition?</i>	Go to Step 3.	Repair or replace.
3	DTC check 1) Check DTC referring to "DTC Check". <i>Is there DTC U0073 or U0100?</i>	Go to applicable DTC diag. flow.	Go to Step 4.
4	Combination Meter Function Check 1) Turn ignition switch ON. <i>Does A/T selector position indicator show correct select lever position?</i>	Replace combination meter.	Substitute a known-good TCM and recheck.

Transmission Warning Light Circuit Check – Light Remains "ON" at Ignition Switch ON (Non-Euro-OBD Model)


S7RW0C5104020

Troubleshooting

Step	Action	Yes	No
1	Diagnostic Trouble Code (DTC) Check 1) Check DTC referring to "DTC Check". <i>Is there any DTC(s)?</i>	Perform DTC Flow to repair and retry.	Substitute a known-good TCM and recheck. If OK, substitute a known-good combination meter and recheck.

DTC P0705: Transmission Range Sensor Circuit Malfunction (P R N D L Input)

S7RW0C5104021

Wiring Diagram

I7RW01510008-02

1. TCM	4. Brake light switch	7. Terminal arrangement of TCM connector (viewed from harness side)
2. Transmission range sensor	5. Backup light	
3. From ignition switch	6. Shift lock solenoid	

DTC Detecting Condition and Trouble Area

DTC detecting condition	Trouble area
Multiple signals are inputted simultaneously from transmission range sensor for 10 seconds or more. (1 driving cycle detection logic)	- Transmission range sensor or its circuit malfunction. - TCM

DTC Confirmation Procedure

- 1) Clear DTC.
- 2) Shift select lever to each of "L", "2", "3", "D", "N", "R" and "P" ranges for 20 seconds each.
- 3) Check DTC.

DTC Troubleshooting

Step	Action	Yes	No
1	Was "A/T System Check" performed?	Go to Step 2.	Go to "A/T System Check".
2	Do you have SUZUKI scan tool?	Go to Step 3.	Go to Step 4.
3	Check transmission range sensor circuit Check by using SUZUKI scan tool: 1) Connect SUZUKI scan tool to DLC with ignition switch turned OFF. 2) Turn ignition switch to ON position and then check transmission range signal ("P", "R", "N", "D", "3", "2" or "L") on display when shifting select lever to each range. <i>Is applicable range indicated?</i>	Intermittent trouble. Check for intermittent referring to "Intermittent and Poor Connection Inspection in Section 00".	Go to Step 5.

Step	Action	Yes	No
4	Check transmission range sensor circuit for operation Check by not using SUZUKI scan tool: 1) Turn ignition switch to ON position. 2) Check voltage at terminals "C07-1", "C07-7", "C07-8", "C07-18", "C07-19" and "C07-20" respectively with select lever shifted to each range. Taking terminal "C07-19" as an example, is battery voltage will be indicated only when select lever is shifted to "2" range and 0 V for other ranges as shown in table. Check voltage at other terminals likewise, referring to table. <i>Are check results satisfactory?</i>	Intermittent trouble. Check for intermittent referring to "Intermittent and Poor Connection Inspection in Section 00".	Go to Step 5.
5	Check transmission range sensor 1) Check transmission range sensor referring to "Transmission Range Sensor Inspection and Adjustment". <i>Are check results satisfactory?</i>	"PNK/BLK", "RED", "GRN/ORN", "GRN/YEL", "GRN" or "LT GRN/BLK" circuit shorted to power circuit or shorted each other. If wires are OK, substitute a know-good TCM and recheck.	Replace Transmission range sensor.

Table for step 4

		Terminal					
		C07-20	C07-1	C07-8	C07-7	C07-19	C07-18
Select lever position	P	B + V	0 V	0 V	0 V	0 V	0 V
	R	0 V	B + V	0 V	0 V	0 V	0 V
	N	0 V	0 V	B + V	0 V	0 V	0 V
	D or 3	0 V	0 V	0 V	B + V	0 V	0 V
	2	0 V	0 V	0 V	0 V	B + V	0 V
	L	0 V	0 V	0 V	0 V	0 V	B + V

DTC P0707: Transmission Range Sensor Circuit Low

S7RW0C5104022

Wiring Diagram

Refer to "DTC P0705: Transmission Range Sensor Circuit Malfunction (P R N D L Input)".

DTC Detecting Condition and Trouble Area

DTC detecting condition	Trouble area
Transmission range sensor signal (P, R, N, D, 2 or L) is not inputted for more than 30 seconds when vehicle speed is higher than 30 km/h (19 mile/h). (2 driving cycle detection logic)	- Select cable maladjusted. - Transmission range sensor maladjusted. - Transmission range sensor or its circuit malfunction. - TCM

DTC Confirmation Procedure**▲ WARNING**

- When performing a road test, select a place where there is no traffic or possibility of a traffic accident and be very careful during testing to avoid occurrence of an accident.
- Road test should be carried out with 2 persons, a driver and tester, on a level road.

5A-36 Automatic Transmission/Transaxle:

- 1) Clear DTC.
- 2) Start vehicle and increase vehicle speed to about 40 km/h (25 mile/h) in "D" range.
- 3) Keep driving the vehicle speed for 30 seconds or more.
- 4) Release accelerator pedal, decrease vehicle speed and stop vehicle.
- 5) Turn ignition switch OFF.
- 6) Repeat Step 3) to 5) one time.
- 7) Check DTC, pending DTC and freeze frame data.

DTC Troubleshooting


Step	Action	Yes	No
1	<i>Was "A/T System Check" performed?</i>	Go to Step 2.	Go to "A/T System Check".
2	<i>Do you have SUZUKI scan tool?</i>	Go to Step 3.	Go to Step 4.
3	Check transmission range sensor circuit for operation Check by using SUZUKI scan tool: 1) Connect SUZUKI scan tool to DLC with ignition switch turned OFF. 2) Turn ignition switch to ON position and then check transmission range signal ("P", "R", "N", "D", "2" or "L") displayed on SUZUKI scan tool when shifting select lever to each range. <i>Is applicable range indicated?</i>	Intermittent trouble. Check for intermittent referring to "Intermittent and Poor Connection Inspection in Section 00".	Go to Step 5.
4	Check transmission range sensor circuit for operation Check by not using SUZUKI scan tool: 1) Turn ignition switch to ON position. 2) Check voltage at terminals "C07-1", "C07-7", "C07-8", "C07-18", "C07-19" and "C07-20" respectively with select lever shifted to each range. Taking terminal "C07-19" as an example, is battery voltage will be indicated only when select lever is shifted to "2" range and 0 V for other ranges as shown in table. Check voltage at other terminals likewise, referring to table. <i>Are check results satisfactory?</i>	Intermittent trouble. Check for intermittent referring to "Intermittent and Poor Connection Inspection in Section 00".	Go to Step 5.
5	Check select cable for adjustment 1) Check select cable for adjustment referring to "Select Cable Adjustment". <i>Is it adjusted correctly?</i>	Go to Step 6.	Adjust.
6	Check transmission range sensor for installation position 1) Shift select lever to "N" range. 2) Check that "N" reference line on switch and center line on shaft are aligned. <i>Are check results satisfactory?</i>	Go to Step 7.	Adjust.
7	Check transmission range sensor 1) Check transmission range sensor referring to "Transmission Range Sensor Inspection and Adjustment". <i>Are check results satisfactory?</i>	"RED/BLK", "GRN", "RED", "GRN/YEL" or "LT GRN/BLK" circuit open. If wires and connections are OK, substitute a known-good TCM and recheck.	Replace Transmission range sensor.

Table for step 4

		Terminal					
		C07-20	C07-1	C07-8	C07-7	C07-19	C07-18
Select lever position	P	B + V	0 V	0 V	0 V	0 V	0 V
	R	0 V	B + V	0 V	0 V	0 V	0 V
	N	0 V	0 V	B + V	0 V	0 V	0 V
	D or 3	0 V	0 V	0 V	B + V	0 V	0 V
	2	0 V	0 V	0 V	0 V	B + V	0 V
	L	0 V	0 V	0 V	0 V	0 V	B + V

DTC P0711: Transmission Fluid Temperature Sensor “A” Circuit Range / Performance

S7RW0C5104023

Wiring Diagram

I7RW01510009-02

1. TCM	3. Terminal arrangement of TCM connector (viewed from harness side)
2. Transmission fluid temperature sensor	

DTC Detecting Condition and Trouble Area

DTC detecting condition	Trouble area
Transmission fluid temperature is no change and less than 20 °C (68 °F) while vehicle is running at 40 km/h (25 mile/h) or more for 10 minutes or more. (2 driving cycle detection logic but MIL does not light up)	- Transmission fluid temperature sensor or its circuit malfunction. - TCM

DTC Confirmation Procedure**⚠ WARNING**

- When performing a road test, select a place where there is no traffic or possibility of a traffic accident and be very careful during testing to avoid occurrence of an accident.
- Road test should be carried out with 2 persons, a driver and a tester, on a level road.

- 1) Clear DTC.
- 2) Drive vehicle and increase vehicle speed to 40 km/h (25 mile/h) for 10 minutes or more.
- 3) Check DTC, pending DTC and freeze frame data.

DTC Troubleshooting

Step	Action	Yes	No
1	Was "A/T System Check" performed?	Go to Step 2.	Go to "A/T System Check".
2	DTC check <i>Is DTC P0712 or DTC P0713 detected?</i>	Go to applicable DTC diag. flow.	Go to Step 3.
3	Check transmission fluid temperature sensor 1) Turn ignition switch to OFF position. 2) Disconnect connectors from TCM and transaxle (valve body harness connector). 3) Check transmission fluid temperature sensor for resistance referring to "Transmission Fluid Temperature Sensor Inspection". <i>Is it in good condition?</i>	Go to Step 4.	Replace transmission fluid temperature sensor.
4	Check transmission fluid temperature sensor circuit 1) Check the following circuit for high resistance. • Between "C06-11" terminal of TCM connector and "LT GRN" terminal of valve body harness connector. • Between "C06-12" terminal of TCM connector and "ORN" terminal of valve body harness connector. <i>Is each resistance 1 Ω or less?</i>	Substitute a known-good TCM and recheck.	Intermittent trouble. Check for intermittent referring to "Intermittent and Poor Connection Inspection in Section 00".

DTC P0712: Transmission Fluid Temperature Sensor "A" Circuit Low

S7RW0C5104024

Wiring Diagram

Refer to "DTC P0711: Transmission Fluid Temperature Sensor "A" Circuit Range / Performance".

DTC Detecting Condition and Trouble Area

DTC detecting condition	Trouble area
Transmission fluid temperature sensor signal voltage is less than specified value for more than 5 minutes while engine is running. (1 driving cycle detection logic but MIL does not light up)	- Transmission fluid temperature sensor or its circuit malfunction. - TCM

DTC Confirmation Procedure

- 1) Clear DTC.
- 2) Keep engine running at idle speed for 5 minutes or more.
- 3) Check DTC.

DTC Troubleshooting

Step	Action	Yes	No
1	Was "A/T System Check" performed?	Go to Step 2.	Go to "A/T System Check".
2	Check transmission fluid temperature sensor circuit for ground short 1) Turn ignition switch to OFF position. 2) Disconnect TCM connectors from TCM. 3) Check for proper connection to transmission fluid temperature sensor at terminals "C06-11" and "C06-12". 4) If OK, check continuity between terminals "C06-11" of disconnected harness side TCM connector and ground. <i>Is continuity indicated?</i>	"LT GRN" circuit shorted to ground.	Go to Step 3.

Step	Action	Yes	No
3	Check transmission fluid temperature sensor 1) Check transmission temperature sensor for resistance referring to "Transmission Fluid Temperature Sensor Inspection". <i>Is it in good condition?</i>	Intermittent trouble or faulty TCM. Check for intermittent referring to "Intermittent and Poor Connection Inspection in Section 00". If OK, substitute a known-good TCM and recheck.	Replace transmission fluid temperature sensor.

DTC P0713: Transmission Fluid Temperature Sensor "A" Circuit High

S7RW0C5104025

Wiring Diagram

Refer to "DTC P0711: Transmission Fluid Temperature Sensor "A" Circuit Range / Performance".

DTC Detecting Condition and Trouble Area

DTC detecting condition	Trouble area
Transmission fluid temperature sensor signal voltage is higher than specified value for 12 minutes while engine is running. (1 driving cycle detection logic but MIL does not light up)	- Transmission fluid temperature sensor or its circuit malfunction. - TCM

DTC Confirmation Procedure**⚠ WARNING**

- When performing a road test, select a place where there is no traffic or possibility of a traffic accident and be very careful during testing to avoid occurrence of an accident.
- Road test should be carried out with 2 persons, a driver and tester, on a level road.

- 1) Clear DTC.
- 2) Shift select lever to "D" range and drive vehicle for 15 minutes or more.
- 3) Stop vehicle and check DTC.


DTC Troubleshooting

Step	Action	Yes	No
1	Was "A/T System Check" performed?	Go to Step 2.	Go to "A/T System Check".
2	Check transmission fluid temperature sensor circuit for open 1) Turn ignition switch to OFF position. 2) Disconnect TCM connectors from TCM. 3) Check for proper connection to transmission fluid temperature sensor at terminals "C06-11" and "C06-12". 4) If OK, check continuity between terminals "C06-11" and "C06-12" of disconnected harness side TCM connector. <i>Is continuity indicated?</i>	Go to step 3.	"ORN" or "LT GRN" circuit open.

Step	Action	Yes	No
3	Check transmission fluid temperature sensor circuit for IG short 1) Cool down A/T fluid temperature under ambient temperature. 2) Connect TCM connectors to TCM with ignition switch turned OFF. 3) Turn ignition switch to ON position. 4) Measure voltage between terminal "C06-11" of TCM connector and ground. <i>Is it 5 V or more?</i>	"LT GRN" circuit shorted to power circuit. If circuit is OK, go to Step 4.	Intermittent trouble or faulty TCM. Check for intermittent referring to "Intermittent and Poor Connection Inspection in Section 00". If OK, substitute a known-good TCM and recheck.
4	Check transmission fluid temperature sensor 1) Check transmission temperature sensor for resistance referring to "Transmission Fluid Temperature Sensor Inspection". <i>Is it in good condition?</i>	Intermittent trouble or faulty TCM. Check for intermittent referring to "Intermittent and Poor Connection Inspection in Section 00". If OK, substitute a known-good TCM and recheck.	Replace transmission fluid temperature sensor.

DTC P0717: Input Speed Sensor "A" Circuit No Signal

S7RW0C5104026

Wiring Diagram

I7RW01510010-01

1. TCM	3. Terminal arrangement of TCM connector (viewed from harness side)
2. Input shaft speed sensor	

DTC Detecting Condition and Trouble Area

DTC detecting condition	Trouble area
Pulse signals of input shaft speed sensor are not input although pulse signals of output shaft speed sensor are input while vehicle is running. (1 driving cycle detection logic)	- Input shaft speed sensor or its circuit malfunction. - Improper input shaft speed sensor installation. - Damaged forward and direct clutches drum. - Foreign material attachment to sensor or drum. - TCM


DTC Confirmation Procedure

⚠ WARNING

- When performing a road test, select a place where there is no traffic or possibility of a traffic accident and be very careful during testing to avoid occurrence of an accident.
- Road test should be carried out with 2 persons, a driver and tester, on a level road.

- 1) Clear DTC.
- 2) Shift select lever to "D" range and drive vehicle at 70 km/h (44 mile/h) or more vehicle at least for 30 seconds.
- 3) Stop vehicle and check DTC.


DTC Troubleshooting

Step	Action	Yes	No
1	Was "A/T System Check" performed?	Go to Step 2.	Go to "A/T System Check".
2	Check input shaft speed sensor circuit 1) Disconnect TCM connectors with ignition switch turned OFF. 2) Check for proper connection to input shaft speed sensor at "C07-6" and "C07-16" terminals. 3) If OK, check resistance of sensor circuit. Resistance of input shaft speed sensor circuit Between terminals "C07-6" and "C07-16" of disconnected harness side TCM connector: 344 – 516 Ω at 20 °C (68 °F) Between terminal "C07-6" / "C07-16" of disconnected harness side TCM connector and ground: No continuity <i>Are they in good condition?</i>	Go to Step 4.	Go to Step 3.
3	Check input shaft speed sensor 1) Check input shaft speed sensor for resistance referring to "Input Shaft Speed Sensor Inspection". <i>Is it in good condition?</i>	"BLK" or "WHT" circuit open or short.	Replace input shaft speed sensor.
4	Check visually input shaft speed sensor and forward and direct clutches drum using mirror for the following • No damage • No foreign material attached • Correct installation  I2RH01510023-01 <i>Are they in good condition?</i>	Intermittent trouble or faulty TCM. Check for intermittent referring to "Intermittent and Poor Connection Inspection in Section 00". If OK, substitute a known-good TCM and recheck.	Clean, repair or replace.

DTC P0722: Output Speed Sensor Circuit No Signal

S7RW0C5104027

Wiring Diagram



I7RW01510011-01

1. TCM	3. Terminal arrangement of TCM connector (viewed from harness side)
2. Output shaft speed sensor	

DTC Detecting Condition and Trouble Area

DTC detecting condition	Trouble area
Pulse signals of output shaft speed sensor are not input although pulse signals of input shaft speed sensor are input while vehicle is running. (1 driving cycle detection logic)	• Output shaft speed sensor or its circuit malfunction. • Improper output shaft speed sensor installation. • Damaged sensor rotor. • Foreign material attachment to sensor or rotor. • TCM


DTC Confirmation Procedure

⚠ WARNING

- When performing a road test, select a place where there is no traffic or possibility of a traffic accident and be very careful during testing to avoid occurrence of an accident.
- Road test should be carried out with 2 persons, a driver and tester, on a level road.

- 1) Clear DTC.
- 2) Warm up engine to normal operating temperature.
- 3) Shift select lever to “D” range and drive vehicle at 70 km/h (44 mile/h) or more vehicle speed at least for 30 seconds.
- 4) Stop vehicle and check DTC.

DTC Troubleshooting

Step	Action	Yes	No
1	Was "A/T System Check" performed?	Go to Step 2.	Go to "A/T System Check".
2	Check output shaft speed sensor circuit 1) Disconnect TCM connectors with ignition switch turned OFF. 2) Check for proper connection to output shaft speed sensor at "C07-5" and "C07-14" terminals. 3) If OK, check resistance of sensor circuit. Resistance of input shaft speed sensor circuit Between terminals "C07-5" and "C07-14" of disconnected harness side TCM connector: 344 – 516 Ω at 20 °C (68 °F) Between terminal "C07-5" / "C07-14" of disconnected harness side TCM connector and ground: No continuity <i>Are they in good condition?</i>	Go to Step 4.	Go to Step 3.
3	Check output shaft speed sensor 1) Check output shaft speed sensor for resistance referring to "Output Shaft Speed Sensor Inspection". <i>Is it in good condition?</i>	"BLK" or "WHT" wire open or short.	Replace output shaft speed sensor.
4	Check visually output shaft speed sensor and sensor rotor using mirror for the following • No damage • No foreign material attached • Correct installation  I2RH01510023-01 <i>Are they in good condition?</i>	Intermittent trouble or faulty TCM. Check for intermittent referring to "Intermittent and Poor Connection Inspection in Section 00". If OK, substitute a known-good TCM and recheck.	Clean, repair or replace.

DTC P0741 / P0742: Torque Converter Clutch Circuit Performance or Stuck OFF / Stuck ON

S7RW0C5104028

DTC Detecting Condition and Trouble Area

DTC detecting condition	Trouble area
DTC P0741: Difference between engine speed and input shaft speed is larger than specification while TCC solenoid valve is turned ON. (2 driving cycle detection logic)	• Mechanical malfunction of TCC solenoid valve. • Malfunction of valve body assembly. • Fluid passage clogged or leaking. • Torque converter clutch malfunction.
DTC P0742: Difference between engine speed and input shaft speed is smaller than specification while TCC solenoid valve is turned OFF. (2 driving cycle detection logic)	

DTC Confirmation Procedure

⚠ WARNING

- When performing a road test, select a place where there is no traffic or possibility of a traffic accident and be very careful during testing to avoid occurrence of an accident.
- Road test should be carried out with 2 persons, a driver and tester, on a level road.

- 1) Clear DTC.
- 2) Start engine and warm it up to normal operating temperature.
- 3) Shift select lever to "D" range and keep it for 20 seconds or longer.
- 4) Drive vehicle with 3rd or 4th gear in "D" range and lock-up ON for 15 seconds or longer referring to "Automatic Gear Shift Table". (Reference: 50% throttle opening and at vehicle speed of 69 – 75 km/h (43 – 47 mile/h))
- 5) Stop vehicle and turn ignition switch OFF.
- 6) Repeat step 3) to 5).
- 7) Stop vehicle.
- 8) Check DTC, pending DTC and freeze frame data.

DTC Troubleshooting

Step	Action	Yes	No
1	Was "A/T System Check" performed?	Go to Step 2.	Go to "A/T System Check".
2	1) Check TCC solenoid valve for operation referring to "Solenoid Valves (Shift Solenoid Valves and TCC Solenoid Valve) Inspection". Is it in good condition?	Clean fluid passage or replace torque converter or valve body assembly.	Replace TCC solenoid valve.

DTC P0751 / P0752: Shift Solenoid "A" Performance or Stuck OFF / Shift Solenoid "A" Stuck ON

S7RW0C5104029

DTC Detecting Condition and Trouble Area

DTC detecting condition	Trouble area
DTC P0751: Actual gear position is different from commanded gear position of TCM (Shift solenoid valve – A does not turn ON). (2 driving cycle detection logic) DTC P0752: Actual gear position is different from commanded gear position of TCM (Shift solenoid valve – A does not turn OFF). (2 driving cycle detection logic)	• Mechanical malfunction of shift solenoid valve – A (No. 1). • Malfunction of valve body assembly. • Fluid passage clogged or leaking. • Mechanical malfunction of transaxle.

DTC Confirmation Procedure

⚠ WARNING

- When performing a road test, select a place where there is no traffic or possibility of a traffic accident and be very careful during testing to avoid occurrence of an accident.
- Road test should be carried out with 2 persons, a driver and a tester, on a level road.

- 1) Clear DTC.
- 2) Start engine and it up to normal operating temperature.
- 3) Shift select lever to "D" range and hold it for 20 seconds or longer.
- 4) Drive vehicle and increase vehicle speed to 40 km/h (25 mile/h) or more for longer than 15 seconds.
- 5) Stop vehicle and turn ignition switch OFF.
- 6) Repeat Step 3) to 5).
- 7) Check DTC, pending DTC and freeze frame data.

DTC Troubleshooting

Step	Action	Yes	No
1	Was "A/T System Check" performed?	Go to Step 2.	Go to "A/T System Check".
2	Check shift solenoid valve – A (No. 1) 1) Check shift solenoid valve – A (No. 1) for operation referring to "Solenoid Valves (Shift Solenoid Valves and TCC Solenoid Valve) Inspection". <i>Is it in good condition?</i>	Clean fluid passage or replace valve body assembly.	Replace shift solenoid valve – A (No. 1).

DTC P0756 / P0757: Shift Solenoid "B" Performance or Stuck OFF / Shift Solenoid "B" Stuck ON

S7RW0C5104030

DTC Detecting Condition and Trouble Area

DTC detecting condition	Trouble area
DTC P0756: Actual gear position is different from commanded gear position of TCM (Shift solenoid valve – B does not turn ON). (2 driving cycle detection logic) DTC P0757: Actual gear position is different from commanded gear position of TCM (Shift solenoid valve – B does not turn OFF). (2 driving cycle detection logic)	• Mechanical malfunction of shift solenoid valve – B (No. 2). • Malfunction of valve body assembly. • Fluid passage clogged or leaking. • Mechanical malfunction of transaxle.

DTC Confirmation Procedure**▲ WARNING**

- When performing a road test, select a place where there is no traffic or possibility of a traffic accident and be very careful during testing to avoid occurrence of an accident.
- Road test should be carried out with 2 persons, a driver and a tester, on a level road.


- 1) Connect scan tool to DLC with ignition switch turned OFF.
- 2) Clear DTC.
- 3) Start engine and it up to normal operating temperature.
- 4) Shift select lever to "D" range and hold it for 20 seconds or longer.
- 5) Drive vehicle and increase vehicle speed to 40 km/h (25 mile/h) or more for longer than 15 seconds.
- 6) Stop vehicle and turn ignition switch to OFF position.
- 7) Repeat Step 3) to 6).
- 8) Check DTC, pending DTC and freeze frame data.

DTC Troubleshooting

Step	Action	Yes	No
1	Was "A/T System Check" performed?	Go to Step 2.	Go to "A/T System Check".
2	Check shift solenoid valve – B (No. 2) 1) Check shift solenoid valve – B (No. 2) for operation referring to "Solenoid Valves (Shift Solenoid Valves and TCC Solenoid Valve) Inspection". <i>Is it in good condition?</i>	Clean fluid passage or replace valve body assembly.	Replace shift solenoid valve – B (No. 2).

DTC P0961: Pressure Control Solenoid “A” Control Circuit Range / Performance

S7RW0C5104031

Wiring Diagram

I7RW01510012-01

1. TCM	3. Terminal arrangement of TCM connector (viewed from harness side)
2. Pressure control solenoid valve	

DTC Detecting Condition and Trouble Area

DTC detecting condition	Trouble area
Difference between actual current of pressure control solenoid valve and current of pressure control solenoid valve calculated by TCM is more than specification. (1 driving cycle detection logic)	- Pressure control solenoid valve or its circuit malfunction - TCM

DTC Confirmation Procedure

- 1) Clear DTC.
- 2) Start engine at idle speed for 15 seconds or more.
- 3) Check DTC.

DTC Troubleshooting

Step	Action	Yes	No
1	Was "A/T System Check" performed?	Go to Step 2.	Go to "A/T System Check".
2	DTC check Is DTC P0962 or DTC P0963 detected?	Go to applicable DTC diag. flow.	Go to Step 3.
3	Check pressure control solenoid valve 1) Turn ignition switch to OFF position. 2) Disconnect connectors from TCM and transaxle (valve body harness connector). 3) Check pressure control solenoid valve for resistance referring to "Pressure Control Solenoid Valve Inspection". Is it in good condition?	Go to Step 4.	Replace pressure control solenoid valve.
4	Check pressure control solenoid valve circuit 1) Check the following circuit for high resistance. - Between "C06-2" terminal of TCM connector and "LT GRN/BLK" terminal of valve body harness connector. - Between "C06-4" terminal of TCM connector and "GRY" terminal of valve body harness connector. Is each resistance 1 Ω or less?	Substitute a known-good TCM and recheck.	Intermittent trouble. Check for intermittent referring to "Intermittent and Poor Connection Inspection in Section 00".

DTC P0962: Pressure Control Solenoid “A” Control Circuit Low

S7RW0C5104032

Wiring Diagram

Refer to “DTC P0961: Pressure Control Solenoid “A” Control Circuit Range / Performance”.


DTC Detecting Condition and Trouble Area

DTC detecting condition	Trouble area
Value of pressure control solenoid valve output current is too low for 12.5 seconds or more. (1 driving cycle detection logic)	- Pressure control solenoid valve or its circuit malfunction. - TCM

DTC Confirmation Procedure

- 1) Clear DTC.
- 2) Start engine and run it for 1 minute.
- 3) Check DTC.

DTC Troubleshooting

Step	Action	Yes	No
1	Was “A/T System Check” performed?	Go to Step 2.	Go to “A/T System Check”.
2	Check pressure control solenoid valve resistance 1) Turn ignition switch to OFF position. 2) Disconnect valve body harness connector (1) on transaxle. 3) Check for proper connection to “LT GRN” and “GRY” terminals of valve body harness connector. 4) Check resistance of pressure control solenoid valve. <u>Resistance of pressure control solenoid valve</u> Between (3) and (4) terminals of valve body harness connector: 3.3 – 3.7 Ω at 20 °C (68 °F) Between (3) terminal of valve body harness connector and vehicle body ground (2): Infinity  I7RW01510013-01 Is check results satisfactory?	Go to Step 4.	Replace pressure control solenoid valve or lead wire.
3	Check pressure control solenoid valve circuit for ground short 1) Connect valve body harness connector. 2) Disconnect TCM connectors. 3) Check for proper connection to TCM at terminals “C06-2” and “C06-4”. 4) If connections are OK, check continuity between terminal “C06-4” of disconnected harness side TCM connector and ground. Is continuity indicated?	“LT GRN/BLK” or “GRY” circuit shorted to ground.	Go to Step 5.


Step	Action	Yes	No
4	Check pressure control solenoid valve circuit for open 1) Check resistance between terminals "C06-2" and "C06-4" of disconnected harness side TCM connector. <i>Is it infinity?</i>	"LT GRN/BLK" or "GRY" circuit open.	Intermittent trouble or faulty TCM. Check for intermittent referring to "Intermittent and Poor Connection Inspection in Section 00". If OK, substitute a known-good TCM and recheck.

DTC P0963: Pressure Control Solenoid "A" Control Circuit High

S7RW0C5104033

Wiring Diagram

Refer to "DTC P0961: Pressure Control Solenoid "A" Control Circuit Range / Performance".



I7RW01510012-01

1. TCM	3. Terminal arrangement of TCM connector (viewed from harness side)
2. Pressure control solenoid valve	

DTC Detecting Condition and Trouble Area


DTC detecting condition	Trouble area
Value of pressure control solenoid valve output current is too high for 12.5 seconds or more. (1 driving cycle detection logic)	- Pressure control solenoid valve or its circuit malfunction. - TCM

DTC Confirmation Procedure

- 1) Clear DTC.
- 2) Start engine and run it for 1 minute.
- 3) Check DTC.


DTC Troubleshooting

Step	Action	Yes	No
1	<i>Was "A/T System Check" performed?</i>	Go to Step 2.	Go to "A/T System Check".
2	Check pressure control solenoid valve circuit for IG short 1) Turn ignition switch to OFF position and disconnect TCM connectors. 2) Check for proper connection to "C06-2" and "C06-4". 3) If OK, turn ignition switch to ON position and measure voltage between "C06-4" terminal of disconnected harness side TCM connector and ground. <i>Is it 0 V?</i>	Go to Step 3.	"LT GRN/BLK" or "GRY" circuit shorted to power circuit.

Step	Action	Yes	No
3	Check pressure control solenoid valve resistance 1) Turn ignition switch to OFF position. 2) Disconnect valve body harness connector (1) on transaxle. 3) Check for proper connection to "LT GRN/BLK" and "GRY" terminals of valve body harness connector. 4) Check resistance of pressure control solenoid valve. Resistance of pressure control solenoid valve Between (3) and (4) terminals of valve body harness connector: 3.3 – 3.7 Ω at 20 °C (68 °F) Between (3) terminal of valve body harness connector and vehicle body ground (2): Infinity  I7RW01510013-01 <i>Is check results satisfactory?</i>	Intermittent trouble or faulty TCM. Check for intermittent referring to "Intermittent and Poor Connection Inspection in Section 00". If OK, substitute a known-good TCM and recheck.	Replace pressure control solenoid valve or lead wire.

DTC P0973 / P0976: Shift Solenoid "A" Control Circuit Low / Shift Solenoid "B" Control Circuit Low

S7RW0C5104034

Wiring Diagram

1. Shift solenoid valve-A (No. 1)	3. TCM
2. Shift solenoid valve-B (No. 2)	4. Terminal arrangement of TCM connector (viewed from harness side)


DTC Detecting Condition and Trouble Area

DTC detecting condition	Trouble area
DTC P0973: Difference between command signal and monitor signal of shift solenoid valve – A (shift solenoid valve – A circuit is shorted to ground). (1 driving cycle detection logic) DTC P0976: Difference between command signal and monitor signal of shift solenoid valve – B (shift solenoid valve – B circuit is shorted to ground). (1 driving cycle detection logic)	- Shift solenoid valve – A (No. 1) or its circuit malfunction. (P0973) - Shift solenoid valve – B (No. 2) or its circuit malfunction. (P0976) - TCM

DTC Confirmation Procedure

- 1) Clear DTC.
- 2) Start engine and run it for 30 seconds.
- 3) Check DTC.

DTC Troubleshooting

Step	Action	Yes	No
1	Was "A/T System Check" performed?	Go to Step 2.	Go to "A/T System Check".
2	Check shift solenoid valve resistance 1) Turn ignition switch to OFF position. 2) Disconnect valve body harness connector (1) on transaxle. 3) Check for proper connection to "BRN" and "BLK/YEL" terminals of valve body harness connector. 4) Check resistance of shift solenoid valve. Resistance of shift solenoid valve Between shift solenoid valve–A (No. 1) terminal (2) and vehicle body ground (4): 12 – 16 Ω at 20 °C (68 °F) Between shift solenoid valve–B (No. 2) terminal (3) and vehicle body ground (4): 11 – 15 Ω at 20 °C (68 °F)  Is check result satisfactory?	Go to Step 3.	Replace shift solenoid valve or lead wire.

I4RH01510247-01

Step	Action	Yes	No
3	Check shift solenoid circuit for ground short valve circuit 1) Disconnect TCM connectors. 2) Check for proper connection to "C06-15" and "C06-16" terminals of TCM connector. 3) If connections are OK, check continuity between "C06-15" or "C06-16" terminals of disconnected harness side TCM connector and ground. <i>Is continuity indicated?</i>	"BRN" or "BLK/YEL" circuit shorted to ground.	Intermittent trouble or faulty TCM. Check for intermittent referring to "Intermittent and Poor Connection Inspection in Section 00". If OK, substitute a known-good TCM and recheck.

DTC P0974 / P0977: Shift Solenoid "A" Control Circuit High / Shift Solenoid "B" Control Circuit High

S7RW0C5104035

Wiring Diagram

Refer to "DTC P0973 / P0976: Shift Solenoid "A" Control Circuit Low / Shift Solenoid "B" Control Circuit Low".

DTC Detecting Condition and Trouble Area

DTC detecting condition	Trouble area
DTC P0974: Difference between command signal and monitor signal of shift solenoid valve – A (shift solenoid valve – A circuit is open or shorted to power supply circuit). (1 driving cycle detection logic) DTC P0977: Difference between command signal and monitor signal of shift solenoid valve – B (shift solenoid valve – B circuit is open or shorted to power supply circuit). (1 driving cycle detection logic)	- Shift solenoid valve – A (No. 1) or its circuit malfunction. (P0974) - Shift solenoid valve – B (No. 2) or its circuit malfunction. (P0977) - TCM


DTC Confirmation Procedure**▲ WARNING**

- When performing a road test, select a place where there is no traffic or possibility of a traffic accident and be very careful during testing to avoid occurrence of an accident.
- Road test should be carried out with 2 persons, a driver and tester, on a level road.

- 1) Clear DTC.
- 2) Start engine and run it for 30 seconds.
- 3) Check DTC.

DTC Troubleshooting

Step	Action	Yes	No
1	Was "A/T System Check" performed?	Go to Step 2.	Go to "A/T System Check".
2	Check shift solenoid valve circuit for IG short 1) Turn ignition switch to OFF position and disconnect TCM connectors. 2) Check for proper connection to "C06-15" and "C06-16" terminals of TCM connector. 3) If OK, turn ignition switch to ON position and measure voltage between "C06-15" or "C06-16" terminals of disconnected harness side TCM connector and ground. <i>Is it 0 – 2 V?</i>	Go to Step 3.	"BRN" or "BLK/YEL" circuit shorted to power circuit.

Step	Action	Yes	No
3	Check shift solenoid valve resistance 1) Turn ignition switch to OFF position. 2) Disconnect valve body harness connector (1) on transaxle. 3) Check for proper connection to "BRN" and "BLK/YEL" terminals of valve body harness connector. 4) Check resistance of shift solenoid valve. Resistance of shift solenoid valve Between shift solenoid valve-A (No. 1) terminal (2) and vehicle body ground (4): 12 – 16 Ω at 20 °C (68 °F) Between shift solenoid valve-B (No. 2) terminal (3) and vehicle body ground (4): 11 – 15 Ω at 20 °C (68 °F)  I4RH01510247-01 <i>Is check result satisfactory?</i>	Go to Step 4.	Replace shift solenoid valve or lead wire.
4	Check shift solenoid circuit for open 1) Connect valve body harness connector. 2) Measure resistance between "C06-15" or "C06-16" terminals of disconnected harness side TCM connector and ground. <i>Is it 12 – 16 Ω (at 20 °C (68 °F))?</i>	Intermittent trouble or faulty TCM. Check for intermittent referring to "Intermittent and Poor Connection Inspection in Section 00". If OK, substitute a known-good TCM and recheck.	"BRN" or "BLK/YEL" circuit open or high resistance.

DTC P0602 / P1702: Control Module Programming Error / Internal Control Module Check Sum Error

S7RW0C5104036

System Description

Internal control module is installed in ECM.

DTC Detecting Condition and Trouble Area

DTC detecting condition	Trouble area
DTC P0602: Data programming error. (1 driving cycle detection logic) DTC P1702: Data write error or check sum error. (1 driving cycle detection logic)	TCM

DTC Confirmation Procedure

- 1) Clear DTC.
- 2) Start engine and run it at idle if possible.
- 3) Check DTC.


DTC Troubleshooting

Step	Action	Yes	No
1	DTC check 1) Clear DTC referring to "DTC Clearance". 2) Turn ignition switch to OFF position. 3) Turn ignition switch to ON position and recheck DTC. <i>Is DTC P0602 or P1702 still detected?</i>	Substitute a known-good TCM and recheck.	Intermittent trouble. Check for intermittent referring to "Intermittent and Poor Connection Inspection in Section 00".

DTC P1723: Range select switch malfunction

S7RW0C5104037

Wiring Diagram



1. TCM	3. Terminal arrangement of TCM connector (viewed from harness side)
2. "3" position switch	

DTC Detecting Condition and Trouble Area

DTC detecting condition	Trouble area
"3" position switch ON signal is inputted although transmission range sensor signal is inputted P, R, N or L range. (1 driving cycle detection logic)	"3" position switch or its circuit malfunction - TCM

DTC Confirmation Procedure

- 1) Clear DTC.
- 2) Start engine and then shift select lever to each of "P", "R", "N" or "L" ranges for 10 seconds each.
- 3) Check DTC.

DTC Troubleshooting

Step	Action	Yes	No
1	Was "A/T System Check" performed?	Go to Step 2.	Go to "A/T System Check".
2	Check "3" position switch signal 1) Connect SUZUKI scan tool to DLC with ignition switch turned OFF. 2) Turn ignition switch to ON position and check "3" position switch signal display on SUZUKI scan tool when shifting select lever to each range. <i>Does indicate "3" position switch OFF when shifting select lever to "P", "R", "N" and "L" range?</i>	Intermittent trouble. Check for intermittent referring to "Intermittent and Poor Connection Inspection in Section 00". If OK, substitute a known-good TCM and recheck.	Go to Step 3.


5A-54 Automatic Transmission/Transaxle:

Step	Action	Yes	No
3	Check “3” position switch circuit 1) Measure voltage between “C07-9” terminal of TCM connector and ground. “3” position switch specifications Shift select lever to “3” or “2” range: Battery voltage Shift select lever to other above range: 0 V <i>Is check result satisfactory?</i>	Intermittent trouble. Check for intermittent referring to “Intermittent and Poor Connection Inspection in Section 00”. If OK, substitute a known-good TCM and recheck.	“YEL” wire is open or shorted to ground. If wire is OK, replace “3” position switch.

DTC P2763: Torque Converter Clutch Pressure Control Solenoid Control Circuit High

S7RW0C5104038

Wiring Diagram



1. TCC solenoid valve	3. Terminal arrangement of TCM connector (viewed from harness side)
2. TCM	

DTC Detecting Condition and Trouble Area


DTC detecting condition	Trouble area
Difference between command signal and monitor signal of TCC lock-up solenoid valve (TCC lock-up solenoid valve circuit is open or shorted to power supply circuit). (1 driving cycle detection logic)	- TCC solenoid valve and its circuit malfunction. - TCM

DTC Confirmation Procedure

- 1) Clear DTC.
- 2) Start engine and run it for 30 seconds.
- 3) Check DTC.

DTC Troubleshooting

Step	Action	Yes	No
1	Was “A/T System Check” performed?	Go to Step 2.	Go to “A/T System Check”.
2	Check TCC solenoid valve circuit for IG short 1) Measure voltage between “C06-5” terminal of harness side TCM connector and ground with ignition switch turned ON. <i>Is it 0 – 2 V?</i>	Go to Step 3.	“WHT/BLU” circuit shorted to power circuit or open.

Step	Action	Yes	No
3	Check TCC solenoid valve resistance 1) Turn ignition switch to OFF position. 2) Disconnect valve body harness connector (1) on transaxle. 3) Check for proper connection to "WHT/BLU" terminal of valve body harness connector. 4) Check resistance of TCC solenoid valve. <u>Resistance between terminal (2) of valve body harness connector and vehicle body ground (3)</u> 11 – 15 Ω (at 20 °C (68 °F))  I4RH01510248-01 <i>Is check result satisfactory?</i>	Intermittent trouble or faulty TCM. Check for intermittent referring to "Intermittent and Poor Connection Inspection in Section 00". If OK, substitute a known-good TCM and recheck.	Replace TCC solenoid valve or lead wire.

DTC P2764: Torque Converter Clutch Pressure Control Solenoid Control Circuit Low

S7RW0C5104039

Wiring Diagram

Refer to "DTC P2763: Torque Converter Clutch Pressure Control Solenoid Control Circuit High".

DTC Detecting Condition and Trouble Area


DTC detecting condition	Trouble area
Difference between command signal and monitor signal of TCC lock-up solenoid valve (TCC lock-up solenoid valve circuit is shorted to ground). (1 driving cycle detection logic)	• TCC solenoid valve and its circuit malfunction. • TCM

DTC Confirmation Procedure**⚠ WARNING**

- When performing a road test, select a place where there is no traffic or possibility of a traffic accident and be very careful during testing to avoid occurrence of an accident.
- Road test should be carried out with 2 persons, a driver and a tester, on a level road.

- 1) Clear DTC.
- 2) Start engine and warm it up to normal operating temperature.
- 3) Drive vehicle with 3rd or 4th gear in "D" range and lock-up ON for 10 seconds or longer referring to "Automatic Gear Shift Table". (Reference: less than 20% throttle opening and at vehicle speed of 80 km/h (50 mile/h) or more)
- 4) Decrease vehicle speed gradually and stop vehicle.
- 5) Check DTC.

DTC Troubleshooting

Step	Action	Yes	No
1	Was "A/T System Check" performed?	Go to Step 2.	Go to "A/T System Check".
2	Check TCC solenoid valve resistance 1) Turn ignition switch to OFF position. 2) Disconnect valve body harness connector (1) on transaxle. 3) Check for proper connection to "WHT/BLU" terminal of valve body harness connector. 4) Check resistance of TCC solenoid valve. <u>Resistance between terminal (2) of valve body harness connector and vehicle body ground (3)</u> 11 – 15 Ω (at 20 °C (68 °F))  I4RH01510248-01	Go to Step 3.	Replace TCC solenoid valve or lead wire.
	Is check result satisfactory?		
3	Check TCC solenoid circuit for ground short 1) Disconnect TCM connectors. 2) Check for proper connection to "C06-5" terminal of TCM connector. 3) If connection is OK, check continuity between "C06-5" terminal of disconnected harness side TCM connector and ground. Is continuity indicated?	"WHT/BLU" circuit shorted to ground.	Intermittent trouble or faulty TCM. Check for intermittent referring to "Intermittent and Poor Connection Inspection in Section 00". If OK, substitute a known-good TCM and recheck.

DTC U0073: Control Module Communication Bus Off

S7RW0C5104040

Refer to "Troubleshooting for CAN-DTC in Section 1A".

DTC U0100: Lost Communication with ECM

S7RW0C5104041

Refer to "Troubleshooting for CAN-DTC in Section 1A".

Inspection of TCM and Its Circuits

S7RW0C5104042

TCM and its circuits can be checked at TCM wiring connectors by measuring voltage and resistance.

⚠ CAUTION


TCM cannot be checked by itself, it is strictly prohibited to connect voltmeter or ohmmeter to TCM with connector disconnected from it.

Inspection


- 1) Remove TCM (1) from vehicle referring to "Transmission Control Module (TCM) Removal and Installation".
- 2) Connect TCM connectors (2) to TCM.
- 3) Check voltage and/or pulse signal at each terminal of connectors connected using voltmeter (3) and oscilloscope (4).

NOTE

- As each terminal voltage is affected by battery voltage, confirm that it is 11 V or more when ignition switch is ON.
- Voltage with asterisk (*) cannot be measured by voltmeter because it is pulse signal. Check it with oscilloscope if necessary.



Terminal arrangement of TCM coupler (Viewed from harness side)



Connector "C06"

Terminal	Wire color	Circuit	Standard voltage	Condition
C06-1	BLK	Ground for TCM	0 – 1 V	Ignition switch is at ON position.
C06-2	LT GRN/ BLK	Ground for pressure control solenoid valve	0.6 – 1.0 V	Ignition switch is at ON position.
C06-3	—	—	—	—
C06-4	GRY	Output for pressure control solenoid valve	* 0 – 1 V ↑↓ 10 – 14 V ("Reference waveform No. 1: ")	Engine is running at idle speed. (Output signal is duty pulse. Duty ratio varies depending on throttle valve opening.)
C06-5	WHT/BLU	Output for TCC pressure control solenoid valve	* 0 – 1 V ↑↓ 10 – 14 V ("Reference waveform No. 2: ")	Vehicle is running. (Sensor signal is pulse. Pulse frequency varies depending on vehicle condition.)
C06-6	YEL/BLK	Main power source	10 – 14 V	Ignition switch is at ON position.
C06-7	WHT	CAN communication line (active low signal)	* 0.5 – 2.5 V ("Reference waveform No. 3: ")	Ignition switch is at ON position. (CAN communication line signal is pulse. Pulse signal frequency varies depending on engine condition.)
C06-8	—	—	—	—
C06-9	—	—	—	—
C06-10	—	—	—	—
C06-11	LT GRN	Signal for transmission fluid temperature sensor	2.9 – 3.1 V	Ignition switch is at ON position and transmission fluid temperature is 20 °C (68 °F).
			0.3 – 0.5 V	Ignition switch is at ON position and transmission fluid temperature is 100 °C (212 °F).
C06-12	ORN	Ground for transmission fluid temperature sensor	0 – 1 V	Ignition switch is at ON position.
C06-13	—	—	—	—
C06-14	—	—	—	—
C06-15	BLK/YEL	Shift solenoid valve – B (No. 2)	10 – 14 V	Ignition switch is at ON position and select lever is at other than "P", "R" or "N" range.
C06-16	BRN	Shift solenoid valve – A (No. 1)	0 – 1 V	Ignition switch is at ON position and select lever is all ranges.
C06-17	RED	CAN communication line (active high signal)	* 2.5 – 4.5 V ("Reference waveform No. 3: ")	Ignition switch is at ON position. (CAN communication line signal is pulse. Pulse signal frequency varies depending on engine condition.)
C06-18	—	—	—	—
C06-19	—	—	—	—
C06-20	—	—	—	—
C06-21	—	—	—	—
C06-22	—	—	—	—
C06-23	BLK	Ground for TCM	0 – 1 V	Ignition switch is at ON position.
C06-24	WHT/RED	Power source for back-up	10 – 14 V	Ignition switch is at ON position.


Connector "C07"

Terminal	Wire color	Circuit	Standard voltage	Condition
C07-1	RED	"R" range signal for transmission range sensor	10 – 14 V	Ignition switch is at ON position and select lever is at "R" range.
			0 – 1 V	Ignition switch is at ON position and select lever is at other than "R" range.
C07-2	—	—	—	—
C07-3	—	—	—	—
C07-4	—	—	—	—
C07-5	WHT	Signal for output shaft speed sensor	2 – 3 V	Ignition switch is at ON position.
			* ("Reference waveform No. 4: ")	Vehicle is running. (Output signal is pulse. pulse frequency varies depending on output shaft speed.)
C07-6	BLK	Signal for input shaft speed sensor	2 – 3 V	Ignition switch is at ON position.
			* ("Reference waveform No. 5: ")	Engine is running at idle speed. (Output signal is pulse. Pulse frequency varies depending on output shaft speed.)
C07-7	GRN	"D" range signal for transmission range sensor	10 – 14 V	Ignition switch is at ON position and select lever is at "D" or "3" range.
			0 – 1 V	Ignition switch is at ON position and select lever is at other than "D" range.
C07-8	GRN/ORN	"N" range signal for transmission range sensor	10 – 14 V	Ignition switch is at ON position and select lever is at "N" range.
			0 – 1 V	Ignition switch is at ON position and select lever is at other than "N" range.
C07-9	YEL	"3" position switch	10 – 14 V	Ignition switch is at ON position and select lever is at other than "3" or "2" range.
			0 – 1 V	Ignition switch is at ON position and select lever is at "3" or "2" range.
C07-10	—	—	—	—
C07-11	—	—	—	—
C07-12	—	—	—	—
C07-13	—	—	—	—
C07-14	BLK	Ground for output shaft speed sensor	0 – 3 V	Ignition switch is at ON position.
C07-15	—	—	—	—
C07-16	WHT	Ground for input shaft speed sensor	0 – 3 V	Ignition switch is at ON position.
C07-17	—	—	—	—
C07-18	LT GRN/ BLK	"L" range signal for transmission range sensor	10 – 14 V	Ignition switch is at ON position and select lever is at "L" range.
			0 – 1 V	Ignition switch is at ON position and select lever is at other than "L" range.
C07-19	GRN/YEL	"2" range signal for transmission range sensor	10 – 14 V	Ignition switch is at ON position and select lever is at "2" range.
			0 – 1 V	Ignition switch is at ON position and select lever is at other than "2" range.
C07-20	PNK/BLK	"P" range signal for transmission range sensor	10 – 14 V	Ignition switch is at ON position and select lever is at "P" range.
			0 – 1 V	Ignition switch is at ON position and select lever is at other than "P" range.
C07-21	—	—	—	—
C07-22	—	—	—	—
C07-23	BLU	Data link connector	10 – 14 V	Ignition switch is at ON position.
C07-24	—	—	—	—
C07-25	—	—	—	—
C07-26	—	—	—	—

Reference waveform No. 1

Signal of pressure control solenoid valve.

Measurement terminal	CH1: "C06-4" to "C06-2"
Oscilloscope setting	CH1: 5 V/DIV TIME: 2 ms/DIV
Measurement condition	Engine running at specified idle speed after warmed up engine.




I7RW01510019-01

Reference waveform No. 2

Signal of TCC pressure control solenoid valve.

Measurement terminal	CH1: "C06-5" to "C06-1"
Oscilloscope setting	CH1: 10 V/DIV TIME: 10 ms/DIV
Measurement condition	Drive vehicle at 60 km/h (37 mile/h) or higher after warmed up engine.




I7RW01510020-01

Reference waveform No. 3

High and low of CAN communication signals.

Measurement terminal	CH1: "C06-7" to "C06-1" CH2: "C06-17" to "C06-1"
Oscilloscope setting	CH1: 1 V/DIV, CH2: 1 V/DIV TIME: 40 μ s/DIV
Measurement condition	Ignition switch is at ON position.




I7RW01510021-01

1. CAN communication line signal (high)
2. CAN communication line signal (low)

Reference waveform No. 4

Signal of output shaft speed sensor.

Measurement terminal	CH1: "C07-5" to "C06-1"
Oscilloscope setting	CH1: 2 V/DIV TIME: 4 ms/DIV
Measurement condition	Drive vehicle at 40 km/h (25 mile/h) after warmed up engine.




I7RW01510022-01

Reference waveform No. 5

Signal of input shaft speed sensor.


Measurement terminal	CH1: "C07-6" to "C06-1"
Oscilloscope setting	CH1: 1 V/DIV TIME: 4 ms/DIV
Measurement condition	Engine running at specified idle speed after warmed up engine.



I7RW01510023-01

TCM Power and Ground Circuit Check

S7RW0C5104043

Wiring Diagram

I7RW01510024-01

1. TCM	3. Ignition switch
2. A/T relay	4. Terminal arrangement of TCM connector (viewed from harness side)


Troubleshooting

Step	Action	Yes	No
1	Check TCM back-up power supply circuit 1) Disconnect connectors from TCM with ignition switch turned OFF. 2) Check for proper connection to "C06-6" and "C06-24" terminals of TCM connector. 3) If OK, measure voltage between "C06-24" terminal of disconnected TCM connector and ground. <i>Is voltage 10 – 14 V?</i>	Go to Step 2.	"WHT/RED" circuit is open or shorted to ground.
2	Check TCM power supply circuit 1) Turn ignition switch to ON position. 2) Measure voltage between "C06-6" terminal of disconnected TCM connector and ground. <i>Is voltage 10 – 14 V?</i>	Go to Step 5.	Go to Step 3.
3	Check A/T relay 1) Turn ignition switch to OFF position. 2) Remove A/T relay. 3) Check A/T relay for operation referring to "A/T Relay Inspection". <i>Is it in good condition?</i>	Go to Step 4.	Replace A/T relay.
4	Check TCM power supply circuit 1) Turn ignition switch to ON position. 2) Measure voltage between "YEL/BLU" and "LT GRN/BLK" terminals of A/T relay connector and ground. <i>Is each voltage 10 – 14 V?</i>	Go to Step 5.	"YEL/BLU" and/or "LT GRN/BLK" circuit are open or shorted to ground.
5	Check TCM ground circuit 1) Turn ignition switch to OFF position. 2) Check for proper connection to "C06-1" and "C06-23" terminals of TCM connector. 3) Measure resistance as follows. - Between "C06-1" terminal of TCM connector and vehicle body ground. - Between "C06-23" terminal of TCM connector and vehicle body ground. <i>Is each resistance 1 Ω or less?</i>	Substitute a known-good TCM and recheck.	"BLK" circuit is open.

Brake Interlock System Inspection

S7RW0C5104044


- 1) Check that select lever cannot be moved to any other range from "P" range position when ignition switch key is at ACC position, at LOCK position or it is removed from keyhole of ignition switch, or brake pedal is not depressed.



I7RW01510025-01


- 2) Shift select lever to "P" range position, check for the following.

- Ignition key can be turned between LOCK and ACC positions back and forth and also it can be removed from ignition switch.




I7RW01510026-01

- With ignition switch turned to ACC position, push shift lock solenoid release plate (1). Then, select lever can be shifted from "P" range position to any other range.
- While ignition switch is at LOCK position, even when shift lock solenoid release plate (1) is pressed, select lever cannot be shifted from P range position to any other range.




I7RW01510027-01

- When ignition switch is turned ON and brake pedal is depressed, select lever can be shifted from "P" range position to any other range.



I7RW01510028-01

- 3) With select lever shifted to any position other than "P" range, check that ignition key cannot be turned LOCK position and it cannot be removed from ignition switch unless it is at LOCK position.



I7RW01510031-01

Repair Instructions

A/T Fluid Level Check

S7RW0C5106001

Level Check at Normal Operation Temperature


- 1) Stop vehicle and place it level.
- 2) Apply parking brake and place chocks against wheels.
- 3) With select lever at "P" position, start engine.
- 4) Warm up engine till fluid temperature reaches normal operating temperature (70 – 80 °C / 158 – 176 °F). As a guide to check fluid temperature, warm up engine to normal operating temperature.
- 5) Keep engine idling and shift select lever slowly to "L" and back to "P" position.
- 6) With engine idling, pull out fluid level gauge, wipe it off with a clean cloth and put it back into place.
- 7) Pull out fluid level gauge (1) again and check fluid level indicated on it. The lowest fluid level should be between FULL HOT and LOW HOT. If it is below LOW HOT, add an equivalent of DEXRON®-III up to FULL HOT.

Automatic transaxle fluid

An equivalent of DEXRON®-III

NOTE

- Do not race engine while checking fluid level, even after the engine start.
- Do not overfill. Overfilling can cause foaming and loss of fluid through breather. Then slippage and transaxle failure can result.
- Bringing the level from LOW HOT to FULL HOT requires 0.4 liters (0.85 / 0.70 US/Imp pt.).
- If vehicle was driven under high load such as pulling a trailer, fluid level should be checked about half an hour after it is stopped.



I4RH01510249-01

1. Fluid level gauge	4. "FULL COLD" mark
2. "FULL HOT" mark	5. "LOW COLD" mark
3. "LOW HOT" mark	


A/T Fluid Change

S7RW0C5106002

- 1) Lift up vehicle.
- 2) When engine is cool, remove drain plug (1) from transaxle housing (2) and drain A/T fluid.
- 3) Install a new gasket to drain plug.
- 4) Install drain plug (1).

Tightening torque

A/T fluid drain plug (a): 40 N·m (4.0 kgf-m, 29.0 lb-ft)




I4RH01510023-01

- 5) Lower vehicle and fill proper amount of an equivalent of DEXRON®-III
- 6) Check fluid level referring to "A/T Fluid Level Check".

Automatic transaxle fluid
: An equivalent of DEXRON®-III

Automatic transaxle fluid capacity
When draining from drain plug hole: 4.5 liters (7.92 / 9.60 US/Imp pt.)
When overhauling: 7.3 liters (12.85 / 15.57 US/ Imp pt.)




I4RH01510249-01

1. Fluid level gauge	4. "FULL COLD" mark
2. "FULL HOT" mark	5. "LOW COLD" mark
3. "LOW HOT" mark	

Select Lever Components

S7RW0C5106003



I7RW01510032-01

1. Shift lock solenoid	3. Connector
2. Select lever assembly	4. "3" position switch

Select Lever Assembly Removal and Installation

S7RW0C5106004

Remove and install select lever referring to "Select Lever Components".

When installing select lever noting the following.

- After installing select lever, adjust select cable referring to "Select Cable Adjustment".

Select Lever Knob Installation


S7RW0C5106005

Screw select lever knob onto select lever by specified numbers of rotation below.

Rotation numbers for select lever knob installation
(a): 11 – 12 rotations

⚠ CAUTION

When installing select lever knob, do not turn more than specified numbers of rotation. Otherwise select lever knob is damaged.



I7RW01510033-01

Select Lever Inspection

S7RW0C5106006

Check select lever for smooth and clear-cut movement individually. If a malfunction is found, replace select lever assembly.

“3” Position Switch Inspection


S7RW0C5106007

- 1) Remove console box referring to “Console Box Components in Section 9H”.
- 2) Disconnect “3” position switch connector (1).
- 3) Check continuity between “3” position switch terminals.
If check result is not as satisfied, replace.

“3” position switch specification

Shift select lever to “3” or “2” range: Continuity

Shift other above range: No continuity




I7RW01510040-01

Shift Lock Solenoid Inspection

S7RW0C5106008

Check that shift lock solenoid rod (1) moves smoothly when battery voltage is conducted and it moves back. If solenoid rod does not move smoothly, replace.




I7RW01510041-01

Shift Lock Solenoid Replacement

S7RW0C5106009


- 1) Remove console box referring to “Console Box Components in Section 9H”.
- 2) Remove shift lock solenoid (1) using slotted screwdriver or the like.
- 3) Install shift lock solenoid.
- 4) Install covers as they were.



I7RW01510042-01

Select Cable Components

S7RW0C5106010



I7RW01510034-01

1. Select lever assembly	6. Manual select lever pin : Apply lithium grease 99000-25010 to all around pin (0.15 g)	11. Heater inlet hose
2. Select cable	7. Select lever pin : Apply lithium grease 99000-25010 to all around pin (0.15 g)	12. Clamp
3. Cable bracket	8. Adjuster case	: 23 N·m (2.0 kgf-m, 17.0 lb-ft)
4. Manual select lever	9. Lock	: 6.5 N·m (0.65 kgf-m, 5.0 lb-ft)
5. Clip	10. EPS control module (EPS model)	: 12 N·m (1.2 kgf-m, 8.0 lb-ft)

Select Cable Removal and Installation

S7RW0C5106011

Removal

- 1) Remove parking brake lever cover.
- 2) Remove console box.
- 3) Disconnect select cable from select lever and then detach from bracket.
- 4) Remove clip and disconnect select cable from manual shift.
- 5) Remove select cable retainer from dash panel.

Installation


Install select cable by reversing removal procedure. The important steps in installation are as follows.

- Apply grease to pin and cable joint.
- Tighten bolts to specified torque referring to "Select Cable Components".
- Adjust select cable referring to "Select Cable Adjustment".

Select Cable Adjustment


S7RW0C5106012

- 1) Remove adjuster (cable end) from select lever pin of select lever assembly.
- 2) Shift manual shift lever (1) to "N" range (transmission range sensor "N" range) aligning arrow (2) of lever (1) with "N" reference line (3).




I4RH01510025-01

- 3) Release lock plate (1) which restricts moving of cable end holder (2).



I2RH01510046-01

- 4) Push cable end holder (1) out from eye-end (2) using an appropriate tool (3) to disengage cable.




I2RH01510047-01

- 5) Shift select lever to "N" position.
- 6) Apply grease to select lever pin and install adjuster (cable end) to it.

: Grease 99000-25010 (SUZUKI Super Grease A)

- 7) With both select lever and transmission range sensor kept each "N" position, drive cable end holder (1) in until it locks cable.
- 8) Slide lock plate (2) to secure cable end holder in position.



I3RM0B510037-01

- 9) After select cable was installed, check for the following.
 - Push vehicle with select lever shifted to "P" range. Vehicle should not move.
 - Vehicle can not be driven in "N" range.
 - Vehicle can be driven in "D", "3", "2" and "L" ranges.
 - Vehicle can be backed in "R" range.

Key Interlock Cable Removal and Installation


S7RW0C5106013

NOTE

Don't bend interlock cable excessively when removing and installing it, or system will not operate correctly.


Removal

- 1) If the vehicle is equipped with air bag system, disconnect negative cable at battery and disable air bag system, referring to "Disabling Air Bag System in Section 8B".
- 2) Remove steering column cover.
- 3) Turn ignition switch to ACC position.
- 4) Pull out key interlock cable (1) from key cylinder cover (2) while pressing checkhook with slotted screwdriver (3) or the like.



I5RW0C510045-01



- 5) Turn ignition switch to LOCK position.
- 6) Remove console box referring to "Console Box Components in Section 9H".
- 7) Detach cable end (1) from interlock cam (2) while pressing claws (3) of interlock cam boss. At this time, be careful not to cause damage to its claws.
- Detach cable casing cap (4) from bracket (5) while pressing checkhook.
- 8) Remove interlock cable.



I5RW0C510046-01

Installation


- 1) Lay interlock cable to its original cabling route.



I5RW0C510073-01


[A]: LH steering vehicle	2. Clamp	6. EPS control module
[B]: RH steering vehicle	3. Steering lock assembly / Steering lock unit (if equipped with keyless start system)	7. Brake switch bracket
[C]: View C	4. key cylinder cover	8. Wiring harness
1. Key interlock	5. Select lever assembly	9. Marking

- 2) Turn ignition switch to ACC position.
- 3) Insert cable casing cap (1) into key cylinder cover (2) securely.



I5RW0C510047-01

- 4) Pull out lock button (1) of select lever side cable end (2).




I2RH01510086-01

- 5) Shift select lever to "N" position.

NOTE

If select lever is in "P" position, shift select lever referring to "Select Lever Inspection".

- 6) Install cable casing cap (3) to bracket (4).
- 7) Connect cable end (1) to interlock cam (2) with ignition switch turned to ACC position.
- 8) Drive lock button (5) in cable end until it locks cable expansion and contraction.



I5RW0C510048-01

- 9) With select lever set at "P" position, turn ignition key to ACC position and then check for the following conditions.

- With knob button released, ignition key can be turned from ACC position to LOCK position.
- With knob button pressed, ignition key cannot be turned from ACC position to LOCK position.

- 10) Install knee protector to steering column.

- 11) Install steering column cover.


- 12) If the vehicle is equipped with air bag system, connect negative cable at battery and enable air bag system, referring to "Enabling Air Bag System in Section 8B".

Transmission Range Sensor Inspection and Adjustment

S7RW0C5106014

Inspection

- 1) Disconnect transmission range sensor connector (1).
- 2) Check that continuity exists at terminals as shown in the following figure by moving select lever. If check result is not as specified, adjust switch.



		Terminal No.									
		1	2	3	4	5	6	7	8	9	10
Sensor Position	P	○	○							○	○
	R				○						○
	N		○				○			○	○
	D								○		○
	2			○							○
	L					○					○

I5RH01510007-01

Adjustment



- 1) Shift manual shift lever (1) to "N" range.
- 2) Connect ohmmeter between 6 and 10 terminals of disconnected transmission range sensor connector (3).
- 3) Turn transmission range sensor (2) gradually to find position where ohmmeter reading indicates continuity. Then fix transmission range sensor (2) at that position by tightening bolts and nut to specified torque.

Tightening torque

Transmission range sensor bolt (a): 25 N·m (2.5 kgf-m, 18.0 lb-ft)

Transmission range sensor nut (b): 7.5 N·m (0.75 kgf-m, 5.5 lb-ft)

- 4) Connect transmission range sensor connector (3).
- 5) Check that engine starts in "N" and "P" ranges but it doesn't start in "D", "3", "2", "L" or "R" range. Also, check that back-up light turn ON in "R" range.




I5RH01510008-01

Output Shaft Speed Sensor Removal and Installation

S7RW0C5106015

Removal

- 1) Disconnect negative cable at battery.
- 2) Disconnect output shaft speed sensor connector (2).
- 3) Remove output shaft speed sensor (1) by removing its bolt.



I7RW01510035-01

3. Battery


Installation

- 1) Apply A/T fluid to new output shaft speed sensor O-ring.
- 2) Install output shaft speed sensor (1) to A/T case and tighten bolt to specified torque.

Tightening torque

Output shaft speed sensor bolt (a): 5.5 N·m (0.55 kgf-m, 4.0 lb-ft)

- 3) Connect output shaft speed sensor connector (2) to output shaft speed sensor (1).



I7RW01510036-01

3. Battery

- 4) Connect negative cable to battery.


Output Shaft Speed Sensor Inspection

S7RW0C5106016

- 1) Disconnect negative cable at battery.
- 2) Disconnect output shaft speed sensor connector (2).
- 3) Check resistance between output shaft speed sensor (1) terminals. If check result is not as specified, replace sensor.

Output shaft speed sensor resistance

Standard: 344 – 516 Ω at 20 °C (68 °F)




I4RH01510030-01

Input Shaft Speed Sensor Removal and Installation

S7RW0C5106017

Removal

- 1) Remove battery and battery tray.
- 2) Disconnect input shaft speed sensor connector (2).
- 3) Remove input shaft speed sensor (1) by removing its bolt.



I7RW01510037-01

3. Transmission range sensor


Installation

- 1) Apply A/T fluid to new input shaft speed sensor O-ring.
- 2) Install input shaft speed sensor (1) to A/T case and tighten bolt to specified torque.

Tightening torque

Input shaft speed sensor bolt (a): 5.5 N·m (0.55 kgf-m, 4.0 lb-ft)

- 3) Connect input shaft speed sensor connector (2) to input shaft speed sensor (1).



I7RW01510038-02

3. Transmission range sensor

- 4) Install battery tray and battery.


Input Shaft Speed Sensor Inspection

S7RW0C5106018

- 1) Disconnect negative cable at battery.
- 2) Disconnect input shaft speed sensor connector (2).
- 3) Check resistance between input shaft speed sensor (1) terminals. If check result is not as specified, replace sensor.

Input shaft speed sensor resistance

Standard: 344 – 516 Ω at 20 °C (68 °F)




I4RH01510033-01

Transmission Fluid Temperature Sensor Removal and Installation

S7RW0C5106019


Removal

- 1) Disconnect negative cable at battery.
- 2) Disconnect transmission fluid temperature sensor connector (1).



I7RW01510039-01

- 3) Lift up vehicle.
- 4) With engine is cool, drain A/T fluid referring to "A/T Fluid Change".
- 5) Remove transmission fluid temperature sensor (1) with O-ring.




I4RH01510035-01

Installation

- 1) Apply A/T fluid to new O-ring.
- 2) Install new O-ring to transmission fluid temperature sensor.
- 3) Install transmission fluid temperature sensor (1), and tighten A/T fluid temperature sensor to specified torque.


Tightening torque

Transmission fluid temperature sensor: 10 N·m (1.0 kgf-m, 7.5 lb-ft)



I4RH01510035-01

- 4) Pour A/T fluid referring to "A/T Fluid Change".
- 5) Connect transmission fluid temperature sensor connector (1).



I7RW01510039-01

- 6) Connect negative cable.
- 7) Verify that there is no A/T fluid leakage.

Transmission Fluid Temperature Sensor Inspection


S7RW0C5106020

- 1) Remove transmission temperature sensor referring to "Transmission Fluid Temperature Sensor Removal and Installation".
- 2) Immerse temperature sensing part of sensor (1) in A/T fluid and check resistance between sensor terminals while heating A/T fluid gradually. If check result is not as specified, replace sensor. After inspection, install transmission fluid temp. sensor and connect connector.

Transmission fluid temperature sensor resistance (Temperature: Resistance)

0 °C (32 °F): 1844 – 2290 Ω

160 °C (320 °F): 19.2 – 22.2 Ω




I4RH01510036-01

Solenoid Valves (Shift Solenoid Valves, TCC Solenoid Valve and Pressure Control Solenoid Valve) Removal and Installation

S7RW0C5106021


Removal

- 1) Disconnect negative cable at battery.
- 2) Drain A/T fluid referring to "A/T Fluid Change".
- 3) Remove transaxle side cover (1).




I4RH01510038-01

- 4) Remove solenoid harness from clamp.
- 5) Disconnect solenoid connectors (1).




I4RH01510039-01

- 6) Remove pressure control solenoid valve (2) after removing bolt (1).



I4RH01510040-01

- 7) Remove TCC solenoid valve (1), shift solenoid valve-B (No. 2) (2) and shift solenoid valve-A (No. 1) (3) by removing bolts.




I4RH01510041-01

Installation

- 1) Apply A/T fluid to new O-rings of solenoid valves and pressure control solenoid.
- 2) Install new O-rings to each solenoid valves and pressure control solenoid.
- 3) Install shift solenoid valve-A (No. 1) (1), shift solenoid valve-B (No. 2) (2) and TCC solenoid valve (3).

Tightening torque

Shift solenoid bolts (a): 7.0 N·m (0.7 kgf-m, 5.0 lb-ft)




I4RH01510042-01

- 4) Install pressure control solenoid (1).

Tightening torque

Pressure control solenoid bolt (a): 7.0 N·m (0.7 kgf-m, 5.0 lb-ft)

Valve body bolt (b): 10.0 N·m (1.0 kgf-m, 7.5 lb-ft)



I4RH01510043-01

- 5) Connect solenoid connectors by identifying wire color.


Solenoid coupler: Wire color

Pressure control solenoid valve (1): Blue + Brown

Shift solenoid valve-A (No. 1) (2): White

Shift solenoid valve-B (No. 2) (3): Black


TCC solenoid valve (4): Yellow



I4RH01510044-01

- 6) Clean mating surface transaxle case.
- 7) Apply sealant to mating surface of transaxle side cover and transaxle case by using a nozzle (1) as shown in figure by such amount that its section is 1.5 mm (0.059 in) in diameter.

“A”: Sealant 99000–31230 (SUZUKI Bond No.1216B)




I4RH01510045-01

- 8) Install new transaxle side cover (1) by tightening new torx® bolts to specified torque.

Tightening torque

Transaxle side cover bolts (a): 13 N·m (1.3 kgf-m, 9.40 lb-ft)



I4RH01510046-01

- 9) Pour A/T fluid referring to “A/T Fluid Change”.
- 10) Verify that there is no A/T fluid leakage.

Solenoid Valves (Shift Solenoid Valves and TCC Solenoid Valve) Inspection

S7RW0C5106022

Resistance Check

Shift solenoid valve-A (No. 1), -B (No. 2) and TCC solenoid valve

Shift solenoid valve-A resistance


Standard: 12 – 16 Ω at 20 °C (68 °F)

Shift solenoid valve-B resistance

Standard: 11 – 15 Ω at 20 °C (68 °F)

TCC solenoid valve resistance

Standard: 11 – 15 Ω at 20 °C (68 °F)




I2RH01510068-01

Operation Check

Shift solenoid valve-A (No. 1) and -B (No. 2)


- Check that solenoid valve (1) actuate with click sound when battery voltage is conducted.
- Apply oiler (2) to solenoid valve (1) and give compression by hands and then check to be sure that transaxle fluid from oiler does not come out of holes in solenoid valve when battery voltage is not conducted.
- Under the same conditions, conduct battery voltage and then make sure that fluid comes out with vigor. If check result is not as described, replace shift solenoid valve.



I5RH01510009-01

TCC solenoid valve

- Check that solenoid valve (1) actuate with click sound when battery voltage is conducted.
- Apply oiler (2) to solenoid valve (1) and give compression by hands and then check to be sure that transaxle fluid from oiler does not come out of holes in solenoid valve when battery voltage is conducted.
- Under the same conditions, release battery voltage and then make sure that fluid comes out with vigor. If check result is not as described, replace shift solenoid valve.



I5RH01510010-01

Pressure Control Solenoid Valve Inspection


S7RW0C5106023

Resistance Check

Check resistance between pressure control solenoid valve (1) terminals. If check result is not as specified, replace solenoid valve.

Pressure control solenoid valve resistance

Standard: 3.3 – 3.7 Ω (at 20 °C (68 °F))



I2RH01510071-01

Operation Check


Check pressure control solenoid valve operation in the either manner of the following.

Using regulated DC power supply

- 1) Connect pressure control solenoid valve (1) with regulated DC power supply (2) as shown in the figure.
- 2) Turn regulated DC power supply switch ON and increase voltage of power supply keeping current within 1.0 A.
- 3) Check for gradual movement of valve (3) in the direction of arrow "A" as voltage is increased.
- 4) Check movement of valve (3) in the direction of arrow "B" as voltage is decreased.
- 5) Turn power supply switch OFF.

⚠ CAUTION

Do not pass current 1.0 A or more, or pressure control solenoid is burned out.




I2RH01510072-01

Not using regulated DC power supply

- 1) Connect pressure control solenoid valve (1) to battery (2) setting the 8 – 10 W bulb (4) on the way as shown in the figure.
- 2) Check for movement of valve (3) in the direction of arrow "A".
- 3) Disconnect pressure control solenoid valve (1) from battery (2) and check movement of valve (3) in the direction of arrow "B" as shown in the figure.

⚠ CAUTION

Set 8 – 10 W bulb on the way, or pressure control solenoid valve is burned out.



I5RH01510011-01

Transmission Control Module (TCM) Removal and Installation


S7RW0C5106024

⚠ CAUTION

TCM consists of highly precise parts, therefore when handling it, be careful not to expose to excessive shock.

Removal

- 1) Disconnect negative cable at battery.
- 2) If the vehicle is equipped with air bag system, disable air bag system. Refer to "Disabling Air Bag System in Section 8B".
- 3) Remove glove box.
- 4) Disconnect connectors from TCM (1).
- 5) Remove TCM by removing its nuts.



I5RW0C510040-01

Installation

Reverse removal procedure noting the following.

- Connect TCM connectors securely.
- If the vehicle is equipped with air bag system, be sure to enable air bag system after TCM is back in place. Refer to "Enabling Air Bag System in Section 8B".


Differential Side Oil Seal Replacement

S7RW0C5106025

- 1) Lift up vehicle and drain A/T fluid.
- 2) Remove drive shaft joints from differential gear of transaxle. Refer to "Front Drive Shaft Assembly Removal and Installation: Front in Section 3A" for procedure to disconnect drive shaft joints. For differential side oil seal removal, it is not necessary to remove drive shafts from steering knuckle.
- 3) Remove differential side oil seal by using screw driver or the like.
- 4) Apply grease to new differential side oil seal lip.
: **Grease 99000-25030 (SUZUKI Super Grease C)**
- 5) Press-fit new differential side oil seal (1) until transaxle case end face (2) is flush with oil seal end, using special tool.

Special tool

(A): 09924-07730




I4RH01510047-01

- 6) Install drive shaft referring to "Front Drive Shaft Assembly Removal and Installation: Front in Section 3A".
- 7) Pour A/T fluid referring to "A/T Fluid Change".

A/T Fluid Cooler Hoses Inspection

S7RW0C5106026

Check automatic transaxle fluid cooler hoses (1) for fluid leakage, cracks, damage and deterioration. Replace hose and/or clamp if any faulty condition is found.




I6RW0C510006-01

A/T Fluid Cooler Hoses Replacement

S7RW0C5106027

The rubber hoses for the A/T fluid cooler should be replaced at specified interval. When replacing them, be sure to note the following.

- to replace clamps at the same time
- to insert hose as far as its limit mark
- to clamp clamps securely





I4RH01510258-01

- | |
|--|
| 1. Radiator |
| 2. Inlet hose (Outlet from A/T fluid cooler) |
| 3. Outlet hose (Inlet to A/T fluid cooler) |

A/T Relay Inspection

S7RW0C5106028


- 1) Disconnect negative cable at battery.
- 2) Remove A/T relay (1), from fuse box.
- 3) Check that there is no continuity between terminal "c" and "d". If there is continuity, replace relay.
- 4) Connect battery positive (+) terminal to terminal "b" of relay. Connect battery negative (-) terminal to terminal "a" of relay. Check for continuity between terminal "c" and "d". If there is no continuity when relay is connected to the battery, replace relay.



I7RW01510059-02

Automatic Transaxle Unit Components

S7RW0C5106029



I7RW01510044-02


1. Clutch housing plate	4. Torque converter	7. Drive plate bolt
2. Transaxle to engine nut	5. Drive plate to torque converter bolt	8. Clutch housing plate bolt (M6 and M10) : First tighten M16 bolt and next tighten M16 bolt
3. Transaxle to engine bolt	6. Drive plate	: Tightening torque

Automatic Transaxle Unit Dismounting and Remounting

S7RW0C5106030


Dismounting

- 1) Take down transaxle with engine. For its procedure, refer to “Engine Assembly Removal and Installation in Section 1D”.
- 2) Remove engine rear mounting No. 1 bracket and engine rear mounting No. 2 bracket with stiffener (for 2WD vehicle).
- 3) Remove transfer referring to “Transfer Dismounting and Remounting in Section 3C” (for 4WD vehicle).
- 4) Remove center bearing support bolts (3) and remove center bearing support (2) with center shaft (1) from differential side gear (for 2WD vehicle).




I2RH01510089-01

- 5) Remove clutch housing plate (1).



I7RW01510045-01

- 6) Remove torque converter bolts.
To lock drive plate (1), engage a flat head rod or the like (2) with drive plate gear.



I7RW01510046-01

- 7) Remove starting motor.
- 8) Remove bolts and nut fastening engine and transaxle, then detach transaxle from engine.

NOTE

When detaching transaxle from engine, move it in parallel with crankshaft and use care so as not to apply excessive force to drive plate and torque converter.

⚠ WARNING

Be sure to keep transaxle with torque converter horizontal or facing up throughout the work. Should it be tilted with torque converter down, converter may fall off and cause personal injury.

Remounting


- 1) Make sure that torque converter is installed correctly to transaxle.
Refer to "Automatic Transaxle Unit Assembly".
- 2) Attach transaxle to engine.

Tightening torque

Transaxle to engine bolts and nut (a): 85 N·m (8.5 kgf-m, 61.5 lb-ft)

⚠ WARNING

Be sure to keep transaxle with torque converter horizontal or facing up throughout the work. Should it be tilted with torque converter down, converter may fall off and cause personal injury.




I7RW01510047-01

- 3) Tighten drive plate-torque converter bolts. Align drive plate bolt hole and torque converter through then tighten bolts through torque converter housing lower plate opening. Lock drive plate (1) by engaging a flat head rod or the like (2) with drive plate gear.

Tightening torque

Drive plate to torque converter bolts (a): 23 N·m (2.3 kgf-m, 16.5 lb-ft)




I7RW01510048-01

- 4) Install clutch housing plate. Tighten clutch housing plate bolts (a) first and next (b) with specified torque.

Tightening torque

Clutch housing plate bolt (M6) (a): 11 N·m (1.1 kgf-m, 8.0 lb-ft)

Clutch housing plate bolt (M10) (b): 30 N·m (3.0 kgf-m, 21.5 lb-ft)



I7RW01510049-01

- 5) Install starter motor referring to "Starting Motor Dismounting and Remounting in Section 1I".
- 6) Install center shaft (1) to differential gear (for 2WD vehicle). Tighten center bearing support bolts to specified torque.
For tightening torque of center bearing support bolts, refer to "Front Drive Shaft Assembly Components Location: Front in Section 3A".


⚠ CAUTION

Be careful not to scratch oil seal lip with center shaft while inserting.

- 7) Install engine rear mounting brackets and stiffener (for 2WD vehicle).
- 8) Install transfer referring to "Transfer Dismounting and Remounting in Section 3C" (for 4WD vehicle).
- 9) Remount engine with transaxle assembly to vehicle. Refer to "Engine Assembly Removal and Installation in Section 1D" for its procedure.

Automatic Transaxle Assembly Components


S7RW0C5106031



I7RW01510050-02

1. Torque converter	6. Input shaft speed sensor	11. O-ring	ⓧ : Tightening torque
2. Transaxle housing	7. Output shaft speed sensor	12. Underdrive brake accumulator bracket	ⓧ : Do not reuse.
3. Valve body harness	8. Parking lock pawl	13. Manual shift shaft	
4. Transmission range sensor	9. Underdrive brake accumulator spring	14. Parking lock rod	

5. Transmission fluid temperature sensor	10. Underdrive brake accumulator piston	15. Manual detent spring
--	---	--------------------------




I4RH01510251-01

1. Transaxle rear cover	14. Planetary front gear	27. Thrust washer	40. Underdrive brake
2. Oil seal ring	15. Thrust bearing	28. One-way No. 1 clutch	41. Snap ring
3. Bearing race	16. Front planetary ring gear	29. O-ring	42. Underdrive brake piston cover
4. Oil seal ring	17. Thrust bearing	30. Oil pump, 2nd coast brake and 2nd brake	43. Underdrive brake piston rod
5. Thrust bearing	18. Bearing race	31. Thrust bearing	44. Underdrive brake piston return spring

5A-84 Automatic Transmission/Transaxle:

6. Bearing race	19. Snap ring	32. Bearing race	45. Differential side right bearing race
7. Input shaft	20. Retaining plate	33. Underdrive gear assembly	46. Differential gear
8. Thrust bearing	21. Friction plate	34. Thrust bearing	47. Differential side left bearing race
9. Planetary sun gear	22. Separate plate	35. Bearing race	48. Shim
10. Thrust bearing	23. Snap ring	36. Underdrive clutch assembly	 : Apply automatic transaxle fluid.
11. Rear planetary ring gear	24. 1st / reverse brake piston return spring	37. Thrust bearing	 : Tightening torque
12. Thrust bearing	25. 1st / reverse brake piston	38. Snap ring	 : Do not reuse.
13. Bearing race	26. Reduction drive gear assembly	39. One-way No. 3 clutch	



I7RW01510051-01

1. Countershaft front bearing	5. Transaxle housing	9. Manual shift shaft oil seal	13. Oil reservoir LH plate	 : Do not reuse.
2. Oil seal ring	6. Differential side oil seal	10. Gasket	14. Oil strainer	
3. Transaxle lubrication tube	7. Transaxle lubrication tube	11. O-ring	15. Transaxle side cover	
4. Oil reservoir RH plate	8. Gasket	12. Oil seal ring	 : Tightening torque	

Automatic Transaxle Unit Disassembly

S7RW0C5106032


⚠ CAUTION

- Thoroughly clean transaxle exterior before overhauling it.
- Keep working table, tools and hands clean while overhauling.
- Use special care to handle aluminum parts so as not to damage them.
- Do not expose removed parts to dust. Keep them always clean.

1) Extract torque converter (1).



⚠ CAUTION

Remove torque converter as much straight as possible. Leaning it may cause to damage oil seal lip.



I4RH01510054-01

- 2) Remove fluid level gauge (1), fluid filler tube (2), output shaft speed sensor (3) and input shaft speed sensor (4) (for speedometer).
- 3) Disconnect transmission fluid temperature sensor connector (6) and remove transmission fluid temperature sensor (7).




I7RW01510052-01

- 4) Pull out transmission range sensor assembly (1).
 - a) Remove nut, washer and manual shift lever (2).
 - b) Pry off lock washer (4).
 - c) Remove lock nut (3).
 - d) Remove lock washer (4).
 - e) Remove bolt (5) and nut (6).


NOTE

Never reuse lock washer after removal.



I7RW01510053-01

5) Remove transaxle side cover (1) by removing bolts.




I4RH01510057-01

6) Remove solenoid harness from clamp.

7) Disconnect pressure control solenoid, shift solenoid-A, shift solenoid-B and TCC solenoid connectors (1, 2, 3, 4).

8) Remove solenoid harness (5) with O-ring.




I4RH01510058-01

9) Remove valve body assembly (1) by removing 9 bolts (4), and then disconnect manual valve connecting rod (2) from manual valve lever (3).


⚠ CAUTION

Be careful not to let manual valve fall off when removing valve body assembly.



I4RH01510059-01


10) Remove 2 gaskets (1).



I4RH01510060-01

11) Remove 17 bolts (1) of transaxle housing.

12) Remove 8 bolts (2) of oil pump body.





I4RH01510061-01

- 13) Remove transaxle housing with oil pump (1), using special tool, and then remove oil pump body (2) by hand.


Special tool

(A): 09912-34510



I5RH01510013-01


- 14) Clean and wipe off gasket sealant on mating surface between transaxle housing and transaxle case.
- 15) Remove oil reservoir RH plate (1) by removing 3 bolts.
- 16) Remove transaxle lubrication tube (2) by removing the bolt and prying up both ends of the tube.



I4RH01510063-01


3. Transaxle housing

- 17) Remove countershaft front bearing (1) using bearing puller.





I4RH01510064-01

- 18) Remove differential gear assembly (1).
- 19) Remove one-way No. 1 clutch assembly (2) and one-way No. 1 clutch front thrust washer (3).
- 20) Remove oil strainer assembly (4) by removing bolt (5).




I4RH01510065-01

- 21) Loosen 11 bolts of transaxle rear cover.
- 22) Lightly and uniformly tap two rib sections of transaxle rear cover (1), using plastic hammer.
- 23) Pull out transaxle rear cover (1) and input shaft rear thrust bearing rear race (2).




I5RH01510014-01

- 24) Remove 4 gaskets (1) from transaxle case.
- 25) Remove tube clamp (2) and transaxle lubrication tube (3) prying up both ends of the tube.




I4RH01510067-01

- 26) Remove forward and direct clutch assembly (1), thrust bearing (2) and bearing front race (3) of input shaft rear side.




I4RH01510068-01

- 27) Remove planetary gear (1) and planetary sun gear (2) with the input shaft front thrust bearing (3) installed.




I4RH01510069-01

- 28) Remove snap ring (1) using flat end rod or the like.
- 29) Remove front planetary ring gear and one-way No. 2 clutch (2) with front planetary ring gear rear thrust bearing (3).
- 30) Remove retaining plates "R", friction plates "F" and separator plates "S" in the following order.
R → F → S → F → S → F → S → F → S → F → R



I4RH01510070-01

- 31) Remove front thrust bearing (2) and bearing race (1) of front planetary ring gear.
- 32) Remove retainer ring (3) and 1st / reverse brake piston return spring (4).




I4RH01510071-01

- 33) Remove 1st / reverse brake piston (1) with O-ring installed while applying and releasing compressed air (400 – 800 kPa, 4 – 8 kg/cm², 57 – 113 psi) through oil hole section (2).


NOTE

If piston will not pop out, it is recommended to use needle nose pliers for removal.




I4RH01510072-01

- 34) Remove reduction drive gear (2) by removing retainer ring (1).





I4RH01510073-01

- 35) Remove oil reservoir LH plate (1).




I4RH01510074-01

- 36) Remove parking lock pawl bracket and manual detent spring (1).
- 37) Remove parking lock pawl shaft (2), torsion spring (3) and parking lock pawl (4).
- 38) Remove parking lock rod (5) and manual shift shaft (6).




I5RH01510015-01

- 39) Remove underdrive gear assembly (1) with bearing (2) and bearing race (3).




I4RH01510076-01

- 40) Remove torsion spring (1), spacer (2) and underdrive brake accumulator bracket (3).



I4RH01510077-01


- 41) Remove underdrive brake accumulator cover (1), piston (2) and spring (3) while applying and releasing compressed air (400 – 800 kPa, 4 – 8 kg/cm², 57 – 113 psi) through oil hole (4).



I4RH01510078-01


- 42) Remove underdrive brake band anchor bolt (1) with O-ring (2), using special tool.

Special tool
(A): 09927-68010




I7RW01510062-02

- 43) Remove underdrive clutch assembly (1) with bearing (2) and race (3).



I4RH01510080-01



- 44) Remove underdrive clutch thrust bearing (1).
45) Remove underdrive brake band (2).



I4RH01510081-01

46) Remove underdrive brake piston as follows.


- a) Using special tool, compress underdrive brake piston cover (2) and remove snap ring using pliers or the like.
- b) Remove cover (2), piston (3) and spring (4) by applying compressed air (400 – 800 kPa, 4 – 8 kg/cm², 57 – 113 psi) from oil hole (1).



I5RH01510016-01


47) Remove snap ring (1) using flat end rod or the like.

48) Remove one-way No. 3 clutch (2).



I4RH01510083-01

49) Remove 2 oil seal rings (1).




I4RH01510084-01

50) Remove differential side oil seal (1) using special tools.

Special tool


(A): 09913-75821

(B): 09924-84510-005



I4RH01510085-01


51) Remove manual shift shaft oil seal (1) using flat end rod or the like.



I4RH01510086-01

Oil Pump 2nd Coast Brake and 2nd Brake Components

S7RW0C5106033



I4RH01510087-01

 1. Oil pump oil seal	8. O-ring	15. Snap ring	22. Friction plate
2. Oil pump body	9. 2nd brake piston	16. 2nd coast brake piston	23. Retaining plate
3. Oil pump driven gear	10. 2nd brake piston return spring	17. O-ring	24. Snap ring
4. Oil pump drive gear	11. Cushion plate	18. 2nd coast brake piston return spring	 : Apply automatic transaxle fluid.
5. Oil pump O-ring	12. Separator plate	19. Snap ring	 : Do not reuse.
6. Oil pump plate	13. Friction plate	20. 2nd coast brake thrust washer	
7. Starter shaft	14. Retaining plate	21. Separator plate	

2nd Coast Brake and 2nd Brake Preliminary Check

S7RW0C5106034

- 1) Measure 2nd brake piston stroke while applying and releasing compressed air (400 – 800 kPa, 4 – 8 kg/cm², 57 – 113 psi) through oil hole (1) by using special tools.
If measured piston stroke exceeds specified value, disassemble and inspect inner parts.


Special tool

(A): 09900–20607

(B): 09900–20701

2nd brake piston stroke

Standard: 1.91 – 2.69 mm (0.075 – 0.106 in.)



2. 2nd brake piston

- 2) Measure 2nd coast brake piston stroke while applying and releasing compressed air (400 – 800 kPa, 4 – 8 kg/cm², 57 – 113 psi) through oil hole (1) by using special tools.
If measured piston stroke exceeds specified valve, disassemble and inspect inner parts.


Special tool

(A): 09900–20607

(B): 09900–20701

2nd coast brake piston stroke

Standard: 0.82 – 1.66 mm (0.032 – 0.156 in.)




2. 2nd coast brake piston

Oil Pump, 2nd Coast Brake and 2nd Brake Disassembly and Reassembly

S7RW0C5106035

Disassembly

- 1) Remove 2nd coast brake thrust washer (1).



- 2) Using special tool and hydraulic press (1), compress 2nd brake piston return spring (2) until spring seat is pushed down to 1 – 2 mm (0.039 – 0.078 in.) lower than snap ring groove and remove snap ring (3).


Special tool

(A): 09941–51010

⚠ CAUTION

Be careful when applying pressure, for overpressure will cause plate section of 2nd brake piston return spring to deform.

- 3) Remove retaining plate, friction plates and separator plates.



- 4) Using special tool and hydraulic press (1), compress 2nd coast brake piston return spring (2) until spring seat is pushed down to 1 – 2 mm (0.039 – 0.078 in.) lower than snap ring groove and remove snap ring (3).


Special tool

(A): 09926–98350

CAUTION

Be careful when applying pressure, for overpressure will cause plate section of 2nd coast brake piston return spring to deform.

- 5) Remove 2nd coast brake piston return spring (2).




I4RH01510092-01

- 6) Remove 2nd coast brake piston (1) with O-rings by applying compressed air (400 – 800 kPa, 4 – 8 kg/cm², 57 – 113 psi) from through oil hole (2).


NOTE

If piston does not pop out, it is recommended to use needle-nose pliers for removal.



I4RH01510093-01

- 7) Remove snap ring (1), using flat end rod or the like.
8) Remove retaining plate, friction plates, separator plates and cushion plate.
9) Remove 2nd brake piston return spring (2).




I4RH01510094-01

- 10) Remove 2nd brake piston (1) with O-rings applying compressed air (400 – 800 kPa, 4 – 8 kg/cm², 57 – 113 psi) from through oil hole (2).


NOTE

If piston does not pop out, it is recommended to use needle-nose pliers for removal.




I4RH01510095-01

- 11) Remove stator shaft (1) by removing 14 bolts (2).



I4RH01510096-01

- 12) Remove oil pump plate (1), driven gear (2) and drive gear (3).
- 13) Remove O-ring.




I4RH01510097-01

- 14) Remove oil pump oil seal (1), using special tool.

Special tool
(A): 09913-50121

NOTE

Never reuse removed oil seal.




I4RH01510098-01

Reassembly

- 1) Press-fit new oil pump oil seal (1) using special tool and hammer and then apply grease to its lip portion.


Special tool
(A): 09913-85210

: Grease 99000-25030 (SUZUKI Super Grease C)



I4RH01510099-01

- 2) After applying A/T fluid to gears, install driven gear (1) and drive gear (2) to oil pump body (3) aligning marks on the gears.
- 3) Apply A/T fluid to new O-ring (4) and install it to oil pump body.
- 4) Install oil pump plate (5).




I4RH01510100-01

- 5) Install stator shaft (1) to oil pump body and tighten bolts (2) to specification.

Tightening torque

Oil pump cover bolts (a): 6.5 N·m (0.65 kgf-m, 4.7 lb-ft)

Oil pump cover bolts (b): 12 N·m (1.2 kgf-m, 8.7 lb-ft)




I4RH01510096-01

- 6) After applying A/T fluid to new O-rings and install it to 2nd brake piston.
- 7) Press 2nd brake piston into starter shaft.

NOTE

Do not twist or deviate O-rings during installation.




I4RH01510101-01

- 8) Install 2nd brake piston return spring.
- 9) Install cushion plate "C", separator plates "S", friction plates "F" and retaining plate "R" with flat end facing to friction plates side in the following order.
C → S → F → S → F → S → F → S → F → R
- 10) Install snap ring.

NOTE

Make sure that opening end of ring is not aligned with groove section of starter shaft.




I4RH01510102-01

- 11) Apply A/T fluid to new O-rings and install them to 2nd coast brake piston.
- 12) Press 2nd coast brake piston (1) into starter shaft (2).

NOTE

Do not twist or deviate O-rings during installation.



I4RH01510103-01

- 13) Install 2nd coast brake piston return spring (1).
- 14) Using special tool and hydraulic press (2), compress 2nd coast brake piston return spring (1) until spring seat is pushed down to 1 – 2 mm (0.039 – 0.078 in.) lower than snap ring groove and install snap ring (3).

Special tool


(A): 09926–98350

⚠ CAUTION

Be careful when applying pressure, for overpressure will cause plate section of spring to deform.

NOTE

- When installing return spring, be careful so that return spring will not fall or tilt.
- Do not align opening in snap ring with lug of 2nd coast brake piston return spring at its retainer section.



I4RH01510104-01

- 15) Install separator plates "S", friction plates "F" and retaining plate "R" in the following order.
S → F → S → F → R

NOTE

Make sure that 2nd brake piston return spring is inserted in 2nd coast brake retaining plate boss.

- 16) Using special tool and hydraulic press (1), compress 2nd brake piston return spring (2) until spring seat is pushed down to 1 – 2 mm (0.039 – 0.078 in.) lower than snap ring groove and install snap ring.

Special tool


(A): 09941-51010

⚠ CAUTION

Be careful when applying pressure, for overpressure will cause plate section of spring to deform.

NOTE

- When installing return spring, be careful so that return spring will not fall or tilt.
- Do not align opening in snap ring with lug of 2nd brake piston return spring at its retainer section.



I4RH01510105-01

- 17) Measure 2nd brake piston stroke again, using special tools.
If measured piston stroke exceeds specified value, check for an improper installation.


Special tool

(A): 09900-20607

(B): 09900-20701

2nd brake piston stroke

Standard: 1.91 – 2.69 mm (0.075 – 0.106 in.)



I4RH01510106-01

- 18) Measure 2nd coast brake piston stroke, using special tools.
If measured piston stroke exceeds specified value, check for an improper installation.


Special tool

(A): 09900-20607

(B): 09900-20701

2nd coast brake piston stroke

Standard: 0.82 – 1.66 mm (0.032 – 0.156 in.)




I4RH01510107-01

- 19) Install 2nd coast brake thrust washer (1).
If measured piston stroke exceeds specified value, check for an improper installation.

NOTE

Make sure lugs of 2nd coast brake thrust washer align with 2nd coast brake piston return spring.



I4RH01510108-01

Oil Pump, 2nd Brake and 2nd Coast Brake Inspection


S7RW0C5106036

- 1) Check body clearance of driven gear (1).
Push driven gear (2) to one side of oil pump body (3). Using a feeler gauge, measure clearance between driven gear (2) and body (3). If clearance exceeds standard value, replace oil pump assembly.

Clearance between driven gear and body

Standard: 0.075 – 0.15 mm (0.00295 – 0.0059 in.)

Limit: 0.20 mm (0.0079 in.)




I4RH01510109-01

- 2) Check tip clearance of both drive and driven gears.
Measure radial clearance between gear tooth tip and crescent (1). If clearance exceeds standard value, replace oil pump assembly.

Clearance between drive gear and crescent

Standard: 0.004 – 0.248 mm (0.0001 – 0.010 in.)

Limit: 0.298 mm (0.0117 in.)




I4RH01510110-00

- 3) Check side clearance of both gears.
Using a straightedge (1) and a feeler gauge, measure side clearance between gears and pump body.
If clearance exceeds standard value, replace oil pump assembly.

Side clearance between gears and oil pump body

Standard: 0.03 – 0.05 mm (0.001 – 0.002 in.)



I4RH01510256-01

- 4) Measure inside diameter of oil pump body bushing, using special tools.
If inside diameter exceeds limit, replace oil pump body.

Oil pump body bushing inside diameter limit:

38.18 mm (1.503 in.)


Special tool

(A): 09900-20607

(B): 09900-22403

NOTE

Perform measurement at several points.



I4RH01510112-01

- 5) Measure inside diameter of starter shaft bushing, using special tools.
If inside diameter exceeds limit, replace starter shaft.

Starter shaft bushing inside diameter limit:
21.57 mm (0.849 in.)


Special tool

(A): 09900-20607

(B): 09900-22403

NOTE

Perform measurement at several points.




I4RH01510113-01

- 6) Check that sliding surface of friction, separator and cushion plates are not worn or burnt.
If necessary, replace.

NOTE

- If friction plate lining is exfoliated, discolored or worn hardly, replace all friction plates.
- Before assembling new friction plates, soak them in A/T fluid for at least two hours.



I2RH01510195-01

- 7) Measure height of 2nd brake return spring and 2nd coast brake return spring. If necessary, replace.

2nd brake return spring height

Standard: 25.17 mm (0.99 in.)


2nd coast brake return spring height

Standard: 14.47 mm (0.57 in.)

NOTE

Do not apply excessive force when measuring spring height.


Perform measurement at several points.



I2RH01510196-01

One-Way No. 1 Clutch Components

S7RW0C5106037




I4RH01510114-01

1. One-way No. 1 clutch inner race	4. One-way No. 1 clutch outer race
2. One-way No. 1 clutch front thrust washer	5. One-way No. 1 clutch rear thrust washer
3. One-way No. 1 clutch	 : Apply automatic transaxle fluid.

One-Way No. 1 Clutch Operation Check

S7RW0C5106038

- 1) Check that one-way No. 1 clutch (1) turns freely when turned counterclockwise [A] and locks when turned clockwise [B].




I4RH01510115-01

One-Way No. 1 Clutch Disassembly and Reassembly

S7RW0C5106039


Disassembly

- 1) Remove one-way No. 1 clutch rear thrust washer (1).



I4RH01510116-01


- 2) Remove one-way No. 1 clutch inner race (1) and one-way No. 1 clutch front thrust washer (2).
- 3) Remove one-way No. 1 clutch (3) from one-way No. 1 clutch outer race (4).



I4RH01510117-01


Reassembly

- 1) Install one-way No. 1 clutch (3) into one-way clutch outer race (4).
- 2) Fit washer (2) to inner race (1) with petroleum jelly so as not to fall washer off when assembling.




I4RH01510117-01

- 3) Install rear thrust washer (1) onto one-way No. 1 clutch outer race (2).



I4RH01510118-01

- 4) Check that one-way No. 1 clutch (1) turns freely when turned counterclockwise [A] and locks when turned clockwise [B].



I4RH01510115-01

One-Way No. 1 Clutch Inspection


S7RW0C5106040

Visually check the following parts for scratches or discoloration.

- Outer surface of one-way No. 1 clutch roller.
- Outer surface of one-way No. 1 clutch inner race.
- Inner surface of one-way No. 1 clutch outer race.

Forward and Direct Clutch Components

S7RW0C5106041




I4RH01510119-01

1. Snap ring	6. Retaining plate	11. O-ring	16. Input shaft rear thrust bearing front race
2. Retaining plate	7. Friction plate	12. Direct clutch piston	17. Input shaft rear thrust bearing
3. Friction plate	8. Separator plate	13. O-ring	18. Oil seal ring
4. Separator plate	9. Snap ring	14. Forward clutch piston	 : Apply automatic transaxle fluid.
5. Snap ring	10. Direct clutch piston return spring	15. Input shaft	 : Do not reuse.

Forward and Direct Clutch Preliminary Check

S7RW0C5106042


- 1) Install forward and direct clutch assembly (1) to transaxle rear cover (2).
- 2) Measure forward clutch piston stroke while applying and releasing compressed air (400 – 800 kPa, 4 – 8 kg/cm², 57 – 113 psi) through oil hole (3) by using special tools.
If measured piston stroke exceeds specified value, disassemble and inspect inner parts.

Special tool**(A): 09900–20607****(B): 09900–20701****Forward clutch piston stroke****Standard: 1.52 – 1.89 mm (0.059 – 0.074 in.)**

I4RH01510120-01

4. Forward clutch piston

- 3) Measure direct clutch piston stroke while applying and releasing compressed air (400 – 800 kPa, 4 – 8 kg/cm², 57 – 113 psi) through oil hole (1) by using special tools.
If measured piston stroke exceeds specified value, disassemble and inspect inner parts.

Special tool**(A): 09900–20607****(B): 09900–20701****Direct clutch piston stroke****Standard: 1.52 – 1.89 mm (0.059 – 0.074 in.)**

I4RH01510121-01

2. Direct clutch piston

Forward and Direct Clutch Disassembly and Reassembly


S7RW0C5106043

Disassembly

- 1) Remove snap ring (1) using flat end rod or the like.
- 2) Remove retaining plate "R", friction plates "F" and separator plates "S" in the following order.
R → F → S → F → S → F → S → F → S

NOTE

Measure thickness of removed retaining plate and record for reference of piston stroke confirmation.




I4RH01510122-01

- 3) Remove snap ring (1) using flat end rod or the like.
- 4) Remove retaining plate, friction plates and separator plates.

NOTE

Measure thickness of removed retaining plate and record for reference of piston stroke confirmation.



I4RH01510123-01

- 5) Using special tool and hydraulic press, compress direct clutch piston return spring and remove snap ring (1).

Special tool


(A): 09926-95420

(B): 09940-51710

⚠ CAUTION

Be careful when applying pressure, for overpressure will cause plate section of direct clutch piston return spring to deform.

- 6) Remove direct clutch piston return spring (2).




I4RH01510259-01

- 7) For removing forward clutch piston and direct clutch piston, install forward and direct clutch assembly (1) to transaxle rear cover (2).

- 8) Remove direct clutch piston (3) with O-rings by applying compressed air (400 – 800 kPa, 4 – 8 kg/cm², 57 – 113 psi) through oil hole (4).

NOTE

If piston does not pop out, it is recommended to use needle-nose pliers for removal.




I4RH01510111-01

- 9) Remove forward clutch piston (1) with O-rings by applying compressed air (400 – 800 kPa, 4 – 8 kg/cm², 57 – 133 psi) from through oil hole (2).

NOTE

If piston does not pop out, it is recommended to use needle-nose pliers for removal.




I4RH01510250-01

- 10) Remove oil seal ring (1) from input shaft (2).

NOTE


Never reuse removed oil seal ring.



I4RH01510125-01

Reassembly

- 1) Apply A/T fluid to new oil seal ring and install new oil seal ring (1) to input shaft (2).



I4RH01510125-01

- 2) Apply A/T fluid to new O-rings and install new O-rings to forward clutch piston.
- 3) Press forward clutch piston to input shaft.

NOTE

Do not twist or deviate O-rings during installation.

- 4) Apply A/T fluid to new O-rings and install O-rings to direct clutch piston.
- 5) Press direct clutch piston to input shaft.

NOTE

Do not twist or deviate O-rings during installation.

- 6) Install direct clutch piston return spring (2).
- 7) Using special tool and hydraulic press, compress direct clutch piston return spring (2) until spring seat is pushed down to 1 – 2 mm (0.039 – 0.078 in.) lower than snap ring groove and install snap ring (1).

Special tool

(A): 09926–95420


(B): 09940–51710

NOTE

- When installing return spring, be careful so that return spring will not fall or tilt.
- Do not align opening in snap ring with lug of direct clutch piston return spring at its retainer section.

⚠ CAUTION

Be careful when applying pressure, for overpressure will cause plate section of direct clutch piston return spring to deform.




I4RH01510259-01

- 8) Install separator plates "S", friction plates "F" and retaining plate "R" in the following order.
S → F → S → F → S → F → S → F → R
- 9) Install snap ring (1).

NOTE

Make sure that opening end of ring is not aligned with groove section of input shaft.



I4RH01510126-01

- 10) Install separator plates "S", friction plates "F" and retaining plate "R" in the following order.
S → F → S → F → S → F → S → F → R


NOTE

Make sure that flat end of retaining plate face toward piston side.

- 11) Install snap ring (1).

NOTE

Make sure that opening end of ring is not aligned with groove section of input shaft.



I4RH01510127-01

- 12) Measure forward clutch piston stroke again, using special tools.
If measured piston stroke exceeds specified value, replace forward clutch retaining plate with new one so that piston stroke is within standard value.

Special tool

(A): 09900-20607


(B): 09900-20701

Forward clutch piston stroke

Standard: 1.52 – 1.89 mm (0.059 – 0.074 in.)

Available forward clutch retaining plate thickness

3.6 mm (0.141 in.), 3.8 mm (0.150 in.), 4.0 mm (0.158 in.)



I4RH01510128-01

1. Forward clutch piston

- 13) Measure direct clutch piston stroke again, using special tools.
If measured piston stroke exceeds specified value, replace direct clutch retaining plate with new one so that piston stroke is within standard value.

Special tool

(A): 09900-20607


(B): 09900-20701

Direct clutch piston stroke

Standard: 1.52 – 1.89 mm (0.059 – 0.074 in.)

Available direct clutch retaining plate thickness

3.6 mm (0.141 in.), 3.8 mm (0.150 in.), 4.0 mm (0.158 in.)



I4RH01510241-01

1. Direct clutch piston


Forward and Direct Clutch Inspection

S7RW0C5106044

- 1) Check that sliding surfaces of friction, separator and retaining plates are not worn or burnt. If necessary, replace.

NOTE

- If friction plate lining is exfoliated, discolored or worn hardly, replace all friction plates.
- Before assembling new friction plates, soak them in A/T fluid for at least two hours.




I2RH01510147-01

- 2) Measure height of direct clutch piston return spring.


Forward clutch return spring height**Standard: 23.59 mm (0.93 in.)****NOTE**

Do not apply excessive force when measuring spring height. Perform measurement at several points.



I2RH01510148-01


- 3) Check that ball makes creaking noise when shaking forward clutch piston and direct clutch piston. (i.e., check that ball is free.)
- 4) Check that there is no leakage from backside of oil hole (1) by applying low pressure air.



I2RH01510149-01

1st / Reverse Brake and One-Way No. 2 Clutch Components

S7RW0C5106045



I7RW01510054-01


1. O-ring	6. Friction plate	11. One-way No. 2 clutch inner race	16. Front planetary ring gear flange
2. 1st / reverse brake piston	7. Retaining plate	12. Snap ring	17. Snap ring
3. 1st / reverse brake piston return spring	8. Snap ring	13. One-way No. 2 clutch	18. Front planetary ring gear rear thrust bearing
4. Snap ring	9. Front planetary ring gear front thrust bearing race	14. Front planetary ring gear thrust washer	 : Apply automatic transaxle fluid.
5. Separate plate	10. Front planetary ring gear front thrust bearing	15. Front planetary ring gear	 : Do not reuse.

1st / Reverse Brake and One-Way No. 2 Clutch Operation Check

S7RW0C5106046

One-Way No. 2 Clutch

- 1) Check that one-way No. 2 clutch (1) turns freely when turned counterclockwise [A] and locks when turned clockwise [B].




I4RH01510130-01

1st / Reverse Brake and One-Way No. 2 Clutch Disassembly and Reassembly

S7RW0C5106047


Disassembly

- 1) Remove one-way No. 2 clutch inner race (1).




I4RH01510131-01

- 2) Remove snap ring (1), using flat end rod or the like.
- 3) Remove one-way No. 2 clutch (2) and front planetary ring gear thrust washer (3).




I4RH01510132-01

- 4) Remove snap ring (1), using pliers or the like.
- 5) Remove front planetary ring gear flange (2) from front planetary ring gear (3).



I4RH01510133-01


- 6) Remove O-rings (1) from 1st / reverse brake piston (2).



I4RH01510134-01


Reassembly

- 1) Apply A/T fluid to new O-rings and install new O-rings (1) to 1st / reverse brake piston (2).




I4RH01510134-01

- 2) Install front planetary ring gear flange (1) on to front planetary ring gear (2).
- 3) Install snap ring (3), using pliers or the like.




I4RH01510135-01

- 4) Fit flat surface of thrust washer (1) to front planetary ring gear with petroleum jelly so as not to fall washer off when reassembling.




I4RH01510136-01

- 5) Install one-way No. 2 clutch (1).
6) Install snap ring, using flat head rod or the like.




I4RH01510137-01

- 7) Apply A/T fluid to outer surface of one-way No. 2 clutch race (1).
8) Install one-way No. 2 clutch race (1) to one-way No. 2 clutch (2).



I4RH01510138-01

- 9) Check that one-way No. 2 clutch (1) turns freely when turned counterclockwise [A] and locks when turned clockwise [B].



I4RH01510130-01


1st / Reverse Brake and One-Way No. 2 Clutch Inspection

S7RW0C5106048

- 1) Check that sliding surfaces of friction, separator and retaining plates are not worn or burnt. If necessary, replace with a new one.

NOTE

- If friction plate lining is exfoliated, discolored or worn hardly, replace all friction plates.
- Before assembling new friction plates, soak them in A/T fluid for at least two hours.




I2RH01510147-01

- 2) Measure height of several 1st / reverse brake piston return spring including plate.

1st / reverse brake piston return spring height
Standard: 19.55 mm (0.77 in.)

NOTE


Do not apply excessive force when measuring spring height or it is not measured accurately.



I2RH01510162-01

Underdrive Clutch and One-Way No. 3 Clutch Components

S7RW0C5106049



I7RW01510055-01

1. Snap ring	5. Snap ring	9. Underdrive clutch drum	13. Cushion plate
2. Separator plate	6. Underdrive clutch piston return spring	10. Underdrive clutch thrust bearing	 : Apply automatic transaxle fluid.
3. Friction plate	7. O-ring	11. Snap ring	 : Do not reuse.
4. Retaining plate	8. Underdrive clutch piston	12. One-way No. 3 clutch	

Underdrive Clutch and One-Way No. 3 Clutch Preliminary Check

S7RW0C5106050

- 1) Install underdrive clutch (1) to transaxle case (2).
- 2) Measure underdrive clutch piston stroke while applying and releasing compressed air (400 – 800 kPa, 4 – 8 kg/cm², 57 – 113 psi) through oil hole (4) by using special tools.
If measured piston stroke exceeds specified value, disassemble and inspect inner parts.



Special tool

(A): 09900-20607

(B): 09900-20701

Underdrive clutch piston stroke

Standard: 1.22 – 1.69 mm (0.048 – 0.067 in.)




I5RH01510017-01

3. Underdrive clutch piston

Underdrive Clutch and One-Way No. 3 Clutch Operation Check

S7RW0C5106051

- 1) Install one-way No. 3 clutch (1) to underdrive clutch drum (2).
- 2) Check that one-way No. 3 clutch turns freely when turned counterclockwise [A] and locks when turned clockwise [B].



I4RH01510141-01

Underdrive Clutch and One-Way No. 3 Clutch Disassembly and Reassembly


S7RW0C5106052

Disassembly

- 1) Remove snap ring (1), using flat head rod or the like.
- 2) Remove retaining plate, friction plates, separator plates and cushion plate.

NOTE

Measure thickness of retaining plate and record for reference of piston stroke confirmation.



I4RH01510142-01

- 3) Using special tool and hydraulic press (2), compress underdrive clutch piston return spring (1) until spring seat is pushed down to 1 – 2 mm (0.039 – 0.078 in.) lower than snap ring groove and remove snap ring (3).


Special tool

(A): 09926–98350

⚠ CAUTION

Be careful when applying pressure, for overpressure will cause plate section of underdrive clutch piston return spring to deform.

- 4) Remove underdrive clutch piston return spring (1).





I4RH01510143-01

- 5) For removing underdrive clutch piston (1), install underdrive clutch drum to transaxle case (2).
- 6) Remove underdrive clutch piston with O-rings by applying compressed air (400 – 800 kPa, 4 – 8 kg/cm², 57 – 113 psi) from through oil hole (3).

NOTE

If piston does not pop out, it is recommended to use needle-nose pliers from removal.




I5RH01510018-01

Reassembly

- 1) After applying A/T fluid to new O-rings and install O-rings (1) to underdrive clutch piston (2).
- 2) Install underdrive clutch piston (2) to underdrive clutch drum (3) by pushing with fingers.

NOTE

Do not twist or deviate O-rings during installation.



I4RH01510145-01

- 3) Using special tool and hydraulic press (2), compress underdrive clutch piston return spring (1) until spring seat is pushed down to 1 – 2 mm (0.039 – 0.078 in.) lower than snap ring groove and install snap ring (3).

Special tool


(A): 09926–98350

NOTE

- When installing return spring, be careful so that return spring will not fall or tilt.
- Do not align opening in snap ring with lug of underdrive clutch piston return spring at its retainer section.

⚠ CAUTION

Be careful when applying pressure, for overpressure will cause plate section of underdrive clutch piston return spring to deform.



I4RH01510143-01

- 4) Install cushion plate “C”, separate plates “S”, friction plates “F” and retaining plate “R” of coast clutch in the following order.
C → S → F → S → F → S → F → R


NOTE

Make sure that “A” section of cushion plate faces toward piston side.

- 5) Install snap ring (1).

NOTE

Make sure that opening end of ring is not aligned with groove section of drum.



I7RW01510056-01

- 6) Measure underdrive clutch piston stroke again, using special tools.
If measured piston stroke exceeds specified value, replace underdrive clutch retaining plate with new one so that piston stroke is within standard value.

Special tool

(A): 09900–20607


(B): 09900–20701

Overdrive clutch piston stroke

Standard: 1.22 – 1.69 mm (0.048 – 0.067 in.)

Available underdrive clutch retaining plate thickness

3.6 mm (0.141 in.), 3.8 mm (0.150 in.), 4.0 mm (0.158 in.)



I4RH01510147-01

- | |
|--------------------------------------|
| 1. Transaxle rear cover |
| 2. Overdrive / coast clutch assembly |
| 3. Underdrive clutch piston |


Underdrive Clutch and One-Way No. 3 Clutch Inspection

S7RW0C5106053

- 1) Check that sliding surfaces of friction, separator and retaining cushion plates are not worn or burnt. If necessary, replace.

NOTE

- If friction plate lining is exfoliated, discolored or worn hardy, replace all friction plates.
- Before assembling new friction plates, soak them in A/T fluid for at least two hours.




I2RH01510147-01

- 2) Measure height of several underdrive clutch piston return spring including plate. If necessary, replace with a new one.

Underdrive clutch piston return spring height
Standard: 20.1 mm (0.79 in.)


NOTE

Do not apply excessive force when measuring spring height or it is not measured accurately.



I2RH01510162-01

- 3) Shake underdrive clutch piston lightly and check that check ball (1) is not stuck. Check that valve does not have leaks by applying low-pressure cam pressed air. If necessary, replace underdrive clutch piston.



I4RH01510148-01

- 4) Measure inside diameter of underdrive clutch drum bushing (1), using special tools. If inside diameter exceeds limit, replace underdrive clutch drum.

Underdrive clutch drum bushing inside diameter limit

28.57 mm (1.124 in.)


Special tool

(A): 09900-20607

(B): 09900-22403

NOTE


Perform measurement at several point.



I4RH01510149-01

Planetary Gear Components

S7RW0C5106054



I4RH01510150-01


1. Planetary front gear	5. Rear planetary ring gear flange	9. Planetary sun gear
2. Front planetary carrier rear thrust bearing race	6. Snap ring	10. Input shaft front thrust bearing
3. Front planetary carrier rear thrust bearing	7. Rear planetary ring gear rear thrust bearing race	 : Apply automatic transaxle fluid.
4. Rear planetary ring gear	8. Rear planetary ring gear rear thrust bearing	 : Do not reuse.

Planetary Gear Disassembly and Reassembly

S7RW0C5106055

Disassembly**Rear planetary ring gear assembly**


- 1) Remove snap ring (1) using flat end rod or the like.
- 2) Remove rear planetary ring gear flange (2) from rear planetary ring gear (3).



I4RH01510151-01

Reassembly**Rear planetary ring gear assembly**

- 1) Install rear planetary ring gear flange (1) to rear planetary ring gear (2).
- 2) Install snap ring (3).



I4RH01510151-01

Planetary Gear Inspection

S7RW0C5106056

Rear Planetary Ring Gear Assembly

Visually check the following parts for scratches or discoloration.

- Inner surface of planetary ring gear.

Planetary Front Gear

Measure inside diameter of planetary front gear (1) bushing, using special tools. If inside diameter exceeds limit, replace planetary front gear.

Planetary front gear bushing inside diameter limit
30.13 mm (1.186 in.)


Special tool

(A): 09900-20607

(B): 09900-22403

NOTE

Perform measurement at several points.



I4RH01510152-01

Planetary Sun Gear

Measure inside diameter of planetary sun gear (1) bushing, using special tools. If inside diameter exceeds limit, replace planetary sun gear.

Planetary sun gear bushing inside diameter limit
21.58 mm (0.849 in.)


Special tool

(A): 09900-20607

(B): 09900-22403

NOTE


Perform measurement at several points.



I4RH01510153-01

Underdrive Brake Components

S7RW0C5106057



I4RH01510154-01

1. Underdrive brake band anchor bolt	6. Underdrive brake piston rod washer	11. O-ring
2. O-ring	7. Underdrive brake piston rod spring	12. Underdrive brake piston cover
3. Underdrive brake band	8. O-ring	13. Snap ring
4. Underdrive brake piston return spring	9. Underdrive brake piston	: Apply automatic transaxle fluid.
5. Underdrive brake piston rod	10. E-ring	: Do not reuse.

Underdrive Brake Disassembly and Reassembly

S7RW0C5106058


Disassembly

- 1) Remove E-ring (1) from underdrive brake piston (2), using flat end rod or the like.
- 2) Remove underdrive brake piston rod, underdrive brake piston rod washer, underdrive brake piston rod spring.

- 3) Remove O-ring (3) from underdrive brake piston.

NOTE

Never reuse removed O-rings.




I4RH01510155-01

- 4) Remove O-rings (1) from underdrive brake piston cover (2).

NOTE


Never reuse removed O-rings.



I4RH01510156-01


Reassembly

- 1) Apply A/T fluid to new O-rings.
- 2) Install new O-rings (1) to underdrive brake piston cover (2).



I4RH01510156-01

- 3) Install underdrive brake piston rod spring (1), underdrive brake piston rod washer (2) and underdrive brake piston rod (3) to underdrive brake piston (4).
- 4) Compress underdrive brake piston rod by hand and then install E-ring (5) using pliers or the like.
- 5) Apply A/T fluid to new O-ring.
- 6) Install new O-ring (6) to underdrive brake piston.



I4RH01510157-01

Underdrive Brake Inspection

S7RW0C5106059


- 1) Measure free length underdrive brake piston return spring. If necessary, replace.

Underdrive brake piston return spring free length

Standard: 63.20 mm (2.49 in.)

NOTE

Do not apply excessive force when measuring spring height.




I4RH01510158-01

- 2) Measure free length underdrive brake piston rod spring. If necessary, replace.

Underdrive brake piston rod spring free length

Standard: 17.50 mm (0.68 in.)



I4RH01510159-01


Reduction Drive Gear Assembly Operation Check

S7RW0C5106060

Measure starting torque of reduction drive gear, using spring force gauge, attach cord at groove of outer race. If starting torque is out of specification, replace reduction drive gear assembly.

Starting torque of reduction drive gear


0.3 – 0.8 N·m (0.03 – 0.08 kgf-m, 0.22 – 0.58 lb-ft)



I4RH01510160-01

Underdrive Gear Assembly Components

S7RW0C5106061



I4RH01510161-01

1. Countershaft front thrust bearing	3. Underdrive gear assembly	5. Countershaft rear thrust bearing race
2. Countershaft front thrust bearing race	4. Countershaft rear thrust bearing	 : Apply automatic transaxle fluid.


Underdrive Gear Preliminary Check

S7RW0C5106062

Measure starting torque of underdrive gear, using spring force gauge, attach cord at gear of underdrive gear. If starting torque is out of specification, replace underdrive gear assembly.

Starting torque of underdrive gear


0.55 – 1.35 N·m (0.06 – 0.14 kgf-m, 0.40 – 1.01 lb-ft)



I4RH01510162-01

Valve Body Assembly Components

S7RW0C5106063



I4RH01510176-01

1. Valve body assembly	5. Pressure control solenoid valve clamp	9. Shift solenoid valve-B (No. 2)	13. Suction cover gasket
2. Manual valve	6. Pressure control solenoid valve	10. TCC solenoid valve	 : Apply automatic transaxle fluid.
3. Manual valve rod	7. O-ring	11. Clamp	 : Tightening torque
4. E-ring	8. Shift solenoid valve-A (No. 1)	12. Suction cover	 : Do not reuse.

CAUTION

When replacing pressure control solenoid valve, it is strictly required to replace it together with valve body assembly as a set.

Valve Body Assembly Disassembly and Reassembly


S7RW0C5106064

Disassembly

- 1) Pull out manual valve.
- 2) Remove solenoid valves with O-ring by removing bolts.

NOTE

Never reuse removed O-ring.



I4RH01510177-01

1. Pressure control solenoid valve	3. Shift solenoid valve-B (No. 2)
2. Shift solenoid valve-A (No. 1)	4. TCC solenoid valve



Reassembly

- 1) Apply A/T fluid to new O-rings and install O-rings to each solenoid valves.
- 2) Install solenoid valves to valve body and tighten bolts to specified torque.

Tightening torque

Shift solenoid bolts (a): 7.0 N·m (0.7 kgf-m, 5.0 lb-ft)

Pressure control solenoid bolt (b): 7.0 N·m (0.7 kgf-m, 5.0 lb-ft)




I5RH01510019-01

- 3) Install manual shift valve to valve body.

Differential Components

S7RW0C5106065



I4RH01510178-01

1. Differential side right bearing race	5. Ring gear set bolt lock plate	: Apply automatic transaxle fluid.
2. Bolt	6. Differential side left bearing race	: Tightening torque
3. Differential gear assembly	7. Shim	: Do not reuse.
4. Final gear		

Differential Preliminary Check

S7RW0C5106066

Differential Assembly Starting Torque

- 1) Install differential assembly (1) to transaxle case and tighten case bolts to specified torque.

Tightening torque

Transaxle housing bolts: 30 N-m (3.0 kgf-m, 22 lb-ft)


- 2) Measure differential assembly starting torque, using special tool. If starting torque exceeds specified value, replace shim in the following so as starting torque to be in standard value.

Starting torque of differential assembly

0.7 – 1.2 N-m (0.07 – 0.12 kgf-m, 0.506 – 0.868 lb-ft)

Special tool

(A): 09928-06060



I4RH01510179-01

Available differential side bearing shim thickness (Thickness: Identification)

1.00 mm (0.039 in.): 21	1.48 mm (0.058 in.): 33
1.05 mm (0.041 in.): 22	1.51 mm (0.059 in.): 34
1.10 mm (0.043 in.): 23	1.54 mm (0.060 in.): 35
1.15 mm (0.045 in.): 24	1.57 mm (0.061 in.): 36
1.20 mm (0.047 in.): 25	1.60 mm (0.062 in.): 37
1.25 mm (0.049 in.): 26	1.65 mm (0.064 in.): 38
1.30 mm (0.051 in.): 27	1.70 mm (0.066 in.): 39
1.33 mm (0.052 in.): 28	1.75 mm (0.068 in.): 40
1.36 mm (0.053 in.): 29	1.80 mm (0.070 in.): 41
1.39 mm (0.054 in.): 30	1.85 mm (0.072 in.): 42
1.42 mm (0.055 in.): 31	1.90 mm (0.074 in.): 43
1.45 mm (0.057 in.): 32	


Differential Gear Thrust Play

- 1) Hold differential assembly with soft jawed vice and set special tools as shown.

Special tool

(A): 09900-20607

(B): 09900-20701



- 2) Measure differential gear thrust play. If thrust play exceeds specified value, replace differential assembly.

Differential gear thrust play

Standard: 0.05 – 0.20 mm (0.0024 – 0.0087 in.)

Differential Gear Assembly Removal and Installation

S7RW0C5106067

Removal


Final gear

- 1) Unclamp 4 final gear bolt lock plates (1).
- 2) Remove 8 bolts and 4 final gear bolt lock plates.

NOTE

Don't reuse lock plates.

- 3) Remove final gear (2).




Installation

Bearing outer race

- 1) Install differential side right bearing race (1) and shim (2) to transaxle case (3), using special tool.

Special tool


(A): 09924-07710



- 2) Install differential side left bearing race (1) to transaxle housing (2), using special tool.

Special tool


(A): 09924-07710



I4RH01510188-01

Final gear

- 1) Heat final gear to about 100 °C (212 °F) in oil bath.
2) Clean mating surfaces of final gear and differential case.




I2RH01510221-01

- 3) Install final gear (1) to differential case (2).
4) Install new 4 final gear set bolt lock plates and 8 bolts and tighten bolts to specified torque.

Tightening torque

Final gear bolts (a): 99 N·m (9.9 kgf-m, 72.0 lb-ft)

- 5) Clamp bolts with lock plate (3) securely.



I4RH01510189-01

- 6) Install differential assembly to transaxle case and tighten case bolts to specified torque.

Tightening torque

Transaxle housing bolts: 30 N·m (3.0 kgf-m, 22.0 lb-ft)


- 7) Measure differential assembly starting torque, using special tool. If starting torque exceeds specified value, replace shim in the following so as starting torque to be in standard value.

Special tool

(A): 09928-06060

Starting torque of differential assembly


0.7 – 1.2 N·m (0.07 – 0.12 kgf-m, 0.506 – 0.868 lb-ft)



I4RH01510179-01

Available differential side bearing shim thickness (Thickness: Identification)

1.00 mm (0.039 in.): 21	1.48 mm (0.058 in.): 33
1.05 mm (0.041 in.): 22	1.51 mm (0.059 in.): 34
1.10 mm (0.043 in.): 23	1.54 mm (0.060 in.): 35
1.15 mm (0.045 in.): 24	1.57 mm (0.061 in.): 36
1.20 mm (0.047 in.): 25	1.60 mm (0.062 in.): 37
1.25 mm (0.049 in.): 26	1.65 mm (0.064 in.): 38
1.30 mm (0.051 in.): 27	1.70 mm (0.066 in.): 39
1.33 mm (0.052 in.): 28	1.75 mm (0.068 in.): 40
1.36 mm (0.053 in.): 29	1.80 mm (0.070 in.): 41
1.39 mm (0.054 in.): 30	1.85 mm (0.072 in.): 42
1.42 mm (0.055 in.): 31	1.90 mm (0.074 in.): 43
1.45 mm (0.057 in.): 32	



I4RH01510190-02


1. Forward clutch accumulator	5. Transaxle rear cover	 : Apply automatic transaxle fluid.
2. Forward clutch accumulator spring	6. Input shaft rear thrust bearing rear race	 : Tightening torque
3. Forward clutch accumulator piston	7. Oil seal ring	 : Do not reuse.
4. O-ring		

Transaxle Rear Cover Disassembly and Reassembly

S7RW0C5106069


Disassembly

- 1) Remove oil seal rings (1).



I4RH01510191-01

- 2) Remove forward clutch accumulator (1), forward clutch accumulator spring (2) and forward clutch accumulator piston (3) cover, by removing 2 bolts.
- 3) Remove O-ring (4) from forward clutch accumulator piston.



I4RH01510192-01

Reassembly

- 1) Apply A/T fluid to new O-ring and install O-ring (1) to forward clutch accumulator piston (2).
- 2) Press forward clutch accumulator piston (2) into transaxle rear cover.


NOTE

Do not twist or deviate O-rings during installation.

- 3) Install forward clutch accumulator spring (3) and forward clutch accumulator cover (4) with 2 bolts.

Tightening torque

Forward clutch accumulator bolts (a): 10 N·m (1.0 kgf-m, 7.5 lb-ft)




I4RH01510193-01

- 4) Apply A/T fluid to new oil seal rings and install oil seal rings (1) to transaxle rear cover (2).

NOTE

- Do not spread oil seal ring ends excessively.
- Make sure that opening ends of oil seal rings are not lined up so as to prevent fluid leakage.



I4RH01510194-01


Transaxle Rear Cover Inspection

S7RW0C5106070

Measure free length forward clutch accumulator spring. If necessary, replace with a new one.

Forward clutch accumulator spring free length

Standard: 66.64 mm (2.624 in.)



I4RH01510158-01

Automatic Transaxle Unit Assembly

S7RW0C5106071


- 1) Apply lithium grease to new manual shift shaft oil seal lip.

: Grease 99000-25030 (SUZUKI Super Grease C)

- 2) Press-fit new manual shift shaft oil seal (1) to transaxle case, using special tool.

Special tool

(A): 09943-88211




I4RH01510195-01

- 3) Apply A/T fluid to new oil seal rings (1) and install oil seal rings (1) to transaxle case.

NOTE

Do not spread oil seal ring ends excessively.



I4RH01510196-01

- 4) Install one-way No. 3 clutch (1) to transaxle case.


NOTE

Make sure that groove section of one-way No. 3 clutch faces (2) toward upper side.

- 5) Install snap ring (3), using flat end rod or the like.

NOTE

Make sure that opening end of snap ring should be aligned with protrusion of transaxle case.




- 6) Apply A/T fluid to new O-rings (1) and install O-rings (1) to underdrive brake accumulator cover (2) and underdrive brake accumulator piston (3).

- 7) Put underdrive brake accumulator spring (4) in transaxle case, and insert under drive brake accumulator piston (3) and underdrive brake accumulator cover (2) into transaxle case.

NOTE

Do not twist or deviate O-rings during installation.




- 8) Push underdrive brake accumulator cover and install underdrive brake accumulator bracket (1), spacer (2) and torsion spring (3) by tighten 2 torx® bolts to specified torque.

Tightening torque

Underdrive brake accumulator bracket bolt(s)

(a): 10 N·m (1.0 kgf-m, 7.5 lb-ft)




- 9) Apply A/T fluid to new O-rings (1) and install O-rings (1) to underdrive brake piston assembly (2) and underdrive brake piston cover (3).

- 10) Put underdrive brake piston return spring (4) in transaxle case, and underdrive brake piston assembly (2) and underdrive brake piston cover (3) into transaxle case.

NOTE

Do not twist or deviate O-rings during installation.




- 11) Apply special tools and push in underdrive brake piston cover (1).

Special tool

(A): 09916-14510


(B): 09916-14910

- 12) Install snap ring (2), using pliers or the like.



I4RH01510201-01

- 13) Install underdrive brake band (1).



I4RH01510202-01

- 14) Apply A/T fluid to new O-ring (1) and install new O-ring (1) to underdrive brake band anchor bolt (2).

- 15) Tighten underdrive brake band anchor bolt (2) to specified torque, using special tool.


Special tool

(A): 09927-68010

Tightening torque

Underdrive brake band anchor bolt (a): 170 N·m (17.0 kgf-m, 123.0 lb-ft)

- 16) Remove oil plug bolt with O-ring installed (3).



I7RW01510063-02



- 17) Measure underdrive brake piston stroke while applying and releasing compressed air (400 – 800 kPa, 4 – 8 kg/cm², 57 – 113 psi) through oil hole (2). If measured piston stroke exceeds specified value, replace underdrive brake piston rod in the following so as piston stroke to be in standard value. If piston stroke is still standard value or more, replace underdrive brake band with a new one.

Underdrive brake piston stroke

Standard: 5.48 – 7.02 mm (0.26 – 0.28 in.)

Available underdrive brake piston rod length

70.5 mm (2.776 in.), 72.0 mm (2.835 in.)



I5RH01510020-01


1. Underdrive brake piston

- 18) Apply A/T fluid to new O-ring and install O-ring to oil plug bolt (1).

- 19) Tighten oil plug bolt to specified torque.


Tightening torque

Underdrive brake oil plug bolt: 7.5 N·m (0.75 kgf-m, 5.5 lb-ft)




I4RH01510205-01

- 20) Apply petroleum jelly to underdrive clutch thrust bearing (1) and countershaft rear thrust bearing race (2).
- 21) Install underdrive clutch thrust bearing (1) and countershaft rear thrust bearing race (2) to underdrive clutch assembly (3).
- 22) Install underdrive clutch assembly (3) onto transaxle case.




I4RH01510206-01

- 23) Make sure that underdrive clutch turns freely when turned counterclockwise [A] and locks when turned clockwise [B].



I4RH01510207-01

- 24) Apply petroleum jelly to countershaft rear thrust bearing (1), countershaft front thrust bearing (2) and countershaft front thrust bearing race (3).
- 25) Install countershaft rear thrust bearing (1), countershaft front thrust bearing race (3) and countershaft front thrust bearing (2) to counter driven gear.
- 26) Install underdrive gear assembly (4) onto under drive clutch (5).




I4RH01510208-01

- 27) Install parking lock pawl (1). Place torsion spring (2) on parking lock pawl shaft (3) and install them into transaxle case.
- 28) Install parking lock pawl bracket and manual detent spring (4) by 2 tightening bolts to specified torque.

Tightening torque


Manual detent spring bolt No.1 (a): 10 N·m (1.0 kgf-m, 7.5 lb-ft)

Manual detent spring bolt No.2 (b): 5.5 N·m (0.55 kgf-m, 4.0 lb-ft)




I7RW01510057-01

- 29) Insert parking lock rod (1) to parking lock pawl bracket and connect parking lock rod (1) with manual shift shaft (2).



I4RH01510210-01

- 30) Install reduction drive gear assembly (1) into transaxle case (2).
- 31) Install snap ring (3).




I4RH01510211-01

- 32) Apply A/T fluid to new O-rings and install O-rings to 1st / reverse brake piston (1).
- 33) Place 1st / reverse brake piston (1) into transaxle case.

NOTE

Do not twist or deviate O-rings during installation.




I4RH01510212-01

- 34) Mount 1st / reverse brake piston return spring (1).
- 35) Install retainer ring (2) by compressing 1st / reverse brake piston return spring (1) with flat end rod or the like.

NOTE


Make sure that opening end of ring is not aligned with protrusion of transaxle case.

- 36) Apply petroleum jelly to front planetary ring gear front thrust bearing race (3).
- 37) Place front planetary ring gear front thrust bearing race (3) onto counter driven gear.




I4RH01510213-01

- 38) Apply petroleum jelly to front planetary ring gear front thrust bearing (1) and front planetary ring gear rear thrust bearing (2).
- 39) Install front planetary ring gear front thrust bearing (1) and front planetary ring gear rear thrust bearing (2) to front planetary ring gear (3).
- 40) Install front planetary ring gear (3).



I4RH01510214-01

- 41) Make sure that front planetary ring gear (1) turns freely when turned counterclockwise [A] and locks when clockwise [B].




I4RH01510215-01

- 42) Install separator plates "S", friction plates "F" and retaining plates "R" in the following order.
R → F → S → F → S → F → S → F → S → F → R
- 43) Install snap ring, using flat end rod or the like.

NOTE

Make sure that opening end of ring is not aligned with protrusion of transaxle case.



I4RH01510216-01

- 44) Measure 1st / reverse brake piston stroke while applying and releasing compressed air (400 – 800 kPa, 4 – 8 kg/cm², 57 – 113 psi) through oil hole (1) by using special tools. If measured piston stroke exceeds specified value, check for an important installation.


Special tool

(A): 09900-20607

(B): 09900-20701


1st / reverse brake piston stroke

Standard: 1.35 – 2.15 mm (0.053 – 0.085 in.)



I4RH01510217-01


- 45) Apply petroleum jelly to front planetary carrier rear thrust bearing race (1).
 46) Place front planetary carrier rear thrust bearing race (1) onto planetary front gear (2).
 47) Install planetary front gear (2) to front planetary ring gear (3).



I4RH01510218-01

- 48) Apply petroleum jelly to input shaft front thrust bearing (1) and rear planetary ring gear rear thrust bearing (2).

- 49) Install input shaft front thrust bearing (1), planetary sun gear (3), and rear planetary ring gear rear thrust bearing (2) to forward and direct clutch assembly (4).




I4RH01510219-01

- 50) Apply petroleum jelly to rear planetary ring gear rear thrust bearing race and front planetary carrier rear thrust bearing.

- 51) Install rear planetary ring gear rear thrust bearing race (1), rear planetary ring gear (2) and front planetary carrier rear thrust bearing (3) to planetary sun gear (4).


NOTE

Make sure that tube of rear planetary ring gear rear thrust bearing race fit into notch of rear planetary ring gear.



I4RH01510220-01

- 52) Install forward and direct clutch assembly (1).
 53) Apply petroleum jelly to input shaft thrust bearing front race (2) and input shaft rear thrust bearing (3).
 54) Place input shaft rear thrust bearing front race (2) and input shaft rear thrust bearing (3) to forward and direct clutch assembly (1).




I4RH01510221-01

- 55) Apply A/T fluid to 4 new gaskets (1).
 56) Install 4 new gaskets (1) to transaxle case.
 57) Apply A/T fluid to transaxle lubrication tubes (2).
 58) Install tube clamp (3) and tighten the torx® bolt to specified torque.


Tightening torque

Tube clamp torx® bolt (a): 9 N·m (0.9 kgf-m, 6.5 lb-ft)



I4RH01510222-01


- 59) Apply petroleum jelly to input shaft rear thrust bearing rear race (1).
 60) Place input shaft rear thrust bearing rear race (1) to transaxle rear cover (2).



I4RH01510223-01

- 61) Apply sealant to mating surface of transaxle case by using a nozzle as shown in figure by such amount that its section is 1.5 mm (0.059 in.) in diameter.

“A”: Sealant 99000-31230 (SUZUKI Bond No.1216B)



I4RH01510224-01

- 62) Install transaxle rear cover to transaxle case by a tightening bolts to specified torque.

Bolt	Size	Length (mm)	Pieces
A	M6	16	2
B	M8	25	2
C	M8	45	4
D	M8	48	3


NOTE

Make sure to use new transaxle rear cover bolts A, B and D.

Tightening torque

Transaxle rear cover bolts (a): 10 N·m (1.0 kgf-m, 7.5 lb-ft)

Transaxle rear cover bolts (b): 24 N·m (2.4 kgf-m, 17.5 lb-ft)




I4RH01510225-01

- 63) Apply A/T fluid to inner surface of new countershaft front bearing (1).
 64) Install new countershaft front bearing (1) to transaxle housing, using special tool.

Special tool

(A): 09913-75510



I4RH01510226-01

5A-134 Automatic Transmission/Transaxle:

- 65) Apply A/T fluid to new oil seal ring (1) and install oil seal ring (1) to transaxle housing.

NOTE

Do not spread oil seal ring ends excessively.

- 66) Apply A/T fluid to transaxle lubrication tube (2).
67) Install tube clamp (3) and tighten the bolt to specified torque.


Tightening torque

Transaxle lubrication tube bolt (a): 5.5 N·m (0.55 kgf-m, 4.0 lb-ft)

- 68) Install oil reservoir RH plate and tighten 3 bolts to specified torque.

Tightening torque

Oil reservoir RH plate bolt (b): 5.5 N·m (0.55 kgf-m, 4.0 lb-ft)




I4RH01510227-01

- 69) Install oil reservoir LH plate (1) and tighten 2 bolts to specified torque.

Tightening torque

Oil reservoir LH plate bolts (a): 5.5 N·m (0.55 kgf-m, 4.0 lb-ft)




I4RH01510257-01

- 70) Install oil strainer assembly (1) and tighten the bolt to specified torque.

Tightening torque

Oil strainer bolt (a): 5.5 N·m (0.55 kgf-m, 4.0 lb-ft)


- 71) Install differential gear assembly.



I4RH01510228-01

- 72) Apply sealant to mating surface of transaxle case by using a nozzle as shown in figure by such amount that its section is 1.5 mm (0.059 in.) in diameter.

“A”: Sealant 99000-31230 (SUZUKI Bond No.1216B)



I4RH01510229-01

- 73) Install transaxle housing to transaxle case by 15 tightening bolts to specified torque.


Bolt	Size	Length (mm)	Pieces
A	M8	30	9
B	M8	30	4
C	M8	35	2
D	M8	45	1
E	M8 Torx® T40	30	1

Tightening torque

Transaxle case bolt: 29 N·m (2.9 kgf-m, 20.98 lb-ft)


NOTE

Make sure to use new transaxle housing bolts B and C.



I4RH01510230-01

- 74) Install one-way No. 1 clutch assembly (1) into oil pump assembly (2).




I4RH01510231-01

- 75) Check for correct installation of each component parts as follows.

Measure the distance "a" by using vernier (1) and straight edge (2). If distance is out of specification, remove one-way No. 1 clutch assembly (3) and install them properly.

Distance between upper edge of one-way No. 1 clutch to oil pump plate

"a": 51.1 – 51.7 mm (2.012 – 2.035 in.)



I4RH01510232-01


- 76) Apply A/T fluid to O-ring and install oil pump assembly (1) by 8 tightening bolts to specified torque.

NOTE

Do not twist or deviate O-ring during installation.

Tightening torque

Oil pump body bolt: 25 N·m (2.5 kgf-m, 18.08 lb-ft)



I4RH01510233-01

77) Measure end play of input shaft (1), using special tool. If end play is out of specification, replace input shaft rear thrust bearing front race in the following so as end play to be in standard value.

Special tool

(A): 09900-20607


(B): 09900-20701

End play of input shaft

Standard: 0.37 – 0.90 mm (0.0034 – 0.035 in.)


Available input shaft rear thrust bearing front race thickness

0.81 mm (0.031 in.), 1.15 mm (0.045 in.)



I4RH01510234-01

78) Apply A/T fluid to new gaskets (1) and install gaskets (1) to transaxle case.



I4RH01510060-01


79) While holding valve body assembly, connect manual valve connecting rod (1) to manual shift shaft (2).

80) Install valve body assembly (3) by 9 tightening bolts to specified torque.

Tightening torque

Valve body bolt: 10 N·m (1.0 kgf-m, 7.5 lb-ft)

Bolt	Length (mm)	Pieces
A	16	2
B	50	4
C	55	3



I5RH01510021-01

81) Apply A/T fluid to new O-ring and install O-ring to solenoid harness (1).

82) Install solenoid harness (1) into transaxle case.

NOTE

Do not twist or deviate O-ring during installation.

83) Connect solenoid connectors by identifying wire color.

Solenoid coupler: Wire color


Pressure control solenoid valve (1): Blue + Brown

Shift solenoid valve-A (No. 1) (2): White

Shift solenoid valve-B (No. 2) (3): Black

TCC solenoid valve (4): Yellow

84) Clamp solenoid harness.




I4RH01510236-01

5. Harness clamp

- 85) Apply sealant to mating surface of transaxle case by using a nozzle as shown in figure by such amount that its section is 1.5 mm (0.059 in.) in diameter.

"A": Sealant 99000-31230 (SUZUKI Bond No.1216B)




I4RH01510237-01

- 86) Install transaxle side cover (1) by tightening new torx® bolts to specified torque.

Tightening torque

Transaxle side cover bolts (a): 13 N·m (1.3 kgf-m, 9.5 lb-ft)



I4RH01510238-01

- 87) Apply A/T fluid to transmission fluid temperature sensor (1), output shaft speed sensor (2), input shaft speed sensor (3) and fluid filler tube (4).
- 88) Install input shaft speed sensor and output shaft speed sensor (with new O-rings installed) by tightening bolts to specified torque.

Tightening torque



Input shaft speed sensor bolt (a): 5.5 N·m (0.55 kgf-m, 4.0 lb-ft)

Output shaft speed sensor bolt (b): 5.5 N·m (0.55 kgf-m, 4.0 lb-ft)

- 89) Install fluid filler tube (4) (with new O-ring installed).
- 90) Install transmission fluid temperature sensor (1) (with new O-ring installed) to specified torque.

Tightening torque

Transmission fluid temperature sensor (d): 10 N·m (1.0 kgf-m, 7.2 lb-ft)



I7RW01510058-01

91) Install transmission range sensor assembly.

- a) Install transmission range sensor plate (1) to groove of solenoid harness.
- b) Install transmission range sensor (2) to manual valve lever shaft (3).
- c) Place lock washer (4).
- d) Insert transmission range sensor bolts.
- e) Tighten transmission range sensor lock nut (5) to specified torque and then bend claws lock washer.

Tightening torque

Transmission range sensor lock nut (a): 7.0 N·m (0.7 kgf-m, 5.0 lb-ft)

- f) Install manual shift lever (6), washer (7) and tighten nut (8) to specified torque.

Tightening torque



Manual select lever nut (b): 12 N·m (1.2 kgf-m, 8.7 lb-ft)

- g) Adjust transmission range sensor.
- h) Tighten transmission range sensor bolt and nut to specified torque.

Tightening torque

Transmission range sensor bolt (c): 25 N·m (2.5 kgf-m, 18.0 lb-ft)

Transmission range sensor nut (d): 7.5 N·m (0.75 kgf-m, 5.5 lb-ft)



I5RH01510023-01

92) Install torque converter (1) to input shaft.

- a) Install torque converter (1), using care not to damage oil seal of oil pump.
- b) After installing torque converter (1), check that distance "a" is within specification.


Distance between torque converter and mating surface of transaxle housing (3)

"a": 21.5 mm (0.846 in.) or more

- c) Check torque converter (1) for smooth rotation.

⚠ CAUTION

- Before installing converter, make sure that its pump hub portion is free from nicks, burrs or damage which may cause oil seal to leak.
- Be very careful not to drop converter on oil pump gear. Damage in gear, should it occur, may cause a critical trouble.




I2RH01510269-01

2. Flange nut

Specifications

Bearing and Race Installation Specification

S7RW0C5107001



I4RH01510243-01

Bearing and race dimensions

	Diameter	A	B	C	D	E	F	G	H	I
		mm (in.)	mm (in.)	mm (in.)	mm (in.)	mm (in.)	mm (in.)	mm (in.)	mm (in.)	mm (in.)
Front race	Outer	58 (2.3)	—	54 (2.1)	74 (2.9)	—	41 (1.6)	—	—	—
	Inner	43.8 (1.7)	—	39 (1.5)	53 (2.1)	—	13.5 (0.53)	—	—	—
Bearing	Outer	62.0 (2.4)	88.7 (3.5)	57 (2.2)	65 (2.6)	43.4 (1.7)	41.7 (1.6)	70.4 (2.8)	41.8 (1.6)	57.3 (2.3)
	Inner	45.8 (1.8)	72.4 (2.9)	39 (1.5)	50 (2.0)	22.1 (0.87)	23 (0.90)	49 (1.9)	28.6 (1.1)	34 (1.3)
Rear race	Outer	—	—	—	—	—	41 (1.6)	71 (2.8)	42.1 (1.7)	—
	Inner	—	—	—	—	—	17.3 (0.68)	49.1 (1.9)	29.1 (1.1)	—

Tightening Torque Specifications

Fastening part	Tightening torque			Note
	N·m	kgf·m	lb·ft	
A/T fluid drain plug	40	4.0	29.0	🔧
Transmission range sensor bolt	25	2.5	18.0	🔧 / 🔧
Transmission range sensor nut	7.5	0.75	5.5	🔧 / 🔧
Output shaft speed sensor bolt	5.5	0.55	4.0	🔧 / 🔧
Input shaft speed sensor bolt	5.5	0.55	4.0	🔧 / 🔧
Transmission fluid temperature sensor	10	1.0	7.5	🔧
Shift solenoid bolts	7.0	0.7	5.0	🔧 / 🔧
Pressure control solenoid bolt	7.0	0.7	5.0	🔧 / 🔧
Valve body bolt	10.0	1.0	7.5	🔧
Transaxle side cover bolts	13	1.3	9.40	🔧
Transaxle to engine bolts and nut	85	8.5	61.5	🔧
Drive plate to torque converter bolts	23	2.3	16.5	🔧
Clutch housing plate bolt (M6)	11	1.1	8.0	🔧
Clutch housing plate bolt (M10)	30	3.0	21.5	🔧
Oil pump cover bolts	6.5	0.65	4.7	🔧
Oil pump cover bolts	12	1.2	8.7	🔧
Transaxle housing bolts	30	3.0	22	🔧
Final gear bolts	99	9.9	72.0	🔧
Transaxle housing bolts	30	3.0	22.0	🔧
Forward clutch accumulator bolts	10	1.0	7.5	🔧
Underdrive brake accumulator bracket bolt(s)	10	1.0	7.5	🔧
Underdrive brake band anchor bolt	170	17.0	123.0	🔧
Underdrive brake oil plug bolt	7.5	0.75	5.5	🔧
Manual detent spring bolt No.1	10	1.0	7.5	🔧
Manual detent spring bolt No.2	5.5	0.55	4.0	🔧
Tube clamp torx® bolt	9	0.9	6.5	🔧
Transaxle rear cover bolts	10	1.0	7.5	🔧
Transaxle rear cover bolts	24	2.4	17.5	🔧
Transaxle lubrication tube bolt	5.5	0.55	4.0	🔧
Oil reservoir RH plate bolt	5.5	0.55	4.0	🔧
Oil reservoir LH plate bolts	5.5	0.55	4.0	🔧
Oil strainer bolt	5.5	0.55	4.0	🔧
Transaxle case bolt	29	2.9	20.98	🔧
Oil pump body bolt	25	2.5	18.08	🔧
Valve body bolt	10	1.0	7.5	🔧
Transaxle side cover bolts	13	1.3	9.5	🔧
Transmission fluid temperature sensor	10	1.0	7.2	🔧
Transmission range sensor lock nut	7.0	0.7	5.0	🔧
Manual select lever nut	12	1.2	8.7	🔧

NOTE

The specified tightening torque is also described in the following.

“Select Cable Components”

“Automatic Transaxle Unit Components”

“Automatic Transaxle Assembly Components”

“Valve Body Assembly Components”

“Differential Components”

“Transaxle Rear Cover Components”

Reference:

For the tightening torque of fastener not specified in this section, refer to “Fasteners Information in Section 0A”.

Special Tools and Equipment

Recommended Service Material

S7RW0C5108001

Material	SUZUKI recommended product or Specification		Note
Grease	SUZUKI Super Grease A	P/No.: 99000-25010	☞
	SUZUKI Super Grease C	P/No.: 99000-25030	☞ / ☞ / ☞
Sealant	SUZUKI Bond No.1216B	P/No.: 99000-31230	☞ / ☞ / ☞ / ☞

NOTE

Required service material is also described in the following.

“Select Cable Components”

“Automatic Transaxle Assembly Components”

“Oil Pump 2nd Coast Brake and 2nd Brake Components”

“One-Way No. 1 Clutch Components”

“Forward and Direct Clutch Components”

“1st / Reverse Brake and One-Way No. 2 Clutch Components”

“Underdrive Clutch and One-Way No. 3 Clutch Components”

“Planetary Gear Components”

“Underdrive Brake Components”

“Underdrive Gear Assembly Components”









“Valve Body Assembly Components”

“Differential Components”















“Transaxle Rear Cover Components”

Special Tool

S7RW0C5108002

09900-20607 Dial gauge ☞ / ☞ / ☞ / ☞ / ☞ / ☞ / ☞ / ☞ / ☞ / ☞ / ☞ / ☞ / ☞ / ☞ / ☞ / ☞ / ☞ / ☞		09900-20701 Magnetic stand ☞ / ☞ / ☞ / ☞ / ☞ / ☞ / ☞ / ☞ / ☞ / ☞ / ☞ / ☞ / ☞	
09900-22403 Small bore gauge (18-35 mm) ☞ / ☞ / ☞ / ☞ / ☞		09912-34510 Case separator ☞	
09913-50121 Oil seal remover ☞		09913-75510 Bearing installer ☞	
09913-75821 Bearing installer attachment ☞		09913-85210 Bearing installer ☞	

5A-142 Automatic Transmission/Transaxle:

09916-14510 Valve lifter 	09916-14910 Valve spring compressor attachment 
09924-07710 Synchronizer hub installer 	09924-07730 Bearing installer 
09924-84510-005 Bearing installer attachment (D) 	09925-37811-001 Oil pressure gauge 
09926-95420 Clutch spring compressor 	09926-98350 Spring compressor No. 4 
09927-68010 Anchor Bolt Socket 	09928-06060 Adaptor, Differential Preload 
09940-51710 Bearing installer 	09941-51010 Lock ring wrench 
09943-88211 Pinion bearing installer 	SUZUKI scan tool (SUZUKI-SDT) — This kit includes following items. 1. SUZUKI-SDT 2. DLC3 cable 3. USB cable 4. AC/DC power supply 5. Voltage meter probe 6. Storage case 

Manual Transmission/Transaxle

General Description

Manual Transaxle Construction

S7RW0C5201001

The transaxle provides five forward speeds and one reverse speed by means of three synchromesh devices and three shafts-input shaft, countershaft and reverse gear shaft. All forward gears are in constant mesh, and reverse uses a sliding idler gear arrangement.

The low speed sleeve & hub is mounted on countershaft and engaged with countershaft 1st gear or 2nd gear, while the high speed sleeve & hub is done on input shaft and engaged with input shaft 3rd gear or 4th gear. The 5th speed sleeve & hub on input shaft is engaged with input shaft 5th gear mounted on the input shaft.


To prevent the cracking noise from the reverse gear when shifting transaxle gear into the reverse gear, the reverse shift braking device is used.

The device utilizes the 5th synchromesh, which is the lever synchro type, to apply the brake on the input shaft rotation. The double cone synchronizing mechanism is provided to 2nd gear synchromesh device for high performance of shifting to 2nd gear.

For servicing, it is necessary to use genuine sealant or its equivalent on mating surfaces of transaxle case which is made of aluminum. The case fastening bolts must be tightened to specified torque by means of torque wrench. It is also important that all parts are thoroughly cleaned with cleaning fluid and air dried before reassembling.

Further, care must be taken to adjust preload of countershaft taper roller bearings. New synchronizer rings are prohibited from being lapped with respective gear cones by using lapping compound before they are assembled.


2WD



I5RW0A520001-01

1. Input shaft	6. Input shaft 3rd gear	11. Countershaft	16. Countershaft 2nd gear
2. 5th speed sleeve & hub	7. Left case	12. Side cover	17. Low speed sleeve & hub
3. Input shaft 5th gear	8. Reverse gear shaft	13. Countershaft 5th gear	18. Countershaft 1st gear
4. Input shaft 4th gear	9. Reverse idler gear	14. Countershaft 4th gear	19. Final gear
5. High speed sleeve & hub	10. Right case	15. Countershaft 3rd gear	20. Differential case

4WD




I5RW0A520002-05

1. Input shaft	8. Reverse gear shaft	15. Countershaft 3rd gear	22. Transfer driven gear
2. 5th speed sleeve & hub	9. Reverse idler gear	16. Countershaft 2nd gear	23. Transfer bevel gear
3. Input shaft 5th gear	10. Right case	17. Low speed sleeve & hub	24. Transfer bevel pinion
4. Input shaft 4th gear	11. Countershaft	18. Countershaft 1st gear	25. Transfer right case
5. High speed sleeve & hub	12. Side cover	19. Final gear	26. Transfer left case
6. Input shaft 3rd gear	13. Countershaft 5th gear	20. Differential case	27. Transfer output flange
7. Left case	14. Countershaft 4th gear	21. Transfer intermediate shaft	28. Transfer output retainer

5B-4 Manual Transmission/Transaxle:

Gear Shift Mechanism

The gear shifting control system consists of the following main parts. Movement of gear shift control lever is transmitted to gear shift & select shaft through gear shift and gear select cables.




I7RW01520011-01

1. Gear shift control cable	7. Reverse gear shift lever	13. Gear shift & select lever
2. Gear select control cable	8. 5th & reverse gear shift guide shaft	14. Low speed gear shift shaft
3. Select cable lever	9. 5th & reverse gear shift shaft	15. High speed gear shift shaft
4. Shift cable lever	10. Gear shift & select shaft assembly	16. Gear shift control lever assembly
5. 5th & reverse gear shift cam	11. 5th to reverse interlock guide bolt	
6. 5th gear shift fork	12. Gear shift interlock bolt	


5th & Reverse Gear Shift Cam

5th & reverse gear shift cam, cam guide return spring and 5th to reverse interlock guide bolt are provided to prevent the gear from being directly shifted from 5th to reverse.



I2RH01520003-02


- 1) When shift lever is at neutral position between 3rd and 4th gear, shift cam (2) is under guide bolt and can turn freely clockwise (to 3rd gear) and counterclockwise (to 4th gear).



I2RH01520004-01

1. Shift & select shaft	4. Reverse select spring (expanded)
3. Return spring (expanded)	


- 2) When shift lever is shifted toward the right from neutral position, shift and select shaft (1) moves up but shift cam (2) is restricted by guide bolt and return spring is contracted.



I2RH01520005-01

3. Reverse select spring (contracted)


- 3) When shift lever is shifted to 5th gear, shift & select shaft (1) turns clockwise letting shift cam (2) off from guide bolt and pushed up by return spring. In this state, movement of shift cam is restricted by guide bolt and therefore, gearshift to reverse is not attainable.



I2RH01520006-01

3. Reverse select spring (expanded)

- 4) When shift lever is shifted from neutral position between 5th gear and reverse gear to reverse gear, shift cam (2) turns counterclockwise to attain reverse gear.



I2RH01520007-01

1. Shift & select shaft	4. Reverse select spring (contracted)
3. Return spring (contracted)	

Diagnostic Information and Procedures

Manual Transaxle Symptom Diagnosis

S7RW0C5204001

Condition	Possible cause	Correction / Reference Item
Gears slipping out of mesh	Worn shift fork shaft	Replace
	Worn shift fork or synchronizer sleeve	Replace
	Weak or damaged locating springs	Replace
	Worn bearings on input shaft or countershaft	Replace
	Worn chamfered tooth on sleeve and gear	Replace sleeve and gear
Hard shifting	Inadequate lubricant	Replenish
	Improper clutch pedal free travel	Replace clutch arm or master cylinder
	Distorted or broken clutch disc	Replace
	Damaged clutch pressure plate	Replace clutch cover
	Worn synchronizer ring	Replace
	Worn chamfered tooth on sleeve or gear	Replace sleeve or gear
	Worn gear shift control shaft joint bush	Replace
	Distorted shift shaft	Replace
	Broken gear shift / select control cables	Replace
Noise	Inadequate or insufficient lubricant	Replenish
	Damaged or worn bearing(s)	Replace
	Damaged or worn gear(s)	Replace
	Damaged or worn synchronizer parts	Replace

Repair Instructions

Manual Transaxle Oil Level Check



S7RW0C5206001

- 1) Lift up vehicle and check oil leakage. Repair leaky point, if any.
- 2) Remove oil level / filler plug (1) and check oil contamination and oil level is lower end of oil level / filler plug hole (2).
If oil is excessive dirty or insufficient, replace oil or pour specified oil up to plug hole.
- 3) Apply sealant to thread of level / filler plug, and then tighten it to specified torque.

“A”: Sealant 99000–31260 (SUZUKI Bond No.1217G)

Tightening torque

Transaxle oil level / filler plug (a): 21 N·m (2.1 kgf-m, 15.5 lb-ft)



I5RW0A520004-01

Manual Transaxle Oil Change

S7RW0C5206002

- 1) Before changing oil, be sure to stop engine and lift vehicle horizontally.
- 2) With vehicle lifted up, check leakage.
If leakage exists, correct it.

NOTE

Whenever vehicle is hoisted for any other service work than oil change, also be sure to check for oil leakage.

- 3) Remove oil level / filler plug (2).
- 4) Remove drain plug (1), and drain old oil.
- 5) Apply sealant to thread of drain plug (1), and tighten it to specified torque.

“A”: Sealant 99000–31260 (SUZUKI Bond No.1217G)

Tightening torque

Transaxle oil drain plug (a): 21 N·m (2.1 kgf-m, 15.5 lb-ft)

- 6) Pour new specified oil until oil level reaches bottom of oil filler plug hole (3) as shown in figure.

NOTE

It is highly recommended to use API GL-4 75W-90 gear oil.

Transaxle oil specification

: API GL-4 (For SAE classification, refer to viscosity chart [A] in figure.)

Transaxle oil capacity




Reference: 2.5 liters (5.3/4.4 US/Imp. pt.)

- 7) Apply sealant to thread of level / filler plug, and then tighten it to specified torque.

“A”: Sealant 99000–31260 (SUZUKI Bond No.1217G)

Tightening torque

Transaxle oil level / filler plug (b): 21 N·m (2.1 kgf-m, 15.5 lb-ft)



I5RW0A520005-01


Differential Side Oil Seal Replacement

S7RW0C5206003

- 1) Lift up vehicle and drain transaxle oil.
- 2) Remove drive shaft assembly and center shaft referring to "Front Drive Shaft Assembly Removal and Installation: Front in Section 3A".
- 3) Remove oil seal (1) by using special tool.

Special tool

(A): 09913-50121



I5RW0A520006-02

- 4) Install a new oil seal (1) by using special tool.

NOTE

- When installing oil seal, face its spring side inward.
- Install oil seal horizontally to surface of case.

Special tool

(A): 09913-75810

(B): 09913-75510

Distance between case and right oil seal for 2WD


"a": 9.5 – 10.5 mm (0.37 – 0.41 in.)

Distance between case and left oil seal

"b": 0 – 1.0 mm (0 – 0.04 in.)

- 5) Apply grease to oil seal lip and at the same time check drive shaft where oil seal contacts and make sure of its smoothness.

"A": Grease 99000-25011 (SUZUKI Super Grease A)




I5RW0A520051-01

- 6) Insert drive shaft assembly and center shaft referring to "Front Drive Shaft Assembly Removal and Installation: Front in Section 3A".
- 7) Pour transaxle oil referring to "Manual Transaxle Oil Change".

Gear Shift Control Lever and Cable Components

S7RW0C5206004



I7RW01520009-02


1. Gear shift control lever knob	6. Gear shift control lever assembly mounting nut	11. Shift cable seal
2. Cable bracket bolt	7. Gear shift control lever assembly	: 13 N·m (1.3 kgf-m, 9.5 lb-ft)
3. Gear shift lever boot	8. Cable grommet bolt	: 10 N·m (1.0 kgf-m, 7.5 lb-ft)
4. Gear shift control cable : Apply grease 99000-25010 to cable end.	9. Cable bracket	: 23 N·m (2.3 kgf-m, 17.0 lb-ft)
5. Gear select control cable : Apply grease 99000-25010 to cable end.	10. Shift lever cover	: Do not reuse.

Gear Shift Control Lever and Cable Removal and Installation

S7RW0C5206005

Removal

- 1) Remove console box.
- 2) Disconnect cable ends (5) from pivot (6) of gear shift control lever assembly by removing clip.
- 3) Disconnect gear shift and select control cables (1) from gear shift control lever assembly (2) while pulling quick joint (4) as shown in figure.
- 4) Remove gear shift control lever assembly mounting nuts (3) and gear shift lever assembly from floor panel.
- 5) Disconnect gear shift and select control cables from transaxle.
- 6) Remove cable grommet bolt, and then remove gear shift and select control cables from floor panel.



I4RS0A520003-01

Installation



Reverse removal procedure for installation nothing the following.

- Tighten each bolts and nuts to specified torque referring to "Gear Shift Control Lever and Cable Components".
- Adjust gear select control cable referring to "Gear Select Control Cable Adjustment".

Gear Select Control Cable Adjustment

S7RW0C5206006

- 1) Release lock plate (1) which restricts moving of cable end holder (2).
- 2) Push cable end holder (2) out from adjuster (4) using appropriate tool (3) to disengage cable.



I4RS0A520004-01

- 3) Apply grease to pin (5) of gear shift control lever, and then install adjuster (1) into pin of gear shift control lever securely.


“A”: Grease 99000–25011 (SUZUKI Super Grease A)

- 4) Push cable end holder (2) in the direction of A.

NOTE

At this time, do not apply force in the cable operation direction B to adjuster.

- 5) Slide lock plate (3) in the direction of C, until it gets over the claw (4) of cable end holder.




I4RS0A520005-01

Back Up Light Switch Removal and Installation

S7RW0C5206007

Removal

- 1) Remove battery and tray with ECM.
- 2) Disconnect back up light switch coupler (1).
- 3) Remove back up light switch.




I5RW0A520009-01

Installation

- 1) Apply oil to new O-ring (1) and tighten back up light switch (2) to specified torque.

Tightening torque

Back up light switch (a): 23 N·m (2.3 kgf-m, 17.0 lb-ft)



I3RH0A520006-01

- 2) Connect back up light switch coupler.
- 3) Install battery and tray with ECM.


Back Up Light Switch Inspection

S7RW0C5206008

Check backup light switch for function using ohmmeter.

Switch ON (Push): Continuity


Switch OFF (Release): No continuity



I5RW0A520050-01

Manual Transaxle Unit Components

S7RW0C5206009



I7RW01520001-01


[A]: Forward	4. Back up light switch connector	8. Transaxle to engine nut
1. Engine	5. Ground cable bolt	9. Stiffener bolt
2. Transaxle	6. Ground cable	 (a) : 85 N·m (8.5 kgf·m, 61.5 lb·ft)
3. Gear shift control cables	7. Transaxle to engine bolt	 (b) : 55 N·m (5.5 kgf·m, 40.0 lb·ft)

Manual Transaxle Unit Dismounting and Remounting

S7RW0C5206010


Dismounting

- 1) Drain coolant.
- 2) Remove battery and tray with ECM.
- 3) Remove air cleaner case and resonator.
- 4) Remove clutch fluid pipe referring to "Clutch Fluid Pipe Removal and Installation in Section 5C".
- 5) Disconnect back up light switch coupler and undo wiring harness clamps.
- 6) Disconnect gear shift and gear select control cables (1) from transaxle.



I5RW0A520011-01


- 7) Remove earth cable from transaxle.
- 8) Remove water inlet pipe.
- 9) Remove starting motor referring to "Starting Motor Dismounting and Remounting in Section 1I".
- 10) Remove transaxle to engine bolt (1) and nut (2) of upper side.



I7RW01520002-01

- 11) Drain transaxle oil and transfer oil (4WD model).
- 12) Remove engine under covers.
- 13) Remove drive shaft assembly and center shaft referring to "Front Drive Shaft Assembly Removal and Installation: Front in Section 3A".
- 14) Remove exhaust No.1 and No.2 pipes referring to "Exhaust Pipe and Muffler Removal and Installation in Section 1K".

- 15) For 2WD model, remove front suspension frame, engine front mounting member and engine mounting member referring to "Front Suspension Frame, Stabilizer Bar and/or Bush Removal and Installation (2WD Model) in Section 2B" and "Engine Mountings Components in Section 1D".
- 16) For 4WD model, remove transfer, engine front mounting member and engine mounting member referring to "Transfer Dismounting and Remounting in Section 3C" and "Engine Mountings Components in Section 1D".
- 17) Support transaxle with transmission jack.
- 18) Remove left mounting and left mounting bracket referring to "Engine Mountings Components in Section 1D".
- 19) Remove stiffener bolts (2), transaxle to engine bolt (1) and nut of lower side, and then lower transaxle.



I7RW01520003-01

Remounting

⚠ CAUTION


- Care should be taken not to scratch oil seal lip with drive shaft while raising transaxle.
- Do not hit drive shaft joint with hammer when installing it into differential gear.

Reverse dismounting procedure for remounting of transaxle, noting the following points.

- Tighten each bolts and nuts to specified torque referring to "Manual Transaxle Unit Components" and "Engine Mountings Components in Section 1D".
- Set each clamp for wiring securely.
- Fill transaxle oil and transfer oil referring to "Manual Transaxle Oil Change" and "Transfer Oil Change in Section 3C".
- Connect battery and check function of engine, clutch and transaxle.

Gear Shift and Select Shaft Assembly Components

S7RW0C5206011



I6RW0C520001-01


1. Gear shift & select shaft	7. Gear shift guide case bolt No.1 : Apply sealant 99000-31260 to bolt thread.	13. Oil seal : Apply grease 99000-25011 to oil seal lip.
2. 5th & reverse gear shift cam	8. Gear shift guide case bolt No.2	: 23 N·m (2.3 kgf-m, 17.0 lb-ft)
3. Gear shift interlock plate	9. 5th to reverse interlock guide bolt : Apply sealant 99000-31260 to bolt thread.	: Do not reuse.
4. Gear shift & select lever	10. Gear shift interlock bolt : Apply sealant 99000-31260 to bolt thread.	: Apply transaxle oil.
5. Shift cable lever	11. Guide case	
6. Select cable lever	12. Select lever bush	

Gear Shift and Select Shaft Assembly Removal and Installation

S7RW0C5206012

Removal

- 1) Remove battery and tray with ECM.
- 2) Disconnect gear shift and gear select control cables from transaxle.
- 3) Remove gear shift interlock bolt (1) and 5th to reverse interlock guide bolt (2) from transaxle case.
- 4) Remove gear shift & select shaft assembly (3).



I5RW0A520016-01

4. Transaxle side cover

Installation

- 1) Clean mating surface of guide case (1) and left case (5), apply sealant to left case as shown in figure by such amount that its section is 1.5 mm (0.059 in.) in diameter, mate guide case with left case.

“B”: Sealant 99000–31260 (SUZUKI Bond No.1217G)

- 2) Install guide case bolts No.1 to which sealant has been applied and guide case bolts No.2 (2), and tighten them to specified torque.

: Sealant 99000–31260 (SUZUKI Bond No.1217G)

Tightening torque

Guide case bolt No.1: 23 N·m (2.3 kgf-m, 17.0 lb-ft)

Guide case bolt No.2 (a): 23 N·m (2.3 kgf-m, 17.0 lb-ft)

- 3) Install washer and gear shift interlock bolt (3) to which sealant has been applied and then tighten it to specified torque.

“A”: Sealant 99000–31260 (SUZUKI Bond No.1217G)

Tightening torque



Gear shift interlock bolt (b): 23 N·m (2.3 kgf-m, 17.0 lb-ft)

- 4) Install washer and 5th to reverse interlock guide bolt (4) to which sealant has been applied and then tighten it to specified torque.

“A”: Sealant 99000–31260 (SUZUKI Bond No.1217G)

Tightening torque

5th to reverse interlock guide bolt (c): 23 N·m (2.3 kgf-m, 17.0 lb-ft)



I5RW0A520017-02

- 5) Connect gear shift and gear select control cables to transaxle.
- 6) Install battery and tray with ECM.
- 7) Check input shaft for rotation in each gear position.

Gear Shift and Select Shaft Assembly Disassembly and Reassembly

S7RW0C5206013

- 1) Push spring pins out using 2.8 – 3.0 mm (0.11 – 0.12 in.) commercially available spring pin remover and specified spring pin removers as shown below.

Special tool


(A): 09922–85811 4.5 mm

(B): 09925–78210 6.0 mm

- 2) Inspect component parts for wear, distortion or damage. If any defect is found, replace defective part with new one.

NOTE

- When driving in spring pins, prevent shaft from being bent by supporting it with wood block.
- Assemble 5th & reverse gear shift cam with its pit and spring pin aligned.
- Make sure to select an appropriate spring by identifying the painted colors to keep gear shifting performance as designed.
 - Low speed select spring - Light blue
 - Reverse select spring - Pink




I6RW0C520002-01

1. E-ring	8. Spring pin
2. Washer	9. Gear shift & select shaft
3. Reverse select spring	10. 5th & reverse gear shift cam
4. Gear shift interlock plate	11. Cam guide return spring
5. Ball	12. 5th & reverse gear shift cam guide
6. Gear shift interlock spring	13. Low speed select spring
7. Gear shift & select lever	14. Spring pin remover

Manual Transaxle Assembly Components

S7RW0C5206014



I7RW01520004-01

1. Transaxle right case	22. Shift fork bolt : Apply thread lock 99000-32110 to all around thread part of bolt.
1217G 2. Transaxle left case : Apply sealant 99000-31260 to mating surface of left case and right case.	23. 5th gear shift fork
1217G 3. Gear shift and select shaft assembly : Apply sealant 99000-31260 to mating surface of guide case and left case.	24. Needle bearing
4. Transaxle left case plate	25. Input shaft 5th gear
1217G 5. Transaxle side cover : Apply sealant 99000-31260 to mating surface of side cover and left case.	26. Reverse gear shift lever
6. Back up light switch	27. Reverse gear shift lever bolt : Apply thread lock 99000-32110 to all around thread part of bolt.
7. O-ring	28. Reverse gear shaft
8. Differential assembly	29. Washer
1217G 9. Oil level / filler plug : Apply sealant 99000-31260 to all around thread part of plug.	30. Reverse idler gear

 10. Oil drain plug : Apply sealant 99000-31260 to all around thread part of plug.	 31. Reverse shaft bolt : Apply sealant 99000-31260 to thread part of bolt.
 11. Oil gutter bolt : Apply thread lock 99000-32110 to all around thread part of bolt.	32. Washer
 12. Left case plate bolt : Apply thread lock 99000-32110 to all around thread part of bolt.	 33. Oil seal : Apply SUZUKI SUPER GREASE A 99000-25010 to Oil seal lip.
13. Side cover bolts	34. Outer race
14. Transaxle case bolts	35. Shim
15. 5th speed synchronizer ring	36. Oil gutter
16. 5th speed synchronizer lever	 (a) : 21 N·m (2.1 kgf-m, 15.5 lb-ft)
17. 5th speed sleeve & hub	 (b) : 23 N·m (2.3 kgf-m, 17.0 lb-ft)
18. Circlip	 (c) : 10 N·m (1.0 kgf-m, 7.5 lb-ft)
19. Bearing set shim	 (d) : 100 N·m (10.0 kgf-m, 72.5 lb-ft)
20. Countershaft 5th gear	 : Do not reuse.
 21. Countershaft nut : After tightening nut to specified torque, caulk nut securely.	 : Apply transaxle oil.

Fifth Gear Disassembly and Reassembly

S7RW0C5206015


Disassembly

- 1) Remove cover bolts and take off transaxle side cover.

CAUTION

Care should be taken not to distort side cover when it is removed from left case.

- 2) Using snap ring pliers, remove circlip (1).
- 3) Remove shift fork shaft bolt (2).
- 4) Remove gear shift fork (3) and 5th gear all together. Use gear puller for removal if spline fitting of hub is tight.




I4RH01520015-01

- 5) Unfasten caulking of countershaft nut (2), install input shaft 5th gear (1) and special tool to stop rotation of shafts, and then remove countershaft nut (2).


Special tool

(A): 09927-76060



I4RH01520016-01


- 6) Remove input shaft 5th gear, needle bearing and then countershaft 5th gear (1). Gear puller (2) would be necessary if spline fitting of countershaft 5th gear is tight.



I4RH01520017-01

Reassembly

- 1) Install countershaft 5th gear (1) to countershaft facing machined boss "A" inward.




I2RH01520088-01

A: Machined boss (Inside)
B: No machining (Outside)

- 2) Apply transaxle oil to needle bearing, and install it to input shaft.
- 3) Install input shaft 5th gear (1) to input shaft.
- 4) Install special tool in order to stop shaft rotation.


Special tool**(A): 09927-76060**

- 5) Tighten new countershaft nut (2) to specified torque, and caulk nut securely.

Tightening torque**Countershaft nut (a): 100 N·m (10.0 kgf-m, 75.0 lb-ft)**


I4RH01520047-01

- 6) Assemble 5th speed synchronizer sleeve (1), hub (2), 5th speed synchronizer levers (3) and synchronizer ring (4) as follows.



I4RH01520054-01

- a) Install hub (1) to 5th speed synchronizer sleeve (2) in specified direction as shown in figure.



I4RH01520048-01


A: Chamfered side

B: Long boss

- b) Fit 5th speed synchronizer levers (1) to hub (2) in specified position as shown in figure.


NOTE

Align protrusion "A" of 5th speed synchronizer levers (1) with groove of hub (2).




I4RH01520049-01

- c) Install synchronizer ring (1) to hub (2) in specified direction as shown in figure.



I4RH01520055-01

- 7) Fit 5th gear shift fork (1) to sleeve (3) and hub (2) assembly, and install them into input shaft and gear shift shaft, aligning punch mark (4) with matching mark (5) on input shaft.



I3RH0A520080-01


- 8) Tighten shift fork shaft bolt (2) to which thread lock cement has been applied.

“A”: Thread lock cement 99000–32110 (Thread Lock Cement Super 1322)

Tightening torque

Shift fork shaft bolt (a): 10 N·m (1.0 kgf-m, 7.5 lb-ft)

- 9) Using snap ring pliers, install new circlip (1) to input shaft (3).




I5RW0A520019-01

- 10) Clean mating surface of both left case and side cover (1), apply sealant to side cover as shown in figure by such amount that its section is 1.5 mm (0.059 in.) in diameter, mate it with left case, and then tighten side cover bolts with specified torque.

“B”: Sealant 99000–31260 (SUZUKI Bond No.1217G)

Tightening torque

Side cover bolt (a): 10 N·m (1.0 kgf-m, 7.5 lb-ft)




I5RW0A520020-01

Manual Transaxle Assembly Disassembly and Reassembly

S7RW0C5206016

Disassembly


- 1) Remove left case plate bolts (1), and take off left case plate (2).



I4RH01520018-01

3. Input shaft

- 2) Remove bearing set shim.
- 3) Remove snap ring (1) using snap ring pliers (4).




I7RW01520005-01

2. Input shaft


3. Input shaft left bearing

- 4) Remove gear shift locating bolts (1), then take out locating springs and steel balls.



I5RW0A520021-01

- 5) Remove reverse shaft bolt (2) with washer.
- 6) Remove transaxle case bolts (1) from outside and another bolts from clutch housing side.
- 7) Tapping left case flanges with plastic hammer, remove left case.




I4RH01520020-01

- 8) Pull out reverse gear shaft (1) with washer (2), then take off reverse idler gear (3).
- 9) Remove reverse gear shift lever bolts (4) and reverse gear shift lever (5).
- 10) Pull out 5th & reverse gear shift guide shaft (6) together with 5th & reverse gear shift shaft (7).


NOTE

When removing 5th & reverse gear shift shaft (7) and guide shaft (6), push up high speed gear shift shaft and shift it to 4th to facilitate removal of 5th & reverse shift shaft.



I3RH0A520012-01

- 11) Tapping input shaft end with plastic hammer, push it out as assembly from case a little, then take out input shaft assembly (1), countershaft assembly (2), high speed gear shift shaft (3) and low speed gear shift shaft (4) all at once.



I2RH01520035-01


- 12) Remove countershaft left bearing outer race from left case.
- 13) Remove differential assembly from right case.

Reassembly

- 1) Install differential assembly into right case.
- 2) Join input shaft (5), countershaft (4), low speed gear shift shaft (2) and high speed gear shift shaft (3) assemblies all together, then install them into right case (1) so as not to damage oil seal by input shaft spline.


NOTE

- Input shaft right bearing on shaft can be installed into right case (1) by tapping shaft with plastic hammer.
- Make sure that countershaft is engaged with final gear while installing.



I2RH01520080-01

- 3) Install 5th & reverse gear shift shaft (1) with 5th & reverse gear shift guide shaft (2) into right case (5). Reverse gear shift arm (4) has to be joined with reverse gear shift lever (3) at the same time.



I3RH0A520013-01

- 4) Make reverse idler gear (1) with reverse gear shift lever (2), insert reverse gear shaft (3) and washer (6) into case (4) through idler gear and then align bolt hole "a" in shaft with notch "b" in case.
- 5) Fasten reverse gear shift lever bolts (5) after applying thread lock cement.

"A": Thread lock cement 99000-32110 (Thread Lock Cement Super 1322)



Tightening torque

Reverse gear shift lever bolt (a): 23 N·m (2.3 kgf-m, 17.0 lb-ft)

NOTE

Check to confirm that reverse gear shift lever end has clearance "c" to idler gear groove.

Distance between lever end and idler gear shaft "c": 0.5 – 1.0 mm (0.02 – 0.04 in.)



I5RW0A520022-02

- 6) Clean mating surfaces of both right and left cases, apply sealant to left case (2) as shown in the figure by such amount that its section is 1.5 mm (0.059 in.) in diameter then mate it with right case (1).

“A”: Sealant 99000–31260 (SUZUKI Bond No.1217G)

- 7) Tighten case bolts (3) from outside and tighten another case bolts from clutch housing side to specified torque.

Tightening torque



Transaxle case bolt (a): 23 N·m (2.3 kgf-m, 17.0 lb-ft)

- 8) Install reverse shaft bolt (4) to which thread lock cement has been applied, with aluminum washer and tighten it to specified torque.

“B”: Sealant 99000–31260 (SUZUKI Bond No.1217G)

Tightening torque

Reverse shaft bolt (b): 21 N·m (21 kgf-m, 15.5 lb-ft)



I5RW0A520023-01

- 9) Check locating springs (2, 4 and 5) for deterioration and replace with new ones as necessary.

Locating spring


Locating spring free length	Standard	Service limit
Low speed (2)	53.1 mm (2.091 in.)	47.8 mm (1.881 in.)
High speed (4)	45.9 mm (1.807 in.)	41.4 mm (1.629 in.)
5th & reverse (5)	29.9 mm (1.777 in.)	27.0 mm (1.062 in.)

- 10) Install steel balls (3) and locating springs (2, 4 and 5) for respective gear shift shaft and tighten bolts (1) to which thread lock cement has been applied.

“A”: Thread lock cement 99000–32110 (Thread Lock Cement Super 1322)


Tightening torque

Gear shift locating bolt (a): 13 N·m (1.3 kgf-m, 9.5 lb-ft)



I5RW0A520024-02

- 11) Install new snap ring (1) using snap ring pliers (4).




I7RW01520006-01

2. Input shaft

3. Input shaft left bearing

- 12) To seat countershaft left bearing outer race (2) to bearing cone, tap cup by using special tool and plastic hammer.

Special tool**(A): 09913-70123**

I5RW0A520025-01

1. Input shaft

- 13) Before selecting shim, keep pushing outer race with the power of 200 N (20.0 kgf) and turn countershaft (2) 10 time or more.
- 14) Put a shim (3) on bearing outer race (4) provisionally, place straight edge (1) over it and compress it by hand through straight edge, and then measure "a" (Clearance between case surface (5) and straight edge) by using feeler gauge (6).

Clearance between case surface and straight edge**"a": 0.08 – 0.13 mm (0.0032 – 0.0050 in.)**



- 15) By repeating step 14), select a suitable shim which adjusts clearance "a" to specification and put it on bearing outer race.

NOTE

Insert 0.1 mm (0.004 in.) feeler to know whether or not a shim fulfills specification quickly.

Available countershaft 5th gear shim thickness

0.55 mm (0.021 in.)	0.7 mm (0.027 in.)	0.85 mm (0.033 in.)	1.0 mm (0.039 in.)
0.6 mm (0.023 in.)	0.75 mm (0.029 in.)	0.9 mm (0.035 in.)	1.05 mm (0.041 in.)
0.65 mm (0.025 in.)	0.8 mm (0.031 in.)	0.95 mm (0.037 in.)	1.1 mm (0.043 in.)



I7RW01520012-01

[A]: Press 200 N (20.0 kgf)

- 16) Place left case plate (2) inserting its end in groove of shift guide shaft (4) and then tighten bolts (1) to which thread lock cement has been applied.


NOTE

After tightening bolts, make sure that countershaft can be rotated by hand feeling certain load.

"A": Thread lock cement 99000-32110 (Thread Lock Cement Super 1322)

Tightening torque

Left case plate bolt (a): 23 N·m (2.3 kgf-m, 17.0 lb-ft)



I2RH01520087-01

3. Input shaft


5. Countershaft

Right Case Disassembly and Reassembly

S7RW0C5206017

Disassembly

- 1) Remove differential side oil seal from right case referring to "Differential Side Oil Seal Replacement", if necessary.
- 2) Remove differential side bearing outer race (1) using brass bar (2), if necessary.




I4RH01520024-01

- 3) Remove input shaft oil seal by using special tool, if necessary.

Special tool

(A): 09913-75830




I5RW0A520026-01

- 4) Pull out countershaft right bearing outer race by using special tools, if necessary.

Special tool

(A): 09930-30104

(B): 09941-64511



I5RW0A520027-01


Reassembly

- 1) Install input shaft oil seal facing its spring side upward until it becomes flush with case surface. Use special tool and hammer for installation and apply grease to oil seal lip.

: Grease 99000-25011 (SUZUKI Super Grease A)

Special tool

(A): 09913-76010




I5RW0A520028-01

- 2) Install countershaft right bearing outer race (1) by using special tools and hammer.

Special tool

(A): 09913-75821

(B): 09924-84510-004




I5RW0A520029-02

- 3) Install differential side bearing outer race by using special tool and hammer.

Special tool

(A): 09924-74510

(B): 09925-14520




I5RW0A520030-01

Left Case Disassembly and Reassembly

S7RW0C5206018

Disassembly

- 1) Removal oil gutter (1), if necessary.




I4RH01520028-01

- 2) Remove oil seal using flat end rod or the like.
- 3) Remove differential side bearing outer race (1) using special tools and then remove shim.

Special tool

(A): 09942-15511

(B): 09944-96011



I5RW0A520031-01


Reassembly

- 1) If oil gutter has been removed, install it with bolt to which thread lock cement has been applied.

“A”: Thread lock cement 99000-32110 (Thread Lock Cement Super 1322)

Tightening torque

Oil gutter bolt (a): 10 N·m (1.0 kgf-m, 7.5 lb-ft)




I2RH01520043-01

2) Select differential side shim as follows.

- Keep pushing outer race (4) with the power of 35 N (3.5 kgf) and turn differential case 10 times or more.
- Measure distance "a" of differential assembly (1).
- Measure depth "b" of left case (2) and "c" of right case (3).
- Calculate the clearance of "d" by the following expressions.

$$\text{Clearance of "d"} = \text{Depth "b"} + \text{Depth "c"} - \text{Distance "a"}$$



I7RW01520013-01

[A]: Press 35 N (3.5 kgf)

3) Select shim closest to clearance "d" from among the following available sizes.

Available shim thickness


Clearance "d"	Select shim
0.800 – 0.839 mm (0.0315 – 0.0330 in.)	1.00 mm (0.0394 in.)
0.840 – 0.879 mm (0.0331 – 0.0345 in.)	1.04 mm (0.0409 in.)
0.880 – 0.919 mm (0.0346 – 0.0362 in.)	1.08 mm (0.0425 in.)
0.920 – 0.959 mm (0.0362 – 0.0378 in.)	1.12 mm (0.0441 in.)
0.960 – 0.999 mm (0.0378 – 0.0393 in.)	1.16 mm (0.0457 in.)
1.000 – 1.039 mm (0.0394 – 0.0409 in.)	1.20 mm (0.0472 in.)
1.040 – 1.079 mm (0.0409 – 0.0425 in.)	1.24 mm (0.0488 in.)
1.080 – 1.119 mm (0.0425 – 0.0441 in.)	1.28 mm (0.0504 in.)
1.120 – 1.159 mm (0.0441 – 0.0456 in.)	1.32 mm (0.0520 in.)
1.160 – 1.199 mm (0.0457 – 0.0472 in.)	1.36 mm (0.0535 in.)
1.200 – 1.239 mm (0.0472 – 0.0488 in.)	1.40 mm (0.0551 in.)
1.240 – 1.279 mm (0.0488 – 0.0504 in.)	1.44 mm (0.0567 in.)
1.280 – 1.319 mm (0.0504 – 0.0519 in.)	1.48 mm (0.0583 in.)
1.320 – 1.359 mm (0.0520 – 0.0535 in.)	1.52 mm (0.0598 in.)
1.360 – 1.399 mm (0.0535 – 0.0551 in.)	1.56 mm (0.0614 in.)
1.400 – 1.439 mm (0.0551 – 0.0567 in.)	1.60 mm (0.0630 in.)
1.440 – 1.479 mm (0.0567 – 0.0582 in.)	1.64 mm (0.0646 in.)
1.480 – 1.529 mm (0.0583 – 0.0602 in.)	1.68 mm (0.0661 in.)

4) Put shim and then install differential side bearing outer race using special tools.

Special tool

(A): 09924-74510

(B): 09925-14520




I5RW0A520032-01

5) Install oil seal referring to "Differential Side Oil Seal Replacement".

Input Shaft and Countershaft Components

S7RW0C5206019



I7RW0C520001-02


[A]: Hatchback Type 1 model	12. Input shaft left bearing	25. Circlip
[B]: Other than hatchback Type 1 model	13. Circlip	26. Countershaft 2nd gear
1. Input shaft	14. 5th gear spacer	27. Countershaft 3rd gear
2. Oil seal : Apply grease 99000-25010 to oil seal lip.	15. Countershaft right bearing	28. 3rd & 4th gear spacer
3. Input shaft right bearing	16. Countershaft	29. Countershaft 4th gear
4. Input shaft 3rd gear	17. Countershaft 1st gear	30. Countershaft left bearing
5. Needle bearing	18. Low speed synchronizer ring	31. Low speed synchronizer outer ring
6. High speed synchronizer ring	19. Low speed synchronizer spring	32. Low speed synchronizer center cone
7. High speed synchronizer spring	20. Low speed synchronizer sleeve & hub	33. Low speed synchronizer inner ring
8. High speed synchronizer sleeve & hub	21. Low speed synchronizer key	: Do not reuse.
9. High speed synchronizer key	22. 2nd gear synchronizer outer ring	: Apply transaxle oil.
10. Circlip	23. 2nd gear synchronizer center cone	
11. Input shaft 4th gear	24. 2nd gear synchronizer inner ring	

Input Shaft Disassembly and Reassembly

S7RW0C5206020

Disassembly

- 1) Remove input shaft right bearing (2) from input shaft (1) using bearing puller (3) and hydraulic press.




I4RH01520029-01

- 2) Drive out 5th gear spacer (2), left bearing (3) and 4th gear (4) all at once using puller (5) and hydraulic press.

⚠ CAUTION

- To avoid gear tooth from being damaged, support it at flat side of bearing puller.
- Stop press work in the middle way and take out 5th gear bush to prevent it from being compressed and then continue to remove bearing with gear.




I3RH0A520018-01

1. Input shaft

- 3) Take out 4th gear needle bearing and high speed synchronizer ring.
- 4) Using snap ring pliers (2), remove circlip (1).

NOTE

For smooth removal of circlip, it is recommended to correct tool tips to be flat.




I7RW01520007-01

- 5) Drive out high speed synchronizer sleeve & hub assembly (2) together with 3rd gear (3) by using puller (4) and hydraulic press.

⚠ CAUTION

To avoid gear tooth from being damaged, support it at flat side of bearing puller.



I2RH01520097-01

1. Input shaft

- 6) Take out 3rd gear needle bearing from input shaft.
- 7) Disassemble synchronizer sleeve & hub assembly.

Reassembly

- 1) Clean all components thoroughly, inspect them for any abnormality and replace with new ones as necessary.
- 2) Check clearance "a" between synchronizer ring (2) and gear (1), key slot width "b" in synchronizer ring and each chamfered tooth of gear and synchronizer ring and replace with new one, if necessary. Also, check gear tooth.

Clearance "a" between synchronizer ring and gear


Standard: 1.0 – 1.4 mm (0.040 – 0.055 in.)

Service limit: 0.5 mm (0.020 in.)

Key slot width "b"


Standard: 10.0 – 10.2 mm (0.394 – 0.401 in.)

Limit: 10.45 mm (0.411 in.)



I5JB0A520054-01

- 3) To ensure lubrication of input shaft (1), air blow oil holes (2) and make sure that they are free from any obstruction.



I2RH01520049-01


- 4) Fit high speed synchronizer sleeve (4) to hub (3), insert 3 keys (2) in it and then set springs (1) as shown in figure.

NOTE

- No specific direction is assigned to high speed synchronizer sleeve or each key but it is assigned as assembly.
- Size of high speed synchronizer sleeve, hub, keys and springs are the smaller than those of low speed one.

Synchronizer key installation position

A = B




I5RW0A520033-01

[A]: 4th gear side	D: Key way
C: Left side (Short flange)	E: Projecting end

- 5) Drive in right bering (1) to input shaft (2) using special tool and hydraulic press.

Special tool

(A): 09913-80113




I3RH0A520019-01

- 6) Install 3rd gear needle bearing (4), apply oil to it, then install 3rd gear (1) and synchronizer ring (2).
- 7) Drive in high speed sleeve & hub assembly (3) by using special tool and hydraulic press.

NOTE

- While press-fitting sleeve & hub, make sure that synchronizer ring key slots are aligned with keys (5) in sleeve & hub assembly.
- Check free rotation of 3rd gear after press-fitting sleeve & hub assembly.
- Synchronizer rings for 3rd and 4th are identical.


Special tool
(B): 09913-84510



I5RW0A520034-02

[A]: 3rd gear side	B: Long boss
A: Key way	

- 8) Install circlip (1) and confirm that circlip is installed in groove securely. Install needle bearing (2) of apply oil to it and then install synchronizer ring (3) and 4th gear (4).



I2RH01520052-01

5. Input shaft


- 9) Press-fit left bearing (2) by using special tool and hydraulic press.

Special tool
(A): 09913-80113

- 10) Using the same special tool at step 9), drive in 5th gear spacer (1).

⚠ CAUTION

To prevent 5th gear spacer (1) from being distorted because of excessive compression, do not press-fit it with left bearing (2) at once.



I3RH0A520020-01

Countershaft Disassembly and Reassembly


S7RW0C5206021

Disassembly

- 1) Drive out left bearing cone (2) with 4th gear (3) by using puller (4) and hydraulic press.

⚠ CAUTION

- Use puller and hydraulic press that will bear at least 5 ton (11,000 lb) safely.
- To avoid tooth damage, support 4th gear (3) at flat side of puller.




I2RH01520054-01

1. Countershaft

- 2) Apply puller (5) to 2nd gear (4) and drive out 3rd & 4th gear spacer (2) and 3rd gear (3) together with 2nd gear by using hydraulic press. Needle bearing would come out with 2nd gear.

⚠ CAUTION

- If compression exceeds 5 ton (11,000 lb), release compression once, reset bearing puller and then continue press work again.
- To avoid gear tooth from being damaged, support it at flat side of bearing puller.




I2RH01520055-01

1. Countershaft

- 3) Take out 2nd synchronizer outer ring, center cone and inner ring.
- 4) Using snap ring pliers (3), remove circlip (1).

NOTE

Correct tool tips to be flat to facilitate removal of circlip.




I7RW01520008-01

2. Low speed synchronizer sleeve

- 5) Apply puller (3) to 1st gear (2) and drive out low speed synchronizer sleeve & hub assembly (1) with 1st gear by using hydraulic press.

⚠ CAUTION

To avoid gear tooth from damage, support it at flat side of bearing puller.




I2RH01520057-01


- 6) Disassemble synchronizer sleeve & hub assembly.
- 7) Take out 1st gear needle bearing from shaft.
- 8) In order to remove right bearing (1) from countershaft, grind with a grinder (2) one part "a" of right bearing (1) as illustrated till it becomes thin.

⚠ CAUTION

Be careful not to grind too far not to damage the shaft (3).



- 9) Break with a chisel (1) the thin ground right bearing (2) and it can be removed.



Reassembly


- 1) Clean all components thoroughly, inspect them for any abnormality and replace with new one as necessary.
- 2) For hatchback model Type 1, check clearance "a" between synchronizer ring (2) and gear (1), key slot width "b" in synchronizer ring and each chamfered tooth of gear and synchronizer ring and replace with new one, if necessary. Also, check gear tooth.

Clearance "a" between synchronizer ring and gear (1st of hatchback model Type 1)

Standard: 1.0 – 1.4 mm (0.040 – 0.055 in.)
Service limit: 0.5 mm (0.020 in.)


Key slot width "b"

Standard: 10.0 – 10.2 mm (0.394 – 0.401 in.)
Limit: 10.45 mm (0.411 in.)




- 3) Put the synchronizer outer ring (1), inner ring (3) and the cone (2) together and then measure the step difference between the outer ring and the inner ring. And also check each chamfered tooth of gear and synchronizer ring and replace with new one, if necessary. Also, check gear tooth.

Difference between synchronizer outer ring and inner ring (2nd of hatchback model Type 1 or 1st and 2nd of other than hatchback Type 1 model)
Standard "b": 0.95 – 1.25 mm (0.036 – 0.048 in.)
Service limit "b": 0.5 mm (0.019 in.)



- 4) To ensure lubrication of countershaft (1), air blow oil holes (2) and make sure that they are free from any obstruction.




- 5) Fit low speed synchronizer sleeve (4) to hub (3), insert 3 keys (2) in it and then set springs (1) as shown in figure.

NOTE

- No specific direction is assigned to each key but it is assigned as sleeve & hub assembly.
- Size of low speed synchronizer keys and springs are the larger than those of high speed one.

Synchronizer key installation position

"a" = "b"



I7RW0C520003-01


[A]: Hatchback Type 1 model	[C]: 1st gear side
[B]: Other than hatchback Type 1 model	5. Key way

- 6) Install right bearing cone (1) to counter shaft (2) by using special tools and hydraulic press.

Special tool

(A): 09913-76010

(B): 09924-07720



I5RW0A520038-01

- 7) Install needle bearing (4), apply oil to it, then install 1st gear (3).
- 8) For hatchback Type 1 model, install synchronizer ring to 1st gear.
For other than hatchback Type 1 model, install synchronizer outer ring, center cone and inner ring to 1st gear.
- 9) Drive in low speed sleeve & hub assembly (1) by using special tools and hammer.

NOTE

- Support shaft with special tool as shown in figure so that retainer of bearing cone (4) will be free from compression.
- Make sure that low speed synchronizer ring (hatchback type 1 model) or low speed synchronizer outer ring (other than hatchback type 1 model) key slots are aligned with keys (2) while press-fitting sleeve & hub assembly.
- Check free rotation of 1st gear (3) after press-fitting sleeve & hub assembly.


Special tool

(A): 09923-78210

(B): 09913-85210

(C): 09940-54910


(D): 09924-07710



I7RW0C520002-01

[A]: Hatchback Type 1 model	5. Key slots
[B]: Other than hatchback Type 1 model	6. Short flange
[C]: 1st gear side	

- 10) Install circlip (1) and confirm that circlip is installed in groove securely.
Install needle bearing (2) and apply oil to needle bearing.
With synchronizer outer ring (3), center cone (4) and inner ring (5) put together and installed to 2nd gear (6) as shown in figure.



I5RW0A520040-01

[A]: Section A - A

- 11) Press-fit 3rd gear (2) and spacer (1) by using special tools and hydraulic press.


NOTE

It is recommended to press-fit spacer and 3rd gear first, and then 4th gear later separately so that countershaft will not be compressed excessively.

Special tool

(A): 09923-78210

(B): 09913-85210



I4RH01520036-01

3. 2nd gear

- 12) Press-fit 4th gear (2) by using the same procedure at step 10).
13) Install left bearing cone (1) by using special tool and hydraulic press.


NOTE

For protection of bearing cone (3), always support shaft with special tool as shown in figure.

Special tool

(A): 09923-78210


(E): 09913-80113



I2RH01520066-01

Gear Shift Shaft Components

S7RW0C5206022



I5RW0A520041-01

1. Low speed gear shift shaft	4. 5th & reverse gear shift guide shaft	7. 5th & reverse gear shift yoke
2. High speed gear shift shaft	5. Reverse gear shift arm	Ⓐ : 13 N-m (1.3 kgf-m, 9.5 lb-ft)
3. 5th & reverse gear shift shaft	Ⓐ 6. Gear shift locating bolt : Apply sealant 99000-31260 to bolt thread.	

5th and Reverse Gear Shift Shafts Disassembly and Reassembly

S7RW0C5206023

Disassembly

Disassemble component parts by using special tool and hammer.

Special tool


: 09922-85811

Reassembly

Replace or correct parts as required and assemble shafts making sure that component parts are in proper order as shown in figure.

NOTE

Install 2 steel balls (3) in reverse gear shift arm (1) without fail.



I5RW0A520042-01

2. Spring	6. 5th & reverse gear shift yoke
4. Spring pin	7. 5th & reverse gear shift guide shaft
5. 5th & reverse gear shift shaft	

Gear Shift Shaft and Fork Inspection


S7RW0C5206024

- Using feeler gauge, check clearance between fork (1) and sleeve (2) and replace those parts if it exceeds limit of 1.0 mm (0.039 in.).

NOTE

For correct judgement of parts replacement, carefully inspect contact portion of fork and sleeve.

Clearance "a" between fork and sleeve
Service limit: 1.0 mm (0.039 in.)




I2RH01520068-01

- Insert each gear shift shaft into case and check that it moves smoothly. If it doesn't, correct by using oilstone, reamer or the like.

Differential Components

S7RW0C5206025



I5RW0A520043-02

1. Differential pinion washer	6. Differential case	: 90 N·m (9.0 kgf-m, 65.0 lb-ft)
2. Differential pinion	7. Final gear	: Do not reuse.
3. Differential side gear	8. Final gear bolt	: Apply transaxle oil.
4. Side gear washer	9. Differential pinion shaft	
5. Differential side bearing	10. Differential pinion shaft pin	

Differential Disassembly and Reassembly


S7RW0C5206026

Disassembly

1) Using special tool, remove left bearing (1).

Special tool

- (A): 09913-65135
(B): 09913-85230




I5RW0A520044-01

2) Using special tool, remove right bearing (1).

Special tool

- (A): 09913-65135
(B): 09913-85230
(C): 09940-54950




I5RW0A520045-01

- 3) Support differential case (1) with soft jawed vise and remove final gear bolts then take out final gear.
- 4) Drive out differential pinion shaft (3) pin by using special tool and hammer and then disassemble components parts.

Special tool

(A): 09922-85811



I5RW0A520046-01

2. Differential side gear

Reassembly

Judging from abnormality noted before disassembly and what is found through visual check of component parts after disassembly, prepare replacing parts and proceed to reassembly. Make sure that all parts are clean.

- 1) Install differential pinion, side gear and pinion shaft to differential case and measure back rash and thrust play of differential side gear as follows. If measured value is out of specification, select suitable side gear washer from among the following available size, install it and check again.

Special tool

(A): 09900-20607

(B): 09900-20701

(C): 09952-06010

- a) Differential side gear backlash
 - Hold differential assembly with soft jawed vise and apply measuring tip of dial gauge to side gear as shown in figure.
 - Fixing differential pinion, turn side gear back and forth and read dial gauge.

Differential side gear backlash

0.10 – 0.15 mm (0.003 – 0.005 in.)



- b) Differential side gear thrust play
 - Hold differential assembly with soft jawed vise and apply measuring tip of dial gauge to side gear as shown in figure.
 - Move side gear up and down by hand and read dial gauge.

Differential side gear thrust play

0.03 – 0.31 mm (0.001 – 0.012 in.)

Available side gear washer thickness

0.9 mm (0.035 in.)	1.1 mm (0.043 in.)
0.95 mm (0.037 in.)	1.15 mm (0.045 in.)
1.0 mm (0.039 in.)	1.20 mm (0.047 in.)
1.05 mm (0.041 in.)	




I5RW0A520047-01

- 2) Drive in spring pin from right side till it is flush with differential case surface.
- 3) Press-fit left bearing (1) by using special tool and hydraulic press.

Special tool

(A): 09913-70123



I2RH01520074-01

2. Differential case


- 4) Press-fit right bearing (1) by using special tools and hydraulic press.

Special tool

(A): 09925-15410

(B): 09924-07720

(C): 09913-85230



I5RW0A520048-01

2. Differential case

3. Differential side left bearing


- 5) Hold differential assembly with soft jawed vise (3), install final gear (2) and then tighten new final gear bolts (1).

⚠ CAUTION

Use of any other bolts than specified ones is prohibited. Otherwise, bolts may loosen.

Tightening torque

Final gear bolt (a): 90 N·m (9.0 kgf-m, 65.0 lb-ft)



I5RW0A520049-01

Specifications

Tightening Torque Specifications

S7RW0C5207001

Fastening part	Tightening torque			Note
	N·m	kgf-m	lb-ft	
Transaxle oil level / filler plug	21	2.1	15.5	⌚ / ⌚
Transaxle oil drain plug	21	2.1	15.5	⌚
Back up light switch	23	2.3	17.0	⌚
Guide case bolt No.1	23	2.3	17.0	⌚
Guide case bolt No.2	23	2.3	17.0	⌚
Gear shift interlock bolt	23	2.3	17.0	⌚
5th to reverse interlock guide bolt	23	2.3	17.0	⌚
Countershaft nut	100	10.0	75.0	⌚
Shift fork shaft bolt	10	1.0	7.5	⌚
Side cover bolt	10	1.0	7.5	⌚
Reverse gear shift lever bolt	23	2.3	17.0	⌚
Transaxle case bolt	23	2.3	17.0	⌚
Reverse shaft bolt	21	2.1	15.5	⌚
Gear shift locating bolt	13	1.3	9.5	⌚
Left case plate bolt	23	2.3	17.0	⌚
Oil gutter bolt	10	1.0	7.5	⌚
Final gear bolt	90	9.0	65.0	⌚

NOTE

The specified tightening torque is also described in the following.

“Gear Shift Control Lever and Cable Components”

“Manual Transaxle Unit Components”

“Gear Shift and Select Shaft Assembly Components”

“Manual Transaxle Assembly Components”

“Gear Shift Shaft Components”

“Differential Components”

Reference:

For the tightening torque of fastener not specified in this section, refer to “Fasteners Information in Section 0A”.

Special Tools and Equipment

Recommended Service Material

S7RW0C5208001

Material	SUZUKI recommended product or Specification		Note
Grease	SUZUKI Super Grease A	P/No.: 99000–25011	🔧 / 🔧 / 🔧
Sealant	SUZUKI Bond No.1217G	P/No.: 99000–31260	🔧 / 🔧 / 🔧 / 🔧 / 🔧 / 🔧 / 🔧 / 🔧 /
Thread lock cement	Thread Lock Cement Super 1322	P/No.: 99000–32110	🔧 / 🔧 / 🔧 / 🔧 / 🔧

NOTE

Required service material is also described in the following.

“Gear Shift Control Lever and Cable Components”

“Gear Shift and Select Shaft Assembly Components”

“Manual Transaxle Assembly Components”











“Input Shaft and Countershaft Components”















“Gear Shift Shaft Components”

“Differential Components”





Special Tool

S7RW0C5208002

09900–20607 Dial gauge 🔧		09900–20701 Magnetic stand 🔧	
09913–50121 Oil seal remover 🔧		09913–65135 Bearing puller 🔧 / 🔧	
09913–70123 Bearing installing tool 🔧 / 🔧		09913–75510 Bearing installer 🔧	
09913–75810 Bearing installer 🔧		09913–75821 Bearing installer attachment 🔧	
09913–75830 Steering pinion bush installer 🔧		09913–76010 Bearing installer 🔧 / 🔧	

09913-80113 Bearing installer  /  /  	09913-84510 Bearing installer  
09913-85210 Bearing installer  /  	09913-85230 Bearing remover tool  /  /  
09922-85811 Spring pin remover (4.5 mm)  /  /  	09923-78210 Bearing installer  /  /  
09924-07710 Synchronizer hub installer  	09924-07720 Synchronizer hub installer  /  
09924-74510 Bearing and oil seal handle  /  	09924-84510-004 Bearing installer attachment  
09925-14520 Bearing and oil seal installer (80 x 50 mm)  /  	09925-15410 Oil seal installer  
09925-78210 Spring pin remover (6 mm)  	09927-76060 Gear holder  /  
09930-30104 Sliding shaft  	09940-54910 Front fork oil seal install driver  

5B-42 Manual Transmission/Transaxle:

09940-54950 Bearing installer attachment  Hand icon	09941-64511 Bearing and oil seal remover (30 mm Min.)  Hand icon
09942-15511 Sliding hammer  Hand icon	09944-96011 Bearing outer race remover  Hand icon
09952-06010 Dial gauge plate No.1  Hand icon	

Clutch

General Description

Clutch (Hydraulic Type) Construction


S7RW0C5301001

The clutch is a diaphragm spring clutch of a dry single disc type. The diaphragm spring is of a tapering-finger type, which is a solid ring in the outer diameter part, with a series of tapered fingers pointing inward.

The disc, carrying four torsional coil springs, is positioned on the transaxle input shaft with an involute spline fit.

The clutch cover is secured to the flywheel, and carries the diaphragm spring in such a way that the peripheral edge part of the spring pushes on the pressure plate against the flywheel (with the disc in between), when the clutch release bearing (incorporated in clutch operating cylinder) is held back. This is the engaged condition of the clutch.

Depressing the clutch pedal causes the release bearing (incorporated in clutch operating cylinder) to advance and pushes on the tips of the tapered fingers of the diaphragm spring. When this happens, the diaphragm spring pulls the pressure plate away from the flywheel, thereby interrupting the flow of drive from flywheel through clutch disc to transaxle input shaft. Clutch fluid is supplied from brake fluid reservoir. Clutch fluid level can be checked by brake fluid level of brake fluid reservoir.



I5RW0A530001-01

1. Crankshaft	4. Pressure plate	7. Operating cylinder assembly
2. Flywheel	5. Clutch cover	8. Input shaft bearing
3. Clutch disc	6. Diaphragm spring	9. Input shaft

Diagnostic Information and Procedures

Clutch System Symptom Diagnosis

S7RW0C5304001

Condition	Possible cause	Correction / Reference Item
Slipping	Improper clutch pedal free travel	<i>Bleed air or replace master cylinder.</i>
	Worn or oily clutch disc facing	<i>Replace disc.</i>
	Warped disc, pressure plate or flywheel surface	<i>Replace disc, clutch cover or flywheel.</i>
	Weakened diaphragm spring	<i>Replace clutch cover.</i>
	Master cylinder piston or seal cup not returning	<i>Replace master cylinder.</i>
Dragging clutch	Improper clutch pedal free travel	<i>Bleed air or replace master cylinder.</i>
	Weakened diaphragm spring, or worn spring tip	<i>Replace clutch cover.</i>
	Rusted input shaft splines	<i>Lubricate.</i>
	Damaged or worn splines of transaxle input shaft	<i>Replace input shaft.</i>
	Excessively wobbly clutch disc	<i>Replace disc.</i>
	Clutch facings broken or dirty with oil	<i>Replace disc.</i>
	Fluid leakage	<i>Repair or replace.</i>
Clutch vibration	Glazed (glass-like) clutch facings	<i>Repair or replace disc.</i>
	Clutch facings dirty with oil	<i>Replace disc.</i>
	Release bearing slides unsmoothly	<i>Replace clutch operating cylinder assembly.</i>
	Wobbly clutch disc, or poor facing contact	<i>Replace disc.</i>
	Weakened torsion springs in clutch disc	<i>Replace disc.</i>
	Clutch disc rivets loose	<i>Replace disc.</i>
	Distorted pressure plate or flywheel surface	<i>Replace clutch cover or flywheel.</i>
	Weakened engine mounting	<i>Replace engine mounting.</i>
	Loosened engine mounting bolt or nut	<i>Retighten engine mounting bolt or nut.</i>
Noisy clutch	Worn or broken release bearing	<i>Replace clutch operating cylinder assembly.</i>
	Input shaft front bearing worn down	<i>Replace input shaft bearing.</i>
	Excessive rattle of clutch disc hub	<i>Replace disc.</i>
	Cracked clutch disc	<i>Replace disc.</i>
	Pressure plate and diaphragm spring rattling	<i>Replace clutch cover.</i>
Grabbing clutch	Clutch disc facings soaked with oil	<i>Replace disc.</i>
	Clutch disc facings excessively worn	<i>Replace disc.</i>
	Rivet heads showing out of facing	<i>Replace disc.</i>
	Weakened torsion springs	<i>Replace disc.</i>

Repair Instructions

Clutch Pedal Inspection

S7RW0C5306001

Cylinder Push Rod Play "a"

- 1) Press clutch pedal (1) gradually with finger, stop when slight increase of resistance is felt and measure how much pedal has moved (push rod play) as represented by "a" as shown.

Push rod play

"a": Max. 3 mm (0.12 in.)

- 2) If "a" is not within specification, replace master cylinder (3) or pedal arm (2).

Clutch Pedal Free Travel "b"

- 1) Depress clutch pedal (1), stop the moment clutch resistance is felt, and measure how much pedal has moved (clutch pedal free travel) as represented by "b" in the figure.

Clutch pedal free travel "b"

: 2 – 8 mm (0.08 – 0.31 in.)

- 2) If "b" is not within specification, check pedal arm (2) and master cylinder (3) and replace defective part.



Clutch Release Margin "c"

- 1) Pull up parking brake fully and block wheels.
- 2) Start engine and keep engine at idle with neutral gear position.
- 3) Without clutch pedal (1) depressed, slightly push the shift lever to reverse position until transaxle emits gear contact noise. Do not shift the lever to reverse position.
- 4) With emitting gear contact noise, be slow to depress clutch pedal (1), and at gear contact noise died position (release point) stop depressing.
- 5) Measure distance between release point (4) and full stroke point (5) on clutch pedal (1) which is shown by "c" in the figure.

Clutch release margin

"c": 25 – 55 mm (0.98 – 2.17 in.)

- 6) If "c" is not within specification, it is possible that air is trapped in this system. If suspected so, bleed air referring to "Air Bleeding of Clutch System". Upon completion of above inspection, start engine and check clutch for proper operation.



I5RW0A530002-01

Clutch Fluid Level Inspection

S7RW0C5306002

- 1) Check clutch system for crack, damage and fluid leakage.
If any faulty is found, repair or replace.
- 2) Check fluid level referring to "Master Cylinder and Brake Fluid Level Inspection in Section 4A".

Air Bleeding of Clutch System

S7RW0C5306003

⚠ CAUTION


- **Brake fluid is extremely damaging to paint. If fluid should accidentally touch painted surface, immediately wipe fluid from paint and clean painted surface.**
- **When operating the pedal stroke for air bleeding of clutch system, after releasing the clutch pedal, be sure to wait 1 second or more before depressing it again. Otherwise, the oil seal of operating cylinder will be damaged, resulting in oil leakage.**

Bleeding operation is necessary to remove air whenever it entered hydraulic clutch system.

- 1) Fill master cylinder reservoir with brake fluid and keep at least one-half full of fluid during bleeding operation.


Clutch fluid specification

: Refer to brake reservoir cap



I7RW01530002-01

- 2) Remove bleeder plug cap. Attach a vinyl tube (1) to bleeder plug, and insert the other end into container (2).



I7RW01530001-01


- 3) Depress clutch pedal several times, and then while holding it depressed, loosen bleeder plug about one-third to one-half turn.
- 4) When fluid pressure in cylinder is almost depleted, retighten bleeder plug.
- 5) Repeat this operation until there are no more air bubbles in hydraulic line.

- 6) When bubbles stop, depress and hold clutch pedal, and tighten bleeder plug.

Tightening torque

Clutch bleeder plug: 5 N·m (0.5 kgf-m, 4.0 lb-ft)

- 7) Then attach bleeder plug cap.
- 8) After completing bleeding operation, apply fluid pressure to pipe line and check for leakage.
- 9) Replenish fluid into reservoir up to specified level.



I7RW01530002-01


- 10) Check clutch pedal for sponginess. If found spongy, repeat entire procedure of bleeding.

Clutch Pedal Position (CPP) Switch Removal and Installation

S7RW0C5306004

Removal

- 1) Disconnect connector of CPP switch (1) with ignition switch OFF.
- 2) Remove CPP switch (1) from pedal bracket.



I7RW01530003-01

Installation

- 1) Install CPP switch to pedal bracket.
- 2) Adjust switch position referring to "Clutch Pedal Position (CPP) Switch Inspection and Adjustment".
- 3) Connect connector to CPP switch securely.

Clutch Pedal Position (CPP) Switch Inspection and Adjustment

S7RW0C5306005


Inspection

Check for resistance between terminals under each condition below. If check result is not satisfactory, replace.

CPP switch resistance

When switch shaft is pushed (1): Continuity

When switch shaft is free (2): No continuity



Adjustment


With clutch pedal (1) depressed, adjust switch (2) position so that clearance between end of thread and clutch pedal arm is within specification and then tighten lock nut to specified torque.

Clearance between end of thread and clutch pedal arm

“a”: 1.5 – 2.0 mm (0.06 – 0.08 in.)

Tightening torque


CPP switch lock nut (a): 7.5 N·m (0.75 kgf-m, 5.5 lb-ft)



I7RW01530004-02

Clutch Fluid Pipe and Hose Components

S7RW0C5306006



I5RW0A530003-02

[A]: RH steering vehicle	3. Clutch reservoir hose
1. Clutch master cylinder	4. Brake master cylinder reservoir
2. Clutch fluid pipe	

Clutch Fluid Pipe Removal and Installation


S7RW0C5306007

Removal

⚠ CAUTION

Do not allow fluid to get on painted surface. It may cause painted surface damage.

- 1) Remove dust and dirt from each joint of pipe to be disconnected and clean around brake master cylinder reservoir cap.
- 2) Take out fluid with syringe or such from brake master cylinder reservoir.
- 3) Pull clamp (1) of clutch master cylinder (3) and pull clamp (5) of fluid pipe joint (4), and then disconnect clutch fluid pipe (2).
- 4) Pull clamp (6) of damper (7), and then disconnect damper (7) from clutch fluid pipe (2).



Installation

Reverse removal procedure for installation noting the following.

⚠ CAUTION


- Do not allow fluid to get on painted surface.
- Do not allow pipe to contact hard against vehicle body or other parts.

- Install each clamp securely.
- After installation, check clutch pedal free travel and bleed air from clutch system referring to "Clutch Pedal Inspection" and "Air Bleeding of Clutch System".
- Check fluid leakage.
- Add fluid to MAX level of reservoir.

Clutch Fluid Pipe Inspection

S7RW0C5306008

Check pipe (1) for damage, dirt and leak. Replace if check result is not satisfactory.



[A]: LH steering vehicle


[B]: RH steering vehicle

Clutch Master Cylinder Removal and Installation

S7RW0C5306009

Removal

- 1) Clean around brake master cylinder reservoir cap and take out fluid with syringe or such from brake master cylinder reservoir.
- 2) Disconnect clutch fluid pipe (4) from clutch master cylinder (1) referring to "Clutch Fluid Pipe Removal and Installation".
- 3) Disconnect clutch reservoir hose (2).
- 4) Remove push rod from clutch pedal, and then remove clutch master cylinder.




3. Brake booster

Installation

Reverse removal procedure for installation noting the following.

- Apply grease to push rod tip.

“A”: Grease 99000–25100 (SUZUKI Silicone Grease)



I5RW0A530007-01

- Tighten clutch master cylinder nut to specified torque.

Tightening torque

Clutch master cylinder nut: 13 N·m (1.3 kgf-m, 9.5 lb-ft)

Clutch Operating Cylinder Assembly Removal and Installation

S7RW0C5306010


⚠ CAUTION

- **Do not allow fluid to get on painted surfaces. It may cause painted surface damage.**
- **Do not disassemble clutch operating cylinder assembly.**

Removal

- 1) Clean around reservoir cap of brake master cylinder and take out fluid with syringe or such.
- 2) Dismount transaxle assembly referring to “Manual Transaxle Unit Dismounting and Remounting in Section 5B”.
- 3) Loosen clutch fluid pipe flare nut (1) of clutch operating cylinder assembly (2).
- 4) Remove clutch pipe joint sleeve (3) from transaxle and then remove clutch fluid pipe (4).

- 5) Remove clutch operating cylinder assembly from transaxle.



I5RW0A530008-01

Installation

- 1) Install clutch operating cylinder assembly (2) to transaxle. Tighten new mounting bolts to specified torque.


Tightening torque

Clutch operating cylinder assembly mounting bolt (a): 10 N·m (1.0 kgf-m, 7.5 lb-ft)

- 2) Connect clutch fluid pipe (4) to clutch operating cylinder assembly temporarily.
- 3) Install clutch pipe joint sleeve (3) to transaxle securely and then tighten clutch fluid pipe flare nut (1) to specified torque.

Tightening torque


Clutch fluid pipe flare nut (b): 16 N·m (1.6 kgf-m, 11.5 lb-ft)



I5RW0A530009-01

5C-8 Clutch:

- 4) Remount transaxle assembly referring to “Manual Transaxle Unit Dismounting and Remounting in Section 5B”.
- 5) Bleed air from system and check clutch pedal free travel. Refer to “Air Bleeding of Clutch System” and “Clutch Pedal Inspection”.



I5RW0B530005-03


Clutch Operating Cylinder Assembly Inspection

S7RW0C5306011

Check clutch fluid leakage, spring for damage and bearing for smooth rotation. If malfunction is found, replace clutch operating cylinder assembly.

Clutch Cover, Clutch Disc and Flywheel Components

S7RW0C5306012



I6RW0C530001-01

1. Clutch cover	4. Flywheel	⚙️(a) : 23 N·m (2.3 kgf·m, 17.0 lb·ft)
2. Clutch disc	5. Input shaft bearing	⚙️(b) : 70 N·m (7.0 kgf·m, 51.0 lb·ft)
3. Clutch cover bolt	6. Flywheel bolt	⚡ : Do not reuse.

Clutch Cover, Clutch Disc and Flywheel Removal and Installation


S7RW0C5306013

Removal

- 1) Dismount manual transaxle assembly referring to "Manual Transaxle Unit Dismounting and Remounting in Section 5B".
- 2) Hold flywheel with special tool and remove clutch cover bolts (1), clutch cover (2) and clutch disc.

Special tool

(A): 09924-17811




I4RS0A530014-01

- 3) Pull out input shaft bearing (1) from flywheel (2), use the following special tool if necessary.

Special tool

(A): 09921-26020

(B): 09930-30104




I2RH01530023-01

- 4) Remove flywheel (1) from crankshaft using special tool.

Special tool

(A): 09924-17810



I4RS0A530015-02

Installation

NOTE

Before assembling, make sure that flywheel surface and pressure plate surface have been cleaned and dried thoroughly.


- 1) Install flywheel (2) to crankshaft and tighten new bolts (1) to specification.

Special tool

(A): 09924-17810

Tightening torque

Flywheel bolt (a): 70 N·m (7.0 kgf-m, 51.0 lb-ft)




I2RH01530024-01

5C-10 Clutch:

- 2) Using special tool, install input shaft bearing to flywheel (1).

Special tool

(B): 09925-98210



I4RS0A530016-01

- 3) Aligning clutch disc to flywheel center using special tool, install clutch cover (1) and bolts (2). Then tighten bolts (2) to specification.

NOTE

- While tightening clutch cover bolts, compress clutch disc with special tool (clutch center guide) by hand so that disc is centered.
- Tighten cover bolts little by little evenly in diagonal order.


Special tool

(A): 09924-17811

(B): 09923-36320

Tightening torque

Clutch cover bolt (a): 23 N·m (2.3 kgf-m, 17.0 lb-ft)




I4RS0A530017-01

- 4) Slightly apply grease to input shaft (1), then join manual transaxle assembly with engine referring to "Manual Transaxle Unit Dismounting and Remounting in Section 5B".

"A": Grease 99000-25210 (SUZUKI Super Grease I)

NOTE

When inserting transaxle input shaft to clutch disc, turn crankshaft little by little to match the splines.



I5RW0A530013-01

Clutch Cover and Clutch Disc Inspection

S7RW0C5306014

Clutch Disc


Measure depth of rivet head depression, i.e. distance between rivet head and facing surface.

If depression is found to have reached service limit at any of rivet holes (2), replace clutch disc assembly (1).

Rivet head depth

Standard: 1.65 – 2.25 mm (0.06 – 0.09 in.)


Limit: 0.5 mm (0.02 in.)



I4RS0A530019-01

Clutch Cover

- 1) Check diaphragm spring (1) for abnormal wear or damage.
- 2) Inspect pressure plate (2) for wear or heat spots.
- 3) If abnormality is found, replace clutch cover.
Do not disassemble it into diaphragm spring and pressure plate.



I3RM0A530015-01

Specifications

Tightening Torque Specifications

S7RW0C5307001

Fastening part	Tightening torque			Note
	N·m	kgf·m	lb·ft	
Clutch bleeder plug	5	0.5	4.0	☞
CPP switch lock nut	7.5	0.75	5.5	☞
Clutch master cylinder nut	13	1.3	9.5	☞
Clutch operating cylinder assembly mounting bolt	10	1.0	7.5	☞
Clutch fluid pipe flare nut	16	1.6	11.5	☞
Flywheel bolt	70	7.0	51.0	☞
Clutch cover bolt	23	2.3	17.0	☞

NOTE

The specified tightening torque is also described in the following.
“Clutch Cover, Clutch Disc and Flywheel Components”

Reference:

For the tightening torque of fastener not specified in this section, refer to “Fasteners Information in Section 0A”.

Special Tools and Equipment







Recommended Service Material

S7RW0C5308001

Material	SUZUKI recommended product or Specification		Note
Grease	SUZUKI Silicone Grease	P/No.: 99000-25100	
	SUZUKI Super Grease I	P/No.: 99000-25210	

Special Tool

S7RW0C5308002

09921-26020 Bearing remover 		09923-36320 Clutch center guide (15 mm) 	
09924-17810 Flywheel holder (drive plate stopper)  / 		09924-17811 Flywheel holder  / 	
09925-98210 Input shaft bearing installer 		09930-30104 Sliding shaft 	

Section 6

Steering

CONTENTS

Precautions	6-1	Precautions in Diagnosing Troubles	6C-1
Precautions.....	6-1	General Description	6C-2
Precautions on Steering.....	6-1	P/S System Description	6C-2
Steering General Diagnosis.....	6A-1	EPS Diagnosis General Description	6C-3
Precautions.....	6A-1	On-Board Diagnostic System Description	6C-3
Precautions for Steering Diagnosis.....	6A-1	Schematic and Routing Diagram	6C-4
Diagnostic Information and Procedures	6A-1	EPS System Wiring Circuit Diagram	6C-4
Steering Symptom Diagnosis.....	6A-1	Diagnostic Information and Procedures	6C-5
Steering System Inspection	6A-2	EPS System Check	6C-5
Steering System Operation Check.....	6A-2	“EPS” Warning Light Check	6C-8
Steering Wheel and Column.....	6B-1	DTC Check.....	6C-8
Precautions.....	6B-1	DTC Clearance	6C-9
Service Precautions of Steering Wheel and		DTC Table	6C-9
Column.....	6B-1	Visual Inspection	6C-11
General Description	6B-1	Scan Tool Data	6C-12
Steering Wheel and Column Construction	6B-1	P/S System Symptom Diagnosis	6C-13
Diagnostic Information and Procedures	6B-2	DLC and Its Communication Check (No	
Checking Steering Column for Accident		communication to P/S Control Module).....	6C-14
Damage	6B-2	“EPS” Warning Light Does Not Come ON with	
Repair Instructions	6B-3	Ignition Switch Turned ON before Engine	
Steering Wheel and Column Components.....	6B-3	Starts.....	6C-16
Steering Wheel Removal and Installation	6B-4	“EPS” Warning Light Remains ON Steady	
Contact Coil Cable Assembly Removal and		after Engine Starts	6C-18
Installation	6B-5	DTC C1111 / C1113 / C1115: Torque Sensor	
Centering Contact Coil Cable Assembly	6B-6	Circuit Failure	6C-19
Contact Coil Cable Assembly Inspection	6B-6	DTC C1116: Steering Torque Sensor Power	
Steering Column Removal and Installation	6B-6	Supply Circuit.....	6C-21
Steering Column Inspection	6B-8	DTC C1121 / C1123 / C1124: Vehicle Speed	
Ignition Switch Cylinder Assembly Removal		Signal Circuit Failure	6C-23
and Installation (Non- Keyless Start Model).....	6B-8	DTC C1122: Engine Speed Signal.....	6C-25
Steering Lock Assembly (Ignition Switch)		DTC C1141 / C1142 / C1143 / C1145: Motor	
Removal and Installation.....	6B-9	Circuit Failure	6C-27
Steering Lower Shaft Removal and		DTC C1153: P/S Control Module Power	
Installation	6B-10	Supply Circuit.....	6C-28
Specifications	6B-11	DTC C1155: P/S Control Module Internal	
Tightening Torque Specifications.....	6B-11	Failure	6C-29
Special Tools and Equipment	6B-11	P/S Control Module Power Supply and	
Special Tool	6B-11	Ground Circuit Check.....	6C-30
Power Assisted Steering System.....	6C-1	Inspection of P/S Control Module and Its	
Precautions.....	6C-1	Circuits	6C-31
P/S System Note.....	6C-1	Steering Wheel Play Check	6C-35
		Steering Force Check	6C-35
		Repair Instructions	6C-36
		Steering Gear Case Assembly Components	6C-36
		Tie-Rod End Boot On-Vehicle Inspection	6C-37

6-ii Table of Contents

Tie-Rod End Removal and Installation.....	6C-37
Tie-Rod End Initial Position Setting.....	6C-38
Tie-Rod End Inspection.....	6C-38
Steering Shaft Joint On-Vehicle Inspection.....	6C-38
Steering Gear Case Assembly Removal and Installation	6C-39
Steering Rack Boot Inspection.....	6C-40
Tie-Rod / Rack Boot Removal and Installation ..	6C-40
Steering Rack Plunger Removal and Installation	6C-41

Steering Rack Plunger Inspection	6C-42
P/S Control Module Removal and Installation...	6C-42
Torque Sensor and Its Circuit Inspection	6C-43
P/S Motor and Its Circuit Inspection.....	6C-44
Specifications	6C-45
Tightening Torque Specifications.....	6C-45
Special Tools and Equipment	6C-45
Recommended Service Material	6C-45
Special Tool	6C-45

Precautions

Precautions

Precautions on Steering

S7RW0C6000001

Air Bag Warning

Refer to "Air Bag Warning in Section 00".

Precautions for Steering Diagnosis

Refer to "Precautions for Steering Diagnosis in Section 6A".

Service Precautions of Steering Wheel and Column

Refer to "Service Precautions of Steering Wheel and Column in Section 6B".

P/S System Note

Refer to "P/S System Note in Section 6C".

Steering General Diagnosis

Precautions

Precautions for Steering Diagnosis

S7RW0C6100001

Since the problems in steering involve several systems, they must all be considered when diagnosing a complaint. To avoid using the wrong symptom, always road test the vehicle first. Proceed with the following preliminary inspection and correct any defects which are found.

- 1) Inspect tires for proper pressure and uneven wear.
- 2) Raise vehicle on a hoist and inspect steering system for loose or damaged parts.
- 3) Spin front wheels. Inspect for out-of-round tires, out-of-balance tires, bent rims, loosen and/or rough wheel bearings.

Diagnostic Information and Procedures

Steering Symptom Diagnosis

S7RW0C6104001

Condition	Possible cause	Correction / Reference Item
Hard steering	Tire not adequately inflated	<i>Inflate tires to proper pressure.</i>
	Malfunction of power steering system	<i>Check and correct. Refer to "P/S System Symptom Diagnosis in Section 6C".</i>
	Bind in tie-rod end ball studs or lower ball joints	<i>Replace tie-rod end or front suspension control arm.</i>
	Disturbed front wheel alignment	<i>Check and adjust front wheel alignment.</i>
	Bind in steering column	<i>Repair or replace steering column assembly.</i>
	Rack and pinion adjustment	<i>Check and adjustment rack and pinion torque.</i>
Too much play in steering	Wheel bearings worn	<i>Replace wheel bearing.</i>
	Loose steering gear case bolts	<i>Tighten gear case bolts.</i>
	Faulty steering gear case assembly	<i>Replace steering gear case assembly.</i>
	Worn steering shaft joints	<i>Replace steering lower shaft assembly.</i>
	Worn tie-rod ends or tie-rod inside ball joints	<i>Replace tie-rod end or tie-rod.</i>
	Worn lower ball joints	<i>Replace front suspension control arm.</i>
Poor return ability	Rack and pinion adjustment	<i>Check and adjustment rack and pinion torque.</i>
	Bind in tie-rod end ball studs	<i>Replace tie-rod end.</i>
	Bind in ball joints	<i>Replace front suspension control arm.</i>
	Bind in steering column	<i>Replace steering column assembly.</i>
	Disturbed front end alignment	<i>Check and adjust front end alignment.</i>
	Faulty steering gear case assembly	<i>Replace steering gear case assembly.</i>
	Tires not adequately inflated	<i>Adjust tire pressure.</i>
	Rack and pinion adjustment	<i>Check and adjustment rack and pinion torque.</i>
Rack and pinion noise (Rattle or chuckle)	Loose steering gear case bolts	<i>Tighten steering gear case bolts.</i>
	Rack and pinion adjustment	<i>Check and adjustment rack and pinion torque.</i>
	Faulty steering gear case assembly	<i>Replace steering gear case assembly.</i>
	Broken or otherwise damaged wheel bearing(s)	<i>Replace wheel bearing(s).</i>
Wander or poor steering stability	Mismatched or uneven tires	<i>Replace or inflate tires to proper pressure.</i>
	Loosen ball joints and tie-rod ends	<i>Replace suspension control arm or tie-rod end.</i>
	Faulty struts or mountings	<i>Replace strut or repair mounting.</i>
	Loose stabilizer bar	<i>Tighten or replace stabilizer bar or bush.</i>
	Broken or sagging coil springs	<i>Replace coil spring.</i>
	Rack and pinion adjustment	<i>Check and adjustment rack and pinion torque.</i>
	Disturbed front wheel alignment	<i>Check and adjust front wheel alignment.</i>
	Faulty steering gear case assembly	<i>Replace steering gear case assembly.</i>

Condition	Possible cause	Correction / Reference Item
Erratic steering when braking	Worn wheel bearings	<i>Replace wheel bearing.</i>
	Broken or sagging coil springs	<i>Replace coil spring.</i>
	Wheel tires are inflated unequally	<i>Inflate tires to proper pressure.</i>
	Disturbed front wheel alignment	<i>Check and adjust front wheel alignment.</i>
	Brakes not working in unison	<i>Check and repair brake system.</i>
	Leaking wheel cylinder or caliper	<i>Repair or replace wheel cylinder or caliper.</i>
	Warped discs	<i>Replace brake disc.</i>
	Badly worn brake linings	<i>Replace brake shoe lining.</i>
	Drum is out of round in some brakes	<i>Replace brake drum.</i>
	Defective wheel cylinders	<i>Replace or repair wheel cylinder.</i>

Steering System Inspection

S7RW0C6104002

Check steering system referring to the following items.

If found a defective part, repair or replace it.

Inspection Item		Inspection description	Referring section
Steering wheel		Play, rattle	"Steering Wheel Play Check in Section 6C"
		Operation, travel	"Steering System Operation Check"
Steering linkage	Tie-rod end	Looseness, damage	"Tie-Rod End Inspection in Section 6C"
	Steering shaft joint	Rattle, damage	"Steering Shaft Joint On-Vehicle Inspection in Section 6C"
	Any other joint	Looseness, damage, rattle	—
Mounting and attaching bolts and nuts		Tightness, damage	—
Wheel alignment		Dimension	"Front Wheel Alignment Inspection and Adjustment in Section 2B"
Boots	Tie-rod end boot	Damage, detachment, tear	"Tie-Rod End Boot On-Vehicle Inspection in Section 6C"
	Steering rack boot	Damage, detachment, tear	"Steering Rack Boot Inspection in Section 6C"
	Any other boot	Damage, detachment, tear	—
Steering gear case		Leak, damage, etc	—

Steering System Operation Check

S7RW0C6104003

- Check that steering wheel can be turned fully to the right and left.
- Check that steering wheel can be turned fully to the right and left more lightly when engine is running at idle speed than when it is stopped.

If found faulty, repair or replace it.

Steering Wheel and Column

Precautions

Service Precautions of Steering Wheel and Column

S7RW0C6200001

For service precautions, refer to "Precautions on Service and Diagnosis of Air Bag System in Section 8B".

Service and Diagnosis

For diagnosis and servicing, refer to "Precautions on Service and Diagnosis of Air Bag System in Section 8B".

Disabling Air Bag System

For disabling air bag system, refer to "Disabling Air Bag System in Section 8B".

Enabling Air Bag System

For enabling air bag system, refer to "Enabling Air Bag System in Section 8B".

Handling and Storage

For handling and storage, refer to "Precautions on Handling and Storage of Air Bag System Components in Section 8B".

Disposal

For disposal, refer to "Precautions on Disposal of Air Bag and Seat Belt Pretensioner in Section 8B".

General Description

Steering Wheel and Column Construction

S7RW0C6201001

This double tube type steering column has the following three important features in addition to the steering function:

- The column is energy absorbing, designed to compress in a front-end collision.
- The ignition switch and lock are mounted conveniently on this column.
- With the column mounted lock, the ignition and steering operations can be locked to inhibit theft of the vehicle.

To insure the energy absorbing action, it is important that only the specified screws, bolts and nuts be used as designated, and that they are tightened to the specified torque. When the column assembly is removed from the vehicle, special care must be taken in handling it. Use of a steering wheel puller other than the recommended puller in this manual or a sharp blow on the end of the steering shaft, leaning on the assembly, or dropping the assembly could shear the plastic shear pins which maintain column length and position.

The driver air bag (inflator) module is one of the supplemental restraint (air bag) system components and is mounted to the center of the steering wheel. During certain frontal crashes, the air bag system supplements the restraint of the driver's and passenger's seat belts by deploying the air bags. The air bag (inflator) module should be handled with care to prevent accidental deployment. When servicing, be sure to observe "Precautions on Service and Diagnosis of Air Bag System in Section 8B".

Diagnostic Information and Procedures


Checking Steering Column for Accident Damage

S7RW0C6204001

NOTE

Vehicles involved in accidents resulting in body damage, where steering column has been impacted or air bag deployed may have a damaged or misaligned steering column.

- Check that two capsules (1) are attached to steering column bracket securely. If found loose, replace steering column assembly.



- Take measurement "a", "b" and "c" as shown. If it is shorter than specified length, replace steering column assembly with new one.

Type A

Steering column length

"a": $397 \pm 2 \text{ mm}$ ($15.6 \pm 0.08 \text{ in.}$)

"b": $65.5 \pm 0.5 \text{ mm}$ ($2.58 \pm 0.02 \text{ in.}$)

"c": $347.7 \pm 1 \text{ mm}$ ($13.7 \pm 0.04 \text{ in.}$)

Type B


Steering column length

"a": $363.6 \pm 1.5 \text{ mm}$ ($14.3 \pm 0.06 \text{ in.}$)


"b": $65 \pm 1 \text{ mm}$ ($2.56 \pm 0.04 \text{ in.}$)

"c": $334 \pm 1.5 \text{ mm}$ ($13.1 \pm 0.06 \text{ in.}$)

- Check that there is no axial looseness "d" and no axially-vertical looseness "e" for steering column shaft. If found defective, replace steering column assembly with new one.



- Check steering shaft joints and shaft for any damages such as crack, breakage, malfunction or excessive play. If anything is found faulty, replace as lower shaft assembly or steering column assembly.




I4RS0A620003-01

- Check steering shaft for smooth rotation. If found defective, replace as steering column assembly.
- Check steering shaft and steering column for bend, cracks or deformation. If found defective, replace.

Repair Instructions

Steering Wheel and Column Components

S7RW0C6206001



I6RW0C620001-01

1. Steering wheel	9. Steering column assembly mounting nut No.1
2. Steering shaft nut	10. Steering column assembly mounting nut No.2 : After tightening column mounting nut No.2, tighten column mounting nut No.1.
3. Contact coil cable assembly	11. Steering lower shaft assembly lower joint bolt
4. Steering column upper cover	12. Steering lower shaft assembly upper joint bolt : After tightening all column mounting nuts and lower shaft lower joint bolt, tighten lower shaft upper joint bolt.
5. Steering column lower cover	13. Steering joint cover
6. Steering column assembly	(a) : 33 N-m (3.3 kgf-m, 24.0 lb-ft)
7. Steering lock assembly	(b) : 25 N-m (2.5 kgf-m, 18.0 lb-ft)
8. Steering lower shaft assembly	(c) : 14 N-m (1.4 kgf-m, 10.5 lb-ft)

Steering Wheel Removal and Installation

S7RW0C6206002

⚠ CAUTION


Do not turn the contact coil more than allowable number of turns (about two and a half turns from the center position clockwise or counterclockwise respectively) with steering wheel removed, or coil will break.

Removal

⚠ CAUTION


Do not hammer the end of the shaft. Hammering it will loosen the plastic shear pins which maintain the column length and impair the collapsible design of the column.

- 1) Disconnect negative (–) cable at battery.
- 2) Disable air bag system referring to “Disabling Air Bag System in Section 8B”.
- 3) Remove driver air bag (inflator) module from steering wheel. Refer to “Driver Air Bag (Inflator) Module Removal and Installation in Section 8B”.
- 4) Disconnect horn connector and audio control switch connector, if equipped.
- 5) Remove steering shaft nut and then make alignment marks (1) on steering wheel and shaft for a guide during reinstallation.



I4RS0A620005-01

- 6) Remove steering wheel using special tool.

Special tool**(A): 09944–36011**

I4RS0A620006-01

Installation


⚠ CAUTION

Following 2 Steps (Step 1) and 2)) are prerequisite for installation of steering wheel. If steering wheel has been installed without these 2 Steps, contact coil will break when steering wheel is turned.

- 1) Check that vehicle's front tires are at straight-ahead position and contact coil is centered. If contact coil is turned after removing steering wheel, center contact coil referring to “Centering Contact Coil Cable Assembly”.
- 2) Install steering wheel to steering shaft with 2 grooves (1) on contact coil fitted in 2 lugs (2) in the back of steering wheel and also aligning marks (3) on steering wheel and steering shaft.
- 3) Tighten steering shaft nut (4) to specified torque.

Tightening torque

Steering shaft nut (a): 33 N·m (3.3 kgf-m, 24.0 lb-ft)



I4RS0A620007-01

6B-5 Steering Wheel and Column:

- 4) Connect horn connector and audio control switch connector, if necessary.
- 5) Install driver air bag (inflator) module to steering wheel. Refer to "Driver Air Bag (Inflator) Module Removal and Installation in Section 8B".
- 6) Connect negative (–) cable to battery.
- 7) Enable air bag system referring to "Enabling Air Bag System in Section 8B".

Contact Coil Cable Assembly Removal and Installation


S7RW0C6206003

⚠ CAUTION

Do not turn contact coil more than allowable number of turns (about two and a half turns from the center position clockwise or counterclockwise respectively), or coil will break.


Removal

- 1) Disconnect negative (–) cable at battery.
- 2) Disable air bag system referring to "Disabling Air Bag System in Section 8B".
- 3) Remove steering wheel from steering column referring to "Steering Wheel Removal and Installation".
- 4) Remove steering column hole cover.
- 5) Remove steering column lower cover (2) and upper cover (1).



I6RW0B620005-01

- 6) Remove contact coil cable assembly (1) from steering column.




I6RW0B620009-02

Installation

- 1) Check to make sure that vehicle's front tires are set at straight-ahead position and then ignition switch is at LOCK position.
- 2) Install contact coil cable assembly to steering column securely.

NOTE

New contact coil cable assembly is supplied with contact coil set and held at its center position with a lock pin (1). Remove this lock pin after installing contact coil cable assembly to steering column.




I4RS0A620010-01

- 3) Install steering column upper cover (1) and lower cover (2).

⚠ CAUTION

When installing covers, be careful so that each lead wire is not caught between covers. Otherwise, each lead wire is damaged.



I6RW0B620003-01

3. Standard screw

4. Tapping screw

- 4) Install steering wheel to steering column. Refer to "Steering Wheel Removal and Installation".
- 5) Connect negative (–) cable to battery.
- 6) Enable air bag system referring to "Enabling Air Bag System in Section 8B".


Centering Contact Coil Cable Assembly

S7RW0C6206004

- 1) Check that vehicle's wheels (front tires) are set at straight-ahead position.
- 2) Check that ignition switch is at LOCK position.
- 3) Turn contact coil counterclockwise slowly with a light force till contact coil will not turn any further.


NOTE

Contact coil can turn about 5 turns at the maximum, that is, if it is at the center position, can turn about two and a half turns both clockwise and counterclockwise.



I4RS0A620012-01

- 4) From the position where contact coil became unable to turn any further (it stopped), turn it back clockwise about two and a half rotations and align center mark with alignment mark (1).



I4RS0A620013-01

Contact Coil Cable Assembly Inspection

S7RW0C6206005

Refer to "Contact Coil Cable and Its Circuit Check in Section 8B".

Steering Column Removal and Installation

S7RW0C6206006

⚠ CAUTION

Once the steering column is removed from the vehicle, the column is extremely susceptible to damage.

- Dropping the column assembly on its end could collapse the steering shaft or loosen the plastic shear pins which maintain column length.
- Leaning on the column assembly could cause it to bend or deform.

Any of the damage could impair the column's collapsible design.

Steering column mounting nuts should not be loosened with steering shaft joint upper side bolt tightened as this could cause damage to shaft joint bearing.

NOTE


When servicing steering column or any column-mounted component, remove steering wheel. But when removing steering column simply to gain access to instrument panel components, leave steering wheel installed on steering column.

Removal

⚠ WARNING

Never rest a steering column assembly on the steering wheel with the air bag (inflator) module face down and column vertical. Otherwise, personal injury may result.

- 1) Disconnect negative (–) cable at battery.
- 2) Disable air bag system. Refer to “Disabling Air Bag System in Section 8B”.
- 3) Remove steering wheel and contact coil cable assembly referring to “Steering Wheel Removal and Installation” and “Contact Coil Cable Assembly Removal and Installation”.
- 4) (Immobilizer model)
Remove immobilizer control module from steering column, referring to “ICM Removal and Installation in Section 10C”.
- 5) Detach lighting switch and wiper switch from steering column.
- 6) Remove lower shaft upper joint bolt (1).




I5RW0A620005-01

- 7) Remove steering column mounting nuts (1), and then remove steering column from vehicle.

NOTE

Do not move tilt lever until mounting bolts and nuts are tightened to specified torque.



I4RS0A620017-01

Installation

⚠ CAUTION

After tightening steering column mounting nuts, shaft joint bolts should be tightened. Wrong tightening order could cause a damage to shaft joint.

- 1) Be sure that front wheels are in straight.
- 2) Install steering column assembly to lower and upper brackets. Tighten steering column mounting nuts No.2 (1) first and then steering column mounting nuts No.1 (2) to specifications as given below.



Tightening torque

Steering column mounting nut No.1 (a): 14 N·m (1.4 kgf-m, 10.5 lb-ft)

Steering column mounting nut No.2 (b): 14 N·m (1.4 kgf-m, 10.5 lb-ft)

NOTE

- When installing, make sure that clearance “a” between bolt (3) and bracket (4) should be 0 (zero).
- After installing tilt steering column, make sure that steering column moves upwards and downwards smoothly and stops when tilt lever is fixed.



I5RW0A620006-02


- 3) Align flat part "a" of steering lower shaft (1) with bolt hole "b" of shaft joint (2) of column as shown. Then insert lower shaft into shaft joint of steering column.
- 4) Tighten lower shaft upper joint bolt (3) to specified torque.

⚠ CAUTION

After tightening column nuts, tighten steering shaft upper joint bolt. Otherwise, shaft joint bearing is damaged.

Tightening torque

Steering lower shaft assembly upper joint bolt (a): 25 N·m (2.5 kgf-m, 18.5 lb-ft)



I5RW0A620007-01

- 5) Install lighting switch and wiper switch to steering column.
- 6) (Immobilizer model)
Install immobilizer control module from steering column, referring to "ICM Removal and Installation in Section 10C".
- 7) Install contact coil cable assembly and steering wheel referring to "Contact Coil Cable Assembly Removal and Installation" and "Steering Wheel Removal and Installation".
- 8) Connect negative (–) cable to battery.
- 9) Enable air bag system referring to "Enabling Air Bag System in Section 8B".

Steering Column Inspection

S7RW0C6206007


Check steering column for damage and operation referring to "Checking Steering Column for Accident Damage".

Ignition Switch Cylinder Assembly Removal and Installation (Non- Keyless Start Model)

S7RW0C6206008

Removal

- 1) Disconnect negative (–) cable at battery.
- 2) Disable air bag system referring to "Disabling Air Bag System in Section 8B".
- 3) Remove steering column upper and lower covers.
- 4) (Immobilizer model)
Remove immobilizer control module referring to "ICM Removal and Installation in Section 10C".
- 5) Remove ignition switch cylinder assembly as follows.
 - a) Turn ignition key to "ACC" position.
 - b) Insert 2 mm (0.078 in.) rod (2) through hole (3) and push ignition switch cylinder lock.
 - c) Detach ignition switch cylinder assembly (1) from steering lock assembly (4).



I5JB0A620025-01

Installation

- 1) Install ignition switch cylinder assembly as follows.
 - a) Turn ignition key to "ACC" position.
 - b) In this state, push ignition switch cylinder assembly into steering lock assembly till it clicks.
- 2) (Immobilizer model)
Install immobilizer control module referring to "ICM Removal and Installation in Section 10C".
- 3) Install upper and lower cover and screws.
- 4) Connect negative (–) cable to battery.
- 5) Enabling air bag system referring to "Enabling Air Bag System in Section 8B".
- 6) (Immobilizer model)
If ignition switch cylinder assembly (that is ignition key) has replaced, register ignition key transponder code to ECM referring to "Registration of the Ignition Key in Section 10C".

Steering Lock Assembly (Ignition Switch) Removal and Installation


S7RW0C6206009

Removal

- 1) Remove steering column. Refer to "Steering Column Removal and Installation".
- 2) Using center punch (1), loosen and remove steering lock mounting bolts (2).

NOTE

Use care not to damage aluminum part of steering lock body with center punch.




I4RS0B620005-02

- 3) Turn ignition key to "ACC" or "ON" position and remove steering lock assembly from steering column.


Installation

- 1) Position oblong hole (1) of steering shaft (2) in the center of hole (3) in column (4).
- 2) Turn ignition key to "ACC" or "ON" position and install steering lock assembly (5) onto column (4).
- 3) Now turn ignition key to "LOCK" position and pull it out.
- 4) Align hub on lock with oblong hole (1) of steering shaft (2) and rotate shaft to assure that steering shaft is locked.



I4RS0B620006-02

- 5) Tighten new bolts (1) until head of each bolt is broken off.
- 6) Turn ignition key to "ACC" or "ON" position and check to be sure that steering shaft (2) rotates smoothly. Also check for lock operation.



I4RS0B620007-02

- 7) Install steering column. Refer to "Steering Column Removal and Installation".
- 8) (Keyless start model)
If steering lock assembly has replaced, after completing installation, register steering lock unit ID code to keyless start control module as following.
 - Immobilizer model:
Register ignition key transponder code in ECM referring to "Registration of the Ignition Key in Section 10C".
 - Non-immobilizer model:
Register steering lock unit ID code in keyless start control module referring to "Keyless Start Registration in Section 10E".

Steering Lower Shaft Removal and Installation

S7RW0C6206010


⚠ CAUTION

Never turn steering wheel while steering lower shaft is removed.

Should it have been turned and contact coil have got out of its centered position, it needs to be centered again. Also, turning steering wheel more than about two and a half turns will break contact coil.

Removal

- 1) Turn steering wheel so that vehicle's front tires are at straight-ahead position.
- 2) Turn ignition switch to LOCK position and remove key.
- 3) Remove steering joint cover.
- 4) Make alignment marks (4) on lower shaft (1) and pinion shaft (3) for a guide during reinstallation.
- 5) Remove lower shaft upper and lower joint bolts (2).
- 6) Remove steering lower shaft (1).



I5RW0A620008-01

Installation

- 1) Be sure that front wheels are in straight forward state.
- 2) Align flat part "a" of steering lower shaft (1) with bolt hole "b" of shaft joint (2) of column as shown. Then insert lower shaft into shaft joint of steering column.
- 3) Insert lower shaft (1) into pinion shaft (3) with matching marks (4).
- 4) Tighten lower joint bolt (6) to specified torque first and then upper joint bolt (5) to specified torque.


Tightening torque

Steering lower shaft assembly upper joint bolt

(a): 25 N·m (2.5 kgf-m, 18.5 lb-ft)

Steering lower shaft assembly lower joint bolt

(b): 25 N·m (2.5 kgf-m, 18.5 lb-ft)



I5RW0A620009-02

Specifications

Tightening Torque Specifications

S7RW0C6207001

Fastening part	Tightening torque			Note
	N·m	kgf-m	lb-ft	
Steering shaft nut	33	3.3	24.0	👉
Steering column mounting nut No.1	14	1.4	10.5	👉
Steering column mounting nut No.2	14	1.4	10.5	👉
Steering lower shaft assembly upper joint bolt	25	2.5	18.5	👉 / 👉
Steering lower shaft assembly lower joint bolt	25	2.5	18.5	👉

NOTE

The specified tightening torque is also described in the following.
 “Steering Wheel and Column Components”


Reference:

For the tightening torque of fastener not specified in this section, refer to “Fasteners Information in Section 0A”.

Special Tools and Equipment

Special Tool

S7RW0C6208001

09944-36011 Steering wheel remover 	
---	--

Power Assisted Steering System

Precautions

P/S System Note

S7RW0C6300001

NOTE

All steering gear fasteners are important attaching parts in that they could affect the performance of vital parts and systems, and/or could result in major repair expense. They must be replaced with one of the same part number or with an equivalent part if replacement becomes necessary. Do not use a replacement part of lesser quality or substitute design. Torque values must be used as specified during reassembly to assure proper retention of these parts.

Precautions in Diagnosing Troubles

S7RW0C6300002

- Take a note of DTC indicated on the SUZUKI scan tool.
- Before inspection, be sure to read "Precautions for Electrical Circuit Service in Section 00" and understand what is written there.
- DTC C1122 (engine speed signal failure) is indicated when ignition switch is at ON position and engine is not running, but it means there is nothing abnormal if indication changes to a normal one when engine is started.
- As DTC is stored in memory of the P/S control module, be sure to clear memory after repair by performing the procedure described in "DTC Clearance".

General Description


P/S System Description

S7RW0C6301001

This electronic power steering (EPS) system consists of a power steering (P/S) control module (3), a torque sensor (4), a P/S motor (5). In this system, the P/S control module determines the level and direction of the assist force for the steering wheel (1) according to the signal from the torque sensor and the vehicle speed signal from BCM (9). The P/S control module runs the motor so as to assist the operation of the steering wheel.

The P/S control module diagnoses troubles which may occur in the area including the following components when the ignition switch is ON and the engine is running. When the P/S control module detects any malfunction, it stops the motor operation.

- Torque sensor
- Vehicle speed signal circuit
- Engine speed signal circuit
- P/S Motor
- P/S control module.



2. Steering column	7. Battery
6. Steering gear case assembly	8. ECM

I7RW01632001-01

EPS Diagnosis General Description

S7RW0C6301002


The P/S system in this vehicle is controlled by the P/S control module. The P/S control module has an on-board diagnostic system which detects a malfunction in this system. When diagnosing troubles, be sure to have full understanding of the outline of “On-Board Diagnostic System Description” and each item in “Precautions in Diagnosing Troubles”, and then execute diagnosis according to “EPS System Check”.

On-Board Diagnostic System Description

S7RW0C6301003

The P/S control module performs the on-board diagnosis (self-diagnosis) on the system and operates the “EPS” warning light (1) as follows.

- The “EPS” warning light lights when the ignition switch is turned to ON position (but the engine at stop) regardless of the condition of the P/S control system. This is only to check if the “EPS” warning light is operated properly.
- If the areas monitored by the P/S control module is free from any trouble after the engine start (while engine is running), the “EPS” warning light turns OFF.
- When the P/S control module detects a trouble which has occurred in the monitored areas the “EPS” warning light comes ON while the engine is running to warn the driver of such occurrence of the trouble and at the same time it stores the exact trouble area in memory inside of the P/S control module.



I7RW01632002-01

Driving Cycle

A “Driving Cycle” consists of engine startup and engine shutoff.


3 Driving Cycles Detection Logic

The malfunction detected in the first and second driving cycle is stored in P/S control module memory (in the form of pending DTC) but the “EPS” warning light does not light at these time. It lights up at the third detection of same malfunction also in the next driving cycle.

Schematic and Routing Diagram

EPS System Wiring Circuit Diagram

S7RW0C6302001



I6RW0C630001-02

[A]: P/S control module connector No.1 "E11" (viewed from harness side)	5. Front (left/right) wheel speed sensor	15. BCM
[B]: P/S control module connector No.2 "E13" (viewed from harness side)	6. ABS control module	16. Individual circuit fuse box No.1
[C]: P/S control module connector No.3 "E12" (viewed from harness side)	7. Combination meter	17. "IGN" fuse
[D]: Combination meter connector "G241" (viewed from harness side)	8. "EPS" warning light	18. "P/S" fuse
[E]: Torque sensor connector "E31" (viewed from harness side)	9. Data link connector (DLC)	19. "IG1 SIG" fuse
[F]: Motor connector "E61" (viewed from harness side)	10. ECM	20. "MTR" fuse
1. Main fuse box	11. P/S control module	21. To ABS control module
2. Ignition switch	12. P/S motor	22. To HVAC control module
3. Junction block assembly	13. Shield	23. To SDM
4. Main fuse	14. Torque sensor (built into steering gear case)	

Terminal Arrangement of P/S Control Module Coupler (Viewed from Harness Side)

Terminal	Circuit	Terminal	Circuit
E11-1	Ignition switch signal for P/S control module	E11-13	—
E11-2	—	E11-14	P/S active signal (idle up signal)
E11-3	—	E11-15	—
E11-4	Vehicle speed signal	E11-16	—
E11-5	“EPS” warning Light	E11-17	—
E11-6	—	E11-18	Torque sensor signal (Main)
E11-7	—	E11-19	Ground for shield wire
E11-8	9 V power supply for torque sensor	E11-20	Reference sensor power supply for torque sensor
E11-9	Ground for torque sensors	E12-1	Motor output 1
E11-10	Torque sensor signal (Sub)	E12-2	Motor output 2
E11-11	Serial communication circuit for data link connector	E13-1	Main power supply for internal memory and EPS motor
E11-12	Engine speed signal	E13-2	Ground for P/S control module

Diagnostic Information and Procedures**EPS System Check**

S7RW0C6304001

⚠ WARNING

Carry out test drive in light traffic area to prevent an accident.

Refer to the following items for the details of each step.

Step	Action	Yes	No
1	🔧 Customer complaint analysis 1) Perform customer complaint analysis referring to “Customer Complaint Analysis”. <i>Was customer complaint analysis performed?</i>	Go to Step 2.	Perform customer complaint analysis.
2	🔧 DTC check, record and clearance 1) Check for DTC (including pending DTC) referring to “DTC Check, Record and Clearance”. <i>Is there any DTC(s)?</i>	Print DTC or write them down and clear them by referring to “DTC Clearance”, and go to Step 3.	Go to Step 4.
3	🔧 Visual inspection 1) Perform visual inspection referring to “Visual Inspection”. <i>Is there any faulty condition?</i>	Repair or replace malfunction part, and go to Step 11.	Go to Step 5.
4	🔧 Visual inspection 1) Perform visual inspection referring to “Visual Inspection”. <i>Is there any faulty condition?</i>	Repair or replace malfunction part, and go to Step 11.	Go to Step 8.
5	🔧 Trouble symptom confirmation 1) Confirm trouble symptom referring to “Trouble Symptom Confirmation”. <i>Is trouble symptom identified?</i>	Go to Step 6.	Go to Step 7.
6	🔧 Rechecking and record of DTC 1) Recheck for DTC referring to “DTC Check”. <i>Is there any DTC(s)?</i>	Go to Step 9.	Go to Step 8.

6C-6 Power Assisted Steering System:

Step	Action	Yes	No
7	☞ Rechecking and record of DTC 1) Recheck for DTC referring to "DTC Check". <i>Is there any DTC(s)?</i>	Go to Step 9.	Go to Step 10.
8	☞ Steering symptom diagnosis and P/S system symptom diagnosis 1) Check and repair according to "Steering Symptom Diagnosis in Section 6A" and "P/S System Symptom Diagnosis". <i>Are check and repair complete?</i>	Go to Step 11.	Check and repair malfunction part(s), and go to Step 11.
9	☞ Troubleshooting for DTC 1) Check and repair according to applicable DTC diag. flow. <i>Are check and repair complete?</i>	Go to Step 11.	Check and repair malfunction part(s), and go to Step 11.
10	☞ Intermittent problems check 1) Check for intermittent problems referring to "Intermittent Problems Check". <i>Is there any faulty condition?</i>	Repair or replace malfunction part(s), and go to Step 11.	Go to Step 11.
11	☞ Final confirmation test 1) Clear DTC if any. 2) Perform final confirmation test referring to "Final Confirmation Test". <i>Is there any problem symptom, DTC or abnormal condition?</i>	Go to Step 6.	End.

NOTE

- As execution of "DTC Clearance" will clear all DTCs, be sure to record all DTCs before service.
- DTC C1122 is indicated when ignition switch is at ON position and engine is not running, it means that nothing is abnormal.
- Current DTC and history DTC can be identified by condition of the "EPS" warning light.
"EPS" warning light operates as follows.

	Current DTC is set. (Abnormality exists at present.)	Only history DTC is set. (Faulty condition occurred once in the past, but normal condition is detected at present.)	Current and history DTC exist.
"EPS" warning light after engine started	Remains ON.	Turns OFF.	Remains ON.

Step 1: Customer Complaint Analysis

Record details of the problem (failure, complaint) and how it occurred as described by the customer. For this purpose, use of such an inspection form will facilitate collecting information to the point required for proper analysis and diagnosis. Check if the problem described in "Customer questionnaire" actually occurs in the vehicle if necessary. (This step should be performed with the customer if possible)

Customer questionnaire (Example)

User name:	Model:	VIN:	
Date of issue:	Date Reg.	Date of problem:	Mileage:
Problem Symptoms	• Steering wheel feels heavy • Vehicle pulls to one side during straight driving • Poor recovery from turns • Too much play in steering • Abnormal noise while vehicle is running: from motor, from rack and pinion, other _____ • Other _____		
Frequency of Occurrence	• Continuous/Intermittent (_____ times a day, a month)/other _____		
Conditions for Occurrence of Problem	• Vehicle at stop & ignition switch ON: • When starting: at initial start only/at every start/Other _____ • Vehicle speed while: while accelerating/while decelerating/at stop/while turning/while running at constant speed/other _____ • Road surface condition: Paved road/rough road/snow-covered road/other _____ • Chain equipment:		
Environmental Condition	• Weather: fair/cloudy/rain/snow/other _____ • Temperature: _____ °F (_____ °C)		
DTC	• First check: Normal code/malfunction code (_____) • Second check after driving test: Normal code/malfunction code (_____)		

I7RW01632004-02

NOTE

This form is a standard sample. It should be modified according to conditions characteristic of each market.

Step 2: DTC check, record and clearance

First, referring to "DTC Check", check DTC (including pending DTC). If DTC exists, print or write down DTC and then clear them by referring to "DTC Clearance". DTC indicates malfunction in the system but it is not possible to know from it whether the malfunction is occurring now or it occurred in the past and normal condition has been restored. In order to know that, check symptom in question according to Step 5 and then recheck DTC according to Step 6 and 7. Diagnosing a trouble based on the DTC in this step only or failure to clear the DTC in this step may result in a faulty diagnosis, trouble diagnosis of a normal circuit or difficulty in troubleshooting which is otherwise unnecessary.

Step 3 and Step 4: Visual inspection

As a preliminary step, be sure to perform visual check of the items that support proper function of the P/S system referring to "Visual Inspection".

Step 5: Trouble Symptom Confirmation

Based on information obtained in "Step 1: Customer Complaint Analysis:" and "Step 2: DTC Check, Record and Clearance:", confirm trouble symptoms. Also, reconfirm trouble symptom by performing test drive and turning steering wheel fully to right and left at stopped vehicle.

Step 6 and 7: Rechecking and Record of DTC

Refer to "DTC Check" for checking procedure.

Step 8: Steering Symptom Diagnosis and P/S System Symptom Diagnosis

Perform basic steering system check according to “Steering Symptom Diagnosis in Section 6A” first. When the end of the flow has been reached, check the parts of the system suspected as a possible cause referring to “P/S System Symptom Diagnosis” and based on symptoms appearing on the vehicle (symptoms obtained through steps of customer complaint analysis, trouble symptom confirmation and/or basic P/S system check) and repair or replace faulty parts, if any.

Step 9: Troubleshooting for DTC (See each DTC Diag. Flow)

Based on the DTC indicated in Step 6 or 7 and referring to the applicable DTC diag. flow, locate the cause of the trouble, namely in a sensor, switch, wire harness, connector, actuator, P/S control module or other part and repair or replace faulty parts.

Step 10: Intermittent Problems Check

Check parts where an intermittent trouble is easy to occur (e.g., wire harness, connector, etc.), referring to “Intermittent and Poor Connection Inspection in Section 00” and related circuit of DTC recorded in Step 2.


Step 11: Final Confirmation Test

Confirm that the problem symptom has gone and the P/S system is free from any abnormal conditions. If what has been repaired is related to the DTC, clear the DTC once, perform DTC confirmation procedure and confirm that no DTC is indicated.

“EPS” Warning Light Check

S7RW0C6304002

- 1) Turn ignition switch to ON position (but without running engine) and check if the “EPS” warning light (1) lights up. If the light does not light up, go to ““EPS” Warning Light Does Not Come ON with Ignition Switch Turned ON before Engine Starts” of the diagnostic flows.
- 2) Start engine and check that “EPS” warning light turns OFF. If light remains ON and no DTC is stored in P/S control module, go to ““EPS” Warning Light Remains ON Steady after Engine Starts” for troubleshooting.



I7RW01632002-01


DTC Check

S7RW0C6304003

- 1) Turn ignition switch to OFF position.
- 2) Connect SUZUKI scan tool to data link connector (DLC) (1) located on underside of instrument panel at driver's seat side.

Special tool

(A): SUZUKI scan tool



I5RW0A630004-01

- 3) Start engine.
- 4) Read DTC according to the instructions displayed on SUZUKI scan tool. For further details, refer to operator's manual for SUZUKI scan tool.

NOTE


- If communication between SUZUKI scan tool and the vehicle can not be established, perform “DLC and Its Communication Check (No communication to P/S Control Module)”.
- DTC C1122 (engine speed signal failure) is indicated when ignition switch is at ON position and engine is not running, but it means there is nothing abnormal if indication changes to a normal one when engine is started.

- 5) After completing the check, turn ignition switch to OFF position and disconnect SUZUKI scan tool from DLC.

DTC Clearance

S7RW0C6304004

- 1) Turn ignition switch to OFF position.
- 2) Connect SUZUKI scan tool to data link connector (DLC) (1) located on underside of instrument panel at driver's seat side.

Special tool**(A): SUZUKI scan tool**

I5RW0A630004-01

- 3) Turn ignition switch to ON position.
- 4) Erase DTC according to the instructions displayed on SUZUKI scan tool. For further details, refer to operator's manual for SUZUKI scan tool.
- 5) After completing the clearance, turn ignition switch to OFF position and disconnect SUZUKI scan tool from DLC.

DTC Table

S7RW0C6304005

⚠ CAUTION

Be sure to perform the "EPS System Check" before starting troubleshooting corresponding to each DTC.

DTC No.	Detecting item	Detecting condition (DTC will set when detecting)	Trouble area	DTC	"EPS" warning light
No CODES	Normal	—	—	—	—
 C1111	Steering torque sensor (Main) circuit voltage	Circuit voltage of sensor main is more than 4.5 V or less than 0.5 V	• Torque sensor signal circuit • Torque sensor • P/S control module	1 driving cycle	1 driving cycle
 C1113	Steering torque sensor (Main and Sub) circuit correlation	Difference between steering torque calculated based on sensor main signal and steering torque calculated based on sensor sub signal is more than 4.9 N·m or Difference between instantaneous value and average value of steering torque calculated based on sensor main signal and steering torque calculated based on sensor sub signal is more than 2.94 N·m		1 driving cycle	1 driving cycle
 C1115	Steering torque sensor (Sub) circuit voltage	Circuit voltage of sensor sub signal is more than 4.5 V or less than 0.5 V		1 driving cycle	1 driving cycle
 C1116	Steering torque sensor power supply circuit	Circuit voltage of torque sensor 9 V power supply is less than 7 V		1 driving cycle	1 driving cycle

6C-10 Power Assisted Steering System:

DTC No.	Detecting item	Detecting condition (DTC will set when detecting)	Trouble area	DTC	"EPS" warning light
 C1121	No vehicle speed signal (60 Seconds or More)	Vehicle speed signal is 0 km/h even though engine speed is more than 4000 rpm for more than 60 seconds continuously (before elapse of 5 min from engine start) or vehicle speed signal is 0 km/h even though engine speed is more than 2500 rpm for more than 60 seconds continuously (after elapse of 5 min for engine start).	• Vehicle speed signal circuit • BCM • ECM • ABS control module • P/S control module • CAN communication line circuit	1 driving cycle	Does not light up
 C1122	Engine speed signal	Engine speed signal is less than 220 rpm for more than 0.8 seconds. or Engine speed signal is less than 220 rpm for more than 20 seconds continuously even though vehicle speed signal is more than 50 km/h.	• Engine speed signal circuit • ECM • P/S control module	1 driving cycle	1 driving cycle
 C1123	No vehicle speed signal (30 seconds or more)	Vehicle speed signal is 0 km/h with continuously more than 3 driving cycles even though engine speed is more than 4000 rpm for more than 30 seconds continuously (before elapse of 5 min from engine start) or vehicle speed signal is 0 km/h with continuously more than 3 driving cycles even though engine speed is more than 2500 rpm for more than 30 seconds continuously (after elapse of 5 min for engine start).	• Vehicle speed signal circuit • BCM • ECM • ABS control module • P/S control module • CAN communication line circuit	3 driving cycle	3 driving cycle
 C1124	Vehicle speed performance (impossible deceleration)	Vehicle speed signal is less than 5 km/h for more than 5 seconds continuously with more than specified deceleration speed (-20 m/s^2) from over 20 km/h.		1 driving cycle	Does not light up

DTC No.	Detecting item	Detecting condition (DTC will set when detecting)	Trouble area	DTC	"EPS" warning light
 C1141	P/S motor circuit voltage	Voltage between both motor drive circuit is more than 8.5 V or less than 0.2 V for 0.5 second continuously while motor is not drove.	- P/S motor circuit - P/S motor - Torque sensor - P/S control module	1 driving cycle	1 driving cycle
 C1142	P/S motor circuit range/performance	Measured motor drive current is more than 10 A as compared with target motor drive current.		1 driving cycle	1 driving cycle
 C1143	P/S motor circuit current too high	Measured motor drive current is more than 65 A.		1 driving cycle	1 driving cycle
 C1145	P/S Motor Circuit Current Too Low	Measured motor drive current is less than 2 A continuously for more than 3 seconds even though target motor drive current is more than 4 A. or Measured motor drive current is less than 0.8 A for total 1 second even though motor control duty is more than 90% when target motor drive current is less than 8 A.		1 driving cycle	1 driving cycle
 C1153	P/S control module power supply circuit	Power supply voltage of P/S control module is less than 9 V for 5 seconds continuously while engine speed is more than 600 rpm	- P/S control module power supply circuit - Undercharged Battery - Generator - P/S control module	1 driving cycle	1 driving cycle
 C1155	P/S control module internal failure	Internal memory (EEPROM) is data error.	P/S control module	1 driving cycle	Does not light up
		Internal circuit is faulty. or Power supply voltage of P/S control module exceeded 17.5 V	- Generator - P/S control module	1 driving cycle	1 driving cycle

Visual Inspection

S7RW0C6304006

Visually check the following parts and systems.

Inspection Item		Referring section
Battery	Level, leakage, color	"Battery Description in Section 1J"
Connectors of electric wire harness	Disconnection friction	"Intermittent and Poor Connection Inspection in Section 00"
Fuses	Burning	"Cautions in Body Electrical System Servicing in Section 9A"
Parts	Installation, damage	
Other parts that can be checked visually		

Scan Tool Data

S7RW0C6304007

NOTE

When P/S motor is cold condition (that is, armature coil of P/S motor is not heated), normal value with asterisk (*) mark in the following table is displayed on scan tool

Scan tool data	Vehicle condition		Normal condition
☞ Power Supply Voltage	Ignition switch ON		10 – 14 V
☞ Sensor Power Supply			7.4 – 10 V
☞ Sensor (Main) Torque	Engine running at idle speed	Steering wheel at fully turned to left	–10.5 – 0 N·m
		Steering wheel at free	0 N·m
		Steering wheel at fully turned to right	0 – 12.85 N·m
☞ Sensor (Sub) Torque	Engine running at idle speed	Steering wheel at fully turned to left	0 – 10.65 N·m
		Steering wheel at free	0 N·m
		Steering wheel at fully turned to right	–12.85 – 0 N·m
☞ Control Torque	Engine running at idle speed	Steering wheel at fully turned to left	–7.22 – 0 N·m
		Steering wheel at free	0 N·m
		Steering wheel at fully turned to right	0 – 7.16 N·m
☞ Target Motor Current	Engine running at idle speed	Steering wheel at free	0 A
		Steering wheel at fully turned to left or right	*45 – 60 A
☞ Measured MOT Current	Engine running at idle speed	Steering wheel at free	0 A
		Steering wheel at fully turned to left or right	*45 – 60 A
☞ Vehicle Speed	Engine running and vehicle at stop		0 km/h
☞ Engine Speed	Engine running at idle speed after warming up		700 ± 50 rpm
☞ Motor Drive Voltage	Engine running at idle speed	Steering wheel at free	0.8 – 1 V
		Steering wheel at fully turned to right	*5.5 – 8.5 V
☞ System Power Status	Ignition switch ON		ON
☞ IGN switch Status			ON
☞ Torque sensor Status	Engine running at idle speed		ON
☞ Fail Safe FET Status			ON

Scan Tool Data Definitions

Power Supply Voltage

This parameter indicates battery positive voltage.

Sensor Power Supply (Torque Sensor Power Supply, V)

This parameter indicates the power supply voltage which the P/S control module supplies to the torque sensor.

Sensor (Main) Torque (Torque Sensor Main Torque, N·m)

The torque sensor is installed to detect the steering force and the steering direction. It consists of two potentiometers and the main torque sensor is one of these.

Sensor (Sub) Torque (Torque Sensor Sub Torque, N·m)

The torque sensor is installed to detect the steering force and the steering direction. It consists of two potentiometers and the sub-torque sensor is one of these. Its output characteristics are compared with those of the main torque sensor.

Control Torque (N·m)

This parameter is an internal parameter of the P/S control module. It is obtained by computing the torque sensor input signal.

Target Motor Current (Motor Control Current, A)

Based on the input signal, the P/S control module determines the assist amount and controls the current to the motor suitable for that assist amount. This parameter indicates that control value.

Measured MOT Current (Motor Monitor Current, A)

This parameter indicates the actually measured value of the current flowing to the motor. The motor circuit condition is diagnosed by comparing this parameter with "Motor Control" parameter described previously.

Vehicle Speed (km/h, MPH)

Vehicle speed signal is fed from BCM. P/S control module determines the amount of power assist based on this vehicle speed signal and the torque sensor signal.

Engine Speed (rpm)

Engine speed signal is fed from the ECM so that it can be used for trouble diagnosis of the electric power steering system.

Motor Drive Voltage (V)

This parameter indicates the voltage between motor terminals.

System Power Status (EPS System Power, ON, OFF)

This parameter indicates input status of EPS system power supply.

IGN switch Status (ON, OFF)

This parameter indicates the condition of the power supply through the ignition switch.

Torque sensor Status (ON, OFF)

This parameter indicates the output status of the torque sensor power supply.

Fail Safe FET Status (ON, OFF)

This parameter indicates the status of the motor drive power supply circuit.

P/S System Symptom Diagnosis

S7RW0C6304008


This section describes trouble diagnosis of the P/S system parts whose trouble is not indicated by the on-board diagnostic system (self-diagnostic function). When no malfunction is indicated by the on-board diagnostic system (self-diagnosis function) and assuredly those steering basic parts as described in "Steering Symptom Diagnosis in Section 6A" are all in good condition, check the following power steering system parts which may be a possible cause for each symptom of the steering.

Condition	Possible cause	Correction / Reference Item
Steering wheel feels heavy (Perform "Steering Force Check:" before diagnosis.)	Steering wheel installed improperly (twisted)	<i>Install steering wheel correctly.</i>
	Poor performance of P/S motor	<i>Check P/S motor referring to "P/S Motor and Its Circuit Inspection".</i>
	Poor performance of torque sensor	<i>Check torque sensor referring to "Torque Sensor and Its Circuit Inspection".</i>
	Steering gear case assembly malfunction	<i>Replace steering gear case assembly.</i>
	Poor performance of vehicle speed signal from BCM	<i>Check vehicle speed signal circuit referring to "DTC C1121 / C1123 / C1124: Vehicle Speed Signal Circuit Failure".</i>
Steering wheel feels heavy momentarily when turning it to the left or right	Steering gear case assembly malfunction	<i>Replace steering gear case assembly.</i>
Poor recovery from turns	Poor performance of torque sensor	<i>Check torque sensor referring to "Torque Sensor and Its Circuit Inspection".</i>
	Steering gear case assembly malfunction	<i>Replace steering gear case assembly.</i>
Vehicle pulls to one side during straight driving	Poor performance of torque sensor	<i>Check torque sensor referring to "Torque Sensor and Its Circuit Inspection".</i>
	Steering gear case assembly malfunction	<i>Replace steering gear case assembly.</i>
Abnormal noise	P/S motor (built in steering gear case assembly) malfunction	<i>Replace steering gear case assembly.</i>
No idle up	P/S control module faulty	<i>Check P/S control module referring to "Inspection of P/S Control Module and Its Circuits".</i>

DLC and Its Communication Check (No communication to P/S Control Module)

S7RW0C6304009

Wiring Diagram



I6RW0C630002-01

[A]: P/S control module connector No.1 "E11" (viewed from harness side)	6. "EPS" warning light	14. Serial data circuit
[B]: P/S control module connector No.2 "E13" (viewed from harness side)	7. Data link connector (DLC)	15. DLC power supply circuit
[C]: Combination meter connector "G241" (viewed from harness side)	8. P/S control module	16. DLC ground circuit
1. Main fuse box	9. BCM	17. "IGN" fuse
2. Ignition switch	10. To HVAC control module	18. "P/S" fuse
3. Junction block assembly	11. To ABS control module	19. "IG1 SIG" fuse
4. Main fuse	12. To SDM	20. "MTR" fuse
5. Combination meter	13. Individual circuit fuse box No.1	

Troubleshooting

Step	Action	Yes	No
1	"EPS" warning light check 1) Turn ignition switch to ON position. <i>Does "EPS" warning light turn on?</i>	Go to step 3.	Go to "EPS" Warning Light Does Not Come ON with Ignition Switch Turned ON before Engine Starts".
2	Scan tool condition check 1) Make sure that SUZUKI scan tool is as follows. • Correct PCMCIA card (software) is used. • There are no deformation and wear for DLC cable terminals. • Connection for DLC cable terminals is in good condition. <i>Are they OK?</i>	Go to step 3.	Repair or replace defective part.

Step	Action	Yes	No
3	Communication check 1) Check DLC terminal for deformation and wear. 2) If it is in good condition, connect SUZUKI scan tool to DLC with ignition switch tuned OFF. 3) Check if communication is possible by making communication with other control modules (BCM, ABS, HVAC control module or SDM). <i>Is it possible to communicate with the other control modules?</i>	Go to Step 4.	Go to Step 6.
4	Serial communication circuit check 1) With ignition switch turned OFF, disconnect "E11" connector from P/S control module and check for proper connection at P/S control module connector terminal. 2) If connections are OK, check that "Serial data circuit" is as follows. Wiring resistance of "Serial data circuit" wire between DLC connector and P/S control module connector is less than 1 Ω. <i>Is it resistance less than 1 Ω?</i>	Go to Step 5.	"Serial data circuit" is open or high resistance.
5	P/S control module power and ground circuit check 1) Check power supply circuit and ground circuit for P/S control module referring to "P/S Control Module Power Supply and Ground Circuit Check". <i>Is check result in good condition?</i>	Substitute a known-good P/S control module and recheck.	Repair or replace defective circuit.
6	DLC power and ground circuit check 1) Check power supply circuit and ground circuit for DLC connector as follows. - Voltage of "DLC connector power supply circuit" between DLC connector terminal and vehicle body ground is 10 – 14 V with ignition switch turned ON. - Wire resistance of each "DLC connector ground circuit" between DLC connector terminal and vehicle body ground is less than 1 Ω. <i>Is check result in good condition?</i>	Go to Step 7.	Repair or replace defective circuit.
7	Serial communication circuit check 1) With ignition switch turned OFF, disconnect "E11" connector from P/S control module and check for terminal to P/S control module connector. 2) If connections are OK, check that "Serial data circuit" is as follows. - Insulation resistance of "Serial data circuit" wire is infinity between its terminal and other terminals at P/S control module connector. - Insulation resistance of "Serial data circuit" wire is infinity between its terminal and vehicle body ground. <i>Is circuit in good condition?</i>	Go to Step 8.	Repair or replace defective circuit.


6C-16 Power Assisted Steering System:

Step	Action	Yes	No
8	Scan tool operation check 1) Check if communication is possible by making communication with other vehicles. <i>Is it possible to communicate with the other vehicle?</i>	Scan tool is in good condition, check intermittent trouble referring to "Intermittent and Poor Connection Inspection in Section 00".	Recheck PCMCIA card and DLC cable for faulty condition. If they are OK, scan tool is faulty.

“EPS” Warning Light Does Not Come ON with Ignition Switch Turned ON before Engine Starts

S7RW0C6304010

Wiring Diagram



I6RW0C630003-01

[A]: P/S control module connector No.1 "E11" (viewed from harness side)	4. Main fuse	10. "IGN" fuse
[B]: P/S control module connector No.2 "E13" (viewed from harness side)	5. Combination meter	11. "P/S" fuse
[C]: Combination meter connector "G241" (viewed from harness side)	6. "EPS" warning light	12. "IG1 SIG" fuse
1. Main fuse box	7. P/S control module	13. "MTR" fuse
2. Ignition switch	8. Individual circuit fuse box No.1	
3. Junction block assembly	9. "EPS" warning light circuit	

Circuit Description

Operation (ON/OFF) of “EPS” warning light is controlled by P/S control module through combination meter. If the P/S system is in good condition, P/S control module turns “EPS” warning light ON at the ignition switch ON, and then turns it OFF at the engine start. If an abnormality in the system is detected, “EPS” warning light is turned ON continuously by P/S control module. If P/S control module is disconnected, “EPS” warning light is not turned ON.

Troubleshooting

Step	Action	Yes	No
1	"EPS" warning light power supply check 1) Turn ignition switch ON. <i>Do the other warning light come on?</i>	Go to Step 2.	"GRN", "RED/BLK" wire circuit or circuit fuse for combination meter is open or short to ground.
2	Fuse check 1) Turn ignition switch OFF. 2) Remove and inspect circuit fuse for P/S control module. <i>Is fuse in good condition?</i>	Reinstall fuse, and then go to Step 3.	Check "GRN" wire circuit for short to ground. If OK, replace fuse.
3	P/S control module power supply and ground circuit check Check power supply circuit and ground circuit for P/S control module referring to "P/S Control Module Power Supply and Ground Circuit Check". <i>Is check result in good condition?</i>	Go to Step 4.	Repair or replace defective circuit.
4	Combination meter power supply circuit check 1) Remove combination meter and disconnect combination meter connector ("G241") with ignition switch turned OFF. 2) Check for proper connection to the combination meter at "G241-31" terminal. 3) If OK, check voltage between "G241-31" ("RED/BLK" wire) terminal and body ground with ignition switch ON. <i>Is it 10 – 14 V?</i>	Go to Step 5.	"RED/BLK" wire circuit is open or short to ground.
5	"EPS" warning light circuit resistance check 1) Check for proper connection to the combination meter at "G241-25" terminal and P/S control module at "E11-5" terminal. 2) Check that "EPS warning light circuit" is as follows. - Insulation resistance of "EPS warning light circuit" wire is infinity between its terminal and each terminal at combination meter connector. - Wiring resistance of "EPS warning light circuit" wire is less than 1 Ω. - Insulation resistance of "EPS warning light circuit" wire is infinity between its terminal and vehicle body ground. <i>Is circuit in good condition?</i>	"GRY" wire circuit is open.	Go to Step 6.
6	"EPS" warning light circuit voltage check 1) Connect combination meter connector ("G241") with ignition switch turned OFF. 2) Check for voltage between "E11-5" ("GRY" wire) terminal and body ground with ignition switch ON. <i>Is it 10 – 14 V?</i>	Replace the P/S control module.	Replace the combination meter.

“EPS” Warning Light Remains ON Steady after Engine Starts

S7RW0C6304011

Wiring Diagram

Refer to ““EPS” Warning Light Does Not Come ON with Ignition Switch Turned ON before Engine Starts”.


Circuit Description

Operation (ON/OFF) of “EPS” warning light is controlled by P/S control module through combination meter.

If the P/S system is in good condition, P/S control module turns “EPS” warning light ON at the ignition switch ON, and then turns it OFF at the engine start. If an abnormality in the system is detected, “EPS” warning light is turned ON continuously by P/S control module. If P/S control module is disconnected, “EPS” warning light is not turned ON.

Troubleshooting

Step	Action	Yes	No
1	Check DTC referring to “DTC Check”. <i>Is there any DTC(s) (NO CODES on SUZUKI scan tool)?</i>	Go to applicable DTC diag. flow.	Go to Step 2.
2	“EPS” warning light circuit check 1) With ignition switch turned OFF, disconnect P/S control module connector. 2) Check for proper connection to the P/S control module at “E11-5” terminal. 3) If OK, then turn ignition switch to ON position. <i>Does “EPS” warning light turn ON?</i>	Go to Step 3.	Replace P/S control module.
3	Combination meter ground circuit check 1) Remove combination meter and disconnect combination meter connector with ignition switch turned OFF. 2) Check combination meter connector for proper connection. 3) If connections are OK, check that “EPS warning light circuit” is as follows. • Insulation resistance of “EPS warning light circuit” wire is infinity between its terminal and each terminal at combination meter connector. • Insulation resistance of “EPS warning light circuit” wire is infinity between its terminal and vehicle body ground. <i>Is circuit in good condition?</i>	Replace combination meter.	Repair defective circuit.

DTC C1111 / C1113 / C1115: Torque Sensor Circuit Failure**DTC C1111: Steering Torque Sensor (Main) Circuit Voltage****DTC C1113: Steering Torque Sensor (Main and Sub) Circuit Correlation****DTC C1115: Steering Torque Sensor (Sub) Circuit Voltage****Wiring Diagram**

I6RW0C630004-02

[A]: P/S control module connector No.1 "E11" (viewed from harness side)	3. Junction block assembly	8. Torque sensor signal circuit
[B]: P/S control module connector No.2 "E13" (viewed from harness side)	4. Main fuse	9. "IGN" fuse
[C]: Torque sensor connector "E31" (viewed from harness side)	5. P/S control module	10. "P/S" fuse
1. Main fuse box	6. Torque sensor	11. "IG1 SIG" fuse
2. Ignition switch	7. Individual circuit fuse box No.1	

DTC Detecting Condition and Trouble Area

DTC detecting condition	Trouble area
DTC C1111: Circuit voltage of sensor main is more than 4.5 V or less than 0.5 V (1 driving cycle detection logic) DTC C1113: Difference between steering torque calculated based on sensor main signal and steering torque calculated based on sensor sub signal is more than 4.9 N·m or Difference between instantaneous value and average value of steering torque calculated based on sensor main signal and steering torque calculated based on sensor sub signal is more than 2.94 N·m (1 driving cycle detection logic) DTC C1115: Circuit voltage of sensor sub signal is more than 4.5 V or less than 0.5 V (1 driving cycle detection logic)	• Torque sensor signal circuit • Torque sensor • P/S control module


DTC Troubleshooting

Step	Action	Yes	No
1	Was "EPS System Check" performed?	Go to Step 2.	Go to "EPS System Check".
2	DTC check <i>Is DTC C1153 or C1116 indicated, together?</i>	Go to applicable diag. flow.	Go to Step 3.
3	Torque sensor signal circuit check 1) With ignition switch turned OFF, disconnect torque sensor connector. 2) Check for voltage between following terminal with ignition switch ON. • "E11-18" ("YEL" wire) terminal and body ground • "E11-10" ("WHT" wire) terminal and body ground <i>Is it about 0 V?</i>	Go to Step 4.	Torque sensor signal circuit is shorted to other circuit.
4	Torque sensor circuit check 1) Disconnect P/S control module connector. 2) Check that torque sensor signal circuit is as follows. • Insulation resistance of wire harness is infinity between "Torque sensor signal circuit" terminal and other terminal at torque sensor connector. • Wiring harness resistance of "Torque sensor signal circuit" is less than 1 Ω . • Insulation resistance between "Torque sensor signal circuit" and vehicle body ground is infinity. <i>Is circuit in good condition?</i>	Go to Step 5.	Repair or replace defective circuit.
5	Torque sensor check 1) Connect connectors to P/S control module and torque sensor with ignition switch turned OFF. 2) Check torque sensor out put voltage referring to "Torque Sensor and Its Circuit Inspection". <i>Is torque sensor in good condition?</i>	Substitute a known-good P/S control module and recheck.	Go to Step 6.
6	P/S control module resistance check 1) With ignition switch turned OFF, disconnect torque sensor connector. 2) Check for resistance between following terminal with ignition switch ON. • "E11-18" ("YEL" wire) terminal and body ground • "E11-10" ("WHT" wire) terminal and body ground <i>Is it about 1 kΩ?</i>	Replace steering gear case.	Replace P/S control module.

DTC C1116: Steering Torque Sensor Power Supply Circuit

S7RW0C6304013

Wiring Diagram



I6RW0C630005-02

[A]: P/S control module connector No.1 "E11" (viewed from harness side)	3. Junction block assembly	8. Torque sensor power supply circuit
[B]: P/S control module connector No.2 "E13" (viewed from harness side)	4. Main fuse	9. "IGN" fuse
[C]: Torque sensor connector "E31" (viewed from harness side)	5. P/S control module	10. "P/S" fuse
1. Main fuse box	6. Torque sensor	11. "IG1 SIG" fuse
2. Ignition switch	7. Individual circuit fuse box No.1	

DTC Detecting Condition and Trouble Area


DTC detecting condition	Trouble area
Circuit voltage of torque sensor 9 V power supply is less than 7 V (1 driving cycle detection logic)	- Torque sensor 9 V power supply circuit - Torque sensor - P/S control module

6C-22 Power Assisted Steering System:**DTC Troubleshooting**

Step	Action	Yes	No
1	Was "EPS System Check" performed?	Go to Step 2.	Go to "EPS System Check".
2	DTC check <i>Is DTC C1153 indicated, together?</i>	Go to applicable DTC diag. flow.	Go to Step 3.
3	Torque sensor power supply voltage check 1) With ignition switch turned OFF, disconnect torque sensor connector. 2) Check for voltage between "E31-3" ("GRN" wire) terminal and body ground with ignition switch ON. <i>Is it approx. 9 V?</i>	Go to Step 4.	Go to Step 5.
4	Torque sensor power supply voltage check 1) With ignition switch turned OFF, connect torque sensor connector. 2) Check for voltage between "E11-8" ("GRN" wire) terminal and body ground with ignition switch ON. <i>Is it approx. 9 V?</i>	Substitute a known-good P/S control module and recheck.	Replace steering gear case.
5	Torque sensor power supply circuit check 1) Check that torque sensor power supply circuit is as follows. • Insulation resistance of wire harness is infinity between "Torque sensor power supply circuit" terminal and each other terminal at torque sensor connector. • Wiring harness resistance of "Torque sensor power supply circuit" is less than 1 Ω. • Insulation between "Torque sensor power supply circuit" and vehicle body ground is infinity. <i>Is circuit in good condition?</i>	Replace P/S control module.	Repair or replace defective circuit.

DTC C1121 / C1123 / C1124: Vehicle Speed Signal Circuit Failure

S7RW0C6304014

DTC C1121: No Vehicle Speed Signal (60 Seconds or More)**DTC C1123: No Vehicle Speed Signal (30 Seconds or More)****DTC C1124: Vehicle Speed Performance (Impossible Deceleration)****Wiring Diagram**

I6RW0C630006-01

[A]: P/S control module connector No.1 "E11" (viewed from harness side)	5. ECM	11. "IGN" fuse
[B]: P/S control module connector No.2 "E13" (viewed from harness side)	6. BCM	12. "P/S" fuse
1. Main fuse box	7. Front left/right wheel speed sensor	13. "IG1 SIG" fuse
2. Ignition switch	8. P/S control module	14. Vehicle speed signal
3. Junction block assembly	9. ABS control module	
4. Main fuse	10. Individual circuit fuse box No.1	

6C-24 Power Assisted Steering System:**DTC Detecting Condition and Trouble Area**

DTC detecting condition	Trouble area
DTC C1121: Vehicle speed signal is 0 km/h even though engine speed is more than 4000 rpm for more than 60 seconds continuously (before elapse of 5 min from engine start) or Vehicle speed signal is 0 km/h even though engine speed is more than 2500 rpm for more than 60 seconds continuously (after elapse of 5 min for engine start). (1 driving cycle detection logic but "EPS" warning light does not light up) DTC C1123: Vehicle speed signal is 0 km/h with continuously more than 3 driving cycles even though engine speed is more than 4000 rpm for more than 30 seconds continuously (before elapse of 5 min from engine start) or Vehicle speed signal is 0 km/h with continuously more than 3 driving cycles even though engine speed is more than 2500 rpm for more than 30 seconds continuously (after elapse of 5 min for engine start). (3 driving cycle detection logic) DTC C1124: Vehicle speed signal is less than 5 km/h for more than 5 seconds continuously with more than specified deceleration speed (-20 m/s^2) from over 20 km/h. (1 driving cycle detection logic but "EPS" warning light does not light up)	• Vehicle speed signal circuit • BCM • ECM • ABS control module • P/S control module • CAN communication line circuit


DTC Troubleshooting

Step	Action	Yes	No
1	Was "EPS System Check" performed?	Go to Step 2.	Go to "EPS System Check".
2	DTC check 1) Check ABS control module and BCM for DTC referring to "DTC Check in Section 4E" and "DTC Check in Section 10B". <i>Is there any DTC(s) detected?</i>	Go to applicable DTC diag. flow.	Go to Step 3.
3	DTC check 1) Check ECM for DTC referring to "DTC Check in Section 1A". <i>Is there any DTC(s) detected?</i>	Go to applicable DTC diag. flow.	Go to Step 4.
4	Vehicle speed signal circuit check 1) With ignition switch turned OFF, disconnect connectors from BCM. 2) Check BCM connector for proper connection. 3) If OK, turn ON ignition switch, measure voltage between "G04-22" wire terminal of BCM connector and body ground. <i>Is voltage 4 – 5 V?</i>	Go to Step 5.	Go to Step 6.

Step	Action	Yes	No
5	BCM voltage check 1) With ignition switch turned OFF, connect BCM connector. 2) Check BCM for vehicle speed signal output referring to "Inspection of P/S Control Module and Its Circuits". <i>Is it in good condition?</i>	Replace P/S control module.	Replace BCM.
6	Vehicle speed signal circuit check 1) Check that vehicle speed signal circuit is as follows. - Insulation resistance of wire harness is infinity between "Vehicle speed signal" terminal and other terminal at P/S control module connector. - Wiring harness resistance of "Vehicle speed signal" circuit is less than 1Ω. - Insulation resistance between "Vehicle speed signal" circuit and vehicle body ground is infinity. - Circuit voltage between "Vehicle speed signal" circuit and ground circuit is 0 – 1 V with ignition switch turned ON. <i>Is it in good condition?</i>	Replace P/S control module.	Repair or replace defective circuit.

DTC C1122: Engine Speed Signal

S7RW0C6304015

Wiring Diagram

I6RW0C630007-01

[A]: P/S control module connector No.1 "E11" (viewed from harness side)	4. Main fuse	9. "P/S" fuse
[B]: P/S control module connector No.2 "E13" (viewed from harness side)	5. ECM	10. "IG1 SIG" fuse
1. Main fuse box	6. P/S control module	11. Engine speed signal circuit
2. Ignition switch	7. Individual circuit fuse box No.1	
3. Junction block assembly	8. "IGN" fuse	

DTC Detecting Condition and Trouble Area


DTC detecting condition	Trouble area
Engine speed signal is less than 220 rpm for more than 0.8 seconds. or Engine speed signal is less than 220 rpm for more than 20 seconds continuously even though vehicle speed signal is more than 50 km/h. (1 driving cycle detection logic)	- Engine speed signal circuit - ECM - P/S control module

DTC Troubleshooting

Step	Action	Yes	No
1	Was "EPS System Check" performed?	Go to Step 2.	Go to "EPS System Check".
2	DTC check 1) Check ECM for DTC referring to "DTC Check in Section 1A". <i>Is there any DTC(s) detected?</i>	Go to applicable DTC diag. flow.	Go to Step 3.
3	Engine speed signal circuit check 1) With ignition switch turned OFF, disconnect P/S control module connector. 2) Check P/S control module connector for proper connection. 3) If OK, turn ON ignition switch, measure voltage between "E11-12" wire terminal of P/S control module connector and vehicle body ground. <i>Is voltage 10 – 14 V?</i>	Go to Step 4.	Go to Step 5.
4	ECM voltage check 1) With ignition switch turned OFF, connect P/S control module and ECM connectors. 2) Check engine speed signal output referring to "Inspection of ECM and Its Circuits in Section 1A". <i>Is it in good condition?</i>	Substitute a known-good P/S control module and recheck.	Substitute a known good ECM and recheck.
5	Engine speed signal circuit check 1) Disconnect ECM connector. 2) Check that engine speed signal circuit is as follows. • Insulation resistance of wire harness is infinity between "Engine speed signal circuit" terminal and other terminal at P/S control module connector. • Wiring harness resistance of "Engine speed signal circuit" is less than 1Ω. • Insulation resistance between "Engine speed signal circuit" and vehicle body ground is infinity • Circuit voltage between "Engine speed signal circuit" and ground circuit is 0 – 1 V with ignition switch turned ON. <i>Is it in good condition?</i>	Substitute a known good ECM and recheck.	Repair or replace defective circuit.

DTC C1141 / C1142 / C1143 / C1145: Motor Circuit Failure

S7RW0C6304016

DTC C1141: P/S Motor Circuit Voltage**DTC C1142: P/S Motor Circuit Range/Performance****DTC C1143: P/S Motor Circuit Current Too High****DTC C1145: P/S Motor Circuit Current Too Low****Wiring Diagram**

I6RW0C630008-01

[A]: P/S control module connector No.1 "E11" (viewed from harness side)	2. Ignition switch	7. Individual circuit fuse box No.1
[B]: P/S control module connector No.2 "E13" (viewed from harness side)	3. Junction block assembly	8. "IGN" fuse
[C]: P/S control module connector No.3 "E12" (viewed from harness side)	4. Main fuse	9. "P/S" fuse
[D]: Motor connector "E61" (viewed from harness side)	5. P/S control module	10. "IG1 SIG" fuse
1. Main fuse box	6. P/S motor	11. Motor circuit

DTC Detecting Condition and Trouble Area

DTC detecting condition	Trouble area
DTC C1141: Voltage between both motor drive circuit is more than 8.5 V or less than 0.2 V for 0.5 second continuously while motor is not drove. (1 driving cycle detection logic) DTC C1142: Measured motor drive current is more than 10 A as compared with target motor drive current. (1 driving cycle detection logic) DTC C1143: Measured motor drive current is more than 65 A. (1 driving cycle detection logic) DTC C1145: Measured motor drive current is less than 2 A continuously for more than 3 seconds even though target motor drive current is more than 4 A. or Measured motor drive current is less than 0.8 A for total 1 second even though motor control duty is more than 90% when target motor drive current is less than 8 A. (1 driving cycle detection logic)	• P/S motor circuit • P/S motor • Torque sensor • P/S control module


DTC Troubleshooting

Step	Action	Yes	No
1	Was "EPS System Check" performed?	Go to Step 2.	Go to "EPS System Check".
2	DTC check <i>Is DTC C1153 and/or C1155 indicated, together?</i>	Go to applicable DTC diag. flow.	Go to Step 3.
3	Power supply and ground circuit check 1) Check P/S control module power supply and ground circuit referring to "P/S Control Module Power Supply and Ground Circuit Check". <i>Is it in good condition?</i>	Go to Step 4.	Repair or replace defective circuit.
4	Motor circuit check 1) With ignition switch turned OFF, disconnect P/S control module connector No.3 and P/S motor connector. 2) Check P/S control module connector and P/S motor connector for proper connection. 3) If OK, check for open, short and/or high resistance in motor circuit between P/S control module and P/S motor. Refer to "Electrical Circuit Inspection Procedure in Section 00". <i>Are they in good condition?</i>	Go to Step 5.	Repair motor circuit.
5	P/S motor check 1) Check P/S motor referring to "P/S Motor and Its Circuit Inspection". <i>Is P/S motor in good condition?</i>	Substitute a known-good P/S control module and recheck.	Replace the steering gear case assembly and recheck.

DTC C1153: P/S Control Module Power Supply Circuit

S7RW0C6304017

Wiring Diagram



I6RW0C630009-01

[A]: P/S control module connector No.1 "E11" (viewed from harness side)	3. Junction block assembly	7. "IGN" fuse
[B]: P/S control module connector No.2 "E13" (viewed from harness side)	4. Main fuse	8. "P/S" fuse
1. Main fuse box	5. P/S control module	9. "IG1 SIG" fuse
2. Ignition switch	6. Individual circuit fuse box No.1	

DTC Detecting Condition and Trouble Area

DTC detecting condition	Trouble area
Power supply voltage of P/S control module is less than 9 V for 5 seconds continuously while engine speed is more than 600 rpm. (1 driving cycle detection logic)	- P/S control module power supply circuit - Battery - Generator - P/S control module

DTC Troubleshooting

Step	Action	Yes	No
1	Was "EPS System Check" performed?	Go to Step 2.	Go to "EPS System Check".
2	Battery voltage check 1) Check circuit fuse for P/S control module. 2) If OK, measure voltage between positive (+) battery terminal and vehicle body ground with engine running. <i>Is voltage 10 V or more?</i>	Go to Step 3.	Check charging system referring to "Generator Test (Undercharged Battery Check) in Section 1J".
3	P/S control module power supply circuit check Check power supply circuit and ground circuit for P/S control module referring to "P/S Control Module Power Supply and Ground Circuit Check". <i>Is check result in good condition?</i>	Substitute a known-good P/S control module and recheck.	Repair defective circuit.

DTC C1155: P/S Control Module Internal Failure

S7RW0C6304018

Wiring Diagram

Refer to "DTC C1153: P/S Control Module Power Supply Circuit".

DTC Detecting Condition and Trouble Area

DTC detecting condition	Trouble area
Internal memory (EEPROM) is data error. (In this case, "EPS" warning light does not light up) or Internal circuit is faulty. or Power supply voltage of P/S control module exceeded 17.5 V (1 driving cycle detection logic)	• Generator • P/S control module

DTC Troubleshooting

Step	Action	Yes	No
1	Was "EPS System Check" performed?	Go to Step 2.	Go to "EPS System Check".
2	P/S control module power supply and ground circuit check Check power supply circuit and ground circuit for P/S control module referring to "P/S Control Module Power Supply and Ground Circuit Check". <i>Is check result in good condition?</i>	Go to Step 3.	Repair or replace defective circuit.
3	Battery voltage check 1) Check voltage between positive (+) battery terminal and vehicle body ground with engine speed at 3000 rpm. <i>Is voltage 15.5 V or less?</i>	Replace P/S control module.	Check charging system referring to "Generator Test (Overcharged Battery Check) in Section 1J".

P/S Control Module Power Supply and Ground Circuit Check

S7RW0C6304019

Wiring Diagram

Refer to "DTC C1153: P/S Control Module Power Supply Circuit".

DTC Troubleshooting

Step	Action	Yes	No
1	Circuit fuse check 1) Disconnect P/S control module connector with ignition switch turned OFF. 2) Check for proper connection to P/S control module connector at "E13-1", "E13-2" and "E11-1" terminals. 3) If OK, check "P/S" fuse and "IG1 SIG" fuse for blowing. <i>Are "P/S" fuse and "IG1 SIG" fuse in good condition?</i>	Go to Step 2.	Replace fuse (s) and check for short in circuits connected to fuse(s).
2	Power supply circuit check 1) Measure voltage between "E13-1" terminal of P/S control module connector and body ground. <i>Is voltage 10 – 14 V?</i>	Go to Step 3.	"GRN" or "WHT" wire is open circuit.
3	Ignition signal check 1) Turn ignition switch to ON position. 2) Measure voltage between "E11-1" terminal of P/S control module connector and body ground. <i>Is voltage 10 – 14 V?</i>	Go to Step 4.	"LT GRN / BLK" or "GRN" wire is open circuit.
4	P/S control module ground circuit check 1) Turn ignition switch to OFF position. 2) Disconnect connectors from P/S control module. 3) Measure resistance between "E13-2" terminals of P/S control module connector and body ground. <i>Is resistance 1Ω or less?</i>	Go to Step 5.	"BLK" wire is open or high resistance circuit.
5	P/S control module ground circuit check 1) Connect connectors to P/S control module. 2) Start engine. 3) Measure voltage between "E13-2" terminals of P/S control module connector and body ground when steering wheel fully turned to left or right. <i>Is voltage 0.3 V or less?</i>	P/S Control Module Power Supply and Ground Circuit is in good condition.	"BLK" wire is high resistance circuit.

Inspection of P/S Control Module and Its Circuits

The P/S control module and its circuits can be checked at the P/S control module wiring couplers by measuring voltage and resistance.

⚠ CAUTION


P/S control module cannot be checked by itself. It is strictly prohibited to connect voltmeter or ohmmeter to the P/S control module with connectors disconnected from the P/S control module.

Voltage Check

- 1) Remove console box.
- 2) Check for voltage at each terminal with connectors connected to the P/S control module.

NOTE

As each terminal voltage is affected by the battery voltage, confirm if the battery voltage is 11 V or more when ignition switch is ON.



[A]: P/S control module connector No.1 "E11" (viewed from harness side)

[B]: P/S control module connector No.2 "E13" (viewed from harness side)

[C]: P/S control module connector No.3 "E12" (viewed from harness side)

6C-32 Power Assisted Steering System:

Terminal	Wire color	Circuit	Normal voltage	Condition
E11-1	LT GRN/BLK	Ignition switch signal for P/S control module	10 – 14 V	Ignition switch ON
E11-2	—	—	—	—
E11-3	—	—	—	—
E11-4	PPL	Vehicle speed signal	*0 – 1 V ↑↓ 8 – 14 V ("Reference waveform No.6" under "Inspection of BCM and Its Circuits in Section 10B")	- Ignition switch ON - Front left tire turned quickly with right tire locked
E11-5	GRY	"EPS" warning light	0 V	Ignition switch ON
			0 – 14 V	Engine running
E11-6	—	—	—	—
E11-7	—	—	—	—
E11-8	GRN	9 V power supply for torque sensor	About 9 V	- Ignition switch ON - Voltage between "E11-8" and "E11-9" terminals
E11-9	BLK	Ground for torque sensors	—	—
E11-10	WHT	Torque sensor signal (Sub)	About 2.5 – 4.0 V	- Steering wheel with left turn - Out put voltage varies linearly depending on steering force
			About 2.5 V	Steering wheel at free
			About 1.0 – 2.5 V	- Steering wheel with right turn - Out put voltage varies linearly depending on steering force
E11-11	BLU	Serial communication circuit for data link connector	—	—
E11-12	BRN	Engine speed signal	*0 – 1 V ↑↓ 8 – 14 V ("Reference waveform No.26 and No.27" under "Inspection of ECM and Its Circuits in Section 1A")	Engine idling
E11-13	—	—	—	—
E11-14	RED/BLU	P/S active signal (idle up signal)	About 12 V	Ignition switch ON
			0 – 1 V	Engine idling and turned steering wheel to the right or left until it stops
E11-15	—	—	—	—
E11-16	—	—	—	—
E11-17	—	—	—	—
E11-18	YEL	Torque sensor signal (Main)	About 1.0 – 2.5 V	- Steering wheel with left turn - Out put voltage varies linearly depending on steering force
			About 2.5 V	Steering wheel at free
			About 2.5 – 4.0 V	- Steering wheel with right turn - Out put voltage varies linearly depending on steering force
E11-19	GRY	Ground for shield wire	—	—

Terminal	Wire color	Circuit	Normal voltage	Condition
E11-20	RED	Reference sensor power supply for torque sensor	About 3.0 – 3.5 V	- Ignition switch ON - Check voltage between “E11-20” and “E11-9” terminals
E12-1	BLK	Motor output 1	*0 – 1 V ↑↓ 10 – 14 V (“Reference waveform No.1: ”, “Reference waveform No.2: ” and “Reference waveform No.3: ”)	- Engine idling and steering wheel at straight position - Voltage between “E12-1” and vehicle body ground
E12-2	RED	Motor output 2	*0 – 1 V ↑↓ 10 – 14 V (“Reference waveform No.1: ”, “Reference waveform No.2: ” and “Reference waveform No.3: ”)	- Engine idling and steering wheel at straight position - Voltage between “E12-2” and vehicle body ground
E13-1	GRN	Main power supply for internal memory and P/S motor	10 – 14 V	—
E13-2	BLK	Ground for P/S control module	Below 0.3 V	—


NOTE

*: The voltage of this circuit may not be checked by voltmeter. If so, use oscilloscope.

Reference waveform No.1

Motor output signal 1(1), Motor output signal 2(2), with engine idling

Measurement terminal	CH1: “E12-1” to vehicle body ground CH2: “E12-2” to vehicle body ground
Oscilloscope setting	CH1: 5 V/DIV, CH2: 5 V/DIV TIME: 20 μs/DIV
Measurement condition	Engine is idling and steering wheel at straight position



I6RS0B630017-01


6C-34 Power Assisted Steering System:

Reference waveform No.2


Motor output signal 1(1), Motor output signal 2(2), with engine idling

Measurement terminal	CH1: "E12-1" to vehicle body ground CH1: "E12-2" to vehicle body ground
Oscilloscope setting	CH1: 5 V/DIV, CH2: 5 V/DIV TIME: 20 μs/DIV
Measurement condition	• Engine is idling and steering wheel is turned to left or right at turning speed of 90° /sec

[A]



[B]



I6RS0B630018-01


[A]:	Steering wheel is turned left at turning speed of 90° /sec
[B]:	Steering wheel is turned right at turning speed of 90° /sec
[C]:	12 V ON
[D]:	GND ON
[E]:	1 duty cycle

Reference waveform No.3


Motor output signal 1(1), Motor output signal 2(2), with engine idling

Measurement terminal	CH1: "E12-1" to vehicle body ground CH1: "E12-2" to vehicle body ground
Oscilloscope setting	CH1: 5 V/DIV, CH2: 5 V/DIV TIME: 20 μs/DIV
Measurement condition	• Engine is idling and steering wheel is kept fully turned to left or right until it stops

[A]



[B]




I6RS0B630019-01

[A]:	Steering wheel is kept fully turned left unit it stops
[B]:	Steering wheel is kept fully turned right unit it stops
[C]:	12 V ON
[D]:	GND ON

Steering Wheel Play Check

S7RW0C6304021

- Check steering wheel for looseness or rattle by moving it in its shaft direction and lateral direction. If found defective, repair or replace.
- Check steering wheel for play, holding vehicle in straight forward condition on the ground with engine stopped.
If steering wheel play is not within specification, inspect as follows and replace if found defective.
 - Tie-rod end ball stud for wear (Ball stud should move when more than 0.2 N·m (2 kg-cm, 0.44 lb-ft) torque is applied.)
 - Lower ball joint for wear
 - Steering shaft joint for wear
 - Steering pinion or rack gear for wear or breakage
 - Each part for looseness


Steering wheel play “a”**: 0 – 30 mm (0 – 1.18 in.)**

I3RM0A630021-01

Steering Force Check

S7RW0C6304022

- 1) Place vehicle on level road and set steering wheel at straight-ahead position.
- 2) Check if tire inflation pressure is as specified referring to the tire placard.
- 3) Remove driver air bag (inflator) module referring to “Driver Air Bag (Inflator) Module Removal and Installation in Section 8B”.
- 4) Start engine.
- 5) With engine idling, measure steering force by turning torque wrench.

Steering force**: Less than 6.4 N·m (0.64 kgf-m, 4.6 lb-ft)**

I3RM0A630022-01

- 6) Install driver air bag (inflator) module referring to “Driver Air Bag (Inflator) Module Removal and Installation in Section 8B”.


Repair Instructions

Steering Gear Case Assembly Components

S7RW0C6306001

NOTE

The figure shows left-hand steering vehicle. For right-hand steering vehicle the figure is symmetrical.



I7RW0C630001-01


1. Steering gear case	11. Clip	21. O-ring
2. Tie-rod lock washer	12. Steering gear case mounting bolt : Refer to "Steering Gear Case Assembly Removal and Installation".	22. Tie-rod end nut (castle nut)
3. Tie-rod	13. Steering gear case grommet	23. Cotter pin
4. Wire	14. Member bracket	(a) : 75 N·m (7.5 kgf-m, 54.5 lb-ft)
5. Boot	15. Steering rack plunger	(b) : 45 N·m (4.5 kgf-m, 32.5 lb-ft) Refer to "Tie-Rod End Removal and Installation".
6. Rack boot clip	16. Steering rack plunger spring	(c) : 70 N·m (7.0 kgf-m, 51.0 lb-ft)
7. Tie-rod end lock nut	17. Steering rack damper screw : Apply sealant 99000-31250 to all around thread part of rack damper screw.	(d) : Refer to "Steering Rack Plunger Removal and Installation".
8. Tie-rod end	18. Steering rack damper lock nut	(e) : 60 N·m (6.0 kgf-m, 43.5 lb-ft)
9. Tie-rod end nut (caulking nut)	19. Washer	(f) : 45 N·m (4.5 kgf-m, 32.5 lb-ft)

10. Boot	 20. Spring washer : Make sure of the direction of installation referring to "Steering Rack Plunger Removal and Installation".	 : Do not reuse.
----------	--	--

Tie-Rod End Boot On-Vehicle Inspection

S7RW0C6306002

Check boot for crack and damage. If any defect is found, replace it with a new one.




I3RM0A630024-01

Tie-Rod End Removal and Installation

S7RW0C6306003


Removal

- 1) Hoist vehicle, and then remove front wheel.
- 2) Remove cotter pin (castle nut type), (2) and tie-rod end nut (1) from steering knuckle.




I8RW01631002-01

- 3) Disconnect tie-rod end (1) from knuckle (2) using puller (3).



I4RS0A630040-01


- 4) For ease of adjustment after installation, make marking (1) of tie-rod end lock nut (2) position on tie-rod end thread. Then, loosen lock nut and remove tie-rod end (3) from tie-rod (4).



I4RS0A630041-01

Installation

- 1) Install tie-rod end lock nut (1) and tie-rod end (2) to tie-rod (3). Align lock nut with mark (4) on tie-rod thread.



I4RS0A630042-01

6C-38 Power Assisted Steering System:

- 2) Connect tie-rod end to knuckle. Tighten tie-rod end nut (1) to specified torque.


Tightening torque

Tie-rod end nut (a): 45 N·m (4.5 kgf-m, 32.5 lb-ft)

- 3) For castle nut type, bend new cotter pin (2).

NOTE

After tightening tie-rod end nut to specified torque, match next first slot of nut with hole of tie-rod end for insertion of cotter pin (rotation angle 60° max).




I8RW01631003-01

- 4) Set tie-rod end initial position referring to "Tie-Rod End Initial Position Setting".
- 5) Inspect for proper toe referring to "Front Wheel Alignment Inspection and Adjustment in Section 2B".
- 6) After confirming proper toe, tighten tie-rod end lock nut to specified torque.

Tightening torque

Tie-rod end lock nut (a): 45 N·m (4.5 kgf-m, 32.5 lb-ft)



I3RM0A630030-01

- 7) Tighten wheel nuts to specified torque and lower hoist.

Tightening torque

Wheel nut: 85 N·m (8.5 kgf-m, 61.5 lb-ft)

Tie-Rod End Initial Position Setting


S7RW0C6306014

Set tie-rods to following specified length "A".

Initial position of tie-rod end "A"

Driver side: Approx. 195 mm (7.68 in.)

Passenger side: Approx. 233 mm (9.17 in.)




I8RW01631005-01

Tie-Rod End Inspection

S7RW0C6306004

- Inspect for play in ball joint.
 - Inspect for play in rack end ball joint.
- In either case, if found defective, replace.




I4RS0A630043-01

Steering Shaft Joint On-Vehicle Inspection

S7RW0C6306005

Check shaft joint for wear, breakage and any other damage and replace if any defect exists.



I4RS0B630012-01

Steering Gear Case Assembly Removal and Installation


S7RW0C6306006

Removal

⚠ CAUTION

Be sure to set front wheels (tires) in straight direction and remove ignition key from key cylinder before performing the following steps, otherwise, contact coil of air bag system may get damaged.


- 1) Remove steering joint cover.
- 2) Make alignment marks (1) on pinion shaft (2) and joint of steering lower shaft (3) for a guide during reinstallation.
- 3) Loosen joint bolt (steering column side) (4) and remove joint bolt (pinion shaft side) (5) and disconnect steering lower shaft (3) from pinion shaft (2).



- 4) Disconnect torque sensor connector and P/S motor connector from steering gear case.
- 5) Remove front suspension frame with steering gear case referring to "Front Suspension Frame, Stabilizer Bar and/or Bush Removal and Installation (2WD Model) in Section 2B" or "Front Suspension Frame, Stabilizer Bar and/or Bush Removal and Installation (4WD Model) in Section 2B", and then remove steering gear case.

Installation

- 1) Install grommet (1) as shown in figure.




2. Protrusion

- 2) Install steering gear case to suspension frame (3) as follows.
 - a) Set member bracket (2) to steering gear case (1).
 - b) Install all steering gear case mounting bolts by hand.
 - c) Tighten steering mounting bolts in numerical order and specified torque.

Tightening torque

Steering gear case mounting bolt (a): 70 N·m (7.0 kgf-m, 51.0 lb-ft)




- 3) Install front suspension frame with steering gear case to vehicle referring to Steps 4) – 22) of "Front Suspension Frame, Stabilizer Bar and/or Bush Removal and Installation (2WD Model) in Section 2B" or "Front Suspension Frame, Stabilizer Bar and/or Bush Removal and Installation (4WD Model) in Section 2B", and then install steering gear case to vehicle.
- 4) Connect torque sensor connector and P/S motor connector to steering gear case.
- 5) Be sure that steering wheel and brake discs (right & left) are all straight-ahead position and then insert steering lower shaft (5) into steering pinion shaft (3) with matching marks (4).
- 6) Tighten steering shaft joint lower bolt (1) and upper bolt (2) to specified torque (tighten lower side first and then tighten upper side).

Tightening torque

Steering lower shaft assembly upper joint bolt (a): 25 N·m (2.5 kgf-m, 18.5 lb-ft)

Steering lower shaft assembly lower joint bolt (b): 25 N·m (2.5 kgf-m, 18.5 lb-ft)



- 7) Install steering joint cover.

Steering Rack Boot Inspection

S7RW0C6306007


Hoist vehicle.

Inspect each boot for tear. A torn boot allows entry of dust and water which can cause wear to steering rack and pinion to produce noise as well as rust to result in malfunction of steering system.

Even if boot tear is small, replace with new one.

Also, check each boot for dent. If there is a dent, keep boot in most compressed state for some seconds to correct dent.

Boots should be visually inspected for any damage, dent and tear during every periodical inspection at specified intervals and whenever vehicle is hoisted for any other purpose.




Tie-Rod / Rack Boot Removal and Installation


S7RW0C6306008

Removal


- 1) Remove steering gear case assembly referring to "Steering Gear Case Assembly Removal and Installation".
- 2) Remove member bracket from steering gear case assembly.
- 3) For ease of adjustment after installation, make marking (1) of tie-rod end lock nut position of tie-rod thread.



- 4) Loosen tie-rod end lock nut and remove tie-rod end.
- 5) Remove boot band (2) and clip (1).
- 6) Remove boot from tie-rod.



- 7) Unbend bent part of tie-rod lock washer (1).
- 8) Remove tie-rod (3) from rack (2).




Installation


- 1) Install tie-rod (1) and new tie-rod lock washer (3) to rack (2).
- 2) Hold rack with soft jawed vise and tighten tie-rod to specified torque.

Tightening torque

Tie-rod (a): 75 N·m (7.5 kgf-m, 54.5 lb-ft)




- 3) Bend lock washer at 2 places (1) as shown in figure.



- 4) Apply grease "A" to boot inside as shown in figure. Position boot properly in grooves of gear case (or rack side mount) and tie-rod. After this, check to ensure that boot is free from twist and dent.


"A": Grease 99000-25050 (SUZUKI Super Grease E)



- 5) Clamp boot with clip and wire. Wire should be new and should go around the boot twice. Pull its both ends together by screwdriver or such and make sure that the wire won't be crossed. Then twist the ends 4 – 5 times, the twisted ends should be bent in the circumferential direction.

NOTE

After clamping, make sure that the boot installation part is fixed.
If the boot turns easily by hand, tighten with higher torque to fix it firmly.




IYSQ01630035-01

- 6) Install tie-rod end lock nut and tie-rod end to tie-rod. Position lock nut to marking (1) made in removal.

NOTE

When tie-rod was replaced, measure length "a" on removed tie-rod and use it on new replacement tie-rod so as to position lock nut properly.




I3RM0A630052-01

- 7) Tighten tie-rod end lock nut to specified torque.

Tightening torque

Tie-rod end lock nut (a): 45 N·m (4.5 kgf-m, 32.5 lb-ft)



I8RW01631004-01


- 8) Install member bracket (1), and then install earth cable (2) as shown in figure.

Angle "a"

: Within 20°

Tightening torque

Earth cable bolt (a): 4.0 N·m (0.4 kgf-m, 2.8 lb-ft)




I6RW0C630011-01

Steering Rack Plunger Removal and Installation

S7RW0C6306009

Removal

- 1) Loosen lock nut (1) with holding damper screw (2).
- 2) Remove lock nut (1), rack damper screw (2), rack plunger spring (3), washer (5), spring washers (6), O-ring (7) and rack plunger (4).



I5RW0A630024-02

Installation

- 1) Install plunger (1), new O-ring (6), washer (4), spring washers (5) and spring (2) as shown.

NOTE


Do not wipe off grease previously applied to new plunger.

- 2) Apply sealant to rack damper screw (3) and tighten them as follows.
 - a) Tighten damper screw to 25 N·m (2.5 kgf-m, 18.0 lb-ft).
 - b) Loosen damper screw until 180°.
 - c) Retighten damper screw to 3.9 N·m (0.39 kgf-m, 3.0 lb-ft).
 - d) After tightening rack damper screw to specified torque, turn it back by 10° or less.

“A”: Water tight sealant 99000-31250 (SUZUKI Bond No.1207F)

Tightening torque

Rack damper screw (a): Tighten 25 N·m (2.5 kgf-m, 18.0 lb-ft) and loosen 180° and then tighten 3.9 N·m (0.39 kgf-m, 3.0 lb-ft) and turn it back by 10° or less by the specified procedure.




- 3) Pinion rotation torque should be checked with rack position centered.
Also, check if rack as a whole moves smoothly.

Special tool

(A): 09944-18220

Tightening torque

Rotation torque of pinion (a): 2.2 N·m (0.22 kgf-m, 1.5 lb-ft)



- 4) After adjustment, tighten lock nut to specified torque with holding damper screw at the position.

Tightening torque

Steering rack damper lock nut: 60 N·m (6.0 kgf-m, 43.5 lb-ft)


Steering Rack Plunger Inspection

S7RW0C6306010

NOTE

Do not wipe off grease applied to rack plunger which is removed.


- Inspect rack plunger (1) for wear or damage.
- Inspect rack plunger spring (2) for deterioration.
If any abnormality is found, replace.



P/S Control Module Removal and Installation

S7RW0C6306011

Removal



- 1) Disconnect negative cable at battery.
- 2) Remove console box.
- 3) Disconnect connectors (1) from P/S control module.
- 4) Remove P/S control module and bracket (2) from floor panel.
- 5) Separate P/S control module and bracket.


Installation

Reverse removal procedure.


Torque Sensor and Its Circuit Inspection

S7RW0C6306012

- 1) Check that torque sensor circuit is in good condition referring to Step 2 to 3 of "DTC C1111 / C1113 / C1115: Torque Sensor Circuit Failure". If check result is not satisfactory, repair torque sensor circuit.
- 2) Remove console box.
- 3) With ignition switch turned OFF, connect scan tool to DLC or connect voltage tester between "E11-18" – "E11-9" (main sensor) or "E11-10" – "E11-9" (sub sensor) with connected connector to P/S control module.





- 4) Set torque wrench to steering wheel referring to "Steering Force Check" for checking steering force.



I3RM0A630022-01

- 5) Turn ON ignition switch without engine running and select scan tool "Data List" mode due to checking "Sensor (Main) Torque" and "Sensor (Sub) Torque" displayed on scan tool when steering wheel turned left and right (if used).
- 6) Check that characteristic of torque sensor (main and sub) output voltage or scan tool data and steering force is as following graph when steering wheel is turned left and right. If sensor voltage or scan tool data is out of specified value or does not vary linearly as the following graph, check EPS control module and its circuit referring to "Inspection of P/S Control Module and Its Circuits". If they are OK, replace steering gear case assembly.



[A]:	Main sensor
[B]:	Sub sensor
[C]:	Steering force at left turn
[D]:	Steering force at right turn
[E]:	Steering wheel at free
[F]:	"Sensor (Main) Torque" in "Data List" displayed on scan tool
[G]:	"Sensor (Sub) Torque" in "Data List" displayed on scan tool

P/S Motor and Its Circuit Inspection

S7RW0C6306013

- 1) Check motor circuit referring to Step 2 to 3 of “DTC C1141 / C1142 / C1143 / C1145: Motor Circuit Failure”. If check result is not satisfactory, repair motor circuit.
- 2) Disconnect motor connector from steering gear case assembly with ignition switch turned OFF.
- 3) Check for resistance between terminals of motor connector.
If check result is not as specified, check P/S motor harness for continuity. If it is OK, replace steering gear case assembly.


Motor circuit resistance

“E12-1” and “E12-2” (For motor)	Approx. 1 Ω
---------------------------------	-------------

- 4) Check for insulation between each terminal of motor connector and body ground.
If check result is not as specified, check P/S motor harness for insulation. If it is OK, replace steering gear case assembly.

Motor circuit resistance

Each terminal and body ground	No continuity
-------------------------------	---------------



I6RW0C630012-00

[A]: Motor connector “E12” (viewed from harness side)

- 5) Hoist vehicle
- 6) Check that steering wheel turns to left and right smoothly. If steering wheel does not turn smoothly, inspect and repair defective steering and suspension parts.
- 7) Connect “E12” connector with ignition switch turned OFF.



- 8) Using ammeter (2), check that P/S motor current (1) is as following table with idling engine. If check result is not satisfactory, check P/S control module for torque sensor signal and P/S motor output referring to “Inspection of P/S Control Module and Its Circuits”. If they are OK, replace steering gear case assembly.

NOTE

When P/S motor is cold condition (that is, armature coil of P/S motor is not heated), motor current in the following table can be measured

Motor current at hoisted vehicle (reference value)

Condition	When steering wheel is left at straight position: [A]	When steering wheel is turned left or right by turning speed with 90° /sec: [B]	When steering wheel is kept fully turned left or right until it stops.: [C]
Motor current	Approx. 0 A	Approx. 0 – 5 A	Approx. 45 – 60 A



I7RW01632012-01

3. P/S control module

Specifications

Tightening Torque Specifications

S7RW0C6307001

Fastening part	Tightening torque			Note
	N·m	kgf·m	lb·ft	
Tie-rod end nut	45	4.5	32.5	🔩
Tie-rod end lock nut	45	4.5	32.5	🔩 / 🔩
Wheel nut	85	8.5	61.5	🔩
Steering gear case mounting bolt	70	7.0	51.0	🔩
Steering lower shaft assembly upper joint bolt	25	2.5	18.5	🔩
Steering lower shaft assembly lower joint bolt	25	2.5	18.5	🔩
Tie-rod	75	7.5	54.5	🔩
Earth cable bolt	4.0	0.4	2.8	🔩
Rack damper screw	Tighten 25 N·m (2.5 kgf·m, 18.0 lb·ft) and loosen 180° and then tighten 3.9 N·m (0.39 kgf·m, 3.0 lb·ft) and turn it back by 10° or less by the specified procedure.			🔩
Rotation torque of pinion	2.2	0.22	1.5	🔩
Steering rack damper lock nut	60	6.0	43.5	🔩

NOTE

The specified tightening torque is also described in the following.
 “Steering Gear Case Assembly Components”

Reference:

For the tightening torque of fastener not specified in this section, refer to “Fasteners Information in Section 0A”.

Special Tools and Equipment

Recommended Service Material

S7RW0C6308001


Material	SUZUKI recommended product or Specification		Note
Grease	SUZUKI Super Grease E	P/No.: 99000–25050	🔩
Water tight sealant	SUZUKI Bond No.1207F	P/No.: 99000–31250	🔩

NOTE

Required service material is also described in the following.
 “Steering Gear Case Assembly Components”

Special Tool

S7RW0C6308002

09944–18220 Pinion torque checking socket 	SUZUKI scan tool  This kit includes following items. 1. Tech 2, 2. PCMCIA card, 3. DLC cable, 4. SAE 16/19 adapter, 5. Cigarette cable, 6. DLC loop back adapter, 7. Battery power cable, 8. RS232 cable, 9. RS232 adapter, 10. RS232 loop back connector, 11. Storage case, 12. 🔩 / 🔩
--	---

Section 7

HVAC

CONTENTS

Precautions	7-1	A/C System Caution.....	7B-1
Precautions.....	7-1	Precautions on Servicing A/C System	7B-1
Precautions on HVAC	7-1	General Description	7B-2
Heater and Ventilation.....	7A-1	Sub-Cool A/C System Description	7B-2
General Description	7A-1	A/C Operation Description at ECM	7B-3
Heater and Ventilation Construction	7A-1	Schematic and Routing Diagram	7B-3
Schematic and Routing Diagram.....	7A-3	Manual A/C Electronic Input Output Diagram	7B-3
Heater and Ventilation Wiring Circuit Diagram	7A-3	A/C System Air Flow Diagram.....	7B-4
Component Location	7A-3	A/C System Wiring Diagram	7B-5
Electronic Control System Components		Component Location	7B-6
Location	7A-3	A/C System Major Components Location	7B-6
Diagnostic Information and Procedures.....	7A-4	Electronic Control System Components	
Heater and Ventilation Symptom Diagnosis.....	7A-4	Location.....	7B-7
Repair Instructions	7A-5	Diagnostic Information and Procedures.....	7B-8
HVAC Unit Components	7A-5	A/C System Performance Inspection	7B-8
HVAC Unit Removal and Installation (Non-A/C)		Trouble Diagnosis for Abnormal Pressure	7B-11
C)	7A-5	A/C System Inspection at ECM.....	7B-12
Blower Motor Removal and Installation.....	7A-5	A/C System Symptom Diagnosis	7B-13
Blower Motor Inspection	7A-5	Abnormal Noise Symptom Diagnosis of A/C	
Blower Motor Resistor Removal and		System	7B-15
Installation	7A-6	Repair Instructions	7B-17
Blower Motor Resistor Inspection	7A-6	Operation Procedure for Refrigerant Charge	7B-17
Blower Motor Relay Inspection	7A-7	Condenser Cooling Fan Removal and	
HVAC Control Unit Components.....	7A-7	Installation.....	7B-22
HVAC Control Unit Removal and Installation.....	7A-8	Condenser Cooling Fan Inspection.....	7B-23
Blower Speed Selector Inspection	7A-10	Condenser Assembly On-Vehicle Inspection....	7B-23
Air Intake Selector Inspection	7A-10	Condenser Assembly Removal and	
Air Intake Control Actuator Removal and		Installation.....	7B-23
Installation	7A-10	Desiccant Removal and Installation	7B-24
Air Intake Control Actuator Inspection	7A-11	HVAC Unit Components	7B-25
Center Ventilation Louver Removal and		HVAC Unit Removal and Installation	7B-26
Installation	7A-12	Evaporator Inspection	7B-27
Side Ventilation Louver Removal and		Evaporator Temperature Sensor Removal	
Installation	7A-12	and Installation	7B-27
Rear Duct Removal and Installation (If		Evaporator Temperature Sensor Inspection	7B-28
Equipped).....	7A-13	Expansion Valve Removal and Installation	7B-28
HVAC Air Filter Removal and Installation (If		Expansion Valve Inspection	7B-28
Equipped).....	7A-13	A/C Refrigerant Pressure Sensor and Its	
HVAC Air Filter Inspection (If Equipped).....	7A-13	Circuit Inspection.....	7B-29
Air Conditioning System.....	7B-1	A/C Refrigerant Pressure Sensor Removal	
Manual Type	7B-1	and Installation	7B-29
Precautions.....	7B-1	A/C Switch Inspection	7B-29
		A/C System Relay Inspection.....	7B-30
		Compressor Drive Belt Inspection and	
		Adjustment	7B-30

Compressor Drive Belt Removal and Installation	7B-30	DTC B1513: Temperature Control Actuator (Motor) and/or Its Circuit Malfunction	7B-63
Compressor Assembly Removal and Installation	7B-30	DTC B1514: Air Flow Control Actuator (Motor) and/or Its Circuit Malfunction	7B-65
Compressor Assembly Components	7B-31	DTC B1520 / B1521 / B1522: Temperature / Blower Speed / Air Flow Selector Malfunction	7B-66
Magnet Clutch Inspection	7B-32	DTC B1541: Back-Up Power Supply Circuit Malfunction	7B-67
Magnet Clutch Removal and Installation	7B-32	DTC B1546: A/C Refrigerant Pressure Malfunction	7B-68
Thermal Switch Inspection	7B-34	DTC B1551: Serial Communication Circuit Malfunction	7B-68
Thermal Switch Removal and Installation	7B-34	DTC B1552: HVAC Control Module Check Sum Error	7B-70
Relief Valve Inspection	7B-34	DTC B1553: CAN Communication Circuit Malfunction	7B-70
Relief valve Removal and Installation	7B-35	DTC B1557: VSS Signal Failure	7B-71
Specifications	7B-35	DTC B1561: ECT Signal Failure	7B-71
Tightening Torque Specifications	7B-35	DTC B1562: Outside Air Temperature Signal Failure	7B-72
Special Tools and Equipment	7B-36	DTC B1563: A/C Refrigerant Pressure Signal Failure	7B-72
Recommended Service Material	7B-36	DTC B1570: Engine Type Signal Failure	7B-73
Special Tool	7B-36	DTC B1571: Combination Meter Spec Signal Failure	7B-73
Automatic Type	7B-37	Inspection of HVAC Control Module and Its Circuit	7B-74
Precautions	7B-37	A/C System Inspection at ECM	7B-77
A/C System Caution	7B-37	Repair Instructions	7B-78
Precautions in Diagnosing Trouble	7B-37	Operation Procedure for Refrigerant Charge	7B-78
Precautions on Servicing A/C System	7B-37	HVAC Unit Components	7B-78
General Description	7B-37	HVAC Unit Removal and Installation	7B-79
Auto A/C System Description	7B-37	Temperature Control Actuator Removal and Installation	7B-79
HVAC Control Description	7B-38	Temperature Control Actuator and Its Circuit Inspection	7B-79
Sub-Cool A/C System Description	7B-38	Air Flow Control Actuator Removal and Installation	7B-81
On-Board Diagnostic System Description	7B-38	Air Flow Control Actuator and Its Circuit Inspection	7B-81
Schematic and Routing Diagram	7B-39	Air Intake Actuator Removal and Installation	7B-82
Auto A/C Electronic Control Input / Output Diagram	7B-39	Air Intake Actuator Inspection	7B-82
A/C System Air Flow Diagram	7B-39	Actuator Linkage Inspection	7B-82
A/C System Wiring Diagram	7B-40	Blower Motor Controller Removal and Installation	7B-82
Component Location	7B-42	Blower Motor Controller Inspection	7B-83
A/C System Major Components Location	7B-42	HVAC Control Module Removal and Installation	7B-83
Electronic Control System Components Location	7B-42	Sunload Sensor Removal and Installation	7B-83
Diagnostic Information and Procedures	7B-43	Sunload Sensor Inspection	7B-84
Air Conditioning System Check	7B-43	Outside Air Temperature Sensor Removal and Installation	7B-84
A/C System Symptom Diagnosis	7B-45	Outside Air Temperature Sensor Inspection	7B-84
Abnormal Noise Symptom Diagnosis of A/C System	7B-47	Inside Air Temperature Sensor Removal and Installation	7B-84
DTC Check	7B-47	Inside Air Temperature Sensor Inspection	7B-84
DTC Clearance	7B-49	Condenser Cooling Fan Relay Inspection	7B-85
DTC Table	7B-49	Condenser Cooling Fan Removal and Installation	7B-85
Fail-Safe Table	7B-52		
Scan Tool Data	7B-53		
Visual Inspection	7B-55		
DTC B1502: Inside Air Temperature Sensor Circuit Malfunction	7B-55		
DTC B1503: Evaporator Temperature Sensor Circuit Malfunction	7B-57		
DTC B1504: Sunload Sensor Circuit Malfunction	7B-58		
DTC B1511: Temperature Control Actuator (Position Sensor) and/or Its Circuit Malfunction	7B-59		
DTC B1512: Air flow Control Actuator (Position Sensor) and/or Its Circuit Malfunction	7B-61		

Condenser Cooling Fan Inspection.....	7B-85	Compressor Drive Belt Inspection and	
Condenser Assembly On-Vehicle Inspection....	7B-85	Adjustment	7B-85
Condenser Assembly Removal and		Compressor Drive Belt Removal and	
Installation	7B-85	Installation	7B-85
Evaporator Inspection	7B-85	Compressor Assembly Removal and	
Evaporator Temperature Sensor Removal		Installation	7B-85
and Installation	7B-85	Compressor Assembly Components.....	7B-85
Evaporator Temperature Sensor Inspection	7B-85	Magnet Clutch Removal and Installation.....	7B-85
Expansion Valve Removal and Installation	7B-85	Magnet Clutch Inspection.....	7B-85
Expansion Valve Inspection	7B-85	Thermal Switch Inspection	7B-85
A/C Refrigerant Pressure Sensor and Its		Thermal Switch Removal and Installation	7B-85
Circuit Inspection	7B-85	Relief Valve Inspection.....	7B-85
A/C Refrigerant Pressure Sensor Removal		Special Tools and Equipment	7B-86
and Installation	7B-85	Recommended Service Material	7B-86
Compressor Relay Inspection	7B-85	Special Tool	7B-86

Precautions

Precautions

Precautions on HVAC

S7RW0C7000001

Air Bag Warning

Refer to “Air Bag Warning in Section 00”.

A/C System Caution

Refer to “A/C System Caution: Manual Type in Section 7B” or “A/C System Caution: Automatic Type in Section 7B”.

Precautions on Servicing A/C System

Refer to “Precautions on Servicing A/C System: Manual Type in Section 7B” or “Precautions on Servicing A/C System: Automatic Type in Section 7B”.

Precaution in Diagnosing Trouble (Automatic Type)

Refer to “Precautions in Diagnosing Trouble: Automatic Type in Section 7B”.

Heater and Ventilation


General Description

Heater and Ventilation Construction

S7RW0C7101001


NOTE

The figure shows left-hand steering vehicle. For right-hand steering vehicle, parts with (*) are installed at the opposite side.



I6RW0C710001-02

7A-2 Heater and Ventilation:



I6RW0C710011-01


A: Air flow	7. Defroster air	15. Rear duct (if equipped)
B: Water flow	8. Demister air	16. Foot duct
1. HVAC unit	9. Fresh air	17. Engine
2. Ventilator duct	10. Recirculation air	18. Radiator
3. Defroster duct and demister duct	11. Center ventilation air	19. Reservoir
4. Heater core	12. Air intake door	20. Temperature control door
5. Side ventilation air	13. Blower motor	21. Air flow control door
6. Foot air	14. Resistance board (non-A/C) or evaporator (A/C)	

Schematic and Routing Diagram

Heater and Ventilation Wiring Circuit Diagram

S7RW0C7102001

Non-A/C



I8RW01710001-01

[A]: Hatchback model	4. Lighting switch	10. Air intake control actuator	16. "REC" indicator light
[B]: Sedan model	5. Blower motor relay	11. To BCM	17. Rear defogger indicator
[C]: Illumination control model	6. Blower motor resistor	12. Main fuse box	18. Illumination light
1. Ignition switch	7. Junction block assembly	13. Blower speed selector	19. Rear defogger relay
2. Blower motor	8. BCM	14. Air intake selector	20. Rear defogger
3. HVAC control unit	9. ECM	15. Rear defogger switch	21. Tail light

Manual A/C

Refer to "A/C System Wiring Diagram: Manual Type in Section 7B".

Auto A/C

Refer to "A/C System Wiring Diagram: Automatic Type in Section 7B".

Component Location

Electronic Control System Components Location

S7RW0C7103001

Refer to "Electronic Control System Components Location: Manual Type in Section 7B" (non-A/C and manual A/C) or "Electronic Control System Components Location: Automatic Type in Section 7B" (auto A/C).

Diagnostic Information and Procedures

Heater and Ventilation Symptom Diagnosis

S7RW0C7104001

Condition	Possible cause	Correction / Reference Item
Blower motor does not operate with blower speed selector ON	Fuse blown	Check related fuses, and then check for short circuit to ground.
	Blower motor relay faulty	Check blower motor relay referring to "Blower Motor Relay Inspection".
	Blower motor resistor faulty	Check blower motor resistor referring to "Blower Motor Resistor Inspection".
	Blower speed selector faulty	Check blower speed selector referring to "Blower Speed Selector Inspection".
	Blower motor faulty	Check blower motor referring to "Blower Motor Inspection".
	Wiring or grounding faulty	Repair as necessary.
Incorrect temperature output	Temperature control cable broken or bent (non-A/C and manual A/C)	Check temperature control cable.
	Temperature selector faulty (non-A/C and manual A/C)	Check temperature selector.
	Incorrect installation of temperature control cable (non-A/C and manual A/C)	Check position and adjust it as necessary.
	Temperature control door assembly broken	Repair temperature control door assembly.
	Air ducts clogged	Repair air ducts.
	Heater core leaked or clogged	Replace heater core.
	Heater hoses leaked or clogged	Replace heater hoses.
	Thermostat faulty	Check thermostat referring to "Thermostat Inspection in Section 1F".
	Temperature control actuator faulty (auto A/C)	Check temperature control actuator referring to "Temperature Control Actuator and Its Circuit Inspection: Automatic Type in Section 7B".
	HVAC control module faulty (auto A/C)	Check HVAC control module referring to "Inspection of HVAC Control Module and Its Circuit: Automatic Type in Section 7B".
	Wiring or grounding faulty (auto A/C)	Repair as necessary.
Air outlet port does not change or does not agree with air flow selector's position even if air flow selector is changed	Air flow control cable broken or bent (non-A/C and manual A/C)	Check air flow control cable.
	Air flow selector faulty (non-A/C and manual A/C)	Check air flow selector.
	Incorrect installation of air flow control cable (non-A/C and manual A/C)	Check position and adjust it as necessary.
	Air flow control door assembly broken	Repair air flow control door assembly.
	Air ducts leaked or clogged	Repair air ducts.
	Air flow control actuator faulty (auto A/C)	Check air flow control actuator referring to "Air Flow Control Actuator and Its Circuit Inspection: Automatic Type in Section 7B".
	HVAC control module faulty (auto A/C)	Check HVAC control module referring to "Inspection of HVAC Control Module and Its Circuit: Automatic Type in Section 7B".
	Wiring or grounding faulty (auto A/C)	Repair as necessary.
Air intake door does not change even if air intake mode is changed	Air intake door broken	Repair air intake door.
	Air intake control actuator faulty	Check air intake control actuator referring to "Air Intake Control Actuator Inspection".
	Air intake selector faulty	Check air intake selector referring to "Air Intake Selector Inspection".
	Wiring or grounding faulty	Repair as necessary.

Repair Instructions

HVAC Unit Components

S7RW0C7106001

For non-A/C and manual A/C, refer to "HVAC Unit Components: Manual Type in Section 7B".

For auto A/C, refer to "HVAC Unit Components: Automatic Type in Section 7B".


HVAC Unit Removal and Installation (Non-A/C)

S7RW0C7106002

For manual A/C and auto A/C, refer to "HVAC Unit Removal and Installation: Manual Type in Section 7B".

Removal

- 1) Drain engine coolant referring to "Cooling System Draining in Section 1F", and then disconnect heater hoses from HVAC unit.
- 2) Remove cowl top cover from vehicle body referring to "Radiator Grille Removal and Installation in Section 9K".
- 3) Remove instrument panel from vehicle body referring to "Instrument Panel Removal and Installation in Section 9C".
- 4) Remove HVAC unit (1) from vehicle body by removing nuts (2).



I7RW01710003-01

Installation

Reverse removal procedure noting the following instructions.


- Be careful not to catch any cable and wiring harness in inappropriate position.
- Adjust control cables of HVAC control unit referring to "HVAC Control Unit Removal and Installation".
- Refill cooling system with coolant referring to "Cooling System Flush and Refill in Section 1F".

Blower Motor Removal and Installation

S7RW0C7106003

Removal

- 1) Disconnect negative (–) cable from battery.
- 2) Disconnect connector (1) from blower motor (2).
- 3) Remove blower motor (2) from HVAC unit as follows.
 - a) Remove screws (4).
 - b) Release tub (3) to arrow direction.
 - c) Hold Step b) and turn blower motor (2) to arrow direction.



I7RW01710004-02


Installation

Reverse removal procedure.

Blower Motor Inspection

S7RW0C7106004

- Check blower motor for resistance between two terminals as shown. If there is no continuity, replace blower motor.




I7RW01710005-01

7A-6 Heater and Ventilation:

- Check for operation and current.
 - a. Put blower motor (1) in a soft-jawed vise.
 - b. Connect battery to blower motor as shown.
 - c. Check if blower motor operates smoothly without noise.
 - d. Check if ammeter indicates the specified current. If measured current is out of specification, replace blower motor.

Blower motor specified current at 12 V
18.5 A maximum at 20 – 25 °C (68 – 77 °F)




Blower Motor Resistor Removal and Installation


S7RW0C7106005

Removal

- 1) Disconnect negative (–) cable from battery.
- 2) Remove glove box from instrument panel.
- 3) Remove passenger side foot duct (1) from HVAC unit by removing screw (2).



- 4) Disconnect connector (1) from blower motor resistor (2), and then remove blower motor resistor from HVAC unit by removing screws (3).



Installation

Reverse removal procedure.

Blower Motor Resistor Inspection

S7RW0C7106006



Measure each terminal-to-terminal resistance. If measured resistance is out of specification, replace blower motor resistor.

Blower motor resistor resistance

“H” – “MH”: Approx. 0.43 Ω at 20 – 25 °C (68 – 77 °F)

“MH” – “ML”: Approx. 0.6 Ω at 20 – 25 °C (68 – 77 °F)


“ML” – “L”: Approx. 2.0 Ω at 20 – 25 °C (68 – 77 °F)



Blower Motor Relay Inspection

S7RW0C7106007


- 1) Disconnect negative (–) cable at battery.
 - 2) Disable air bag system referring to “Disabling Air Bag System in Section 8B”.
 - 3) Remove junction block assembly (2).
 - 4) Disconnect blower motor relay (1) from junction block assembly (2).
 - 5) Check that there is no continuity between terminal “C” and “D”. If there is continuity, replace relay.
 - 6) Connect battery positive (+) terminal to terminal “B” of relay. Connect battery negative (–) terminal “A” of relay.
- Check continuity between terminal “C” and “D”. If there is no continuity when relay is connected to the battery, replace relay.



I4RS0B710008-01

HVAC Control Unit Components

S7RW0C7106008



I5RW0A710005-01


1. Heater control body assembly	4. Bulb	7. Air intake selector	10. Rear defogger switch
2. Air flow selector	5. Temperature control cable	8. Temperature selector	
3. Blower speed selector	6. Air flow control cable	9. A/C switch (if equipped)	

HVAC Control Unit Removal and Installation

S7RW0C7106009

Removal


- 1) Disconnect negative (–) cable at battery.
- 2) Remove steering column hole cover from instrument panel.
- 3) Remove audio unit from instrument panel referring to “Audio Unit Removal and Installation (If Equipped) in Section 9C”.
- 4) Remove driver side foot duct (1) from HVAC unit by removing screw (2).



I7RW01710010-01


- 5) Disconnect temperature control cable (1) and air flow control cable (2) from HVAC unit (3).

LH steering vehicle



I7RW01710012-02

RH steering vehicle



I6RW0C710005-01


F: Vehicle forward

- 6) Remove center garnish from instrument panel.
- 7) Remove HVAC control unit from instrument panel.
- 8) Disconnect connectors from HVAC control unit.

Installation


Reverse removal procedure noting the following instructions.

- Connect temperature control cable and air flow control cable of HVAC control unit to links of HVAC unit.
 - a. For LH steering vehicle, set airflow selector (1) to “DEF” position and temperature selector (2) to “MAX HOT” position.



I4RS0B710013-01


For RH steering vehicle, set airflow selector (1) to “VENT” position and temperature selector (2) to “MAX COOL” position.



I4RS0A710016-01


- b. Move temperature control lever (1) to "MAX HOT" position "a" (LH steering vehicle) or "MAX COOL" position "b" (RH steering vehicle), then fix temperature control inner cable (2) to pin of temperature control lever and fix outer cable (3) to cable lock clamp (4).

LH steering vehicle



I7RW01710013-02

RH steering vehicle




I6RW0C710007-01

F: Vehicle forward


- c. Move air flow control plate (1) to "DEF" position "c" (LH steering vehicle) or "VENT" position "d" (RH steering vehicle), then fix air flow control inner cable (2) to pin of air flow control plate and fix outer cable (3) to cable lock clamp (4).

LH steering vehicle



I7RW01710014-02

RH steering vehicle



I6RW0C710008-01

F: Vehicle forward

NOTE


After installing control cables, make sure that control lever and plate move smoothly and stop at proper position.

- Make sure that air flow outlet changes correctly as air flow selector is changed.

Blower Speed Selector Inspection

S7RW0C7106010

Check blower speed selector for each terminal to terminal continuity. If check result does not meet the following conditions, replace HVAC control unit.



Terminal Position	GND	I	L	ML	MH	H
OFF	○					
1	○	○	○			
2	○	○		○		
3	○	○			○	
4	○	○				○



I4RS0A710019-01

Air Intake Selector Inspection

S7RW0C7106011

- Check that there is continuity between terminal (1) and terminal (2) when air intake selector is at “FRE” position.
- Check that there is no continuity between terminal (1) and terminal (2) when air intake selector is at “REC” position.

If check result does not meet the above conditions, replace HVAC control unit.




I5RW0A710007-01

Air Intake Control Actuator Removal and Installation

S7RW0C7106012


Removal

- 1) Disconnect negative cable from battery.
- 2) Remove glove box from instrument panel.
- 3) Remove passenger side foot duct (1) from HVAC unit by removing screw (2). (LH steering vehicle only.)



I7RW01710007-01

- 4) Disconnect connector (1) from air intake control actuator (2).
- 5) Detach linkage rod (3) and remove air intake control actuator (2) by removing screws (4).




I7RW01710016-02

Installation

Reverse removal procedure noting the following instruction.

- Be sure to insert the linkage rod (1) into the hole (2) of air intake control actuator.



I7RW01710017-02



Air Intake Control Actuator Inspection

S7RW0C7106013

Check air intake control actuator as follows:

- 1) Using service wire, connect battery positive terminal to "d" terminal and battery negative terminal to terminal "a". And, check if air intake selector link operates smoothly and it stops at "FRE" position (1).
- 2) Using service wire, connect battery positive terminal to "d" terminal and battery negative terminal to terminal "c". And, check if air intake selector link operates smoothly and it stops at "REC" position (2).
- 3) For auto A/C model, using service wire, connect battery positive terminal to "d" terminal and battery negative terminal to "b" terminal. And, check air intake selector link operates smoothly and it stops at MIX position (3).

If malfunction is found, replace air intake control actuator.



4. Motor rotation direction

I7RW01710018-05

Center Ventilation Louver Removal and Installation

S7RW0C7106014


Removal

- 1) Disconnect negative (–) cable from battery.
- 2) Remove audio unit from instrument panel referring to “Audio Unit Removal and Installation (If Equipped) in Section 9C”.
- 3) Remove center ventilation louver (1) with garnish (2) from instrument panel, and then disconnect connector from hazard switch.

NOTE

Garnish is fitted to instrument panel with six clips. When removing garnish from instrument panel, be careful not to break them.

- 4) Separate center ventilation louver and garnish.



I5RW0A710008-01

Installation


Reverse removal procedure.

Side Ventilation Louver Removal and Installation

S7RW0C7106015


Removal

- 1) Remove instrument panel from vehicle body referring to “Instrument Panel Removal and Installation in Section 9C”
- 2) Remove steering support member (1), defroster nozzle (2) and ventilator duct (3) from instrument panel.



I5RW0A710009-01

- 3) Remove side ventilation louver (1) from instrument panel while pressing clips (2).




I5RW0A710010-01

Installation

Reverse removal procedure noting the following instruction.


- Side ventilation louver is fitted to instrument panel with four clips (1). When installing side ventilation louver to instrument panel, position the smallest clip to the top.



I5RW0A710011-01

Rear Duct Removal and Installation (If Equipped)

S7RW0C7106016



I7RW01710019-01

1. Center rear duct	4. Clip
2. Right rear duct	5. HVAC unit
3. Left rear duct	

Removal

- 1) Disconnect negative (–) cable at battery.
- 2) Remove front seats referring to “Front Seat Removal and Installation in Section 9G”.
- 3) Remove console box referring to “Console Box Components in Section 9H”.
- 4) Take off carpet till rear ducts is totally exposed.
- 5) Remove right and left rear ducts.
- 6) Remove center rear duct as follows, if necessary.
 - a) Remove HVAC control unit referring to “HVAC Control Unit Removal and Installation” (non-A/C or manual A/C) or “HVAC Control Module Removal and Installation: Automatic Type in Section 7B” (auto A/C).
 - b) Remove center rear duct from HVAC unit.

Installation

Reverse removal procedure noting the following instructions.


- Install HVAC control unit referring to “HVAC Control Unit Removal and Installation” (non-A/C or manual A/C) or “HVAC Control Module Removal and Installation: Automatic Type in Section 7B” (auto A/C), if removed.
- Install console box referring to “Console Box Components in Section 9H”.
- Install front seats referring to “Front Seat Removal and Installation in Section 9G”.

HVAC Air Filter Removal and Installation (If Equipped)

S7RW0C7106017

Removal

- 1) Remove glove box from instrument panel.
- 2) Remove air filter (1) from HVAC unit while releasing claws (2).




I6RW0C710010-01

Installation

Reverse removal procedure noting the following instructions.

- Position air filter by directing its arrow mark to the upward.




I6RW0C710009-01

HVAC Air Filter Inspection (If Equipped)

S7RW0C7106018

Reference: “HVAC Air Filter Removal and Installation (If Equipped)”

Check that filter is not excessively dirty, damage or oily, clean filter with compressed air from air outlet side of filter. If abnormality is found, replace filter with new one.



I4RS0A710032-01

Air Conditioning System

Manual Type

Precautions

A/C System Caution

S7RW0C7210001

⚠ CAUTION

The A/C system of this vehicle uses HFC-134a (R-134a) refrigerant, specified compressor oil and specified parts.

Do not use CFC-12 (R-12) refrigerant, R-12 exclusive use compressor oil and R-12 exclusive parts in this A/C system, do not attempt to use R-12 servicing equipment. Otherwise, use of it will result in leakage of refrigerant, damage or other faulty condition of A/C system and damage or other faulty condition of servicing equipment.

When replenishing or changing refrigerant and compressor oil and when replacing parts, make sure that the material or the part to be used is appropriate to the A/C installed in the vehicle being serviced. Use of incorrect one will result in leakage of refrigerant, damage in parts or other faulty condition.

Precautions on Servicing A/C System

S7RW0C7210002

⚠ WARNING

Should refrigerant HFC-134a (R-134a) be exposed to your eye(s), consult a doctor immediately.

- Do not reuse your hand to rub affected eye(s). Instead, use fresh cold water to splash it over affected area to thus gradually raise its temperature above the freezing point.
 - Obtain proper treatment as soon as possible from a doctor or eye specialist. Should liquid refrigerant HFC-134a (R-134a) be exposed to your skin, such affected part should be treated in the same manner as when skin is frostbitten or frozen.
-

Handling Refrigerant HFC-134a (R-134a)

- Always wear goggles to protect your eyes.
- Avoid direct contact to liquid refrigerant.
- Do not heat refrigerant container higher than 40 °C (104 °F).
- Do not discharge refrigerant into atmosphere.
- Do not expose bright metals to liquid refrigerant. Refrigerant combined with moisture is corrosive and tarnishes surfaces of bright metals including chrome.
- Never use heat for bending pipes. When bending a pipe, try to make its bending angle as smooth as possible.
- Keep internal parts of air conditioning free from moisture and dirt. When disconnecting any line from system, install a blind plug or cap to the fitting immediately.
- When handling recovery and recycling equipment, be sure to follow the instruction manual for the equipment.
- Check local governmental regulations regarding working with refrigerator systems and its tooling.
- When connecting hoses and pipes, apply a few drops of compressor oil (refrigerant oil) to O-ring.
- Replace O-ring with new one once hoses, pipes and parts disconnected.
- When tightening or loosening a fitting, use two wrenches, one for turning and the other for support.
- Route drain hose so that drained water does not make any contact to vehicle components.
- If pipes or hoses are replaced, replenish specified amount of compressor oil to compressor suction side referring to "Replenishing Compressor Oil" in "Operation Procedure for Refrigerant Charge: Manual Type".

Refrigerant Recovery

When discharging refrigerant out of A/C system, always recover it by using refrigerant recovery and recycling equipment because discharging refrigerant HFC-134a (R-134a) into atmosphere would cause adverse effect to environments referring to “Recovery” in “Operation Procedure for Refrigerant Charge: Manual Type”.

Refrigerant Charge


After performing compressor oil replenishment and evacuation, charge a proper amount of refrigerant to A/C system referring to “Charge” in “Operation Procedure for Refrigerant Charge: Manual Type”.

General Description

Sub-Cool A/C System Description

S7RW0C7211001

In the sub-cool A/C system (condenser integrated with receiver / dryer), the inside of the condenser is divided into the condensation part and the sub-cooler part, and the receiver / dryer is located between those. In the receiver / dryer, the refrigerant is separated into the vapor refrigerant and the liquid refrigerant. Only the liquid refrigerant is delivered to the sub-cooler part of the condenser. The refrigerant is supercooled by the sub-cooler part of the condenser. The refrigerant is supercooled by the sub-cooler part of the condenser.



I5RW0A721003-02

[A]: Liquid	2. Magnet clutch	6. Expansion valve	10. Desiccant
[B]: Vapor	3. Condenser	7. A/C evaporator	11. Filter
[C]: Superheated vapor	4. Receiver/dryer	8. Condensation part	12. Vapor refrigerant
1. Compressor	5. Refrigerant pressure sensor	9. Sub-cooler part	13. Liquid refrigerant

A/C Operation Description at ECM

S7RW0C7211002

ECM controls the A/C compressor relay and condenser cooling fan relay according to signals from HVAC control unit, A/C refrigerant pressure sensor, ECT sensor and evaporator temperature sensor. The A/C switch ON signal from HVAC control unit is transmitted to ECM through BCM. For CAN communication system, refer to "CAN Communication System Description in Section 1A".

ECM turns ON the A/C compressor relay when the vehicle state satisfy conditions described below.


- A/C switch ON signal is inputted from HVAC control unit
- A/C refrigerant pressure is within specified range
- Evaporator temperature is within specified range
- Engine speed is within specified range
- Engine coolant temperature is lower than specified value
- Throttle opening is lower than specified value
- Vehicle is not in either state of starting or quick acceleration
- ECT sensor malfunction is not detected
- A/C refrigerant pressure sensor malfunction is not detected

Condenser Cooling Fan Relay Control

ECM turn ON the condenser cooling fan relay at the same time when ECM turn ON the A/C compressor relay.

Schematic and Routing Diagram**Manual A/C Electronic Input Output Diagram**


S7RW0C7212001



I6RW0C721001-01

A/C System Air Flow Diagram

S7RW0C7212002




I7RW01721002-03

A: Air flow	5. Discharge hose	11. Foot air	17. Air intake door
B: Refrigerant flow	6. Suction hose	12. Front defroster air	18. Temperature control door
1. HVAC unit	7. Liquid pipe	13. Side defroster air	19. Air flow control door
2. Compressor	8. Expansion valve	14. Fresh air	20. Heater core
3. Condenser assembly	9. Side ventilation air	15. Recirculation air	
4. Receiver/dryer	10. Center ventilation air	16. Evaporator	

A/C System Wiring Diagram

S7RW0C7212003




I7RW0A721001-01

[A]: Hatchback model	8. BCM	18. Condenser cooling fan relay	27. Illumination light
[B]: Sedan model	9. A/C refrigerant pressure sensor	19. Condenser cooling fan motor	28. Rear defogger relay
[C]: Illumination control model	10. ECM	20. Blower speed selector	29. Rear defogger
1. Ignition switch	11. Air intake control actuator	21. A/C switch	30. Main relay
2. Blower motor	12. Compressor relay	22. Air intake selector	31. Tail light
3. HVAC control unit	13. Compressor	23. Rear defogger switch	32. TCM
4. Lighting switch	14. Evaporator temperature sensor	24. "A/C" indicator light	33. To other control module and DLC
5. Blower motor relay	15. ECT sensor	25. "REC" indicator light	34. ABS control module
6. Blower motor resistor	16. To BCM	25. "REC" indicator light	
7. Junction block assembly	17. Main fuse box	27. Illumination light	

Component Location

A/C System Major Components Location

S7RW0C7213001



I7RW01721004-03

1. HVAC unit	6. Discharge hose	⌚(b) : 25 N·m (2.5 kgf-m, 18.0 lb-ft)
2. Compressor	7. Suction hose	⌚(c) : 3.5 N·m (0.35 kgf-m, 2.51 lb-ft)
3. Condenser assembly	8. Liquid pipe	🔧 : Apply compressor oil to O-ring.
4. Condenser cooling fan	9. Expansion valve	
5. Receiver/dryer	⌚(a) : 11 N·m (1.1 kgf-m, 8.0 lb-ft)	

Diagnostic Information and Procedures


A/C System Performance Inspection

S7RW0C7214001

- 1) Confirm that vehicle and environmental conditions are as follows.
 - Vehicle is put indoors.
 - Ambient temperature is within 25 – 35 °C (77 – 95 °F).
 - Relative humidity is within 30 – 70%.
 - There is no wind indoors.
 - HVAC unit is normal.
 - Blower motor is normal.
 - There is no air leakage from air ducts.
 - Condenser fins are clean.
 - HVAC air filter is not clogged with dirt and dust (if equipped).
 - Battery voltage is about 12 V.
 - Radiator cooling fan operates normally.
- 2) Make sure that high pressure valve (1) and low pressure valve (2) of manifold gauge are firmly closed.
- 3) Connect high pressure charging hose (3) to high pressure service valve (5) on vehicle and low pressure charging hose (4) to low pressure service valve (6).
- 4) Bleed the air in charging hoses (3) and (4) by loosening their nuts respectively utilizing the refrigerant pressure. When a hissing sound is heard, immediately tighten nut.


⚠ CAUTION

Do not connect high and low pressure charging hoses in reverse.



I7RW01721006-01

- 5) Warm up engine to the normal operating temperature and keep it at the specified idle speed.
- 6) Turn A/C switch ON, set blower speed selector at maximum speed position, temperature selector at maximum cold position, air flow selector at face position, and air intake selector at recirculation position. (Confirm that A/C compressor, A/C condenser cooling fan and radiator cooling fan are working.)
- 7) Wait for ten minutes to stabilize the A/C operation.
- 8) Open all door windows, front doors and engine hood.
- 9) With about 20 mm (0.8 in.) of dry bulb thermometer (1) put right in front of center ventilation louver and a wet and dry bulb thermometer (2) near air inlet of HVAC unit.



I5RW0A721008-01

7B-9 Air Conditioning System: Manual Type

10) Check for each pressure of low side and high side if it is within shaded range of graph. If each gauge reading is out of specified pressure, correct defective part referring to the following table.

When diagnosing troubles of abnormal pressure on the low side and high side for each pressure more specifically, refer to "Trouble Diagnosis for Abnormal Pressure: Manual Type".


NOTE

Pressure registered on gauge varies with ambient temperature. Therefore, use the graphs when determining if pressures are normal or not.

Low side and high side pressure example, Gauges should read as follows when ambient temperature is 30 °C (86 °F)

Pressure on high pressure gauge (HI): 1240 – 1620 kPa (12.4 – 16.2 kgf/cm²)

Pressure on low pressure gauge (LO): 250 – 360 kPa (2.5 – 3.6 kgf/cm²)



I6RW0C721004-02

[A]: Pressure of high pressure gauge	[C]: Ambient temperature	[E]: Acceptable range
[B]: Pressure of low pressure gauge	[D]: Humidity	

High pressure gauge

Condition	Possible cause	Correction
Pressure is higher than acceptable range ("A" area)	Refrigerant overcharged	Recharge.
	Expansion valve frozen or clogged	Check expansion valve.
	Clogged refrigerant passage of high pressure side	Clean or replace.
	Condenser cooling fan malfunction (Insufficient cooling of condenser)	Check condenser cooling fan.
	Dirty or bent condenser fins (Insufficient cooling of condenser)	Clean or repair.
	Compressor malfunction (Insufficient oil etc.)	Check compressor.
	Engine overheat	Check engine cooling system referring to "Engine Cooling Symptom Diagnosis in Section 1F".


Condition	Possible cause	Correction
Pressure is lower than acceptable range ("B" area)	Insufficient refrigerant (Insufficient charge or leakage)	Check for leakage, repair if necessary and recharge.
	Expansion valve malfunction (valve opens too wide)	Check expansion valve.
	Compressor malfunction (Insufficient compression)	Check compressor.

Low pressure gauge

Condition	Possible cause	Correction
Pressure is higher than acceptable range ("C" area)	Expansion valve malfunction (valve opens too wide)	Check expansion valve.
	Compressor malfunction (Insufficient compression)	Check compressor.
Pressure is lower than acceptable range ("D" area)	Insufficient refrigerant (Insufficient charge or leakage)	Check for leakage, repair if necessary and recharge.
	Expansion valve malfunction (valve opens too narrow)	Check expansion valve.
	Clogged refrigerant passage (crashed pipe)	Repair or replace.

11) Check inlet port temperature-to-outlet port temperature relationship using the graph. For example, if temperature near air inlet of HVAC unit is 30 °C (86 °F) and the one at air outlet of center ventilation louver is 17 °C (62.6 °F), their crossing point is within acceptable range as shown in the graph. In this case, cooling performance is satisfactory and proper.

12) If crossing point is out of acceptable range, diagnose trouble referring to the following table.



I6RW0C721005-02

[A]: Temp at air outlet of center ventilation louver	[C]: Humidity
[B]: Temp near air inlet of HVAC unit	[D]: Acceptable range

Thermometer at center ventilation louver

Condition	Possible cause	Correction
Crossing point is higher than acceptable range ("E" area)	Insufficient or excessive charge of refrigerant	Check refrigerant pressure.
	Dirty or bent A/C evaporator fins	Clean or repair.
	Air leakage from cooling (heater) unit or air duct	Repair or replace.
	Malfunctioning, switch over function of door in cooling (heater) unit	Repair or replace.
	Compressor malfunction	Check compressor.
Crossing point is lower than acceptable range ("F" area)	Insufficient air volume from center duct (Heater blower malfunction)	Check blower motor and fan.
	Compressor malfunction	Check compressor.

Trouble Diagnosis for Abnormal Pressure

S7RW0C7214002

NOTE

Normal pressure values on high side and low side in following table are measured when the ambient temperature is 30 °C. As normal pressure values on high side and low side vary depending on the ambient temperature, be sure to perform following steps first when diagnosing troubles.

1. Measure the ambient temperature and using that value, read the normal value from the graph given in Step 10 of "A/C System Performance Inspection: Manual Type".
2. Put that value in place of the normal pressure in following table.

Condition		Detail	Possible cause	Correction
Manifold gauge	MPa (kgf/cm ²) (psi)			
Lo	Hi			
0.25 – 0.36 (2.5 – 3.6) (35.6 – 51.2)	1.24 – 1.62 (12.4 – 16.2) (176.3 – 230.4)	Normal condition	—	—
Negative pressure	0.5 – 0.6 (5 – 6) (71.2 – 85.3)	The low pressure side reads a negative pressure, and the high pressure side reads an extremely low pressure. Presence of frost around tubing to and from receiver/dryer and expansion valve.	Dust particles or water droplets are either stuck or frozen inside expansion valve, preventing the refrigerant from flowing.	Replace expansion valve. Replace desiccant and cap with filter. Evacuate the A/C system and recharge with fresh refrigerant.
Normal: 0.25 – 0.36 (2.5 – 3.6) (35.6 – 51.2) ↑↓ Abnormal: Negative pressure	Normal: 1.24 – 1.62 (12.4 – 16.2) (176.3 – 230.4) ↑↓ Abnormal: 0.7 – 1.0 (7 – 10) (100 – 142)	During A/C operation, the low pressure side sometimes indicates negative pressure, and sometimes normal pressure. Also high pressure side reading fluctuates between the abnormal and normal pressure.	Expansion valve is frozen due to moisture in the system, and temporarily shuts off the refrigeration cycle.	Replace expansion valve. Replace desiccant and cap with filter. Evacuate A/C system and recharge with fresh refrigerant.

Condition			Possible cause	Correction
Manifold gauge	MPa (kgf/cm ²) (psi)	Detail		
Lo	Hi			
0.05 – 0.15 (0.5 – 1.5) (4.2 – 21.3)	0.7 – 1.0 (7 – 10) (100 – 142)	Both low and high pressure sides indicate low readings. Output air is slightly cold.	Insufficient refrigerant in system (Refrigerant leaking).	Using leak detector, check for leaks and repair as necessary. Recharge refrigerant to a specified amount. If the pressure reading is almost 0 when the manifold gauges are attached, check for any leaks, repair them, and evacuate the system.
0.4 – 0.6 (4 – 6) (56.9 – 85.3)		Pressure on low pressure side is high. Pressure on high pressure side is low. Both pressure becoming equal right after A/C is turned OFF.	Internal leak in compressor.	Inspect compressor and repair or replace as necessary.
0.40 – 0.45 (4.0 – 4.5) (57 – 64)	2.0 – 2.5 (20 – 25) (285 – 355)	High pressure reading on both low and high pressure sides.	Overcharged A/C system. Faulty condenser cooling operation. Faulty condenser cooling fan operation.	Adjust refrigerant to specified amount. Clean condenser. Inspect and repair condenser cooling fan.
		High pressure reading on both low and high pressure sides. Low pressure side tubing is not cold when touched.	Presence of air in A/C system (Improperly evacuated).	Replace desiccant and cap with filter. Inspect quantity of compressor oil and presence of contaminants in oil. Evacuate system and recharge with fresh refrigerant.
0.45 – 0.55 (4.5 – 5.5) (64 – 78)		High pressure reading on both low and high pressure sides. Large amount of frost or dew on the low pressure side tubing.	Faulty expansion valve. Refrigerant flow is not regulated properly.	Replace expansion valve.

A/C System Inspection at ECM

S7RW0C7214003

When checking voltage at ECM terminals related to A/C system, refer to “Inspection of ECM and Its Circuits in Section 1A”.

A/C System Symptom Diagnosis

Condition	Possible cause	Correction / Reference Item
No cool air comes out (A/C compressor does not operate)	No refrigerant	Perform recovery, evacuation and charge referring to "Operation Procedure for Refrigerant Charge: Manual Type".
	Fuse blown	Check related fuses, and then check for short circuit to ground.
	A/C switch faulty	Check A/C switch referring to "A/C Switch Inspection: Manual Type".
	Blower speed selector faulty	Check blower speed selector referring to "Blower Speed Selector Inspection in Section 7A".
	Evaporator temperature sensor faulty	Check evaporator temperature sensor referring to "Evaporator Temperature Sensor Inspection: Manual Type".
	A/C refrigerant pressure sensor faulty	Check A/C refrigerant pressure sensor referring to "A/C Refrigerant Pressure Sensor and Its Circuit Inspection: Manual Type".
	Wiring or grounding faulty	Repair as necessary.
	ECM faulty	Check ECM referring to "A/C System Inspection at ECM: Manual Type".
	Magnet clutch faulty	Check magnet clutch referring to "Magnet Clutch Inspection: Manual Type".
	Compressor drive belt loosened or broken	Adjust or replace drive belt.
	Compressor faulty	Check compressor.
	Compressor relay faulty	Check compressor relay referring to "A/C System Relay Inspection: Manual Type".
	BCM faulty	Check BCM referring to "Inspection of BCM and Its Circuits in Section 10B".
No cool air comes out (radiator cooling fan motor does not operate)	Fuse blown	Check related fuses, and then check for short circuit to ground.
	Wiring or grounding faulty	Repair as necessary.
	Condenser cooling fan relay faulty	Check condenser cooling fan motor relay referring to "A/C System Relay Inspection: Manual Type".
	Condenser cooling fan motor faulty	Check condenser cooling fan motor referring to "Condenser Cooling Fan Inspection: Manual Type".
	ECM faulty	Check ECM referring to "A/C System Inspection at ECM: Manual Type".
No cool air comes out (blower motor does not operate)	Fuse blown	Check related fuses, and then check for short circuit to ground.
	Blower motor relay faulty	Check blower motor relay referring to "Blower Motor Relay Inspection in Section 7A".
	Blower motor resistor faulty	Check blower motor resistor referring to "Blower Motor Resistor Inspection in Section 7A".
	Blower speed selector faulty	Check blower speed selector referring to "Blower Speed Selector Inspection in Section 7A".
	Wiring or grounding faulty	Repair as necessary.
	Blower motor faulty	Check blower motor referring to "Blower Motor Inspection in Section 7A".

Condition	Possible cause	Correction / Reference Item
Cool air does not come out or insufficient cooling (A/C compressor normal operation)	Insufficient or excessive charge of refrigerant	Check the amount of refrigerant and system for leaks.
	Condenser clogged	Check condenser referring to "Condenser Assembly On-Vehicle Inspection: Manual Type".
	A/C evaporator clogged or frosted	Check A/C evaporator and evaporator temperature sensor referring to "Evaporator Inspection: Manual Type" and "Evaporator Temperature Sensor Inspection: Manual Type".
	Evaporator temperature sensor faulty	Check evaporator temperature sensor referring to "Evaporator Temperature Sensor Inspection: Manual Type".
	Expansion valve faulty	Check expansion valve referring to "Expansion Valve Inspection: Manual Type".
	Desiccant clogged	Check desiccant and cap with filter.
	Compressor drive belt loosened or broken	Adjust or replace drive belt.
	Magnet clutch faulty	Check magnet clutch referring to "Magnet Clutch Inspection: Manual Type".
	Compressor faulty	Check compressor.
	Air in A/C system	Replace condenser, and then perform evacuation and charge referring to "Operation Procedure for Refrigerant Charge: Manual Type".
	Air leaking from HVAC unit or air duct	Repair as necessary.
	Heater and ventilation system faulty	Check HVAC unit.
	Blower motor faulty	Check blower motor referring to "Blower Motor Inspection in Section 7A".
	Excessive compressor oil in A/C system	Drain excessive compressor oil from A/C system circuit and compressor.
Cool air does not come out only intermittently	Wiring connection faulty	Repair as necessary.
	Evaporator temperature sensor faulty	Check evaporator temperature sensor referring to "Evaporator Temperature Sensor Inspection: Manual Type".
	Expansion valve faulty	Check expansion valve referring to "Expansion Valve Inspection: Manual Type".
	Excessive moisture in A/C system	Replace condenser, and then perform evacuation and charge referring to "Operation Procedure for Refrigerant Charge: Manual Type".
	Magnet clutch faulty	Check magnet clutch referring to "Magnet Clutch Inspection: Manual Type".
	Excessive amount of refrigerant	Check the amount of refrigerant.
Cool air comes out only at high speed	Condenser clogged	Check condenser referring to "Condenser Assembly On-Vehicle Inspection: Manual Type".
	Insufficient charge of refrigerant	Check the amount of refrigerant and system for leaks.
	Air in A/C system	Replace condenser, and then perform evacuation and charge referring to "Operation Procedure for Refrigerant Charge: Manual Type".
	Compressor drive belt loosened or broken	Adjust or replace drive belt.
	Compressor faulty	Check compressor.

Condition	Possible cause	Correction / Reference Item
Cool air does not come out only at high speed	Excessive amount of refrigerant	<i>Check the amount of refrigerant.</i>
	A/C evaporator frosted	<i>Check A/C evaporator and evaporator temperature sensor referring to "Evaporator Inspection: Manual Type" and "Evaporator Temperature Sensor Inspection: Manual Type".</i>
Insufficient air flow of cooled air	A/C evaporator clogged or frosted	<i>Check A/C evaporator and evaporator temperature sensor referring to "Evaporator Inspection: Manual Type" and "Evaporator Temperature Sensor Inspection: Manual Type".</i>
	Air leaking from HVAC unit or air duct	<i>Repair as necessary.</i>
	Blower motor faulty	<i>Check blower motor referring to "Blower Motor Inspection in Section 7A".</i>
	Wiring or grounding faulty	<i>Repair as necessary.</i>

Abnormal Noise Symptom Diagnosis of A/C System

S7RW0C7214005

Abnormal Noise from Compressor

Condition	Possible cause	Correction / Reference Item
During compressor operation, a rumbling noise is heard proportional to engine revolutions	Inadequate clearance in scroll area	<i>Replace compressor.</i>
A loud noise is heard at a certain rpm, disproportionately to engine revolution	Loose or faulty compressor drive belt	<i>Adjust drive belt tension or replace drive belt.</i>
	Loose compressor mounting bolts	<i>Retighten mounting bolts.</i>
A loud rattle is heard at low engine rpm	Loose compressor clutch plate bolt	<i>Retighten clutch plate bolt. Replace compressor if it was operated in this condition for a long time.</i>

Abnormal Noise from Magnetic Clutch

Condition	Possible cause	Correction / Reference Item
A rumbling noise is heard when compressor is not in operation	Worn or damaged bearings	<i>Replace magnet clutch assembly.</i>
A chattering noise is heard when compressor is in operation	Faulty magnet clutch clearance (excessive clearance)	<i>Adjust magnet clutch clearance.</i>
	Worn magnet clutch friction surface	<i>Replace magnet clutch assembly.</i>
	Compressor oil leaked from shaft seal, contaminating the friction surface	<i>Replace compressor body assembly.</i>

Abnormal Noise from Tubing

Condition	Possible cause	Correction / Reference Item
A droning noise is heard from inside of the vehicle, but not particularly noticeable in engine compartment	Faulty tubing clamps	<i>Reposition clamps or increase the number of clamps.</i>
	Resonance caused by pulsation from variations in refrigerant pressure	<i>Attach a silencer to tubing, or modify its position and length.</i>

Abnormal Noise from Condenser Assembly

Condition	Possible cause	Correction / Reference Item
Considerable vibration in condenser assembly	Resonance from condenser assembly bracket and body	<i>Firmly insert a silencer between condenser assembly bracket and body.</i>

Abnormal Noise from Crankshaft Pulley

Condition	Possible cause	Correction / Reference Item
A large rattling noise is heard at idle or sudden acceleration	Loosen crankshaft pulley bolt	<i>Retighten bolt.</i>

Abnormal Noise from Tension Pulley

Condition	Possible cause	Correction / Reference Item
Clattering noise is heard from pulley	Worn or damaged bearing	<i>Replace tension pulley.</i>
Pulley cranks upon contact	Cracked or loose bracket	<i>Replace or retighten bracket.</i>

Abnormal Noise from A/C Evaporator

Condition	Possible cause	Correction / Reference Item
Whistling sound is heard from A/C evaporator	Depending on the combination of the interior / exterior temperatures, engine rpm and refrigerant pressure, the refrigerant flowing out of the expansion valve may, under certain conditions, make a whistling sound	<i>At times, slightly decreasing refrigerant volume may stop this noise. Inspect expansion valve and replace if faulty.</i>

Abnormal Noise from Blower Motor

Condition	Possible cause	Correction / Reference Item
Blower motor emits a chirping sound in proportion to its speed of rotation	Worn or damaged motor brushes or commutator	<i>Replace blower motor.</i>
Fluttering noise or large droning noise is heard from blower motor	Leaves or other debris introduced from fresh air inlet to blower motor	<i>Remove debris and make sure that the screen at fresh air inlet is intact.</i>


Repair Instructions

Operation Procedure for Refrigerant Charge

S7RW0C7216001

▲ WARNING

- Your eyes should not be exposed to refrigerant (liquid).
Any liquid HFC-134a (R-134a) escaping by accident shows a temperature as low as approximately -6°C (21.2°F) below freezing point. Should liquid HFC-134a (R-134a) be exposed to your eyes, it may cause a serious injury. To protect your eyes from such accident, it is necessary to always wear goggles. Should it occur that HFC-134a (R-134a) be exposed to your eyes, consult a doctor immediately.
 - Do not use your hand to rub the affected eye(s). Instead, use fresh cold water to splash it over the affected area to gradually raise temperature of such area above freezing point.
 - Obtain proper treatment as soon as possible from a doctor or eye specialist.
- Should the liquid refrigerant HFC-134a (R-134a) be exposed to your skin, the affected area should be treated in the same manner as when skin is frostbitten or frozen.
- Do not handle refrigerant near any place where welding or steam cleaning is performed.
- Refrigerant should be kept in a cold and dark place. It should never be stored in any place where temperature is high, e.g. where exposed to direct sun light, close to fire or inside vehicle (including trunk room).
- Avoid breathing fume produced when HFC-134a (R-134a) is burned. Such fume may be hazardous to your health.




I5RW0A721011-01

Recovery

When discharging refrigerant out of A/C system, always recover it by using refrigerant recovery and recycling equipment because discharging refrigerant HFC-134a (R-134a) into atmosphere would cause adverse effect to environments.

NOTE


- After recovering refrigerant from system, the amount of removed compressor oil must be measured for replenishing compressor oil.
- When handling recovery and recycling equipment, be sure to follow the instruction manual for the equipment.



I7RW01721009-01

Replenishing Compressor Oil

It is necessary to replenish specified amount of compressor oil to compressor from compressor suction side hole (1) before evacuating and charging refrigerant.



I7RW01721010-01

When charging refrigerant only

When charging refrigerant without replacing any component, replenish the same amount of measured oil when recovering refrigerant (if not measure, replenish 10 cm³ (10 ml, 0.34 US.oz, 0.35 Imp.oz) oil).

When replacing compressor**⚠ CAUTION**

Be sure to use specified compressor oil or an equivalent compressor oil.

Compressor oil is sealed in each new compressor by the amount required for A/C system. Therefore, when using a new compressor, drain the calculated amount of oil from it.

$$“C” = “A” - “B”$$

“C”: Amount of oil to be drained

“A”: Amount of oil in a new compressor

“B”: Amount of oil in removed compressor


NOTE

Compressor assembly supplied from factory is filled up with the following amount of oil.

: Compressor oil 99000-99015-00A
(MATSUSHITADENKI GU10)

Oil amount in compressor

75 + 10, - 0 cm³ (75 + 10, - 0 ml, 2.54 + 0.34, - 0 US.oz, 2.64 + 0.35, - 0 Imp.oz)



I2RH01720015-01

1. New compressor

2. Removed compressor

When replacing other parts

Replenish the following amount of oil to compressor.

Amount of compressor oil to be replenished

Evaporator: 15 cm³ (15 ml, 0.51 US.oz, 0.53 Imp.oz)

Condenser: 10 cm³ (10 ml, 0.34 US.oz, 0.35 Imp.oz)

Dryer: 10 cm³ (10 ml, 0.34 US.oz, 0.35 Imp.oz)

Hoses: 5 cm³ (5 ml, 0.17 US.oz, 0.18 Imp.oz) each

Pipes: 5 cm³ (5 ml, 0.17 US.oz, 0.18 Imp.oz) each

Evacuation

⚠ CAUTION

Do not evacuate before recovering refrigerant in A/C system.

NOTE

Once air conditioning system circuit is opened (exposed) to atmospheric air, system must be evacuated by using a vacuum pump. The A/C system should be attached with a manifold gauge set, and should be evacuated for approximately 15 minutes.

- 1) Connect high charging hose (1) and low charging hose (2) of manifold gauge set (3) (special tool) respectively as follows:
 High charging hose → High pressure charging valve (4) on discharge hose
 Low charging hose → Low pressure charging valve (5) on suction pipe

Special tool


(A): 09990-06020

- 2) Attach center charging hose (6) of manifold gauge set to vacuum pump (7).
- 3) Operate vacuum pump, and then open discharge side valve (Hi) (8) of manifold gauge set.
 If there is no blockage in the system, there will be an indication on high pressure gauge (9).
 When this occurs, open the other side valve (Lo) (10) of the set.
- 4) Approximately 10 minutes later, low pressure gauge (11) should show a vacuum lower than -100 kPa (-1.0 kgf/cm^2 , -760 mmHg , -14.7 psi) providing no leakage exists.

NOTE

- If the system does not show a vacuum below -100 kPa (-1.0 kgf/cm^2 , -760 mmHg , -14.7 psi), close both valves, stop vacuum pump and watch movement of low pressure gauge.
- Increase in the gauge reading suggests existence of leakage. In this case, repair the system before continuing its evacuation.
- If the gauge shows a stable reading (suggesting no leakage), continue evacuation.

- 5) Evacuation should be carried out for a total of at least 15 minutes.
- 6) Continue evacuation until low pressure gauge indicates a vacuum less than -100 kPa (-1.0 kgf/cm^2 , -760 mmHg , -14.7 psi), and then close both valves.
- 7) Stop vacuum pump. Disconnect center charging hose from pump inlet. Now, the system is ready for charging refrigerant.



I7RW01721011-01

Checking A/C System for Pressure Leaks

After completing the evacuation, close manifold gauge high pressure valve and low pressure valve and wait 10 minutes. Verify that low pressure gauge reading has not changed.

⚠ CAUTION

If the gauge reading moves closer to "0", there is a leak somewhere. Inspect the tubing connections and make necessary corrections. And then, evacuate system once again and make sure that there are no leaks.

Charge

⚠ CAUTION

- Because the sight glass is not used for this A/C system, do not perform an additional charge to the A/C system. To charge the proper amount of refrigerant, recover and evacuate the A/C system first. And then, charge the proper amount of refrigerant into the A/C system.
- Always charge refrigerant through low pressure side of A/C system after the initial charge is performed from the high pressure side with the engine stopped.
- Never charge refrigerant through high pressure side of A/C system with engine running.
- Do not charge refrigerant while compressor is hot.
- When installing tap valve to refrigerant container to make a hole there through, carefully follow directions given by manufacturer.
- A pressure gauge should always be used before and during refrigerant charge.
- The refrigerant container should be emptied of refrigerant when discarding it.
- The refrigerant container should not be heated up to 40 °C (104 °F) or over.
- Refrigerant container should not be reversed in direction during refrigerant charge. Reversing in direction causes liquid refrigerant to enter compressor, causing troubles, such as compression of liquid refrigerant and the like.

NOTE

The air conditioning system contains HFC-134a (R-134a).

Described here is a method to charge the air conditioning system with refrigerant from the refrigerant service container.

When charging refrigerant recovered by using the refrigerant and recycling equipment (when recycling refrigerant), follow the procedure described in the equipment manufacturer's instruction manual.


The initial charge of the A/C system is performed through the high pressure side with the engine stopped. And next, this method must be followed by charging from the low pressure side with the engine running.

- 1) Check if hoses are routed properly after evacuating the system.
- 2) Connect low charging hose (1) and high charging hose (2) of the manifold gauge set (3) in position. Then, open refrigerant container valve (4) to purge the charging line.
- 3) Open the high pressure side valve (5) and charge refrigerant to system.
- 4) After a while, open the low pressure side valve (6) and close the high pressure side valve.

⚠ WARNING


Make sure that high pressure side valve is closed securely.

- 5) Start engine and keep engine speed at 1500 r/min, and then operate A/C system.
- 6) Charge A/C system with refrigerant in vapor state. At this time, refrigerant container should be held upright.




I7RW01721012-01

- 7) When refrigerant container (1) is emptied, use the following procedure to replace it with a new refrigerant container.
 - a) Close low pressure valve.
 - b) Replace empty container with a refrigerant container which has been charged with refrigerant. When using refrigerant container tap valve (2), use the following procedure for replacement.
 - i) Retract needle (3) and remove refrigerant container tap valve by loosening its plate nut (4).
 - ii) Install the refrigerant container tap valve to a new refrigerant container.



I2RH01720018-01

- c) Purge any air existing in center charging hose. When using refrigerant container tap valve, use the following procedure to purge air.
 - i) Once fully tighten refrigerant container tap valve (1), and then loosen (open) plate nut (2) slightly.
 - ii) Open low pressure side valve (3) of manifold gauge set (4) a little.
 - iii) As soon as refrigerant comes out with a "hiss" through a clearance between refrigerant container and tap valve, tighten plate nut as well as low pressure side valve.
 - iv) Turn handle of tap valve clockwise so that its needle is screwed into the new container to make a hole for refrigerant flow.



I2RH01720019-01


- 8) After the system has been charged with specified amount of refrigerant or when low pressure gauge (1) and high pressure gauge (2) have indicated the following specified value, close low pressure side valve (3) on manifold gauge set (4).

Specified amount of refrigerant

430 ± 20 g (15.2 ± 0.7 oz)

Low side and high side pressure example

Gauges should read as follows when ambient temperature is 30 °C (86 °F).	
Pressure on high pressure gauge	1240 – 1620 kPa 12.4 – 16.2 kgf/cm ² 176.3 – 230.4 psi
Pressure on low pressure gauge	250 – 360 kPa 2.5 – 3.6 kgf/cm ² 35.6 – 51.2 psi



I7RW01721013-02

Removal of Manifold Gauge Set

⚠ WARNING

High pressure side is under high pressure. Therefore, be careful not to get injured especially on your eyes and skin.

For the A/C system charged with the specified amount of refrigerant, remove manifold gauge set as follows:

- 1) Close low pressure side valve of manifold gauge set. (The high pressure side valve is closed continuously during the process of charging.)
- 2) Close refrigerant container valve.
- 3) Stop engine.
- 4) Using shop rag, remove charging hoses from service valves. This operation must be performed quickly.
- 5) Put caps on service valves.

Check A/C System for Refrigerant Leaks

Whenever a refrigerant leak is suspected in the system or any service operation has been performed which may result in malfunction of lines and connections, it is advisable to check for leaks.

Common sense should be used during refrigerant leak test, since the need and extent of any such test will, in general, depend upon the nature of a complaint and the type of a service performed on the system.

Liquid leak detector

⚠ WARNING

- To prevent explosions and fires, make sure that there are no flammables in the vicinity.
- When the refrigerant exposed to fire, it turns into a poisonous gas (phosgene). Do not inhale this gas.


There is a number of fittings and places throughout the A/C system where a liquid leak detector solution may be used to pinpoint refrigerant leaks.

By merely applying the solution to the area in question with a swab, such as attached to the cap of a vial, bubbles will form within seconds if there is a leak.

For confined areas, such as sections of the evaporator and condenser, an electronic (refrigerant) leak detector is more practical for determining leaks.

Special tool

(A): 09990-86012



I5RW0A721054-01

Condenser Cooling Fan Removal and Installation


S7RW0C7216002

⚠ CAUTION

Be careful not to damage fins of radiator. If radiator fin is bent, straighten it by using flat head screwdriver or pair of pliers.

Removal

- 1) Disconnect negative (–) cable at battery.
- 2) Disconnect condenser cooling fan motor coupler.
- 3) Remove reservoir (1) from radiator.
- 4) Remove condenser cooling fan (2) from radiator (3).



I5RW0A721017-01


Installation

Reverse removal procedure to install condenser cooling fan.

Condenser Cooling Fan Inspection

S7RW0C7216003

- 1) Check condenser cooling fan motor for resistance between terminal "a" and "b" as shown. If there is no continuity, replace condenser cooling fan motor.




I5RW0A721018-02

- 2) Connect battery to condenser cooling fan motor terminal "a" and "b" as shown in figure, and then check if the condenser cooling fan motor operates smoothly.

Reference

**Condenser cooling fan specified current at 12 V:
7 A maximum**



I5RW0A721019-02

Condenser Assembly On-Vehicle Inspection

S7RW0C7216004

Check the followings.

- Clog of condenser fins
If any clog is found, condenser fins should be washed with water and should be dried with compressed air.
- Condenser fins for leakage and breakage
If any defects are found, repair or replace condenser.
- Condenser fittings for leakage.
If any defects are found, repair or replace condenser.

Condenser Assembly Removal and Installation

S7RW0C7216005

⚠ CAUTION

Do not damage condenser fins. If condenser fin is bent, straighten it by using flat head screwdriver or pair of pliers.


Removal

- 1) Recover refrigerant from A/C system referring to "Operation Procedure for Refrigerant Charge: Manual Type".

NOTE


The amount of removed compressor oil must be measured for replenishing compressor oil.

- 2) Remove front bumper referring to "Front Bumper and Rear Bumper Components in Section 9K".
- 3) Disconnect discharge hose (1) and liquid pipe (2) from condenser assembly (3).
- 4) Remove radiator assembly and condenser assembly mounting bolts (4).



I7RW01721025-04

- 5) Move condenser assembly from the vehicle in the arrow direction in the order of 1, 2 and 3 as shown, and it can be removed.



I5RW0A721021-02

Installation

Reverse the removal procedure to install condenser noting the following instructions.

- Replenish specified amount of compressor oil to compressor suction side referring to "Replenishing Compressor Oil" in "Operation Procedure for Refrigerant Charge: Manual Type".
- Evacuate and charge the A/C system referring to "Evacuation" and "Charge" in "Operation Procedure for Refrigerant Charge: Manual Type".

Desiccant Removal and Installation

S7RW0C7216006


Removal

- 1) Remove condenser assembly referring to "Condenser Assembly Removal and Installation: Manual Type".
- 2) Remove circlip (4) using special tool.

Special tool

: 09900-06107

- 3) Remove the cap (1) from the receiver / dryer tank (2).
- 4) Remove desiccant (3).




I5RW0A721022-01

Installation

Reverse the removal procedure noting the following instructions.

- Replenish specified amount of compressor oil to compressor suction side referring to "Operation Procedure for Refrigerant Charge: Manual Type".
- Do not remove desiccant from the plastic bag until just before inserting it into the receiver.
- Apply compressor oil to O-ring (1).
- Be sure to install circlip (2) with its flat face (3) directed to cap.
- Install condenser assembly referring to "Condenser Assembly Removal and Installation: Manual Type".
- Evacuate and charge the A/C system referring to "Evacuation" and "Charge" in "Operation Procedure for Refrigerant Charge: Manual Type".



I5RW0A721052-01


⊗ : Do not reuse

HVAC Unit Components

S7RW0C7216007

NOTE

The figure shows left-hand steering vehicle. For right-hand steering vehicle, parts with (*) are installed at the opposite side.



I6RW0C721006-01


1. Blower upper case	8. Air intake control actuator	15. Evaporator	22. Temperature control door assembly
2. Blower lower case	9. Air intake control link	16. Evaporator temperature sensor	23. Drain hose
3. Heater unit upper case	10. Air intake control door	17. Expansion valve	24. Cable lock clamp
4. Heater unit lower case	11. Blower motor	18. Expansion pipe	25. Packing
5. Foot duct	12. Blower motor cap	19. Air flow control lever	26. O-ring : Apply compressor oil.
6. HVAC air filter (if equipped)	13. Blower motor resistor	20. Air flow control door assembly	27. Resistance board (non-A/C)
7. Cover (without HVAC air filter)	14. Heater core	21. Temperature control lever	: Do not reuse.

HVAC Unit Removal and Installation

S7RW0C7216008


Removal

- 1) Recover refrigerant from A/C system with recovery and recycling equipment referring to "Recovery" in "Operation Procedure for Refrigerant Charge: Manual Type".
- 2) Drain engine coolant referring to "Cooling System Draining in Section 1F", and then disconnect heater hoses from HVAC unit.
- 3) Remove cowl top cover from vehicle body referring to "Radiator Grille Removal and Installation in Section 9K".
- 4) Remove instrument panel from vehicle body referring to "Instrument Panel Removal and Installation in Section 9C".
- 5) Loosen a bolt (1) and remove pipes from expansion valve (2).



I7RW01721016-01

- 6) Remove HVAC unit (1) from vehicle body by removing nuts (2).




I7RW01710003-01

Installation

Reverse removal procedure noting the following instructions.

- Replenish specified amount of compressor oil to compressor suction side referring to "Replenishing Compressor Oil" in "Operation Procedure for Refrigerant Charge: Manual Type".
- Install the padding (1) to the installation hole uniformly.



I5RW0A721025-02

- Evacuate and charge the A/C system referring to "Evacuation" and "Charge" in "Operation Procedure for Refrigerant Charge: Manual Type".
- Refill cooling system with coolant referring to "Cooling System Flush and Refill in Section 1F".
- Adjust control cables referring to "HVAC Control Unit Removal and Installation in Section 7A". (vehicle with manual type A/C)

Evaporator Inspection

S7RW0C7216009

Check the followings.


- Clog of A/C evaporator fins.
If any clogs are found, A/C evaporator fins should be washed with water, and then should be dried with compressed air.
- A/C evaporator fins for leakage and breakage.
If any defects are found, repair or replace A/C evaporator.
- A/C evaporator fittings for leakage.
If any defects are found, repair or replace A/C evaporator.

Evaporator Temperature Sensor Removal and Installation

S7RW0C7216010

Removal

- 1) Remove HVAC unit from vehicle body referring to "HVAC Unit Removal and Installation: Manual Type".
- 2) Remove evaporator temperature sensor (1) from evaporator by (2) disassembling HVAC unit.




I7RW01721018-01

Installation

Reverse the removal procedure noting the following instruction.


- Install evaporator temperature sensor (1) onto evaporator (2) as shown.

LH steering vehicle



I7RW01721026-01

RH steering vehicle



I6RW0C721007-01

- | | |
|----|---|
| 3. | 138 ± 5 mm (3.3 ± 0.2 in.) |
| 4. | Sensor part fixed to 12th fin from pipe fitting side |
| 5. | Holding part fixed to 13th fin from pipe fitting side |
| 6. | Pipe fitting |

Evaporator Temperature Sensor Inspection

S7RW0C7216011



Check resistance between terminals of evaporator temperature sensor (1).

If check results are as not specified, replace evaporator temperature sensor.

Evaporator temperature sensor resistance

0 °C (32 °F): 6.6 – 6.8 kΩ

25 °C (77 °F): 2.0 – 2.1 kΩ



I7RW01721020-01

[A]: Resistance


[B]: Temperature

Expansion Valve Removal and Installation

S7RW0C7216012

Removal

- 1) Recover refrigerant from the A/C system with recovery and recycling equipment referring to "Recovery" in "Operation Procedure for Refrigerant Charge: Manual Type".
- 2) Loosen a bolt (1) and remove pipes from expansion valve (2).
- 3) Loosen bolts (3) and remove expansion valve.



I4RS0A720028-01

Installation

Reverse removal procedure noting the following instructions.

- Apply compressor oil to O-ring of expansion valve and pipes.
- Tighten expansion valve bolts to specified torque.

Tightening torque

Expansion valve bolt: 4.5 N·m (0.45 kgf-m, 3.5 lb-ft)

- Evacuate and charge the A/C system referring to "Evacuation" and "Charge" in "Operation Procedure for Refrigerant Charge: Manual Type".

Expansion Valve Inspection

S7RW0C7216013

Refer to "A/C System Performance Inspection: Manual Type".

A/C Refrigerant Pressure Sensor and Its Circuit Inspection

S7RW0C7216014

- 1) Disconnect A/C refrigerant pressure sensor connector.
- 2) Turn ignition switch to ON position.
- 3) Check if voltage between “RED” wire terminal and “ORN” wire terminal of A/C refrigerant pressure sensor connector is 4.75 V to 5.25 V.
If not, check A/C refrigerant pressure sensor circuit.
- 4) Connect A/C refrigerant pressure sensor connector with ignition switch turned OFF.
- 5) Connect manifold gauge set to the charging valves.
- 6) Check A/C refrigerant pressure sensor voltage of ECM connector referring to “A/C System Inspection at ECM: Manual Type”.
If voltage is not as specified below, replace A/C refrigerant pressure sensor.

A/C refrigerant pressure sensor voltage specifications (A/C refrigerant pressure measured by manifold gauge)


0.8 MPa (8.0 kgf/cm², 116 psi): 1.40 – 1.78 V
 1.4 MPa (14 kgf/cm², 203 psi): 2.18 – 2.64 V
 1.6 MPa (16 kgf/cm², 232 psi): 2.44 – 2.92 V
 1.8 MPa (18 kgf/cm², 261 psi): 2.70 – 3.21 V

A/C Refrigerant Pressure Sensor Removal and Installation

S7RW0C7216015

Removal

- 1) Recover refrigerant from the A/C system with the recovery and recycling equipment referring to “Recovery” in “Operation Procedure for Refrigerant Charge: Manual Type”.
- 2) Disconnect negative (–) cable from battery.
- 3) Disconnect A/C refrigerant pressure sensor connector.
- 4) Remove A/C refrigerant pressure sensor (1) from liquid pipe (2).



I5RW0A721029-01


Installation

Reverse removal procedure noting the following instructions.

- Apply compressor oil to O-ring of A/C refrigerant pressure sensor.
- Tighten A/C refrigerant pressure sensor to specified torque.

Tightening torque

A/C refrigerant pressure sensor (a): 11 N·m (1.1 kgf-m, 8.0 lb-ft)



I5RW0A721030-01



- Evacuate and charge the A/C system referring to “Evacuation” and “Charge” in “Operation Procedure for Refrigerant Charge: Manual Type”.

A/C Switch Inspection

S7RW0C7216016

- Check that there is continuity between terminal (1) and terminal (2) when A/C switch is at ON position.
- Check that there is no continuity between terminal (1) and terminal (2) when A/C switch is at OFF position.

If check result does not meet the above conditions, replace HVAC control unit.



I5RW0A721031-01



A/C System Relay Inspection

S7RW0C7216017

NOTE

Do not use blue relay for the substitute of white relay because internal durability of a blue relay is different from the durability of a white relay.

- 1) Disconnect negative (-) cable from battery.
- 2) Remove compressor relay (1) or condenser cooling fan relay (2) from main fuse box (3).
- 3) Check that there is no continuity between terminal "c" and "d". If there is continuity, replace relay.
- 4) Connect battery positive (+) terminal to terminal "b" of relay and battery negative (-) terminal to terminal "a" of relay, and then check continuity between terminal "c" and "d". If there is no continuity, replace relay.



I5RW0B721023-01

Compressor Drive Belt Inspection and Adjustment

S7RW0C7216018

Refer to "Water Pump and Generator Drive Belt On-Vehicle Inspection in Section 1J".

Compressor Drive Belt Removal and Installation

S7RW0C7216019

Refer to "Water Pump and Generator Drive Belt Removal and Installation in Section 1J".

Compressor Assembly Removal and Installation


S7RW0C7216020

Removal

- 1) Run engine at idle speed with A/C ON for 10 minutes.
- 2) Stop the engine.
- 3) Disconnect negative (-) cable from battery.
- 4) Recover refrigerant from the A/C system with recovery and recycling equipment referring to "Recovery" in "Operation Procedure for Refrigerant Charge: Manual Type".
- 5) Remove condenser cooling fan referring to "Condenser Cooling Fan Removal and Installation: Manual Type".
- 6) Remove compressor drive belt referring to "Compressor Drive Belt Removal and Installation: Manual Type".
- 7) Remove right side engine under cover.
- 8) Disconnect magnet clutch lead wire coupler (1).
- 9) Disconnect discharge hose (2) and suction hose (3) from compressor (4).


NOTE

Cap open fittings immediately to keep moisture out of the system.



I7RW01721021-01

- 10) Remove compressor mounting bolts (1), and then remove compressor (2) from its bracket.



I7RW01721022-01

Installation

Reverse removal procedure noting the following instructions.

- If compressor is replaced, pour new compressor oil referring to “Replenishing Compressor Oil” in “Operation Procedure for Refrigerant Charge: Manual Type”.

- Tighten compressor mounting bolts to specified torque.


Tightening torque

Compressor mounting bolt: 25 N·m (2.5 kgf·m, 18.0 lb·ft)

- Evacuate and charge the A/C system referring to “Evacuation” and “Charge” in “Operation Procedure for Refrigerant Charge: Manual Type”.
- Adjust drive belt tension referring to “Compressor Drive Belt Inspection and Adjustment: Manual Type”.

Compressor Assembly Components

S7RW0C7216021



I7RW01721023-01

1. Armature plate bolt	5. Shim	9. O-ring : Apply compressor oil.	⊗ : Do not reuse.
2. Compressor	6. Magnet clutch coil	10. Thermal switch	
3. Relief valve	7. Magnet clutch pulley	(a) : 15 N·m (1.5 kgf·m, 11.0 lb·ft)	
4. Circlip	8. Armature plate	(b) : 8 N·m (0.8 kgf·m, 6.0 lb·ft)	


Magnet Clutch Inspection

S7RW0C7216022

- Check armature plate and magnet clutch pulley for wear and oil soak respectively.
- Check magnet clutch pulley bearing for noise, wear and grease leakage.
- Measure magnet clutch coil for resistance at 20 °C (68 °F). If the measured resistance is out of specification, replace magnet clutch assembly.

Magnet clutch coil resistance

Standard: 3.5 – 4.0 Ω



I4RS0A720038-01

Magnet Clutch Removal and Installation

S7RW0C7216023


Removal

- 1) Remove compressor from vehicle referring to "Compressor Assembly Removal and Installation: Manual Type".
- 2) Fix armature plate (1) with special tool and remove armature plate bolt (2).

Special tool

(A): 09991-06310

- 3) Remove armature plate (1).




I4RS0A720039-01

- 4) Remove shims from shaft.
- 5) Remove circlip (1) using special tool.

Special tool

(B): 09900-06107




I4RS0A720040-01

- 6) Remove magnet clutch pulley (2).

NOTE

- If it is difficult to remove magnet clutch pulley by hand, use puller (1).
- Do not damage magnet clutch pulley when using puller.




I4RS0A720041-01

- 7) Remove thermal switch from compressor referring to "Thermal Switch Removal and Installation: Manual Type".
- 8) Remove circlip (1) by using special tool.

Special tool

(B): 09900-06107

- 9) Remove magnet clutch coil (2) from compressor (3).




I4RS0A720042-01

Installation

- 1) Install magnet clutch coil (2) fitting protrusion (4) of magnet clutch coil onto hole (5) of compressor (3).
- 2) Install circlip (1) directing chamfer side (6) downward.

Special tool

(B): 09900-06107




I4RS0A720043-01

- 3) Install thermal switch to compressor referring to "Thermal Switch Removal and Installation: Manual Type".
- 4) Install magnet clutch pulley (1).
- 5) Install new circlip (2) directing chamfer side (3) upward.

Special tool

(B): 09900-06107



I4RS0A720044-01


- 6) Tighten new armature plate bolt to specified torque.

Tightening torque

Armature plate nut (a): 16 N·m (1.6 kgf-m, 11.5 lb-ft)

Special tool

(A): 09991-06310




I4RS0A720045-01

- 7) Adjust clearance between armature plate (1) and magnet clutch pulley by putting shim(s) on compressor shaft. To measure the clearance, perform the following steps.
 - a) Put compressor in a vise (2).
 - b) Set dial gauge (3) on armature plate, and then adjust its pointer at 0.
 - c) Connect battery positive terminal (+) to magnet clutch coil lead wire.
 - d) Connect battery negative terminal (-) to compressor body assembly. (At this point, armature plate and magnet clutch pulley are kept in contact.)
 - e) Disconnect battery negative terminal (-) to compressor body assembly. (At this point, armature plate and magnet clutch pulley are not in contact.)
 - f) Read stroke of armature plate from dial gauge by performing step d) and e) repeatedly. (Stroke of armature plate is clearance between armature plate and magnet clutch pulley.)

Standard clearance between armature plate and magnet clutch pulley:

0.3 – 0.5 mm (0.012 – 0.020 in.)



I4RS0A720046-01


Thermal Switch Inspection

S7RW0C7216024

Measured thermal switch for resistance at 20 °C (68 °F)

Thermal switch resistance

Standard: 50 mΩ (DC 16 V, 5A at 20 °C (68 °F))




I7RW01721024-01

Thermal Switch Removal and Installation

S7RW0C7216025

Removal

- 1) Remove compressor from engine referring to "Compressor Assembly Removal and Installation: Manual Type".
- 2) Disconnect thermal switch connector.
- 3) Remove magnet clutch lead wire clamp.
- 4) Remove thermal switch (1) from compressor using flat head (2).




I5RS0C721011-01

Installation

Reverse removal procedure noting the following instructions.

- Apply silicon sealant to contact face (2) of thermal switch (1).

"A": Silicon sealant 99000-34220 (SUZUKI SILICON SEALANT KE-347W (100g))



I5RS0C721012-02

- Install compressor to vehicle referring to "Compressor Assembly Removal and Installation: Manual Type".
- Evacuate and charge the A/C system referring to "Evacuation" and "Charge" in "Operation Procedure for Refrigerant Charge: Manual Type".

Relief Valve Inspection


S7RW0C7216026

By using special tool, check is there is refrigerant leakage.

If there is refrigerant leakage, replace the relief valve.

Special tool

(A) : 09990-86012




I5RS0C721014-01

Relief valve Removal and Installation

S7RW0C7216027

Removal

- 1) Recover refrigerant from the A/C system with recovery and recycling equipment referring to "Recovery" in "Operation Procedure for Refrigerant Charge: Manual Type".
- 2) Remove right side engine under cover.
- 3) Remove relief valve (1) from compressor (2).




I4RS0A720048-01

Installation

Reverse removal procedure noting the following instructions.

- Use new O-ring
- Apply compressor oil to O-ring.
- Tighten relief valve to the specified torque.

Tightening torque**Relief valve (a): 8 N·m (0.8 kgf-m, 6.0 lb-ft)**

I4RS0A720049-01

- Evacuate and charge the A/C system referring to "Evacuation" and "Charge" in "Operation Procedure for Refrigerant Charge: Manual Type".

Specifications**Tightening Torque Specifications**

S7RW0C7217001

Fastening part	Tightening torque			Note
	N·m	kgf-m	lb-ft	
Expansion valve bolt	4.5	0.45	3.5	☞
A/C refrigerant pressure sensor	11	1.1	8.0	☞
Compressor mounting bolt	25	2.5	18.0	☞
Armature plate nut	16	1.6	11.5	☞
Relief valve	8	0.8	6.0	☞

NOTE

The specified tightening torque is also described in the following.

"A/C System Major Components Location: Manual Type"

"Compressor Assembly Components: Manual Type"

Reference:

For the tightening torque of fastener not specified in this section, refer to "Fasteners Information in Section 0A".

Special Tools and Equipment

Recommended Service Material

S7RW0C7218001

Material	SUZUKI recommended product or Specification		Note
Compressor oil	MATSUSHITADENKI GU10	P/No.: 99000-99015-00A	☞
Silicon sealant	SUZUKI SILICON SEALANT KE-347W (100g)	P/No.: 99000-34220	☞

NOTE





Required service material is also described in the following.

“HVAC Unit Components: Manual Type”

“Compressor Assembly Components: Manual Type”

Special Tool

S7RW0C7218002

09900-06107 Snap ring pliers (opening type) ☞ / ☞ / ☞ / ☞ / ☞		09990-06020 Manifold gauge set (R134a) 
09990-86012 Gas leak detector This kit includes following items. 1. Gas leak detector, 2. Instruction manual, 3. Filter, 4. Sensor, 5. Dri-sell battery (size D) ☞ / ☞		09991-06310 Armature plate holder ☞ / ☞ 

Automatic Type

Precautions

A/C System Caution

S7RW0C7220001

Refer to “A/C System Caution: Manual Type”.

Precautions in Diagnosing Trouble

S7RW0C7220002

- Do not disconnect couplers from HVAC control module, battery cable from battery, HVAC control module ground wire harness from body or main fuse before confirming diagnostic information (diagnostic trouble code) stored in HVAC control module memory.
- Diagnostic information (diagnostic trouble code) stored in HVAC control module can be checked by display of HVAC control module. Also, it can be checked by using SUZUKI scan tool. Before checking diagnostic information (diagnostic trouble code), read this manual and operator's manual for SUZUKI scan tool to know how to read diagnostic information (diagnostic trouble code).
- When trouble is diagnosed using diagnostic information (diagnostic trouble code) on display of HVAC control module, keep in your mind that each diagnostic information (diagnostic trouble code) has priority, and only diagnostic information (diagnostic trouble code) which has the highest priority is indicated. Therefore, after troubleshooting the malfunction, make sure if there exists any other diagnostic information (diagnostic trouble code).
- Be sure to read “Precautions for Electrical Circuit Service in Section 00” before inspection.

Precautions on Servicing A/C System

S7RW0C7220003

Refer to “Precautions on Servicing A/C System: Manual Type”.

General Description

Auto A/C System Description

S7RW0C7221001

The automatic type air conditioning system (auto A/C) is provided with the function to automatically control the inside air temperature, fan speed, air flow outlet direction and air intake position by HVAC control module in addition to functions of the manual type air conditioning system (manual A/C). Once the inside air temperature is set using the temperature selector, HVAC control module automatically controls the inside air temperature at the constant level at all times based on the inside air temperature, outside air temperature, amount of sunlight and engine coolant temperature detected respectively by the inside air temperature sensor, outside air temperature sensor, sunload sensor and ECT sensor. For the electronic control system components location, refer to “Electronic Control System Components Location: Manual Type”. For the A/C system components location, refer to “A/C System Major Components Location: Automatic Type”.

Refer to “Auto A/C Electronic Control Input / Output Diagram: Automatic Type”.

HVAC Control Description

S7RW0C7221002

Temperature Control

HVAC control module calculates the target temperature control door position based on signals from the temperature selector, inside air temperature sensor, outside air temperature sensor and sunload sensor and controls the temperature control actuator so that the current position of the temperature control door matches its target position.

Fan Speed Control

HVAC control module calculates the target blower fan speed based on signals from the temperature selector, inside air temperature sensor, outside air temperature sensor, ECT sensor and sunload sensor, compares it with the current blower fan speed inputted from the blower motor controller to control the current blower fan speed to the target level.

Air Flow Outlet Control

HVAC control module calculates the target temperature control door position based on signals from the temperature selector, inside air temperature sensor, outside air temperature sensor, ECT sensor and sunload sensor. Using thus obtained target temperature control door position, it further calculates the target air flow control door position and controls the air flow control actuator so that the current air flow control door position becomes the target position.

Air Intake Position Control

HVAC control module determines the position of the air intake control door based on signals from the temperature selector, inside air temperature sensor, outside air temperature sensor and sunload sensor and selects any of the following positions by controlling the position of the air intake control door.

- FRESH position (FRE)
- RECIRCULATION position (REC)
- MIX position (MIX)

A/C Compressor Relay Control

HVAC control module outputs A/C switch ON signal to ECM via BCM when the vehicle state satisfy conditions described below.

- A/C switch is ON
- Evaporator temperature is higher than specified value
- Evaporator temperature sensor malfunction is not detected

Communication of ECM and BCM is established by CAN (Controller Area Network). (For more detail of CAN communication, refer to "CAN Communication System Description in Section 1A").

ECM turns ON the A/C compressor relay when the vehicle state satisfy conditions described below.

- A/C switch ON signal is inputted
- A/C refrigerant pressure is within specified range
- Engine speed is within specified range
- Engine coolant temperature is lower than specified value
- Throttle opening is lower than specified value
- Vehicle is not in either state of starting or quick acceleration
- ECT sensor malfunction is not detected
- A/C refrigerant pressure sensor malfunction is not detected

Condenser Cooling Fan Relay Control

ECM turn ON the condenser cooling fan relay at the same time when ECM turn ON the A/C compressor relay.

Sub-Cool A/C System Description

S7RW0C7221003

Refer to "Sub-Cool A/C System Description: Manual Type".

On-Board Diagnostic System Description

S7RW0C7221004

NOTE

The diagnostic information as diagnostic trouble code (DTC) can be known by using SUZUKI scan tool. For further details, refer to "DTC Check: Automatic Type".


HVAC control module detects malfunctions, which may occur in the following area.

- Inside air temperature sensor
- Evaporator temperature sensor
- Sunload sensor
- Temperature control actuator
- Air flow control actuator
- Temperature selector of HVAC control module
- Air flow selector of HVAC control module
- Blower speed selector of HVAC control module
- Back-up power supply circuit of HVAC control module
- Serial communication line between BCM and HVAC control module

7B-39 Air Conditioning System: Automatic Type

- Received data from BCM as follows
 - Outside air temperature sensor signal
 - ECT sensor signal
 - A/C refrigerant pressure sensor signal
 - VSS signal
 - Engine type signal
 - Combination meter spec signal
 - CAN communication circuit failure signal

When HVAC control module detects malfunction, the “A/C” indicator light (1) flashes to warn and the diagnostic trouble code (DTC) is stored in the memory of the module. When diagnosing trouble, the DTC can be checked according to “DTC Check: Automatic Type”.




I5RW0A722002-01

Schematic and Routing Diagram

Auto A/C Electronic Control Input / Output Diagram

S7RW0C722001



I6RW0C722001-01


A/C System Air Flow Diagram

Refer to “A/C System Air Flow Diagram: Manual Type”.

S7RW0C722002

A/C System Wiring Diagram

S7RW0C722003



7B-41 Air Conditioning System: Automatic Type

[A]: Hatchback model	10. Air intake actuator	22. Compressor	34. "A/C" indicator light
[B]: Sedan model	11. Air flow control actuator	23. HVAC control module	35. Rear defogger switch
[C]: Illumination control model	12. Temperature control actuator	24. BCM	36. Rear defogger indicator
1. Main fuse box	13. Inside air temperature sensor	25. A/C refrigerant pressure sensor	37. To other control module
2. Ignition switch	14. Outside air temperature sensor	26. Condenser cooling fan relay	38. Indicator light, switch, selector
3. CAN junction connector	15. Evaporator temperature sensor	27. Information display	39. "FRE" indicator light
4. Rear defogger relay	16. Sunload sensor	28. Lighting switch	40. "REC" indicator light
5. Rear defogger	17. Junction block assembly	29. A/C switch	41. Temperature selector
6. Blower motor relay	18. ECM	30. Air intake selector	42. Blower speed selector
7. Blower motor	19. ECT sensor	31. To BCM	43. MODE (air flow) selector
8. Blower motor controller	20. Condenser cooling fan motor	32. ABS control module	44. Tail light
9. DLC	21. Compressor relay	33. Illumination light	45. Main relay

Component Location

A/C System Major Components Location

S7RW0C7223001


Refer to "A/C System Major Components Location: Manual Type".

Electronic Control System Components Location

S7RW0C7223002

NOTE

The figure shows left-hand steering vehicle. For right-hand steering vehicle, parts with (*) are installed at the opposite side.



I6RW0C722003-01

[A]: Junction block assembly viewed from relay side	8. Junction block assembly	16. Blower motor controller
1. A/C refrigerant pressure sensor	9. Sunload sensor	17. HVAC control module
2. Compressor relay	10. Inside air temperature sensor	18. Temperature selector
3. Condenser cooling fan relay	11. Air flow control actuator	19. Blower speed selector
4. Outside air temperature sensor	12. Temperature control actuator	20. MODE (air flow) selector
5. ECT sensor	13. Evaporator temperature sensor	21. A/C switch
6. Condenser cooling fan	14. Air intake actuator	22. Air intake selector
7. Blower motor relay	15. Blower motor	23. Rear defogger switch

Diagnostic Information and Procedures

Air Conditioning System Check

S7RW0C7224001

Step	Action	Yes	No
1	Customer complaint analysis 1) Perform ☞ "Customer complaint analysis". <i>Was customer complaint analysis performed?</i>	Go to Step 2.	Perform customer complaint analysis.
2	Visual inspection 1) Perform ☞ "Visual inspection". <i>Is there any faulty condition?</i>	Repair or replace malfunction part.	Go to Step 3.
3	DTC check 1) Perform ☞ "DTC check". <i>Is there any DTC code?</i>	Go to Step 4.	Go to Step 5.
4	DTC troubleshooting 1) Perform ☞ "DTC Troubleshooting". <i>Is there any faulty condition?</i>	Repair or replace malfunction part, and go to Step 7.	Go to Step 5.
5	A/C system performance inspection 1) Perform ☞ "A/C system performance inspection". <i>Is there any faulty condition?</i>	Repair or replace malfunction part, and go to Step 8.	Go to Step 6.
6	Perform A/C system symptom diagnosis 1) Inspect and repair referring to "A/C System Symptom Diagnosis: Automatic Type". <i>Is there any faulty condition?</i>	Repair or replace malfunction part, and go to Step 7.	Go to Step 8.
7	Check for intermittent problem 1) Check for intermittent troubles referring to "Intermittent and Poor Connection Inspection in Section 00". <i>Is there any faulty condition?</i>	Repair or replace malfunction part, and go to Step 8.	Go to Step 8.
8	Final confirmation test 1) Perform ☞ "Final confirmation test". <i>Is there any malfunction code?</i>	Go to Step 4.	End.

Description for Each Step**Step 1. Customer complaint analysis**

Talk to customer, and then record details of the problem.

Customer questionnaire (Example)

Customer's Name:	Model:	VIN:	
Date of Issue:	Date of Reg:	Date of Problem:	Mileage:

Problem Symptoms	● A/C switch indicator lamp abnormal: fails to turn on/fails to turn off/flashes ● Abnormal noise while A/C compressor is working: from compressor/ from condenser fan motor other_____ ● Chattering from A/C compressor: ● Condenser fan motor does not work: ● A/C compressor does not work: ● Other:
Frequency of Occurrence	● Continuous/Intermittent (_____ times a day, a month)/ other_____
Conditions for Occurrence of Problem	● Vehicle at stop & A/C compressor is working: ● For some time after A/C switch is ON: ● When outside air temperature is high: ● When outside air temperature is low: ● All the time:
Environmental Condition	● Weather: fair/cloudy/rain/snow/other_____ ● Temperature: °F (_____ °C)
Diagnostic Trouble Code	● First check: _____ Normal code/malfunctional code (_____) ● Second check after test drive: Normal code/malfunctional code (_____)

I4RH01722014-01

NOTE

The form is a standard sample. It should be modified according to conditions characteristic of each market.

Step 2. Visual inspection

As a preliminary step, be sure to perform visual check of the items that support proper function of the air conditioning system referring to "Visual Inspection: Automatic Type".

Step 3. DTC check

Check DTC referring to "DTC Check: Automatic Type".

Step 4. DTC troubleshooting

Based on the DTC, perform an applicable DTC diagnostic flow and locate the cause of the trouble, namely in a sensor, wire harness, connector, actuator, HVAC control module or other part and repair faulty parts.

Step 5. A/C system performance inspection

Inspect A/C system suspected to be a possible cause referring to "A/C System Performance Inspection: Manual Type".

Step 6. A/C system symptom diagnosis

Check any part or system suspected to be a possible cause referring to "A/C System Symptom Diagnosis: Automatic Type".

Step 7. Check for intermittent problem

Check any part where an intermittent trouble is easy to occur (e.g., wire harness, connector, etc.), referring to "Intermittent and Poor Connection Inspection in Section 00" and related circuit of trouble cord recorded.

Step 8. Final confirmation test

Confirm if the problem symptom is troubleshoot and the A/C system is free from any abnormal conditions. If there existed DTC, clear the DTC. Then, check if the DTC is still detected and if there is any other DTC.

A/C System Symptom Diagnosis

S7RW0C7224002

Condition	Possible cause	Correction / Reference Item
No cool air comes out (A/C system does not operate)	No refrigerant	Perform recovery, evacuation and charge referring to "Operation Procedure for Refrigerant Charge: Manual Type".
	Fuse blown	Check related fuses, and then check for short circuit to ground.
	A/C switch faulty	Check A/C switch referring to "Inspection of HVAC Control Module and Its Circuit: Automatic Type".
	Evaporator temperature sensor faulty	Check evaporator temperature sensor referring to "Evaporator Temperature Sensor Inspection: Manual Type".
	A/C refrigerant pressure sensor faulty	Check A/C refrigerant pressure sensor referring to "A/C Refrigerant Pressure Sensor and Its Circuit Inspection: Manual Type".
	Wiring or grounding faulty	Repair as necessary.
	ECM faulty	Check ECM referring to "A/C System Inspection at ECM: Automatic Type".
	HVAC control module faulty	Check HVAC control module referring to "Inspection of HVAC Control Module and Its Circuit: Automatic Type".
	Magnet clutch faulty	Check magnet clutch referring to "Magnet Clutch Inspection: Manual Type".
	Compressor drive belt loosened or broken	Adjust or replace drive belt.
	Compressor faulty	Check compressor.
	Compressor relay faulty	Check compressor relay referring to "A/C System Relay Inspection: Manual Type".
	BCM faulty	Check BCM referring to "Inspection of BCM and Its Circuits in Section 10B".
No cool air comes out (radiator cooling fan motor does not operate)	Fuse blown	Check related fuses, and then check for short circuit to ground.
	Wiring or grounding faulty	Repair as necessary.
	Condenser cooling fan motor relay faulty	Check condenser cooling fan motor relay referring to "A/C System Relay Inspection: Manual Type".
	Condenser cooling fan motor faulty	Check condenser cooling fan motor referring to "Condenser Cooling Fan Inspection: Manual Type".
	ECM faulty	Check ECM referring to "A/C System Inspection at ECM: Automatic Type".
	HVAC control module faulty	Check HVAC control module referring to "Inspection of HVAC Control Module and Its Circuit: Automatic Type".

Condition	Possible cause	Correction / Reference Item
No cool air comes out (blower motor does not operate)	Fuse blown	Check related fuses, and then check for short circuit to ground.
	Blower motor controller faulty	Check blower motor controller referring to "Blower Motor Controller Inspection: Automatic Type".
	HVAC control module faulty	Check HVAC control module referring to "Inspection of HVAC Control Module and Its Circuit: Automatic Type".
	Wiring or grounding faulty	Repair as necessary.
	Blower motor faulty	Check blower motor referring to "Blower Motor Inspection in Section 7A".
	Blower motor relay faulty	Check blower motor relay referring to "Blower Motor Relay Inspection in Section 7A".
Cool air does not come out or insufficient cooling (A/C compressor normal operation)	Insufficient or excessive charge of refrigerant	Check the amount of refrigerant and system for leaks.
	Condenser clogged	Check condenser referring to "Condenser Assembly On-Vehicle Inspection: Manual Type".
	A/C evaporator clogged or frosted	Check A/C evaporator and evaporator temperature sensor referring to "Evaporator Inspection: Manual Type" and "Evaporator Temperature Sensor Inspection: Manual Type".
	Evaporator temperature sensor faulty	Check evaporator temperature sensor referring to "Evaporator Temperature Sensor Inspection: Manual Type".
	Expansion valve faulty	Check expansion valve referring to "Expansion Valve Inspection: Manual Type".
	Desiccant clogged	Check desiccant and cap with filter.
	Compressor drive belt loosened or broken	Adjust or replace drive belt.
	Magnet clutch faulty	Check magnet clutch referring to "Magnet Clutch Inspection: Manual Type".
	Compressor faulty	Check compressor.
	Air in A/C system	Replace condenser, and then perform evacuation and charge referring to "Operation Procedure for Refrigerant Charge: Manual Type".
	Air leaking from HVAC unit or air duct	Repair as necessary.
	Heater and ventilation system faulty	Check HVAC unit.
	HVAC control module faulty	Check HVAC control module referring to "Inspection of HVAC Control Module and Its Circuit: Automatic Type".
	Temperature control actuator faulty	Check temperature control actuator referring to "Temperature Control Actuator and Its Circuit Inspection: Automatic Type".
	Blower motor faulty	Check blower motor referring to "Blower Motor Inspection in Section 7A".
	Excessive compressor oil in A/C system	Drain excessive compressor oil from A/C system circuit and compressor.
Cool air does not come out only intermittently	Wiring connection faulty	Repair as necessary.
	Expansion valve faulty	Check expansion valve referring to "Expansion Valve Inspection: Manual Type".
	Excessive moisture in A/C system	Replace condenser, and then perform evacuation and charge referring to "Operation Procedure for Refrigerant Charge: Manual Type".
	Magnet clutch faulty	Check magnet clutch referring to "Magnet Clutch Inspection: Manual Type".
	Excessive amount of refrigerant	Check the amount of refrigerant.

Condition	Possible cause	Correction / Reference Item
Cool air comes out only at high speed	Condenser clogged	Check condenser referring to "Condenser Assembly On-Vehicle Inspection: Manual Type".
	Insufficient charge of refrigerant	Check the amount of refrigerant and system for leaks.
	Air in A/C system	Replace condenser, and then perform evacuation and charge referring to "Operation Procedure for Refrigerant Charge: Manual Type".
	Compressor drive belt loosened or broken	Adjust or replace drive belt.
	Compressor faulty	Check compressor.
Cool air does not come out only at high speed	Excessive amount of refrigerant	Check the amount of refrigerant.
	A/C evaporator frosted	Check A/C evaporator and evaporator temperature sensor referring to "Evaporator Inspection: Manual Type" and "Evaporator Temperature Sensor Inspection: Manual Type".
Insufficient air flow of cooled air	A/C evaporator clogged or frosted	Check A/C evaporator and evaporator temperature sensor referring to "Evaporator Inspection: Manual Type" and "Evaporator Temperature Sensor Inspection: Manual Type".
	Air leaking from HVAC unit or air duct	Repair as necessary.
	Blower motor faulty	Check blower motor referring to "Blower Motor Inspection in Section 7A".
	Wiring or grounding faulty	Repair as necessary.

Abnormal Noise Symptom Diagnosis of A/C System

S7RW0C7224003

Refer to "Abnormal Noise Symptom Diagnosis of A/C System: Manual Type".

DTC Check


S7RW0C7224004

Using SUZUKI Scan Tool

- 1) Turn ignition switch to OFF position.
- 2) Connect SUZUKI scan tool to data link connector (DLC) (1) located on underside of instrument panel at driver's seat side.

Special tool

(A): SUZUKI scan tool



I5RW0A722004-01

- 3) Light over sunload sensor vertically with an incandescent light of approximately 100 W apart from about 100 mm (3.94 in.).

NOTE

If sunload sensor is not lighted over with an incandescent light, DTC B1504 is detected even though there is not any malfunction.

- 4) Turn ignition switch to ON position.
- 5) Read DTC displayed on SUZUKI scan tool.

NOTE

To know how to use SUZUKI scan tool, refer to operator's manual for SUZUKI scan tool.

- 6) After completing the check, turn ignition switch to OFF position and disconnect SUZUKI scan tool from data link connector (DLC).

Not Using SUZUKI Scan Tool

NOTE

In case of malfunction of temperature selector, blower speed selector and air flow selector, DTC can not be checked by the following procedure. Use SUZUKI scan tool for DTC check.

- 1) Light over sunload sensor vertically with an incandescent light of approximately 100 W apart from about 100 mm (3.94 in.).


NOTE

If sunload sensor is not lighted over with an incandescent light, DTC of sunload sensor is detected as current DTC even though there is not any malfunction.

- 2) Set the following selectors to specified positions below respectively with ignition switch off position.
 - Temperature selector (1) is maximum cool position
 - Blower speed selector (2) is OFF position
 - Air flow selector (3) is AUTO position
- 3) While pressing A/C switch (4) and air intake selector (5) simultaneously, turn ignition switch to ON position.
- 4) Wait for about 5 seconds (start of diagnosis).
- 5) Read flashing pattern of "FRE" (6) and "REC" (7) indicator lights which represents DTC and write it down.


NOTE

- When 2 or more current DTCs are detected, only DTC having the highest priority is indicated. Therefore, after troubleshooting the malfunction, DTC check has to be performed again to see if any other DTC(s) is detected.
- Pressing "A/C" switch alternates display of current DTC and history DTC. "A/C" indicator light (8) remains off when display is in current DTC mode and it lights up when display is in history DTC mode.
- When a history DTC is indicated while 2 or more history DTCs are detected, it is possible to have other history DTC(s) stored in HVAC control module displayed by pressing the air intake selector.



I5RW0A722005-01


Example: When inside air temperature sensor circuit malfunction (Open) is set



I5RW0A722006-02

[A]: "REC" indicator light	L: OFF
[B]: "FRE" indicator light	a. About 0.5 seconds
H: ON	b. About 2 seconds

Example: When VSS signal failure (Data error) is set



I5RW0A722025-01

[A]: "REC" indicator light	a. About 0.5 seconds
[B]: "FRE" indicator light	b. About 3 seconds
H: ON	c. About 1.5 seconds
L: OFF	


- 6) After completing above check, turn ignition switch to "OFF" position.

DTC Clearance

S7RW0C7224005

Using SUZUKI Scan tool

- 1) Turn ignition switch to OFF position.
- 2) Connect SUZUKI scan tool to data link connector (DLC) (1) located on underside of instrument panel at driver's seat side.

Special tool**(A): SUZUKI scan tool**

I5RW0A722004-01

- 3) Turn ignition switch to ON position.
- 4) Erase DTC according to instructions displayed on SUZUKI scan tool.


NOTE

To know how to use SUZUKI scan tool, refer to operator's manual for SUZUKI scan tool.

- 5) After completing the clearance, perform "DTC Check" and confirm if normal DTC (No code) is displayed.
- 6) Turn ignition switch to OFF position, and then disconnect SUZUKI scan tool from DLC.

Not Using SUZUKI Scan Tool

- 1) Display history DTC by HVAC control module referring to "Not Using SUZUKI Scan Tool" under "DTC Check".
- 2) Press air intake selector (1) and "A/C" switch (2) at the same time for 5 seconds or more.



I5RW0A722007-01

- 3) After completing above Steps, turn ignition switch to OFF position.
- 4) Perform "DTC Check" and confirm if normal DTC is indicated.

DTC Table

S7RW0C7224006

⚠ CAUTION

Be sure to perform "Air Conditioning System Check: Automatic Type" before starting diagnosis.

NOTE

- History DTC is such DTC which HVAC control module saves in its memory when it detects current DTC for 60 seconds or more continuously.
- DTC B1504, B1541, B1546, B1570 and B1571 are displayed as a current DTC only when a current malfunction is detected.
- When HVAC control module detects DTC B1513 and B1514, both current and history DTCs are displayed at the same time.

DTC No. (displayed on SUZUKI scan tool)	Detection item	DTC (indicated on HVAC control module)		Condition when trouble detected (DTC is determined when following condition detected)	"A/C" indicator light
		Indicated by "REC" indicator light	Indicated by "FRE" indicator light		
B1502	Inside Air Temperature Sensor Circuit Malfunction	2	1	Signal voltage of inside air temperature sensor is higher than specification.	Flashed
		2	2	Signal voltage of inside air temperature sensor is lower than specification.	Flashed
B1503	Evaporator Temperature Sensor Circuit Malfunction	3	1	Signal voltage of evaporator temperature sensor is higher than specification.	Flashed
		3	2	Signal voltage of evaporator temperature sensor is lower than specification.	Flashed

DTC No. (displayed on SUZUKI scan tool)	Detection item	DTC (indicated on HVAC control module)		Condition when trouble detected (DTC is determined when following condition detected)	“A/C” indicator light
		Indicated by “REC” indicator light	Indicated by “FRE” indicator light		
☞ B1504	Sun load Sensor Circuit Malfunction	4	1	- Signal voltage of sun load sensor is higher than specification. - Without sunlight.	—
		4	2	Signal voltage of sun load sensor is lower than specification.	Flashed
☞ B1511	Temperature Control Actuator (Position Sensor) and/or Its Circuit Malfunction	6	1	Signal voltage of position sensor included in temperature control actuator is higher than specification.	Flashed
		6	2	Signal voltage of position sensor included in temperature control actuator is lower than specification.	Flashed
☞ B1512	Air Flow Control Actuator (Position Sensor) and/or Its Circuit Malfunction	7	1	Signal voltage of position sensor included in airflow control actuator is higher than specification.	Flashed
		7	2	Signal voltage of position sensor included in airflow control actuator is lower than specification.	Flashed
☞ B1513	Temperature Control Actuator (Motor) and/or Its Circuit Malfunction	6	3	Motor of temperature control actuator is not operated more than specified time.	Flashed
☞ B1514	Air Flow Control Actuator (Motor) and/or Its Circuit Malfunction	7	3	Motor of air flow control actuator is not operated more than specified time.	Flashed
☞ B1520	Temperature Selector Malfunction	15	1	Signal voltage of temperature selector in HVAC control module is higher than specification.	Flashed
		15	2	Signal voltage of temperature selector in HVAC control module is lower than specification.	Flashed
☞ B1521	Blower Speed Selector Malfunction	16	1	Signal voltage of blower speed selector in HVAC control module is higher than specification.	Flashed
		16	2	Signal voltage of blower speed selector in HVAC control module is lower than specification.	Flashed
☞ B1522	Air Flow Selector Malfunction	17	1	Signal voltage of airflow selector in HVAC control module is higher than specification.	Flashed
		17	2	Signal voltage of airflow selector in HVAC control module is lower than specification.	Flashed
☞ B1541	Back-up Power Supply Circuit Malfunction	14	1	- Back-up power supply voltage of HVAC control module is higher than or lower than specification. - When connect battery with vehicle and then, turn ignition switch to ON position for first time.	—
☞ B1546	A/C Refrigerant Pressure Malfunction	13	5	- Signal voltage of outside air temperature sensor is more than specified value. However, A/C refrigerant pressure is less than specified value. - Insufficient refrigerant in A/C system.	—
☞ B1551	Serial Communication Circuit Malfunction	9	1	Circuit voltage of serial communication circuit is higher than specification.	Flashed
		9	2	Circuit voltage of serial communication circuit is lower than specification.	Flashed



DTC No. (displayed on SUZUKI scan tool)	Detection item	DTC (indicated on HVAC control module)		Condition when trouble detected (DTC is determined when following condition detected)	“A/C” indicator light
		Indicated by “REC” indicator light	Indicated by “FRE” indicator light		
☞ B1552	HVAC Control Module Check Sum Error	9	4	HVAC control module received unspecified data from BCM more than 8 times.	Flashed
☞ B1553	CAN Communication Circuit Malfunction	10	4	HVAC control module received signal indicating reception error from ECM.	Flashed
☞ B1557	VSS Signal Failure	11	4	HVAC control module receives invalid data of VSS signal from BCM.	—
☞ B1561	ECT signal Failure	5	4	HVAC control module receives invalid data of ECT signal from BCM.	Flashed
☞ B1562	Outside Temperature Sensor Signal Failure	1	4	HVAC control module receives invalid data of outside air temperature sensor signal from BCM.	Flashed
☞ B1563	A/C Refrigerant Pressure Sensor Signal Failure	13	4	HVAC control module receives invalid data of A/C refrigerant pressure sensor signal from BCM.	—
☞ B1570	Engine Type Signal Failure	20	4	HVAC control module receives invalid data of engine type signal from BCM.	—
☞ B1571	Combination Meter Spec Signal Failure	21	4	HVAC control module receives invalid data of combination meter spec signal from BCM.	—
NO CODE	Normal	See NOTE below		—	—

DTC of A/C System detected by ECM

DTC No.	Detection item	Detecting condition (DTC will set when detecting)	MIL
P0481	Fan 2 Control Circuit	Refer to “DTC Table in Section 1A”.	
P0532	A/C Refrigerant Pressure Sensor Circuit Low		
P0533	A/C Refrigerant Pressure Sensor Circuit High		

NOTE

When no DTC is detected, “FRE” [A] and “REC” [B] indicator lights on HVAC control module flash at the same time in specific pattern.



ISRW0A722008-01

H: ON	a. About 3 seconds
L: OFF	b. About 1 seconds

Fail-Safe Table

When any of the following malfunctions (DTCs) is detected, fail-safe mode is activated.

However, when HVAC control module detects normal operation of A/C system, fail-safe mode is canceled.

DTC No.	Trouble Area	Fail-Safe Operation	
		When ignition switch is turned ON after malfunction is already detected	When malfunction is detected during ignition switch is ON
☞ B1502	Inside air temperature sensor circuit	HVAC control module maintains last normal value.	HVAC control module controls actuators assuming that inside air temperature is 25 °C (77 °F).
☞ B1503	A/C evaporator temperature sensor circuit	HVAC control module assuming that evaporator temperature is 0 °C (32 °F).	• HVAC control module turns off A/C switch signal. • HVAC control module controls actuators assuming that evaporator temperature is 0 °C (32 °F).
☞ B1504	Sunload sensor circuit	HVAC control module maintains last normal value.	HVAC control module controls actuators assuming that amount of sunlight is 0 W/ m ² .
☞ B1520	Temperature selector malfunction	HVAC control module maintains last normal value.	HVAC control module controls actuators assuming that setting of temperature selector is 25 °C (77 °F) position.
☞ B1521	Blower speed selector malfunction	HVAC control module maintains last normal value.	HVAC control module controls actuators assuming that setting of blower speed selector is low (1st) position.
☞ B1522	Air flow selector malfunction	HVAC control module maintains last normal value.	HVAC control module controls actuators assuming that setting of air flow selector is DEF position.
☞ B1551	Serial communication circuit	• HVAC control module maintains last normal value of outside air temperature. 4 seconds after, HVAC control module assuming that outside air temperature is 20 °C (68 °F). • HVAC control module maintains last normal value of engine coolant temperature. 4 seconds after, HVAC control module assuming that engine coolant temperature is 80 °C (176 °F). • HVAC control module controls actuators assuming that vehicle speed is 40 km/h (25 mph). • HVAC control module controls actuators assuming that engine type signal is J20. • HVAC control module controls actuators assuming that combination meter spec signal is US.	HVAC control module controls actuators assuming that outside air temperature is 20 °C (68 °F), engine coolant temperature is 80 °C (176 °F), vehicle speed is 40 km/h (25 mph), engine type signal is J20 and combination meter spec signal is US.
☞ B1552	HVAC control module check sum error		
☞ B1553	CAN communication circuit		
☞ B1557	VSS signal failure	HVAC control module controls actuators assuming that vehicle speed is 40 km/h (25 mph).	
☞ B1561	ECT signal failure	HVAC control module maintains last normal value of engine coolant temperature. 4 seconds after, HVAC control module assuming that engine coolant temperature is 80 °C (176 °F).	HVAC control module controls actuators assuming that engine coolant temperature is 80 °C (176 °F).

DTC No.	Trouble Area	Fail-Safe Operation	
		When ignition switch is turned ON after malfunction is already detected	When malfunction is detected during ignition switch is ON
B1562	Outside air temperature signal failure	HVAC control module maintains last normal value of outside air temperature. 4 seconds after, HVAC control module assuming that outside air temperature is 20 °C (68 °F).	HVAC control module controls actuators assuming that outside air temperature is 20 °C (68 °F).
B1570	Engine type signal failure	HVAC control module controls actuators assuming that engine type signal is J20.	
B1571	Combination meter spec signal failure	HVAC control module controls actuators assuming that combination meter spec signal is US.	

Scan Tool Data

S7RW0C7224008

As the data values given in the following are standard values estimated on the basis of values obtained from the normally operation vehicles by using a scan tool, use them as reference values. Even when the vehicles are in good condition, there may be cases where the checked values do not fall within each specifies data range. Therefore, judgement as abnormal should not be made by checking with these data alone.

Scan Tool Data	Condition	Normal Condition / Reference Value
TEMP CONT SWITCH	Ignition switch turned ON and temperature selector at maximum cool position	MAX Cool (Selected position of temperature selector is displayed)
CABIN TEMPERATURE	Ignition switch turned ON	In-car temperature is displayed
OUTSIDE AIR TEMP	Ignition switch turned ON	Outside air temperature is displayed
EVAPORATOR TEMP	Ignition switch turned ON	Evaporator temperature is displayed
COOLANT TEMP	Ignition switch turned ON	Engine coolant temperature is displayed
SUN LOAD	Reference value depends on the situation	0 W/m ² – 1988 W/m ²
MODE CONT SWITCH	Ignition switch turned ON and air flow selector at AUTO position	AUTO (Selected position of air flow selector is displayed)
FAN CONT SWITCH	Ignition switch turned ON and blower speed selector at AUTO position	AUTO (Selected position of blower speed selector is displayed)
FAN DESIRED VOLT	Ignition switch turned ON and blower speed selector at High	Approx. 12.0 V
	Ignition switch turned ON and blower speed selector at Low	Approx. 4.0 V
AIR MIX POS SEN	Ignition switch turned ON and temperature selector at maximum cool position	Approx. 0.5 V
	Ignition switch turned ON and temperature selector at maximum hot position	Approx. 4.5 V
MODE POS SENSOR	Ignition switch turned ON and air flow selector at DEF position	Approx. 4.5 V
	Ignition switch turned ON and air flow selector at VENT position	Approx. 0.5 V
A/C CONT SIG	A/C switch turned ON, blower speed selector at other than OFF position with engine running	ON
	A/C switch turned OFF with engine running	OFF
BLOWER LOAD SIG	Ignition switch turned ON, blower speed selector at other than OFF position	ON
	Ignition switch turned ON, blower speed selector at OFF position	OFF

Scan Tool Data	Condition	Normal Condition / Reference Value
AIR INTAKE MODE	Ignition switch turned ON and air intake selector at fresh air (FRE) position	FRE
	Ignition switch turned ON and air intake selector at recirculation air (REC) position	REC
	Ignition switch turned ON, air flow selector and blower speed selector at AUTO position	AUTO
REFRIGERANT PRESSURE	A/C ON (A/C is operating) with engine running at ambient temperature 30 °C (86 °F)	1240 – 1620 kPa (For details, refer to pressure of high pressure gauge under “A/C System Performance Inspection: Manual Type”)
	A/C OFF (A/C is not operating) with engine running at ambient temperature 30 °C (86 °F) and engine coolant temperature 90 °C (194 °F) – 100 °C (212 °F)	600 – 1000 kPa after longer than 10 minute for A/C switch turned off
A/C COMP CLUTCH	A/C switch turned ON, blower speed selector at other than OFF position with engine running	ON
	A/C switch turned OFF with engine running	OFF
VEHICLE SPEED	At stop with ignition switch turned ON	0 km/h (0 mph)
ENGINE TYPE	Ignition switch turned ON	Engine type is displayed.
METER SPEC	Ignition switch turned ON	Combination meter spec is displayed.

Scan Tool Data Definitions

TEMP CONT SWITCH: (Temperature control selector position, Max Cool, °C / °F, Max Hot): This parameter indicates the selected position of temperature control selector.

CABIN TEMPERATURE: (In-car temperature, °C, °F): This parameter indicates the in-car temperature detected by inside air temperature sensor.

OUTSIDE AIR TEMP (Outside air temperature, °C, °F): This parameter indicates the outside air temperature detected by outside air temperature sensor.

EVAPORATOR TEMP (Evaporator temperature, °C, °F): This parameter indicates the temperature of air passed through evaporator.

COOLANT TEMP (Engine Coolant Temperature °C, °F): This parameter indicates the engine coolant temperature detected by engine coolant temperature sensor.

SUN LOAD (W/m²): This parameter indicates the amount of sunlight detected by sunload sensor.

MODE CONT SWITCH (Air flow selector position, AUTO, FACE, B/L, FOOT, D/F, DEF): This parameter indicates the selected position of air flow selector.

FAN CONT SWITCH (Blower speed selector, AUTO, OFF, 1st – 8th): This parameter indicates the selected position of blower speed selector.

FAN DESIRE VOLT (Fan desired voltage, V): This parameter indicates the consumption voltage of blower motor.

AIR MIX POS SENSOR (Temperature control actuator position sensor, V): This parameter indicates the input signal from position sensor in temperature control actuator.

MODE POS SENSOR (Air flow control actuator position sensor, V): This parameter indicates the input signal from position sensor in air flow control actuator.

A/C CONT SIG (A/C control signal, ON, OFF): This parameter indicates the state of A/C switch.

BLOWER LOAD SIG (Blower fan load signal, ON, OFF): ON: Position of blower speed selector is 1st position or more.
OFF: Position of blower speed selector is OFF position.

AIR INTAKE MODE (Air intake selector position, AUTO, FRE, REC): This parameter indicates the selected position of air intake selector.

REFRIGERANT PRESSURE (A/C refrigerant absolute pressure, kPa): This parameter indicates the A/C refrigerant absolute pressure calculated by ECM

A/C COMP CLUCH (A/C compressor magnet clutch, ON, OFF): This parameter indicates the state of the A/C compressor magnet clutch.

VEHICLE SPEED (km/h, mph): This parameter indicates the vehicle speed calculated by ECM.

ENGINE TYPE (Engine type signal, J20): This parameter indicates the engine type signal transmitted by ECM.

METER SPEC (Combination meter spec signal, UK, EU, US, Canada, DOM): This parameter indicates the combination meter spec signal transmitted by combination meter.

Visual Inspection

S7RW0C7224009


Check visually the following parts and systems.

Inspection item	Correction	
Refrigerant	leakage and amount	
A/C pipe or hose	disconnection, looseness and deterioration	
A/C compressor drive belt	looseness and damage	Refer to “Compressor Drive Belt Inspection and Adjustment: Manual Type”.
- Battery - Connectors of electric wire harness	fluid level and corrosion of terminal disconnection and friction	
- Fuses - Parts	burning installation and damage	
Other parts that can be checked visually		

DTC B1502: Inside Air Temperature Sensor Circuit Malfunction

S7RW0C7224010

Wiring Diagram



I7RW01722004-01

[S]: Inside air temperature sensor signal circuit	1. HVAC control module	3. To other sensors
[G]: Inside air temperature sensor ground circuit	2. Inside air temperature sensor	

DTC Detecting Condition and Trouble Area

DTC Detecting Condition	Trouble Area
Inside air temperature sensor signal voltage is higher than or lower than specified value for specified time continuously.	- Inside air temperature sensor circuit - Inside air temperature sensor - HVAC control module

DTC Troubleshooting

NOTE


When DTC B1503, B1504, B1511 and B1512 are indicated together, it is possible that sensor ground circuit is open.

Step	Action	Yes	No
1	Was "Air Conditioning System Check" performed?	Go to Step 2.	Go to "Air Conditioning System Check: Automatic Type".
2	Wire harness check 1) Turn ignition switch to OFF position. 2) Disconnect connectors from inside air temperature sensor and HVAC control module. 3) Check for proper connection to each signal circuit terminal and ground circuit terminal of inside air temperature sensor and HVAC control module connectors. 4) If OK, check that inside air temperature sensor circuit is as follows. • Wiring harness resistance of each inside air temperature sensor signal circuit and ground circuit is less than 3 Ω • Insulation resistance between inside air temperature sensor signal circuit and vehicle body ground is infinity • Circuit voltage of each inside air temperature sensor signal circuit and ground circuit is 0 – 1 V with ignition switch turned ON Are they in good condition?	Go to Step 3.	Inside air temperature sensor signal circuit and/or ground circuit are open, short or high resistance.
3	Inside air temperature sensor reference voltage check 1) Connect connector to HVAC control module with ignition switch turned OFF. 2) Turn ignition switch to ON position. 3) Measure voltage between signal terminal and ground terminal of inside air temperature sensor connector. Is voltage 4.5 – 5.5 V?	Go to Step 4.	Substitute a known-good HVAC control module and recheck.
4	Inside air temperature sensor check 1) Check inside air temperature sensor for performance referring to "Inside Air Temperature Sensor Inspection: Automatic Type". Is it in good condition?	Substitute a known-good HVAC control module and recheck.	Replace inside air temperature sensor.

DTC B1503: Evaporator Temperature Sensor Circuit Malfunction

S7RW0C7224011

Wiring Diagram



I7RW01722005-01

[S]: Evaporator temperature sensor signal circuit	1. HVAC control module	3. To other sensors
[G]: Evaporator temperature sensor ground circuit	2. Evaporator temperature sensor	

DTC Detecting Condition and Trouble Area

DTC Detecting Condition	Trouble Area
Evaporator temperature sensor signal voltage is higher than or lower than specified value for specified time continuously.	- Evaporator temperature sensor circuit - Evaporator temperature sensor - HVAC control module

DTC Troubleshooting

NOTE

When DTC B1502, B1504, B1511 and B1512 are indicated together, it is possible that sensor ground circuit is open.


Step	Action	Yes	No
1	Was "Air Conditioning System Check" performed?	Go to Step 2.	Go to "Air Conditioning System Check: Automatic Type".
2	Wire harness check - Turn ignition switch to OFF position. - Disconnect connectors from evaporator temperature sensor and HVAC control module. - Check for proper connection to each signal circuit terminal and ground circuit terminal of evaporator temperature sensor and HVAC control module connectors. - If OK, check that evaporator temperature sensor circuit is as follows. - Wiring harness resistance of each evaporator temperature sensor signal circuit and ground circuit is less than 3 Ω - Insulation resistance between evaporator temperature sensor signal circuit and vehicle body ground is Infinity - Circuit voltage of each evaporator temperature sensor signal circuit and ground circuit is 0 - 1 V with ignition switch turned ON Are they good condition?	Go to Step 3.	Evaporator temperature sensor signal circuit and/or ground circuit are open, short or high resistance.

Step	Action	Yes	No
3	Evaporator temperature sensor reference voltage check 1) Connect connector to HVAC control module with ignition switch turned OFF. 2) Turn ignition switch to ON position. 3) Measure voltage between signal terminal and ground terminal of evaporator temperature sensor connector. <i>Is voltage 4.5 – 5.5 V?</i>	Go to Step 4.	Substitute a known-good HVAC control module and recheck.
4	Evaporator temperature sensor check 1) Check evaporator temperature sensor for performance referring to “Evaporator Temperature Sensor Inspection: Automatic Type”. <i>Is it in good condition?</i>	Substitute a known-good HVAC control module and recheck.	Replace evaporator temperature sensor.

DTC B1504: Sunload Sensor Circuit Malfunction

S7RW0C7224012

Wiring Diagram



I7RW01722006-01

[S]: Sunload sensor signal circuit	1. HVAC control module	3. To other sensors
[G]: Sunload sensor ground circuit	2. Sunload sensor	

DTC Detecting Condition and Trouble Area

NOTE

When DTC B1502, B1503, B1511 and B1512 are indicated together, it is possible that sensor ground circuit is open.

DTC Detecting Condition	Trouble Area
- Sunload sensor signal voltage is higher than or lower than specified value for specified time continuously. - Without sunlight	- Sunload sensor circuit - Sunload sensor - HVAC control module


DTC Troubleshooting

Step	Action	Yes	No
1	Was "Air Conditioning System Check" performed?	Go to Step 2.	Go to "Air Conditioning System Check: Automatic Type".
2	Wire harness check 1) Turn ignition switch to OFF position. 2) Disconnect connectors from sunload sensor and HVAC control module. 3) Check for proper connection to each signal circuit terminal and ground circuit terminal of sunload sensor and HVAC control module connectors. 4) If OK, check that sunload sensor circuit is as follows. • Wiring harness resistance of each sunload sensor signal circuit and ground circuit is less than 3 Ω • Insulation resistance of each sunload sensor signal circuit and ground circuit between sunload sensor connector and vehicle body ground is Infinity • Circuit voltage of each sunload sensor signal circuit and ground circuit is 0 – 1 V with ignition switch turned ON Are they in good condition?	Go to Step 3.	Sunload sensor power supply circuit and/or signal circuit are open, short or high resistance.
3	Sunload sensor power supply voltage check 1) Connect connector to HVAC control module with ignition switch turned OFF. 2) Turn ignition switch to ON position. 3) Measure voltage between signal terminal and ground terminal of sunload sensor connector. Is voltage 4.5 – 5.5 V?	Go to Step 4.	Substitute a known-good HVAC control module and recheck.
4	Sunload sensor check 1) Check sunload sensor for performance referring to "Sunload Sensor Inspection". Is it in good condition?	Substitute a known-good HVAC control module and recheck.	Replace sunload sensor.

DTC B1511: Temperature Control Actuator (Position Sensor) and/or Its Circuit Malfunction

S7RW0C7224013

Wiring Diagram



I6RW0C722004-01

[P]: Position sensor power supply circuit	[G]: Position sensor ground circuit	2. Temperature control actuator	4. To other sensors
[S]: Position sensor signal circuit	1. HVAC control module	3. To air flow control actuator	

DTC Detecting Condition and Trouble Area

DTC Detecting Condition	Trouble Area
Temperature control actuator position sensor signal voltage is higher than or lower than specified value for specified time continuously.	• Temperature control actuator circuit • Temperature control actuator • HVAC control module

DTC Troubleshooting**NOTE**

- When DTC B1502, B1503, B1504 and B1512 are indicated together, it is possible that sensor ground circuit is open.
- When DTC B1512 is indicated together, it is possible that position sensor power supply circuit is open.

Step	Action	Yes	No
1	Was "Air Conditioning System Check" performed?	Go to Step 2.	Go to "Air Conditioning System Check: Automatic Type".
2	Wire harness check 1) Turn ignition switch to OFF position. 2) Disconnect connectors from temperature control actuator and HVAC control module. 3) Check for proper connection to position sensor power supply, signal and ground circuit terminals of temperature control actuator and HVAC control module connectors. 4) If OK, check that position sensor of temperature control actuator circuit is as follows. • Wiring harness resistance of each position sensor power supply, signal and ground circuit is less than 3 Ω • Insulation resistance of each position sensor power supply, signal and ground circuit is infinity between temperature control actuator connector and vehicle body ground • Circuit voltage of each position sensor power supply, signal and ground circuit is 0 - 1 V with ignition switch turned ON <i>Are they in good condition?</i>	Go to Step 3.	Position sensor power supply, signal circuit and/or ground circuit are open, short or high resistance.
3	Position sensor of temperature control actuator power supply voltage check 1) Connect connector to HVAC control module. 2) Turn ignition switch to ON position. 3) Measure voltage between. • Position sensor power supply terminal and position sensor ground terminal of temperature control actuator connector • Position sensor signal terminal and position sensor ground terminal of temperature control actuator connector <i>Is voltage 4.5 – 5.5 V?</i>	Go to Step 4.	Go to Step 5.


7B-61 Air Conditioning System: Automatic Type

Step	Action	Yes	No
4	Temperature control actuator check 1) Check position sensor of temperature control actuator for performance referring to "Temperature Control Actuator and Its Circuit Inspection: Automatic Type". <i>Is it in good condition?</i>	Substitute a known-good HVAC control module and recheck.	Replace temperature control actuator.
5	Position sensor of temperature control actuator power supply voltage check 1) Turn ignition switch to OFF position. 2) Disconnect connector from air flow control actuator. 3) Turn ignition switch to ON position. 4) Measure voltage between. - Position sensor power supply terminal and position sensor ground terminal of temperature control actuator connector - Position sensor signal terminal and position sensor ground terminal of temperature control actuator connector <i>Is voltage 4.5 – 5.5 V?</i>	Check air flow control actuator and its circuit.	Substitute a known-good HVAC control module and recheck.

DTC B1512: Air flow Control Actuator (Position Sensor) and/or Its Circuit Malfunction

S7RW0C7224014

Wiring Diagram



I6RW0C722005-01

[P]: Position sensor power supply circuit	[G]: Position sensor ground circuit	2. Air flow control actuator	4. To other sensors
[S]: Position sensor signal circuit	1. HVAC control module	3. To temperature control actuator	

DTC Detecting Condition and Trouble Area

DTC Detecting Condition	Trouble Area
Air flow control actuator position sensor signal voltage is higher than or lower than specified value for specified time continuously.	- Air flow control actuator circuit - Air flow control actuator - HVAC control module

DTC Troubleshooting

NOTE

- When DTC B1502, B1503, B1504 and B1511 are indicated together, it is possible that sensor ground circuit is open.
- When DTC B1511 is indicated together, it is possible that position sensor power supply circuit is open.


Step	Action	Yes	No
1	Was "Air Conditioning System Check" performed?	Go to Step 2.	Go to "Air Conditioning System Check: Automatic Type".
2	Wire harness check 1) Turn ignition switch to OFF position. 2) Disconnect connectors from air flow control actuator and HVAC control module. 3) Check for proper connection to position sensor power supply, signal and ground circuit terminals of air flow control actuator and HVAC control module connectors. 4) If OK, check that position sensor of air flow control actuator circuit is as follows. • Wiring harness resistance of each position sensor power supply, signal and ground circuit is less than 3 Ω • Insulation resistance of each position sensor power supply, signal and ground circuit is infinity between air flow control actuator connector and vehicle body ground • Circuit voltage of each position sensor power supply, signal and ground circuit is 0 - 1 V with ignition switch turned ON Are they in good condition?	Go to Step 3.	Position sensor power supply, signal circuit and/or ground circuit are open, short or high resistance.
3	Position sensor of air flow control actuator power supply voltage check 1) Connect connector to HVAC control module with ignition switch turned OFF. 2) Turn ignition switch to ON position. 3) Measure voltage between. • Position sensor power supply terminal and position sensor ground terminal of air flow control actuator connector • Position sensor signal terminal and position sensor ground terminal of air flow control actuator connector Is voltage 4.5 – 5.5 V?	Go to Step 4.	Go to Step 5.
4	Air flow control actuator check 1) Check position sensor of air flow control actuator for performance referring to "Air Flow Control Actuator and Its Circuit Inspection: Automatic Type". Is it in good condition?	Substitute a known-good HVAC control module and recheck.	Replace air flow control actuator.

Step	Action	Yes	No
5	Position sensor of temperature control actuator power supply voltage check 1) Turn ignition switch to OFF position. 2) Disconnect connector from temperature control actuator. 3) Turn ignition switch to ON position. 4) Measure voltage between. - Position sensor power supply terminal and position sensor ground terminal of air flow control actuator connector - Position sensor signal terminal and position sensor ground terminal of air flow control actuator connector <i>Is voltage 4.5 – 5.5 V?</i>	Check temperature control actuator and its circuit.	Substitute a known-good HVAC control module and recheck.

DTC B1513: Temperature Control Actuator (Motor) and/or Its Circuit Malfunction

S7RW0C7224015

Wiring Diagram



I6RW0C722006-02

[D]: Temperature control actuator motor drive circuit	2. Temperature control actuator	4. To other sensors
1. HVAC control module	3. To air flow control actuator	

DTC Detecting Condition and Trouble Area

DTC Detecting Condition	Trouble Area
Motor of temperature control actuator does not move longer than specified time.	- Temperature control actuator circuit - Temperature control linkage - Temperature control actuator - HVAC unit - HVAC control module


DTC Troubleshooting

Step	Action	Yes	No
1	Was "Air Conditioning System Check" performed?	Go to Step 2.	Go to "Air Conditioning System Check: Automatic Type".
2	DTC check 1) Connect scan tool to DLC with ignition switch turned OFF. 2) Turn ignition switch to ON position and check DTC. <i>Is DTC B1511 detected together?</i>	Go to "DTC B1511: Temperature Control Actuator (Position Sensor) and/or Its Circuit Malfunction: Automatic Type".	Go to Step 3.
3	Visual Check Check if there is any obstruction in operating range of actuator linkage and if actuator linkage operates smoothly. <i>Is it in good condition?</i>	Go to Step 4.	Obstruction in operating range of actuator linkage, actuator linkage faulty and/or internal fault of HVAC unit.
4	Wire harness check 1) Turn ignition switch to OFF position. 2) Disconnect connectors from temperature control actuator and HVAC control module. 3) Check for proper connection to actuator motor drive circuit terminals of temperature control actuator and HVAC control module connectors. 4) If OK, check that actuator motor drive circuit of temperature control actuator is as follows. - Wiring harness resistance of each actuator motor drive circuit is less than 3 Ω - Insulation resistance of each actuator motor drive circuit is infinity between temperature control actuator connector and vehicle body ground - Circuit voltage of each actuator motor drive circuit is 0 – 1 V with ignition switch turned ON <i>Are they in good condition?</i>	Go to Step 5.	Actuator motor drive circuit(s) is open, short or high resistance.
5	Wire harness check Check position sensor circuit of temperature control actuator for condition referring to Step 2 of "DTC B1511: Temperature Control Actuator (Position Sensor) and/or Its Circuit Malfunction: Automatic Type". <i>Is it in good condition?</i>	Go to Step 6.	Repair or replace.
6	Temperature control actuator check 1) Check temperature control actuator for performance referring to "Temperature Control Actuator and Its Circuit Inspection: Automatic Type". <i>Is it in good condition?</i>	Substitute a known-good HVAC control module and recheck.	Replace temperature control actuator.

DTC B1514: Air Flow Control Actuator (Motor) and/or Its Circuit Malfunction

S7RW0C7224016

Wiring Diagram



I6RW0C722007-01

[D]: Air flow actuator motor drive circuit	2. Air flow control actuator	4. To other sensors
1. HVAC control module	3. To temperature control actuator	

DTC Detecting Condition and Trouble Area

DTC Detecting Condition	Trouble Area
Motor of air flow control actuator does not move longer than specified time.	- Air flow control actuator circuit - Air flow control linkage - Air flow control actuator - HVAC unit - HVAC control module

DTC Troubleshooting

Step	Action	Yes	No
1	Was "Air Conditioning System Check" performed?	Go to Step 2.	Go to "Air Conditioning System Check: Automatic Type".
2	DTC check 1) Connect scan tool to DLC with ignition switch turned OFF. 2) Turn ignition switch to ON position and check DTC. <i>Is DTC B1512 detected together?</i>	Go to "DTC B1512: Air flow Control Actuator (Position Sensor) and/or Its Circuit Malfunction: Automatic Type".	Go to Step 3.
3	Visual Check Check if there is any obstruction in operating range of actuator linkage and if actuator linkage operates smoothly. <i>Is it in good condition?</i>	Go to Step 4.	Obstruction in operating range of actuator linkage, actuator linkage faulty and/or internal fault of HVAC unit.

Step	Action	Yes	No
4	Wire harness check 1) Turn ignition switch to OFF position. 2) Disconnect connectors from air flow control actuator and HVAC control module. 3) Check for proper connection to actuator motor drive circuit terminals of air flow control actuator and HVAC control module connectors. 4) If OK, check that actuator motor drive circuit of air flow control actuator is as follows. • Wiring harness resistance of each actuator motor drive circuit is less than 3 Ω • Insulation resistance of each actuator motor drive circuit is infinity between air flow control actuator connector and vehicle body ground • Circuit voltage of each actuator motor drive circuit is 0 – 1 V with ignition switch turned ON <i>Are they in good condition?</i>	Go to Step 5.	Actuator motor drive circuit(s) is open, short or high resistance.
5	Wire harness check Check position sensor circuit of temperature control actuator for condition referring to Step 2 of “DTC B1512: Air flow Control Actuator (Position Sensor) and/or Its Circuit Malfunction: Automatic Type”. <i>Is it in good condition?</i>	Go to Step 6.	Repair or replace.
6	Air Flow control actuator check 1) Check air flow control actuator for performance referring to “Air Flow Control Actuator and Its Circuit Inspection: Automatic Type”. <i>Is it in good condition?</i>	Substitute a known-good HVAC control module and recheck.	Replace air flow control actuator.

DTC B1520 / B1521 / B1522: Temperature / Blower Speed / Air Flow Selector Malfunction

S7RW0C7224017

DTC Detecting Condition and Trouble Area

DTC Detecting Condition	Trouble Area
When internal malfunction is detected in the HVAC control module.	• Temperature selector included in HVAC control module (DTC B1520) • Blower speed selector included in HVAC control module (DTC B1521) • Air flow selector included in HVAC control module (DTC B1522)


DTC Troubleshooting

Step	Action	Yes	No
1	Was “Air Conditioning System Check” performed?	Go to Step 2.	Go to “Air Conditioning System Check: Automatic Type”.
2	DTC check 1) Clear DTC referring to “DTC Clearance: Automatic Type”. 2) Recheck DTC. <i>Are DTC B1520, B1521 and/or B1522 still detected?</i>	Substitute a known good HVAC control module and recheck.	Intermittent trouble. Check for intermittent referring to “Intermittent and Poor Connection Inspection in Section 00”.

DTC B1541: Back-Up Power Supply Circuit Malfunction

S7RW0C7224018

Wiring Diagram



DTC Detecting Condition and Trouble Area

DTC Detecting Condition	Trouble Area
- Back-up power supply voltage is lower than specified value continuously. - When connect battery with vehicle and then, turn ignition switch to ON position for first time.	- Battery voltage supply circuit - HVAC control module

NOTE

When checking DTC after connecting battery cable, be sure to turn ignition switch from OFF to ON and from ON to OFF at least once, or DTC B1541 will be detected.

DTC Troubleshooting

Step	Action	Yes	No
1	Was "Air Conditioning System Check" performed?	Go to Step 2.	Go to "Air Conditioning System Check: Automatic Type".
2	DTC check 1) Turn ignition switch to ON position for 20 sec. or more. 2) Ignition switch turned OFF and connect scan tool to DLC. 3) Turn ON ignition switch and check DTC. Is there DTC B1541?	Go to Step 3.	Intermittent trouble. Check for intermittent referring to "Intermittent and Poor Connection Inspection in Section 00".
3	Battery voltage supply circuit check 1) Disconnect connector from HVAC control module with ignition switch turned OFF. 2) Check for proper connection to back-up power supply circuit terminal of HVAC control module connector. 3) If OK, measure voltage between back-up power supply circuit terminal of HVAC control module connector and vehicle body ground. Is voltage 10 – 14 V?	Substitute a known-good HVAC control module and recheck.	Back-up power supply circuit is open or shorted to ground.

DTC B1546: A/C Refrigerant Pressure Malfunction

S7RW0C7224019

DTC Detecting Condition and Trouble Area


DTC detecting condition	Trouble area
- A/C refrigerant pressure sensor signal voltage is lower than specified value even though outside air temperature is higher than specified value for specified time continuously. - Insufficient refrigerant in A/C system	- Insufficient of refrigerant - A/C refrigerant pressure sensor - Outside air temperature sensor - HVAC control module

DTC Troubleshooting

Step	Action	Yes	No
1	Was "Air Conditioning System Check" performed?	Go to Step 2.	Go to "Air Conditioning System Check: Automatic Type".
2	DTC check 1) Connect scan tool to DLC with ignition switch turned OFF. 2) Turn ignition switch to ON position and check DTC in BCM. <i>Is DTC B1141 or B1142 (BCM) detected?</i>	Go to applicable DTC diag. flow.	Go to Step 3.
3	DTC check Check DTC in ECM. <i>Is DTC P0532 or P0533 detected?</i>	Go to applicable DTC diag. flow.	Go to Step 4.
4	A/C refrigerant pressure and outside air temperature data check 1) Start engine and select "DATA LIST" mode on scan tool. 2) Check "Refrigerant Pressure" and "Outside Air Temp" displayed on scan tool. <i>Are values of A/C refrigerant pressure sensor and outside air temperature within specified ranges indicated in "Scan Tool Data"?</i>	Substitute a known-good HVAC control module and recheck.	Check the amount of refrigerant and system for leaks.

DTC B1551: Serial Communication Circuit Malfunction

S7RW0C7224020

Wiring Diagram

I7RW01722012-02

[B]: Back-up power supply circuit	1. HVAC control module	3. Information display
[S]: Serial communication circuit	2. BCM	4. Circuit fuse

DTC Detecting Condition and Trouble Area

DTC detecting condition	Trouble area
Serial communication signal is higher than or lower than specified value for specified time continuously.	• Back-up power supply circuit • Serial communication circuit • BCM • Information display • HVAC control module

DTC Troubleshooting

Step	Action	Yes	No
1	Was "Air Conditioning System Check" performed?	Go to Step 2.	Go to "Air Conditioning System Check: Automatic Type".
2	Back-up power supply circuit fuse check 1) Check back-up power supply circuit fuse for blowing. <i>Is fuse(s) blown?</i>	Replace blown fuse and check for short in back-up power supply circuit.	Go to Step 3.
3	Wire harness check 1) Turn ignition switch to OFF position. 2) Disconnect connectors from BCM, information display and HVAC control module. 3) Check for proper connection to serial communication circuit terminal of BCM, information display and HVAC control module connectors. 4) If OK, check that serial communication circuit is as follows. • Wiring harness resistance of serial communication circuit is less than 3 Ω • Insulation resistance between serial communication circuit terminal and vehicle body ground is Infinity • Circuit voltage of serial communication circuit is 0 - 1 V with ignition switch turned ON <i>Are they in good condition?</i>	Go to Step 4.	Serial communication circuit is open, short or high resistance.
4	Serial communication signal check 1) Connect connectors to BCM and HVAC control module with ignition switch turned OFF. 2) Turn ignition switch to ON position. 3) Check that serial communication signal is outputted from BCM referring to "Voltage Check" under "Inspection of BCM and Its Circuits in Section 10B". <i>Is serial communication signal outputted?</i>	Replace information display.	Go to Step 5.
5	Communication data check 1) Connect connector to information display with ignition switch turned OFF. 2) Check that serial communication signal is outputted from BCM referring to "Voltage Check" under "Inspection of BCM and Its Circuits in Section 10B". <i>Is serial communication signal outputted?</i>	Substitute a known-good HVAC control module and recheck.	Substitute a known-good BCM and recheck.

DTC B1552: HVAC Control Module Check Sum Error

S7RW0C7224021

DTC Detecting Condition and Trouble Area

DTC detecting condition	Trouble area
Data received by HVAC control module from BCM is erroneous continuously.	• BCM • HVAC control module

DTC Troubleshooting

Step	Action	Yes	No
1	Was "Air Conditioning System Check" performed?	Go to Step 2.	Go to "Air Conditioning System Check: Automatic Type".
2	Serial communication signal data check 1) Connect scan tool to DLC with ignition switch turned OFF. 2) Start engine and select "DATA LIST" mode on scan tool. 3) Check "Refrigerant Pressure", "Vehicle Speed", "Coolant Temp" and "Outside Air Temp" displayed on scan tool. <i>Are values of A/C refrigerant pressure sensor and outside air temperature within specified ranges indicated in "Scan Tool Data"?</i>	Intermittent trouble. Check for intermittent referring to "Intermittent and Poor Connection Inspection in Section 00"	Substitute a known-good HVAC control module and recheck. If DTC is still detected substitute a known-good BCM and recheck.

DTC B1553: CAN Communication Circuit Malfunction

S7RW0C7224022

DTC Detecting Condition and Trouble Area

DTC detecting condition	Trouble area
HVAC control module receives error code from BCM continuously.	• CAN communication circuit • BCM • ECM • Combination meter • HVAC control module

DTC Troubleshooting

Step	Action	Yes	No
1	Was "Air Conditioning System Check" performed?	Go to Step 2.	Go to "Air Conditioning System Check: Automatic Type".
2	DTC check 1) Connect scan tool to DLC with ignition switch turned OFF. 2) Check DTC in BCM. <i>Is DTC U0073 (No.0073), U0100 (No.0100) and/or U0155 (No.0155) detected?</i>	Go to applicable DTC diag. flow.	Substitute a known-good HVAC control module and recheck.

DTC B1557: VSS Signal Failure

S7RW0C7224023

DTC Detecting Condition and Trouble Area

DTC detecting condition	Trouble area
HVAC control module receives invalid data of VSS signal from BCM.	• VSS circuit • VSS • HVAC control module

DTC Troubleshooting

Step	Action	Yes	No
1	<i>Was "Air Conditioning System Check" performed?</i>	Go to Step 2.	Go to "Air Conditioning System Check: Automatic Type".
2	DTC check 1) Connect scan tool to DLC with ignition switch turned OFF. 2) Check DTC in ECM. <i>Is DTC P0500 detected?</i>	Go to applicable DTC diag flow.	Substitute a known-good HVAC control module and recheck.

DTC B1561: ECT Signal Failure

S7RW0C7224024

DTC Detecting Condition and Trouble Area

DTC detecting condition	Trouble area
HVAC control module receives invalid data of ECT signal from BCM.	• ECT sensor circuit • ECT sensor • HVAC control module

DTC Troubleshooting

Step	Action	Yes	No
1	<i>Was "Air Conditioning System Check" performed?</i>	Go to Step 2.	Go to "Air Conditioning System Check: Automatic Type".
2	DTC check 1) Connect scan tool to DLC with ignition switch turned OFF. 2) Check DTC in ECM. <i>Is DTC P0116, P0117 or P0118 detected?</i>	Go to applicable DTC diag. flow.	Substitute a known-good HVAC control module and recheck.

DTC B1562: Outside Air Temperature Signal Failure

S7RW0C7224025

DTC Detecting Condition and Trouble Area

DTC detecting condition	Trouble area
HVAC control module receives invalid data of outside air temperature signal from BCM.	• Outside air temperature sensor circuit • Outside air temperature sensor • HVAC control module

DTC Troubleshooting

Step	Action	Yes	No
1	Was "Air Conditioning System Check" performed?	Go to Step 2.	Go to "Air Conditioning System Check: Automatic Type".
2	DTC check 1) Connect scan tool to DLC with ignition switch turned OFF. 2) Check DTC in BCM. <i>Is DTC B1141 or B1142 detected?</i>	Go to applicable DTC diag. flow.	Substitute a known-good HVAC control module and recheck.

DTC B1563: A/C Refrigerant Pressure Signal Failure

S7RW0C7224026

DTC Detecting Condition and Trouble Area

DTC detecting condition	Trouble area
HVAC control module receives invalid data of A/C refrigerant pressure signal from BCM.	• A/C refrigerant pressure sensor circuit • A/C refrigerant pressure sensor • HVAC control module

DTC Troubleshooting

Step	Action	Yes	No
1	Was "Air Conditioning System Check" performed?	Go to Step 2.	Go to "Air Conditioning System Check: Automatic Type".
2	DTC check 1) Connect scan tool to DLC with ignition switch turned OFF. 2) Check DTC in ECM. <i>Is DTC P0532 or P0533 detected?</i>	Go to applicable DTC diag. flow.	Substitute a known-good HVAC control module and recheck.

DTC B1570: Engine Type Signal Failure

S7RW0C7224027

DTC Detecting Condition and Trouble Area

DTC detecting condition	Trouble area
HVAC control module receives invalid data of engine type signal from BCM.	• CAN communication circuit • HVAC control module • ECM

DTC Troubleshooting

Step	Action	Yes	No
1	<i>Was "Air Conditioning System Check" performed?</i>	Go to Step 2.	Go to "Air Conditioning System Check: Automatic Type".
2	Scan tool data check 1) Connect scan tool with ignition switch turned OFF position. 2) Ignition switch turned ON and select "DATA LIST" mode. 3) Check "ENGINE TYPE" displayed on scan tool. <i>Is value of engine type signal within specified ranges indicated in "Scan Tool Data"?</i>	Substitute a known good HVAC control module and recheck.	Go to step 3.
3	Scan tool data check 1) Check "ENGINE TYPE" displayed on scan tool. <i>Is "CAN Err" displayed on scan tool data?</i>	Check CAN communication circuit referring to "Troubleshooting for CAN-DTC in Section 1A".	Substitute a known good ECM and recheck.

DTC B1571: Combination Meter Spec Signal Failure

S7RW0C7224028

DTC Detecting Condition and Trouble Area

DTC detecting condition	Trouble area
HVAC control module receives invalid data of Combination meter spec signal from BCM.	• CAN communication circuit • Combination meter • HVAC control module

DTC Troubleshooting

Step	Action	Yes	No
1	<i>Was "Air Conditioning System Check" performed?</i>	Go to Step 2.	Go to "Air Conditioning System Check: Automatic Type".
2	Scan tool data check 1) Connect scan tool with ignition switch turned OFF position. 2) Ignition switch turned ON and select "DATA LIST" mode. 3) Check "METER SPEC" displayed on scan tool. <i>Is value of combination meter spec signal within specified ranges indicated in "Scan Tool Data"?</i>	Substitute a known good HVAC control module and recheck.	Go to step 3.
3	Scan tool data check 1) Check "METER SPEC" displayed on scan tool. <i>Is "CAN Err" displayed on scan tool data?</i>	Check CAN communication circuit referring to "Troubleshooting for CAN-DTC in Section 1A".	Substitute a known good combination meter and recheck.

Inspection of HVAC Control Module and Its Circuit

HVAC control module and its circuits can be checked at HVAC control module wiring couplers by measuring voltage.

⚠ CAUTION


HVAC control module can not be checked by itself. It is strictly prohibited to connect voltmeter to HVAC control module with couplers disconnected from it.

Voltage Check

- 1) Remove HVAC control module referring to “HVAC Control Module Removal and Installation: Automatic Type”.
- 2) Check voltage at each terminal.

NOTE

As each terminal voltage is affected by the battery voltage, confirm that it is 11 V or more when ignition switch is ON.



I7RW01722013-01

1. HVAC control module

2. HVAC control module connector (viewed from harness side)

Terminal	Wire Color	Circuit	Normal Voltage	Condition
G20-1	GRY/BLU	Temperature control actuator (COOL)	10 – 14 V	Ignition switch turned ON, temperature control actuator is working in operation from HOT to COOL position
			0 – 2 V	Ignition switch turned ON, except the above condition
G20-2	GRY/RED	Temperature control actuator (HOT)	10 – 14 V	Ignition switch turned ON, temperature control actuator is working in operation from COOL to HOT position
			0 – 2 V	Ignition switch turned ON, except the above condition
G20-3	BLU	Serial communication line of data link connector	10 – 14 V	Ignition switch turned ON
G20-4	GRN/YEL	Rear defogger switch	Refer to “Reference waveform No. 1: Automatic Type”.	
G20-5	BLK/YEL	Illumination ground	0 – 1 V	Full-time
G20-6	RED/YEL	Illumination switch	0 – 1 V	Ignition switch turned ON, lighting switch OFF position
			10 – 14 V	Ignition switch turned ON, lighting switch ON position
G20-7	WHT/RED	Electric power source for back-up	10 – 14 V	Constantly

7B-75 Air Conditioning System: Automatic Type


Terminal	Wire Color	Circuit	Normal Voltage	Condition
G20-8	BLU/WHT	Electric load signal for blower motor	10 – 14 V	- Ignition switch turned ON, blower speed selector OFF or 1st position - Ignition switch turned ON, blower speed selector from 1st to 2nd position
			0 – 2 V	- Ignition switch turned ON, blower speed selector between 3rd and HIGH position - Ignition switch turned ON, blower speed selector from 3rd to 2nd position
G20-9	WHT/BLK	Evaporator temperature sensor signal	Approx. 2.6 V	Ignition switch turned ON, evaporator temperature 0 °C (32 °F)
			Approx. 1.7 V	Ignition switch turned ON, evaporator temperature 15 °C (59 °F)
			Approx. 1.0 V	Ignition switch turned ON, evaporator temperature 30 °C (86 °F)
G20-10	PNK/BLK	Inside air temperature sensor signal	Approx. 2.5 V	Ignition switch turned ON, room temperature 25 °C (77 °F)
			Approx. 3.7 V	Ignition switch turned ON, room temperature 0 °C (32 °F)
G20-11	—	—	—	—
G20-12	WHT	Output of 5 V power source for air flow control actuator position sensor and temperature control actuator position sensor	4 – 6 V	Ignition switch turned ON
G20-13	YEL	Serial communication line of BCM	Refer to “Reference waveform No. 2: Automatic Type”.	
G20-14	—	—	—	—
G20-15	BRN/YEL	Air flow control actuator (FACE)	10 – 14 V	Ignition switch turned ON, air flow control actuator is working in operation from “DEF” to “FACE” position
			0 – 1 V	Ignition switch turned ON, except the above condition
G20-16	BRN/WHT	Air flow control actuator (DEF)	10 – 14 V	Ignition switch turned ON, air flow control actuator is working in operation from “FACE” to “DEF” position
			0 – 1 V	Ignition switch turned ON, except the above condition
G20-17	GRN	Air intake actuator (FRESH AIR)	0 – 1 V	Ignition switch turned ON, air intake selector “FRE” position
			10 – 14 V	Ignition switch turned ON, air intake selector “REC” position
G20-18	RED	Air intake actuator (RECIRCULATION AIR)	0 – 1 V	Ignition switch turned ON, air intake selector “REC” position
			10 – 14 V	Ignition switch turned ON, air intake selector “FRE” position
G20-19	GRN/RED	Air intake actuator (MIX AIR)	10 – 14 V	Ignition switch turned ON, air intake selector “FRE” or “REC” position
			0 – 1 V	Ignition switch turned ON, air intake selector is working in operation from “FRE” to “REC” or “REC” to “FRE” position
G20-20	—	—	—	—
G20-21	GRN/WHT	A/C switch signal	Refer to “Reference waveform No. 1: Automatic Type”.	
G20-22	RED/BLK	Electric power source	10 – 14 V	Ignition switch turned ON
G20-23	BLK/ORN	Ground for HVAC control module	Below 0.5 V	Ignition switch turned ON
G20-24	ORN	Ground for sensors	Below 0.5 V	Ignition switch turned ON

Terminal	Wire Color	Circuit	Normal Voltage	Condition
G20-25	PNK	Sunload sensor signal	Approx. 3.5 V	Ignition switch turned ON, amount of insolation is 500 W/m ²
			Approx. 5 V	Ignition switch turned ON, amount of insolation is 0 W/m ²
G20-26	BLK/RED	Rear defogger indicator	0 – 1 V	Ignition switch turned ON, rear defogger switch OFF
			10 – 14 V	Ignition switch turned ON, rear defogger switch ON
G20-27	YEL	Temperature control actuator position sensor signal	Approx. 0.5 V	Ignition switch turned ON, temperature selector “MAX COOL” position
			Approx. 4.5 V	Ignition switch turned ON, temperature selector “MAX HOT” position
G20-28	WHT/BLU	Air flow control actuator position sensor signal	Approx. 0.5 V	Ignition switch turned ON, air flow selector “FACE” position
			Approx. 4.5 V	Ignition switch turned ON, air flow selector “DEF” position
G20-29	GRY	Blower motor controller	0 – 1 V	Ignition switch turned ON, blower speed selector OFF position
			2 – 3.5 V	Ignition switch turned ON, blower speed selector between 1st and 6th position
			Approx. 10.0 V	Ignition switch turned ON, blower speed selector 7th and HIGH position
G20-30	BLU/RED	Blower motor control voltage feedback	10 – 14 V	Ignition switch turned ON, blower speed selector OFF position
			Approx. 8.1 V	Ignition switch turned ON, blower speed selector 1st position
			Approx. 6.8 V	Ignition switch turned ON, blower speed selector 2nd position
			Approx. 5.5 V	Ignition switch turned ON, blower speed selector 3rd position
			Approx. 4.0 V	Ignition switch turned ON, blower speed selector 4th position
			Approx. 2.6 V	Ignition switch turned ON, blower speed selector 5th position
			Approx. 1.2 V	Ignition switch turned ON, blower speed selector 6th position
			Approx. 0.2 V	Ignition switch turned ON, blower speed selector 7th and HIGH position

Reference waveform No. 1

Rear defogger switch or A/C switch signal (1)


Measurement terminal	Rear defogger switch CH1: "G20-4" to "G20-23" A/C switch CH1: "G20-21" to "G20-23"
Oscilloscope setting	CH1: 5 V / DIV TIME: 10 ms / DIV
Measurement condition	Rear defogger switch: - Ignition switch is at ON position and rear defogger switch is not pushed A/C switch: - Ignition switch is at ON position and A/C switch is not pushed



Reference waveform No. 2

Serial communication line of BCM (1)

Measurement terminal	CH1: "G20-13" to "G20-23"
Oscilloscope setting	CH1: 5 V / DIV TIME: 20 ms / DIV
Measurement condition	Ignition switch is at ON position



A/C System Inspection at ECM

When checking voltage at ECM terminals related to A/C system, refer to "Inspection of ECM and Its Circuits in Section 1A".

S7RW0C7224030

Repair Instructions


Operation Procedure for Refrigerant Charge

S7RW0C7226001

Refer to "Operation Procedure for Refrigerant Charge: Manual Type".

HVAC Unit Components

S7RW0C7226002



I6RW0C722008-01

1. Blower upper case	9. Air intake control link	17. Expansion valve	25. Inside air temperature sensor
2. Blower lower case	10. Air intake control door	18. Expansion pipe	26. Aspirator

7B-79 Air Conditioning System: Automatic Type

3. Heater unit upper case	11. Blower motor	19. Air flow control actuator	27. Aspirator hose
4. Heater unit lower case	12. Blower motor cap	20. Air flow control links	28. Drain hose
5. Foot duct	13. Blower motor controller	21. Air flow control door assembly	29. Packing
6. HVAC air filter (if equipped)	14. Heater core	22. Temperature control actuator	 30. O-ring : Apply compressor oil.
7. Cover (without HVAC air filter)	15. Evaporator	23. Temperature control link	 : Do not reuse.
8. Air intake control actuator	16. Evaporator temperature sensor	24. Temperature control door assembly	

HVAC Unit Removal and Installation

S7RW0C7226003


Refer to “HVAC Unit Removal and Installation: Manual Type”.

Temperature Control Actuator Removal and Installation

S7RW0C7226004

Removal


- 1) Disconnect negative (–) cable at battery.
- 2) Remove steering column hole cover from instrument panel.
- 3) Remove driver side foot duct from HVAC unit.
- 4) Disconnect temperature control actuator connector (1).
- 5) Remove temperature control actuator (2) from HVAC unit by removing screws (3).



Installation

Reverse removal procedure noting the following instructions.

- Before installing actuator, make sure that position of actuator lever is in between “MAX HOT” position and “MAX COOL” position.
- Be sure to insert pin (1) of temperature control actuator into the groove (2) of link.



Temperature Control Actuator and Its Circuit Inspection


S7RW0C7226005

- 1) Remove temperature control actuator from HVAC unit referring to “Temperature Control Actuator Removal and Installation: Automatic Type”.
- 2) Connect connector to temperature control actuator.
- 3) Set temperature selector to “MAX COOL” position with ignition switch turned ON.
- 4) Connect voltage meter between terminal “2” and body ground.
- 5) Turn temperature selector to “MAX HOT” position.

- 6) Measure output voltage variation while temperature control actuator is operated from "MAX COOL" position (B) to "MAX HOT" position (A) as following specification.

If measure voltage is out of specification or does not vary linearly as the shown in graph, check related wire circuit and HVAC control module. If wire circuits and HVAC control module are OK, go to next step.

Temperature control actuator output voltage
0.48 – 4.53V (linear variation as following graph)



[A]: MAX HOT	[C]: Actuator lever position
[B]: MAX COOL	


- 7) Set temperature selector of HVAC control module to "MAX HOT" position with ignition switch turned ON, and make sure if the position of actuator lever is "MAX HOT" position (A).
- 8) Turn ignition switch to OFF position, and then disconnect connector from temperature control actuator.

- 9) Measure resistance between terminal "1" and "2".

Temperature control actuator resistance between terminal "1" and "2" (MAX HOT position)

(Reference value)

Approx. 0.45 kΩ at 25 °C (77 °F)




I7RW01722020-02

- 10) Connect connector to temperature control actuator.
- 11) Set temperature selector of HVAC control module to "MAX COOL" position with ignition switch turned ON, and make sure if the position of actuator lever is "MAX COOL" position (B).
- 12) Turn ignition switch to OFF position, and then disconnect connector from temperature control actuator.
- 13) Measure resistance between terminal "1" and "2".

Temperature control actuator resistance between terminal "1" and "2" (MAX COOL position)

(Reference value)

Approx. 4.3 kΩ at 25 °C (77 °F)



I7RW01722021-02


If measure resistance is out of specification, replace the actuator with new one.

Air Flow Control Actuator Removal and Installation

S7RW0C7226006

Removal

- 1) Disconnect negative cable at battery.
- 2) Remove steering column hole cover from instrument panel.
- 3) Remove driver side foot duct from HVAC unit.
- 4) Disconnect air flow control actuator connector (2).
- 5) Remove air flow control actuator (1) from HVAC unit by removing screws (3).




I7RW01722022-01

Installation

Reverse removal procedure noting the following instructions.

- Before installing actuator, make sure that position of actuator lever is in between “BENT” position and “DEF” position.
- Be sure to insert pin (1) of air flow control actuator into the groove (2) of link.




I7RW01722023-02

Air Flow Control Actuator and Its Circuit Inspection

S7RW0C7226007

- 1) Remove air flow control actuator from HVAC unit referring to “Air Flow Control Actuator Removal and Installation: Automatic Type”.
- 2) Connect connector to air flow control actuator.
- 3) Set air flow selector to “BENT” position with ignition switch turned ON.
- 4) Connect voltage meter between terminal “2” and body ground.
- 5) Turn air flow selector to “DEF” position.
- 6) Measure output voltage variation while air flow control actuator is operated from “BENT” position (A) to “DEF” position (B) as following specification. If measure voltage is out of specification or does not vary linearly as the shown in graph, check related wire circuit and HVAC control module. If wire circuits and HVAC control module are OK, go to next step.

Air flow control actuator output voltage
0.48 – 4.53 V (linear variation as following graph)




I7RW01722024-02

[A]: BENT	[D]: FOOT
[B]: DEF	[E]: DEF / FOOT
[C]: BI-LEVEL	[F]: Actuator lever position

- 7) Set air flow selector of HVAC control module to "DEF" position with ignition switch turned ON, and make sure if the position of actuator lever is "DEF" position (A).
- 8) Turn ignition switch to OFF position, and then disconnect connector from air flow control actuator.
- 9) Measure resistance between terminal "1" and "2".

Air flow control actuator resistance between terminal "1" and "2" (DEF position) (Reference value)

Approx. 0.45 kΩ at 25 °C (77 °F)




I7RW01722025-01

- 10) Connect connector to air flow control actuator.
- 11) Set air flow selector of HVAC control module to "VENT" position with ignition switch turned ON, and make sure if the position of actuator lever is "VENT" position (B).
- 12) Turn ignition switch to OFF position, and then disconnect connector from air flow control actuator.

- 13) Measure resistance between terminal "1" and "2".

Air flow control actuator resistance between terminal "1" and "2" (VENT position) (Reference value)

Approx. 4.3 kΩ at 25 °C (77 °F)



I7RW01722026-01

If measure resistance is out of specification, replace the actuator with new one.

Air Intake Actuator Removal and Installation

S7RW0C7226008

Remove and install air intake actuator referring to "Air Intake Control Actuator Removal and Installation in Section 7A".

Air Intake Actuator Inspection

S7RW0C7226009

For inspection, refer to "Air Intake Control Actuator Inspection in Section 7A".

Actuator Linkage Inspection

S7RW0C7226010

- Check if each actuator linkage operates smoothly.
- Check actuator rod for bend.
- Check each actuator linkage for breakage.
- Make sure if there is not any obstruction in operating range of actuator linkage.
If any malfunction is found, repair or replace faulty part(s).

Blower Motor Controller Removal and Installation

S7RW0C7226011

Refer to "Blower Motor Resistor Removal and Installation in Section 7A".

Blower Motor Controller Inspection




S7RW0C7226012

- 1) Check internal circuit of controller for resistance as follows.
 - a) Measure resistance between "1" terminal and "2" terminal of blower motor controller.

Blower motor controller resistance**"1" – "2": approximately 10 kΩ**

If resistance does not meet above specification, replace blower motor controller.

- b) Using ohmmeter, connect its positive terminal to "3" terminal of blower motor controller and negative terminal to "1" terminal of blower motor controller and check that there is no continuity.
- 2) Check controller for operation as follows.
 - a) Using bulb (3.4 W) (5) and service wire, connect battery positive terminal to "3" terminal of blower motor controller as shown in figure.
 - b) Using service wire, connect battery negative terminal to "1" terminal of blower motor controller.
 - c) Arrange 3 new 1.5 V batteries (6) in series (check that total voltage is 4.5 – 5.0 V) and connect its positive terminal to "2" terminal of blower motor controller and negative terminal to "1" terminal of blower motor controller. Then, check that bulb lights. If bulb does not light under the above conditions, replace blower motor controller.




I7RW01722027-01

HVAC Control Module Removal and Installation

S7RW0C7226013

Removal

- 1) Remove audio unit from instrument panel referring to "Audio Unit Removal and Installation (If Equipped) in Section 9C".
- 2) Remove HVAC control module (1) with its garnish (2) from instrument panel.
- 3) Remove HVAC control module from garnish.



I5RW0A722024-02

Installation


Reverse removal procedure.

Sunload Sensor Removal and Installation

S7RW0C7226014

Removal

- 1) Disconnect negative (–) cable at battery.
- 2) Remove combination meter from instrument panel referring to "Combination Meter Removal and Installation in Section 9C".
- 3) Remove sunload sensor (1) from instrument panel by depressing tab and pushing sensor upward from underneath.
- 4) Disconnect sunload sensor connector (2).




I7RW01722028-01

Installation

Reverse removal procedure noting the following instructions.

- Install sunload sensor (1) to instrument panel fitting tab (2) of sunload sensor into the groove (3) of instrument panel as shown in figure.




Sunload Sensor Inspection

S7RW0C7226015

- 1) Light over sunload sensor vertically with an incandescent light of approximately 100 W. The distance between sunload sensor and light should be approximately 100 mm (3.94 in.).
- 2) Measure voltage between terminals “a” and “b” of sunload sensor as shown in figure. If check result is not satisfactory, replace sunload sensor with new one.

Sunload sensor voltage specification

“a” – “b”: Approx. 0.38 – 0.42 V



Outside Air Temperature Sensor Removal and Installation

S7RW0C7226016

Refer to “Outside Air Temperature Sensor Removal and Installation (If Equipped)” in Section 9C”.

Outside Air Temperature Sensor Inspection

S7RW0C7226017


Refer to “Outside Air Temperature Sensor Inspection (If Equipped)” in Section 9C”.

Inside Air Temperature Sensor Removal and Installation

S7RW0C7226018

Removal

- 1) Disconnect negative (–) cable at battery.
- 2) Remove audio unit from instrument panel referring to “Audio Unit Removal and Installation (If Equipped)” in Section 9C”.
- 3) Remove combination meter from instrument panel referring to “Combination Meter Removal and Installation in Section 9C”.
- 4) Remove connector (3) and aspirator hose (1) from inside air temperature sensor (2).
- 5) Remove inside air temperature sensor (2) from instrument panel by removing screw (4).



Installation

Reverse removal procedure.

Inside Air Temperature Sensor Inspection


S7RW0C7226019

Measure resistance between each connector terminal with an ohmmeter.

If resistance is incorrect, replace inside air temperature sensor with new one.

Inside air temperature sensor resistance

$2.2 \pm 0.07 \text{ k}\Omega$ at 25 °C (77 °F)



Condenser Cooling Fan Relay Inspection

S7RW0C7226020

Refer to “A/C System Relay Inspection: Manual Type”.

Condenser Cooling Fan Removal and Installation

S7RW0C7226021

Refer to “Condenser Cooling Fan Removal and Installation: Manual Type”.

Condenser Cooling Fan Inspection

S7RW0C7226022

Refer to “Condenser Cooling Fan Inspection: Manual Type”.

Condenser Assembly On-Vehicle Inspection

S7RW0C7226023

Refer to “Condenser Assembly On-Vehicle Inspection: Manual Type”.

Condenser Assembly Removal and Installation

S7RW0C7226024

Refer to “Condenser Assembly Removal and Installation: Manual Type”.

Evaporator Inspection

S7RW0C7226025

Refer to “Evaporator Inspection: Manual Type”.

Evaporator Temperature Sensor Removal and Installation

S7RW0C7226026

Refer to “Evaporator Temperature Sensor Removal and Installation: Manual Type”.

Evaporator Temperature Sensor Inspection

S7RW0C7226027

Refer to “Evaporator Temperature Sensor Inspection: Manual Type”.

Expansion Valve Removal and Installation

S7RW0C7226028

Refer to “Expansion Valve Removal and Installation: Manual Type”.

Expansion Valve Inspection

S7RW0C7226029

Refer to “Expansion Valve Inspection: Manual Type”.

A/C Refrigerant Pressure Sensor and Its Circuit Inspection

S7RW0C7226030

Refer to “A/C Refrigerant Pressure Sensor and Its Circuit Inspection: Manual Type”.

A/C Refrigerant Pressure Sensor Removal and Installation

S7RW0C7226031

Refer to “A/C Refrigerant Pressure Sensor Removal and Installation: Manual Type”.

Compressor Relay Inspection

S7RW0C7226032

Refer to “A/C System Relay Inspection: Manual Type”.

Compressor Drive Belt Inspection and Adjustment

S7RW0C7226033

Refer to “Compressor Drive Belt Inspection and Adjustment: Manual Type”.

Compressor Drive Belt Removal and Installation

S7RW0C7226034

Refer to “Compressor Drive Belt Removal and Installation: Manual Type”.

Compressor Assembly Removal and Installation

S7RW0C7226035

Refer to “Compressor Assembly Removal and Installation: Manual Type”.

Compressor Assembly Components

S7RW0C7226036

Refer to “Compressor Assembly Components: Manual Type”.

Magnet Clutch Removal and Installation

S7RW0C7226037

Refer to “Magnet Clutch Removal and Installation: Manual Type”.

Magnet Clutch Inspection

S7RW0C7226038

Refer to “Magnet Clutch Inspection: Manual Type”.

Thermal Switch Inspection

S7RW0C7226039

Refer to “Thermal Switch Inspection: Manual Type”.

Thermal Switch Removal and Installation

S7RW0C7226040

Refer to “Thermal Switch Removal and Installation: Manual Type”.

Relief Valve Inspection

S7RW0C7226041

Refer to “Relief Valve Inspection: Manual Type”.

Special Tools and Equipment

Recommended Service Material

S7RW0C7228001

NOTE


Required service material is also described in the following.
“HVAC Unit Components: Automatic Type”

Special Tool

S7RW0C7228002

SUZUKI scan tool

This kit includes following items. 1. Tech 2, 2. PCMCIA card, 3. DLC cable, 4. SAE 16/19 adapter, 5. Cigarette cable, 6. DLC loop back adapter, 7. Battery power cable, 8. RS232 cable, 9. RS232 adapter, 10. RS232 loop back connector, 11. Storage case, 12.  / 



Section 8

Restraint

CONTENTS

Precautions	8-1	DTC Check.....	8B-17
Precautions.....	8-1	DTC Clearance	8B-17
Precautions on Restraint.....	8-1	Scan Tool Data	8B-17
Seat Belts	8A-1	“AIR BAG” Warning Light Comes ON Steady ...	8B-18
Precautions.....	8A-1	“AIR BAG” Warning Light Does Not Come ON ..	8B-21
Precautions on Service and Diagnosis of Seat		Serial Data Link Circuit Check	8B-22
Belt.....	8A-1	DTC B1013: SDM Internal Failure	8B-24
General Description	8A-2	DTC B1014: “AIR BAG” Warning Light Circuit ..	8B-25
Seat Belt Construction	8A-2	DTC B1016: Power Supply Voltage too High....	8B-25
Diagnostic Information and Procedures.....	8A-4	DTC B1017: Power Supply Voltage too Low	8B-26
Repair and Inspection Required after		DTC B1021: Front Air Bag Deployment	
Accident	8A-4	Record.....	8B-27
Repair Instructions	8A-5	DTC B1024 / B1025: Side Air-Bag	
Front Seat Belt Components.....	8A-5	Deployment Record	8B-28
Front Seat Belt Removal and Installation.....	8A-6	DTC B1026: Seat Belt Pretensioner	
Front Seat Belt Inspection.....	8A-7	Activation Record	8B-28
Rear Seat Belt Components	8A-8	DTC B1027: Number of Deployment Times	
Rear Seat Belt Removal and Installation	8A-10	Exceeded Limit.....	8B-29
Rear Seat Belt Inspection	8A-10	DTC B1031: Driver Air Bag Circuit High	
Specifications	8A-10	Resistance	8B-30
Tightening Torque Specifications.....	8A-10	DTC B1032: Driver Air Bag Circuit Low	
Air Bag System	8B-1	Resistance	8B-32
Precautions.....	8B-1	DTC B1033: Driver Air Bag Circuit Shorted to	
Precautions on Service and Diagnosis of Air		Ground	8B-34
Bag System.....	8B-1	DTC B1034: Driver Air Bag Circuit Shorted to	
Precautions on Handling and Storage of Air		Power Supply	8B-36
Bag System Components	8B-1	DTC B1041: Passenger Air Bag Circuit High	
Precautions on Disposal of Air Bag and Seat		Resistance	8B-39
Belt Pretensioner	8B-5	DTC B1042: Passenger Air Bag Circuit Low	
General Description	8B-5	Resistance	8B-42
Air Bag System Construction	8B-5	DTC B1043: Passenger Air Bag Circuit	
Air Bag System Input / Output Table	8B-6	Shorted to Ground.....	8B-44
Schematic and Routing Diagram.....	8B-7	DTC B1044: Passenger Air Bag Circuit	
Air Bag System Wiring Circuit Diagram	8B-7	Shorted to Power Supply	8B-45
Air Bag System Input / Output Diagram	8B-9	DTC B1051 / B1055: Seat Belt Pretensioner	
Component Location	8B-10	Circuit High Resistance.....	8B-47
Air Bag System Components, Wiring and		DTC B1052 / B1056: Seat Belt Pretensioner	
Connectors Location	8B-10	Circuit Low Resistance.....	8B-50
Diagnostic Information and Procedures.....	8B-11	DTC B1053 / B1057: Seat Belt Pretensioner	
Air Bag Diagnostic System Check	8B-11	Shorted to Ground.....	8B-51
Air Bag Diagnostic System Check Flow.....	8B-12	DTC B1054 / B1058: Seat Belt Pretensioner	
DTC Table.....	8B-13	Circuit Shorted to Power Supply	8B-53
		DTC B1061 / B1065: Side-Air Bag Circuit	
		High Resistance	8B-54

DTC B1062 / B1066: Side-Air Bag Circuit Low Resistance	8B-58	Repair and Inspection Required after Accident	8B-90
DTC B1063 / B1067: Side-Air Bag Circuit Shorted to Ground	8B-60	Repair Instructions	8B-93
DTC B1064 / B1068: Side-Air Bag Circuit Shorted to Power Supply	8B-63	Disabling Air Bag System	8B-93
DTC B1071: Driver Forward Impact-Sensor Communication Data Inconsistent	8B-65	Enabling Air Bag System	8B-94
DTC B1072: Driver Forward Impact-Sensor Communication Data Invalid	8B-65	SDM Removal and Installation	8B-94
DTC B1073: Driver Forward Impact-Sensor Circuit Shorted to Ground	8B-66	SDM Inspection	8B-96
DTC B1074: Driver Forward Impact-Sensor Circuit Open	8B-67	Driver Air Bag (Inflator) Module Removal and Installation	8B-96
DTC B1081 / B1091: Side Impact-Sensor No Response	8B-69	Driver Air Bag (Inflator) Module Inspection	8B-97
DTC B1082 / B1092: Side Impact-Sensor Communication DATA Invalid	8B-69	Passenger Air Bag (Inflator) Module Removal and Installation	8B-97
DTC B1083 / B1093: Side Impact-Sensor Circuit Shorted to Ground	8B-70	Passenger Air Bag (Inflator) Module Inspection	8B-99
DTC B1084 / B1094: Side Impact-Sensor Circuit Open	8B-72	Side-Air Bag (Inflator) Module Removal and Installation	8B-100
DTC B1085 / B1095: Side Impact-Sensor Communication DATA Inconsistent	8B-73	Side-Air Bag (Inflator) Inspection	8B-102
DTC B1361 / B1365: Curtain-Air Bag Circuit High Resistance	8B-74	Side Curtain-Air Bag (Inflator) Module Removal and Installation	8B-102
DTC B1362 / B1366: Curtain-Air Bag Circuit Low Resistance	8B-77	Side Curtain-Air Bag (Inflator) Module Inspection	8B-104
DTC B1363 / B1367: Curtain-Air Bag Circuit Shorted to Ground	8B-80	Forward Impact-Sensor Removal and Installation	8B-104
DTC B1364 / B1368: Curtain-Air Bag Circuit Shorted to Power Supply	8B-82	Forward Impact-Sensor Inspection	8B-105
SDM Power Supply and Ground Circuit Check	8B-84	Side Impact-Sensor Removal and Installation	8B-106
Contact Coil Cable and Its Circuit Check	8B-86	Side Impact-Sensor Inspection	8B-106
Inspection of Intermittent and Poor Connections	8B-89	Passenger Air Bag (Inflator) Module Repair Harness Installation	8B-107
		Air Bag (Inflator) Module and Seat Belt Pretensioner Disposal	8B-108
		Deployed Air Bag (Inflator) Module and Activated Seat Belt Pretensioner Disposal	8B-118
		Specifications	8B-119
		Tightening Torque Specifications	8B-119
		Special Tools and Equipment	8B-119
		Use of Special Tools	8B-119
		Special Tool	8B-121

Precautions

Precautions

Precautions on Restraint

S7RW0C8000001

Air Bag Warning

Refer to "Air Bag Warning in Section 00".

Fastener Caution

Refer to "Fastener Caution in Section 00".

Precautions on Service and Diagnosis of Seat Belt

Refer to "Precautions on Service and Diagnosis of Seat Belt in Section 8A".

Precautions on Service and Diagnosis of Air Bag System

Refer to "Precautions on Service and Diagnosis of Air Bag System in Section 8B".

Precautions on Handling and Storage of Air Bag Components

Refer to "Precautions on Handling and Storage of Air Bag System Components in Section 8B".

Precautions on Disposal of Air Bag and Seat Belt Pretensioner

Refer to "Precautions on Disposal of Air Bag and Seat Belt Pretensioner in Section 8B".

Seat Belts

Precautions

Precautions on Service and Diagnosis of Seat Belt

S7RW0C8100001

▲ WARNING

If replacing seat belt is necessary, replace buckle and seat belt together as a set. This is for the reason of ensuring locking of tongue plate with buckle. If these parts are replaced individually, such a locking condition may become unreliable. For this reason, SUZUKI will supply only the spare buckle and seat belt assembly in a set part.

Before servicing or replacing seat belts, refer to the following precautionary items.


- Seat belts should be normal relative to strap retractor and buckle portions.
- Keep sharp edges and damaging objects away from belts.
- Avoid bending or damaging any portion of belt buckle or latch plate.
- Do not bleach or dye belt webbing. (Use only mild soap and lukewarm water to clean it.)
- When installing a seat belt anchor bolt, it should be tightened by hand at first to prevent cross-threading and then to specified torque.
- Do not attempt any repairs on retractor mechanisms or retractor covers. Replace defective assemblies with new replacement parts.
- Keep belts dry and clean at all times.
- If there exist any parts in question, replace such parts.
- Replace belts whose webbing is cut or otherwise damaged.
- Do not put anything into trim panel opening which seat belt webbing passes through.

General Description

Seat Belt Construction


S7RW0C8101001

Hatchback Model



I6RW0C810001-01

Sedan Model



I7RW0A810001-01

[A]: A-ELR rear center seat belt model	2. Rear seat belt (with A-ELR or ELR)	5. Buckle for rear seat belt
[B]: Non-A-ELR rear center seat belt model	3. Rear center seat belt (with A-ELR or ELR)	6. Retractor
1. Front seat belt (with ELR and pretensioner)	4. Buckle for front seat belt	7. Rear center seat belt (without A-ELR or ELR)

Seat Belt with ELR

The seat belt with emergency locking retractor (ELR) is designed so that it locks immediately (to prevent the webbing from being pulled out of the retractor any further) when any of the following items is detected as exceeding each set value;

- Speed at which the webbing is pulled out of the retractor.
- Acceleration or deceleration of the vehicle speed.
- Inclination.

Seat Belt with A-ELR

The automatic and emergency locking retractor (A-ELR) works as an Emergency Locking Retractor (ELR) till its webbing is pulled all the way out and then on as an Automatic Locking Retractor (ALR) till it is retracted fully. ALR: Automatically locks when the webbing is pulled out from the retractor and allowed to retract even a little. Then the webbing can not be pulled out any further, unless it is wound all the way back into the retractor, which releases the lock and allows the webbing to be pulled out.

Seat Belt with ELR and Pretensioner

The seat belt with ELR and a pretensioner has a pretensioner mechanism which operates in linkage with the air bag in addition to the described ELR.

The pretensioner is incorporated in retractor and controlled by SDM as one of air bag system components. It will be activated at the same time as the driver and passenger air bag module when an impact at the front of vehicle exceeds the specified value. When servicing seat belt (retractor) with pretensioner, be sure to observe all WARNINGS and CAUTIONS and "Precautions on Service and Diagnosis of Air Bag System in Section 8B".

⚠ CAUTION

Do not reuse the seat belt pretensioner (retractor) that has activated. Replace it with a new seat belt and buckle together as a set. For checking procedure of its activation, refer to "Repair and Inspection Required after Accident in Section 8B".

Seat Belt Remainder

When driver's seat belt is unfastened (under the following conditions), seat belt reminder light inform that driver's seat belt is unfastened. Seat belt reminder light located in combination meter located inside BCM operate as follows:

- Seat belt reminder light comes on when driver's seat belt is unfastened while ignition key switch is at ON position.

Diagnostic Information and Procedures

Repair and Inspection Required after Accident

S7RW0C8104001

After an accident, whether the seat belt pretensioner has been activated or not, be sure to perform checks and repairs described on "Repair and Inspection Required after Accident in Section 8B".


Repair Instructions

Front Seat Belt Components

S7RW0C8106001

▲ WARNING

- Never attempt to disassemble or repair the seat belt pretensioner (retractor). If any abnormality is found, be sure to replace it with new one as an assembly.
- Be sure to read “Precautions on Service and Diagnosis of Seat Belt” before starting to work and observe every precaution during work. Neglecting them may result in personal injury or unactivation of the seat belt pretensioner when necessary.



I7RW01810002-01

1. Sash guide	10. Buckle mounting bolt
2. Anchor plate	▲ 11. Sash guide bolt : Tighten sash guide bolt first, then tighten anchor bolt.
3. Retractor	12. Spacer
4. Buckle	13. Washer
5. Yellow connector (for seat belt pretensioner)	14. Spring washer
6. Retractor mounting bolt	15. Wave washer
7. Shoulder adjuster	⌚(a) : 43 N·m (4.3 kgf-m, 31.5 lb-ft)
▲ 8. Shoulder adjuster bolt : Tighten upper bolt first, then tighten lower bolt.	⌚(b) : 5.5 N·m (0.55 kgf-m, 4.0 lb-ft)
▲ 9. Anchor bolt : Tighten sash guide bolt first, then tighten anchor bolt.	

Front Seat Belt Removal and Installation


S7RW0C8106002

⚠ WARNING

- **Never attempt to disassemble or repair the retractor (seat belt pretensioner). If any abnormality is found, be sure to replace it with new one as an assembly.**
- **Be sure to read “Precautions on Service and Diagnosis of Seat Belt” before starting to work and observe every precaution during work. Neglecting them may result in personal injury or unactivation of the seat belt pretensioner when necessary.**

Removal

- 1) Disconnect negative (–) cable at battery.
- 2) Disable air bag system. Refer to “Disabling Air Bag System in Section 8B”.
- 3) Remove center pillar lower trim.
- 4) Disconnect connector (1) from retractor (seat belt pretensioner) (2) as following steps.
 - a) Unlock lock button (3) by pulling it.
 - b) After unlocked, disconnect connector.




I5RW0A810002-02

- 5) Remove front seat belts from the vehicle.

Installation

Install in reverse order of removal, noting the following.

- Seat belt anchor bolts should have an unified fine thread (7/16-20 UNF). Under no circumstances should any different sized or metric screw threads be used.
- Connect seat belt pretensioner connector (1) to retractor (seat belt pretensioner) securely as following steps.
 - a. Make sure that lock button (2) is unlock position.
 - b. Insert connector to retractor (seat belt pretensioner) until it stops with unlocked lock button (2).
 - c. Lock connector securely by showing in lock button (2).



I5RW0A810003-03


- Enable air bag system. Refer to “Enabling Air Bag System in Section 8B”.

Front Seat Belt Inspection

S7RW0C8106003

⚠ WARNING

- **Never attempt to disassemble or repair the seat belt pretensioner (retractor). If any abnormality is found, be sure to replace it with new one as an assembly.**
- **Be sure to read “Precautions on Service and Diagnosis of Seat Belt”, before starting to work and observe every precaution during work. Neglecting them may result in personal injury or unactivation of the seat belt pretensioner when necessary.**
- **Never measure resistance of pretensioner or disassemble it. Otherwise, personal injury may result.**



I2RH01810004-01

⚠ CAUTION

If seat belt pretensioner (retractor) was dropped from a height of 30 cm (1 ft) or more, it should be replaced.

Seat belts and attaching parts can affect the vital components and systems of a vehicle. Therefore, they should be inspected carefully and replaced with genuine parts only.

Seat Belt


- The seat belt webbing or strap should be free from damage.

Retractor (with Seat Belt Pretensioner)

- 1) Let the seat belt retract fully to confirm its easy retraction.
 - The retractor should lock webbing when pulled quickly.
 - The front seat belt retractor (1) should pass the inspection and should lock webbing even when tilted (approx. 15°) toward the fore and aft or right and left directions.

- 2) Check retractor (1) with seat belt pretensioner appearance visually for following symptoms and if any one of them is applicable, replace it with a new one as an assembly.

- Pretensioner has activated.
- There is a crack in seat belt pretensioner (retractor).
- Seat belt pretensioner (retractor) is damaged or a strong impact (e.g., dropping) was applied to it.



I2RH01810005-01

Anchor Bolt

- Anchor bolts should be torqued to specification.

Belt Latch

- It should be secure when latched.

Seat Belt Buckle Switch

Check driver side seat belt switch and passenger side seat belt switch for continuity by using ohmmeter.


Seat belt switch specification

Without inserted buckle tongue to buckle catch:

Terminal “A” and “B”: Continuity

With inserted buckle tongue to buckle catch:

Terminal “A” and “B”: No continuity



I4RS0B810001-01

1. Buckle tongue

2. Buckle catch



Rear Seat Belt Components

S7RW0C8106004

⚠ WARNING


Be sure to read "Precautions on Service and Diagnosis of Seat Belt" before starting to work and observe every precaution during work.

Hatchback Model



I6RW0C810002-01

Sedan Model



I7RW0A810002-01

[A]: A-ELR rear center seat belt model	11. Center retractor
[B]: Non-A-ELR rear center seat belt model	12. Center retractor mounting bolt (hatchback model) : Tighten lower bolt first, then tighten upper bolt.
1. Sash guide	13. Sash guide bolt (hatchback model) : Tighten sash guide bolt first, then tighten side retractor mounting bolt.
2. Anchor plate	14. Spring washer
3. Side retractor	15. Washer
4. Center seat belt	16. Spacer
5. Buckle for seat belt	17. Side retractor mounting bolt (sedan model) : Tighten side retractor mounting bolt first, then Tighten anchor bolt.
6. Buckle for center seat belt	18. Anchor bolt (sedan model) : Tighten side retractor mounting bolt first, then Tighten anchor bolt.
7. Seat belt	19. Center retractor mounting bolt (sedan model) : Tighten center retractor mounting bolt first, then Tighten anchor bolt.
8. Side retractor mounting bolt (hatchback model) : Tighten sash guide bolt first, then tighten side retractor mounting bolt.	10(a) : 43 N·m (4.3 kgf-m, 31.5 lb-ft)
9. Anchor bolt (hatchback model) : Tighten retractor mounting bolts and sash guide bolt first, then tighten anchor bolt.	10(b) : 5.5 N·m (0.55 kgf-m, 4.0 lb-ft)
10. Buckle bolt	

Rear Seat Belt Removal and Installation


S7RW0C8106005

⚠ WARNING

Be sure to read “Precautions on Service and Diagnosis of Seat Belt” before starting to work and observe every precaution during work.

Removal

- 1) Fold rear seats referring to “Folding Rear Seats” in Owners Manual (hatchback model).
- 2) Remove rear side sill scuff (1), quarter lower trim (2) and quarter upper trim (3).



I5RW0A810005-01

- 3) Remove partition trim referring to “Trunk Lid Removal and Installation (Sedan Model) in Section 9J”.
- 4) Remove rear seat belt referring to “Rear Seat Belt Components”.

Installation

Reverse removal procedure for installation noting the following.

- Seat belt anchor bolts should have an unified fine thread (7/16-20 UNF). Under no circumstances should any different sized or metric screw threads be used.

Rear Seat Belt Inspection

S7RW0C8106006

⚠ WARNING

Be sure to read “Precautions on Service and Diagnosis of Seat Belt” before starting to work and observe every precaution during work.

- Check the rear seat belt in the same way as “Front Seat Belt Inspection”.
- As to seat belts with A-ELR, check them as follows.
 - With vehicle at stop, pull seat belt all the way out, let it retract a little and try to pull it. It should not be pulled out, that is, it should be locked where retracted.
 - Let seat belt retract to its original state. Next, pull it half way out, let it retract a little and try to pull it again. It should be pulled out smoothly, that is it should not be locked at this time.

Specifications

Tightening Torque Specifications

S7RW0C8107001

NOTE

The specified tightening torque is also described in the following.

“Front Seat Belt Components”

“Rear Seat Belt Components”

Reference:

For the tightening torque of fastener not specified in this section, refer to “Fasteners Information in Section 0A”.

Air Bag System

Precautions

Precautions on Service and Diagnosis of Air Bag System

S7RW0C8200001

▲ WARNING

- If the air bag system and another vehicle system both need repair, SUZUKI recommends that the air bag system be repaired first, to help avoid unintended air bag system activation.
 - Do not modify the steering wheel, dashboard, both front seat or any other on or around air bag system components. Modifications can adversely affect air bag system performance and lead to injury.
 - Be sure to follow the procedures described in this section. Failure to follow procedures could result in possible air bag system activation, personal injury or unneeded air bag system repairs.
-
- WARNING / CAUTION labels are attached on each part of air bag system components (SDM, air bag (inflator) modules and seat belt pretensioners). Be sure to follow the instructions.
 - Many of service procedures require disconnection of "A/B" fuse and air bag (inflator) module(s) (driver module, passenger module, side modules and curtain modules) from initiator circuit to avoid an accidental deployment.
 - Do not apply power to the air bag system unless all components are connected or a diagnostic flow requests it, as this will set a DTC.
 - The "Air Bag Diagnostic System Check" must be the starting point of any air bag diagnostics. The "Air Bag Diagnostic System Check" will verify proper "AIR BAG" warning light operation and will lead you to the correct flow to diagnose any air bag malfunctions. Bypassing these procedures may result in extended diagnostic time, incorrect diagnosis, and incorrect parts replacements.
 - Never use air bag component parts from another vehicle.
 - If the vehicle will be exposed to temperatures over 93 °C (200 °F) (for example, during a paint baking process), remove the air bag system components beforehand to avoid component damage or unintended system activation.

- When handling the air bag (inflator) modules (driver module, passenger module, side modules and curtain modules), seat belt pretensioners (driver module and passenger module), SDM, forward impact-sensor or side impact-sensor be careful not to drop it or apply an impact to it. If an excessive impact was applied (e.g., SDM, forward impact-sensor are dropped, air bag (inflator) module is dropped from a height of 90 cm (3 ft) or more, seat belt pretensioner (retractor assembly) is dropped from a height of 30 cm (1 ft) or more), never attempt disassembly or repair but replace it with a new one.
- When using electric welding, be sure to disconnect air bag (inflator) module connectors (driver module, passenger module, side modules and curtain modules) and seat belt pretensioner connectors (driver module and passenger module) respectively.
- When applying paint around the air bag system related parts, use care so that the harness or connector will not be exposed to the paint mist.
- Never expose air bag system component parts directly to hot air (drying or baking the vehicle after painting) or flames.

▲ WARNING

When performing service on or around air bag system components or air bag wiring, follow the procedures listed in "Disabling Air Bag System" to temporarily disable the air bag system.

Failure to follow procedures could result in possible air bag system activation, personal injury or unneeded air bag system repairs.

Precautions on Handling and Storage of Air Bag System Components

S7RW0C8200002

SDM


▲ WARNING

Never power up air bag system when SDM is not rigidly attached to the vehicle. Otherwise, personal injury may result.

▲ CAUTION

After detecting one time of such collision as to meet deployment conditions, SDM must not be used. Refer to "Air Bag Diagnostic System Check" when checking SDM.

- Never attempt disassembly of SDM.
- When storing SDM, select a place where neither high temperature nor high humidity is anticipated and oil, water and dust are kept off.



I5RW0A820001-03

- If SDM has been dropped, replace it with a new one.
- If SDM installation part of floor was damaged, repair that part completely before reinstallation.
- All SDM and mounting bracket fasteners must be carefully torqued and the arrow must be pointed toward the front of the vehicle to ensure proper operation of the air bag system.



Live (Undeployed) Air Bag (Inflator) Modules

Special care is necessary when handling and storing a live (undeployed) air bag (inflator) modules.



The rapid gas generation produced during deployment of the air bag could cause the air bag (inflator) module, or an object in front of the air bag (inflator) module, to be thrown through the air in the unlikely event of an accidental deployment.

⚠ WARNING

Never attempt to measure the resistance of the air bag (inflator) modules (driver module, passenger module and side modules and curtain modules). It is very dangerous as the electric current from the tester may deploy the air bag.



I7RW01821001-01




I6RW0B820001-01

- Never attempt disassembly of the air bag (inflator) modules.
- If any abnormality is found, be sure to replace it with new one as an assembly.
- When an abnormality is noted as existing in the live (undeployed) air bag (inflator) module, be sure to deploy it before discarding it.
- When grease, cleaning agent, oil, water, etc., got on the air bag (inflator) modules (driver and passenger), wipe it off immediately with a dry cloth.
- If air bag (inflator) module was dropped from a height of 90 cm (3 ft) or more, it should be replaced with a new one as an assembly.

⚠ WARNING

- For handling and storage of a live air bag (inflator) module, select a place where the ambient temperature below 65 °C (150 °F), without high humidity and away from electric noise.
- When carrying a live air bag (inflator) module, make sure the bag opening is pointed away from you. In case of an accidental deployment, the bag will then deploy with minimal chance of injury. Never carry the air bag (inflator) module by the wires or connector on the underside of the module.

Otherwise, personal injury may result.




I5JB0A820003-01

⚠ WARNING

When leaving or storing live air bag (inflator) module unattended on bench or other surface, always its bag (trim cover) facing up and away from surface.

It is also prohibited to place anything on top of the trim cover and stack air bag (inflator) modules.

This is necessary so that a free space is provided to allow the air bag to expand in the unlikely event of accidental deployment. Otherwise, personal injury may result.




I5RW0A820004-03

Live (Inactivated) Seat Belt Pretensioner

Special care is necessary when handling and storing a live (inactivated) seat belt pretensioners.

Also, when the seat belt pretensioners activate, gas is generated and the seat belt (1) is retracted into the retractor assembly (2) quickly.


Note, therefore, that if they activate accidentally, the seat belt pretensioners and other object(s) around them may be thrown through the air.



I3JA01820043-01

⚠ WARNING

Never attempt to measure the resistance of the seat belt pretensioners. It is very dangerous as the electric current from the tester may activate pretensioner.




I5RW0A820005-03

- Never attempt to disassemble the seat belt pretensioners (retractor assembly).
- If any abnormality is found, be sure to replace it with new one as an assembly.
- When an abnormality is noted as existing in the live (inactivated) seat belt pretensioner, be sure to activate it before discarding it.
- When grease, cleaning agent oil, water, etc., got on the seat belt pretensioners (retractor assembly), wipe it off immediately with a dry cloth.
- If seat belt pretensioner was dropped from a height of 30 cm (1 ft) or more, it should be replaced with a new one as an assembly.

⚠ WARNING

- **For handling and storage of a live seat belt pretensioner, select a place where the ambient temperature below 65 °C (150 °F), without high humidity and away from electric noise.**
- **Never carry the seat belt pretensioner by webbing.**
- **When placing a live seat belt pretensioner on the workbench or other surface, be sure not to lay it with its exhaust hole (1) provided side facing down. It is also prohibited to put something on its face with an exhaust hole (1) or to put a seat belt pretensioner on top of another. Otherwise, personal injury may result.**



Deployed Air Bag (Inflator) Module and Activated Seat Belt Pretensioner

⚠ WARNING

- **The air bag (inflator) module and seat belt pretensioner immediately after deployment/activation is very hot. Wait for at least 30 minutes to cool it off before proceeding the work.**
- **Do not apply water, oil, etc. to deployed air bag (inflator) module and to activate seat belt pretensioner.**


- **After an air bag (inflator) module has been deployed, the surface of the air bag may contain a powdery residue. This powder consists primarily of cornstarch (used to lubricate the bag as it inflates) and by-products of the chemical reaction. As with many service procedures, gloves and safety glasses should be worn.**
- **Wash your hands with mild soap and water after completing the work.**

Refer to the procedure described under "Deployed Air Bag (Inflator) Module and Activated Seat Belt Pretensioner Disposal" for disposal.

Air Bag Wire Harness and Connector

Air bag wire harness is included in main harness (1), instrument panel harness (4), floor harness (3), seat harness (5) and curtain air bag harness (6) (hatchback model). Air bag wire harness can be identified easily as the part of connector side wire harness is covered with a yellow protection tube. Be very careful when handling it.

- When an open in air bag wire harness, damaged wire harness, connector or terminal is found, replace wire harness, connectors and terminals as an assembly.
- When installing it, be careful so that the air bag wire harness is not caught or does not interfere with other parts.
- Make sure air bag system grounding point (2) is clean and ground is securely fastened for optimum metal-to-metal contact. Poor grounding can cause intermittent problems that are difficult to diagnose.



7. Side curtain-air bag (inflator) module (sedan model)

8. Side curtain-air bag (inflator) module (hatchback model)

Precautions on Disposal of Air Bag and Seat Belt Pretensioner

S7RW0C8200003

Do not dispose of the live (undeployed) air bag (inflator) modules and the live (inactivated) seat belt pretensioners.

When disposal is necessary, be sure to deploy / activate the air bag and seat belt pretensioner according to deployment / activation procedure described in “Air Bag (Inflator) Module and Seat Belt Pretensioner Disposal”.

⚠ WARNING

Failure to follow proper air bag (inflator) module and seat belt pretensioner disposal procedures can result in air bag deployment and pretensioner activation which could cause personal injury. Undeployed air bag (inflator) module and inactivated seat belt pretensioner must not be disposed of through normal refuse channels. The undeployed air bag (inflator) module and inactivated seat belt pretensioner contain substances that can cause severe illness or personal injury if the sealed container is damaged during disposal.

General Description

Air Bag System Construction

S7RW0C8201001

There are two types of air bag system in this model depending on vehicle specification. One is 4-channel air bag system and other is 8-channel air bag system.

4-channel air bag system consists of the following parts.

- Driver and passenger air bag (inflator) modules
- Driver and passenger seat belt pretensioners
- Forward impact-sensor
- SDM

8-channel air bag system consists of the following component.


- Driver and passenger air bag (inflator) modules
- Driver and passenger seat belt pretensioners
- Driver and passenger side-air bag (inflator) modules
- Driver and passenger side curtain-air bag (inflator) modules
- Forward impact-sensor
- Driver and passenger side impact-sensors
- SDM

With the air bag system which includes front air bags for both the driver's and passenger's sides as well as the seat belt pretensioners, the sag of the seat belt is taken up (for seat belt with pretensioner), the driver air bag (inflator) module is deployed from the center of the steering column and the passenger air bag (inflator) module from the top of the instrument panel in front of the front passenger seat in occurrence of a front collision with an impact larger than a certain set value to supplement protection offered by the driver and front passenger seat belts.

In addition, with the air bag system which includes side-air bags and side curtain-air bags for both the driver's and passenger's side (8-channel system).

Side-air bag (inflator) module is deployed from the side of the seat back in occurrence of a sideward collision with an impact larger than a certain set value.


Side curtain-air bag (inflator) module is deployed from the roof side in occurrence of a sideward collision with an impact larger than a certain set value. For details of air bag system input / output, refer to “Air Bag System Input / Output Table”.



I4RS0B820002-02

1. Driver air bag	4. Side-air bag
2. Passenger air bag	5. Side curtain-air bag
3. Seat belt pretensioner	

The air bag system is designed to activate only in severe frontal “a” and sideward “b” collisions. It is not designed to activate in rear impacts, rollovers, or minor frontal and sideward collisions, since it would offer no protection in those types of accidents.



I6RW0C820019-01

Air Bag System Input / Output Table

S7RW0C8201003


OUTPUT (deployment & activation device) INPUT (sensor signal)	Driver & Passenger air bag inflator modules	Driver & Passenger seat belt pretensioners	Driver side-air bag & driver side curtain-air bag inflator modules	Passenger side-air bag & passenger side curtain-air bag inflator modules
X-Y G sensor (longitudinal / lateral acceleration) in SDM	○	○	○	○
Mecanical longitudinal G sensor in SDM	○	○	—	—
Forward impact-sensor	○	○	—	—
Driver side impact- sensor	—	—	○	—
Passenger side impact- sensor	—	—	—	○

I7RW0A820009-02

Schematic and Routing Diagram

Air Bag System Wiring Circuit Diagram


S7RW0C8202001



I7RW0A820001-03

[A]: Shorting bar	9. "METER" fuse	23. Driver air bag (inflator) module
[B]: Connector	10. "A/B" fuse	24. Passenger air bag (inflator) module
[C]: Junction block with BCM model	11. BCM	25. Driver seat belt pretensioner
[D]: Junction block without BCM model	12. Combination meter	26. Passenger seat belt pretensioner
[E]: Hatchback model	13. "AIR BAG" warning light	27. Driver side-air bag (inflator) module (8-channel system)
[F]: Sedan model	14. Light driver	28. Passenger side-air bag (inflator) module (8-channel system)
1. Battery	15. SDM	29. Driver side curtain-air bag (inflator) module (8-channel system)
2. Main fuse box	16. To HVAC control module (auto A/C model)	30. Passenger side curtain-air bag (inflator) module (8-channel system)
3. Fuse	17. Data link connector (DLC)	31. Safing power driver
4. Individual circuit fuse box No.1	18. Forward impact-sensor	32. X-Y-G (longitudinal / lateral acceleration)
5. "IGN" fuse box	19. Driver side impact-sensor (8-channel system)	33. DC / DC converter
6. Ignition switch	20. Passenger side impact-sensor (8-channel system)	34. Mechanical longitudinal G sensor (switch)
7. Junction block assembly	21. Ground for air bag system	35. Back up capacitor
8. "DOME" fuse	22. Contact coil assembly	

Terminal arrangement of SDM (viewed from harness side)



1. SDM Connector "L04"

I7RW01822003-02

Connector "L04" (SDM connector)


Terminal	Circuit	Terminal	Circuit
L04-1	—	L04-27	Ignition switch (power source)
L04-2	"AIR BAG" warning light	L04-28	Ground
L04-3	Driver air bag (—)	L04-29	—
L04-4	Driver air bag (+)	L04-30	—
L04-5	Passenger air bag (+)	L04-31	—
L04-6	Passenger air bag (—)	L04-32	DLC
L04-7	Driver seat belt pretensioner (—)	L04-33	—
L04-8	Driver seat belt pretensioner (+)	L04-34	—
L04-9	Passenger seat belt pretensioner (+)	L04-35	—
L04-10	Passenger seat belt pretensioner (—)	L04-36	—
L04-11	Driver side-air bag (—) (8-channel system)	L04-37	BCM communication line (air bag deployment signal)
L04-12	Driver side-air bag (+) (8-channel system)	L04-38	—
L04-13	Passenger side-air bag (+) (8-channel system)	L04-39	—
L04-14	Passenger side-air bag (—) (8-channel system)	L04-40	—
L04-15	—	L04-41	—
L04-16	—	L04-42	—
L04-17	—	L04-43	—
L04-18	—	L04-44	Passenger side impact-sensor (—) (8-channel system)
L04-19	Driver side curtain-air bag (—) (8-channel system)	L04-45	Passenger side impact-sensor (+) (8-channel system)
L04-20	Driver side curtain-air bag (+) (8-channel system)	L04-46	Driver side impact-sensor (+) (8-channel system)
L04-21	Passenger side curtain-air bag (+) (8-channel system)	L04-47	Driver side impact-sensor (—) (8-channel system)

8B-9 Air Bag System:

Terminal	Circuit	Terminal	Circuit
L04-22	Passenger side curtain-air bag (-) (8-channel system)	L04-48	—
L04-23	—	L04-49	—
L04-24	—	L04-50	Forward impact-sensor (+)
L04-25	—	L04-51	Forward impact-sensor (-)
L04-26	—		

Air Bag System Input / Output Diagram

S7RW0C8202002




I6RW0C820001-01

Component Location

Air Bag System Components, Wiring and Connectors Location

S7RW0C8203001



I6RW0B820004-02

8B-11 Air Bag System:

A: Combination meter	5. Side-air bag (inflator) module (8-channel system)	14. "A/B" fuse in junction block assembly
B: Steering wheel	6. Side curtain-air bag (inflator) module (8-channel system)	15. Air bag harness in main harness
C: Seat	7. Contact coil assembly	16. Air bag harness in instrument panel harness
[D]: Hatchback model	8. Forward impact-sensor	17. Air bag harness in floor harness
[E]: Sedan model	9. Apron-side-member (driver side)	18. Side-air bag harness (8-channel system)
1. "AIR BAG" warning light	10. Side impact-sensor (8-channel system)	19. Side curtain-air bag harness (8-channel system)
2. Driver air bag (inflator) module	11. Side sill inner panel	20. Ground for air bag system
3. Passenger air bag facing cover	12. SDM	
4. Passenger air bag (inflator) module	13. Seat belt pretensioner	

Diagnostic Information and Procedures

Air Bag Diagnostic System Check

S7RW0C8204001

⚠ WARNING

To avoid deployment when troubleshooting the air bag system, do not use electrical test equipment such as a battery powered or AC powered voltmeter, ohmmeter, etc., or any type of electrical equipment other than that specified in this manual. Do not use a non-powered probe type tester.

Instructions in this manual must be followed carefully, otherwise personal injury may result.

⚠ CAUTION

- **The order in which DTCs are diagnosed is very important. Failure to diagnose the DTCs in the order specified may result in extended diagnostic time, incorrect diagnosis and incorrect parts replacement.**
- **When measurement of resistance or voltage is required in the flow, use a tester along with a correct terminal adapter from special tool (Connector test adapter kit).**
- **When a check for proper connection is required, refer to "Inspection of Intermittent and Poor Connections".**
- **If an open circuit in the air bag wire harness damaged, connector or terminal is found, replace the wire harness, connectors and terminals as an assembly.**

The diagnostic procedures used are designed to find and repair air bag system malfunctions.

To get the best results, it is important to use the diagnostic flow and follow the sequence in the following.

- 1) Perform the "Air Bag Diagnostic System Check Flow".
(The "Air Bag Diagnostic System Check Flow" must be the starting point of any air bag system diagnosis. The "Air Bag Diagnostic System Check Flow" checks for proper "AIR BAG" warning light operation through "AIR BAG" warning light and whether air bag DTCs exist.)
- 2) Refer to the proper diagnostic flow as directed by the "Air Bag Diagnostic System Check Flow".
(The "Air Bag Diagnostic System Check Flow" will lead you to the correct flow to diagnose any air bag system malfunctions. Bypassing these procedures may result in extended diagnostic time, incorrect diagnosis and incorrect parts replacement.)
- 3) Repeat the "Air Bag Diagnostic System Check Flow" after any repair or diagnostic procedures have been performed.
(Performing the "Air Bag Diagnostic System Check Flow" after all repair or diagnostic procedures will ensure that the repair has been made correctly and that no other malfunctions exist.)

Air Bag Diagnostic System Check Flow

⚠ CAUTION

- Be sure to perform “Air Bag Diagnostic System Check” before starting diagnosis according to each flow.
- When measurement of resistance or voltage is required in the flow, use a tester along with a correct terminal adapter from special tool (Connector test adapter kit).
- When a check for proper connection is required, refer to “Inspection of Intermittent and Poor Connections”.
- If an open circuit in the air bag wire harness damaged, connector or terminal is found, replace the wire harness, connectors and terminals as an assembly.

Step	Action	Yes	No
1	Battery voltage check. 1) Measure battery voltage. <i>Is it 10 – 14 V?</i>	Go to Step 2.	Proceed to “Battery Inspection in Section 1J”.
2	“AIR BAG” warning light check (6 times flushing check). 1) Turn ON ignition switch, and then check that “AIR BAG” warning light flushes. <i>Does “AIR BAG” warning light flash 6 times?</i>	Go to Step 3.	Go to Step 4.
3	“AIR BAG” warning light check (turning off check). 1) In the state of Step 2. check that “AIR BAG” warning light turn OFF after flashing 6 times. <i>Does “AIR BAG” warning light turn OFF?</i>	Go to Step 5.	Go to Step 6.
4	“AIR BAG” warning light circuit check <i>Does “AIR BAG” warning light come ON steady?</i>	Go to checking flow of ““AIR BAG” Warning Light Comes ON Steady”. After carrying out it flow, proceed to Step 6.	Go to checking flow of ““AIR BAG” Warning Light Does Not Come ON”. After carrying out it flow, proceed to Step 6.
5	DTC check 1) Check DTC using SUZUKI scan tool referring to “DTC Check”. <i>Is “NO CODES” displayed on SUZUKI scan tool?</i>	Air bag system is in good condition.	Check intermittent troubles referring to “Inspection of Intermittent and Poor Connections”. If intermittent troubles are OK, check and repair applicable DTC flow and then repeat this flow.
6	DTC check 1) Check DTC using SUZUKI scan tool, referring to “DTC Check”. <i>Is “NO CODES” displayed on SUZUKI scan tool?</i>	Substitute a known-good SDM and recheck.	Check and repair applicable DTC flow, and then repeat this flow.

DTC Table

NOTE

The DTCs (B1022 and B1023) shown with asterisk (*) below have been established only for the M15A engine model with 4A/T equipped with slip-control (i.e., Hong Kong model). These codes are meant to be recorded when External Scrapping Deployment Controller is operated by a Japanese authorized special scrapping trader. Therefore, normally these codes will not appear outside Japan. However, should these codes be detected, SDM must be replaced because the cause is due to SDM detection failure.

SDM DTC

DTC No.	Detecting item	Detecting condition (DTC will set when detecting)	Trouble area
—	Normal	—	—
☞ B1013	SDM internal failure	Malfunctioned SDM internal circuit, G sensor, memory or CPU.	• SDM
☞ B1014	"AIR BAG" warning light circuit	"AIR BAG" warning light circuit has been shorted to ground, shorted to power or opened for more than 4 sec.	• "AIR BAG" warning light circuit • Combination meter • SDM
☞ B1016	Power supply voltage too high	Power supply voltage is more than 21.4 V for, more than 16 sec.	• Charging system • SDM
☞ B1017	Power supply voltage too low	Power supply voltage is less than 7.2 V for more than 16 sec.	• Charging system • SDM
☞ B1021	Front air bag deployment record	Deployment of front air bag has been recorded in SDM.	If this DTC has been recorded even though air bag has not been deployed • SDM • Driver and/or Passenger air bag module • Those initiator circuit.
*B1022	Scrapping deployment controller activated	Scrapping deployment command has been input to SDM from external scrapping deployment controller	• SDM
*B1023	Scrapping deployment record	Scrapping deployment execution has been recorded in SDM	• SDM
☞ B1024	Driver side-air bag deployment record	Deployment of driver side-air bag has been recorded in SDM.	If this DTC has been recorded even though side-air bag has not been deployed • SDM • Driver side-air bag module • Its initiator circuit
☞ B1025	Passenger side-air bag deployment record	Deployment of passenger side-air bag has been recorded in SDM.	If this DTC has been recorded even though side-air bag has not been deployed • SDM • Passenger side-air bag module • Its initiator circuit

DTC No.	Detecting item	Detecting condition (DTC will set when detecting)	Trouble area
B1026	Seat belt pretensioner activation record	Activation of seat belt pretensioner has been recorded in SDM.	If this DTC has been recorded even though pretensioner has not been activated - SDM - Driver and/or Passenger seat belt pretensioner - Those initiator circuit
B1027	Number of deployment times exceeded limit	Deployment of air bag and activation of seat belt pretensioner have been recorded in SDM 5 times or more.	If this DTC has been recorded even though air bag (front and side) and pretensioner have not been deployed more than 4 place. - SDM (internal fault or reused SDM) - Each of deployment and activation module - Those initiator circuit
B1031	Driver air bag circuit high resistance	Driver air bag circuit is more than 5.2 Ω for more than 4 sec.	- Driver air bag circuit - Contact coil assembly - Driver air bag module - SDM
B1032	Driver air bag circuit low resistance	Driver air bag circuit is less than 1.1 Ω for more than 4 sec.	
B1033	Driver air bag circuit shorted to ground	Driver air bag circuit has been shorted to ground for more than 4 sec.	- Driver air bag circuit - SDM
B1034	Driver air bag circuit shorted to power supply	Driver air bag circuit has been shorted to power supply for more than 4 sec.	
B1041	Passenger air bag circuit high resistance	Passenger air bag circuit is more than 4.0 Ω for more than 4 sec.	- Passenger air bag circuit - Passenger air bag module - SDM
B1042	Passenger air bag circuit low resistance	Passenger air bag circuit is less than 0.9 Ω for more than 4 sec.	
B1043	Passenger air bag circuit shorted to ground	Passenger air bag circuit has been shorted to ground for more than 4 sec.	- Passenger air bag circuit - SDM
B1044	Passenger air bag circuit shorted to power supply	Passenger air bag circuit has been shorted to power supply for more than 4 sec.	
B1051	Driver seat belt pretensioner circuit high resistance	Driver seat belt pretensioner circuit is more than 4.0 Ω for more than 4 sec.	- Driver seat belt pretensioner circuit - Driver seat belt pretensioner - SDM
B1052	Driver seat belt pretensioner circuit low resistance	Driver seat belt pretensioner circuit is less than 0.9 Ω for more than 4 sec.	
B1053	Driver seat belt pretensioner circuit shorted to ground	Driver seat belt pretensioner circuit has been shorted to ground for more than 4 sec.	- Driver seat belt pretensioner circuit - SDM
B1054	Driver seat belt pretensioner circuit shorted to power supply	Driver seat belt pretensioner circuit has been shorted to power supply for more than 4 sec.	
B1055	Passenger seat belt pretensioner circuit high resistance	Passenger seat belt pretensioner circuit is more than 4.0 Ω for more than 4 sec.	- Passenger seat belt pretensioner circuit - Passenger seat belt pretensioner - SDM
B1056	Passenger seat belt pretensioner circuit low resistance	Passenger seat belt pretensioner circuit is less than 0.9 Ω for more than 4 sec.	

8B-15 Air Bag System:

DTC No.	Detecting item	Detecting condition (DTC will set when detecting)	Trouble area
☞ B1057	Passenger seat belt pretensioner circuit shorted to ground	Passenger seat belt pretensioner circuit has been shorted to ground for more than 4 sec.	- Passenger seat belt pretensioner circuit - SDM
☞ B1058	Passenger seat belt pretensioner circuit shorted to power supply	Passenger seat belt pretensioner circuit has been shorted to power circuit for more than 4 sec.	
☞ B1061	Driver side-air bag circuit high resistance	Driver side-air bag circuit is more than 3.7 Ω for more than 4 sec.	- Driver side-air bag circuit - Driver side-air bag module - SDM
☞ B1062	Driver side-air bag circuit low resistance	Driver side-air bag circuit is less than 1.0 Ω for more than 4 sec.	
☞ B1063	Driver side-air bag circuit shorted to ground	Driver side-air bag circuit has been shorted to ground for more than 4 sec.	- Driver side-air bag circuit - SDM
☞ B1064	Driver side-air bag circuit shorted to power supply	Driver side-air bag circuit has been shorted to power supply for more than 4 sec.	
☞ B1065	Passenger side-air bag circuit high resistance	Passenger side-air bag circuit is more than 3.7 Ω for more than 4 sec.	- Passenger side-air bag circuit - Driver side-air bag module - SDM
☞ B1066	Passenger side-air bag circuit low resistance	Passenger side-air bag circuit is less than 1.0 Ω for more than 4 sec.	
☞ B1067	Passenger side-air bag circuit shorted to ground	Passenger side-air bag circuit has been shorted to ground for more than 4 sec.	- Passenger side-air bag circuit - SDM
☞ B1068	Passenger side-air bag circuit shorted to power	Passenger side-air bag circuit has been shorted to power circuit for more than 4 sec.	
☞ B1071	Driver forward impact-sensor communication data inconsistent	Driver forward impact-sensor has been communicated with no response or inconsistent ID code for more than 4 sec.	- Driver forward impact-sensor - Driver forward impact-sensor circuit - SDM
☞ B1072	Driver forward impact-sensor communication data invalid	Driver forward impact-sensor has been communicated with invalid data for more than 4 sec.	- Driver forward impact-sensor - SDM
☞ B1073	Driver forward impact-sensor circuit shorted to ground	Driver forward impact-sensor circuit has been shorted to ground for more than 4 sec.	- Driver forward impact-sensor - Driver forward impact-sensor circuit - SDM
☞ B1074	Driver forward impact-sensor circuit open	Driver forward impact-sensor circuit has been shorted to power circuit or opened for more than 4 sec.	
☞ B1081	Driver side impact-sensor no response	Driver side impact-sensor has been communicated with no response for more than 4 sec.	- Driver side impact-sensor circuit - Driver side impact-sensor - SDM
☞ B1082	Driver side impact-sensor communication data invalid	Driver side impact-sensor has been communicated with invalid data for more than 4 sec.	- Driver side impact-sensor - SDM
☞ B1083	Driver side impact-sensor circuit shorted to ground	Driver side impact-sensor circuit has been shorted to ground for more than 4 sec.	- Driver side impact-sensor circuit - Driver side impact-sensor - SDM
☞ B1084	Driver side impact-sensor circuit open	Driver side impact-sensor circuit has been shorted to power circuit or opened for more than 4 sec.	

DTC No.	Detecting item	Detecting condition (DTC will set when detecting)	Trouble area
B1085	Driver side impact-sensor communication data inconsistent	Driver side impact-sensor has been communicated with inconsistent ID code for more than 4 sec.	- Driver side impact-sensor - SDM
B1091	Passenger side impact-sensor no response	Communication with passenger side impact-sensor has been no response for more than 4 sec.	- Passenger side impact-sensor circuit - Passenger side impact-sensor - SDM
B1092	Passenger side impact-sensor communication data invalid	Passenger side impact-sensor has been communicated with invalid data for more than 4 sec.	- Passenger side impact-sensor circuit - SDM
B1093	Passenger side impact-sensor circuit shorted to ground	Passenger side impact-sensor circuit has been shorted to ground for more than 4 sec.	- Passenger side impact-sensor - SDM
B1094	Passenger side impact-sensor circuit open	Passenger side impact-sensor circuit has been shorted to power circuit or opened for more than 4 sec.	
B1095	Passenger side impact-sensor communication data inconsistent	Passenger side impact-sensor has been communicated with inconsistent ID code for more than 4 sec.	- Passenger side impact-sensor - SDM
B1361	Driver curtain-air bag circuit high resistance	Driver curtain-air bag circuit is more than 3.8 Ω for more than 4 sec.	- Driver curtain-air bag circuit - Driver curtain-air bag module - SDM
B1362	Driver curtain-air bag circuit low resistance	Driver curtain-air bag circuit is less than 1.0 Ω for more than 4 sec.	
B1363	Driver curtain-air bag circuit shorted to ground	Driver curtain-air bag circuit has been shorted to ground for more than 4 sec.	- Driver curtain-air bag circuit - SDM
B1364	Driver curtain-air bag circuit shorted to power	Driver curtain-air bag circuit has been shorted to power circuit for more than 4 sec.	
B1365	Passenger curtain-air bag circuit high resistance	Passenger curtain-air bag circuit is more than 3.8 Ω for more than 4 sec.	- Passenger curtain-air bag circuit - Passenger curtain-air bag module - SDM
B1366	Passenger curtain-air bag circuit low resistance	Passenger curtain-air bag circuit is less than 1.0 Ω for more than 4 sec.	
B1367	Passenger curtain-air bag circuit shorted to ground	Passenger curtain-air bag circuit has been shorted to ground for more than 4 sec.	- Passenger curtain-air bag circuit - SDM
B1368	Passenger curtain-air bag circuit shorted to power	Passenger curtain-air bag circuit has been shorted to power circuit for more than 4 sec.	

DTC Check

S7RW0C8204004

- 1) Turn ignition switch to OFF position.
- 2) Connect SUZUKI scan tool to data link connector (DLC) located on underside of instrument panel at driver's seat side.


Special tool**(A): SUZUKI scan tool**

- 3) Turn ignition switch to ON position.
- 4) Read DTC according to instructions displayed on SUZUKI scan tool and print it or write it down. Refer to SUZUKI scan tool operator's manual for further details.

If communication between scan tool and SDM is not possible, check if scan tool is communicable by connecting it to SDM in another vehicle. If communication is possible in this case, scan tool is in good condition. Then check data link connector and serial data line (circuit) in the vehicle with which communication was not possible.

If connector and circuit are OK, check that DLC circuit and power supply and ground circuits of SDM are in good condition referring to "SDM Power Supply and Ground Circuit Check" and "Serial Data Link Circuit Check".

- 5) After completing the check, turn ignition switch to OFF position and disconnect SUZUKI scan tool from data link connector (DLC) (1).




I5RW0A820010-03

DTC Clearance

S7RW0C8204005

- 1) Turn ignition switch to OFF position.
- 2) Connect SUZUKI scan tool to data link connector (DLC) (1) in the same manner as when making this connection for DTC check.

Special tool**(A): SUZUKI scan tool**

I5RW0A820010-03

- 3) Turn ignition switch to ON position.
- 4) Erase DTC according to instructions displayed on SUZUKI scan tool. Refer to SUZUKI scan tool operator's manual for further details.
- 5) After completing the clearance, perform "DTC Check" and confirm that normal DTC (NO CODES) is displayed and not malfunction DTC.
- 6) Turn ignition switch to OFF position and disconnect SUZUKI scan tool from DLC.

NOTE

If DTC B1013, DTC B1021 or DTC B1027 is stored in SDM, it is not possible to clear DTC.

Scan Tool Data

S7RW0C8204006

Data list of SDM

Scan Tool Data	Normal Condition / Reference Value
Buck Up Volt	27.0 – 33.0 V
Battery Voltage	10 – 14 V
Driv Air Bag Ini Res	1.5 – 5.0 ohm
Pass Air Bag Ini Res	1.0 – 3.8 ohm
Driv Preten Ini Res	1.0 – 3.8 ohm
Pass Preten Ini Res	1.0 – 3.8 ohm
Driv Sidebag Ini Res	1.0 – 3.5 ohm
Pass Sidebag Ini Res	1.0 – 3.5 ohm
Driv curtain Ini Res	1.0 – 3.5 ohm
Pass curtain Ini Res	1.0 – 3.5 ohm
System ID	4ch or 8ch

Scan Tool Data Definition**Buck Up Volt (V)**

This parameter indicates the capacity of the backup capacitor installed to maintain the ignition current (as much as possible) even when the power supply to SDM that ignites the inflator is shut off.

Battery Voltage (V)

Battery voltage is an analog input signal read by SDM.

Dirv Air Bag Ini Res (Driver air bag initiator resistance) (ohm)

This parameter indicates the resistance of the driver air bag initiator circuit.

Pass Air Bag Ini Res (Passenger air bag initiator resistance) (ohm)

This parameter indicates the resistance of the passenger air bag initiator circuit.

Driv Preten Ini Res (Driver pretensioner initiator resistance) (ohm)

This parameter indicates the resistance of the driver seat belt pretensioner initiator circuit.

Pass Preten Ini Res (Passenger pretensioner initiator resistance) (ohm)

This parameter indicates the resistance of the passenger seat belt pretensioner initiator circuit.

Driv Sidebag Ini Res (Driver side-air bag initiator resistance) (ohm)

This parameter indicates the resistance of the driver side-air bag initiator circuit.

Pass Sidebag Ini Res (Passenger side-air bag initiator resistance) (ohm)

This parameter indicates the resistance of the passenger side-air bag initiator circuit.

Driv curtain Ini RES (Driver side curtain-air bag initiator resistance) (ohm)

This parameter indicates the resistance of the driver side curtain-air bag initiator circuit.

Pass curtain Ini RES (Passenger side curtain-air bag initiator resistance) (ohm)


This parameter indicates the resistance of the passenger side curtain-air bag initiator circuit.

System ID (4ch/8ch)

This parameter indicates the number of initiator circuits.

“AIR BAG” Warning Light Comes ON Steady



S7RW0C8204007



Wiring Diagram

I6RW0C820005-01

1. Battery	5. "IGN" fuse	9. "METER" fuse	13. Light driver
2. Main fuse box	6. Ignition switch	10. "DOME" fuse	14. SDM
3. Fuse	7. Junction block assembly	11. Combination meter	15. Ground for SDM
4. Individual circuit fuse box No.1	8. "A/B" fuse	12. "AIR BAG" warning light	

Troubleshooting

Step	Action	Yes	No
1	Was "Air Bag Diagnostic System Check Flow" performed?	Go to Step 2.	Go to "Air Bag Diagnostic System Check Flow".
2	SDM power supply and ground circuit check 1) Check SDM power supply and ground circuit referring to "SDM Power Supply and Ground Circuit Check". <i>Is SDM power supply and ground circuit in good condition?</i>	Go to Step 3.	Repair defective power supply and ground circuit.
3	"AIR BAG" warning light circuit check 1) Disconnect combination meter connector "G241" referring to "Combination Meter Removal and Installation in Section 9C". 2) Disconnect SDM connector "L04". 3) Check for proper connection to SDM connector at terminal "L04-2". 4) Check for proper connection to combination meter at terminal "G241-5". 5) If OK, measure resistance between "G241-5" and "L04-2" terminals. Special tool (A): 09932-76010  I7RW01822006-01 <i>Is measured resistance 1 Ω or less?</i>	Go to Step 4.	Repair "YEL/BLK" wire (between combination meter and SDM connector) for open or high resistance.
4	"AIR BAG" warning light circuit check 1) Measure resistance between "L04-2" terminal and body ground. Special tool (A): 09932-76010  I7RW01822007-01 <i>Is measured resistance infinity?</i>	Go to Step 5.	Repair "YEL/BLK" wire (between combination meter and SDM connector) for short to ground.

Step	Action	Yes	No
5	“AIR BAG” warning light circuit check 1) Connect SDM connector “L04” and combination meter connector “G241”. 2) With ignition switch turned ON, measure voltage between “G241-5” terminal and body ground. Special tool (A): 09932-76010  <i>Is measured voltage in 8 – 12 V?</i>	Replace combination meter.	Go to Step 6.
6	“AIR BAG” warning light circuit check 1) Disconnect combination meter connector “G241”. 2) Measure voltage between “G241-5” terminal and body ground. Special tool (A): 09932-76010  <i>Is measured voltage in 10 – 14 V?</i>	Replace combination meter.	Replace SDM.

NOTE


Upon completion of inspection and repair work, perform the following items.

- Reconnect all air bag system components and ensure all components are properly mounted.
- Repeat “Air Bag Diagnostic System Check” to confirm that the trouble has been corrected.

“AIR BAG” Warning Light Does Not Come ON**Wiring Diagram**

Refer to ““AIR BAG” Warning Light Comes ON Steady”.

Troubleshooting

Step	Action	Yes	No
1	Was “Air Bag Diagnostic System Check Flow” performed?	Go to Step 2.	Go to “Air Bag Diagnostic System Check Flow”.
2	Combination meter power feed circuit check 1) Set parking brake. 2) Note combination meter when ignition switch is turned ON. <i>Does the “BRAKE” indicator (warning light) come ON?</i>	Go to Step 3.	Check combination meter power and ground circuit referring to “C-1 Combination Meter Circuit Diagram (Meter) in Section 9A”.
3	“AIR BAG” warning light circuit check 1) Disconnect SDM connector “L04”. 2) Note combination meter when ignition switch is turned ON. <i>Does the “AIR BAG” warning light come ON?</i>	Substitute a known-good SDM and recheck.	Go to Step 4.
4	“AIR BAG” warning light circuit check 1) Disconnect SDM connector “L04”. 2) With ignition switch turned ON, measure voltage between “L04-02” terminal and body ground. Special tool (A): 09932-76010  <i>Is measured voltage 0 V?</i>	Replace combination meter.	Repair “YEL/BLK” circuit for short to power circuit.


NOTE

Upon completion of inspection and repair work, perform the following items.

- Reconnect all air bag system components and ensure all components are properly mounted.
- Repeat “Air Bag Diagnostic System Check” to confirm that the trouble has been corrected.

Serial Data Link Circuit Check

Wiring Diagram



I6RW0C820006-01

[A]: Junction block with BCM model	4. Individual circuit fuse box No.1	12. "METER" fuse
[B]: Junction block without BCM model (That is, TAIWAN spec model)	5. "IGN" fuse	13. "A/B" fuse
A: Serial data circuit	6. Ignition switch	14. BCM
B: DLC power supply circuit	7. Combination meter	15. Data link connector (DLC)
C: DLC ground circuit	8. "AIR BAG" warning light	16. Ground for air system
1. Battery	9. Light driver	17. To HVAC control module (auto A/C model)
2. Main fuse box	10. Junction block assembly	18. SDM
3. Fuse	11. "DOME" fuse	

Troubleshooting

Step	Action	Yes	No
1	“AIR BAG” warning light check 1) Turn ignition switch to ON position. <i>Does “AIR BAG” warning light come ON steady?</i>	Go to “AIR BAG” Warning Light Comes ON Steady”.	Go to Step 2.
2	Scan tool condition check 1) Make sure that SUZUKI scan tool is as follows. • Correct PCMCIA card (software) is used. • There are no deformation and wear for DLC cable terminals. • Connection for DLC cable terminals is in good condition. <i>Are they OK?</i>	Go to Step 3.	Repair or replace defective part.
3	Scan tool operation check 1) Check DLC terminal for deformation and wear. 2) If it is in good condition, connect SUZUKI scan tool to DLC with ignition switch turned OFF. 3) Check if communication is possible by making communication with other control modules (BCM, ABS control module, HVAC control module (auto A/C model) or P/S control module). <i>Is it possible to communicate with the other control modules?</i>	Go to Step 4.	Go to Step 6.
4	Serial communication circuit check 1) With ignition switch turned OFF, disconnect SDM connector “L04” and check for proper connection at SDM connector terminal. 2) If connections are OK, check that “Serial data circuit” is as follows. • Wiring resistance of “Serial data circuit” wire between DLC and SDM connector is less than 1 Ω. <i>Is it resistance less than 1 Ω?</i>	Go to Step 5.	“Serial data circuit” is open or high resistance.
5	SDM power and ground circuit check 1) Check power supply circuit and ground circuit for SDM referring to “SDM Power Supply and Ground Circuit Check”. <i>Is check result in good condition?</i>	Substitute a known-good SDM and recheck.	Repair or replace defective circuit.
6	DLC power and ground circuit check 1) Check power supply circuit and ground circuit for DLC as follows. • Voltage of “DLC power supply circuit” between DLC terminal and vehicle body ground is 10 – 14 V with ignition switch turned ON. • Wire resistance of each “DLC ground circuit” between DLC terminal and vehicle body ground is less than 1Ω. <i>Is check result in good condition?</i>	Go to Step 7.	Repair or replace defective circuit.

Step	Action	Yes	No
7	Serial communication circuit check 1) With ignition switch turned OFF, disconnect SDM connector "L04" and check for proper connection at SDM connector terminal. 2) If connections are OK, check that "Serial data circuit" is as follows. - Insulation resistance of "Serial data circuit" wire is infinity between its terminal and other terminals at SDM connector. - Insulation resistance of "Serial data circuit" wire is infinity between its terminal and vehicle body ground. <i>Is circuit in good condition?</i>	Go to Step 8.	Repair or replace defective circuit.
8	Scan tool operation check 1) Check if communication is possible by making communication with other vehicles. <i>Is it possible to communicate with the other vehicle?</i>	Scan tool is in good condition, check intermittent trouble referring to "Intermittent and Poor Connection Inspection in Section 00".	Recheck PCMCIA card and DLC cable for faulty condition. If they are OK, scan tool is faulty.

DTC B1013: SDM Internal Failure

S7RW0C8204010

DTC Detecting Condition and Trouble Area

DTC detecting condition	Trouble area
Malfunctioned SDM internal circuit, G sensor, memory or CPU.	• SDM

NOTE

DTC B1013 can never be cleared once it has been set.

DTC Troubleshooting

Step	Action	Yes	No
1	<i>Was "Air Bag Diagnostic System Check Flow" performed?</i>	Go to Step 2.	Go to "Air Bag Diagnostic System Check Flow"
2	DTC check 1) Clear DTC referring to "DTC Clearance". 2) Turn OFF ignition switch. 3) Turn ON ignition switch and check DTC. <i>Is DTC B1013 still indicated?</i>	Go to Step 3.	Intermittent trouble. Check for intermittent referring to "Intermittent and Poor Connection Inspection in Section 00".
3	SDM power supply and ground circuit check 1) Check SDM power supply and ground circuit referring to "SDM Power Supply and Ground Circuit Check". <i>Is SDM power supply and ground circuit in good condition?</i>	Substitute a known-good SDM and recheck.	Repair power supply and ground circuit.

NOTE

Upon completion of inspection and repair work, perform the following items.

- Reconnect all air bag system components and ensure all components are properly mounted.
- Clear DTCs referring to "DTC Clearance", if any.
- Repeat "Air Bag Diagnostic System Check" to confirm that the trouble has been corrected.

8B-25 Air Bag System:

DTC B1014: “AIR BAG” Warning Light Circuit

S7RW0C8204011

Wiring Diagram

Refer to “AIR BAG” Warning Light Comes ON Steady”.

DTC Detecting Condition and Trouble Area

DTC detecting condition	Trouble area
“AIR BAG” warning light circuit has been shorted to ground, shorted to power or opened for more than 4 sec.	“AIR BAG” warning light circuit - Combination meter - SDM

DTC Troubleshooting

Step	Action	Yes	No
1	Was “Air Bag Diagnostic System Check Flow” performed?	Go to Step 2.	Go to “Air Bag Diagnostic System Check Flow”.
2	Air bag warning light check <i>In “Air Bag Diagnostic System Check Flow”, was air bag warning light operation in good condition?</i>	Substitute a known good SDM and recheck.	Go to applicable symptom diagnosis check flow referring to “AIR BAG” Warning Light Comes ON Steady” or “AIR BAG” Warning Light Does Not Come ON”.

NOTE


Upon completion of inspection and repair work, perform the following items.

- Reconnect all air bag system components and ensure all components are properly mounted.
- Clear DTCs referring to “DTC Clearance”, if any.
- Repeat “Air Bag Diagnostic System Check” to confirm that the trouble has been corrected.

DTC B1016: Power Supply Voltage too High

S7RW0C8204012

Wiring Diagram




I6RW0C820007-01

1. Battery	5. Ignition switch	9. Ground for air bag system
2. Main fuse box	6. Junction block assembly	10. DC / DC converter
3. Fuse	7. “A/B” fuse	11. Back up capacitor
4. Generator	8. SDM	

DTC Detecting Condition and Trouble Area

DTC detecting condition	Trouble area
Power supply voltage is more than 21.4 V for, more than 16 sec.	Charging system SDM

DTC Troubleshooting

Step	Action	Yes	No
1	Was "Air Bag Diagnostic System Check Flow" performed?	Go to Step 2.	Go to "Air Bag Diagnostic System Check Flow".
2	SDM power supply voltage check 1) With ignition switch turned OFF, disconnect SDM connector "L04". 2) Check for proper connection to SDM at "L04-27" terminal. 3) If OK, run engine with more than 3000 rpm. 4) In this state, check voltage between "L04-27" terminal on SDM connector and body ground. Special tool (A): 09932-76010  <i>Is measured voltage 15 V or less?</i>	Go to Step 3.	Check charging system and repair as necessary referring to "Generator Test (Overcharged Battery Check) in Section 1J".
3	DTC B1016 recheck 1) With ignition switch turned OFF, reconnect SDM connector. <i>With ignition switch turned ON, is DTC B1016 still indicated?</i>	Substitute a known-good SDM and recheck.	Intermittent trouble. Check for intermittent trouble referring to "Inspection of Intermittent and Poor Connections" If OK, substitute a known-good SDM and recheck.

NOTE

Upon completion of inspection and repair work, perform the following items.

- Reconnect all air bag system components and ensure all components are properly mounted.
- Clear DTCs referring to "DTC Clearance", if any.
- Repeat "Air Bag Diagnostic System Check" to confirm that the trouble has been corrected.

DTC B1017: Power Supply Voltage too Low

S7RW0C8204013

Wiring Diagram

Refer to "DTC B1016: Power Supply Voltage too High".

DTC Detecting Condition and Trouble Area

DTC detecting condition	Trouble area
Power supply voltage is less than 7.2 V for more than 16 sec.	• Charging system • SDM

8B-27 Air Bag System:

DTC Troubleshooting

Step	Action	Yes	No
1	Was "Air Bag Diagnostic System Check Flow" performed?	Go to Step 2.	Go to "Air Bag Diagnostic System Check Flow".
2	SDM power supply and ground circuit check 1) Check SDM power supply and ground circuit referring to "SDM Power Supply and Ground Circuit Check". <i>Is SDM power supply and ground circuit in good condition?</i>	Go to Step 3.	Repair defective wire circuit.
3	DTC B1017 recheck 1) With ignition switch turned OFF, reconnect SDM connector. <i>With ignition switch ON, does DTC B1017 exist?</i>	Substitute a known-good SDM and recheck.	Intermittent trouble. Check for intermittent trouble referring to "Inspection of Intermittent and Poor Connections" If OK, substitute a known-good SDM and recheck.

NOTE

Upon completion of inspection and repair work, perform the following items.

- Reconnect all air bag system components and ensure all components are properly mounted.
- Clear DTCs referring to "DTC Clearance", if any.
- Repeat "Air Bag Diagnostic System Check" to confirm that the trouble has been corrected.

DTC B1021: Front Air Bag Deployment Record

S7RW0C8204014

DTC Detecting Condition and Trouble Area

DTC detecting condition	Trouble area
Deployment of front air bag has been recorded in SDM.	If this DTC has been recorded even though air bag has not been deployed • SDM • Driver and/or Passenger air bag module • Those initiator circuit.

NOTE

DTC B1201 can never be cleared once it has been set.

DTC Troubleshooting

Step	Action	Yes	No
1	Was "Air Bag Diagnostic System Check Flow" performed?	Go to Step 2.	Go to "Air Bag Diagnostic System Check Flow".
2	Front air bag deployment check 1) Turn OFF ignition switch. 2) Check that DTC B1021 has been set although air bag has not been deployed. <i>Has air bag deployed?</i>	Inspect and replace components according to "Repair and Inspection Required after Accident".	Go to Step 3.
3	Front impact sign check 1) Inspect front of vehicle and undercarriage for signs of impact. <i>Are there any signs of impact?</i>	Inspect and replace components according to "Repair and Inspection Required after Accident".	Replace SDM.

NOTE

Upon completion of inspection and repair work, perform the following items.

- Reconnect all air bag system components and ensure all components are properly mounted.
- Repeat “Air Bag Diagnostic System Check” to confirm that the trouble has been corrected.
- Clear DTCs of BCM referring to “DTC Clearance in Section 10B”.
- Clear DTC B1157 (air bag deployed) of BCM referring to “DTC Clearance in Section 10B”, if any.

DTC B1024 / B1025: Side Air-Bag Deployment Record

S7RW0C8204015

DTC B1024: Driver Side Air-Bag Deployment Record**DTC B1025: Passenger Side Air-Bag Deployment Record****DTC Detecting Condition and Trouble Area**

DTC detecting condition	Trouble area
DTC B1024: Deployment of driver side-air bag has been recorded in SDM. DTC B1025: Deployment of passenger side-air bag has been recorded in SDM.	If this DTC has been recorded even though side-air bag has not been deployed • SDM • Driver (passenger) side-air bag module • Its initiator circuit

DTC Troubleshooting

Step	Action	Yes	No
1	Was “Air Bag Diagnostic System Check Flow” performed?	Go to Step 2.	Go to “Air Bag Diagnostic System Check Flow”.
2	Side-air bag deployment check 1) Turn OFF ignition switch. 2) Check that DTC B1024 or B1025 has been set although side-air bag has not been deployed. <i>Has air bag deployed?</i>	Inspect and replace components according to “Repair and Inspection Required after Accident”.	Go to Step 3.
3	Side impact sign (driver / passenger) check 1) Inspect side of vehicle and undercarriage for signs of impact. <i>Are there any signs of impact?</i>	Inspect and replace components according to “Repair and Inspection Required after Accident”.	Replace SDM.

NOTE

Upon completion of inspection and repair work, perform the following items.

- Reconnect all air bag system components and ensure all components are properly mounted.
- Repeat “Air Bag Diagnostic System Check” to confirm that the trouble has been corrected.
- Clear DTC B1157 (air bag deployed) of BCM referring to “DTC Clearance in Section 10B”, if any.

DTC B1026: Seat Belt Pretensioner Activation Record

S7RW0C8204016

DTC Detecting Condition and Trouble Area

DTC detecting condition	Trouble area
Activation of seat belt pretensioner has been recorded in SDM.	If this DTC has been recorded even though pretensioner has not been activated • SDM • Driver and/or Passenger seat belt pretensioner • Those initiator circuit

DTC Troubleshooting

Step	Action	Yes	No
1	Was "Air Bag Diagnostic System Check Flow" performed?	Go to Step 2.	Go to "Air Bag Diagnostic System Check Flow".
2	Seat belt pretensioner activation check 1) Turn OFF ignition switch. 2) Check that DTC B1026 has been set although pretensioner has not been activated. <i>Has pretensioner activated?</i>	Inspect and replace components according to "Repair and Inspection Required after Accident".	Go to Step 3.
3	Front impact sign check 1) Inspect front of vehicle and undercarriage for signs of impact. <i>Are there any signs of impact?</i>	Inspect and replace components according to "Repair and Inspection Required after Accident".	Replace SDM.

NOTE

Upon completion of inspection and repair work, perform the following items.

- Reconnect all air bag system components and ensure all components are properly mounted.
- Repeat "Air Bag Diagnostic System Check" to confirm that the trouble has been corrected.
- Clear DTC B1157 (air bag deployed) of BCM referring to "DTC Clearance in Section 10B", if any.

DTC B1027: Number of Deployment Times Exceeded Limit

S7RW0C8204017

DTC Detecting Condition and Trouble Area

DTC detecting condition	Trouble area
Deployment of air bag and/or activation of seat belt pretensioner have been recorded in SDM 5 times or more.	If this DTC has been recorded even though air bag (front and side) and pretensioner have not been deployed more than 4 place. • SDM (internal fault or reused SDM) • Each of deployment and activation module • Those initiator circuit

NOTE

DTC B1027 can never be cleared once it has been set.

DTC Trouble shooting

Step	Action	Yes	No
1	Was "Air Bag Diagnostic System Check Flow" performed?	Go to Step 2.	Go to "Air Bag Diagnostic System Check Flow".
2	Air bag deployment check 1) Turn OFF ignition switch. 2) Check that DTC B1027 has been set although air bag (front and side) and pretensioner has not been deployed. <i>Have air bag and pretensioner deployed more than 4 place?</i>	Inspect and replace components according to "Repair and Inspection Required after Accident".	Go to Step 3.
3	Impact sign check 1) Inspect front, side of vehicle and undercarriage for signs of impact. <i>Are there any signs of impact?</i>	Inspect and replace components according to "Repair and Inspection Required after Accident".	Replace SDM.


NOTE

Upon completion of inspection and repair work, perform the following items.

- Reconnect all air bag system components and ensure all components are properly mounted.
- Repeat “Air Bag Diagnostic System Check” to confirm that the trouble has been corrected.
- Clear DTC B1157 (air bag deployed) of BCM referring to “DTC Clearance in Section 10B”, if any.

DTC B1031: Driver Air Bag Circuit High Resistance

S7RW0C8204018

Wiring Diagram



I6RW0C820008-01


[A]: Shorting bar	6. Ignition switch	12. Driver air bag (inflator) module
1. Battery	7. "A/B" fuse	13. DC / DC converter
2. Fuse	8. Junction block assembly	14. Back up capacitor
3. Main fuse box	9. Ground for air bag system	15. Safing power driver
4. "IGN" fuse	10. SDM	16. Mechanical longitudinal G sensor (switch)
5. Individual circuit fuse box No.1	11. Contact coil assembly	

DTC Detecting Condition and Trouble Area

DTC detecting condition	Trouble area
Driver air bag circuit is more than 5.2 Ω for more than 4 sec.	• Driver air bag circuit • Contact coil assembly • Driver air bag module • SDM

DTC Troubleshooting

Step	Action	Yes	No
1	Was "Air Bag Diagnostic System Check Flow" performed?	Go to Step 2.	Go to "Air Bag Diagnostic System Check Flow".
2	Drive air bag circuit check 1) With ignition switch turned OFF, disconnect contact coil connector located under the steering column. 2) Check for proper connection to contact coil at terminal in "G347" connector. 3) If OK, then connect special tools (A) and (B) to "G347" connector disconnected in Step 1). Special tool (A): 09932-75010 (B): 09932-78340  I7RW01821018-02 4) Check SDM for DTC. With ignition switch turned ON, is DTC B1031 indicated?	Go to Step 3.	Go to Step 5.
3	Driver air bag circuit check 1) Disconnect SDM connector "L04". 2) Check for proper connection to SDM connector at terminal "L04-3" and "L04-4". 3) If OK, release shorting bar in SDM connector inserting release tool (1) included in special tool (A). Special tool (A): 09932-76010 4) Measure resistance between "L04-3" and "G347-2" terminals. 5) Measure resistance between "L04-4" and "G347-1" terminals.  I7RW01821019-01 Is each measured resistance 1Ω or less?	Substitute a known-good SDM and recheck.	Go to Step 4.

Step	Action	Yes	No
4	Floor harness circuit check 1) Disconnect "L378" connector located near the driver side front pillar lower trim. 2) Check for proper connection to floor harness connector at terminal in "L378" connector. 3) If OK, release shorting bar in SDM connector inserting release tool (1) included in special tool (A). Special tool (A): 09932-76010 4) Measure resistance between "L04-3" and "L378-1" terminals. 5) Measure resistance between "L04-4" and "L378-2" terminals.  <i>Is each measured resistance 1Ω or less?</i>	Repair high resistance or open wire in "GRN/RED" or "GRN" circuit at instrument panel harness.	Repair high resistance or open wire in "GRN/RED" or "GRN" circuit at floor harness.
5	Contact coil circuit check 1) Check contact coil circuit referring to "Contact Coil Cable and Its Circuit Check". <i>Is contact coil circuit in good condition?</i>	Replace driver air bag (inflator) module referring to "Driver Air Bag (Inflator) Module Removal and Installation".	Replace contact coil assembly referring to "Contact Coil Cable Assembly Removal and Installation in Section 6B".

NOTE

Upon completion of inspection and repair work, perform the following items.

- Reconnect all air bag system components and ensure all components are properly mounted.
- Clear DTCs referring to "DTC Clearance", if any.
- Repeat "Air Bag Diagnostic System Check" to confirm that the trouble has been corrected.

DTC B1032: Driver Air Bag Circuit Low Resistance

S7RW0C8204019



Wiring Diagram


Refer to "DTC B1031: Driver Air Bag Circuit High Resistance".

DTC Detecting Condition and Trouble Area

DTC detecting condition	Trouble area
Driver air bag circuit is less than 1.1 Ω for more than 4 sec.	• Driver air bag circuit • Contact coil assembly • Driver air bag module • SDM

DTC Troubleshooting

Step	Action	Yes	No
1	Was "Air Bag Diagnostic System Check Flow" performed?	Go to Step 2.	Go to "Air Bag Diagnostic System Check Flow".
2	Driver air bag circuit check 1) With ignition switch turned OFF, disconnect contact coil connector located under the steering column. 2) Check for proper connection to contact coil at terminal in "G347" connector. 3) If OK, then connect special tools (A) and (B) to "G347" connector disconnected in Step 1). Special tool (A): 09932-75010 (B): 09932-78340  I7RW01821018-02 4) Check SDM for DTC. With ignition switch turned ON, is DTC B1032 indicated?	Go to Step 3.	Go to Step 5.
3	Driver air bag circuit check 1) Disconnect SDM connector "L04". 2) Check for proper connection to SDM connector at terminal "L04-3" and "L04-2". 3) If OK, release shorting bar in SDM connector inserting release tool (1) included in special tool (A). Special tool (A): 09932-76010 4) Measure resistance between "G347-1" and "G347-2" terminals.  I7RW01821019-01 Is measured resistance infinity?	Substitute a known-good SDM and recheck.	Go to Step 4.

Step	Action	Yes	No
4	Floor harness resistance check 1) Disconnect "L378" connector located near the driver side front pillar lower trim. 2) Check for proper connection to floor harness connector at terminal in "L378" connector. 3) If OK, release shorting bar in SDM connector inserting release tool (1) included in special tool (A). Special tool (A): 09932-76010 4) Measure resistance between "L378-1" and "L378-2" terminals.  Is measured resistance infinity?	Repair "GRN/RED" circuit for short to "GRN" circuit at instrument panel harness.	Repair "GRN/RED" circuit for short to "GRN" circuit at floor harness.
5	Contact coil circuit check 1) Check contact coil circuit referring to "Contact Coil Cable and Its Circuit Check". Is contact coil circuit in good condition?	Replace driver air bag (inflator) module referring to "Driver Air Bag (Inflator) Module Removal and Installation".	Replace contact coil assembly referring to "Contact Coil Cable Assembly Removal and Installation in Section 6B".

NOTE

Upon completion of inspection and repair work, perform the following items.

- Reconnect all air bag system components and ensure all components are properly mounted.
- Clear DTCs referring to "DTC Clearance", if any.
- Repeat "Air Bag Diagnostic System Check" to confirm that the trouble has been corrected.

DTC B1033: Driver Air Bag Circuit Shorted to Ground

S7RW0C8204020



Wiring Diagram


Refer to "DTC B1031: Driver Air Bag Circuit High Resistance".

DTC Detecting Condition and Trouble Area

DTC detecting condition	Trouble area
Driver air bag circuit has been shorted to ground for more than 4 sec.	• Driver air bag circuit • SDM

DTC Troubleshooting

Step	Action	Yes	No
1	Was "Air Bag Diagnostic System Check Flow" performed?	Go to Step 2.	Go to "Air Bag Diagnostic System Check Flow".
2	Driver air bag circuit check 1) With ignition switch turned OFF, disconnect contact coil connector "G347" located under the steering column. 2) Disconnect SDM connector "L04". 3) Check for proper connection to flow harness connector at terminal in "G347" connector. 4) Check for proper connection to SDM connector at terminal "L04-3" and "L04-4". 5) If OK, release shorting bar in SDM connector inserting release tool (1) included in special tool (A). Special tool (A): 09932-76010 6) Measure resistance between "G347-1" terminal and body ground, and between "G347-2" terminal and body ground.  I7RW01821020-01 Is each measured resistance infinity?	Go to Step 4.	Go to Step 3.
3	Floor harness circuit check 1) Disconnect "L378" connector located near the driver side front pillar lower trim. 2) If OK, release shorting bar in SDM connector inserting release tool (1) included in special tool (A). Special tool (A): 09932-76010 3) Measure resistance between "L378-1" terminal and body ground, and between "L378-2" terminal and body ground.  I7RW01821020-01 Is each measured resistance infinity?	Repair "GRN/RED" circuit or "GRN" circuit for short to ground at instrument panel harness.	Repair "GRN/RED" circuit or "GRN" circuit for short to ground at floor harness.

Step	Action	Yes	No
4	Contact coil circuit check 1) Connect contact coil connector “G347” located under the steering column. 2) Remove driver air bag (inflator) module from steering column referring to “Driver Air Bag (Inflator) Module Removal and Installation”. 3) Check for proper connection to driver air bag (inflator) module at terminal in connector (2). 4) If OK, release shorting bar in SDM connector inserting release tool (1) included in special tool (A). Special tool (A): 09932-76010 5) Measure resistance between each terminals of driver air bag (inflator) module connector (2) and body ground.  Is each measured resistance infinity?	Substitute a known-good SDM and recheck.	Replace contact coil assembly referring to “Contact Coil Cable Assembly Removal and Installation in Section 6B”.

NOTE

Upon completion of inspection and repair work, perform the following items.

- Reconnect all air bag system components and ensure all components are properly mounted.
- Clear DTCs referring to “DTC Clearance”, if any.
- Repeat “Air Bag Diagnostic System Check” to confirm that the trouble has been corrected.

DTC B1034: Driver Air Bag Circuit Shorted to Power Supply

S7RW0C8204021



Wiring Diagram



Refer to “DTC B1031: Driver Air Bag Circuit High Resistance”.

DTC Detecting Condition and Trouble Area

DTC detecting condition	Trouble area
Driver air bag circuit has been shorted to power supply for more than 4 sec.	• Driver air bag circuit • SDM

DTC Troubleshooting

Step	Action	Yes	No
1	Was "Air Bag Diagnostic System Check Flow" performed?	Go to Step 2.	Go to "Air Bag Diagnostic System Check Flow".
2	Driver air bag circuit check 1) With ignition switch turned OFF, disconnect contact coil connector "G347" located under the steering column. 2) Disconnect SDM connector "L04". 3) Check for proper connection to contact coil connector at terminal in "G347" connector. 4) Check for proper connection to SDM connector at terminal "L04-3" and "L04-4". 5) If OK, release shorting bar in SDM connector inserting release tool (1) included in special tool (A). Special tool (A): 09932-76010 6) With ignition switch turned ON, measure voltage between "G347-1" terminal and body ground, and between "G347-2" terminal and body ground.  17RW01821022-01 Is each measured voltage 0 V?	Go to Step 4.	Go to Step 3.
3	Floor harness circuit check 1) Disconnect "L378" connector located near the driver side front pillar lower trim. 2) If OK, release shorting bar in SDM connector inserting release tool (1) included in special tool (A). Special tool (A): 09932-76010 3) With ignition switch turned ON, measure voltage between "L378-1" terminal and body ground, and between "L378-2" terminal and body ground.  17RW01821022-01 Is each measured voltage 0 V?	Repair "GRN/RED" circuit or "GRN" circuit for short to power supply circuit at instrument panel harness.	Repair "GRN/RED" circuit or "GRN" circuit for short to power supply circuit at floor harness.

Step	Action	Yes	No
4	Contact coil circuit check 1) Connect contact coil connector "G347" located under the steering column. 2) Remove driver air bag (inflator) module from steering column referring to "Driver Air Bag (Inflator) Module Removal and Installation". 3) Check for proper connection to driver air bag (inflator) module at terminal in connector (2). 4) If OK, release shorting bar in SDM connector inserting release tool (1) included in special tool (A). Special tool (A): 09932-76010 5) With ignition switch turned ON, measure voltage between each terminals of driver air bag (inflator) module connector (2) and body ground.    I7RW01821023-01 <i>Is each measured voltage 0 V?</i>	Substitute a known-good SDM and recheck.	Replace contact coil assembly referring to "Contact Coil Cable Assembly Removal and Installation in Section 6B".

NOTE


Upon completion of inspection and repair work, perform the following items.

- Reconnect all air bag system components and ensure all components are properly mounted.
- Clear DTCs referring to "DTC Clearance", if any.
- Repeat "Air Bag Diagnostic System Check" to confirm that the trouble has been corrected.

DTC B1041: Passenger Air Bag Circuit High Resistance

S7RW0C8204022


Wiring Diagram





DTC Detecting Condition and Trouble Area

DTC detecting condition	Trouble area
Passenger air bag circuit is more than 4.0 Ω for more than 4 sec.	- Passenger air bag circuit - Passenger air bag module - SDM

DTC Troubleshooting

Step	Action	Yes	No
1	Was "Air Bag Diagnostic System Check Flow" performed?	Go to Step 2.	Go to "Air Bag Diagnostic System Check Flow".
2	Passenger air bag check 1) Remove passenger air bag (inflator) module referring to "Passenger Air Bag (Inflator) Module Removal and Installation". 2) Check for proper connection to passenger air bag (inflator) module at terminals in "G259" connector. 3) If OK, then connect special tools (A), (B) and (C) to "G259" connector. Special tool (A): 09932-76010 (B): 09932-75010 (C): 09932-78310  I7RW01821025-02 4) Check SDM for DTC. With ignition switch turned ON, is DTC B1041 indicated?	Go to Step 3.	Replace passenger air bag (inflator) module referring to "Passenger Air Bag (Inflator) Module Removal and Installation".

8B-41 Air Bag System:

Step	Action	Yes	No
3	Passenger air bag circuit check 1) With ignition switch turned OFF, disconnect SDM connector "L04". 2) Check for proper connection to SDM connector at terminal "L04-5" and "L04-6". 3) If OK, release shorting bar in SDM connector by inserting release tool (1) included in special tool (A). Special tool (A): 09932-76010 4) Measure resistance between "L04-5" and "G259-1" terminals. 5) Measure resistance between "L04-6" and "G259-2" terminals.  I7RW01821026-01 <i>Is each measured resistance 1Ω or less?</i>	Substitute a known-good SDM and recheck.	Go to Step 4.
4	Floor harness circuit check 1) Disconnect "L377" connector located near the passenger side front pillar lower trim. 2) Check for proper connection to floor harness connector at terminal in "L377" connector. 3) If OK, release shorting bar in SDM connector by inserting release tool (1) included in special tool (A). Special tool (A): 09932-76010 4) Measure resistance between "L04-5" and "L377-2" terminals. 5) Measure resistance between "L04-6" and "L377-1" terminals.  I7RW01821026-01 <i>Is each measured resistance 1 Ω or less?</i>	Repair high resistance or open wire in "BLU/RED" or "YEL/RED" circuit at instrument panel harness.	Repair high resistance or open wire in "BLU/RED" or "YEL/RED" circuit at floor harness.

NOTE

Upon completion of inspection and repair work, perform the following items.

- Reconnect all air bag system components and ensure all components are properly mounted.
- Clear DTCs referring to "DTC Clearance", if any.
- Repeat "Air Bag Diagnostic System Check" to confirm that the trouble has been corrected.


DTC B1042: Passenger Air Bag Circuit Low Resistance**Wiring Diagram**

Refer to "DTC B1041: Passenger Air Bag Circuit High Resistance".



DTC Detecting Condition and Trouble Area

DTC detecting condition	Trouble area
Passenger air bag circuit is less than 0.9 Ω for more than 4 sec.	• Passenger air bag circuit • Passenger air bag module • SDM

DTC Troubleshooting

Step	Action	Yes	No
1	Was "Air Bag Diagnostic System Check Flow" performed?	Go to Step 2.	Go to "Air Bag Diagnostic System Check Flow".
2	Passenger air bag circuit check 1) Remove passenger air bag (inflator) module referring to "Passenger Air Bag (Inflator) Module Removal and Installation". 2) Check for proper connection to passenger air bag (inflator) module at terminals in "G259" connector. 3) If OK, then connect special tools (A), (B) and (C) to "G259" connector. Special tool (A): 09932-76010 (B): 09932-75010 (C): 09932-78310  4) Check SDM for DTC. With ignition switch ON, is DTC B1042 indicated?	Go to Step 3.	Replace passenger air bag (inflator) module referring to "Passenger Air Bag (Inflator) Module Removal and Installation".

8B-43 Air Bag System:

Step	Action	Yes	No
3	Passenger air bag circuit check 1) With ignition switch turned OFF, disconnect SDM connector "L04". 2) Check for proper connection to SDM connector at terminal "L04-5" and "L04-6". 3) If OK, release shorting bar in SDM connector inserting release tool (1) included in special tool (A). Special tool (A): 09932-76010 4) Measure resistance between "G259-1" and "G259-2" terminals.  I7RW01821026-01 <i>Is measured resistance infinity?</i>	Substitute a known-good SDM and recheck.	Go to Step 4.
4	Floor harness circuit check 1) Disconnect "L377" connector located near the passenger side front pillar lower trim. 2) Check for proper connection to floor harness connector at terminal in "L377" connector. 3) If OK, release shorting bar in SDM connector inserting release tool (1) included in special tool (A). Special tool (A): 09932-76010 4) Measure resistance between "L377-1" and "L377-2" terminals.  I7RW01821026-01 <i>Is measured resistance infinity?</i>	Repair "BLU/RED" circuit for short to "YEL/RED" circuit at instrument panel harness.	Repair "BLU/RED" circuit for short to "YEL/RED" circuit at floor harness.

NOTE

Upon completion of inspection and repair work, perform the following items.

- Reconnect all air bag system components and ensure all components are properly mounted.
- Clear DTCs referring to "DTC Clearance", if any.
- Repeat "Air Bag Diagnostic System Check" to confirm that the trouble has been corrected.


DTC B1043: Passenger Air Bag Circuit Shorted to Ground**Wiring Diagram**

Refer to "DTC B1041: Passenger Air Bag Circuit High Resistance".


DTC Detecting Condition and Trouble Area

DTC detecting condition	Trouble area
Passenger air bag circuit has been shorted to ground for more than 4 sec.	- Passenger air bag circuit - SDM

DTC Troubleshooting

Step	Action	Yes	No
1	Was "Air Bag Diagnostic System Check Flow" performed?	Go to Step 2.	Go to "Air Bag Diagnostic System Check Flow".
2	Passenger air bag circuit check - Remove passenger air bag (inflator) module from steering column referring to "Passenger Air Bag (Inflator) Module Removal and Installation". - Disconnect SDM connector "L04". - Check for proper connection to SDM connector at terminal "L04-5" and "L04-6". - Check for proper connection to passenger air bag (inflator) module at terminals in "G259" connector. - If OK, release shorting bar in SDM connector inserting release tool (1) included in special tool (A). Special tool (A): 09932-76010 - Measure resistance between "L04-5" terminal and body ground, and between "L04-6" terminal and body ground.  I7RW01822046-01 Is each measured resistance infinity?	Substitute a known-good SDM and recheck.	Go to Step 3.

8B-45 Air Bag System:

Step	Action	Yes	No
3	Floor harness circuit check 1) Disconnect "L377" connector located near the passenger side front pillar lower trim. 2) Check for proper connection to floor harness connector at terminal in "L377" connector. 3) If OK, release shorting bar in SDM connector inserting release tool (1) included in special tool (A). Special tool (A): 09932-76010 4) Measure resistance between "L377-1" terminal and body ground, and between "L377-2" terminal and body ground.  I7RW01822046-01 <i>Is each measured resistance infinity?</i>	Repair "BLU/RED" circuit or "YEL/RED" circuit for short to ground at instrument panel harness.	Repair "BLU/RED" circuit or "YEL/RED" circuit for short to ground at floor harness.

NOTE

Upon completion of inspection and repair work, perform the following items.

- Reconnect all air bag system components and ensure all components are properly mounted.
- Clear DTCs referring to "DTC Clearance", if any.
- Repeat "Air Bag Diagnostic System Check" to confirm that the trouble has been corrected.

DTC B1044: Passenger Air Bag Circuit Shorted to Power Supply

S7RW0C8204025

Wiring Diagram



Refer to "DTC B1041: Passenger Air Bag Circuit High Resistance".

DTC Detecting Condition and Trouble Area

DTC detecting condition	Trouble area
Passenger air bag circuit has been shorted to power supply for more than 4 sec.	• Passenger air bag circuit • SDM

DTC Troubleshooting

Step	Action	Yes	No
1	Was "Air Bag Diagnostic System Check Flow" performed?	Go to Step 2.	Go to "Air Bag Diagnostic System Check Flow".

Step	Action	Yes	No
2	Passenger air bag circuit check 1) Remove passenger air bag (inflator) module from steering column referring to “Passenger Air Bag (Inflator) Module Removal and Installation”. 2) Disconnect SDM connector “L04”. 3) Check for proper connection to SDM connector at terminal “L04-5” and “L04-6”. 4) Check for proper connection to passenger air bag (inflator) module at terminals in “G259” connector. 5) If OK, release shorting bar in SDM connector inserting release tool (1) included in special tool (A). Special tool (A): 09932-76010 6) With ignition switch turned ON, measure voltage between “L04-5” terminal and body ground, and between “L04-6” terminal and body ground.  I7RW01822047-01 <i>Is each measured voltage 0 V?</i>	Substitute a known-good SDM and recheck.	Go to Step 3.
3	Floor harness circuit check 1) Disconnect “L377” connector located near the passenger side front pillar lower trim. 2) Check for proper connection to floor harness connector at terminal in “L377” connector. 3) If OK, release shorting bar in SDM connector inserting release tool (1) included in special tool (A). Special tool (A): 09932-76010 4) With ignition switch turned ON, measure voltage between “L377-1” terminal and body ground, and between “L377-2” terminal and body ground.  I7RW01822047-01 <i>Is each measured voltage 0 V?</i>	Repair “BLU/RED” circuit or “YEL/RED” circuit for short to power supply circuit at instrument panel harness.	Repair “BLU/RED” circuit or “YEL/RED” circuit for short to power supply circuit at floor harness.

NOTE

Upon completion of inspection and repair work, perform the following items.

- Reconnect all air bag system components and ensure all components are properly mounted.
- Clear DTCs referring to “DTC Clearance”, if any.
- Repeat “Air Bag Diagnostic System Check” to confirm that the trouble has been corrected.


DTC B1051 / B1055: Seat Belt Pretensioner Circuit High Resistance

S7RW0C8204026

DTC B1051: Driver Seat Belt Pretensioner Circuit High Resistance

DTC B1055: Passenger Seat Belt Pretensioner Circuit High Resistance

Wiring Diagram




I6RW0C820010-01

[A]: Shorting bar	6. Ignition switch	12. Passenger seat belt pretensioner
1. Battery	7. "A/B" fuse	13. DC / DC converter
2. Fuse	8. Junction block assembly	14. Back up capacitor
3. Main fuse box	9. Ground for air bag system	15. Safing power driver
4. "IGN" fuse	10. SDM	16. Mechanical longitudinal G sensor (switch)
5. Individual circuit fuse box No.1	11. Driver seat belt pretensioner	


DTC Detecting Condition and Trouble Area

DTC detecting condition	Trouble area
DTC B1051: Driver seat belt pretensioner circuit is more than 4.0 Ω for more than 4 sec. DTC B1055: Passenger seat belt pretensioner circuit is more than 4.0 Ω for more than 4 sec.	- Driver / passenger seat belt pretensioner circuit - Driver / passenger seat belt pretensioner - SDM

DTC Troubleshooting

Step	Action	Yes	No
1	Was "Air Bag Diagnostic System Check Flow" performed?	Go to Step 2.	Go to "Air Bag Diagnostic System Check Flow".
2	Seat belt pretensioner circuit check 1) With ignition switch turned OFF, remove center pillar lower trim of applicable side and disconnect seat belt pretensioner connector "L283" or "L285". 2) Check for proper connection to applicable seat belt pretensioner at terminals in "L283" or "L285" connector. 3) If OK, then connect special tools (A), (B) and (C) to "L283" or "L285" connector disconnected in Step 1). Special tool (A): 09932-76010 (B): 09932-75010 (C): 09932-78310  I7RW01822057-01 4) Check SDM for DTC. With ignition switch turned ON, is DTC B1051 or B1055 still indicated?	Go to Step 3.	Replace defective seat belt pretensioner referring to "Front Seat Belt Removal and Installation in Section 8A".

8B-49 Air Bag System:

Step	Action	Yes	No
3	Seat belt pretensioner circuit resistance check 1) Disconnect special tools from applicable seat belt pretensioner connector. 2) Disconnect SDM connector "L04". 3) Check for proper connection to SDM at terminals "L04-7" and "L04-8" (for DTC B1051) or terminals "L04-9" and "L04-10" (for DTC B1055). 4) If OK, release shorting bar in SDM connector inserting release tool (1) included in special tool (A). 5) Measure resistance between "L04-7" and "L283-2", and between "L04-8" and "L283-1" (for DTC B1051). 6) Measure resistance between "L04-9" and "L285-1", and between "L04-10" and "L285-2" (for DTC B1055).  <i>Is each measured resistance 1Ω or less?</i>	Substitute a known-good SDM and recheck.	Repair open or high resistance wire in defective circuit.

NOTE

Upon completion of inspection and repair work, perform the following items.

- Reconnect all air bag system components and ensure all components are properly mounted.
- Clear DTCs referring to "DTC Clearance", if any.
- Repeat "Air Bag Diagnostic System Check" to confirm that the trouble has been corrected.


DTC B1052 / B1056: Seat Belt Pretensioner Circuit Low Resistance**DTC B1052: Driver Seat Belt Pretensioner Circuit Low Resistance****DTC B1056: Passenger Seat Belt Pretensioner Circuit Low Resistance****Wiring Diagram**

Refer to "DTC B1051 / B1055: Seat Belt Pretensioner Circuit High Resistance".

DTC Detecting Condition and Trouble Area


DTC detecting condition	Trouble area
DTC B1052: Driver seat belt pretensioner circuit is less than 0.9 Ω for more than 4 sec. DTC B1056: Passenger seat belt pretensioner circuit is less than 0.9 Ω for more than 4 sec.	• Driver / passenger seat belt pretensioner circuit • Driver / passenger seat belt pretensioner • SDM

DTC Troubleshooting

Step	Action	Yes	No
1	Was "Air Bag Diagnostic System Check Flow" performed?	Go to Step 2.	Go to "Air Bag Diagnostic System Check Flow".
2	Seat belt pretensioner circuit check 1) With ignition switch turned OFF, remove center pillar lower trim of applicable side and disconnect applicable seat belt pretensioner connector "L283" or "L285". 2) Check for proper connection to applicable seat belt pretensioner at terminals in "L283" or "L285" connector. 3) If OK, then connect special tools (A), (B) and (C) to "L283" or "L285" connector disconnected in Step 1). Special tool (A): 09932-76010 (B): 09932-75010 (C): 09932-78310  4) Check SDM for DTC. With ignition switch turned ON, is DTC B1052 or B1056 still indicated?	Go to Step 3.	Replace defective seat belt pretensioner referring to "Front Seat Belt Removal and Installation in Section 8A".

I7RW01822057-01

8B-51 Air Bag System:

Step	Action	Yes	No
3	Seat belt pretensioner circuit resistance check 1) Disconnect special tools from applicable seat belt pretensioner connector. 2) Disconnect SDM connector "L04". 3) Check for proper connection to SDM at terminals "L04-7" and "L04-8" (for DTC B1052) or terminals "L04-9" and "L04-10" (for DTC B1056). 4) If OK, release shorting bar in SDM connector inserting release tool (1) included in special tool (A). 5) Measure resistance between "L04-7" and "L04-8" (for DTC B1052) or between "L04-9" and "L04-10" (for DTC B1056).  I7RW01822059-01 <i>Is each measured resistance infinity?</i>	Substitute a known-good SDM and recheck.	Repair short wire in defective circuit.

NOTE

Upon completion of inspection and repair work, perform the following items.

- Reconnect all air bag system components and ensure all components are properly mounted.
- Clear DTCs referring to "DTC Clearance", if any.
- Repeat "Air Bag Diagnostic System Check" to confirm that the trouble has been corrected.

DTC B1053 / B1057: Seat Belt Pretensioner Shorted to Ground

S7RW0C8204028

DTC B1053: Driver Seat Belt Pretensioner Shorted to Ground

DTC B1057: Passenger Seat Belt Pretensioner Shorted to Ground


Wiring Diagram

Refer to "DTC B1051 / B1055: Seat Belt Pretensioner Circuit High Resistance".

DTC Detecting Condition and Trouble Area

DTC detecting condition	Trouble area
DTC B1053: Driver seat belt pretensioner circuit has been shorted to ground for more than 4 sec. DTC B1057: Passenger seat belt pretensioner circuit has been shorted to ground for more than 4 sec.	• Driver / passenger seat belt pretensioner circuit • SDM

DTC Troubleshooting

Step	Action	Yes	No
1	Was "Air Bag Diagnostic System Check Flow" performed?	Go to Step 2.	Go to "Air Bag Diagnostic System Check Flow".
2	Seat belt pretensioner circuit check 1) With ignition switch turned OFF, remove center pillar lower trim of applicable side and disconnect applicable seat belt pretensioner connector "L283" or "L285". 2) Disconnect SDM connector "L04". 3) Check for proper connection to applicable seat belt pretensioner at terminals in "L283" or "L285". 4) Check for proper connection to SDM at terminals "L04-7" and "L04-8" (for DTC B1053) or terminals "L04-9" and "L04-10" (for DTC B1057). 5) If OK, release shorting bar in SDM connector inserting release tool (1) included in special tool (A). 6) Measure resistance between "L04-7" and body ground, and between "L04-8" and body ground (for DTC B1053). 7) Measure resistance between "L04-9" and body ground, and between "L04-10" and body ground (for DTC B1057). Special tool (A): 09932-76010  17RW01822060-01 Is each measured resistance infinity?	Substitute a known-good SDM and recheck.	Repair short to ground in defective circuit.

NOTE

Upon completion of inspection and repair work, perform the following items.

- Reconnect all air bag system components and ensure all components are properly mounted.
- Clear DTCs referring to "DTC Clearance", if any.
- Repeat "Air Bag Diagnostic System Check" to confirm that the trouble has been corrected.


DTC B1054 / B1058: Seat Belt Pretensioner Circuit Shorted to Power Supply**DTC B1054: Driver Seat Belt Pretensioner Circuit Shorted to Power Supply****DTC B1058: Passenger Seat Belt Pretensioner Circuit Shorted to Power Supply****Wiring Diagram**

Refer to "DTC B1051 / B1055: Seat Belt Pretensioner Circuit High Resistance".

DTC Detecting Condition and Trouble Area

DTC detecting condition	Trouble area
DTC B1054: Driver seat belt pretensioner circuit has been shorted to power supply for more than 4 sec. DTC B1058: Passenger seat belt pretensioner circuit has been shorted to power supply for more than 4 sec.	• Driver / passenger seat belt pretensioner circuit • SDM


DTC Troubleshooting

Step	Action	Yes	No
1	Was "Air Bag Diagnostic System Check Flow" performed?	Go to Step 2.	Go to "Air Bag Diagnostic System Check Flow".
2	Seat belt pretensioner circuit check 1) With ignition switch turned OFF, remove center pillar lower trim of applicable side and disconnect applicable seat belt pretensioner connector "L283" or "L285". 2) Disconnect SDM connector "L04". 3) Check for proper connection to applicable seat belt pretensioner at terminals in "L283" or "L285". 4) Check for proper connection to SDM at terminals "L04-7" and "L04-8" (for DTC B1054) or terminals "L04-9" and "L04-10" (for DTC B1058). 5) If OK, release shorting bar in SDM connector inserting release tool (1) included in special tool (A). 6) With ignition switch turned ON, measure voltage between "L04-7" and body ground, and between "L04-8" and body ground (for DTC B1054). 7) Measure voltage between "L04-9" and body ground and between "L04-10" and body ground (for DTC B1058). Special tool (A): 09932-76010  <i>Is each measured voltage 0 V?</i>	Substitute a known-good SDM and recheck.	Repair short to power supply in defective circuit.

NOTE

Upon completion of inspection and repair work, perform the following items.

- Reconnect all air bag system components and ensure all components are properly mounted.
- Clear DTCs referring to "DTC Clearance", if any.
- Repeat "Air Bag Diagnostic System Check" to confirm that the trouble has been corrected.

DTC B1061 / B1065: Side-Air Bag Circuit High Resistance**DTC B1061: Driver Side-Air Bag Circuit High Resistance****DTC B1065: Passenger Side-Air Bag Circuit High Resistance****Wiring Diagram**


I6RW0C820011-01


[A]: Shorting bar	5. Individual circuit fuse box No.1	10. SDM
1. Battery	6. Ignition switch	11. Driver side-air bag (inflator) model
2. Fuse	7. "A/B" fuse	12. Passenger side-air bag (inflator) module
3. Main fuse box	8. Junction block assembly	13. DC / DC converter
4. "IGN" fuse	9. Ground for air bag system	14. Back up capacitor


DTC Detecting Condition and Trouble Area

DTC detecting condition	Trouble area
DTC B1061: Driver side-air bag circuit is more than 3.7 Ω for more than 4 sec. DTC B1065: Passenger side-air bag circuit is more than 3.7 Ω for more than 4 sec.	• Driver / passenger side-air bag circuit • Driver / passenger side-air bag module • SDM

DTC Troubleshooting

Step	Action	Yes	No
1	Was "Air Bag Diagnostic System Check Flow" performed?	Go to Step 2.	Go to "Air Bag Diagnostic System Check Flow".
2	Side-air bag circuit check 1) Remove applicable driver / passenger side-air bag (inflator) module from seat back referring to "Side-Air Bag (Inflator) Module Removal and Installation". 2) Check for proper connection to applicable side-air bag (inflator) module at terminal in connector "Q104" or "Q105". 3) If OK, then connect special tools (A), (B) and (C) to applicable side-air bag (inflator) connector "Q104" or "Q105". Special tool (A): 09932-76010 (B): 09932-75010 (C): 09932-78310  STEERING WHEEL Q104, Q105 (A) (B) (C) I7RW01822077-01 4) Check SDM for DTC. With ignition switch turned ON, is DTC B1061 or B1065 still indicated?	Go to Step 3.	Replace side-air bag (inflator) module referring to "Side-Air Bag (Inflator) Module Removal and Installation".

Step	Action	Yes	No
3	Side-air bag circuit check 1) With ignition switch turned OFF, disconnect special tools from applicable side-air bag (inflator) connector "Q104" or "Q105". 2) Disconnect SDM connector "L04". 3) Check for proper connection to SDM connector at terminal "L04-11" and "L04-12" (for DTC B1061) or terminal "L04-13" and "L04-14" (for DTC B1065). 4) If OK, release shorting bar in SDM connector inserting release tool (1) included in special tool (A). Special tool (A): 09932-76010 5) Measure resistance between "L04-12" and "Q105-1" terminals, between "L04-11" and "Q105-2" terminals (for DTC B1061). 6) Measure resistance between "L04-13" and "Q104-1" terminals, between "L04-14" and "Q104-2" terminals (for DTC B1065).  I7RW01822078-01 <i>Is each measured resistance 1Ω or less?</i>	Substitute a known-good SDM and recheck.	Go to Step 4.

Step	Action	Yes	No
4	Floor harness circuit check 1) Disconnect applicable "L384" or "L385" connector under front cushion. 2) Check for proper connection to floor harness connector at terminal "L385-1" and "L385-2" (for DTC B1061) or terminal "L384-1" and "L384-2" (for DTC B1065). 3) If OK, release shorting bar in SDM connector inserting release tool (1) included in special tool (A). Special tool (A): 09932-76010 4) Measure resistance between "L04-12" and "L385-1" terminals, between "L04-11" and "L385-2" terminals (for DTC B1061). 5) Measure resistance between "L04-13" and "L384-1" terminals, between "L04-14" and "L384-2" terminals (for DTC B1065).  I7RW01822079-01 <i>Is each measured resistance 1Ω or less?</i>	DTC B1061: Repair high resistance or open wire in "BLU" or "BLK" circuit at driver side-air bag harness. DTC B1065: Repair high resistance or open wire in "BLU" or "BLK" circuit at passenger side-air bag harness.	DTC B1061: Repair high resistance or open wire in "GRY/RED" or "GRY" circuit at floor harness. DTC B1065: Repair high resistance or open wire in "BRN/WHT" or "BRN" circuit at floor harness.

NOTE

Upon completion of inspection and repair work, perform the following items.

- Reconnect all air bag system components, ensure all components are properly mounted.
- Clear DTCs referring to "DTC Clearance", if any.
- Repeat "Air Bag Diagnostic System Check" to confirm that the trouble has been corrected.


DTC B1062 / B1066: Side-Air Bag Circuit Low Resistance**DTC B1062: Driver Side-Air Bag Circuit Low Resistance****DTC B1066: Passenger Side-Air Bag Circuit Low Resistance****Wiring Diagram**




Refer to "DTC B1061 / B1065: Side-Air Bag Circuit High Resistance".

DTC Detecting Condition and Trouble Area

DTC detecting condition	Trouble area
DTC B1062: Driver side-air bag circuit is less than 1.0 Ω for more than 4 sec. DTC B1066: Passenger side-air bag circuit is less than 1.0 Ω for more than 4 sec.	• Driver / passenger side-air bag circuit • Driver / passenger side-air bag module • SDM

DTC Troubleshooting

Step	Action	Yes	No
1	Was "Air Bag Diagnostic System Check Flow" performed?	Go to Step 2.	Go to "Air Bag Diagnostic System Check Flow".
2	Side-air bag circuit check 1) Remove applicable driver / passenger side-air bag (inflator) module from seat back referring to "Side-Air Bag (Inflator) Module Removal and Installation". 2) Check for proper connection to applicable side-air bag (inflator) module at terminal in connector "Q104" or "Q105". 3) If OK, then connect special tools (A), (B) and (C) to applicable side-air bag (inflator) connector "Q104" or "Q105". Special tool (A): 09932-76010 (B): 09932-75010 (C): 09932-78310  STEERING WHEEL I7RW01822077-01 4) Check SDM for DTC. With ignition switch turned ON, is DTC B1062 or B1066 still indicated?	Go to Step 3.	Replace side-air bag (inflator) module referring to "Side-Air Bag (Inflator) Module Removal and Installation".

Step	Action	Yes	No
3	Side-air bag circuit check 1) With ignition switch turned OFF, disconnect special tools from applicable side-air bag (inflator) connector "Q104" or "Q105". 2) Disconnect SDM connector "L04". 3) Check for proper connection to SDM connector at terminal "L04-11" and "L04-12" (for DTC B1062) or terminal "L04-13" and "L04-14" (for DTC B1066). 4) If OK, release shorting bar in SDM connector inserting release tool (1) included in special tool (A). Special tool (A): 09932-76010 5) Measure resistance between "L04-11" and "L04-12" terminals (for DTC B1062) or between "L04-13" and "L04-14" terminals (for DTC B1066).  I7RW01822080-01 <i>Is each measured resistance infinity?</i>	Substitute a known-good SDM and recheck.	Go to Step 4.
4	Floor harness circuit check 1) Disconnect applicable "L384" or "L385" connector under front cushion. 2) Check for proper connection to applicable floor harness connector at terminal in connector "L384" or "L385". 3) If OK, release shorting bar in SDM connector inserting release tool (1) included in special tool (A). Special tool (A): 09932-76010 4) Measure resistance between "L04-11" and "L04-12" terminals (for DTC B1062) or between "L04-13" and "L04-14" terminals (for DTC B1066).   I7RW01822081-01 <i>Is each measured resistance infinity?</i>	DTC B1062: Repair "BLU" circuit for short to "BLK" circuit at driver side-air bag harness. DTC B1066: Repair "BLU" circuit for short to "BLK" circuit at passenger side-air bag harness.	DTC B1062: Repair "GRY/RED" circuit for short to "GRY" circuit at floor harness. DTC B1066: Repair "BRN/WHT" circuit for short to "BRN" circuit at floor harness.

NOTE

Upon completion of inspection and repair work, perform the following items.

- Reconnect all air bag system components, ensure all components are properly mounted.
- Clear DTCs referring to “DTC Clearance”, if any.
- Repeat “Air Bag Diagnostic System Check” to confirm that the trouble has been corrected.

DTC B1063 / B1067: Side-Air Bag Circuit Shorted to Ground

S7RW0C8204032


DTC B1063: Driver Side-Air Bag Circuit Shorted to Ground**DTC B1067: Passenger Side-Air Bag Circuit Shorted to Ground****Wiring Diagram**


Refer to “DTC B1061 / B1065: Side-Air Bag Circuit High Resistance”.

DTC Detecting Condition and Trouble Area

DTC detecting condition	Trouble area
DTC B1063: Driver side-air bag circuit has been shorted to ground for more than 4 sec. DTC B1067: Passenger side-air bag circuit has been shorted to ground for more than 4 sec.	• Driver / passenger side-air bag circuit • SDM

DTC Troubleshooting

Step	Action	Yes	No
1	Was "Air Bag Diagnostic System Check Flow" performed?	Go to Step 2.	Go to "Air Bag Diagnostic System Check Flow".
2	Side-air bag circuit check 1) Remove applicable driver / passenger side-air bag (inflator) module from seat back referring to "Side-Air Bag (Inflator) Module Removal and Installation". 2) Check for proper connection to applicable side-air bag (inflator) module at terminal in connector "Q104" or "Q105". 3) Disconnect SDM connector "L04". 4) Check for proper connection to SDM connector at terminal "L04-11" and "L04-12" (for DTC B1063) or terminal "L04-13" and "L04-14" (for DTC B1067). 5) If OK, release shorting bar in SDM connector inserting release tool (1) included in special tool (A). Special tool (A): 09932-76010 6) Measure resistance between "L04-11" terminal and body ground, and between "L04-12" terminal and body ground (for DTC B1063). 7) Measure resistance between "L04-13" terminal and body ground, and between "L04-14" terminal and body ground (for DTC B1067).  17RW01822082-01 Is each measured resistance infinity?	Substitute a known-good SDM and recheck.	Go to Step 3.

Step	Action	Yes	No
3	Floor harness circuit check 1) Disconnect applicable "L384" or "L385" connector under front cushion. 2) Check for proper connection to applicable floor harness connector at terminal in connector "L384" or "L385". 3) If OK, release shorting bar in SDM connector inserting release tool (1) included in special tool (A). Special tool (A): 09932-76010 4) Measure resistance between "L04-11" terminal and body ground, and between "L04-12" terminal and body ground (for DTC B1063). 5) Measure resistance between "L04-13" terminal and body ground, and between "L04-14" terminal and body ground (for DTC B1067).  I7RW01822083-01 <i>Is each measured resistance infinity?</i>	DTC B1063: Repair "BLU" circuit or "BLK" circuit for short to ground at driver side-air bag harness. DTC B1067: Repair "BLU" circuit or "BLK" circuit for short to ground at passenger side-air bag harness.	DTC B1063: Repair "GRY/RED" circuit or "GRY" circuit for short to ground at floor harness. DTC B1067: Repair "BRN/WHT" circuit or "BRN" circuit for short to ground at floor harness.

NOTE

Upon completion of inspection and repair work, perform the following items.

- Reconnect all air bag system components, ensure all components are properly mounted.
- Clear DTCs referring to "DTC Clearance", if any.
- Repeat "Air Bag Diagnostic System Check" to confirm that the trouble has been corrected.


DTC B1064 / B1068: Side-Air Bag Circuit Shorted to Power Supply**DTC B1064: Driver Side-Air Bag Circuit Shorted to Power Supply****DTC B1068: Passenger Side-Air Bag Circuit Shorted to Power Supply****Wiring Diagram**

Refer to "DTC B1061 / B1065: Side-Air Bag Circuit High Resistance".


DTC Detecting Condition and Trouble Area

DTC detecting condition	Trouble area
DTC B1064: Driver side-air bag circuit has been shorted to power supply for more than 4 sec. DTC B1068: Passenger side-air bag circuit has been shorted to power supply for more than 4 sec.	• Driver / passenger side-air bag circuit • SDM

DTC Troubleshooting

Step	Action	Yes	No
1	Was "Air Bag Diagnostic System Check Flow" performed?	Go to Step 2.	Go to "Air Bag Diagnostic System Check Flow".
2	Side-air bag circuit check 1) Remove applicable driver / passenger side-air bag (inflator) module from seat back referring to "Side-Air Bag (Inflator) Module Removal and Installation". 2) Disconnect SDM connector "L04". 3) Check for proper connection to applicable side-air bag (inflator) module at terminal in connector "Q104" or "Q105". 4) Check for proper connection to SDM connector at terminal "L04-11" and "L04-12" (for DTC B1064) or terminal "L04-13" and "L04-14" (for DTC B1068). 5) If OK, release shorting bar in SDM connector inserting release tool (1) included in special tool (A). Special tool (A): 09932-76010 6) With ignition switch turned ON, measure voltage between "L04-11" terminal and body ground, and between "L04-12" terminal and body ground (for DTC B1064). 7) Measure voltage between "L04-13" terminal and body ground, and between "L04-14" terminal and body ground (for DTC B1068).  <i>Is each measured voltage 0 V?</i>	Substitute a known-good SDM and recheck.	Go to Step 3.

I7RW01822084-01

Step	Action	Yes	No
3	Floor harness circuit check 1) Disconnect applicable "L384" or "L385" connector under front cushion. 2) Check for proper connection to applicable floor harness connector at terminal in connector "L384" or "L385". 3) If OK, release shorting bar in SDM connector inserting release tool (1) included in special tool (A). Special tool (A): 09932-76010 4) With ignition switch turned ON, measure voltage between "L04-11" terminal and body ground, and between "L04-12" terminal and body ground (for DTC B1064). 5) Measure voltage between "L04-13" terminal and body ground, and between "L04-14" terminal and body ground (for DTC B1068).  I7RW01822085-01 <i>Is each measured voltage 0 V?</i>	DTC B1064: Repair "BLU" circuit or "BLK" circuit for short to power supply circuit at driver side-air bag harness. DTC B1068: Repair "BLU" circuit or "BLK" circuit for short to power supply circuit at passenger side-air bag harness.	DTC B1064: Repair "GRY/RED" circuit or "GRY" circuit for short to power supply circuit at floor harness. DTC B1068: Repair "BRN/WHT" circuit or "BRN" circuit for short to power supply circuit at floor harness.

NOTE

Upon completion of inspection and repair work, perform the following items.

- Reconnect all air bag system components, ensure all components are properly mounted.
- Clear DTCs referring to "DTC Clearance", if any.
- Repeat "Air Bag Diagnostic System Check" to confirm that the trouble has been corrected.

DTC B1071: Driver Forward Impact-Sensor Communication Data Inconsistent

S7RW0C8204034

DTC Detecting Condition and Trouble Area

DTC detecting condition	Trouble area
Forward impact-sensor has been communicated with no response or inconsistent ID code for more than 4 sec.	- Forward impact-sensor - Forward impact-sensor circuit - SDM

DTC Troubleshooting

Step	Action	Yes	No
1	Was "Air Bag Diagnostic System Check Flow" performed?	Go to Step 2.	Go to "Air Bag Diagnostic System Check Flow".
2	DTC check 1) Connect scan tool to DLC with ignition switch turned OFF. 2) Turn ON ignition switch and check SDM for DTC. <i>Are there any DTC(s) B1073, B1074?</i>	Go to applicable DTC diag. flow.	Replace defective forward impact-sensor and recheck. If this DTC still detected, replace SDM.

NOTE

Upon completion of inspection and repair work, perform the following items.

- Reconnect all air bag system components and ensure all components are properly mounted.
- Clear DTCs referring to "DTC Clearance", if any.
- Repeat "Air Bag Diagnostic System Check" to confirm that the trouble has been corrected.

DTC B1072: Driver Forward Impact-Sensor Communication Data Invalid

S7RW0C8204035

DTC Detecting Condition and Trouble Area

DTC detecting condition	Trouble area
Forward impact-sensor has been communicated with invalid data for more than 4 sec.	- Forward impact-sensor - SDM

DTC Troubleshooting

Step	Action	Yes	No
1	Was "Air Bag Diagnostic System Check Flow" performed?	Go to Step 2.	Go to "Air Bag Diagnostic System Check Flow".
2	DTC check 1) Connect scan tool to DLC with ignition switch turned OFF. 2) Turn ON ignition switch and check SDM for DTC. <i>Are there any DTC(s) B1071, B1073, B1074?</i>	Go to applicable DTC diag. flow.	Replace defective forward impact-sensor and recheck. If this DTC still detected, replace SDM.


NOTE

Upon completion of inspection and repair work, perform the following items.

- Reconnect all air bag system components and ensure all components are properly mounted.
- Clear DTCs referring to "DTC Clearance", if any.
- Repeat "Air Bag Diagnostic System Check" to confirm that the trouble has been corrected.

S7RW0C8204036

8B-67 Air Bag System:

Step	Action	Yes	No
3	Forward impact-sensor circuit check 1) Measure resistance between “L04-50” and “L04-51” terminals. Special tool (A): 09932-76010  <i>Is each measured resistance infinity?</i>	Replace defective forward impact-sensor, and recheck. If this DTC is still detected, replace SDM.	Repair short to ground in defective circuit.

NOTE

Upon completion of inspection and repair work, perform the following items.

- Reconnect all air bag system components and ensure all components are properly mounted.
- Clear DTCs referring to “DTC Clearance”, if any.
- Repeat “Air Bag Diagnostic System Check” to confirm that the trouble has been corrected.

DTC B1074: Driver Forward Impact-Sensor Circuit Open

S7RW0C8204037



Wiring Diagram

Refer to “DTC B1073: Driver Forward Impact-Sensor Circuit Shorted to Ground”.

DTC Detecting Condition and Trouble Area

DTC detecting condition	Trouble area
Forward impact-sensor circuit has been shorted to power circuit or opened for more than 4 sec.	• Forward impact-sensor • Forward impact-sensor circuit • SDM

DTC Troubleshooting

Step	Action	Yes	No
1	Was "Air Bag Diagnostic System Check Flow" performed?	Go to Step 2.	Go to "Air Bag Diagnostic System Check Flow".
2	Forward impact-sensor circuit check 1) Disconnect forward impact-sensor connector "E40". 2) Disconnect SDM connector "L04". 3) Check for proper connection to SDM connector at terminals "L04-50" and "L04-51". 4) Check for proper connection to forward impact-sensor connector at terminals "E40-1" and "E40-2". 5) Measure resistance between "L04-50" and "E40-2" terminals, between "L04-51" and "E40-1" terminals. Special tool (A): 09932-76010  I7RW01822067-02 Is each measured resistance 1 Ω or less?	Go to Step 3.	Repair high resistance or open in defective circuit.
3	Forward impact-sensor circuit check 1) With ignition turned ON, measure voltage between "L04-50" terminal and body ground, between "L04-51" terminal and body ground. Special tool (A): 09932-76010  I7RW01821029-01 Is each measured voltage 0 V?	Replace forward impact-sensor, and recheck. If DTC still detected, replace SDM.	Repair short to power supply circuit or other circuit in defective circuit.

NOTE

Upon completion of inspection and repair work, perform the following items.

- Reconnect all air bag system components and ensure all components are properly mounted.
- Clear DTCs referring to "DTC Clearance", if any.
- Repeat "Air Bag Diagnostic System Check" to confirm that the trouble has been corrected.

DTC B1081 / B1091: Side Impact-Sensor No Response

S7RW0C8204038

DTC B1081: Driver Side Impact-Sensor No Response**DTC B1091: Passenger Side Impact-Sensor No Response****DTC Detecting Condition and Trouble Area**

DTC detecting condition	Trouble area
DTC B1081: Driver side impact-sensor has been communicated with no response for more than 4 sec. DTC B1091: Passenger side impact-sensor has been communicated with no response for more than 4 sec.	• Driver / passenger side impact-sensor circuit • Driver / passenger side impact-sensor • SDM

DTC Troubleshooting

Step	Action	Yes	No
1	Was "Air Bag Diagnostic System Check Flow" performed?	Go to Step 2.	Go to "Air Bag Diagnostic System Check Flow".
2	DTC check 1) Connect scan tool to DLC with ignition switch turned OFF. 2) Turn ON ignition switch and check SDM for DTC. Are there any DTCs B1083, B1084 (for DTC B1081) or B1093, B1094 (for DTC B1091)?	Go to applicable DTC diag. flow.	Replace defective side impact-sensor and recheck. If this DTC still detected, replace SDM.

NOTE

Upon completion of inspection and repair work, perform the following items.

- Reconnect all air bag system components and ensure all components are properly mounted.
- Clear DTCs referring to "DTC Clearance", if any.
- Repeat "Air Bag Diagnostic System Check" to confirm that the trouble has been corrected.

DTC B1082 / B1092: Side Impact-Sensor Communication DATA Invalid

S7RW0C8204039

DTC B1082: Driver Side Impact-Sensor Communication DATA Invalid**DTC B1092: Passenger Side Impact-Sensor Communication DATA Invalid****DTC Detecting Condition and Trouble Area**

DTC detecting condition	Trouble area
DTC B1082: Driver side impact-sensor has been communicated with invalid data for more than 4 sec. DTC B1092: Passenger side impact-sensor has been communicated with invalid data for more than 4 sec.	• Driver / passenger side impact-sensor • SDM

DTC Troubleshooting

Step	Action	Yes	No
1	Was "Air Bag Diagnostic System Check Flow" performed?	Go to Step 2.	Go to "Air Bag Diagnostic System Check Flow".
2	DTC check 1) Connect scan tool to DLC with ignition switch turned OFF. 2) Turn ON ignition switch and check SDM for DTC. <i>Are there any DTC(s) B1083, B1084, B1085 (for DTC B1082) or B1093, B1094, B1095 (for DTC B1092)?</i>	Go to applicable DTC diag. flow.	Replace defective side impact-sensor and recheck. If this DTC still detected, replace SDM.

NOTE

Upon completion of inspection and repair work, perform the following items.

- Reconnect all air bag system components and ensure all components are properly mounted.
- Clear DTCs referring to "DTC Clearance", if any.
- Repeat "Air Bag Diagnostic System Check" to confirm that the trouble has been corrected.


DTC B1083 / B1093: Side Impact-Sensor Circuit Shorted to Ground

S7RW0C8204040

DTC B1083: Driver Side Impact-Sensor Circuit Shorted to Ground

DTC B1093: Passenger Side Impact-Sensor Circuit Shorted to Ground

Wiring Diagram





I6RW0C820013-01

1. Battery	5. Individual circuit fuse box No.1	9. Ground for air bag system	13. DC / DC converter
2. Fuse	6. Ignition switch	10. SDM	14. Back up capacitor
3. Main fuse box	7. "A/B" fuse	11. Driver side impact-sensor	
4. "IGN" fuse	8. Junction block assembly	12. Passenger side impact-sensor	

DTC Detecting Condition and Trouble Area

DTC detecting condition	Trouble area
DTC B1083: Driver side impact-sensor circuit has been shorted to ground for more than 4 sec. DTC B1093: Passenger side impact-sensor circuit has been shorted to ground for more than 4 sec.	• Driver / passenger side impact-sensor circuit • Driver / passenger side impact-sensor • SDM

DTC Troubleshooting

Step	Action	Yes	No
1	Was "Air Bag Diagnostic System Check Flow" performed?	Go to Step 2.	Go to "Air Bag Diagnostic System Check Flow".
2	Side impact-sensor circuit check 1) Disconnect applicable side impact-sensor connector "L35" or "L36". 2) Disconnect SDM connector "L04". 3) Check for proper connection to SDM connector at terminals "L04-46" and "L04-47" (for DTC B1083) or terminals "L04-44" and "L04-45" (for DTC B1093). 4) Check for proper connection to applicable side impact-sensor connector at terminals in connector "L35" or "L36". 5) Measure resistance between "L04-46" terminal and body ground (for DTC B1083) or between "L04-45" terminal and body ground (for DTC B1093). Special tool (A): 09932-76010  I7RW01822069-01 Is each measured resistance infinity?	Go to Step 3.	Repair short to ground in defective circuit.
3	Side impact-sensor circuit check 1) Measure resistance between "L04-46" and "L04-47" terminals, between "L04-46" and "L04-44" terminals (for DTC B1083). 2) Measure resistance between "L04-45" and "L04-44" terminals, between "L04-45" and "L04-47" terminals (for DTC B1093). Special tool (A): 09932-76010  I7RW01822070-01 Is each measured resistance infinity?	Replace defective side impact-sensor, and recheck. If this DTC is still detected, replace SDM.	Repair short to ground in defective circuit.

NOTE

Upon completion of inspection and repair work, perform the following items.

- Reconnect all air bag system components and ensure all components are properly mounted.
- Clear DTCs referring to "DTC Clearance", if any.
- Repeat "Air Bag Diagnostic System Check" to confirm that the trouble has been corrected.


DTC B1084 / B1094: Side Impact-Sensor Circuit Open**DTC B1084: Driver Side Impact-Sensor Circuit Open****DTC B1094: Passenger Side Impact-Sensor Circuit Open****Wiring Diagram**

Refer to "DTC B1083 / B1093: Side Impact-Sensor Circuit Shorted to Ground".

DTC Detecting Condition and Trouble Area


DTC detecting condition	Trouble area
DTC B1084: Driver side impact-sensor circuit has been shorted to power circuit or opened for more than 4 sec. DTC B1094: Passenger side impact-sensor circuit has been shorted to power circuit or opened for more than 4 sec.	• Driver / passenger side impact-sensor circuit • Driver / passenger side impact-sensor • SDM

DTC Troubleshooting

Step	Action	Yes	No
1	Was "Air Bag Diagnostic System Check Flow" performed?	Go to Step 2.	Go to "Air Bag Diagnostic System Check Flow".
2	Side impact-sensor circuit check 1) Disconnect applicable side impact-sensor connector "L35" or "L36". 2) Disconnect SDM connector "L04". 3) Check for proper connection to SDM connector at terminals "L04-46" and "L04-47" (for DTC B1084) or terminals "L04-44" and "L04-45" (for DTC B1094). 4) Check for proper connection to applicable side impact-sensor connector at terminals in connector "L35" or "L36". 5) Measure resistance between "L04-46" and "L36-2" terminals, between "L04-47" and "L36-1" terminals (for DTC B1084). 6) Measure resistance between "L04-45" and "L35-2" terminals, between "L04-44" and "L35-2" terminals (for DTC B1094). Special tool (A): 09932-76010  Is each measured resistance 1 Ω or less?	Go to Step 3.	Repair open in defective circuit.

I7RW01822071-01

8B-73 Air Bag System:

Step	Action	Yes	No
3	Side impact-sensor circuit check 1) With ignition turn ON, measure voltage between “L04-46” terminal and body ground, between “L04-47” terminal and body ground (for DTC B1084). 2) Measure voltage between “L04-45” terminal and body ground, between “L04-44” terminal and body ground (for DTC B1094). Special tool (A): 09932-76010  <i>Is each measured voltage 0 V?</i>	Replace side impact-sensor, and recheck. If DTC still detected, replace SDM.	Repair short to power supply circuit or other circuit in defective circuit.

NOTE

Upon completion of inspection and repair work, perform the following items.

- Reconnect all air bag system components and ensure all components are properly mounted.
- Clear DTCs referring to “DTC Clearance”, if any.
- Repeat “Air Bag Diagnostic System Check” to confirm that the trouble has been corrected.

DTC B1085 / B1095: Side Impact-Sensor Communication DATA Inconsistent

S7RW0C8204042

DTC B1085: Driver Side Impact-Sensor Communication DATA Inconsistent

DTC B1095: Passenger Side Impact-Sensor Communication DATA Inconsistent

DTC Detecting Condition and Trouble Area

DTC detecting condition	Trouble area
DTC B1085: Driver side impact-sensor has been communicated with inconsistent ID code for more than 4 sec. DTC B1095: Passenger side impact-sensor has been communicated with inconsistent ID code for more than 4 sec.	• Driver / passenger side impact-sensor • SDM

DTC Troubleshooting

Step	Action	Yes	No
1	Was “Air Bag Diagnostic System Check Flow” performed?	Go to Step 2.	Go to “Air Bag Diagnostic System Check Flow”.
2	DTC check 1) Connect scan tool to DLC with ignition switch turned OFF. 2) Turn ON ignition switch and clear DTC referring to “DTC Clearance”. 3) Turn OFF ignition switch and recheck DTC. <i>Is DTC(s) B1085 and/or B1095 still detected?</i>	Replace defective side impact-sensor.	Intermittent trouble. Check for intermittent trouble referring to “Inspection of Intermittent and Poor Connections”.


NOTE

Upon completion of inspection and repair work, perform the following items.

- Reconnect all air bag system components and ensure all components are properly mounted.
- Clear DTCs referring to “DTC Clearance”, if any.
- Repeat “Air Bag Diagnostic System Check” to confirm that the trouble has been corrected.

DTC B1361 / B1365: Curtain-Air Bag Circuit High Resistance

S7RW0C8204043

DTC B1361: Driver Curtain-Air Bag Circuit High Resistance**DTC B1365: Passenger Curtain-Air Bag Circuit High Resistance****Wiring Diagram**


I7RW0A820002-01


[A]: Shorting bar	4. "IGN" fuse	10. SDM
[B]: Hatchback model	5. Individual circuit fuse box No.1	11. Driver side curtain-air bag (inflator) module
[C]: Sedan model	6. Ignition switch	12. Passenger side curtain-air bag (inflator) module
1. Battery	7. "A/B" fuse	13. DC / DC converter
2. Fuse	8. Junction block assembly	14. Back up capacitor
3. Main fuse box	9. Ground for air bag system	


DTC Detecting Condition and Trouble Area

DTC detecting condition	Trouble area
DTC B1361: Driver curtain-air bag circuit is more than 3.8 Ω for more than 4 sec. DTC B1365: Passenger curtain-air bag circuit is more than 3.8 Ω for more than 4 sec.	• Driver / passenger curtain-air bag circuit • Driver / passenger curtain-air bag module • SDM

DTC Troubleshooting

Step	Action	Yes	No
1	Was "Air Bag Diagnostic System Check Flow" performed?	Go to Step 2.	Go to "Air Bag Diagnostic System Check Flow".
2	Driver / passenger curtain-air bag circuit check 1) With ignition switch turned OFF, remove rear quarter upper trim (hatchback model [A]) or rear pillar inner trim (sedan model [B]) of applicable side and disconnect applicable side curtain-air bag (inflator) module connector. 2) Check for proper connection to applicable side curtain-air bag (inflator) module at terminals in connector "Q102" or "Q103" (hatchback model), "L291" or "L290" (sedan model). 3) If OK, then connect special tools (A), (B) and (C) to applicable side curtain-air bag (inflator) module connector. Special tool (A): 09932-76010 (B): 09932-75010 (C): 09932-78310  4) Check SDM for DTC. <i>With ignition switch turned ON, is DTC B1361 or B1365 still indicated?</i>	Go to Step 3.	Replace side curtain-air bag (inflator) module referring to "Side Curtain-Air Bag (Inflator) Module Removal and Installation".

Step	Action	Yes	No
3	Driver / passenger curtain-air bag circuit check 1) Disconnect special tools from applicable side curtain-air bag connector. 2) With ignition switch turned OFF, disconnect SDM connector "L04". 3) Check for proper connection to SDM connector at terminal "L04-19" and "L04-20" (for DTC B1361) or terminal "L04-21" and "L04-22" (for DTC B1365). 4) If OK, release shorting bar in SDM connector inserting release tool (1) included in special tool (A). Special tool (A): 09932-76010 5) Measure resistance at following connector terminals (for DTC B1361). • Between "L04-19" and "Q103-2" terminals, between "L04-20" and "Q103-1" terminals. (hatchback model) • Between "L04-19" and "L291-2" terminals, between "L04-20" and "L291-1" terminals. (sedan model) 6) Measure resistance at following connector terminals (for DTC B1365). • Between "L04-21" and "Q102-1" terminals, between "L04-22" and "Q102-2" terminals. (hatchback model) • Between "L04-21" and "L290-1" terminals, between "L04-22" and "L290-2" terminals. (sedan model)  I6RW0B820011-02	Substitute a known-good SDM and recheck.	Hatchback model: Go to Step 4. Sedan model: Repair high resistance or open wire in "YEL/GRN" or "YEL/BLU" circuit at floor harness. (for DTCB1361) Repair high resistance or open wire in "BLK/YEL" or "BRN/YEL" circuit at floor harness. (for DTCB1365)
Is each measured resistance 1Ω or less?			

Step	Action	Yes	No
4	Floor harness circuit check (hatchback model) - With ignition switch turned OFF, remove rear inner trim of right side and disconnect "L395" connector. - Check for proper connection to applicable side curtain-air bag at terminal in "L395" connector. - If OK, release shorting bar in SDM connector inserting release tool (1) included in special tool (A). Special tool (A): 09932-76010 - Measure resistance between "L04-19" and "L395-4" terminals, between "L04-20" and "L395-3" terminals (for DTC B1361). - Measure resistance between "L04-21" and "L395-1" terminals, between "L04-22" and "L395-2" terminals (for DTC B1065).  I7RW01822089-01 <i>Is each measured resistance 1Ω or less?</i>	DTC B1361: Repair high resistance or open wire in "YEL/GRN" or "YEL/BLU" circuit at driver curtain-air bag harness. DTC B1365: Repair high resistance or open wire in "BLK/YEL" or "BRN/YEL" circuit at passenger curtain-air bag harness.	DTC B1361: Repair high resistance or open wire in "YEL/GRN" or "YEL/BLU" circuit at floor harness. DTC B1365: Repair high resistance or open wire in "BLK/YEL" or "BRN/YEL" circuit at floor harness.

NOTE

Upon completion of inspection and repair work, perform the following items.

- Reconnect all air bag system components, ensure all components are properly mounted.
- Clear DTCs referring to "DTC Clearance", if any.
- Repeat "Air Bag Diagnostic System Check" to confirm that the trouble has been corrected.

DTC B1362 / B1366: Curtain-Air Bag Circuit Low Resistance

S7RW0C8204044


DTC B1362: Driver Curtain-Air Bag Circuit Low Resistance**DTC B1366: Passenger Curtain-Air Bag Circuit Low Resistance****Wiring Diagram**



Refer to "DTC B1361 / B1365: Curtain-Air Bag Circuit High Resistance".

DTC Detecting Condition and Trouble Area

DTC detecting condition	Trouble area
DTC B1362: Driver curtain-air bag circuit is less than 1.0 Ω for more than 4 sec.	• Driver / passenger curtain-air bag circuit • Driver / passenger curtain-air bag module • SDM
DTC B1366: Passenger curtain-air bag circuit is less than 1.0 Ω for more than 4 sec.	

DTC Troubleshooting

Step	Action	Yes	No
1	Was "Air Bag Diagnostic System Check Flow" performed?	Go to Step 2.	Go to "Air Bag Diagnostic System Check Flow".
2	Driver / passenger curtain-air bag circuit check 1) With ignition switch turned OFF, remove rear quarter upper trim (hatchback model [A]) or rear pillar inner trim (sedan model [B]) of applicable side and disconnect applicable side curtain-air bag (inflator) module connector. 2) Check for proper connection to applicable side curtain-air bag (inflator) module at terminals in connector "Q103" or "Q102" (hatchback model), "L291" or "L290" (sedan model). 3) If OK, then connect special tools (A), (B) and (C) to applicable side curtain-air bag (inflator) module connector. Special tool (A): 09932-76010 (B): 09932-75010 (C): 09932-78310  4) Check SDM for DTC. With ignition switch turned ON, is DTC B1362 or B1366 still indicated?	Go to Step 3.	Replace side curtain-air bag (inflator) module referring to "Side Curtain-Air Bag (Inflator) Module Removal and Installation".

Step	Action	Yes	No
3	Driver / passenger curtain-air bag circuit check 1) Disconnect special tools from applicable side curtain-air bag connector. 2) With ignition switch turned OFF, disconnect SDM connector "L04". 3) Check for proper connection to SDM connector at terminal "L04-19" and "L04-20" (for DTC B1362) or terminal "L04-21" and "L04-22" (for DTC B1366). 4) If OK, release shorting bar in SDM connector inserting release tool (1) included in special tool (A). Special tool (A): 09932-76010 5) Measure resistance between "L04-19" and "L04-20" terminals (for DTC B1362) and between "L04-21" and "L04-22" terminals (for DTC B1366).  I7RW01822090-01 <i>Is each measured resistance infinity?</i>	Substitute a known-good SDM and recheck.	Hatchback model: Go to Step 4. Sedan model: Repair "YEL/GRN" circuit for short to "YEL/BLU" circuit at floor harness. (for DTC B1362) Repair "BLK/YEL" circuit for short to "BRN/YEL" circuit at floor harness. (for DTC B1366)
4	Floor harness circuit check (hatchback model) 1) With ignition switch turned OFF, remove rear inner trim of right side and disconnect "L395" connector. 2) Check for proper connection to applicable side curtain-air bag at terminal in "L395" connector. 3) If OK, release shorting bar in SDM connector inserting release tool (1) included in special tool (A). Special tool (A): 09932-76010 4) Measure resistance between "L04-19" and "L04-20" terminals (for DTC B1362) and between "L04-21" and "L04-22" terminals (for DTC B1366).  I7RW01822091-01 <i>Is each measured resistance infinity?</i>	DTC B1362: Repair "YEL/GRN" circuit for short to "YEL/BLU" circuit at driver curtain-air bag harness. DTC B1366: Repair "BLK/YEL" circuit for short to "BRN/YEL" circuit at passenger curtain-air bag harness.	DTC B1362: Repair "YEL/GRN" circuit for short to "YEL/BLU" circuit at floor harness. DTC B1366: Repair "BLK/YEL" circuit for short to "BRN/YEL" circuit at floor harness.

NOTE

Upon completion of inspection and repair work, perform the following items.

- Reconnect all air bag system components, ensure all components are properly mounted.
- Clear DTCs referring to "DTC Clearance", if any.
- Repeat "Air Bag Diagnostic System Check" to confirm that the trouble has been corrected.


DTC B1363 / B1367: Curtain-Air Bag Circuit Shorted to Ground**DTC B1363: Driver Curtain-Air Bag Circuit Shorted to Ground****DTC B1367: Passenger Curtain-Air Bag Circuit Shorted to Ground****Wiring Diagram**


Refer to "DTC B1361 / B1365: Curtain-Air Bag Circuit High Resistance".

DTC Detecting Condition and Trouble Area

DTC detecting condition	Trouble area
DTC B1363: Driver curtain-air bag circuit has been shorted to ground for more than 4 sec. DTC B1367: Passenger curtain-air bag circuit has been shorted to ground for more than 4 sec.	• Driver / passenger curtain-air bag circuit • SDM

DTC Troubleshooting

Step	Action	Yes	No
1	Was "Air Bag Diagnostic System Check Flow" performed?	Go to Step 2.	Go to "Air Bag Diagnostic System Check Flow".
2	Driver / passenger curtain-air bag circuit check 1) With ignition switch turned OFF, remove rear quarter upper trim (hatchback model) or rear pillar inner trim (sedan model) of applicable side and disconnect applicable side curtain-air bag (inflator) module connector. 2) Disconnect SDM connector "L04". 3) Check for proper connection to SDM connector at terminal "L04-19" and "L04-20" (for DTC B1363) or terminal "L04-21" and "L04-22" (For DTC B1367). 4) Check for proper connection to applicable side curtain-air bag (inflator) module connector at terminal in its connector. 5) If OK, release shorting bar in SDM connector inserting release tool (1) included in special tool (A). Special tool (A): 09932-76010 6) Measure resistance between "L04-19" terminal and body ground, and between "L04-20" terminal and body ground (for DTC B1363). 7) Measure resistance between "L04-21" terminal and body ground, and between "L04-22" terminal and body ground (for DTC B1367).  I7RW01822092-01 Is each measured resistance infinity?	Substitute a known-good SDM and recheck.	Hatchback model: Go to Step 3. Sedan model: Repair "YEL/GRN" or "YEL/BLU" circuit for short to ground at floor harness. (for DTC B1363) Repair "BLK/YEL" or "BRN/YEL" circuit for short to ground at floor harness. (for DTC B1367)

Step	Action	Yes	No
3	Floor harness circuit check (hatchback model) 1) With ignition switch turned OFF, remove rear inner trim of right side and disconnect "L395" connector. 2) Check for proper connection to applicable side curtain-air bag at terminal in "L395" connector. 3) If OK, release shorting bar in SDM connector inserting release tool (1) included in special tool (A). Special tool (A): 09932-76010 4) Measure resistance between "L04-19" terminal and body ground, and between "L04-20" terminal and body ground (for DTC B1363). 5) Measure resistance between "L04-21" terminal and body ground, and between "L04-22" terminal and body ground (for DTC B1367).  17RW01822093-01 <i>Is each measured resistance infinity?</i>	DTC B1363: Repair "YEL/GRN" or "YEL/BLU" circuit for short to ground at driver curtain-air bag harness. DTC B1367: Repair "BLK/YEL" or "BRN/YEL" circuit for short to ground at passenger curtain-air bag harness.	DTC B1363: Repair "YEL/GRN" or "YEL/BLU" circuit for short to ground at floor harness. DTC B1367: Repair "BLK/YEL" or "BRN/YEL" circuit for short to ground at floor harness.

NOTE

Upon completion of inspection and repair work, perform the following items.

- Reconnect all air bag system components, ensure all components are properly mounted.
- Clear DTCs referring to "DTC Clearance", if any.
- Repeat "Air Bag Diagnostic System Check" to confirm that the trouble has been corrected.


DTC B1364 / B1368: Curtain-Air Bag Circuit Shorted to Power Supply**DTC B1364: Driver Curtain-Air Bag Circuit Shorted to Power Supply****DTC B1368: Passenger Curtain-Air Bag Circuit Shorted to Power Supply****Wiring Diagram**


Refer to "DTC B1361 / B1365: Curtain-Air Bag Circuit High Resistance".

DTC Detecting Condition and Trouble Area

DTC detecting condition	Trouble area
DTC B1364: Driver curtain-air bag circuit has been shorted to power circuit for more than 4 sec. DTC B1368: Passenger curtain-air bag circuit has been shorted to power circuit for more than 4 sec.	• Driver / passenger curtain-air bag circuit • SDM

DTC Troubleshooting

Step	Action	Yes	No
1	Was "Air Bag Diagnostic System Check Flow" performed?	Go to Step 2.	Go to "Air Bag Diagnostic System Check Flow".
2	Driver / passenger curtain-air bag circuit check 1) With ignition switch turned OFF, remove rear quarter upper trim (hatchback model) or rear pillar inner trim (sedan model) of applicable side and disconnect applicable side curtain-air bag (inflator) module connector. 2) Disconnect SDM connector "L04". 3) Check for proper connection to SDM connector at terminal "L04-19" and "L04-20" (for DTC B1364) or terminal "L04-21" and "L04-22" (for DTC B1368). 4) Check for proper connection to applicable side curtain-air bag (inflator) module its connector at terminal in its connector. 5) If OK, release shorting bar in SDM connector inserting release tool (1) included in special tool (A). Special tool (A): 09932-76010 6) With ignition switch turned ON, measure voltage between "L04-19" terminal and body ground, and between "L04-20" terminal and body ground (for DTC B1364). 7) Measure voltage between "L04-21" terminal and body ground, and between "L04-22" terminal and body ground (for DTC B1368).  <i>Is each measured voltage 0 V?</i>	Substitute a known-good SDM and recheck.	Hatchback model: Go to Step 3. Sedan model: Repair "YEL/GRN" or "YEL/BLU" circuit for short to power supply at floor harness. (for DTC B1364) Repair "BLK/YEL" or "BRN/YEL" circuit for short to power supply at floor harness. (for DTC B1368)

Step	Action	Yes	No
3	Floor harness circuit check (hatchback model) 1) With ignition switch turned OFF, remove rear inner trim of right side and disconnect "L395" connector. 2) Check for proper connection to applicable side curtain-air bag at terminal in "L395" connector. 3) If OK, release shorting bar in SDM connector inserting release tool (1) included in special tool (A). Special tool (A): 09932-76010 4) With ignition switch turned ON, measure voltage between "L04-19" terminal and body ground, and between "L04-20" terminal and body ground (for DTC B1364). 5) Measure voltage between "L04-21" terminal and body ground, and between "L04-22" terminal and body ground (for DTC B1368).  17RW01822095-01 <i>Is each measured voltage 0 V?</i>	DTC B1364: Repair "YEL/GRN" or "YEL/BLU" circuit for short to power supply at driver curtain-air bag harness. DTC B1368: Repair "BLK/YEL" or "BRN/YEL" circuit for short to power supply at passenger curtain-air bag harness.	DTC B1364: Repair "YEL/GRN" or "YEL/BLU" circuit for short to power supply at floor harness. DTC B1368: Repair "BLK/YEL" or "BRN/YEL" circuit for short to power supply at floor harness.



NOTE

Upon completion of inspection and repair work, perform the following items.

- Reconnect all air bag system components, ensure all components are properly mounted.
- Clear DTCs referring to "DTC Clearance", if any.
- Repeat "Air Bag Diagnostic System Check" to confirm that the trouble has been corrected.



Step	Action	Yes	No
1	Battery voltage check 1) Measure voltage on battery. <i>Is voltage in 9 – 16 V?</i>	Go to Step 2.	Check charging system and repair as necessary referring to “Generator Test (Undercharged Battery Check) in Section 1J” or “Generator Test (Overcharged Battery Check) in Section 1J”.
2	Connection check 1) Check for loose each connection. <i>Is it connected securely?</i>	Go to Step 3.	Intermittent trouble. Check for intermittent trouble referring to “Inspection of Intermittent and Poor Connections” If OK, substitute a known-good SDM and recheck
3	Circuit fuse check 1) With ignition switch turn OFF, check “A/B” fuse for blowing. <i>Is “A/B” fuse in good condition?</i>	Go to Step 4.	Repair defective wire circuit. After repaired, replace “A/B” fuse.


8B-85 Air Bag System:


Step	Action	Yes	No
4	Power supply circuit check 1) With ignition switch turned OFF, disconnect connector from SDM. 2) Check for proper connection to SDM terminal at "L04-27". 3) With ignition switch turned ON, measure voltage between "L04-27" terminal of SDM connector and body ground. Special tool (A): 09932-76010  <i>Is voltage in 10 – 14 V?</i>	Go to Step 5.	Repair defective wire circuit.
5	Ground circuit check 1) Turn ignition switch to OFF position. 2) Check for proper connection to SDM terminal at "L04-28". 3) Measure resistance between "L04-28" terminal and vehicle body ground. Special tool (A): 09932-76010  <i>Is resistance 1 Ω or less?</i>	SDM Power Supply and ground circuit is good condition.	Repair defective wire circuit.

Contact Coil Cable and Its Circuit Check

Troubleshooting

Step	Action	Yes	No
1	Driver air bag circuit check 1) Remove driver air bag (inflator) module referring to "Driver Air Bag (Inflator) Module Removal and Installation". 2) With ignition switch turned OFF, disconnect SDM connector "L04". 3) Release shorting bar in SDM connector inserting release tool (1) included in special tool (A). Special tool (A): 09932-76010 4) Measure resistance between "L04-3" and "L04-4" terminals.  I7RW01821030-01 <i>Is each measured resistance infinity?</i>	Go to Step 2.	Check defective wire harness. If wire is OK, replace contact coil.
2	Contact coil circuit (driver air bag circuit) check 1) Remove contact coil referring to "Contact Coil Cable Assembly Removal and Installation in Section 6B". 2) Measure resistance between "A" terminal of driver air bag connector (1) and "a" terminal of contact coil connector (2). 3) Measure resistance between "B" terminal of driver air bag connector (1) and "b" terminal of contact coil connector (2). Special tool (A): 09932-76010  I6RW0B820013-03 <i>Is each measured resistance 1 Ω or less?</i>	Go to Step 3 or 4.	Replace contact coil.

Step	Action	Yes	No														
3	Contact coil circuit (horn and audio control switch circuit) check (non cruise control model) 1) Check for continuity between each terminal of horn switch terminals [A] and audio control switch terminals [B] (if equipped) as shown in figure.  [A] <table><thead><tr><th colspan="2">Terminal</th></tr></thead><tbody><tr><td>E</td><td>e</td></tr><tr><td>F</td><td>f</td></tr></tbody></table> [B] <table><tbody><tr><td>A</td><td>a</td></tr><tr><td>B</td><td>b</td></tr><tr><td>C</td><td>c</td></tr><tr><td>D</td><td>d</td></tr></tbody></table> I6RW0C820017-01 <i>Is each measured resistance 3 Ω or less?</i>	Terminal		E	e	F	f	A	a	B	b	C	c	D	d	Go to Step 5.	Replace contact coil.
Terminal																	
E	e																
F	f																
A	a																
B	b																
C	c																
D	d																

Step	Action	Yes	No																												
4	Contact coil circuit (horn, audio control and cruise control switch circuit) check (cruise control model) 1) Check for continuity between each terminal of horn switch terminals, audio control switch terminals and cruise control switch terminals as shown in figure.  <table><tr><th colspan="2">Terminal</th></tr><tr><td>A</td><td>a</td></tr><tr><td>B</td><td>b</td></tr><tr><td>C</td><td>c</td></tr><tr><td>D</td><td>d</td></tr><tr><td>E</td><td>e</td></tr><tr><td>F</td><td>f</td></tr></table><table><tr><th colspan="2">Terminal</th></tr><tr><td>G</td><td>g</td></tr><tr><td>H</td><td>h</td></tr><tr><td>I</td><td>i</td></tr><tr><td>J</td><td>j</td></tr><tr><td>K</td><td>k</td></tr><tr><td>L</td><td>l</td></tr></table> <i>Is each measured resistance 3 Ω or less?</i>	Terminal		A	a	B	b	C	c	D	d	E	e	F	f	Terminal		G	g	H	h	I	i	J	j	K	k	L	l	Go to Step 5.	Replace contact coil.
Terminal																															
A	a																														
B	b																														
C	c																														
D	d																														
E	e																														
F	f																														
Terminal																															
G	g																														
H	h																														
I	i																														
J	j																														
K	k																														
L	l																														
5	Contact coil circuit check 1) Measure resistance between each terminal and other terminal. <i>Is each measured resistance infinity?</i>	Contact coil and its circuit are good condition.	Replace contact coil.																												

Inspection of Intermittent and Poor Connections

S7RW0C8204049


Most intermittents are caused by faulty electrical connections or wiring. When a check for proper connection is requested in a diagnostic flow, perform careful check of suspect circuits.

If any abnormality is found, repair or replace as a wire harness assembly.

- Poor mating of connector halves, or terminals not fully seated in the connector body (backed out).
- Dirt or corrosion on the terminals. The terminals must be clean and free of any foreign material which could impede proper terminal contact. However, cleaning the terminal with a sand paper or the like is prohibited.
- Damaged connector body, exposing the terminals to moisture and dirt, as well as not maintaining proper terminal orientation with the component or mating connector.
- Improperly formed or damaged terminals. Check each connector terminal in problem circuits carefully to ensure good contact tension by using the corresponding mating terminal included in the connector test adapter kit (special tool). If contact tension is not enough, reform the terminal to increase contact tension or replace it.


Special tool

(A): 09932-76010 Connector test adapter kit




I4RS0A820045-01

- Poor terminal-to-wire connection. Check each wire harness in problem circuits for poor connection by shaking it by hand lightly. If any abnormal condition is found, change the wire harness assembly or component parts with new ones.



IYSQ01010028-01

- Wire insulation which is rubbed through, causing an intermittent short as the bare area touches other wiring or parts of the vehicle.
- Wire broken inside the insulation. This condition could cause a continuity check to show a good circuit, but if only 1 or 2 strands of a multi-strand-type wire are intact, resistance could be far too high.



IYSQ01820025-01

Repair and Inspection Required after Accident

S7RW0C8204050

⚠ CAUTION

- All air bag system components, including the electrical harness (component mounting points), must be inspected after an accident. If any components are damaged or bent, they must be replaced even if air bag system activation did not occur.
- Never use air bag system parts from another vehicle.
- Do not attempt to service the parts below. Service of these parts is by replacement only.
 - Driver / Passenger air bag (inflator) modules
 - Driver / Passenger side-air bag (inflator) modules
 - Driver / Passenger side curtain-air bag (inflator) modules
 - Driver / Passenger seat belt pretensioners
 - Forward impact-sensor
 - Driver / Passenger side impact-sensors
 - SDM
 - Contact coil and combination switch assembly
 - Air bag wire harness in main harness, instrument panel harness, floor harness, passenger air bag harness, side-air bag harness and side curtain-air bag harness.
- Proper operation of the sensors and air bag system requires that any repairs to the vehicle structure return it to its original production configuration.

⚠ CAUTION

After detecting one time of such collision as to meet deployment conditions, the SDM must not be used.

Refer to “Air Bag Diagnostic System Check” when checking the SDM.

Accident with Deployment / Activation – Component Replacement

When driver and passenger air bags are deployed, the following components must be replaced.


- Driver and passenger air bag (inflator) modules
 - Driver and passenger seat belt pretensioners
 - SDM after detecting such collision as to meet deployment conditions
 - Forward impact-sensor
 - Instrument panel
- When side-air bag and side curtain-air bag are deployed, the following components must be replaced.
- Deployed side-air bag (inflator) module
 - Deployed side curtain-air bag (inflator) module
 - Side impact-sensor
 - SDM

Accident with or without Deployment / Activation – Component Inspections

Certain air bag and restraint system components must be inspected after any crash, whether the air bag system activated or not. If any faulty condition is found in the following checks, replace faulty part.

Those components are:


- Steering column (1) and shaft joints
 - Check for length, damage and bend according to “Checking Steering Column for Accident Damage in Section 6B”.
- Steering column bracket (2) and capsules
 - Check for damage and bent.



I6RW0B820015-01


8B-91 Air Bag System:

- Steering wheel and driver air bag (inflator) module
 - Check for damage or air bag (inflator) module fitness.
 - Check trim cover (pad surface) for cracks.
 - Check wire harness and connector for damage or tightness.




I5JB0A820062-01

- Contact coil assembly
 - Check wire harness and connectors for damage or tightness.
 - Check contact coil case for damage.
 - Check contact coil circuit referring to “Contact Coil Cable and Its Circuit Check”.




I4RS0A820048-01

- Instrument panel member and reinforcement
 - Check for any distortion, bending, cracking or other damage.
 - Check instrument panel for cracks or deformities.
- Passenger air bag (inflator) module
 - Check for dents, cracks, damage or fitness.
 - Check harness and connector for damage or tightness.




I5RW0A820058-03

- SDM
 - Check for external damage such as deformation, scratch, crack, peeled paint, etc.
 - Check SDM for a cause in itself preventing its proper installation. (There is a gap between SDM and SDM plate, or it cannot be fixed securely.)
 - Check connector or lead wire of SDM for scorching, melting or damage.
 - Check SDM connector and terminals for tightness.
 - Check if SDM sets a DTC and is judged as malfunctioning according to the diagnostic flow.



I5RH01820092-01


- Air bag wire harness and connections
 - Check for damages, deformities or poor connections.
Refer to “Inspection of Intermittent and Poor Connections”.
 - Check wire harness clamps for tightness.



I6RW0B820002-01


1. Main harness	5. Side-air bag harness
2. Grounding point	6. Side curtain-air bag harness (hatchback model)
3. Floor harness	7. Side curtain-air bag (inflator) module (sedan model)
4. Instrument panel harness	8. Side curtain-air bag (inflator) module (hatchback model)

- Forward impact-sensor
 - Check sensor (1) and apron-side-member (driver side) (2) for damage, bend or rust.
 - Check connector (3) or lead wire (4) of forward-sensor for scorching, melting or damage.




I5RW0A820059-01

- Side impact-sensor
 - Check sensor (1) and under body (2) for dents, cracks, deformation or rust.
 - Check sensor connector (sensor side and harness side) (3) or sensor lead wire (4) for damage, crack, scorching or melting.



I5RW0A820060-01

- Seat belt pretensioner
 - Check for dents, cracks, damage or fitness
 - Check harness and connector for damage or tightness.



I3JA01820043-01

1. Seat belt	2. Retractor assembly
--------------	-----------------------

- Seat belts and mounting points
 - Refer to “Front Seat Belt Components in Section 8A”.
- “AIR BAG” warning light
 - After vehicle is completely repaired, perform “Air Bag Diagnostic System Check”.
- Side-air bag (inflator) module
 - Check for dents, cracks, damage or fitness.
 - Check trim cover for cracks or deformities.
 - Check wire harness and connector for damage or tightness.
- Side curtain-air bag (inflator) module
 - Check for dents, cracks, damage or fitness.
 - Check harness wire harness and connector for damage or tightness.
 - Check headlining for cracks or deformation.

Repair Instructions


Disabling Air Bag System

S7RW0C8206001

NOTE


With "A/B" fuse removed and ignition switch ON, "AIR BAG" warning light will be ON. This is normal operation and does not indicate air bag system malfunction.

- 1) Turn steering wheel so that vehicle's wheels (front tires) are pointing straight ahead.
- 2) Disconnect negative (-) cable at battery.
- 3) Turn ignition switch to "LOCK" position and remove key.
- 4) Remove "A/B" fuse from junction block assembly.
- 5) Remove driver side front pillar lower trim and disconnect yellow connector (1) for driver air bag as follows.
 - a) Release locking of lock slider (2).
 - b) After unlocked, disconnect connector.
- 6) Remove passenger side front pillar lower trim and disconnect yellow connector (3) for passenger air bag as follows.
 - a) Release locking of lock slider (2).
 - b) After unlocked, disconnect connector.



I7RW01821012-01

- 7) Disconnect yellow connector of side-air bag (inflator) module under front seat cushion (1).
 - a) Release locking of lock slider (2).
 - b) After unlocked, disconnect connector.




I6RW0B820017-01

- 8) Disconnect connector of side curtain-air bag (inflator) module as follows.

For hatchback model:


- a) Remove right-side rear quarter lower trim.
- b) Release locking of lock slider (2) of yellow connector (1).
- c) With unlocked, disconnect connector.



I6RW0B820018-01

For sedan model

- a) Remove rear side sill scuff referring to step 3) of "Floor Carpet Removal and Installation in Section 9H".
- b) Remove rear seat side back.
- c) Remove rear pillar inner trim.
- d) Unlock lock button (2) of black connector (1).
- e) With lock button unlocked, disconnect connector.




I7RW0A820004-01

Enabling Air Bag System


S7RW0C8206002

- 1) Confirm that battery negative (–) cable is disconnected.
- 2) Turn ignition switch to “LOCK” position and remove key.
- 3) Connect yellow connector (1) of driver air bag (inflator) module by pushing connector till click is heard from it.




I5RW0A820091-01

- 4) Connect yellow connector (1) of passenger air bag (inflator) module by pushing connector till click is heard from it.



I5RW0A820062-02

- 5) Install driver and passenger side front pillar lower trim.
- 6) Connect yellow connector (1) of side-air bag (inflator) module by pushing connector till click is heard from it.




I5JB0A820070-01

- 7) Connect connector of side curtain-air bag (inflator) module and then install each trim as follows.

For hatchback model:


- a) Connect yellow connector (1) by pushing connector till click is heard from it.
- b) Install right-side rear quarter lower trim.



I5RW0A820063-01

For sedan model

- a) Connect black connector (1).
- b) Lock connector with lock button (2).
- c) Install rear pillar inner trim.
- d) Install rear seat side back referring to “Rear Seat Components in Section 9G”.
- e) Install rear side sill scuff.



I6RW0B820020-01

- 8) Install “A/B” fuse to fuse box.
- 9) Connect negative (–) cable at battery.
- 10) Turn ignition switch to ON position and verify that “AIR BAG” warning light flashes 6 times and then turns OFF. If it does not operate as described, perform “Air Bag Diagnostic System Check”.

SDM Removal and Installation

S7RW0C8206003


⚠ WARNING

During service procedures, be very careful when handling a Sensing and Diagnostic Module (SDM).

Be sure to read “Precautions on Service and Diagnosis of Air Bag System” before starting to work and observe every precaution during work. Neglecting them may result in personal injury or inactivation of the air bag system when necessary.

Removal


- 1) Disconnect negative (–) cable at battery.
- 2) Disable air bag system referring to “Disabling Air Bag System”.
- 3) Remove console box referring to “Console Box Components in Section 9H”.
- 4) Remove G sensor referring to “G Sensor Removal and Installation (4WD Model) in Section 4E” and its bracket (1).



I5RW0A820064-01

2. SDM

- 5) Disconnect SDM connector (1) from SDM (2).
- 6) Remove SDM (2) from vehicle.



I4RS0A820056-01

A: Forward

Installation

- 1) Check that none of the following faulty conditions exists.
 - Bend, scratch, deformity in vehicle body where SDM is mounted.
 - Foreign matter or rust on mating surface of vehicle body where SDM is mounted.
- 2) Install SDM (2) to vehicle.

⚠ CAUTION


Ensure that arrow on the SDM is pointing toward the front of the vehicle.

- 3) Tighten SDM bolts (1) to specified torque.

Tightening torque

SDM bolt (a): 9 N·m (0.9 kgf-m, 6.5 lb-ft)


- 4) Connect SDM connector (2) to SDM (3) securely.



I4RS0A820107-01

A: Forward

- 5) Install G sensor bracket (1) to floor panel.



I5RW0A820064-01

2. SDM

- 6) Install G sensor referring to "G Sensor Removal and Installation (4WD Model) in Section 4E".
- 7) Install console box upper cover.
- 8) Enable air bag system referring to "Enabling Air Bag System".
- 9) Connect negative (–) cable at battery.

SDM Inspection

S7RW0C8206004

⚠ WARNING

During service procedures, be very careful when handling a Sensing and Diagnostic Module (SDM).

Be sure to read "Precautions on Service and Diagnosis of Air Bag System" before starting to work and observe every precaution during work. Neglecting them may result in personal injury or inactivation of the air bag system when necessary.

⚠ CAUTION

- Do not connect a tester whatever type it may be.
- Never repair or disassemble SDM.
- If SDM has been dropped, it should be replaced.

If any faulty condition is found in the following checks, replace.

- Check SDM and SDM plate for dents, cracks or deformation.
- Check SDM connector for damage, cracks or lock mechanism.
- Check SDM terminal for bend, corrosion or rust.

Driver Air Bag (Inflator) Module Removal and Installation


S7RW0C8206005

⚠ WARNING

When handling an air bag (inflator) module, be sure to read "Precautions on Handling and Storage of Air Bag System Components" and observe each instruction. Failure to follow them could cause a damage to the air bag (inflator) module or result in personal injury.


Removal

- 1) Disconnect negative (–) cable at battery.
- 2) Disable air bag system. Refer to "Disabling Air Bag System".
- 3) Loosen driver air bag (inflator) module mounting bolts (1) till it turns freely, pull them out and fix them to bolt clamps.



I3JA01820031-01

- 4) Remove air bag (inflator) module from steering wheel.
- 5) Disconnect driver air bag (inflator) module connector (1) of driver air bag (inflator) module and horn connector (2) (if equipped) as shown in figure.
 - a) Unlock lock button (3).
 - b) With lock button unlocked, disconnect connector.




I5RW0A820065-01

⚠ WARNING

Special care is necessary when handling and storing a live (undeployed) air bag (inflator) module. Observe "Precautions on Handling and Storage of Air Bag System Components". Otherwise, personal injury may result.

Installation

- 1) Connect horn connector (1) securely (if equipped).
- 2) Connect driver air bag (inflator) module connector (2) to driver air bag (inflator) module (3) securely as shown in figure.
 - a) Connect connector.
 - b) Lock connector with lock button.




I5RW0A820066-01

- 3) Install driver air bag (inflator) module (1) to steering wheel (2), taking care so that no part of wire harness is caught between them.
- 4) Make sure that clearance between module (1) and steering wheel (2) is uniform all the way.
- 5) Tighten driver air bag (inflator) module mounting bolt (left side) (3) to specified torque first and then driver air bag (inflator) module mounting bolt (right side) (4) to specified torque.

Tightening torque

Driver air bag (inflator) module mounting bolt (a): 9 N·m (0.9 kgf-m, 6.5 lb-ft)



I5RH01820103-01

- 6) Enable air bag system. Refer to "Enabling Air Bag System".
- 7) Connect negative (–) cable at battery.

Driver Air Bag (Inflator) Module Inspection

S7RW0C8206006

⚠ WARNING


Never disassemble air bag (inflator) module or measure its resistance. Otherwise, personal injury may result.

⚠ CAUTION

If air bag (inflator) module was dropped from a height of 90 cm (3 ft) or more, it should be replaced.

Check air bag (inflator) module visually and if any of the following is found, replace it with a new one.

- Air bag being deployed
- Trim cover (pad surface) (1) being cracked
- Inflator case (2) being damaged or having been exposed to strong impact (dropped)
- Bend or deformity of air bag (inflator) module bracket.



I5RW0A820067-01

Passenger Air Bag (Inflator) Module Removal and Installation


S7RW0C8206007

⚠ WARNING

- **Never attempt to disassemble or repair the passenger air bag (inflator) module. If any abnormality is found, be sure to replace it with new one as an assembly.**
- **Be sure to read "Precautions on Service and Diagnosis of Air Bag System", "Precautions on Handling and Storage of Air Bag System Components" and "Precautions on Disposal of Air Bag and Seat Belt Pretensioner" before starting to work and observe every precaution during work. Neglecting them may result in personal injury or undeployment of the air bag when necessary.**


Removal

- 1) Disable air bag system. Refer to "Disabling Air Bag System".
- 2) Remove center ventilation louver with garnish referring to "Center Ventilation Louver Removal and Installation in Section 7A".
- 3) Pull out glove box while pushing its stopper from both right and left sides.
- 4) Remove passenger air bag (inflator) module attaching bolts (1) and its facing cover bolt (6).
- 5) Hold up passenger air bag (inflator) module with its facing cover (5) without extending wire harness (2) to avoid air bag connector damage and to disconnect passenger air bag (inflator) module connector (3) as shown in figure.
 - a) Unlock lock button (4).
 - b) With lock button unlocked, disconnect connector.
- 6) Remove passenger air bag (inflator) module with its facing cover (5) from instrument panel.



I7RW01821033-01

- 7) Remove passenger air bag (inflator) module (1) from its facing cover (2).



I5RW0A820069-01

⚠ WARNING


- When carrying a live air bag (inflator) module, make sure the bag opening is pointed away from you. Never carry air bag (inflator) module by wires or connector on the side of the module. In case of an accidental deployment, the bag will then deploy with minimal chance of injury.
- The live passenger air bag (inflator) module must be kept with its bag (trim cover) facing up while being stored or left standing. This is necessary so that a free space is provided to allow the air bag to expand in the unlikely event of accidental deployment.
- Observe "Precautions on Handling and Storage of Air Bag System Components" for handling and storing it. Otherwise, personal injury may result.

Installation

- 1) Install passenger air bag (inflator) module to its facing cover (2).

⚠ CAUTION

Confirm claw (1) of passenger air bag (inflator) module hangs in its facing cover (2).




I5RW0A820070-01

- 2) Connect passenger air bag (inflator) module connector (1) securely as shown in figure.
 - a) Connect connector.
 - b) Lock connector with lock button (2).
- 3) Install passenger air bag (inflator) module with its facing cover (3) to instrument panel at specified torque as shown.

Tightening torque

Passenger air bag (inflator) module attaching bolt (a): 23 N·m (2.3 kgf-m, 17.0 lb-ft)



I7RW01821034-01


- 4) Install glove box.
- 5) Install center ventilation louver with garnish referring to "Center Ventilation Louver Removal and Installation in Section 7A".
- 6) Enable air bag system. Refer to "Enabling Air Bag System".

Passenger Air Bag (Inflator) Module Inspection

S7RW0C8206008

⚠ WARNING

- Never measure resistance of passenger air bag (inflator) module or disassemble it. Otherwise personal injury may result.
- Never attempt to disassemble or repair the passenger air bag (inflator) module. If any abnormality is found, be sure to replace it with new one as an assembly.
- Be sure to read "Precautions on Service and Diagnosis of Air Bag System", "Precautions on Handling and Storage of Air Bag System Components" and "Precautions on Disposal of Air Bag and Seat Belt Pretensioner" before starting to work and observe every precaution during work. Neglecting them may result in personal injury or undeployment of the air bag when necessary.



I5RW0A820072-03

⚠ CAUTION

If air bag (Inflator) module was dropped from a height of 90 cm (3 ft) or more, it should be replaced.

Check air bag (inflator) module appearance visually for the following symptoms and if any one of them is found, replace with a new one.


- Air bag has deployed.
- Wire harness or connector is damaged.
- Air bag (inflator) module is damaged or a strong impact was applied to it.
- Bend or deformity of air bag (inflator) module bracket.

Side-Air Bag (Inflator) Module Removal and Installation

S7RW0C8206009

⚠ WARNING

- Never attempt to disassemble or repair the side-air bag (inflator) module. If any abnormality is found, be sure to replace it with new one as an assembly.
- Be sure to read “Precautions on Service and Diagnosis of Air Bag System”, “Precautions on Handling and Storage of Air Bag System Components” and “Precautions on Disposal of Air Bag and Seat Belt Pretensioner” before starting to work and observe every precaution during work. Neglecting them may result in personal injury or undeployment of the air bag when necessary.




I7RW01822144-01

1. Side-air bag (inflator) module	6. Sleeve
2. Seat back frame bracket	7. Sleeve lock nut
3. Side-air bag (inflator) module connector	8. Fastener
4. Seat back	(a) : 2.5 N·m (0.25 kgf-m, 2.0 lb-ft)
5. Air bag harness in floor harness	: Do not reuse.

Removal


- 1) Disable air bag system. Refer to “Disabling Air Bag System”.
- 2) Loosen seat back surface fastener (1) and roll up backside of seat back surface.



I7RW01822145-01


2. Seat back

- 3) Remove sleeve lock nut (1) from side-air bag (inflator) module (2).



I7RW01822146-01

- 4) Remove side-air bag (inflator) module from seat back.
- 5) Disconnect side-air bag (inflator) module connector (1) as shown in the figure.
 - a) Unlock lock button (2).
 - b) With lock button unlocked, disconnect connector.




I4RS0A820068-01

⚠ WARNING


- When carrying a live air bag (inflator) module, make sure the bag opening is pointed away from you. Never carry air bag (inflator) module by wires or connector on the side of the module. In case of an accidental deployment, the bag will then deploy with minimal chance of injury.
- As the live side-air bag (inflator) module must be kept with its bag (trim cover) facing up while being stored or left standing. This is necessary so that a free space is provided to allow the air bag to expand in the unlikely event of accidental deployment.
- Observe “Precautions on Handling and Storage of Air Bag System Components” for handling and storing it. Otherwise, personal injury may result.

6) Remove fastener (1) with sleeve (2) from seat back.



Installation


1) Install new fastener (1) to seat back.



2) Install new sleeve (1) and sleeve lock nut (2) to side-air bag (inflator) module, then tighten nut to specified torque.


Tightening torque

Sleeve lock nut (a): 2.5 N·m (0.25 kgf-m, 2.0 lb-ft)




3) Connect side-air bag (inflator) module connector (1) securely as shown in the figure.

- Connect connector.
- Lock connector with lock button (2).



4) Insert claw (1) of side-air bag (inflator) module on installation hole (2).

5) Install side-air bag (inflator) module by pushing it into fastener (3) securely.




6) Roll down backside seat back surface and fix seat back surface fastener securely.

Side-Air Bag (Inflator) Inspection

S7RW0C8206010

⚠ WARNING

- Never attempt to disassemble or repair the side-air bag (inflator) module. If any abnormality is found, be sure to replace it with new one as an assembly.
- Be sure to read “Precautions on Service and Diagnosis of Air Bag System” before starting to work and observe every precaution during work. Neglecting them may result in personal injury or undeployment of the air bag when necessary.

**⚠ CAUTION**

If air bag (inflator) module was dropped from a height of 90 cm (3 ft) or more, it should be replaced.

Check air bag (inflator) module appearance visually for the following symptoms and if any one of them is found, replace with a new one.

- Air bag has deployed.
- There is a crack in trim cover (pad surface).
- Wire harness or connector is damaged.
- Air bag (inflator) module is damaged or a strong impact was applied to it.
- Bend or deformity of air bag (inflator) module bracket.

Side Curtain-Air Bag (Inflator) Module Removal and Installation


S7RW0C8206011

⚠ WARNING

- Never attempt to disassemble or repair the side curtain-air bag (inflator) module. If any abnormality is found, be sure to replace it with new one as an assembly.
- Be sure to read “Precautions on Service and Diagnosis of Air Bag System”, “Precautions on Handling and Storage of Air Bag System Components” and “Precautions on Disposal of Air Bag and Seat Belt Pretensioner” before starting to work and observe every precaution during work. Neglecting them may result in personal injury or undeployment of the air bag when necessary.

Removal

- 1) Disable air bag system. Refer to “Disabling Air Bag System”.
- 2) Remove head lining referring to “Head Lining Removal and Installation in Section 9H”.
- 3) Disconnect side curtain-air bag (inflator) module connector (1) as shown in figure.
 - a) Unlock lock button (2).
 - b) With lock button unlocked, disconnect connector.




I6RW0B820021-01

[A]: Hatchback model

[B]: Sedan model

8B-103 Air Bag System:

- 4) Remove side curtain-air bag (inflator) module fixing bolts (1) and clips (2).



I6RW0B820022-01

[A]: Hatchback model

[B]: Sedan model

- 5) Remove side curtain-air bag (inflator) module.

⚠ WARNING

- When carrying a live air bag (inflator) module, make sure the bag opening is pointed away from you. Never carry air bag (inflator) module by wires or connector on the side of the module. In case of an accidental deployment, the bag will then deploy with minimal chance of injury.
- As the live curtain air bag (inflator) module must be kept with its bag facing up while being stored or left standing. This is necessary so that a free space is provided to allow the air bag to expand in the unlikely event of accidental deployment.
- Observe "Precautions on Handling and Storage of Air Bag System Components" for handling and storing it. Otherwise, personal injury may result.

Installation

⚠ WARNING

Do not install side curtain-air bag (inflator) module while twisted or bent. Otherwise, side curtain-air bag (inflator) module may not deploy and injury may result.


- 1) Install side curtain-air bag (inflator) module (1) with clips (2) and new bolts (3).
- 2) Tighten side curtain-air bag (inflator) module attaching bolts (4) to specified torque.

NOTE

Confirm not to move clip (2) after tightening bolt.

Tightening torque

Side curtain-air bag (inflator) module attaching bolts (a): 11 N·m (1.1 kgf·m, 8.0 lb-ft)




I7RW0A820005-01

[A]: Hatchback model


[B]: Sedan model

- 3) Connect side curtain-air bag (inflator) module connector (1) securely as shown in figure.
 - a) Connect connector.
 - b) Lock connector with lock button (2).

[A]



[B]



I6RW0B820024-01

[A]: Hatchback model

[B]: Sedan model


- 4) Install head lining referring to "Head Lining Removal and Installation in Section 9H".
- 5) Enable air bag system. Refer to "Enabling Air Bag System".

Side Curtain-Air Bag (Inflator) Module Inspection

S7RW0C8206012

⚠ WARNING

- Never measure resistance of side curtain-air bag (inflator) module or disassemble it. Otherwise personal injury may result.
- Never attempt to disassemble or repair the side curtain-air bag (inflator) module. If any abnormality is found, be sure to replace it with new one as an assembly.
- Be sure to read "Precautions on Service and Diagnosis of Air Bag System", "Precautions on Handling and Storage of Air Bag System Components" and "Precautions on Disposal of Air Bag and Seat Belt Pretensioner" before starting to work and observe every precaution during work. Neglecting them may result in personal injury or undeployment of the air bag when necessary.



I5JB0A820089-02

⚠ CAUTION

If air bag (inflator) module was dropped from a height of 90 cm (3 ft) or more, it should be replaced.

Check air bag (inflator) module appearance visually for the following symptoms and if any one of them is found, replace with a new one.

- Air bag has deployed.
- Inflator case being damaged or having been exposed to strong impact (dropped).

Forward Impact-Sensor Removal and Installation

S7RW0C8206013


⚠ WARNING

During service procedures, be very careful when handling a sensor.

- Never strike or jar a sensor.
- A sensor and mounting bracket bolts must be carefully torqued to assure proper operation. Under loose connection, it could cause improper operation of the air bag system.

Removal

- 1) Disconnect negative (–) cable at battery.
- 2) Disable air bag system referring to “Disabling Air Bag System”.
- 3) Remove front bumper referring to “Front Bumper and Rear Bumper Components in Section 9K”.
- 4) Disconnect forward impact-sensor connector (1) sliding connector outer (2) as shown.
- 5) Remove forward impact-sensor bolt (3) and forward impact-sensor (4) from apron-side-member (driver side) (5).



Installation

⚠ CAUTION


Proper operation of forward impact-sensor requires sensor be rigidly attached to vehicle structure and that the arrow on sensor be pointing toward the front of the vehicle.

- 1) Check that none of the following faulty conditions exists.
 - Bend, deformity or rust of front panel.
 - Foreign matter on mating surface of sensor.
- 2) Install forward impact-sensor (1) to apron-side-member (driver side) (3) and tighten mounting bolt (2) to specified torque.

Tightening torque

Forward impact-sensor mounting bolt (a): 9 N·m (0.9 kgf-m, 6.5 lb-ft)

- 3) Connect forward impact-sensor connector (4) by pushing connector till click is heard from it.



- 4) Install front bumper referring to “Front Bumper and Rear Bumper Components in Section 9K”.
- 5) Enable air bag system referring to “Enabling Air Bag System”.
- 6) Connect negative (–) cable at battery.

Forward Impact-Sensor Inspection

S7RW0C8206014

⚠ WARNING

During service procedures, be very careful when handling a sensor.

- Never strike or jar a sensor.
- A sensor and mounting bracket bolts must be carefully torqued to assure proper operation. Under loose connection, it could cause improper operation of the air bag system.

⚠ CAUTION

- Never disassemble forward impact-sensor.
- Sensor should be replaced when it was dropped from a height of 90 cm (3 ft) or more.

- Check sensor for dents, cracks or deformation.
- Check sensor connector (sensor side and harness side) and sensor connector lock mechanism for damage or crack.
- Check connector terminals for bend, corrosion or rust.

Side Impact-Sensor Removal and Installation

S7RW0C8206015


⚠ WARNING

During service procedures, be very careful when handling a sensor.

- Never strike or jar a sensor.
- A sensor bolt must be carefully torqued to assure proper operation. Under loose connection, it could cause improper operation of the air bag system.

Removal

- 1) Disconnect negative (–) cable at battery.
- 2) Disable air bag system. Refer to “Disabling Air Bag System”.
- 3) Remove center pillar lower trim.
- 4) Turn up floor carpet at front seat side.
- 5) Disconnect side impact-sensor connector (1) sliding connector outer (2) as shown.
- 6) Remove side impact-sensor bolts (3), and side impact-sensor (4) from side sill inner panel (5).



I7RW01822149-01

Installation

⚠ CAUTION

Proper operation of side impact-sensor requires that sensor is rigidly attached to specified position.


- 1) Check that none of following faulty conditions exists.
 - Bend, deformity or rust of under body.
 - Foreign matter on mating surface of sensor.

- 2) Install side impact-sensor (1) to side sill inner panel (2) and tighten side impact-sensor bolt (3) to specified torque.

Tightening torque

Side impact-sensor bolt (a): 9 N·m (0.9 kgf-m, 6.5 lb-ft)

- 3) Connect side impact-sensor connector (4) by pushing connector till click is heard from it.



I7RW01822150-01

- 4) Return the carpet, and install center pillar lower trim.
- 5) Enable air bag system. Refer to “Enabling Air Bag System”.
- 6) Connect negative (–) cable at battery.

Side Impact-Sensor Inspection

S7RW0C8206016

⚠ WARNING

During service procedures, be very careful when handling a sensor.

- Never strike or jar a sensor.
- A sensor and mounting bracket bolts must be carefully torqued to assure proper operation. Under loose connection, it could cause improper operation of the air bag system.

⚠ CAUTION



- Never disassemble side impact-sensor.
- Sensor should be replaced when it was dropped from a height of 90 cm (3 ft) or more.

- Check sensor for dents, crack, deformation.
- Check sensor connector (sensor side and harness side), lock mechanism or sensor lead wire for damage, crack, scorching or melting.
- Check connector terminals for bent, corrosion or rust. If any faulty condition is found in above checks, replace.

Passenger Air Bag (Inflator) Module Repair
 Harness Installation

S7RW0C8206017


Replace passenger air bag (inflator) module repair harness (2) according to the following procedure when the harness (9) connected with passenger air bag (inflator) module of the air bag harness included in instrument panel harness (7) and passenger air bag (inflator) module connector (1) is damaged.



I5RW0C820001-01



3.	Driver air bag (inflator) module
4.	Passenger air bag (inflator) module
5.	Floor harness
6.	Vinyl tape
7.	Instrument panel harness
8.	Floor harness joint (yellow) connector with passenger air bag (inflator) module of air bag harness included in instrument panel harness
10.	Floor harness joint (yellow) connector of passenger air bag (inflator) module repair harness

- 1) Disable air bag system. Refer to “Disabling Air Bag System”.
- 2) Remove passenger air bag (inflator) module referring to “Passenger Air Bag (Inflator) Module Removal and Installation” if it has installed.
- 3) Disconnect floor harness joint (yellow) connector (1) with passenger air bag (inflator) module of air bag harness included in instrument panel harness from floor harness located near the glove box.



I5RW0C820002-01

- 4) Cut off passenger air bag (inflator) module connector (1) and floor harness joint (yellow) connector (2) with passenger air bag (inflator) module of air bag harness included in instrument panel harness as shown, and then fasten it to instrument panel harness with vinyl tape for avoiding interference with other parts.




I5RW0C820003-01

- 5) Fix passenger air bag (inflator) module repair harness (1) to instrument panel harness (2).

⚠ CAUTION

To avoid interference with other parts, fasten the repair harness to instrument panel harness with a clamp (3) as shown in figure.

- 6) Connect passenger air bag (inflator) module repair harness connector (4) to floor harness securely till click is heard.



I5RW0C820004-01

[A]: Viewed from dash panel side

- 7) Install passenger air bag (inflator) module referring to "Passenger Air Bag (Inflator) Module Removal and Installation".
- 8) Enabling air bag system referring to "Enabling Air Bag System".
- 9) Confirm that there is no DTC detected to SDM with ignition switch turned ON.

Air Bag (Inflator) Module and Seat Belt Pretensioner Disposal

S7RW0C8206018

⚠ WARNING

Failure to follow proper air bag (inflator) module and seat belt pretensioner disposal procedures can result in air bag deployment and pretensioner activation which may cause personal injury. Do not dispose of live (undeployed) air bag (inflator) modules and seat belt pretensioners. Because undeployed air bag (inflator) module / inactivated seat belt pretensioner must not be disposed of through normal refuse channels. Undeployed air bag (inflator) module and inactivated seat belt pretensioner contain substances that can cause severe illness or personal injury if sealed container is damaged during disposal.

Air bag (inflator) module / seat belt pretensioner can be deployed / activated inside or outside of vehicle. Deployment / Activation method used depends upon final disposition of vehicle. Review the following instructions in order to determine which will work best in a given situation.

Deployment / Activation Outside of Vehicle: When you intend to return the vehicle to service, deploy the air bag (inflator) module(s) and/or activate seat belt pretensioner(s) outside of the vehicle.

Deployment / Activation Inside of Vehicle: When the vehicle will be destroyed, or salvaged for component parts, deploy the air bag module(s) and/or activate seat belt pretensioner(s) installed on vehicle.

⚠ WARNING

The following precautions must be observed for this work. Failure to observe any of them may result in personal injury.

- Procedure should be followed strictly as described here.
- Be sure to read "Precautions on Service and Diagnosis of Air Bag System" beforehand.
- To avoid accidental deployment / activation, this work should be performed by no more than one person.
- Since smoke is produced when air bag (inflator) module is deployed and pretensioner is activated, select well-ventilated area.
- Air bag (inflator) module and seat belt pretensioner will immediately deploy / activate when 12 volts vehicle battery is connected to it. Wear safety glasses throughout this entire deployment / activation and disposal procedure.
- Wear suitable ear protection when deploying air bag (inflator) module / activating seat belt pretensioner. Also, advise those who are in area close to deployment / activation site to wear suitable ear protection.
- Do not deploy / activate two or more air bag system components (air bag (inflator) modules and seat belt pretensioners) at the same time.
- Never connect deployment harness to any 12 volts vehicle battery before connecting deployment harness to air bag (inflator) module and seat belt pretensioner. Deployment harness shall remain shorted and not be connected to 12 volts vehicle battery till you are ready to deploy air bag (inflator) module or activate seat belt pretensioner.

Deployment / Activation Outside of Vehicle

When you intend to return the vehicle to service, deploy the air bag (inflator) module(s) or activate seat belt pretensioner(s) outside of the vehicle.

- 1) Turn ignition switch to LOCK position and remove key.
- 2) Wear safety glasses during this deployment / activation procedure.
- 3) Check that there is no open, short or damage in special tools (deployment harness (A) and adapter cable (B)). If any faulty is found, do not use it and be sure to use new special tool.

Special tool


(A): 09932-75031

(B): 09932-76510

- 4) Short two deployment harness leads (1) together by fully seating one banana plug into the other.

⚠ WARNING

Deployment harness (A) shall remain shorted and not be connected to 12 volts vehicle battery till you are ready to deploy air bag module or activate seat belt pretensioner.



I4RS0A820084-01


- 5) Remove air bag (inflator) module(s) or seat belt pretensioner(s) from vehicle referring to "Driver Air Bag (Inflator) Module Removal and Installation", "Passenger Air Bag (Inflator) Module Removal and Installation", "Side-Air Bag (Inflator) Module Removal and Installation", "Side Curtain-Air Bag (Inflator) Module Removal and Installation" or "Front Seat Belt Removal and Installation in Section 8A".

⚠ WARNING


- For handling and storage of live air bag (inflator) module, select place where ambient temperature below 65 °C (150 °F), without high humidity and away from electric noise.
- Always carry live air bag (inflator) module with trim cover away from you.
- When storing live air bag (inflator) module or when leaving live air bag (inflator) module unattended on bench or other surface, always face trim cover up and away from surface. It is also prohibited to place anything on top of the trim cover and stack air bag (inflator) modules. This is necessary so that free space is provided to allow air bag (inflator) module to expand in the unlikely event of accidental deployment.

Failure to follow procedures may result in personal injury.

[A]



[B]



I5RW0A820084-03


[A]: Always carry air bag (inflator) module with trim cover (air bag opening) away from body.

[B]: Always place air bag (inflator) module on workbench with trim cover (air bag opening) up, away from loose objects.

⚠ WARNING

- For handling and storage of seat belt pretensioner, select place where ambient temperature is below 65 °C (150 °F), without high humidity and away from electric noise.
- Never carry seat belt pretensioner by webbing.
- When placing seat belt pretensioner on workbench or other surface, be sure to lay it with its exhaust hole (1) side facing up. It is also prohibited to put something on seat belt pretensioner.


Otherwise, personal injury may result.



I4JA01822118-01

6) Set air bag (inflator) module or seat belt pretensioner as follows.

- For driver air bag (inflator) module
 - a. Clear space (3) on ground about 185 cm (6 ft) in diameter where driver air bag (inflator) module (1) is set for deployment. Paved, outdoor location where there is no activity is preferred. If outdoor location is not available, use space on shop floor where there is no activity and sufficient ventilation is provided. Ensure no loose or flammable object exists within deployment area.
 - b. Place driver air bag (inflator) module (1) with its vinyl trim cover facing up (2) on ground in Step a.



I3JA01820036-01

- For passenger air bag (inflator) module
 - a. Clear space (3) on ground about 185 cm (6 ft) in diameter where passenger air bag (inflator) module (1) is set for deployment. Paved, outdoor location where there is no activity is preferred. If outdoor location is not available, use space on shop floor where there is no activity and sufficient ventilation is provided. Ensure no loose or flammable object exists within deployment area.
 - b. Place deployment fixture (A) on ground in Step a.


Special tool

(A): 09932-75041

- c. Fill plastic reservoir in deployment fixture (A) with water or sand. This is necessary to provide sufficient stabilization of fixture during deployment.
- d. Attach passenger air bag (inflator) module (1) in deployment fixture (A) securely using M8 bolt (2).


⚠ CAUTION

Be sure to use M8 size and 7T strength bolt for fixing passenger air bag (inflator) module (1) to deployment fixture (A).



I5RW0A820085-02

- For side-air bag (inflator) module
 - a. Remove sleeve (1) and sleeve lock nut (2), if equipped.



I4RS0A820088-01

- b. Clear space (3) on ground about 185 cm (6 ft) in diameter where side-air bag (inflator) module for deployment. Paved, outdoor location where there is no activity is preferred. If outdoor location is not available, space on shop floor where there is no activity and provide sufficient ventilation. Ensure no loose or flammable objects are within deployment area.
- c. Place deployment fixture (A) on ground.


Special tool

(A): 09932-75041

- d. Fill plastic reservoir in deployment fixture (A) with water or sand. This is necessary to provide sufficient stabilization of fixture during deployment.
- e. Attach side-air bag (inflator) module (1) in deployment fixture using mounting attachment, sleeve lock nut and washer (2).


NOTE

Make sure that deploying direction faces as shown in the figure against mounting attachment.



I4RS0A820089-01

- For side curtain-air bag (inflator) module
 - a. Cut off bag (1) of side curtain-air bag (inflator) module.



I5RW0A820086-01

- b. Tie side curtain-air bag inflator (1) to tire (3) with wire harness (2) as shown.

Wire harness specifications

Stripped wire harness section 1.25 mm² (0.0019 in.²) or more (Stripped wire harness diameter 1.25 mm (0.05 in.) or more)


⚠ CAUTION

Make sure that wire harness is tight. It is very dangerous if looseness in wire harness results in side curtain-air bag inflator flying off due to shock from inflator deploying.

NOTE

Wind wire harness (2) around at least 3 times.

- c. Clear space (5) on ground about 185 cm (6 ft) in diameter where side curtain-air bag (inflator) module (1) is set for deployment. Paved, outdoor location where there is no activity is preferred. If outdoor location is not available, use space on shop floor where there is no activity and sufficient ventilation is provided. Ensure no loose or flammable object exists within activation area.
- d. Pile tire with side curtain-air bag (inflator) module on tire (4).




I5JB0A820101-01

- For seat belt pretensioner
 - a. Cut webbing (1) at tongue plate stopper (3) of seat belt pretensioner (2) side as shown.


NOTE

Hold seat belt pretensioner (2) vertically in the same condition as it is installed. Otherwise, webbing can't be pulled out.

- b. Remove tongue plate (4) and shoulder anchor (5) from webbing.
- c. Tie webbing (1) tightly at 10 cm (3.9 in.) from cutting edge as shown.



I3JA01820037-01



I4RS0A820104-01

- d. Tie seat belt pretensioner (2) with wire harness (3) to wheel-installed tire (4) as shown.


Wire harness specifications

Stripped wire harness section 1.25 mm² (0.0019 in.²) or more (Stripped wire harness diameter 1.25 mm (0.05 in.) or more)

NOTE

Wind wire harness (3) around at least 3 times.

- e. Clear space (5) on ground about 185 cm (6 ft) in diameter where seat belt pretensioner (2) is to be activated. Paved, outdoor location where there is no activity is preferred. If outdoor location is not available, use space on shop floor where there is no activity and sufficient ventilation is provided. Ensure no loose or flammable object exists within activation area.
- f. Place wheel-installed tire (4) with seat belt pretensioner (2) on ground in Step e.



I4RS0A820105-01

1. Webbing

- 7) Stretch deployment harness (A) from air bag (inflator) module or seat belt pretensioner to its full length 10 m (33 ft).

Special tool

(A): 09932-75031

- 8) Place 12 volts vehicle battery (1) near the shorted end of deployment harness (A).
- 9) Check that area around air bag (inflator) module or seat belt pretensioner is clear of all people and loose or flammable objects.

10) Connect adapter cable (B) as follows.

Special tool

(B): 09932-76510

- For driver air bag (inflator) module [A]:
Check that driver air bag (inflator) module is placed with its vinyl trim cover facing up, and connect adapter cable (B) to driver air bag (inflator) module.
- For passenger air bag (inflator) module [B]:
Check that passenger air bag (inflator) module is firmly and properly secured on deployment fixture (special tool), and connect adapter cable (B) to passenger air bag (inflator) module.

NOTE

Wind wire harness (5) around at least 2 times.

- For side-air bag (inflator) module [C]:
Verify that side-air bag (inflator) module is firmly and properly on deployment fixture (special tool), and connect adapter cable (B) to side-air bag (inflator) module.
- For side curtain-air bag (inflator) module [D]:
 - Connect adapter cable (B) to side curtain-air bag (inflator) module.
 - Pile 2 tires (2) and wheel-installed tire (3) on top of tire with side curtain-air bag (inflator) (4), and tie them with wire harness (5) as shown.

Wire harness specifications

Stripped wire harness section 1.25 mm² (0.0019 in.²) or more (Stripped wire harness diameter 1.25 mm (0.05 in.) or more)

NOTE

Wind wire harness (5) around at least 2 times.

- For seat belt pretensioner [E]:
 - Connect adapter cable (B) to seat belt pretensioner.
 - Pile 2 wheel-installed tires (3) on top of tire with seat belt pretensioner (6), and tie them with wire harness (5) as shown.

Wire harness specifications


Stripped wire harness section 1.25 mm² (0.0019 in.²) or more (Stripped wire harness diameter 1.25 mm (0.05 in.) or more)

NOTE

Wind wire harness (5) around at least 2 times.

- Drape blanket (7) over those tires.

11) Connect adapter cable (B) to deployment harness (A) connector and lock connectors with lock lever.



- 12) Notify all people in immediate area that you intend to deploy / activate air bag (inflator) module or seat belt pretensioner.

NOTE


- When air bag (inflator) module deploys and seat belt pretensioner activates, rapid gas expansion will create substantial report. Wear suitable ear protection. Notify all people in immediate area that you intend to deploy air bag (inflator) module or activate seat belt pretensioner and suitable ear protection should be worn.
- When driver air bag (inflator) module deploys, driver air bag (inflator) module may jump about 30 cm (1 ft) vertically. This is normal reaction to force of rapid gas expansion inside of driver air bag (inflator) module.
- After air bag (inflator) module has been deployed, surface of air bag (inflator) may contain powdery residue. This powder consists primarily of cornstarch (used to lubricate bag (inflator) as it inflates) and by products of chemical reaction.

⚠ WARNING

- Do not place deployed air bag (inflator) module and activated seat belt pretensioner near any flammable objects.
- Do not apply water, oil, etc. to deployed air bag (inflator) module and activated seat belt pretensioner.
- Wait for about 30 minutes before touching any metal surface of air bag (inflator) module or seat belt pretensioner module. Disregarding these precautions may cause fire or personal injury.


Failure to follow procedures may result in fire or personal injury.

- 13) Separate two banana plugs (1) on deployment harness.
- 14) Connect deployment harness to 12 volts vehicle battery (2). This will immediately deploy or activate air bag (inflator) module or seat belt pretensioner.
- 15) Disconnect deployment harness from 12 volts vehicle battery (2) and short two deployment harness leads together by fully seating one banana plug into the other.



I2RH01820069-01

- 16) In the unlikely event that air bag (inflator) module or seat belt pretensioner did not deploy / activate after following these procedures, proceed immediately with Step 22) through 25). If air bag (inflator) module or seat belt pretensioner did deploy or activate, proceed with Steps 18) through 21).
- 17) Put on pair of shop gloves to protect your hands from possible irritation and heat when handling deployed air bag (inflator) module or activated seat belt pretensioner.
- 18) Disconnect adapter cable (special tool) from air bag (inflator) module or seat belt pretensioner as soon as possible. This will prevent adapter cable (special tool) from damage due to possible contact with hot air bag (inflator) module or hot seat belt pretensioner.
- 19) Check adapter cable as follows.
- For air bag (inflator) module
Be sure to check air bag (inflator) module adapter cable (special tool) for damage after deployment and replace it with new adapter cable (special tool), if it is damaged.
 - For seat belt pretensioner
Be sure to check seat belt pretensioner adapter cable (special tool) for damage after seat belt pretensioner is activated. Replace it with spare connector (special tool) or new adapter, if necessary.
- 20) Dispose of deployed air bag (inflator) module (1) or activated seat belt pretensioner (2) through normal refuse channels after it has cooled for at least 30 minutes and tightly seal air bag (inflator) module (1) or seat belt pretensioner (2) in strong vinyl bag. Refer to "Deployed Air Bag (Inflator) Module and Activated Seat Belt Pretensioner Disposal" for details.



I3JA01820116-01

- 21) Wash your hands with mild soap and water afterward.

NOTE

Remaining steps are to be followed in the unlikely event that air bag (inflator) module did not deploy or seat belt pretensioner did not activate.

- 22) Ensure that deployment harness has been disconnected from 12 volts vehicle battery and that its two banana plugs have been shorted together by fully seating one banana plug into the other.
- 23) Disconnect deployment harness and adapter cable from air bag (inflator) module or seat belt pretensioner.
- 24) Temporarily store undeployed air bag (inflator) module referring to "Precautions on Service and Diagnosis of Air Bag System" for details.
- 25) Contact your local distributor for further assistance.

Deployment / Activation Inside of Vehicle


When the vehicle will be destroyed, or salvaged for component parts, deploy the air bag modules and/or activate seat belt pretensioners installed on vehicle.

NOTE

If equipped with the seat belt pretensioners, activate both side of seat belt pretensioners at the same time when using special tool (C).

- 1) Turn ignition switch to LOCK position, remove key and put on safety glasses.
- 2) Remove all loose objects from front seats and instrument panel.
- 3) Disconnect air bag (inflator) module or seat belt pretensioner connector as follows.
 - For driver air bag (inflator) module [A]
Remove driver side front pillar lower trim and disconnect driver air bag (inflator) module connector (1).
 - For passenger air bag (inflator) module [B]
Remove passenger side front pillar lower trim and disconnect passenger air bag (inflator) module connector (2).
 - For side-air bag (inflator) module [C]
Disconnect side-air bag (inflator) module connectors (3) under front seat cushion.
 - For side curtain-air bag (inflator) module (hatchback model) [D]
Remove right-side rear quarter lower trim and disconnect side curtain-air bag (inflator) module connector (4).
 - For side curtain-air bag (inflator) module (sedan model) [E]
Remove rear pillar inner trim and disconnect side curtain-air bag (inflator) module connector (6).

- For seat belt pretensioners (right and left) [F]
Remove both side (driver and passenger side) center pillar lower trim and disconnect seat belt pretensioner connectors (5).
- 4) Confirm that each air bag (inflator) module and/or seat belt pretensioners is securely mounted.



- 5) Check that there is no open, short or damage in special tools (deployment harness (A), adapter cable (B), (C) and (D)). If any faulty condition is found, do not use it and be sure to use new special tool. And connect adapter cable (B), (C) or (D) to deployment harness (A) and lock connectors with lock slider.

Special tool

(A): 09932-75031

(B): 09932-78332

(C): 09932-77310

(D): 09932-76510


- 6) Short two deployment harness leads together by fully seating one banana plug (1) into the other.

⚠ WARNING


Deployment harness (A) shall remain shorted and not be connected to 12 volts vehicle battery until you are ready to deploy air bag (inflator) module or activate seat belt pretensioner.

- 7) Connect adapter cable (B), (C) or (D) in series with deployment harness (A) to air bag (inflator) module or seat belt pretensioner as follows.

- For driver air bag (inflator) module [A]
Connect adapter cable (B) in series with deployment harness (A) and push adapter cable (B) connector to air bag (inflator) module connector till click can be heard.
- For passenger air bag (inflator) module [B]
Connect adapter cable (B) in series with deployment harness (A) and push adapter cable (B) connector to air bag (inflator) module connector till click can be heard.
- For side-air bag (inflator) module [C]
Connect adapter cable (B) in series with deployment harness (A) and push adapter cable (B) connector to side bag (inflator) module connector till click can be heard.
- For side curtain-air bag (inflator) module (hatchback model) [D]
Connect adapter cable (C) in series with deployment harness (A) and push adapter cable (C) connector to air bag (inflator) module connector till click can be heard.
- For side curtain-air bag (inflator) module (sedan model) [E]
Connect adapter cable (D) in series with deployment harness (A) to air bag (inflator) module and lock connect with lock part.
- For seat belt pretensioners [F]
Connect adapter cable (D) in series with deployment harness (A) to seat belt pretensioner and lock connector with lock part.



- 8) Route deployment harness (1) out of vehicle.
- 9) Check that inside of vehicle and area surrounding vehicle are clear of all people and loose or flammable objects.
- 10) Stretch deployment harness (1) to its full length 10 m (33 ft).
- 11) Place 12 volts vehicle battery (2) near shorted end of deployment harness (1).
- 12) Completely cover windshield area and front door window openings with drop cloth, a blanket or any similar item. This reduces possibility of injury due to possible fragmentation of vehicle's glass or interior.



- 13) Notify all people in immediate area that you intend to deploy air bag (inflator) module or activate seat belt pretensioners.

NOTE


- When air bag (inflator) module deploys or seat belt pretensioners activate, rapid gas expansion will create substantial report. Wear suitable ear protection. Notify all people in immediate area that you intend to deploy air bag (inflator) module or to activate seat belt pretensioner and suitable ear protection should be worn.
- After air bag (inflator) module has been deployed, surface of air bag may contain powdery residue. This powder consists primarily of cornstarch (used to lubricate air bag (inflator) module as it inflates) and by-products of chemical reaction.

⚠ WARNING

- Do not place deployed air bag (inflator) module and activated seat belt pretensioners near any flammable objects.
- Do not apply water, oil, etc. to deployed air bag (inflator) module and activated seat belt pretensioners.
- Wait for about 30 minutes before touching any metal surface of air bag (inflator) module or seat belt pretensioner modules. Disregarding these precautions may cause fire or personal injury.

Failure to follow procedures may result in fire or personal injury.

- 14) Separate two banana plugs (1) on deployment harness (2).
- 15) Connect deployment harness (2) to 12 volts vehicle battery (3). This will immediately deploy or activate air bag (inflator) module or seat belt pretensioners.
- 16) Disconnect deployment harness (2) from 12 volts vehicle battery (3) and short two deployment harness leads together by fully seating one banana plug into the other.



- 17) Repeat Steps 3) through 16) to deploy / activate air bag (inflator) modules and seat belt pretensioners which has not been deployed / activated, if any.
- 18) In the unlikely event that air bag (inflator) module and seat belt pretensioners after following these procedures, proceed immediately with Step 24) through 26). If air bag (inflator) module and seat belt pretensioners did deploy / activate, proceed with Steps 19) through 23).
- 19) Carefully remove drop cloth from vehicle and clean off any fragments or discard it entirely.
- 20) Put on pair of shop gloves to protect your hands from possible irritation and heat when handling deployed air bag (inflator) module and activated seat belt pretensioners.

- 21) Disconnect adapter cable (special tool) from air bag (inflator) module or seat belt pretensioner as soon as possible. This will prevent adapter cable (special tool) from damage due to possible contact with hot air bag (inflator) module or hot seat belt pretensioner.
- 22) Check adapter cable connector as follows.
Adapter cable connector (special tool) is designed to be reused. However it should be inspected for damage after deployment and replaced if necessary.
- 23) With air bag (inflator) modules deployed and seat belt pretensioners activated, vehicle may be scrapped in the same manner as non-air bag system / seat belt pretensioner equipped vehicle.

NOTE

Remaining steps are to be followed in the unlikely event that air bag (inflator) module did not deploy or seat belt pretensioner did not activate.

- 24) Remove undeployed air bag (inflator) module(s) and/or inactivated seat belt pretensioner(s) from vehicle. For driver air bag (inflator) module, refer to "Driver Air Bag (Inflator) Module Removal and Installation". For passenger air bag (inflator) module, refer to "Passenger Air Bag (Inflator) Module Removal and Installation". For side air bag (inflator) module, refer to "Side-Air Bag (Inflator) Module Removal and Installation". For side curtain-air bag (inflator) module, refer to "Side Curtain-Air Bag (Inflator) Module Removal and Installation". For seat belt pretensioner, refer to "Front Seat Belt Removal and Installation in Section 8A".
- 25) Temporarily store undeployed air bag (inflator) module referring to "Precautions on Service and Diagnosis of Air Bag System" for details.
- 26) Contact your local distributor for further assistance.

Deployed Air Bag (Inflator) Module and Activated Seat Belt Pretensioner Disposal

S7RW0C8206019


⚠ WARNING

Failure to follow proper air bag (inflator) module and seat belt pretensioner disposal procedures can result in air bag deployment and pretensioner activation which may cause personal injury. The undeployed air bag (inflator) module and the inactivated seat belt pretensioner must not be disposed of through normal refuse channels.

The undeployed air bag (inflator) module and the inactivated seat belt pretensioner contains substances that can cause severe illness or personal injury if the sealed container is damaged during disposal.


Deployed air bag (inflator) module and the activated seat belt pretensioner can be disposed of through normal refuse channels just like any other parts. For their disposal, however, the following points should be noted.

- The air bag (inflator) module and the seat belt pretensioner immediately after deployment / activation is very hot. Wait for 30 minutes to cool it off before handling it.
- Never apply water, oil, etc. to deployed air bag (inflator) module and the activated seat belt pretensioner to cool it off and be careful so that water, oil etc. does not get on the deployed air bag (inflator) module and the activated seat belt pretensioner.



IYSQ01820095-01

- After the air bag (inflator) module has been deployed, the surface of the air bag may contain a powdery residue. This powder consists primarily of cornstarch (used to lubricate the bag as it inflates) and by-products of the chemical reaction. As with many service procedures, you should wear gloves and safety glasses.
- When disposing of the deployed air bag (inflator) module and the activated seat belt pretensioner, be sure to seal it in a vinyl bag.



I3JA01820119-01

- When air bag (inflator) module and seat belt pretensioner have been deployed / activated inside the vehicle which is going to be scrapped, leave them as installed to the vehicle.
- Be sure to wash your hands with mild soap and water after handling them.

Specifications

Tightening Torque Specifications

S7RW0C8207001

Fastening part	Tightening torque			Note
	N·m	kgf-m	lb-ft	
SDM bolt	9	0.9	6.5	☞
Driver air bag (inflator) module mounting bolt	9	0.9	6.5	☞
Passenger air bag (inflator) module attaching bolt	23	2.3	17.0	☞
Sleeve lock nut	2.5	0.25	2.0	☞
Side curtain-air bag (inflator) module attaching bolts	11	1.1	8.0	☞
Forward impact-sensor mounting bolt	9	0.9	6.5	☞
Side impact-sensor bolt	9	0.9	6.5	☞

NOTE

The specified tightening torque is also described in the following.
“Side-Air Bag (Inflator) Module Removal and Installation”

Reference:

For the tightening torque of fastener not specified in this section, refer to “Fasteners Information in Section 0A”.

Special Tools and Equipment

Use of Special Tools

S7RW0C8208001

⚠ WARNING

To avoid deployment when troubleshooting the air bag system, do not use electrical equipment such as a battery powered or AC powered voltmeter, ohmmeter, etc., or any type of electrical equipment other than that specified. Do not use a non-powered probe type tester.


Instructions must be followed carefully, otherwise personal injury may result.

You should be familiar with the tools listed under the heading “Special Tool”. You should be able to measure voltage and resistance. You should be familiar with proper use of a scan tool such as Air Bag Driver / Passenger Load Tool, Connector Test Adapter Kit and the Digital Multimeter.

Special tool


(A): 09932-76010 Connector Test Adapter Kit

This must be used whenever a diagnostic procedure requests checking or probing a terminal. Using the appropriate adapter in the special tool will ensure that no damage to the terminal will occur from the multimeter probe, such as spreading or bending.



I7RW01822127-01

The adapter (1) will also give an idea of whether or not contact tension is sufficient, helping to find an open or intermittent open due to poor terminal contact. An SDM short bar release tool (2) is included in the connector test adapter kit. Inserting it into the SDM connector (3) will release the shorting bar.



I4RS0A820108-01

Special tool

(B): 09932-75010 Air bag driver / passenger load tool


This tool is used as a diagnostic aid and safety device to prevent inadvertent air bag (inflator) module deployment. The load tool has three connectors attached to its case which are electrically functional and serve as resistive load substitutions.

No more than two connectors are used at any time. One of connectors ("STEERING WHEEL") is used to substitute the load of the followings.

- Driver air bag (inflator) module when it is connected at the top of the column to the contact coil assembly.
- Passenger air bag (inflator) module when it is connected to the air bag harness connector in instrument panel harness for passenger air bag (inflator) module.
- Each of driver and passenger seat belt pretensioners when it is connected to air bag harness connector in instrument panel harness for driver and passenger seat belt pretensioners.
- Side-air bag (inflator) module when it is connected to the floor harness connector for side-air bag (inflator) module.
- Side curtain-air bag (inflator) module when it is connected to the floor harness connector for side curtain-air bag (inflator) module.

Another connector ("BASE OF COLUMN") is used to substitute the load of the driver air bag (inflator) module and the contact coil assembly when it is connected at the base of the column to the air bag wire harness. The third connector ("PASSENGER INFLATOR") is not used.

By substituting the resistance of the load tool when called for, a determination can be made as to whether an inflator circuit component is causing system malfunction and which component is causing the malfunction. The load tool should be used only when specifically called for in the diagnostic procedures.



I1JA01820004-01



- | | |
|----|--|
| 1. | Connector for contact coil and driver air bag (inflator) module (Located near the base of the steering column) |
| 2. | Connector for driver, passenger air bag (inflator) module, side-air bag (inflator) module and driver and passenger seat belt pretensioners |
| 3. | Not used |

Special Tool

S7RW0C8208002


09932-75010

Air bag load tool




09932-75031

Air bag deployment harness










09932-75041

Passenger air bag (inflator)
module deployment fixture


09932-76010

Connector test adapter set


This set includes the
following items. 1.Connector test adapter kit
(09932-75020), 2.Connector test adapter &
shorting bar release tool(09932-76020)                   

09932-76510

Deployment adapter cable





09932-77310

Deployment adapter cable
4P


09932-78310

Adapter cable




09932-78332

Deployment adapter cable




09932-78340


Deployment adapter cable



SUZUKI scan tool

—

This kit includes following items. 1. Tech 2, 2. PCMCIA card, 3. DLC cable, 4. SAE 16/19 adapter, 5. Cigarette cable, 6. DLC loop back adapter, 7. Battery power cable, 8. RS232 cable, 9. RS232 adapter, 10. RS232 loop back connector, 11. Storage case, 12.         



Section 9

Body, Cab and Accessories

CONTENTS

Precautions	9-1	
Precautions.....	9-1	
Precautions on Body, Cab and Accessories	9-1	
Precautions for Body Service	9-1	
Fastener Caution for Body Service	9-1	
Wiring Systems.....	9A-1	
Precautions.....	9A-1	
Cautions in Body Electrical System Servicing.....	9A-1	
General Description	9A-1	
Abbreviations	9A-1	
Wire / Connector Color Symbols.....	9A-1	
Symbols and Marks	9A-2	
How to Read Connector Layout Diagram	9A-4	
How to Read Connector Codes and Terminal Nos.....	9A-5	
How to Read Ground Point	9A-8	
How to Read Power Supply Diagram.....	9A-9	
How to Read System Circuit Diagram.....	9A-9	
Connector Layout Diagram	9A-11	
Connector Layout Diagram	9A-11	
Engine Compartment	9A-11	
Instrument Panel	9A-22	
Door, Roof.....	9A-28	
Floor	9A-32	
Rear	9A-41	
Ground Point	9A-43	
Ground (earth) Point	9A-43	
Power Supply Diagram	9A-44	
Power Supply Diagram	9A-44	
Fuses and the Protected Parts	9A-46	
Fuses in Main Fuse Box	9A-46	
Individual Circuit Fuse Box No. 1	9A-47	
Individual Circuit Fuse Box No. 2 (In J/B (Except Taiwan)).....	9A-48	
Individual Circuit Fuse Box No. 2 (In J/B (Taiwan)).....	9A-50	
Individual Circuit Fuse Box No.3 (Sedan)	9A-52	
Junction Block (J/B) Connector / Fuse Layout ..	9A-53	
Junction Block Inner Circuit (Overview (Except Taiwan)).....	9A-54	
Junction Block Inner Circuit (Detail (Except Taiwan))	9A-56	
Junction Block Inner Circuit (Overview (Taiwan)).....	9A-61	
Junction Block Inner Circuit (Detail (Taiwan))...	9A-63	
System Circuit Diagram.....	9A-68	
System Circuit Diagram	9A-68	
A-1 Cranking System Circuit Diagram	9A-70	
A-2 Charging System Circuit Diagram	9A-71	
A-3 Ignition System Circuit Diagram (M15A engine, M16A engine)	9A-72	
A-3 Ignition System Circuit Diagram (J20A engine)	9A-73	
A-4 Cooling System Circuit Diagram (M15A engine, M16A engine)	9A-74	
A-4 Cooling System Circuit Diagram (J20A engine)	9A-75	
A-5 Engine and A/C Control System Circuit Diagram (M15A engine)	9A-76	
A-5 Engine and A/C Control System Circuit Diagram (M16A engine)	9A-80	
A-5 Engine and A/C Control System Circuit Diagram (J20A engine)	9A-84	
A-6 A/T Control System Circuit Diagram.....	9A-88	
A-7 Immobilizer System Circuit Diagram	9A-90	
A-8 Body Control System Circuit Diagram (Except Taiwan)	9A-91	
A-8 Body Control System Circuit Diagram (Taiwan)	9A-95	
A-10 4WD Control System (Except Taiwan)	9A-99	
B-1 Windshield Wiper and Washer Circuit Diagram.....	9A-100	
B-2 Rear Wiper and Washer Circuit Diagram (Except Taiwan)	9A-101	
B-2 Rear Wiper and Washer Circuit Diagram (Taiwan)	9A-102	
B-3 Rear Defogger Circuit Diagram (Hatchback (Except Taiwan)).....	9A-103	
B-3 Rear Defogger Circuit Diagram (Hatchback (Taiwan)).....	9A-104	
B-3 Rear Defogger Circuit Diagram (Sedan) ..	9A-105	
B-4 Power Window Circuit Diagram	9A-106	
B-5 Power Door Lock Circuit Diagram (Except Taiwan)	9A-108	
B-5 Power Door Lock Circuit Diagram (Taiwan)	9A-110	

B-6 Power Mirror Circuit Diagram (Hatchback (Except Taiwan)).....	9A-112	D-7 Brake Light System Circuit Diagram (Hatchback).....	9A-146
B-6 Power Mirror Circuit Diagram (Hatchback (Taiwan)).....	9A-113	D-7 Brake Light System Circuit Diagram (Sedan).....	9A-147
B-6 Power Mirror Circuit Diagram (Sedan (Except Taiwan)).....	9A-114	D-8 Back-Up Light System Circuit Diagram (Hatchback).....	9A-148
B-6 Power Mirror Circuit Diagram (Sedan (Taiwan)).....	9A-115	D-8 Back-Up Light System Circuit Diagram (Sedan).....	9A-149
B-7 Horn Circuit Diagram.....	9A-116	D-9 Headlight Beam Leveling System Circuit Diagram (Manual Leveling).....	9A-150
B-8 Seat Heater Circuit Diagram.....	9A-117	D-10 Rear Fog Light Circuit Diagram (Hatchback).....	9A-151
B-9 Keyless Start System Circuit Diagram.....	9A-118	D-10 Rear Fog Light Circuit Diagram (Sedan).....	9A-152
C-1 Combination Meter Circuit Diagram (Meter).....	9A-119	E-1 Heater System Circuit Diagram.....	9A-153
C-2 Combination Meter Circuit Diagram (Indicator).....	9A-120	E-2 Auto A/C System Circuit Diagram.....	9A-155
C-3 Combination Meter Circuit Diagram (Warning Light).....	9A-121	F-1 Air-Bag System Circuit Diagram (4ch).....	9A-157
D-1 Headlight System Circuit Diagram (Except Taiwan).....	9A-123	F-1 Air-Bag System Circuit Diagram (8ch).....	9A-158
D-1 Headlight System Circuit Diagram (Taiwan).....	9A-125	F-2 Anti-Lock Brake System Circuit Diagram.....	9A-160
D-2 Position, Tail and Licence Plate Light System Circuit Diagram (Hatchback (Except Taiwan)).....	9A-126	F-3 Electronic Stability Program System Circuit Diagram.....	9A-162
D-2 Position, Tail and Licence Plate Light System Circuit Diagram (Sedan (Except Taiwan)).....	9A-127	F-4 Power Steering System Circuit Diagram ..	9A-164
D-2 Position, Tail and Licence Plate Light System Circuit Diagram (Hatchback (Taiwan)).....	9A-128	G-1 Audio System Circuit Diagram.....	9A-166
D-2 Position, Tail and Licence Plate Light System Circuit Diagram (Sedan (Taiwan))....	9A-129	G-2 Multi Information Display / Accessory Socket System Circuit Diagram.....	9A-168
D-3 Front Fog Light System Circuit Diagram (Except Taiwan).....	9A-130	G-4 Navigation System Circuit Diagram.....	9A-169
D-3 Front Fog Light System Circuit Diagram (Taiwan).....	9A-131	List of Connector.....	9A-171
D-4 Illumination Light System Circuit Diagram (Except Taiwan).....	9A-132	List of Connectors.....	9A-171
D-4 Illumination Light System Circuit Diagram (Taiwan).....	9A-133	C Connector.....	9A-171
D-5 Interior Light System Circuit Diagram (Hatchback (Except Taiwan)).....	9A-134	E Connector.....	9A-172
D-5 Interior Light System Circuit Diagram (Hatchback (Taiwan)).....	9A-135	G Connector.....	9A-174
D-5 Interior Light System Circuit Diagram (Sedan (Except Taiwan)).....	9A-136	J Connector.....	9A-176
D-5 Interior Light System Circuit Diagram (Sedan (Taiwan)).....	9A-137	K Connector.....	9A-177
D-6 Turn Signal and Hazard Warning Light System Circuit Diagram (Hatchback (Except Taiwan)).....	9A-138	L Connector.....	9A-177
D-6 Turn Signal and Hazard Warning Light System Circuit Diagram (Sedan (Except Taiwan)).....	9A-140	M Connector (Sedan).....	9A-180
D-6 Turn Signal and Hazard Warning Light System Circuit Diagram (Hatchback (Taiwan)).....	9A-142	O Connector (Hatchback).....	9A-180
D-6 Turn Signal and Hazard Warning Light System Circuit Diagram (Sedan (Taiwan))....	9A-144	Q Connector (8ch).....	9A-180
		R Connector.....	9A-181
		S Connector.....	9A-181
		Lighting Systems.....	9B-1
		Precautions.....	9B-1
		Precautions for Discharge Headlight Service (If Equipped).....	9B-1
		Precautions in Diagnosing Troubles (Headlight Auto Leveling System).....	9B-1
		General Description.....	9B-2
		Discharge Headlight Description (If Equipped).....	9B-2
		Headlight Auto Leveling System Description (If Equipped).....	9B-3
		Auto-On Headlight System Description (If Equipped).....	9B-5
		Schematic and Routing Diagram.....	9B-6
		Headlight Auto Leveling System Wiring Circuit Diagram.....	9B-6
		Component Location.....	9B-6
		Lighting System Components Location.....	9B-6
		Interior Light System Location.....	9B-8
		Diagnostic Information and Procedures.....	9B-8

Self-Diagnosis Function for Headlight Auto Leveling System.....	9B-8	Turn Signal and Hazard Warning Relay Removal and Installation.....	9B-26
Headlight Leveling Warning Light Check.....	9B-9	Turn Signal and Hazard Warning Relay Inspection.....	9B-27
Headlight Symptom Diagnosis (Discharge Headlight Model).....	9B-9	License Light Assembly Removal and Installation (Hatchback).....	9B-27
Headlight Symptom diagnosis (Other than Discharge Headlight Model).....	9B-10	License Light Removal and Installation (Sedan).....	9B-28
Auto-On Headlight System Symptom Diagnosis (If Equipped).....	9B-10	Front Fog Light Assembly Removal and Installation (If Equipped).....	9B-28
DRL System Symptom Diagnosis (If Equipped).....	9B-11	Front Fog Light Switch Inspection (If Equipped).....	9B-29
Headlight Auto Leveling System Symptom Diagnosis (If Equipped).....	9B-11	Front Fog Light Aiming Adjustment with Screen (If Equipped).....	9B-29
Headlight Manual Leveling System Symptom Diagnosis (If Equipped).....	9B-12	Rear Fog Light Switch Inspection (If Equipped).....	9B-30
Turn Signal and Hazard Warning Light Symptom Diagnosis.....	9B-12	Headlight Manual Levering Switch Inspection (If Equipped).....	9B-31
Clearance, Tail and License Plate Light Symptom Diagnosis.....	9B-13	Headlight Leveling Actuator Inspection (If Equipped).....	9B-31
Back-Up Light Symptom Diagnosis.....	9B-13	Height Sensor Removal and Installation (If Equipped).....	9B-32
Brake Light Symptom Diagnosis.....	9B-13	Height Sensor and Its Circuit Inspection (If Equipped).....	9B-33
Front Fog Light Symptom Diagnosis (If Equipped).....	9B-13	Headlight Leveling Control Module Removal and Installation (If Equipped).....	9B-33
Rear Fog Light Symptom Diagnosis (If Equipped).....	9B-14	Initialization of Headlight Auto Leveling System.....	9B-33
Illumination Cancel System Symptom Diagnosis (If Equipped).....	9B-14	Auto-On Headlight Sensor Inspection (If Equipped).....	9B-34
Interior Light Symptom Diagnosis.....	9B-14	Illumination Cancel Switch Inspection (If Equipped).....	9B-35
DRL Operation Inspection (If Equipped).....	9B-14	Tail Light Relay, Headlight Relay, Front Fog Light Relay Inspection (If Equipped).....	9B-35
Inspection of DRL Controller and Its Circuits (If Equipped).....	9B-15	Specifications.....	9B-36
Auto-On Headlight Operation Inspection (If Equipped).....	9B-16	Tightening Torque Specifications.....	9B-36
Inspection of Auto-On Headlight Controller and Its Circuit (If Equipped).....	9B-16	Instrumentation / Driver Info. / Horn.....	9C-1
Inspection of Headlight Leveling Control Module and Its Circuit (Headlight Auto Leveling System).....	9B-17	Precautions.....	9C-1
Repair Instructions.....	9B-19	Precautions in Diagnosing Troubles for Combination Meter.....	9C-1
Headlight Housing Removal and Installation.....	9B-19	General Description.....	9C-1
Headlight Bulb Replacement (Discharge Headlight Model).....	9B-20	CAN Communication System Description.....	9C-1
Ballast Removal and Installation (Discharge Headlight Model).....	9B-21	Auto Volume Control System Description (If Equipped).....	9C-3
Igniter Removal and Installation (Discharge Headlight Model).....	9B-21	Schematic and Routing Diagram.....	9C-4
Headlight Aiming Adjustment with Screen.....	9B-22	Combination Meter Circuit Diagram.....	9C-4
Headlight Switch (in Lighting Switch) Removal and Installation.....	9B-24	Component Location.....	9C-6
Headlight Switch (in Lighting Switch) Inspection.....	9B-24	Audio System Component Location.....	9C-6
Hazard Warning Switch Removal and Installation.....	9B-25	Diagnostic Information and Procedures.....	9C-7
Hazard Warning Switch Inspection.....	9B-25	Speedometer and VSS Symptom Diagnosis.....	9C-7
Brake Light Switch Inspection.....	9B-25	Tachometer Symptom Diagnosis.....	9C-7
Turn Signal Light Switch (in Lighting Switch) Removal and Installation.....	9B-25	Engine Coolant Temperature (ECT) Meter Symptom Diagnosis.....	9C-7
Turn Signal Light Switch (in Lighting Switch) Inspection.....	9B-26	Fuel Meter Symptom Diagnosis.....	9C-7
		Low Fuel Warning Light Symptom Diagnosis.....	9C-8
		Oil Pressure Warning Light Symptom Diagnosis.....	9C-8

Brake and Parking Brake Warning Light Symptom Diagnosis	9C-9	Vehicle Speed Signal Inspection (For Audio Unit) (If Equipped)	9C-24
Seat Belt Reminder Light Symptom Diagnosis	9C-9	Specifications	9C-24
A/T Shift Position Indicator Symptom Diagnosis (A/T Model)	9C-9	Tightening Torque Specifications	9C-24
Charge Warning Light Symptom Diagnosis	9C-10	Wipers / Washers	9D-1
Main Beam (High Beam) Indicator Symptom Diagnosis	9C-10	Diagnostic Information and Procedures	9D-1
Warning Buzzer Circuit Symptom Diagnosis	9C-10	Front Wiper and Washer Symptom Diagnosis	9D-1
Cigarette Lighter Symptom Diagnosis (If Equipped)	9C-11	Rear Wiper and Washer Symptom Diagnosis	9D-1
Horn Symptom Diagnosis	9C-11	Repair Instructions	9D-2
Information Display Symptom Diagnosis (If Equipped)	9C-11	Wipers and Washers Components	9D-2
Clock System Diagnosis (If Equipped)	9C-12	Washer Tank and Washer Pump Removal and Installation	9D-3
Audio System Symptom Diagnosis (If Equipped)	9C-13	Washer Pump Inspection	9D-3
Remote Audio Control Switch Symptom Diagnosis (If Equipped)	9C-15	Windshield Wiper Removal and Installation	9D-3
Navigation Symptom Diagnosis (If Equipped)	9C-15	Windshield Wiper Motor Inspection	9D-4
Repair Instructions	9C-15	Rear Wiper Removal and Installation	9D-6
Ignition Switch Removal and Installation	9C-15	Rear Wiper Motor Inspection	9D-7
Ignition Switch Inspection	9C-16	Windshield Wiper and Washer Switch Removal and Installation	9D-8
Combination Meter Removal and Installation	9C-16	Windshield Wiper and Washer Switch Inspection	9D-8
Fuel Level Sensor Removal and Installation	9C-17	Rear Wiper and Washer Switch Removal and Installation	9D-10
Fuel Level Sensor Inspection	9C-17	Rear Wiper and Washer Switch Inspection	9D-10
Oil Pressure Switch Removal and Installation	9C-17	Rear Wiper Relay Removal and Installation	9D-10
Oil Pressure Switch Inspection	9C-17	Rear Wiper Relay Inspection	9D-11
Engine Coolant Temperature (ECT) Sensor Inspection	9C-17	Specifications	9D-11
Brake Fluid Level Switch Inspection	9C-17	Tightening Torque Specifications	9D-11
Parking Brake Switch Inspection	9C-18	Glass / Windows / Mirrors	9E-1
Door Switch (Front / Rear Door) Inspection	9C-18	General Description	9E-1
Rear End Door Switch Inspection (Hatchback)	9C-18	Rear End Door Window Defogger System Description	9E-1
Trunk Lid Switch Inspection (Sedan)	9C-18	Diagnostic Information and Procedures	9E-1
Outside Air Temperature Sensor Removal and Installation (If Equipped)	9C-19	Rear End door Window / Back Window Defogger Symptom Diagnosis	9E-1
Outside Air Temperature Sensor Inspection (If Equipped)	9C-19	Power Window Control System Symptom Diagnosis	9E-1
Instrument Panel Removal and Installation	9C-19	Power Door Mirror Control System Symptom Diagnosis	9E-2
Information Display (Clock) Removal and Installation	9C-20	Repair Instructions	9E-2
Audio Unit Removal and Installation (If Equipped)	9C-21	Windshield Components	9E-2
Front Speaker Removal and Installation (If Equipped)	9C-21	Windshield Removal and Installation	9E-3
Rear Speaker Removal and Installation (If Equipped)	9C-21	Front Pillar Window Components	9E-7
GPS Antenna Removal and Installation (If Equipped)	9C-22	Front Pillar Window Removal and Installation	9E-7
Horn Removal and Installation	9C-22	Rear Quarter Window Components (Hatchback Model)	9E-8
Horn Inspection	9C-22	Rear Quarter Window Removal and Installation (Hatchback Model)	9E-8
Horn Relay Inspection	9C-22	Rear End Door Window Components (Hatchback Model)	9E-9
Antenna Base Removal and Installation (Hatchback)	9C-23	Rear End Door Glass Removal and Installation (Hatchback Model)	9E-9
Remote Audio Control Switch Removal and Installation (If Equipped)	9C-23	Back Window Components (Sedan Model)	9E-10
Remote Audio Control Switch Inspection (If Equipped)	9C-24	Back Window Removal and Installation (Sedan Model)	9E-10
		Front Door Window Components	9E-11
		Front Door Glass Removal and Installation	9E-11

Front Door Window Regulator Removal and Installation	9E-12	Rear End Door Lock Assembly Removal and Installation (Hatchback Model)	9F-11
Front Door Window Regulator Inspection	9E-13	Rear End Door Lock Assembly Inspection (Hatchback Model)	9F-12
Rear Door Window Components	9E-13	Rear End Door Opener Switch Inspection (Hatchback Model)	9F-12
Rear Door Glass Removal and Installation	9E-14	Trunk Lid Lock Assembly Components (Sedan Model)	9F-13
Rear Door Window Regulator Removal and Installation	9E-15	Trunk Lid Lock Assembly Removal and Installation (Sedan Model)	9F-14
Rear Door Window Regulator Inspection	9E-16	Trunk Lid Lock Assembly Inspection (Sedan Model)	9F-15
Rear End Door Window / Back Window Defogger Switch Inspection	9E-16	Replacement of Transmitter Battery (Other than Keyless Start Model)	9F-15
Rear End Door Window / Back Window Defogger Relay Inspection	9E-17	Programming Transmitter Code for Keyless Entry System (Other than Keyless Start Model)	9F-15
Rear End Door Window / Back Window Defogger Wire Inspection	9E-17	Keyless Entry Answer Back Function Change-over Procedure	9F-16
Rear End Door Window / Back Window Defogger Wire Repair	9E-19	Keyless Entry Receiver Removal and Installation (If Equipped)	9F-16
Power Window Main Switch Inspection	9E-19	Keyless Entry Receiver and Its Circuit Inspection (If Equipped)	9F-17
Power Window Sub Switch Inspection	9E-20	Specifications	9F-18
Door Mirror Components	9E-21	Tightening Torque Specifications	9F-18
Door Mirror Removal and Installation	9E-21	Special Tools and Equipment	9F-18
Power Door Mirror Switch Inspection	9E-21	Recommended Service Material	9F-18
Power Door Mirror Actuator Inspection	9E-22		
Special Tools and Equipment	9E-22	Seats	9G-1
Recommended Service Material	9E-22	Repair Instructions	9G-1
Security and Locks	9F-1	Front Seat Components	9G-1
General Description	9F-1	Front Seat Removal and Installation	9G-2
Key Coding Construction	9F-1	Rear Seat Components	9G-2
Rear End Door Opener System Description	9F-1	Rear Seat Removal and Installation	9G-4
Component Location	9F-2	Specifications	9G-4
Power Door Lock and Keyless Entry System Component Location	9F-2	Tightening Torque Specifications	9G-4
Diagnostic Information and Procedures	9F-3	Special Tools and Equipment	9G-4
Power Door Lock System Symptom Diagnosis	9F-3	Recommended Service Material	9G-4
Power Door Lock System Operation Inspection	9F-3		
Keyless Entry System Symptom Diagnosis	9F-4	Interior Trim	9H-1
Keyless Entry System Operation Inspection	9F-5	Repair Instructions	9H-1
Door Lock Function of Keyless Start System Symptom Diagnosis (If Equipped)	9F-5	Floor Carpet Removal and Installation	9H-1
Rear End Door Opener System Symptom Diagnosis	9F-5	Head Lining Removal and Installation	9H-2
Rear End Door Opener System Operation Inspection	9F-5	Console Box Components	9H-4
Repair Instructions	9F-6	Specifications	9H-4
Front Door Lock Assembly Components	9F-6	Tightening Torque Specifications	9H-4
Front Door Lock Assembly Removal and Installation	9F-6		
Front Door Lock Assembly Inspection	9F-8	Hood / Fenders / Doors	9J-1
Power Door Lock Switch Inspection	9F-8	Repair Instructions	9J-1
Door Key Cylinder Switch Inspection	9F-8	Hood Removal and Installation	9J-1
Power Door Lock Actuator Inspection	9F-9	Hood Inspection and Adjustment	9J-1
Rear Door Lock Assembly Components	9F-10	Front Fender Components	9J-2
Rear Door Lock Assembly Removal and Installation	9F-10	Front Fender Removal and Installation	9J-2
Rear Door Lock Assembly Inspection	9F-10	Front Door Assembly Components	9J-3
Rear End Door Lock Assembly Components (Hatchback Model)	9F-11	Front Door Assembly Removal and Installation	9J-3
		Rear Door Assembly Components	9J-5
		Rear Door Assembly Removal and Installation	9J-5

Rear End Door Assembly Components (Hatchback Model)	9J-6
Rear End Door Assembly Removal and Installation (Hatchback Model)	9J-7
All Latches, Hinges and Locks Inspection	9J-8
Trunk Lid Components (Sedan Model)	9J-8
Trunk Lid Removal and Installation (Sedan Model)	9J-9
Specifications	9J-11
Tightening Torque Specifications	9J-11
Special Tools and Equipment	9J-11
Recommended Service Material	9J-11
Body Structure	9K-1
Repair Instructions	9K-1
Front Bumper and Rear Bumper Components	9K-1
Radiator Grille Removal and Installation	9K-2
Front Bumper Extension Removal and Installation (if equipped)	9K-3
Rear Bumper Extension Removal and Installation (if equipped)	9K-4
Cowl Top and Front Lower Crossmember Components	9K-5

Specifications	9K-6
Body Dimensions	9K-6
Panel Clearance	9K-18
Tightening Torque Specifications	9K-19
Paint / Coatings	9L-1
General Description	9L-1
Anti-Corrosion Treatment Construction	9L-1
Plastic Parts Finishing	9L-1
Component Location	9L-2
Sealant Application Areas	9L-2
Under Coating Application Areas	9L-10
Anti-Corrosion Compound Application Area	9L-12
Exterior Trim	9M-1
Repair Instructions	9M-1
Roof Molding Removal and Installation	9M-1
Splash Guard Removal and Installation (If Equipped)	9M-2
Specifications	9M-2
Tightening Torque Specifications	9M-2

Precautions

Precautions

Precautions on Body, Cab and Accessories

S7RW0C9000001

Air Bag Warning

Refer to "Air Bag Warning in Section 00".

Fastener Caution

Refer to "Fastener Caution in Section 00".

Precautions for Body Service

Refer to "Precautions for Body Service".

Fastener Caution for Body Service

Refer to "Fastener Caution for Body Service".

Cautions in Body Electrical System Servicing

Refer to "Cautions in Body Electrical System Servicing in Section 9A".

Precautions for Discharge Headlight Service (If Equipped)

Refer to "Precautions for Discharge Headlight Service (If Equipped) in Section 9B".

Precautions for Body Service

S7RW0C9000002

⚠ WARNING

For vehicles equipped with a Supplemental Restraint (Air Bag) System:

When servicing vehicle body, if shock may be applied to air bag system component parts, remove those parts beforehand.

Fastener Caution for Body Service

S7RW0C9000003

⚠ CAUTION

- Fasteners are important attaching parts in that they could affect the performance of vital components and systems, and/or could result in major repair expense. They must be replaced with one of the same part number or with an equivalent part if replacement become necessary.
- Do not use a replacement part of lesser quality or substitute a design. Torque values must be used as specified during reassembly to assure proper retention of these parts.

Wiring Systems

Precautions

Cautions in Body Electrical System Servicing

S7RW0C9100001

When servicing the electric systems, observe the cautions described in “Precautions for Electrical Circuit Service in Section 00” to protect electrical parts and to prevent a fire.

General Description

Abbreviations

S7RW0C9101001

Refer to the “Abbreviations in Section 0A” for the general abbreviations.

Abbreviation	Full term	Abbreviation	Full term
2WD	2 Wheel Drive Vehicles	J/B	Junction block
4WD	4 Wheel Drive Vehicles	J/C	Joint connector
A/B	Air Bag	KLS	Keyless Start System
ACC	Accessory	L	Left
CAN	Controller Area Network	LED	Light Emitting Diode
COMB	Combination	LHD	Left Hand Drive Vehicle
DSL	Diesel engine	LO	Low
ELCM	EVAP leak check module	OCV	Oil Control valve
ESP®	Electronic Stability Program	P/N	Power Normal
FWD	Forward	R	Right
HI	High	RHD	Right Hand Drive Vehicle
IF EQPD	If equipped	ST	Starter
IG COIL	Ignition coil	TPMS	Tire Pressure Monitoring System
ILL	Illumination	VIM	Variable Intake Manifold
IND	Indicator	VSV	Vacuum switching valve
INT	Intermittent	5 dr	5 door








ESP® is a registered trademark of Daimler Chrysler AG.

Wire / Connector Color Symbols





S7RW0C9101002

Refer to “Wire Color Symbols in Section 0A”.

Symbols and Marks

Battery	Ground		Normal fuse	Slow blow fuse
 I2RH01910910-01	 IYSQ01910915-01	 IYSQ01910916-01	 IYSQ01910917-01	 IYSQ01910918-01
Circuit breaker	Coil, Solenoid	Heater	Bulb	
 IYSQ01910919-01	 IYSQ01910920-01	 IYSQ01910921-01	 IYSQ01910922-01	 IYSQ01910923-01
Cigarette lighter	Motor	Pump	Horn	Speaker
 IYSQ01910924-01	 IYSQ01910925-01	 IYSQ01910926-01	 I2RH01910911-01	 I5JB0B910995-02
Buzzer	Chime	Condenser	Thermistor	Reed switch
 IYSQ01910929-01	 IYSQ01910930-01	 IYSQ01910931-01	 IYSQ01910932-01	 IYSQ01910933-01
Resistance	Variable resistance		Transistor	
 IYSQ01910934-01	 IYSQ01910935-01	 IYSQ01910936-01	 IYSQ01910937-01 NPN	 IYSQ01910938-01 PNP
Photo transistor	Diode	Zener diode	Light emitting diode	Photo diode
 IYSQ01910939-01	 IYSQ01910940-01	 IYSQ01910941-01	 IYSQ01910942-01	 IYSQ01910943-01
Piezoelectric element	Harness		Ring terminal	Connector
 IYSQ01910944-01	 IYSQ01910945-01 Connected	 IYSQ01910946-01 Not connected	 IYSQ01910947-01	 IYSQ01910948-01
Relay		Switch		
 I5RW0A910982-01 Normal open	 I5RW0A910983-01 Normal closed	 I5RW0A910984-01 Open switch	 I5RW0A910985-01 Closed switch	

9A-3 Wiring Systems:

Ignition switch  I2RH01910912-01	Keyless entry  I3JA01910902-01	Immobilizer system  I5RH01910901-01	Combination meter  I2RH01910915-01	Lighting switch  I2RH01910916-01
Headlight leveling  I3JA01910904-01	Hazard warning light  I3JA01910905-01	Front fog light  I3JA01910906-01	Rear fog light  I3JA01910907-01	Spark plug  I2RH01910921-01
Radiator fan  I2RH01910922-01	Fuel pump  I3JA01910908-01	Fuel injector  I5RW0A910987-01	XX control module  I2RH01910925-01	Windshield wiper  I3JA01910909-01
Windshield washer  I3JA01910910-01	Rear wiper  I3JA01910911-01	Rear washer  I3JA01910912-01	Rear defogger  I2RH01910930-01	Power window  I3JA01910913-01
Power door lock  I3JA01910914-01	Power mirror  I3JA01910915-01	A/B  I3JA01910916-01	Pretensioner  I3JA01910917-01	Passenger side  I3JA01910918-01
Driver side  I3JA01910919-01	Seat heater  I2RH01910938-01	A/C  I3JA01910920-01	Power steering  I3JA01910921-01	Side air-bag (R)  I4JA01910901-01
Side air-bag (L)  I4JA01910902-01	Side curtain air-bag (R)  I5RS0A910958-01	Side curtain air bag (L)  I5RS0A910959-01	Glow plug  I5RW0A910986-01	


How to Read Connector Layout Diagram

[A-1]: Harness symbol and corresponding harness name

- A: Battery harness
- B: A/C harness
- C: Engine harness
- D: Injector harness
- E: Main harness, Oil pressure switch wire, Console wire
- G: Instrument panel harness
- J: Side door wire (Power window)
- K: Interior light harness, Rear speaker wire, Roof wire
- L: Floor harness, G sensor wire (Fuel pump harness)
- M: Rear bumper harness
- O: Rear end door harness
- Q: Air bag/Pretensioner harness
- R: (Fuel pump wire)

[A-2]: Connector Number

[B]: Ground point No.




How to Read Connector Codes and Terminal Nos.

S7RW0C9101005

1) Connector code/Terminal No./Terminal layout

- The connector shape and terminal layout shown in this manual are those when viewed from "Z" in the illustration.
Refer to "List of Connectors".




I5RW0A910988-02

NOTE


Molded terminal numbers that are different from the above can be found on some connectors in rare cases.

These molded numbers are not applied in this manual.


2) Connector type




I2RH01910903-01



- Several different wires with the same wire color are joined at a part of J/C.




- Several different wires with the same wire color are joined by welding at a W/S.



9A-7 Wiring Systems:

6) Junction block (J/B)

Example




7) Connector location, shape and terminal No.

Refer to "Connector Layout Diagram".

Refer to "System Circuit Diagram".

Refer to "List of Connectors".




I5RW0A910991-02

How to Read Ground Point

Refer to "System Circuit Diagram".

Refer to "Ground (earth) Point".




How to Read Power Supply Diagram

S7RW0C9101007

Refer to "Power Supply Diagram".

Refer to "System Circuit Diagram".



I5RW0A910993-02

How to Read System Circuit Diagram

S7RW0C9101008

The circuit diagram is designed so the current flows from the top of the diagram (power source) to the bottom of the diagram (ground) as if giving an image of water flow.

[A]: Fuse No.

[B]: Circuit jumping page / direction

NOTE

This means "Jump to the page directed with the arrow(s) by their number.

(For example: "Two arrows directing left" means "Jump to two pages before".)

You will find the same symbol with the arrows directing opposite in the referenced page. The circuit continues between the symbols.

[C]: Circuit jumping point / direction

NOTE

The circuit continues to the same symbol with opposite direction within the page.

You will find the other symbol in the direction of the arrow.

[D]: Terminals-in-one-connector mark

[E]: Wire color

[F]: Shield wire

[G]: Ground point

[H]: "From" or "To" (With ID letter (s))

[I]: Specification variation

The white arrow between A and B means "or".

[J]: "From" (With ID letter (s))


[K]: "To" (With ID letter (s))

[L]: Connector code

[M]: Terminal No.

[N]: Symbol mark

[O]: "SEE" mark



Connector Layout Diagram

Connector Layout Diagram

S7RW0C910A001

Refer to "Engine Compartment".

Refer to "Instrument Panel".

Refer to "Door, Roof".

Refer to "Floor".


Refer to "Rear".

ESP® is a registered trademark of Daimler Chrysler AG.

Engine Compartment

S7RW0C910A002

A: Battery cable / C: Engine harness (M15A engine RHD)




I7RW0A910A00-03

C: Engine harness

No.	Color	Connective position	Remarks
C01	GRY	ECM	
C06	N	TCM	A/T
C07	N	TCM	A/T
C31	GRY	CKP sensor	
C32	BLK	CMP sensor	
C34	GRY	VSS	A/T
C36	BLK	MAP sensor	
C37	GRY	Knock sensor	
C39	BLK	ECT sensor	
C40	BLK	A/F sensor	
C42	GRN	Heated oxygen sensor	
C44	BLU	Input shaft speed sensor	A/T
C46	GRY	Current sensor	
C47	BLK	MAF sensor	
C48	BLK	Electric throttle body	
C91	GRY	Fuel injector #1	
C92	GRY	Fuel injector #2	
C93	GRY	Fuel injector #3	
C94	GRY	Fuel injector #4	
C101	GRY	IG COIL #1	
C102	GRY	IG COIL #2	
C122	GRY	EGR valve	
C123	BLK	EVAP canister purge valve	
C124	BLU	OCV	
C139	GRY	Shift solenoid	A/T
C141	BLK	A/C compressor	
C162	N	Oil pressure switch	
C166	GRY	Transaxle range sensor	A/T
C192	-	Generator	
C194	BLK	Generator	
C195	BLK	Starting motor	
C196	-	Starting motor	
C282	-	Main fuse box	
C283	-	Main fuse box	
C343	N	Main harness (To E371)	


A: Battery cable / C: Engine harness (M16A engine RHD)



No.	Color	Connective position	Remarks
C01	GRY	ECM	
C06	N	TCM	A/T
C07	N	TCM	A/T
C31	GRY	CKP sensor	
C32	BLK or GRY	CMP sensor	
C34	GRY	VSS	A/T
C36	BLK	MAP sensor	
C37	GRY	Knock sensor	
C39	BLK	ECT sensor	
C42	BLK	Heated oxygen sensor #1	
C43	GRN	Heated oxygen sensor #2	
C44	BLU	Input shaft speed sensor	A/T
C47	BLK	MAF sensor	
C48	BLK	Electric throttle body	
C91	GRY	Fuel injector #1	
C92	GRY	Fuel injector #2	
C93	GRY	Fuel injector #3	
C94	GRY	Fuel injector #4	
C101	GRY	IG COIL #1	
C102	GRY	IG COIL #2	
C122	GRY	EGR valve	
C123	BLK	EVAP canister purge valve	


No.	Color	Connective position	Remarks
C124	BLU	OCV	IF EQPD
C139	GRY	Shift solenoid	A/T
C141	BLK	A/C compressor	
C162	-	Oil pressure switch	
C165	BLK	Back-up light switch	M/T
C166	GRY	Transaxle range sensor	A/T
C192	-	Generator	
C194	BLK	Generator	
C195	BLK	Starting motor	
C196	-	Starting motor	
C282	-	Main fuse box	
C283	-	Main fuse box	
C343	N	Main harness (To E371)	

A: Battery cable / C: Engine harness (M16A engine LHD)



9A-15 Wiring Systems:**C: Engine harness**

No.	Color	Connective position	Remarks
C01	GRY	ECM	
C06	N	TCM	A/T
C07	N	TCM	A/T
C31	GRY	CKP sensor	
C32	BLK or GRY	CMP sensor	
C34	GRY	VSS	A/T
C36	BLK	MAP sensor	
C37	GRY	Knock sensor	
C39	BLK	ECT sensor	
C42	BLK	Heated oxygen sensor #1	
C43	GRN	Heated oxygen sensor #2	
C44	BLU	Input shaft speed sensor	A/T
C47	BLK	MAF sensor	
C48	BLK	Electric throttle body	
C91	GRY	Fuel injector #1	
C92	GRY	Fuel injector #2	
C93	GRY	Fuel injector #3	
C94	GRY	Fuel injector #4	
C101	GRY	IG COIL #1	
C102	GRY	IG COIL #2	
C122	GRY	EGR valve	
C123	BLK	EVAP canister purge valve	
C124	BLU	OCV	IF EQPD
C139	GRY	Shift solenoid	A/T
C141	BLK	A/C compressor	
C162	-	Oil pressure switch	
C165	BLK	Back-up light switch	M/T
C166	GRY	Transaxle range sensor	A/T
C192	-	Generator	
C194	BLK	Generator	
C195	BLK	Starting motor	
C196	-	Starting motor	
C282	-	Main fuse box	
C283	-	Main fuse box	
C343	N	Main harness (To E371)	

A: Battery cable / C: Engine harness (J20A engine RHD)

I7RW0A910960-02


C: Engine harness

No.	Color	Connective position	Remarks
C01	GRY	ECM	
C06	N	TCM	A/T
C07	N	TCM	A/T
C31	GRY	CKP sensor	
C32	N	CMP sensor	
C37	GRY	Knock sensor	
C39	BLK	ECT sensor	
C40	GRN	A/F sensor	
C42	GRY	Heated oxygen sensor	
C44	BLK	Input shaft speed sensor	A/T
C45	BLK	Output shaft speed sensor	A/T
C46	GRY	Current sensor	
C47	BLK	MAF sensor	
C48	BLK	Electric throttle body	
C64	BRN	VIM motor	
C91	GRY	Fuel injector #1	
C92	GRY	Fuel injector #2	
C93	GRY	Fuel injector #3	
C94	GRY	Fuel injector #4	
C101	GRY	IG COIL #1	
C102	GRY	IG COIL #2	
C103	GRY	IG COIL #3	
C104	GRY	IG COIL #4	

9A-17 Wiring Systems:


No.	Color	Connective position	Remarks
C123	BLU	EVAP canister purge valve	
C139	GRY	Shift solenoid	A/T
C141	BLK	A/C compressor	
C162	N	Oil pressure switch	
C163	N	P/S pressure switch	IF EQPD
C165	BLK	Back-up light switch	M/T
C166	BLK	Transaxle range sensor	A/T
C192	-	Generator	
C194	BLK	Generator	
C195	BLK	Starting motor	
C196	-	Starting motor	
C282	-	Main fuse box	
C283	-	Main fuse box	
C343	N	Main harness (To E371)	

A: Battery cable / C: Engine harness (J20A engine LHD)



C: Engine harness

No.	Color	Connective position	Remarks
C01	GRY	ECM	
C06	N	TCM	A/T
C07	N	TCM	A/T
C31	GRY	CKP sensor	
C32	N	CMP sensor	
C37	GRY	Knock sensor	
C39	BLK	ECT sensor	
C40	GRN	A/F sensor	
C42	GRY	Heated oxygen sensor	
C44	BLK	Input shaft speed sensor	A/T
C45	BLK	Output shaft speed sensor	A/T
C46	GRY	Current sensor	
C47	BLK	MAF sensor	
C48	BLK	Electric throttle body	
C64	BRN	VIM motor	
C91	GRY	Fuel injector #1	
C92	GRY	Fuel injector #2	
C93	GRY	Fuel injector #3	
C94	GRY	Fuel injector #4	
C101	GRY	IG COIL #1	
C102	GRY	IG COIL #2	
C103	GRY	IG COIL #3	
C104	GRY	IG COIL #4	
C123	BLU	EVAP canister purge valve	
C139	GRY	Shift solenoid	A/T
C141	BLK	A/C compressor	
C162	N	Oil pressure switch	
C163	N	P/S pressure switch	IF EQPD
C165	BLK	Back-up light switch	M/T
C166	BLK	Transaxle range sensor	A/T
C192	-	Generator	
C194	BLK	Generator	
C195	BLK	Starting motor	
C196	-	Starting motor	
C282	-	Main fuse box	
C283	-	Main fuse box	
C343	N	Main harness (To E371)	


E: Main harness (RHD)

I6RW0C910906-07

E: Main harness

No.	Color	Connective position	Remarks
E01	GRY	ECM	
E08	BLK	ABS control module	
E33	N	Wheel speed sensor (FR)	
E35	BLU	Wheel speed sensor (FL)	
E36	BLK	A/C refrigerant pressure sensor	
E37	BLK	Outside air temperature sensor	
E40	YEL	Forward sensor	
E62	BLU	Windshield washer motor	
E63	GRN	Rear washer motor	
E64	GRY	Windshield wiper motor	
E65	BLK	Radiator fan motor	
E68	GRY	Headlight beam leveling actuator (R)	IF EQPD
E69	GRY	Headlight beam leveling actuator (L)	IF EQPD
E70	BLK	Condenser fan motor	
E151	BLK	Headlight (R)	
E152	BLK	Headlight (L)	
E159	GRY	Front turn signal light (R)	
E160	GRY	Front turn signal light (L)	
E161	N	Front position light (R)	
E162	N	Front position light (L)	
E163	BLK	Front fog light (R)	
E164	BLK	Front fog light (L)	
E165	N	Side turn signal light (R)	
E166	N	Side turn signal light (L)	

No.	Color	Connective position	Remarks
E183	GRY	Brake fluid level switch	
E221	BLK	Main relay	
E222	BLK	Radiator fan relay #1	
E223	BLK	Radiator fan relay #2	
E224	BLK	Radiator fan relay #3	
E225	BLK	Starting motor relay	
E226	BLK	Throttle actuator control relay	
E227	BLK	Fuel pump relay	
E229	BLK	A/C compressor relay	
E230	BLK	Condenser fan relay	
E231	BLK	A/T relay	A/T
E234	BLK	Front fog light relay	
E241	BLK	Shift lock relay	A/T
E281	BLK	Horn	
E311	BLK	Main fuse box	
E312	N	Main fuse box	
E371	N	Engine harness (To C343)	

E: Main harness (LHD)


9A-21 Wiring Systems:**E: Main harness**

No.	Color	Connective position	Remarks
E01	GRY	ECM	
E08	BLK	ABS control module	
E33	N	Wheel speed sensor (FR)	
E35	BLU	Wheel speed sensor (FL)	
E36	BLK	A/C refrigerant pressure sensor	
E37	BLK	Outside air temperature sensor	
E40	YEL	Forward sensor	
E62	BLU	Windshield washer motor	
E63	GRN	Rear washer motor	
E64	GRY	Windshield wiper motor	
E65	BLK	Radiator fan motor	
E68	GLY	Headlight beam leveling actuator (R)	IF EQPD
E69	GLY	Headlight beam leveling actuator (L)	IF EQPD
E70	BLK	Condenser fan motor	
E151	BLK	Headlight (R)	
E152	BLK	Headlight (L)	
E159	GRY	Front turn signal light (R)	
E160	GRY	Front turn signal light (L)	
E161	N	Front position light (R)	
E162	N	Front position light (L)	
E163	BLK	Front fog light (R)	
E164	BLK	Front fog light (L)	
E165	N	Side turn signal light (R)	
E166	N	Side turn signal light (L)	
E183	GRY	Brake fluid level switch	
E221	BLK	Main relay	
E222	BLK	Radiator fan relay #1	
E223	BLK	Radiator fan relay #2	Except Taiwan
E224	BLK	Radiator fan relay #3	Except Taiwan
E225	BLK	Starting motor relay	
E226	BLK	Throttle actuator control relay	
E227	BLK	Fuel pump relay	
E229	BLK	A/C compressor relay	
E230	BLK	Condenser fan relay	
E231	BLK	A/T relay	A/T
E232	BLK	Headlight HI relay (R)	Taiwan
E233	BLK	Headlight HI relay (L)	Taiwan
E234	BLK	Front fog light relay	
E241	BLK	Shift lock relay	A/T
E247	BLK	Headlight LO relay (R)	Taiwan
E248	BLK	Headlight LO relay (L)	Taiwan
E281	BLK	Horn	
E311	BLK	Main fuse box	
E312	N	Main fuse box	
E371	N	Engine harness (To C343)	

Instrument Panel

S7RW0C910A003

E: Main harness, power steering wire (RHD)



I6RW0C910908-04

E: Main harness


No.	Color	Connective position	Remarks
E04	BLU	BCM	
E13	BLK	P/S control module	
E181	N	Brake light switch	
E191	BLK	APP (Acceleration pedal position) sensor	
E192	N	CPP (clutch pedal position) cut switch	
E323	BRN	J/B	
E324	N	J/B	
E325	N	J/B	
E377	BLU	Power steering wire (To E378)	
E381	GRY	Instrument panel harness (To G333)	
E382	BRN	Instrument panel harness (To G334)	
E383	GRN	Instrument panel harness (To G335)	IF EQPD
E387	N	Floor harness (To L371)	
E388	YEL	Floor harness (To L372)	

E: Power steering wire

No.	Color	Connective position	Remarks
E11	BLK	P/S control module	
E12	BLU	P/S control module	
E31	GRY	Torque sensor	
E61	GRY	P/S motor	
E378	BLU	Main harness (To E377)	

9A-23 Wiring Systems:

E: Main harness, power steering wire (LHD)



I6RW0C910909-02

E: Main harness

No.	Color	Connective position	Remarks
E04	BLU	BCM	Except Taiwan
E13	BLK	P/S control module	
E181	N	Brake light switch	
E191	BLK	APP (Acceleration pedal position) sensor	
E323	BRN	J/B	
E324	N	J/B	
E325	N	J/B	
E377	BLU	Power steering wire (To E378)	
E381	GRY	Instrument panel harness (To G333)	
E382	BRN	Instrument panel harness (To G334)	
E387	N	Floor harness (To L371)	
E388	YEL	Floor harness (To L372)	

E: Power steering wire

No.	Color	Connective position	Remarks
E11	BLK	P/S control module	
E12	BLU	P/S control module	
E31	GRY	Torque sensor	
E61	GRY	P/S motor	
E378	BLU	Main harness (To E377)	

G: Instrument panel harness, Instrument panel antenna wire / S: Contact coil (RHD)

9A-25 Wiring Systems:

No.	Color	Connective position	Remarks
G253	GRN	Multi information display	
G254	N	Keyless receiver	IF EQPD
G255	BLK	Diode #1	Auto A/C
G259	ORN	Passenger inflator	
G271	N	J/B	
G272	N	J/B	
G273	N	J/B	
G306	N	J/C	
G307	N	J/C	IF EQPD
G308	N	J/C	
G309	GRY	J/C	
G310	N	J/C	Auto A/C
G311	GRY	J/C	
G333	GRY	Main harness (To E381)	
G334	BRN	Main harness (To E382)	
G335	GRN	Main harness (To E383)	IF EQPD
G341	BLU	Floor harness (To L374)	
G342	N	Floor harness (To L375)	IF EQPD
G343	N	Floor harness (To L376)	
G344	YEL	Floor harness (To L377)	
G345	YEL	Floor harness (To L378)	
G346	N or BLK	Contact coil (To S171)	
G347	YEL	Contact coil (To S172)	
G348	N	Roof audio antenna wire (To K153)	

G: Instrument panel antenna wire

No.	Color	Connective position	Remarks
G266	GRY	Navigation	IF EQPD
G267	GRY	Audio (Navigation)	
G354	BLK	Roof audio antenna wire (To K154)	
G355	GRY	Floor antenna wire (To L409)	IF EQPD

S: Contact coil

No.	Color	Connective position	Remarks
S61	-	Steering switch (Horn, Auto cruise, Audio control)	
S121	-	Driver inflator	
S171	-	Instrument panel harness (To G346)	
S172	-	Instrument panel harness (To G347)	

G: Instrument panel harness, Instrument panel antenna wire / S: Contact coil (LHD)

9A-27 Wiring Systems:

No.	Color	Connective position	Remarks
G248	BLU	Audio (Navigation)	
G251	N	ACC socket	
G253	GRN	Multi information display	
G254	N	Keyless receiver	IF EQPD
G255	BLK	Diode #1	Auto A/C
G259	ORN	Passenger inflator #1	
G265	N	Security option	Taiwan
G271	N	J/B	
G272	N	J/B	
G273	N	J/B	
G306	N	J/C	
G307	N	J/C	IF EQPD
G308	N	J/C	
G309	GRY	J/C	
G310	N	J/C	Auto A/C
G311	GRY	J/C	
G333	GRY or N	Main harness (To E381)	
G334	BRN	Main harness (To E382)	
G341	BLU	Floor harness (To L374)	
G342	N	Floor harness (To L375)	IF EQPD
G343	N	Floor harness (To L376)	
G344	YEL	Floor harness (To L377)	
G345	YEL	Floor harness (To L378)	
G346	N	Contact coil (To S171)	
G347	YEL	Contact coil (To S172)	
G348	N	Roof audio antenna wire (To K153)	
G349	YEL	Floor harness (To L399)	Taiwan
G352	N	Floor harness (To L402)	Taiwan

G: Instrument panel antenna wire

No.	Color	Connective position	Remarks
G266	GRY	Navigation	IF EQPD
G267	GRY	Audio (Navigation)	
G354	BLK	Roof audio antenna wire (To K154)	
G355	GRY	Floor antenna wire (To L409)	IF EQPD


S: Contact coil

No.	Color	Connective position	Remarks
S61	-	Steering switch (Horn, Audio control)	
S121	-	Driver inflator	
S171	-	Instrument panel harness (To G346)	
S172	-	Instrument panel harness (To G347)	

Door, Roof

S7RW0C910A004

J: Front and rear door wire and rear door wire / K: Roof wire, Roof audio antenna wire (RHD)



I6RW0C910911-02

9A-29 Wiring Systems:**J: Door harness (Driver side)**

No.	Color	Connective position	Remarks
J21	BLK	Front power window motor (Driver side)	
J27	N	Mirror motor (Driver side)	
J31	N	Front door lock motor (Driver side)	
J81	BLU	Power window main switch	
J85	N	Request switch (Driver side)	IF EQPD
J87	N	Mirror switch	
J141	/N	Front speaker (R)	
J147	BLK	Tweeter (R)	IF EQPD
J153	N	Door antenna (Driver side)	IF EQPD
J215	GRY	Floor harness (To L379)	

J: Door harness (Passenger side)

No.	Color	Connective position	Remarks
J22	BLK	Front power window motor (Passenger side)	
J28	N	Mirror motor (Passenger side)	
J32	N	Front door lock motor (Passenger side)	
J82	N	Power window sub switch	
J86	N	Request switch (Passenger side)	IF EQPD
J142	N	Front speaker (L)	
J148	BLK	Tweeter (L)	IF EQPD
J154	N	Door antenna (Passenger side)	IF EQPD
J216	GRY	Floor harness (To L380)	

J: Rear door wire

No.	Color	Connective position	Remarks
J25	BLK	Rear power window motor (R)	
J26	BLK	Rear power window motor (L)	
J35	N	Rear door lock motor (R)	
J36	N	Rear door lock motor (L)	
J83	N	Rear power window sub switch (R)	
J84	N	Rear power window sub switch (L)	
J145	N	Rear speaker (R)	
J146	N	Rear speaker (L)	
J151	BLK	Rear Tweeter (R)	IF EQPD
J152	BLK	Rear Tweeter (L)	IF EQPD
J217	N	Floor harness (To L381)	
J218	N	Floor harness (To L382)	


K: Roof wire

No.	Color	Connective position	Remarks
K51	N	Interior light	
K52	N	Spot light	
K152	N	Floor harness (To L383)	

K: Roof audio antenna wire

No.	Color	Connective position	Remarks
K121	N	Antenna amplifier	
K153	N	Instrument panel harness (To G348)	
K154	BLK	Instrument panel antenna wire (To G354)	

J: Front and rear door wire and rear door wire / K: Roof wire, Roof audio antenna wire (LHD)



9A-31 Wiring Systems:**J: Door harness (Driver side)**

No.	Color	Connective position	Remarks
J21	BLK	Front power window motor (Driver side)	
J27	N	Mirror motor (Driver side)	
J31	N	Front door lock motor (Driver side)	
J81	BLU	Power window main switch	
J85	N	Request switch (Driver side)	IF EQPD
J87	N	Mirror switch	
J142	N	Front speaker (L)	
J148	BLK	Tweeter (L)	IF EQPD
J153	N	Door antenna (Driver side)	IF EQPD
J215	GRY	Floor harness (To L379)	

J: Door harness (Passenger side)

No.	Color	Connective position	Remarks
J22	BLK	Front power window motor (Passenger side)	
J28	N	Mirror motor (Passenger side)	
J32	N	Front door lock motor (Passenger side)	
J82	N	Power window sub switch	
J86	N	Request switch (Passenger side)	IF EQPD
J141	N	Front speaker (R)	
J147	BLK	Tweeter (R)	IF EQPD
J154	N	Door antenna (Passenger side)	IF EQPD
J216	GRY	Floor harness (To L380)	

J: Rear door wire

No.	Color	Connective position	Remarks
J25	BLK	Rear power window motor (R)	
J26	BLK	Rear power window motor (L)	
J35	N	Rear door lock motor (R)	
J36	N	Rear door lock motor (L)	
J83	N	Rear power window sub switch (R)	
J84	N	Rear power window sub switch (L)	
J145	N	Rear speaker (R)	
J146	N	Rear speaker (L)	
J151	BLK	Rear Tweeter (R)	IF EQPD
J152	BLK	Rear Tweeter (L)	IF EQPD
J217	N	Floor harness (To L381)	
J218	N	Floor harness (To L382)	

K: Roof wire

No.	Color	Connective position	Remarks
K51	N	Interior light	
K52	N	Spot light	
K152	N	Floor harness (To L383)	


K: Roof audio antenna wire

No.	Color	Connective position	Remarks
K121	N	Antenna amplifier	
K153	N	Instrument panel harness (To G348)	
K154	BLK	Instrument panel antenna wire (To G354)	

Floor

S7RW0C910A005

L: Floor harness, Coupling harness, Floor antenna wire / Q: Side curtain air-bag wire, Side air-bag (R) harness, Side air-bag (L) harness / R: Fuel pump wire (RHD, Hatchback)



I7RW0A910962-01

L: Floor harness

No.	Color	Connective position	Remarks
L01	BLU	BCM	
L04	PNK	A/B SDM	4ch
L04	BRN	A/B SDM	8ch
L31	GRY	Wheel speed sensor (RR)	
L32	GRY	Wheel speed sensor (RL)	
L33	BLK	G sensor	IF EQPD
L34	BLK	YAW/G sensor	IF EQPD
L35	N	Driver side-sensor	8ch
L36	N	Passenger side-sensor	8ch
L101	N	A/T shift lever assy (Shift lock solenoid, 3 position switch)	
L132	GRY	Luggage compartment light	
L133	N	Rear combination light (R)	
L134	N	Rear combination light (L)	
L161	N	Front door switch (Driver side)	
L162	N	Front door switch (Passenger side)	
L163	N	Rear door switch (R)	
L164	N	Rear door switch (L)	

9A-33 Wiring Systems:

No.	Color	Connective position	Remarks
L167	BLK	Parking brake switch	
L169	BRN	ESP® off switch	IF EQPD
L170	N	Seat belt switch	
L174	N	2WD/4WD switch	IF EQPD
L283	BLK	Pretensioner (Driver side)	
L285	BLK	Pretensioner (Passenger side)	
L292	GRY	Back antenna	IF EQPD
L293	BRN	Luggage antenna	IF EQPD
L294	BRN	Inside antenna	IF EQPD
L296	N	Rear ACC socket	
L301	BLK	Diode #2	
L312	N	J/B	
L313	YEL	J/B	
L314	N	J/B	
L315	N	J/B	
L346	N	J/C	
L347	N	J/C	
L348	GRY	J/C	
L371	N	Main harness (To E387)	
L372	YEL	Main harness (To E388)	
L374	BLU	Instrument panel harness (To G341)	
L375	N	Instrument panel harness (To G342)	IF EQPD
L376	N	Instrument panel harness (To G343)	
L377	YEL	Instrument panel harness (To G344)	
L378	YEL	Instrument panel harness (To G345)	
L379	GRY	Door harness (Driver side) (To J215)	
L380	GRY	Door harness (Passenger side) (To J216)	
L381	N	Rear door wire (To J217)	
L382	N	Rear door wire (To J218)	
L383	N	Roof wire (To K152)	
L384	YEL	Side air-bag (R) harness (To Q133)	8ch
L385	YEL	Side air-bag (L) harness (To Q134)	8ch
L389	GRY	Fuel pump wire (To R151)	
L390	N	Rear end door harness (To O231)	
L391	N	Rear end door harness (To O232)	IF EQPD
L393	N	High mounted stop light wire (To O233)	
L395	YEL	Side curtain air-bag wire (To Q132)	8ch
L397	GRY	Coupling harness (To L408)	IF EQPD

L: Coupling harness

No.	Color	Connective position	Remarks
L40	BLK	Coupling air temperature sensor	IF EQPD
L102	GRY	Coupling solenoid	IF EQPD
L408	GRY	Floor harness (To L397)	IF EQPD

L: Floor antenna wire

No.	Color	Connective position	Remarks
L307	BLK	TV antenna #1	IF EQPD
L308	BLK	TV antenna #2	IF EQPD
L409	GRY	Instrument panel antenna wire (To G355)	IF EQPD
L410	GRY	Back door antenna wire (To O240)	IF EQPD

Q: Side curtain air-bag wire

No.	Color	Connective position	Remarks
Q102	BLK	Side curtain air-bag (R)	8ch
Q103	BLK	Side curtain air-bag (L)	8ch
Q132	YEL	Floor harness (To L395)	8ch

Q: Side air-bag (R) harness

No.	Color	Connective position	Remarks
Q104	BLK	Side air-bag inflator (R)	8ch
Q133	YEL	Floor harness (To L384)	8ch


Q: Side air-bag (L) harness

No.	Color	Connective position	Remarks
Q105	BLK	Side air-bag inflator (L)	8ch
Q134	YEL	Floor harness (To L385)	8ch

R: Fuel pump wire

No.	Color	Connective position	Remarks
R101	BLK	Fuel pump and gauge	8ch
R151	GRY	Floor harness (To L389)	8ch

L: Floor harness, Coupling harness, Floor antenna wire / Q: Side air-bag (R) harness, Side air-bag (L) harness / R: Fuel pump wire (RHD, Sedan)



I7RW0A910903-03

L: Floor harness

No.	Color	Connective position	Remarks
L01	BLU	BCM	
L04	PNK	A/B SDM	4ch
L04	BRN	A/B SDM	8ch
L31	GRY	Wheel speed sensor (RR)	
L32	GRY	Wheel speed sensor (RL)	
L35	N	Driver side-sensor	8ch

9A-35 Wiring Systems:

No.	Color	Connective position	Remarks
L36	N	Passenger side-sensor	8ch
L101	N	A/T shift lever assy (Shift lock solenoid, 3 position switch)	
L133	N	Rear combination light (R)	
L134	N	Rear combination light (L)	
L139	N	High mounted stop light	
L141	N	Trunk room light	
L161	N	Front door switch (Driver side)	
L162	N	Front door switch (Passenger side)	
L163	N	Rear door switch (R)	
L164	N	Rear door switch (L)	
L167	BLK	Parking brake switch	
L170	N	Seat belt switch	
L173	N	Trunk room light switch	
L233	BLK	Rear defogger relay	
L283	BLK	Pretensioner (Driver side)	
L285	BLK	Pretensioner (Passenger side)	
L290	BLK	Side curtain air-bag (R)	
L291	BLK	Side curtain air-bag (L)	
L292	GRY	Back antenna	IF EQPD
L293	BRN	Luggage antenna	IF EQPD
L294	BRN	Inside antenna	IF EQPD
L299	BLK	Rear defogger (+)	
L300	BLK	Rear defogger (-)	
L301	N	Diode	
L303	N	Condenser (+)	
L312	N	J/B	
L313	YEL	J/B	
L314	N	J/B	
L315	N	J/B	
L317	N	Individual circuit fuse box No.3	
L346	N	J/C	
L347	N	J/C	
L348	GRY	J/C	
L371	N	Main harness (To E387)	
L372	YEL	Main harness (To E388)	
L374	BLU	Instrument panel harness (To G341)	
L375	N	Instrument panel harness (To G342)	IF EQPD
L376	N	Instrument panel harness (To G343)	
L377	YEL	Instrument panel harness (To G344)	4ch
L378	YEL	Instrument panel harness (To G345)	4ch
L379	GRY	Door harness (Driver side) (To J215)	
L380	GRY	Door harness (Passenger side) (To J216)	
L381	N	Rear door wire (To J217)	
L382	N	Rear door wire (To J218)	
L383	N	Roof wire (To K152)	
L384	YEL	Side air-bag (R) harness (To Q133)	8ch
L385	YEL	Side air-bag (L) harness (To Q134)	8ch
L389	GRY	Fuel pump wire (To R151)	
L394	BLK	Trunk room harness (To M152)	

M: Trunk room harness

No.	Color	Connective position	Remarks
M53	N	License plate light #1	
M54	N	License plate light #2	
M81	N	Trunk room lock solenoid	
M82	N	Trunk room request switch	
M152	BLK	Floor harness (To L394)	

9A-37 Wiring Systems:**L: Floor harness**

No.	Color	Connective position	Remarks
L01	BLU	BCM	Except Taiwan
L04	PNK	A/B SDM	4ch
L04	BRN	A/B SDM	8ch
L31	GRY	Wheel speed sensor (RR)	
L32	GRY	Wheel speed sensor (RL)	
L35	N	Driver side-sensor	8ch
L36	N	Passenger side-sensor	8ch
L101	N	A/T shift lever assy (Shift lock solenoid, 3 position switch)	
L132	GRY	Luggage compartment light	
L133	N	Rear combination light (R)	
L134	N	Rear combination light (L)	
L161	N	Front door switch (Driver side)	
L162	N	Front door switch (Passenger side)	
L163	N	Rear door switch (R)	
L164	N	Rear door switch (L)	
L167	BLK	Parking brake switch	
L170	N	Seat belt switch	
L171	YEL	Seat heater switch (Driver side)	IF EQPD
L172	GRN	Seat heater switch (Passenger side)	IF EQPD
L281	N	Seat heater (Driver side)	IF EQPD
L282	N	Seat heater (Passenger side)	IF EQPD
L283	BLK	Pretensioner (Driver side)	
L285	BLK	Pretensioner (Passenger side)	
L292	GRY	Back antenna	IF EQPD
L293	BRN	Luggage antenna	IF EQPD
L294	BRN	Inside antenna	IF EQPD
L296	N	Rear ACC socket	IF EQPD
L301	BLK	Diode #2	
L312	N	J/B	
L313	YEL	J/B	
L314	N	J/B	
L315	N	J/B	
L346	N	J/C	
L347	N	J/C	
L348	GRY	J/C	
L371	N	Main harness (To E387)	
L372	YEL	Main harness (To E388)	
L374	BLU	Instrument panel harness (To G341)	
L375	N	Instrument panel harness (To G342)	IF EQPD
L376	N	Instrument panel harness (To G343)	
L377	YEL	Instrument panel harness (To G344)	
L378	YEL	Instrument panel harness (To G345)	
L379	GRY	Door harness (Driver side) (To J215)	
L380	GRY	Door harness (Passenger side) (To J216)	
L381	N	Rear door wire (To J217)	
L382	N	Rear door wire (To J218)	
L383	N	Roof wire (To K152)	
L384	YEL	Side air-bag (R) harness (To Q133)	8ch
L385	YEL	Side air-bag (L) harness (To Q134)	8ch
L389	GRY	Fuel pump wire (To R151)	
L390	N	Rear end door harness (To O231)	
L391	N	Rear end door harness (To O232)	IF EQPD
L393	N	High mounted stop light wire (To O233)	
L395	YEL	Side curtain air-bag wire (To Q132)	8ch
L399	YEL	Instrument panel harness (To G349)	Taiwan
L402	YEL	Instrument panel harness (To G352)	Taiwan

L: Floor antenna wire

No.	Color	Connective position	Remarks
L307	BLK	TV antenna #1	IF EQPD
L308	BLK	TV antenna #2	IF EQPD
L409	GRY	Instrument panel antenna wire (To G355)	IF EQPD
L410	GRY	Back door antenna wire (To O240)	IF EQPD

Q: Side curtain air-bag wire

No.	Color	Connective position	Remarks
Q102	BLK	Side curtain air-bag (R)	8ch
Q103	BLK	Side curtain air-bag (L)	8ch
Q132	YEL	Floor harness (To L395)	8ch

Q: Side air-bag (R) harness

No.	Color	Connective position	Remarks
Q104	BLK	Side air-bag inflator (R)	8ch
Q133	YEL	Floor harness (To L384)	8ch

Q: Side air-bag (L) harness


No.	Color	Connective position	Remarks
Q105	BLK	Side air-bag inflator (L)	8ch
Q134	YEL	Floor harness (To L385)	8ch

R: Fuel pump wire

No.	Color	Connective position	Remarks
R101	BLK	Fuel pump and gauge	
R151	GRY	Floor harness (To L389)	

9A-39 Wiring Systems:

L: Floor harness, Coupling harness, Floor antenna wire / M: Trunk room harness / Q: Side air-bag (R) harness, Side air-bag (L) harness / R: Fuel pump wire (LHD, Sedan)



I7RW0A910905-02

L: Floor harness

No.	Color	Connective position	Remarks
L01	BLU	BCM	
L04	PNK	A/B SDM	4ch
L04	BRN	A/B SDM	8ch
L31	GRY	Wheel speed sensor (RR)	
L32	GRY	Wheel speed sensor (RL)	
L34	BLK	YAW/G sensor	IF EQPD
L35	N	Driver side-sensor	8ch
L36	N	Passenger side-sensor	8ch
L101	N	A/T shift lever assy (Shift solenoid, 3 position switch)	
L133	N	Rear combination light (R)	
L134	N	Rear combination light (L)	
L139	N	High mounted stop light	
L141	N	Trunk room light	
L161	N	Front door switch (Driver side)	
L162	N	Front door switch (Passenger side)	
L163	N	Rear door switch (R)	
L164	N	Rear door switch (L)	
L167	BLK	Parking brake switch	
L169	BRN	ESP® off switch	IF EQPD

No.	Color	Connective position	Remarks
L170	N	Seat belt switch	
L171	YEL	Seat heater switch (Driver side)	
L172	GRN	Seat heater switch (Passenger side)	
L173	N	Trunk room light switch	
L233	BLK	Rear defogger relay	
L283	BLK	Pretensioner (Driver side)	
L285	BLK	Pretensioner (Passenger side)	
L290	BLK	Side curtain air-bag (R)	
L291	BLK	Side curtain air-bag (L)	
L292	GRY	Back antenna	IF EQPD
L293	BRN	Luggage antenna	IF EQPD
L294	BRN	Inside antenna	IF EQPD
L299	BLK	Rear defogger (+)	
L300	BLK	Rear defogger (-)	
L301	N	Diode	
L303	N	Condenser (+)	
L312	N	J/B	
L313	YEL	J/B	
L314	N	J/B	
L315	N	J/B	
L317	N	Individual circuit fuse box No.3	
L346	N	J/C	
L347	N	J/C	
L348	GRY	J/C	
L371	N	Main harness (To E387)	
L372	YEL	Main harness (To E388)	
L374	BLU	Instrument panel harness (To G341)	
L375	N	Instrument panel harness (To G342)	IF EQPD
L376	N	Instrument panel harness (To G343)	
L377	YEL	Instrument panel harness (To G344)	4ch
L378	YEL	Instrument panel harness (To G345)	4ch
L379	GRY	Door harness (Driver side) (To J215)	
L380	GRY	Door harness (Passenger side) (To J216)	
L381	N	Rear door wire (To J217)	
L382	N	Rear door wire (To J218)	
L383	N	Roof wire (To K152)	
L384	YEL	Side air-bag (R) harness (To Q133)	8ch
L385	YEL	Side air-bag (L) harness (To Q134)	8ch
L389	GRY	Fuel pump wire (To R151)	
L394	BLK	Trunk room harness (To M152)	
L396	GRY	Fuel pump wire (To R152)	IF EQPD

M: Trunk room harness

No.	Color	Connective position	Remarks
M53	N	License plate light #1	
M54	N	License plate light #2	
M81	N	Trunk room lock solenoid	
M82	N	Trunk room request switch	
M152	BLK	Floor harness (To L394)	

Q: Side air-bag (R) harness

No.	Color	Connective position	Remarks
Q104	BLK	Side air-bag inflator (R)	10ch
Q133	YEL	Floor harness (To L384)	10ch

Q: Side air-bag (L) harness

No.	Color	Connective position	Remarks
Q105	BLK	Side air-bag inflator (L)	10ch
Q134	YEL	Floor harness (To L385)	10ch

9A-41 Wiring Systems:


R: Fuel pump wire

No.	Color	Connective position	Remarks
R101	BLK	Fuel pump and gauge	
R103	BLK	ELCM	IF EQPD
R151	GRY	Floor harness (To L389)	
R152	GRY	Floor harness (To L396)	IF EQPD

Rear

S7RW0C910A006

O: Rear end door harness, High mounted stop light wire, Rear end door antenna wire



I6RW0C910916-01

O: Rear end door harness

No.	Color	Connective position	Remarks
O21	N	Rear wiper motor	
O94	N	License plate light #1	
O95	N	License plate light #2	
O121	N	Rear end door switch	
O122	N	Rear end door request switch	
O181	BLK	Rear defogger (+)	
O182	BLK	Rear defogger (-)	
O231	N	Floor harness (To L390)	
O232	N	Floor harness (To L391)	IF EQPD

O: High mounted stop light wire

No.	Color	Connective position	Remarks
O92	N	High mounted stop light	
O233	N	Floor harness (To L393)	

O: Rear end door antenna wire


No.	Color	Connective position	Remarks
O186	BLK	TV antenna #3	IF EQPD
O187	BLK	TV antenna #4	IF EQPD
O240	GRY	Floor antenna wire (To L410)	IF EQPD

Ground Point


Ground (earth) Point

Refer to "Connector Layout Diagram".

S7RW0C910C001




S7RW0C910D001



9A-45 Wiring Systems:

(A) Except Taiwan
(B) Taiwan



J/B

I6RW0C910920-04


Fuses and the Protected Parts

S7RW0C910D002

The chart below describes what parts each fuse protects.

Fuses in Main Fuse Box

S7RW0C910D003




I7RW0A910908-01

No.	Fuse	Protected circuit
④3	80 A	All electric circuit
		Battery
		Generator
④4	50 A	J/B
④5	50 A	J/B

Individual Circuit Fuse Box No. 1

S7RW0C910D004




I7RW0A910963-01

No.	Fuse	Description on the cover	Protected circuit
①	15 A	FI	Main relay
②	15 A	AT	A/T relay
③	15 A	THR MOT	Throttle actuator control relay
④	20 A	A/C	A/C compressor relay
⑤	BLANK	BLANK	Condenser fan relay
⑥	30 A	BLW	BLANK
⑦	50 A	IGN	J/B
⑧	30 A	ST	IG switch
⑨	30 A	ABS SOL	Starting motor relay
⑩	30 A	RDTR	ABS control module
⑪	40 A	ABS MOT	Radiator fan relay #1
⑫	60 A	P/S	Radiator fan relay #2
⑬	BLANK	BLANK	Radiator fan relay #3
⑭	20 A	FR FOG	ABS control module
⑮	15 A	H/L L	Power steering control module
⑯	15 A	H/L R	BLANK
⑰	BLANK	BLANK	BLANK
⑱	BLANK	BLANK	BLANK

Individual Circuit Fuse Box No. 2 (In J/B (Except Taiwan))

S7RW0C910D005



I7RW01910912-02


No.	Fuse	Description on the cover	Protected circuit
①⑨	15 A	RR WIP	Rear wiper motor Rear washer motor
②⑩	15 A	IG COIL	A/F sensor Current sensor ECM Fuel pump relay Generator Heated oxygen sensor #1 Heated oxygen sensor #2 VSS ICM IG coil #1 IG coil #2 IG coil #3 IG coil #4
②①	10 A	BACK	Back-up light switch Air intake control actuator HVAC control unit HVAC control module 4WD control module KLS control module Transaxle range sensor Headlight beam leveling switch Headlight beam leveling actuator (R) Headlight beam leveling actuator (L)
②②	10 A	MTR	COMB meter Flasher relay
②③	15 A	ACC	BCM Power mirror switch ACC socket
②④	15 A	ACC 2	Rear ACC socket Audio Multi information display KLS control module

9A-49 Wiring Systems:

No.	Fuse	Description on the cover	Protected circuit
②⑤	30 A	WIP	COMB switch
			Windshield washer motor
			Windshield wiper motor
			Rear wiper relay
			DRL controller
②⑥	10 A	IG1 SIG	Power steering control module
			A/T relay
			Brake light switch
②⑦	15 A	A/B	A/B SDM
②⑧	10 A	ABS	ABS control module
			G sensor
②⑨	10 A	TAIL	COMB switch
			DRL controller
③⑩	15 A	STOP	Brake light switch
③①	20 A	D/L	BCM
③②	15 A	4WD	4WD control module
③③	10 A	ST SIG	Starting motor relay
③④	15 A	S/H	Seat heater switch (Driver side)
			Seat heater switch (Passenger side)
③⑤	10 A	IG2 SIG	Blower motor relay
③⑥	15 A	RR FOG	COMB switch
③⑦	15 A	DOME	Audio
			BCM
			COMB meter
			DLC
			ECM
			Interior light
			ICM
			TCM
			Rear interior light
			Luggage compartment light
			Main switch (Key switch)
			Multi information display
			KLS control module
③⑧	30 A	RR DEF	Rear defogger relay
			Mirror motor (R)
			Mirror motor (L)
③⑨	15 A	HORN-HAZ	Horn relay
			Flasher relay
④⑩	BLANK	BLANK	BLANK
④①	BLANK	BLANK	BLANK
④②	30 A	P/W	Power window main switch
			Front power window sub switch
			Rear power window sub switch (R)
			Rear power window sub switch (L)

Individual Circuit Fuse Box No. 2 (In J/B (Taiwan))

S7RW0C910D006



I7RW01910912-02


No.	Fuse	Description on the cover	Protected circuit
①⑨	15 A	RR WIP	Rear wiper motor Rear washer motor
②⑩	15 A	IG COIL	BCM A/F ECM Fuel pump relay Generator Heated oxygen sensor #1 Heated oxygen sensor #2 VSS ICM IG coil #1 IG coil #2 IG coil #3 IG coil #4
②①	10 A	BACK	Back-up light switch Air intake control actuator HVAC control unit HVAC control module KLS control module Transaxle range sensor
②②	10 A	MTR	COMB meter Flasher relay
②③	15 A	ACC	BCM Power mirror switch ACC socket
②④	15 A	ACC 2	Rear ACC socket Audio Multi information display KLS control module
②⑤	30 A	WIP	COMB switch Windshield washer motor Windshield wiper motor Rear wiper relay
②⑥	10 A	IG1 SIG	Power steering control module A/T relay
②⑦	15 A	A/B	A/B SDM

9A-51 Wiring Systems:

No.	Fuse	Description on the cover	Protected circuit
⑳	10 A	ABS	ABS control module G sensor
㉑	BLANK	BLANK	BLANK
㉒	15 A	STOP	Brake light switch
㉓	20 A	D/L	BCM
㉔	BLANK	BLANK	BLANK
㉕	10 A	ST SIG	Starting motor relay
㉖	BLANK	BLANK	BLANK
㉗	10 A	IG2 SIG	Blower motor relay
㉘	10 A	TAIL	Tail light relay
㉙	15 A	DOME	Audio
			BCM
			COMB meter
			DLC
			ECM
			Interior light
			ICM
			TCM
			Rear interior light
			Luggage compartment light
			Main switch (Key switch)
			Multi information display
			KLS control module
㉚	30 A	RR DEF	Rear defogger relay
			Mirror motor (R)
			Mirror motor (L)
㉛	15 A	HORN-HAZ	Horn relay
			Flasher relay
㉜	BLANK	BLANK	BLANK
㉝	BLANK	BLANK	BLANK
㉞	30 A	P/W	Power window main switch
			Front power window sub switch
			Rear power window sub switch (R)
			Rear power window sub switch (L)

Individual Circuit Fuse Box No.3 (Sedan)

S7RW0C910D012




I7RW0A910909-02

No.	Fuse	Description on the cover	Protected circuit
46	30 A	RR DEF	Rear defogger relay
47	BLANK	BLANK	BLANK

Junction Block (J/B) Connector / Fuse Layout


S7RW0C910D007

BCM side



I7RW01910913-02

Relay side




I6RW0C910921-02

Junction Block Inner Circuit (Overview (Except Taiwan))

S7RW0C910D008


Abbreviations

Abbreviation	Full term	Abbreviation	Full term
AS	Assistant (Front passenger)	LP	Lamp
CTR	Center	O/H	Over head
DR	Driver	R/B	Relay box
F-L	Front L	R-L	Rear L
F-R	Front R	R-R	Rear R
FR	Front	RR	Rear
INP	Instrument panel	S/H	Seat heater
LEV	(Headlight) leveling		




Junction Block Inner Circuit (Detail (Except Taiwan))


S7RW0C910D009




(Continued)




(Continued)




(Continued)




(Continued)




(Continued)





(Continued)



(Continued)



(Continued)




Junction Block Inner Circuit (Overview (Taiwan))

S7RW0C910D010

Abbreviations


Abbreviation	Full term	Abbreviation	Full term
AS	Assistant (Front passenger)	LP	Lamp
CTR	Center	O/H	Over head
DR	Driver	R/B	Relay box
F-L	Front L	R-L	Rear L
F-R	Front R	R-R	Rear R
FR	Front	RR	Rear
INP	Instrument panel	S/H	Seat heater
LEV	(Headlight) leveling		

*: Not used




Junction Block Inner Circuit (Detail (Taiwan))


S7RW0C910D011




(Continued)




(Continued)




(Continued)




(Continued)




(Continued)





(Continued)



(Continued)



(Continued)



System Circuit Diagram

System Circuit Diagram

S7RW0C910E001

Refer to "A-1 Cranking System Circuit Diagram".

Refer to "A-2 Charging System Circuit Diagram".

Refer to "A-3 Ignition System Circuit Diagram (M15A engine, M16A engine)".

Refer to "A-3 Ignition System Circuit Diagram (J20A engine)".

Refer to "A-4 Cooling System Circuit Diagram (M15A engine, M16A engine)".

Refer to "A-4 Cooling System Circuit Diagram (J20A engine)".

Refer to "A-5 Engine and A/C Control System Circuit Diagram (M15A engine)".

Refer to "A-5 Engine and A/C Control System Circuit Diagram (M16A engine)".

Refer to "A-5 Engine and A/C Control System Circuit Diagram (J20A engine)".

Refer to "A-6 A/T Control System Circuit Diagram".

Refer to "A-7 Immobilizer System Circuit Diagram".

Refer to "A-8 Body Control System Circuit Diagram (Except Taiwan)".

Refer to "A-8 Body Control System Circuit Diagram (Taiwan)".

Refer to "A-10 4WD Control System (Except Taiwan)".

Refer to "B-1 Windshield Wiper and Washer Circuit Diagram".

Refer to "B-2 Rear Wiper and Washer Circuit Diagram (Except Taiwan)".

Refer to "B-2 Rear Wiper and Washer Circuit Diagram (Taiwan)".

Refer to "B-3 Rear Defogger Circuit Diagram (Hatchback (Except Taiwan))".

Refer to "B-3 Rear Defogger Circuit Diagram (Hatchback (Taiwan))".

Refer to "B-3 Rear Defogger Circuit Diagram (Sedan)".

Refer to "B-4 Power Window Circuit Diagram".

Refer to "B-5 Power Door Lock Circuit Diagram (Except Taiwan)".

Refer to "B-5 Power Door Lock Circuit Diagram (Taiwan)".

Refer to "B-6 Power Mirror Circuit Diagram (Hatchback (Except Taiwan))".

Refer to "B-6 Power Mirror Circuit Diagram (Hatchback (Taiwan))".

Refer to "B-6 Power Mirror Circuit Diagram (Sedan (Except Taiwan))".

Refer to "B-6 Power Mirror Circuit Diagram (Sedan (Taiwan))".

Refer to "B-7 Horn Circuit Diagram".

Refer to "B-8 Seat Heater Circuit Diagram".

Refer to "B-9 Keyless Start System Circuit Diagram".

Refer to "C-1 Combination Meter Circuit Diagram (Meter)".

Refer to "C-2 Combination Meter Circuit Diagram (Indicator)".

Refer to "C-3 Combination Meter Circuit Diagram (Warning Light)".

Refer to "D-1 Headlight System Circuit Diagram (Except Taiwan)".

Refer to "D-1 Headlight System Circuit Diagram (Taiwan)".

Refer to "D-2 Position, Tail and Licence Plate Light System Circuit Diagram (Hatchback (Except Taiwan))".

Refer to "D-2 Position, Tail and Licence Plate Light System Circuit Diagram (Sedan (Except Taiwan))".

Refer to "D-2 Position, Tail and Licence Plate Light System Circuit Diagram (Hatchback (Taiwan))".

Refer to "D-2 Position, Tail and Licence Plate Light System Circuit Diagram (Sedan (Taiwan))".

Refer to "D-3 Front Fog Light System Circuit Diagram (Except Taiwan)".

Refer to "D-3 Front Fog Light System Circuit Diagram (Taiwan)".

Refer to "D-4 Illumination Light System Circuit Diagram (Except Taiwan)".

Refer to "D-4 Illumination Light System Circuit Diagram (Taiwan)".

Refer to "D-5 Interior Light System Circuit Diagram (Hatchback (Except Taiwan))".

Refer to "D-5 Interior Light System Circuit Diagram (Hatchback (Taiwan))".

Refer to "D-5 Interior Light System Circuit Diagram (Sedan (Except Taiwan))".

Refer to "D-5 Interior Light System Circuit Diagram (Sedan (Taiwan))".

Refer to "D-6 Turn Signal and Hazard Warning Light System Circuit Diagram (Hatchback (Except Taiwan))".

Refer to "D-6 Turn Signal and Hazard Warning Light System Circuit Diagram (Sedan (Except Taiwan))".

Refer to "D-6 Turn Signal and Hazard Warning Light System Circuit Diagram (Hatchback (Taiwan))".

Refer to "D-6 Turn Signal and Hazard Warning Light System Circuit Diagram (Sedan (Taiwan))".

Refer to "D-7 Brake Light System Circuit Diagram (Hatchback)".

Refer to "D-7 Brake Light System Circuit Diagram (Sedan)".

Refer to "D-8 Back-Up Light System Circuit Diagram (Hatchback)".

Refer to "D-8 Back-Up Light System Circuit Diagram (Sedan)".

Refer to "D-9 Headlight Beam Leveling System Circuit Diagram (Manual Leveling)".

9A-69 Wiring Systems:

Refer to “D-10 Rear Fog Light Circuit Diagram (Hatchback)”.

Refer to “D-10 Rear Fog Light Circuit Diagram (Sedan)”.

Refer to “E-1 Heater System Circuit Diagram”.

Refer to “E-2 Auto A/C System Circuit Diagram”.

Refer to “F-1 Air-Bag System Circuit Diagram (4ch)”.

Refer to “F-1 Air-Bag System Circuit Diagram (8ch)”.

Refer to “F-2 Anti-Lock Brake System Circuit Diagram”.

Refer to “F-3 Electronic Stability Program System Circuit Diagram”.

Refer to “F-4 Power Steering System Circuit Diagram”.


Refer to “G-1 Audio System Circuit Diagram”.

Refer to “G-2 Multi Information Display / Accessory Socket System Circuit Diagram”.

Refer to “G-4 Navigation System Circuit Diagram”.


A-1 Cranking System Circuit Diagram

- Ⓐ M15A engine, M16A engine
 Ⓑ J20A engine




A-2 Charging System Circuit Diagram

S7RW0C910E003



A-3 Ignition System Circuit Diagram (J20A engine)


S7RW0C910E005



I7RW0A910970-03


A-4 Cooling System Circuit Diagram (M15A engine, M16A engine)

S7RW0C910E006




A-4 Cooling System Circuit Diagram (J20A engine)


S7RW0C910E007





I7RW01910924-02

I7RW0A910910-03











ESP® is a registered trademark of Daimler Chrysler AG.
17RW0A910913-03


A-5 Engine and A/C Control System Circuit Diagram (M16A engine)


S7RW0C910E009




I7RW0A910914-04










I7RW0A910918-03










ESP® is a registered trademark of Daimler Chrysler AG.

17RW0A910921-03


A-6 A/T Control System Circuit Diagram

S7RW0C910E011

- Ⓐ M15A engine, M16A engine
 Ⓑ J20A engine




I7RW0A910922-03



A-7 Immobilizer System Circuit Diagram

S7RW0C910E012

- (A) J/B side connector (BCM)
 (B) Except Taiwan
 (C) Taiwan
 (D) Except M16A engine M/T
 (E) M16A engine M/T




I7RW0A910924-03


A-8 Body Control System Circuit Diagram (Except Taiwan)

S7RW0C910E013


- (A) J/B side connector (BCM)
 (B) Except M16A engine M/T
 (C) M16A engine M/T




I7RW0A910925-03






④ J/B side connector (BCM)





Ⓐ J/B side connector (BCM)
















B-1 Windshield Wiper and Washer Circuit Diagram

S7RW0C910E016


☐ (A) RHD
☐ (B) LHD





B-2 Rear Wiper and Washer Circuit Diagram (Taiwan)


S7RW0C910E018



I7RW0A910973-02

B-3 Rear Defogger Circuit Diagram (Hatchback (Except Taiwan))

S7RW0C910E019




I7RW0A910974-02

B-3 Rear Defogger Circuit Diagram (Sedan)

S7RW0C910E057

- (A) Manual A/C
 (B) Auto A/C
 (C) J/B side connector (BCM)
 (D) Except Taiwan
 (E) Taiwan




I7RW0A910976-04


B-4 Power Window Circuit Diagram

S7RW0C910E021


Ⓐ RHD
Ⓑ LHD




I7RW0A910933-02





I7RW0A910977-02






I7RW0A910978-03






I7RW0A910979-03




B-6 Power Mirror Circuit Diagram (Hatchback (Taiwan))


S7RW0C910E025



I7RW0A910980-03


I7RW0A910A01-03





B-7 Horn Circuit Diagram


S7RW0C910E026




I7RW0A910981-02

B-8 Seat Heater Circuit Diagram

S7RW0C910E027




I7RW0A910936-04



C-1 Combination Meter Circuit Diagram (Meter)


S7RW0C910E029





I7RW0A910937-03

C-2 Combination Meter Circuit Diagram (Indicator)

S7RW0C910E030









ESP® is a registered trademark of Daimler Chrysler AG.
17RW0A910940-03

D-1 Headlight System Circuit Diagram (Except Taiwan)

S7RW0C910E032




With DRL controller



D-1 Headlight System Circuit Diagram (Taiwan)


S7RW0C910E033



I6RW0C910977-01

D-2 Position, Tail and Licence Plate Light System Circuit Diagram (Hatchback (Except Taiwan))


S7RW0C910E034



I7RW0A910982-03

D-2 Position, Tail and Licence Plate Light System Circuit Diagram (Sedan (Except Taiwan))


S7RW0C910E064



I7RW0A910983-03

D-2 Position, Tail and Licence Plate Light System Circuit Diagram (Hatchback (Taiwan))


S7RW0C910E035



I6RW0C910980-01

D-2 Position, Tail and Licence Plate Light System Circuit Diagram (Sedan (Taiwan))


S7RW0C910E058



I7RW0A910941-02

D-3 Front Fog Light System Circuit Diagram (Except Taiwan)


S7RW0C910E036



I6RW0C910983-01


D-3 Front Fog Light System Circuit Diagram (Taiwan)

S7RW0C910E037




I6RW0C910982-01

I7RW0A910942-03




D-4 Illumination Light System Circuit Diagram (Taiwan)

S7RW0C910E039




I7RW0A910984-02

I7RW0A910985-03



D-5 Interior Light System Circuit Diagram (Hatchback (Taiwan))


S7RW0C910E041



I7RW0A910987-03

D-5 Interior Light System Circuit Diagram (Sedan (Except Taiwan))


S7RW0C910E065



I7RW0A910986-04

D-5 Interior Light System Circuit Diagram (Sedan (Taiwan))

S7RW0C910E059




I7RW0A910943-04


D-6 Turn Signal and Hazard Warning Light System Circuit Diagram (Hatchback (Except Taiwan))

S7RW0C910E042

- (A) J/B side connector (BCM)
 (B) RHD
 (C) LHD




I7RW0A910988-02




D-6 Turn Signal and Hazard Warning Light System Circuit Diagram (Sedan (Except Taiwan))


S7RW0C910E066

- (A) J/B side connector (BCM)
 (B) RHD
 (C) LHD




I7RW0A910989-02






D-6 Turn Signal and Hazard Warning Light System Circuit Diagram (Sedan (Taiwan))

S7RW0C910E060




I7RW0A910944-03




D-7 Brake Light System Circuit Diagram (Hatchback)

S7RW0C910E044



D-7 Brake Light System Circuit Diagram (Sedan)


S7RW0C910E061



D-8 Back-Up Light System Circuit Diagram (Hatchback)

S7RW0C910E045

- Ⓐ M15A engine, M16A engine
 Ⓑ J20A engine




I7RW0A910A05-02

D-8 Back-Up Light System Circuit Diagram (Sedan)


S7RW0C910E062

- Ⓐ M15A engine, M16A engine
 Ⓑ J20A engine




D-9 Headlight Beam Leveling System Circuit Diagram (Manual Leveling)


S7RW0C910E046



I6RW0D910921-01




I7RW0A910991-01




E-1 Heater System Circuit Diagram

S7RW0C910E048


- (A) Except Taiwan
(B) Taiwan






E-2 Auto A/C System Circuit Diagram

S7RW0C910E049




I7RW0A910993-03



F-1 Air-Bag System Circuit Diagram (4ch)


S7RW0C910E050



I7RW0A910994-02


F-1 Air-Bag System Circuit Diagram (8ch)

S7RW0C910E051




I7RW0A910995-02

- (A) J/B side connector (BCM)
 (B) Except M16A engine M/T
 (C) M16A engine M/T
 (D) RHD
 (E) LHD



F-2 Anti-Lock Brake System Circuit Diagram


S7RW0C910E052




I7RW0A910996-02


9A-161 Wiring Systems:

Ⓐ M16A engine M/T




I7RW0A910951-03






F-4 Power Steering System Circuit Diagram


S7RW0C910E053





G-1 Audio System Circuit Diagram

S7RW0C910E054




I7RW0A910953-02




G-2 Multi Information Display / Accessory Socket System Circuit Diagram

S7RW0C910E055





G-4 Navigation System Circuit Diagram

S7RW0C910E056



I7RW0A910956-02

- (A) RHD
 (B) LHD
 (C) Except Taiwan
 (D) Taiwan
 (E) Without ILL cancel switch
 (F) With ILL cancel switch



List of Connector

List of Connectors

S7RW0C910F001

Refer to "C Connector".

Refer to "E Connector".

Refer to "G Connector".

Refer to "J Connector".

Refer to "K Connector".

Refer to "L Connector".

Refer to "M Connector (Sedan)".

Refer to "O Connector (Hatchback)".

Refer to "Q Connector (8ch)".










Refer to "R Connector".

Refer to "S Connector".

C Connector




S7RW0C910F002

C01		C06			
1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16 17 18 19 20 21 22 23 24 25 26 27 28 29 30 31 32 33 34 35 36 37 38 39 40 41 42 43 44 45 46 47 48 49 50 51 52 53 54 55 56 57 58 59 60 MCONF600002-01		1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16 17 18 19 20 21 22 23 24 MCONF240020-01			
		A/T			
C07	C31	C31	C32	C32	C32
1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16 17 18 19 20 21 22 23 24 25 26 MCONF260020-01 A/T	1 2 3 MCONF030103-02 M15A engine, M16A engine	1 2 3 MCONF030038-01 J20A engine	1 2 3 MCONF030123-01 With OCV	1 2 3 MCONF030103-02 Without OCV	
C32	C34	C36	C37	C39	C40
1 2 3 MCONF030053-01 J20A engine	1 2 3 MCONF030103-02 A/T	1 2 3 MCONF030030-01 M15A engine, M16A engine	1 MCONF010054-01	1 2 MCONF020042-01	1 2 3 4 MCONF040102-02 M15A engine
C40	C42	C42	C43	C44	C45
1 2 3 4 MCONF040024-01 J20A engine	1 2 3 4 MCONF040024-01 M15A engine	1 2 3 4 MCONF040102-02 M16A engine, J20A engine	1 2 3 4 MCONF040024-01 M16A engine	1 2 MCONF020150-01 A/T	1 2 MCONF020150-01 J20A engine A/T
C46	C47	C47	C48	C64	
1 2 3 MCONF030040-01 M15A engine, J20A engine	1 2 3 4 5 MCONF050025-01 M15A engine, M16A engine	1 2 3 4 5 MCONF050050-01 J20A engine	1 2 3 4 5 6 MCONF060068-01	1 2 MCONF020150-01 J20A engine	




















C91  MCONF020266-01	C92  MCONF020266-01	C93  MCONF020266-01	C94  MCONF020266-01	C101  MCONF030055-01 M15A engine, M16A engine	C101  MCONF030103-02 J20A engine
C102  MCONF030055-01 M15A engine, M16A engine	C102  MCONF030103-02 J20A engine	C103  MCONF030103-02 J20A engine	C104  MCONF030103-02 J20A engine	C122  MCONF060018-01 IF EQPD	C123  MCONF020042-01 M15A engine, M16A engine
C123  MCONF020150-01 J20A engine	C124  MCONM020033-01 IF EQPD	C139  MCONF100049-01 M15A engine A/T, M16A engine A/T	C139  MCONF080028-02 J20A engine A/T	C141  MCONF010076-01	C162  MCONF010030-01
C163  MCONF010001-01 J20A engine	C165  MCONF020176-01 M/T	C166  MCONF090011-01 M15A engine A/T, M16A engine A/T	C166  MCONF110011-02 J20A engine A/T	C192  MCONF010057-03	C194  MCONF040127-01
C195  MCONF010021-01	C196  MCONF010057-03	C282  MCONF010078-01	C283  MCONF010074-01	C343 (TO E371)  MCONF200011-01	






E Connector

S7RW0C910F003

E01  MCONF600002-01	E04  MCONF140012-01 Except Taiwan	
E08  MCONF260018-01	E11  MCONF200029-01	E12  MCONF020204-01

9A-173 Wiring Systems:

E13  MCONF020185-01	E31  MCONF060052-01	E33  MCONM020033-01	E35  MCONM020033-01	E36  MCONF030062-01	E37  MCONF020200-01
E40  MCONF020199-01	E61  MCONF020205-01	E62  MCONF020008-01	E63  MCONF020008-01	E64  MCONF050027-01	E65  MCONF020183-01 M16A engine
E65  MCONF040130-01 J20A engine	E68  MCONF030128-01 IF EQPD	E69  MCONF030128-01 IF EQPD	E70  MCONF020183-01	E151  MCONF030101-01	E152  MCONF030101-01
E159  MCONF020289-01	E160  MCONF020289-01	E161  MCONF020013-01	E162  MCONF020013-01	E163  MCONF020162-01	E164  MCONF020162-01
E165  MCONF020196-01	E166  MCONF020196-01	E181  MCONF040045-01	E183  MCONF020115-01	E191  MCONF060068-01	
E192  MCONF020151-01 J20A engine	E221  MCONF040131-01	E222  MCONF050044-01	E223  MCONF050044-01 J20A engine	E224  MCONF050044-01 J20A engine	E225  MCONF040131-01
E226  MCONF040131-01	E227  MCONF040131-01	E229  MCONF040131-01	E230  MCONF040131-01	E231  MCONF040131-01 A/T	E232  MCONF050044-01 IF EQPD
E233  MCONF050044-01 IF EQPD	E234  MCONF040131-01	E241  MCONF050044-01 A/T	E247  MCONF050044-01 IF EQPD	E248  MCONF050044-01 IF EQPD	E281  MCONF010079-01
E311  MCONF020201-01	E312  MCONF020202-01	E323  MCONF100054-01	E324  MCONF020202-01	E325  MCONF160034-01	

E371 (TO C343)  MCONM200005-01	E377 (TO E378)  MCONM080012-01	E378 (TO E377)  MCONF080050-01	E381 (TO G333)  MCONM180001-01	
E382 (TO G334)  MCONM200004-01	E387 (TO L371)  MCONF200008-01	E388 (TO L372)  MCONF020151-01		













G Connector

S7RW0C910F004

G04 1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16 17 18 19 20 21 22 MCONF220009-01 Except Taiwan		G04 1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16 17 18 19 20 21 22 23 24 MCONF240014-01 Taiwan			
G05 1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16 17 18 19 20 21 22 23 24 25 26 27 28 29 30 31 32 33 34 35 36 37 38 39 40 MCONF400005-01 Taiwan		G06 1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 MCONF150005-01 Taiwan			
G14 1 2 3 4 5 6 7 8 9 MCONF240015-01 IF EQPD		G16 1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16 17 18 19 20 21 22 23 24 25 26 27 28 29 30 31 32 33 34 35 36 37 38 39 40 MCONF400005-01 IF EQPD			
G17 1 2 3 4 5 6 7 8 9 10 11 12 MCONF120051-01	G20 1 2 3 4 5 6 7 8 9 10 11 12 13 14 MCONF300004-01 Auto A/C				
G26 1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16 17 18 19 20 21 22 23 24 25 26 MCONF260010-01 IF EQPD		G32 1 2 3 MCONF030078-01	G33 1 2 3 4 5 6 7 8 9 10 MCONF100064-01 IF EQPD		
G34 1 2 MCONF020111-01 Auto A/C	G35 1 2 MCONF020111-01 Auto A/C	G61 1 2 MCONF020008-01	G62 1 2 3 4 5 6 MCONF060093-01 Auto A/C	G63 1 2 3 4 5 6 MCONF060093-01 Auto A/C	G64 1 2 3 4 5 6 MCONF060093-01 Auto A/C












9A-175 Wiring Systems:





G65 1 2 3 4 MCONF040009-01 Auto A/C	G65 1 2 3 4 MCONF040142-01 Manual A/C	G141 1 2 3 4 5 6 7 8 9 10 MCONF100038-01	G144 1 2 5 6 7 8 9 10 11 12 13 MCONF130010-01		
G146 1 2 4 5 6 7 8 MCONF080050-01	G147 1 2 3 4 5 6 MCONF060063-01	G150 1 2 4 5 6 7 8 MCONF080002-01 IF EQPD	G151 1 2 4 5 6 7 8 MCONF080002-01 IF EQPD	G152 1 3 4 5 6 MCONF060025-01 IF EQPD	G153 1 2 3 4 MCONF040098-01
G154 1 2 3 7 8 9 10 11 12 13 14 MCONF140018-01 Manual A/C	G155 1 4 5 6 7 MCONF070016-01 Manual A/C	G211 1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16 MCONF160023-01	G214 1 2 3 4 5 6 7 8 9 10 MCONF100060-01 IF EQPD		
G241 1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16 17 18 19 20 21 22 23 24 25 26 27 28 29 30 31 32 MCONF320015-01	G243 1 2 3 4 5 MCONF050021-01 IF EQPD	G248 1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16 17 18 19 20 MCONF200012-01			
G251 1 2 MCONF020304-01	G253 1 2 3 4 5 6 7 MCONF070004-01	G254 1 2 3 4 MCONF040096-01 IF EQPD	G255 1 2 (➔) MCONF020147-01 Auto A/C	G259 1 2 MCONF020235-01	
G265 1 MCONF010010-01 Taiwan	G266 1 2 3 4 MCONF040146-01 IF EQPD	G267 1 2 MCONF020305-01 With Navigation	G267 ① MCONF010040-01 Without Navigation	G271 1 2 3 4 5 6 7 8 9 10 11 12 MCONF120028-01	
G272 1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16 17 18 19 20 MCONF200020-01	G273 1 2 3 4 5 6 MCONF060064-01	G306 A A A A A B B B B B C C C C C D D D D D • • • • • • • • • • • • • • • • • • • • MCONF220018-01			
G307 A A B A A B B B B C C • • • • • • • • • • • • • • • • MCONF130019-01 IF EQPD	G308 A A B A A B B B B C C • • • • • • • • • • • • • • • • MCONF130019-01	G309 A A A A A A B B B B B • • • • • • • • • • • • • • • • MCONF130021-01			

G310  MCONF070023-01 Auto A/C	G311  MCONF130021-01	G333 (TO E381)  MCONF180012-01		
G334 (TO E382)  MCONF200008-01	G335 (TO E383)  MCONF100060-01 IF EQPD	G341 (TO L374)  MCONM140005-02		
G342 (TO L375)  MCONM200008-01 IF EQPD	G343 (TO L376)  MCONM200005-01	G344 (TO L377)  MCONM020065-01	G345 (TO L378)  MCONM020065-01	G346 (TO S171)  MCONF120052-01 With auto cruise
G346 (TO S171)  MCONF060080-01 Without auto cruise	G347 (TO S172)  MCONF040099-01 With auto cruise	G347 (TO S172)  MCONF020212-01 Without auto cruise	G348 (TO K153)  MCONM010017-01	G349 (TO L399)  MCONF020151-01 Taiwan
G352 (TO L402)  MCONM140005-02 IF EQPD	G354 (TO K154)  MCONF010046-01	G355 (TO L409)  MCONM040035-01 IF EQPD		

J Connector

S7RW0C910F005

J21  MCONF020236-01 Type A	J21  MCONF060087-01 Type B	J22  MCONF020236-01	J25  MCONF020236-01	J26  MCONF020236-01	J27  MCONM070004-01
J28  MCONM070004-01	J31  MCONF100054-01	J32  MCONF100054-01	J35  MCONF100054-01	J36  MCONF100054-01	
J81  MCONF180006-01	J82  MCONF050001-01	J83  MCONF050001-01	J84  MCONF050001-01	J85  MCONM020016-01 IF EQPD	
J86  MCONM020016-01 IF EQPD	J87  MCONF130011-01	J141  MCONF020008-01	J142  MCONF020008-01	J145  MCONF020008-01	

J146  MCONF020008-01	J147  MCONF020159-01 IF EQPD	J148  MCONF020159-01 IF EQPD	J151  MCONF020159-01 IF EQPD	J152  MCONF020159-01 IF EQPD	J153  MCONM020018-01 IF EQPD
J154  MCONM020018-01 IF EQPD	J215 (L379)  MCONM340003-02	J216 (L380)  MCONM340003-02	J217 (TO L381)  MCONF100060-01	J218 (TO L382)  MCONF100060-01	



K Connector











S7RW0C910F006

K51  MCONF030134-01	K52  MCONF020157-01	K121  MCONM020068-01 Hatchback	K121  MCONM020065-01 Sedan	K152 (TO L383)  MCONM030021-01 Hatchback	K152 (TO L383)  MCONF030134-01 Sedan
K153 (TO G348)  MCONF010010-01	K154 (TO G354)  MCONM010040-01				





L Connector

S7RW0C910F007

L01  MCONF180012-01 Except Taiwan	L04  MCONF510001-01
---	---



L31  MCONM020066-01	L32  MCONM020066-01	L33  MCONF030123-01 IF EQPD	L34  MCONF040122-01 IF EQPD	L35  MCONF020210-01 8ch	L36  MCONF020210-01 8ch
L37  MCONM030023-01 IF EQPD	L40  MCONF020042-01 IF EQPD	L101  MCONF060044-01	L102  MCONM020058-01 IF EQPD	L132  MCONF020211-01 Hatchback	
L133  MCONF060044-01 Hatchback	L133  MCONM060012-01 Sedan	L134  MCONF060044-01 Hatchback	L134  MCONM060012-01 Sedan	L139  MCONF020013-01 Sedan	L141  MCONF020013-01 Sedan
L161  MCONF010100-01	L162  MCONF010100-01	L163  MCONF010100-01	L164  MCONF010100-01	L167  MCONF010021-01	L169  MCONF060025-01 IF EQPD
L170  MCONF020268-01	L171  MCONF060025-01 IF EQPD	L172  MCONF060025-01 IF EQPD	L173  MCONM010013-01 Sedan	L174  MCONF060025-01 IF EQPD	L233  MCONF050044-01 Sedan
L281  MCONF040132-01 IF EQPD	L282  MCONF040132-01 IF EQPD	L283  MCONF020209-01	L285  MCONF020209-01	L290  MCONF020207-01 Sedan	L291  MCONF020207-01 Sedan
L292  MCONF020266-01 IF EQPD	L293  MCONF020228-01 IF EQPD	L294  MCONF020228-01 IF EQPD	L296  MCONF020304-01 IF EQPD	L299  MCONF010021-01 Sedan	L300  MCONF010021-01 Sedan
L301  (→) MCONF020147-01	L303  MCONM010004-01 Sedan	L307  MCONF010021-01 IF EQPD	 MCONF010021-01 IF EQPD	L312  MCONF060078-01	L313  MCONF040033-01
L314  MCONF180013-01	L315  MCONF160014-01	L317  MCONF040156-01 Sedan			

L346 A A B B C C D D E E F F MCONF120055-01	L347 A A B B C C D D E E F F MCONF120055-01	L348 A A A A A A B B B B B MCONF130021-01			
L371 (TO E387) 6 5 4 13 12 11 10 9 8 7 20 19 18 17 16 15 14 MCONM200004-01	L372 (TO E388) 2 1 MCONM020057-01	L374 (TO G341) 1 2 3 4 5 6 7 8 9 10 11 12 13 14 MCONF140012-01			
L375 (TO G342) 1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16 17 18 19 20 MCONF200021-01	L376 (TO G343) 1 2 5 6 7 8 9 10 11 12 13 14 15 16 17 18 19 20 MCONF200011-01	L377 (TO G344) 1 2 MCONF020212-01	L378 (TO G345) 1 2 MCONF020212-01	L379 (J215) 14 26 13 25 24 6 12 23 34 5 11 22 33 4 11 21 32 3 31 30 2 10 20 29 1 9 19 28 8 17 16 7 15 MCONF340006-01	
IF EQPD					
L380 (J216) 14 26 13 25 24 6 12 23 34 5 11 22 33 4 11 21 32 3 31 30 2 10 20 29 1 9 19 28 8 17 16 7 15 MCONF340006-01	L381 (TO J217) 5 4 3 2 1 10 9 8 7 6 MCONM100010-01	L382 (TO J218) 5 4 3 2 1 10 9 8 7 6 MCONM100010-01	L383 (TO K152) 1 2 3 MCONF030134-01	L383 (TO K152) 3 2 1 MCONM030021-01	L384 (TO Q133) 1 2 MCONF020212-01
		Hatchback	Sedan	8ch	

L385 (TO Q134)  MCONF020212-01 8ch	L389 (TO R151)  MCONF040123-01 Hatchback	L390 (TO O231)  MCONM080013-01 Hatchback	L391 (TO O232)  MCONM020056-01 IF EQPD	L393 (TO O233)  MCONM020057-01 Hatchback	L394 (TO M152)  MCONF060065-01 Sedan
L395 (TO Q132)  MCONF040099-01 8ch	L397 (TO L408)  MCONM040030-01 IF EQPD	L399 (TO G349)  MCONM020057-01 IF EQPD	L402 (TO G352)  MCONF140012-01 IF EQPD	L408 (TO L397)  MCONF040092-01 IF EQPD	L409 (TO G355)  MCONF040146-01 IF EQPD
L410 (TO O240)  MCONM020067-01 IF EQPD					



M Connector (Sedan)

S7RW0C910F012

M53  MCONF020013-01	M54  MCONF020013-01	M81  MCONF020151-01	M82  MCONM040028-01	M152 (TO L394)  MCONM060036-01
---	---	---	--	--







O Connector (Hatchback)

S7RW0C910F008

O21  MCONF040012-01	O92  MCONF020026-01	O94  MCONF020013-01	O95  MCONF020013-01	O121  MCONF040093-01	O122  MCONM040028-01
O181  MCONF010021-01	O182  MCONF010021-01	O186  MCONF010021-01 IF EQPD	O187  MCONF010021-01 IF EQPD	O231 (TO L390)  MCONF080026-01	O232 (TO L391)  MCONF020267-01 IF EQPD
O233 (TO L393)  MCONF020151-01	O240 (TO L410)  MCONF020305-01 IF EQPD				

Q Connector (8ch)

S7RW0C910F009

Q102  MCONF020207-01 Hatchback	Q103  MCONF020207-01 Hatchback	Q104  MCONF020207-01	Q105  MCONF020207-01	Q132 (TO L395)  MCONM040026-01	Q133 (TO L384)  MCONM020065-01
Q134 (TO L385)  MCONM020065-01					








R Connector

S7RW0C910F010

R101  MCONF040145-01	R151 (L389)  MCONM040027-01
---	--

S Connector

S7RW0C910F011

S61  MCONF120052-01 With auto cruise	S61  MCONF060080-01 Without auto cruise	S121  MCONF040099-01 With auto cruise	S121  MCONF020207-01 Without auto cruise	S171 (TO G346)  MCONM120007-01 With auto cruise
S171 (TO G346)  MCONM060037-01 Without auto cruise	S172 (TO G347)  MCONM040026-01 With auto cruise	S172 (TO G347)  MCONM020065-01 Without auto cruise		

Lighting Systems

Precautions

Precautions for Discharge Headlight Service (If Equipped)

S7RW0C9200001

⚠ WARNING

- Do not touch igniter or ballast when lighting switch is at “HEAD” position to avoid possible electric shock.
- Do not measure voltage or resistance with tester connected to output connector of ballast or igniter to avoid possible electric shock.
- Do not perform work where exposed to water including rain or with wet hands to avoid possible electric shock.
- Disassembling igniter or ballast is strictly prohibited as it may cause an electric shock.
- Before inspecting or repairing discharge headlight or its peripheral parts, make sure that lighting switch is at OFF position and battery is disconnected at negative terminal to avoid possible electrical shock.
- Do not set lighting switch to “HEAD” position with connector disconnected or any part removed to avoid possible electric shock.
- Do not touch glass surface of headlight bulb. Oil or grease attached on it may not only make bulb service life shorter but also cause bulb to burst when lighting switch is turned on.
- Mercury, metal iodide and xenon gas are sealed in discharge headlight bulb. Be sure to dispose of used discharge headlight bulb properly according to applicable rules or regulations.

Precautions in Diagnosing Troubles (Headlight Auto Leveling System)

S7RW0C9200002


- Be sure to read “Precautions for Electrical Circuit Service in Section 00” before inspection and observe what is written there.
- Replacement of height sensor and headlight leveling control module. When height sensor and/or headlight leveling control module is replaced with new one, perform initialization of headlight auto leveling system according to “Initialization of Headlight Auto Leveling System”.

General Description

Discharge Headlight Description (If Equipped)

S7RW0C9201001

Discharge headlight provides more brightness and consumes less electricity as compared with the conventional halogen headlight. It consists of a ballast (1), igniter (2) and discharge headlight bulb (3).



I6RW0C920001-01

Ballast


Ballast makes the voltage from the battery rise and converts the current from DC to AC. It also outputs high voltage to the igniter when the headlight is turned on and supplies to discharge headlight bulb with necessary voltage for continuous lighting while it is lit.

Igniter

Igniter generates high voltage needed to turn on the discharge headlight. It is charged with high voltage raised by the ballast and it applies voltage pulse as high as about 20,000V to the tungsten electrode in the discharge headlight bulb. After the discharge headlights light up, the ballast supplies voltage to bulbs.

Discharge headlight bulb

Discharge headlight bulb is used for the low beam. It does not have a filament but xenon gas (1), mercury (3) and metal iodide (2) sealed in it. It lights up when its tungsten electrodes (4) apply high voltage to these contents.



I5JB0A920001-01

Fail-safe function of discharge headlight


As the ballast has a fail-safe function which stops supply of the voltage to the igniter when it detects any of the following condition.

- Ignition switch is set to "HEAD" position while igniter is not connected to discharge headlight bulb
- Discharge headlight does not light up even when lighting switch is set to "HEAD" position.
- Ballast detects a short in the circuit between discharge headlight bulb and ballast when lighting switch is at "HEAD" position.

Headlight Auto Leveling System Description (If Equipped)


S7RW0C9201002

Headlight Auto Leveling System adjusts the optical axis of the headlight automatically to be suitable for the varied vehicle position while the headlights are lit. It consists of front height sensor (1), rear height sensor (2), headlight leveling control module (3), headlight leveling actuator (4) and headlight leveling warning light (5).



I6RW0C920002-01

With more passenger(s) or luggage in the vehicle, the vehicle position differs from that in such vehicle state with one person and no load in the vehicle and angle of the headlight optical axis varies accordingly. This system automatically adjusts the varied angle to maintain the optical axis properly.




I6RW0C920003-01

[A]:	Optical axis of headlight in standard position
[B]:	Corrected optical axis of headlight

9B-4 Lighting Systems:

Front and rear height sensors

Front height sensor (1) is installed to the front suspension frame (2) respectively and connected to the lower arm (4) with the link (3). Also rear height sensor is installed to the rear floor center cross member (5) respectively and connected to the rear axle (6) with the link (3). Each height sensor converts vertical movement of the lower arm into the resistance value and outputs the detected change in the vehicle position as a voltage signal to the headlight leveling control module.



I6RW0C920004-01

Headlight leveling control module

Headlight leveling control module is installed at the inside of the glove box. It uses the headlight ON signal from the lighting switch, vehicle speed signal from BCM and vehicle position signal from height sensors to calculate the angle of the headlight optical axis to be corrected. Then it adjusts the optical axis angle of headlight based on the calculated angle value by driving the headlight leveling actuator so that proper headlight aiming is obtained. Also, when any abnormality is detected in the system, the headlight leveling control module makes the headlight leveling warning light in the combination meter light up to warn the driver of an abnormality in the system.


Fail-safe function of headlight leveling control module

Headlight leveling control module has a fail-safe function which operates as follows.

Detecting condition	Fail-safe operation	Warning light
Power voltage supplied to headlight leveling control module is higher than 18.5V	Stops headlight leveling actuator operation.	OFF
Power voltage supplied to headlight leveling control module is lower than 9V	Stops headlight leveling actuator operation.	OFF
Vehicle speed is 180km/h or higher	Stops headlight leveling actuator operation.	OFF
Voltage supplied to height sensor is lower than 4.6V	Stops headlight leveling actuator operation.	ON
Signal voltage from height sensor is higher than 4.75V or lower than 0.25V	Stops headlight leveling actuator operation.	ON
Abnormality in headlight leveling control module is detected	Resets microcomputer in headlight leveling control module.	ON
Correction value calculated by headlight leveling control module exceeds operation range of headlight leveling actuator	Drives headlight leveling actuator within its operation range.	OFF

Headlight leveling actuator


Headlight leveling actuator is (1) located in the headlight housing (2). It moves the reflector (3) in the headlight housing according to the drive signal from the headlight leveling control module so as to adjust the optical axis of the headlight to the angle calculated by the headlight leveling control module.



Auto-On Headlight System Description (If Equipped)

S7RW0C9201003


The auto-on headlight is controlled by auto-on headlight controller (1) and works as follows. Under such conditions as the ignition switch turned ON and the lighting switch (2) turned to the “AUTO” position, when illuminance to the auto-on headlight sensor (3) becomes lower than the specified value, the headlights and clearance lights are turned ON by auto-on headlight controller. On the other hand, when illuminance to the auto-on headlight sensor becomes higher than the specified value under the same conditions, the headlights and clearance lights are turned OFF by auto-on headlight controller.



Schematic and Routing Diagram

Headlight Auto Leveling System Wiring Circuit Diagram

S7RW0C9202001



I6RW0C920007-01

[A]: Headlight leveling control module connector (viewed from harness side)	4. BCM	8. Headlight leveling warning light
1. Headlight leveling control module	5. Right headlight leveling actuator	9. Ignition switch
2. Front height sensor	6. Left headlight leveling actuator	10. Lighting switch
3. Rear height sensor	7. Combination meter	11. Diagnosis connector


Component Location

Lighting System Components Location

S7RW0C9203001

NOTE

Below figure shows left-hand steering vehicle. For right-hand steering vehicle, parts with (*) are installed at the opposite side.




9B-8 Lighting Systems:

[A]: Discharge headlight model	9. Front fog light (if equipped)	21. Turn signal / hazard warning relay
[B]: Other than discharge headlight model	10. Rear combination light	22. Tail light relay (junction block without BCM type)
[C]: Junction block without BCM type	11. Rear fog light (if equipped)	23. BCM (junction block without BCM type)
[D]: Junction block viewed from relay side	12. Rear height sensor (if equipped)	24. Auto-on headlight controller (if equipped)
1. Headlight bulb	13. Front height sensor (if equipped)	25. Front fog light switch (if equipped)
2. Clearance light	14. Front fog light relay (if equipped)	26. Headlight manual leveling switch (if equipped)
3. Turn signal light	15. Headlight high beam relay (left side)	27. Illumination cancel switch (if equipped)
4. Headlight unit	16. Headlight high beam relay (right side)	28. Lighting switch
5. Discharge headlight bulb	17. Headlight low beam relay (left side)	29. Rear fog light switch (if equipped)
6. Igniter	18. Headlight low beam relay (right side)	30. Hazard warning switch
7. Ballast	19. Tail light relay	31. DRL controller or headlight leveling control module (if equipped)
8. Auto-on headlight sensor (if equipped)	20. BCM (junction block with BCM type) : BCM cannot be removed from junction block.	

Interior Light System Location

S7RW0C9203002



I6RW0B920002-01

1. Dome light	4. Rear end door switch (included in lock assembly)	7. Front spot light
2. Luggage compartment light	5. Trunk room light	[A]: Hatchback
3. Door switches (both sides)	6. Trunk lid switch	[B]: Sedan

Diagnostic Information and Procedures

Self-Diagnosis Function for Headlight Auto Leveling System


S7RW0C9204001

The headlight leveling control module has self-diagnosis function to monitor the system components and circuits while the headlight auto leveling system is at work. When the headlight leveling control module detects an abnormality in the system, the headlight leveling warning light in the combination meter turns ON. However, the headlight leveling control module does not have a function to indicate location of such abnormality.

Headlight Leveling Warning Light Check

S7RW0C9204002

- 1) Turn ignition switch to ON position.
- 2) Check that headlight leveling warning light (1) lights for about 2 seconds and then goes OFF. If the headlight leveling warning light lights up again 10 seconds after it turned off, go to "Headlight Auto Leveling System Symptom Diagnosis (If Equipped)". If headlight leveling warning light flashes, go to "Initialization of Headlight Auto Leveling System".



I6RW0C920009-01

Headlight Symptom Diagnosis (Discharge Headlight Model)

S7RW0C9204003

Condition	Possible cause	Correction / Reference Item
Only one low beam does not light up	Circuit fuse blown	Replace fuse and check for short circuit.
	Headlight low beam relay faulty	Check headlight relay referring to "Tail Light Relay, Headlight Relay, Front Fog Light Relay Inspection (If Equipped)".
	Bulb faulty	Replace bulb.
	Igniter faulty	Replace igniter.
	Ballast faulty	Replace ballast.
	Wiring or ground faulty	Repair circuit.
Low beam does not light up	Circuit fuses blown	Replace fuses and check for short circuit.
	Headlight low beam relay faulty	Check headlight relay referring to "Tail Light Relay, Headlight Relay, Front Fog Light Relay Inspection (If Equipped)".
	Lighting or dimmer switch faulty	Check lighting and dimmer switch referring to "Headlight Switch (in Lighting Switch) Inspection".
	Bulbs faulty	Replace bulbs.
	Igniters faulty	Replace igniters.
	Ballasts faulty	Replace ballasts.
	Wiring or ground faulty	Repair circuit.
Only one high beam does not light up	Circuit fuse blown	Replace fuse and check for short circuit.
	Headlight high beam relay faulty	Check headlight relay referring to "Tail Light Relay, Headlight Relay, Front Fog Light Relay Inspection (If Equipped)".
	Bulb blown	Replace bulb.
	Wiring or ground faulty	Repair circuit.
High beam does not light up	Circuit fuses blown	Replace fuses and check for short circuit.
	Headlight high beam relay faulty	Check headlight relay referring to "Tail Light Relay, Headlight Relay, Front Fog Light Relay Inspection (If Equipped)".
	Lighting or dimmer switch faulty	Check lighting and dimmer switch referring to "Headlight Switch (in Lighting Switch) Inspection".
	Bulbs blown	Replace bulbs.
	Wiring or ground faulty	Repair circuit.

Headlight Symptom diagnosis (Other than Discharge Headlight Model)

S7RW0C9204004

Condition	Possible cause	Correction / Reference Item
Only one low beam does not light up	Circuit fuse blown	Replace fuse and check for short circuit.
	Bulb blown	Replace bulb.
	Headlight low beam relay faulty (if equipped)	Check headlight relay referring to "Tail Light Relay, Headlight Relay, Front Fog Light Relay Inspection (If Equipped)".
	Wiring or ground faulty	Repair circuit.
Low beam does not light up	Circuit fuse blown	Replace fuses and check for short circuit.
	Headlight low beam relay faulty (if equipped)	Check headlight relay referring to "Tail Light Relay, Headlight Relay, Front Fog Light Relay Inspection (If Equipped)".
	Lighting or dimmer switch faulty	Check lighting and dimmer switch referring to "Headlight Switch (in Lighting Switch) Inspection".
	Bulbs blown	Replace bulbs.
	Wiring or ground faulty	Repair circuit.
	DRL controller faulty (if equipped)	Check system referring to "Inspection of DRL Controller and Its Circuits (If Equipped)".
Only one high beam does not light up	Circuit fuse blown	Replace fuse and check for short circuit.
	Bulb blown	Replace bulb.
	Headlight high beam relay faulty (if equipped)	Check headlight relay referring to "Tail Light Relay, Headlight Relay, Front Fog Light Relay Inspection (If Equipped)".
	Wiring or ground faulty	Repair circuit.
High beam does not light up	Circuit fuse blown	Replace fuses and check for short circuit.
	Headlight high beam relay faulty (if equipped)	Check headlight relay referring to "Tail Light Relay, Headlight Relay, Front Fog Light Relay Inspection (If Equipped)".
	Lighting or dimmer switch faulty	Check lighting and dimmer switch referring to "Headlight Switch (in Lighting Switch) Inspection".
	Bulbs blown	Replace bulbs.
	Wiring or ground faulty	Repair circuit.

Auto-On Headlight System Symptom Diagnosis (If Equipped)

S7RW0C9204005

Condition	Possible cause	Correction / Reference Item
Headlights are not turned ON or OFF automatically even after darkened or lightened	Circuit fuse blown	Replace fuse and check for short circuit.
	Lighting or dimmer switch faulty	Check lighting and dimmer switch referring to "Headlight Switch (in Lighting Switch) Inspection".
	Auto-on headlight sensor faulty	Check auto-on headlight sensor referring to "Auto-On Headlight Sensor Inspection (If Equipped)".
	Wiring or ground faulty	Repair circuit.
	Auto-on headlight controller faulty	Check auto-on headlight controller for function referring to "Inspection of Auto-On Headlight Controller and Its Circuit (If Equipped)".

DRL System Symptom Diagnosis (If Equipped)

S7RW0C9204006

Condition	Possible cause	Correction / Reference Item
Headlight does not light when lighting switch is in OFF position and engine is running	Lighting switch faulty	Check lighting switch referring to "Headlight Switch (in Lighting Switch) Inspection".
	Oil pressure switch faulty	Check oil pressure switch referring to "Oil Pressure Switch Inspection in Section 9C".
	DRL controller faulty	Check lighting switch referring to "Inspection of DRL Controller and Its Circuits (If Equipped)".
	Wiring or grounding faulty	Repair circuit.
Headlight lights even if engine stop and lighting switch is OFF position	Lighting switch faulty	Check system referring to "Headlight Switch (in Lighting Switch) Inspection".
	Oil pressure switch faulty	Check oil pressure switch referring to "Oil Pressure Switch Inspection in Section 9C".
	DRL controller faulty	Check system referring to "Inspection of DRL Controller and Its Circuits (If Equipped)".
	Wiring or grounding faulty	Repair circuit.

Headlight Auto Leveling System Symptom Diagnosis (If Equipped)

S7RW0C9204007

Condition	Possible cause	Correction / Reference Item
Headlight leveling warning light comes on steady	Height sensor faulty	Check height sensor referring to "Height Sensor and Its Circuit Inspection (If Equipped)".
	Wiring or ground faulty	Repair circuit.
	Headlight leveling control module faulty	Check headlight leveling control module for function referring to "Inspection of Headlight Leveling Control Module and Its Circuit (Headlight Auto Leveling System)".
Optical axes of both headlights do not change	Circuit fuse blown	Replace fuse and check for short circuit.
	Supply voltage too low or too high	Check charging system referring to "Generator Test (Undercharged Battery Check) in Section 1J" or "Generator Test (Overcharged Battery Check) in Section 1J".
	Wiring or ground faulty	Repair circuit.
	Headlight leveling control module faulty	Check headlight leveling control module for function referring to "Inspection of Headlight Leveling Control Module and Its Circuit (Headlight Auto Leveling System)".
Optical axis of only one headlight does not change	Headlight levering actuator faulty	Check actuator referring to "Headlight Leveling Actuator Inspection (If Equipped)".
	Headlight housing deformed	Replace headlight housing.
	Wiring or ground faulty	Repair circuit.

Headlight Manual Leveling System Symptom Diagnosis (If Equipped)

S7RW0C9204008

Condition	Possible cause	Correction / Reference Item
Optical axes of both headlights do not change	Circuit fuse blown	Replace fuse and check for short circuit.
	Headlight leveling switch faulty	Check headlight leveling switch referring to "Headlight Manual Levering Switch Inspection (If Equipped)".
	Supply voltage too low	Check charging system referring to "Generator Test (Undercharged Battery Check) in Section 1J".
	Wiring or grounding faulty	Repair circuit.
Optical axis of only one headlight does not change	Circuit fuse blown	Replace fuse and check for short circuit.
	Headlight leveling actuator faulty	Check actuator referring to "Headlight Leveling Actuator Inspection (If Equipped)".
	Headlight housing deformed	Replace headlight housing.
	Wiring or grounding faulty	Repair circuit.

Turn Signal and Hazard Warning Light Symptom Diagnosis

S7RW0C9204009

Condition	Possible cause	Correction / Reference Item
Flash rate high or one side only flashes	Bulb blown on "flash rate high"-side	Replace bulb.
	Incorrect bulb	Replace bulb.
	Turn signal / hazard warning relay faulty	Check turn signal / hazard warning relay referring to "Turn Signal and Hazard Warning Relay Inspection".
	Open circuit or high resistance existing either; between turn signal switch and non lighting bulb, or between hazard warning switch and non lighting bulb	Repair circuit.
	Wiring or grounding faulty	Repair circuit.
No flashing NOTE • Use of SUZUKI scan tool makes it easy to check whether a faulty condition is on the input side or output side of BCM. For checking procedure, refer to "Diagnosis Using Output Test Function of SUZUKI Scan Tool" under "Scan Tool Data in Section 10B". • Check each part in the order from the top of the following list.	Circuit fuse(s) blown	Replace fuse(s) and check for short circuit.
	Turn signal / hazard warning relay faulty	Check turn signal / hazard warning relay referring to "Turn Signal and Hazard Warning Relay Inspection".
	Turn signal light switch faulty	Check turn signal light switch referring to "Turn Signal Light Switch (in Lighting Switch) Inspection".
	Hazard warning switch faulty	Check hazard warning switch referring to "Hazard Warning Switch Inspection".
	Open circuit or high resistance existing between battery and switch	Repair circuit.
	Wiring or grounding faulty	Repair circuit.
	BCM faulty	Replace after making sure that none of above parts is faulty.
Flash rate low	Supply voltage low	Check charging system referring to "Generator Test (Undercharged Battery Check) in Section 1J".
	Turn signal / hazard warning relay faulty	Check turn signal / hazard warning relay referring to "Turn Signal and Hazard Warning Relay Inspection".

Clearance, Tail and License Plate Light Symptom Diagnosis

S7RW0C9204010

Condition	Possible cause	Correction / Reference Item
All lights do not light up	Circuit fuse blown	Replace fuse and check for short circuit.
	Tail light relay faulty (if equipped)	Check tail light relay referring to "Tail Light Relay, Headlight Relay, Front Fog Light Relay Inspection (If Equipped)".
	Lighting and dimmer switch faulty	Check lighting and dimmer switch referring to "Headlight Switch (in Lighting Switch) Inspection".
	Wiring or grounding faulty	Repair circuit.
Some lights do not light up	Bulb(s) blown	Replace bulb(s).
	Wiring or grounding faulty	Repair circuit.

Back-Up Light Symptom Diagnosis

S7RW0C9204011

Condition	Possible cause	Correction / Reference Item
Back-up lights do not light up	Bulb(s) blown	Replace bulb(s).
	Circuit fuse blown	Replace fuse and check for short circuit.
	Back-up light switch (M/T model) or transmission range sensor (A/T model) faulty	Check back-up light switch or transmission range sensor referring to "Back Up Light Switch Inspection in Section 5B" or "Transmission Range Sensor Inspection and Adjustment in Section 5A".
	Wiring or grounding faulty	Repair circuit.
Back-up lights stay on	Back-up light switch (M/T model) or transmission range sensor (A/T model) faulty	Check back-up light switch or transmission range sensor referring to "Back Up Light Switch Inspection in Section 5B" or "Transmission Range Sensor Inspection and Adjustment in Section 5A".

Brake Light Symptom Diagnosis

S7RW0C9204012

Condition	Possible cause	Correction / Reference Item
Brake light do not light up	Bulb(s) blown	Replace bulb(s).
	Circuit fuse blown	Replace fuse and check for short circuit.
	Brake light switch faulty	Check brake light switch referring to "Brake Light Switch Inspection".
	Wiring or grounding faulty	Repair circuit.
Brake light stay on	Brake light switch faulty	Check or adjust brake light switch referring to "Brake Light Switch Inspection" or "Brake Light Switch Adjustment in Section 4A".

Front Fog Light Symptom Diagnosis (If Equipped)

S7RW0C9204013

Condition	Possible cause	Correction / Reference Item
Only one light does not light	Bulb blown	Replace bulb.
	Wiring or grounding faulty	Repair circuit.
Front fog lights do not light	Circuit fuse blown	Replace fuse and check for short circuit.
	Bulb blown	Replace bulb.
	Front fog light switch faulty	Check front fog light switch referring to "Front Fog Light Switch Inspection (If Equipped)".
	Front fog light relay faulty	Check front fog light relay referring to "Tail Light Relay, Headlight Relay, Front Fog Light Relay Inspection (If Equipped)".
	Wiring or grounding faulty	Repair circuit.

Rear Fog Light Symptom Diagnosis (If Equipped)

S7RW0C9204014

Condition	Possible cause	Correction / Reference Item
Rear fog light do not light	Circuit fuse blown	Replace fuse and check for short circuit.
	Bulb blown	Replace bulb.
	Rear fog light switch faulty	Check rear fog light switch referring to "Rear Fog Light Switch Inspection (If Equipped)".
	Wiring or grounding faulty	Repair circuit.

Illumination Cancel System Symptom Diagnosis (If Equipped)

S7RW0C9204015

Condition	Possible cause	Correction / Reference Item
Illumination cancel do not normal operation	Circuit fuse blown	Replace fuse and check for short circuit.
	Illumination cancel switch faulty	Check illumination cancel switch referring to "Illumination Cancel Switch Inspection (If Equipped)".
	Combination meter and/or information display faulty	Replace combination meter and/or information display.
	Wiring or grounding faulty	Repair circuit.

Interior Light Symptom Diagnosis

S7RW0C9204016

NOTE

- Use of SUZUKI scan tool makes it easy to check whether a faulty condition is on the input side or output side of BCM. For checking procedure, refer to "Diagnosis Using Output Test Function of SUZUKI Scan Tool" under "Scan Tool Data in Section 10B".
- Check each part in the order from the top of the following list.

Condition	Possible cause	Correction / Reference Item
Dome light does not light up	Bulb blown	Replace bulb.
	Circuit fuse blown	Replace fuse and check for short circuit.
	Dome light switch faulty	Check dome light switch.
	Door switch faulty	Check door switch referring to "Door Switch (Front / Rear Door) Inspection in Section 9C".
	Wiring or grounding faulty	Repair circuit.
	BCM faulty	Replace after making sure that none of above parts is faulty.
Luggage compartment light does not light up	Bulb blown	Replace bulb.
	Rear end door / trunk lid switch faulty	Check switch referring to "Rear End Door Switch Inspection (Hatchback) in Section 9C" or "Trunk Lid Switch Inspection (Sedan) in Section 9C".
	Wiring or grounding faulty	Repair circuit.
Front spot lights do not light up	Bulb(s) blown	Replace bulb(s).
	Spot light switch faulty	Check spot light switch.
	Wiring or grounding faulty	Repair circuit.

DRL Operation Inspection (If Equipped)



S7RW0C9204017

- 1) Confirm that lighting switch is in OFF position.
- 2) Confirm that dimmer and passing switch is in low beam position.
- 3) Check DRL for operation as follows.
 - a) Turn ignition switch to ON position and check headlights remain OFF.
 - b) Start engine and run it at idle speed. Check headlights turn ON at low beam.
 - c) Switch dimmer and passing switch to high beam position and check headlights remain turning ON at low beam.
- 4) If check result is not as satisfied, go to "Inspection of DRL Controller and Its Circuits (If Equipped)".

Inspection of DRL Controller and Its Circuits (If Equipped)

S7RW0C9204018

- 1) Confirm that lighting switch is in good condition referring to "Headlight Switch (in Lighting Switch) Inspection".
 - 2) Confirm that oil pressure switch is in good condition referring to "Oil Pressure Switch Inspection in Section 9C".
 - 3) Remove glove box.
 - 4) Remove DRL controller (1) from steering support member.
 - 5) Connect connector to DRL controller.
 - 6) Check that the voltage between the following terminals and vehicle body ground are specifications under each condition.
 - 7) Check that voltage between the following terminals and body ground are as specification under each condition.
If measuring voltage is not within specification, check applicable circuit for open or short. If circuits are normal, replace DRL controller.
- If measuring voltage is within specification, DRL controller and its circuits are good condition.



15RW0A920003-01

[A]: DRL controller connector viewed from harness side

Terminal	Circuit	Specification	Condition
1	To clearance lamp	0 – 1 V	Engine is at stop and lighting switch is at OFF position.
		10 – 14 V	Engine is at running and lighting switch is at OFF position.
2	To ignition switch	0 – 1 V	Ignition switch is at OFF position.
		10 – 14 V	Ignition switch is at ON position.
3	To lighting switch (CLEARANCE)	0 – 1 V	Lighting switch is at OFF position.
		10 – 14 V	Lighting switch is at CLEARANCE position or HEAD position.
4	Ground	0 – 1 V	—
5	Ground	0 – 1 V	—
6	To head lamp	0 – 1 V	- Lighting switch is at HEAD position and dimmer switch is at LOW position. - Engine is running and lighting switch is at OFF position.
		10 – 14 V	Lighting switch is at HEAD position and dimmer switch is at HI position.
7	To oil pressure switch	8 – 10 V	Engine is at running (Oil pressure warning lamp is turned OFF).
		0 – 1 V	Engine is at stop.
8	Main fuse	10 – 14 V	—
9	To lighting switch (HEAD)	6 – 8 V	- Engine is at running and lighting switch is at OFF position. - Engine is running and lighting switch is CLEARANCE position.
		0 – 1 V	- Engine is at running and dimmer switch is at HEAD position. - Engine is at stop.


9B-16 Lighting Systems:

Terminal	Circuit	Specification	Condition
10	To lighting switch (LOW)	0 – 1 V	- Engine is at running and lighting switch is at OFF position. - Lighting switch is at HEAD position and dimmer switch is at LOW position.
		10 – 14 V	Lighting switch is at HEAD position and dimmer switch is at HI position.

Auto-On Headlight Operation Inspection (If Equipped)

S7RW0C9204019

- Turn ignition switch to ON position and then turn lighting switch to "AUTO" position.
- Check headlights for operation as follows. If headlights do not turn ON or OFF, go to "Inspection of Auto-On Headlight Controller and Its Circuit (If Equipped)".
 - Cover auto-on headlight sensor by hand and check that headlights light up then.
 - Light over auto-on headlight sensor vertically with on incandescent lamp of approx. 100 W apart from about 100 mm (3.94 in.) (1) and check that headlights go off then.



I6RW0C920010-02

[A]: Fig. for Step a)

[B]: Fig. for Step b)


Inspection of Auto-On Headlight Controller and Its Circuit (If Equipped)

S7RW0C9204020

- Confirm that lighting switch is in good condition referring to "Headlight Switch (in Lighting Switch) Inspection".
- Remove steering column hole cover.
- Remove auto-on headlight controller (1) from steering support member.
- Connect connector to auto-on headlight control module.
- Check that the voltage between the following terminals and vehicle body ground are specifications under each condition.

If measuring voltage is not within specification, check applicable circuit for open or short. If circuits are normal, replace auto-on headlight controller.

If measuring voltage is within specification, auto-on headlight controller and its circuits are good condition.



I6RW0C920011-01

[A]: Auto-on headlight controller connector viewed from harness side

Terminal	Circuit	Specification	Condition
1	Tail light control signal	0 V	Lighting switch at "AUTO" position, tail / position light at ON.
		10 – 14 V	Ignition switch is at ON position, lighting switch at "OFF" position.

Terminal	Circuit	Specification	Condition
2	Headlight control signal	0 V	Lighting switch at "AUTO" position, headlight at ON.
		10 – 14 V	Ignition switch is at ON position, lighting switch at "OFF" position.
3	Power supply for auto-on headlight sensor	About 5 V	Ignition switch is at OFF position.
4	Auto-on headlight sensor signal	3 – 4.5 V	Light the sensor lens with incandescent lamp 100 W
		Less than 1 V	Cover the sensor lens with hand.
5	Ground for auto-on headlight controller	0 V	—
6	Ground for auto-on headlight sensor	0 V	—
7	Lighting switch signal	0 V	Ignition switch is at ON position, lighting switch at "AUTO" position.
		1.0 – 5.0 V	Ignition switch is at ON position, lighting switch at other than "AUTO" position.
8	Ignition switch signal	10 – 14 V	Ignition switch is at ON position.

Inspection of Headlight Leveling Control Module and Its Circuit (Headlight Auto Leveling System)

S7RW0C9204021

Headlight auto leveling control module and its circuits can be checked at headlight auto leveling control module wiring couplers by measuring voltage and pulse signal.

⚠ CAUTION


Headlight auto leveling control module cannot be checked by itself. It is strictly prohibited to connect voltmeter or ohmmeter to headlight auto leveling control module with couplers disconnected from it.

Voltage Check

Check voltage between each terminal of headlight auto leveling control module and vehicle body ground under each condition. If measured voltage is out of standard value, check circuit (including switch and sensor) of terminal where voltage was measured.

NOTE

- As each terminal voltage is affected by the battery voltage, confirm that it is 11 V or more when ignition switch is ON.
- Voltage with asterisk (*) cannot be measured by voltmeter because it is pulse signal. Check it with oscilloscope if necessary.



[A]: Headlight leveling control module connector (viewed from harness side)

I6RW0C920012-01

9B-18 Lighting Systems:


Terminal	Circuit	Specification	Condition
1	Power source	10 – 14 V	Ignition switch is at ON position.
2	—	—	—
3	Lighting switch	Less than 1.5 V	Lighting switch is at “HEAD” position.
		10 – 14 V	Lighting switch is at OFF position.
4	—	—	—
5	Diagnosis switch terminal	About 5 V	Ignition switch is at ON position.
6	Headlight auto leveling indicator	Less than 1.5 V	For about 3 seconds after ignition switch is turned on (i.e., headlight auto leveling indicator is lit up).
		10 – 14 V	More than about 3 seconds after ignition switch is turned on (i.e., headlight auto leveling indicator is not lit up).
7	—	—	—
8	—	—	—
9	Ground for headlight auto leveling control unit	0 V	Ignition switch is at ON position.
10	Power supply for right headlight leveling actuator	10 – 14 V	Ignition switch is at ON position.
11	Power supply for left headlight leveling actuator	10 – 14 V	Ignition switch is at ON position.
12	Power supply for rear height sensor	About 5 V	Ignition switch is at ON position.
13	Power supply for front height sensor	About 5 V	Ignition switch is at ON position.
14	—	—	—
15	—	—	—
16	Vehicle speed signal	Refer to “Reference waveform No.1: ”.	
17	Signal for right headlight leveling actuator	Less than 1 V	Lighting switch is at OFF position.
		1.0 – 12.6 V	For 17 seconds after turning lighting switch to ON position.
18	Signal for left headlight leveling actuator	Less than 1 V	Lighting switch is at OFF position.
		1.0 – 12.6 V	For 17 seconds after turning lighting switch to ON position.
19	Input signal for rear height sensor	About 2.5 V	Ignition switch is at ON position.
20	Input signal for front height sensor	About 2.5 V	Ignition switch is at ON position.
21	Ground for rear height sensor	0 V	Ignition switch is at ON position.
22	Ground for front height sensor	0 V	Ignition switch is at ON position.
23	Ground for right headlight leveling actuator	0 V	Ignition switch is at ON position.
24	Ground for left headlight leveling actuator	0 V	Ignition switch is at ON position.

Reference waveform No.1

Vehicle speed signal (1).

Vehicle speed signal is pulse. Pulse frequency varies depending on vehicle speed.

Measurement terminal	CH 1: "G14-16" to "G14-9"
Oscilloscope setting	CH 1: 2 V TIME: 20 ms/DIV
Measurement condition	Engine is running and vehicle speed 40 km/h (24 mph)



Repair Instructions

Headlight Housing Removal and Installation


S7RW0C9206001

⚠ WARNING

- To avoid danger of being burned, don't touch when the bulb is hot.
- Don't touch glass surface of bulb, to avoid deteriorate as the case may be unclear when bulb light on at dirty condition.
- Be sure to read "Precautions for Discharge Headlight Service (If Equipped)" before starting to service work.

Removal

- 1) Disconnect negative (–) cable at battery.
- 2) Remove front bumper. Refer to "Front Bumper and Rear Bumper Components in Section 9K".
- 3) Remove headlight mounting bolts and clip.
- 4) Detach headlight housing (1) from vehicle.
- 5) Disconnect couplers (2) from headlight housing (1).




I5RW0A920004-01

Installation

Reverse removal procedure noting the following.

- Install headlight mounting bolts and clip (1), and then tighten headlight mounting bolts ("1" – "2") according to numerical order as shown in figure.



I5RW0A920005-01

- After installation, be sure to inspect and adjust aiming referring to "Headlight Aiming Adjustment with Screen".


Headlight Bulb Replacement (Discharge Headlight Model)

S7RW0C9206002

⚠ WARNING


- To avoid danger of being burned, don't touch when the bulb is hot.
- Don't touch glass surface of bulb, to avoid deteriorate as the case may be unclear when bulb light on at dirty condition.
- Be sure to read "Precautions for Discharge Headlight Service (If Equipped)" before starting to service work.

- 1) Check to ensure that lighting switch is at OFF position.
- 2) Disconnect negative (–) cable at battery.
- 3) Remove headlight housing referring to "Headlight Housing Removal and Installation".
- 4) Remove cover (1) from headlight housing by turning it counterclockwise.
- 5) Remove igniter (2) from discharge headlight bulb by turning it counterclockwise.



I6RW0C920014-02

- 6) Replace bulb (1) from headlight housing.



I6RW0C920015-02

- 7) Install igniter to discharge headlight bulb by turning it clockwise.
- 8) Install cover to headlight housing by turning it clockwise.
- 9) Install headlight housing to vehicle body referring to "Headlight Housing Removal and Installation".
- 10) Connect negative (–) cable at battery.
- 11) After installation, be sure to inspect and adjust aiming referring to "Headlight Aiming Adjustment with Screen".

Ballast Removal and Installation (Discharge Headlight Model)


S7RW0C9206003

⚠ WARNING

Be sure to read “Precautions for Discharge Headlight Service (If Equipped)” carefully before working. Neglecting them may result in personal injury.

Removal

- 1) Check to ensure that lighting switch is at OFF position.
- 2) Disconnect negative (–) cable at battery.
- 3) Remove headlight housing referring to “Headlight Housing Removal and Installation”.
- 4) Remove ballast (1) from headlight housing (2).
- 5) Disconnect connector (3) from ballast.



I6RW0C920016-02

Installation

Reverse removal procedure noting the following.

- Connect connectors securely.
- After installation, be sure to inspect and adjust aiming referring to “Headlight Aiming Adjustment with Screen”.

Igniter Removal and Installation (Discharge Headlight Model)


S7RW0C9206004

⚠ WARNING

Be sure to read “Precautions for Discharge Headlight Service (If Equipped)” carefully before working. Neglecting them may result in personal injury.

Removal

- 1) Remove ballast referring to “Ballast Removal and Installation (Discharge Headlight Model)”.
- 2) Remove cover (1) from headlight housing by turning it counterclockwise.
- 3) Remove igniter (2) from discharge headlight bulb by turning it counterclockwise.
- 4) After disconnecting ground wire (3), pull out igniter (2) from headlight housing.



I6RW0C920017-01

Installation

Reverse removal procedure noting the following.

- Connect connectors securely.
- After installation, be sure to inspect and adjust aiming referring to “Headlight Aiming Adjustment with Screen”.

Headlight Aiming Adjustment with Screen

S7RW0C9206005

NOTE

- Unless otherwise obligated by local regulations, adjust headlight aiming according to the following procedure.
 - After replacing headlight housing, be sure to adjust aiming.
 - When inspecting and adjusting headlight with leveling system, make sure to set the leveling switch to "0" position with ignition switch turned ON.
-

1) Make sure the following items.

- Place vehicle on a flat surface in front of blank wall (screen) (1) ahead of headlight surface.

Distance "a"

10 m (32.8 ft.)

- Adjust air pressure of all tires to the specified value respectively.
- Bounce vehicle body up and down by hand to stabilize suspension.
- Carry out aiming with a driver aboard.

Driver's weight

75 kg (165 lb)

2) Check to see if hot spot (high intensity zone) of each low beam axis falls as shown in figure.

NOTE


If the headlights interfere each other and make it hard to see the cut line clearly, cover the headlight on one side. This helps to make aiming adjustment easier.

Hot spot specification

Angle "b": 0.75° (Specification)

Calculated distance "H": Approx. 130 mm (5.15 in.)

3) Align headlight aiming to specification by adjusting aiming gear if it is not set properly.



I6RW0C920018-02


2. Headlight bulb	10. Headlight housing	[D]: LH steering vehicle shown
3. Cut line (bounding line)	11. Headlight leveling actuator	[E]: Without headlight leveling actuator
4. Hot spot	X-X: Horizontal center line of headlight bulbs	[F]: Headlight manual leveling model
5. Turning (for up adjustment)	A-A: Vertical center line of left headlight bulb	[G]: Headlight auto leveling model
6. Turning (for down adjustment)	B-B: Vertical center line of right headlight bulb	[H]: Other than discharge headlight model
7. Aiming gear (for right / left adjustment)	[A]: Left headlight	[I]: Discharge headlight model
8. Turning (for right adjustment)	[B]: Right headlight	
9. Turning (for left adjustment)	[C]: RH steering vehicle shown	

Headlight Switch (in Lighting Switch) Removal and Installation

S7RW0C9206006


Removal

- 1) Disconnect negative (–) cable at battery.
- 2) Remove steering column hole cover (3).
- 3) Remove steering column covers (1).
Turn steering wheel to access steering column cover screws (2).



I5RW0A920007-02

- 4) Remove lighting switch (1) from combination switch assembly (2) and disconnect its coupler (3).



I5RW0A920008-01

Installation



Reverse removal procedure for installation.

Headlight Switch (in Lighting Switch) Inspection

S7RW0C9206007

Check for continuity between terminals at each switch position. If check result is not as specified, replace switch.

Without rear fog light switch and auto-on headlight switch





[C]		5	3	1	2	4	6*
OFF	LOW			○			○
	PASS				○	○	○
	HI				○		○
•	LOW	○	○	○			○
	PASS	○	○		○	○	○
	HI	○	○		○		○
☰	LOW	○	○	○		○	○
	PASS	○	○		○	○	○
	HI	○	○		○	○	○

I6JB0B920003-02

[A]: LHD	[D]: Shaft condition
[B]: RHD	*: If equipped
[C]: Terminal	

With rear fog light switch




[A]		1	4	2	3	5	6
OFF	LOW						
	PASS				○	○	
	HI						
•	LOW	○	○				
	PASS	○	○		○	○	
	HI	○	○				
☰	LOW	○	○	○	○		○
	PASS	○	○	○	○	○	
	HI	○	○	○	○	○	

I5JB0D920011-04

[A]: Terminal
[B]: Shaft condition

With auto-on headlight switch



[B] \ [A]		1	4	2	3	5	6	7
OFF	LOW						○	○
	PASS				○	○		○
	HI					○		○
●	LOW	○	○				○	○
	PASS	○	○		○	○		○
	HI	○	○			○		○
☰	LOW	○	○		○		○	○
	PASS	○	○		○	○		○
	HI	○	○		○	○		○
AUTO	LOW			○	○		○	○
	PASS			○	○	○		○
	HI			○	○	○		○

I6RW0C920019-01


[A]: Terminal
[B]: Shaft condition

Hazard Warning Switch Removal and Installation

S7RW0C9206008

Removal

- 1) Disconnect negative (–) cable at battery.
- 2) Remove center ventilation louver (1) referring to “Center Ventilation Louver Removal and Installation in Section 7A”.
- 3) Disconnect coupler, and then remove hazard warning switch (2) from center ventilation louver (1) while releasing the locks (3).



I5RW0A920009-01


Installation

Reverse removal procedure for installation.

Hazard Warning Switch Inspection

S7RW0C9206009

Check for continuity between terminals at each switch position. If check result is not as specified, replace switch.



Switch \ Terminal		1	2	3	4
OFF				○	○
				○	○
ON		○	○	○	○
		○	○	○	○


I5RW0C920004-01

Brake Light Switch Inspection

S7RW0C9206010

Check brake light switch for continuity between terminals at each switch position.

If check result is not as specified, replace switch.



Shaft condition \ Terminal		1	2	3	4
FREE				○	○
				○	○
PUSH		○	○		
		○	○		

I5RW0A920010-01

Turn Signal Light Switch (in Lighting Switch) Removal and Installation


S7RW0C9206011

For removal and Installation, refer to “Headlight Switch (in Lighting Switch) Removal and Installation”.

Turn Signal Light Switch (in Lighting Switch) Inspection

S7RW0C9206012

Check for continuity between terminals at each switch position. If check result is not as specified, replace switch.



[D]	[C]	1	2	3
	←		○	○
	N			
	→	○	○	

I5JB0D920018-01


[A]: Other than RHD without rear for light
[B]: RHD without rear fog light
[C]: Terminal
[D]: Switch position

Turn Signal and Hazard Warning Relay Removal and Installation

S7RW0C9206013

Removal

- 1) Disconnect negative (–) cable at battery.
- 2) Remove junction block assembly (1) referring to “BCM (Included in Junction Block) Removal and Installation in Section 10B”.
- 3) Remove turn signal and hazard warning relay (2).



I7RW01920008-01


Installation

Reverse removal procedure for installation.

Turn Signal and Hazard Warning Relay Inspection

S7RW0C9206014


- 1) Connect turn signal and hazard warning relay (1), battery (2) and six test bulbs ((12V, 21W) (3) and 12 V, 5W (4)) as shown.



I4RS0A920014-01

- 2) Check turn L circuit
Connect terminal "5" and battery negative (–) terminal by a jumper wire.
Check left side bulbs (1) for flashing cycle.
If check result is not as specified, replace turn signal and hazard warning relay.


Reference flashing cycle
60 – 120 cycle/minute



I4RS0A920015-01

- 3) Check turn R circuit
Connect terminal "6" and battery negative (–) terminal by a jumper wire.
Check right side bulbs (1) for flashing cycle.
If check result is not as specified, replace turn signal and hazard warning relay.


Reference flashing cycle
60 – 120 cycle/minute



I4RS0A920016-01

- 4) Check Hazard ON circuit
Connect terminal "8" and battery negative (–) terminal by a jumper wire.
Check all bulbs (1) for flashing cycle.
If check result is not as specified, replace turn signal and hazard warning relay.

Reference flashing cycle
60 – 120 cycle/minute




I4RS0A920017-01

License Light Assembly Removal and Installation (Hatchback)

S7RW0C9206015

Removal

- 1) Disconnect negative (–) cable at battery.
- 2) Remove rear end door license garnish referring to "Rear End Door Lock Assembly Components (Hatchback Model) in Section 9F".
- 3) Disconnect coupler (1) from license light.
- 4) Push locking part to arrow direction, and then remove license light.



I5RW0A920012-01

- | |
|-------------------------------|
| 2. License light socket |
| 3. License light lens |
| 4. License light bulb |
| 5. License light socket cover |

Installation


Reverse removal procedure for installation.

License Light Removal and Installation (Sedan)

S7RW0C9206029


Removal

- 1) Remove trunk lid trim (1) from trunk lid panel.



I6RW0B920004-01

- 2) Remove trunk lid license garnish referring to "Trunk Lid Lock Assembly Components (Sedan Model) in Section 9F".
- 3) Disconnect coupler from license light socket.
- 4) Remove license light bulb (1) as shown.
- 5) Push locking part (2) to arrow direction, and then remove license light lens.



I6RW0B920005-01

Installation

Reverse removal procedure for installation.

Front Fog Light Assembly Removal and Installation (If Equipped)

S7RW0C9206016

⚠ WARNING


- To avoid danger of being burned, don't touch when the bulb is hot.
- Don't touch glass surface of bulb to avoid deteriorate as the case may be unclear when bulb light on at dirty condition.

Removal

- 1) Disconnect negative (–) cable at battery.
- 2) Remove front bumper. Refer to "Front Bumper and Rear Bumper Components in Section 9K".
- 3) Disconnect coupler from fog light (1).
- 4) Remove front fog light as follows.

Hatchback


- Detach fog light pushing clips to arrow direction, and remove front fog light.



I5RW0A920013-01

Sedan

- Remove fog light screws (2), and remove front fog light.



I7RW0C920002-01

Installation

Reverse removal procedure for installation nothing the following:


- After installing, adjust aiming referring to "Front Fog Light Aiming Adjustment with Screen (If Equipped)".

Front Fog Light Switch Inspection (If Equipped)
S7RW0C9206017

NOTE

Front fog lights light up only when headlight switch is in HEADLIGHT position (low or high beams) or SMALL position. Front fog lights turn OFF automatically when headlight switch is turned to OFF position. If front fog light switch holds ON position, front fog lights turn ON automatically when headlight switch is tuned to HEADLIGHT position (low or high beams) or SMALL position again.

Check for continuity between terminals at each switch position. If check result is not as specified, replace switch.



Terminal Switch Position	2	3	1	5	4
OFF					
ON (PUSH IN)					

I4RS0A920021-01

Front Fog Light Aiming Adjustment with Screen
(If Equipped)
S7RW0C9206018

Basic Aiming

NOTE

- Unless otherwise obligated by local regulations, adjust front fog light aiming according to the following procedure.
- An example in case that the light-to-wall distance 10 m is shown in the illustration. The beam descending distance “H” is calculated when “a” is 10 m with the specification angle “b” (1.14°).

- 1) Make sure the following items.
- Place vehicle on a flat surface in front of blank wall (screen) (1) ahead of front fog light surface.
- Distance between screen and front fog light “a”: 10 m (32.8 ft.)**
- Adjust air pressure of all tired to the specified value respectively.
 - Bounce vehicle body up and down by hand to stabilize suspension.
 - Carry out aiming with a driver aboard.

Driver’s weight
75 kg (165 lb)




- 2) Check to see if hot spot (high intensity zone) of each front fog light axis falls as shown in the figure.

NOTE

If the fog lights interfere each other and make it hard to see the cut line clearly, cover the fog light on one side. This helps to make aiming adjustment easier.

Hot spot specification
Angle “b”: 1.14° (Specification)
Calculated distance “H”: Approx. 199 mm (7.83 in.)

- 3) If it is not set properly, align front fog light to specification by rotating aiming gear.



I7RW0C920003-03

2. Bounding line
3. Hot spot
4. Aiming gear (for up / down adjustment)
5. Turning (for up adjustment)
6. Turning (for down adjustment)
7. Front fog light assembly
X-X: Horizontal center line of front fog light bulb
A-A: Vertical center line of left front fog light bulb
B-B: Vertical center line of right front fog light bulb
[A]: Sedan
[B]: Hatchback
[C]: Left front fog light
[D]: Right front fog light

Rear Fog Light Switch Inspection (If Equipped)



S7RW0C9206019

NOTE

- Rear fog light switch can be turned to ON position only when headlight switch is turned to HEADLIGHT position (low or high beams).
- Rear fog light switch turns OFF automatically when headlight switch is turned to OFF position.

Check for continuity between terminals at each switch position.

If check result is not as specified, replace switch.



Terminal	1	2
Shaft condition		
OFF		
ON	○	○


I4RS0B920013-01

Headlight Manual Levering Switch Inspection (If Equipped)

S7RW0C9206020

Check for resistance between terminals at each switch position.

If check result is not as specified, replace switch.



Switch Position	Terminal	Resistance (Ω)
-	1 and 2	4370 - 4830
0	1 and 3	646 - 714
	2 and 3	3724 - 4116
1	1 and 3	1292 - 1428
	2 and 3	3078 - 3402
2	1 and 3	1938 - 2142
	2 and 3	2432 - 2688
3	1 and 3	2584 - 2856
	2 and 3	1786 - 1974
4	1 and 3	3230 - 3570
	2 and 3	1140 - 1260


I4RS0B920012-01

Headlight Leveling Actuator Inspection (If Equipped)

S7RW0C9206021

Headlight auto leveling system

- 1) Make sure all couplers of headlight and leveling actuator are connected securely.
- 2) Park vehicle in front of blank wall (screen).
- 3) Turn ignition switch to ON position.
- 4) Perform "Headlight Leveling Warning Light Check".
- 5) Connect service wire (2) to terminals of diagnosis connector (1).
- 6) Perform Steps a) through c) described below within 20 seconds after Step 5).
 - a) Turn lighting switch (3) to "HEAD" position and then turn lighting switch to OFF position.
 - b) Repeat Step a) 2 times.
 - c) Turn lighting switch (3) to "HEAD" position.



I6RW0C920021-01

- 7) Check that optical axes of headlights reflected on blank wall (screen) change. If not, go to "Headlight Auto Leveling System Symptom Diagnosis (If Equipped)".

Headlight manual leveling system

- 1) Make sure all couplers of headlight and leveling actuator are connected securely.
- 2) Park vehicle in front of blank wall (screen).
- 3) Turn ignition switch to ON position.
- 4) Turn lighting switch to "HEAD" position.
- 5) Move headlight leveling switch and check that optical axes of headlights reflected on blank wall (screen) change then. Also check that leveling actuator sounds slightly while moving leveling switch. If optical axes do not change, go to "Headlight Manual Leveling System Symptom Diagnosis (If Equipped)".

Height Sensor Removal and Installation (If Equipped)



S7RW0C9206022

Removal

⚠ CAUTION

- Do not remove bracket (4) and link (3) from height sensor (2). Removal will spoil its original function. If faulty condition is found, replace it with new one in a set.
- If height sensor was dropped from a height of 30 cm (0.9 ft) or more, replace it with new one.

- 1) Disconnect negative (–) cable at battery.
- 2) Disconnect height sensor connector (1) from height sensor (2).
- 3) Remove front and rear height sensor (2) with its bracket (4) from suspension frame (6) or rear floor center cross member (7) and lower arm (5).



I6RW0C920022-01

[A]: Front

[B]: Rear

Installation



For installation, reverse removal procedure noting the following.

- Check that bracket and link of height sensor are not deformed.
- Tighten height sensor bolts and nuts to specified torque.

Tightening torque

Height sensor bolt (a): 5.5 N·m (0.6 kgf-m, 4.0 lb-ft)

Height sensor nut (b): 13 N·m (1.3 kgf-m, 9.5 lb-ft)



I6RW0C920023-01

[A]: Front

[B]: Rear

- Connect connector securely.
- After installation, initialize headlight auto leveling system referring to “Initialization of Headlight Auto Leveling System”.

Height Sensor and Its Circuit Inspection (If Equipped)


S7RW0C9206023

- 1) Remove front or rear height sensor from vehicle referring to "Height Sensor Removal and Installation (If Equipped)".
- 2) Connect connector to height sensor.
- 3) Vary position of height sensor link (1) and measure voltage between terminals of headlight leveling control module (4) as described below.
 - For front height sensor
Between "G14-20" and "G14-22" terminals of headlight leveling control module.
 - For rear height sensor
Between "G14-19" and "G14-21" terminals of headlight leveling control module.
 If check result is not as specified, perform inspections of power supply, ground and signal circuits of front or rear height sensor which is described under "Inspection of Headlight Leveling Control Module and Its Circuit (Headlight Auto Leveling System)". If circuits are OK, replace height sensor.

Height sensor output voltage

Full bound position (2): about 0.5 V

Full rebound position (3): about 4.5 V



I6RW0C920024-01

[A]: Front


[B]: Rear

Headlight Leveling Control Module Removal and Installation (If Equipped)

S7RW0C9206024

Removal

- 1) Disconnect negative (–) cable at battery.
- 2) Remove glove box.
- 3) Disconnect connector (1) from headlight leveling control module (2).
- 4) Remove headlight leveling control module with its bracket from steering support member (3).



I6RW0C920025-01

Installation

For installation, reverse removal procedure noting the following.

- Connect connector securely.
- After replacing headlight leveling control module with new one, initialize headlight auto leveling system referring to "Initialization of Headlight Auto Leveling System".

Initialization of Headlight Auto Leveling System

S7RW0C9206025


Initialization of the headlight auto leveling system is to make the headlight leveling control module learn signals which are fed from the height sensors when the vehicle is at the standard height. Standard height means the height of the vehicle with a driver but without load in it. Initialization of the headlight auto leveling system is required when any of the following works has been performed.

- Replacement of headlight leveling control module
- Removal of front and/or rear height sensor link from lower arm
- Removal of front and/or rear height sensor from suspension frame
- Replacement of front and/or rear height sensor


9B-34 Lighting Systems:

Without initialization of the headlight auto leveling system, it is not possible to obtain its proper function. Also, if the headlight auto leveling system is not initialized after replacing the headlight leveling control module, the headlight leveling warning light in the combination meter flashes.

- 1) Observe the following instructions.
 - Park vehicle on level ground.
 - Adjust air pressure of all tires to the specified value respectively.
 - Bounce vehicle body up and down by hand to stabilize suspension.
- 2) Turn ignition switch to ON position.
- 3) Perform "Headlight Leveling Warning Light Check".
- 4) Connect service wire (2) to terminals of diagnosis connector (1).
- 5) Perform Steps a) through b) described below within 20 seconds after Step 4).
 - a) Turn lighting switch (3) to "HEAD" position and then turn lighting switch to OFF position.
 - b) Repeat Step a) 2 times.




- 6) Confirm that headlight leveling warning light flashes 3 times and turns off, which indicates that system initialization was completed properly. If it does not turn off after flashing 3 times, it means initialization was not successful. In such case, turn off ignition switch and perform Steps 1) to 6) again.



Auto-On Headlight Sensor Inspection (If Equipped)

S7RW0C9206026

- 1) Disconnect negative (-) cable at battery.
- 2) Remove auto-on headlight sensor (1) located on the passenger side of the dashboard (2). Be careful not to damage the sensor (1) and dashboard by using rag (3).




- 3) Measure voltage between white wire terminal and black wire terminal at the following condition. If measured voltage is out of specification, replace sensor.

Auto-on headlight sensor voltage specifications

Cover the sensor lens with hand: 0.4 V

Light the sensor lens with incandescent lamp

100 W: 3 – 4.5 V




Illumination Cancel Switch Inspection (If Equipped)

S7RW0C9206027

Check for continuity between terminals at each switch position.

If check result is not as specified, replace switch.





Terminal	1	2	3
Switch Position			
OFF			
ON (PUSH IN)			

I6RW0A920015-01


Tail Light Relay, Headlight Relay, Front Fog Light Relay Inspection (If Equipped)

S7RW0C9206028

- 1) Remove tail light relay (1), headlight relay and/or front fog light relay (2).




I6RW0C920027-02



I6RW0C920028-01

[A]:	Junction block with BCM type (other than discharge headlight model)
[B]:	Junction block with BCM type (discharge headlight model)
[C]:	Junction block without BCM type
3.	Headlight low beam relay (left side)
4.	Headlight low beam relay (right side)
5.	Headlight high beam relay (left side)
6.	Headlight high beam relay (right side)
7.	Junction block
8.	Battery

- 2) Check that there is no continuity between terminal "3" and "4". If there is continuity, replace relay.
- 3) Connect battery positive (+) terminal to terminal "2" of relay.
- 4) Connect battery negative (-) terminal to terminal "A" of relay.
- 5) Check continuity between terminal "3" and "4". If there is no continuity when relay is connected to the battery, replace relay.



I4RS0A920022-01

Specifications

Tightening Torque Specifications

S7RW0C9207001

Fastening part	Tightening torque			Note
	N·m	kgf-m	lb-ft	
Height sensor bolt	5.5	0.6	4.0	☞
Height sensor nut	13	1.3	9.5	☞

Reference:

For the tightening torque of fastener not specified in this section, refer to “Fasteners Information in Section 0A”.

Instrumentation / Driver Info. / Horn

Precautions

Precautions in Diagnosing Troubles for Combination Meter

S7RW0C9300001

Combination meter uses signals (information) from each control module by CAN communication to control speedometer, tachometer, fuel meter, engine coolant temp meter, warning light and indicator light (other than air bag warning light, EPS warning light, headlight leveling warning light (if equipped), rear fog light indicator light (if equipped), high beam indicator light and turn signal indicator light). Therefor, check that no DTC is detected in each module before performing combination meter symptom diagnosis. If any DTC is detected, correct trouble indicated by that DTC troubleshooting first.


General Description

CAN Communication System Description

S7RW0C9301001

Refer to “CAN Communication System Description in Section 1A” for CAN communication system description. Combination meter communicates control data with each control module as follows.

Combination Meter Transmission Data



I5RW0A930001-02

Combination Meter Reception Data


		ECM	TCM (A/T model)	BCM	ABS Control Module	4WD Control Module (if equipped)	Keyless Start Control Module (if equipped)
Combination Meter		Engine speed signal	☐				
		Immobilizer indicator light control signal	☐				
		Vehicle speed signal	☐				
		Engine coolant temperature signal	☐				
		Fuel level signal	☐				
		"CRUSE" and "SET" indicator light control signal	☐				
		Odometer signal	☐				
		MIL control signal	☐	☐			
		Transmission warning light signal		☐			
		Transmission range sensor signal		☐			
		Diagnostic trouble code (DTC)		☐			
		Brake fluid level switch signal (brake warning light control signal)		☐			
		Driver side seat belt buckle switch signal (seat belt reminder light control signal)		☐			
		Charging system warning light signal (charge warning light control signal)		☐			
		Engine oil pressure switch signal (oil pressure warning light control signal)		☐			
		Parking brake switch signal (brake warning light control signal)		☐			
		Illumination ON signal		☐			
		Door switch signal (open door warning light control signal)		☐			
		ABS indication signal			☐		
		EBD indication signal (brake warning light control signal)			☐		
		4WD mode indicator control signal				☐	
		Key indicator light control signal					☐

Auto Volume Control System Description (If Equipped)

S7RW0C9301002

Function of auto volume control system is to vary sound volume according to changes of vehicle speed. How much sound volume varies depends on selected level.


Reference Correlation Chart of Vehicle Speed and Sound Volume



Schematic and Routing Diagram

Combination Meter Circuit Diagram

S7RW0C9302001




I6RW0C930002-01

1. DOME fuse	8. ODO-TRIP	15. Power supply
2. METER fuse	9. 4WD control module (if equipped)	16. Interface circuit
3. Combination switch	10. CAN junction connector	17. CAN driver
4. Tachometer	11. SDM	18. Stepper motor and LED output driver
5. Speedometer	12. Combination switch (high beam)	19. A/T shift position indicator ("P", "R", "N", "D", "3", "2" and "L")
6. Fuel meter	13. P/S control module	20. Combination meter
7. ECT meter	14. CPU	

Terminal arrangement of coupler viewed from terminal side

NOTE

Molded numbers (1) have no relation to the terminal numbers.




I7RW01930004-01

Terminal	Circuit	Terminal	Circuit
G241-1	To turn signal light switch (turn R)	G241-17	—
G241-2	—	G241-18	—
G241-3	—	G241-19	To headlight leveling control module (if equipped)
G241-4	—	G241-20	—
G241-5	To SDM (air bag warning light control signal)	G241-21	To rear fog light switch (if equipped)
G241-6	CAN communication line (Active High Signal)	G241-22	To lighting switch (high beam)
G241-7	CAN communication line (Active High Signal)	G241-23	—
G241-8	—	G241-24	—
G241-9	CAN communication line (Active Low Signal)	G241-25	To P/S control module (EPS warning light control signal)
G241-10	CAN communication line (Active Low Signal)	G241-26	To turn signal light switch (turn L)
G241-11	—	G241-27	—
G241-12	—	G241-28	—
G241-13	—	G241-29	—
G241-14	—	G241-30	—
G241-15	—	G241-31	To METER fuse
G241-16	GND	G241-32	To DOME fuse

Component Location

Audio System Component Location

S7RW0C9303001



I7RW0C930001-02

1. Radio or navigation assembly	4. Antenna feeder	7. GPS antenna (if equipped)	10. Glass antenna (Sedan)
2. Front speaker	5. Antenna (Hatchback)	8. Front tweeter speaker (if equipped)	11. Antenna amplifier (Sedan)
3. Rear speaker	6. Antenna base (Hatchback)	9. Rear tweeter speaker (if equipped)	(a) : 5.0 N·m (0.5 kgf-m, 4.0 lb-ft)

Diagnostic Information and Procedures

Speedometer and VSS Symptom Diagnosis

S7RW0C9304001

Condition	Possible cause	Correction / Reference Item
Speedometer shows no operation or incorrect operation	Circuit fuse blown	<i>Replace fuse and check for short circuit.</i>
	Front wheel speed sensor or sensor encoder faulty	<i>Check front wheel speed sensor or sensor encoder referring to "Front and Rear Wheel Speed Sensor On-Vehicle Inspection in Section 4E" or "Front Wheel Speed Sensor Encoder On-Vehicle Inspection in Section 4E".</i>
	Wiring or grounding faulty	<i>Repair circuit.</i>
	Combination meter faulty	<i>Replace combination meter.</i>
	ECM faulty	<i>Replace after making sure that none of above parts is faulty.</i>

Tachometer Symptom Diagnosis

S7RW0C9304002

Condition	Possible cause	Correction / Reference Item
Tachometer shows no operation or incorrect operation	Circuit fuse blown	<i>Replace fuse and check for short circuit.</i>
	Wiring or grounding faulty	<i>Repair circuit.</i>
	Combination meter faulty	<i>Replace combination meter.</i>
	ECM faulty	<i>Replace after making sure that none of above parts is faulty.</i>

Engine Coolant Temperature (ECT) Meter Symptom Diagnosis

S7RW0C9304003

Condition	Possible cause	Correction / Reference Item
Engine coolant temperature (ECT) meter shows no operation or incorrect operation	Circuit fuse blown	<i>Replace fuse and check for short circuit.</i>
	ECT sensor faulty	<i>Check ECT sensor referring to "Engine Coolant Temperature (ECT) Sensor Inspection in Section 1C".</i>
	Wiring or grounding faulty	<i>Repair circuit.</i>
	Combination meter faulty	<i>Replace combination meter.</i>
	ECM faulty	<i>Replace after making sure that none of above parts is faulty.</i>

Fuel Meter Symptom Diagnosis

S7RW0C9304004

Condition	Possible cause	Correction / Reference Item
Fuel meter shows no operation or incorrect operation	Circuit fuse blown	<i>Replace fuse and check for short circuit.</i>
	Fuel level sensor faulty	<i>Check fuel level sensor referring to "Fuel Level Sensor Inspection".</i>
	Wiring or grounding faulty	<i>Repair circuit.</i>
	Combination meter faulty	<i>Replace combination meter.</i>
	ECM faulty	<i>Replace after making sure that none of above parts is faulty.</i>

Low Fuel Warning Light Symptom Diagnosis

S7RW0C9304005

NOTE

- Confirm that fuel meter is in good condition before referring to the following possible causes.
- When fuel level sensor circuit is open or short, fuel level meter indicates empty even if fuel tank does not empty.
- The low fuel warning light comes ON when fuel level is lower than specification below.

Low fuel warning light operation:

Low fuel warning light operation:	Fuel amount:	Resistance of fuel level sensor:
ON (2WD)	Approx. 7.5 liter	Approx. 261 Ω
ON (4WD)	Approx. 6.8 liter	Approx. 261 Ω

Condition	Possible cause	Correction / Reference Item
Low fuel warning light does not come ON when fuel level is lower than specification	Circuit fuse blown	Replace fuse and check for short circuit.
	Fuel level sensor faulty	Check fuel level sensor referring to "Fuel Level Sensor Inspection".
	Wiring or grounding faulty	Repair circuit.
	Combination meter faulty	Replace combination meter.
	ECM faulty	Replace after making sure that none of above parts is faulty.
Low fuel warning light comes ON steady	Low fuel	Refill fuel.
	Fuel level sensor faulty	Check fuel level sensor referring to "Fuel Level Sensor Inspection".
	Wiring or grounding faulty	Repair circuit.
	Combination meter faulty	Replace combination meter.
	ECM faulty	Replace after making sure that none of above parts is faulty.

Oil Pressure Warning Light Symptom Diagnosis

S7RW0C9304006

Condition	Possible cause	Correction / Reference Item
Oil pressure warning light does not light up when ignition switch is turned to ON position at engine off	Circuit fuse blown	Replace fuse and check for short circuit.
	Oil pressure switch faulty	Check oil pressure switch referring to "Oil Pressure Switch Inspection".
	Wiring or grounding faulty	Repair circuit.
	Combination meter faulty	Replace combination meter.
	BCM faulty	Replace after making sure that none of above parts is faulty.
Oil pressure warning light stays ON	Oil pressure switch faulty	Check oil pressure switch referring to "Oil Pressure Switch Inspection".
	Wiring or grounding faulty	Repair circuit.
	Combination meter faulty	Replace combination meter.
	BCM faulty	Replace after making sure that none of above parts is faulty.

Brake and Parking Brake Warning Light Symptom Diagnosis

S7RW0C9304007

Condition	Possible cause	Correction / Reference Item
Brake warning light does not light up when brake fluid level is low or parking brake is pulled up or for 5 seconds after turning ON ignition switch	Circuit fuse blown	Replace fuse and check for short circuit.
	Brake fluid level switch faulty	Check brake fluid level switch referring to "Brake Fluid Level Switch Inspection".
	Parking brake switch faulty	Check parking brake switch referring to "Parking Brake Switch Inspection".
	ABS system faulty	Refer to "ABS Check in Section 4E".
	Wiring or grounding faulty	Repair circuit.
	Combination meter faulty	Replace combination meter.
	BCM faulty	Replace after making sure that none of above parts is faulty.
Brake warning light stays ON	Brake fluid level switch faulty	Check brake fluid level switch referring to "Brake Fluid Level Switch Inspection".
	Parking brake switch faulty	Check parking brake switch referring to "Parking Brake Switch Inspection".
	EBD system faulty	Refer to "EBD Warning Light (Brake Warning Light) Check in Section 4E".
	Wiring or grounding faulty	Repair circuit.
	Combination meter faulty	Replace combination meter.
	BCM faulty	Replace after making sure that none of above parts is faulty.

Seat Belt Reminder Light Symptom Diagnosis

S7RW0C9304008

Condition	Possible cause	Correction / Reference Item
Seat belt reminder light does not light up	Circuit fuse blown	Replace fuse and check for short circuit.
	Seat belt switch faulty	Check seat belt switch referring to "Front Seat Belt Inspection in Section 8A".
	Wiring or grounding faulty	Repair circuit.
	Combination meter faulty	Replace combination meter.
	BCM faulty	Replace after making sure that none of above parts is faulty.
Seat belt reminder light stays ON	Seat belt switch faulty	Check seat belt switch referring to "Front Seat Belt Inspection in Section 8A".
	Wiring or grounding faulty	Repair circuit.
	Combination meter faulty	Replace combination meter.
	BCM faulty	Replace after making sure that none of above parts is faulty.

A/T Shift Position Indicator Symptom Diagnosis (A/T Model)

S7RW0C9304009

Condition	Possible cause	Correction / Reference Item
All A/T shift position indicator does not light up	Circuit fuse blown	Replace fuse and check for short circuit.
	Transmission range sensor (shift switch) faulty	Check transmission range sensor referring to "Transmission Range Sensor Inspection and Adjustment in Section 5A".
	Wiring or ground faulty	Repair circuit.
	Combination meter faulty	Replace combination meter.
	TCM faulty	Replace after making sure that none of above parts is faulty.

Charge Warning Light Symptom Diagnosis

S7RW0C9304010

Condition	Possible cause	Correction / Reference Item
Charge warning light does not come ON	Circuit fuse blown	Replace fuse and check for short circuit.
	Wiring or grounding faulty	Repair circuit.
	Combination meter faulty	Replace combination meter.
	BCM faulty	Replace after making sure that none of above parts is faulty.
Charge warning light stay ON	Charging system faulty	Check charging system.
	Wiring or grounding faulty	Repair circuit.
	Combination meter faulty	Replace combination meter.
	BCM faulty	Replace after making sure that none of above parts is faulty.

Main Beam (High Beam) Indicator Symptom Diagnosis

S7RW0C9304011

Condition	Possible cause	Correction / Reference Item
Main beam (high beam) indicator does not come ON	Circuit fuse blown	Replace fuse and check for short circuit.
	Combination switch faulty	Check combination switch referring to "Headlight Switch (in Lighting Switch) Inspection in Section 9B".
	Wiring or grounding faulty	Repair circuit.
	Combination meter faulty	Replace combination meter.
Main beam (high beam) indicator stay ON	Combination switch faulty	Check combination switch referring to "Headlight Switch (in Lighting Switch) Inspection in Section 9B".
	Wiring or grounding faulty	Repair circuit.
	Combination meter faulty	Replace combination meter.

Warning Buzzer Circuit Symptom Diagnosis

S7RW0C9304012

NOTE

- Use of SUZUKI scan tool makes it easy to check whether a faulty condition is on the input side or output side of BCM. For checking procedure, refer to "Diagnosis Using Output Test Function of SUZUKI Scan Tool" under "Scan Tool Data in Section 10B".
- Check each part in the order from the top of the following list.

Condition	Possible cause	Correction / Reference Item
Warning buzzer shows no sounding	Circuit fuse blown	Replace fuse and check for short circuit.
	Driver side door switch faulty	Check driver side door switch referring to "Door Switch (Front / Rear Door) Inspection".
	Lighting switch faulty	Check lighting switch referring to "Headlight Switch (in Lighting Switch) Inspection in Section 9B".
	Key reminder switch faulty	Check key reminder switch referring to "Ignition Switch Inspection".
	Seat belt switch faulty	Check seat belt switch referring to "Front Seat Belt Inspection in Section 8A".
	Wiring or grounding faulty	Repair circuit.
	BCM faulty	Replace after making sure that none of above parts is faulty.

Cigarette Lighter Symptom Diagnosis (If Equipped)

S7RW0C9304013

Condition	Possible cause	Correction / Reference Item
Cigarette lighter shows no operation	Circuit fuse blown	<i>Replace fuse and check for short circuit.</i>
	Cigarette lighter faulty	<i>Check cigarette lighter.</i>
	Ignition switch faulty	<i>Check ignition switch referring to "Ignition Switch Inspection".</i>
	Wiring or grounding faulty	<i>Repair circuit.</i>

Horn Symptom Diagnosis

S7RW0C9304014

Condition	Possible cause	Correction / Reference Item
Horn does not operate	Circuit fuse blown	<i>Replace fuse and check for short circuit.</i>
	Horn switch faulty	<i>Check horn switch.</i>
	Horn relay faulty	<i>Check horn relay referring to "Horn Relay Inspection".</i>
	Wiring or grounding faulty	<i>Repair circuit.</i>
	Horn faulty	<i>Check horn referring to "Horn Inspection".</i>

Information Display Symptom Diagnosis (If Equipped)

S7RW0C9304015

NOTE

This thermometer indicates the ambient temperature in the under side of front bumper member. Under any one of the following listed conditions, however, even when the ambient temperature goes up, the thermometer display does not rise so as to correct the rise of the ambient temperature caused by the radiant heat of the engine. When the ambient temperature drops, the thermometer reading follows the change in the temperature.

Be sure to bear this in mind when diagnosing trouble.

- The vehicle speed is 30 km/h (18 mph) or lower.
- Vehicle speed signal is faulty.
- The ignition switch is turned on again within 2 hours.

Condition	Possible cause	Correction / Reference Item
No displaying of information display	Circuit fuse Blown	<i>Replace fuse and check for short circuit.</i>
	Wiring or grounding faulty	<i>Repair circuit.</i>
	Information display unit faulty	<i>Replace unit.</i>
Incorrect thermometer display	Outside air temperature sensor faulty	<i>Check outside air temperature sensor referring to "Outside Air Temperature Sensor Inspection (If Equipped)".</i>
	Vehicle speed signal faulty	<i>Check ECM for DTC referring to "DTC Check in Section 1A".</i>
	Wiring or grounding faulty	<i>Repair circuit.</i>
	Information display unit faulty	<i>Replace unit.</i>
	BCM faulty	<i>Replace after making sure that none of above parts is faulty.</i>
Display of thermometer does not change at -30 °C (-22 °F)	Outside air temperature is -30 °C (-22 °F) or less	—
	Outside air temperature sensor faulty	<i>Check outside air temperature sensor referring to "Outside Air Temperature Sensor Inspection (If Equipped)".</i>
	Information display unit faulty	<i>Replace unit.</i>
	BCM faulty	<i>Replace after making sure that none of above parts is faulty.</i>

Condition	Possible cause	Correction / Reference Item
Display of thermometer does not change at 50 °C (122 °F)	Outside air temperature is 50 °C (122 °F) or more	—
	Outside air temperature sensor faulty	Check outside air temperature sensor referring to “Outside Air Temperature Sensor Inspection (If Equipped)”.
	Information display unit faulty	Replace unit.
	BCM faulty	Replace after making sure that none of above parts is faulty.
Display of thermometer does not change at “- - - °C (°F)”	Outside air temperature sensor faulty	Check outside air temperature sensor referring to “Outside Air Temperature Sensor Inspection (If Equipped)”.
	Outside air temperature sensor circuit is open or short	Repair circuit.
	Wiring or grounding faulty	Repair circuit.
	Information display unit faulty	Replace unit.
	BCM faulty	Replace after making sure that none of above parts is faulty.
Display of fuel consumption does not change at “- - - l / 100 km (km/l, MPG)”	Vehicle is not running (instantaneous fuel consumption mode)	—
	Fuel consumption was reset (average fuel consumption mode, if equipped)	Vehicle runs for a while.
	Vehicle speed signal faulty	Check ECM for DTC referring to “DTC Check in Section 1A”.
	Wiring or grounding faulty	Repair circuit.
	CAN communication data (information) can not be received by BCM	Check BCM for DTC referring to “DTC Check in Section 10B”.
	Information display unit faulty	Replace unit.
	BCM faulty	Replace after making sure that none of above parts is faulty.

Clock System Diagnosis (If Equipped)

S7RW0C9304016

Condition	Possible cause	Correction / Reference Item
No displaying of clock	Circuit fuse blown	Replace fuse and check for short circuit.
	Wiring or grounding faulty	Repair circuit.
	Clock unit faulty	Replace unit.

Audio System Symptom Diagnosis (If Equipped)

S7RW0C9304017

Radio**NOTE**

Electronic part / system with undiagnosed problem may cause electromagnetic interference. Electromagnetic interference condition may have poor radio reception. To test for presence of electromagnetic interference in part / system, perform the following procedures.

1. Turn ignition switch to OFF.
2. Systematically disconnect the electronic part / system connector(s) one at a time.
3. Turn ignition switch to ON.
4. Check any improvement in radio reception.

Condition	Possible cause	Correction / Reference Item
Poor radio reception	Out of service area (Poor location)	—
	Antenna faulty	<i>Replace antenna.</i>
	Electrical part / system faulty	<i>Repair or replace electrical part / system referring to above-mentioned NOTE.</i>
	Wiring or grounding faulty	<i>Repair circuit.</i>
	Radio assembly faulty	<i>Replace radio assembly.</i>
Radio does not operate and speaker does not sound	Circuit fuse(s) blown	<i>Replace fuse(s) and check for short circuit.</i>
	Wiring or grounding faulty	<i>Repair circuit.</i>
	Radio assembly faulty	<i>Replace radio assembly.</i>
Radio does not operate, but speaker sound	Wiring or grounding faulty	<i>Repair circuit.</i>
	Radio assembly faulty	<i>Replace radio assembly.</i>
Radio is operative, but all speakers does not sound	Wiring or grounding faulty	<i>Repair circuit.</i>
	Radio assembly faulty	<i>Replace radio assembly.</i>
Individual speaker is noisy or inoperative	Wiring or grounding faulty	<i>Repair circuit.</i>
	Speaker faulty	<i>Replace speaker.</i>
	Radio assembly faulty	<i>Replace radio assembly.</i>
Sound quality is poor	Out of service area (Poor location)	—
	Speaker installed incorrectly	<i>Install correctly.</i>
	Wiring or grounding faulty	<i>Repair circuit.</i>
	Speaker faulty	<i>Replace speaker.</i>
	Radio assembly faulty	<i>Replace radio assembly.</i>

CD Player

Condition	Possible cause	Correction / Reference Item
CD-ROM does not insert	Another CD-ROM already inserted	<i>Eject CD-ROM.</i>
	Circuit fuse blown	<i>Replace fuse and check for short circuit.</i>
	Wiring or grounding faulty	<i>Repair circuit.</i>
	Extraneous material come to be mixed CD player	<i>Clear extraneous material from CD player or replace radio assembly.</i>
	Radio assembly faulty	<i>Replace radio assembly.</i>
CD-ROM does not eject	Circuit fuse blown	<i>Replace fuse and check for short circuit.</i>
	Wiring or grounding faulty	<i>Repair circuit.</i>
	Extraneous material come to be mixed in CD player	<i>Clear extraneous material from CD player or replace radio assembly.</i>
	Radio assembly faulty	<i>Replace radio assembly.</i>
CD player does not load CD-ROM	CD-ROM faulty	—
	CD-ROM inserted with incorrect side up	<i>Insert correctly.</i>
	Temperature in cabin is too hot	—
	Water droplets form on internal lens	<i>Dry about 1 hour with power on.</i>
	Radio assembly faulty	<i>Replace radio assembly.</i>
Sound skips or is noisy	CD-ROM faulty	—
	Driving vibration	—
	Water droplets form on internal lens	<i>Dry about 1 hour with power on.</i>
	Radio assembly installed incorrectly	<i>Install correctly.</i>
	Radio assembly faulty	<i>Replace radio assembly.</i>
CD player is operative, but all speakers does not sound	Wiring or grounding faulty	<i>Repair circuit.</i>
	Radio assembly faulty	<i>Replace radio assembly.</i>
Individual speaker is noisy or inoperative	Wiring or grounding faulty	<i>Repair circuit.</i>
	Speaker faulty	<i>Replace speaker.</i>
	Radio assembly faulty	<i>Replace radio assembly.</i>
Sound quality or volume is poor	CD-ROM faulty	—
	Wiring or grounding faulty	<i>Repair circuit.</i>
	Speaker installed incorrectly	<i>Install correctly.</i>
	Speaker faulty	<i>Replace speaker.</i>

Auto Volume Control System

Condition	Possible cause	Correction / Reference Item
Sound volume does not vary according to changes of vehicle speed	Auto volume control system is "OFF" mode	<i>Select auto volume control.</i>
	Vehicle speed signal faulty	<i>Check vehicle speed signal referring to "Vehicle Speed Signal Inspection (For Audio Unit) (If Equipped)".</i>
	Wiring or grounding faulty	<i>Repair circuit.</i>
	BCM faulty	<i>Check input and output signal of BCM referring to "Inspection of BCM and Its Circuits in Section 10B".</i>
	Radio assembly faulty	<i>Replace radio assembly.</i>

Remote Audio Control Switch Symptom Diagnosis (If Equipped)

S7RW0C9304018

Condition	Possible cause	Correction / Reference Item
Audio system is operative, but remote control switch does not control audio system	Remote audio control switch faulty	Check remote audio control switch referring to "Remote Audio Control Switch Inspection (If Equipped)".
	Contact coil faulty	Replace contact coil.
	Wiring or grounding faulty	Repair circuit.
	Radio assembly faulty	Replace radio assembly.

Navigation Symptom Diagnosis (If Equipped)

S7RW0C9304019


Condition	Possible cause	Correction / Reference Item
No displaying of navigation	Circuit fuse Blown	Replace fuse and check for short circuit.
	Wiring or grounding faulty	Repair circuit.
	Navigation unit faulty	Replace unit.

Repair Instructions**Ignition Switch Removal and Installation**

S7RW0C9306001


Removal

- 1) Disconnect negative cable at battery.
- 2) Confirm that ignition key is removed.
- 3) Remove dash side trim (4) and steering column hole cover (1).
- 4) Turn steering wheel to remove steering column cover screws (3) and then remove steering column covers (2).



I7RW01930006-01

- 5) Remove steering column mounting nuts referring to Step 7) under "Removal" of "Steering Column Removal and Installation in Section 6B".
- 6) Disconnect couplers (1) from ignition switch (2).
- 7) Remove ignition switch (2) from key cylinder (3).



I4RS0A930008-01


Installation

Reverse removal procedure noting the following. Tighten steering column mounting nuts referring to Step 2) under “Installation” of “Steering Column Removal and Installation in Section 6B”.

Ignition Switch Inspection

S7RW0C9306002

- Check for continuity between terminals at each switch position. If check result is not as specified, replace switch.



Terminal		B1	B2	ACC	IG1	IG2	ST	K1	K2
Key	Position								
OUT	LOCK	☐							
		☐							
IN	ACC	☐		☐					
	ON	☐		☐	☐			☐	☐
	START	☐		☐	☐		☐		

Terminal		P1	P2
Ignition knob switch (with keyless start system only)			
OFF (ignition knob switch released)			
ON (ignition knob switch pushed)		☐	☐


I5RS0D930003-02

Combination Meter Removal and Installation

S7RW0C9306003


Removal

- 1) Disconnect negative (–) cable at battery.
- 2) Remove dash side trim (1) and steering column hole cover (2).




I7RW01930007-01

- 3) Remove center ventilation louver referring to Step 1) and 2) of “Information Display (Clock) Removal and Installation”.
- 4) Remove combination meter cluster panel (1) pulling it in arrow direction shown in figure.



I5RW0A930009-01

- 5) Remove screws (1) fastening combination meter.
- 6) Remove combination meter (2) pulling it arrow direction as shown.



I4RS0A930012-02

Installation

Reverse removal procedure.

Fuel Level Sensor Removal and Installation

S7RW0C9306004

Removal

Remove fuel pump assembly referring to "Fuel Pump Assembly Removal and Installation in Section 1G".

Installation

Install fuel pump assembly referring to "Fuel Pump Assembly Removal and Installation in Section 1G".


Fuel Level Sensor Inspection

S7RW0C9306005

- Check that resistance between terminals "a" and "b" of fuel level sensor changes with change of float position.
- Check resistance between terminals "a" and "b" at each float position in the following.
If the measured value is out of specification, replace.

Fuel level sensor specifications

Float Position		Resistance (Ω)
Full Upper "c"	204 mm (8.03 in.)	40 ± 2
Full Lower "d"	32 mm (1.26 in.)	280 ± 3.3



I7RW01930008-01

Oil Pressure Switch Removal and Installation

S7RW0C9306006

For removal and installation, refer to "Oil Pressure Check in Section 1E".

Oil Pressure Switch Inspection



S7RW0C9306007

- 1) Disconnect oil pressure switch (1) lead wire.
- 2) Check for continuity between oil pressure switch terminal (2) and cylinder block (3) as shown. If check result is not as specified, replace oil pressure switch (1).

Oil pressure sensor specification

During engine running: No continuity

At engine stop: Continuity



I7RW01930009-01

Engine Coolant Temperature (ECT) Sensor Inspection

S7RW0C9306008


Check engine coolant temperature sensor for resistance, refer to "Engine Coolant Temperature (ECT) Sensor Inspection in Section 1C".

Brake Fluid Level Switch Inspection

S7RW0C9306009

Check for continuity between terminals of brake fluid level switch coupler (1). If found defective, replace switch.

Brake fluid level switch specification
OFF position (float up): No continuity
ON position (float down): Continuity



I5RW0A930011-01

Parking Brake Switch Inspection

S7RW0C9306010


Check for continuity between parking brake switch terminal and body ground as shown in figure. If found defective, replace switch.

Parking brake switch specification

OFF position (parking brake released): No continuity

ON position (parking brake lever pulled up):

Continuity



I4RS0A930014-01

1. Parking brake switch

2. Parking brake lever

Door Switch (Front / Rear Door) Inspection


S7RW0C9306011

Remove door switch from body and check switch for continuity. If found defective, replace switch.

Door switch (front / rear door) specification

OFF position (Door closed): No continuity

ON position (Door open): Continuity



I3RH0A930004-01

Rear End Door Switch Inspection (Hatchback)

S7RW0C9306012


Check for continuity between terminal "a" and "b" shown in the following.

If check result is not as specified, replace switch.

Rear end door switch specification

Rear end door closed: No continuity

Rear end door opened: Continuity



I4RS0A930015-01

Trunk Lid Switch Inspection (Sedan)

S7RW0C9306028


Check for continuity between trunk lid connector terminal (1) and body ground.

If check result is not as specified, replace switch.

Trunk lid switch specification

Trunk lid switch (2) is pushed: No continuity

Trunk lid switch (2) is free: Continuity




I2RH01920026-01

Outside Air Temperature Sensor Removal and Installation (If Equipped)

S7RW0C9306013

Removal

- 1) Disconnect negative (–) cable at battery.
- 2) Remove front bumper referring to “Front Bumper and Rear Bumper Components in Section 9K”.
- 3) Disconnect connector from outside air temperature sensor.
- 4) Remove outside air temperature sensor (1) from front bumper member.



I5RW0A930012-01

Installation

Reverse removal procedure for installation.



Outside Air Temperature Sensor Inspection (If Equipped)

S7RW0C9306014

Measure resistance of outside air temperature sensor using an ohmmeter.

If resistance is out of specification, replace outside air temperature sensor.

Outside air temperature sensor resistance
1.61 kΩ – 1.79 kΩ at 25 °C (77 °F)



I4RS0A930017-01

Instrument Panel Removal and Installation


S7RW0C9306015

⚠ WARNING

Refer to “Air Bag Warning in Section 00” before starting service work.


Removal

- 1) Disconnect negative cable at battery.
- 2) Disable air bag system referring to “Disabling Air Bag System in Section 8B”.
- 3) Remove dash side trims (4) and steering column hole cover (1).
- 4) Turn steering wheel to remove steering column cover screws (3).
- 5) Remove steering column covers (2).




I7RW01930010-01

- 6) Remove glove box (1).
- 7) Remove hood latch release lever (2).




I4RS0B930008-01

- 8) Remove console box referring to “Console Box Components in Section 9H”.
- 9) Remove instrument panel center lower bracket bolts (1).




I5RW0A930014-01

- 10) Remove front pillar trims (1).



I7RW01930011-01

- 11) Disconnect instrument panel harness connectors, heater control cables and antenna cable for instrument panel removal.
- 12) Remove steering column assembly referring to "Steering Column Removal and Installation in Section 6B".
- 13) Remove instrument panel ground wire.
- 14) Remove instrument panel mounting bolts (1).
- 15) Remove instrument panel (2) with steering support member (3) and instrument panel harness.



I5RW0A930016-01


Installation

Reverse removal procedure noting the following.

- When installing each part, be careful not to catch any cable or wiring harness.
- Tighten instrument panel mounting bolts to specified torque.

Tightening torque

Instrument panel mounting bolt (a): 23 N·m (2.3 kgf-m, 17.0 lb-ft)



I5RW0A930017-01


- Install steering column assembly referring to "Steering Column Removal and Installation in Section 6B".
- Enable air bag system referring to "Enabling Air Bag System in Section 8B".

Information Display (Clock) Removal and Installation

S7RW0C93006016


Removal

- 1) Remove audio unit referring to "Audio Unit Removal and Installation (If Equipped)".
- 2) Remove center ventilation louver (1) from instrument panel and then disconnect hazard switch connector.



I5RW0A930018-01

- 3) Remove information display (clock) (1) from instrument panel (2) pulling it in arrow direction shown in figure.
- 4) Disconnect information display coupler.



I5RW0A930019-01

Installation


Reverse removal procedure.

Audio Unit Removal and Installation (If Equipped)

S7RW0C9306017


Removal

- 1) Disconnect negative (–) cable at battery.
- 2) Remove instrument panel center garnish trims (1).



I5RW0A930020-03

- 3) Remove 4 mounting screws (1).
- 4) Disconnect electrical connectors from audio unit.
- 5) Remove audio unit (2) from instrument panel.



I5RW0A930021-01

Installation


Reverse removal procedure.

Front Speaker Removal and Installation (If Equipped)

S7RW0C9306018

Removal

- 1) Remove front door trim referring to Step 1) to 3) of "Front Door Glass Removal and Installation in Section 9E".
- 2) Remove 3 front speaker mounting screws (1).
- 3) Remove front speaker (2) from front door panel (3).
- 4) Disconnect front speaker coupler from front speaker (2).



I4RS0A930027-01

Installation


Reverse removal procedure.

Rear Speaker Removal and Installation (If Equipped)

S7RW0C9306019

Removal

- 1) Remove rear door trim referring to Step 1) to 3) of "Rear Door Glass Removal and Installation in Section 9E".
- 2) Remove 3 rear speaker mounting screws (1).
- 3) Remove rear speaker (2) from rear door panel (3).
- 4) Disconnect rear speaker coupler from rear speaker (2).



I4RS0A930027-01

Installation


Reverse removal procedure.

GPS Antenna Removal and Installation (If Equipped)

S7RW0C9306020

Removal

- 1) Remove combination meter cluster panel referring to step 1) to 4) of "Combination Meter Removal and Installation".
- 2) Disconnect GPS antenna connector from navigation unit referring to "Audio Unit Removal and Installation (If Equipped)".
- 3) Remove GPS antenna (1).



I5RW0A930022-01

Installation


Reverse removal procedure.

Horn Removal and Installation

S7RW0C9306021

Removal

- 1) Disconnect negative (–) cable at battery.
- 2) Remove front bumper referring to "Front Bumper and Rear Bumper Components in Section 9K".
- 3) Disconnect horn connector (1).
- 4) Remove horn (2).



I7RW01930015-01

Installation


Reverse removal procedure for installation.

Horn Inspection

S7RW0C9306022

- 1) Disconnect negative (–) cable at battery.
- 2) Remove front bumper referring to "Front Bumper and Rear Bumper Components in Section 9K".
- 3) Disconnect horn connector (1).
- 4) Connect battery positive (+) to terminal of horn connector (2) and negative (–) terminal to body ground.

If horn is not sounding, replace horn.




I7RW01930016-01

Horn Relay Inspection



S7RW0C9306023

- 1) Disconnect negative (–) cable at battery.
- 2) Remove junction block.
- 3) Remove horn relay (1) from junction block (2).



I4RS0B930018-01

- 4) Check that there is no continuity between terminals "c" and "d". If there is continuity, replace relay.
- 5) Check that there is continuity between terminals "c" and "d" when a 12 V battery is connected to terminals "a" and "b". If malfunction is found, replace it with a new one.



I3JA01920006-01

Antenna Base Removal and Installation (Hatchback)

S7RW0C9306024

Removal

- 1) Remove head lining referring to "Head Lining Removal and Installation in Section 9H".
- 2) Remove antenna (1) from antenna base (2).
- 3) Disconnect antenna feeder from antenna base (2).
- 4) Remove antenna base (2) from vehicle.

Installation


Reverse removal procedure noting the following.

- Tighten antenna base mounting bolt to specified torque.

Tightening torque

Antenna base mounting bolt (a): 5.0 N·m (0.5 kgf-m, 4.0 lb-ft)

- Install head lining referring to "Head Lining Removal and Installation in Section 9H".




I7RW01930012-01

Remote Audio Control Switch Removal and Installation (If Equipped)

S7RW0C9306025

Remove


- 1) Remove steering wheel referring to "Steering Wheel Removal and Installation in Section 6B".
- 2) Remove steering wheel cover (1) from steering wheel.



I5RW0A930025-02

2. screw

- 3) Remove remote audio control switch (1) with cruise control switch (3) (if equipped).



I7RW01930013-01

2. screw

Installation

Reverse removal procedure noting the following.

- Install steering wheel referring to "Steering Wheel Removal and Installation in Section 6B".


Remote Audio Control Switch Inspection (If Equipped)

S7RW0C9306026

- 1) Remove driver air bag (inflator) module referring to “Driver Air Bag (Inflator) Module Removal and Installation in Section 8B”.
- 2) Disconnect remote audio control switch connector from contact coil.
- 3) Check switch for resistance between “a” and “b” terminals under each condition below.
If check result is not satisfactory, replace remote audio control switch.

Remote audio control switch resistance

- All switches released (OFF): 5119 – 5223 Ω
- Switch “1” pushing on (ON): 55 – 57 Ω
- Switch “2” pushing on (ON): 129 – 133 Ω
- Switch “3” pushing on (ON): 238 – 244 Ω
- Switch “4” pushing on (ON): 416 – 426 Ω
- Switch “5” pushing on (ON): 743 – 759 Ω
- Switch “6” pushing on (ON): 1555 – 1587 Ω



I6RW0C930004-01

[A]: With cruise control system

[B]: Without cruise control system

Vehicle Speed Signal Inspection (For Audio Unit) (If Equipped)

S7RW0C9306027

Check vehicle speed pulse output signal of BCM referring to “Reference waveform No.7” under “Inspection of BCM and Its Circuits in Section 10B”.

Specifications

Tightening Torque Specifications

S7RW0C9307001

Fastening part	Tightening torque			Note
	N·m	kgf-m	lb-ft	
Instrument panel mounting bolt	23	2.3	17.0	☞
Antenna base mounting bolt	5.0	0.5	4.0	☞

NOTE

The specified tightening torque is also described in the following.
“Audio System Component Location”

Reference:

For the tightening torque of fastener not specified in this section, refer to “Fasteners Information in Section 0A”.

Wipers / Washers

Diagnostic Information and Procedures

Front Wiper and Washer Symptom Diagnosis

S7RW0C9404001

Condition	Possible cause	Correction / Reference Item
Wiper malfunctions	Circuit fuse blown	<i>Replace fuse and check for short circuit.</i>
	Wiper motor faulty	<i>Check wiper motor referring to "Windshield Wiper Motor Inspection".</i>
	Combination switch (wiper switch) faulty	<i>Check wiper switch referring to "Windshield Wiper and Washer Switch Inspection".</i>
	Wiring or grounding faulty	<i>Repair circuit.</i>
Washer malfunctions	Washer hose or nozzle clogged	<i>Clean or repair clogged hose or nozzle.</i>
	Circuit fuse blown	<i>Replace fuse and check for short circuit.</i>
	Washer pump faulty	<i>Check washer pump referring to "Washer Pump Inspection".</i>
	Combination switch (washer switch) faulty	<i>Check washer switch referring to "Windshield Wiper and Washer Switch Inspection".</i>
	Wiring or grounding faulty	<i>Repair circuit.</i>

Rear Wiper and Washer Symptom Diagnosis


S7RW0C9404002

Condition	Possible cause	Correction / Reference Item
Wiper malfunctions NOTE • Use of SUZUKI scan tool makes it easy to check whether a faulty condition is on the input side or output side of BCM. For checking procedure, refer to "Diagnosis Using Output Test Function of SUZUKI Scan Tool" under "Scan Tool Data in Section 10B". • Check each part in the order from the top of the following list.	Circuit fuse blown	<i>Replace fuse and check for short circuit.</i>
	Wiper motor faulty	<i>Check wiper motor referring to "Rear Wiper Motor Inspection".</i>
	Combination switch (wiper switch) faulty	<i>Check wiper switch referring to "Rear Wiper and Washer Switch Inspection".</i>
	Rear wiper relay faulty	<i>Check rear wiper relay referring to "Rear Wiper Relay Inspection".</i>
	Wiring or grounding faulty	<i>Repair circuit.</i>
	BCM faulty	<i>Replace after making sure that none of above parts is faulty.</i>
Washer malfunctions	Washer hose or nozzle clogged	<i>Clean or repair clogged hose or nozzle.</i>
	Circuit fuse blown	<i>Replace fuse and check for short circuit.</i>
	Washer pump faulty	<i>Check washer pump referring to "Washer Pump Inspection".</i>
	Combination switch (washer switch) faulty	<i>Check washer switch referring to "Rear Wiper and Washer Switch Inspection".</i>
	Wiring or grounding faulty	<i>Repair circuit.</i>

Repair Instructions

Wipers and Washers Components

S7RW0C9406001



I7RW01940001-03

1. Windshield wiper blade	8. Washer pump for rear washer	15. Windshield wiper bolt :Tighten bolts in specified order.
2. Windshield wiper arm	9. Washer tank	16. Washer tank bolt
3. Windshield wiper motor	10. Washer hose	[A]: Junction block viewed from relay side
4. Windshield wiper link	11. Washer nozzle	(a) : 18 N·m (1.8 kgf·m, 13.0 lb·ft)


5. Rear wiper arm with blade assembly	12. Wiper switch	⚙(b) : 8 N·m (0.8 kgf-m, 6.0 lb-ft)
6. Rear wiper motor	13. Rear wiper relay	⚙(c) : 5 N·m (0.5 kgf-m, 4.0 lb-ft)
7. Washer pump for windshield washer	14. Junction block.	

Washer Tank and Washer Pump Removal and Installation

S7RW0C9406002

Removal

- 1) Disconnect negative (–) cable at battery.
- 2) Remove front bumper referring to “Front Bumper and Rear Bumper Components in Section 9K”.
- 3) Disconnect washer pump lead wire couplers and hoses.
- 4) Remove washer tank attaching bolts (4).
- 5) Remove washer tank (1).
- 6) Remove windshield washer pump (2) and rear washer pump (3) from washer tank (1).



I7RW01940007-01

5. Right side headlight housing

Installation


Install washer tank and washer pump by reversing removal procedure, noting the following instructions.

- Connect washer pump connector(s) and hose securely.

Washer Pump Inspection

S7RW0C9406003

- 1) Connect battery positive (+) and negative (–) terminals to pump (+) and (–) terminals respectively.
- 2) Check windshield and rear washer pumps for operation.
If pump does not operate, replace washer pump.




I5RW0A940004-01

Windshield Wiper Removal and Installation

S7RW0C9406004


Removal

- 1) Disconnect negative (–) cable at battery.
- 2) Remove wiper pivot caps (1) and wiper arm nuts (2), and remove windshield wiper arms with wiper blades (3).



I4RS0B940003-03

- 3) Remove cowl top garnish referring to “Cowl Top and Front Lower Crossmember Components in Section 9K”.
- 4) Disconnect coupler from windshield wiper motor.
- 5) Remove bolts (1), and remove windshield wiper assembly (2).




I5RW0A940005-02

Installation

- 1) Install windshield wiper assembly (1), and tighten bolts to specified torque in order of "i", "ii" and "iii" indicated in figure.

Tightening torque

Windshield wiper bolt (a): 8 N·m (0.8 kgf-m, 6.0 lb-ft)




I5RW0A940006-02

- 2) Connect coupler to windshield wiper motor.
- 3) Install cowl top garnish referring to "Cowl Top and Front Lower Crossmember Components in Section 9K".
- 4) Install windshield wiper arms with wiper blades (1) to specified position as shown in figure, and then tighten windshield wiper nuts to specified torque.

Tightening torque

Windshield wiper arm nut (a): 18 N·m (1.8 kgf-m, 13.0 lb-ft)

- 5) Install wiper pivot caps (2) to windshield wiper arm nuts.



I7RW01940008-03

3. Ceramic line	6. Ceramic mark
4. Wiper blade center	[A]: Driver side
5. Wiper blade edge	[B]: Passenger side

- 6) Connect negative (–) cable to battery.


Windshield Wiper Motor Inspection

S7RW0C9406005

NOTE

Make sure that battery voltage is 12 V or more.

- 1) Make a mark (1) on windshield wiper motor (2) stop position as shown.






I5RW0A940007-01

- 2) Check windshield wiper motor for operation as follows

- For motor operation in low speed
 - Connect battery positive (+) terminal to terminal "1" and its negative (–) terminal to terminal "5".
 - Check if motor revolution speed is as specification. If check result is not as specified, replace motor.

Specification

41 – 49 r/min (rpm)






I5RW0A940008-01

[A]: LHD

[B]: RHD

- For motor operation in high speed
 - a. Connect battery positive (+) terminal to "2" and its negative (-) terminal to terminal "5".
 - b. Check if motor revolution speed is as specification. If check result is not as specified, replace motor.




Specification**63 – 77 r/min (rpm)**

I5RW0A940009-01

[A]: LHD

[B]: RHD

- For automatic stop operation
 - a. Connect battery positive (+) terminal to terminal "1" and its negative (-) terminal to terminal "5" and let the motor turn.
 - b. Disconnect terminal "1" from battery positive (+) terminal, and let the motor stop.
 - c. Connect terminals "1" and "3" with a jumper wire, and connect terminal "4" to battery positive (+) terminal. Observe the motor turns once again then stops at a specified position as shown.



I5RW0A940010-01

[A]: LHD

[B]: RHD

2. Mark

- d. Repeat Step a. to c. several times and check that the motor stops at the specified position every time.


If check result is not satisfied, replace motor.

Rear Wiper Removal and Installation

S7RW0C9406006

Removal

- 1) Disconnect negative (–) cable at battery.
- 2) Remove arm cover (1), rear wiper arm nut (2), rear wiper arm with blade assembly (3), rear wiper pivot cap (4), rear wiper nut (5) and rear wiper seal (6).



I4RS0A940013-01


- 3) Remove rear end door trim referring to “Rear End Door Lock Assembly Removal and Installation (Hatchback Model) in Section 9F”.
- 4) Disconnect coupler from rear wiper motor.
- 5) Remove rear wiper motor.

Installation

- 1) Install rear wiper motor (1) and tighten rear wiper motor mounting bolts to specified torque.

Tightening torque

Rear wiper motor mounting bolt (a): 8 N·m (0.8 kgf-m, 6.0 lb-ft)




I5RW0A940011-01

- 2) Connect coupler to rear wiper motor
- 3) Install rear end door trim referring to “Rear End Door Lock Assembly Removal and Installation (Hatchback Model) in Section 9F”.
- 4) Install rear wiper seal (1), and tighten rear wiper nut to specified torque.

Tightening torque


Rear wiper nut (a): 5 N·m (0.5 kgf-m, 4.0 lb-ft)

- 5) Install rear wiper pivot cap (2).



I4RS0A940015-01

- 6) Install rear wiper arm with blade assembly (1) to specified position as shown in figure.




I5RW0A940012-01

- | |
|---------------------|
| 2. Rear wiper blade |
| 3. Ceramic line |

- 7) Tighten rear wiper arm nut to specified torque, and then install arm cover (1).

Tightening torque

Rear wiper arm nut (a): 8 N·m (0.8 kgf-m, 6.0 lb-ft)



I4RS0A940017-01

- 8) Connect negative (–) cable to battery.


Rear Wiper Motor Inspection

S7RW0C9406007

NOTE

Make sure that battery voltage is 12 V or more.

- 1) Make a mark (1) on rear wiper motor (2) stop position as shown.





I5RW0A940013-02

- 2) Check rear wiper motor for operation as follows.

- For motor operation
 - a. Connect battery positive terminal to terminal "1" and its negative terminal to terminal "2".
 - b. Check if motor reciprocation speed is as specification. If check result is not as specified, replace motor.



Specification

35 – 45 r/min (rpm)



I5RW0A940014-01

- For automatic stop operation
 - a. Connect battery positive (+) terminal to terminal "1" and its negative (-) terminal to terminal "2" and let the motor turn.
 - b. Disconnect terminal "2" from battery negative (-) terminal and let the motor stop.
 - c. Observe the motor (4) turns once again then stops at a specified position as shown.



I5RW0A940015-02

5. Mark


- d. Repeat Step a. to c. several times and check that the motor stops at the specified position every time.
If check result is not satisfied, replace motor.

Windshield Wiper and Washer Switch Removal and Installation

S7RW0C9406008


Removal

- 1) Disconnect negative (–) cable at battery.
- 2) Remove steering column hole cover (1).
- 3) Remove steering column covers (2).
Turn steering wheel to access steering column cover rear end screws (3).



I5RW0A940016-01

- 4) (Immobilizer model)
Remove immobilizer control module referring to “ICM Removal and Installation in Section 10C”.
- 5) Remove windshield wiper and washer switch (1) from combination switch assembly (2) and disconnect its coupler (3).



I4RS0B940008-01

Installation



Reverse removal procedure.

Windshield Wiper and Washer Switch Inspection

S7RW0C9406009

Windshield Wiper and Washer Switch

Check for continuity between terminals at each switch position. If check result is not as specified, replace switch.



[D]	[C]	6	5	4	3
OFF				○	○
INT				○	○
LO			○	○	
HI		○	○		
MIST			○	○	


[E]	[C]	1	2
ON		○	○
OFF			

I5JB0D940001-01

[A]: RHD without rear fog light
[B]: Other than RHD without rear fog light
[C]: Terminal
[D]: Wiper switch
[E]: Washer switch

Intermittent Wiper Relay Circuit



- 1) Turn the windshield wiper switch to "INT" position.
- 2) Connect battery positive (+) terminal to terminal "5" and its negative (-) terminal to terminal "2".
- 3) Connect voltmeter positive lead to terminal "4" and its negative lead to terminal "2".
- 4) Check that the voltmeter indicates the battery voltage (10 – 14 V).
- 5) Connect terminal "3" and terminal "5" by a jumper wire.



I5JB0D940002-02

[A]: RHD without rear fog light
[B]: Other than RHD without rear fog light

- 6) Disconnect end of the jumper wire from terminal "5".
 - 7) Connect disconnected jumper wire end to terminal "2", then check that voltage between terminal "4" and terminal "2" changes as shown.
- If check result is not satisfied, replace switch.





I5JB0D940003-02

[A]: RHD without rear fog light
[B]: Other than RHD without rear fog light

[C]: Voltage
[D]: INT time control switch position
[E]: 1.6 ± 1 sec.
[F]: 10.7 ± 5 sec.

Washer Linked Circuit

- 1) Make sure that front wiper switch is at "OFF" position.
 - 2) Connect battery positive (+) terminal to terminal "5" and its negative (-) terminal to terminal "2".
 - 3) Connect voltmeter positive lead to terminal "4" and its negative lead to terminal "2".
 - 4) When front washer switch is ON, check that voltage changes as shown in figure.
- If check result is not satisfied, replace switch.



I5JB0D940004-02

[A]: RHD without rear fog light
[B]: Other than RHD without rear fog light
[C]: Wiper switch
[D]: Voltage
[E]: Approx. 2.2 sec.
[F]: Approx 0.3 se.

Rear Wiper and Washer Switch Removal and Installation


S7RW0C9406010

For removal and installation, refer to “Windshield Wiper and Washer Switch Removal and Installation”.

Rear Wiper and Washer Switch Inspection

S7RW0C9406011

Check for continuity between terminals at each switch position. If check result is not as specified, replace switch.



	1	2	3	4
OFF				
[C]	○			○
[D]	○		○	
[E]	○	○	○	
[F]	○	○		

I5JB0D940005-01

- [A]: RHD without rear fog light
- [B]: Other than RHD without rear fog light

Rear Wiper Relay Removal and Installation

S7RW0C9406012

Removal

- 1) Disconnect negative (–) cable at battery.
- 2) Remove junction block (1).
- 3) Remove rear wiper relay (2) from junction block.



I7RW01940006-01


Installation

Reverse removal procedure for installation.

Rear Wiper Relay Inspection

S7RW0C9406013

- 1) Check that there is no continuity between terminal “3” and “4”. If there is continuity, replace relay.
- 2) Connect battery positive (+) terminal to terminal “2” of relay.
- 3) Connect battery negative (–) terminal to terminal “1” of relay.
- 4) Check continuity between terminal “3” and “4”. If there is no continuity when relay is connected to the battery, replace relay.



I4RS0A940028-01

Specifications**Tightening Torque Specifications**

S7RW0C9407001

Fastening part	Tightening torque			Note
	N·m	kgf-m	lb-ft	
Windshield wiper bolt	8	0.8	6.0	🔧
Windshield wiper arm nut	18	1.8	13.0	🔧
Rear wiper motor mounting bolt	8	0.8	6.0	🔧
Rear wiper nut	5	0.5	4.0	🔧
Rear wiper arm nut	8	0.8	6.0	🔧

NOTE

The specified tightening torque is also described in the following.
“Wipers and Washers Components”

Reference:

For the tightening torque of fastener not specified in this section, refer to “Fasteners Information in Section 0A”.

Glass / Windows / Mirrors

General Description

Rear End Door Window Defogger System Description

S7RW0C9501001

The rear end door window defogger is controlled by BCM. For the BCM description refer to “BCM General Description in Section 10B”.

Diagnostic Information and Procedures

Rear End door Window / Back Window Defogger Symptom Diagnosis

S7RW0C9504001

NOTE

- Use of SUZUKI scan tool makes it easy to check whether a faulty condition is on the input side or output side of BCM. For checking procedure, refer to “Diagnosis Using Output Test Function of SUZUKI Scan Tool” under “Scan Tool Data in Section 10B”.
- Check each part in the order from the top of the following list.

Condition	Possible cause	Correction / Reference Item
Rear end door window back window defogger does not operate	Circuit fuse blown	Replace fuse and check for short circuit.
	Rear end door window / back window defogger switch faulty	Check rear end door window / back window defogger switch referring to “Rear End Door Window / Back Window Defogger Switch Inspection”.
	Rear end door window / back window defogger relay faulty	Check rear end door window / back window defogger relay referring to “Rear End Door Window / Back Window Defogger Relay Inspection”.
	Defogger wire faulty	Check defogger wire referring to “Rear End Door Window / Back Window Defogger Wire Inspection”.
	Wiring or grounding faulty	Repair circuit.
	BCM faulty	Replace after making sure that none of above parts is faulty.

Power Window Control System Symptom Diagnosis

S7RW0C9504002

Condition	Possible cause	Correction / Reference Item
All power windows do not operate	Circuit fuse blown	Replace fuse and check for short circuit.
	Power window main switch faulty	Check power window main switch referring to “Power Window Main Switch Inspection”.
	Ignition switch faulty	Check ignition switch referring to “Ignition Switch Inspection in Section 9C”.
	Wiring or grounding faulty	Repair circuit.
Only one power window does not operate	Power window main switch faulty	Check power window main switch referring to “Power Window Main Switch Inspection”.
	Power window sub switch faulty	Check power window sub switch referring to “Power Window Sub Switch Inspection”.
	Wiring and/or coupler faulty	Check wiring and/or coupler.
	Power window regulator faulty	Check window regulator.
	Power window motor faulty	Check power window motor.
	Wiring or grounding faulty	Repair circuit.

Power Door Mirror Control System Symptom Diagnosis


S7RW0C9504003

Condition	Possible cause	Correction / Reference Item
All power mirrors do not operate	Circuit fuse blown	Replace fuse and check for short circuit.
	Power door mirror switch faulty	Check power door mirror switch referring to "Power Door Mirror Switch Inspection".
	Wiring or grounding faulty	Repair circuit.
One power mirror does not operate	Power door mirror switch faulty	Check power door mirror switch referring to "Power Door Mirror Switch Inspection".
	Power door mirror actuator faulty	Check actuator refraining to "Power Door Mirror Actuator Inspection".
	Wiring or grounding faulty	Repair circuit.

Repair Instructions

Windshield Components

S7RW0C9506001



I5RW0A950001-02

1. Windshield glass	3. Windshield glass stopper	⊗ : Do not reuse.
2. Windshield molding	4. Spacer	

Windshield Removal and Installation

S7RW0C9506002

Preparation

The windshield is installed by using a special type of adhesive (that is, one component urethane adhesive used with primer). For the windshield replacement, it is important to use an adhesive which provides sufficient adhesion strength and follow the proper procedure.

⚠ CAUTION

- **Described is the glass replacement by using 3 types of primers and 1 type of adhesive made by YOKOHAMA (one component urethane adhesive to be used with primer in combination). When using primer and adhesive made by other manufacturers, be sure to refer to handling instructions supplied with them. Negligence in following such procedure or misuse of the adhesive in any way hinders its inherent adhesive property. Therefore, before the work, make sure to read carefully the instruction and description given by the maker of the adhesive to be used and be sure to follow the procedure and observe each precaution throughout the work.**
- **Should coated surface be scratched or otherwise damaged, be sure to repair damaged part, or corrosion may start from there.**

Use the specific adhesive which has the following property.


**Glass adhesive shearing strength
40 kg/cm² (569 lb/in²) or more**

Adhesive materials and tools required for removal and installation.

- One component urethane adhesive and primers used in combination (For one sheet of windshield).
 - Adhesive (470 g (15.7 oz.))
 - Primer for glass (30 g (1.0 oz.))
 - Primer for body (30 g (1.0 oz.))
 - Primer for molding (30 g (1.0 oz.))
- Eyeleteer
- Piano string
- Windshield knife
- Brush for primer application (2 pcs)
- Knife
- Rubber sucker grip
- Sealant gun (for filling adhesive)
- Putty spatula (for correcting adhered parts)

Removal

- 1) Clean both inside and outside of glass and around it.
- 2) Remove wiper arms and cowl top garnish.
- 3) Using tape, cover body surface around glass to prevent any damage.
- 4) Remove rear view mirror, sun visor and front pillar trims (right & left).
- 5) If necessary, remove instrument panel. Refer to "Instrument Panel Removal and Installation in Section 9C".
- 6) If necessary, remove head lining. Refer to "Head Lining Removal and Installation in Section 9H".
- 7) Remove (or cut) windshield molding.
- 8) Drill hole with eyeleteer (1) through adhesive and let piano string through it.




I2RH01950040-01

- 9) Cut adhesive all around windshield (1) with piano string (2). When using tool, windshield knife (3), to cut adhesive, be careful not to cause damage to windshield. Use wire to cut adhesive along lower part of windshield.

NOTE

Use piano string (2) as close to glass as possible so as to prevent damage to body and instrument panel.




I3RH0A950006-01

- 10) Using knife (1), smoothen adhesive (2) remaining on body side (3) so that it is 1 – 2 mm (0.040 – 0.078 in.) thick all around.


NOTE

Before using knife (1), clean it with alcohol or the like to remove oil from it.



I2RH01950042-01


- 11) When reusing windshield, remove the adhesive (1) from it, using care not to damage primer coated surface (2).



I2RH01950043-01

Installation

- 1) Using cleaning solvent, clean windshield edge where windshield glass is to be adhered. (Let it dry for more than 10 minutes.)
- 2) Install new glass stoppers (1) (2 pieces) to lower side of windshield (2) as shown.




I5RW0A950002-01

3. Mark

- 3) To determine installing position of glass (1) to body (2), position glass against body so that clearance between upper end of glass (1) and body (2) is approximately 5.5 mm (0.217 in.) and clearances between each side end (right & left) of glass (1) and body (2) are even. Then mark mating marks (3) on glass (1) and body (2) as shown. Upper clearance can be adjusted by moving glass stoppers position.

Windshield clearance

"a": approx. 5.5 mm (0.217 in.)




I5RW0A950003-02

9E-5 Glass / Windows / Mirrors:

- 4) Clean contact surfaces of old adhesive (4), paint or bare metal thoroughly.
If surfaces of paint or bare metal come out, apply primer (2) for body with caution not to apply primer (2) to surface of adhesive remaining on body.

NOTE

- Be sure to refer to primer maker's instruction for proper handling and drying time.
- Do not touch body and old adhesive surfaces where glass is to be adhered.




I2RH01950046-01

- 5) Install new molding to glass.
6) Clean glass surface to be adhered to body with clean cloth. If cleaning solvent is used, let it dry for 10 minutes or more.

Cleaning Area for windshield (distance from the edge of glass or molding)

30 – 50 mm (1.19 – 1.96 in.)

- 7) Install new spacers (1) to windshield (2).



I5RW0A950004-01

- 8) Using new brush, apply sufficient amount of primer onto glass along glass edge.


NOTE

- Be sure to refer to maker's instruction for proper handling and drying time.
- Do not apply primer on outside of ceramic coated surface.
- Do not touch primer coated surface.

Width applied primer for windshield

"a": 17 mm (0.67 in.)

"b": 20 mm (0.79 in.)



I5RW0A950005-01

- 9) Apply primer for molding along molding surface all around.

10) Apply adhesive (1) referring to figure.

NOTE

- Press glass (2) against fittings surface of body panel quickly after adhesive (1) is applied.
- Use of rubber sucker grip is helpful to hold and carry glass after adhesive (1) is applied.
- Perform steps 8) to 9) within 10 min. to ensure sufficient adhesion.
- Be sure to refer to adhesive maker's instruction for proper handling and drying time.
- Start from bottom side of glass (2).
- Be careful not to damage primer.


Adhesive amount specifications and position for windshield

Width "a": Approx. 7 mm (0.27 in.)

Height "b": Approx. 15 mm (0.59 in.)


Position "c": Approx. 10 mm (0.39 in.) for right, left and upper sections

Position "d": Approx. 50 mm (1.97 in.) for bottom section



I5RW0A950006-01

11) Holding rubber sucker grips (1), place glass onto body by aligning mating marks marked in step 3) and press it.



I2RH01950050-01

12) Check for water leakage by pouring water over windshield through hose. If leakage is found, dry windshield and fill leaky point with adhesive. If water still leaks even after that, remove glass and start installation procedure all over again.

NOTE

- Do not use high pressure water.
- Do not blow compressed air directly at adhesive applied part when drying.
- Do not use infrared light or like for drying.



I2RH01950051-01

3. Molding

4. Windshield glass spacer


⚠ CAUTION

Upon completion of installation, note the following.

- Sudden closing of door before adhesive is completely set may cause glass to become loose or to come off. Therefore, if door is opened or closed before adhesive is completely set, make sure to open all door glasses and use proper care.
- If molding is not securely in place, hold it down with a tape until adhesive is completely set.
- Each adhesive has its own setting time.
- Be sure to refer to its maker's instruction, check setting time of adhesive to be used and observe precautions to be taken before adhesive is set.
- Refrain from driving till adhesive is completely set so as to ensure proper and sufficient adhesion.

Front Pillar Window Components

S7RW0C9506003



I5RW0A950007-02

1. Front pillar window glass

Front Pillar Window Removal and Installation

S7RW0C9506004

Refer to "Windshield Removal and Installation" as preparation, removal and installation procedures are basically the same. However, note the following.

- Observe the following precautions when applying adhesive (1) along glass (2) edge.
- Adhesive (1) should be applied evenly especially in height.
- Be careful not to damage primer (3).
- Press glass against body quickly after adhesive (1) is applied.

Adhesive amount specification and position for front pillar window

Height "a": 10 mm (0.39 in.)

Width "b": 6 mm (0.24 in.)


Position "c": 4.5 mm (0.18 in.)

Width "d": 12 mm (0.47 in.)

Position "e": 3.5 mm (0.14 in.)

Position "f": 5.5 mm (0.22 in.)

Width "g": 11.3 mm (0.44 in.)




I5RW0A950008-01

4. Molding

Rear Quarter Window Components (Hatchback Model)

S7RW0C9506005



I7RW01950001-03

1. Rear quarter window glass

2. Fastener

Rear Quarter Window Removal and Installation (Hatchback Model)

S7RW0C9506006

Refer to "Windshield Removal and Installation" as preparation, removal and installation procedures are basically the same. However, note the following.

- Observe the following precautions when applying adhesive (1) along glass (2) edge.
- Adhesive (1) should be applied evenly especially in height.
- Be careful not to damage primer (3).
- Press glass against body quickly after adhesive (1) is applied.

Adhesive amount specifications and position for rear quarter window


Width "a": Approx. 6 mm (0.24 in.)

Height "b": Approx. 13 mm (0.51 in.)

Position "c": Approx. 12 mm (0.47 in.)

Width "d": Approx. 14 mm (0.55 in.)

Position "e": Approx. 84 mm (3.31 in.)




I5RW0A950010-02

4. Ceramic print line

Rear End Door Window Components (Hatchback Model)

S7RW0C9506007



1. Rear end door glass

2. Fastener

I5RW0A950011-02

Rear End Door Glass Removal and Installation (Hatchback Model)

S7RW0C9506008

Refer to "Windshield Removal and Installation" as preparation, removal and installation procedures are basically the same. However, note the following.

- Observe the following precautions when applying adhesive (1) along glass (2) edge.
- Adhesive (1) should be applied evenly especially in height.
- Be careful not to damage primer (3).
- Install glass (2) on rear end door panel (5) noting the following.
 - With the position of fastener (4) properly aligned.
 - With the position of ceramic mark (6) aligned to the mark (7) of rear end door panel (5).
- Press glass against body quickly after adhesive (1) is applied.

Adhesive amount specifications and position for rear end door glass

Height "a": 13 mm (0.51 in.)

Width "b": 7 mm (0.28 in.)

Width "c": 14 mm (0.55 in.)


Position "d": 15 mm (0.59 in.)

Position "e": 42 mm (1.65 in.)

Position "f": 37 mm (1.46 in.)

Position "g": 9 mm (0.35 in.)


Position "h": 14 mm (0.55 in.)



I7RW01950010-01

Back Window Components (Sedan Model)

S7RW0C9506031



I6RW0B950001-01

1. Back window	2. Back window spacer	3. Back window molding	4. Fastener
----------------	-----------------------	------------------------	-------------

Back Window Removal and Installation (Sedan Model)

S7RW0C9506032

Refer to "Windshield Removal and Installation" as preparation, removal and installation procedures are basically the same. However, note the following.

- Observe the following precautions when applying adhesive (1) along glass (2) edge.
- Adhesive (1) should be applied evenly especially in height.
- Be careful not to damage primer (3).
- Press glass against body quickly after adhesive (1) is applied.

Adhesive amount specifications and position for back window

Width "a": 7.0 mm (0.28 in.)

Width "b": 7.4 mm (0.29 in.)

Height "c": 13.0 mm (0.51 in.)


Height "d": 12.3 mm (0.48 in.)

Position "e": 6.0 mm (0.24 in.)

Position "f": 10.4 mm (0.41 in.)

Position "g": 6.3 mm (0.25 in.)


Width "h": 14.0 mm (0.55 in.)



I6RW0B950002-01

Front Door Window Components

S7RW0C9506009



I7RW01950002-01


1. Door glass	5. Door sealing cover	9. Front door inner weather-strip
 2. Window regulator assembly: Apply lithium grease 99000-25011 to sliding part.	6. Door panel	10. Front door outer weather-strip
3. Glass run	7. Front door sash	11. Door trim bracket
4. Door trim	 8. Door glass mounting screw: Tighten rear screw first, and then tighten front screw.	12. Door mirror trim

Front Door Glass Removal and Installation

S7RW0C9506010


Removal

- 1) Remove door mirror trim (1).
- 2) Remove door trim mounting screws (2).




I5RW0A950014-02

- 3) Remove door trim (1) as shown.
And disconnect connectors from power window switch, door mirror and tweeter (if equipped).




I8RW01950002-01

- 4) Remove door inner weather-strip (3).
- 5) Remove door trim bracket (1).
- 6) Remove door sealing cover (2).



I5RW0A950016-02

- 7) Remove door glass mounting screws (1).
- 8) Remove door glass (2) while tilting it as shown.




I5RW0A950017-03

Installation


Reverse removal procedure noting the following instructions.

- If there is deformity for glass run, replace it with a new one.
- Tighten door glass rear mounting screw (1) first, and then tighten door glass front mounting screw (2).



I5RW0A950018-02

- Secure door sealing cover (1) with adhesive (2).




I5RW0A950019-02

- Install front door trim.

Front door trim attaching order

(1) → (2) → (3) → (4) → (5) → (6) → (7) → (8)




I8RW01950003-01

Front Door Window Regulator Removal and Installation

S7RW0C9506011

Removal

- 1) Remove door glass referring to "Front Door Glass Removal and Installation".
- 2) Disconnect power window motor lead wire at coupler.
- 3) Remove regulator mounting screws (1), and then remove front door window regulator (2).



I5RW0A950021-02

Installation

Reverse removal procedure noting the following instruction.

- Apply grease to sliding portions of window regulator.

: Grease 99000-25011 (SUZUKI Super Grease A)

Front Door Window Regulator Inspection


S7RW0C9506012

Check the following parts for wear, damage, smooth operation and lubrication:

- Check regulator sliding and rotating parts.
- Check rollers.

Rear Door Window Components

S7RW0C9506013




1. Door glass	7. Door panel	13. Rear door outer garnish
 2. Window regulator assembly : Apply lithium grease 99000-25011 to sliding part.	 8. Rear door window regulator mounting screw : Tighten front screws first, and then tighten rear screws.	14. Rear door partition glass
3. Glass run	9. Rear door outer weather-strip	15. Rear door partition weather-strip
4. Door trim	10. Rear door inner weather-strip	[A]: Hatchback model
5. Door sealing cover	11. Rear door inner garnish	[B]: Sedan model
6. Door sash	12. Door trim bracket	 a, b, c: Door sash mounting bolt and screw. : Tightening order: a → b → c

Rear Door Glass Removal and Installation


S7RW0C9506014

Removal


- 1) Remove rear door inner garnish (1) (hatchback model).
- 2) Remove door trim mounting screws (2).




- 3) Remove door trim (1) as shown.





- 4) Remove door outer garnish (1) (hatchback model).
- 5) Remove door outer weather-strip (2).



- 6) Remove door inner weather-strip (3).
- 7) Remove door trim bracket (1).
- 8) Remove door sealing cover (2).



- 9) Detach rear part of glass run (2) with rear door sash (1).




[A]: Hatchback model

[B]: Sedan model


9E-15 Glass / Windows / Mirrors:

- 10) Remove rear door partition glass (1) with rear door partition weather-strip (2) (sedan model).



I6RW0B950005-01

- 11) Remove door glass as shown.




I5RW0A950028-01

Installation


Reverse removal procedure noting the following instructions.

- Tighten door sash mounting bolts and screw ("1" – "3") according to numerical order as shown in figure.



I6RW0B950006-01

- If there is deformity for glass run, replace it with a new one.
- Secure door sealing cover (1) with adhesive (2).




I5RW0A950029-04

- Install rear door trim.

Rear door trim attaching order

(1) → (2) → (3) → (4) → (5) → (6) → (7)




I8RW01950006-01

Rear Door Window Regulator Removal and Installation

S7RW0C9506015

Removal

- 1) Remove door glass referring to "Rear Door Glass Removal and Installation".
- 2) Disconnect power window motor lead wire at coupler.
- 3) Loosen regulator mounting screws, and then remove rear window regulator (1).



I5RW0A950031-01


Installation

Reverse removal procedure noting the following.

- Apply grease to sliding and rotating portions of window regulator.
- **: Grease 99000–25011 (SUZUKI Super Grease A)**
- Tighten rear door window regulator attaching screws.

Rear door window regulator screw tightening order

(1) → (2)



I5RW0A950032-01

Rear Door Window Regulator Inspection

S7RW0C9506016

Check the following point:



- Check regulator sliding and rotating parts.
- Check rollers for wear and damage.

Rear End Door Window / Back Window Defogger Switch Inspection

S7RW0C9506017

- 1) Check rear end door window / back window defogger switch for operation as follows.
 - a) Rear end door window / back window defogger switch is built in HVAC control unit. Remove HVAC control module (unit) referring to "HVAC Control Unit Removal and Installation in Section 7A" or "HVAC Control Module Removal and Installation: Automatic Type in Section 7B".
 - b) Check that there is continuity between terminal (1) and terminal (2) of HVAC control module (unit) when rear end door window / back window defogger switch is at ON position. (Rear end door window / back window defogger switch is kept in push.)
 - c) Check that there is no continuity between terminal (1) and terminal (2) of HVAC control module (unit) when rear end door window / back window defogger switch is at OFF position.

If check result does not meet the above conditions, replace HVAC control module (unit).



I5RW0A950033-01


[A]: Manual A/C model

[B]: Auto A/C model

Rear End Door Window / Back Window Defogger Relay Inspection

S7RW0C9506018



- 1) Disconnect negative (–) cable from battery.
- 2) Remove junction block for inspection of rear end door window / back window defogger relay.
For removal, refer to “BCM (Included in Junction Block) Removal and Installation in Section 10B” (hatchback model).
- 3) Remove rear end door window defogger relay (1) (hatchback model) or back window defogger relay (4) (sedan model) from junction block (2).



I6RW0B950007-02

3. Hood latch release cable

- 4) Check that there is no continuity between terminal “c” and “d”. If there is continuity, replace relay.
- 5) Check that there is continuity between terminals “c” and “d” when a 12 V battery is connected to terminals “a” and “b”.
If malfunction is found, replace it with a new one.




I4RS0A950028-01

Rear End Door Window / Back Window Defogger Wire Inspection

S7RW0C9506019

NOTE

- When cleaning rear end door window glass, use a dry cloth to wipe it along heat wire (1) direction.
- When cleaning glass, do not use detergent or abrasive-containing glass cleaner.
- When measuring wire voltage, use a tester with positive probe (2) wrapped with a tin foil (3) which should be held down on wire by finger pressure.



I2RH01950002-01

Wire Damage Inspection


- 1) Start engine and run it idle speed.
- 2) Turn on defogger switch.
- 3) Measure voltage at each position(s) as follows.
Hatchback model:
Measure voltage at the center of each defogger wire (1), and check defogger wire condition according to the following table.
Sedan model:
Measure voltage at position “a” and position “b” of each defogger wire (1), and check defogger wire condition according to the following table.
If defogger wire open is found, go to next step.

Defogger wire voltage for hatchback model

Voltage	Circuit
10 – 12 V	Defogger wire open between its center and defogger wire ground terminal end (3)
4 – 6 V	Normal condition
0 – 1 V	Defogger wire open between its center and defogger wire power source terminal end (2)

Defogger wire voltage for sedan model


Measuring position	Voltage	Circuit
“a”	5 – 7 V	Defogger wire open between defogger wire power source terminal end (2) and position “a”
	8 – 10 V	Normal condition
	12 – 14 V	Defogger wire open between position “a” and center line (4)
“b”	0 – 1 V	Defogger wire open between center line (4) and position “b”
	2 – 4 V	Normal condition
	5 – 7 V	Defogger wire open between position “b” and defogger wire ground terminal end (3)



I6RW0B950008-01

5. Glass antenna	[B]: Sedan model
[A]: Hatchback model	

- 4) Touch voltmeter negative (–) lead to defogger wire ground terminal end (1).
- 5) Touch voltmeter positive (+) lead with a foil strip to defogger wire power source terminal end (2), then move it along wire to defogger wire ground terminal end (1).
- For hatchback model:
The place where voltmeter fluctuates from 10 – 12 V to 0 – 1 V is where there is open.
- For sedan model:
The place where voltmeter fluctuates from 12 – 14 V to 5 – 7 V or 5 – 7 V to 0 – 1 V is where there is open.
- If found defective, repair defogger wire referring to “Rear End Door Window / Back Window Defogger Wire Repair”.




I6RW0B950009-01

3. Glass antenna	[B]: Sedan model
[A]: Hatchback model	

Rear End Door Window / Back Window Defogger Wire Repair

S7RW0C9506020

- 1) Use white gasoline for cleaning.
- 2) Apply masking tape (1) at both upper and lower sides of heat wire (2) to be repaired.
- 3) Apply commercially-available repair agent (3) with a fine-tip brush (4).
- 4) 2 to 3 minutes later, remove masking tapes (1).




- 5) Leave repaired heat wire as it is for at least 24 hours before operating the defogger again.

Power Window Main Switch Inspection


S7RW0C9506021

Switch for driver side window

- 1) Remove driver side door trim referring to step 1) to 3) of “Front Door Glass Removal and Installation”.
- 2) Remove power window main switch from door trim.
- 3) Connect 12 V battery positive (+) terminal to terminal “IG” of power window main switch and its negative (–) terminal to terminal “E” of power window main switch.
- 4) Check for continuity between terminals as shown below.
If check result is not as specified, replace power window main switch.




Driver side window switch (1)	IG	DRU	DRD	E
UP	○	○	○	○
OFF		○	○	○
DOWN	○	○	○	○



Switch for other window than driver side

- 1) Remove driver side door trim referring to step 1) to 3) of “Front Door Glass Removal and Installation”.
 - 2) Remove power window main switch from door trim.
 - 3) Check for continuity between terminals as shown below.
- If check result is not as specified, replace power window main switch.

Passenger side window switch (1)		IG	ASU	ASD	E
Rear right side window switch (2)		IG	RRU	RRD	E
Rear left side window switch (3)		IG	RLU	RLD	E
UNLOCK (4)	UP				
	OFF				
	DOWN				
LOCK (4)	UP				
	OFF				
	DOWN				



I5RW0A950036-02


[A]: Left-hand steering vehicle
[B]: Right-hand steering vehicle

Power Window Sub Switch Inspection

S7RW0C9506022

- 1) Remove front door trim from door panel, refer to Step 1) to 3) of “Front Door Glass Removal and Installation”.
 - 2) Remove power window sub switch from door trim.
 - 3) Check for continuity between terminals at each switch condition.
- If check result is not as specified, replace switch.


Switch Position	Terminal				
	A	B	C	D	E
UP					
OFF					
DOWN					



I5JB0A950037-01

Door Mirror Components

S7RW0C9506023



I5RW0A950038-03

1.	Door mirror
2.	Door mirror mounting nut :Tighten nuts in such order as indicated in the figure.
3.	Door mirror trim

Door Mirror Removal and Installation

S7RW0C9506024


When removing or installing door mirror, refer to the figure in “Door Mirror Components”.

Power Door Mirror Switch Inspection

S7RW0C9506025

- 1) Remove driver side door trim referring to step 1) to 3) of “Front Door Glass Removal and Installation”.
- 2) Remove power window main switch from door trim.
- 3) Check for continuity between terminals at each switch position.
If check result is not as specified, replace door mirror switch.

L	A	C	D	E	G
R	B			F	
Up		○	○	○	○
Down		○	○	○	○
Left	○	○	○	○	
Right	○	○	○	○	





I5JB0A950039-01

Power Door Mirror Actuator Inspection

S7RW0C9506026

- 1) Remove door trim referring to step 1) to 3) of "Front Door Glass Removal and Installation".
- 2) Disconnect door mirror coupler (1).
- 3) Check that door mirror operates properly when battery voltage is applied to connector terminals.
- 4) Connect battery positive (+) and negative (–) terminal to the door mirror terminals as shown. If it does not follow the table's operation, replace door mirror assembly.

Terminal Operation	A	B	C
Up	⊕		⊖
Down	⊖		⊕
Left		⊕	⊖
Right		⊖	⊕



I7RW01950007-01

Special Tools and Equipment**Recommended Service Material**

S7RW0C9508001

Material	SUZUKI recommended product or Specification		Note
Grease	SUZUKI Super Grease A	P/No.: 99000–25011	② / ②

NOTE

Required service material is also described in the following.

"Front Door Window Components"

"Rear Door Window Components"

Security and Locks

General Description

Key Coding Construction

S7RW0C9601001

Key Usage and Identification

Key is used for ignition and door lock cylinders. Key is cut on both edges to make them reversible.

Key identification is obtained from five character key code stamped on key code tag. Using this key code, key code cutting combination can be determined from a code list (available to owners of key cutting equipment from suppliers).

Rear End Door Opener System Description


S7RW0C9601002

Rear end door opener system consists of rear end door opener switch (1), rear end door opener relay (in BCM) (3), rear end door lock assembly (2) and BCM (3).

Rear end door opener system is activated by pushing rear end door opener switch after all doors are unlocked by manual door switch, key cylinder switch, keyless entry transmitter or request switch (5) (if equipped).

When rear end door opener switch pushed rear end door opener relay is ON. Then, BCM releases latch of rear end door lock assembly from striker and rear end door can be opened.

In addition, in case that rear end door cannot be opened by rear end door opener switch, rear end door can be opened by emergency lever (4) in rear end door lock assembly.




I7RW0C960001-02

Component Location

Power Door Lock and Keyless Entry System Component Location

S7RW0C9603001



I7RW0C960002-02

1. Keyless entry receiver	4. Front door actuator	7. Door switch
2. Transmitter	5. Rear door actuator	8. BCM
3. Power door lock switch	6. Rear end door actuator	

Diagnostic Information and Procedures

Power Door Lock System Symptom Diagnosis

S7RW0C9604001

NOTE

- Use of SUZUKI scan tool makes it easy to check whether a faulty condition is on the input side or output side of BCM. For checking procedure, refer to “Diagnosis Using Output Test Function of SUZUKI Scan Tool” under “Scan Tool Data in Section 10B”.
- Check each part in the order from the top of the following list.

Condition	Possible cause	Correction / Reference Item
All door can not be locked / unlocked by all of switches	Circuit fuse blown	Replace fuse and check for short circuit.
	Wiring or grounding faulty	Repair circuit.
	BCM faulty	Replace after making sure that none of above parts is faulty.
All door can not be locked / unlocked by only power door lock switch	Circuit fuse blown	Replace fuse and check for short circuit.
	Power door lock switch faulty	Check power door lock switch referring to “Power Door Lock Switch Inspection”.
	Wiring harness connected to power door lock switch faulty	Repair.
	Wiring or grounding faulty	Repair circuit.
	BCM faulty	Replace after making sure that none of above parts is faulty.
All door can not be locked / unlocked by only key cylinder switch	Circuit fuse blown	Replace fuse and check for short circuit.
	Key cylinder switch faulty	Check key cylinder switch referring to “Door Key Cylinder Switch Inspection”.
	Wiring or grounding faulty	Repair circuit.
	BCM faulty	Replace after making sure that none of above parts is faulty.
Only one door can not be locked / unlocked	Power door lock actuator faulty	Check actuator referring to “Power Door Lock Actuator Inspection”.
	Wiring harness connected to applicable door lock actuator faulty	Repair.
	BCM faulty	Replace after making sure that none of above parts is faulty.

Power Door Lock System Operation Inspection

S7RW0C9604002

1) Check the following operation:

- Turn the driver side key cylinder is turned LOCK once, check all doors lock.
- Turn the driver side door key cylinder is turned UNLOCK position with door key twice, check all doors unlock.
- With all doors unlocked, insert key in key cylinder of driver side door and turn it to lock side, turn it again to lock side within 3 seconds and check that no door can be opened even when door lock knob is moved to unlock side (dead lock function, if equipped).

If malfunction is found, go to “Power Door Lock System Symptom Diagnosis”.

Keyless Entry System Symptom Diagnosis

S7RW0C9604003

NOTE

- Confirm that power door lock system is in good condition before referring to the following possible causes.
- Check each part in the order from the top of the following list.

Condition	Possible cause	Correction / Reference Item
All door can not be locked / unlocked by only keyless entry transmitter	Transmitter battery dead	Replace battery referring to "Replacement of Transmitter Battery (Other than Keyless Start Model)".
	Door switch faulty	Check door switch referring to "Door Switch (Front / Rear Door) Inspection in Section 9C" and/or "Rear End Door Switch Inspection (Hatchback) in Section 9C".
	Transmitter faulty	Replace transmitter.
	Key reminder switch in ignition switch faulty	Check ignition switch referring to "Ignition Switch Inspection in Section 9C".
	Wiring or grounding faulty	Repair circuit.
	Keyless entry receiver faulty	Check keyless entry receiver referring to "Keyless Entry Receiver and Its Circuit Inspection (If Equipped)".
	BCM faulty	Replace after making sure that none of above parts is faulty.
Turn signal lights can not be flashed when doors are locked / unlocked by keyless entry transmitter	Turn signal and hazard warning relay faulty	Check turn signal and hazard warning relay referring to "Turn Signal and Hazard Warning Relay Inspection in Section 9B".
	Wiring or grounding faulty	Repair circuit.
	BCM faulty	Replace after making sure that none of above parts is faulty.
Interior light does not light when doors are unlocked by keyless entry transmitter	Wiring or grounding faulty	Repair circuit.
	BCM faulty	Replace after making sure that none of above parts is faulty.
Hazard warning lights do not light when doors are locked/unlocked by keyless entry transmitter	Turn signal and hazard warning relay faulty	Check turn signal and hazard warning relay referring to "Turn Signal and Hazard Warning Relay Inspection in Section 9B".
	Wiring or grounding faulty	Repair circuit.
	BCM faulty	Replace after making sure that none of above parts is faulty.
Transmitter code can not be programmed to BCM	Door switch faulty	Check door switch referring to "Door Switch (Front / Rear Door) Inspection in Section 9C" and/or "Rear End Door Switch Inspection (Hatchback) in Section 9C".
	Keyless entry receiver faulty	Check keyless entry receiver referring to "Keyless Entry Receiver and Its Circuit Inspection (If Equipped)".
	Key reminder switch in ignition switch faulty	Check ignition switch referring to "Ignition Switch Inspection in Section 9C".
	Wiring or grounding faulty	Repair circuit.
	BCM faulty	Replace after making sure that none of above parts is faulty.

Keyless Entry System Operation Inspection


S7RW0C9604004

NOTE

When performing the this inspection, make sure to have any of the door once opened / closed after the ignition key has been removed from the ignition key cylinder.

- 1) Confirm that power door lock system operates normally, refer to "Power Door Lock System Operation Inspection".
- 2) All doors are closed and unlocked.
- 3) Check the following operation:
 - a) Push "lock" button (1) on transmitter (2) or remote controller once, and check all doors lock and hazard warning lights flash once.
 - b) Push "unlock" button (3) on transmitter (2) or remote controller twice, and check all doors unlock and hazard warning lights flash twice and interior light turns on several seconds with the interior light switch in the middle position.

If malfunction is found, go to "Keyless Entry System Symptom Diagnosis".



I4RS0B960013-01

Door Lock Function of Keyless Start System Symptom Diagnosis (If Equipped)

S7RW0C9604005

Proceed to "Keyless Start System Symptom Diagnosis in Section 10E" in case that doors cannot be locked and unlocked by operating the request switch at the outside door handle.

Rear End Door Opener System Symptom Diagnosis

S7RW0C9604006

NOTE

- Use of SUZUKI scan tool makes it easy to check whether a faulty condition is on the input side or output side of BCM. For checking procedure, refer to "Diagnosis Using Output Test Function of SUZUKI Scan Tool" under "Scan Tool Data in Section 10B".
- Check each part in the order from the top of the following list.

Condition	Possible cause	Correction / Reference Item
Rear end door can not be opened	Circuit fuse blown	Replace fuse and check for short circuit.
	Rear end door opener switch faulty	Check rear end door opener switch referring to "Rear End Door Opener Switch Inspection (Hatchback Model)".
	Rear end door actuator faulty	Check rear end door actuator referring to "Power Door Lock Actuator Inspection".
	Wiring or grounding faulty	Repair circuit.
	BCM faulty	Replace after making sure that none of above parts is faulty.

Rear End Door Opener System Operation Inspection


S7RW0C9604007

- 1) Unlock all doors by using manual lock switch, keyless entry transmitter, or key cylinder switch.
- 2) Make sure that latch of rear end door is released from striker when rear end door opener switch is pushed.
If malfunction is found, go to "Rear End Door Opener System Symptom Diagnosis".

Repair Instructions

Front Door Lock Assembly Components

S7RW0C9606001



I5RW0A960003-01


1. Front door latch assembly : Apply lithium grease 99000-25011 to sliding and rotating parts and spring if any.	4. Latch striker	(a) : 5.0 N-m (0.5 kgf-m, 4.0 lb-ft)
2. Outside handle assembly : Apply lithium grease 99000-25011 to sliding part.	5. Key cylinder	(b) : 10 N-m (1.0 kgf-m, 7.5 lb-ft)
3. Outside handle frame : Apply lithium grease 99000-25011 to sliding part and spring.	6. Inside handle bezel	

Front Door Lock Assembly Removal and Installation

S7RW0C9606002


Removal

- 1) Remove door trim and door sealing cover referring to step 1) to 6) of “Front Door Glass Removal and Installation in Section 9E”.
- 2) Raise window all the way up.
- 3) Remove door sash (1).



I4RS0A960007-01


- 4) Remove key cylinder mounting bolt (1), and then remove key cylinder (2).



I4RS0B960005-01

9F-7 Security and Locks:

- 5) Disconnect door opening control rod (1) from outside handle.
- 6) Disconnect door lock motor lead wire at coupler.
- 7) Remove door latch screws (2) and remove door lock assembly (3).



I4RS0A960006-01


Installation

Reverse removal procedure to install front door lock assembly noting the following instructions.

- Apply grease to sliding parts of door latch assembly.
: Grease 99000-25011 (SUZUKI Super Grease A)
- Tighten door latch screws to specified torque.

Tightening torque

Door latch screw (a): 5.0 N·m (0.5 kgf-m, 4.0 lb-ft)




I4RS0A960008-01

- Move door latch striker (2) up or down so its center aligns with the center of groove "A" on the door lock assembly (1) as shown.
Striker should be moved vertically and placed level.
Do not adjust door lock (1).

Tightening torque



Door latch striker screw (a): 10 N·m (1.0 kgf-m, 7.5 lb-ft)



I5RW0A960005-01

3. Shaft

- Move door latch striker (1) sideways to adjust door outer panel surface (2) flush with rear door outer panel or body outer panel surface (3) as shown.



I5RW0A960012-01

[A]: Front door

[B]: Rear door

- Install door trim referring to "Front Door Glass Removal and Installation in Section 9E".

Front Door Lock Assembly Inspection


S7RW0C9606003

- Check that door open and closes smoothly and properly.
- Check that door stops in the secondary latched position properly (preventing door from opening freely) and that door closed completely in the fully latched position.
- Adjust door latch striker position referring to “Front Door Lock Assembly Removal and Installation”, if necessary.

Power Door Lock Switch Inspection

S7RW0C9606004

Check for continuity between terminals at each switch position. If check result is not as specified, replace switch.



Terminal	A	B	C
Switch			
LOCK			
OFF			
UNLOCK			


I6RW0C960003-01

1. Power door lock switch

Door Key Cylinder Switch Inspection

S7RW0C9606005

- 1) Remove front door trim referring to Step 1) to 3) of “Front Door Glass Removal and Installation in Section 9E”.
- 2) Check for continuity between terminals at each switch position. If check result is not as specified, replace door lock assembly.



Right side switch terminals	b	c	d
Left side switch terminals	c	b	a
LOCK			
OFF			
UNLOCK			


I4RS0B960007-01

Power Door Lock Actuator Inspection

S7RW0C9606006

- 1) Remove door trim from door panel.
For front door, refer to Step 1) to 3) of “Front Door Glass Removal and Installation in Section 9E”.
For rear door, refer to Step 1) to 3) of “Rear Door Glass Removal and Installation in Section 9E”.
For rear end door, refer to Step 1) of “Rear End Door Assembly Removal and Installation (Hatchback Model) in Section 9J”.
- 2) Disconnect power door lock actuator coupler.
- 3) Connect battery positive (+) and negative (–) terminals to the door lock actuator terminals (a, b, c, d) as shown in figure.
If it does not operate as specified in the following table, replace door lock assembly.


For front door



Right side switch terminals	d	b
Left side switch terminals	a	c
Lock → Unlock	⊕	⊖
Unlock → Lock	⊖	⊕

17RW0C960003-01


For rear door



Right side switch terminals	a	c
Left side switch terminals	d	b
Lock → Unlock	⊕	⊖
Unlock → Lock	⊖	⊕

17RW0C960004-01


For rear end door



	a	b
Lock → Unlock	⊕	⊖

15RW0C960003-03

For trunk lid




	a	b
Lock → Unlock	⊕	⊖

18RW01960001-01

Rear Door Lock Assembly Components

S7RW0C9606007



I5RW0A960006-01


1. Outside handle : Apply lithium grease 99000-25011 to sliding part.	4. Latch striker	: 5.0 N·m (0.5 kgf·m, 4.0 lb-ft)
2. Outside handle frame : Apply lithium grease 99000-25011 to sliding part and spring.	5. Inside handle bezel	: 10 N·m (1.0 kgf·m, 7.5 lb-ft)
3. Rear door latch assembly : Apply lithium grease 99000-25011 to sliding part.	6. Out side handle cap	

Rear Door Lock Assembly Removal and Installation

S7RW0C9606008

Removal

- 1) Remove rear door glass referring to “Rear Door Glass Removal and Installation in Section 9E”.
- 2) Disconnect door lock motor lead wire.
- 3) Remove door latch mounting screws (1) and remove door latch assembly (2).



I4RS0A960013-01


Installation

Reverse removal procedure to install rear door lock assembly referring to the following instruction and “Front Door Lock Assembly Removal and Installation”.

- Tighten door latch screw to specified torque.

Tightening torque

Door latch screw (a): 5.0 N·m (0.5 kgf·m, 4.0 lb-ft)



I4RS0A960014-01

- Install door trim referring to “Rear Door Glass Removal and Installation in Section 9E”.


Rear Door Lock Assembly Inspection

S7RW0C9606009

- Check that door opens and closes smoothly and properly.
- Check that door stops in the secondary latched position properly (preventing door from opening freely) and that door closes completely in the fully latched position.
- Adjust door latch striker position referring to “Front Door Lock Assembly Removal and Installation”, if necessary.

Rear End Door Lock Assembly Components (Hatchback Model)

S7RW0C9606010



I7RW01960007-04


1. Rear end door latch assembly (rear end door switch is built in this assembly)	5. Emergency lever : Rear end door is unlocked by pushing emergency lever with flat head driver if rear end door lock can not be released by door opener switch.	(a) : 10 N-m (1.0 kgf-m, 7.5 lb-ft)
2. Rear end door opener switch	6. Rear end door request switch (if equipped)	(b) : 23 N-m (2.3 kgf-m, 17.0 lb-ft)
3. Latch striker	7. Rear end door license garnish	(c) : 6 N-m (0.6 kgf-m, 4.5 lb-ft)
4. Door handle	8. Rear end door license garnish mounting nut : Tighten nuts in such order as indicated in figure.	

Rear End Door Lock Assembly Removal and Installation (Hatchback Model)

S7RW0C9606011


Removal

- 1) Remove door trim (1) from rear end door panel (2).



I5RW0A960008-02

- 2) Disconnect door lock motor lead wire.
- 3) Loosen door latch bolts (1) and remove door latch assembly (2).



I4RS0A960017-01


Installation

Reverse removal procedure to install rear end door lock assembly noting the following instruction.

- Tighten rear end door latch bolt to specified torque.

Tightening torque

Rear end door latch bolt (a): 10 N·m (1.0 kgf-m, 7.5 lb-ft)




I4RS0A960018-01

- Adjust door latch striker so that its center aligns with the center of groove in door latch base.

Tightening torque

Rear end door striker screw (a): 23 N·m (2.3 kgf-m, 17.0 lb-ft)



I4RS0A960019-01

Rear End Door Lock Assembly Inspection (Hatchback Model)


S7RW0C9606012

- Check that door opens and closes smoothly and properly.
- Check that door stops in the secondary latched position properly (preventing door from opening freely) and that door closes completely in the fully latched position.
- Adjust door latch striker position referring to "Front Door Lock Assembly Removal and Installation", if necessary.

Rear End Door Opener Switch Inspection (Hatchback Model)

S7RW0C9606013

- 1) Remove rear end door trim.
 - 2) Disconnect rear end door switch coupler.
 - 3) Check that there is continuity between terminals "a" and "b" when rear end door opener switch (1) is pushed.
 - 4) Check that there is no continuity between terminals "a" and "b" when rear end door opener switch (1) is not pushed.
- If check result is not as specified, replace switch.




I5RW0A960009-02

Trunk Lid Lock Assembly Removal and Installation (Sedan Model)

S7RW0C9606020


Removal

- 1) Remove trunk lid trim (1) from trunk lid panel (if equipped).




I6RW0B960006-01

- 2) Disconnect trunk lid latch control rod (1) from trunk lid.
- 3) (Keyless start model)
Disconnect trunk lid latch actuator coupler (3).
- 4) (Keyless start model)
Remove trunk lid latch actuator (2) from trunk lid.




I8RW01960003-01

- 5) (Non- keyless start model)
Remove trunk lid lock cylinder (1) from trunk lid.



I8RW01960004-01

- 6) Remove trunk lid latch bolt (1), and then disconnect trunk lid opener wire (2) from trunk lid latch (4).
- 7) Remove trunk lid latch (4) with trunk lid latch control rod (3).



I6RW0B960005-01


Installation

Reverse removal procedure to install trunk lid lock assembly noting the following instruction.

- Tighten trunk lid latch bolt (1) to specified torque.

Tightening torque

Trunk lid latch bolt (a): 4.5 N·m (0.45 kgf-m, 3.5 lb-ft)




I6RW0B960008-01

- Adjust trunk lid latch striker (1) so that its center aligns with the center of groove in trunk lid latch base (2).

Tightening torque

Trunk lid latch striker bolt (a): 4.5 N·m (0.45 kgf-m, 3.5 lb-ft)



I6RW0B960011-01

Trunk Lid Lock Assembly Inspection (Sedan Model)

S7RW0C9606021

- Check that trunk lid opens and closes smoothly and properly.
- Adjust trunk lid latch striker position referring to “Front Door Lock Assembly Removal and Installation”, if necessary.

Replacement of Transmitter Battery (Other than Keyless Start Model)

S7RW0C9606014

NOTE

For keyless start model, perform “Replacement of Remote Controller Battery in Section 10E” instead of “Replacement of Transmitter Battery (Other than Keyless Start Model)”.


If transmitter becomes unreliable, replace transmitter battery as follows.

- 1) Remove screw (1) and transmitter cover (2).
- 2) Remove transmitter (3) from transmitter holder (4).

⚠ CAUTION

Use care not to allow grease or dirt to be attached on the printed circuit board and the battery.

- 3) With tip of flat blade screwdriver put in slot of transmitter, pry it open.
- 4) Replace the battery (lithium disc-type CR 1620 or equivalent battery) so its (+) terminal faces “+” mark on transmitter.
- 5) Fit together transmitter (3) and install it into transmitter holder (4).
- 6) Install transmitter cover (2) and screw (1).
- 7) Make sure that door locks can be operated with transmitter.



I4RS0B960014-01

NOTE

- To prevent theft, be sure to break the transmitter before discarding it.

- Dispose of the used battery properly according to applicable rules or regulations. Do not dispose of lithium batteries with ordinary household trash.

Programming Transmitter Code for Keyless Entry System (Other than Keyless Start Model)


S7RW0C9606015

NOTE

- Three transmitter codes can be registered.
- When a new transmitter code is registered, the oldest one will be cleared.
- As for vehicle equipped with keyless start system, perform “Registration Procedure for Remote Controller ID Code in Section 10E” instead of “Programming Transmitter Code for Keyless Entry System (Other than Keyless Start Model)”.

If transmitter or BCM (included in junction block assembly) is replaced with a new one or additional transmitter(s) is necessary, program transmitter code(s).

- 1) Confirm that all doors are closed and ignition key is out of ignition key cylinder.
- 2) Open driver side door.
- 3) Turn ignition switch to ON position, and then drawn ignition key from ignition key cylinder within 10 seconds after that.
- 4) Push and release driver side door switch (1) at 3 times by hand within 20 seconds after removing ignition key from ignition key cylinder.
- 5) Turn ignition switch to ON position, and then drawn ignition key from ignition key cylinder within 10 seconds after that. All doors automatically lock and unlock once.
With this, registration mode.
- 6) Push “UNLOCK” button (2) on transmitter (3) within 20 seconds after Step 5). All doors automatically lock and unlock once.
With this, code registration is completed.
- 7) If an additional transmitter, needs to be programed repeat the procedure of Step 1).



I4RS0B960010-01

Keyless Entry Answer Back Function Change-over Procedure

S7RW0C9606016

Output of keyless entry answer back function can be switched over by performing the following procedure.

- 1) Confirm that all doors are closed, all doors are unlocked, ignition key is out of ignition key cylinder and interior light switch is in the middle position.
- 2) Perform Step a) through c) described below within 10 seconds.
 - a) Insert ignition key in ignition key cylinder.
 - b) Remove ignition key from ignition key cylinder.
 - c) Repeat Step a) and b) once.
- 3) Push “UNLOCK” button on transmitter 3 times within 10 seconds.
- 4) Interior light flashes once which indicates that answer back function is changed over from A mode to B mode.

NOTE

When answer back function is changed from B mode to A mode, hazard warning lights flashes once.

	Answer back A mode		Answer back B mode	
	LOCK	UNLOCK	LOCK	UNLOCK
Hazard warning light	Flashes once	Flashes twice		
Interior light		Turn on for a while	Flashes once	Turn on for a while


I5RS0C960001-01

Keyless Entry Receiver Removal and Installation (If Equipped)

S7RW0C9606017

Removal

- 1) Disconnect negative cable at battery.
- 2) Remove grove box referring to Step 6) of “Instrument Panel Removal and Installation in Section 9C”.
- 3) Disconnect keyless entry receiver coupler.
- 4) Remove keyless entry receiver (1) from steering support member (2).



I5RW0A960010-02


Installation

Reverse removal procedure.

Keyless Entry Receiver and Its Circuit Inspection (If Equipped)

S7RW0C9606018

- 1) Check that the voltage between the following terminals and body ground are specifications under each conditions.
If check result is not as specified, check applicable circuit for open or short. If circuit is normal, proceed to next step.




1. Keyless entry receiver
2. Keyless entry receiver connector (view from harness side)

Terminal	Circuit	Specification	Condition
1	Power source	Figure [A]	Push “Lock” or “Unlock” button on transmitter.
		0 – 1 V	Except the above-mentioned condition.
3	Lock/Unlock output signal circuit	Figure [A]	Push “Lock” or “Unlock” button on transmitter.
		0 – 1 V	Except the above-mentioned condition.
4	Ground	0 – 1 V	—

Oscilloscope setting

CH1: 2V/DIV
 CH2: 2V/DIV
 TIME: 200 ms/DIV



1. Lock/Unlock out put signal
2. Power source

- 1) Recheck keyless entry receiver as follows.
 - a) Substitute a known-good keyless entry receiver.
 - b) Record key code referring to “Programming Transmitter Code for Keyless Entry System (Other than Keyless Start Model)”.
 - c) Recheck keyless entry receiver system.

Specifications

Tightening Torque Specifications

S7RW0C9607001

Fastening part	Tightening torque			Note
	N·m	kgf·m	lb·ft	
Door latch screw	5.0	0.5	4.0	🔩 / 🔩
Door latch striker screw	10	1.0	7.5	🔩
Rear end door latch bolt	10	1.0	7.5	🔩
Rear end door striker screw	23	2.3	17.0	🔩
Trunk lid latch bolt	4.5	0.45	3.5	🔩
Trunk lid latch striker bolt	4.5	0.45	3.5	🔩

NOTE

The specified tightening torque is also described in the following.

“Front Door Lock Assembly Components”

“Rear Door Lock Assembly Components”

“Rear End Door Lock Assembly Components (Hatchback Model)”

“Trunk Lid Lock Assembly Components (Sedan Model)”

Reference:

For the tightening torque of fastener not specified in this section, refer to “Fasteners Information in Section 0A”.

Special Tools and Equipment

Recommended Service Material

S7RW0C9608001

Material	SUZUKI recommended product or Specification		Note
Grease	SUZUKI Super Grease A	P/No.: 99000-25011	🔩

NOTE

Required service material is also described in the following.

“Front Door Lock Assembly Components”


“Rear Door Lock Assembly Components”

Seats

Repair Instructions

Front Seat Components

S7RW0C9706001



I6RW0C970001-01

1. Seat cushion	7. Side air bag module (if equipped)
2. Seat back : Apply lithium grease 99000-25011 to sliding part of reclining.	8. Side air bag harness (if equipped)
3. Headrest	: 23 N·m (2.3 kgf-m, 17.0 lb-ft)
4. Cover	: 35 N·m (3.5 kgf-m, 25.5 lb-ft)
5. Seat adjuster : Apply lithium grease 99000-25011 to seat adjuster inside.	: 28 N·m (2.8 kgf-m, 20.5 lb-ft) (Seat lifter type) 35 N·m (3.5 kgf-m, 25.5 lb-ft) (Non seat lifter type)
6. Knob	a, b, c, d: Seat back mounting bolt Seat mounting bolt Tightening order: a → b → c → d

Front Seat Removal and Installation

S7RW0C9706002

⚠ WARNING

- Refer to “Air Bag Warning in Section 00” before starting service work.

Removal

- 1) Disable air bag system referring to “Disabling Air Bag System in Section 8B”.
- 2) Disconnect seat harness coupler and side air bag coupler, if equipped.
- 3) Remove 4 mounting bolts to remove seat assembly.
- 4) Disassemble and repair seat as necessary.


Installation

Reverse removal procedure to install front seat.

- Torque to specifications as shown in “Front Seat Components”.
- Enable air bag system referring to “Enabling Air Bag System in Section 8B”.


Rear Seat Components

S7RW0C9706003



I7RW0C970001-02

[B]



I7RW0C970002-02

[A]: Hatchback model	11. Child anchorage left bracket
[B]: Sedan model	12. Rear seat side hinge
1. Seat cushion	(a) : 35 N·m (3.5 kgf-m, 25.5 lb-ft)
2. Seat back	(b) : 23 N·m (2.3 kgf-m, 17.0 lb-ft)
3. Head rest (if equipped)	(c) : 25 N·m (2.5 kgf-m, 18.0 lb-ft)
4. Cover	(d) : 45 N·m (4.5 kgf-m, 33.0 lb-ft)
5. Rear center seat belt (if equipped)	(e) : 43 N·m (4.3 kgf-m, 31.5 lb-ft)
6. Seat back striker	(f) : 5.5 N·m (0.55 kgf-m, 4.0 lb-ft)
7. Rear cushion leg : Apply lithium grease to 99000-25011 to cushion leg.	a, b, c: Seat back striker mounting bolt : Tightening order (Left side): a→b→c : Tightening order (Right side): b→a→c
8. Rear seat back lock	d, e, f: Rear seat center hinge mounting bolt : Tightening order: d→e→f
9. Rear seat side back	g, h: Child anchorage bracket mounting bolt : Tightening order: g→h
10. Rear seat center hinge	i, j: Seat back mounting bolt : Tightening order: i→j

Rear Seat Removal and Installation

S7RW0C9706004

Hatchback model

Removal

- 1) Fold rear seat back forward.
- 2) Remove seat mounting bolts and nuts to remove seat assembly.
- 3) Disassemble and repair seat as necessary.

Installation

Reverse removal procedure to install rear seat.

- Torque to specifications in “Rear Seat Components”.

Sedan model

Removal

- 1) Remove seat cushion.
- 2) Remove rear side sill scuffs referring to Step 3) of “Floor Carpet Removal and Installation in Section 9H”.
- 3) Remove rear seat side back.
- 4) Remove seat back.
- 5) Disassemble and repair seat as necessary.

Installation

Reverse removal procedure to install rear seat.

- Torque to specifications in “Rear Seat Components”.
- When installing seat cushion, align seat cushion hook with seat back bracket.

Specifications

Tightening Torque Specifications

S7RW0C9707001

NOTE

The specified tightening torque is also described in the following.

“Front Seat Components”

“Rear Seat Components”

Reference:

For the tightening torque of fastener not specified in this section, refer to “Fasteners Information in Section 0A”.

Special Tools and Equipment

Recommended Service Material

S7RW0C9708001

NOTE

Required service material is also described in the following.

“Front Seat Components”

“Rear Seat Components”

Interior Trim


Repair Instructions

Floor Carpet Removal and Installation




S7RW0C9806001

Removal

- 1) Remove front seat and rear seat referring to “Front Seat Removal and Installation in Section 9G” and “Rear Seat Removal and Installation in Section 9G”.
- 2) Remove seat belt lower anchor bolts (front and rear).
- 3) Remove side sill scuffs (1) (front and rear), front pillar lower trims (2), center pillar inner lower trims (3), back panel trim (4), rear quarter lower trims (5).




[A]



I6RW0B980001-02

[B]



I6RW0B980002-02

[A]: Hatchback	6. Forward
[B]: Sedan	

- 4) Remove console box referring to “Console Box Components”.
- 5) Remove floor carpet.

Installation

Reverse removal sequence to install front floor carpet, noting the following instruction.

- For tightening torque of rear seat mounting bolt, refer to “Rear Seat Components in Section 9G”.
- For tightening torque of front seat mounting bolt, refer to “Front Seat Components in Section 9G”.
- For tightening torque of seat belt lower anchor bolt, refer to “Front Seat Belt Components in Section 8A” and “Rear Seat Belt Components in Section 8A”.

Head Lining Removal and Installation


S7RW0C9806002

▲ WARNING

Refer to "Air Bag Warning in Section 00"
before starting service work.


Removal

- 1) Remove sun visor (1).




I5RW0A980001-01

- 2) Remove dome lights of front (1) and center (2).



I5RW0A980002-01

- 3) For hatchback, remove front pillar upper trims (1) rear side sill scuffs (2), center pillar inner lower trims (3), center pillar inner upper trims (4), back panel trim (5), rear quarter lower trims (6) and rear quarter upper trims (7).






I5RW0A980004-03

[A]: With curtain air bag

[B]: Without curtain air bag

9H-3 Interior Trim:

- 4) For sedan, remove front pillar upper trims (1), center pillar inner lower trims (3), rear side sill scuffs (2), center pillar upper trims (4), side backs (6) and rear pillar inner trims (5).





I8RW01980001-01

[A]: With curtain air bag

[B]: Without curtain air bag

- 5) Remove assistant grip (1).

- 6) Remove head lining clips (2) at rear end and remove head lining (3).



I7RW01980001-01

4. Clip

5. Flat head driver



Installation

Reverse removal procedure noting the following.

- Fix sun visor clip (1) first and adjust head lining in position and fix three clips (2) at rear end.
- Tighten sun visor screw to specified torque.

Tightening torque

Sun visor screw (a): 4 N·m (0.4 kgf-m, 3.0 lb-ft)




I5RW0A980006-01

- Tighten rear seatbelt referring to "Rear Seat Components in Section 9C"

Console Box Components

S7RW0C9806003



I5RW0A980007-02

Specifications

Tightening Torque Specifications

S7RW0C9807001

Fastening part	Tightening torque			Note
	N·m	kgf·m	lb·ft	
Sun visor screw	4	0.4	3.0	☞

Reference:
For the tightening torque of fastener not specified in this section, refer to “Fasteners Information in Section 0A”.

Hood / Fenders / Doors

Repair Instructions

Hood Removal and Installation

S7RW0C9A06001

Removal

⚠ CAUTION

Place cloth to prevent body from any damage.

- 1) Remove hood silencer (4).
- 2) Disconnect window washer hose (1) from hood.
- 3) Remove 4 mounting bolts (3) to detach hood (2).


Installation

Reverse removal procedure noting the following.

- Apply sealant to contact face "A" of hood hinge. Specified sealant.

"A": Sealant 99000-31110 (SUZUKI Bond No.1215)

- Adjust hood lock position if necessary referring to "Hood Inspection and Adjustment".



I5RW0A9A0001-01

Hood Inspection and Adjustment

S7RW0C9A06002


Inspection

- Check that hood opens and closes smoothly and properly. Lubricate if necessary.
- Check that hood stops in the secondary latched position properly (preventing hood from opening freely) and that hood closes completely in the fully latched position.
- Adjust hood locks position, if necessary.

Adjustment

Adjust the following point:

- Hood position adjustment.
Fore-and-aft and right-and-left adjustment.
Adjust hood clearance by loosening hood mounting bolts. Refer to "Panel Clearance in Section 9K".
- Vertical adjustment
If only one side (right or left) of hood is not level with front fender, make it level by tightening or loosening hood cushion (1).




I5RW0A9A0002-01

- Hood lock position adjustment
 - a. Loosen hood lock bolts.
 - b. Adjust hood lock height position so the hood is locked without looseness.
 - c. Tighten hood latch bolts to specified torque.

Tightening torque

Hood latch bolt (a): 10 N·m (1.0 kgf-m, 7.5 lb-ft)




I5RW0A9A0003-01

- d. Make sure the hood is locked smoothly and securely.

Front Fender Components

S7RW0C9A06003



I5RW0A9A0004-01

1. Front fender lining	2. Front fender	3. Front fender cover
------------------------	-----------------	-----------------------

Front Fender Removal and Installation

S7RW0C9A06004

Removal

- 1) Remove side sill splash guard and front fender splash guard (if equipped) referring to "Splash Guard Removal and Installation (If Equipped) in Section 9M".
- 2) Remove front fender lining.
- 3) Remove front bumper referring to "Front Bumper and Rear Bumper Components in Section 9K".
- 4) Remove headlight assembly referring to "Headlight Housing Removal and Installation in Section 9B".
- 5) Disconnect connector from side turn signal light (if equipped).
- 6) Remove front fender cover.
- 7) Remove front fender.


Installation

Reverse removal procedure to install front fender noting the following instruction.

- If paint on fender bolt is peeled off, be sure to apply paint again.
- Adjust panel clearance referring to "Panel Clearance in Section 9K".

Front Door Assembly Components

S7RW0C9A06005



I6RW0B9A0002-01


1. Door panel	5. Door open stopper bolt	(c) : 21 N·m (2.1 kgf-m, 15.5 lb-ft)
(A) 1215 2. Door hinge : Apply lithium grease 99000-25011 to rotating part. : Apply sealant 99000-31110 to contact face.	6. Front door opening weather-strip	a, b: Front door hinge bolt (door side) Loosen and tightening order: a→b
3. Door open stopper	(a) : 27 N·m (2.7 kgf-m, 19.5 lb-ft)	
4. Front door hinge bolt (body side)	(b) : 23 N·m (2.3 kgf-m, 17.0 lb-ft)	

Front Door Assembly Removal and Installation

S7RW0C9A06006


Removal

- 1) Remove front fender referring to “Front Fender Removal and Installation”.
- 2) Disconnect door harness lead wires at each coupler.
- 3) Remove door open stopper (1).




I4RS0A9A0005-01

- 4) Support door panel (1) using a jack (2) with rags (3) and a piece of wood (4) placed between jack (2) and panel (1) as shown.



I2RH019A0003-01

- 5) Remove door assembly (1) by loosening hinge mounting bolts (2).



I4RS0A9A0006-01


Installation

Reverse removal procedure to install door assembly noting the following instructions.

- When replacing door, coat replacement door inside with wax for proper anti-corrosion treatment. Refer to "Sealant Application Areas in Section 9L".
- Apply sealant to contact face "A" of hinge (1) and apply grease to rotating part "B" of hinge (1). Specified sealant and grease.

"A": Sealant 99000-31110 (SUZUKI Bond No.1215)

"B": Grease 99000-25011 (SUZUKI Super Grease A)




I6RW0B9A0003-01

- Tighten front door hinge bolts and door open stopper bolt to specified torque referring to "Front Door Assembly Components".
- When door open stopper (1) is installed, be careful make sure punch mark (2) comes to the top.

Door open stopper installing direction

Left side door: L punch mark is upward

Right side door: R punch mark is upward




I6RW0B9A0004-01

- Adjust door latch striker position referring to "Front Door Lock Assembly Removal and Installation in Section 9F".
- After installation, open and close the door to check looseness.

Rear Door Assembly Components

S7RW0C9A06007



I6RW0B9A0005-01

1. Door panel	4. Rear door hinge nut	23 N·m (2.3 kgf-m, 17.0 lb-ft)
2. Door hinge : Apply lithium grease 99000-25011 to rotating part. : Apply sealant 99000-31110 to contact face.	5. Door open stopper bolt	21 N·m (2.1 kgf-m, 15.5 lb-ft)
3. Door open stopper	6. Rear door opening weather-strip	a, b: Rear door hinge bolt Loosen and tightening order: a→b

Rear Door Assembly Removal and Installation


S7RW0C9A06008

Refer to “Front Door Assembly Removal and Installation” as removal and installation procedures are basically the same. However, note the following.

- Tighten rear door hinge bolts and nuts to specified torque referring to “Rear Door Assembly Components”.

Rear End Door Assembly Components (Hatchback Model)

S7RW0C9A06009



I7RW0C9A0001-02

[A]: Rear end door spoiler installation position	4. Rear end door balancer	8. Cap
1. Rear end door panel assembly	5. Rear end door trim	9. Clip
2. Rear end door window glass	6. Rear end door opening wether-strip	10. Rear end door balancer bolt
1215 3. Rear end door hinge : Apply lithium grease 99000-25011 to door hinge moving section. : Apply sealant 99000-31110 to contact face.	7. Rear end door spoiler	(a) : 23 N·m (2.3 kgf-m, 17.0 lb-ft)

Rear End Door Assembly Removal and Installation (Hatchback Model)

S7RW0C9A06010


▲ WARNING

Be careful enough when you open and shut with door balancer has not adhered to rear end door.

Otherwise, Rear end door doses in weight and is injured.

Removal

- 1) Remove rear end door trim (1).
- 2) Remove related section of head lining and rear trim.
- 3) Disconnect rear end door harness couplers (2) and washer hose (3).
- 4) Remove rear end door balancers (4).
- 5) Remove door hinge nuts (5) and remove rear end door assembly (6).




▲ WARNING

Handling of rear end door balancer (damper)

- Handle balancer carefully. Do not scar or scratch exposed surface of its piston rod, and never allow any paint or oil to stick to its surface.
- Do not turn piston rod with balancer fully extended.
- Do not disassemble balancer (1) because its cylinder is filled with gas.

Discarding of rear end door balancer (damper)

- The gas itself in balancer is harmless but it may issue out of the hole together with chips generated by the drill (2). Therefore, be sure to wear goggle when drilling.
- Using a 2 to 3 mm (0.08 to 0.12 in.) drill (2), make a hole to remove gas inside as shown before discarding.



I2RH019A0010-01


Installation

Reverse removal procedure noting the following.

- Tighten rear end door balancer bolt to specified torque.


Tightening torque

Rear end door balancer bolt (a): 23 N·m (2.3 kgf-m, 17.0 lb-ft)



I5RW0A9A0009-02

- Secure wiring harness (1).




I5RW0A9A0010-01

- Adjust door latch striker position by referring to "Rear End Door Lock Assembly Removal and Installation (Hatchback Model) in Section 9F".
- Adjust door cushion so that door contacts body when closed.
- Apply sealant to contact face "A" of door hinge (1) and apply grease to rotating part "B" of hinge (1). Specified sealant and grease.

"A": Sealant 99000-31110 (SUZUKI Bond No.1215)

"B": Grease 99000-25011 (SUZUKI Super Grease A)



I2RH019A1012-01

All Latches, Hinges and Locks Inspection

S7RW0C9A06011

Doors

Check that each door of front, rear and back doors opens and closes smoothly and locks securely when closed.

If any malfunction is found, lubricate hinge and latch or repair door lock system.


Engine Hood

Check that secondary latch operates properly (check that secondary latch keeps hood from opening all the way even when pulling hood release handle inside vehicle.) Also check that hood opens and closes smoothly and properly and hood locks securely when closed.

If any malfunction is found, lubricate hinge and latch, or repair hood lock system.

Trunk Lid Components (Sedan Model)

S7RW0C9A06012



I7RW0A9A0002-02

[A]: Trunk lid trim installation position	4. Hinge	8. Blue mark
1. Trunk lid panel	5. Torsion bar (left side) : Apply grease 99000-25050 to rotating part.	9. Trunk lid trim (if equipped)
2. Torsion bar holder	6. Torsion bar (right side) : Apply grease 99000-25050 to rotating part.	
3. Weather-strip	7. Yellow mark	

Trunk Lid Removal and Installation (Sedan Model)


S7RW0C9A06013

Removal

⚠ WARNING

When removing torsion bar, be careful for its repulsion.

- 1) Remove trunk lid trim (if equipped).
- 2) Remove trunk lid opener wire and trunk room harness from trunk lid panel (1).
- 3) Remove trunk lid attaching bolts (2) and trunk lid.




I2RH019A0014-01

NOTE


Handle removed trunk lid carefully. Dropping it can cause damage to itself and vehicle body.

- 4) Remove torsion bars (1).




I2RH019A0015-01

- 5) Fold rear seat back forward.
- 6) Remove center pillar inner lower trims (1) and side sill scuffs (2).




I6RW0B9A0008-02

- 7) Remove high mounted stop light (if equipped).




I8RW019A0003-01

- 8) Remove rear seat side backs (1).




I6RW0B9A0009-02

- 9) Remove rear pillar inner trims (3), partition front trims (1) and partition trim (2).



I8RW019A0002-02

- 10) Remove hinge attaching bolts (1) and take out trunk lid hinges.



I2RH019A0018-01

Installation


Reverse removal procedure noting the following.

- Install torsion bars as following:
 - a. Open trunk lid and hold it.
 - b. Distinguish left side torsion bar (marking color: yellow) from right side torsion bar (marking color: blue) by marking color (1).
 - c. Apply grease to rotating part "A" of torsion bar.

"A": Grease 99000-25050 (SUZUKI Super Grease E)
 - d. Install edge (2) of torsion bar to upward and fit end (3) to groove of right side hinge bracket.
 - e. Install edge (2) of torsion bar to upward and fit end (3) to groove of left side hinge bracket.



NOTE

Be sure to wipe off excess grease thoroughly as it may stain trunk interior and luggage in it.



I6RW0B9A0011-02

- Fore-and-aft and right-and-left adjustment. Adjust trunk lid clearance by loosening trunk lid mounting bolts (2).
- Adjust trunk lid latch striker (1) so that striker shaft approximately aligns with the center of groove of trunk lid latch.



I6RW0B9A0012-01

- Tighten rear seat bolts referring to "Rear Seat Components in Section 9G".

Specifications

Tightening Torque Specifications

S7RW0C9A07001

Fastening part	Tightening torque			Note
	N·m	kgf-m	lb-ft	
Hood latch bolt	10	1.0	7.5	🔩
Rear end door balancer bolt	23	2.3	17.0	🔩

NOTE

The specified tightening torque is also described in the following.

“Front Door Assembly Components”

“Rear Door Assembly Components”

“Rear End Door Assembly Components (Hatchback Model)”

Reference:

For the tightening torque of fastener not specified in this section, refer to “Fasteners Information in Section 0A”.

Special Tools and Equipment

Recommended Service Material

S7RW0C9A08001

Material	SUZUKI recommended product or Specification		Note
Grease	SUZUKI Super Grease A	P/No.: 99000-25011	🔩 / 🔩
	SUZUKI Super Grease E	P/No.: 99000-25050	🔩
Sealant	SUZUKI Bond No.1215	P/No.: 99000-31110	🔩 / 🔩 / 🔩

NOTE

Required service material is also described in the following.

“Front Door Assembly Components”

“Rear Door Assembly Components”

“Rear End Door Assembly Components (Hatchback Model)”


“Trunk Lid Components (Sedan Model)”

Body Structure


Repair Instructions

Front Bumper and Rear Bumper Components


S7RW0C9B06001



[A]



I8RW019B0001-01




I8RW019B0002-02

[A]: Hatchback model	3. Front bumper upper member	7. Rear bumper
[B]: Sedan model	4. Front bumper lower member	8. Reflector
1. Front bumper	5. Front bumper holder	9. Rear bumper absorber (if equipped)
2. Front bumper absorber (if equipped)	6. Rear bumper holder	10. Fender lining

Radiator Grille Removal and Installation

S7RW0C9B06002




I8RW019B0003-01


[A]: Hatchback model	1. Radiator upper grille	3. Retainer
[B]: Sedan model	2. Radiator lower grille	4. Front bumper

Front Bumper Extension Removal and Installation (if equipped)



S7RW0C9B06003



I8RW019B0004-01




I8RW019B0005-02



Cowl Top and Front Lower Crossmember Components

S7RW0C9B06005



I7RW0A9B0001-02


1. Cowl top garnish	3. Hood rear seal	5. Damper	: 55 N·m (5.5 kgf-m, 40.0 lb-ft)
2. Cowl top panel	4. Front lower crossmember	6. Damper bracket	: 25 N·m (2.5 kgf-m, 18.5 lb-ft)

Specifications

Body Dimensions

S7RW0C9B07004


Engine Room



I7RW0A9B0003-02

Point	position		
2	Jig hole	L	φ8
3	Cowl top side cover installation hole	R	10×15
4	↑	L	↑
5	Aiming hole	R	φ12
6	↑	L	↑
7	Headlight installation hole	R	Weld nut M6
8	↑	L	↑
10	Cover installation hole	L	φ12
12	Hood cushion installation hole	L	φ10.4
13	Front fender installation front hole	R	Weld nut M6
14	↑	L	↑
15	Front bumper lower member installation lower hole	R	φ10
16	↑	L	↑
18	Jig hole	L	φ7
19	Cowl garnish installation hole	R	φ8
20	↑	L	↑
21	Right side engine mounting installation upper front hole	R	φ12
24	Left side engine mounting installation upper front hole	L	φ11.5



Rear End Door (Hatchback Model)



I7RW0A9B0017-03

Point	position		
30	Wire harness hole	R	17×22
31	↑	L	↑
32	Rear end door balancer lower hole	R	Weld nut M8
33	↑	L	↑
34	Combination lamp installation upper hole	R	Weld nut M6
35	↑	L	↑
36	Rear bumper installation hole	R	↑
37	↑	L	↑
39	Rear end door striker installation left side hole	L	Retainer M8
40	Rear seat back striker installation rear hole	R	Weld nut M8
41	↑	L	↑




Trunk Room (Sedan Model)



I7RW0A9B0004-02

Point	position		
47	Joint of panel (roof panel & side body outer panel)	R	
48	↑	L	
49	Joint of panel (side body outer panel & partition panel)	R	
50	↑	L	
51	Torsion bar holder installation hole		□7.9
53	joint of panel (side body outer panel & partition panel)	R	
54	↑	L	
55	Trunk side trim installation hole	R	φ7
56	↑	L	↑
57	Rear bumper installation hole	R	Weld nut M6
58	↑	L	↑
59	Trunk lid striker installation rear hole	R	↑


Side Body (Hatchback Model)



I7RW0A9B0006-01

Point	position		
67	Instrumental panel upper mounting hole	L	φ12
69	Front door lower hinge installation upper hole	L	↑
71	Front pillar rear trim installation hole	L	Weld nut M6
73	Curtain-air bag module installation hole	L	↑
75	↑	L	↑
77	Front shoulder adjuster installation upper hole	L	Weld nut M10
79	Front door switch mounting screw hole	L	
81	Bleeding hole	L	φ15
83	Rear door upper hinge installation upper hole	L	φ14
85	Rear door lower hinge installation front hole	L	↑
87	Curtain-air bag module installation hole	L	Weld nut M6
89	Rear seat belt upper anchor installation hole	L	Weld nut 7/16–20UNF
91	Rear door switch mounting screw hole	L	
93	Side sill scuff installation rear hole	L	φ7
95	Parking brake wire bracket front hole		φ11




9K-10 Body Structure:



I7RW0A9B0007-02





Point	position		
95	Parking brake wire bracket front hole		φ11
101	Front end of windshield upper installation section	R	
102	↑	L	
103	Front end of windshield lower installation section	R	
104	↑	L	

Side Body (Sedan Model)



I7RW0A9B0008-02


Point	position		
112	Instrumental panel upper mounting hole	L	φ12
114	Front door lower hinge installation upper hole	L	↑
116	Front pillar rear trim installation hole	L	Weld nut M6
118	Curtain-air bag module installation hole	L	↑
120	↑	L	↑
122	Front shoulder adjuster installation upper hole	L	Weld nut M10
124	Front door switch mounting screw hole	L	
126	Bleeding hole	L	φ15
128	Rear door upper hinge installation upper hole	L	φ14
130	Rear door lower hinge installation front hole	L	↑
132	Curtain-air bag module installation hole	L	Weld nut M6
134	Rear pillar inner trim installation hole	L	φ8.5
136	Rear door switch mounting screw hole	L	
138	Side sill scuff installation rear hole	L	φ7
140	Parking brake wire bracket front hole	L	φ11



I7RW0A9B0009-02

Point	position		
140	Parking brake wire bracket front hole		φ11
146	Front end of windshield upper installation section	R	
147	↑	L	
148	Front end of windshield lower installation section	R	
149	↑	L	
150	Partition front trim installation hole	R	φ7
151	↑	L	↑
152	Partition trim installation hole		↑


Under Body (Hatchback Model)



I7RW0A9B0010-01

Point	position		
159	Jig hole	R	φ20
160	↑	L	↑
161	Front suspension frame installation hole	R	
162	↑	L	
163	↑	R	
164	↑	L	
165	Jig hole	R	φ10
166	↑	L	↑
167	↑	R	↑
168	↑	L	↑
169	↑	R	φ15
170	↑	L	↑
171	↑	R	φ25
172	↑	L	↑
173	Rear axle housing installation inside hole	R	
174	↑	L	
175	Drain hole	R	φ10
176	↑	L	↑
177	Jig hole	R	φ12
178	↑	L	↑


9K-14 Body Structure:




I7RW0A9B0011-01

Point	position		
160	Jig hole	L	φ20
162	Front suspension frame installation hole	L	
164	↑	L	
166	Jig hole	L	φ10
168	↑	L	↑
170	↑	L	φ15
172	↑	L	φ25
174	Rear axle housing installation inside hole	L	
176	Drain hole	L	φ10
178	Jig hole	L	φ12

Under Body (Sedan Model)




9K-16 Body Structure:



I7RW0A9B0013-01


Point	position		
185	Jig hole	L	φ20
187	Front suspension frame installation hole	L	
189	↑	L	
191	Jig hole	L	φ10
193	↑	L	↑
195	↑	L	φ15
197	↑	L	φ25
199	Rear axle housing installation inside hole	L	
201	Drain hole	L	φ10
203	Jig hole	L	φ12
205	↑	L	↑

Front Suspension Frame



I7RW0A9B0014-01


Point	position		
211	root of stud	R	
212	↑	L	
213	front suspension frame installation hole	R	
214	↑	L	
215	front suspension control arm installation hole	R	
216	↑	L	
217	front suspension frame installation hole	R	
218	↑	L	
219	front suspension control arm installation hole	R	
220	↑	L	



I7RW0A9B0015-01

Point	position		
212	root of stud	L	
214	front suspension frame installation hole	L	
216	front suspension control arm installation hole	L	
218	front suspension frame installation hole	L	
220	front suspension control arm installation hole	L	

Engine Front Mounting Member




I7RW0A9B0016-02

Point	position		
226	Engine front mounting member installation hole	R	
227	↑	L	
228	Jig hole	R	φ15
229	↑	L	↑
230	Engine front mounting member installation hole	R	
231	↑	L	


Panel Clearance

S7RW0C9B07005

[A]



[B]



I6RW0B9B0009-01

Panel to panel distance

[A]: Hatchback model	o: 0 – 1.0 mm (0 – 0.039 in.)
[B]: Sedan model	p: 5.2 – 7.2 mm (0.205 – 0.283 in.) (Hatchback model) 6.2 – 8.2 mm (0.244 – 0.323 in.) (Sedan model)
a: 0 – 1.5 mm (0 – 0.059 in.)	q: 2.0 mm (0.079 in.)
b: 2.7 – 4.7 mm (0.106 – 0.185 in.)	r: 7.5 – 9.0 mm (0.295 – 0.354 in.)
c: 3.6 – 5.6 mm (0.142 – 0.220 in.)	s: 5.0 – 7.0 mm (0.197 – 0.276 in.)
d: 1.0 – 3.0 mm (0.039 – 0.118 in.) (Vehicle with splash guard) : 2.0 – 3.0 mm (0.079 – 0.118 in.) (Vehicle without splash guard)	t: 4.0 – 6.0 mm (0.157 – 0.236 in.) u: 1.0 – 3.0 mm (0.039 – 0.118 in.) (Vehicle with splash guard)
e: 4.8 – 6.8 mm (0.189 – 0.268 in.)	v: 1.0 – 3.0 mm (0.039 – 0.118 in.) (Vehicle with splash guard)
f: 4.0 – 6.0 mm (0.157 – 0.236 in.)	w: 1.0 – 3.0 mm (0.039 – 0.118 in.) (Vehicle with splash guard)
g: 3.6 – 5.6 mm (0.142 – 0.220 in.)	x: 1.0 – 3.0 mm (0.039 – 0.118 in.) (Vehicle with splash guard)
h: 3.6 – 5.6 mm (0.142 – 0.220 in.)	y: 4.1 – 6.1 mm (0.161 – 0.240 in.)
i: 4.8 – 6.8 mm (0.189 – 0.268 in.)	z: 2.8 – 4.8 mm (0.110 – 0.189 in.)
j: 4.0 – 6.0 mm (0.157 – 0.236 in.)	aa: 2.5 – 4.5 mm (0.098 – 0.177 in.)
k: 3.5 – 5.5 mm (0.138 – 0.217 in.)	bb: 1.0 – 3.0 mm (0.039 – 0.118 in.)
l: 3.5 – 5.5 mm (0.138 – 0.217 in.)	cc: 7.7 – 9.2 mm (0.303 – 0.362 in.)
m: 4.0 – 6.0 mm (0.157 – 0.236 in.)	dd: 6.3 – 8.3 mm (0.248 – 0.327 in.)
n: 4.1 – 6.1 mm (0.161 – 0.240 in.)	ee: 3.5 – 5.5 mm (0.138 – 0.217 in.)

Tightening Torque Specifications

S7RW0C9B07006

NOTE

The specified tightening torque is also described in the following.
 “Cowl Top and Front Lower Crossmember Components”

Reference:

For the tightening torque of fastener not specified in this section, refer to “Fasteners Information in Section 0A”.

Paint / Coatings

General Description

Anti-Corrosion Treatment Construction

S7RW0C9C01001

▲ WARNING

Standard shop practices, particularly eye protection, should be followed during the performance of the following operations to avoid personal injury.

As rust proof treatment, steel sheets are given corrosion resistance on the interior and/or exterior.

These corrosion resistance steel sheet materials are called one of two-side galvanized steel sheets.

It is for the sake of rust protection that these materials are selected and given a variety of treatments as described blow.

- Steel sheets are treated with cathodic electro primer which is excellent in corrosion resistance.
- Rust proof wax coatings are applied to door and side sill insides where moisture is liable to stay.
- Vinyl coating is applied to body underside and wheel housing inside.
- Sealer is applied to door hem, engine compartment steel sheet-to-steel sheet joint, and the like portions to prevent water penetration and resulting in rust occurrence.

In panel replacement or collision damage repair, leaving the relevant area untreated as it is in any operation which does disturb the rust proof treatment will cause corrosion to that area. Therefore, it is the essential function of any repair operation to correctly recoat the related surfaces of the relevant area.

All the metal panels are coated with metal conditioners and primer coating during vehicle production. Following the repair and/or replacement parts installation, every accessible bare metal surface should be cleaned and coated with rust proof primer. Perform this operation prior to the application of sealer and rust proof wax coating.

Sealer is applied to the specific joints of a vehicle during production. The sealer is intended to prevent dust from entering the vehicle and serves also as an anticorrosion barrier. The sealer is applied to the door and hood hem areas and between panels. Correct and reseal the originally sealed joints if damaged. Reseal the attaching joints of a new replacement panel and reseal the hem area of a replacement door or hood.

Use a quality sealer to seal the flanged joints, overlap joints and seams. The sealer must have flexible characteristics and paint ability after it's applied to repair areas.

For the sealer to fill open joints, use caulking material. Select a sealer in conformance with the place and purpose of a specific use. Observe the manufacturer's label-stand instructions when using the sealer.

In many cases, repaired places require color painting. When this is required, follow the ordinary techniques specified for the finish preparation, color painting and undercoating build-up.

Rust proof wax, a penetrative compound, is applied to the metal-to-metal surfaces (door and side sill insides) where it is difficult to use ordinary undercoating material for coating. Therefore, when selecting the rust proof wax, it may be the penetrative type.

During the undercoating (vinyl coating) application, care should be taken that sealer is not applied to the engine-related parts and shock absorber mounting or rotating parts. Following the under coating, make sure that body drain holes are kept open.

The sequence of the application steps of the anti-corrosion materials are as follows:

- 1) Clean and prepare the metal surface.
- 2) Apply primer.
- 3) Apply sealer (all joints sealed originally).
- 4) Apply color in areas where color is required such as hem flanges, exposed joints and under body components.
- 5) Apply anticorrosion compound (penetrative wax).
- 6) Apply undercoating (rust proof material).

Plastic Parts Finishing

S7RW0C9C01002

Painting

Rigid or hard ABS plastic needs no primer coating.

General acrylic lacquers can be painted properly over hard ABS plastic in terms of adherence.

- 1) Use cleaning solvent for paint finish to wash each part.
- 2) Apply conventional acrylic color lacquer to part surface.
- 3) Follow lacquer directions for required drying time. (Proper drying temperature range is 60 – 70 °C (140 – 158 °F)).

Reference

Plastic parts employ not only ABS (Acrylonitrile Butadiene Styrene) plastic but also polypropylene, vinyl, or the like plastic. Burning test method to identify ABS plastic is described below.


- 1) Use a sharp blade to cut off a plastic sliver from the part at its hidden backside.
- 2) Hold sliver with pincers and set it on fire.
- 3) Carefully observe condition of the burning plastic.
- 4) ABS plastic must raise readily distinguishable back smoke while burning with its residue suspended in air temporarily.

- 5) Polypropylene must raise no readily distinguishable smoke while burning.


Component Location

Sealant Application Areas

S7RW0C9C03001





I8RW019C0001-01



I7RW0C9C0002-01


[A]: Hatchback model	"A": Apply sealant.	"E": Never fill up drain holes with sealant.
[B]: Sedan model	"B": Wipe off excess sealant after application.	"F": Fill gap / hole with sealant.
[C]: RHD	"C": Smooth out sealant with a brush.	"G": R end
[D]: LHD	"D": Do not apply sealant.	






I8RW019C0004-01

[A]: Hatchback model	"B": Fill gap / hole with sealant.	"E": Wipe off excess sealant after application.
[B]: Sedan model	"C": Smooth out sealant with a brush.	"F": Smooth out sealant with a brush. Do not fill hole with sealant.
"A": Apply sealant.	"D": Do not apply sealant.	"G": Apply sealant covering flange end.




I6RW0B9C0005-01




[A]: Hatchback model	"A": Apply sealant.	"C": Never fill up drain holes ("a" to "f") with sealant.
[B]: Sedan model	"B": Wipe off excess sealant after application.	"D": Apply sealant covering flange end.






[A]



[B]




M1



I8RW019C0006-01










[A]: Hatchback model	"B": Wipe off excess sealant application.	"E": Apply sealant covering flange end.
[B]: Sedan model	"C": Smooth out sealant with a brush.	"F": Apply sealant covering flange end. Do not fill hole with sealant.
"A": Apply sealant.	"D": Fill gap / hole with sealant.	1. Hole



"A": Apply sealant covering flange end.

Under Coating Application Areas

S7RW0C9C03002




I8RW019C0008-01

[A]: LH side	"C": Do not apply undercoating.
[B]: RH side	"D": Apply under coating (PVC, 400 μ m or more) after painting black color.
[C]: Both side	"E": Apply under coating (PVC, 600 μ m or more).
"A": Apply undercoating (PVC, 400 μ m or more).	"F": Do not apply under coating and anti-clip coat.

9L-11 Paint / Coatings:

"B": Apply anti-chip coat (300 μm or more) (Except vehicle with splash guard).




18RW019C0009-01

[A]: Hatchback model	"A": Apply undercoating (PVC, 400 μm or more).	"D": Do not apply undercoating (Apply all stud-bolts).
[B]: Sedan model	"B": Apply undercoating (PVC, 600 μm or more).	"E": Do not apply undercoating.
[C]: 4WD model	"C": Do not apply undercoating and anti-chip coat.	


Anti-Corrosion Compound Application Area

S7RW0C9C03003

[A]




[B]



I6RW0B9C0011-01

[A]: Hatchback model	"B": Apply rust proof wax (high viscosity wax 50 μ m or more) (with side turn signal light).
[B]: Sedan model	"C": Never fill up drain holes with rust proof wax.
"A": Apply rust proof wax (hot wax 50 μ m or more).	




[A]: Hatchback model	"A": Apply rust proof wax (hot wax 50 µm or more).
[B]: Sedan model	"B": Never fill up drain holes with rust proof wax.

Exterior Trim

Repair Instructions

Roof Molding Removal and Installation

S7RW0C9D06001




I5RW0C9D0002-04

[A]: Roof molding installation Position roof molding with touching A to B.	3. Roof rail nut (if equipped)
[B]: Roof molding clip installation position	4. Roof molding
A: Positioning rib	5. Roof molding clip (Push-in type) : Install roof molding clip to specified position on body with epoxy adhesive applied.
B: Positioning for roof molding (Edge of panel flange)	6. Groove
1. Roof rail (if equipped)	(a) : 10 N·m (1.0 kgf-m, 7.5 lb-ft)
2. Roof rail cap (if equipped)	

Splash Guard Removal and Installation (If Equipped)

S7RW0C9D06002



Specifications

Tightening Torque Specifications

S7RW0C9D07001

NOTE

The specified tightening torque is also described in the following.
“Roof Molding Removal and Installation”

Reference:

For the tightening torque of fastener not specified in this section, refer to “Fasteners Information in Section 0A”.

Section 10

Control Systems

CONTENTS

Precautions	10-1		
Precautions.....	10-1		
Precautions for Control Systems.....	10-1		
Cruise Control System.....	10A-1		
General Description	10A-1		
Cruise Control System Construction	10A-1		
Components and Functions of Cruise Control System	10A-2		
Cancel Conditions of Cruise Control System	10A-3		
Schematic and Routing Diagram.....	10A-3		
Cruise Control System Input / Output Diagram ..	10A-3		
Cruise Control System Wiring Diagram	10A-4		
Diagnostic Information and Procedures.....	10A-5		
Cruise Control System Symptom Diagnosis	10A-5		
Inspection of Cruise Control System Circuit.....	10A-6		
Repair Instructions	10A-7		
Cruise Control Switch Removal and Installation	10A-7		
Cruise Control Switch Inspection	10A-7		
CPP Switch (for Cruise Control) Removal and Installation	10A-7		
Clutch Pedal Position (CPP) Switch (for Cruise Control) Inspection and Adjustment	10A-8		
Brake Light Switch Removal and Installation	10A-8		
Brake Light Switch Inspection	10A-8		
ECM Removal and Installation.....	10A-8		
Specifications	10A-8		
Tightening Torque Specifications.....	10A-8		
Body Electrical Control System	10B-1		
Precautions.....	10B-1		
Precautions in Diagnosing Trouble	10B-1		
General Description	10B-1		
BCM General Description	10B-1		
CAN Communication System Description.....	10B-1		
Theft Deterrent Light Description	10B-2		
Schematic and Routing Diagram.....	10B-2		
Body Electrical Control System Wiring Circuit Diagram	10B-2		
Connector Layout Diagram of BCM and Junction Block.....	10B-5		
Component Location	10B-6		
		BCM and Related System Component	
		Location.....	10B-6
		Diagnostic Information and Procedures	10B-7
		BCM Self-Diagnosis Function	10B-7
		Body Electrical Control System Check.....	10B-8
		Scan Tool Data	10B-10
		DTC Table	10B-12
		DTC Check.....	10B-12
		DTC Clearance	10B-13
		BCM Power Circuit and Ground Circuit Check	10B-14
		DTC B1133 (No. 1133): Battery Voltage Too High.....	10B-15
		DTC B1141 / B1142 (No. 1141 / No. 1142): Outside Air Temperature (Ambient Temp.) Sensor Circuit Malfunction	10B-16
		DTC B1150 (No. 1150): Air Bag Communication Circuit Malfunction.....	10B-17
		DTC B1157 (No. 1157): Air Bag Deployment Signal Input	10B-18
		DTC B1170 (No. 1170): EEPROM Access Error	10B-18
		DTC U0073 (No. 0073): Control Module Communication Bus Off	10B-18
		DTC U0100 (No. 0100): Lost Communication with ECM.....	10B-18
		DTC U0101 (No. 0101): Lost Communication with TCM	10B-18
		DTC U0155 (No. 0155): Lost Communication with Instrument Panel Cluster (IPC) Control Module	10B-18
		DTC U1144 (No. 1144): Lost Communication with Keyless Start Control Module	10B-18
		Inspection of BCM and Its Circuits	10B-19
		Repair Instructions	10B-26
		BCM (Included in Junction Block) Removal and Installation	10B-26
		Outside Air Temperature Sensor Removal and Installation	10B-27
		Outside Air Temperature Sensor Inspection ...	10B-27
		Special Tools and Equipment	10B-27
		Special Tool	10B-27
		Immobilizer Control System	10C-1
		Precautions.....	10C-1
		Precautions in Diagnosing Troubles	10C-1

Precaution in Replacing ECM	10C-1	Operation Area of Remote Controller.....	10E-7
Precaution in Replacing Ignition Key	10C-1	Alarm Function	10E-8
Precautions in Handling Immobilizer Control System	10C-1	CAN Communication System Description.....	10E-8
General Description	10C-2	Schematic and Routing Diagram	10E-9
Immobilizer Control System Introduction	10C-2	Keyless Start System Electric Wiring Circuit Diagram.....	10E-9
On-Board Diagnostic System Description (Self-diagnosis Function)	10C-2	Diagnostic Information and Procedures	10E-10
Schematic and Routing Diagram	10C-3	Self-Diagnosis Function	10E-10
Immobilizer Control System Wiring Circuit Diagram	10C-3	Keyless Start System Diagnosis Introduction ..	10E-10
Component Location	10C-4	Keyless Start System Check.....	10E-10
Immobilizer Control System Components Location	10C-4	Customer Questionnaire (Example).....	10E-11
Diagnostic Information and Procedures	10C-4	Key Indicator Light Check	10E-11
Immobilizer Control System Check	10C-4	DTC Check.....	10E-12
DTC Check.....	10C-5	DTC Table.....	10E-13
DTC Clearance	10C-5	DTC Clearance	10E-13
DTC Table.....	10C-6	Keyless Start System Symptom Diagnosis	10E-14
Scan Tool Data	10C-7	Keyless Start System Operation Inspection ...	10E-16
Immobilizer Indicator Light Does Not Come ON with Ignition Switch ON and Engine Stop ..	10C-8	Door Lock Operation Check (Keyless Start System).....	10E-16
Immobilizer Indicator Light Remains ON after Engine Start	10C-9	Inspection of Keyless Start Control Module and Its Circuits	10E-17
DTC P1614: Transponder Response Error.....	10C-9	No DTC Detection After Performing DTC Check	10E-22
DTC P1615: Steering Lock Unit Communication Error	10C-10	Key Indicator Light Circuit Check (Key Indicator Light Doesn't Light when Ignition Knob Switch is Pushed)	10E-23
DTC P1616: Unregistered Keyless Start Control Module.....	10C-11	Keyless Start Control Module Power and Ground Circuit Check.....	10E-25
DTC P1618: Keyless Start Control Module CAN Communication Error.....	10C-11	DTC No. 11: Communication Error with Steering Lock Unit.....	10E-26
DTC P1621: Immobilizer Communication Line Error	10C-12	DTC No. 13 / No. 14: Release Signal Error from Steering Lock Unit / Steering Lock Unit Malfunction	10E-27
DTC P1622: EEPROM Reading / Writing Error	10C-13	DTC No. 21 / No. 22: Internal Error of Keyless Start Control Module (EEPROM Reading Error) / (EEPROM Writing Error).....	10E-27
DTC P1623: Unregistered Transponder	10C-13	DTC No. 31: Lost Communication with BCM ..	10E-28
DTC P1625: Immobilizer Antenna Error.....	10C-13	DTC No. 33: Control Module Communication Bus Off	10E-28
DTC P1636: Immobilizer Information Registration Failure	10C-14	DTC No. 51 / No. 52 / No. 53: Driver Side / Passenger Side / Rear End Door / Trunk Lid Request Switch Failure	10E-28
DTC P1638: Immobilizer Information Mismatched.....	10C-15	Repair Instructions	10E-29
Inspection of ICM and Its Circuit	10C-16	Antennas and Request Switches Removal and Installation	10E-29
Repair Instructions	10C-18	Front Door (Driver and Passenger Side), Rear End Door / Trunk Lid Request Switch Inspection	10E-30
ICM Removal and Installation	10C-18	Steering Lock Unit Removal and Installation ..	10E-30
Registration of the Ignition Key	10C-18	Steering Lock Unit Inspection	10E-30
Procedure after ECM Replacement	10C-18	Front Door Lock Switch Inspection	10E-31
Special Tools and Equipment	10C-19	Keyless Start Control Module Removal and Installation	10E-31
Special Tool	10C-19	Remote Controller Inspection.....	10E-31
Keyless Start System	10E-1	Replacement of Remote Controller Battery	10E-31
Precautions	10E-1	Registration Procedure for Remote Controller ID Code	10E-32
Precautions in Diagnosing Troubles	10E-1	Keyless Start Registration	10E-33
General Description	10E-2		
Keyless Start System Description	10E-2		
Parts and Functions	10E-3		
Keyless Engine Start Function	10E-4		
Door Lock Function of Keyless Start System....	10E-5		
Trunk Lid Opener Function of Keyless Start System (Sedan)	10E-6		

Precautions

Precautions

Precautions for Control Systems

S7RW0CA000001

Air Bag Warning

Refer to “Air Bag Warning in Section 00”.

Precaution on CAN Troubleshooting

Refer to “Precaution on CAN Troubleshooting in Section 1A”.


Cruise Control System

General Description

Cruise Control System Construction

S7RW0CA101001

The cruise control system is a device which maintains a preset vehicle speed while driving at a high speed, e.g., on a highway. It allows the driver to drive his vehicle at a constant speed of 40 km/h (25 mile/h) or higher without depressing the accelerator pedal. The system also has such functions as to change the vehicle speed without operating the accelerator pedal (but using SET/COAST and RES/ACC switches), cancel cruise control (CANCEL switch) and resume the speed in memory automatically after cruise control is cancelled (RES/ACC switch). The system mainly consists of electric throttle body assembly, ECM, cruise control switch (MAIN (ON/OFF) switch, SET/COAST switch, RES/ACC switch and CANCEL switch), etc.



I7RW01A10001-01

1. Combination meter	6. MAIN (ON/OFF) switch	11. Clutch pedal position (CPP) switch (M/T model)
2. "CRUISE" indicator light	7. SET/COAST switch	12. ECM
3. "SET" indicator light	8. CANCEL switch	13. Transmission range switch (A/T model)
4. Cruise control switch	9. Wheel speed sensor (vehicle speed signal)	14. TCM (A/T model)
5. RES/ACC switch	10. Brake light switch with brake pedal position switch	15. Electric throttle body

Components and Functions of Cruise Control System

S7RW0CA101002

Component	Function
ECM and electric throttle body	ECM executes centralized control over all functions including setting a constant speed, resuming it, setting coast, cancelling cruise control limiting minimum speed. ECM controls electric throttle valve opening to keep actual vehicle speed at set (target) speed.
MAIN (ON/OFF) switch	This switch has a momentary contact type button to press cruise control system ON and OFF.
SET/COAST switch	When this switch is pressed (ON) and then released (OFF) while vehicle is running at a speed 40 km/h (25 mile/h) or higher, vehicle speed at that OFF moment is stored in memory and it is maintained (constant cruising). Pressing this switch (ON) continuously during constant cruising keeps slowing down vehicle speed as long as it is ON. When it is released (OFF), vehicle speed at that moment is stored in memory and vehicle starts constant cruising. Pushing this switch during constant cruising decreases vehicle speed according to number of times the switch is pushed.
RES/ACC switch	When this switch is pressed (ON) during constant cruising, vehicle speed keeps increasing as long as it is ON. When it is released (OFF), vehicle speed at that moment is stored in memory and vehicle starts constant cruising. If vehicle speed is higher than 40 km/h (25 mile/h) after cruise control is cancelled, pressing this switch ON momentarily will resume the speed at which vehicle was running before cancellation. Pushing this switch during constant cruising increases vehicle speed according to number of times the switch is pushed.
CANCEL switch	When this switch is pressed (ON), cruise control (throttle valve control) is cancelled.
Wheel speed sensor (vehicle speed signal)	ECM receives speed sensor signal from ABS control module through CAN communication and calculates vehicle speed using that signal.
Brake light switch	Brake light switch has 2 contact points. One contact point closes when brake pedal is depressed to light brake light and provides a voltage signal to the ECM. The other contact point (brake pedal position switch) opens when brake pedal is depressed, to shut off power to cruise control of ECM, thereby cancelling cruise control (throttle valve control). This switch is installed to cancel cruise control (constant cruising).
Clutch pedal position switch (M/T model)	When clutch pedal is depressed, clutch pedal position switch closes and provides a ground signal to ECM. ECM cancels cruise control (throttle valve control) when this signal is inputted.
Transmission range switch (A/T model)	When selector lever is placed in either "P", "R" or "N" position, transmission range switch closes and provides a ground signal to TCM. TCM transmits signal from transmission range switch to ECM through CAN communication. When ECM receives a signal indicating that selector lever position is "P", "R" or "N", it cancels cruise control (throttle valve control).
TCM (A/T model)	TCM receives the SET signal for the cruise control from ECM through CAN communication. When TCM receives the SET signal from ECM, the gear shift control is performed by using the gear shift map for the cruise control changed from the one for normal gear shift. For details, refer to "Automatic Gear Shift Table in Section 5A".
"CRUISE" indicator light	In the state with ignition switch ON and cruise control system OFF, pressing MAIN (ON/OFF) switch once and releasing it will activate the cruise control system and ECM will cause indicator light to light up.
"SET" indicator light	It lights up when cruise control (throttle valve control) is functioning.

10A-3 Cruise Control System:

Cancel Conditions of Cruise Control System

S7RW0CA101003

Constant cruising is cancelled under the following conditions.

- Ignition switch is turned OFF.
- MAIN (ON/OFF) switch is turned OFF.
- *Vehicle speed becomes lower than minimum operating speed (40 km/h (25 mile/h)).
- *Vehicle speed varies beyond cancel speed range (20% decrease from preset speed).
- *Brake pedal is depressed (Brake light switch is turned ON).

- *Clutch pedal is depressed (Clutch pedal position switch is turned ON) (M/T model).
- *Selector lever is shifted to "P", "R" or "N" range (A/T model).
- *CANCEL switch is turned ON.

NOTE

When constant cruising is cancelled under any condition with * (asterisk), vehicle speed before cancellation can be resumed by operating RES/ACC switch, provided that vehicle speed is higher than 40 km/h (25 mile/h).

Schematic and Routing Diagram

Cruise Control System Input / Output Diagram

S7RW0CA102001

Input

Cruise control switch

MAIN (ON/OFF) switch
RES/ACC switch
SET/COAST switch
CANCEL switch

CPP switch
(M/T model)

Brake light switch

Transmission range switch
("P", "R" or "N" range signal)
(A/T model)

Wheel speed sensor
(vehicle speed signal)

ABS control module

ECM

Output

Electric throttle body
(throttle valve control)


Combination meter
(Indicator light control)

TCM (Shift control)
(A/T model)


I6RW0CA10001-01

Cruise Control System Wiring Diagram

S7RW0CA102002



[A]



I6RW0CA10002-01

[A]: ECM connector (viewed from harness side)	7. "CRUISE" indicator light	14. MAIN (ON/OFF) switch
1. ECM	8. "SET" indicator light	15. RES/ACC switch
2. Electric throttle valve relay	9. BCM	16. SET/COAST switch
3. Electric throttle body	10. ABS control module	17. CANCEL switch
4. Ignition switch	11. TCM	18. Brake light switch
5. Main relay	12. Accelerator pedal position sensor	19. Brake light
6. Combination meter	13. Cruise control switch	20. CPP switch

Diagnostic Information and Procedures

Cruise Control System Symptom Diagnosis

S7RW0CA104001

NOTE

- ECM uses TCM, combination meter, ABS control module and CAN communication to transmit and receive data for cruise control. Therefore, check that no DTC is detected from ECM, TCM, ABS control module before performing this Cruise Control System Symptom Diagnosis. If DTC is detected, correct trouble indicated by that DTC first.
- Check each part in the order from the top of the following list.

Condition	Possible cause	Correction / Reference Item
CRUISE or SET indicator light does not turn ON or OFF	MAIN (ON/OFF) switch faulty	Check MAIN (ON/OFF) switch for function referring to "Cruise Control Switch Inspection".
	SET/COAST switch faulty	Check SET/COAST switch for function referring to "Cruise Control Switch Inspection".
	Brake light switch faulty	Check brake light switch for function referring to "Brake Light Switch Inspection".
	Wiring or grounding faulty	Repair.
	Combination meter faulty	Replace.
	ECM faulty	Replace after making sure that none of above parts is faulty.
Vehicle speed can not be set	MAIN (ON/OFF) switch faulty	Check MAIN (ON/OFF) switch for function referring to "Cruise Control Switch Inspection".
	SET/COAST switch faulty	Check SET/COAST switch for function referring to "Cruise Control Switch Inspection".
	Brake light switch faulty	Check brake light switch for function referring to "Brake Light Switch Inspection".
	CPP switch faulty (M/T model)	Check CPP switch for function referring to "Clutch Pedal Position (CPP) Switch (for Cruise Control) Inspection and Adjustment".
	Wiring or grounding faulty	Repair.
	ECM faulty	Replace after making sure that none of above parts is faulty.
Acceleration or deceleration is not available by using RES/ACC or SET/COAST switch	RES/ACC or SET/COAST switch faulty	Check RES/ACC or SET/COAST switch for function referring to "Cruise Control Switch Inspection".
	Wiring or grounding faulty	Repair.
	ECM faulty	Replace after making sure that none of above parts is faulty.
Cruise control cannot be cancelled	CANCEL switch faulty	Check CANCEL switch for function referring to "Cruise Control Switch Inspection".
	Brake light switch faulty	Check brake light switch for function referring to "Brake Light Switch Inspection".
	CPP switch faulty (M/T model)	Check CPP switch for function referring to "Clutch Pedal Position (CPP) Switch (for Cruise Control) Inspection and Adjustment".
	Wiring or grounding faulty	Repair.
	ECM faulty	Replace after making sure that none of above parts is faulty.
Cruise control at vehicle speed stored in memory cannot be resumed after cruise control was cancelled by means other than MAIN (ON/OFF) switch	RES/ACC switch faulty	Check RES/ACC switch for function referring to "Cruise Control Switch Inspection".
	Wiring or grounding faulty	Repair.
	ECM faulty	Replace after making sure that none of above parts is faulty.

Inspection of Cruise Control System Circuit


S7RW0CA104002

Cruise control system is controlled by ECM. Each switch and circuit can be checked by taking measurement of terminal voltage and terminal to terminal resistance of ECM. When measuring these values, be sure to read precautions for measurement described under "Inspection of ECM and Its Circuits in Section 1A".

Voltage Check

Check voltage between the following terminals with ECM connector connected.

Terminal arrangement of ECM connector viewed from harness side



I7RW01A10004-01

Terminals	Circuit	Normal Voltage	Condition
E01-6 – ground	Cruise control main switch circuit	0 V	Ignition switch is at ON position and cruise control MAIN (ON/OFF) switch is not pushed.
		10 – 14 V	Ignition switch is at ON position and cruise control MAIN (ON/OFF) switch is kept in push.
E01-7 – ground	CPP switch circuit	10 – 14 V	Ignition switch is at ON position and clutch pedal is not depressed.
		0 V	Ignition switch is at ON position and clutch pedal is depressed.
E01-8 – ground	Brake pedal position switch circuit	10 – 14 V	Ignition switch is at ON position and brake pedal is not depressed.
		0 V	Ignition switch is at ON position and brake pedal is depressed.
E01-20 – ground	Brake light switch circuit	0 V	Ignition switch is at ON position and brake pedal is not depressed.
		10 – 14 V	Ignition switch is at ON position and brake pedal is depressed.
E01-21 – ground	Ground circuit for cruise control command switch	Below 1.3 V	Ignition switch is at ON position.
E01-22 – ground	Cruise control command switch (SET/COAST, ACC/RES and CANCEL switch) circuit	0 – 1.2 V	Ignition switch is at ON position and cruise control CANCEL switch is kept in push.
		1.2 – 2.6 V	Ignition switch is at ON position and SET/COAST switch of cruise control is kept in push.
		2.6 – 4.4 V	Ignition switch is at ON position and ACC/RES switch of cruise control is kept in push.
		4.4 – 5.5 V	Ignition switch is at ON position and cruise control command switches are not pushed.

Repair Instructions

Cruise Control Switch Removal and Installation

S7RW0CA106001

For removal and installation, refer to "Remote Audio Control Switch Removal and Installation (If Equipped) in Section 9C".

Cruise Control Switch Inspection

S7RW0CA106002

NOTE

**Never disassemble cruise control switch.
Disassembly will spoil its original functions.**

- 1) Remove driver air bag (inflator) module referring to "Passenger Air Bag (Inflator) Module Removal and Installation in Section 8B".
- 2) Disconnect cruise control switch connector (1) from control coil.
- 3) Check cruise control switch as follows.

For MAIN (ON/OFF) Switch

Check for continuity between "1" and "8" terminals under each condition below.

If check result is not satisfactory, replace cruise control switch (2).

Cruise MAIN (ON/OFF) switch (3) specification: [B]

Switch button released: Infinity

Switch button pressed: Continuity

For SET/COAST, RES/ACC and CANCEL Switch

Check for resistance between "7" and "9" terminals under each condition below.

If check result is not satisfactory, replace cruise control switch (2).

SET/COAST, RES/ACC and CANCEL switches


resistance: [C]

All switches released (OFF): Infinity

CANCEL switch (4) pressed (ON): About 0 Ω

SET/COAST switch (5) pressed (ON): 213 – 227 Ω

RES/ACC switch (6) pressed (ON): 882 – 938 Ω



I7RW01A10005-01


[A]: Cruise control switch connector viewed from harness side

CPP Switch (for Cruise Control) Removal and Installation

S7RW0CA106003

Removal

- 1) Disconnect connector of CPP switch (for cruise control) (1) with ignition switch OFF.
- 2) Remove CPP switch (for cruise control) (1) from pedal bracket.



I7RW01A10006-01

2. Brake light switch

Installation

- 1) Install CPP switch (for cruise control) (2) to pedal bracket.
- 2) With clutch pedal (1) released, adjust switch position so that clearance between end of thread and clutch pedal bracket is within specification.


Clearance between end of thread and clutch pedal bracket

“a”: 1.5 – 2.0 mm (0.06 – 0.08 in.)

- 3) Tighten lock nut (3) to specified torque.

Tightening torque

CPP switch lock nut (a): 7.5 N·m (0.75 kgf-m, 5.5 lb-ft)



I7RW01A10007-01

- 4) Connect connector to CPP switch (for cruise control) securely.

Clutch Pedal Position (CPP) Switch (for Cruise Control) Inspection and Adjustment

S7RW0CA106004


Inspection

Check for resistance between terminals under each condition below. If check result is not satisfactory, replace.

CPP switch (for cruise control) resistance

When switch shaft is pushed [A]: No continuity

When switch shaft is free [B]: Continuity



I5JB0AA10009-01

Adjustment

For adjustment, refer to “Installation” under “CPP Switch (for Cruise Control) Removal and Installation”.

Brake Light Switch Removal and Installation

S7RW0CA106005

For removal and installation, refer to “Brake Light Switch Adjustment in Section 4A”.

Brake Light Switch Inspection

S7RW0CA106006

Check for continuity between terminals referring to “Brake Light Switch Inspection in Section 9B”.

ECM Removal and Installation

S7RW0CA106007

For removal and installation, refer to “Engine Control Module (ECM) Removal and Installation in Section 1C”.

Specifications**Tightening Torque Specifications**

S7RW0CA107001

Fastening part	Tightening torque			Note
	N·m	kgf-m	lb-ft	
CPP switch lock nut	7.5	0.75	5.5	⌚

Reference:

For the tightening torque of fastener not specified in this section, refer to “Fasteners Information in Section 0A”.

Body Electrical Control System

Precautions

Precautions in Diagnosing Trouble

S7RW0CA200001

- Diagnostic information stored in BCM memory can be cleared as well as checked by using SUZUKI scan tool. Before using scan tool, read its Operator's (Instruction) Manual carefully to have good understanding as to what functions are available and how to use it.
- Be sure to read "Precautions for Electrical Circuit Service in Section 00" before inspection and observe what is written there.

- Communication of ECM, TCM (A/T model), ABS control module, 4WD control module (if equipped), keyless start control module (if equipped), combination meter and BCM is established by CAN (Controller Area Network). For detail of CAN communication for BCM, refer to "CAN Communication System Description". Therefore, handle CAN communication line with care referring to "Precaution for CAN Communication System in Section 00".

General Description

BCM General Description

S7RW0CA201001

The Body electrical Control Module (BCM) is incorporated in junction block. Do not attempt removal of BCM from junction block as it may cause contact failure. The BCM incorporates relays and controllers which are used for the following systems and controls them.

- Power door lock
- Keyless entry
- Door lock function of keyless start system (if equipped)
- Rear wiper
- Combination meter
- Interior light

- Warning buzzer
- Rear end door window / back window defogger
- Rear end door opener (if equipped)
- Trunk lid opener function of keyless start system (if equipped)
- Theft deterrent light

Also, the BCM has a function to cause the interior light and open door warning light in the combination meter to turn off when any door is left open for longer than 15 minutes to reduce wasteful battery consumption. In addition, it is possible to check operation of actuator which is controlled by BCM by using the output test function of SUZUKI scan tool to operate actuator simulatively.

CAN Communication System Description

S7RW0CA201002

Refer to "CAN Communication System Description in Section 1A" for CAN communication system description. BCM communication control data with each control module as follows.

BCM Transmission Data

			ECM	Combination Meter	Keyless Start Control Module (if equipped)
BCM	Transmit	DATA	A/C switch ON signal	○	
			Electric load signal	○	
			Brake fluid level switch signal		○
			Parking brake switch signal		○
			Diagnostic trouble code (DTC)		○
			Illumination ON signal		○
			Seat belt buckle switch signal		○
			Charging system signal		○
			Engine oil pressure switch signal		○
			Door switch status		○
			Door lock status		○
			Trunk lid switch status		○

I7RW0CA20001-01

BCM Reception Data


				ECM	TCM (A/T model)	Combination Meter	Keyless Start Control Module (if equipped)
BCM	Receive	DATA	Engine speed signal	○			
			Engine coolant temperature signal	○			
			Vehicle speed signal	○			
			Brake pedal switch signal	○			
			A/C compressor clutch signal	○			
			A/C refrigerant pressure signal	○			
			Fuel consumption signal	○			
			Engine type signal	○			
			Transmission range sensor signal		○		
			Combination meter spec signal			○	
			Ignition knob switch signal				○
			Door lock/unlock request signal				○
			Trunk lid open request signal				○
			Buzzer request signal				○
			Answer back request signal				○

I7RW0CA20002-01

Theft Deterrent Light Description

S7RW0CA201003

The information display or clock (1) of this vehicle includes a theft deterrent light (2) for the theft preventive purpose. The BCM makes the theft deterrent light flash at certain intervals after the ignition switch is turned off until it is turned on again. Also, DTCs stored in BCM can be checked by reading the flashing patterns of the theft deterrent light when diagnosing troubles.



I5RW0AA20003-01

Schematic and Routing Diagram

Body Electrical Control System Wiring Circuit Diagram

S7RW0CA202001

NOTE

This wiring diagram shows circuits related to only BCM, not the entire circuits of BCM and junction block. Refer to “Power Supply Diagram in Section 9A” for wiring circuits other than the figure below.

10B-3 Body Electrical Control System:




[A]: Hatchback	20. Driver side seat belt switch	41. Door lock actuator relay (if equipped)
[B]: Sedan	21. Brake fluid level switch	42. Driver side door lock actuator (if equipped)
1. BCM (included in junction block)	22. Parking brake switch	43. Passenger side door lock actuator (if equipped)
2. Rear end door / trunk lid opener actuator (if equipped)	23. Door key cylinder switch (included in door lock actuator) (if equipped)	44. Rear door lock actuator (if equipped)
3. Rear end door / trunk lid opener relay (if equipped)	24. Manual door lock switch (if equipped)	45. Hazard warning switch
4. Rear washer motor	25. Rear end door opener switch (if equipped)	46. Turn signal and hazard warning relay
5. Rear wiper and washer switch	26. A/C switch (if equipped)	47. To turn signal light
6. Outside air temperature sensor (if equipped)	27. Rear end door window / back window defogger switch	48. Interior light
7. Key reminder switch	28. Rear wiper motor	49. Rear end door window defogger relay
8. Theft deterrent light	29. Rear wiper relay	50. Rear end door window defogger
9. Oil pressure switch	30. TCM (A/T model)	51. Rear end door window / back window defogger indicator light
10. SDM	31. ECM	52. Horn relay
11. P/S control module	32. ABS control module	53. Horn switch
12. Audio unit (if equipped)	33. Keyless start control module (if equipped)	54. Horn
13. Generator	34. CAN junction connector	55. Lighting switch
14. Information display (if equipped)	35. Combination meter	56. Ignition switch
15. HVAC control module (if equipped)	36. 4WD control module (if equipped)	57. Battery
16. Keyless entry receiver (if equipped)	37. DLC	58. Body ground
17. Driver side door switch	38. To ABS control module and P/S control module	59. Engine ground
18. Other than driver side door switch	39. To SDM	60. Back window defogger relay
19. Rear end door / trunk lid switch	40. To HVAC control module (if equipped)	61. Back window defogger

Connector Layout Diagram of BCM and Junction Block

S7RW0CA202002

BCM and Junction Block Connectors (Viewed from Harness Side)




I6RW0CA20004-01

[A]: Junction block (viewed from BCM side)	2. Junction block	5. Rear wiper relay
[B]: Junction block (viewed from relay side)	3. Blower motor relay	6. Rear end door window defogger relay
1. BCM	4. Horn relay	7. Turn signal and hazard warning relay

Component Location

BCM and Related System Component Location

S7RW0CA203001



I7RW0CA20004-02

[A]: Auto A/C	9. Rear end door opener switch (if equipped)	21. Key reminder switch (included in ignition switch)
[B]: Manual A/C	10. Rear end door opener actuator (incorporated in door switch)	22. Junction block
[C]: Hatchback	11. Keyless entry receiver or keyless start control module (if equipped)	23. BCM
[D]: Sedan	12. Parking brake switch	24. Horn relay
1. Generator	13. Seat belt buckle switch	25. Rear wiper relay
2. Brake fluid level switch	14. Theft deterrent light	26. Rear end door window defogger relay (Hatchback)
3. ECM	15. Rear end door window / back window defogger switch	27. Turn signal and hazard warning relay
4. Oil pressure switch	16. A/C switch (if equipped)	28. Trunk lid opener actuator (keyless start model)
5. Outside air temperature sensor (if equipped)	17. Hazard warning switch	29. Trunk lid switch (keyless start model)

10B-7 Body Electrical Control System:


6. Door lock actuator (incorporated in key cylinder switch)	18. Rear wiper switch	30. Back window defogger relay (Sedan)
7. Door switch	19. Lighting switch	
8. Interior light	20. Manual door lock switch (if equipped)	

Diagnostic Information and Procedures

BCM Self-Diagnosis Function

S7RW0CA204001

- BCM monitors conditions of the system components and its circuit with ignition switch turned to ON position. When an abnormality in the system occurs, the area where that abnormality lies is stored in the memory of EEPROM in BCM.
- DTC can be checked in either one of following ways.
 - DTC can be checked by SUZUKI scan tool (2) connected to DLC (1).
 - DTC can be read from flashing pattern of Theft deterrent light (3). Also, DTC is displayed on combination meter (4) at the same time.



I5RW0AA20007-01

BCM Input / Output Table

Control	Input	Output
Power door lock system	• Key cylinder switch • Manual door lock switch	• Each door lock actuator
Keyless entry system	• Key reminder switch • Keyless entry receiver • Driver side door switch	• Each door lock actuator • Turn signal and hazard warning relay • Interior light
Keyless start system (Door lock function)	• Keyless start control module	• Each door lock actuator • Turn signal and hazard warning relay • Interior light
Keyless start system (Trunk lid opener function)	• Keyless start control module	• Trunk lid opener actuator
Rear wiper	• Rear wiper INT switch • Rear wiper LO switch	• Rear wiper relay
Combination meter	• Tail light switch • Oil pressure switch • Parking brake switch • Driver side seat belt switch • Brake fluid level switch • Generator • Each door switch	• Combination meter

Control	Input	Output
Interior light	- Each door switch - Key reminder switch	Interior light
Warning buzzer	- Key reminder switch - Tail light switch - Driver side door switch - Keyless start control module (if equipped) - ECM (vehicle speed signal)	Warning buzzer (located in BCM)
Rear end door window / back window defogger	- Rear end door window / back window defogger switch - Generator	Rear end door window / back window defogger relay
Rear end door opener	- Manual door lock switch (unlock signal) - Key cylinder switch (unlock signal) - Keyless entry transmitter (unlock signal) - Rear end door opener switch	Rear end door opener relay
Door lock canceller	SDM (air bag deployment signal)	Each door lock actuator
Theft deterrent light	Key reminder switch	Theft deterrent light (located in information display or clock)

Body Electrical Control System Check

S7RW0CA204002

Step	Action	Yes	No
1	☞ Customer complaint analysis 1) Perform customer complaint analysis. <i>Was customer complaint analysis performed?</i>	Go to Step 2.	Perform customer complaint analysis.
2	☞ Problem symptom confirmation 1) Perform problem symptom confirmation. <i>Does trouble recur?</i>	Go to Step 3.	Go to Step 7.
3	☞ DTC check 1) Check DTC. <i>Is it malfunction code?</i>	Go to Step 4.	Go to Step 5.
4	☞ Troubleshooting for DTC 1) Check and repair according to DTC diag. flow. <i>Are check and repair completed?</i>	Go to Step 7.	Check and repair malfunction part(s).
5	☞ Body electrical control system symptom diagnosis 1) Perform check and repair referring to "Symptom Diagnosis" of system having a trouble. <i>Is there faulty condition?</i>	Repair or replace malfunction part(s).	Go to Step 6.
6	☞ Check for intermittent problem 1) Check for intermittent problem. <i>Is there faulty condition?</i>	Repair or replace malfunction part(s).	Go to Step 7.
7	☞ Final confirmation test 1) Clear DTC referring to "DTC Clearance". 2) Check DTC referring to "DTC Check". <i>Is there any DTC?</i>	Go to Step 4.	End.

Customer Complaint Analysis

Record details of the problem (failure, complaint) and how it occurred as described by the customer.

For this purpose, use of such a questionnaire form as shown in the figure will facilitate collecting information to the point required for proper analysis and diagnosis.

Customer questionnaire (example)

Customer's name:	Model:	VIN:	
Date of issue:	Date Reg:	Date of problem:	Mileage:

Problem Symptoms	• Power door lock system does not operate • Keyless entry system does not operate • Rear end door window defogger does not operate • Rear wiper does not operate • Rear end door opener does not operate • Warning buzzer does not sound • Interior light does not light • Theft deterrent light does not flush • Other _____
Frequency of Occurrence	• Continuous / Intermittent (times a day, a month) / Other _____
Environmental Condition	• Weather: Fine / Cloudy / Rain / Snow / Other _____ • Temperature: °C(° F)
Diagnostic Trouble Code	• Normal code / Malfunction code ()

I5RS0DA20006-01

Problem Symptom Confirmation

Check if what the customer claimed in "Customer Questionnaire" is accurately found in the vehicle. If that symptom is found, check whether the symptom is identified as a failure. (This step should be shared with the customer if possible.)

DTC Check

Check DTC stored in BCM memory referring to "DTC Check", record it and then clear it referring to "DTC Clearance". DTC indicates malfunction that occurred in the system but does not indicate whether it exists now or it occurred in the past and the normal condition has been restored now. To check which case applies, clear DTC once and check whether or not any fault exists.

Troubleshooting for DTC

Based on the DTC indicated in Step 3 and referring to applicable DTC flow, locate the cause of the trouble, namely in a sensor, wire harness, connector, BCM or other part and repair or replace faulty parts.

Body Electrical Control System Symptom Diagnosis

Check the parts or system suspected as a possible cause referring to symptom diagnosis of each system.

Check for Intermittent Problem

Check parts where an intermittent trouble is easy to occur (e.g., wire harness, connector, etc.), referring to "Intermittent and Poor Connection Inspection in Section 00".

Final Confirmation Test

Confirm that the problem symptom has gone and the body electrical control system is free from any abnormal conditions. If what has been repaired is related to the malfunction DTC, check DTC again and confirm that no DTC is indicated.

Scan Tool Data

S7RW0CA204003

Scan tool data	Condition	Normal condition / reference value
Vehicle Speed 	At stop with ignition switch turned ON	0 km/h
Outside air Temp 	Reference value is relative to outside air temperature	-40 °C – 70 °C (-40 °F – 158 °F)
Battery Voltage 	At specified idle speed after warming up	10 – 14 V
Coolant Temp 	At specified idle speed after warming up	80 °C – 100 °C (176 °F – 212 °F)
Engine Speed 	Engine idling with no load applied after warming up	Desired idle speed ± 50 rpm
Fuel Consumption 	At specified idle speed after warming up	0.0 km/l
Key Reminder Sw 	Ignition key inserted in ignition key cylinder	Key in
	Ignition key pulled out from ignition key cylinder	Pulled
Rear Wiper Sw 	Rear wiper switch at ON position and ignition switch turned ON	ON
	Rear wiper switch at INT position and ignition switch turned ON	INT
	Rear wiper switch at OFF position and ignition switch turned ON	OFF
Door key Sw 	Key cylinder switch of driver side door at lock position	LOCK
	Key cylinder switch of driver side door not turned	Neutral
	Key cylinder switch of driver side door at unlock position	Unlock
Door Lock Sw 	Lock side of manual door lock switch pressed	LOCK
	Manual door lock switch not pressed	Neutral
	Unlock side of manual door lock switch pressed	Unlock
Driv Door Sw 	Driver side door open	Open
	Driver side door closed	Close
Pass Door Sw 	Doors other than driver side door open	Open
	Doors other than driver side door closed	Close
Brake Fluid Level 	Brake fluid level at MIN level or higher	Normal
	Brake fluid level lower than MIN level	Low
Parking Brake Sw 	Parking brake lever pulled	ON
	Parking brake lever released	OFF
Rear Defogger Sw 	Rear end door window / back window defogger switch pressed with engine running	ON
	Rear end door window / back window defogger switch not pressed with engine running	OFF
Headlight Sw 	Lighting switch at HEAD position	ON
	Lighting switch at OFF position	OFF
Tail Light Sw 	Lighting switch at HEAD or CLEARANCE position	ON
	Lighting switch at OFF position	OFF
Front Fog Light Sw 	Lighting switch at HEAD position and front fog light switch at ON position	ON
	Lighting switch at HEAD position and front fog light switch at OFF position	OFF
Driv Seat belt Sw 	Driver side seat belt fastened	Fasten
	Driver side seat belt unfastened	Unfasten
Rear end door opener 	Rear end door opener switch pressed	ON
	Rear end door opener switch not pressed	OFF
Trunk Sw 	Trunk lid opened	ON
	Trunk lid closed	OFF
Charge light 	Engine at stop with ignition switch turned ON	ON
	Engine running	OFF
Oil pressure switch 	Engine at stop with ignition switch turned ON	ON
	Engine running	OFF
A/C Switch 	A/C and ignition switch turned ON	ON
	A/C switch turned OFF	OFF

Scan Tool Data Definitions

Vehicle Speed (km/h, mph): This parameter indicates the vehicle speed computed by ECM.

Outside air Temp (°C, °F): It is detected by outside air temperature sensor.

10B-11 Body Electrical Control System:

Battery Voltage (V): This parameter indicates battery positive voltage inputted to BCM.

Coolant Temp (Engine coolant temperature) (°C, °F): It is detected by engine coolant temperature sensor.

Engine Speed (RPM): It is computed by reference pulse signals from CMP sensor.

Fuel Consumption (km/l): This parameter indicates the fuel consumption computed by ECM.

Key Reminder Sw (Key reminder switch) (Pulled / Key in): This parameter indicates the state of the key reminder switch.

Rear Wiper Sw (Rear wiper switch) (ON / INT / OFF): This parameter indicates the state of the rear wiper switch.

Door key Sw (Door key cylinder switch) (Lock / Neutral / Unlock): This parameter indicates the state of the door key cylinder switch.

Door Lock Sw (Manual door lock switch) (Lock / Neutral / Unlock): This parameter indicates the state of the manual door lock switch.

Driv Door Sw (Driver side door switch) (Open / Close): This parameter indicates the state of the driver side door switch.

Pass Door Sw (Other than driver side door switch) (Open / Close): This parameter indicates the state of the door switches other than driver side door switch.

Brake Fluid Level (Low / Normal): Low: Brake fluid level is lower than specified level.

Normal: Brake fluid level is higher than MIN level.

Parking Brake Sw (Parking brake switch) (ON / OFF): ON: Parking brake lever is pulled up.

OFF: Parking lever is released.

Rear Defogger Sw (Rear end door window defogger switch) (ON / OFF): This parameter indicates the state of the rear end door window / back window defogger switch.

Headlight Sw (Headlight switch) (ON / OFF) (Junction block without BCM type): This parameter indicates the state of the lighting switch.

Tail Light Sw (Lighting switch) (ON / OFF): This parameter indicates the state of the lighting switch.

Front Fog Light Sw (Front fog light switch) (ON / OFF) (Junction block without BCM type): This parameter indicates the state of the front fog light switch.

Driv Seatbelt Sw (Driver seat belt switch) (Fasten / Unfasten): This parameter indicates the state of the driver side seat belt buckle switch.

Rear end door opener (Rear end door opener switch) (ON / OFF): This parameter indicates the state of the rear end door opener switch.

Trunk Sw (Trunk lid switch) (ON / OFF) (keyless start model): This parameter indicates the state of the trunk lid switch.

Charge light (ON / OFF): This parameter indicates the state of the charge system monitor switch.

Oil pressure switch (ON / OFF): This parameter indicates the state of the oil pressure switch.

A/C Switch (ON / OFF): This parameter indicates the state of the air conditioning switch.

Diagnosis Using Output Test Function of SUZUKI Scan Tool

SUZUKI scan tool has the output test function which can force operation of following actuators and relays of the system controlled by BCM. When a malfunction is found in the system controlled by BCM, execute the output test which enables easy judgment whether the malfunction is on the input side or output side of BCM. For detailed information on operation of SUZUKI scan tool, refer to "SUZUKI Scan Tool Operator's Manual".

Output Test Item	Controlled Parts
Hazard Warning Light	Turn signal and hazard warning relay
Interior (Dome) Light	Interior (Dome) light (when interior light switch is at DOOR position)
Tail Light*1	Tail light relay
Front Fog Light*1	Front fog light relay (when lighting switch is at HEAD position)
Rear defogger	Rear end door window / back window defogger relay
Dead lock	Each door lock actuator
Rear end door (trunk) open	Rear end door / trunk lid opener relay
Door	Each door lock actuator
Warning Buzzer	Warning buzzer (in BCM)
Rear wiper	Rear wiper relay
Alarm indicator	Theft deterrent light (in information display or clock)
Horn*1	Horn relay

NOTE

*1: Junction block without BCM type

DTC Table

S7RW0CA204004

DTC (displayed on SUZUKI scan tool)	DTC (indicated by theft deterrent light)	DTC (displayed on odometer in combination meter)	Detected item	Detecting condition
NO DTC	0000	0000	—	No DTC detected
☞ B1133	1133	b1133	Battery voltage too high	Battery voltage too high
☞ B1141	1141	b1141	Outside air temperature (ambient temperature) sensor circuit open	Sensor output voltage too high
☞ B1142	1142	b1142	Outside air temperature (ambient temperature) sensor circuit short to ground	Sensor output voltage too low
☞ B1150	1150	b1150	Air bag communication circuit malfunction	Air bag communication circuit open or short to ground
☞ B1157	1157	b1157	Air bag deployment signal input	Air bag deployment signal inputted
☞ B1170	1170	b1170	EEPROM access error	Memory error
☞ U0073	0073	U0073	Control module communication bus off	Transmitting and receiving error of BCM for specified time continuously
☞ U0100	0100	U0100	Lost communication with ECM	Receiving error of BCM from ECM for specified time continuously
☞ U0101	0101	U0101	Lost communication with TCM	Receiving error of BCM from TCM for specified time continuously
☞ U0155	0155	U0155	Lost communication with instrument panel cluster (IPC) control module	Receiving error of BCM from combination meter for specified time continuously
☞ U1144	1144	U1144	Lost communication with keyless start control module	Receiving error of BCM from keyless start control module for specified time continuously

DTC Check


S7RW0CA204005

Using SUZUKI Scan Tool

- 1) Prepare SUZUKI scan tool.
- 2) With ignition switch turned OFF, connect it to data link connector (DLC) located on underside of instrument panel of driver's side.

Special tool

(A): SUZUKI scan tool




I5RW0AA20008-02

- 3) Turn ignition switch ON.
- 4) Read DTC according to instructions displayed on SUZUKI scan tool and print it or write it down. Refer to SUZUKI scan tool operator's manual for further details.
If communication between SUZUKI scan tool and BCM is not possible, check if SUZUKI scan tool is communicable by connecting it to BCM in another vehicle. If communication is possible in this case, SUZUKI scan tool is in good condition. Then check data link connector and serial data line (circuit) in the vehicle with which communication was not possible.
- 5) After completing the check, turn ignition switch off and disconnect SUZUKI scan tool from data link connector.

Without Using SUZUKI Scan Tool

- 1) Turn ignition switch to OFF position.
- 2) Perform following Steps a) to d) within 10 seconds after ignition switch is turned ON and engine stops.
 - a) Turn headlight switch to "SMALL" position.
 - b) Turn headlight switch to "OFF" position.
 - c) Repeat Steps a) and b) 2 times.
 - d) Press and release driver side door switch 3 times.
- 3) Check DTC displayed on odometer of combination meter or read flashing pattern of theft deterrent light which represents DTC as shown in the following example and write it down.
When more than 2 DTCs are stored in memory, flashing for each DTC starts with the smallest DTC number in increasing order. Also, DTC is indicated repeatedly until the ignition switch is turned OFF.



I5RW0AA20009-01

[A]: No DTC (No. 0000)	A: Indicator lamp turned ON	T2: 1.0 seconds	2. Odometer
[B]: DTC B1133 (No. 1133)	B: Indicator lamp turned OFF	T3: 3.0 seconds	
[C]: When 2 DTCs are detected	T1: 0.3 seconds	1. Theft deterrent light	

- 4) After completing the check, turn ignition switch to OFF position.

DTC Clearance

S7RW0CA204006

After repair or replace of malfunction part(s), clear all DTCs by performing the following procedure.

Using SUZUKI Scan Tool

- 1) Connect SUZUKI scan tool to data link connector in the same manner as when making this connection for DTC check.
- 2) Turn ignition switch ON and engine stops.
- 3) Erase DTC according to instructions displayed on scan tool. Refer to scan tool operator's manual for further details.
- 4) After completing the clearance, turn ignition switch off and disconnect scan tool from data link connector.


Without Using SUZUKI Scan Tool

- 1) Turn ignition switch to OFF position.
- 2) Perform following Steps a) to d) within 10 seconds after ignition switch is turned ON and engine stops.
 - a) Turn headlight switch to "SMALL" position.
 - b) Turn headlight switch to "OFF" position.
 - c) Repeat Steps a) and b) 3 times.
 - d) Press and release driver side door switch 4 times.
- 3) After completing above Steps, confirm that no malfunction DTC is detected.

BCM Power Circuit and Ground Circuit Check

S7RW0CA204007

Wiring Diagram



I6RW0CA20006-02

[A]: Junction block connector viewed from harness side

2. Ignition switch

1. Junction block

3. Battery

Troubleshooting

Step	Action	Yes	No
1	Fuse check 1) Turn ignition switch to OFF position. 2) Check circuit fuses for condition. <i>Are circuit fuses in good condition?</i>	Go to Step 2.	Replace fuse and check for short circuit to ground.
2	Power supply circuit check 1) Disconnect connectors from junction block. 2) Check for proper connection to junction block connector at terminal "E324-2". 3) If OK, then measure voltage between "E324-2" terminal of junction block connector and vehicle body ground. <i>Is voltage 10 – 14 V?</i>	Go to Step 3.	Repair power supply circuit.
3	Power supply circuit check 1) Check for proper connection to junction block connector at terminals "G273-2" and "G273-5". 2) If OK, turn ignition switch to ON position. 3) Measure voltage between following terminals. - Between "G273-2" terminal of junction block connector and vehicle body ground - Between "G273-5" terminal of junction block connector and vehicle body ground <i>Is each voltage 10 – 14 V?</i>	Go to Step 4.	Repair power supply circuit.

10B-15 Body Electrical Control System:

Step	Action	Yes	No
4	Ground circuit check 1) Turn ignition switch to OFF position. 2) Check for proper connection to junction block connector at terminals "G271-3", "G272-9" and "L314-4". 3) If OK, then measure resistance between following terminals. - Between "G271-3" terminal of junction block connector and vehicle body ground - Between "G272-9" terminal of junction block connector and vehicle body ground - Between "L314-4" terminal of junction block connector and vehicle body ground <i>Is each resistance 2 Ω or less?</i>	BCM power supply circuit and ground circuit are in good condition.	Repair ground circuit.

DTC B1133 (No. 1133): Battery Voltage Too High

S7RW0CA204008

Wiring Diagram

Refer to "BCM Power Circuit and Ground Circuit Check".

DTC Detecting Condition and Possible Cause


DTC detecting condition	Possible cause
Power voltage supplied from battery to BCM is higher than 16V.	- Charging system malfunction - BCM malfunction

Flow Test Description**Step 1: Check charging system****DTC Troubleshooting**

Step	Action	Yes	No
1	Charging system operation check 1) Check generator for operation referring to "Generator Test (Overcharged Battery Check) in Section 1J". <i>Is it in good condition?</i>	Substitute a known good BCM (included in junction block) and recheck.	Repair charging system.

DTC B1141 / B1142 (No. 1141 / No. 1142): Outside Air Temperature (Ambient Temp.) Sensor Circuit Malfunction

S7RW0CA204009

Wiring Diagram

I6RW0CA20007-01

[A]: BCM connector viewed from harness side	2. BCM
1. Outside air temperature sensor	

DTC Detecting Condition and Possible Cause

DTC detecting condition	Possible cause
DTC B1141 (DTC No. 1141): Input signal from outside air temperature sensor is higher than 4.88 V.	• Open in outside air temperature sensor circuit • Outside air temperature sensor malfunction • BCM malfunction
DTC B1142 (DTC No. 1142): Input signal from outside air temperature sensor is lower than 0.1 V.	• Short in outside air temperature sensor circuit • Outside air temperature sensor malfunction • BCM malfunction


Flow Test Description**Step 1: Check whether malfunction is in outside air temperature sensor.****Step 2: Check outside air temperature sensor circuit.****DTC Troubleshooting**

Step	Action	Yes	No
1	Outside air temperature sensor check 1) Turn ignition switch to OFF position. 2) Disconnect connector from outside air temperature sensor. 3) Check outside air temperature sensor for resistance referring to "Outside Air Temperature Sensor Inspection (If Equipped) in Section 9C". <i>Is it in good condition?</i>	Go to Step 2.	Replace outside air temperature sensor.
2	Outside air temperature sensor circuit check 1) Disconnect connector from BCM and check for proper terminal connection to BCM connector. 2) If connections are OK, check outside air temperature sensor circuit for open, short and high resistance. <i>Is each circuit in good condition?</i>	Substitute a known-good BCM (included in junction block) and recheck.	Repair circuit.

DTC B1150 (No. 1150): Air Bag Communication Circuit Malfunction

S7RW0CA204010

Wiring Diagram



DTC Detecting Condition and Possible Cause

DTC detecting condition	Possible cause
After ignition switch is turned ON, abnormal signal is fed from SDM to BCM.	- Air bag communication circuit open or short - SDM malfunction - BCM malfunction

Flow Test Description

Step 1: Check air bag communication circuit.

Step 2: Check air bag communication circuit.

DTC Troubleshooting

Step	Action	Yes	No
1	Air bag communication circuit check - Turn ignition switch to OFF position. - Disconnect connectors from junction block and SDM. - Check for proper terminal connection to BCM and SDM connectors. - If connections are OK, check air bag communication circuit for open, short and high resistance. <i>Is circuit in good condition?</i>	Go to Step 2.	Repair circuit.
2	Air bag communication circuit check - Turn ignition switch to OFF position. - Connect connectors to junction block. - Turn ignition switch to ON position. - Measure voltage between “L313-2” terminal of junction block connector and vehicle body ground. <i>Is voltage 4 – 6 V?</i>	Substitute a known-good SDM and recheck.	Substitute a known-good BCM (included in junction block) and recheck.

DTC B1157 (No. 1157): Air Bag Deployment Signal Input

S7RW0CA204011

Wiring Diagram

Refer to "DTC B1150 (No. 1150): Air Bag Communication Circuit Malfunction".

DTC Detecting Condition and Possible Cause

DTC detecting condition	Possible cause
Air bag deployment signal is fed from SDM to BCM.	- Air bag component parts - BCM malfunction

Flow Test Description**Step 1: Check DTC for SDM.****DTC Troubleshooting**

Step	Action	Yes	No
1	DTC check of SDM 1) Check DTC stored in SDM referring to "DTC Check in Section 8B". <i>Is DTC B1021 detected?</i>	Go to "DTC B1021: Front Air Bag Deployment Record in Section 8B".	Substitute a known-good BCM (included in junction block) and recheck.

DTC B1170 (No. 1170): EEPROM Access Error

S7RW0CA204012

DTC Detecting Condition and Possible Cause

DTC detecting condition	Possible cause
Data write error or check sum error.	BCM malfunction

DTC Troubleshooting**NOTE**

Before performing steps below, be sure to perform "Body Electrical Control System Check".

- 1) Ignition switch OFF.
- 2) Replace BCM.
- 3) Repeat BCM Check Flow Table.

DTC U0073 (No. 0073): Control Module Communication Bus Off

S7RW0CA204013

Refer to "Troubleshooting for CAN-DTC in Section 1A".

DTC U0100 (No. 0100): Lost Communication with ECM

S7RW0CA204014

Refer to "Troubleshooting for CAN-DTC in Section 1A".

DTC U0101 (No. 0101): Lost Communication with TCM

S7RW0CA204015

Refer to "Troubleshooting for CAN-DTC in Section 1A".

DTC U0155 (No. 0155): Lost Communication with Instrument Panel Cluster (IPC) Control Module

S7RW0CA204016

Refer to "Troubleshooting for CAN-DTC in Section 1A".

DTC U1144 (No. 1144): Lost Communication with Keyless Start Control Module

S7RW0CA204017

Refer to "Troubleshooting for CAN-DTC in Section 1A".

Inspection of BCM and Its Circuits


BCM and its circuits can be checked at BCM wiring couplers by measuring voltage and resistance.

⚠ CAUTION

BCM cannot be checked by itself. It is strictly prohibited to connect voltmeter or ohmmeter to BCM with couplers disconnected from it.

Voltage Check

- 1) Disconnect negative cable (–) at battery.
- 2) Remove BCM (included in junction block) referring to “BCM (Included in Junction Block) Removal and Installation”.
- 3) Connect connectors to BCM (1) and junction block (2).
- 4) Check voltage at each terminal number of couplers connected.
For connector and terminal number, refer to “Connector Layout Diagram of BCM and Junction Block”.



I4RS0AA20030-01

NOTE

- As each terminal voltage is affected by the battery voltage, confirm that it is 11 V or more when ignition switch is ON.
- Voltage with asterisk (*) can not be measured by voltmeter because it is pulse signal. Check it with oscilloscope if necessary.

BCM connector “L01”

Terminal	Circuit	Normal voltage	Condition
L01-1	Passenger side door lock actuator control (Unlock) (if equipped)	10 – 14 V	Unlock signal is output for passenger side door lock actuator
		0 V	Unlock signal is not output for passenger side door lock actuator
L01-2	—	—	—
L01-3	Rear end door switch (Hatchback)	10 – 14 V	Rear end door is closed
		0 V	Rear end door is opened
	Trunk lid switch (Sedan) (keyless start model)	10 – 14 V	Trunk lid is closed
		0 V	Trunk lid is opened
L01-4	Rear end door opener switch (if equipped)	10 – 14 V	Rear end door opener switch is not pushed
		0 V	Rear end door opener switch is pushed
L01-5	Manual door lock switch (Unlock) (if equipped)	10 – 14 V	Manual door lock switch is at any position other than unlock position
		0 V	Manual door lock switch is at unlock position
L01-6	Parking brake switch	*0 – 3 V ↑↓ 10 – 14 V	Refer to “Reference waveform No. 1: ”
		0 V	Ignition switch is at ON position and parking brake lever is pulled up
L01-7	Driver side door switch	10 – 14 V	Driver side door is closed
		0 V	Driver side door is opened

Terminal	Circuit	Normal voltage	Condition
L01-8	—	—	—
L01-9	—	—	—
L01-10	Driver side door lock actuator control (Unlock) (if equipped)	10 – 14 V	Unlock signal is output for driver side door lock actuator
		0 V	Unlock signal is not output for driver side door lock actuator
L01-11	Rear end door / trunk lid opener actuator control (if equipped)	0 V	Rear end door / trunk lid actuator motor is not in operation
		10 – 14 V	Rear end door / trunk lid actuator motor is in operation
L01-12	Manual door lock switch (Lock) (if equipped)	10 – 14 V	Manual door lock switch is at any position other than lock position
		0 V	Manual door lock switch is at lock position
L01-13	—	—	—
L01-14	Driver side seat belt switch	*0 – 3 V ↑↓ 10 – 14 V	Refer to “Reference waveform No. 2: ”
		0 V	Ignition switch is at ON position and driver side seat belt is unfastened
L01-15	Door switch (other than driver side door and rear end door)	10 – 14 V	Rear right and left side door and passenger side door are closed
		0 V	Any one of the door is opened (except driver side door and rear end door)
L01-16	Driver side door key cylinder switch (Lock) (if equipped)	10 – 14 V	Driver side door key cylinder switch is at any position other than lock position
		0 V	Driver side door key cylinder switch is at lock position
L01-17	Driver side door key cylinder switch (Unlock) (if equipped)	10 – 14 V	Driver side door key cylinder switch is at any position other than unlock position
		0 V	Driver side door key cylinder switch is at unlock position
L01-18	—	—	—

BCM connector “E04”

Terminal	Circuit	Normal voltage	Condition
E04-1	CAN communication line (high) for ABS control module	*2.5 – 3.6 V	Refer to “Reference waveform No. 3: ”
E04-2	CAN communication line (low) for ABS control module	*1.6 – 2.5 V	
E04-3	—	—	—
E04-4	Generator “L” terminal	10 – 14 V	Engine is running
		0 V	Ignition switch is at ON position
E04-5	Brake fluid level switch	*0 – 3 V ↑↓ 10 – 14 V	Refer to “Reference waveform No. 1: ”
		0 V	Ignition switch is at ON position, parking brake lever is released and brake fluid level is lower than MIN level
E04-6	—	—	—
E04-7	—	—	—
E04-8	Sensor ground for outside air temperature sensor (if equipped)	0 V	—
E04-9	Serial communication line of data link connector for ABS control module	7 – 12 V	Ignition switch is at ON position
E04-10	Outside air temperature sensor (if equipped)	About 1.5 V	Ignition switch is at ON position and outside air temperature approx. 20 °C (68 °F)

10B-21 Body Electrical Control System:

Terminal	Circuit	Normal voltage	Condition
E04-11	Oil pressure switch	*3 – 14 V	Refer to “Reference waveform No. 4: ”
		0 V	Ignition switch is at ON position and engine is at stop
E04-12	—	—	—
E04-13	—	—	—
E04-14	—	—	—

BCM connector “G04”

Terminal	Circuit	Normal voltage	Condition
G04-1	CAN communication line (low) for DLC	*1.6 – 2.5 V	Refer to “Reference waveform No. 3: ”
G04-2	CAN communication line (low) for each control module	*1.6 – 2.5 V	
G04-3	CAN communication line (high) for DLC	*2.5 – 3.6 V	
G04-4	CAN communication line (high) for each control module	*2.5 – 3.6 V	
G04-5	Serial communication line of data link connector	7 – 12 V	Ignition switch is at ON position
G04-6	—	—	—
G04-7	—	—	—
G04-8	Theft deterrent light	10 – 14 V	Theft deterrent light is not lit up
		0 V	Theft deterrent light is lit up
G04-9	—	—	—
G04-10	—	—	—
G04-11	Serial communication line for information display and HVAC control module (if equipped)	*0 – 1 V ↑↓ 10 – 14 V	Refer to “Reference waveform No. 5: ”
G04-12	Ground for keyless entry receiver (if equipped)	0 V	—
G04-13	Power supply for keyless entry receiver (if equipped)	4 – 6 V	Ignition switch is at all positions
G04-14	Signal for keyless entry receiver (if equipped)	*0 – 1 V ↑↓ 4 – 6 V	Refer to “Reference waveform No. 6: ”
G04-15	Vehicle speed signal output	*0 – 1 V ↑↓ 4 – 6V	Refer to “Reference waveform No. 7: ”
G04-16	Key reminder switch	10 – 14 V	Ignition key is inserted to ignition key cylinder
		0 V	Ignition key is pulled out from ignition key cylinder
G04-17	Rear end door window / back window defogger switch	*3 – 14 V	Refer to “Reference waveform No. 8: ”
		0 V	Ignition switch is at ON position and rear end door window / back window defogger switch is pushed
G04-18	A/C switch (if equipped)	*3 – 14 V	Refer to “Reference waveform No. 8: ”
		0 V	Ignition switch is at ON position, blower speed selector is at any position other than OFF position and A/C switch is at ON position
G04-19	—	—	—
G04-20	—	—	—
G04-21	Rear wiper INT switch	*0 – 1 V ↑↓ 10 – 14 V	Refer to “Reference waveform No. 9: ”
		0 V	Ignition switch is at ON position and rear wiper switch is at INT position

Terminal	Circuit	Normal voltage	Condition
G04-22	Rear wiper low switch	*0 – 1 V ↑↓	Refer to “Reference waveform No. 9: ”
		10 – 14 V	
		0 V	Ignition switch is at ON position and rear wiper switch is at LOW position

Junction block connector “E324”

Terminal	Circuit	Normal voltage	Condition
E324-2	Backup power source	10 – 14 V	Ignition switch is at all positions

Junction block connector “E325”

Terminal	Circuit	Normal voltage	Condition
E325-3	Horn	10 – 14 V	Horn switch is at ON position
		0 V	Horn switch is at OFF position

Junction block connector “G271”

Terminal	Circuit	Normal voltage	Condition
G271-3	Ground for BCM	0 V	Ignition switch is at all positions
G271-7	Rear end door window defogger indicator light	10 – 14 V	Engine is running and rear end door window defogger indicator light is lit up
		0 V	Engine is running and rear end door window defogger indicator light is not lit up

Junction block connector “G272”

Terminal	Circuit	Normal voltage	Condition
G272-3	Horn switch	10 – 14 V	Horn switch is not pushed
		0 V	Horn switch is pushed
G272-7	Lighting switch	10 – 14 V	Lighting switch is at any position other than OFF position
		0 V	Lighting switch is at OFF position
G272-9	Ground for BCM	0 V	Ignition switch is at all positions
G272-11	Hazard warning switch	10 – 14 V	Hazard warning switch is at OFF position
		0 V	Hazard warning switch is at ON position or lock or unlock button of keyless entry transmitter (answer back control) is pushed

Junction block connector “G273”

Terminal	Circuit	Normal voltage	Condition
G273-2	Power source (IG)	10 – 14 V	Ignition switch is at ON position
		0 V	Ignition switch is at any position other than ON position
G273-5	Power source (ACC)	10 – 14 V	Ignition switch is at ACC or ON position
		0 V	Ignition switch is at any position other than ACC or ON position

Junction block connector “L312”

Terminal	Circuit	Normal voltage	Condition
L312-4	Power supply for rear wiper motor	10 – 14 V	Ignition switch is at ON position
L312-5	Interior light	10 – 14 V	Interior light switch is at DOOR position and interior light is not lit up
		0 V	Interior light switch is at DOOR position and interior light is lit up

Junction block connector “L313”

Terminal	Circuit	Normal voltage	Condition
L313-2	Air bag communication line	*0 – 1 V ↑↓ 4 – 6 V	Refer to “Reference waveform No. 10: ”
L313-3	Serial communication line of data link connector for SDM	7 – 12 V	Ignition switch is at ON position

Junction block connector “L314”

Terminal	Circuit	Normal voltage	Condition
L314-4	Ground for BCM	0 V	Ignition switch is at all positions
L314-8	Rear end door window defogger wire (Hatchback)	10 – 14 V	Engine is running and rear end door window defogger is in operation
		0 V	Engine is running and rear end door window defogger is not in operation
L314-9	Rear wiper control	10 – 14 V	Ignition switch is at ON position and rear wiper is not in operation
		0 V	Ignition switch is at ON position and rear wiper is in operation


Junction block connector “L315”

Terminal	Circuit	Normal voltage	Condition
L315-5	Back window defogger control (Sedan)	10 – 14 V	Engine is running and back window defogger is not in operation
		0 V	Engine is running and back window defogger is in operation
L315-9	Rear right and left door lock actuator control (Unlock) (if equipped)	10 – 14 V	Unlock signal is output for rear door lock actuator
		0 V	Unlock signal is not output for rear door lock actuator
L315-10	Door lock actuator control (Lock) (if equipped)	10 – 14 V	Lock signal is output for all door lock actuators
		0 V	Lock signal is not output for all door lock actuators

Reference waveform No. 1

Parking brake or brake fluid level switch signal (1)

Measurement terminal	Parking brake switch CH2: "L01-6" to "G271-3" Brake fluid level switch CH2: "E04-5" to "G271-3"
Oscilloscope setting	CH1: 5 V / DIV TIME: 10 ms / DIV
Measurement condition	Parking brake switch: - Ignition switch is at ON position, parking brake lever is released Brake fluid level switch - Ignition switch is at ON position, brake fluid level is in normal




I4RS0AA20018-02

Reference waveform No. 2

Driver seat belt switch signal (1)

Measurement terminal	CH2: "L01-14" to "G271-3"
Oscilloscope setting	CH2: 5 V/DIV TIME: 4 ms/DIV
Measurement condition	Ignition switch is at ON position and driver side seat belt is fastened




I4RS0AA20016-02

Reference waveform No. 3

CAN communication signal

Measurement terminal	CAN communication signal for ABS control module CH2: "E04-1" to "G271-3" CH3: "E04-2" to "G271-3" CAN communication signal for DLC CH2: "G04-3" to "G271-3" CH3: "G04-1" to "G271-3" CAN communication signal for each control module CH2: "G04-4" to "G271-3" CH3: "G04-2" to "G271-3"
Oscilloscope setting	CH2: 1 V/DIV CH3: 1 V/DIV TIME: 40 μ s/ DIV
Measurement condition	Ignition switch is at ON position




I4RS0AA20017-02

- | |
|---|
| 1. CAN communication line signal (High) |
| 2. CAN communication line signal (Low) |

Reference waveform No. 4

Oil pressure switch signal (1)

Measurement terminal	CH2: "E04-11" to "G271-3"
Oscilloscope setting	CH2: 5 V / DIV TIME: 10 ms / DIV
Measurement condition	Engine is running and oil pressure is in normal condition




I4RS0AA20018-02

Reference waveform No. 5


Information display and HVAC control module serial communication signal (1)

Measurement terminal	CH2: "G04-11" to "G271-3"
Oscilloscope setting	CH2: 5 V / DIV TIME: 2 ms / DIV
Measurement condition	Ignition switch is at ON position


Reference waveform No. 6


Keyless entry receiver signal (1)

Measurement terminal	CH2: "G04-14" to "G271-3"
Oscilloscope setting	CH2: 2 V / DIV TIME: 200 ms / DIV
Measurement condition	Lock or unlock button of keyless entry transmitter is pushed


Reference waveform No. 7


Vehicle speed pulse output signal (1)

Measurement terminal	CH1: "G04-15" to "G271-3"
Oscilloscope setting	CH1: 2 V / DIV TIME: 100 ms / DIV
Measurement condition	Vehicle speed at 10 km/h (6 mph)


Reference waveform No. 8

A/C or rear end door window / back window defogger switch signal (1)


Measurement terminal	Rear end door window / back window defogger switch CH2: "G04-17" to "G271-3" A/C switch CH2: "G04-18" to "G271-3"
Oscilloscope setting	CH2: 5 V/DIV TIME: 10 ms/DIV
Measurement condition	Rear end door window / back window defogger switch: - Ignition switch is at ON position and rear end door window / back window defogger switch is not pushed A/C switch: - Ignition switch is at ON position, A/C switch or blower speed selector is at OFF position



Reference waveform No. 9


Rear wiper switch signal (1)

Measurement terminal	Rear wiper INT switch CH2: "G04-21" to "G271-3" Rear wiper LOW switch CH2: "G04-22" to "G271-3"
Oscilloscope setting	CH2: 5 V/DIV TIME: 10 ms/DIV
Measurement condition	Rear wiper INT switch: - Ignition switch is at ON position and rear wiper switch is at any position other than INT position Rear wiper LOW switch: - Ignition switch is at ON position and rear wiper switch is at any position other than LOW position

**Reference waveform No. 10**

SDM communication signal (1)

Measurement terminal	CH2: "L314-2" to "G271-3"
Oscilloscope setting	CH2: 2 V / DIV TIME: 400 ms / DIV
Measurement condition	Ignition switch is at ON position

**Repair Instructions****BCM (Included in Junction Block) Removal and Installation**


S7RW0CA206001

⚠ CAUTION

Do not attempt removal of BCM from junction block as it may cause contact failure.
If there is faulty condition in BCM, replace junction block assembly.

Removal

- 1) Disconnect negative cable from battery.
- 2) Disable air bag system referring to "Disabling Air Bag System in Section 8B".
- 3) Remove dash side trim (1) and steering column hole cover (2).
- 4) Remove junction block mounting nuts (3).



I5RW0AA20015-01

4. BCM

5. Junction block

10B-27 Body Electrical Control System:

- 5) Disconnect connectors from BCM and junction block.
- 6) Detach wiring harness clamp from junction block.

Installation

Reverse removal procedure for installation, noting following points.

- Connect connectors securely.
- Enable air bag system referring to “Enabling Air Bag System in Section 8B”.
- With keyless entry system (other than keyless start model), if BCM is replaced, register transmitter code into BCM, referring to “Programming Transmitter Code for Keyless Entry System (Other than Keyless Start Model) in Section 9F”.

Outside Air Temperature Sensor Removal and Installation

S7RW0CA206002

For removal and installation, refer to “Outside Air Temperature Sensor Removal and Installation (If Equipped) in Section 9C”.

Outside Air Temperature Sensor Inspection

S7RW0CA206003

For inspection, refer to “Outside Air Temperature Sensor Inspection (If Equipped) in Section 9C”.


Special Tools and Equipment

Special Tool

S7RW0CA208001

SUZUKI scan tool

—
This kit includes following items. 1. Tech 2, 2. PCMCIA card, 3. DLC cable, 4. SAE 16/19 adapter, 5. Cigarette cable, 6. DLC loop back adapter, 7. Battery power cable, 8. RS232 cable, 9. RS232 adapter, 10. RS232 loop back connector, 11. Storage case, 12. 



Immobilizer Control System

Precautions

Precautions in Diagnosing Troubles

S7RW0CA300001

- Before confirming the diagnostic trouble code (DTC), do not disconnect connector from ECM, battery cable from battery, ground wire harness, or main fuse. Such disconnection will erase DTC stored in ECM.
- DTC stored in ECM memory can be checked as well as cleared by using SUZUKI scan tool. Before using SUZUKI scan tool, read its operator's manual carefully to know how to use it and what functions are available.
- Be sure to read "Precautions for Electrical Circuit Service in Section 00" before inspection.
- Communication of ECM, BCM, ABS control module, TCM (if equipped), 4WD control module (if equipped), keyless start control module (if equipped), combination meter and DLC is established by CAN (Controller Area Network). Therefore, handle CAN communication lines with care referring to "Precaution for CAN Communication System in Section 00". For CAN communication system, refer to description on "CAN Communication System Description in Section 1A".

Precaution in Replacing ECM

S7RW0CA300002

- If ECM is replaced with new or used one without Immobilizer control function, the engine will not be started. In case of the above, check if the newly installed ECM has Immobilizer control function.
- After ECM is replaced with new one or used one, the transponder code in the transponder built in the ignition key has to be registered with ECM. Or, the engine cannot be started up. For the registration procedure, refer to "Procedure after ECM Replacement".

Precaution in Replacing Ignition Key


S7RW0CA300003

To register ignition key in case of replacing key(s) and/or making spare key(s), the transponder code in the ignition key is registered with ECM. Or the engine can not be started up. For the registration procedure, refer to "Registration of the Ignition Key".

Precautions in Handling Immobilizer Control System


S7RW0CA300004

- Do not turn ON ignition switch with ignition key in contact with another one or quite close to another one. Or, the immobilizer control system may detect some abnormal condition and prevent the engine from starting.



I3RH0AA30001-01


- Do not turn ON ignition switch by using ignition key with any type of metal (1) wrapped its grip or in contact with it. Or, the immobilizer control system may detect some abnormal condition and prevent the engine from starting.



I3RH0AA30002-01


10C-2 Immobilizer Control System:

- Do not leave ignition key in a place where temperature is high. High temperature may cause damage to the transponder built in the ignition key.



I3RH0AA30003-01

- Do not turn ignition switch to ON position by bringing radio antenna close to coil antenna. Or, the immobilizer control system may detect some abnormal condition and prevent the engine from starting.



I3RH0AA30004-01

General Description

Immobilizer Control System Introduction

S7RW0CA301001

The immobilizer control system is an anti-theft device that immobilizes the vehicle. It stops the engine from working and prevents the vehicle from being stolen. It mainly consists of the following components. For immobilizer control system components location, refer to “Immobilizer Control System Components Location”.

- ECM
- ICM with the built-in coil antenna
- Ignition key with the built-in transponder

A code called the transponder code is memorized in the transponder. And, the code is registered with ECM. Basically, when the ignition switch is turned ON, ECM reads the code by the coil antenna. Then, if the code in transponder in the ignition key does not match with the one registered with ECM, ECM stops the operation of the fuel injection so as not to start up the engine and turns the immobilizer indicator light ON and OFF using CAN communication lines. (In addition to the above operation, ECM also turns the immobilizer indicator light ON and OFF when some trouble is detected in the keyless start system.)

On-Board Diagnostic System Description (Self-diagnosis Function)

S7RW0CA301002

ECM diagnoses if there is any trouble with the immobilizer control system. The diagnostic information is stored as the diagnostic trouble code (DTC) in ECM. To read the diagnostic information, use SUZUKI scan tool referring to “DTC Check”.

With the ignition switch turned ON (but the engine at stop) regardless of the condition of the engine and emission control system, ECM indicates whether there is any trouble with the immobilizer control system or not by either lighting ON or flashing ON and OFF the immobilizer indicator light.

Immobilizer indicator light lights ON:

No trouble exists in the immobilizer control system. (After starting up the engine, the light turns OFF.)

Immobilizer indicator light flashes ON and OFF:

There is some trouble in the immobilizer control system or in the keyless start system. Its diagnostic information is stored in ECM.


Schematic and Routing Diagram

Immobilizer Control System Wiring Circuit Diagram

S7RW0CA302001

NOTE

For more details about power supply circuit, ground wire circuit, and each circuit for ECM, BCM, ABS control module, keyless start control module and combination meter, refer to "System Circuit Diagram in Section 9A".




I6RW0CA30001-01

[A]: ICM connector (harness side view)	7. To BCM	14. Steering lock unit (keyless start model)
1. Battery	8. ABS control module	15. Keyless start control module (if equipped)
2. Fuse	9. DLC	16. CAN junction connector
3. Ignition switch	10. ECM	17. Combination meter
4. Junction block	11. BCM	18. Immobilizer indicator light
5. ICM	12. To SDM	
6. Illumination ring (if equipped)	13. To ABS control module	

Component Location

Immobilizer Control System Components Location

S7RW0CA303001



I6RW0BA30001-01

1. ECM	5. Ignition key (non keyless entry model)
2. Immobilizer indicator light	6. Ignition key (keyless start model)
3. ICM	7. Transponder
4. Ignition key (keyless entry model)	

Diagnostic Information and Procedures

Immobilizer Control System Check

S7RW0CA304001

Step	Action	Yes	No
1	Immobilizer indicator light check 1) Turn ignition switch to ON position using ignition key. <i>Does immobilizer indicator light come on?</i>	Go to Step 2.	Check if DTC P1636 and/or P1638 are detected by ECM referring to "DTC Check". If detected, go to applicable DTC diag. flow. If not detected, go to "Immobilizer Indicator Light Does Not Come ON with Ignition Switch ON and Engine Stop".
2	Immobilizer indicator light check <i>Does immobilizer indicator light flash on and off continuously in Step 1?</i>	Check ECM for DTC referring to "DTC Check". Then, go to applicable DTC diag. flow.	Go to Step 3.
3	Engine start check 1) Start engine using ignition key. <i>Does engine start?</i>	Go to Step 4.	Go to "Engine and Emission Control System Check in Section 1A".
4	Immobilizer indicator light check 1) Check if immobilizer indicator light remains ON after engine start. <i>Does immobilizer indicator light remains ON after engine start?</i>	Go to "Immobilizer Indicator Light Remains ON after Engine Start".	Immobilizer control system is in good condition. Then, go to "Keyless Start System Check in Section 10E" for keyless start model.

DTC Check

S7RW0CA304002


NOTE

To know how to use SUZUKI scan tool in detail, refer to its operator's manual.

- 1) Turn the ignition switch to OFF position.
- 2) Connect SUZUKI scan tool to data link connector (DLC) (1) located under instrument panel at driver's seat side.

Special tool

(A): SUZUKI scan tool (SUZUKI-SDT)



I5RW0CA30002-01

- 3) Turn the ignition switch to ON position.
- 4) Read DTC according to instructions displayed on SUZUKI scan tool and print them or write them down. Refer to scan tool operator's manual for details.
If communication between scan tool and ECM is not possible, go to "Troubleshooting for Communication Error with Scan Tool Using CAN in Section 1A".
- 5) After completing the check, turn ignition switch to OFF position, and then disconnect SUZUKI scan tool from DLC.

DTC Clearance

S7RW0CA304003


NOTE

To know how to use SUZUKI scan tool in detail, refer to its operator's manual.

- 1) Turn the ignition switch to OFF position,
- 2) Connect SUZUKI scan tool to data link connector (DLC) (1) located under instrument panel at driver's seat side.

Special tool

(A): SUZUKI scan tool (SUZUKI-SDT)



I5RW0CA30002-01

- 3) Turn the ignition switch to ON position.
- 4) Clear DTC(s) according to the instructions displayed on SUZUKI scan tool.
- 5) After completing the clearance, turn the ignition switch to OFF position, and then disconnect SUZUKI scan tool from DLC.

DTC Table

S7RW0CA304004

ECM

NOTE

ECM detects DTC. ICM does not.

DTC No.	Detecting Item	Detecting Condition	Immobilizer Indicator Light
P1614	Transponder response error	Transponder code in transponder built in ignition key cannot be read through ICM.	Flash
P1615	Steering lock unit communication error	- While registering the transponder code in the transponder built in the ignition key in ECM, the keyless start control module sent a signal to ECM indicating that the ID code could not be registered. - The ID code could not be registered in the keyless start control module or ECM.	Flash
P1616	Unregistered keyless start control module	ECM detects different ID codes registered in ECM and keyless start control module.	Flash
P1618	Keyless start control module CAN communication error	Reception error of communication data for keyless start control module is detected for longer than specified time continuously.	Flash
P1621	Immobilizer communication line error	Communication error between ICM and ECM.	Flash
P1622	EEPROM reading / writing error	EEPROM in ECM is corrupted.	Flash
P1623	Unregistered transponder	Transponder code in the transponder built in the ignition key is invalid.	Flash
P1625	Immobilizer antenna error	ICM is faulty.	Flash
P1636	Immobilizer information registration failure	Communication error between ECM and BCM.	No operation
P1638	Immobilizer information mismatched	- Communication error between ECM and BCM. - Wrong ECM or BCM is used.	No operation

NOTE

If any DTC other than the above DTCs is detected, refer to "DTC Table in Section 1A".

Scan Tool Data

Suzuki scan tool displays the following data using "Registration Information" mode.

Scan Tool Data (Registration Information Data)	Vehicle Condition	Normal Data
☞ Component ID	Ignition switch at ON position	****
☞ Keyfree System Code		Registered
☞ Remote Starter Code		Unregistered
☞ Number of the Registered Immobilizer Key		2 Keys
☞ Latest Year for the Key Registration		2006
☞ Latest Month for the Key Registration		June

Scan Tool Data Definitions

Component ID (****)

This parameter indicates the vehicle ID number of four digits used for the Suzuki scan tool.

Keyfree System Code (Keyless start control system ID code, Registered, Unregistered)

Registered: ID code of the keyless start system is registered in the ECM.

Unregistered: ID code of the keyless start system is unregistered in the ECM.

Remote Starter Code (Remote starter control system code, Registered, Unregistered)

Registered: Remote starter system is registered in the ECM.

Unregistered: Remote starter system is unregistered in the ECM.

Number of the Registered Immobilizer Key (0 – 4 keys)

The number of the transponder code in the transponder built in the ignition key that is registered with ECM.

NOTE

A maximum of four transponder codes can be registered with ECM. Therefore, the maximal value should be 4.

Latest Year for the Key Registration (2006 or Later)

The year in which the transponder code in the transponder built in the ignition key is registered with ECM.

Latest Month for the Key Registration (January-December)

The month in which the transponder code in the transponder built in the ignition key is registered with ECM.

Immobilizer Indicator Light Does Not Come ON with Ignition Switch ON and Engine Stop**Wiring Diagram**

Refer to “Immobilizer Control System Wiring Circuit Diagram”.

Circuit Description

When the ignition switch is turned ON, ECM transmits the indication ON signal to the combination meter to turn ON the immobilizer indicator light in case that there is not any problem with the immobilizer control system. Then, the combination meter turns ON the light. When the engine is started up, ECM transmits the indication OFF signal to the combination meter to turn OFF the light. Then, the combination meter turns OFF the immobilizer indicator light. However, in case that there is some trouble with the immobilizer control system, the immobilizer indicator light flashes ON and OFF when the ignition switch is turned ON.

Troubleshooting

Step	Action	Yes	No
1	Immobilizer indicator light power supply check 1) Turn the ignition switch to ON position. <i>Do other warning lights come ON?</i>	Go to Step 2.	Go to Step 4.
2	DTC check of ECM 1) Check ECM for DTC referring to “DTC Check in Section 1A”. <i>Is DTC U0073, U0101, U0121 and/or U0140 detected?</i>	Go to applicable DTC diag. flow.	Go to Step 3.
3	DTC check of BCM 1) Check BCM for DTC referring to “DTC Check in Section 10B”. <i>Is DTC U0073, U0100, U0101, U0155 and/or U1144 detected?</i>	Go to applicable DTC diag. flow.	Substitute a known-good combination meter and recheck. If immobilizer indicator light still remains OFF, substitute a known-good ECM and recheck.
4	Fuse check 1) Turn the ignition switch to OFF position. 2) Check fuse for combination meter circuit. <i>Is fuse blown?</i>	Replace blown fuse, and then check for short.	Go to Step 5.
5	Combination meter power supply wire circuit check 1) Remove combination meter referring to “Combination Meter Removal and Installation in Section 9C”. 2) Check for proper connection at terminals and wires of combination meter connector. 3) If OK, turn the ignition switch to ON position and measure voltage between power supply terminal of combination meter and vehicle body ground. Refer to “Combination Meter Circuit Diagram in Section 9C”. <i>Is it 10 – 14 V?</i>	Go to Step 6.	Repair open in power supply wire circuit.
6	Combination meter ground wire circuit check 1) Turn ignition switch OFF position. 2) Measure resistance between ground terminal of combination meter connector and vehicle body ground. Refer to “Combination Meter Circuit Diagram in Section 9C”. <i>Is resistance 1 Ω or less?</i>	Substitute a known-good combination meter and recheck. If still remains OFF, substitute a known-good ECM and recheck.	Repair open or high resistance in ground circuit.

Immobilizer Indicator Light Remains ON after Engine Start

S7RW0CA304007

Wiring Diagram

Refer to "Immobilizer Control System Wiring Circuit Diagram".

Circuit Description

Refer to "Immobilizer Indicator Light Does Not Come ON with Ignition Switch ON and Engine Stop".

Troubleshooting

Step	Action	Yes	No
1	DTC check of ECM 1) Check ECM for DTC referring to "DTC Check in Section 1A". <i>Is DTC detected?</i>	Go to applicable DTC diag. flow.	Go to Step 2.
2	CAN communication circuit check 1) Disconnect connectors from ECM, BCM, ABS control module and combination meter. 2) Check CAN communication circuit for open, short and high resistance. - Between ECM and ABS control module - Between BCM and ABS control module - Between BCM and combination meter <i>Is each CAN communication circuit in good condition?</i>	Substitute a known-good combination meter and recheck. If immobilizer indicator light still remains ON, substitute a known-good ECM and recheck.	Repair circuit.

DTC P1614: Transponder Response Error

S7RW0CA304008

Wiring Diagram

Refer to "Immobilizer Control System Wiring Circuit Diagram".

Detecting Condition and Trouble Area

Detecting Condition	Trouble Area
Transponder code in transponder built in ignition key cannot be read through ICM.	- Use of ignition key without transponder - Use of unregistered ignition key - Corruption of transponder in ignition key - ICM - ECM

Troubleshooting

Step	Action	Yes	No
1	<i>Was "Immobilizer Control System Check" performed?</i>	Go to Step 2.	Go to "Immobilizer Control System Check".
2	DTC check of ECM 1) Check if any DTC other than P1614 is detected referring to "DTC Check". <i>Is DTC other than P1614 detected?</i>	Go to applicable DTC diag. flow.	Go to Step 3.
3	Registration of ignition key in use with ECM 1) Register ignition key in use with ECM referring to "Registration of the Ignition Key". <i>Was registration of ignition key completed?</i>	Recheck DTC.	Go to Step 4.
4	Registration of the spare ignition key 1) Register the spare ignition key with ECM referring to "Registration of the Ignition Key". <i>Was registration of spare ignition key completed?</i>	Replace ignition key which can not be registered.	Substitute a known-good ECM and recheck.

DTC P1615: Steering Lock Unit Communication Error**Wiring Diagram**

Refer to "Immobilizer Control System Wiring Circuit Diagram".

Circuit Description

When the transponder code in the ignition key is registered in ECM, the ID code is registered in both ECM and keyless start control module at the same time. This DTC is detected only in case that the ID code cannot be registered in both ECM and keyless start control module when the transponder code in the ignition key is registered in ECM.

NOTE

- Troubleshoot DTC P1618 first if both DTC P1615 and P1618 are detected at the same time.
- After replacing ECM, be sure to register the transponder code in the ignition key with ECM referring to "Registration of the Ignition Key". After replacing the keyless start control module of the vehicle equipped with the keyless start system, be sure to perform "Registration of the Ignition Key".

Detecting Condition and Trouble Area

Detecting Condition	Trouble Area
• While registering the transponder code in ECM, the keyless start control module sent a signal to ECM indicating that the ID code could not be registered. • The ID code could not be registered in the keyless start control module or ECM.	• Wire circuits between steering lock unit and keyless start control module • CAN communication circuit • Steering lock unit • Keyless start control module • Combination meter • TCM (if equipped) • 4WD control module (if equipped) • ABS control module • BCM • ECM

Troubleshooting

Step	Action	Yes	No
1	Was "Immobilizer Control System Check" performed?	Go to Step 2.	Go to "Immobilizer Control System Check".
2	Registration of ignition key 1) Register ignition key in use with ECM referring to "Registration of the Ignition Key". Was registration of ignition key completed?	Recheck ECM for DTC. If DTC P1615 is still detected, go to Step 3.	Go to Step 3.
3	DTC check of ECM 1) Check ECM for DTC referring to "DTC Check in Section 1A". Is DTC U0073, U0101, U0121 and/or U0140 detected?	Go to applicable DTC diag. flow.	Go to Step 4.
4	DTC check of keyless start control module 1) Check keyless start control module for DTC referring to "DTC Check in Section 10E". Is DTC detected?	Go to applicable DTC diag. flow.	Go to Step 5.
5	Check for communication circuit between steering lock unit and keyless start control module 1) Check for open, short, and high resistance in steering lock unit circuit. Refer to Step 2 in "DTC No. 11: Communication Error with Steering Lock Unit in Section 10E". Is each circuit in good condition?	Go to Step 6.	Repair malfunction part and recheck.

Step	Action	Yes	No
6	Steering lock unit power supply check 1) Connect keyless start control module connector. 2) With ignition switch at ON position, check power supply terminal voltage of steering lock unit connector. Refer to "Keyless Start Control Module Power and Ground Circuit Check in Section 10E". <i>Is voltage 4 – 6 V?</i>	Replace steering lock unit and recheck.	Substitute a known-good keyless start control module and recheck. If DTC P1615 is still detected, substitute a known-good ECM and recheck.

DTC P1616: Unregistered Keyless Start Control Module

S7RW0CA304010

Wiring Diagram

Refer to "Immobilizer Control System Wiring Circuit Diagram".

Circuit Description

P1616 is detected when ECM detects different ID codes registered in ECM and keyless start control module after turning engine start knob to ON position. Normally, when keyless start control module is replaced with new one, ECM automatically registers the applicable code in keyless start control module after turning ignition switch to ON position. However, when keyless start control module is replaced with used one, ECM does not automatically register the applicable code in keyless start control module even if ignition switch is turned to ON position.

Detecting Condition and Trouble Area

Detecting Condition	Trouble Area
ECM detects different ID codes registered in ECM and keyless start control module.	• Keyless start system wire circuit • Keyless start control module • ECM

Troubleshooting

Step	Action	Yes	No
1	<i>Was "Immobilizer Control System Check" performed?</i>	Go to Step 2.	Go to "Immobilizer Control System Check".
2	Registration of the ignition key 1) Register the ignition key with ECM referring to "Registration of the Ignition Key". <i>Was registration of ignition key completed?</i>	Recheck ECM for DTC.	Go to Step 3.
3	DTC check of ECM 1) Check DTC referring to "DTC Check". <i>Is DTC P1618 and/or P1615 detected other than P1616?</i>	Go to DTC P1618 troubleshooting.	Go to DTC P1615 troubleshooting.

DTC P1618: Keyless Start Control Module CAN Communication Error

S7RW0CA304011

Refer to "Troubleshooting for CAN-DTC in Section 1A".

DTC P1621: Immobilizer Communication Line Error

S7RW0CA304012

Wiring Diagram

Refer to "Immobilizer Control System Wiring Circuit Diagram".

Detecting Condition and Trouble Area

Detecting Condition	Trouble Area
Communication error between ICM and ECM.	• Related fuse(s) blown • Poor connection at ICM connector • Poor connection at ECM connector • Power supply circuit • Ground circuit • Communication circuits between ICM and ECM • ICM • ECM

Troubleshooting

Step	Action	Yes	No
1	Was "Immobilizer Control System Check" performed?	Go to Step 2.	Go to "Immobilizer Control System Check".
2	Fuse check 1) Check fuse for ICM circuit. <i>Is fuse in good condition?</i>	Replace blown fuse(s) and then, check for short circuit.	Go to Step 3.
3	Voltage check at power and ground terminal 1) Check power and ground terminal voltage of ICM connector referring to "Inspection of ICM and Its Circuit". <i>Is each terminal voltage in good condition?</i>	Go to Step 4.	Repair circuit.
4	ICM and ECM connector check 1) With the ignition switch at OFF position, check intermittent and poor connection of ICM connector and ECM connectors referring to "Intermittent and Poor Connection Inspection in Section 00". <i>Is each connector in good condition?</i>	Go to Step 5.	Repair poor connection.
5	Communication circuit check between ICM and ECM 1) Check for open, short and high resistance in serial communication and clock circuit between ICM and ECM. <i>Is each communication circuit in good condition?</i>	Substitute a known-good ICM and recheck. If DTC P1621 is still detected, substitute a known good ECM and recheck.	Repair circuit.

DTC P1622: EEPROM Reading / Writing Error

S7RW0CA304013

Detecting Condition and Trouble Area

Detecting Condition	Trouble Area
EEPROM in ECM is corrupted.	Internal failure (EEPROM corruption) of ECM

Troubleshooting

- 1) Clear DTC(s) referring to "DTC Clearance".
- 2) Turn the ignition switch to OFF position.
- 3) Check if DTC P1622 is still detected referring to "DTC Check". If still detected, go to the next step. If not, the troubleshooting is completed.
- 4) Replace ECM with new one referring to "Engine Control Module (ECM) Removal and Installation in Section 1C".
- 5) Perform "Procedure after ECM Replacement".

DTC P1623: Unregistered Transponder

S7RW0CA304014

Wiring Diagram

Refer to "Immobilizer Control System Wiring Circuit Diagram".

Detecting Condition and Trouble Area

Detecting Condition	Trouble Area
Transponder code in the transponder built in the ignition key is invalid.	• Use of the unregistered ignition key • ICM • ECM

Troubleshooting

Step	Action	Yes	No
1	Was "Immobilizer Control System Check" performed?	Go to Step 2.	Go to "Immobilizer Control System Check".
2	DTC check of ECM 1) Check if any DTC other than P1623 is detected referring to "DTC Check". <i>Is DTC other than P1623 detected?</i>	Go to applicable DTC diag. flow.	Go to Step 3.
3	Registration of unregistered ignition key with ECM 1) Register the unregistered ignition key with ECM referring to "Registration of the Ignition Key". <i>Was registration of ignition key completed?</i>	Recheck DTC.	Go to Step 4.
4	Registration of the spare ignition key 1) Register the spare ignition key referring to "Registration of the Ignition Key". <i>Was registration of spare ignition key completed?</i>	Replace ignition key which cannot be registered.	Substitute a known-good ECM and recheck.

DTC P1625: Immobilizer Antenna Error

S7RW0CA304015

Wiring Diagram

Refer to "Immobilizer Control System Wiring Circuit Diagram".

Detecting Condition and Trouble Area

Detecting Condition	Trouble Area
ICM is faulty.	• ICM • ECM

10C-14 Immobilizer Control System:

Troubleshooting

Step	Action	Yes	No
1	Was "Immobilizer Control System Check" performed?	Go to Step 2.	Go to "Immobilizer Control System Check".
2	DTC confirmation 1) Clear DTC referring to "DTC Clearance". 2) Turn the ignition switch to OFF position. 3) Check DTC referring to "DTC Check". <i>Is DTC P1625 still detected?</i>	Substitute a known-good ICM and recheck DTC. If DTC P1625 is still detected, substitute a known-good ECM and recheck.	Intermittent trouble. Check for intermittent referring to "Intermittent and Poor Connection Inspection in Section 00".

DTC P1636: Immobilizer Information Registration Failure

S7RW0CA304016

Wiring Diagram

Refer to "Immobilizer Control System Wiring Circuit Diagram".

Detecting Condition and Trouble Area

Detecting Condition	Trouble Area
The registration of the immobilizer control system information in ECM is failed.	• CAN communication circuit • Keyless start control module (if equipped) • Combination meter • TCM (A/T model) • 4WD control module (if equipped) • ABS control module • BCM • ECM

Troubleshooting

Step	Action	Yes	No
1	Was "Immobilizer Control System Check" performed?	Go to Step 2.	Go to "Immobilizer Control System Check".
2	DTC check of ECM 1) Check ECM for DTC referring to "DTC Check in Section 1A". <i>Is DTC U0073, U0101, U0121 and/or U0140 detected?</i>	Go to applicable DTC diag. flow.	Go to Step 3.
3	DTC check of BCM 1) Check BCM for DTC referring to "DTC Check in Section 10B". <i>Is DTC U0073, U0100, U0101, U0155 and/or U1144 detected?</i>	Go to applicable DTC diag. flow.	Go to Step 4.
4	CAN communication circuit check 1) Disconnect connectors from ECM, BCM and ABS control module. 2) Check CAN communication circuit for open, short and high resistance. • Between ECM and ABS control module • Between BCM and ABS control module <i>Is each CAN communication circuit in good condition?</i>	Go to Step 5.	Repair circuit.

Step	Action	Yes	No
5	Replacement of BCM 1) Replace BCM with new one referring to "BCM (Included in Junction Block) Removal and Installation in Section 10B". 2) Check ECM for DTC referring to "DTC Check". <i>Is DTC P1636 still detected?</i>	Substitute a known-good ECM and recheck.	BCM faulty.

DTC P1638: Immobilizer Information Mismatched

S7RW0CA304017

Wiring Diagram

Refer to "Immobilizer Control System Wiring Circuit Diagram".

Detecting Condition and Trouble Area

Detecting Condition	Trouble Area
- The immobilizer control system information in ECM and the one in BCM does not match. - The registration of the immobilizer control system information in ECM is failed.	- Use of the wrong ECM - CAN communication circuit - Keyless start control module (if equipped) - Combination meter - TCM (A/T model) 4WD control module (if equipped) - ABS control module - BCM - ECM

Troubleshooting

Step	Action	Yes	No
1	<i>Was "Immobilizer Control System Check" performed?</i>	Go to Step 2.	Go to "Immobilizer Control System Check".
2	DTC confirmation 1) Disconnect negative (–) cable from battery for more than 5 seconds. 2) Connect negative (–) cable to battery. 3) Check if any DTC is detected referring to "DTC Check". <i>Is DTC P1638 still detected?</i>	Go to Step 3.	Intermittent trouble. Check for intermittent referring to "Intermittent and Poor Connection Inspection in Section 00".
3	ECM specification check 1) Check ECM part number to see if ECM is applicable to the vehicle in service. <i>Is a correct ECM used for the vehicle in service?</i>	Go to Step 4.	Replace ECM with the correct one and recheck if DTC P1638 is still detected by ECM.
4	DTC check of ECM 1) Check ECM for DTC referring to "DTC Check in Section 1A". <i>Is DTC U0073, U0101, U0121 and/or U0140 detected?</i>	Go to applicable DTC diag. flow.	Go to Step 5.
5	DTC check of BCM 1) Check BCM for DTC referring to "DTC Check in Section 10B". <i>Is DTC U0073, U0100, U0101, U0155 and/or U1144 detected?</i>	Go to applicable DTC diag. flow.	Go to Step 6.

10C-16 Immobilizer Control System:

Step	Action	Yes	No
6	CAN communication circuit check 1) Disconnect connectors from ECM, BCM and ABS control module. 2) Check CAN communication circuit for open, short and high resistance. • Between ECM and ABS control module • Between BCM and ABS control module <i>Is each CAN communication circuit in good condition?</i>	Go to Step 7.	Repair circuit.
7	Replacement of BCM 1) Replace BCM with new one referring to "BCM (Included in Junction Block) Removal and Installation in Section 10B". 2) Check ECM for DTC referring to "DTC Check". <i>Is DTC P1638 still detected?</i>	Substitute a known-good ECM and recheck.	BCM faulty.

Inspection of ICM and Its Circuit

S7RW0CA304018

ICM and its circuit can be checked at ICM wiring connector by measuring voltage.

⚠ CAUTION


ICM cannot be checked by itself. It is strictly prohibited to connect voltmeter or ohmmeter to ICM with connector disconnected from it.

Voltage Check

- 1) Remove ICM (1) from steering lock assembly or steering lock unit referring to "ICM Removal and Installation".
- 2) Connect ICM connector (2) to ICM.
- 3) Check voltage at each terminal.

NOTE


As each terminal voltage is affected by the battery voltage, confirm that it is 11 V or more when the ignition switch is turned to ON position.



I6RW0BA30003-01

Terminal	Circuit	Normal Voltage	Condition
G17-1	Power supply	About 12.0 V	Ignition switch at ON position
		0.0 V	Ignition switch at OFF position
G17-2	Ground	0.0 V	—
G17-3	Serial communication line	See the reference waveform.	—
		0.0 V	Ignition switch at OFF position
G17-4	Clock line	See the reference waveform.	—
		0.0 V	Ignition switch at OFF position
G17-5	Illumination ring control (if equipped)	0 V	- Ignition key not inserted to the key cylinder - Door opened
		0 V → 12 V	- Ignition key at OFF position - From the time door is closed to the time interior light faded out completely (As the interior light fades out, the voltage increases.)
		0 V → 12 V	- Door closed - From the ignition switch is turned ON to the time interior light is completely faded out (As the interior light fades out, the voltage increases.)
G17-6	Illumination ring power supply (if equipped)	About 12.0 V	—

Reference Waveform



I6RW0CA30003-01

[A]: The transponder code read successfully at the first try.	2. Clock line
[B]: The transponder code read successfully at the second try.	3. First try
1. Serial communication line	4. Second try

NOTE

When ECM cannot read the transponder code at the first try, ECM tries to read the transponder code repeatedly up to 8 times. The second waveform is the example showing that ECM read the transponder code successfully at the second try.

Measurement terminals	CH1: G17-3 to G17-2 CH2: G17-4 to G17-2
Oscilloscope settings	CH1: 5 V/DIV CH2: 5 V/DIV TIME: 20 ms
Measurement condition	Right after the ignition switch is turned ON, the waveform can be read.


Repair Instructions

ICM Removal and Installation

S7RW0CA306001


Removal

- 1) Disconnect negative (–) cable at battery.
- 2) Remove dash side trim (4) and steering column hole cover (3).
- 3) Remove steering column covers (1).
Turn steering wheel to access steering column cover screws (2).



I6RW0BA30004-01

- 4) Remove engine start knob (keyless start model).
- 5) Disconnect connector (1) from ICM (2).
- 6) Remove a screw (3) from ICM.



I4RS0BA30007-03

- 7) Remove ICM from steering lock assembly or steering lock unit.

NOTE

The antenna part of ICM is fragile. Therefore, do not add strong power to the part or twist the part.

Installation

Reverse the removal procedure.

Registration of the Ignition Key

S7RW0CA306002

To finish the registration of the ignition key, the transponder code memorized in the transponder built in the ignition key has to be registered with ECM. To register the transponder code with ECM, perform "Immobilizer Key Registration" mode of SUZUKI scan tool referring to "SUZUKI scan tool Operator's Manual".

NOTE

- A maximum of four transponder codes can be registered with ECM.
- At an early part of the registration process, all transponder codes of the ignition keys in use already registered with ECM are cleared. Therefore, before starting the registration, prepare all ignition keys in use in addition to the new ignition key(s) to be registered with ECM.

Procedure after ECM Replacement

S7RW0CA306003

After ECM is replaced with new one or used one, the transponder code in the transponder built in the ignition key has to be registered with ECM. To register transponder code in the ignition key with ECM, perform "Immobilizer Key Registration" mode of SUZUKI scan tool referring to "SUZUKI scan tool Operator's Manual".

NOTE

A maximum of four transponder codes can be registered with ECM.


Special Tools and Equipment

Special Tool

S7RW0CA308001

SUZUKI scan tool (SUZUKI-SDT)

—
This kit includes following items. 1. SUZUKI-SDT 2. DLC3 cable 3. USB cable 4. AC/DC power supply 5. Voltage meter probe 6. Storage case



Keyless Start System

Precautions

Precautions in Diagnosing Troubles

S7RW0CA500001

- The keyless start system executes data transmission/reception by means of the radio wave. Therefore, proper operation may not be obtained if use of the door lock function and engine start function of the keyless start system is attempted near the place where strong radio wave is emitted (TV and radio broadcasting stations, etc.).
- Diagnostic information stored in keyless start control module memory can be checked only by key indicator light.
- Be sure to use the trouble diagnosis procedure as described in “Keyless Start System Check”. Failure to follow it may result in incorrect diagnosis. (Some other DTC may be stored by mistake in the memory of keyless start control module during inspection.)
- Be sure to read “Precautions for Electrical Circuit Service in Section 00” before inspection and observe what is written there.
- Communication of ECM, TCM (A/T model), BCM, ABS control module, 4WD control module (if equipped), keyless start control module and combination meter is established by CAN (Controller Area Network). (For detail of CAN communication for keyless start control module, refer to “CAN Communication System Description”). Therefore, handle CAN communication line with care referring to “Precaution for CAN Communication System in Section 00”.
- Replacement of the keyless start control module
When keyless start control module is replaced with new one, make sure that register remote controller ID code to keyless start control module correctly according to “Registration Procedure for Remote Controller ID Code”.
- Keyless start control module substitution
When the keyless start control module used in another vehicle was installed in the vehicle being serviced, register the ID code of the remote controller to the keyless start control module first and then the following code.
 - With immobilizer control system, register the ignition key transponder code for the immobilizer control system in ECM. For registration procedure of that, refer to “Registration of the Ignition Key in Section 10C”.
 - Without immobilizer control system, register the steering lock unit ID code in keyless start control module. For registration procedure of that, refer to “Keyless Start Registration”.


General Description

Keyless Start System Description

S7RW0CA501001

Keyless start system consisting of the parts shown below has four functions as described below.

- **Keyless engine start function:**
With the remote controller which has been registered in the keyless start control module carried with oneself, the engine can be started without using the ignition key.
- **Door lock function:**
Pushing the request switch incorporated in the outside handle of the driver side door, passenger side door or rear end door (Hatchback) while carrying the remote controller which has been registered in the keyless start control module, doors can be locked or unlocked.
- **Trunk lid opener function (Sedan):**
Pushing the trunk lid request switch while carrying the remote controller which has been registered in the keyless start control module, trunk lid can be opened.
- **Keyless entry system function:**
It is possible to lock or unlock doors by pushing the lock or unlock button of remote controller.
The keyless start control module can accept registration of up to four remote controllers.



I6RW0BA50001-01

1. Keyless start control module	7. Passenger side door antenna	13. Key indicator light
2. Remote controller	8. Rear end door / trunk lid antenna	14. ECM
3. Request switch	9. Steering lock unit	15. Trunk room antenna (Sedan)
4. Center antenna	10. Lock button	16. Trunk lid opener actuator (Sedan)
5. Luggage room antenna (Hatchback)	11. Unlock button	
6. Driver side door antenna	12. BCM	

Parts and Functions


Parts	Function
Keyless start control module	• Activates each antenna • Verifies ID code of remote controller • Requests steering lock unit to release steering lock • Requests BCM to lock or unlock doors • Requests BCM to open trunk lid (Sedan) • Controls key indicator light in combination meter • Transmits its ID code to ECM
Remote controller	• Receives request signal from each antenna • Transmits ID code and request signal to keyless start control module • Request keyless start control module to lock or unlock doors (keyless entry system function)
Request switch	• Requests keyless start control module to activate each antenna
Center antenna	• Transmits request signal to remote controller
Luggage room / trunk room antenna	• Transmits request signal to remote controller
Driver side door antenna	• Transmits request signal to remote controller
Passenger side door antenna	• Transmits request signal to remote controller
Rear end door / trunk lid antenna	• Transmits request signal to remote controller
Steering lock unit	• Releases steering lock
Unlock button	• Transmits door unlock request signal (keyless entry system function)
Lock button	• Transmits door lock request signal (keyless entry system function)
BCM	• Controls each door lock actuator • Controls trunk lid opener actuator (Sedan) • Controls warning buzzer • Lights hazard warning light and interior (DOME) light (answer back)
Key indicator light	• Indicates operation state of keyless start system (indicates check result of remote controller ID code)
ECM	• Checks keyless start control module ID code • Transmits its ID code to keyless start control module • Starts engine

Keyless Engine Start Function

When the ignition knob switch (2) installed to the steering lock unit (1) is pushed, the keyless start control module (3) activates the center antenna (4) to send out the request signal in the vehicle compartment. When the remote controller (5) receives the request signal from the center antenna, it transmits the ID code to the keyless start control module. The keyless start control module compares the ID code sent by the remote controller with the ID code registered in the keyless start control module. When these ID codes match, the keyless start control module makes the key indicator light (7) in the combination meter (6) light in blue and unlocks the steering lock unit to enable the ignition knob switch to turn. When the ignition knob switch is turned to ON position in this state, ID codes of ECM and keyless start control module are compared through CAN communication (immobilizer function). When they match, turning the ignition knob switch to start position will start the engine.

NOTE

When ignition knob switch is at ACC or ON position (engine not running) and any door has been kept open for a certain time, it may happen that engine fails to start. In such a case, turn ignition knob switch to OFF position once and then try to start engine again.



[A]: i) ~ vii)

[A]: Signal flow

8. ECM

I5RW0AA50002-03

When the ID code from the remote controller and the ID code registered in the keyless start control module do not match or when the remote controller is outside the operation area of the remote controller and the ignition knob switch is pushed, the steering lock unit cannot be unlocked and so the ignition knob switch cannot be turned. Then, the keyless start control module makes the key indicator light in the combination meter light in red to warn the driver that it is not possible to turn the ignition knob switch.

In case of vehicle equipped with immobilizer control system, when the ID code of ECM and that of the keyless start control module do not match, the engine cannot be started even if the ignition knob switch is turned to the start position. Then ECM makes the immobilizer indicator light in the combination meter flash to warn the driver that it is not possible to start the engine.


Door Lock Function of Keyless Start System

When the request switch (1) incorporated in the outside handle of the driver side door, front passenger side door or rear end door (Hatchback) is pushed, the keyless start control module (2) activates the center antenna (3) and luggage room antenna (4) (Hatchback) or trunk room antenna (10) (Sedan) to send out the radio wave in the vehicle compartment to check if the remote controller (5) is in the vehicle compartment or not. When the keyless start control module receives no signal from the remote controller (i.e., the remote controller does not exist in the vehicle compartment), it activates the antenna (6) of the door of which the request switch has been pushed to send the request signal out of the compartment.

If the remote controller exists within the door lock operation area, it receives the request signal sent from the above said antenna, sends the ID code of the remote controller and the request signal to the keyless start control module and at the same time, it makes the operation indicator light (7) of the remote controller light up. Lighting of the operation indicator light indicates that the remote controller sent the ID code and the request signal.

The keyless start control module compares the ID code sent from the remote controller with the ID code registered in the keyless start control module. If both ID codes match, the keyless start control module outputs the lock or unlock request signal (depending on the door lock switch (8) state then) to BCM (9). When BCM receives such signal through CAN communication from the keyless start control module, it activates the door lock actuator to lock or unlock doors. When the keyless start control module receives a signal from the remote controller (i.e., the remote controller exists in the vehicle compartment), the function of the keyless start system to prevent the remote controller from being closed in the vehicle works and the keyless start control module sends a request signal to unlock doors to BCM. In this way, doors are kept unlocked.

Also, when the driver or passenger has left the vehicle with the remote controller left behind in the vehicle compartment and locked doors by using the door lock knob or manual door lock switch, the function to prevent the remote controller from being closed in the vehicle works to unlock doors.



[A]: i) ~ viii)

[A]: Signal flow

I6RW0BA50002-01

Furthermore, when ID codes of the remote controller and keyless start control module do not match or the remote controller exists outside of the operation area, doors are not locked or unlocked even if the request switch of the outside handle is operated.

Trunk Lid Opener Function of Keyless Start System (Sedan)


S7RW0CA501008

When the trunk lid request switch (1) is pushed, the keyless start control module (2) activates the trunk room antenna (3) to send out the radio wave in the trunk room to check if the remote controller (4) is in the trunk room or not. When the keyless start control module receives no signal from the remote controller (i.e., the remote controller does not exist in the trunk room), it activates the trunk lid antenna (5) to send the request signal out of the compartment.

If the remote controller exists within the trunk lid opener operation area, it receives the request signal sent from the trunk lid antenna, sends the ID code of the remote controller and the request signal to the keyless start control module and at the same time, it makes the operation indicator light (6) of the remote controller light up. Lighting of the operation indicator light indicates that the remote controller sent the ID code and the request signal.

The keyless start control module compares the ID code sent from the remote controller with the ID code registered in the keyless start control module. If both ID codes match, the keyless start control module outputs the trunk lid open request signal to BCM (7). When BCM receives such signal through CAN communication from the keyless start control module, it activates the trunk lid opener actuator (8) to open trunk lid.

When the trunk lid is closed while the front driver side and/or front passenger side door lock is at the lock position and all doors are closed, the keyless start control module activates the trunk room antenna to send the radio wave in the trunk room so as to check whether the remote controller is in the trunk room or not. When the keyless start control module receives a signal from the remote controller (i.e., the remote controller exists in the trunk room), the function the keyless start system to prevent the remote controller from being closed in the trunk room and the keyless start control module sends a trunk lid open request signal to open trunk lid to BCM. In this way, trunk lid is kept opened.



[A]: i) ~ viii)


[A]: Signal flow

I6RW0BA50003-01

Furthermore, when ID codes of the remote controller and keyless start control module do not match or the remote controller exists outside of the operation area, trunk lid is not opened even if the trunk lid request switch is operated.

Operation Area of Remote Controller

Shown below are the operation areas of the remote controller for the keyless engine start function, door lock function and trunk lid opener function (Sedan) of the keyless start system.



I6RW0BA50004-02

[A]: Door lock function of keyless start system	3. Center antenna
[B]: Function of keyless start system to prevent remote controller from being closed in vehicle compartment	4. Luggage room antenna
[C]: Keyless engine start function	5. Vehicle compartment including luggage room / trunk room
[D]: Trunk lid opener function of keyless start system (Sedan)	6. Vehicle compartment excluding luggage room / trunk room
[E]: Hatchback	7. Trunk room antenna
1. About 80 cm (31.5 in, 2.6 ft)	8. Trunk lid antenna
2. Each door antenna	

However, even when the remote controller is within the operation area as shown above, there are cases where the keyless start system doesn't work under certain conditions as described below. And when the keyless engine start function doesn't work, the key indicator light in the combination meter may light up.

- Doors cannot be locked or unlocked using the door lock function of keyless start system when:
 - The remote controller which has been registered in the keyless start control module and another un-registered one are both carried at the same time
 - The remote controller is kept in some metallic container which disturb radio wave transmission/reception
 - One of doors is open
 - The ignition key is inserted in the ignition key cylinder
- Trunk lid cannot be opened using the trunk lid opener function of keyless start system when:
 - The remote controller which has been registered in the keyless start control module and another un-registered one are both carried at the same time
 - The remote controller is kept in some metallic container which disturb radio wave transmission/reception
- The function of the keyless start system to prevent the remote controller from being closed in the vehicle compartment doesn't work when:
 - The remote controller is in the door pocket or in the glove box
 - The remote controller is kept in some metallic container which disturb radio wave transmission/reception
 - The remote controller is placed close to outside of the vehicle compartment (such as on the instrument panel beside the front window shield glass, on the rear parcel shelf (partition trim) or in a corner of the luggage room / trunk room)
- The ignition knob switch cannot be turned using the keyless engine start function fails to turn:

- The remote controller which has been registered in the keyless start control module and another un-registered one are both carried at the same time
- The remote controller is kept in some metallic container which disturbs radio wave transmission/reception
- The ignition knob switch has been pushed for 5 seconds or longer
- The remote controller is placed close to outside of the vehicle compartment (such as on the instrument panel beside the front window shield glass, on the rear parcel shelf (partition trim) or in a corner of the luggage room / trunk room)

Alarm Function

S7RW0CA501006

Under conditions as described in the table below, the keyless start control module makes the key indicator light flash in red and the buzzer sound to call the driver's attention.

Condition	Buzzer operation	Key indicator light operation
Ignition knob switch has stopped between ACC and OFF positions while driver side door is opened (ignition knob switch un-returned alarm)	Intermittent	—
Ignition switch has stopped between ACC and OFF positions while driver side door is closed (ignition knob switch un-returned alarm)	2 times	Flashing in red
Remote controller is carried out of vehicle and doors are closed while ignition switch is at ON position (remote controller carried-out alarm)	5 times	Flashing in red
Remote controller is carried out of vehicle through a window without opening door while ignition switch is at ON position (engine is running) and vehicle has been driven at 10 km/h (6 MPH) or more speed without remote controller in vehicle compartment (the first time 10 km/h (6 MPH) speed is exceeded only) (Remote controller carried-out alarm)	5 times	Flashing in red

CAN Communication System Description

S7RW0CA501007

Refer to "CAN Communication System Description in Section 1A" for CAN communication system description. Keyless start control module communicates control data with each control module as follows.

Keyless Start Control Module Transmission Data

Keyless Start Control Module		DATA		ECM	BCM	Combination Meter
			ID code of keyless start control module	○		
			ECM-keyless start control module code	○		
			Ignition knob switch signal		○	
			Door lock/unlock request signal		○	
			Buzzer request signal		○	
			Answer back request signal		○	
			Trunk lid open request signal		○	
			Key indicator light control signal			○

I6RW0BA50005-02

Keyless Start Control Module Reception Data


Keyless Start Control Module		DATA		ECM	BCM
			Vehicle speed signal	○	
			ECM-keyless start control module code	○	
			Door switch status		○
			Trunk lid switch status		○
			Door lock status		○
			Charging system signal		○
			Engine oil pressure switch signal		○

I6RW0BA50006-01

Schematic and Routing Diagram

Keyless Start System Electric Wiring Circuit Diagram

S7RW0CA502001



I6RW0CA50008-01

[A]: Keyless start control module connector (viewed from harness side)	8. Rear end door / trunk lid antenna	16. Combination meter
1. Keyless start control module	9. Center antenna	17. Key indicator light
2. Steering Lock unit	10. Luggage room / trunk room antenna	18. BCM
3. Steering lock solenoid	11. Driver side door request switch	19. ECM
4. Ignition knob switch	12. Passenger side door request switch	20. ABS control module
5. Key reminder switch	13. Rear end door / trunk lid request switch	21. CAN junction connector
6. Driver side door antenna	14. Driver side door lock switch	22. Ignition switch
7. Passenger side door antenna	15. Passenger side door lock switch	

Diagnostic Information and Procedures

Self-Diagnosis Function

S7RW0CA504001

The keyless start control module has self-diagnosis function to monitor the system components and circuits while the keyless start system is at work. When the keyless start control module detects an abnormality in the system, it saves the area where such abnormality has occurred as a DTC in its memory. The DTC stored in memory of the keyless start control module is indicated by the key indicator light in the combination meter

flashing in a specific pattern. For DTC indication, refer to “DTC Check” and for the clearing procedure, to “DTC Clearance”.

Keyless Start System Diagnosis Introduction

S7RW0CA504002

To ensure that the trouble diagnosis is done accurately and smoothly, observe “Precautions in Diagnosing Troubles” and follow “Keyless Start System Check”.

Keyless Start System Check

S7RW0CA504003

Step	Action	Yes	No
1	1) Record details of the problem. For your record, use of a questionnaire form will facilitate collecting information for proper analysis and diagnosis. 2) Check if the problem described in “Customer Questionnaire (Example)” actually occurs in the vehicle. (This step should be performed with the customer if possible.) Perform “Keyless Start System Operation Inspection” procedure to check if the symptom which has occurred is abnormal or not. 3) Check for DTC referring to “DTC Check”, and then record DTC(s). 4) Clear DTC referring to “DTC Clearance” if any DTC exists, and then recheck for DTC. <i>Is any DTC still detected?</i>	Go to Step 2.	Go to Step 3.
2	1) Check and repair referring to applicable “DTC Table”. <i>Are check and repair complete?</i>	Go to Step 5.	Check and repair malfunction part(s), and go to Step 5.
3	1) Inspect and repair basic parts referring to “Keyless Start System Symptom Diagnosis”. <i>Is there faulty condition?</i>	Repair or replace malfunction part(s), and go to Step 5.	Go to Step 4.
4	1) Check for intermittent problems referring to “Intermittent and Poor Connection Inspection in Section 00”. <i>Is there any faulty condition?</i>	Repair or replace malfunction part(s), and go to Step 5.	Go to Step 5.
5	1) Confirm if the problem is solved and the keyless start system is free from any abnormal conditions. If what has been repaired is related to the DTC, clear the DTC once and then confirm that no DTC is indicated. <i>Is there any problem symptom, DTC or abnormal condition?</i>	Go to 2) of Step 1 and perform trouble diagnosis again.	End.

Customer Questionnaire (Example)

S7RW0CA504004

Customer's name:	Model:	VIN:	
Date of issue:	Date Reg:	Date of problem:	Mileage:


Problem Symptoms	• Engine can not be started by turning Ignition knob switch • All doors can not be locked / unlocked by all of request switches • Other_____
Frequency of Occurrence	• Continuous / Intermittent (times a day, a month) / Other_____
Environmental Condition	• Weather: Fine / Cloudy / Rain / Snow / Other_____ • Temperature: °C(° F) • Stopping near area where intense radio waves are emitted such as TV station, radio station, etc. Yes / No
Diagnostic Trouble Code	• First check: Normal code / malfunction code () • Second check: Normal code / malfunction code ()

I4RS0BA50007-03

Key Indicator Light Check

S7RW0CA504005

Push the ignition knob switch (2) of the steering lock unit (1) and check that the key indicator light (3) in the combination meter lights up in red or blue. If it does not light, go to "Key Indicator Light Circuit Check (Key Indicator Light Doesn't Light when Ignition Knob Switch is Pushed)".





I4RS0BA50008-01

DTC Check

S7RW0CA504006

- 1) Check to make sure that all doors are closed.
- 2) Open driver side door window glass and door.
- 3) Check to make sure that ignition key is not inserted in ignition key cylinder. If it is, remove it.
- 4) Perform "Key Indicator Light Check".
- 5) Close driver side door and within 15 seconds after that, perform Steps a) through e) described below.
 - a) Insert ignition key (1) in ignition key cylinder (2).
 - b) Remove ignition key from ignition key cylinder.
 - c) Repeat Steps a) and b) twice.
 - d) Insert ignition key in ignition key cylinder.
 - e) Push driver side door request switch (3) 4 times. At the end of Step e), buzzer sounds 4 times to inform that trouble diagnosis mode has started.





I4RS0BA50009-02

- 6) Read flashing pattern of key indicator light (1) which represents DTC as shown in example below and write it down. When more than 2 DTCs are stored in memory, flashing for each DTC is repeated three times starting with the smallest DTC number in increasing order.

NOTE

Go to "No DTC Detection After Performing DTC Check" in case that any DTC is detected after performing the procedure mentioned above.



I4RS0BA50010-02

[A]: DTC No. 12 (Normal)	a: 0.3 seconds
[B]: DTC No. 52	b: 1.0 second
H: Key indicator light turned ON	c: 3.0 seconds
L: Key indicator light turned OFF	

- 7) After completing the check, remove ignition key from ignition key cylinder.

DTC Table

S7RW0CA504007


DTC (Flashing pattern of key indicator light)	Detected parts item	Detecting condition
11	Communication Error with Steering Lock Unit	No communication is available between keyless start control module and steering lock unit
12	—	Normal (No malfunction DTC is detected)
13	Release Signal Error from Steering Lock Unit	Although lock release signal is output to steering lock unit, it is not inputted from steering lock unit
14	Steering Lock Unit Malfunction	Steering lock unit cannot be unlocked due to its temperature rise
21	Internal Error in Keyless Start Control Module (EEPROM Reading Error)	Data cannot be read from memory in keyless start control module
22	Internal Error in Keyless Start Control Module (EEPROM Writing Error)	Data cannot be written into memory in keyless start control module
31	Lost Communication with BCM	Keyless start control module cannot receive data sent by CAN from BCM
33	Control Module Communication Bus Off	No communication is available with all control modules connected by CAN
51	Driver Side Door Request Switch Malfunction	Input signal from driver side door request switch remains ON, unchanged
52	Passenger Side Door Request Switch Malfunction	Input signal from passenger side door request switch remains ON, unchanged
53	Rear End Door / Trunk Lid Request Switch Malfunction	Input signal from rear end door / trunk lid request switch remains ON, unchanged

DTC Clearance

S7RW0CA504008

- 1) Perform Steps 1) through 5) of DTC check procedure and have DTC indicated.
- 2) Open driver side door.
- 3) Close driver side door and within 10 seconds after that, perform Steps a) to c) described below.
 - a) Push unlock side (3) of driver side manual door lock switch (1).
 - b) Push lock side (2) of driver side manual door lock switch.
 - c) Repeat Steps a) and b) 3 times.

At the end of Step c), DTCs are cleared and key indicator light indicates DTC No. 12 (Normal).



I4RS0BA50011-02

- 4) After completing DTC clearance, remove ignition key from ignition key cylinder.

Keyless Start System Symptom Diagnosis

Door Lock Function of Keyless Start System

NOTE

Before performing trouble diagnosis procedure for door lock function of keyless start system, check that power door lock system operates properly referring to “Power Door Lock System Operation Inspection in Section 9F”. If power door lock system does not operate properly, go to “Power Door Lock System Symptom Diagnosis in Section 9F”.

Condition	Possible cause	Correction / Reference Item
All doors can not be locked / unlocked by all of door request switches	Circuit fuse(s) blown	Replace fuse(s) and check for short circuit.
	Remote controller battery dead	Replace battery.
	Remote controller faulty	Check remote controller for operation referring to “Remote Controller Inspection”.
	Wiring or grounding faulty	Repair circuit.
	Antennas or keyless start control module faulty	Check input and output signals of keyless start control module referring to “Inspection of Keyless Start Control Module and Its Circuits”.
	BCM faulty	Check input and output signal of BCM referring to “Inspection of BCM and Its Circuits in Section 10B”.
All doors can not be locked / unlocked by any one of door request switch	Request switch faulty	Check request switch for operation referring to “Front Door (Driver and Passenger Side), Rear End Door / Trunk Lid Request Switch Inspection”.
	Wiring or grounding faulty	Repair circuit.
	Antennas or keyless start control module faulty	Check input and output signals of keyless start control module referring to “Inspection of Keyless Start Control Module and Its Circuits”.
	BCM faulty	Check input and output signal of BCM referring to “Inspection of BCM and Its Circuits in Section 10B”.

Trunk Lid Opener Function of Keyless Start System (Sedan)

NOTE

- Use of SUZUKI scan tool makes it easy to check whether a faulty condition is on the input side or output side of BCM. For checking procedure, refer to “Diagnosis Using Output Test Function of SUZUKI Scan Tool” under “Scan Tool Data in Section 10B”.
- Check each part in the order from the top of the following list.

Condition	Possible cause	Correction / Reference Item
Trunk lid can not be opened by trunk lid request switch	Circuit fuse(s) blown	Replace fuse(s) and check for short circuit.
	Remote controller battery dead	Replace battery.
	Remote controller faulty	Check remote controller for operation referring to “Remote Controller Inspection”.
	Request switch faulty	Check request switch for operation referring to “Front Door (Driver and Passenger Side), Rear End Door / Trunk Lid Request Switch Inspection”.
	Trunk lid opener actuator faulty	Check trunk lid opener actuator operation referring to “Power Door Lock Actuator Inspection in Section 9F”.
	Wiring or grounding faulty	Repair circuit.
	Antennas or keyless start control module faulty	Check input and output signals of keyless start control module referring to “Inspection of Keyless Start Control Module and Its Circuits”.
	BCM faulty	Check input and output signal of BCM referring to “Inspection of BCM and Its Circuits in Section 10B”.

Keyless Engine Start Function

NOTE

Before performing symptom diagnosis procedure for keyless engine start system, check that engine starts by using ignition key. If it cannot be started by using ignition key, go to “Engine Symptom Diagnosis in Section 1A”.

Condition	Possible cause	Correction / Reference Item
Engine can not be started by turning Ignition knob switch	Circuit fuse(s) blown	Replace fuse(s) and check for short circuit.
	Remote controller battery dead	Replace battery.
	Remote controller faulty	Check remote controller for operation referring to “Remote Controller Inspection”.
	Steering lock unit faulty	Check steering lock unit for operation referring to “Steering Lock Unit Inspection”.
	Wiring or grounding faulty	Repair circuit.
	Antennas or keyless start control module faulty	Check input and output signals of keyless start control module referring to “Inspection of Keyless Start Control Module and Its Circuits”.
	ECM faulty	Check input and output signal of ECM referring to “Inspection of ECM and Its Circuits in Section 1A”.

Keyless Start System Operation Inspection

S7RW0CA504010

Keyless Engine Start Operation

- 1) Sit in driver seat with remote controller carried with you.
- 2) Check that all doors are closed and ignition key is not inserted in ignition key cylinder.
- 3) While pushing ignition knob switch (1) of steering lock unit, check if ignition knob switch can be turned from its lock position.

If key indicator light (2) in combination meter lights in blue and ignition knob switch can be turned from its lock position in this check, keyless engine start operation is in good condition.

If key indicator light in combination meter lights in red and ignition knob switch cannot be turned from its lock position in this check, go to "Keyless Start System Check".

NOTE

Pushing ignition knob switch for 5 seconds or longer causes function to protect steering lock releasing solenoid against heat to work. Then steering lock unit stops energizing solenoid, preventing ignition knob switch from turning. At the same time, key indicator light in combination meter turns off. In such case, take your hand off from ignition knob switch once and operate it again.




I4RS0BA50012-01

Door Lock Operation Check (Keyless Start System)

S7RW0CA504011

- 1) Check that all door locks are released and all doors are closed.
- 2) With remote controller of which ID code is registered in keyless start control module carried with yourself, check that pushing driver door request switch once releases all doors.
- 3) Check that pushing request switch of driver door, passenger door or rear end door (Hatchback) once releases corresponding door lock.
- 4) Check that pushing again request switch pushed in Step 3) releases all door locks.



I4RS0BA50013-01

NOTE

If door of which request switch has been pushed is opened/closed before performing Step 4), all door locks will not be released even when Step 4) is performed. If Step 4) is performed after door is opened/closed, only the door of which request switch was pushed will be locked.

Inspection of Keyless Start Control Module and Its Circuits

Keyless start control module and its circuits can be checked at keyless start control module wiring couplers by measuring voltage and resistance.

⚠ CAUTION


Keyless start control module cannot be checked by itself. It is strictly prohibited to connect voltmeter or ohmmeter to keyless start control module with coupler disconnected from it.

Voltage Check

- 1) Disconnect negative cable (–) at battery.
- 2) Remove keyless start control module from vehicle body referring to “Keyless Start Control Module Removal and Installation”.
- 3) Connect connector to keyless start control module.
- 4) Check voltage at each terminal number of couplers connected.

NOTE

- As each terminal voltage is affected by the battery voltage, confirm that it is 11 V or more when ignition switch is ON.
- Voltage with asterisk (*) cannot be measured by voltmeter because it is pulse signal.



[A]

20	19	18	16	15	14	11	10	9	8	7	6	5	4	3	2	1
37	36	34	33	32	31	30	29						24	23		

[A]: Keyless start control module connector (viewed from harness side)

I5RW0AA50008-03


Terminal Number	Circuit	Normal Voltage	Condition
G16-1	Driver side door antenna (–)	*0 – 5 V	Refer to “Reference waveform No. 1: ”
G16-2	Driver side door antenna (+)		
G16-3	Rear end door / trunk lid antenna (–)	*0 – 5 V	Refer to “Reference waveform No. 1: ”
G16-4	Rear end door / trunk lid antenna (+)		
G16-5	Center antenna (–)	*–2 – 2 V	Refer to “Reference waveform No. 2: ”
G16-6	Center antenna (+)	*–10 – 15 V	
G16-7	Luggage room / trunk room antenna (–)	*–10 – 10 V	Refer to “Reference waveform No. 3: ”
G16-8	Luggage room / trunk room antenna (+)	*–8 – 14 V	
G16-9	Ground for keyless start control module	0 – 1 V	Ignition switch is at all positions
G16-10	Power source	10 – 12 V	Ignition switch is at all positions
G16-11	Ignition switch (ACC signal)	10 – 12 V	Ignition switch is at ACC or ON position
		0 – 1 V	Ignition switch is at any position other than ACC or ON position
G16-12	—	—	—

Terminal Number	Circuit	Normal Voltage	Condition
G16-13	—	—	—
G16-14	Ignition switch (key reminder signal)	10 – 12 V	Insert ignition key to ignition key cylinder
		0 – 1 V	Pull out ignition key from ignition key cylinder
G16-15	Ignition switch (ON signal)	10 – 12 V	Ignition switch is at ON position
		0 – 1 V	Ignition switch is at any position other than ON position
G16-16	Driver side door request switch	10 – 12 V	Request switch of driver side door is released
		0 – 1 V	Request switch of driver side door is pushed
G16-17	—	—	—
G16-18	CAN communication line (low)	*1.6 – 2.5 V	Refer to “Reference waveform No. 4: ”
G16-19	CAN communication line (high)	*2.5 – 3.6 V	
G16-20	Power supply for steering lock unit	4 – 6 V	Full time
G16-21	—	—	—
G16-22	—	—	—
G16-23	Passenger side door antenna (–)	*0 – 5 V	Refer to “Reference waveform No. 1: ”
G16-24	Passenger side door antenna (+)		
G16-25	—	—	—
G16-26	—	—	—
G16-27	—	—	—
G16-28	—	—	—
G16-29	Signal for steering lock unit	4 – 6 V	Ignition knob switch is at any position other than ON and OFF position
		*0 – 5 V	Refer to “Reference waveform No. 5: ”
G16-30	Ground for steering lock unit	0 – 1 V	Full time
G16-31	—	—	—
G16-32	Rear end door / trunk lid request switch	10 – 12 V	Request switch of rear end door / trunk lid is released
		0 – 1 V	Request switch of rear end door / trunk lid is pushed
G16-33	Driver side door lock switch	0 – 1 V	Driver side door is at unlock position and passenger side door is at lock position
		4 – 6 V	Driver and passenger side door is at lock position
		*3 – 5 V	Refer to “Reference waveform No. 6: ”
G16-34	Ignition knob switch	10 – 12 V	When pushing ignition knob switch of steering lock unit
		0 – 1 V	When releasing ignition knob switch of steering lock unit
G16-35	—	—	—
G16-36	Passenger side door request switch	10 – 12 V	Request switch of passenger side door is released
		0 – 1 V	Request switch of passenger side door is pushed
G16-37	Passenger side door lock switch	0 – 1 V	Passenger side door is at unlock position and driver side door is at lock position
		4 – 6 V	Driver and passenger side door is at lock position
		*3 – 5 V	Refer to “Reference waveform No. 6: ”
G16-38	—	—	—
G16-39	—	—	—
G16-40	—	—	—

Reference waveform No. 1

Driver, passenger and rear end door / trunk lid antenna request signals (Request signal (1) transmitted by each door antenna when each door request switch is pushed)

Measurement terminal	Driver side door antenna - CH1: "G16-2" to "G16-9" - CH2: "G16-1" to "G16-9" Passenger side door antenna - CH1: "G16-24" to "G16-9" - CH2: "G16-23" to "G16-9" Rear end door / trunk lid antenna - CH1: "G16-4" to "G16-9" - CH2: "G16-3" to "G16-9"
Oscilloscope setting	CH1: 5 V/DIV, CH2: 5 V/DIV TIME: 40 ms/DIV
Measurement condition	Request switch of each door is pushed with remote controller carried




I4RS0BA50015-02

Reference waveform No. 2

Center antenna signal

(Request signal (1) transmitted by center antenna when each door request switch is pushed)

Measurement terminal	CH1: "G16-6" to "G16-9" CH2: "G16-5" to "G16-9"
Oscilloscope setting	CH1: 10 V/DIV, CH2: 2 V/DIV TIME: 20 ms/DIV
Measurement condition	- Ignition knob switch of steering lock unit is pushed - Request switch of each door is pushed with remote controller carried




I5JB0AA50024-03

Reference waveform No. 3

Luggage room / trunk room antenna signal

(Request signal (1) transmitted by luggage room / trunk room antenna when each door request switch is pushed)

Measurement terminal	CH1: "G16-8" to "G16-9" CH2: "G16-7" to "G16-9"
Oscilloscope setting	CH1: 10 V/DIV, CH2: 10 V/DIV TIME: 20 ms/DIV
Measurement condition	Request switch of each door is pushed with remote controller carried




I5JB0AA50025-02

Reference waveform No. 4

CAN communication signals

(CAN signal communicated to each control module when ignition switch is turned ON)


Measurement terminal	CH1: "G16-19" to "G16-9" CH2: "G16-18" to "G16-9"
Oscilloscope setting	CH1: 1 V/DIV, CH2: 1 V/DIV TIME: 40 μ s/DIV
Measurement condition	Ignition switch is at ON position

**Reference waveform No. 5**

Steering lock unit signal

(Signal (1) communicated between keyless start control module and steering lock unit when measurement condition described below applies)

Measurement terminal	CH1: "G16-29" to "G16-9"
Oscilloscope setting	CH1: 2 V/DIV TIME: 4 ms/DIV
Measurement condition	- Ignition knob switch of steering lock unit is pushed - Any one of door is opened - Request switch of each door is pushed


**Reference waveform No. 6**

Driver and passenger side door lock switch signals.

(This signal indicates door lock status.)

In case the position of driver and passenger side door lock is changed from the unlock to the lock.


Measurement terminal	Driver side door lock switch • CH1: "G16-33" to "G16-9" Passenger side door lock switch • CH2: "G16-37" to "G16-9"
Oscilloscope setting	CH1: 2 V/DIV CH2: 2 V/DIV TIME: 1 s/DIV
Measurement condition	Press lock side of manual door lock switch



10E-21 Keyless Start System:

In case the position of passenger side door lock is changed from the lock to the unlock when the position of driver and passenger side door is at the lock


Measurement terminal	Driver side door lock switch • CH1: "G16-33" to "G16-9" Passenger side door lock switch • CH2: "G16-37" to "G16-9"
Oscilloscope setting	CH1: 2 V/DIV CH2: 2 V/DIV TIME: 400 ms/DIV
Measurement condition	Driver door is at lock position and passenger side door is at unlock position




1. Lock signal	2. Unlock signal
----------------	------------------

In case the position of driver side door lock is changed from the lock to the unlock when the position of driver and passenger side door is at the lock.

Measurement terminal	Driver side door lock switch • CH1: "G16-33" to "G16-9" Passenger side door lock switch • CH2: "G16-37" to "G16-9"
Oscilloscope setting	CH1: 2 V/DIV CH2: 2 V/DIV TIME: 400 ms/DIV
Measurement condition	Driver door is at unlock position and passenger side door is at lock position



1. Lock signal	2. Unlock signal
----------------	------------------




1. Lock signal	2. Unlock signal
----------------	------------------

In case the position of driver and passenger side door lock is changed from the lock to the unlock.

Measurement terminal	Driver side door lock switch • CH1: "G16-33" to "G16-9" Passenger side door lock switch • CH2: "G16-37" to "G16-9"
Oscilloscope setting	CH1: 2 V/DIV CH2: 2 V/DIV TIME: 400 ms/DIV
Measurement condition	Driver door is at unlock position and passenger side door is at lock position

No DTC Detection After Performing DTC Check

Wiring Diagram



I7RW01A50004-02

[A]: Keyless start control module connector (viewed from harness side)	4. Ignition knob switch	8. Key indicator light
1. Keyless start control module	5. Key reminder switch	9. CAN junction connector
2. Steering lock unit	6. Driver side door request switch	
3. Steering lock solenoid	7. Combination meter	

Description

The keyless start control module detects DTC by using signals from the key reminder and driver side door request switches. The keyless start control module makes the key indicator light in the combination meter flash on and off by using CAN communication.

Troubleshooting

Step	Action	Yes	No
1	Combination meter power and ground circuit check 1) Turn ignition switch to ON position. <i>Do warning lights in combination meter other than key indicator light light up?</i>	Go to Step 2.	Check main fuse, circuit fuse, combination meter power and ground circuit.
2	Driver side door request switch and its circuit check 1) Check driver side door request switch and its circuit referring to "DTC No. 51 / No. 52 / No. 53: Driver Side / Passenger Side / Rear End Door / Trunk Lid Request Switch Failure". <i>Is it in good condition?</i>	Go to Step 3.	Repair or replace malfunction part.
3	Key reminder switch and its circuit check 1) Turn ignition switch to OFF position. 2) Disconnect connector from ignition switch. 3) Check key reminder switch for operation referring to "Ignition Switch Inspection in Section 9C". 4) If OK, check for open, short and high resistance in key reminder switch circuit. <i>Is it in good condition?</i>	Go to Step 4.	Repair or replace malfunction part.


10E-23 Keyless Start System:

Step	Action	Yes	No
4	Keyless start control module power and ground circuit check 1) Check keyless start control module power and ground circuit for condition referring to “Keyless Start Control Module Power and Ground Circuit Check”. <i>Is it in good condition?</i>	Go to Step 5.	Repair circuit.
5	CAN communication circuit check 1) Turn ignition switch to OFF position. 2) Disconnect connectors of all control modules communicating by means of CAN. 3) Check CAN communication circuit between control modules for open, short and high resistance. <i>Is each CAN communication circuit in good condition?</i>	Substitute a known-good keyless start control module and recheck.	Repair circuit.

Key Indicator Light Circuit Check (Key Indicator Light Doesn’t Light when Ignition Knob Switch is Pushed)

S7RW0CA504014

Wiring Diagram



I7RW01A50005-01

[A]: Keyless start control module connector (viewed from harness side)	5. Steering lock solenoid
1. Keyless start control module	6. Key reminder switch
2. Combination meter	7. Ignition knob switch
3. Key indicator light	8. CAN junction connector
4. Steering lock unit	9. Ignition knob switch signal circuit

Description

When the ignition knob switch is pushed, the key indicator light lights up in blue if you carry the remote controller registered in the keyless start control module and it lights in red if you carry the remote controller which has not been registered in the keyless start control module or if you carry no remote controller.


Troubleshooting

Step	Action	Yes	No
1	Combination meter power and ground circuit check 1) Turn ignition switch to ON position. <i>Do warning lights in combination meter other than key indicator light light up?</i>	Go to Step 2.	Check main fuse, circuit fuse, combination meter power and ground circuit.
2	Keyless start control module power and ground circuit check 1) Check keyless start control module power and ground circuit for condition referring to "Keyless Start Control Module Power and Ground Circuit Check". <i>Is it in good condition?</i>	Go to Step 3.	Repair circuit.
3	Steering lock unit ignition knob switch check 1) Check ignition knob switch of steering lock unit for operation referring to "Steering Lock Unit Inspection". <i>Is it in good condition?</i>	Go to Step 4.	Replace steering lock unit.
4	Wire harness check 1) Turn ignition switch to OFF position. 2) Disconnect connectors from keyless start control module, steering lock unit and combination meter. 3) Check for open, short and high resistance in following circuits. • Ignition knob switch signal circuit • Keyless start control module and combination meter CAN communication circuit <i>Is each circuit in good condition?</i>	Go to Step 5.	Repair circuit.
5	Keyless start system operation check 1) With remote controller of which ID code is registered in keyless start control module carried with you, try to turn ignition knob switch. <i>Can it be turned to any position other than "LOCK" position?</i>	Replace combination meter.	Substitute a known-good keyless start control module and recheck.

Keyless Start Control Module Power and Ground Circuit Check

S7RW0CA504015

Wiring Diagram



I7RW01A50006-02


[A]: Keyless start control module connector (viewed from harness side)	3. Circuit fuse	6. ACC signal circuit
1. Keyless start control module	4. Main fuse	7. IG ON signal circuit
2. Ignition switch	5. Power source circuit	8. Ground circuit

Troubleshooting

Step	Action	Yes	No
1	Fuse check 1) Turn ignition switch to OFF position. 2) Check circuit fuse and main fuse for condition. <i>Are fuses in good condition?</i>	Go to Step 2.	Replace fuse(s) and check for short.
2	Power supply circuit check 1) Disconnect connector from keyless start control module. 2) Check for proper connection to "Power source", "ACC signal" and "IG ON signal" terminal of keyless start control module connector. 3) If OK, measure voltage between following terminals. "Power source" terminal of keyless start control module connector and vehicle body ground with ignition switch is at OFF position "ACC signal" terminal of keyless start control module connector and vehicle body ground with ignition switch is at ACC position "IG ON signal" terminal of keyless start control module connector and vehicle body ground with ignition switch is at ON position <i>Is each terminal voltage is 10 – 14 V?</i>	Go to Step 3.	Repair defective power supply circuit.
3	Ground circuit check 1) Check for proper connection to "Ground" terminal of keyless start control module connector. 2) If OK, measure resistance between "Ground" terminal of keyless start control module connector and vehicle body ground. <i>Is resistance 1 Ω or less?</i>	Power and ground circuit is in good condition.	Repair ground circuit.

DTC No. 11: Communication Error with Steering Lock Unit

S7RW0CA504016

Wiring Diagram

I7RW01A50007-02

[A]: Keyless start control module connector (viewed from harness side)	3. Steering lock unit power supply circuit
1. Keyless start control module	4. Steering lock unit signal circuit
2. Steering lock unit	5. Steering lock unit ground circuit

DTC Detecting Condition and Trouble Area

DTC detecting condition	Trouble area
No communication is available between keyless start control module and steering lock unit.	- Steering lock unit and its circuit - Keyless start control module

DTC Confirmation Procedure

- 1) Clear DTC referring to "DTC Clearance".
- 2) Turn ignition knob switch pushing ignition knob switch.
- 3) Check DTC referring to "DTC Check".

DTC Troubleshooting

Step	Action	Yes	No
1	Was "Keyless Start System Check" performed?	Go to Step 2.	Go to "Keyless Start System Check".
2	Steering lock unit circuit check 1) Disconnect connector from keyless start control module. 2) Check for proper connection to "Steering lock unit power supply", "Steering lock unit signal" and "Steering lock unit ground" terminals of keyless start control module connector. 3) If OK, check for open, short and high resistance in following circuits. - Steering lock unit power supply circuit - Steering lock unit signal circuit - Steering lock unit ground circuit Is each circuit in good condition?	Go to Step 3.	Repair circuit.

10E-27 Keyless Start System:

Step	Action	Yes	No
3	Steering lock unit power supply voltage check 1) Connect connector to keyless start control module. 2) Measure voltage between "Steering lock unit power supply" terminal of steering lock unit connector and vehicle body ground. <i>Is voltage 4 – 6 V?</i>	Replace steering lock unit.	Substitute a known-good keyless start control module and recheck.

DTC No. 13 / No. 14: Release Signal Error from Steering Lock Unit / Steering Lock Unit Malfunction

S7RW0CA504017

DTC Detecting Condition and Trouble Area

DTC detecting condition	Trouble area
DTC No. 13: Although lock release signal is output to steering lock unit, no lock release signal is inputted from steering lock unit. (wire harness is normal) DTC No. 14: Although lock release signal is output to steering lock unit, steering lock is not released due to temperature rise of steering lock unit solenoid and no lock release signal is inputted. (wire harness is normal)	Steering lock unit

DTC Confirmation Procedure

- 1) Clear DTC referring to "DTC Clearance".
- 2) Turn ignition knob switch pushing ignition knob switch.
- 3) Check DTC referring to "DTC Check".

DTC Troubleshooting

Replace steering lock unit and recheck.

NOTE

Be sure to register the following code when a used keyless start control module is installed. Otherwise DTC No.13 is detected by keyless start control module though steering lock unit is normal.

- With immobilizer control system, ignition key transponder code is not registered in ECM.
- Without immobilizer control system, steering lock unit ID code is not registered in keyless start control module.

DTC No. 21 / No. 22: Internal Error of Keyless Start Control Module (EEPROM Reading Error) / (EEPROM Writing Error)

S7RW0CA504018

DTC Detecting Condition and Trouble Area

DTC detecting condition	Trouble area
DTC No. 21: Data cannot be read from memory in keyless start control module. DTC No. 22: Data cannot be written into memory in keyless start control module.	Keyless start control module

DTC Confirmation Procedure

- 1) Clear DTC referring to "DTC Clearance".
- 2) Turn ignition knob switch pushing ignition knob switch.
- 3) Push request switch of each door.
- 4) Check DTC referring to "DTC Check".

DTC Troubleshooting

Substitute a known-good keyless start control module and recheck.

DTC No. 31: Lost Communication with BCM

S7RW0CA504019

Refer to "Troubleshooting for CAN-DTC in Section 1A".


DTC No. 33: Control Module Communication Bus Off

S7RW0CA504020

Refer to "Troubleshooting for CAN-DTC in Section 1A".

DTC No. 51 / No. 52 / No. 53: Driver Side / Passenger Side / Rear End Door / Trunk Lid Request Switch Failure

S7RW0CA504021

Wiring Diagram

I7RW01A50009-02

[A]: Keyless start control module connector (viewed from harness side)	3. Passenger side door request switch
1. Keyless start control module	4. Rear end door / trunk lid request switch
2. Driver side door request switch	

DTC Detecting Condition and Trouble Area

DTC detecting condition	Trouble area
DTC No. 51: Input signal from driver side door request switch remains ON, unchanged for 10 minutes or longer. DTC No. 52: Input signal from passenger side door request switch remains ON, unchanged for 10 minutes or longer. DTC No. 53: Input signal from rear end door / trunk lid request switch remains ON, unchanged for 10 minutes or longer.	• Driver side door request switch and its circuit • Passenger side door request switch and its circuit • Rear end door / trunk lid request switch and its circuit • Keyless start control module

DTC Confirmation Procedure

- 1) Clear DTC referring to "DTC Clearance".
- 2) Push request switch of each door.
- 3) Check DTC referring to "DTC Check".

DTC Troubleshooting

Step	Action	Yes	No
1	Was "Keyless Start System Check" performed?	Go to Step 2.	Go to "Keyless Start System Check".


Step	Action	Yes	No
2	Request switch check 1) Check related door request switch for function referring to "Front Door (Driver and Passenger Side), Rear End Door / Trunk Lid Request Switch Inspection". <i>Is each switch in good condition?</i>	Go to Step 3.	Replace request switch.
3	Wire harness check 1) Disconnect connector from keyless start control module. 2) Check for open, short and high resistance in related door request switch circuit. <i>Is each circuit in good condition?</i>	Substitute a known-good keyless start control module and recheck.	Repair circuit.

Repair Instructions

Antennas and Request Switches Removal and Installation

S7RW0CA506001

Remove and install antennas and request switches referring to the following figures.



I6RW0BA50011-01

[A]: Front door antenna and request switch (included in outside door handle)	1. Outside handle : Antenna and request switch can not be removed from outside door handle
[B]: Center antenna	2. Parking brake lever
[C]: Rear end door / trunk lid antenna	3. Rear bumper
[D]: Trunk lid request switch (Sedan)	4. Trunk lid license garnish
[E]: Rear end door opener and request switch (Hatchback)	5. Rear end door license garnish
[F]: Luggage room antenna (Hatchback)	6. Tail end member trim
[G]: Trunk room antenna (Sedan)	7. High mount stop lamp

Front Door (Driver and Passenger Side), Rear End Door / Trunk Lid Request Switch Inspection

S7RW0CA506002


- 1) Remove front door trim, rear end door trim or trunk lid trim.
- 2) Disconnect request switch connector.
- 3) Check for continuity between terminals "1" and "2" at each switch position as shown below. If check result is not as specified, replace.

Request switch specification


ON position (request switch pushed): Continuity

OFF position (request switch released): No continuity

[A]




[B]



I6RW0BA50012-01

[C]



I6RW0BA50013-01

[A]: Front door request switch (driver and passenger side)

[B]: Rear end door request switch (Hatchback)

[C]: Trunk lid request switch (Sedan)

[D]: Request switch connector (viewed from harness side)

Steering Lock Unit Removal and Installation

S7RW0CA506003

For removal and installation, refer to "Steering Lock Assembly (Ignition Switch) Removal and Installation in Section 6B".

Steering Lock Unit Inspection

S7RW0CA506004


Check key reminder switch and ignition knob switch in steering lock unit for operation referring to "Ignition Switch Inspection in Section 9C".

Front Door Lock Switch Inspection

S7RW0CA506005

- 1) Remove door trim from door panel referring to Step 1) to 3) of "Front Door Glass Removal and Installation in Section 9E".
- 2) Check for continuity between terminals "1" and "2" at each switch position as shown below. If check result is not as specified, replace.

Door lock switch specification

LOCK position: No continuity
UNLOCK position: Continuity


I4RS0BA50029-01


[A]: Lock	[C]: Right side door lock switch
[B]: Unlock	[D]: Left side door lock switch

Keyless Start Control Module Removal and Installation

S7RW0CA506006

Removal

- 1) Disconnect negative cable at battery.
- 2) Remove glove box from instrument panel.
- 3) Disconnect connector from keyless start control module.
- 4) Remove keyless start control module mounting bolt and then remove keyless start control module (1) from steering support member (2).



I5RW0AA50016-01

Installation

For installation, reverse removal procedure.

If keyless start control module is replaced, register ID code of remote controller into keyless start control module, referring to "Registration Procedure for Remote Controller ID Code".

Remote Controller Inspection


S7RW0CA506007

Check that remote controller operation indicator light (3) lights up when lock (1) or unlock (2) button of remote controller is pushed.

If it doesn't light up in this check, replace battery and then recheck. If it doesn't light up even after battery replacement, replace remote controller.

NOTE

When remote controller transmits lock, unlock or panic signal, it makes operation indicator light light up.




I4RS0BA50031-01

Replacement of Remote Controller Battery

S7RW0CA506008

If remote controller operation indicator light fails to light up when lock or unlock button of remote controller is pushed, replace its battery as follows.

- 1) If ignition key (1) is inserted in remote controller, remove it.
- 2) With tip of flat blade screwdriver (2) put in slot (3) of remote controller (4), pry it open.




I4RS0BA50032-01

- 3) Remove battery (4) from lower case (5).

⚠ CAUTION

Use care not to allow grease or dirt to be attached on the printed circuit board and the battery.

- 4) Replace the battery (lithium disc-type CR 2032 or equivalent battery) so its (+) terminal faces on remote controller lower case.



1. Upper case	3. Printed circuit board
2. Rubber switch	

- 5) Install printed circuit board and rubber switch to upper case and then fit lower case securely.

NOTE

- To prevent theft, be sure to break the remote controller before discarding it.
- Dispose of the used battery properly according to applicable rules or regulations. Do not dispose of lithium batteries with ordinary household trash.

Registration Procedure for Remote Controller ID Code

S7RW0CA506009

NOTE

- It is possible to register up to 4 remote controllers in keyless start control module.
- Setting keyless start control module to ID code registration mode of remote controller will erase all remote controller ID codes that have been registered in keyless start control module.



Therefore, when registering remote controller ID codes in keyless start control module, have all of those to be registered ready and execute their registration at the same time.

- When registration of more than four remote controller ID codes is attempted, the oldest remote controller ID code will be erased and that inputted after the fourth one will be registered.
- When keyless start control module which was used in another vehicle has been installed, register the ID code of the remote controller to the keyless start control module first and then the following code.
 - With immobilizer control system, register the ignition key transponder code for the immobilizer control system in ECM. For registration procedure of that, refer to “Registration of the Ignition Key in Section 10C”.
 - Without immobilizer control system, register the steering lock unit ID code in keyless start control module. For registration procedure of that, refer to “Keyless Start Registration”.

10E-33 Keyless Start System:

If remote controller or keyless start control module is replaced or additional remote controller is necessary, register ID code(s) of remote controller.

- 1) Sit in driver seat and close all doors.
- 2) Check that door lock of driver seat is unlocked.
- 3) Insert ignition key (1) into ignition key cylinder.
- 4) Perform Steps a) through f) described below within 25 seconds after Step 3).
 - a) First push manual door lock switch (2) toward lock side (3) and then push it toward unlock side (4).
 - b) Repeat Step a) 2 more times.
 - c) Push lock side of manual door lock switch.
 - d) Remove ignition key from ignition key cylinder once and then insert it again.
 - e) Repeat Step d) 3 more times.
 - f) Start engine and wait for 3 seconds.



NOTE

When 60 seconds elapse after engine is started, the above process to enter registration mode will be cancelled. Therefore, be sure to proceed to the next step within 60 seconds.

- 5) Turn ignition switch to OFF position.
When ignition switch is turned to OFF position, buzzer sounds twice and door lock is activated from lock position to unlock position. This operation indicates that keyless start control module has entered registration mode.
- 6) Push lock or unlock button of remote controller within 30 seconds after Step 5) to be registered.
When lock or unlock button of remote controller is pushed, buzzer sounds twice, door lock is activated to lock position and then to unlock position. This operation indicates that remote controller ID code has been registered in keyless start control module. If an additional remote controller needs to be registered, repeat the procedure of Step 6) within 30 seconds after Step 5).
- 7) To end registration mode, remove ignition key from ignition key cylinder or turn it to ON position.
In case of vehicle equipped with immobilizer control system, if engine start function of keyless start system does not work after registration, check ECM if DTC P1615 is detected. If it is detected, go to "DTC P1615: Steering Lock Unit Communication Error in Section 10C". If it is not detected, perform registration procedure again.

Keyless Start Registration

S7RW0CA506010

In case of vehicle not equipped with immobilizer control system, register steering lock unit ID code in keyless start control module when keyless start control module which was used in another vehicle has been installed or steering lock unit was replaced, according to "Keyless start registration" of "Keyless Start System" under "Utility" of "Immobi and/or Keyless System" mode of SUZUKI scan tool (SUZUKI-SDT) referring to "SDT Diagnosis Software Operator's Manual".

Prepared by
SUZUKI MOTOR CORPORATION

1st Ed. Jul., 2007

31.5 mm

SUZUKI **SX4**

SUZUKI

SX4

SUZUKI MOTOR CORPORATION

VOL.
1 OF 2

SERVICE MANUAL

99500-80J10-01E

SERVICE MANUAL

RW420

VOLUME 1 OF 2

SUZUKI
Caring for Customers
99500-80J10-01E
(英)

30.5 mm

SUZUKI
SX4

SUZUKI

SX4

SUZUKI MOTOR CORPORATION

VOL.
2 OF 2

SERVICE MANUAL

99500-80J10-01E

SERVICE MANUAL

RW420

VOLUME 2 OF 2

SUZUKI
Caring for Customers
99500-80J10-01E
(英)