

5. Fail-Safe Function

The headlight beam level control ECU operates in the fail-safe mode if an abnormal condition such as those listed below has been detected, and illuminates the automatic headlight leveling system warning light in the combination meter.

Item	Abnormality Detection Condition	Description of Control
Headlight Leveling Actuator	Open or Short	Holds the beam at the position of the headlight leveling actuator when the abnormality has been detected.
Height Control Sensor	Signal Level Abnormality	Returns the beam to the headlight leveling actuator's initial set position if an abnormality has been detected higher than the initial set position.
		Holds the beam at the position of the headlight leveling actuator when an abnormality has been detected, if the abnormality has been detected lower than the initial set position.
Headlight Beam Level Control ECU	When an abnormal processing of the CPU has been detected.	Holds the beam at position of the headlight leveling actuator when the abnormality has been detected.