



1 COROLLA MATRIX




2 COROLLA MATRIX

COROLLA MATRIX (EM00F0U)




(Cont. next page)




Engine Control (2ZZ-GE)


* 3 : w/ Cruise Control



COROLLA MATRIX (EM00F0U)




(Cont. next page)




Engine Control (1ZZ-FE 4WD)


* 3 : w/ Cruise Control



4 COROLLA MATRIX (Cont' d)




(Cont. next page)



Engine Control (1ZZ-FE 2WD)

* 3 : M/T




(Cont. next page)


5 COROLLA MATRIX (Cont' d)


Engine Control (1ZZ-FE 2WD)


* 3 : M/T
* 4 : w/ VSC
* 5 : Shielded




- * 3 : M/T
- * 4 : w/ VSC
- * 5 : Shielded
- * 6 : w/o VSC w/ ABS









7 COROLLA MATRIX






Taillight and Illumination

* 3 : w/ Cigarette Lighter Illumination
* 4 : w/ AC 115 Volts Power Outlet




9 COROLLA MATRIX




10 COROLLA MATRIX

COROLLA MATRIX (EM00F0U)

299






11 COROLLA MATRIX (Cont' d)

Interior Light

- * 1 : w/ Moon Roof
- * 2 : w/o Moon Roof
- * 3 : w/ TVIP System
- * 4 : w/ Automatic Glare-Resistant EC Mirror
- * 5 : w/o Door Lock Control
- * 6 : w/o Automatic Glare-Resistant EC Mirror
- * 7 : w/ Door Lock Control
- * 8 : Separate Type Amplifier
- * 9 : Built-In Type Amplifier




(Cont. next page)


12 COROLLA MATRIX

Power Source

Electronically Controlled Transmission


- * 1 : 1ZZ-FE 2WD
- * 2 : 1ZZ-FE 4WD
- * 3 : 1ZZ-FE 4WD w/ Cruise Control







13 COROLLA MATRIX

COROLLA MATRIX (EM00F0U)







ABS (w/ VSC), TRAC, VSC and Tire Pressure Warning System (w/ VSC)




COROLLA MATRIX (EM00F0U)


14 COROLLA MATRIX (Cont' d)








16 COROLLA MATRIX (Cont' d)



Power Source

Front Wiper and Washer

Rear Wiper and Washer



(Cont. next page)


18 COROLLA MATRIX

Power Source

Door Lock Control


* 1 : w/ Power Window
 * 2 : w/o Power Window
 * 3 : w/ TVIP System

* 4 : Separate Type Amplifier
 * 5 : Built-In Type Amplifier
 * 6 : A/T




COROLLA MATRIX (EM00F0U)

Door Lock Control




COROLLA MATRIX (EM00F0U)

Wireless Door Lock Control




19 COROLLA MATRIX

COROLLA MATRIX (EM00F0U)




COROLLA MATRIX (EM00F0U)




21 COROLLA MATRIX

COROLLA MATRIX (EM00F0U)

319




22 COROLLA MATRIX



23 COROLLA MATRIX


COROLLA MATRIX (EM00F0U)

321



24 COROLLA MATRIX


OVERALL ELECTRICAL WIRING DIAGRAM



25 COROLLA MATRIX

COROLLA MATRIX (EM00F0U)


323



26 COROLLA MATRIX


324

COROLLA MATRIX (EM00F0U)



27 COROLLA MATRIX


COROLLA MATRIX (EM00F0U)



OVERALL ELECTRICAL WIRING DIAGRAM









Combination Meter

* 1 : w/o ABS
* 5 : w/ VSC
* 6 : w/o VSC w/ ABS




COROLLARY MATRIX (EM00F0U)

30 COROLLA MATRIX





- * 1 : 2ZZ-GE
- * 2 : 1ZZ-FE 4WD
- * 3 : 2ZZ-GE, 1ZZ-FE 4WD
- * 4 : 1ZZ-FE 2WD




2006 COROLLA MATRIX ELECTRICAL WIRING DIAGRAM SYSTEM CIRCUITS


	Page
ABS (w/ VSC)	186
ABS (w/o VSC)	194
Air Conditioning	236
Audio System (Built-In Type Amplifier)	222
Audio System (Separate Type Amplifier)	218
Automatic Glare-Resistant EC Mirror with Compass	138
Back-Up Light	120
Charging	56
Cigarette Lighter	130
Clock	216
Combination Meter	224
Cruise Control (1ZZ-FE 2WD)	180
Cruise Control (2ZZ-GE, 1ZZ-FE 4WD)	174
Door Lock Control	144
Electronically Controlled Transmission	168
Engine Control (1ZZ-FE 2WD)	82
Engine Control (1ZZ-FE 4WD)	70
Engine Control (2ZZ-GE)	58
Engine Immobiliser System	94
Front Fog Light	104
Front Wiper and Washer	122
Headlight	100
Heater	232
Horn	128
Ignition	54
Illumination	108
Interior Light	114
Key Reminder	208
Light Reminder	208
Moon Roof	166
Multiplex Communication System (CAN Bus)	98
Power Outlet (115V)	134
Power Outlet (12V)	132
Power Source	48
Power Window	140
Radiator Fan	230
Rear Window Defogger	214
Rear Wiper and Washer	124
Remote Control Mirror	136
Seat Belt Warning	210
Shift Lock	206
SRS	199
Starting	52
Stop Light	118
Taillight	108
Tire Pressure Warning System (w/ VSC)	186
Tire Pressure Warning System (w/o VSC)	194
TRAC	186
Turn Signal and Hazard Warning Light	106
TVIP System	160
VSC	186
Wireless Door Lock Control	152

F RELAY LOCATIONS

[Engine Compartment]




[Instrument Panel]



F RELAY LOCATIONS


[Body]



① : Engine Room R/B


○ : Engine Room J/B


Engine Compartment Left (See Page 20)



F RELAY LOCATIONS


 : Instrument Panel J/B	Lower Finish Panel (See Page 21)
--	----------------------------------






F RELAY LOCATIONS

[Instrument Panel J/B Inner Circuit]




(Cont. Next Page)


(Cont'd)



F RELAY LOCATIONS


③ : RH R/B	Right Side of the Instrument Panel Reinforcement (See Page 21)
○ : RH J/B	






F RELAY LOCATIONS

[RH J/B Inner Circuit]



② : ABS R/B


Near the Front Left Suspension Tower (See Page 20)




F RELAY LOCATIONS


 : Center J/B


Behind the Combination Meter (See Page 21)



[Center J/B Inner Circuit]

Power Source





Power Source

: Parts Location

Code	See Page	Code	See Page	Code	See Page
G2	34 (2ZZ-GE)	I11	39	J7	39
	36 (1ZZ-FE)	J2	39		

: Relay Blocks

Code	See Page	Relay Blocks (Relay Block Location)
1	23	Engine Room R/B (Engine Compartment Left)
3	28	RH R/B (Right Side of the Instrument Panel Reinforcement)

: Junction Block and Wire Harness Connector


Code	See Page	Junction Block and Wire Harness (Connector Location)
IA	25	Engine Room Main Wire and Instrument Panel J/B (Lower Finish Panel)
IB		
IF	25	Instrument Panel Wire and Instrument Panel J/B (Lower Finish Panel)
IH		
IM	24	
1A	23	Engine Wire and Engine Room J/B (Engine Compartment Left)
1B		
1C	23	Engine Room Main Wire and Engine Room J/B (Engine Compartment Left)
1D		

: Connector Joining Wire Harness and Wire Harness

Code	See Page	Joining Wire Harness and Wire Harness (Connector Location)
IA5	44	Engine Room Main Wire and Instrument Panel Wire (Instrument Panel Reinforcement LH)

: Ground Points

Code	See Page	Ground Points Location
IE	44	Behind Combination Meter
IG	44	Right Kick Panel



 : Parts Location

Code	See Page	Code	See Page	Code	See Page
C10	38	J6	A	39	
E3	A	38	J7	39	S3
I11	39	P1	37 (1ZZ-FE)	S6	B
J2	39		35 (2ZZ-GE)	T3	39
J5	B	39	37 (1ZZ-FE)		

 : Relay Blocks

Code	See Page	Relay Blocks (Relay Block Location)
1	23	Engine Room R/B (Engine Compartment Left)

 : Junction Block and Wire Harness Connector


Code	See Page	Junction Block and Wire Harness (Connector Location)
IF	25	Instrument Panel Wire and Instrument Panel J/B (Lower Finish Panel)
IH		
IL	24	
IM		
1A	23	Engine Wire and Engine Room J/B (Engine Compartment Left)

 : Connector Joining Wire Harness and Wire Harness

Code	See Page	Joining Wire Harness and Wire Harness (Connector Location)
IA2	44	Engine Room Main Wire and Instrument Panel Wire (Instrument Panel Reinforcement LH)
IA4		
IA5		
IG1	45	Engine Wire and Instrument Panel Wire (Blower Unit RH)
IG3		

 : Ground Points

Code	See Page	Ground Points Location
IE	44	Behind Combination Meter
IG	44	Right Kick Panel



 : Parts Location

Code	See Page	Code	See Page	Code	See Page
E3	38	I4	A 37 (1ZZ-FE)	J5	B 39
I2	A 37 (1ZZ-FE)		B 35 (2ZZ-GE)	J6	A 39
I3	B 35 (2ZZ-GE)	I5	A 37 (1ZZ-FE)	N1	35 (2ZZ-GE)
	A 37 (1ZZ-FE)		B 35 (2ZZ-GE)		37 (1ZZ-FE)
I3	B 35 (2ZZ-GE)	I11	39		

 : Relay Blocks

Code	See Page	Relay Blocks (Relay Block Location)
1	23	Engine Room R/B (Engine Compartment Left)

 : Junction Block and Wire Harness Connector


Code	See Page	Junction Block and Wire Harness (Connector Location)
IC	25	Engine Room Main Wire and Instrument Panel J/B (Lower Finish Panel)
IL	24	Instrument Panel Wire and Instrument Panel J/B (Lower Finish Panel)
IM		
1A	23	Engine Wire and Engine Room J/B (Engine Compartment Left)

 : Connector Joining Wire Harness and Wire Harness

Code	See Page	Joining Wire Harness and Wire Harness (Connector Location)
EA1	42 (2ZZ-GE)	Engine Wire and Engine Room Main Wire (Inside of the Engine Room R/B)
	43 (1ZZ-FE)	
IA5	44	Engine Room Main Wire and Instrument Panel Wire (Instrument Panel Reinforcement LH)

 : Ground Points

Code	See Page	Ground Points Location
ED	42 (2ZZ-GE)	Left Side of the Cylinder Head
	43 (1ZZ-FE)	



☐ : Parts Location

Code		See Page		Code		See Page		Code		See Page	
C11		38		G1	A	36 (1ZZ–FE)		I11		39	
D2		38		G2	B	34 (2ZZ–GE)		J3	A	39	
G1	A	34 (2ZZ–GE)				36 (1ZZ–FE)		J4	B	39	

☐ : Relay Blocks

Code	See Page	Relay Blocks (Relay Block Location)
1	23	Engine Room R/B (Engine Compartment Left)


☐ : Junction Block and Wire Harness Connector


Code	See Page	Junction Block and Wire Harness (Connector Location)
IG	25	Instrument Panel Wire and Instrument Panel J/B (Lower Finish Panel)
IK	24	
IL		
IM		
1A	23	Engine Wire and Engine Room J/B (Engine Compartment Left)
1B		
3B	29	Instrument Panel Wire and RH J/B (Right Side of the Instrument Panel Reinforcement)

☐ : Connector Joining Wire Harness and Wire Harness


Code	See Page	Joining Wire Harness and Wire Harness (Connector Location)
EA1	42 (2ZZ-GE)	Engine Wire and Engine Room Main Wire (Inside of the Engine Room R/B)
	43 (1ZZ-FE)	
IA5	44	Engine Room Main Wire and Instrument Panel Wire (Instrument Panel Reinforcement LH)
IG3	45	Engine Wire and Instrument Panel Wire (Blower Unit RH)


Engine Control for 2ZZ-GE







Engine Control for 2ZZ-GE





Engine Control for 2ZZ-GE






Wiring Diagram for 2000 Nissan Xterra 2.5L Engine

Legend:

- BR: Brown
- B: Black
- W: White
- W-B: White with Black
- V-W: Violet with White
- Y-R: Yellow with Red
- R-Y: Red with Yellow
- R-B: Red with Black
- W-B: White with Black
- EC: Engine Control
- IE: Ignition

Components and Connections:

- D 1 Data Link Connector 3:**
 - SIL (7) to L-R (3B)
 - TC (13) to P-B (4C)
 - WFSE (15) to P (4C)
 - SG (5) to BR (10) IG3
 - CG (4) to W-B
 - BAT (16) to R-B (7) IJ
- E 3(A), E 4(B), E 5(C), E 6(D) Engine Control Module:**
 - SIL (15) to L-R (3B)
 - TC (20) to P-B (4C)
 - WFSE (19) to P (4C)
 - E1 (5) to BR
 - KNK1 (1) to B
 - EKNK (2) to W
 - EOM (15) to W-B
 - SPD (17) to V-W
 - TACH (3) to B
 - THWO (14) to Y-R
 - W (11) to R-Y
- K 1 Knock Sensor (Bank 1):**
 - 1 to W
 - 2 to B
- J 3(A), J 4(B) Junction Connector:**
 - BR (8) IG3
 - BR (10) IG3
 - BR (11) W
 - BR (12) W-B
 - BR (13) W-B
 - BR (14) W-B
 - BR (15) W-B
 - BR (16) W-B
 - BR (17) W-B
 - BR (18) W-B
 - BR (19) W-B
 - BR (20) W-B
 - BR (21) W-B
 - BR (22) W-B
 - BR (23) W-B
 - BR (24) W-B
 - BR (25) W-B
 - BR (26) W-B
 - BR (27) W-B
 - BR (28) W-B
 - BR (29) W-B
 - BR (30) W-B
 - BR (31) W-B
 - BR (32) W-B
 - BR (33) W-B
 - BR (34) W-B
 - BR (35) W-B
 - BR (36) W-B
 - BR (37) W-B
 - BR (38) W-B
 - BR (39) W-B
 - BR (40) W-B
 - BR (41) W-B
 - BR (42) W-B
 - BR (43) W-B
 - BR (44) W-B
 - BR (45) W-B
 - BR (46) W-B
 - BR (47) W-B
 - BR (48) W-B
 - BR (49) W-B
 - BR (50) W-B
 - BR (51) W-B
 - BR (52) W-B
 - BR (53) W-B
 - BR (54) W-B
 - BR (55) W-B
 - BR (56) W-B
 - BR (57) W-B
 - BR (58) W-B
 - BR (59) W-B
 - BR (60) W-B
 - BR (61) W-B
 - BR (62) W-B
 - BR (63) W-B
 - BR (64) W-B
 - BR (65) W-B
 - BR (66) W-B
 - BR (67) W-B
 - BR (68) W-B
 - BR (69) W-B
 - BR (70) W-B
 - BR (71) W-B
 - BR (72) W-B
 - BR (73) W-B
 - BR (74) W-B
 - BR (75) W-B
 - BR (76) W-B
 - BR (77) W-B
 - BR (78) W-B
 - BR (79) W-B
 - BR (80) W-B
 - BR (81) W-B
 - BR (82) W-B
 - BR (83) W-B
 - BR (84) W-B
 - BR (85) W-B
 - BR (86) W-B
 - BR (87) W-B
 - BR (88) W-B
 - BR (89) W-B
 - BR (90) W-B
 - BR (91) W-B
 - BR (92) W-B
 - BR (93) W-B
 - BR (94) W-B
 - BR (95) W-B
 - BR (96) W-B
 - BR (97) W-B
 - BR (98) W-B
 - BR (99) W-B
 - BR (100) W-B
- J 2 Junction Connector:**
 - W-B (13) 4B
 - W-B (16) 4B
 - W-B (21) 4B



System Outline

The engine control system utilizes a microcomputer and maintains overall control of the engine, etc. An outline of engine control is given here.

1. Input Signals

(1) Engine coolant temp. signal system

The engine coolant temp. sensor detects the engine coolant temp. and has a built-in thermistor with a resistance which varies according to the engine coolant temp. Thus the engine coolant temp. is input as a control signal to TERMINAL THW of the engine control module.

(2) Intake air temp. signal system

The intake air temp. sensor is installed in the mass air flow meter and detects the intake air temp., which is input as a control signal to TERMINAL THA of the engine control module.

(3) Power steering oil pressure signal system

Power steering oil pressure is detected by the power steering oil pressure SW and is input as a control signal to TERMINAL PSW of the engine control module.

(4) RPM signal system

Camshaft position and crankshaft position are detected by the camshaft position sensor and crankshaft position sensor. Camshaft position is input as a control signal to TERMINAL G2 of the engine control module, and engine RPM is input into TERMINAL NE+.

(5) Throttle signal system

The throttle position sensor detects the throttle valve opening angle, which is input as a control signal to TERMINAL VTA of the engine control module.

(6) Vehicle speed signal system

The vehicle speed is detected by the ABS speed sensor and the signal is input to TERMINAL SPD of the engine control module via the comb. meter and the skid control ECU with actuator. (w/ ABS)

The vehicle speed is detected by the vehicle speed sensor installed in the transaxle and the signal is input to TERMINAL SPD of the engine control module via the comb. meter. (w/o ABS)

(7) A/C SW signal system

The operating voltage of the A/C SW is detected and is input as a control signal to TERMINAL A/CS of the engine control module.

(8) Battery signal system

Voltage is constantly applied to TERMINAL BATT of the engine control module. When the ignition SW is turned to on, voltage for engine control module operation is applied via the EFI relay to TERMINAL +B of the engine control module.

(9) Intake air volume signal system

Intake air volume is detected by the mass air flow meter, and is input as a control signal to TERMINAL VG of the engine control module.

(10) STA signal system

To confirm that the engine is cranking, the voltage applied to the starter motor during cranking is detected and is input as a control signal to TERMINAL STA of the engine control module.

(11) Oxygen sensor signal system

The oxygen density in the exhaust gases is detected and is input as a control signal into TERMINALS OX1A and OX1B of the engine control module. To maintain stable detection performance by the oxygen sensor, a heater is used for warming the sensor. The heater is also controlled by the engine control module (HT1A and HT1B).

(12) Engine knock signal system

Engine knocking is detected by the knock sensor (Bank 1) and input as a control signal to TERMINAL KNK1 of the engine control module.

(13) Electrical load signal system

When systems which cause a high electrical load such as the rear window defogger, taillight are turned on, a signal is input to TERMINALS ELS and ELS2 as a control signal.

2. Control System

* SFI system

The SFI system monitors the engine conditions through the signals, which are input from each sensor to the engine control module. Based on this data and the program memorized in the engine control module, the most appropriate fuel injection timing is decided and current is output to TERMINALS #10, #20, #30 and #40 of the engine control module, operating the injectors (to inject fuel). This is the system which finely controls the fuel injection in response to the driving conditions, through the engine control module.

* ESA system

The ESA system monitors the engine conditions using the signals, which are input to the engine control module from each sensor. Based on this data and the program memorized in the engine control module, the most appropriate ignition timing is decided and current is output to TERMINALS IGT1, IGT2, IGT3 and IGT4 of the engine control module. This output controls the ignition coil and igniter No. 1, No. 2, No. 3 and No. 4 to produce the most appropriate ignition timing for the driving conditions.

* IAC system

The IAC system increases the RPM and provides idle stability for fast idle-up when the engine is cold, and when the idle speed has dropped due to electrical load and so on. The engine control module evaluates the signals from each sensor, and outputs current to TERMINAL RSD to control the idle air control valve.

* Knock control system

Knock control system controls the gate based on the engine rotation speed and detects knocking by the peak value of the knock sensor (Bank 1) output during the gate open period, and then controls it to the most suitable ignition timing in proportion to the driving condition.

* Evaporaparge control system

This system leads the vapor stuck to the canister to the surge tank in order not to agitate the air fuel by adjusting the fuel injection volume.

The signal at this time will be output from TERMINAL PRG of the engine control module to VSV (Purge).

3. Diagnosis System

With the diagnosis system, when there is a malfunctioning in the engine control module signal system, the malfunction system is recorded in the memory. The malfunctioning system can be found by reading the display (Code) of the malfunction indicator lamp.

4. Fail-Safe System

When a malfunction occurs in any system, if there is a possibility of engine trouble being caused by continued control based on the signals from that system, the fail-safe system either controls the system by using the data (Standard values) recorded in the engine control module memory or else stops the engine.

○ : Parts Location

Code	See Page	Code	See Page	Code	See Page
A13	38	E6	D	J5	B
A21	34 (2ZZ-GE)	F10		J6	A
A22	34 (2ZZ-GE)	H5	B	J7	
A23	34 (2ZZ-GE)	H8	C	K1	35 (2ZZ-GE)
C1	B	I1		L4	41
C2	B	I2	B	M1	35 (2ZZ-GE)
C3	34 (2ZZ-GE)	I3	B	O3	35 (2ZZ-GE)
C4	B	I4	B	P2	35 (2ZZ-GE)
C10	38	I5	B	S1	B
C11	38	I6	B	S7	A
C12	38	I7		S7	B
C16	38	I8	B	T1	35 (2ZZ-GE)
D1	38	I9		T10	39
E2	34 (2ZZ-GE)	I11		V3	35 (2ZZ-GE)
E3	A	J2		V5	A
E4	B	J3	A	V9	35 (2ZZ-GE)
E5	C	J4	B		

Engine Control for 2ZZ-GE

: Relay Blocks

Code	See Page	Relay Blocks (Relay Block Location)
1	23	Engine Room R/B (Engine Compartment Left)
3	28	RH R/B (Right Side of the Instrument Panel Reinforcement)

: Junction Block and Wire Harness Connector


Code	See Page	Junction Block and Wire Harness (Connector Location)
IC	25	Engine Room Main Wire and Instrument Panel J/B (Lower Finish Panel)
ID	25	Floor Wire and Instrument Panel J/B (Lower Finish Panel)
IG	25	Instrument Panel Wire and Instrument Panel J/B (Lower Finish Panel)
IH		
II		
IJ		
IK	24	
IL		
IM		
1A	23	Engine Wire and Engine Room J/B (Engine Compartment Left)
3B	29	Instrument Panel Wire and RH J/B (Right Side of the Instrument Panel Reinforcement)
3C		
4B	32	Instrument Panel Wire and Center J/B (Behind the Combination Meter)
4C		


: Connector Joining Wire Harness and Wire Harness

Code	See Page	Joining Wire Harness and Wire Harness (Connector Location)
EA1	42 (2ZZ-GE)	Engine Wire and Engine Room Main Wire (Inside of the Engine Room R/B)
IA2	44	Engine Room Main Wire and Instrument Panel Wire (Instrument Panel Reinforcement LH)
IA4		
IA5		
IA6		
ID2	44	Instrument Panel Wire and Floor Wire (Left Kick Panel)
IG1	45	Engine Wire and Instrument Panel Wire (Blower Unit RH)
IG2		
IG3		


: Ground Points


Code	See Page	Ground Points Location
EB	42 (2ZZ-GE)	Front Left Suspension Tower
EC	42 (2ZZ-GE)	Left Side of the Cylinder Head
ED		
EJ	42 (2ZZ-GE)	Left Fender
EK	42 (2ZZ-GE)	Front Left Suspension Tower
IE	44	Behind Combination Meter
IG	44	Right Kick Panel
BH	46	Left Quarter Panel
BI	46	Right Quarter Panel







Engine Control for 1ZZ-FE (4WD)









System Outline

The engine control system utilizes a microcomputer and maintains overall control of the engine, etc. An outline of engine control is given here.

1. Input Signals

(1) Engine coolant temp. signal system

The engine coolant temp. sensor detects the engine coolant temp. and has a built-in thermistor with a resistance which varies according to the engine coolant temp. Thus the engine coolant temp. is input as a control signal to TERMINAL THW of the engine control module.

(2) Intake air temp. signal system

The intake air temp. sensor is installed in the mass air flow meter and detects the intake air temp., which is input as a control signal to TERMINAL THA of the engine control module.

(3) Power steering oil pressure signal system

Power steering oil pressure is detected by the power steering oil pressure SW and is input as a control signal to TERMINAL PSW of the engine control module.

(4) RPM signal system

Camshaft position and crankshaft position are detected by the camshaft position sensor and crankshaft position sensor. Camshaft position is input as a control signal to TERMINAL G2 of the engine control module, and engine RPM is input into TERMINAL NE+.

(5) Throttle signal system

The throttle position sensor detects the throttle valve opening angle, which is input as a control signal to TERMINAL VTA of the engine control module.

(6) Vehicle speed signal system

The vehicle speed is detected by the ABS speed sensor and the signal is input to TERMINAL SPD of the engine control module via the comb. meter and the skid control ECU with actuator. (w/ ABS)

The vehicle speed is detected by the vehicle speed sensor installed in the transaxle and the signal is input to TERMINAL SPD of the engine control module via the comb. meter. (w/o ABS)

(7) NSW signal system (A/T)

The Park/Neutral position SW detects whether the shift position is in neutral or not, and inputs a control signal to TERMINAL NSW of the engine control module.

(8) A/C SW signal system

The operating voltage of the A/C SW is detected and is input as a control signal to TERMINAL A/CS of the engine control module.

(9) Battery signal system

Voltage is constantly applied to TERMINAL BATT of the engine control module. When the ignition SW is turned to on, voltage for engine control module operation is applied via the EFI relay to TERMINAL +B of the engine control module.

(10) Intake air volume signal system

Intake air volume is detected by the mass air flow meter, and is input as a control signal to TERMINAL VG of the engine control module.

(11) STA signal system

To confirm that the engine is cranking, the voltage applied to the starter motor during cranking is detected and is input as a control signal to TERMINAL STA of the engine control module.

(12) Oxygen sensor signal system

The oxygen density in the exhaust gases is detected and is input as a control signal into TERMINALS OX1A and OX1B of the engine control module. To maintain stable detection performance by the oxygen sensor, a heater is used for warming the sensor. The heater is also controlled by the engine control module (HT1A and HT1B).

(13) Engine knock signal system

Engine knocking is detected by the knock sensor (Bank 1) and input as a control signal to TERMINAL KNK1 of the engine control module.

(14) Electrical load signal system

When systems which cause a high electrical load such as the rear window defogger, taillight are turned on, a signal is input to TERMINALS ELS and ELS2 as a control signal.

2. Control System

* SFI system

The SFI system monitors the engine conditions through the signals, which are input from each sensor to the engine control module. Based on this data and the program memorized in the engine control module, the most appropriate fuel injection timing is decided and current is output to TERMINALS #10, #20, #30 and #40 of the engine control module, operating the injectors (to inject fuel). This is the system which finely controls the fuel injection in response to the driving conditions, through the engine control module.

* ESA system

The ESA system monitors the engine conditions using the signals, which are input to the engine control module from each sensor. Based on this data and the program memorized in the engine control module, the most appropriate ignition timing is decided and current is output to TERMINALS IGT1, IGT2, IGT3 and IGT4 of the engine control module. This output controls the ignition coil and igniter No. 1, No. 2, No. 3 and No. 4 to produce the most appropriate ignition timing for the driving conditions.

* IAC system

The IAC system increases the RPM and provides idle stability for fast idle-up when the engine is cold, and when the idle speed has dropped due to electrical load and so on. The engine control module evaluates the signals from each sensor, and outputs current to TERMINAL RSD to control the idle air control valve.

* Knock control system

Knock control system controls the gate based on the engine rotation speed and detects knocking by the peak value of the knock sensor (Bank 1) output during the gate open period, and then controls it to the most suitable ignition timing in proportion to the driving condition.

* Evaporaparge control system

This system leads the vapor stuck to the canister to the surge tank in order not to agitate the air fuel by adjusting the fuel injection volume.

The signal at this time will be output from TERMINAL PRG of the engine control module to VSV (Purge).

3. Diagnosis System

With the diagnosis system, when there is a malfunctioning in the engine control module signal system, the malfunction system is recorded in the memory. The malfunctioning system can be found by reading the display (Code) of the malfunction indicator lamp.

4. Fail-Safe System

When a malfunction occurs in any system, if there is a possibility of engine trouble being caused by continued control based on the signals from that system, the fail-safe system either controls the system by using the data (Standard values) recorded in the engine control module memory or else stops the engine.

○ : Parts Location

Code	See Page	Code	See Page	Code	See Page
A13	38	H5	A	J6	A
C1	A	H8	B	J7	
C2	A	I1		K1	
C4	A	I2	A	L4	
C10	38	I3	A	M1	
C11	38	I4	A	P1	
C12	38	I5	A	P2	
C16	38	I6	A	S1	B
D1	38	I7		S7	A
E2	36 (1ZZ-FE)	I8	A		B
E3	A	I9		T1	
E4	B	I11		T10	
E5	C	J2		V1	
E6	D	J3	A	V5	B
F10	40	J4	B		
H5	A	J5	B		

○ : Relay Blocks

Code	See Page	Relay Blocks (Relay Block Location)
1	23	Engine Room R/B (Engine Compartment Left)
3	28	RH R/B (Right Side of the Instrument Panel Reinforcement)

Engine Control for 1ZZ-FE (4WD)



: Junction Block and Wire Harness Connector

Code	See Page	Junction Block and Wire Harness (Connector Location)
IC	25	Engine Room Main Wire and Instrument Panel J/B (Lower Finish Panel)
ID	25	Floor Wire and Instrument Panel J/B (Lower Finish Panel)
IG	25	Instrument Panel Wire and Instrument Panel J/B (Lower Finish Panel)
IH		
II		
IJ		
IK	24	
IL		
IM		
1A	23	Engine Wire and Engine Room J/B (Engine Compartment Left)
3B	29	Instrument Panel Wire and RH J/B (Right Side of the Instrument Panel Reinforcement)
3C		
4B	32	Instrument Panel Wire and Center J/B (Behind the Combination Meter)
4C		



: Connector Joining Wire Harness and Wire Harness


Code	See Page	Joining Wire Harness and Wire Harness (Connector Location)
EA1	43 (1ZZ-FE)	Engine Wire and Engine Room Main Wire (Inside of the Engine Room R/B)
IA2	44	Engine Room Main Wire and Instrument Panel Wire (Instrument Panel Reinforcement LH)
IA4		
IA5		
IA6		
ID2	44	Instrument Panel Wire and Floor Wire (Left Kick Panel)
IG1	45	Engine Wire and Instrument Panel Wire (Blower Unit RH)
IG3		
BI1	46	Floor Wire and Floor No.3 Wire (Near the Fuel Tank)





: Ground Points

Code	See Page	Ground Points Location
EB	43 (1ZZ-FE)	Front Left Suspension Tower
EC	43 (1ZZ-FE)	Left Side of the Cylinder Head
ED		
IE	44	Behind Combination Meter
IG	44	Right Kick Panel
BH	46	Left Quarter Panel
BI	46	Right Quarter Panel


Engine Control for 1ZZ-FE (2WD)









Engine Control for 1ZZ-FE (2WD)





Engine Control for 1ZZ-FE (2WD)



Engine Control for 1ZZ-FE (2WD)

System Outline

The engine control system utilizes a microcomputer and maintains overall control of the engine, etc. An outline of engine control is given here.

1. Input Signals

(1) Engine coolant temp. signal system

The engine coolant temp. sensor detects the engine coolant temp. and has a built-in thermistor with a resistance which varies according to the engine coolant temp. Thus the engine coolant temp. is input as a control signal to TERMINAL THW of the engine control module.

(2) Intake air temp. signal system

The intake air temp. sensor is installed in the mass air flow meter and detects the intake air temp., which is input as a control signal to TERMINAL THA of the engine control module.

(3) Power steering oil pressure signal system

Power steering oil pressure is detected by the power steering oil pressure SW and is input as a control signal to TERMINAL PSW of the engine control module.

(4) RPM signal system

Camshaft position and crankshaft position are detected by the camshaft position sensor and crankshaft position sensor. Camshaft position is input as a control signal to TERMINAL G2+ of the engine control module, and engine RPM is input into TERMINAL NE+.

(5) Throttle signal system

The throttle position sensor detects the throttle valve opening angle, which is input as a control signal to TERMINALS VTA1 and VTA2 of the engine control module.

(6) Vehicle speed signal system

The vehicle speed is detected by the ABS speed sensor and the signal is input to TERMINAL SPD of the engine control module via the comb. meter and the skid control ECU with actuator. (w/ ABS)

The vehicle speed is detected by the vehicle speed sensor installed in the transaxle and the signal is input to TERMINAL SPD of the engine control module via the comb. meter. (w/o ABS)

(7) NSW signal system (A/T)

The Park/Neutral position SW detects whether the shift position is in neutral or not, and inputs a control signal to TERMINAL NSW of the engine control module.

(8) A/C SW signal system

The operating voltage of the A/C SW is detected and is input as a control signal to TERMINAL A/CS of the engine control module.

(9) Battery signal system

Voltage is constantly applied to TERMINAL BATT of the engine control module. When the ignition SW is turned to on, voltage for engine control module operation is applied via the EFI relay to TERMINAL +B of the engine control module.

(10) Intake air volume signal system

Intake air volume is detected by the mass air flow meter, and is input as a control signal to TERMINAL VG of the engine control module.

(11) STA signal system

To confirm that the engine is cranking, the voltage applied to the starter motor during cranking is detected and is input as a control signal to TERMINAL STA of the engine control module.

(12) Oxygen sensor signal system

The oxygen density in the exhaust gases is detected and is input as a control signal into TERMINAL OX1B of the engine control module. To maintain stable detection performance by the oxygen sensor, a heater is used for warming the sensor. The heater is also controlled by the engine control module (HT1B).

(13) Engine knock signal system

Engine knocking is detected by the knock sensor (Bank 1) and input as a control signal to TERMINAL KNK1 of the engine control module.

(14) Electrical load signal system

When systems which cause a high electrical load such as the rear window defogger, taillight are turned on, a signal is input to TERMINALS ELS1 and ELS2 as a control signal.

(15) Air fuel ratio signal circuit

The air fuel ratio is detected and input as a control signal into TERMINAL A1A+ of the engine control module.

2. Control System

* SFI system

The SFI system monitors the engine conditions through the signals, which are input from each sensor to the engine control module. Based on this data and the program memorized in the engine control module, the most appropriate fuel injection timing is decided and current is output to TERMINALS #10, #20, #30 and #40 of the engine control module, operating the injectors (to inject fuel). This is the system which finely controls the fuel injection in response to the driving conditions, through the engine control module.

* ESA system

The ESA system monitors the engine conditions using the signals, which are input to the engine control module from each sensor. Based on this data and the program memorized in the engine control module, the most appropriate ignition timing is decided and current is output to TERMINALS IGT1, IGT2, IGT3 and IGT4 of the engine control module. This output controls the ignition coil and igniter No. 1, No. 2, No. 3 and No. 4 to produce the most appropriate ignition timing for the driving conditions.

* Knock control system

Knock control system controls the gate based on the engine rotation speed and detects knocking by the peak value of the knock sensor (Bank 1) output during the gate open period, and then controls it to the most suitable ignition timing in proportion to the driving condition.

* Evapopurge control system

This system leads the vapor stuck to the canister to the surge tank in order not to agitate the air fuel by adjusting the fuel injection volume.

The signal at this time will be output from TERMINAL PRG of the engine control module to VSV (Purge).

3. Diagnosis System

With the diagnosis system, when there is a malfunctioning in the engine control module signal system, the malfunction system is recorded in the memory. The malfunctioning system can be found by reading the display (Code) of the malfunction indicator lamp.

4. Fail-Safe System

When a malfunction occurs in any system, if there is a possibility of engine trouble being caused by continued control based on the signals from that system, the fail-safe system either controls the system by using the data (Standard values) recorded in the engine control module memory or else stops the engine.

○ : Parts Location

Code	See Page	Code	See Page	Code	See Page
A13	38	F10	40	J6	A 39
A24	36 (1ZZ-FE)	H8	A 39	J7	39
A25	38	I2	A 37 (1ZZ-FE)	K1	37 (1ZZ-FE)
C1	A 36 (1ZZ-FE)	I3	A 37 (1ZZ-FE)	L4	41
C2	A 36 (1ZZ-FE)	I4	A 37 (1ZZ-FE)	M1	37 (1ZZ-FE)
C4	A 36 (1ZZ-FE)	I5	A 37 (1ZZ-FE)	P1	37 (1ZZ-FE)
C10	38	I6	A 37 (1ZZ-FE)	P2	37 (1ZZ-FE)
C11	38	I7	37 (1ZZ-FE)	S1	A 37 (1ZZ-FE)
C12	38	I8	A 37 (1ZZ-FE)		B 37 (1ZZ-FE)
D1	38	I9	37 (1ZZ-FE)	S7	A 39
E2	36 (1ZZ-FE)	I11	39	T6	37 (1ZZ-FE)
E3	A 38	J2	39	T10	39
E4	B 38	J3	A 39	V1	37 (1ZZ-FE)
E5	C 38	J4	B 39	V5	A 37 (1ZZ-FE)
E6	D 38	J5	B 39		

○ : Relay Blocks

Code	See Page	Relay Blocks (Relay Block Location)
1	23	Engine Room R/B (Engine Compartment Left)
3	28	RH R/B (Right Side of the Instrument Panel Reinforcement)

Engine Control for 1ZZ-FE (2WD)



: Junction Block and Wire Harness Connector

Code	See Page	Junction Block and Wire Harness (Connector Location)
IC	25	Engine Room Main Wire and Instrument Panel J/B (Lower Finish Panel)
ID	25	Floor Wire and Instrument Panel J/B (Lower Finish Panel)
IG	25	Instrument Panel Wire and Instrument Panel J/B (Lower Finish Panel)
IH		
II		
IJ		
IK	24	
IL		
IM		
1A	23	Engine Wire and Engine Room J/B (Engine Compartment Left)
3B	29	Instrument Panel Wire and RH J/B (Right Side of the Instrument Panel Reinforcement)
3C		
4B	32	Instrument Panel Wire and Center J/B (Behind the Combination Meter)
4C		



: Connector Joining Wire Harness and Wire Harness


Code	See Page	Joining Wire Harness and Wire Harness (Connector Location)
EA1	43 (1ZZ–FE)	Engine Wire and Engine Room Main Wire (Inside of the Engine Room R/B)
IA2	44	Engine Room Main Wire and Instrument Panel Wire (Instrument Panel Reinforcement LH)
IA4	44	
IA5		
IA6		
IA7		
ID2	44	
IG1	45	Engine Wire and Instrument Panel Wire (Blower Unit RH)
IG3		




: Ground Points

Code	See Page	Ground Points Location
EB	43 (1ZZ-FE)	Front Left Suspension Tower
EC	43 (1ZZ-FE)	Left Side of the Cylinder Head
ED		
IE	44	Behind Combination Meter
IG	44	Right Kick Panel
BH	46	Left Quarter Panel
BI	46	Right Quarter Panel

Engine Immobiliser System





Engine Immobiliser System

: Parts Location

Code	See Page	Code	See Page	Code	See Page
D7	40	I11	39	S4	A 39
E3	A 38	J2	39		B 39
E4	B 38	J3	A 39	T9	39
E5	C 38	J4	B 39	T10	39
E6	D 38	J7	39	U1	39

: Relay Blocks

Code	See Page	Relay Blocks (Relay Block Location)
1	23	Engine Room R/B (Engine Compartment Left)

: Junction Block and Wire Harness Connector


Code	See Page	Junction Block and Wire Harness (Connector Location)
ID	25	Floor Wire and Instrument Panel J/B (Lower Finish Panel)
IH	25	Instrument Panel Wire and Instrument Panel J/B (Lower Finish Panel)
IL	24	
IM		
1A	23	
3A	29	Instrument Panel Wire and RH J/B (Right Side of the Instrument Panel Reinforcement)
3B		
4B	32	Instrument Panel Wire and Center J/B (Behind the Combination Meter)

: Connector Joining Wire Harness and Wire Harness

Code	See Page	Joining Wire Harness and Wire Harness (Connector Location)
EA1	42 (2ZZ-GE)	Engine Wire and Engine Room Main Wire (Inside of the Engine Room R/B)
	43 (1ZZ-FE)	
IA2	44	Engine Room Main Wire and Instrument Panel Wire (Instrument Panel Reinforcement LH)
IA5		
IG1	45	Engine Wire and Instrument Panel Wire (Blower Unit RH)
IG3		

: Ground Points

Code	See Page	Ground Points Location
EB	42 (2ZZ-GE)	Front Left Suspension Tower
	43 (1ZZ-FE)	
EC	42 (2ZZ-GE)	Left Side of the Cylinder Head
	43 (1ZZ-FE)	
ED	42 (2ZZ-GE)	
	43 (1ZZ-FE)	
IE	44	Behind Combination Meter
IG	44	Right Kick Panel



System Outline

Multiplex communication system (CAN) uses a serial communication protocol and communicates with a differential voltage. In this network system, TERMINALS CANH and CANL are used for communication between the ECUs and sensors, and excellent data communication speed and communication error detecting facility are provided.

This system is working for the following systems:

- * ABS
- * TRAC
- * VSC

○ : Parts Location


Code	See Page	Code	See Page	Code	See Page
D1	38	S1	A	37 (1ZZ-FE)	Y1
J13	39	S12	39		


□ : Connector Joining Wire Harness and Wire Harness

Code	See Page	Joining Wire Harness and Wire Harness (Connector Location)
IA7	44	Engine Room Main Wire and Instrument Panel Wire (Instrument Panel Reinforcement LH)

Headlight

* 1 : w/ VSC
* 2 : w/o VSC





Headlight

System Outline

The current is always flowing from the HEAD MAIN fuse to HEAD relay (Coil side) to TERMINAL 6 of the daytime running light relay and from ECU-B fuse to TERMINAL 3 of the daytime running light relay. The current is always flowing from the TAIL fuse to TAIL relay (Coil side) to TERMINAL 14 of the daytime running light relay.

When the ignition SW is turned on, the current flowing through the GAUGE fuse flows to TERMINAL 12 of the daytime running light relay.

1. Daytime Running Light Operation

When the engine is started, voltage generated at TERMINAL L of the generator is applied to TERMINAL 8 of the daytime running light relay. If the parking brake lever is pulled up (Parking brake SW on) at this time, the relay is not activated so the daytime running light system does not operate. If the parking brake lever is then released (Parking brake SW off), a signal is input to TERMINAL 11 of the relay.

This activates the daytime running light relay and the HEAD relay is turned to on, so the current flows from the HEAD MAIN fuse to the HEAD relay (Point side) to HEAD LH LWR, HEAD RH LWR fuses to TERMINAL 2 of the headlights to TERMINAL 1 to TERMINAL 1 of the daytime running light relay to TERMINAL 2 to GROUND, causing the headlights to light up (Headlights light up dimmer than normal brightness.). Once the daytime running light system operates and the headlights light up, the headlights remain on even if the parking brake lever is pulled up (Parking brake SW on).

If the engine stalls and the ignition SW remains on, the headlights remain light up even through current is no longer output from TERMINAL L of the generator. If the ignition SW is then turned off, the headlights go off.

If the engine is started with the parking brake lever released (Parking brake SW off), the daytime running light system operates and headlights light up when the engine starts.

2. Headlight Operation

When the light control SW is switched to Head position and the dimmer SW is set to Low position, causing the daytime running light relay and the HEAD relay to turn on, so the current flows from the HEAD MAIN fuse to HEAD relay (Coil side) to TERMINAL 6 of the daytime running light relay to TERMINAL 7 to TERMINAL 12 of the light control SW to TERMINAL 11 to GROUND. The current to HEAD relay (Point side) then flows to HEAD LH LWR, HEAD RH LWR fuses to TERMINAL 2 of the headlights (Low) to TERMINAL 1 to TERMINAL 1 of the daytime running light relay to TERMINAL 2 to GROUND, causing the headlights to light up at normal intensity.

When the light control SW is switched to Head position and the dimmer SW is set to High position, the signal from the dimmer SW is input to the daytime running light relay. This activates the daytime running light relay and the HEAD relay is turned on, so the current flows from the HEAD MAIN fuse to HEAD relay (Point side) to TERMINAL 1 of the DIMMER relay to TERMINAL 2 to TERMINAL 13 of the daytime running light relay, activating the DIMMER relay. This causes current to flow from TERMINAL 3 of the DIMMER relay to TERMINAL 5 to HEAD LH UPR, HEAD RH UPR fuses to TERMINAL 2 of the headlights (High) to TERMINAL 1 to GROUND, causing the headlights to light up at high beam and the high beam indicator light to light up.

When the dimmer SW is switched to Flash position, the signal from the dimmer SW is input to the daytime running light relay. This activates the daytime running light relay and the HEAD relay is turned on, so the current flows from the HEAD MAIN fuse to HEAD relay (Point side) to TERMINAL 1 of the DIMMER relay to TERMINAL 2 to TERMINAL 13 of the daytime running light relay, activating the DIMMER relay, and also flows from the HEAD LH UPR, HEAD RH UPR fuses to TERMINAL 2 of the headlights to TERMINAL 1 to GROUND, causing the headlights to light up at high beam and the high beam indicator light to light up.

3. Automatic Light Control Operation (USA)

When the daytime running light is operating and the Automatic control sensor detects a decrease in the ambient light, the automatic light control operation starts. At the same time, daytime running light relay is activated, so current flows from the TAIL fuse to the TAIL relay (Coil side) to TERMINAL 14 of the daytime running light relay, and the HEAD MAIN fuse to the HEAD relay (Coil side) to TERMINAL 6 of the daytime running light relay, activating both the TAIL relay and the HEAD relay, so that the taillights and headlights light up.

When the automatic light control sensor detects an increase in the ambient light, the ignition SW is turned to off, the light control SW is turned to Head position, and the automatic light control operation stops.



: Parts Location

Code	See Page	Code	See Page	Code	See Page
A18	38	H1	34 (2ZZ-GE)	J1	37 (1ZZ-FE)
B2	34 (2ZZ-GE)		36 (1ZZ-FE)	J2	39
	36 (1ZZ-FE)	H2	34 (2ZZ-GE)	P4	39
C11	38		36 (1ZZ-FE)	S1	A 37 (1ZZ-FE)
C12	38	H3	34 (2ZZ-GE)		B 35 (2ZZ-GE)
D2	38		36 (1ZZ-FE)		37 (1ZZ-FE)
G1	34 (2ZZ-GE)	H4	34 (2ZZ-GE)		
	36 (1ZZ-FE)		36 (1ZZ-FE)		

 : **Relay Blocks**

Code	See Page	Relay Blocks (Relay Block Location)
1	23	Engine Room R/B (Engine Compartment Left)
3	28	RH R/B (Right Side of the Instrument Panel Reinforcement)

 : **Junction Block and Wire Harness Connector**

Code	See Page	Junction Block and Wire Harness (Connector Location)
IC	25	Engine Room Main Wire and Instrument Panel J/B (Lower Finish Panel)
IG	25	Instrument Panel Wire and Instrument Panel J/B (Lower Finish Panel)
IH		
IL	24	
3B	29	Instrument Panel Wire and RH J/B (Right Side of the Instrument Panel Reinforcement)
3C		
4B	32	Instrument Panel Wire and Center J/B (Behind the Combination Meter)
4C		


 : **Connector Joining Wire Harness and Wire Harness**

Code	See Page	Joining Wire Harness and Wire Harness (Connector Location)
IA2	44	Engine Room Main Wire and Instrument Panel Wire (Instrument Panel Reinforcement LH)
IA4		
IA5		
IA6		
IE1	45	Instrument Panel Wire and Instrument Panel No.4 Wire (Behind the Combination Meter)
IG3	45	Engine Wire and Instrument Panel Wire (Blower Unit RH)

 : **Ground Points**

Code	See Page	Ground Points Location
EA	42 (2ZZ-GE)	Front Right Fender
	43 (1ZZ-FE)	
EB	42 (2ZZ-GE)	Front Left Suspension Tower
	43 (1ZZ-FE)	
IE	44	Behind Combination Meter

Front Fog Light



 : Parts Location

Code	See Page	Code	See Page	Code	See Page
C12	38	F1	36 (1ZZ-FE)	J2	39
D2	38	F2	34 (2ZZ-GE)		
F1	34 (2ZZ-GE)		36 (1ZZ-FE)		

 : Relay Blocks

Code	See Page	Relay Blocks (Relay Block Location)
1	23	Engine Room R/B (Engine Compartment Left)

 : Junction Block and Wire Harness Connector

Code	See Page	Junction Block and Wire Harness (Connector Location)
IG	25	Instrument Panel Wire and Instrument Panel J/B (Lower Finish Panel)
IH		
3B	29	Instrument Panel Wire and RH J/B (Right Side of the Instrument Panel Reinforcement)
3C		

 : Connector Joining Wire Harness and Wire Harness


Code	See Page	Joining Wire Harness and Wire Harness (Connector Location)
IA4	44	Engine Room Main Wire and Instrument Panel Wire (Instrument Panel Reinforcement LH)
IA5		

 : Ground Points

Code	See Page	Ground Points Location
EA	42 (2ZZ-GE)	Front Right Fender
	43 (1ZZ-FE)	
EB	42 (2ZZ-GE)	Front Left Suspension Tower
	43 (1ZZ-FE)	
IE	44	Behind Combination Meter

Turn Signal and Hazard Warning Light

* 1 : w/ Wireless Door Lock Control
* 2 : w/o Wireless Door Lock Control



 : Parts Location

Code	See Page	Code	See Page	Code	See Page
C11	38	F4	36 (1ZZ-FE)	J9	B 40
C12	38	H7	39	R9	41
F3	34 (2ZZ-GE)	J2	39	R10	41
	36 (1ZZ-FE)	J7	39	T2	39
F4	34 (2ZZ-GE)	J8	A 40		

 : Relay Blocks

Code	See Page	Relay Blocks (Relay Block Location)
1	23	Engine Room R/B (Engine Compartment Left)

 : Junction Block and Wire Harness Connector


Code	See Page	Junction Block and Wire Harness (Connector Location)
IC	25	Engine Room Main Wire and Instrument Panel J/B (Lower Finish Panel)
ID	25	Floor Wire and Instrument Panel J/B (Lower Finish Panel)
IG	25	Instrument Panel Wire and Instrument Panel J/B (Lower Finish Panel)
IH		
IK	24	Instrument Panel Wire and Instrument Panel J/B (Lower Finish Panel)
IL		
3A	29	Instrument Panel Wire and RH J/B (Right Side of the Instrument Panel Reinforcement)
3B		
3C		
4B	32	Instrument Panel Wire and Center J/B (Behind the Combination Meter)


 : Connector Joining Wire Harness and Wire Harness

Code	See Page	Joining Wire Harness and Wire Harness (Connector Location)
IA4	44	Engine Room Main Wire and Instrument Panel Wire (Instrument Panel Reinforcement LH)


 : Ground Points

Code	See Page	Ground Points Location
EA	42 (2ZZ-GE)	Front Right Fender
	43 (1ZZ-FE)	
EB	42 (2ZZ-GE)	Front Left Suspension Tower
	43 (1ZZ-FE)	
IE	44	Behind Combination Meter
IG	44	Right Kick Panel
BH	46	Left Quarter Panel
BI	46	Right Quarter Panel






Taillight and Illumination



- * 1 : Separate Type Amplifier
- * 2 : Built-In Type Amplifier
- * 3 : w/ Cigarette Lighter Illumination
- * 4 : w/ AC 115 Volts Power Outlet



Taillight and Illumination

: Parts Location

Code	See Page	Code		See Page	Code		See Page
A7	38	F4		36(1ZZ–FE)	M2		39
A9	38	H7		39	R6		39
B5	38	J1		35(2ZZ–GE)	R8		39
C9	38			37(1ZZ–FE)	R9		41
C11	38	J2		39	R10		41
C12	38	J7		39	R16	A	39
C17	38	J8	A	40		B	39
D2	38	J9	B	40	R17	C	39
F3	34(2ZZ–GE)	J11		40	T8		39
	36(1ZZ–FE)	L1		41			
F4	34(2ZZ–GE)	L2		41			

: Relay Blocks

Code	See Page	Relay Blocks (Relay Block Location)
1	23	Engine Room R/B (Engine Compartment Left)
3	28	RH R/B (Right Side of the Instrument Panel Reinforcement)

: Junction Block and Wire Harness Connector

Code	See Page	Junction Block and Wire Harness (Connector Location)
IC	25	Engine Room Main Wire and Instrument Panel J/B (Lower Finish Panel)
ID	25	Floor Wire and Instrument Panel J/B (Lower Finish Panel)
IG	25	Instrument Panel Wire and Instrument Panel J/B (Lower Finish Panel)
IH		
IL	24	
3A	29	Instrument Panel Wire and RH J/B (Right Side of the Instrument Panel Reinforcement)
3B		
4B	32	Instrument Panel Wire and Center J/B (Behind the Combination Meter)
4C		


: Connector Joining Wire Harness and Wire Harness

Code	See Page	Joining Wire Harness and Wire Harness (Connector Location)
BC2	46	Back Door No.1 Wire and Floor Wire (Left Quarter Panel)
BF1	46	Back Door No.1 Wire and Back Door No.2 Wire (Back Panel LH)
BF2		

: Ground Points


Code	See Page	Ground Points Location
EA	42 (2ZZ-GE)	Front Right Fender
	43 (1ZZ-FE)	
EB	42 (2ZZ-GE)	Front Left Suspension Tower
	43 (1ZZ-FE)	
IE	44	Behind Combination Meter
IF		
IG	44	Right Kick Panel
BH	46	Left Quarter Panel
BI	46	Right Quarter Panel

Interior Light




- * 1 : w/ Moon Roof
- * 2 : w/ Automatic Glare-Resistant EC Mirror
- * 3 : w/o Automatic Glare-Resistant EC Mirror
- * 4 : w/o Moon Roof

I12(A) Integration Relay



Interior Light

- * 3 : w/o Automatic Glare-Resistant EC Mirror
- * 4 : w/o Moon Roof
- * 5 : w/o Door Lock Control
- * 6 : w/ Door Lock Control
- * 7 : Separate Type Amplifier
- * 8 : Built-in Type Amplifier



 : Parts Location

Code	See Page	Code	See Page	Code	See Page
B6	40	D10	40	J7	39
C11	38	G5	40	J11	40
D5	40	I12	A 39	L3	41
D7	40	I13	40	M3	41
D8	40	I14	40		
D9	40	J2	39		

 : Relay Blocks

Code	See Page	Relay Blocks (Relay Block Location)
1	23	Engine Room R/B (Engine Compartment Left)

 : Junction Block and Wire Harness Connector


Code	See Page	Junction Block and Wire Harness (Connector Location)
IC	25	Engine Room Main Wire and Instrument Panel J/B (Lower Finish Panel)
ID	25	Floor Wire and Instrument Panel J/B (Lower Finish Panel)
IE	25	Roof Wire and Instrument Panel J/B (Lower Finish Panel)
IF	25	Instrument Panel Wire and Instrument Panel J/B (Lower Finish Panel)
IG		
IH		
IK		
IL	24	
4B	32	Instrument Panel Wire and Center J/B (Behind the Combination Meter)
4C		

 : Connector Joining Wire Harness and Wire Harness

Code	See Page	Joining Wire Harness and Wire Harness (Connector Location)
IK1	45	Roof Wire and Instrument Panel Wire (Instrument Panel Reinforcement LH)
IL2	45	Floor Wire and Instrument Panel Wire (Right Kick Panel)
BC2	46	Back Door No.1 Wire and Floor Wire (Left Quarter Panel)
BF2	46	Back Door No.1 Wire and Back Door No.2 Wire (Back Panel LH)

 : Ground Points

Code	See Page	Ground Points Location
IE	44	Behind Combination Meter
IG	44	Right Kick Panel
BH	46	Left Quarter Panel



 : Parts Location

Code		See Page	Code		See Page	Code		See Page
H9		40	R9		41	S7	B	39
J8	A	40	R10		41			
J9	B	40	S7	A	39			

 : Junction Block and Wire Harness Connector


Code	See Page	Junction Block and Wire Harness (Connector Location)
IC	25	Engine Room Main Wire and Instrument Panel J/B (Lower Finish Panel)
ID	25	Floor Wire and Instrument Panel J/B (Lower Finish Panel)

 : Connector Joining Wire Harness and Wire Harness

Code	See Page	Joining Wire Harness and Wire Harness (Connector Location)
BC1	46	Back Door No.1 Wire and Floor Wire (Left Quarter Panel)

 : Ground Points

Code	See Page	Ground Points Location
BH	46	Left Quarter Panel
BI	46	Right Quarter Panel



 : Parts Location

Code	See Page	Code	See Page	Code	See Page
B1	34 (2ZZ-GE)	J3	39	P1	37 (1ZZ-FE)
	36 (1ZZ-FE)	J8 A	40	R9	41
C11	38	J9 B	40	R10	41
J2	39	J10	40		

 : Junction Block and Wire Harness Connector

Code	See Page	Junction Block and Wire Harness (Connector Location)
ID	25	Floor Wire and Instrument Panel J/B (Lower Finish Panel)
IG	25	Instrument Panel Wire and Instrument Panel J/B (Lower Finish Panel)
IK	24	
3B	29	Instrument Panel Wire and RH J/B (Right Side of the Instrument Panel Reinforcement)
4B	32	Instrument Panel Wire and Center J/B (Behind the Combination Meter)

 : Connector Joining Wire Harness and Wire Harness


Code	See Page	Joining Wire Harness and Wire Harness (Connector Location)
IG3	45	Engine Wire and Instrument Panel Wire (Blower Unit RH)

 : Ground Points

Code	See Page	Ground Points Location
IE	44	Behind Combination Meter
BH	46	Left Quarter Panel
BI	46	Right Quarter Panel

Front Wiper and Washer

* 1 : w/ Intermittent Volume SW
* 2 : w/o Intermittent Volume SW



System Outline

With the ignition SW turned on, the current flows to TERMINAL 8 of the front wiper and washer SW, TERMINAL 2 of the front wiper motor through the WIPER fuse, and the current flows to TERMINAL 2 of the washer motor through the WASHER fuse.

1. Low Speed Position

With the front wiper SW turned to LO position, the current flows from TERMINAL 8 of the front wiper and washer SW to TERMINAL 7 to TERMINAL 1 of the front wiper motor to TERMINAL 5 to GROUND and causes to the front wiper motor to run at low speed.

2. High Speed Position

With the front wiper SW turned to HI position, the current flows from TERMINAL 8 of the front wiper and washer SW to TERMINAL 9 to TERMINAL 4 of the front wiper motor to TERMINAL 5 to GROUND and causes to the wiper motor to run at high speed.

3. INT Position

With the front wiper SW turned to INT position, the wiper relay operates and the current which is connected by relay function flows from TERMINAL 8 of the front wiper and washer SW to TERMINAL 5 to GROUND. This flow of current operates the intermittent circuit and the current flows from TERMINAL 8 of the front wiper and washer SW to TERMINAL 7 to TERMINAL 1 of the front wiper motor to TERMINAL 5 to GROUND and the functions.

The intermittent operation is controlled by the charge/discharge function of the condenser installed in the relay, and the intermittent time is controlled by a time control SW (w/ intermittent volume SW) to change the charging time of the condenser.

4. MIST Position

With the front wiper SW turned to MIST position, the current flows from TERMINAL 8 of the front wiper and washer SW to TERMINAL 7 to TERMINAL 1 of the front wiper motor to TERMINAL 5 to GROUND and causes to the front wiper motor to run at low speed.

5. Washer Continuous Operation

With the front washer SW turned to on, the current flows from TERMINAL 2 of the front washer motor to TERMINAL 1 to TERMINAL 4 of the front wiper and washer SW to TERMINAL 5 to GROUND and causes to the washer motor to run, and the window washer jet operates. This causes the current to flow to washer continuous operation circuit in TERMINAL 8 of the front wiper and washer SW to TERMINAL 7 to TERMINAL 1 of the front wiper motor to TERMINAL 5 to GROUND and the washer operates continuously.

○ : Parts Location

Code	See Page	Code	See Page	Code	See Page
C14	38	F6	34 (2ZZ-GE)	J1	37 (1ZZ-FE)
F5	34 (2ZZ-GE)		36 (1ZZ-FE)	J2	39
	36 (1ZZ-FE)	J1	35 (2ZZ-GE)		

○ : Junction Block and Wire Harness Connector


Code	See Page	Junction Block and Wire Harness (Connector Location)
IC	25	Engine Room Main Wire and Instrument Panel J/B (Lower Finish Panel)
IL	24	Instrument Panel Wire and Instrument Panel J/B (Lower Finish Panel)

□ : Connector Joining Wire Harness and Wire Harness

Code	See Page	Joining Wire Harness and Wire Harness (Connector Location)
IA2	44	Engine Room Main Wire and Instrument Panel Wire (Instrument Panel Reinforcement LH)

▽ : Ground Points

Code	See Page	Ground Points Location
EB	42 (2ZZ-GE)	Front Left Suspension Tower
	43 (1ZZ-FE)	
IE	44	Behind Combination Meter



Rear Wiper and Washer

System Outline

When the ignition SW is turned on and glass hatch is closed, the current flows through the WASHER fuse to TERMINAL 2 of the rear washer motor, the current flows through the RR WIPER fuse to IG relay (Point side) to TERMINAL 7 of the junction SW and TERMINAL 3 of the rear wiper relay.

1. Rear Wiper Normal Operation

When the ignition SW is turned on, glass hatch is closed and rear wiper SW turned to ON position, the current flows through the TERMINAL 3 of the rear wiper relay to TERMINAL 6 to TERMINAL 2 of the rear wiper SW to TERMINAL 5 to GROUND. As a result, the rear wiper relay is operated, and the current flows through the TERMINAL 3 of the rear wiper relay to TERMINAL 4 to TERMINAL 3 of the junction SW to rear wiper motor to TERMINAL 1 of the junction SW to GROUND, causing the motor to operate the rear wiper.

2. Rear Wiper Intermittent Operation

When the ignition SW is turned on, glass hatch is closed and rear wiper SW turned to INT position, the current flows through the TERMINAL 3 of the rear wiper relay to TERMINAL 2 to TERMINAL 1 of the rear wiper SW to TERMINAL 5 to GROUND. As a result, the intermittent circuit of the relay operates and the rear wiper motor operates.

3. Washer Operation

With the ignition SW is turned on, glass hatch is closed and rear washer SW turned to ON and washer position, when the rear wiper SW is turned further, the current flows through the WASHER fuse to TERMINAL 2 of the rear washer motor to TERMINAL 1 to TERMINAL 3 of the rear washer SW to TERMINAL 5 to GROUND, so that the rear washer motor rotates and the window washer emits a water, only while the switch is fully turned.

With the ignition SW turned on and the rear wiper and washer SW turned to OFF position, when the washer is turned ON (to Wiper OFF side), current flows as above so that the rear washer motor rotates and the window washer emits water as well as the wiper operates.

○ : Parts Location

Code	See Page	Code	See Page	Code	See Page
C14	38	J1	35 (2ZZ-GE)	J12	40
D4	38		37 (1ZZ-FE)	R3	35 (2ZZ-GE)
D18	38	J2	39		37 (1ZZ-FE)
G5	40	J10	40	R13	41
I10	39	J11	40		

○ : Junction Block and Wire Harness Connector

Code	See Page	Junction Block and Wire Harness (Connector Location)
IC	25	Engine Room Main Wire and Instrument Panel J/B (Lower Finish Panel)
ID	25	Floor Wire and Instrument Panel J/B (Lower Finish Panel)
IG	25	Instrument Panel Wire and Instrument Panel J/B (Lower Finish Panel)
3B	29	Instrument Panel Wire and RH J/B (Right Side of the Instrument Panel Reinforcement)
4C	32	Instrument Panel Wire and Center J/B (Behind the Combination Meter)


□ : Connector Joining Wire Harness and Wire Harness

Code	See Page	Joining Wire Harness and Wire Harness (Connector Location)
IA2	44	Engine Room Main Wire and Instrument Panel Wire (Instrument Panel Reinforcement LH)
ID1	44	Instrument Panel Wire and Floor Wire (Left Kick Panel)
ID2		
BC1	46	Back Door No.1 Wire and Floor Wire (Left Quarter Panel)
BC2		
BF1	46	Back Door No.1 Wire and Back Door No.2 Wire (Back Panel LH)
BF2		

▽ : Ground Points

Code	See Page	Ground Points Location
IE	44	Behind Combination Meter
BH	46	Left Quarter Panel

- * 1 : w/ Wireless Door Lock Control
- * 2 : w/o Wireless Door Lock Control
- * 3 : w/ TVIP System



☐ : Parts Location

Code	See Page	Code	See Page	Code	See Page
C13	38	H6	36 (1ZZ-FE)		
H6	34 (2ZZ-GE)	T3	39		

☐ : Relay Blocks

Code	See Page	Relay Blocks (Relay Block Location)
1	23	Engine Room R/B (Engine Compartment Left)


☐ : Junction Block and Wire Harness Connector

Code	See Page	Junction Block and Wire Harness (Connector Location)
4A	32	Instrument Panel Wire and Center J/B (Behind the Combination Meter)

☐ : Connector Joining Wire Harness and Wire Harness

Code	See Page	Joining Wire Harness and Wire Harness (Connector Location)
IA4	44	Engine Room Main Wire and Instrument Panel Wire (Instrument Panel Reinforcement LH)

Cigaratte Lighter



 : Parts Location

Code	See Page	Code	See Page	Code	See Page
C8	38	J2	39		

 : Junction Block and Wire Harness Connector


Code	See Page	Junction Block and Wire Harness (Connector Location)
IF	25	Instrument Panel Wire and Instrument Panel J/B (Lower Finish Panel)
3A	29	Instrument Panel Wire and RH J/B (Right Side of the Instrument Panel Reinforcement)

 : Ground Points

Code	See Page	Ground Points Location
IE	44	Behind Combination Meter

Power Outlet for 12V

* 1 : w/o Cigarette Lighter



 : Parts Location

Code	See Page	Code	See Page	Code	See Page
C8	38	J7	39		
J2	39	P6	39		

 : Relay Blocks

Code	See Page	Relay Blocks (Relay Block Location)
3	28	RH R/B (Right Side of the Instrument Panel Reinforcement)

 : Junction Block and Wire Harness Connector

Code	See Page	Junction Block and Wire Harness (Connector Location)
IF	25	Instrument Panel Wire and Instrument Panel J/B (Lower Finish Panel)
IH		
3A	29	Instrument Panel Wire and RH J/B (Right Side of the Instrument Panel Reinforcement)


 : Connector Joining Wire Harness and Wire Harness

Code	See Page	Joining Wire Harness and Wire Harness (Connector Location)
IJ1	45	Console Wire and Instrument Panel Wire (Front Side of the Parking Brake Lever)

 : Ground Points

Code	See Page	Ground Points Location
IE	44	Behind Combination Meter
IG	44	Right Kick Panel

Power Outlet for 115V



 : Parts Location

Code	See Page	Code	See Page	Code	See Page
J2	39	M2	39	V6	39
J7	39	P5	39		

 : Relay Blocks

Code	See Page	Relay Blocks (Relay Block Location)
3	28	RH R/B (Right Side of the Instrument Panel Reinforcement)


 : Junction Block and Wire Harness Connector

Code	See Page	Junction Block and Wire Harness (Connector Location)
IG	25	Instrument Panel Wire and Instrument Panel J/B (Lower Finish Panel)
IH		
3A	29	Instrument Panel Wire and RH J/B (Right Side of the Instrument Panel Reinforcement)
3B		
4B	32	Instrument Panel Wire and Center J/B (Behind the Combination Meter)

 : Ground Points

Code	See Page	Ground Points Location
IE	44	Behind Combination Meter
IG	44	Right Kick Panel

Remote Control Mirror



 : Parts Location

Code	See Page	Code	See Page	Code	See Page
J2	39	R14	41		
R7	39	R15	41		

 : Junction Block and Wire Harness Connector

Code	See Page	Junction Block and Wire Harness (Connector Location)
IF	25	Instrument Panel Wire and Instrument Panel J/B (Lower Finish Panel)
3A	29	Instrument Panel Wire and RH J/B (Right Side of the Instrument Panel Reinforcement)
3C		
4B	32	Instrument Panel Wire and Center J/B (Behind the Combination Meter)


 : Connector Joining Wire Harness and Wire Harness

Code	See Page	Joining Wire Harness and Wire Harness (Connector Location)
IC3	44	Front Door LH Wire and Instrument Panel Wire (Left Kick Panel)
IH1	45	Front Door RH Wire and Instrument Panel Wire (Right Kick Panel)

 : Ground Points

Code	See Page	Ground Points Location
IE	44	Behind Combination Meter

Automatic Glare-Resistant EC Mirror with Compass



 : Parts Location

Code	See Page	Code	See Page	Code	See Page
I13	40				

 : Junction Block and Wire Harness Connector

Code	See Page	Junction Block and Wire Harness (Connector Location)
IE	25	Roof Wire and Instrument Panel J/B (Lower Finish Panel)


 : Connector Joining Wire Harness and Wire Harness

Code	See Page	Joining Wire Harness and Wire Harness (Connector Location)
IK1	45	Roof Wire and Instrument Panel Wire (Instrument Panel Reinforcement LH)


 : Ground Points

Code	See Page	Ground Points Location
IE	44	Behind Combination Meter

Power Window



* 1 : Separate Type Amplifier
* 2 : Built-In Type Amplifier



System Outline

When the ignition SW is turned on, the current flows through the GAUGE fuse to TERMINAL 1 of the P/W relay to TERMINAL 2 to GROUND. This activates the relay and the current flows through the POWER fuse to TERMINAL 5 of the relay to TERMINAL 3 to TERMINAL B of the power window master SW, TERMINAL 4 of the power window control SW front RH and TERMINAL 3 of the power window control SW rear LH, RH.

1. Manual Operation (Driver's Window)

With the ignition SW turned on and with the power window master SW (Front LH) in Up position, the current flowing to TERMINAL B of the power window master SW flows to TERMINAL DU of the master SW to TERMINAL 4 of the power window motor to TERMINAL 5 to TERMINAL DD of the master SW to TERMINAL E to GROUND and rotates the power window motor in the up direction. The window ascends only while the SW is being pulled. In down operation, the flows of current from TERMINAL B of the power window master SW to TERMINAL DD to TERMINAL 5 of the motor to TERMINAL 4 to TERMINAL DU of the master SW to TERMINAL E to GROUND, flowing in the opposite direction to manual up operation and rotating the motor in reverse, thus opening the window.

2. Auto Down Operation (Driver's Window)

When the front LH window control SW in the power window master SW is pushed strongly on the down side, current flows from TERMINAL B of the master SW to TERMINAL DD to TERMINAL 5 of the power window motor to TERMINAL 4 to TERMINAL DU of the master SW to TERMINAL E to GROUND. Because the hold circuit inside the master SW keeps the relay on the down side activated, the power window motor continues operating even if the power window master SW is released. When the driver's window is fully opened, the hold circuit turns off and the relay on the down side turns off, and auto down operation is completed.

3. Stopping of Auto Down Operation (Driver's Window)

When the master SW (Front LH) is pulled to the up side during auto down operation, a ground circuit opens in the master SW and current does not flow from TERMINAL DU of the master SW to TERMINAL E, so the motor stops, causing auto down operation to stop. If the master SW is pulled continuously, the motor rotates in the up direction in manual up operation.

4. Manual Operation (Front RH Window)

With the power window control SW (Front RH) pulled to the up side, current flowing from TERMINAL 4 of the power window control SW flows to TERMINAL 3 to TERMINAL 4 of the power window motor to TERMINAL 5 to TERMINAL 1 of the power window control SW to TERMINAL 2 to TERMINAL PD of the master SW to TERMINAL E to GROUND and rotates the power window motor (Front RH) in the up direction. Up operation continues only while the power window control SW is pulled to the up side. When the window descends, the current flowing to the motor flows in the opposite direction, and the motor rotates in reverse. When the window lock SW is pushed to the lock side, the ground circuit to the passenger's window becomes open. As a result, even if Open/Close operation of the passenger's window is attempted, the current from TERMINAL E of the power window master SW is not grounded and the motor does not rotate, so the passenger's window can not be operated and window lock occurs.

5. Manual Operation (Rear LH, Rear RH Window)

With the power window control SW (Rear LH, rear RH) pulled to the up side, current flowing from TERMINAL 3 of the power window control SW flows to TERMINAL 4 to TERMINAL 5 of the power window motor to TERMINAL 4 to TERMINAL 2 of the power window control SW to TERMINAL 1 to TERMINAL RLD, RRD of the master SW to TERMINAL E to GROUND and rotates the power window motor (Rear LH, rear RH) in the up direction. Up operation continues only while the power window control SW is pulled to the up side. When the window descends, the current flowing to the motor flows in the opposite direction, and the motor rotates in reverse. When the window lock SW is pushed to the lock side, the ground circuit to the passenger's window becomes open. As a result, even if Open/Close operation of the passenger's window is attempted, the current from TERMINAL E of the power window master SW is not grounded and the motor does not rotate, so the passenger's window can not be operated and window lock occurs.

○ : Parts Location

Code	See Page	Code	See Page	Code	See Page
D14	40	P8	41	P12	41
J2	39	P9	41	P13	41
J7	39	P10	41		
P7	41	P11	41		



: Junction Block and Wire Harness Connector

Code	See Page	Junction Block and Wire Harness (Connector Location)
ID	25	Floor Wire and Instrument Panel J/B (Lower Finish Panel)
IF	25	Instrument Panel Wire and Instrument Panel J/B (Lower Finish Panel)
IG		
IH		
4B	32	Instrument Panel Wire and Center J/B (Behind the Combination Meter)



: Connector Joining Wire Harness and Wire Harness


Code	See Page	Joining Wire Harness and Wire Harness (Connector Location)
IC1	44	Front Door LH Wire and Instrument Panel Wire (Left Kick Panel)
IC2		
ID1	44	Instrument Panel Wire and Floor Wire (Left Kick Panel)
IH2	45	Front Door RH Wire and Instrument Panel Wire (Right Kick Panel)
IL2	45	Floor Wire and Instrument Panel Wire (Right Kick Panel)
BA1	46	Rear Door LH Wire and Floor Wire (Left Center Pillar)
BB1	46	Rear Door RH Wire and Instrument Panel Wire (Right Center Pillar)
BG1	46	Rear Door RH Wire and Floor Wire (Right Center Pillar)




: Ground Points

Code	See Page	Ground Points Location
IE	44	Behind Combination Meter
IG	44	Right Kick Panel


Door Lock Control



- * 1 : w/ Power Window
- * 2 : w/o Power Window
- * 3 : Separate Type Amplifier
- * 4 : Built-In Type Amplifier
- * 5 : A/T





Door Lock Control



- * 3 : Separate Type Amplifier
- * 4 : Built-In Type Amplifier
- * 5 : A/T

I12(A)
Integration Relay





System Outline

The current always flows to TERMINAL 1 of the integration relay through the DOOR fuse.

1. Manual Lock Operation

When the door lock control SW or door key lock and unlock SW are operated to Lock position, a lock signal is input to TERMINAL (A) 9 or (A) 7 of the integration relay and causes the relay to function. The current flows from TERMINAL 1 of the relay to TERMINAL 2 to the door lock motors to TERMINALS (A) 1 and 3 of the relay to TERMINAL 9 to GROUND and the door lock motors locks the door.

2. Manual Unlock Operation

When the door lock control SW or door key lock and unlock SW are operated to Unlock position, an unlock signal is input to TERMINAL (A) 8, (A) 6 or (A) 5 of the integration relay and causes the relay to function. The current flows from TERMINAL 1 of the relay to TERMINALS (A) 1 and 3 to the door lock motors to TERMINAL 2 of the relay to TERMINAL 9 to GROUND and the door lock motors unlocks the door.

3. Double Operation Unlock Operation

When the door key lock and unlock SW LH is turned to the unlock side, only the driver's door is unlocked. By turning the door key lock and unlock SW LH to the unlock side, a signal is input to TERMINAL (A) 6 of the relay, and if the signal is input again within 3 seconds by turning the SW to the unlock side again, current flows from TERMINAL 3 of the integration relay to the door lock motors to TERMINAL 2 of the relay to TERMINAL 9 to GROUND, causing the door lock motors to operate and unlock the doors.

4. Ignition Key Reminder Operation

* Operating door lock knob (Operation of door lock motors)

With the ignition key in the cylinder (Unlock warning SW on), when the door is opened and locked using door lock knob (Door lock motor), the door is locked once but each door is unlocked soon by the function of the relay. As a result, the current flows from TERMINAL 1 of the integration relay to TERMINALS (A) 1 and 3 to the door lock motors to TERMINAL 2 of the relay to TERMINAL 9 to GROUND and unlocks all the doors.

* Operating door lock control SW or door key lock and unlock SW

With the ignition key in the cylinder (Unlock warning SW on), when the door is opened and locked using door lock control SW or key SW, the door is locked once but each door is unlocked by the function of SW contained in motors, and the signal is input to TERMINAL (A) 19 of the relay. According to this input signal, the current flows from TERMINAL 1 of the relay to TERMINALS (A) 1 and 3 to the door lock motors to TERMINAL 2 of the relay to TERMINAL 9 to GROUND and unlocks all the doors.

* In case of key less lock

With the ignition the key in the cylinder (Unlock warning SW on), when the unlock function is disturbed for example pushing the door lock knob etc., the door holds on lock condition. After closing the door, door courtesy SW inputs the signal into TERMINAL 5 or 6 or (A) 13 of the integration relay. By this input signal, the relay works and current flows from TERMINAL 1 of the relay to TERMINALS (A) 1 and 3 to the door lock motors to TERMINAL 2 of the relay to TERMINAL 9 to GROUND and unlocks all the doors.

5. Glass Hatch Open Operation

When the glass hatch opener SW on, the ignition SW at OFF position or the ignition SW at ON position and the vehicle speed is less than approx. 16 km/h (9.6 mph), the glass hatch is opened.

○ : Parts Location

Code	See Page	Code	See Page	Code	See Page
B6	40	D15	40	J6	A 39
B7	40	D16	40	J7	39
C11	38	D17	40	J8	A 40
D5	40	G4	39	J10	40
D7	40	G5	40	J11	40
D8	40	I12	A 39	P1	37 (1ZZ-FE)
D9	40	J1	35 (2ZZ-GE)	S1	A 37 (1ZZ-FE)
D10	40		37 (1ZZ-FE)		B 35 (2ZZ-GE)
D11	40	J2	39		37 (1ZZ-FE)
D12	40	J3	A 39	U1	39
D13	B 40	J4	B 39	V1	37 (1ZZ-FE)
D14	A 40	J5	B 39		

Door Lock Control

: Relay Blocks

Code	See Page	Relay Blocks (Relay Block Location)
1	23	Engine Room R/B (Engine Compartment Left)

: Junction Block and Wire Harness Connector


Code	See Page	Junction Block and Wire Harness (Connector Location)
IC	25	Engine Room Main Wire and Instrument Panel J/B (Lower Finish Panel)
ID	25	Floor Wire and Instrument Panel J/B (Lower Finish Panel)
IF	25	Instrument Panel Wire and Instrument Panel J/B (Lower Finish Panel)
IG		
IH		
IJ		
IK	24	
IL		
3A	29	Instrument Panel Wire and RH J/B (Right Side of the Instrument Panel Reinforcement)
3B		
4A	32	Instrument Panel Wire and Center J/B (Behind the Combination Meter)
4C		

: Connector Joining Wire Harness and Wire Harness


Code	See Page	Joining Wire Harness and Wire Harness (Connector Location)
EA1	42 (2ZZ-GE)	Engine Wire and Engine Room Main Wire (Inside of the Engine Room R/B)
	43 (1ZZ-FE)	
IA6	44	Engine Room Main Wire and Instrument Panel Wire (Instrument Panel Reinforcement LH)
IC1	44	Front Door LH Wire and Instrument Panel Wire (Left Kick Panel)
IC3		
ID2	44	Instrument Panel Wire and Floor Wire (Left Kick Panel)
IG3	45	Engine Wire and Instrument Panel Wire (Blower Unit RH)
IH1	45	Front Door RH Wire and Instrument Panel Wire (Right Kick Panel)
IH2		
II1	45	Instrument Panel Wire and Floor Wire (Under the Instrument Panel Center)
IL2	45	Floor Wire and Instrument Panel Wire (Right Kick Panel)
BA1	46	Rear Door LH Wire and Floor Wire (Left Center Pillar)
BB1	46	Rear Door RH Wire and Instrument Panel Wire (Right Center Pillar)
BC1	46	Back Door No.1 Wire and Floor Wire (Left Quarter Panel)
BC2		
BF1	46	Back Door No.1 Wire and Back Door No.2 Wire (Back Panel LH)
BF2		
BG1	46	Rear Door RH Wire and Floor Wire (Right Center Pillar)

: Ground Points


Code	See Page	Ground Points Location
EC	42 (2ZZ-GE)	Left Side of the Cylinder Head
	43 (1ZZ-FE)	
IE	44	Behind Combination Meter
IG	44	Right Kick Panel
BH	46	Left Quarter Panel



- * 1 : w/ Power Window
- * 2 : w/o Power Window
- * 3 : Separate Type Amplifier
- * 4 : Built-In Type Amplifier
- * 5 : A/T





Wireless Door Lock Control



- * 3 : Separate Type Amplifier
- * 4 : Built-In Type Amplifier
- * 5 : A/T

112(A)
Integration Relay





System Outline

Door lock control (Lock and unlock) and panic control (TVIP alarm and flash) is performed by remote control, without the ignition key inserted in the door key cylinder, using low-power electrical waves emitted by a transmitter.

1. Wireless Door Lock or Unlock Normal Operation

With the ignition key not inserted into the ignition key cylinder (Unlock warning SW off) and all the doors completely closed, when the lock or unlock button (Transmitter) is pushed, the door control receiver receives the electrical waves from the transmitter, and sends a signal to the integration relay causing it to operate.

As a result, the integration relay judges whether the door is locked or unlocked based on the signal from the door lock motor and door unlock detection SW, and sends a signal to switch the condition from lock to unlock or vice versa, causing the door lock motor to operate.

2. Visual Confirmation of Lock or Unlock

If all doors indicate that they are locked after the lock command, parking lights and taillights will flash once. If any door indicates that it is open after the unlock command, parking lights and taillights will flash twice.

3. Wireless Door Unlock Operation

Pushing the unlock button (Transmitter) once, driver's door is unlocked. Furthermore, pushing the button again within 3 seconds, the other doors are unlocked.

4. Automatic Lock Operation

With the ignition key not inserted into the ignition key cylinder (Unlock warning SW off) and all the doors completely closed, after pushing the button (Transmitter) to unlock all the doors, if a door is not opened within 30 seconds, all the doors will be automatically relocked.

5. Glass Hatch Open Operation

With the ignition key not inserted into the ignition key cylinder, when the hatch button (Transmitter) is pushed, the door control receiver receives the electrical waves from the transmitter, and sends a signal to the integration relay causing it to operate.

As a result, the glass hatch is opened.

6. Wireless Control Stop Function

If a door is open (Door courtesy SW on), a signal is input from the door courtesy SW to the integration relay stopping wireless door lock or unlock.

If the ignition key is in the ignition key cylinder (Unlock warning SW on), the unlock warning SW inputs a signal to the integration relay stopping wireless door lock or unlock.

7. Repeat Function

In case an appropriate lock detection signal is not received after outputting a lock signal when pushing the lock button (Transmitter), 1 seconds later, the integration relay output the lock signal again.

8. Remote Panic Operation

Panic will function when doors are locked or unlocked, open or closed. When the panic button (Transmitter) is pushed once, theft alarm sounds and headlights and taillights flash. Then, the panic or the unlock button (Transmitter) is pushed once more, sounding and flashing will stop. Panic will not function when ignition key is in ignition key cylinder.

○ : Parts Location

Code	See Page	Code	See Page	Code	See Page
B6	40	D12	40	J2	39
D2	38	D13	B	J7	39
D5	40	D14	A	J8	A
D6	40	D15	40	J9	B
D7	40	D16	40	J10	40
D8	40	D17	40	J11	40
D9	40	G4	39	T2	39
D10	40	G5	40	U1	39
D11	40	I12	A		

○ : Relay Blocks

Code	See Page	Relay Blocks (Relay Block Location)
1	23	Engine Room R/B (Engine Compartment Left)

Wireless Door Lock Control



: Junction Block and Wire Harness Connector

Code	See Page	Junction Block and Wire Harness (Connector Location)
IC	25	Engine Room Main Wire and Instrument Panel J/B (Lower Finish Panel)
ID	25	Floor Wire and Instrument Panel J/B (Lower Finish Panel)
IF	25	Instrument Panel Wire and Instrument Panel J/B (Lower Finish Panel)
IH		
IJ		
IK	24	
3C	29	Instrument Panel Wire and RH J/B (Right Side of the Instrument Panel Reinforcement)
4A	32	Instrument Panel Wire and Center J/B (Behind the Combination Meter)




: Connector Joining Wire Harness and Wire Harness

Code	See Page	Joining Wire Harness and Wire Harness (Connector Location)
IA2	44	Engine Room Main Wire and Instrument Panel Wire (Instrument Panel Reinforcement LH)
IA4		
IC1	44	Front Door LH Wire and Instrument Panel Wire (Left Kick Panel)
IC3		
ID2	44	Instrument Panel Wire and Floor Wire (Left Kick Panel)
IH1	45	Front Door RH Wire and Instrument Panel Wire (Right Kick Panel)
IH2		
IL2	45	Floor Wire and Instrument Panel Wire (Right Kick Panel)
BA1	46	Rear Door LH Wire and Floor Wire (Left Center Pillar)
BB1	46	Rear Door RH Wire and Instrument Panel Wire (Right Center Pillar)
BC1	46	Back Door No.1 Wire and Floor Wire (Left Quarter Panel)
BC2		
BF1	46	Back Door No.1 Wire and Back Door No.2 Wire (Back Panel LH)
BF2		
BG1	46	Rear Door RH Wire and Floor Wire (Right Center Pillar)





: Ground Points

Code	See Page	Ground Points Location
IE	44	Behind Combination Meter
IG	44	Right Kick Panel
BH	46	Left Quarter Panel




T 3
TVIP ECU






- * 1 : Separate Type Amplifier
- * 2 : Built-In Type Amplifier

I12(A) Integration Relay





 : Parts Location

Code	See Page	Code	See Page	Code	See Page	
B6	40	G3	39	J11	40	
C10	38	G5	40	L3	41	
D2	38	H6	34 (2ZZ-GE)	P1	37 (1ZZ-FE)	
D5	40		36 (1ZZ-FE)	S3	35 (2ZZ-GE)	
D7	40	I11	39		37 (1ZZ-FE)	
D8	40	I12	A	S4	A	39
D9	40	I14	40	S6	39	
D10	40	J2	39	T2	39	
D11	40	J6	39	T3	39	
D12	40	J7	39	U1	39	

 : Relay Blocks

Code	See Page	Relay Blocks (Relay Block Location)
1	23	Engine Room R/B (Engine Compartment Left)

 : Junction Block and Wire Harness Connector


Code	See Page	Junction Block and Wire Harness (Connector Location)
IC	25	Engine Room Main Wire and Instrument Panel J/B (Lower Finish Panel)
ID	25	Floor Wire and Instrument Panel J/B (Lower Finish Panel)
IE	25	Roof Wire and Instrument Panel J/B (Lower Finish Panel)
IF	25	Instrument Panel Wire and Instrument Panel J/B (Lower Finish Panel)
IG		
IH		
IK		
IL	24	Instrument Panel Wire and Instrument Panel J/B (Lower Finish Panel)
IM		
1A	23	Engine Wire and Engine Room J/B (Engine Compartment Left)
3A	29	Instrument Panel Wire and RH J/B (Right Side of the Instrument Panel Reinforcement)
3C		
4A	32	Instrument Panel Wire and Center J/B (Behind the Combination Meter)

 : Connector Joining Wire Harness and Wire Harness

Code	See Page	Joining Wire Harness and Wire Harness (Connector Location)
IA2	44	Engine Room Main Wire and Instrument Panel Wire (Instrument Panel Reinforcement LH)
IA4		
IA5		
IC1	44	Front Door LH Wire and Instrument Panel Wire (Left Kick Panel)
IC3		
IG1	45	Engine Wire and Instrument Panel Wire (Blower Unit RH)
IG3		
IH1	45	Front Door RH Wire and Instrument Panel Wire (Right Kick Panel)
IH2		
IL2	45	Floor Wire and Instrument Panel Wire (Right Kick Panel)
BC2	46	Back Door No.1 Wire and Floor Wire (Left Quarter Panel)
BF2	46	Back Door No.1 Wire and Back Door No.2 Wire (Back Panel LH)

 : Ground Points

Code	See Page	Ground Points Location
IE	44	Behind Combination Meter
IG	44	Right Kick Panel
BH	46	Left Quarter Panel



System Outline

The moon roof can be operated when the ignition SW is turned to ON position.

1. Slide Open Operation

The moon roof fully opens automatically by pressing the slide open button of the moon roof control SW once. If the moon roof control switch is pressed again when the moon roof is operating, the movement of the moon roof stops.

The operation of slide open is not worked when the moon roof at tilt up position.

2. Slide Close Operation

If you keep pressing the slide close button of the moon roof control SW when the moon roof is open, the moon roof closes half and stops the operation once. If you keep pressing the slide close once again, the moon roof fully closes.

3. Tilt Up Operation

If you press the tilt up button of the moon roof control SW, the moon roof is tilted up. However, the moon roof is not tilted up when it is open

4. Tilt Down Operation

If you press the tilt down button when the tilt up of the moon roof control SW is pressed, the moon roof is tilted down.

: Parts Location

Code	See Page	Code	See Page	Code	See Page
J2	39	M3	41		
J7	39	M4	41		


: Junction Block and Wire Harness Connector


Code	See Page	Junction Block and Wire Harness (Connector Location)
IE	25	Roof Wire and Instrument Panel J/B (Lower Finish Panel)
IF	25	Instrument Panel Wire and Instrument Panel J/B (Lower Finish Panel)
IH		

: Ground Points


Code	See Page	Ground Points Location
IE	44	Behind Combination Meter
IG	44	Right Kick Panel


Electronically Controlled Transmission





Electronically Controlled Transmission





Electronically Controlled Transmission

System Outline

Previous automatic transaxle have selected each gear shift using mechanically controlled throttle hydraulic pressure, governor hydraulic pressure and lock-up hydraulic pressure. The electronically controlled transmission, however, controls the line pressure and lock-up pressure etc. electrically, through the solenoid valve. The engine control module controls each solenoid valve based on the input signals from each sensor, which makes smooth driving possible by shift selection for each gear that is most appropriate to the driving conditions at that time.

1. Gear Shift Operation

When driving, the engine warm up condition is input as a signal to TERMINAL THW of the engine control module from the engine coolant temp. sensor and the vehicle speed signal from vehicle speed sensor is input to TERMINAL NT+ of the engine control module. At the same time, the throttle valve opening signal from the throttle position sensor is input to TERMINAL VTA (4WD) or TERMINALS VTA1 and VTA2 (2WD) of the engine control module as throttle angle signal. Based on these signals, the engine control module selects the best shift position for the driving conditions and sends current to the electronically controlled transmission solenoid.

2. Stop Light SW Circuit

If the brake pedal is depressed (Stop light SW on) when driving in lock-up condition, a signal is input to TERMINAL STP of the engine control module, the engine control module operates and continuity to the lock-up solenoid is cut.

3. Overdrive Circuit

* Overdrive on

When the engine is turned on from ignition off, the engine control module turns the O/D on. When the O/D main SW is pushed while the O/D is off, a signal is input into TERMINAL ODMS of the engine control module, and the O/D is turned on by the engine control module. In this case, the engine control module controls the gear shift according to the vehicle's driving condition, using the O/D range. At this time, the O/D OFF indicator light is off.

* Overdrive off

When the O/D main SW is pushed while the O/D is on, a signal is input into TERMINAL ODMS of the engine control module, and the O/D is turned off. At this time, the current flows through the O/D OFF indicator light to TERMINAL ODLP of the engine control module. As a result, the O/D OFF indicator light turns on, and the engine control module controls the gear shift according to the vehicle's driving condition, without using the O/D range.

○ : Parts Location

Code		See Page	Code		See Page	Code		See Page
A9		38	E5	C	38	P1		37 (1ZZ–FE)
C11	A	38	E6	D	38	S1	A	37 (1ZZ–FE)
C16		38	I11		39		B	37 (1ZZ–FE)
C18	B	38	I12	A	39	S7	A	39
D1		38	J1		37 (1ZZ–FE)		B	39
E1	A	36 (1ZZ–FE)	J3	A	39	T1		37 (1ZZ–FE)
	B	36 (1ZZ–FE)	J4	B	39	T6		37 (1ZZ–FE)
E2		36 (1ZZ–FE)	J5	B	39	V1		37 (1ZZ–FE)
E3	A	38	J6	A	39	V2		37 (1ZZ–FE)
E4	B	38	J7		39			

○ : Relay Blocks

Code	See Page	Relay Blocks (Relay Block Location)
1	23	Engine Room R/B (Engine Compartment Left)

**: Junction Block and Wire Harness Connector**

Code	See Page	Junction Block and Wire Harness (Connector Location)
IC	25	Engine Room Main Wire and Instrument Panel J/B (Lower Finish Panel)
IG	25	Instrument Panel Wire and Instrument Panel J/B (Lower Finish Panel)
IK	24	
IL		
IM		
1A	23	Engine Wire and Engine Room J/B (Engine Compartment Left)
3A	29	Instrument Panel Wire and RH J/B (Right Side of the Instrument Panel Reinforcement)
3B		
3C		
4B	32	Instrument Panel Wire and Center J/B (Behind the Combination Meter)
4C		


**: Connector Joining Wire Harness and Wire Harness**


Code	See Page	Joining Wire Harness and Wire Harness (Connector Location)
EA1	43 (1ZZ-FE)	Engine Wire and Engine Room Main Wire (Inside of the Engine Room R/B)
IA2	44	Engine Room Main Wire and Instrument Panel Wire (Instrument Panel Reinforcement LH)
IA5		
IA6		
IG1	45	Engine Wire and Instrument Panel Wire (Blower Unit RH)
IG3		

**: Ground Points**

Code	See Page	Ground Points Location
EB	43 (1ZZ-FE)	Front Left Suspension Tower
EC	43 (1ZZ-FE)	Left Side of the Cylinder Head
ED		
IG	44	Right Kick Panel

Cruise Control for 2ZZ-GE and 1ZZ-FE (4WD)





Cruise Control for 2ZZ-GE and 1ZZ-FE (4WD)

System Outline

The current is applied at all times through the STOP fuse to TERMINAL (A) 2 of the stop light SW.

With the ignition SW turned on, the current flows through the MAIN fuse to AM2 fuse to ignition SW (IG2) to TERMINAL 2 of the combination meter and the current through the ECU-IG fuse flows to TERMINAL 2 of the cruise control ECU.

When the ignition SW is on and the CRUISE SW is turned on, a signal is input from TERMINAL 2 of the cruise control SW to TERMINAL 11 of the cruise control ECU. As a result, the cruise control ECU functions and the current flows from the ECU-IG fuse to TERMINAL 2 of the cruise control ECU to TERMINAL 16 of the cruise control ECU to GROUND, and the cruise control system is in a condition ready for operation.

At the same time, the current through the MAIN fuse flows to AM2 fuse to ignition SW (IG2) to TERMINAL 2 of the CRUISE indicator light to TERMINAL 14 to TERMINAL 5 of the cruise control ECU to TERMINAL 16 to GROUND, causing the CRUISE indicator light to light up, indicating that cruise control is ready for operation.

1. Set Operation

When the CRUISE SW is turned on and the SET SW is pushed with the vehicle speed within the set limit (Approx. 40 km/h, 25 mph to 200 km/h, 124 mph), a signal is input to TERMINAL 11 of the cruise control ECU, and the vehicle speed at the time the SET SW is released is memorized in the ECU as the set speed.

2. Set Speed Control

During cruise control driving, the ECU compares the set speed memorized in the ECU with the actual vehicle speed input into TERMINAL 12 of the cruise control ECU from the combination meter, and controls the cruise control actuator to maintain the set speed.

When the actual speed is lower than the set speed, the ECU causes the current to the cruise control actuator to flow from TERMINAL 15 of the cruise control ECU to TERMINAL 1 of the cruise control actuator to TERMINAL 2 to TERMINAL 7 of the cruise control ECU. As a result, the motor in the cruise control actuator is rotated to open the throttle valve and the throttle cable is pulled to increase the vehicle speed. When the actual driving speed is higher than the set speed, the current to the cruise control actuator flows from TERMINAL 7 of the ECU to TERMINAL 2 of the cruise control actuator to TERMINAL 1 to TERMINAL 15 of the cruise control ECU.

This causes the motor in the cruise control actuator to rotate to close the throttle valve and return the throttle cable to decrease the vehicle speed.

3. Coast Control

During cruise control driving, while the -/SET SW is on, the cruise control actuator returns the throttle cable to close the throttle valve and decrease the driving speed. The vehicle speed when the -/SET SW is turned off is memorized, and the vehicle continues at the new set speed.

4. Accel Control

During cruise control driving, while the +/RES SW is turned on, the cruise control actuator pulls the throttle cable to open the throttle valve and increase the driving speed.

The vehicle speed when the +/RES SW is turned off is memorized and the vehicle continues at the new set speed.

5. Resume Control

The set speed is maintained even after the vehicle speed drops down to approx. 40 km/h (25 mph) or less. Therefore the resume control will be effective when the vehicle speed reaches back to approx. 40 km/h (25 mph). After canceling the set speed by the CANCEL SW, pushing the +/RES SW will cause the vehicle to resume the speed set before cancellation.

6. Manual Cancel Mechanism

If any of the following operations occurs during cruise control operation, the magnetic clutch of the actuator turns off and the motor rotates to close the throttle valve and the cruise control is released.

- * Placing the shift lever to positions except "D" position (Park/Neutral position SW except "D" position)(A/T), depressing the clutch pedal (Cruise control clutch SW off)(M/T). "Signal is not input to TERMINAL 4 of the ECU"
- * Depressing the brake pedal (Stop light SW on). "Signal input to TERMINAL 3 of the ECU"
- * Pushing the CANCEL SW (CANCEL SW on). "Signal input to TERMINAL 11 of the ECU"
- * Pushing the CRUISE SW off "signal input to TERMINAL 11 of the ECU".

7. Tap-Up Control Function

When the difference between the actual vehicle speed and the set speed is less than 5 km/h (3 mph), the set speed can be increased 1.6 km/h (1 mph) each time by operating the +/RES SW quickly within 0.6 seconds.

8. Tap-Down Control Function

When the difference between the actual vehicle speed and the set speed is less than 5 km/h (3 mph), the set speed can be lowered 1.6 km/h (1 mph) each time by operating the -/SET SW quickly within 0.6 seconds.

9. Auto Cancel Function

A) If any of the following operating conditions occurs during cruise control operation, the set speed is erased, current flow to the magnetic clutch is stopped and the cruise control is released, (CRUISE SW turns off).

When this occurs, the ignition SW must be turned off once before the CRUISE SW will turn on.

- * When current continues to flow to the motor inside the actuator in the throttle valve "OPEN" direction.

- * The motor does not operate despite the motor drive signal being output.

B) If any of the following operating conditions occurs during cruise control operation, the set speed is erased, current flow to the magnetic clutch is stopped and the cruise control is released. (CRUISE SW turn off).

When this occurs, the cancel state is cleared as the CRUISE SW will turn on again.

- * Over current to transistor driving the motor or the magnetic clutch.

- * Open circuit in the magnetic clutch.

- * Momentary interruption of vehicle speed signal.

- * Short circuit in the cruise control SW.

- * Short circuit of the ground when the control SW is turned ON.

C) If the following condition occurs during cruise control operation, the set speed is erased and the cruise control is released. (The power to the magnetic clutch is cut off until the SET SW is "ON" again.)

- * When the power to the cruise system is momentarily cut off.

D) If the following condition occurs during cruise control operation, the cruise control is released. (The power to the magnetic clutch is cut off until the SET SW is "ON" again.)

- * When the vehicle speed falls below the minimum speed limit, approx. 40 km/h (25 mph).

10. Automatic Transaxle Control Function (A/T)

- * In overdrive. If the vehicle speed becomes lower than the overdrive cut speed (Set speed minus approx. 4 km/h, 2.5 mph) during cruise control operation, such as driving up a hill, the overdrive is released and the power is increased to prevent a reduction in vehicle speed.

- * After releasing the overdrive, if the vehicle speed becomes higher than the overdrive return speed (Set speed minus approx. 2 km/h, 1.2 mph) and the ECU judges by the signals from the actuator's potentiometer that the upward slope has finished, the overdrive is resumed after approximately 2 seconds.

- * During cruise control driving, the cruise control operation signal is output from the cruise control ECU to the engine control module. Upon receiving this signal, the engine control module changes the shift pattern to normal.

To maintain smooth cruise control operation (on a downward slope etc.), the lock-up release of the transaxle when the idling point of the throttle position is "ON" is forbidden.

: Parts Location

Code		See Page		Code		See Page		Code		See Page	
C5		34 (2ZZ–GE)		E4	B	38		J6	A	39	
		36 (1ZZ–FE)		E5	C	38		P1		37 (1ZZ–FE)	
C11		38		E6	D	38		S1	A	37 (1ZZ–FE)	
C13		38		I11		39			B	35 (2ZZ–GE)	
C15		38		J2		39				37 (1ZZ–FE)	
C16		38		J3	A	39		S7	A	39	
D1		38		J4	B	39		V1		37 (1ZZ–FE)	
E1	B	36 (1ZZ–FE)		J5	B	39					

: Relay Blocks

Code	See Page	Relay Blocks (Relay Block Location)
1	23	Engine Room R/B (Engine Compartment Left)

Cruise Control for 2ZZ-GE and 1ZZ-FE (4WD)



: Junction Block and Wire Harness Connector

Code	See Page	Junction Block and Wire Harness (Connector Location)
IC	25	Engine Room Main Wire and Instrument Panel J/B (Lower Finish Panel)
IF	25	Instrument Panel Wire and Instrument Panel J/B (Lower Finish Panel)
IG		
IK		
IL		
IM		
1A	23	Engine Wire and Engine Room J/B (Engine Compartment Left)
3B	29	Instrument Panel Wire and RH J/B (Right Side of the Instrument Panel Reinforcement)
3C		
4B	32	Instrument Panel Wire and Center J/B (Behind the Combination Meter)
4C		



: Connector Joining Wire Harness and Wire Harness


Code	See Page	Joining Wire Harness and Wire Harness (Connector Location)
IA4	44	Engine Room Main Wire and Instrument Panel Wire (Instrument Panel Reinforcement LH)
IA5		
IA6		
IG1	45	Engine Wire and Instrument Panel Wire (Blower Unit RH)
IG3		




: Ground Points


Code	See Page	Ground Points Location
EC	42 (2ZZ-GE)	Left Side of the Cylinder Head
	43 (1ZZ-FE)	
IE	44	Behind Combination Meter


Cruise Control for 1ZZ-FE (2WD)





Cruise Control for 1ZZ-FE (2WD)





Cruise Control for 1ZZ-FE (2WD)

System Outline

The cruise control system is a constant vehicle speed controller in which control of the switch on the instrument panel makes it possible to automatically adjust the opening of the engine throttle valve without depressing of the accel pedal.

1. Set Operation

When the cruise control main SW is turned on, the system starts preparations necessary for the cruise control and turns on the indicator light in the combination meter.

2. Set Speed Control

When the -/SET SW is operated with the cruise control main SW turned on during travelling, the constant vehicle speed is controlled.

3. Coast Control

When the -/SET SW is kept turned on during cruise control travelling, the engine control module controls the throttle valve to decelerate the vehicle. Every time the -/SET SW is turned on instantaneously, the vehicle speed is decelerated approximately 1.6 km/h.

4. Accel Control

When the +/RES SW is kept turned on during cruise control travelling, the engine control module controls the throttle valve to accelerate the vehicle. Every time the +/RES SW is turned on instantaneously, the vehicle speed is accelerated approximately 1.6 km/h.

5. Resume Control

If the cruise control is cancelled, use of the +/RES SW accelerates the vehicle to the speed level used before canceling the cruise control.

6. Manual Cancel Mechanism

If any of the following signals is input during cruise control travelling, the cruise control is cancelled.

- * The stop light SW is turned on.
- * The CANCEL SW is turned on.
- * The cruise control main SW is turned off.

7. Auto Cancel Function

If any of the following conditions is encountered, the cruise control is automatically cancelled.

- * The stop light SW wiring is faulty or short-circuited.
- * The vehicle speed signal is faulty.
- * The electronically controlled throttle malfunctions.

8. Overdrive Control Function

The overdrive control may be cancelled if the vehicle travels on the slope during cruise control travelling. After the overdrive control has been cancelled it is decided that the slope is finished, the vehicle returns to the overdrive control mode again.

○ : Parts Location

Code		See Page		Code		See Page		Code		See Page	
A25		38		E6	D	38		P1		37 (1ZZ–FE)	
C11		38		I11		39		S1	A	37 (1ZZ–FE)	
C13		38		J2		39			B	37 (1ZZ–FE)	
C15		38		J3	A	39		S7	A	39	
D1		38		J4	B	39		T6		37 (1ZZ–FE)	
E3	A	38		J5	B	39		V1		37 (1ZZ–FE)	
E4	B	38		J6	A	39					
E5	C	38		J7		39					

○ : Relay Blocks

Code	See Page	Relay Blocks (Relay Block Location)
1	23	Engine Room R/B (Engine Compartment Left)

**: Junction Block and Wire Harness Connector**

Code	See Page	Junction Block and Wire Harness (Connector Location)
IC	25	Engine Room Main Wire and Instrument Panel J/B (Lower Finish Panel)
IG	25	Instrument Panel Wire and Instrument Panel J/B (Lower Finish Panel)
IK	24	
IL		
IM		
1A	23	Engine Wire and Engine Room J/B (Engine Compartment Left)
3B	29	Instrument Panel Wire and RH J/B (Right Side of the Instrument Panel Reinforcement)
3C		
4B	32	Instrument Panel Wire and Center J/B (Behind the Combination Meter)
4C		


**: Connector Joining Wire Harness and Wire Harness**


Code	See Page	Joining Wire Harness and Wire Harness (Connector Location)
EA1	43 (1ZZ-FE)	Engine Wire and Engine Room Main Wire (Inside of the Engine Room R/B)
IA2	44	Engine Room Main Wire and Instrument Panel Wire (Instrument Panel Reinforcement LH)
IA4		
IA5		
IA6		
IA7		
IG1	45	Engine Wire and Instrument Panel Wire (Blower Unit RH)
IG3		

**: Ground Points**


Code	See Page	Ground Points Location
EB	43 (1ZZ-FE)	Front Left Suspension Tower
EC	43 (1ZZ-FE)	Left Side of the Cylinder Head
ED		
IE	44	Behind Combination Meter
IG	44	Right Kick Panel


ABS, TRAC, VSC and Tire Pressure Warning System






ABS, TRAC, VSC and Tire Pressure Warning System







System Outline

The vehicle could be in an extreme over steering or under steering tendency due to unexpected accidents, road conditions, vehicle speed, or by other external factors. In such a case, this system automatically controls the engine output and the braking to each wheel, to decrease the extreme over steering and under steering.

* To decrease extreme over steering tendency

When the system determines that the over steering tendency is large, the system applies brakes to the outer wheels according to the degree of over steering, and creates a moment towards the outer side of the vehicle, to decrease the tendency of over steering. Also, when the brakes are applied, the vehicle speed decreases while the stability increases.

* To decrease extreme under steering tendency

When the system determines that the under steering tendency is large, the system applies brakes to the front or rear wheels according to the degree of under steering, to decrease the tendency of under steering.

* TRAC OFF SW

TRAC OFF SW is only for two-wheel drive models. Four-wheel drive models is needless this SW.

The SW to send the traction control system into OFF mode. When the SW is pushed after starting the engine, the system will be in OFF mode, and the TRAC OFF indicator light will turn on. When the SW is pushed again, the system will be in standby mode. When the engine is stopped and re-started, regardless of the TRAC OFF SW, the system will be in standby mode.

Information to the driver

The VSC system informs the driver when the tire grip is about to exceed its grip capacity, by blinking the slip indicator light and emitting an intermittent sound of the buzzer. Accordingly, the driver is informed to drive more gently.

○ : Parts Location

Code	See Page	Code	See Page	Code	See Page
A2	36 (1ZZ-FE)	E6	38	P4	39
A3	36 (1ZZ-FE)	I11	39	S1	A 37 (1ZZ-FE)
A19	40	J1	37 (1ZZ-FE)	S7	A 39
A20	40	J2	39	S12	39
B2	36 (1ZZ-FE)	J3	39	T7	39
C11	A 38	J5	39	T8	39
C18	B 38	J7	39	V10	39
D1	38	J13	39	Y1	39
D2	38	P1	37 (1ZZ-FE)		

○ : Relay Blocks

Code	See Page	Relay Blocks (Relay Block Location)
1	23	Engine Room R/B (Engine Compartment Left)
2	31	ABS R/B (Near the Front Left Suspension Tower)

○ : Junction Block and Wire Harness Connector

Code	See Page	Junction Block and Wire Harness (Connector Location)
IC	25	Engine Room Main Wire and Instrument Panel J/B (Lower Finish Panel)
IF	25	Instrument Panel Wire and Instrument Panel J/B (Lower Finish Panel)
IG		
IH		
IK		
IL	24	
IM		
1A	23	Engine Wire and Engine Room J/B (Engine Compartment Left)
3A	29	Instrument Panel Wire and RH J/B (Right Side of the Instrument Panel Reinforcement)
3B		
4B	32	Instrument Panel Wire and Center J/B (Behind the Combination Meter)
4C		

ABS, TRAC, VSC and Tire Pressure Warning System


 : Connector Joining Wire Harness and Wire Harness

Code	See Page	Joining Wire Harness and Wire Harness (Connector Location)
EA1	43 (1ZZ-FE)	Engine Wire and Engine Room Main Wire (Inside of the Engine Room R/B)
EB2	43 (1ZZ-FE)	Engine Room Main Wire and Engine Room Main Wire (Front Right Suspension Tower)
IA4	44	Engine Room Main Wire and Instrument Panel Wire (Instrument Panel Reinforcement LH)
IA5		
IA6		
IA7		
IB1	44	Engine Room Main Wire and Floor Wire (Cowl Side Panel LH)
IG3	45	Engine Wire and Instrument Panel Wire (Blower Unit RH)
BD1	46	Skid Control Sensor Wire LH and Floor Wire (Quarter Wheel House LH)
BE1	46	Skid Control Sensor Wire RH and Floor Wire (Quarter Wheel House RH)


 : Ground Points

Code	See Page	Ground Points Location
EA	43 (1ZZ-FE)	Front Right Fender
EB	43 (1ZZ-FE)	Front Left Suspension Tower
EC	43 (1ZZ-FE)	Left Side of the Cylinder Head
IE	44	Behind Combination Meter
IG	44	Right Kick Panel

ABS and Tire Pressure Warning System



- * 1 : 2ZZ-GE w/ Cruise Control,
1ZZ-FE Except 4WD w/o Cruise Control
- * 2 : 2ZZ-GE w/o Cruise Control,
1ZZ-FE 4WD w/o Cruise Control



ABS and Tire Pressure Warning System

System Outline

ABS is a brake system designed to improve the operating ability and securing the stability of the vehicle by preventing the lock-up of the vehicle by controlling the wheel cylinder pressure of all the four wheels at the time of sudden braking.

1. Input Signals

(1) Speed sensor signal

The speed of the wheels is detected and input to TERMINALS FL+, FR+, RL+, and RR+ of the skid control ECU with actuator.

(2) Stop light SW signal

A signal is input to TERMINAL STP of the skid control ECU with actuator when brake pedal is depressed.

2. System Operation

When the wheels are locked-up, the solenoid inside the actuator is controlled by the signal from the skid control ECU with actuator, and the brake fluid in the wheel cylinder will flow through the reservoir and reduce the hydraulic pressure.

While the ABS is in operation, as the skid control ECU with actuator always outputs the operation signal to the pump inside the actuator, and the brake fluid stored inside the reservoir will be sucked up by the pump inside the actuator and returned to the master cylinder.

When the hydraulic pressure of the wheel cylinder is decompressed or increased until the necessary hydraulic pressure, the solenoid inside the actuator is controlled by the control signal from the skid control ECU with actuator and as a result, hydraulic pressure of the wheel cylinder will be closed at both the master cylinder and reservoir sides routes, and the hydraulic pressure of the wheel cylinder will be in the hold condition.

If increase of the hydraulic pressure volume of the wheel cylinder becomes necessary, the control signals from the skid control ECU with actuator control the solenoid inside the actuator, to resume to the normal condition. Thus the brake fluid of the master cylinder will be sent to the wheel cylinder and will increase the hydraulic pressure of the wheel cylinder. At this time, in the case that the brake fluid is left in the reservoir, it will be sucked up by the pump inside the actuator and will be sent to the wheel cylinder.

○ : Parts Location

Code	See Page	Code	See Page	Code	See Page
A2	34 (2ZZ-GE)	C11	A	38	P1
	36 (1ZZ-FE)	C18	B	38	P4
A3	34 (2ZZ-GE)	D1	38	S1	B
	36 (1ZZ-FE)	D2	38		
A10	38	I11	39	S7	A
A19	40	J1	37 (1ZZ-FE)		B
A20	40	J2	39	T7	
B2	34 (2ZZ-GE)	J3	39		
	36 (1ZZ-FE)	J5	B	39	

○ : Relay Blocks

Code	See Page	Relay Blocks (Relay Block Location)
1	23	Engine Room R/B (Engine Compartment Left)

○ : Junction Block and Wire Harness Connector

Code	See Page	Junction Block and Wire Harness (Connector Location)
IC	25	Engine Room Main Wire and Instrument Panel J/B (Lower Finish Panel)
IG	25	Instrument Panel Wire and Instrument Panel J/B (Lower Finish Panel)
IK	24	
IL		
IM		
1A	23	Engine Wire and Engine Room J/B (Engine Compartment Left)
3B	29	Instrument Panel Wire and RH J/B (Right Side of the Instrument Panel Reinforcement)
4B	32	Instrument Panel Wire and Center J/B (Behind the Combination Meter)
4C		

 : **Connector Joining Wire Harness and Wire Harness**

Code	See Page	Joining Wire Harness and Wire Harness (Connector Location)
EA1	43 (1ZZ-FE)	Engine Wire and Engine Room Main Wire (Inside of the Engine Room R/B)
IA4	44	Engine Room Main Wire and Instrument Panel Wire (Instrument Panel Reinforcement LH)
IA5		
IA6		
IB1	44	Engine Room Main Wire and Floor Wire (Cowl Side Panel LH)
IG3	45	Engine Wire and Instrument Panel Wire (Blower Unit RH)
BD1	46	Skid Control Sensor Wire LH and Floor Wire (Quarter Wheel House LH)
BE1	46	Skid Control Sensor Wire RH and Floor Wire (Quarter Wheel House RH)


 : **Ground Points**


Code	See Page	Ground Points Location
EA	42 (2ZZ-GE)	Front Right Fender
	43 (1ZZ-FE)	
EB	42 (2ZZ-GE)	Front Left Suspension Tower
	43 (1ZZ-FE)	
EC	42 (2ZZ-GE)	Left Side of the Cylinder Head
	43 (1ZZ-FE)	
IE	44	Behind Combination Meter


NOTICE: When inspecting or repairing the SRS, perform service in accordance with the following precautionary instructions and the procedure, and precautions in the Repair Manual applicable for the model year.


- Malfunction symptoms of the SRS are difficult to confirm, so the DTCs become the most important source of information when troubleshooting. When troubleshooting the SRS, always inspect the DTCs before disconnecting the battery.
- **Work must be started more than 90 seconds after the ignition SW is turned to the "LOCK" position and the negative (-) terminal cable is disconnected from the battery.**
(The SRS is equipped with a back-up power source so that if work is started within 90 seconds from disconnecting the negative (-) terminal cable of the battery, the SRS may deploy.)
- When the negative (-) terminal cable is disconnected from the battery, the memory of the clock and audio system will be cleared. So before starting work, make a record of the contents in the audio memory system. When work is finished, reset the audio systems as they were before and adjust the clock. Some vehicles have power tilt steering, power telescopic steering, power seat and power outside rear view mirror which are all equipped with memory function. However, it is not possible to make a record of these memory contents. So when the work is finished, it will be necessary to explain it to your customer, and ask the customer to adjust the features and reset the memory. To avoid erasing the memory in each system, never use a back-up power supply from outside the vehicle.
- Before repair, remove the airbag sensor if shocks are likely to be applied to the sensor during repair.
- Do not expose the following parts directly to hot air or flame;
- Even in cases of a minor collision where the SRS does not deploy, the following parts should be inspected;
- Never use SRS parts from another vehicle. When replacing parts, replace with new parts.
- For the purpose of reuse, never disassemble and repair the following parts.
- If the following parts have been dropped, or have cracks, dents and other defects in their case, bracket, and connector, replace with new one.
- Use a volt/ohmmeter with high impedance (10 k Ω /V minimum) for troubleshooting electrical circuits of the system.
- Information labels are attached to the periphery of the SRS components. Follow the instructions of the notice.
- After work on the SRS is completed, check the SRS warning light.
- If the vehicle is equipped with a mobile communication system, refer to the precaution in the IN section of the Repair Manual.

- * Steering wheel pad
- * Front passenger airbag assembly
- * Side airbag assembly
- * Curtain shield airbag assembly
- * Seat belt pretensioner
- * Center airbag sensor assembly
- * Front airbag sensor assembly
- * Side airbag sensor assembly
- * Rear airbag sensor assembly









System Outline

The SRS is a driver and front passenger protection device which has a supplemental role to the seat belts.

When the ignition SW is turned to ON, current from the MAIN fuse flows to AM2 fuse to ignition SW (IG2) to TERMINAL (B) 21 of the airbag sensor assembly.

If an accident occurs while driving, when the frontal impact exceeds a set level, the current from the TERMINAL (B) 21 of the airbag sensor assembly flows to TERMINALS (B) 5, (B) 8, (B) 4, (B) 1, (A) 2 and (C) 4 of the airbag sensor assembly to the airbag squibs and the pretensioners to TERMINALS (B) 6, (B) 7, (B) 3, (B) 2, (A) 1 and (C) 5 of the airbag sensor assembly to TERMINAL (B) 25, (B) 26 or BODY GROUND to GROUND, so that the current flows to the front airbag squibs and the pretensioners, and causes them to operate.

When the side impact also exceeds a set level, the current from the TERMINAL (B) 21 of the airbag sensor assembly flows to TERMINALS (A) 9, (C) 7, (A) 7, (C) 9 of the airbag sensor assembly to the side airbag squibs and curtain shield airbag squibs to TERMINALS (A) 10, (C) 6, (A) 6, (C) 10 of the airbag sensor assembly to TERMINAL (B) 25, (B) 26 or BODY GROUND to GROUND, causing side airbag squibs to operate.

The airbag stored inside the steering wheel pad is instantaneously expanded to soften the shock to the driver.

The airbag stored inside the passenger's instrument panel is instantaneously expanded to soften the shock to the front passenger.

Side airbags are instantaneously expanded to soften the shock of side to the driver and front passenger.

The curtain shield airbag can reduce impact on the head of the front and rear passengers and reduce risk of injury.

The pretensioners make sure of the seat belt restrainability.

○ : Parts Location

Code	See Page	Code	See Page	Code	See Page
A4	34 (2ZZ-GE)	C17	38	O8	41
	36 (1ZZ-FE)	C19	40	O9	41
A5	34 (2ZZ-GE)	C20	40	P14	41
	36 (1ZZ-FE)	D1	38	P15	41
A12	A	E6	38	S10	41
A13	B	I11	39	S11	41
A14	C	J2	39	S15	41
A15	38	J5	39	S16	41
A16	38	O4	A	S17	41
B7	40	O5	B	S18	41
B8	40	O6	41		
C11	38	O7	41		

○ : Relay Blocks

Code	See Page	Relay Blocks (Relay Block Location)
1	23	Engine Room R/B (Engine Compartment Left)

○ : Junction Block and Wire Harness Connector

Code	See Page	Junction Block and Wire Harness (Connector Location)
IF	25	Instrument Panel Wire and Instrument Panel J/B (Lower Finish Panel)
IG		
IH		
II		
IJ		
IK	24	
IL		
IM		
1A	23	Engine Wire and Engine Room J/B (Engine Compartment Left)
3B	29	Instrument Panel Wire and RH J/B (Right Side of the Instrument Panel Reinforcement)
4C	32	Instrument Panel Wire and Center J/B (Behind the Combination Meter)

 : **Connector Joining Wire Harness and Wire Harness**


Code	See Page	Joining Wire Harness and Wire Harness (Connector Location)
IA1	44	Engine Room Main Wire and Instrument Panel Wire (Instrument Panel Reinforcement LH)
IA5		
IG3	45	Engine Wire and Instrument Panel Wire (Blower Unit RH)
II1	45	Instrument Panel Wire and Floor Wire (Under the Instrument Panel Center)
IM1	45	Instrument Panel Wire and Instrument Panel No.3 Wire (Under the Instrument Panel Center)

 : **Ground Points**

Code	See Page	Ground Points Location
EC	42 (2ZZ-GE)	Left Side of the Cylinder Head
	43 (1ZZ-FE)	
IE	44	Behind Combination Meter

Shift Lock

- * 1 : Except 4WD w/o Cruise Control
- * 2 : 4WD w/o Cruise Control



System Outline

When the ignition SW is turned to ON position, the current from the ECU-IG fuse flows to TERMINAL 5 of the shift lock control ECU.

Shift Lock Mechanism

With the ignition SW at ON position, when a signal that the brake pedal is depressed (Stop light SW on) and a signal that the shift lever is put in P position is input to the ECU, the ECU operates and the current flows from TERMINAL 5 of the ECU to TERMINAL SLS+ of the shift lock solenoid to TERMINAL SLS- to TERMINAL 1 of the ECU to GROUND. This causes the shift lock solenoid to turn on (Plate stopper disengages) and the shift lever can shift into position other than P.

○ : Parts Location

Code	See Page	Code	See Page	Code	See Page
J7	39	S7	A	39	
S5	39		B	39	

○ : Junction Block and Wire Harness Connector


Code	See Page	Junction Block and Wire Harness (Connector Location)
IC	25	Engine Room Main Wire and Instrument Panel J/B (Lower Finish Panel)
IF	25	Instrument Panel Wire and Instrument Panel J/B (Lower Finish Panel)
IL	24	
3A	29	Instrument Panel Wire and RH J/B (Right Side of the Instrument Panel Reinforcement)
3B		
3C		

▽ : Ground Points

Code	See Page	Ground Points Location
IG	44	Right Kick Panel

Light Reminder and Key Reminder

* 1 : w/ Door Lock Control
 * 2 : w/o Door Lock Control



System Outline

The current is applied at all times to TERMINAL 1 of the combination meter through the DOME fuse.

When the ignition SW is turned to ON position, the current flows to TERMINAL 21 of the combination meter through the GAUGE fuse. When the light control SW is turned to Tail or Head position, current is applied to TERMINAL 4 of the combination meter through the TAIL fuse via the TAIL relay (USA) or light control SW (Canada).

1. Light Reminder System

When the light control SW is in Tail or Head position, the ignition SW turned to OFF from ON position, and the driver's door opened (Door courtesy SW on), the current flows to TERMINAL 21 of the combination meter stops. As a result, the combination meter is activated and current flows from TERMINAL 1 of the combination meter to TERMINAL 40 to GROUND, the buzzer in the combination meter goes on to remind the light is lighting up.

2. Key Reminder System

When the driver door is opened with the ignition SW off and ignition key remaining in the key cylinder (Unlock warning SW on), a signal is input from the unlock warning SW to TERMINAL 15 of the combination meter, and from the door courtesy SW front LH to TERMINAL 26 of the combination meter. As a result, the buzzer in the combination meter goes on and warns the driver that the key is remaining in the key cylinder.

○ : Parts Location

Code	See Page	Code	See Page	Code	See Page
C11	38	D2	38	J2	39
C12	38	D7	40	U1	39

□ : Relay Blocks

Code	See Page	Relay Blocks (Relay Block Location)
1	23	Engine Room R/B (Engine Compartment Left)
3	28	RH R/B (Right Side of the Instrument Panel Reinforcement)


□ : Junction Block and Wire Harness Connector


Code	See Page	Junction Block and Wire Harness (Connector Location)
IC	25	Engine Room Main Wire and Instrument Panel J/B (Lower Finish Panel)
ID	25	Floor Wire and Instrument Panel J/B (Lower Finish Panel)
IG	25	Instrument Panel Wire and Instrument Panel J/B (Lower Finish Panel)
IH		
IL		
3B	29	Instrument Panel Wire and RH J/B (Right Side of the Instrument Panel Reinforcement)
4A	32	Instrument Panel Wire and Center J/B (Behind the Combination Meter)
4B		
4C		

▽ : Ground Points

Code	See Page	Ground Points Location
IE	44	Behind Combination Meter

Seat Belt Warning





Seat Belt Warning

System Outline

Current is always applied from the DOME fuse to TERMINAL 1 of the combination meter. When the ignition SW is turned to ON position, the current from the GAUGE fuse flows to TERMINAL 21 of the combination meter and flows to TERMINAL 4 of the front passenger seat belt warning light.

Seat Belt Warning System

When the ignition SW turned on, a signal is input to the combination meter. To determine whether the driver has fastened the seat belt, a signal is input from the buckle SW LH to TERMINAL 31 of the combination meter. When the seat belt is not fastened, the seat belt warning light in the combination meter blinks, and emits a warning sound.

In addition, the front passenger is recognized by a sensor (Occupant detection sensor) is installed in the front passenger seat, and determines whether the seat belt is fastened. When not fastened, the signals from the occupant detection sensor is input to TERMINAL 37 of the combination meter, and the front passenger seat belt warning light blinks.

○ : Parts Location

Code		See Page	Code	See Page	Code	See Page
A13	B	38	C11	38	J5	39
A14	C	38	C17	38	J7	39
B7		40	I11	39	O4	41
B8		40	J2	39		

○ : Relay Blocks

Code	See Page	Relay Blocks (Relay Block Location)
1	23	Engine Room R/B (Engine Compartment Left)

○ : Junction Block and Wire Harness Connector

Code	See Page	Junction Block and Wire Harness (Connector Location)
IC	25	Engine Room Main Wire and Instrument Panel J/B (Lower Finish Panel)
IG	25	Instrument Panel Wire and Instrument Panel J/B (Lower Finish Panel)
IH		
IL	24	
IM		
3A	29	Instrument Panel Wire and RH J/B (Right Side of the Instrument Panel Reinforcement)
3B		
4B	32	Instrument Panel Wire and Center J/B (Behind the Combination Meter)
4C		


□ : Connector Joining Wire Harness and Wire Harness

Code	See Page	Joining Wire Harness and Wire Harness (Connector Location)
IG3	45	Engine Wire and Instrument Panel Wire (Blower Unit RH)
II1	45	Instrument Panel Wire and Floor Wire (Under the Instrument Panel Center)
IM1	45	Instrument Panel Wire and Instrument Panel No.3 Wire (Under the Instrument Panel Center)

▽ : Ground Points

Code	See Page	Ground Points Location
EC	42 (2ZZ-GE)	Left Side of the Cylinder Head
	43 (1ZZ-FE)	
IE	44	Behind Combination Meter
IG	44	Right Kick Panel

Rear Window Defogger



 : Parts Location

Code	See Page	Code	See Page	Code	See Page
D4	38	J10	40	N2	41
G5	40	J11	40	R6	39
I10	39	J12	40		

 : Junction Block and Wire Harness Connector


Code	See Page	Junction Block and Wire Harness (Connector Location)
ID	25	Floor Wire and Instrument Panel J/B (Lower Finish Panel)
IF	25	Instrument Panel Wire and Instrument Panel J/B (Lower Finish Panel)
IG		
IL	24	Instrument Panel Wire and Instrument Panel J/B (Lower Finish Panel)
IM		
3B	29	Instrument Panel Wire and RH J/B (Right Side of the Instrument Panel Reinforcement)

 : Connector Joining Wire Harness and Wire Harness

Code	See Page	Joining Wire Harness and Wire Harness (Connector Location)
ID1	44	Instrument Panel Wire and Floor Wire (Left Kick Panel)
BC2	46	Back Door No.1 Wire and Floor Wire (Left Quarter Panel)
BF1	46	Back Door No.1 Wire and Back Door No.2 Wire (Back Panel LH)
BF2		

 : Ground Points

Code	See Page	Ground Points Location
IE	44	Behind Combination Meter
BH	46	Left Quarter Panel



 : Parts Location

Code	See Page	Code	See Page	Code	See Page
A13	38	C17	38	J7	39

 : Relay Blocks

Code	See Page	Relay Blocks (Relay Block Location)
1	23	Engine Room R/B (Engine Compartment Left)


 : Junction Block and Wire Harness Connector


Code	See Page	Junction Block and Wire Harness (Connector Location)
IC	25	Engine Room Main Wire and Instrument Panel J/B (Lower Finish Panel)
IF	25	Instrument Panel Wire and Instrument Panel J/B (Lower Finish Panel)
IG		
IL	24	
3A	29	Instrument Panel Wire and RH J/B (Right Side of the Instrument Panel Reinforcement)
3B		
4C	32	Instrument Panel Wire and Center J/B (Behind the Combination Meter)

 : Ground Points

Code	See Page	Ground Points Location
IG	44	Right Kick Panel

Audio System for Separate Amplifier





Audio System for Separate Amplifier

: Parts Location

Code	See Page	Code	See Page	Code	See Page
A17	38	R11	41	S14	B 39
F8	40	R12	41	T4	41
F9	40	R16	B 39	T5	41
J7	39	S13	A 39	W1	41

: Relay Blocks

Code	See Page	Relay Blocks (Relay Block Location)
1	23	Engine Room R/B (Engine Compartment Left)

: Junction Block and Wire Harness Connector

Code	See Page	Junction Block and Wire Harness (Connector Location)
IC	25	Engine Room Main Wire and Instrument Panel J/B (Lower Finish Panel)
IF	25	Instrument Panel Wire and Instrument Panel J/B (Lower Finish Panel)
IL	24	
3A	29	Instrument Panel Wire and RH J/B (Right Side of the Instrument Panel Reinforcement)
4C	32	Instrument Panel Wire and Center J/B (Behind the Combination Meter)


: Connector Joining Wire Harness and Wire Harness

Code	See Page	Joining Wire Harness and Wire Harness (Connector Location)
IA2	44	Engine Room Main Wire and Instrument Panel Wire (Instrument Panel Reinforcement LH)
IC1	44	Front Door LH Wire and Instrument Panel Wire (Left Kick Panel)
IH2	45	Front Door RH Wire and Instrument Panel Wire (Right Kick Panel)
IL1	45	Floor Wire and Instrument Panel Wire (Right Kick Panel)
IL2		
IL3		
BA1	46	Rear Door LH Wire and Floor Wire (Left Center Pillar)
BG1	46	Rear Door RH Wire and Floor Wire (Right Center Pillar)
BH1	46	Floor Wire and Floor Wire (Under the Right Center Pillar)

: Ground Points

Code	See Page	Ground Points Location
IF	44	Behind Combination Meter
IG	44	Right Kick Panel

Audio System for Built-In Amplifier



 : Parts Location

Code	See Page	Code	See Page	Code	See Page
A17	38	R11	41	R17	B 39
F8	40	R12	41	T4	41
F9	40	R16	A 39	T5	41

 : Relay Blocks

Code	See Page	Relay Blocks (Relay Block Location)
1	23	Engine Room R/B (Engine Compartment Left)

 : Junction Block and Wire Harness Connector

Code	See Page	Junction Block and Wire Harness (Connector Location)
IC	25	Engine Room Main Wire and Instrument Panel J/B (Lower Finish Panel)
IF	25	Instrument Panel Wire and Instrument Panel J/B (Lower Finish Panel)
IL	24	
3A	29	Instrument Panel Wire and RH J/B (Right Side of the Instrument Panel Reinforcement)
4C	32	Instrument Panel Wire and Center J/B (Behind the Combination Meter)


 : Connector Joining Wire Harness and Wire Harness

Code	See Page	Joining Wire Harness and Wire Harness (Connector Location)
IC1	44	Front Door LH Wire and Instrument Panel Wire (Left Kick Panel)
ID1	44	Instrument Panel Wire and Floor Wire (Left Kick Panel)
IH2	45	Front Door RH Wire and Instrument Panel Wire (Right Kick Panel)
BA1	46	Rear Door LH Wire and Floor Wire (Left Center Pillar)
BB1	46	Rear Door RH Wire and Instrument Panel Wire (Right Center Pillar)


 : Ground Points

Code	See Page	Ground Points Location
IF	44	Behind Combination Meter

Combination Meter




Combination Meter



Combination Meter

* 4 : w/ ABS
* 5 : w/o ABS

C11(A), C18(B)
Combination Meter



 : Parts Location

Code	See Page	Code	See Page	Code	See Page
A6	34 (2ZZ-GE)	J1	35 (2ZZ-GE)	P4	39
	36 (1ZZ-FE)		37 (1ZZ-FE)	S1	A 37 (1ZZ-FE)
B2	34 (2ZZ-GE)	J2	39		B 35 (2ZZ-GE)
	36 (1ZZ-FE)	J3	A 39		37 (1ZZ-FE)
C11	A 38	J4	B 39	V1	37 (1ZZ-FE)
C18	B 38	J5	B 39	W2	35 (2ZZ-GE)
D2	38	J6	A 39		37 (1ZZ-FE)
F10	40	O2	35 (2ZZ-GE)		
I11	39		37 (1ZZ-FE)		

 : Relay Blocks

Code	See Page	Relay Blocks (Relay Block Location)
1	23	Engine Room R/B (Engine Compartment Left)

 : Junction Block and Wire Harness Connector

Code	See Page	Junction Block and Wire Harness (Connector Location)
IC	25	Engine Room Main Wire and Instrument Panel J/B (Lower Finish Panel)
IG	25	Instrument Panel Wire and Instrument Panel J/B (Lower Finish Panel)
IK	24	
IL		
IM		
1A	23	Engine Wire and Engine Room J/B (Engine Compartment Left)
3B	29	Instrument Panel Wire and RH J/B (Right Side of the Instrument Panel Reinforcement)
4B	32	Instrument Panel Wire and Center J/B (Behind the Combination Meter)
4C		


 : Connector Joining Wire Harness and Wire Harness

Code	See Page	Joining Wire Harness and Wire Harness (Connector Location)
IA4	44	Engine Room Main Wire and Instrument Panel Wire (Instrument Panel Reinforcement LH)
IA5		
IA6		
ID2	44	Instrument Panel Wire and Floor Wire (Left Kick Panel)
IG3	45	Engine Wire and Instrument Panel Wire (Blower Unit RH)

 : Ground Points

Code	See Page	Ground Points Location
EA	42 (2ZZ-GE)	Front Right Fender
	43 (1ZZ-FE)	
EB	42 (2ZZ-GE)	Front Left Suspension Tower
	43 (1ZZ-FE)	
EC	42 (2ZZ-GE)	Left Side of the Cylinder Head
	43 (1ZZ-FE)	
IE	44	Behind Combination Meter

Radiator Fan



System Outline

The current is applied at all times through the RDI FAN fuse to TERMINAL 5 of the FAN NO.1 relay. When the ignition SW is turned on, the current flows through the ECU-IG fuse to FAN NO.1 relay (Coil side) to TERMINAL CF of the engine control module. At the same time as this current flow, the current from ECU-IG fuse flows to the FAN NO.2 relay (Coil side) to TERMINAL 3 of the pressure SW.

1. Low Speed Operation

When the A/C system is operating, the FAN NO.1 Relay is turned on. As a result, the current flows from the RDI FAN fuse to FAN NO.1 relay (Point side) to TERMINAL 2 of the radiator fan motor to TERMINAL 1 to TERMINAL 3 of the FAN NO.2 relay to TERMINAL 4 to TERMINAL 2 of the radiator fan resistor to TERMINAL 1 to GROUND, and the radiator fan motor rotates at low speed.

2. High Speed Operation

When the pressure SW is on or engine control module operated, the FAN NO.1 and NO.2 relay is turned on. As a result, the current flows from the RDI FAN fuse to FAN NO.1 relay (Point side) to radiator fan motor to TERMINAL 3 of the FAN NO.2 Relay to TERMINAL 5 to GROUND, and the radiator fan motor rotates at high speed.

○ : Parts Location

Code	See Page	Code	See Page	Code	See Page
E3	A	38	P3	37 (1ZZ-FE)	R2
E4	B	38	R1	35 (2ZZ-GE)	
P3		35 (2ZZ-GE)		37 (1ZZ-FE)	

○ : Relay Blocks

Code	See Page	Relay Blocks (Relay Block Location)
1	23	Engine Room R/B (Engine Compartment Left)

○ : Junction Block and Wire Harness Connector

Code	See Page	Junction Block and Wire Harness (Connector Location)
IC	25	Engine Room Main Wire and Instrument Panel J/B (Lower Finish Panel)


□ : Connector Joining Wire Harness and Wire Harness


Code	See Page	Joining Wire Harness and Wire Harness (Connector Location)
EA1	42 (2ZZ-GE)	Engine Wire and Engine Room Main Wire (Inside of the Engine Room R/B)
	43 (1ZZ-FE)	

▽ : Ground Points

Code	See Page	Ground Points Location
EA	42 (2ZZ-GE)	Front Right Fender
	43 (1ZZ-FE)	
EB	42 (2ZZ-GE)	Front Left Suspension Tower
	43 (1ZZ-FE)	

Heater





Heater

System Outline

Current is applied at all times through the HEATER fuse to TERMINAL 5 of the HTR relay.

When the ignition SW is turned on, the current flows through the GAUGE fuse to TERMINAL 2 of the HTR relay to TERMINAL 1 to TERMINAL 6 of the blower SW.

1. Heater Blower Motor Operation

* Low speed operation

When the blower SW is moved to LO position, the current flows to TERMINAL 6 of the blower SW to TERMINAL 5 to GROUND, causing the HTR relay to turn on. This causes the current flows from the HEATER fuse to TERMINAL 5 of the HTR relay to TERMINAL 3 to the blower motor to the blower resistor to GROUND, rotating the blower motor at low speed.

* Medium speed operation (Operation at M1, M2)

When the blower SW is moved to M1 position, the current flows to TERMINAL 6 of the blower SW to TERMINAL 5 to GROUND, causing the HTR relay to turn on. This causes the current flows from the HEATER fuse to TERMINAL 5 of the HTR relay to TERMINAL 3 to the blower motor to the blower resistor to TERMINAL 2 of the blower SW to TERMINAL 5 to GROUND. At this time, the blower resistance of the blower resistor is smaller than at low speed, so the blower motor rotates at medium low speed.

When the blower SW is moved to M2 position, the current flows through the HTR relay to the blower motor to the blower resistor to TERMINAL 1 of the blower SW to TERMINAL 5 to GROUND. At this time, resistance of the blower resistor is smaller than at M1 position, so the blower motor rotates at medium high speed.

* High speed operation

When the blower SW is moved to HI position, the current flows to TERMINAL 6 of the blower SW to TERMINAL 5 to GROUND, causing the HTR relay to turn on.

This causes the current flows from the HEATER fuse to TERMINAL 5 of the HTR relay to TERMINAL 3 to the blower motor to TERMINAL 4 of the blower SW to TERMINAL 5 to GROUND, rotating the blower motor at high speed.

○ : Parts Location

Code	See Page	Code	See Page	Code	See Page
A7	38	B4	38	J7	39
A11	38	B5	38		
B3	38	D3	38		

○ : Relay Blocks

Code	See Page	Relay Blocks (Relay Block Location)
1	23	Engine Room R/B (Engine Compartment Left)
3	28	RH R/B (Right Side of the Instrument Panel Reinforcement)

○ : Junction Block and Wire Harness Connector

Code	See Page	Junction Block and Wire Harness (Connector Location)
IC	25	Engine Room Main Wire and Instrument Panel J/B (Lower Finish Panel)
IG	25	Instrument Panel Wire and Instrument Panel J/B (Lower Finish Panel)
IL	24	
IM		
3A	29	
3B		


□ : Connector Joining Wire Harness and Wire Harness


Code	See Page	Joining Wire Harness and Wire Harness (Connector Location)
IF1	45	Instrument Panel Wire and A/C Sub Wire (Left Upper Side of the Blower Unit)

▽ : Ground Points


Code	See Page	Ground Points Location
IG	44	Right Kick Panel

Air Conditioning





Air Conditioning



System Outline

Current is applied at all times through the HEATER fuse to TERMINAL 5 of the HTR relay.

When the ignition SW is turned on, the current flows through the GAUGE fuse to TERMINAL 2 of the HTR relay to TERMINAL 1 to TERMINAL 6 of the blower SW.

1. Heater Blower Motor Operation

* Low speed operation

When the blower SW is moved to LO position, the current flows to TERMINAL 6 of the blower SW to TERMINAL 5 to GROUND, causing the HTR relay to turn on. This causes the current flows from the HEATER fuse to TERMINAL 5 of the HTR relay to TERMINAL 3 to the blower motor to the blower resistor to GROUND, rotating the blower motor at low speed.

* Medium speed operation (Operation at M1, M2)

When the blower SW is moved to M1 position, the current flows to TERMINAL 6 of the blower SW to TERMINAL 5 to GROUND, causing the HTR relay to turn on. This causes the current flows from the HEATER fuse to TERMINAL 5 of the HTR relay to TERMINAL 3 to the blower motor to the blower resistor to TERMINAL 2 of the blower SW to TERMINAL 5 to GROUND. At this time, the blower resistance of the blower resistor is smaller than at low speed, so the blower motor rotates at medium low speed.

When the blower SW is moved to M2 position, the current flows through the HTR relay to the blower motor to the blower resistor to TERMINAL 1 of the blower SW to TERMINAL 5 to GROUND. At this time, resistance of the blower resistor is smaller than at M1 position, so the blower motor rotates at medium high speed.

* High speed operation

When the blower SW is moved to HI position, the current flows to TERMINAL 6 of the blower SW to TERMINAL 5 to GROUND, causing the HTR relay to turn on.

This causes the current flows from the HEATER fuse to TERMINAL 5 of the HTR relay to TERMINAL 3 to the blower motor to TERMINAL 4 of the blower SW to TERMINAL 5 to GROUND, rotating the blower motor at high speed.

2. Air Conditioning Operation

When the blower SW is set on, the current flows from the HEATER fuse to the HTR relay (Point side) to the A/C fuse to the TERMINAL 8 of the A/C SW and TERMINAL 2 of the defroster mode SW. If the A/C SW or the defroster mode SW is turned on, at this time a signal is input into the engine control module. This activates the engine control module and M/G CLT relay. So that current flows from the A/C fuse to M/G CLT relay (Point side) to A/C magnetic clutch. Causing the compressor to operate.

3. DEF or FOOT & DEF Synchronized Control Function

When the blower SW is on and the heater control lever (Air vent mode control lever) turned to DEF or FOOT & DEF position, it causes A/C to run and the air inlet control SW to be at FRESH position whether A/C SW is on or not.

○ : Parts Location

Code	See Page	Code	See Page	Code	See Page
A1	34 (2ZZ-GE)	B5	38	J5	39
	36 (1ZZ-FE)	D3	38	J7	39
A7	38	E3	A	P3	35 (2ZZ-GE)
A11	38	E4	B		37 (1ZZ-FE)
B3	38	E5	C		
B4	38	E6	D		

○ : Relay Blocks

Code	See Page	Relay Blocks (Relay Block Location)
1	23	Engine Room R/B (Engine Compartment Left)
3	28	RH R/B (Right Side of the Instrument Panel Reinforcement)

Air Conditioning



: Junction Block and Wire Harness Connector

Code	See Page	Junction Block and Wire Harness (Connector Location)
IC	25	Engine Room Main Wire and Instrument Panel J/B (Lower Finish Panel)
IF	25	Instrument Panel Wire and Instrument Panel J/B (Lower Finish Panel)
IG		
IL	24	
IM		
3A	29	Instrument Panel Wire and RH J/B (Right Side of the Instrument Panel Reinforcement)
3B		



: Connector Joining Wire Harness and Wire Harness

Code	See Page	Joining Wire Harness and Wire Harness (Connector Location)
EA1	42 (2ZZ-GE)	Engine Wire and Engine Room Main Wire (Inside of the Engine Room R/B)
	43 (1ZZ-FE)	
IA6	44	Engine Room Main Wire and Instrument Panel Wire (Instrument Panel Reinforcement LH)
IF1	45	Instrument Panel Wire and A/C Sub Wire (Left Upper Side of the Blower Unit)
IG3	45	Engine Wire and Instrument Panel Wire (Blower Unit RH)



: Ground Points

Code	See Page	Ground Points Location
EA	42 (2ZZ-GE)	Front Right Fender
	43 (1ZZ-FE)	
IG	44	Right Kick Panel

