

INSTALLATION

Installation is in reverse order of removal ([See page FI-41](#)).

HINT:

Install the IAC valve with a new gasket.