





REMOVAL


1. DISCONNECT HIGH-TENSION CORDS FROM IGNITION COILS
2. DISCONNECT IGNITION COIL CONNECTORS FROM IGNITION COILS



3. REMOVE IGNITION COIL AND BRACKET ASSEMBLIES

Remove the bolt and ignition coil and bracket assembly. Remove the 3 ignition coil and bracket assemblies.


Torque: 18 N·m (185 kgf·cm, 13 ft·lbf)



4. REMOVE IGNITION COIL FROM BRACKET

- (a) Remove the 4 bolts and ignition coil.

Torque: 9.8 N·m (100 kgf·cm, 85 in·lbf)



- (b) Remove the 2 bolts and ignition coil.

Torque: 9.8 N·m (100 kgf·cm, 85 in·lbf)