

REMOVAL

REMOVE CRANKSHAFT POSITION SENSOR

- (a) Disconnect the crankshaft position sensor connector.
- (b) Remove the 3 bolts and crankshaft position sensor protector.

Torque: 9.5 N·m (97 kgf·cm, 84 in·lbf)

- (c) Remove the bolt and 2 nuts crankshaft position sensor.

Torque: 9.3 N·m (95 kgf·cm, 82 in·lbf)