

TERMS

ABBREVIATIONS USED IN THIS MANUAL

IN07U-02

Abbreviations	Meaning
A/C	Air Conditioner
A/T	Automatic Transmission
BTDC	Before Top Dead Center
DLC3	Data Link Connector 3
ECU	Electronic Control Unit
EFI	Electronic Fuel Injection
EVAP	Evaporative Emission Control
FIPG	Formed In Place Gasket
FL	Fusible Link
MP	Multipurpose
M/T	Manual Transmission
IG	Ignition
ISC	Idle Speed Control
J/C	Junction Connector
J/B	Junction Block
LH	Left-Hand
LHD	Left-Hand Drive
O/S	Oversize
PCV	Positive Crankcase Ventilation
RH	Right-Hand
RHD	Right-Hand Drive
SSM	Special Service Materials
SST	Special Service Tools
SW	Switch
TDC	Top Dead Center
TEMP.	Temperature
VSV	Vacuum Switching valve
w/	With
w/ o	Without