




INSTALLATION

1. INSTALL OIL NOZZLES AND CHECK VALVES

- (a) Align the pin of the nozzle with the pin hole of the cylinder block.
- (b) Install the oil nozzle with the check valve. Install the 6 oil nozzles and 6 check valves.

Torque: 27 N·m (275 kgf·cm, 20 ft·lbf)

2. INSTALL OIL PAN (See page LU-13)