

SUB FUEL PUMP (w/ Sub Fuel Tank)

FI0DI-01

ON-VEHICLE INSPECTION

CHECK SUB FUEL PUMP OPERATION AND FUEL PRESSURE

(See steps 1 and 2 in [FI-7](#))

NOTICE:

Push the fuel tank changeover switch ON.