


LHD:



I06740


BLOWER MOTOR CONTROL RELAY (Auto A/C) INSPECTION

AC1TL-01

1. REMOVE BLOWER MOTOR CONTROL RELAY

- (a) Disconnect the connector.
- (b) Remove the screw and relay.

RHD:




I07843

2. INSPECT BLOWER MOTOR CONTROL RELAY

Connect the connector to relay and inspect wire harness side connector from the back side, as shown in the chart below.

Test condition

- Turn ignition switch to ON



N17641

Tester connection	Condition	Specified condition
1 – Ground	Constant	Continuity
2 – Ground	Blower speed control switch at "LO" position	Approx. 3.5 V
	Blower speed control switch at "M1" position	Approx. 2.2 V
	Blower speed control switch at "HI" position	No voltage
3 – Ground	Operate blower motor	Battery voltage
	Blower speed control switch at "OFF"	No voltage
4 – 5	Blower speed control switch at "LO" position	Approx. 3.6 V
	Blower speed control switch at "M2" position	Approx. 8.3 V
	Blower speed control switch at "HI" position	Approx. 13.0 V

If the circuit is not as specified, replace the relay.