




NEUTRAL START SWITCH ON-VEHICLE REPAIR

AT09I-01

1. IFS Only:
REMOVE NO.2 ENGINE UNDER COVER
2. 1HD-FTE Only:
REMOVE TRANSMISSION UNDER COVER
3. DISCONNECT NEUTRAL START SWITCH CONNECTOR
4. REMOVE NEUTRAL START SWITCH
 - (a) Using a screwdriver, pry off the lock washer.
 - (b) Remove the nut and lock washer.
 - (c) Remove the 2 bolts and neutral start switch.
5. INSTALL NEUTRAL START SWITCH
 - (a) Install the neutral start switch with the 2 bolts.
Torque: 13 N·m (130 kgf·cm, 9 ft·lbf)
 - (b) Install a new lock washer and nut.
Torque: 3.9 N·m (40 kgf·cm, 35 in·lbf)
 - (c) Stake the nut with the lock washer.
 - (d) Adjust the neutral start switch ([See page DI-80](#)).
6. CONNECT NEUTRAL START SWITCH CONNECTOR
7. 1HD-FTE Only:
REMOVE TRANSMISSION UNDER COVER
8. IFS Only:
INSTALL NO.2 ENGINE UNDER COVER

