




INSTALLATION

1. CHECK TORQUE CONVERTER INSTALLATION

Using calipers and a straight edge, measure the distance from the installed surface of the transmission housing to the installed surface of the torque converter.

Correct distance: 17.1 mm (0.673 in.)

2. INSTALL TRANSMISSION

Installation is in the reverse order of removal

([See page AT-53](#)).

HINT:

- After installation, adjust the shift lever position ([See page DI-80](#)).
- Fill ATF and check fluid level ([See page DI-80](#)).