




CL0239


## INSPECTION

### 1. INSPECT CLUTCH DISC FOR WEAR OR DAMAGE

Using calipers, measure the rivet head depth.

**Minimum rivet depth: 0.3 mm (0.012 in.)**

If necessary, replace the clutch disc.




CL0373

### 2. INSPECT CLUTCH DISC RUNOUT

Using a dial indicator, check the disc runout.

**Maximum runout: 0.8 mm (0.031 in.)**

If necessary, replace the clutch disc.




Q07250

### 3. INSPECT FLYWHEEL RUNOUT

Using a dial indicator, check the flywheel runout.

**Maximum runout: 0.1 mm (0.004 in.)**

If necessary, replace the flywheel.



Q02481


### 4. INSPECT PILOT BEARING

Turn the bearing by hand while applying force in the rotation direction.

If the bearing sticks or has much resistance, replace the pilot bearing.

**HINT:**

The bearing is permanently lubricated and requires no cleaning or lubrication.




Q07150

### 5. IF NECESSARY, REPLACE PILOT BEARING

- Remove the 2 bolts at diametrically opposite points.
- Using SST, remove the pilot bearing.

SST 09303-35011



- (c) Using SST and a hammer, install the pilot bearing.  
SST Q07151

**HINT:**

After assembling the pilot bearing to the hub, make sure that it rotates smoothly.

- (d) Install 2 new bolts.


**Torque:**

**1FZ-FE Engine: 20 N·m (210 kgf·cm, 15 ft·lbf)**

**2UZ-FE Engine: 50 N·m (510 kgf·cm, 37 ft·lbf)**

**1HZ, 1HD-T, 1HD-FTE Engine:**

**127 N·m (1,300 kgf·cm, 94 ft·lbf)**




**6. INSPECT DIAPHRAGM SPRING FOR WEAR**

Using calipers, measure the diaphragm spring for depth and width of wear.

**Maximum depth A: 0.6 mm (0.024 in.)**

**Maximum width B: 5.0 mm (0.197 in.)**

If necessary, replace the clutch cover.



**7. INSPECT RELEASE BEARING**

Turn the bearing by hand while applying force in the axial direction.

**HINT:**

The bearing is permanently lubricated and requires no cleaning or lubrication.

If the bearing sticks or has much resistance, replace the release bearing.