

|            |                  |                           |
|------------|------------------|---------------------------|
| <b>DTC</b> | <b>Always ON</b> | <b>Malfunction in ECU</b> |
|------------|------------------|---------------------------|

## CIRCUIT DESCRIPTION

| DTC No.   | DTC Detecting Condition                                                                                                                                                                                                 | Trouble Area                                                                                                                           |
|-----------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------|
| Always ON | Either of the following (1) through (3) is detected:<br>(1) The ECU connectors are OFF from the ECU.<br>(2) There is a malfunction in the ECU internal circuit.<br>(3) The voltage of terminal IG1 is more than 18.5 V. | <ul style="list-style-type: none"> <li>• Battery</li> <li>• IC regulator</li> <li>• Power source circuit</li> <li>• ABS ECU</li> </ul> |


### HINT:

There is a case that hand-held tester cannot be used when ECU is abnormal.

### Fail safe function:

If trouble occurs in the ECU, the ECU cuts off current to the ABS solenoid relay and prohibits ABS control.

## WIRING DIAGRAM



**INSPECTION PROCEDURE**

**1** Check that the ECU connectors are securely connected to the ECU.

**NO**

Connect the connector to the ECU.

**YES**

**2** Is DTC output?

Check DTC on [page DI-312](#).

**YES**

Repair circuit indicated by the output code .

**NO**

**3** Is normal code displayed?

**YES**

Check solenoid relay. Check for short circuit in harness and connector between solenoid relay and check connector ([See page IN-24](#)).

**NO**

**4** Does ABS warning light go off?

**YES**

Check for open or short circuit in harness and connector between ECU-IG fuse and ECU ([See page IN-24](#)).

**NO**

**5 Check battery voltage.****CHECK:**

- (a) Start the engine.
- (b) Check the battery voltage.

**OK:****Voltage: 10 – 16 V****NG****Check and repair the charging system.****OK****6 Check operation of the ABS warning light.****IN CASE OF USING HAND-HELD TESTER:****PREPARATION:**

- (a) Connect the hand-held tester to the DLC3.
- (b) Turn the ignition switch ON and push the hand-held tester main switch ON.
- (c) Select the ACTIVE TEST mode on the hand-held tester.

**CHECK:**

Check that "ON" and "OFF" of the ABS warning light can be shown on the combination meter by the hand-held tester.

**IN CASE OF NOT USING HAND-HELD TESTER:****PREPARATION:**

- (a) Turn the ignition switch OFF.
- (b) Disconnect the connector from the ABS ECU.
- (c) Turn the ignition switch ON.

**CHECK:**

Check the ABS warning light condition when pushing in and pulling out the short pin from the check connector.

**OK:****When the short pin is pulled out: ABS warning light goes off****When the short pin is pushed in: ABS warning light goes on****OK****Check and replace ABS ECU.****NG**

**Check for short circuit in harness and connector between combination meter and ABS ECU, combination meter and check connector (See page IN-24).**  
**Check ABS solenoid relay circuit (See page DI-335).**