















TRANSFER (Part-Time 4WD Type)






SST (Special Service Tools)

PP1IK-01

	09223-15020 Oil Seal & Bearing Replacer	
	09316-20011 Transfer Bearing Replacer	
	09316-60011 Transmission & Transfer Bearing Replacer	
	(09316-00011) Replacer Pipe	
	(09316-00031) Replacer "B"	
	(09316-00051) Replacer "D"	
	(09316-00061) Replacer "E"	
	(09316-00071) Replacer "F"	
	09330-00021 Companion Flange Holding Tool	
	09350-32014 TOYOTA Automatic Transmission Tool Set	
	(09351-32120) Overdrive Bearing Replacer	
	(09351-32140) Oil Seal Replacer	

	(09351-32180) Bearing Replacer	
	09950-00020 Bearing Remover	
	09950-40011 Puller B Set	
	(09951-04020) Hanger 200	
	(09952-04010) Slide Arm	
	(09953-04030) Center Bolt 200	
	(09954-04010) Arm 25	
	(09954-04030) Arm 150	
	(09955-04010) Claw No.1	
	(09955-04020) Claw No.2	
	(09955-04050) Claw No.5	
	(09955-04060) Claw No.6	
	(09957-04010) Attachment	

PREPARATION - TRANSFER (Part-Time 4WD Type)

	(09958-04010) Holder	
	09950-60010 Replacer Set	
	(09951-00270) Replacer 27	
	(09951-00300) Replacer 30	
	(09951-00320) Replacer 32	
	(09951-00400) Replacer 40	
	09950-60020 Replacer Set No.2	
	(09951-00790) Replacer 79	
	(09951-00890) Replacer 89	
	09950-70010 Handle Set	
	(09951-07150) Handle 150	